

Challenger®

MT745C / MT755C / MT765C

Rubber Track Tractor

SERVICE MANUAL

79033093 D Rev.

Volume 1

CONTENTS

Volume 1

INTRODUCTION.....	01
ENGINE	02
POWERTRAIN.....	03
FRAME	04
STEERING AND BRAKE SYSTEM	05
IMPLEMENT AND THREE-POINT HITCH HYDRAULIC SYSTEMS.....	06
ELECTRICAL SCHEMATICS.....	07
AIR SYSTEM	08
VIRTUAL TERMINAL	09
CAB	10

Volume 2

HEATING VENTILATION AND AIR CONDITIONING.....	11
BALLASTING	12
APPEARANCE GROUP.....	13
ELECTRONICS.....	14

Challenger®

MT745C / MT755C / MT765C

Rubber Track Tractor

SERVICE MANUAL

79033093 D Rev.

01 - Introduction

Contents

INTRODUCTION	
Service Manual	01-1
Divisions and Page Numbers	01-1
Units of Measurement	01-1
Replacement Parts	01-1
Important Safety Information	01-2
Safety Alert Symbol	01-3
Signal Words	01-3
Informational Messages	01-3
General Hazard Information	01-4
Protective Clothing	01-6
Mounting and Dismounting	01-6
Crushing/Cutting Prevention	01-6
Exhaust Dangers	01-7
Before Operation	01-7
Parking	01-7
Operation	01-8
Operator Station	01-8
Engine Starting	01-9
Seat Belts	01-9
Shield Removal	01-9
Fluid Precautions	01-10
Battery Disconnect	01-10
Rollover Protective Structure (ROPS)	01-10
Burn Hazards	01-11
Coolant Precautions	01-11
Escaping Fluid Dangers	01-11
Batteries	01-12
Lights, Reflector and Signs	01-13
Fire and Explosion Prevention	01-13
Fire Extinguisher	01-14
Auto-Guide Precautions	01-14
Asbestos Information	01-14
Electrical Storm Injury Prevention	01-14
Machine Identification	01-15
Product Identification Information	01-15
Torque Specifications	01-17
Constant Torque Hose Clamps	01-17
Fasteners Information	01-18
Metric Fasteners	01-18
Inch Fasteners	01-19
Tightening Straight Thread Fittings	01-20
Metric Information	01-21

Contents

Lubricant Viscosities And Refill Capacities	01-22
Lubricant Viscosities	01-22
Refill Capacities	01-22
Service Intervals	01-23
When Required	01-23
Maintenance Access	01-26
Engine Compartment	01-26
Location of Guards	01-26
Engine Screen Cover	01-27
Electrical System	01-29
Main Fuse Panel	01-29
Main Fuse	01-35
Circuit Breakers (ECM)	01-35
Special Tooling	01-35
INDEX	01-37

INTRODUCTION

SERVICE MANUAL

This service manual has been prepared with the latest service information available at publication. Read and understand service manual carefully before doing any service on machine.

Right-hand and left-hand, as used in manual, are determined by facing direction machine travels when in use.

Photos, illustrations and data used were current at time of printing, due to possible production changes, machine may vary slightly. Manufacturer reserves right to redesign and change machine as necessary without notification.



WARNING: Some pictures in manual show shields removed to allow a clearer view. Never operate machine with any shields removed.

Divisions and Page Numbers

Service manual is separated into divisions. Refer to Master Table of Contents.

Each division has an identifying part number with an alpha revision level indicator. Each division also has a Table of Contents, Safety section and Index.

Each page is identified with division part number and revision level. Pages are in numeric order within each division.

UNITS OF MEASUREMENT

Measurements are given in metric units followed by equivalent in U.S. units. Hardware sizes are given in millimeters for metric hardware and inches for U.S. hardware.

REPLACEMENT PARTS

To receive prompt efficient service, always remember to have correct part number and description along with model and serial number of machine.

Introduction

IMPORTANT SAFETY INFORMATION

FIG. 1: Most personal injuries occurring during product operation, maintenance or repair are caused by failure to observe basic safety rules and precautions. In most cases, an injury can be avoided by recognizing hazardous situations before an injury occurs.

Be alert to potential hazards and have the necessary training, skills and tools to perform these functions properly.

Improper operation, lubrication, maintenance or repair of product can be hazardous and could result in injury or death.

Do not operate or perform any lubrication, maintenance or repair on product, until reading and understanding operation, lubrication, maintenance and repair information.

Safety precautions and warnings are provided in manual and on product. If hazard warnings are not heeded, bodily injury or death could occur to operator or bystanders.

Not every possible circumstance involving a potential hazard can be anticipated. Warnings in service manual and on product are, therefore, not all inclusive. If a tool, procedure, work method or operating technique not specifically recommended by AGCO is used, ensure it is safe for operators and others.

Make sure product will not be damaged or be made unsafe by operation, lubrication, maintenance or repair procedures chosen. Information, specifications and illustrations in publication are based on information available at time of publication.

Specifications, torques, pressures, measurements, adjustments, illustrations and other items can change at any time. Changes can affect service given to product. Obtain complete and most current information before beginning any job. Dealers have the most current information available.



WARNING: When replacement parts are required for this product, AGCO recommends using AGCO replacement parts or parts with equivalent specifications including, but not limited to, physical dimensions, type, strength and material. Failure to heed this warning can lead to premature failures, product damage, personal injury or death.




FIG. 1

Safety Alert Symbol

FIG. 2: This is the safety alert symbol. It means ATTENTION! BECOME ALERT! SAFETY IS INVOLVED!

Look for it, both in this manual and on safety decals on machine. It directs attention to information involving operator safety and safety of others.



FIG. 2

Signal Words

FIG. 3: Words DANGER, WARNING or CAUTION are used with safety alert symbol. Learn to recognize safety alerts and follow recommended precautions and safe practices.



DANGER: Indicates an imminently hazardous situation, if not avoided, will result in DEATH OR VERY SERIOUS INJURY.



WARNING: Indicates a potentially hazardous situation, if not avoided, could result in DEATH OR SERIOUS INJURY.



CAUTION: Indicates a potentially hazardous situation, if not avoided, may result in MINOR INJURY.



FIG. 3

Informational Messages

FIG. 4: Do not operate or perform any lubrication, maintenance or repair on machine until reading and understanding operation, lubrication, maintenance and repair information.

Read and understand this manual, operator's manual and manuals for all attachments before operation.

Learn how to operate machine and use controls properly.

Do not allow anyone to operate machine without instruction and training.

For operator's safety and safety of others, follow all safety precautions and instructions found in manuals and on decals affixed to machine and attachments.

Personal injury and death may result if precautions are not followed.

Words IMPORTANT and NOTE are not related to personal safety, but are used to give additional information and tips for operating or servicing equipment.




FIG. 4

Introduction

IMPORTANT: Used to identify special instructions or procedures which, if not strictly observed, could result in damage to or destruction of machine, process or its surroundings.

NOTE: Used to indicate points of particular interest for more efficient and convenient repair or operation.

Right-hand and left-hand, as used in this manual, are determined by facing direction machine travels when in use.

General Hazard Information

FIG. 5: When engine is running and steering wheel is turned, machine will turn with transmission control lever in PARK (P) position.

IMPORTANT: Ensure all personnel are a safe distance from machine before turning steering wheel.

Do not start engine until area is free of personnel to avoid personal injury due to unexpected machine movement.

Unless instructed otherwise, perform maintenance under the following conditions:

- Machine is parked on level ground.
- Implements are lowered to ground.
- Transmission control lever is in PARK position.
- Engine is stopped.
- Engine start switch is turned off and switch key is removed.
- Machine has cooled down.
- Steering cylinder lock is in place.



WARNING: Do not start engine until area is free of personnel to avoid personal injury due to unexpected machine movement.

Know width of equipment to maintain proper clearance when operating machine near fences or boundary obstacles.

Wear a hard hat, protective glasses and other protective equipment, as required.

If wearing clothing that is too loose or not using correct safety equipment for job, injury can occur. Never wear clothing that will catch on objects. Extra safety equipment that can be required includes hard hat, safety shoes, ear protection, eye or face protection, heavy gloves and reflective clothing.

Make sure all protective guards and covers are secured in place.

Keep machine free of foreign material. Remove debris, oil, tools and other items from deck, walkways and steps.

Secure lunch boxes, tools and other loose items not a part of machine.

Know appropriate work site hand signals and personnel authorized to give hand signals. Accept hand signals from one person only.



FIG. 5

Hydraulic oil or diesel fuel leaking under pressure can penetrate skin and cause infection or other injury.

To prevent personal injury relieve all pressure before disconnecting fluid lines. Before applying pressure, make sure all connections are tight and components are in good condition. Do not use hand to check for suspected leaks under pressure. Use a piece of cardboard or wood for this purpose. If injured by leaking fluid, see a doctor immediately.

Never put maintenance fluids into glass containers, drain into a suitable container.

Discard any drained fluids and filter elements according to local regulations.

Report all necessary repairs.

Some components of machine are very heavy. Use suitable lifting equipment or additional help as instructed in Service Manual.

Do not allow unauthorized personnel on machine.


Do not smoke when servicing an air conditioner or when refrigerant gas may be present. Inhaling fumes released from a flame contacting air conditioner refrigerant can cause bodily harm or death.

Inhaling gas from air conditioner refrigerant through a lit cigarette can cause bodily harm or death.

Use all cleaning solutions with care.

FIG. 6: Be prepared for emergencies. Always carry one or more suitable fire extinguishers - ABC rating, dry chemical.

Keep a first aid kit handy for treatment of minor cuts and scratches.



N021603005

FIG. 6

Introduction

Protective Clothing

FIG. 7: Wear a hard hat, protective glasses and other protective equipment as required.




FIG. 7

Mounting and Dismounting

FIG. 8: Mount and dismount machine only where there are steps and/or handholds. Face machine whenever mounting or dismounting.

Maintain three-point contact with steps and handrails. Three-point contact is two feet and one hand or one foot and two hands.

Never mount or dismount a moving machine and never jump off machine except in an emergency.

Do not get on or off machine while moving.

Do not carry tools or supplies when mounting or dismounting machine. Use a hand line to pull equipment onto platform.

Do not use any controls as handholds when entering or exiting operator compartment.



FIG. 8

Crushing/Cutting Prevention

Stay clear of center articulation joint area of machine when engine is running. Connect articulation joint stop whenever servicing this area.

Support equipment properly when performing work under equipment. Do not depend on hydraulic cylinders to hold equipment.



WARNING: An implement can fall if a control lever is moved or if a hydraulic line breaks.

Never jump start machine by short circuiting across starter solenoid terminals. Always start machine from operator's seat.

Never attempt adjustments while machine is moving or engine is running.

When there are attachment control linkages, clearance in linkage area changes with movement of attachment.

Stay clear of all rotating and moving parts. Keep objects away from moving fan blades. Fan blades will throw and cut objects.

Wear gloves to handle wire cable and do not use kinked or frayed wire cable.

Retainer pins can fly when struck, ensure there are no personnel in area before striking. Wear protective glasses to protect eyes. When striking objects, chips or other debris may fly off. Ensure there will be no injury prior to striking any object.

Exhaust Dangers

FIG. 9: Diesel engine exhaust contains products of combustion, potentially harmful to health. Always run engine in a well-ventilated area. Never operate engine in a closed building unless exhaust is vented outside.

Before Operation

Clear all personnel from machine and surrounding area. Make sure all obstacles are cleared from machine's path. Operator must be familiar with hazards (wires, ditches, fences, etc).

Be sure all windows are clean. Secure doors and windows in open or closed position.

Adjust rearview mirrors for best visibility close to machine. Make sure horn, backup alarm (if equipped) and all other warning devices are working properly.

Fasten seat belt securely, low around hips.

Parking

Park on a level surface. When parking on a grade, chock machine tires.

Move transmission control lever to PARK and lower all implements to ground. Move implement controls to HOLD position.

Before stopping engine, move throttle control lever to LOW IDLE position. Allow turbocharger to cool by running engine at low idle speed for five minutes.

Stop engine, turn engine start switch to OFF and remove engine start switch key.

Turn battery disconnect switch to OFF position.




FIG. 9

Introduction

Operation

Only operate machine from operator's seat. Seat belt must be fastened during machine operation. Only operate controls while engine is running.

Check for proper operation of all controls and protective devices while operating machine slowly in an open area.

Make sure area is free of personnel before moving machine.

Report any damage noted during operation of machine and make necessary repairs.

Hold attachments approximately 40 cm (15 inches) above ground level while driving machine. Do not drive machine near an overhang, edge of a cliff or excavation.

If machine begins to sideslip on a grade, immediately dispose of load and turn machine downhill.

Avoid any ground condition that could cause machine to tip.

A rollover can occur when working on hills, banks or slopes or when crossing ditches, ridges or other unexpected obstacles.

When possible, operate machine up and down slopes. Always avoid driving across slopes.

Keep machine under control and do not overload beyond capacity.

Make sure towing devices are adequate for application. Connect trailing equipment only to drawbar or hitch.

Never straddle or allow any personnel to straddle a wire cable.

When maneuvering to connect equipment, ensure no personnel are between machine and trailing equipment. Block up hitch of trailing equipment to align equipment with drawbar.

Know maximum dimensions of machine.

When operating on icy roads, reduce travel speed. If stability is noticeably reduced, reduce speed.

Select a gear that controls machine speed when descending a hill.

Downshift if braking is required to control machine speed. Never coast down a hill with transmission in NEUTRAL.

Do not allow passengers anywhere on machine except in approved passenger seat.

Operator Station

Any modifications to inside of cab should not project into operator space. Addition of a radio, fire extinguisher and other equipment must be installed so defined operator space is maintained.

Any item brought into cab should not project into defined operator space. A lunch box or other loose items must be secured. Objects must not pose an impact hazard in rough terrain or a rollover.

Engine Starting

FIG. 10: Only start engine from operator's seat. Never short across starter terminals or batteries.

Move all hydraulic controls to HOLD position and transmission control lever to PARK before starting engine.



WARNING: Machine will turn if steering wheel is moved and engine is starting or running.

Do not start engine until area is free of personnel. This aids in avoiding personal injury due to unexpected machine movement.




N020903010

FIG. 10

Seat Belts

FIG. 11: Only operate machine from operator's seat with seat belt fastened. Only operate controls while engine is running.

Any rider in instructor's seat must fasten seat belt. Never allow anyone on any part of machine or its attachments except in operator's and instructor's seat when engine is running.



N020903011

FIG. 11

Shield Removal

FIG. 12: Some photos in this manual may have been taken with shields removed for clarity.



WARNING: To provide a better view, certain photographs and illustrations in manual may show an assembly with shields removed. Do not operate machine unless all shields are in good condition and are in place. Replace shields immediately upon completion of inspection, repairs, cleaning or adjustments and before operating begins or resumes.



N020903012

FIG. 12

Introduction

Fluid Precautions

FIG. 13: Drain all fluids into suitable container and never put maintenance fluid into glass containers.

Discard drained fluids and fluid-saturated materials according to local regulations. Use all cleaning solution with care.



FIG. 13

FIG. 14: Do not smoke when serving an air conditioner. Inhaling gas from air conditioner refrigerant through a lit cigarette can cause bodily harm or death.

Keep machine free of foreign material (fuel, oil, some coolants, oily rags and debris).

Do not weld on lines or tanks containing flammable fluids.

Use caution when refueling machine and do not smoke. Always stop engine before refueling. Fill fuel tank outdoors.



FIG. 14

Battery Disconnect

FIG. 15: Always shut off engine, shift transmission to park, remove ignition key and set battery disconnect switch (1) to OFF before permitting inspection, cleaning, lubrication, adjustment or repair of any part of machine or attachments.

Rollover Protective Structure (ROPS)

Do not make any modifications to ROPS as this affects protection. Do not alter structure by welding, cutting, adding weight or drilling holes into structure.

Any alteration, not specifically authorized by AGCO, invalidates AGCO certification for ROPS. Protection offered by ROPS is impaired if ROPS has structural damage. Damage to structure can be caused by a roll over or by falling objects.

Do not mount items (fire extinguishers, first aid kits, work lights, etc) by welding brackets to or drilling holes into ROPS. See dealer for mounting guidelines.




FIG. 15

Burn Hazards

FIG. 16: Do not touch any part of an operating engine. Other components such as transmission, axles and oil reservoir may be hot. Allow engine to cool before any maintenance is performed. Relieve all pressure in air, oil, lubrication, fuel system or cooling system before any line, fittings or related items are disconnected.



FIG. 16

Coolant Precautions

FIG. 17: When engine is at operating temperature, engine coolant is hot and under pressure. Radiator and all lines to heaters or engine contain hot coolant.

Any contact with hot coolant or steam can cause severe burns. Allow cooling system components to cool before cooling system is drained.

Check coolant level only after engine has been stopped.

Cooling system conditioner contains alkali that can cause personal injury.

Do not allow alkali to contact skin, eyes or mouth. Do not remove radiator cap if engine is hot. Only remove cap when it is cool enough to touch with bare hands. Loosen cap slowly to first notch to relieve pressure, then remove cap.




FIG. 17

Escaping Fluid Dangers

FIG. 18: Escaping fluid under high pressure can be almost invisible but can penetrate skin causing serious injury and possible death. A pinhole leak can cause severe injury.

Consult a doctor immediately if an injury from escaping fluids is sustained. Fluid injected into skin must be surgically removed within a few hours or gangrene may result.

Hot oil and hot components can cause personal injury.




FIG. 18

Introduction

FIG. 19: Use a piece of cardboard or wood to search for possible leaks, never use hands.

IMPORTANT: *Ensure fluids are contained during performance of inspection, maintenance, testing, adjusting and repair of machine. Be prepared to collect fluid with suitable containers before opening any compartment or disassembling any component containing fluids. Dispose of all fluids according to local regulations and mandates.*

Do not bend or strike any high-pressure line. Do not install bent or damaged lines.

Check lines, tubes and hoses carefully. Repair loose or damaged lines. Tighten all connections to recommended torque.

Replace parts if any of the following conditions are present:

End fittings are damaged or leaking.

Outer coverings are chafed or cut.

Wires are exposed.

Outer covering is ballooning.

Flexible parts of hoses are kinked.

Outer covers have embedded armoring.

End fittings are displaced.

Batteries

FIG. 20: Electrolyte is an acid and can cause personal injury. Do not allow electrolyte to contact skin or eyes. Always wear protective glasses when servicing batteries. Wash hands after touching batteries and connectors.




FIG. 19




FIG. 20

FIG. 21: Battery gases can explode. Keep any open flames or sparks away from top of battery. Do not smoke in battery charging areas.

Never check battery charge by placing a metal object across terminal posts. Do not lay tools or other conductive materials on battery. Use a voltmeter or a hydrometer.

Improper jumper cable connections can cause an explosion resulting injury.

Be careful when connecting booster cables to batteries. Electrical component damage or battery explosion can result if booster cables are not installed correctly.

Do not charge a frozen battery as it may explode. Warm battery to 16 degrees C (60 degrees F).




FIG. 21

Lights, Reflector and Signs

FIG. 22: Ensure all machine lights, reflectors and slow moving vehicle (SMV) are installed, in good condition and wiped clean.

Consult local law enforcement agency for local regulations regarding movement of equipment on public roads.


**FIG. 22****Fire and Explosion Prevention**

FIG. 23: All fuels, most lubricants and some coolant mixtures are flammable.

Flammable fluids leaking or spilled onto hot surfaces or electrical components can cause fire.

Fire may cause personal injury and property damage.

Remove all flammable materials such as fuel, oil and debris from machine.

Store fuels and lubricants in properly marked containers away from unauthorized persons. Store oily rags and any flammable materials in protective containers.

Do not smoke in areas used for storing flammable materials.

Do not operate machine near any flame.

Exhaust shields protect hot exhaust components from oil or fuel spray in case of a break in a line, hose or seal. Exhaust shields must be installed correctly.

Do not weld or flame cut on lines or tanks containing flammable fluids. Clean any such lines or tanks thoroughly with non-flammable solvent prior to welding or flame cutting.

Check all electrical wires daily. Repair any loose or frayed wires before operating machine. Clean and tighten all electrical connections.

Dust generated from repairing non-metallic hoods or fenders can be flammable and/or explosive. Repair such components in a well-ventilated area away from open flames or sparks.

Inspect all lines and hoses for wear or deterioration.

Hoses must be properly routed. Lines and hoses must have adequate support and secure clamps. Tighten all connections to recommended torque.

**FIG. 23**

Introduction

FIG. 24: Use caution and do not smoke while refueling a machine. Do not refuel a machine near open flames or sparks and always stop engine before refueling. Always refuel outdoors.




FIG. 24

Fire Extinguisher

FIG. 25: Ensure a fire extinguisher is available. Be familiar with operation of fire extinguisher. Inspect and service extinguisher regularly and obey instructions on instruction plate.

A mounting bracket can be installed on right front frame rail. Bracket is designed to hold a 4.5 kg (10 lb) extinguisher.

Ensure all clamps, guards and shields are installed correctly to prevent vibration, rubbing against other parts and excessive heat.




FIG. 25

Auto-Guide Precautions

Auto-Guide can be momentarily disabled if satellite signal is lost. It is imperative operator be alert to position and conditions in field at all times.

Auto-Guide System is designed to aid operator with machine steering. Operator attention is required at all times.

Asbestos Information

AGCO equipment and replacement parts shipped from AGCO are asbestos-free. AGCO recommends use of only genuine AGCO replacement parts.

Electrical Storm Injury Prevention

When lightning is striking in vicinity of machine, do not mount or dismount machine.

If in operator's station during an electrical storm, remain there. If on ground during an electrical storm, stay away from machine.

MACHINE IDENTIFICATION

Product Identification Information

Plate Locations

Product identification number (PIN) will be used to identify a machine designed for an operator to ride.

Components such as engines, transmissions and major attachments that are not designed for an operator to ride, are identified by serial numbers.

For quick reference, record identification numbers in spaces provided next to illustration.

FIG. 26: Machine PIN. Plate is located on left side of frame rail.

Machine PIN: _____



FIG. 26

FIG. 27: Engine Serial Number. Plate is located on right side of engine.

Engine Serial Number: _____



FIG. 27

FIG. 28: Transmission Serial Number. Plate is located on right rear side of transmission.

Transmission Serial Number: _____



FIG. 28

Introduction

FIG. 29: Cab Serial Number. Plate is located inside cab, below inching clutch control.

Cab Serial Number: _____




FIG. 29

FIG. 30: Operators Seat Serial Number. Tag (1) is located on rear of operator's seat.

Seat Serial Number: _____




FIG. 30

FIG. 31: Track Belt Serial Number. The serial number is located on edge of each belt.

Left Belt Serial Number: _____

Right Belt Serial Number: _____



FIG. 31

FIG. 32: Serial Number for differential and for axles. The plate is located beneath rock shaft for three-point hitch.

Differential and Axles Serial Number: _____



FIG. 32

TORQUE SPECIFICATIONS



WARNING: Mismatched or incorrect fasteners can result in damage, malfunction or personal injury. Avoid mixing metric and inch dimensioned fasteners.

Exceptions to torques are listed in Service Manual, if necessary.

Prior to installation of any hardware, ensure components are in near new condition. Bolts and threads must not be worn or damaged. Threads must not have burrs or nicks and hardware must be free of rust and corrosion. Clean hardware with a noncorrosive cleaner.

Do not lubricate fastener threads except with rust preventative. Rust preventative should be applied by supplier of component for purposes of shipping and storage. Other applications for lubricating components may be specified in Service Manual.

Constant Torque Hose Clamps

Due to extreme temperature changes, hose will heat set. Heat setting can cause hose clamps to loosen. Loose hose clamps can result in leaks. Constant torque of hose clamp helps prevent leaks.

FIG. 33: Constant torque hose clamp is installed correctly under the following conditions:

- Screw tip (1) extends 6.35 mm (.25 inch) (A) beyond housing.
- Belleville washers are collapsed nearly flat after screw (2) is tightened to a torque of 11 Nm (8.1 lbf ft).




FIG. 33

Introduction

FASTENERS INFORMATION

Metric Fasteners

Assembly Torque for Metric Fasteners

Standard			High		Low	
Thread Size	Torque Pound Feet lbf ft	Torque Newton Meters Nm	Torque Pound Feet lbf ft	Torque Newton Meters Nm	Torque Pound Feet lbf ft	Torque Newton Meters Nm
M6 x 1	8 to 10	9 to 15	9 to 11	10 to 16	3.5 to 4.5	5 to 7
M8 x 1.25	19 to 23	21 to 35	20 to 24	23 to 37	10 to 12	12 to 18
M10 x 1.5	37 to 45	45 to 65	40 to 48	48 to 72	20 to 24	23 to 37
M12 x 1.75	67 to 83	80 to 120	72 to 88	85 to 125	31 to 39	40 to 60
M14 x 2	108 to 132	130 to 190	120 to 140	145 to 205	55 to 65	65 to 95
M16 x 2	160 to 190	200 to 280	180 to 220	230 to 310	80 to 100	105 to 145
M20 x 2.5	305 to 375	400 to 520	350 to 430	460 to 600	165 to 205	210 to 290
M24 x 3	530 to 650	700 to 900	600 to 730	800 to 1000	285 to 345	375 to 475
M30 x 3.5	1060 to 13000	1400 to 1800	1200 to 1460	1600 to 2000	565 to 685	750 to 950
M36 x 4	1800 to 2200	2400 to 3000	2055 to 2515	2750 to 3450	990 to 1210	1300 to 1700

Standard Taperlock Studs		
Thread Size	Torque Pound Feet lbf ft	Torque Newton Meters Nm
M6	6	8
M8	13	17
M10	26	35
M12	48	65
M16	80	110
M20	125	170
M24	300	400
M30	550	750
M36	880	1200

Inch Fasteners**Assembly Torque for Inch Fasteners**

Standard			High		Low	
Thread Size	Torque Pound Feet lbf ft	Torque Newton Meters Nm	Torque Pound Feet lbf ft	Torque Newton Meters Nm	Torque Pound Feet lbf ft	Torque Newton Meters Nm
1/4 - 20	8 to 10	9 to 15	9 to 11	10 to 16	3.5 to 4.5	5 to 7
5/16 - 18	16 to 20	19 to 31	18 to 22	21 to 35	9 to 11	10 to 16
3/8 - 16	31 to 39	38 to 56	36 to 44	40 to 60	16 to 20	19 to 31
7/16 - 14	45 to 55	55 to 85	54 to 66	65 to 95	27 to 33	32 to 48
1/2 - 13	67 to 83	85 to 125	81 to 99	100 to 140	40 to 50	48 to 72
9/16 - 12	110 to 130	130 to 190	117 to 143	145 to 205	55 to 65	70 to 100
5/8 - 11	145 to 175	175 to 255	160 to 190	200 to 280	75 to 95	95 to 135
3/4 - 10	245 to 305	320 to 420	290 to 350	370 to 490	135 to 165	160 to 240
7/8 - 9	410 to 510	540 to 700	470 to 570	610 to 790	215 to 265	285 to 365
1 - 8	590 to 730	800 to 1000	700 to 850	900 to 2200	335 to 405	435 to 565
1 1/8 - 7	860 to 1060	1150 to 1450	965 to 1175	1300 to 1600	465 to 565	610 to 790
1 1/4 - 7	1190 to 1450	1600 to 2000	1395 to 1705	1850 to 2350	880 to 1070	875 to 1125
1 3/8 - 6	1600 to 1960	2100 to 2700	1790 to 2190	2400 to 3000	1185 to 1445	850 to 1150
1 1/2 - 5	2050 to 2510	2750 to 3450	2385 to 2915	3200 to 40000	1515 to 1845	1500 to 1900

Standard Taperlock Studs		
Thread Size	Torque Pound Feet lbf ft	Torque Newton Meters Nm
1/4	6	8
5/16	13	17
3/8	26	35
7/16	33	45
1/2	48	65
5/8	80	110
3/4	125	170
7/8	190	260
1	300	400
1 1/8	390	525
1 1/4	550	750
1 3/8	700	950
1 1/2	880	1200

Introduction

TIGHTENING STRAIGHT THREAD FITTINGS

Straight thread hydraulic fittings require precise tightening. Overtightening ruins sealing surfaces and require replacement of damaged parts.

Proper initial tightening depends on mating parts to be connected. Proceed as follows:

An adapter fitting (37 degree flare) connected to a double flare tube assembly, fitting must be tightened finger tight and wrenched 1/2 turn (for single flare, 1/4 turn).

An adapter fitting (37 degree flare) connected to a hose, fitting must be tightened finger tight and wrenched 1/4 turn.

An o-ring adapter fitting connected to a solid port, fitting must be tightened so backup washer contacts face of boss after fitting has been properly positioned.

To retighten after initial tightening, as in service work, both tube and hose connections should be tightened finger tight and wrenched 1/4 turn. O-ring fittings should be tightened as for initial assembly.

JIC SWIVEL NUTS (37 degree SEAT). Following values are maximum recommended torque values for JIC (37 degree seat) swivel nuts either swaged or brazed type. Swivel nuts normally withstand torque for a minimum of 15 repeated assemblies.

Torque required to seal swivel female fittings or hose couplings to a male connector depends on many variables such as medium, pressure, surface finish, etc. Following values are intended only as a guide for maximum values fittings may be subjected to.

DASH SIZE	TUBE O. D. (REF.)	TORQUE MAX		
		Nm	lbf in	lbf ft
-4	1/4	12	110	9
-5	5/16	20	180	15
-6	3/8	27	240	20
-8	1/2	40	360	30
-10	5/8	54	480	40
-12	3/4	95	840	70
-14	7/8	110	980	80
-16	1	120	1080	90
-20	1 1/4	160	1440	120
-24	1 1/2	180	1575	130
-32	2	400	3600	300
-40	2 1/2	540	4800	400
-48	3	680	6000	500

METRIC INFORMATION

	MULTIPLY:	BY:	To Get:	MULTIPLY	BY:	To Get:
LINEAR	inches	x 25.4	= millimeters (mm)	x 0.03937	= inches	
	feet	x 0.3048	= meters (m)	x 3.281	= feet	
	yards	x 0.9144	= meters (m)	x 1.0936	= yards	
	miles	x 1.6093	= kilometers (km)	x 0.6214	= miles	
	inches	x 2.54	= centimeters (cm)	x 0.3937	= inches	
	microinches	x 0.0254	= micrometers (um)	x 39.37	= microinches	
AREA	inches ²	x 645.16	= millimeters ² (mm ²)	x 0.00155	= inches ²	
	inches ²	x 6.4516	= centimeters ² (cm ²)	x 0.155	= inches ²	
	feet ²	x 0.0929	= meters ² (m ²)	x 10.764	= feet ²	
	yards ²	x 0.8361	= meters ² (m ²)	x 1.196	= yards ²	
	acres	x 0.4047	= hectometers ² (hm ²)	x 2.471	= acres	
			= hectares (ha)			
VOLUME	inches ³	x 16387	= millimeters ³ (mm ³)	x 0.000061	= inches ³	
	inches ³	x 16.387	= centimeters ³ (cm ³)	x 0.06102	= inches ³	
	inches ³	x 0.01639	= liters	x 61.024	= inches ³	
	quarts	x 0.94635	= liters	x 1.0567	= quarts	
	gallons	x 3.7854	= liters	x 0.2642	= gallons	
	feet ³	x 28.317	= liters	x 0.03531	= feet ³	
	feet ³	x 0.02832	= meters ³ (m ³)	x 35.315	= feet ³	
	fluid oz.	x 29.57	= milliliters (ml)	x 0.03381	= fluid oz.	
	yards ³	x 0.7646	= meters ³ (m ³)	x 1.3080	= yards ³	
	teaspoons	x 4.929	= milliliters (ml)	x 0.2029	= teaspoons	
	cups	x 0.2366	= liters	x 4.227	= cups	
	bushel	x 35.239	= liters	x 0.02838	= bushels	
	bushel	x 0.03524	= meters ³ (m ³)	x 28.378	= bushels	
MASS	ounces (av)	x 28.35	= grams (g)	x 0.03527	= ounces (av)	
	pounds (av)	x 0.4536	= kilograms (kg)	x 2.2046	= pounds (av)	
	tons (2000 lbs)	x 907.18	= kilograms (kg)	x 0.001102	= tons (2000 lbs)	
	tons (2000 lbs)	x .90718	= metric tons(t)	x 1.1023	= tons(2000 lbs)	
	tons (long) (2240 lbs)	x 1016.05	= kilograms (kg)	x .000984	= tons (long) (2240 lbs)	
FORCE	ounces - f (av)	x 0.278	= newtons (N)	x 3.597	= ounces - f (av)	
	pounds - f (av)	x 4.488	= newtons (N)	x 0.2248	= pounds - f (av)	
	kilograms - f	x 9.807	= newtons (N)	x 0.10197	= kilograms - f	
PRESSURE OR STRESS	pounds/sq.in.	x 6.895	= kilopascals (kPa)	x 0.145	= pounds/sq. in.	
	pounds/sq.in.	x 0.0689	= bar	x 14.503	= pounds/sq. in.	
POWER	horsepower	x 0.746	= kilowatts (kW)	x 1.34	= horsepower	
	ft-lbf/min.	x 0.0226	= watts (W)	x 44.25	= ft - lbf/min.	
TORQUE	pound - inches	x 0.11298	= newton-meters (N.m)	x 8.851	= pound-inches	
	pound - feet	x 1.3558	= newton-meters (N.m)	x 0.7376	= pound-feet	
VELOCITY	miles/hour	x 1.6093	= kilometers/hour (km/h)	x 0.6214	= miles/hour	
	feet/sec.	x 0.3048	= meters/sec. (m/s)	x 3.281	= feet/sec.	
	kilometers/hr.	x 0.27778	= meters/sec. (m/s)	x 3.600	= kilometers/hr.	
	miles/hours	x 0.4470	= meters/sec. (m/s)	x 2.237	= miles/hour	
TEMPERATURE						

MetConv.doc

METCONV

Introduction

LUBRICANT VISCOSITIES AND REFILL CAPACITIES

Lubricant Viscosities

Proper oil viscosity grade is determined by minimum outside temperature while machine is started and while operated. To determine proper oil viscosity grade, refer to minimum column in following table. This information reflects coldest ambient temperature condition for starting and for operating a cold machine. Refer to maximum column in table to select oil viscosity grade for operating machine at highest temperature anticipated. Use highest oil viscosity allowed for ambient temperature when starting machine.

Machines operated continuously should use oils having higher oil viscosity in final drives and in differentials. Oils with higher oil viscosity will maintain highest possible oil film thickness. Consult dealer if additional information is needed.

Lubricant Viscosities for Ambient Temperatures						
Compartment or System	Oil Type and Classification	Oil Viscosities	Celsius		Fahrenheit	
			Min.	Max	Min.	Max
Engine Crankcase	CI-4 CH-4	SAE 0W20	-40	10	-40	50
		SAE 0W30	-40	30	-40	86
		SAE 5W30	-30	30	-22	86
		SAE 5W40	-30	40	-22	104
		SAE 10W30	-20	40	-4	104
		SAE 15W40	-15	50	5	122
Front Idler Hub Midwheel Hub Drive Wheel Hub	TO-4	SAE 50 synthetic	-30	50	-22	122
Hydraulic System Transmission Final Drive	AGCO® Permatran® 821XL	SAE 10W30	-25	40	-13	104

Refill Capacities

Approximate Refill Capacities		
Compartment or System		Liter (Gal)
Cooling System		43.3 L (11.4 gal)
Fuel Tank (Standard Gauge)		413 L (109 gal)
Fuel Tank (Wide Gauge) ⁽¹⁾		640 L (169 gal)
Engine Crankcase and Filter		30 L (7.9 gal)
Hydraulic System	Standard Gauge	219 L (58 gal)
	Wide Gauge	227 L (60 gal)
	Ultra Wide Gauge	257 L (68 gal)
Front Idler Hub		0.45 L (0.12 gal)
Midwheel Hub		0.189 L (0.05 gal)
Drive Wheel Hub		1.590 L (0.42 gal)
Windshield Washer Reservoir		3.78 L (1gal)
(1) Value for two modular tanks. Available third tank will add 30 gallons.		

SERVICE INTERVALS

When Required

- Cab Recirculation Filter - Clean/Inspect/Replace
- Cab Air Filter - Clean/Replace
- Primary Engine Air Filter - Clean
- Batteries - Replace
- Air Conditioner and Alternator belt - Replace
- Fan Belt - Replace
- Cooling Cores - Clean
- Drawbar wearplates and swing stops - Replace
- Drive Wheel Hub oil level - Check
- Engine Air Precleaner - Clean
- Ether Starting Aid Cylinder - Replace
- Fuel Tank Water and Sediment - Drain
- Fuses, Circuit Breakers, and Relays - Replace/Reset
- Idler Hubs oil level - Check
- Midwheel Hub oil level - check
- Quick Hitch - lubricate
- Undercarriage Belt - Remove/Replace
- Undercarriage Belt Alignment - Check/Adjust
- Fuel System Water Separator - Drain
- Window Washer Reservoir - Fill
- Window Wipers - Inspect/Replace
- Windows - Clean

Introduction

	Every 10 hours or Daily	Every 50 hours	Initial 250 Hours	Every 250 hours	Initial 500 hours	Every 500 hours	Every 1000 hours	Every 2000 hours	Every 3000 hours
Initially: Check all hose clamps on engine at 10 hrs and again at 50 hrs, tighten and retorque as required, repeat when a hose is replaced									
Cooling System Level - Check	x								
Engine Oil Level - Check	x								
Fuel System - Fill	x								
Hydraulic System oil level - Check	x								
Undercarriage system - Check	x								
Fuel System Water Separator - Check	x								
Air Tank - Drain		x							
Three Point Hitch - Lubricate		x							
Hydraulic System oil filters - Replace			x						
Batteries - Inspect				x					
Air Conditioner belt - Inspect/Replace				x					
Fan belt - Inspect/Replace				x					
Primary Fuel Filter - Clean/Replace				x					
Secondary Fuel Filter - Clean/Replace				x					
Hydraulic System oil sample -Obtain				x					
Engine Oil and Filter - Change				x					
Engine oil sample - Obtain				x					
Engine Valve Lash - Check					x				
Cooling System sample - Obtain						x			
Engine Crankcase Breather - Clean						x			
Hydraulic System Breather - Clean						x			
Drive Wheel Hub Fluid - Change						x			
Fuel Cap Filter - Inspect/Replace						x			
Fuel Cap - Clean/Replace						x			
Primary Engine Air Filter - Replace							x		

Introduction

	Every 10 hours or Daily	Every 50 hours	Initial 250 Hours	Every 250 hours	Initial 500 hours	Every 500 hours	Every 1000 hours	Every 2000 hours	Every 3000 hours
Secondary Engine Air Filter - Replace							X		
Case Drain Filter - Replace							X		
Hydraulic System Oil - Change							X		
Hydraulic System Oil Filters - Replace							X		
ROPS - Inspect							X		
Seat Belt - Inspect							X		
Air Dryer Cartridge - Replace								X	
Engine Valve Lash - Check								X	
Cooling System Coolant - Change									X
Refrigerant Accumulator - Replace									X

Introduction

MAINTENANCE ACCESS

Engine Compartment

FIG. 34: Raise hood pull slowly outward on plastic latch (1). This will allow you to release rubber strap (2) from hood. Release plastic latches and rubber straps on other side of machine.

Use handle (3) to raise hood.




FIG. 34

Location of Guards

Left and Right side guards

Move machine to a smooth horizontal location.

Lower all implements to ground and lower three-point hitch to ground.

Make sure that transmission control lever is in park position.

Stop engine and remove key.

FIG. 35: Remove following guards to gain access to modular fuel tanks:

Remove five bolts and washers to remove guard (1).

Remove five bolts and washers to remove guard (2).

Remove eight bolts and washers guard (3).

Install guards in reverse order they were removed.




FIG. 35

FIG. 36: Remove following guards listed to gain access to left side of transmission housing.

Remove five bolts and washers to remove guard (1).

Remove four bolts and washers to remove guard (2).

Remove four bolts and washers to remove guard (3).

Remove four bolts and washers to remove guard (4).

Remove four bolts and washers to remove guard (5).

Remove four bolts and washers to remove guard (6).

Install guards in reverse order they were removed.




FIG. 36

Bottom Guards

FIG. 37: Support guard (1) with proper lifting device before removing. Remove seven bolts and washers from shield (1) to lower shield (1).

Remove two bolts from guard (2).

Install guards in reverse order they were removed.




FIG. 37

Engine Screen Cover

Left Hand Side

FIG. 38: Remove bolts securing engine screen (1).




FIG. 38

Introduction

Right Hand Side

FIG. 39: Remove bolts securing engine screen (1).




FIG. 39

ELECTRICAL SYSTEM


Main Fuse Panel



FIG. 40

FIG. 40: Main fuse panel is located near floor of cab on right side.

Introduction



R060811001

FIG. 41

FIG. 41: Fuse Panel Descriptions

Item	Description
1	ISO - TBC (Terminating Bias Circuit)
2	Power Train Resistor 120 OHM
3	Light/Auxiliary Resistor 120 OHM
4	Guidance RS232
5	ET - Electronic Service Connector
6	EDT- Electronic Diagnostic Service Connector
7	ISO - Service Connector
8	40 Amp - A/C Fuse

FIG. 42: Fuse Block 1

Fuse Block 1		
Item	Rating	Description
Switched Battery		
1	10 Amp	Cigar Lighter
2	10 Amp	Not used
3	15 Amp	Brakes
4	30 Amp	Light Module Front
5	30 Amp	Light Module Front
6	30 Amp	Light Module Rear
7	30 Amp	Light Module Rear
8	30 Amp	Light Module Front
9	15 Amp	Trailer Lights
10	10 Amp	Not used
Item	Rating	Description
Battery +		
11	15 Amp	Not used
12	15 Amp	Not used
13	15 Amp	Not used
14	20 Amp	Not used
15	10 Amp	Radio Battery Power
16	30 Amp	Roof Light Module
17	30 Amp	Roof Light Module
18	30 Amp	Roof Light Module
19	30 Amp	Roof Light Module
20	30 Amp	Power Port




FIG. 42

Introduction

FIG. 43: Fuse Block 2

Fuse Block 2		
Item	Rating	Description
Switched Battery		
1	20 Amp	Implement Valve/Hitch Valve
2	10 Amp	Inch Sensor/Steer Sensor/Rockshaft Sensor
3	15 Amp	Trailer Auxiliary
4	30 Amp	Not used
5	10 Amp	Decel Sensor/Air Sensor/Belt Tension Sensor
6	10 Amp	Mirror Power/Heat
7	10 Amp	Rear Wiper
8	10 Amp	Front Wiper
9	20 Amp	Not used
10	10 Amp	Not used
Item	Rating	Description
Switched Battery		
11	15 Amp	Radio
12	20 Amp	Seat
13	15 Amp	Terminal Strip
14	30 Amp	Power Ports Switched
15	10 Amp	Virtual Terminal
16	15 Amp	Not used
17	15 Amp	Product Link
18	15 Amp	Horn
19	10 Amp	Cell phone port power port Undertrainer seat
20	10 Amp	Light Switch





FIG. 43

FIG. 44: Fuse/ Relay Block 1

Fuse/Relay Block 1		
Item	Relay	Description
1	35 Amp	Not used
2	35 Amp	Not used
3	35 Amp	Not used
4	35 Amp	Italian Trailer Brakes
5	35 Amp	Trailer Work Lights




P101411014

FIG. 44

FIG. 45: Fuse/ Relay Block 1

Fuse/Relay Block 1 - Battery +		
Item	Fuse	Description
1	15 Amp	Not used
2	15 Amp	Not used
3	10 Amp	Not used
4	10 Amp	Not used
5	20 Amp - Circuit Breaker	Engine CTRL
6	20 Amp - Circuit Breaker	Transmission ABL
7	10 Amp	Monitor (Monitor Bar)
8	10 Amp	Key Power
9	15 Amp	ISO ECU Power
10	30 Amp	ISO Power



P101411014

FIG. 45

Introduction

FIG. 46: Fuse/Relay Block 2

Fuse/Relay Block 2		
Item	Relay	Description
1	35 Amp	Neutral Start Relay
2	35 Amp	Horn Relay
3	35 Amp	ISO Power Relay
4	35 Amp	ISO ECU Relay
5	35 Amp	ECU Relay




FIG. 46

FIG. 47: Fuse/Relay Block 2

Fuse/Relay Block 2 - ECU Relay Power		
Item	Fuse	Description
1	15 Amp	Not used
2	15 Amp	Not used
3	10 Amp	Not used
4	10 Amp	Not used
5	10 Amp	GPS
6	10 Amp	Armrest
7	10 Amp	Dash
8	20 Amp	Rear Light Module
9	20 Amp	Rear Light Module
10	20 Amp	Front Light Module




FIG. 47

Main Fuse

FIG. 48: Two main fuses are located on left side of machine on inside of frame rail, as shown.

Fuse (1) is rated at 175 Amps and is main fuse for cab power.

Fuse (2) is rated at 200 Amps and is main fuse for alternator.

Circuit Breakers (ECM)

The circuit breakers for machine ECM are in the cab in the fuse panel area.

Both circuit breakers are rated at 20 Amps.

SPECIAL TOOLING

Special tooling listed below may be required for removal, installation, disassembly or assembly of components of the machine.

These parts can be ordered from AGCO.




FIG. 48

Part Number	Description
516186D1	Hose AS. - Tensioner Charge
548008D1	Adapter GP - Communications
516200D1	Communications Adapter II
516201D1	Cable - Data Link
547710D1	Tool - Seal Installation Field Machinable

Introduction

NOTES

INDEX

A

Asbestos Information	01-14
Assembly Torque for Inch Fasteners	01-19
Assembly Torque for Metric Fasteners	01-18
Auto-Guide Precautions	01-14

B

Batteries	01-12
Battery Disconnect	01-10
Before Operation	01-7
Burn Hazards	01-11

C

Circuit Breakers (ECM)	01-35
Constant Torque Hose Clamps	01-17
Coolant Precautions	01-11
Cooling System	
Refill Capacity	01-22
Crushing and Cutting Prevention	01-6

D

Divisions and Page Numbers	01-1
----------------------------------	------

E

Electrical Storm Injury Prevention	01-14
Electrical System	01-29
Main Fuse Panel	01-29
Engine	
Refill Capacity	01-22
Engine Starting	01-9
Escaping Fluid Dangers	01-11
Exhaust Dangers	01-7

F

Fasteners Information	01-18
Fire and Explosion Prevention	01-13
Fire Extinguisher	01-14
Fluid Precautions	01-10
Fuel Tank	
Capacity	01-22
Fuses	
Main Fuse	01-35
Main Fuse Panel	01-29

G

General Hazard Information	01-4
----------------------------------	------

H

Hood	01-26
Hydraulic System	
Fluid Capacity	01-22
Hydraulic System Fluid Capacity	01-22

I

Inch Fasteners	01-19
Informational Messages	01-3

L

Lights, Reflector and Signs	01-13
Lubricant Viscosities	01-22

M

Maintenance Access	01-26
Bottom Guards	01-27
Engine Compartment	01-26
Engine Screen Cover	01-27
Left and Right side guards	01-26
Metric Fasteners	01-18
Metric Information	01-21
Mounting and Dismounting	01-6

O

Operation	01-8
Operator Station	01-8

P

Parking	01-7
Plate Locations	01-15
Product Identification Information	01-15
Protective Clothing	01-6

R

Refill Capacities	01-22
Replacement Parts	01-1
Rollover Protective Structure (ROPS)	01-10

S

Safety Alert Symbol	01-3
Safety Information	01-2
Safety Words And Symbols	01-3
Seat Belts	01-9
Service Intervals	

Index

When Required	01-23
Shield Removal	01-9
Signal Words	01-3
Special Tooling	01-35

T

Tightening Straight Thread Fittings	01-20
Torque Specifications	01-17

U

Undercarriage (Mobil Trac) System	
Fluid Capacity	01-22
Units of Measurement	01-1

W

Windshield Washer reservoir	01-22
-----------------------------------	-------

Challenger®

MT745C / MT755C / MT765C

Rubber Track Tractor

SERVICE MANUAL

79033093 D Rev.

02 - Engine

Contents

ENGINE COMPONENTS

Introduction	02-1
Specifications and Standards Concerning Fuel, Oil and Coolant	02-1
Fuel Quality	02-1
Oil Quality	02-1
Coolant Quality	02-1
Serpentine Belt Replacement	02-2
Serpentine Belt Removal	02-2
Serpentine Belt Installation	02-6
Alternator - Removal and Installation	02-10
Alternator Removal Procedure	02-10
Alternator Installation Procedure	02-14
Cooling Assembly - Removal and Installation	02-18
Cooling Assembly Removal Procedure	02-18
Cooling Assembly Installation Procedure	02-31
Cooling Assembly - Radiator Core Removal and Installation	02-42
Radiator Core Removal Procedure	02-42
Radiator Core Installation Procedure	02-54
Cooling Assembly - Hydraulic Oil cooler Core Removal And Installation	02-65
Hydraulic Oil Cooler Core Removal Procedure	02-65
Hydraulic Oil Cooler Core Installation Procedure	02-73
Cooling Assembly - Charge Air Cooler Removal and Installation	02-80
Charge Air Cooler Removal	02-80
Charge Air Cooler Removal	02-84
Cooling Assembly - Air Conditioning Condenser Removal and Installation	02-87
Air Conditioning Condenser Removal	02-87
Air Conditioning Condenser Installation	02-92
Air Intake Assembly - Removal and Installation	02-96
Air Intake Assembly Removal	02-96
Air Intake Assembly Installation	02-102
Dust Ejector - Removal and Installation	02-107
Dust Ejector Removal Procedure	02-107
Dust Ejector Installation Procedure	02-111
Exhaust System Removal and Installation	02-115
Exhaust System Removal Procedure	02-115
Exhaust System Installation Procedure	02-119
Muffler Removal and Installation	02-122
Muffler Removal Procedure	02-122
Muffler Installation Procedure	02-125
Battery Removal and Installation	02-127
Battery Removal Procedure	02-127
Battery Installation Procedure	02-130
Fan Removal and Installation	02-132
Fan Removal Procedure	02-132

Contents

Fan Installation Procedure	02-135
Air Conditioning Compressor Removal and Installation	02-138
Air Conditioning Compressor Removal	02-138
Air Conditioning Compressor Installation	02-142
Air Conditioning Accumulator Removal and Installation	02-146
Air Conditioning Accumulator Removal	02-146
Air Conditioning Accumulator Installation	02-151
Hood Removal and Installation	02-156
Hood Removal Procedure	02-156
Hood Installation	02-158
Input Shaft and Input Coupling Removal and Installation	02-160
Input Shaft and Input Coupling Removal Procedure	02-160
Input Shaft and Input Coupling Installation Procedure	02-162
Air Compressor Removal and Installation	02-164
Air Compressor Removal Procedure	02-164
Air Compressor Installation Procedure	02-170
Air Reservoir Removal and Installation	02-174
Air Reservoir Removal Procedure	02-174
Air Reservoir Installation Procedure	02-179
Air Dryer removal and Installation	02-182
Air Dryer Removal Procedure	02-182
Air Dryer Installation Procedure	02-185
Engine Removal and Installation	02-186
Engine Removal Procedure	02-186
Engine Installation Procedure	02-207
Fuel Line Removal and Installation	02-226
Fuel Line Removal Procedure	02-226
Fuel Line Installation Procedure	02-229
Primary Fuel Filter / Water Separator Removal and Installation	02-231
Primary Fuel Filter / Water Separator Removal Procedure	02-231
Primary Fuel Filter / Water Separator Installation Procedure	02-234
Secondary Fuel Filter Removal and Installation	02-235
Secondary Fuel Filter Removal Procedure	02-235
Secondary Fuel Filter Installation Procedure	02-238
Fuel Priming Pump	02-239
Fuel Priming Pump Procedure	02-239
INDEX	02-243

ENGINE COMPONENTS

INTRODUCTION

The machine utilizes a diesel engine manufactured by CAT for AGCO.

Many of the components are mounted and operate directly with the CAT engine. This section describes the proper procedures to remove and install the components.

If an internal engine problem arises that warrants engine removal from the frame of the machine this section will describe the proper procedure for removal and installation.

SPECIFICATIONS AND STANDARDS CONCERNING FUEL, OIL AND COOLANT

The engines fitted on the machine series comply with standards concerning emissions imposed by the authorities. (EU97/68/EC and 2007 US EPA and California Regulations for Large Non Road Compression Ignition Engines)

The quality of the fluids used in these engines, as well as the servicing schedule, must be respected in order to keep pollution emission levels low and to maintain the machine's performance throughout the machine's life.

Fuel Quality

The fuel must comply with standard DIN EN 590 and with the following specifications:

Density at 15 degrees C (59 degrees F): 0.82 to 0.84 kg/dm

Viscosity at 40 degrees C (104 degrees F): 2 to 4.5 mm/sec

Cetane index: min 51

Sulphur content: max 0.005p-%

Water content: max 200mg/kg

Oil Quality

The oil used must comply with API CI-4 standard.

Coolant Quality

The coolant used must comply with the ASTM d 3306 standard. The coolant must consist of pure water and ethylene/propylene glycol type antifreeze in the following proportions:

- 40-60% water
- 40-60% antifreeze

The ideal ratio is 50% water to 50% antifreeze.

Engine Components

SERPENTINE BELT REPLACEMENT



WARNING: Hot engine components can cause injury from burns. Before performing maintenance on the engine, allow the engine and the components to cool.

Serpentine Belt Removal



WARNING: Hot engine components can cause injury from burns. Before performing maintenance on the engine, allow the engine and the components to cool.

FIG. 1: Battery disconnect switch.

IMPORTANT: Park the machine on a hard, level surface.

Location of battery disconnect switch (1).




FIG. 1

FIG. 2: Disconnect battery power at battery disconnect switch.

Rotate and remove key (1) to disconnect the battery power.




FIG. 2

FIG. 3: Lift right-hand side latch lever up (1) and remove latch (2) from keeper. Repeat on left-hand side.




FIG. 3

FIG. 4: Use handle (1) to lift hood (2) completely open.




FIG. 4

FIG. 5: Remove right-hand guard.

NOTE: Right-hand side guard does not need to be removed if replacing just the alternator serpentine belt.

Remove bolts (1) and remove guard (2).




FIG. 5

Engine Components

FIG. 6: Remove left-hand guard.

Remove loop clip bolts (1) and remove loop clips. Remove mounting bolts (2) and remove guard (3).




FIG. 6

FIG. 7: Air conditioning compressor serpentine belt removal.



WARNING: Equipment or parts under spring tension can cause bodily injury. Use caution in releasing belt tension.

Use a ratchet wrench in the square hole (1) on the belt tensioner (2) and turn counter clockwise to relieve belt tension. Remove serpentine belt (3). Slowly release the belt tensioner to relax into a neutral position.

NOTE: Be sure to allow enough room for the swing of the ratchet to allow belt tensioner to relax into a neutral position.

Carefully remove air conditioning serpentine belt over the fan.




FIG. 7

FIG. 8: Alternator serpentine belt removal.

NOTE: Skip this step if the alternator serpentine belt does not need to be replaced.

NOTE: Air conditioning compressor serpentine belt must be removed to replace alternator serpentine belt.



WARNING: Equipment or parts under spring tension can cause bodily injury. Use caution in releasing belt tension.

Use a ratchet wrench in the square hole (1) on the belt tensioner (2) and turn counter clockwise to relieve belt tension. Remove serpentine belt (3). Slowly release the belt tensioner to relax into a neutral position.

NOTE: Be sure to allow enough room for the swing of the ratchet to allow belt tensioner to relax into a neutral position.

Carefully remove alternator serpentine belt over the fan.




FIG. 8

Engine Components

Serpentine Belt Installation

FIG. 9: Alternator serpentine belt install.

NOTE: Skip this step if the alternator serpentine belt was not removed.



WARNING: Equipment or parts under spring tension can cause bodily injury. Use caution in applying pressure to belt tensioner.

Carefully install alternator serpentine belt over the fan.

Install serpentine belt (3) over pulleys on front of engine, leaving serpentine belt off of alternator pulley (4). Ensure that belt ribs are properly seated in pulley valleys.

Insert square drive of ratchet into square hole (1) on belt tensioner (2) and rotate tensioner counter clockwise and hold.

NOTE: Be sure to allow enough room for the swing of the ratchet to allow belt tensioner to relax into a neutral position.

Carefully place belt onto alternator pulley (4) ensuring belt ribs are properly seated in pulley valleys and slowly allow belt tensioner to release until belt tensioner makes contact with belt. When the belt tensioner has tensioned the serpentine belt remove ratchet.

FIG. 10: Air conditioning compressor serpentine belt install.



WARNING: Equipment or parts under spring tension can cause bodily injury. Use caution in releasing belt tension.

Install air conditioning serpentine belt (3) over pulleys on front of engine, leaving air conditioning serpentine belt off of the air conditioning compressor pulley (4). Ensure that belt ribs are properly seated in pulley valleys.

Insert square drive of ratchet into square hole (1) on belt tensioner (2) and rotate tensioner counter clockwise and hold.

NOTE: Be sure to allow enough room for the swing of the ratchet to allow belt tensioner to relax into a neutral position.

Carefully place belt onto air conditioning compressor pulley (4) ensuring belt ribs are properly seated in pulley valleys and slowly allow belt tensioner to release until belt tensioner makes contact with belt. When the belt tensioner has tensioned the serpentine belt remove ratchet.




FIG. 9




FIG. 10

FIG. 11: Remove left-hand guard.

Install guard (3) and install bolts and washers (2) and tighten. Tighten to 28 Nm (20 lbf ft).

Install loop clips, bolts and washers (1) and tighten. Tighten to 12 Nm (9 lbf ft).




FIG. 11

This as a preview PDF file from **best-manuals.com**



Download full PDF manual at **best-manuals.com**