

Service Manual

A2300 Diesel Engine

D15S-5, D18S-5, D20SC-5

G15S-5, G18S-5, G20SC-5

GC15S-5, GC18S-5, GC20SC-5

Important Safety Information

Most accidents involving product operation, maintenance and repair are caused by failure to observe basic safety rules or precautions. An accident can often be avoided by recognizing potentially hazardous situations before an accident occurs. A person must be alert to potential hazards. This person should also have the necessary training, skills and tools to perform these functions properly.

Read and understand all safety precautions and warnings before operating or performing lubrication, maintenance and repair on this product.

Basic safety precautions are listed in the "Safety" section of the Service or Technical Manual. Additional safety precautions are listed in the "Safety" section of the owner/operation/maintenance publication. Specific safety warnings for all these publications are provided in the description of operations where hazards exist. WARNING labels have also been put on the product to provide instructions and to identify specific hazards.

If these hazard warnings are not heeded, bodily injury or death could occur to you or other persons. Warnings in this publication and on the product labels are identified by the following symbol.



Improper operation, lubrication, maintenance or repair of this product can be dangerous and could result in injury or death.

Do not operate or perform any lubrication, maintenance or repair on this product, until you have read and understood the operation, lubrication, maintenance and repair information.

Operations that may cause product damage are identified by NOTICE labels on the product and in this publication.

DOOSAN cannot anticipate every possible circumstance that might involve a potential hazard. The warnings in this publication and on the product are therefore not all inclusive. If a tool, procedure, work method or operating technique not specifically recommended by DOOSAN is used, you must satisfy yourself that it is safe for you and others. You should also ensure that the product will not be damaged or made unsafe by the operation, lubrication, maintenance or repair procedures you choose.

The information, specifications, and illustrations in this publication are on the basis of information available at the time it was written. The specifications, torques, pressures, measurements, adjustments, illustrations, and other items can change at any time. These changes can affect the service given to the product. Obtain the complete and most current information before starting any job. DOOSAN dealers have the most current information available.

Index

Introduction

About the Manual	5
How to Use the Manual	5
Generic Symbols.....	6
Definition of Terms	7
Illustrations	8

General Engine Information

External Engine Components	9
Engine Specifications	11

Troubleshooting Logic

Engine Diagrams	12
Problem Isolation and Correction	12
Troubleshooting Logic(List of Symptoms).....	13

Coolant System

Cooling System Components and Flow.....	53
Pressure Caps	56
Water(Coolant) Pump.....	57
Thermostat	60
Gauges, Overfueling and Loading	61
Cooling System Replacement Procedures	62
Belt Tensioner Replacement	62
Fan Pulley Replacement.....	62
Fan Hub Replacement	63
Water Pump Replacement.....	64
Cup Plug Replacement	67

Fuel System

Fuel System Components and Flow	68
Fuel System Malfunction Diagnosis.....	69
Air in the Fuel System.....	70
Fuel Water Separator/Filter Unit	71
Injection Pump	72
Governor Malfunctions	72
Fuel Control Lever TRavel and Adjustment	73
VE Pump Adjustment Screws	73
Manual Shut Down Levers.....	74
Advance Timing Mechanism	74
Electrical Shut off Valves	75
Injection Pump Timing.....	77
High Pressure Fuel Line	78
Injectors.....	79
Fuel Drain Manifold.....	81

Air System

Air System Flow	98
Diagnosing Air System Malfunctions.....	99
Air Flow Restriction	99
Damage from Non-Filtered Air	100
Pressure Side Air Leaks.....	100
Exhaust Leaks.....	101
Malfunctioning Turbocharger.....	101
Oil Consumption and Leaks.....	102
Turbocharger Noise	103
Rotor Assembly Clearance Measure	104

Lubricating System

Lubricating System Flow	113
Lubricating Oil Pump.....	113
Pressure Regulating Valve	113
Oil Coolers.....	114
Oil Filters	114
Oil Filters Bypass Valve.....	114
Low Oil Pressure	116
Oil Level	116
Oil Filter	117
Oil Gauge	117
Oil Suction Tube	117
Bearings and Oil Pump	117
Incorrect Oil Pump.....	118
Oil Dilution	118
Coolant Diluted Oil	118
Fuel Diluted Oil.....	119
Oil Leaks	123

Electrical System

Electrical System Description/Operation.....	134
Electrical System Spec.	136
Starting Motor.....	137
Engine Cranking Speed Too Slow	139
Alternator.....	140
Fuel Shut Off Valve Check.....	143
Oil Pressure Switch.....	143

Base Engine Components

Operation and Description	148
Cylinder Head and Valve Train	149
Front Gear Housing and Gear Train	150
Front Crankshaft Seal	150
Camshaft, Tappets and Push Rods	150
Flywheel Housing and Flywheel	151
Piston and Rod Assemblies	152
Crankshaft and Main Bearings.....	154
Oil Pan	156
Base Engine Component.....	156
Air and Fuel System.....	157
Compression Check.....	158
Piston Ring Seal	158
Valve Sealing	158
Valve Seal Wear.....	160
Front Gear Housing and Gear Train.....	161
Rocker Levers	162
Piston and Rod Assembly	163
Crankshaft and Main Bearings.....	165
Cylinder Block	166
Flywheel Housing and Flywheel	166
Base Engine Component Specifications.....	168
Gear Train	169
Camshaft.....	169
Tappets.....	169
Pistons	170
Connecting Rod	171
Crankshaft.....	171
Cylinder Block	171
Cylinder Bore	172
Base Engine Components	173
Rocker Levers	174
Rocker Levers Assembly	179
Valve Clearance	179
Four Cylinder Engine	179
Camshaft and Tappet	180
Camshaft Inspection	181
Camshaft Bushing Inspection	182
Tappet Inspection	183
Gear Housing or Gasket	186
Flywheel Ring Gear and Rear Sel	187
Brass Drift Pin	187
Flywheel	188
In Chassis Overhaul.....	189
Cylinder Head Removal	190
Main Bearing Preliminary Inspection	191
Main Bearing	194
Piston and Rod	196
Piston, Pin and Connecting Rod.....	197
Piston Ring Gap.....	202
Piston Rings.....	202
Piston and Rod Assembly	204
Cylinder Head and Gasket.....	207
Cylinder Head.....	211
Valves.....	214
Valve Seats	216
Cylinder Head	220
Hydraulic Pump Drive Gear and Shaft.....	221

Balancer-Remove	221
Balancer-Install	222

Engine Replacement and Testing

Engine Replacement.....	223
Engine Removal.....	224
Engine Installation.....	225
Engine Testing.....	227

Specifications

General Engine	228
Fuel System	228
Lubricating Oil System	228
Cooling System	229
Air Intake System.....	229
Exhaust System	229
Electrical System.....	229
Drive Belt Tension	229
Capscrew Markings and Torque Values.....	230
Fraction, Decimal, Millimeter Conversions.....	233
Newton-Meter to Foot-Pound Conversions.....	234
Pipe Plug Torque Values.....	234
Weights and Measures-Conversion Factors.....	235

Special Tools

Special Tool List	237
-------------------------	-----

Introduction

About the Manual

The procedures in this manual were developed for an in-chassis environment. The information has been grouped by the main engine systems. The Table of Contents defines the systems. The index at the beginning of each section subdivides the instructions for the various components of the system. Wrench sizes and special tools are identified in the procedures as needed.

How to Use the Manual

The organization of this manual is based on the troubleshooting logic presented in Section 2. To fix a problem, find the logic chart for the particular symptom. Follow the steps specified until the problem is corrected.

The left column of the charts indicates a probable cause. The right column provides a brief description of the corrective action with a reference to the repair procedure or diagnostic discussion when appropriate.

The logic charts reflect three basic considerations:

1. Assumes the engine has provided satisfactory service prior to the problem.
2. Performing the easiest things first.
3. Most logical cause in descending order.

If the problem occurs with a new engine or after repair of the engine, the diagnostics discussion for each major system will provide guidance for sorting out the cause of the problem.

Generic Symbols

The following group of symbols has been used in this manual to help communicate the intent of the instructions. When one of the symbols appears, it conveys the meaning defined below.



Warning – Serious personal injury or extensive property damage can result if the warning instructions are not followed.



Caution – Minor personal injury can result or a part, an assembly or the engine can be damaged if the caution instructions are not followed.



The component weighs 23kg [50lb] or more. To avoid personal injury, use a hoist or get assistance to lift the component.



Indicates a REMOVAL or DISASSEMBLY step.



Indicates an INSTALLATION or ASSEMBLY step.



INSPECTION is required.



CLEAN the part or assembly.



PERFORM a mechanical or time MEASUREMENT.



LUBRICATE the part or assembly.



Indicates that a WRENCH or TOOL SIZE will be given.



TIGHTEN to a specific torque



PERFORM an electrical MEASUREMENT.




Refer to another location in this manual or another publication for additional information.

Definition of Terms

The following is a list of guidelines for each procedure in the “repair Sections” of the Troubleshooting and Repair Manual. The procedure will be given first; followed by a definition of the step or steps involved.

Check	Examine a component or system for damage, excessive wear, accuracy, safety, or performance.
Inspect	Examine a component or dimension to make sure it meets the required specifications.
Test	Check or compare the performance of a component or system to established specifications.
Adjust	Complete the necessary steps to set or adjust the component, assemblies, or system in the required setting or position.
Visually Inspect	Look for any obvious damage or problem.
Remove	Take off a component or assembly
Clean	Remove dirt, grease or other contamination.
Disassemble	Take the component or assembly apart.
Repair	Restore a component or assembly to a serviceable condition within the established specifications.
Note	Only the easiest and simplest repairs will be made to a component or assembly. If a component or assembly must be rebuilt; it must be replaced with a new or Cummins Diesel Recon, Inc. replacement or be rebuilt at a Cummins authorized repair location.
Replace	Install a new, properly rebuilt, or Cummins Diesel Recon, Inc. component or assembly in place of one which is removed.
Install	Place a component or assembly in the correct position.




Star Pattern Torque Sequence



Illustrations

The illustrations used in the Diagnosis Sections of this manual are intended to give an example of a problem, show what to look for and where to look for the problem.

Most of the illustrations are generic and might not look exactly like the engine or parts used in your application. Some illustrations contain symbols to indicate an action required and an acceptable or unacceptable condition.





The illustrations used in the Replacement Sections are intended to show replacement procedures when the engine is installed in a chassis. The illustration may differ from your application, but the procedure given will be the same.

General Engine Information

External Engine Components

The pictures which follow show the locations of the major external engine components, the filters, and other service and maintenance points. Some external components will be at different locations for different engine models. Note: The pictures are only a reference to show a typical engine.




Exhaust Side [Naturally Aspirated]


- | | |
|------------------------|----------------------|
| 1. Exhaust Manifold | 5. Crankshaft Pulley |
| 2. Oil Fill Cap | 6. Dip Stick |
| 3. Fan | 7. Oil Filter |
| 4. Fuel Injection Pump | |

Intake Side [Naturally Aspirated]



- | | |
|-----------------------|-------------------|
| 1. Intake Manifold | 4. Starting Motor |
| 2. Alternator | |
| 3. Thermostat housing | |



Front View
(Naturally Aspirated)



Rear View
(Naturally Aspirated)




Exhaust Side [Turbocharged]


- | | |
|----------------------|--------------------------------|
| 1. Fuel Filter | 5. Dipstick |
| 2. Crankshaft Pulley | 6. Oil Cooler |
| 3. Cooling Fan | 7. Fuel Injection Pump |
| 4. Exhaust Manifold | 8. Turbocharger Oil Drain Tube |

Intake Side [Turbocharged]

- | | |
|-----------------------|--------------------------|
| 1. Turbocharger | 5. Starting Motor |
| 2. Alternator | 6. Turbocharger Oil Tube |
| 3. Thermostat Housing | 7. Oil Fill Cup |
| 4. Intake Manifold | 8. Air Crossover Tube |



Front View
(Turbocharged)



Rear View
(Turbocharged)

Engine Specifications

Engine Model	A2300
General Engine Data	Naturally Aspirated
Engine Weight(Dry) Less Flywheel and Electronics	169 kg [373 lb]
Compression Ratio	21:1
Bore [mm/inch]	88 [3.46]
Stroke [mm/inch]	94 [3.7]
Displacement [ℓ/in3]	2.29 [139]
Firing Order	1-3-4-2
Valve Clearance	Intake Exhaust
	0.3 mm [0.012 in] 0.3 mm [0.012 in]
Rotation Viewed from the Front of the Engine	Clockwise

Lubrication System	Naturally Aspirated
Regulating Valve Opening Pressure	290 – 390kPa [42-56 psi]
Lubricating Oil Capacity [ℓ/gal]	Total System Standard Oil Pan Only
	7.0 [1.85] 6.5 [1.72]
Lubricating Oil Pressure at Idle(Max. Allowable)	69 kPa [10 psi]
Lubricating Oil Pressure at Rated(Min. Allowable)	245 kPa [35 psi]
Oil Filter Differential Pressure to Open Bypass Valve	98 kPa [14 psi]
Number of liters [qt] from Low to High	2.0 ℓ [0.53 gal]
Lubrication System	Forced Lubrication with Pump

Cooling System	Naturally Aspirated
Coolant Capacity (Engine Only) [ℓ/gal]	3.0 [0.7]
Standard Modulating Thermostat Range [°C/F]	Start Pulley Open
	71 [160] 8 [185]
Cooling System	Forced Lubrication with Pump

Air Induction System	Naturally Aspirated
Maximum Allowable Intake Restriction at Rated Speed and Load with Dirty Filter Element	6.23 kPa [635 mmAq]

Exhaust System	Naturally Aspirated
Maximum Allowable Exhaust Restriction at Rated Speed and Load with Dirty Filter Element	5.88 kPa [600 mmAq]

Fuel System	Naturally Aspirated
Injection Pressure	150 kPa [22 psi]
Starting System	Electric starting with Starter Motor (12 V –2.0 kW)

Troubleshooting Logic

Engine Diagrams

A schematic of each of the major engine systems is provided at the beginning of the section of the manual devoted to troubleshooting and repairing that particular system.

The diagrams depict flow through the various engine systems. The information and configuration of the components illustrated in the drawings are of a general nature. Some items for specific applications and installations may be different.

Each Section also contains a discussion regarding diagnosing malfunctions for that specific system.

Knowledge of the systems can help you troubleshoot and repair the engine.

Problem Isolation and Correction

The following Troubleshooting Logic is designed to help you organize your study of a problem and to plan a procedure to correct it. The series of fault/logic charts given do not provide all the answers, but they should stimulate a train of thought that will lead you to the source of the trouble.

Be sure to consider any maintenance or repair action that could have caused the problem.


If the engine surges or runs rough initially after not being used for 2 months or more, do not assume that the engine has a malfunction. Varnish can form on the internal parts of the injection pump and the oil film can drain from the piston rings. Operate the engine for at least 5 minutes before troubleshooting.

The basic procedure is as follows:

- Study the problem thoroughly.
- Relate the symptoms to your knowledge of the engine components and systems.
- Double-check before beginning the disassembly.
- Solve the problem by deduction starting with the easiest things.
- Determine the cause of the problem and make a thorough repair.
- After making corrections, operate the engine in normal conditions to verify the cause of the problem was corrected.

Troubleshooting Logic

Page	List of Symptoms
52	Alternator Not Charging or Insufficient Charging
36	Coolant Loss
32	Coolant Temperature Above Normal
35	Coolant Temperature Below Normal
46	Compression Knocks
43	Contaminated Coolant
44	Contaminated Lube Oil
15	Engine Cranks But Will Not Start – No Smoke From Exhaust
16	Engine Hard to Start Or Will Not Start – Smoke From Exhaust
24	Engine RPM Will Not Reach Rated Speed
22	Engine Runs Rough or Misfiring
18	Engine Starts But Will Not Keep Running
14	Engine Will Not Crank Or Cranks Slowly
48	Engine Will Not Shut Off
51	Excessive Engine Noises
30	Excessive Engine Smoke
47	Excessive Fuel Consumption
49	Excessive Vibration
45	Fuel or Oil Leaking From Exhaust Manifold
26	Low Power
41	Lube Oil Loss
38	Lubricating Oil Pressure Low
40	Lubricating Oil Pressure Too High
20	Rough Idle (Irregularly Firing Or Engine Shaking)
19	Surging (Engine Speed Change)



Engine Cranks But Not Start – No Smoke From Exhaust

Cause

Correction

No Fuel in Supply Tank

Check/Replenish Fuel Supply

OK



Electrical or Manual Fuel Shutdown Not Open

Check for Loose Wires and Verify that the Valve is Functioning. Check to be sure Manual Shut Off Lever is in the Run Position. Refer to Page 74

OK



Air Intake or Exhaust Plugged

Visually Check: Remove the Obstruction.

OK



Fuel Filter Plugged With Water or Other Contamination

Drain Fuel/Water Separator or Replace Fuel Filter. Refer to Page 71, 83

OK



Injection Pump Not Getting Fuel or Fuel is Aerated

Check Fuel Flow/Bleed Fuel System. Refer to Page 83

OK



Worn or Malfunctioning Injection Pump

Visually Check Fuel Delivery with an Externally Connected Injector to One of the Pump Outlets. Replace the Pump if Fuel is Not Being Delivered. Refer to Page 94

OK



Internal Pump Timing Incorrect

Verify/Time the Pump. Refer to Page 77

OK



Camshaft Out of Time

Check/Correct Gear Train Timing Alignment. Refer to Page 77, 185

Engine Hard To Start Or Will Not Start – Smoke From Exhaust

Cause

Correction

Incorrect Starting Procedure

The Fuel Control Lever on the Bosch VE Pump Must be Moved to One-Half Travel. The Fuel Shut Off Control Must Be in the Run Position. Refer to O&M Manual.

OK



Cranking Speed Too Slow

Verify that the Driven Units are not Engaged.

OK



Cold Starting Aids Not Working or Are Needed

Verify the Aids are Operating. Refer To O&M Manual.

OK



Insufficient Intake Air

Inspect or Replace Filter and Check for Obstructions to the Air Supply Tube. Refer to Page 98, 112

OK



Air in the Fuel System or the Fuel Supply is Inadequate

Check the Flow through the Filter and Bleed the System. Locate and Correct the Air Source. Refer to Page 83

OK



(Continued)

Engine Hard To Start Or Will Not Start – Smoke From Exhaust (Continued)

Cause

Correction

Contaminated Fuel

Verify by Operating the Engine with Clean Fuel from a Temporary Tank. Drain and Flush Fuel Supply Tanks.

OK



Worn or Malfunctioning Injection Pump

Visually Check Fuel Delivery With an Externally Connected Injector to one of the Pump Outlets. Replace the Pump if Fuel is Not Being Delivered. Refer to 94

OK



Injection Pump Out of Time

Check/Time the Pump.
Refer to Page 77, 96

OK



Valves Incorrectly Adjusted

Adjust Valves. Refer to Page 179

OK



One or More Injectors Worn or Malfunctioning


Check/Replace Injectors.
Refer to Page 88


OK



Engine Compression Low

Perform a Compression Check to Identify the Problem. Refer to Page 158





Rough Idle (Irregularly Firing Or Engine Shaking)

Cause

Correction

Cold Engine

Refer to Troubleshooting Logic for Engine Running Too Cold. Refer to 35

OK
↓

Idle Speed Too Low for the Accessories

Check/Adjust Low Idle Screw. Refer to Page 73

OK
↓

Engine Mounts Over-Tightened, Damaged or Loose

Verify Condition of Mounts. Refer to Equip. Manufactures Service Instructions.

OK
↓

High Pressure Fuel Leak

Inspect/Correct Leaks in the High Pressure Lines, Fittings Injection Sealing Washers or Delivery Valve Seals. Refer to Page 78

OK
↓

Air in the Fuel System

Bleed the Fuel System and Correct the Source of the Air. Refer to Page 83

OK
↓

Sticking Needle Valve in an Injector

Replace the Injector. Refer to Page 88

OK
↓

Malfunctioning Delivery Valve

Replace Delivery Valves. Refer to Page 92

OK
↓

(Continued)

Rough Idle (Irregularly Firing Or Engine Shaking)(Continued)

Cause

Correction

Valves Not Sealing

Adjust Valves. Refer to Page 179

OK



**One or More Cylinders Losing
Compression**

Perform a Compression Check and Repair
as Required. Refer to Page 160

Engine Runs Rough Or Misfiring

Cause

Correction

Fuel Injection Lines Leaking

Inspect/Correct Leaks in the High Pressure Lines, Fittings Injector Sealing Washers, or Delivery Valve. Refer to Page 78

OK
↓

Air in the Fuel or the Fuel Supply is Inadequate

Check the Flow Through the Filter and Bleed the System. Locate and Correct the Air Source. Refer to Page 83

OK
↓

Contaminated Fuel

Verify by Operating the Engine with Clean Fuel from a Temporary Tank.

OK
↓

Incorrect Valve Adjustment

Check for a Bent Push Rod and Adjust Valves. Refer to Page 179

OK
↓

Injection Pump Timing Incorrect

Check/Time Pump. Refer to Page 77


OK
↓


One or More Cylinders Has Low Compression

Perform a Compression Check to Isolate the Cause of Low Compression (Piston Rings, Head Gasket or Valves). Refer to Page 158

OK
↓

(Continued)





Engine RPM will Not Reach Rated Speed (Continued)

Cause

Correction


**If the Condition is Intermittent,
Restricted Manifold Drain Line**


Check/Remove Restriction.
Refer to Page 81


OK
↓


Malfunctioning Injection Pump


Replace Pump.
Refer to Page 94

















Coolant Temperature Above Normal (Continued)

Cause

Correction

Malfunctioning Temperature Sensor/Gage

Verify that the Gage and Temperature Sensor are Accurate.
Refer to Pages 55

OK
↓

Malfunctioning, Incorrect or No Thermostat

Check/Replace the Thermostat.
Refer to Page 60, 65

OK
↓

Air in the Cooling System

Make Sure the Fill Rate is not Being Exceeded and the Correct Vented Thermostat is Installed. Refer to Page 55

OK
↓

If Aeration Continued, Check for a Compression Leak Through the Head Gasket. Refer to Page 116

Malfunctioning Water Pump

Check/Replace the Water Pump.
Refer to Page 58, 64

OK
↓

Incorrect Injection Pump Timing

Check/Time the Injection Pump.
Refer to Page 77

OK
↓

Incorrect External Injection Pump Timing

Verify Pump Timing Marks are Aligned.
Refer to Page 77, 83

OK
↓

Over fueled Injection Pump

Replace the Injection Pump.
Refer to Page 94

OK
↓

(Continued)

Coolant Temperature Above Normal (Continued)

Cause

Correction


**Plugged Cooling Passages in
Radiator, Head, Head Gasket or
Block**


Flush the System and Fill with Clean
Coolant. Refer to Page 55


OK
↓


Engine Overloaded

Verify that the Engine Load Rating is Not
being Exceeded. Refer to Page 60, 65









Lubricating Oil Pressure Low (Continued)

Cause

Correction

Loose or Missing Cup Plugs

Check/Replace Cup Plugs.
Refer to Page 123, 132

OK
↓

Suction Tube Loose or Seal Leaking

Check/Replace Seal.
Refer to Page 117

OK
↓

Worn Lube Pump

Check/Replace Lube Pump.
Refer to Page 118, 128

OK
↓


Loose Main Bearing Cap


Check/Install New Bearings (s) and
Tighten Cap


OK
↓


Worn Bearings


Inspect/Replace Bearings; also
Check/Replace Piston Cooling Nozzles.
Refer to Page 154, 165




















Excessive Fuel Consumption (Continued)

Cause

Correction


Fuel Shutoff Valve Inoperative


Stop the Engine Mechanically with Lever on the Fuel Pump. Check/Replace Sealing Washer, Piston and Spring. Refer to Page 75


OK
↓


Engine Running on Fumes Drawn into the Air Intake

Check the Air Intake Ducts for Source of the Fumes.









Coolant System

Coolant System Component and Flow

The following illustration identifies the significant features of the coolant system.

Coolant is drawn from the radiator by the integrally mounted water pump. The output from the water pump empties into the oil cooler cavity of the cylinder block.


The Coolant then circulates around each cylinder and crosses the block to the fuel pump side of the engine.

Coolant then flows up into the cylinder head, crosses over the bridges and down the exhaust manifold side of the engine to the integral thermostat housing.

As the coolant flows across the head toward the thermostat housing, it provides cooling for the injector nozzle. When the engine is below operating temperature, the thermostat is closed, and the coolant flow bypasses the radiator and goes to the water pump inlet via internal drillings in the block and cylinder head.


When Operating temperature is reached, the thermostat open, blocking the bypass passage to the water pump and opening the outlet to the radiator.

Caution: Never operate the engine without a thermostat. Without a thermostat, the coolant will not flow to the radiator and the engine will overheat.




1. Radiator. 2. Thermostat. 3. Water Temperature Gauge. 4. Water Pump. 5. Water Manifold. 6. Cylinder Head. 7. Piston. 8. Cylinder Block. 9. Oil Cooler (Optional).
A. From Oil Pump (Oil)

Cooling System Specifications	A2300
Coolant Capacity (Engine Only) - Liter [U.S. Qts.]..	3.0 [3.2]
Standard Modulating Thermostat – Range – °C [°F]	71 [160] to 85 [185]




Coolant System Malfunctions - Diagnosis –

The function of the coolant system is to maintain a specified operating temperature of the engine. Some of the heat generated by the engine is absorbed by the coolant flowing through the passages in the cylinder block and head. Then, heat is removed from the coolant as it flows through the radiator. When you troubleshoot over heating, remember that too much oil in the oil pan can cause additional heat from friction when the rod journals are submerged in oil.




Overfilling with oil raises the oil temperature which is transferred to the coolant system at the oil cooler.




The system is designed to use a specific quantity of coolant. If the coolant level is low, the engine will run hot.

1. The engine or system has a leak if frequent addition of coolant is necessary. Find and repair the leak.




Caution : The engine coolant passages must be completely filled with coolant.

During operation entrapped air mixes with the coolant which results in cavitation corrosion and poor heat transfer. Highly aerated coolant can cause localized overheating of the cylinder head and block which can result in a cracked head, scored cylinder or blown head gasket.




During filling, air must be vented from the engine coolant passages. The air vents through the "jiggle pin" opening and the notched vent hole to the top radiator hose and out the fill opening. Additional venting is provided for engines equipped with an after cooler. Open the petcock during filling.



Caution : Never use only water for engine coolant. In tropical climates where antifreeze availability may be limited, use a corrosion inhibitor (Cummins Liquid DCA) to protect the engine cooling system.


A mixture of 50% ethylene-glycol base antifreeze is required for operation of the engine in temperature environments above -37°C [-34°F]. A mixture of 40% water and 60% antifreeze is recommended for temperatures below -37 °C [-34°F].



Caution : The small holes in the head gasket are especially susceptible to plugging.


Water will cause rust formation reducing the flow in the smaller coolant passages.

Caution : These holes are orifices and their size is critical. Do not enlarge the size of the orifices. To do so will disturb the coolant flow and will not solve an overheating problem.



Also, water used as a coolant for even a relatively short period can result in the cup plugs rusting through allowing the coolant to leak.

Note : A sudden loss of coolant from a heavily loaded engine can result in severe damage to the pistons and cylinder bore.




Pressure Caps


The system is designed to use a pressure cap to prevent boiling of the coolant. Different caps are specified for the two recommended

systems:


	System	Cap
A -	104 °C [220°F]	103kPa [15 PSI]
B -	99 °C [210°F]	48kPa [7 PSI]



An incorrect or malfunctioning cap can result in the loss of coolant and the engine running hot.




Air in the coolant can result in loss from the overflow when the aerated coolant is hot. The heated air expands, increasing the pressure in the system causing the cap to open. Similarly, coolant can be displaced through the overflow if the head gasket leaks compression gasses to the coolant system.




The operating pressure of the coolant system and the lubricating system can result in mixing of the fluids if there is a leak between the systems: head gasket, oil cooler, etc. (refer to the Lubricating System).

Note: Transmission fluid can also leak into the coolant through bottom tank oil coolers.




Water (Coolant) Pump

The water pump pulls coolant from the bottom of the radiator and pumps it through the engine back to the top of the radiator for cooling. Reduced or interrupted flow will result in the engine running hot.




The pump is belt driven from the crankshaft pulley. A belt tensioner is used to prevent the belt from slipping on the pump pulley. A malfunction of the tensioner will cause the water pump impeller to rotate at a slower speed, reducing the amount of coolant flow.




The coolant flow can also be reduced if the inlet hose to the water pump collapses. A hose will usually not collapse while the engine is running at low speed. Check the hose while the engine is running at rated speed.


Note : Be sure the engine is warm, a minimum of 85°C[185°F], so the thermostat is open.



A worn or malfunctioning water pump will not produce the flow required to prevent the engine from running hot. However, be sure to check the other possibilities indicated in the Troubleshooting Logic before checking the flow or replacing the pump.




As stated in the coolant discussion, an obstruction in the passages can interrupt flow.




Radiator, Fans and Shutters

Air forced through the fins of the radiator by a fan cools the coolant pumped through the radiator. Environmental debris (paper, straw, lint, dust, etc.) can obstruct the fins and stop the flow of air which will reduce the cooling effect of the radiator.




If the fan is belt driven, a slipping belt will result in a slower fan speed and reduced cooling. A malfunctioning belt tensioner can be the problem.

Note : Check the bearings in the fan hub and other pulleys to make sure they are not causing excessive belt vibration and slippage.




Interruption of the circuit to an electrically driven fan can result in insufficient airflow and cause the engine to run hot.

Note : Make sure that the temperature sensor is functioning correctly.




Shutters are designed to control air flow across the radiator. If the shutters fail to open when needed, the engine can run hot. Failure of the shutters to close can result in too much air flow and the engine running cold.

Note : Make sure that the air temperature sensor is functioning correctly. Check the air operated shutter controls. Check for air leaks.



An incorrect fan shroud or obstructions can reduce airflow and cause the engine to run hot.


Note : Check to be sure air is not recirculating.
Check for missing baffles.



Thermostat

The thermostat controls the coolant temperature. When the coolant temperature is below the operating range, coolant is bypassed back to the inlet of the water pump.

When the coolant temperature reaches the operating range, the thermostat opens, sealing off the bypass, forcing coolant to flow to the radiator.




Caution : Never operate the engine without a thermostat. Without a thermostat the path of least resistance for the coolant is through the bypass to the pump inlet.

This will cause the engine to overheat.




An incorrect or malfunctioning thermostat can cause the engine to run too hot or too cold.




Gauges, Overfueling and Loading


Gauges and sensors are used in the system to measure the coolant temperature. These can malfunction and provide an incorrect temperature indication.



Caution : Overfueling can cause the engine to overheat. Make sure that the fuel pump is calibrated correctly.



Caution : Constant overloading (lugging) can cause the engine to run hot.



Cooling System Replacement Procedures



Drive Belt – Replacement

12mm


Lift the tensioner to remove and install the drive belt.



Belt Tensioner – Replacement

Preparatory Step:

- Remove the drive belt



12mm

Remove the capscrew and replace the tensioner.


Torque Valve: 25.5 Nm [19ft-lbs]



Fan Pulley – Replacement

Preparatory Step:

- Remove the drive belt.



12mm

Remove the four capscrews, fan and spacer.
Replace the fan pulley.

Torque Valve: 25.5 Nm [19ft-lbs]



Fan Hub – Replacement

Preparatory Steps:


- Remove the drive belt.
- Remove the fan pulley.



12mm

Remove the four capscrews and replace the fan hub.

Torque Valve: 25.5 Nm [19ft-lbs]




Coolant – Draining

The coolant is 50% mixture of water and ethylene-glycol base antifreeze; a 20 liter (4 U.S. gallons) drain pan will contain the coolant in most applications.

Water Pump – Replacement

Preparatory Steps:

- Drain the coolant.
- Remove the drive belt.




12mm


Remove the four cap screws and water pump, and complete the following steps.



Clean the sealing surface on the cylinder block.



Install the new gasket.



12mm

Install the water pump.

Torque Valve: 25.5 Nm [19ft-lbs]



Thermostat - Replacement


Preparatory Steps:

- Drain the coolant.
- Remove the drive belt.
- Disconnect negative battery cable.
- Disconnect the upper radiator hose.



12mm


Note : Loosen the alternator link capscrew and complete the following steps.



14mm

Remove the alternator mounting capscrew and lower the alternator.






12mm

Remove the thermostat housing, lifting bracket and thermostat.



Clean the mating surfaces.



Position the rubber seal as shown for reassembly.



Assemble the removed parts in the reverse order of removal.



Torque Valve:

(Alternator Link) 25.5 Nm [19 ft-lbs]


(Alternator Mounting) 49Nm [37 ft-lbs]

(Thermostat Mounting) 25.5 Nm [19 ft-lbs]



Cup Plugs – Replacement

Remove the cup plugs from the coolant passages as shown.



Apply a bead of Loctite 277 to the coolant passage cup plugs.




Drive the plugs in until the outer edge is flush with the counter sink in the block.

Fuel System

Fuel System Component and Flow

The following illustration identifies the components of the fuel system.




1. Fuel Injection Pump. 2. Overflow Valve. 3. Fuel Shut-Off Solenoid. 4. Fuel Injection Nozzle. 5. Fuel Tank. 6. Water in Fuel Sensor (WIF). 7. Fuel Filter. 8. Hand Priming Pump

Most of the engines will be quipped with a cam-actuated lift pump. Fuel flow begins as the lift pump pulls fuel from the supply tank. The pump supplies low-pressure fuel (21-35kPa, [3-5psi]) to the fuel filter head, through the filter and then to the distributor injection pump.

The engines use distributor-type fuel pumps supplied by Robert Bosch.

The distributor pump builds the high injection pressures required for combustion, and routes the fuel through individual high-pressure fuel lines to each injector.


When the high-pressure fuel reaches the injector, the pressure lifts the needle valve against the spring tension to let the fuel enter the combustion chamber.



Fuel System Malfunction – Diagnosis

The function of the fuel system is to inject clean, atomized fuel into the engine cylinders at a precise time near the end of the compression stroke of each piston.


The components of the system contribute to the delivery of fuel to the cylinders.



Normal pressure drop across the filter is 21 kPa [3 psi], maximum.


The pressure drop will increase as the filter removes contamination from the fuel. Therefore, a worn lift pump will have reduced capacity to force fuel through a dirty filter. This can cause low engine power.

Note : Frequent filter replacement to get full power from the engine can indicate a worn lift pump.




Air In the Fuel System

A replacement of supply lines, fuel filters, injection pump, high pressure lines and injectors will let air enter the fuel system. Follow the specified procedure to bleed the air from the system.




Since the lift pump provides a positive pressure through the fuel filter and supply line to the injection pump, loose connections or defective seals will show as a fuel leak.



The most usual place for air to enter the fuel system is between the inlet of the lift pump and the suction tube in the tank. Fuel tanks that have the outlet fitting at the top will have a suction tube that extends down in the tank. Cracks or pin holes in the weld that joins the tube to the fitting can let air enter the fuel system.



Air in the system will make the engine: hart to start, run rough, misfire, produce low power, and can cause excessive smoke and a fuel knock.




Fuel Water Separator/Filter Unit




Caution : Be sure to use the correct element.

Filtration and separation of water from the fuel is important for trouble-free operation and long life of the fuel system. Some of the clearances between the pump parts are very close. For this reason the parts can easily be damaged by rust formation and contaminants.

The element has a valve which can be opened regularly to drain the collected water.




Regular maintenance, including draining moisture from the fuel water separator/filter and supply tanks, is essential to keep water out of the fuel.



Injection Pump


The injection pumps are rotary distributor pumps. These pumps perform the four basic functions of:

1. Producing the high fuel pressure required for injection.
2. Metering the exact amount of fuel for each injection cycle.
3. Distributing the high pressure, metered fuel to each cylinder at the precise time.
4. Varying the timing relative to engine speed.



A single plunger or rotor is used by the pumps to develop and distribute the high pressure required for injection.


A four-cylinder, Robert Bosch VE pump plunger is shown in this illustration.



Governor Malfunctions


Balance between the flyweight governor and control lever position controls the metering of the amount of fuel to be injected.

The pump governor performance and setting can affect engine power. Special equipment and qualified personnel are required to verify governor performance. If the seals are broken on the external Robert Bosch VE adjustment screw, the fuel rate may be out of adjustment.



Fuel Control Lever Travel and Adjustment

The amount of fuel injected and subsequently the speed and power from the engine is controlled by the fuel control lever. Restricted travel of the lever can cause low power. Always check for full travel of the lever when diagnosing a low power complaint.




VE Pump Adjustment Screws


A – Idle Screw
B – High Idle Screw

The high speed adjustment screw on both pumps provides the stop for full speed. The high speed adjusting screws are sealed. Adjustment of this screw must be performed only by an authorized pump service center, and then resealed.

The high speed adjusting screw can be used to derate engines. The procedure is provided in this section.



Caution : The fuel control lever on the Robert Bosch VE pump is indexed to the shaft during pump calibration. If the lever has been removed and reinstalled incorrectly, engine speed and power will be affected.




Manual Shut Down Levers

Injection pumps are equipped with mechanical shut down levers. These levers are spring-loaded in the run position. Not all applications will use these manual shut down controls and there will be no cable or rod connected to the lever.

Note : Partial actuation of the mechanical shutdown levers will affect fuel flow and engine power.

Low power or the inability to stop the engine with the manual shut down control can be corrected by adjusting the cable/rod length to permit stop-to-stop lever travel.




Advance Timing Mechanism

Regulated pressure produced by a vane supply in both injection pumps is used to advance the timing as the engine speed increases.

A return spring is used to retard the timing as the engine speed is reduced. If a spring should break, the timing will go to the advance position resulting in torque loss, a fuel knock and possible engine overheating.


Retarded(late) timing will result in torque loss, high fuel consumption and white to black smoke.



Electrical Shut Off Valves


The injection pumps are equipped with electrical shut off valves. These solenoid-operated valves block the supply of fuel to the high pressure pumping and distribution components.

The Robert Bosch VE shut off valve is located at the top, rear of the pump.



The Robert Bosch valve does not make a very audible sound when actuated, but it can be checked with an ohmmeter for the following values:

Robert Bosch Shut Down Values	Resistance Ohms	Peak Amperes
12 Volt	7.4 + 0.5	2




Caution : Do not connect the electrical wire to the solenoid when the plunger has been removed. Without the plunger the valve can be damaged.

Malfunctioning valves can be diagnosed by removing the plunger and spring, then reinstall the solenoid.

Injection Pump Timing


Pump to engine timing is extremely critical. Pump timing that is off by only a few crankshaft degrees will cause:

1. Poor performance – starting and power
2. Excessive smoke and emission
3. Poor fuel economy



Engine pump timing begins with the timing of the injection pump drive gear to the camshaft gear. The first step is the location of TDC for cylinder Number 1.

After installing each gear, make sure that aligning marks A, B and C of the idle gear are aligned with those of the fuel injection pump drive gear, cam shaft gear and crank shaft gear.



High Pressure Fuel Line




Caution : The high pressure lines must be clamped securely and routed so they do not contact each other or any other component.

The high pressure fuel lines are designed and manufactured to deliver fuel at injection pressure to the injectors. The high pressure pulses will cause the lines to expand and contract during the injection cycle.




Caution : Do not weld or substitute lines; use only the specified part number for the engine.

The length, internal size and rigidity of the lines is critical to smooth engine operation.




Warning : The pressure of the fuel in the line is sufficient to penetrate the skin and cause serious bodily harm.


Use cardboard to check for cracks and leaks. With the engine running, move the cardboard over the fuel lines and look for fuel spray on the cardboard. Fuel leaks can cause poor engine performance.



It is normal to have entrapped air in the fuel lines after replacing the pump or the lines. Air in the lines will cause the engine to run rough or produce a fuel knock.




Bleed the air from the high pressure line at the fitting that connects the injector. Bleed one line at a time until the engine runs smooth. If the air cannot be removed, check the pump and supply line for suction leaks.




Injectors


Caution: Use only the specified injector for the engine.



During the injection cycle, high pressure from the injection pump rises to the operating (pop) pressure which causes the needle valve in the injector to lift. Fuel is then injected into the cylinder. A shimmed spring is used to force the needle valve closed as the injection pressure drops below the pop pressure to seal off the nozzle after injection.



Failure of the needle valve to lift and close at the correct time or needle valve stuck open can cause the engine to misfire and produce low power. Fuel leaking from the open nozzle can cause a fuel knock, poor performance, smoke, poor fuel economy, and rough running.




Caution : Be sure to tighten the fuel line nut before proceeding to the next injector.

To find which cylinder is misfiring, operate the engine and loosen the fuel line nut at one injector and listen for a change in engine speed.


Note : A drop in engine speed indicates the injector was delivering fuel to the cylinder. Check each cylinder until the malfunctioning injector is found.

Remove the malfunctioning injector to test or replace it.

If the engine continues to misfire after replacing the injector, check for leaks in the high pressure line. Also check for a defective delivery valve that lets the fuel drain back into the injection pump.



Carbon build up in the orifices in the nozzle will also cause low power from the engine. Remove and check the spray pattern or replace the injectors.




Fuel Drain Manifold

The fuel system is designed to use fuel to cool and lubricate the injection pump and injectors. Fuel is continually vented from the injection pump and a small amount of fuel leaks by the injector needle valve during injection. This fuel is returned to the supply tank by the fuel drain manifold.

Fuel System Replacement Procedure


A certain amount of air will be entrapped in the system during replacement of any of the system components. After replacement of a component, bleed the system according to the following procedure.



Fuel System – Bleeding

Controlled venting is provided at the injection pump through the fuel drain manifold.

Small amounts of air introduced by changing the filters or injection pump supply line will be vented automatically, if the fuel filter is changed in accordance with the instructions.




However, manual bleeding will be required if:

The fuel filter is not filled prior to installation.

Injection pump is replaced.

High pressure fuel line connections are loosened or lines replaced.

Initial engine start up or start up after an extended period of no engine operation.



High Pressure Lines – Venting

17mm




Warning : The pressure of the fuel in the line is sufficient to penetrate the skin and cause serious bodily harm.

Loosen the fittings at the injector, and crank the engine to allow entrapped air to bleed from the line. Tighten the fittings.



Warning : Do not bleed a hot engine as this could cause fuel to spill onto a hot exhaust manifold creating a danger of fire.




Fuel Filter – Replacement




80 to 95 mm, Filter Wrench


Remove the combination water separator/fuel filter.




Fill the new filter(s) with clean fuel.



Lubricate the seal with clean oil.



Install the filter(s) and tighten it 1/2 turn after its seal contacts the filter head.



High Pressure Lines – Replacement

17mm



Disconnect the high pressure lines from the injectors and complete the following steps.



10mm

Remove the line clamp capscrew from the intake cover.



14mm and 17mm

Remove the lines from the injection pump.



Note : Use two wrenches to prevent the delivery valve holder from turning.



10mm

Assemble the lines in the reverse order of removal.

Torque Value: 11Nm [8 ft-lbs]



Warning : Do not bleed a hot engine as this could cause fuel to spill onto a hot exhaust manifold creating a danger of fire.

Start the engine and vent one line at a time until the engine runs smoothly.




Fuel Drain Manifold – Replacement



17mm

Remove the high pressure fuel line.



17mm

Remove the head cap nuts.



17mm

Assemble the high pressure fuel line and fuel drain manifold in the reverse order of disassembly.




Torque Value: 49Nm [37 ft-lbs]

Injector – Replacement

Preparatory Steps:


- Disconnect the high pressure fuel supply lines
- Disconnect the fuel drain manifold.
- Clean around the injectors.



Rust Penetrating Solvent




Caution : When rust has formed on the hold down nut, the injector can turn in the bore when the nut is loosed. This will cause severe damage to the head by the injector locating ball cutting a groove in the bore.



Brass Drift Pin, Hammer


Hit the injector body with the drift pin to loosen any rust.



22mm Box Wrench, Adjustable Wrench




Hold the injector body with an adjustable wrench while you loosen the hold won nut with a 22mm box wrench.



Injector Bore Brush

Clean the injector nozzle bore.



Assemble the injector and new copper sealing washer.

Use Only One Copper Washer.



Apply a coat of anti-seize compound to the threads of the injector hold-down nut and between the top of the nut and injector body.



22mm Deep Well Socket


Caution : Align the injector's protrusion with the notch in the bore.




Torque Value: 73 Nm [55 ft-lbs]



Note : The current Bosch injector has an o-ring located above the hold down nut. After tightening the injector be sure to push the o-ring into the groove.



Assemble the fuel drain manifold and high pressure lines.
Leave the high pressure fittings loose at the injectors.




17mm



Warning : It is necessary to put the engine in the “run” position: Because the engine may start, be sure to follow all the safety precautions. Use the normal engine starting procedure.

Crank the engine to allow entrapped air to bleed from the lines. Tighten the fittings.



Electrical Fuel Shut Off Valve – Replacement



8mm




Remove the electrical wire and complete the following steps.
Clean around the valve.




24mm
Remove the valve.



Note : The Bosch VE valve is shown.



Caution : When removing the valve, be careful not to drop the plunger and spring.



“Package” the solenoid, o-ring, spring and plunger.




24mm
Tighten the solenoid securely.
Connect the electric wire.



Torque Value: 20 Nm [15 ft-lbs]






Delivery Valve Holder and Sealing Washer (Bosch VE) – Replacement




14mm and 17mm

Disconnect the high pressure line.




14mm

Remove the delivery valve holder and sealing washer.



Insert the sealing washer(1) and the delivery valve(2) in the pump. Insert the shim(4) and spring(3) in the holder(5).


Fit the spring(3) over the valve(2) and turn the holder(5) into the pump.



14mm


Tighten the holder to 49 Nm [37 ft-lbs].






14mm and 17mm

Connect the high pressure lines.




17mm

Start the engine and vent one line at a time until the engine runs smoothly.



External Pump Leaks

Check for excessive flow in the injection pump and fuel line due to leakage



Removal (Injection Pump)

Caution : Do not drop the nut and washer inside gear housing or engine damage can occur.

12mm

Remove the retaining nuts on the fuel injection pump mounting on the rear of the gear housing. Remove the access cover and gasket from the front of the gear housing.

Rotate the engine to line up the "B" mark on the fuel pump gear to the "B" mark on the idler gear. This can take a number of crankshaft revolutions to accomplish


17mm.

Remove the nut from the fuel injection pump shaft inside the housing.

Remove the fuel injection pump support bracket and mounting capscrews.


Remove the gear with a gear puller.

If the gear housing is in place, use the arms of the puller to push against the inside front of the housing and force the pump shaft rearward out of the gear.



12mm

Remove the fuel injection pump.



Installation (Injection Pump)

The pump shaft is keyed to the gear, and the gear has timing mark "B" for alignment to the idler gear mark "B".

In order to make sure that the fuel pump key is aligned properly to the gear keyway; rotate the engine opposite engine rotation (counterclockwise) several degrees to put the keyway in the gear approximately at 9:00 o'clock position. The "B" mark on the fuel pump gear will be on the top edge of the viewing hole.


Make sure the o-ring seal is installed.

The key on the pump shaft must be approximately in the 9:00 o'clock position looking at the shaft end.

Hold the fuel pump drive gear to the back of the housing to prevent disengagement of gear teeth.

12mm

Align the shaft key to the gear keyway and install the fuel injection pump on the rear of the gear housing.



Hand-tighten the retaining nuts on the mounting studs.

17mm

Install the gear, washer, and nut on the fuel injection pump shaft. Tighten the nut.

Torque Value : 88 n.m [65 ft-lb]




Rotate the engine in the direction of engine rotation. Check the "B" timing marks again for proper alignment.

12mm

Install the access cover. Tighten the cover capscrews.

Torque Value : 26 n.m [19 ft-lb]

Refer to Procedure 1 for fuel injection pump timing.




Tighten the retaining nuts on the fuel injection pump mounting studs on the rear of the gear housing.

Torque Value : 26 n.m [19 ft-lb]

Tighten the supporting bracket on the bottom of the fuel injection pump.

Torque Value : 26 n.m [19 ft-lb]




Timing


Dial Indicator Method

Find number 1 or top dead center (TDC) on compression for the number 1 cylinder by barring the engine until the hashmarks on the crank pulley line up with the indicator mark on the gear cover. This can be confirmed by removing the front cover access plate and ensuring that the idler gear and fuel pump gear timing marks are aligned.

A straight edge can be used to aid lining up the gear cover pointer and number 1 or top dead center (TDC) mark.




The flywheel also contains number 1 or top dead center (TDC) marks. The starter plate or flywheel contains the alignment mark. The mark is located at the 3 o'clock position as viewed from the rear of the engine. The flywheel can be used instead of the crank pulley if accessible.




12mm

Remove the access plug from the distributor head on the fuel pump.




Thread the timing tool assembly into the access plug hole and finger tighten.



Bar the crankshaft in the direction opposite engine rotation until the indicator needle stops moving. Adjust the indicator face to read zero.

Rotate the crankshaft in direction of engine rotation back to the mark on the crank pulley. This is the number 1 or top dead center (TDC) mark. If accessible, the flywheel and starter plate can be used to locate this position more easily.



At this point the dial indicator should read 1 mm [0.04 in] of lift.




If the dial indicator does not read 1 mm [0.04 in], loosen the fuel pump mounting bolts and rotate the pump till the correct plunger lift value is attained

12mm



Tighten the fuel pump mounting capscrews.
Torque Value : 29 n.m [21 ft-lb]



Re-rating

The pump governor performance and setting can affect engine power. Special equipment and qualified personnel are required to verify governor performance. The fuel rate change is not allowed

Injection pump re-rating must be discuss with Cummins dealer.

Air System

Air System Flow

The engines are available in naturally aspirated, turbocharged.


Air is pulled into the engine from an air filter. Clean air is very important to the life of the engine. Ingested dust and dirt can damaged the cylinders very quickly.

Caution : Make sure that a quality air cleaner is used and that it is periodically replaced according to the manufacturer's recommendations.

Intake air for naturally aspirated engines flows directly from the filter to the intake manifold. From the intake manifold, air is pulled into the cylinder and used for combustion. After combustion it is forced out of the cylinders through the exhaust manifold.


On turbocharged engines the flow is from the filter to the turbocharger, and then through the crossover tube to the manifold. From the intake manifold, air is forced into the cylinder and used for combustion. The exhaust gases flows through the turbocharger to rotate the turbine and impeller, thereby utilizing exhaust energy to force more air into the cylinders.

The additional air provided by the turbocharger allows more fuel to be injected to increase the power output from the engine. Thus, the power-to-weight ration for the engine is increased significantly with the addition of the turbocharger.



Air Intake System


1. Filtered air. 2. Turbocharger. 3. Air crossover tube
4. Intake manifold. 5. Intake valve port



Exhaust System


1. Exhaust valve port. 2. Exhaust manifold
3. Turbocharger turbine

Intake Air, Exhaust and Fuel System	A2300
Intake Restriction at Rated Speed and Load with Dirty Air Filter Element – kPa [mmAq]	6.23 [635]
Exhaust Restriction at Rated Speed and Load – kPa [mmAq]	7.65 [780]




Diagnosing Air System Malfunctions

The correct amount of clean air to the cylinders is required for good performance. As discussed earlier in System Air Flow, ingested dust and dirt will damage the engine cylinders. Dust and dirt can also damage the valve stems and guides. Larger debris can damage the blades of the turbocharger.



Air Flow Restriction Results in Excess Smoke and Low Power


Restriction increases as the filter removes contaminants from the intake air. Restricted air flow changes the air-to-fuel ratio, reducing power and increasing smoke from the engine. Verify that the air cleaner is being maintained correctly. Measurement of air intake restriction is described in this Section.




Damage From Non-Filtered Air

Loose connections or cracks in the suction side of the intake pipe can allow debris to be ingested by the engine causing rapid wear in the cylinders.

Leaks at the intake manifold, unsealed bolt holes or manifold cover gasket can also allow dust and dirt to be ingested into naturally aspirated engines.




Loose connections or cracks in the suction side of the intake pipe on turbocharged engines can allow debris to be ingested into the turbocharger compressor and forced into the engine.




Debris drawn into the air suction side can damage the compressor blades causing an imbalance resulting in a bearing failure.

To verify a bearing failure or damaged compressor, remove the intake and exhaust piping and check for contact. The rotor assembly must rotate freely. Measurement of axial and radial clearance is described in this Section.




Pressure Side Air Leaks (Turbocharged Engines)

Excess smoke and low power from a turbocharged engine can be caused by pressurized air leaking from loose connections or cracks in the crossover tube or intake manifold.



In addition to the visual inspection for cracks and loose fittings, liquid soap can be applied to the crossover tube, connections and the manifold cover sealing surfaces to find the leaks.


The leaks will create bubbles that are easier to detect. Measurement of manifold pressure is described in this Section.



Exhaust Leaks (Turbocharged Engines)


Inspect for exhaust leaks at the exhaust manifold and turbocharger, gasket leaks, or exhaust pipe restrictions.

Leaks or restrictions will cause the turbine and impeller to operate at a lower speed and reduce the amount of air being forced into the cylinders. Again, the symptom will be excess smoke, low manifold pressure and low power.




Exhaust leaks can usually be detected audibly or visually by a discoloration caused by the escaping hot gases.

Don't overlook exhaust restrictions as a cause of low power. If the exhaust gasses can not flow freely, the turbocharger will not operate efficiently.




Malfunctioning Turbocharger

Failure of the internal components of the turbocharger can reduce its effectiveness and also cause excess smoke and low power. A bearing failure can produce friction which will slow the speed of the rotor assembly. Failed bearings can also allow the blades of the rotor assembly to rub the housings, thus reducing the rotor assembly speed.




Oil Consumption and Leaks


Engine lubricating oil is used to lubricate the bearings and provide some cooling for the turbocharger. The oil is supplied to the turbocharger through the supply line is at engine operating pressure. A return line connected to the bottom of the turbocharger routes the oil back to the engine oil pan.




Seals are used on each end of the rotor assembly. The primary function of the seals is to prevent exhaust gases and compressed air from entering the turbocharger housing. Oil leakage from the seals is rare, but it can occur.




A restricted or damaged oil return line will cause the turbocharger housing to be pressurized causing oil to migrate by the seals.



Additionally, high intake or exhaust restrictions can cause a vacuum between the compressor and the turbocharger housing resulting in oil leaking by the seals.




To verify oil leakage past the seals, remove the exhaust pipe and crossover tube and look for oil in the turbine casing and the crossover tube. Locate and correct the restriction as previously discussed.




Turbocharger Noise

It is normal for the turbocharger to emit a “whine” sound that varies in intensity depending on engine speed and load. The sound is caused by the very high rotational speed of the rotor assembly. Consequently, the sound will be more audible at full speed.

Note: If possible, operate the engine at full speed to verify the noise level.




Leaks in the air system, both intake and exhaust components, can produce additional noises. Check the air intake and crossover tube leaks.




Note : Before removing a turbocharger, make sure that the noise complaint is not caused by leaks in the air system components.

Look for loose turbocharger mounting, exhaust manifold gasket leaks, and cracks in the exhaust manifold.




Lower pitch sounds or rattles at slower engine speeds can indicate debris in the system or the rotor assembly is touching the housings.



Rotor Assembly Clearance – Measure

Measure the shaft end play.

mm	End Play (a)	Inch
0.03	MIN	0.001
0.06	MAX	0.0024




Measure radial clearance of the shaft.

mm	Radial Clearance (B)	Inch
0.08	MIN	0.003
0.13	MAX	0.005



The turbocharger should be removed for replacement or rebuild if the clearances are beyond these limits.




Air System Replacement Procedures



Air Crossover Tube – Replacement

7mm

Loosen the hose clamps and position the hose so the crossover tube can be removed.



Use a new gasket and new hoses and clamps as required to install the air crossover tube.

Torque Value:


- **Hose Clamps: 39 Nm [29 ft-lbs]**



Intake Manifold Cover and Gasket – Replacement

Preparatory Steps:

- Remove the high pressure fuel lines.
- Disconnect the cold starting aid.
- Remove the air crossover tube.



12mm


Remove the manifold cover and complete the following steps.



Caution : Keep the gasket material and any other material out of the air intake.



Clean the sealing surface.




12mm


Install the gasket and cover.

Torque Value : 25.5Nm [19 ft-lbs]





Assemble the intake piping and connect the cold starting aid.




Install and bleed the high pressure fuel lines.

Turbocharger – Replacement


Preparatory Steps:

- Remove the air crossover tube.
- Disconnect the intake and exhaust piping.




10mm

Remove the oil drain tube capscrews and complete the following steps.



14mm


Remove the oil supply line.



12mm
Remove the turbocharger.




Caution : If the turbocharger is not to be installed immediately, cover the opening to prevent material from falling into the manifold.



Clean and inspect the sealing surface.




Install a new gasket and apply antiseize compound to the mounting studs.



7mm

Install the turbocharger and connect the air crossover tube.


Torque Value : 39Nm [29 ft-lbs]



12mm

Use a new gasket and connect drain line.

Torque Value : 25.5Nm [19 ft-lbs]




Caution : New turbochargers must be prelubricated before start up.



Pour 30 to 40cc of oil into supply fitting.

Note : Rotate the turbine wheel to allow oil to enter the turbocharger.



14mm

Install the oil supply line.


After installing the air intake and exhaust piping, operate the engine to check for leaks.



Exhaust Manifold and/or Gasket - Replacement

Preparatory Steps:

- Remove the air crossover tube.
- Disconnect the air intake and exhaust piping.
- Remove the turbocharger and gasket.




12mm

Remove the manifold and gasket.



Clean the sealing surface.




12mm

Install the manifold and gaskets.

Torque Value : 25.5Nm [19 ft-lbs]

Follow the sequence shown in the illustration.


Install the turbocharger, air crossover tube, oil drain tube, oil supply line, and the exhaust and intake piping. Operate the engine to check for leaks.



Intake Air Restriction

Replace the air cleaner element when the restriction reaches the maximum limit at rated engine RPM.


Naturally Aspirated	Turbocharged
6.23 kPa [635 mmAq]	6.23 kPa [635 mmAq]



Measure the restriction just before the turbocharger. Measure just before the intake manifold for naturally aspirated engines.

Lubricating System

Lubricating System Flow




-
1. Oil strainer. 2. Oil pump. 3. Oil cooler (Option).
4. Regulator valve. 5. Oil filter. 6. Safety valve.
7. Crankshaft. 8. Camshaft. 9. Piston.
10. Intake and exhaust valve. 11. Rocker arm
12. Timing gear. 13. Cooling water. 14. Turbocharger

Lubricating Oil Pump

The engine use trochoid type oil pumps (1). The machined cavity in the block is the same for all engines.

Pressure Regulating Valve

The pressure regulating valve (2) is designed to keep the oil pressure from exceeding 343 kPa [50 PSI]. When the oil pressure from the pump is greater than 343 kPa [50 PSI], the valve opens uncovering the dump port so part of the oil is routed to the oil pan. Because of manufacturing tolerances of the components and the oil passages, the oil pressure can differ as much as 50 kPa [7.2 PSI] between engines.



Oil Coolers

The engines use full flow, plate type oil coolers. The oil flows through a cast passage in the cooler cover and through the element where it is cooled by engine coolant flowing past the plates of the element.

The use of incorrect components can cause high or low oil temperature, varnish and sludge build up.

Oil Filters

After the oil is cooled, it flows through the full flow oil filter.

Oil Filter Bypass Valve


The oil cooler cover contains a safety valve that will let the oil flow bypass a plugged filter. The valve is designed to open when the pressure drop across the filter is more than 138 kPa [20 PSI], as with a plugged filter, and lets the oil continue on through the engine. When a filter becomes plugged, an oil pressure decrease of 50 kPa [7.2 PSI] or less from the normal operating pressure can be observed on the vehicle oil pressure gauge.

The main bearings and the valve train are lubricated by pressurized oil directly from the main oil rifle. The other power components, connecting rods, pistons, and camshaft receive pressurized oil indirectly from the main oil rifle.

The drillings in the crankshaft supply oil to the connecting rod bearing. The oil is supplied to the camshaft journals through drillings in the main bearing saddle. Smaller drillings in the main bearing saddle supply oil to the piston cooling nozzles. The spray from the nozzles also provides lubrication for the piston pins.

The number five main bearing saddle does not contain a piston cooling nozzle. Cylinder Number One receives the lubricating and cooling spray from the nozzle located in the Number One Bearing Saddle. Cylinder Number Two receives the spray from the Number Two Bearing Saddle, etc..

Lubrication for the valve train is supplied through separate drillings in the cylinder block. The oil flows through the drillings and across the oil transfer slot in the cylinder head gasket. From the transfer slot, the oil flows around the outside diameter at the cylinder head capscrew, across a slot in the bottom of the rocker lever support, and up a vertical drilling in the support. From these drillings, oil flows through drillings in the rocker lever support. From these drillings, oil flows through drillings in the rocker lever shaft to lubricate the rocker levers. Oil flows through a drilling in the rocker levers to fill a channel cast into the top of the levers. The oil from the channel lubricates the valve stems, push rods and tappets.




Diagnosing Lubricating System Malfunctions

Be sure to check items related to oil pressure, such as: gauges, high and low oil level, excessive oil contamination, oil viscosity, etc.


High Oil Pressure

High oil pressure usually occurs after the engine is first started in cold weather. The lubrication system does not have a cold start relief valve. The pressure regulating valve components are machined to a size that will relieve the excessive pressure created by cold engine oil.




Oil Pressure Regulating Valve

The engine will have high oil pressure if the regulator sticks in the closed position. Check the regulator for freedom of movement.




Low Oil Pressure

Low oil pressure can be caused by several lubrication system related malfunctions. To begin the investigation, determine the engine operating conditions when the low pressure was first observed.




Oil Level

Low oil level can cause low oil pressure. Caution: Never operate the engine with the oil level below the low (L) mark.




Oil Filter

A plugged filter will cause a gradual loss of pressure by approximately 69 kPa [10 PSI]. The pressure will return to normal when the filter bypass valve opens.




Oil Gauge

Check the oil gauge and sending unit to make sure they are operating correctly by verifying the pressure with a manual gauge.



Oil Suction Tube

A loose suction tube, damaged gasket or crack in the suction tube can cause a temporary loss of prime for oil pump. The engine will have low pressure or no oil pressure at starting followed by normal oil pressure.




Bearings and Oil Pump

A steady decrease in oil pressure over a long period of time can be an indication of worn bearings or excessive oil pump wear.

Incorrect Oil Pump

If low or high pressure occurs after changing the pump, verify that the correct pump was used.



Oil Dilution


Caution: Diluted oil can cause severe engine damage.

Check the condition of the oil

- Thin, black oil is an indication of fuel in the oil.
- Milky discoloration is an indication of coolant in the oil.

Coolant in the oil can be caused by


- Cup plugs leaking.
- Damaged cylinder head gasket.
- Oil cooler element leaking.



Coolant Diluted Oil


Coolant leaking from the oil cup plugs in the cylinder block water jacket will dilute the oil.

To check for leaks, remove the tappet cover and pressurize the cooling system.



Coolant in the oil can also be caused by a damaged cylinder head gasket.

Pressurize the cooling system to check for leaks. It may be necessary to remove the oil pan to locate internal leaks.



During operation the oil pressure will be higher than coolant pressure. A leak in the oil cooler will show as oil in the coolant.



However, following an engine shutdown, the residual pressure in the coolant system can cause coolant to seep through the leak path into the oil.

Fuel Diluted Oil


Fuel dilution is limited to four sources:

1. Injection pump shaft seal
2. Fuel leaking by the rings
3. A crack in the cylinder head from the fuel filter location to the air intake.

Use the following logic to determine the source of the oil dilution with fuel:




A worn or damaged injection pump shaft seal will allow fuel to leak into the gear housing and then into the oil pan.




The seal is designed to provide increased sealing as the pump case pressure increases. Pressure forces the lip (1) tighter around the shaft. A worn seal is more apt to leak during start up and shut down when case pressure is low.


Caution : A worn seal can not be detected pressurizing the pump.




The bushing (2) in the Bosch VE pump can cause a seal leak. If the bushing is loose in the housing it will move toward the seal raising the lip (1) and providing a leak path for fuel.




To check for such a leak remove the fuel drain manifold connection (1) at the pump and install a plug (2).




Remove the access cover and rotate the engine so one of the holes in the fuel pump gear exposes the back gear housing.




Activate the fuel shut down valve by turning the switch to the ON position.




Incomplete combustion in the cylinders can result in unburned fuel draining into the oil pan. This condition can be caused by a leaking injector or reduced compression caused by inadequate piston ring sealing.




An increase in white exhaust smoke during the first start of the day is a symptom that an injector is leaking. An injector leak will also cause the engine to run rough and have low power. Remove and replace leaking injectors



Perform a compression check to verify piston ring sealing




Another remote possibility is a crack or porosity in the head casting could allow fuel to leak to the air intake and on to the cylinders.




Oil Leaks


Various gaskets, seals and plugs are used to contain the oil. Most leaks can be identified during routine inspection of the engine and vehicle.




If the oil cooler element ruptures, the oil pressure will force oil into the coolant system. Oil in the coolant should be visible when the radiator cap is removed.



Worn or damaged seal in the turbocharger can also allow oil to leak into the air crossover pipe and be burned in the engine. The condition can be verified by removing the air crossover tube and looking for oil.



Inadequate sealing of the piston rings will result in oil being blown out the breather tube and/or consumed by the engine



Lubricating System Replacement Procedures

Oil Pressure Regulator Valve and/or Spring Replacement



24mm

Remove the plug and valve.



Clean and inspect the plunger, bore and seat before assembly.



Note : The plunger must move freely in the valve bore.




Assemble the valve in the reverse order of disassembly.
Torque Value : 69Nm [51 ft-lbs]




Oil Cooler Element and/or Gasket – Replacement

Preparatory Step : Drain the coolant.




Fill the coolant system and operate the engine to check for leaks.
Stop the engine and check the coolant and oil level.



Oil Pan, Suction Tube and/or Gaskets – Replacement

17mm

Drain the oil and remove the pan and gasket.



12mm



Caution : Be sure to connect the support bracket.




If required, remove the suction tube and gasket.

Clean the sealing surfaces.

Install the suction tube and gasket.


Torque Value: 25.5Nm [19 ft-lbs]



Caution : Be sure to fill the joints between the pan rail, gear housing and rear cover. Use Three Bond 1207-C.




Clean the pan sealing surfaces.



12mm

Install the pan and gasket.


Torque Value: 25.5Nm [19 ft-lbs]



17mm

Install the drain plug.

Torque Value: 78 Nm [59 ft-lbs]



Fill the engine with oil. Run the engine and check for leaks.


Stop the engine and check the oil level with the dipstick.

Oil Pump – Replacement

Preparatory Step:


- Remove the drive belt.

Note : Removal is easier if the crankshaft pulley is loosened before removing the belt.




19mm

Remove the crankshaft pulley.



12mm

Remove the front cover.




Remove the Lubricating Oil Pump

5mm Hex Lench

Remove the four mounting capscrews.


Remove the pump from the bore in the cylinder block.



Clean and Inspect

If the pump is to be inspected for reuse, follow these steps.


Visually inspect the lube pump gears for chips, cracks, or excessive wear.



Installing the Lubricating Oil Pump

Lubricate the pump with clean engine oil.

Note : Filling the pump with oil during installation will help to prime the pump at engine start up.




12mm

Install a new gasket.

Tighten in the sequence shown.

Torque Value : 25.5Nm [19 ft-lbs]



Note : Be sure the gear backlash is correct if installing a new pump.

Measure gear backlash.

Backlash Limits

A
0.11 to 0.19mm [0.0043 to 0.0075 inch]

Note : If the adjusting gear moves when you measure the backlash, the reading will be incorrect.



Gear Cover – Installation

Lubricate the front gear train with clean engine oil.



Caution : The seal lip and the sealing surface on the crankshaft must be free from all oil residue to prevent seal leaks.

Thoroughly clean the front seal area of the crankshaft.



12mm

Install the front cover and gasket.

Note : Install the capscrews but do not tighten at this time.

Torque Value : 25.5 Nm [19 ft-lb]




19mm

Install the crankshaft pulley




19mm

Torque Value : 113Nm [98 ft-lbs]



Cup Plugs – Replacement

Remove the cup plugs from the oil passages.




To Install the Cup Plugs

Apply a bead of Loctite 277 around the outside diameter of the oil passage cup plugs.



Drive the cup plugs in until they bottom in the bore.



Fill the engine with oil. Run the engine and check for leaks.
Stop the engine and check the oil level with the dipstick.

Electrical System

Electrical System Description/Operation


The electrical system basically consists of the starting motor and the alternator.

The injection pump uses an electrical fuel shut off valve. The function of the valve was discussed in the fuel system section.


The engine should have temperature and oil pressure sensors connected to indicators or wired for automatic shutdown.

The engine may also be fitted with a block heater or an oil pan heater.

Densko Poongsung 12V 2.0kw Starting Motor




Basic Wiring Circuit




Basic Solenoid Circuit

Injection Pump Fuel Shut Off Valve




Oil Pressure Switch and Temperature Sensors



Electrical System Spec.


- Minimum Recommended Battery : 12 V –75A
- Starter Motor: 12V – 2.0kW
- Alternator: 12V – 45A



Diagnosing Electrical Malfunctions Starting Motor




Before you troubleshoot the starting motor, make sure the battery terminals are not loose or corroded.




Engine Does Not Crank

If the solenoid does not make an audible sound, check for loose wiring connections.




Check the voltage at the solenoid battery post.

- No voltage – Check the condition of the battery. Check the connections at the battery, engine and solenoid.




- 12 volts at the solenoid battery post – check the voltage at the S (switch) terminal on the solenoid. The ignition switch must be in the start position.


The solenoid is at fault if the check indicates 12 volts at the S terminal.



- If no voltage is indicated at the S terminal, check:
- Fuses
- Voltages to the ignition switch
- And, if the vehicle is so equipped, voltage to clutch switch, neutral safety switch and engine safety shutoff system.




If the solenoid does make an audible sound, turn the switch off and attempt to bar the engine in both directions.



Bar the engine as follows:

1. Direction of engine rotation.
2. Direction of opposite engine rotations.
3. Direction of engine rotation.

If the engine will bar at Step 3, attempt to start the engine. If the starter cranks the engine, check the starter pinion gear and flywheel ring gear for damage.




If the engine bars and the starting motor does not crank, check the voltage between the solenoid and starting motor. The ignition switch must be in the start position.

No Voltage: Starter is at fault

Normal Voltage: The solenoid is at fault.


When troubleshooting a 24 volt system, the value is 24 volts.




Engine Cranking Speed Too Slow

Make sure the wiring connections are clean, tight and not damaged.

Check the battery voltages.




If the engine was not rotated to check the starting motor (page 7-8), bar the engine in the direction of engine rotation to make sure the engine is free and does not have an internal malfunction.



If the engine is free, check the voltage at the starter during cranking. If the voltage drops more than 2.4 volts, check that all connections are tight. The limit for 24 volt systems is 4.8 volts.


If the cable correct and the voltage drop exceeds the limit, replace the starter.




If the engine requires more than a normal effort to bar, check for excessive load from the driven units and accessories.

Alternator

The terminals on the alternator are shown in this illustration. The "R" terminal provides one-half system voltage and is used to operate accessories such as the tachometer on generator sets.




Trouble with the charging system may be indicated by the indicator lamp or ammeter.



Abnormal Indicator Lamp Operation


Check the indicator lamp for normal operation as shown below.

Engine	Switch	Lamp	Ammeter
Stopped	Off	Off	0
Stopped	On	On	-
Running	On	On	+




Switch Off, Lamp On, Engine Stopped

Disconnect the lamp lead at the ignition switch. If the lamp stays on, there is a short to a positive wire on the ignition side of the lamp.




If the lamp goes out, there is a short in the switch.




Switch On, Lamp Off, Engine Stopped

The condition can be caused by an open in the circuit. To determine where an open exists. Check for a blown fuse, a burned out bulb, defective bulb socket, or an open in No. 1 lead circuit between alternator and ignition switch.




Switch On, Lamp On, Engine Running


Check the drive belt and alternator pulley to be sure the alternator is rotating.



Disconnect the lead to Terminals No. 1 and No. 2. If the lamp stays on, there is a short to ground on the alternator side of the lamp.



If the lamp goes out, replace the alternator.




Abnormal Charging System Operation

Check the battery and all wiring connections.

Inspect the wiring for defects.

Check all connections for tightness and cleanliness, including the slip connectors at the alternator and firewall, and connections at the battery.




With ignition switch on and all wiring harness leads connected, connect a voltmeter from:

- Alternator "BAT" terminal to ground
- Alternator No. 1 terminal to ground
- Alternator No. 2 terminal to ground

A zero reading indicates an open between the voltmeter connection and the battery.


Locate and repair the open circuit.



With all accessories turned off, connect a voltmeter across the battery.

Operate engine at moderate speed.


If voltage is 15.5 or more, remove the alternator for repair. The limit for 24 volt system is 25 volts.



Fuel Shutoff Valve – Check


Note : Check all connections for loose or corroded connections for broken wires.

Remove the valve. Ground the valve and connect 12 volts DC to the terminal and observe plunger movement.



Oil Pressure Switch and Temperature Sensor

When diagnosing problems with either the pressure switch or the temperature sensor, check for loose or corroded connections and for broken wires.




Oil Pressure Switch - Check

Remove the pressure switch, install a gauge, start the engine and measure oil pressure. Minimum oil pressure:

Idle	147 kPa [21PSI]
Full Speed	294 kPa [42 PSI]

Note : The pressure switch is set to actuate when oil pressure drops to 98 kPa [14 PSI].



Temperature Sensor – Check

Check for continuity.

Voltage : DC 12 V


Temperature	54.4 °C	110 °C
Resistance	560~716Ω	72.1~81.8Ω

Engine Electrical System Replacement Procedures

Starting Motor - Replacement

Preparatory Steps:

- Disconnect the ground cable from the battery terminal.
- Identify each electrical wire with a tag indicating location.



12mm

Remove the battery cable from the solenoid.



17mm

Remove the starting motor.


Install the starting motor in the reverse order of removal.

Torque Value : 78Nm [59 ft-lbs]

Alternator - Replacement


Preparatory Steps:

- Disconnect the ground cable from the battery terminal.
- Remove the drive belt from the alternator pulley.



12mm

Remove the alternator bolts.



14mm

Remove the alternator mounting nuts.




12mm, 14mm

Install the alternator by tightening the 12mm bolts before the 14mm bolts. Reconnect all wires.



**Torque Value : (12mm) 25.5Nm [19 ft-lbs]
(14mm) 49Nm [37 ft-lbs]**






Electric Fuel Shut Off Valve - Replacement

8mm

Remove the electrical wire(s) and complete the following steps.



24mm

Caution : When removing the valve, be careful not to drop the piston and spring.



Clean around the valve.


Replace the valve and connect the electrical wire.



Oil Pressure Switch – Replacement

Disconnect the wire from the sending unit.

Note : The sending units illustrated may differ from those installed by the equipment manufacturer.




Reconnect the wire to the sending unit.



Torque Value :
(Installed into Cast Iron)
16Nm [12 ft-lbs]

Temperature Sensor – Replacement

Preparatory Step:
Drain coolant



Disconnect the temperature sensor wiring.



17mm
Remove the temperature sensor.



17mm
Apply liquid Teflon sealant to the threads when installing the temperature sensor.
Reconnect the wiring.



Torque Value:
(Installed into Aluminum)
39Nm [29 ft-lbs]



Base Engine Components


Operation and Description

This section of the manual defines the base engine components, describes the operation of those components, provides guidelines for diagnosing malfunctions and gives procedures for component replacement and in-chassis overhaul.

Definition

For the purpose of this manual, Base Engine Components are defined as mechanical functions not included in the other major engine systems. The components include:


- Valve Train and Cylinder Gear Head
- Front Gear Housing and Gear Train
- Camshaft, Tappets and Push Rods
- Piston and Connecting Rod Assemblies
- Crankshaft and Main Bearings
- Cylinder Block



Cylinder Head and Valve Train


The cylinder head is a one piece, crossflow design with two valves per cylinder.

The head has integrally steel alloy valve guides and hardened valve seat surfaces which can be repaired in a machine shop using the appropriate service parts.




The cylinder head has a cast intake manifold, fuel filter head, thermostat housing and an internal water bypass.


The injectors are mounted in the head for direct injection into the cylinders.



Separate pedestals for each cylinder are used to support and route oil to the rocker levers.



The cylinder head gasket is a laminated design with print o-seal on both sides around the water holes. A fire ring in the gasket seals the cylinder bores. As discussed in the Cooling System, the gasket also provides orifices to control coolant flow.





Front Gear Housing and Gear Train

The gear train consists of the crankshaft gear, lube pump gear idler, the camshaft gear, the fuel pump gear and the accessory drive gear, if used.




The gear housing provides a support for the injection pump, and the accessory drive gear, if used.




Front Crankshaft Seal

The front crankshaft seal is mounted in the front gear cover. A double lipped Teflon seal is used. The sealing surface on the gearcase must be clean and free of oil during assembly.




Camshaft, Tappets and Push Rods


The camshaft is gear driven from the crankshaft. A replaceable bushing is used for the front journal to carry the side loading from the accessory drive. The remainder of the journals operate in cast iron bores in the cylinder block.




The camshaft has lobes to operate the intake and exhaust valves.
The valve lobes contact “mushroom” shaped valve tappets which operate the push rods.
The profile of the cam lobes is the same for all A series engines.



The tappets are mushroom shaped. The convex shape of the surface which contacts the camshaft lobe causes the tappet to rotate as it lifts the push rod.




The ball end of the push rod fits into a ball socket in the tappet.
The other end of the push rod is fitted with a socket into which the ball end of the rocker lever adjusting screw operates.




Flywheel Housing and Flywheel

Several Optional flywheel housing and flywheels are used depending on the application.




Piston and Rod Assemblies


Piston features include : high swirl combustion bowl
cast aluminum body and 3 ring grooves.
Always check the part number to be sure the correct
configuration is used during piston replacement.



The piston ring sets are also different. While both sets
consist of three rings; two compression rings and one
oil ring.




A free floating, hollow piston pin is used to attach the
piston to the connecting rod.
Lubrication of the pin and journal is accomplished by
residual spray from piston cooling.



The connecting rod is made of high-strength forged carbon-steel.

The large end with the special aluminum-ally metal can be separated into two and the small end has a copper alloy coil bushing.

Oversize service rod bearings are available for use with re-ground crankshafts.




Crankshaft and Main Bearings

The crankshaft is a balanced, forged steel unit. Four cylinder engines have a main bearing.

The lower bearing shells are all the same.

All of the upper bearing shells are all the same.

The two thrust bearings control the end thrust of the crankshaft.



The upper bearings have two holes in them. The one side hole receives oil from the main oil rifle.


One of the adjacent holes is aligned with drilling to the camshaft journal and serves as an orifice for lubrication flow to the journal and is used for piston cooling.

The hole does not align perfectly with the cooling nozzle. The hole is off-set to keep it away from the highly loaded bearing area.

Note : Oversize service main bearings are available for reground crankshafts.

Cylinder Block


We have discussed the cylinder block relative to cooling and lubrication in those respective systems. We have also discussed the interfaces of some of the above power functions with the block. This discussion will cover the remaining interfaces including the cylinder bores.



The cylinder bores are machined directly into the block during production.
The size and condition of the bore is critical to engine performance and life.
During repair, be sure to inspect the bore carefully.


Cylinder liner can be replaced into cylinder block. Both cylinder and liner have size mark on.
The block and liner marks are identified as follows:

	Mark
Cylinder block	L
	M
	S
Cylinder Liner	L
	M
	S




Oil Pan

A front sump, rear sump or center sump pan options may be used depending on the application. The mounting of the oil pick up tube will vary with the pan used.



Rear Crankshaft Seal


The rear crankshaft seal is mounted in a housing that bolts to the rear of the block. Double lipped Teflon seals are used. The sealing surface on the crankshaft must be cleaned and free of oil during installation of the seal.



Diagnosing Base Engine Component Malfunctions

Valve Train and Head Assembly

The sound emitted from the overhead can indicate a valve train problem. Loose rocker levers will chatter. A squeaking noise can mean lack of lubrication for adjusting screw and the push rod socket.




Caution : If the end of the individual support pedestals is removed during inspection or repair, all head bolts must be retightened according to the head bolt torque sequence.




Air and Fuel System – Check


When diagnosing a low power problem first troubleshoot the air and fuel systems to make sure the engine is receiving adequate intake air and fuel.



Check the intake air system for leaks. Make sure a sealant is used on the through-hole capscrews with secure manifold cover to the head. Verify the turbocharger is operating correctly.




Check the fuel system for correct timing and fuel delivery.



Valve Adjustment – Check

Verify that the valves are adjusted correctly.






Compression Check

If the air and fuel system are functioning correctly, perform a compression check to determine whether the problem is:


- Piston ring sealing
- Valve sealing
- Head gasket sealing or a crack in the cylinder head



Piston Ring Seal


If the compression is low but can be increased significantly by squirting oil into the cylinder, the cause of low compression is inadequate sealing between the rings and the cylinder walls.

Normal compression is 3430 kPa [497 PSI] at 250 RPM cranking speed. A 26 kPa [383 PSI] difference between cylinders indicates a compression seal problem.




Valve Sealing

If the compression is low on one or more non-adjacent cylinders and the pressure cannot be increased by oiling the rings, poor valve sealing is to be suspected.




Valve leakage is often audible from the intake and exhaust manifold.




Head Gasket Sealing


If the compression was found low on adjacent cylinders and the pressure cannot be increased by oiling the rings, the head gasket is probably leaking between the cylinders.




Low compression on a single cylinder can be caused by an external leak or a leak to a coolant passage.



A compression leak to the coolant will normally be detected by loss of coolant as the coolant is blown from the cooling system.




External head gasket leaks can be detected visually. Liquid soap can be used to locate external leaks.




Valve Seal – Wear

Worn valve seals are typically detected by excessive smoke at idle or when the engine is unloaded when the vehicle is going down hill. Verify the condition by removing the valve spring and inspecting the seals.




Hardening of the material and wear or damage to the sealing surface will cause the seal to leak (refer to page 219 for replacement instructions).




Front Gear Housing and Gear Train

Troubleshooting the front gear housing and gear train consists of checking for leaks at the gaskets (front cover, and injection pump) and the front crankshaft oil seal, inspecting the gears and measuring backlash when required.




Gear noise emitted from the cover can indicate worn gear teeth.

Note : Excessive backlash can affect engine timing and engine performance.




Rocker Lever, Valve Stem, Push Rod, Tappet, and Camshaft

Excessive valve lash can indicate a worn valve stem or rocker lever.




Loose rocker levers and the need to re-set the valve clearance frequently, can also indicate cam lobe or tappet wear. If an inspection of the levers, valve stems and push rods does not show wear, then tappet and/or cam lobe wear can be suspected.




Caution : Anytime a new camshaft is installed, new tappets must also be installed.



The camshaft lobes can be visually inspected after removing the pan. Similarly, the face of the tappet can be inspected after removing the push rods and lifting the tappet.




A several damaged camshaft journal (s) can generate metal chips which will be found in the pan and filter. As the clearance in the journal (s) increases, a small decrease in oil pressure may be detected.




Piston and Rod Assembly

There are a number of power relate problems including excessive oil consumption, smoke, blow-by and poor performance that can be caused by inadequate sealing between the piston rings and the cylinder walls.

A blow-by measurement can help detect the problem.




Verification of the damaged or worn component requires visual/dimensional inspection of rings, pistons and cylinder bore.




The cause of piston ring wear can range from wear over a long period of service to a dust-out in a short period of time because of poor maintenance of the air intake system.


Refer to Section 5 for troubleshooting the Air System.




During repair it is essential that the cylinder wall be deglazed so that new rings will seat against the cylinder wall. The marks on cylinder block and cylinder liner must be matched. The different marks are matched, excessive blow by gas and excessive oil consumption occur.




However, it is also critical that the cylinder liner walls be thoroughly cleaned. Grit left in the cylinder wall will cause rapid wear out of the new rings leading to the previously discussed power problems.




Overheating of the engine from a loss of coolant will cause the cylinder to overheat resulting in seizure of the piston. Loss of piston cooling can also lead to piston seizure.




Improper maintenance of the lubrication system is the primary cause of reduced main bearing life.



Normally, worn bearings can be detected by reduced oil pressure. But if this wear goes undetected, the excessive clearance will cause the rod to strike the crankshaft causing a distinct knocking sound.




A rod knock occurs when the engine is not loaded. Verify by first applying load and then unloading and listening for the knock.




Crankshaft and Main Bearings


Improper maintenance of the lubrication system is also the primary cause of reduced main bearing life. A malfunction of the crankshaft/main bearing will usually be detected by reduced oil pressure. As with rod bearings, continued operation with low oil pressure will lead to a rapid deterioration of the bearings and eventually will produce a knocking sound.




A main bearing will be heard when the engine is loaded.



A damaged or worn thrust bearing flange of the upper main bearing shell can be detected by measuring the end play of the crankshaft .



Failure of driven units at the front or rear of the engine which increase the end loading can damage the thrust bearing.




Cylinder Block

Diagnosis of cylinder block malfunctions relative to cooling and lubrication has been discussed in those respective systems.

The potential problems with cylinder, the camshaft bore and the crankshaft main journals have also been discussed in this Section.




Malfunctions of the block such as leaks. Require a visual or dimensional inspection to isolate the problem.




Flywheel Housing and Flywheel

Diagnostics of the flywheel housing and flywheel is normally limited to a visual inspection of the parts for damage or wear.




Occasional failure of a starter to engage can be caused by damaged teeth on the ring gear. Service ring gears are available for repairing flywheels.



When troubleshooting a transmission vibration problem, it may be necessary to measure the concentricity of flywheel housing-to-crankshaft.

Note : The following procedure is for use with an indicator whose needle rotates clockwise as the top is depressed.




Base Engine Components Specifications




Valve Train

Valve Clearance


- - Intake 0.3mm [0.012 in]
- - Exhaust 0.3mm [0.012 in]




- Valve Guide Diameter
8.025 mm [0.316 in] MAX
8.010 mm [0.3153 in] MIN



- Valve Stem Diameter
7.97 mm [0.3138 in] MAX
7.96 mm [0.3134 in] MIN



- Valve Seat Angle
Intake 30 degrees
Exhaust 45 degrees
- Valve Depth (Installed)
0.6 to 0.8 mm [0.0236 to 0.0315 in]
Wear Limit: 1.0 mm [0.0394 in]




- Cylinder Head Flatness
Total
Maximum Overall
0.15 mm [0.006 in]




Gear Train

- Gear Backlash
Crankshaft, Injection pump drive, camshaft:
0.07 to 0.15mm [0,0027 to 0.006 in]
Oil pump:
0.11 to 0.119mm [0,0043 to 0.0075 in]




Camshaft

- Journal Diameter
44.964 to 44.95 mm [1.7702 to 1.7697 in]
Worn Limit: 44.89 mm [1.767 in]
- Valve Lobes
Standard: 37.935 to 38.065 mm
[1.4935 to 1.4986 in]
Worn Limit: 37.83 mm [1.4893 in]




Tappets

- Stem Diameter
Standard: 14.238 to 14.210 mm
[0.5606 to 0.5598 in]
Worn Limit: 14.18 mm [0.5583 in]




Pistons

- Skirt Diameter (Minimum)
Nominal
87.95 to 87.97 mm
[3.463 to 3.4634 in]
Worn Limit
87.90 mm [3.46 in]




- Pin Bore Diameter (Maximum)
30.008 mm [1.181 in]
Worn Limit: 30.02 mm [1.1819 in]


Note : Measure the diameter on a vertical axis only.



- Ring Groove (Minimum)
Top Groove
2.006 mm [0.079 in]
Oil Control Groove
3.002 mm [0.118 in]




- Piston Pin Diameter (Minimum)
30 mm [1.181 in]
Worn Limit: 29.9 mm [1.177 in]




Connecting Rod

- Pin Bore Diameter
MAX: 30.038 mm [1.1823 in]
Worn Limit: 30.1 mm [1.185 in]



Crankshaft


- Main Bearing Journal Diameter
Standard: 53.964 to 53.95 mm
[2.2146 to 2.1240 in]
Worn Limit: 53.91 mm [2.122 in]
- Connecting Rod Journal
Standard: 49.964 to 49.95 mm
[1.967 to 1.966 in]
Worn Limit: 49.91 mm [1.965 in]




Cylinder Block

- Top Surface Flatness
(Maximum Overall Variation)
Standard: 0.03 mm [0.00118 in]
Worn Limit: 0.15 mm [0.0059 in]






- Main Bearing Bore Diameter
Standard: 50.0 to 50.045 mm
[1.9685 to 1.97 in]



- Camshaft Bore Diameter (Maximum)
Standard: 45.03 to 45.06 mm
[1.773 to 1.774 in]



- Tappet Bore Diameter
Standard: 14.26 to 14.28 mm
[0.561 to 0.562 in]



Cylinder Bore

- Cylinder Bore Diameter
Standard: 88.0 to 88.02 mm
[3.464 to 3.465 in]
- Out of Round
0.34mm [0.0012 in]



Base Engine Components Replacement Procedures

Rocker Lever and Push Rods – Replacement



Preparatory Step:

17mm



- Remove the valve covers.



Removal


12mm

Loosen the adjusting screw locknuts. Loosen the adjusting screws until they stop.



19mm

Remove the 19mm nuts from the rocker lever pedestals. Remove the pedestals. Remove the pedestals and rocker lever assemblies.



Remove the push rods.



Rocker Levers – Disassembly


If the rocker lever and push rods are to be inspected for reuse, follow these steps.
Remove the retaining rings and thrust washers.




Remove the rocker levers.




Caution : Do not disassemble the rocker lever shaft and pedestal. The pedestal and shaft must be replaced as an assembly.



Remove the lock nut and adjusting screw.




Clean all parts in a strong solution of laundry detergent in hot water.




Use compressed air to dry the parts after rinsing in clean hot water.

Note : The pedestals are made from powdered metal and will continue to show wetness after they have been cleaned and dried.



Inspect for cracks and excessive wear in the bore and the contact surface for the valve stem.



Measure the rocker lever bore.

Standard: 19.0 to 19.021 mm

[0.748 to 0.749 in]

Worn Limit: 19.09 mm [0.751 in]




Inspect the pedestal and shaft.

Measure the shaft diameter.

Standard: 19.0 to 19.021 mm

[0.748 to 0.749 in]

Worn Limit: 19.09 mm [0.751 in]



Rocker Levers – Assembly

Install the adjusting screw and lock nut.




Lubricate the shaft with engine oil.




Position the levers on the rocker shaft.




Install the snap rings.



Clean the push rods in hot soapy water.



Inspect the push rod ball and socket for signs of scoring. Check for cracks where the ball and the socket are pressed into the tube.



Check the push rods for roundness and straightness.



Install the push rods into the sockets of the valve tappets. Lubricate the push rod sockets with clean engine oil.



Caution : Make sure the rocker lever adjusting screws are completely backed out.



Rocker Lever Assembly – Installation

Use clean engine oil to lubricate the threads and under the heads of the 19mm nuts.
Install the nuts into the pedestals.



Valve Clearance – Adjustment

Caution : Adjust the valves when the engine is cold – below 60 °C [140°F].



Four-Cylinder Engine


Step A

12mm


Adjust the clearance for the valves shown in the illustration.

Clearance: 0.3 mm [0.012 in]

Tighten the locknut and check the clearance.




Note : Adjust intake and exhaust clearances in the following firing order by rotating the crankshaft 180 degrees in the normal direction:
(1->2->3->4)



Adjust the valve clearances for intake valves No. 1 and No. 2.




Adjust the valve clearances for exhaust valves No. 1 and No. 3.



Rotate the crankshaft in the normal direction one revolution.

Adjust the valve clearances for intake valves No. 3 and No. 4.

Adjust the valve clearances for exhaust valves No. 2 and No. 4.



Tighten the locknut to secure the adjustment screw.


Locknut Torque Value

N.m		Ft-lb
23	MIN	17
29	MAX	21


Camshaft and Tappet – Replacement

Preparatory Steps:

- Remove the valve covers
- Remove the push rods
- Remove the drive belt
- Remove the crankshaft pulley
- Remove the gear cover
- Remove the oil pan
- Remove the oil pan flange




Rotate the engine to align the crankshaft to camshaft timing marks.




12mm

Remove the capscrews from the thrust plate.




Remove the camshaft and thrust plate.




Camshaft Inspection

Inspect the lift pump lobe, valve lobes and bearing journals for wear, cracking, pitting and other damage.



Inspect the gear teeth for wear and damage. Look for cracks at the root of the teeth.




Measure the bearing journals and valve lobes.

Journal Diameter:

Standard: 44.964 to 44.95 mm [1.7702 to 1.7697 in]

Worn Limit: 44.89 mm [1.767 in]



Camshaft Bushing Inspection

Caution : If the bushing is worn beyond the limit, install a new service bushing.




Inspect the camshaft bore for damage or excessive wear.



The limit for the bushing in the No. 1 bore is the same as for the other bores without bushings.


Standard: 37.935 to 38.065 mm [1.4935 to 1.4986 in]

Worn Limit: 37.83 mm [1.4893 in]



Note : If the bores without a bushing are worn beyond the limit, the engine must be removed for machining and installation of service bushings or replacement of the cylinder block.


Remove the bushing from the Number 1 bore.




Note : Mark the cylinder block so you can align the oil hole in the cylinder block with the oil hole in the bushing.



Install the bushing so that it is even with the front face of the cylinder block.



Measure the installed bushing.
Inside Diameter:
Standard: 45.03 to 45.06 mm [1.773 to 1.774 in]




Tappet Inspection

Inspect the socket, stem and face for excessive wear, cracks and other damage.

Limit


(A)	- Normal wear
(B) and (C)	- Abnormal wear – Do not reuse



Tappet stem specifications


Inside Diameter:

Standard: 14.228 to 14.243 mm [0.5601 to 0.5607 in]




Camshaft Installation


Apply a coat of Lubriplate 105 to the camshaft bores.




Lubricate the camshaft lobes, journals and thrust washer with Lubriplate 105.



Install the camshaft/thrust washer. Align the timing marks as illustrated.




Install the thrust washer capscrews and tighten to 25.5Nm [19 ft-lbs].



Verify the camshaft has proper back lash and end play.


A = 0.07 to 0.15 mm [0.0027 to 0.0059 in]

B = 0.05 to 0.25 mm [0.002 to 0.0098 inch]



Complete the installation of the removed parts.

- Gear cover
- Vibration damper
- Rocker levers and valve cover
- Lift pump



Operate the engine at idle for 5 to 10 minutes and check for leaks and loose parts.

Gear Housing or Gasket – Replacement

Preparatory Step:

- Remove the v-pulley.
- Remove the gear driven accessory drive if the engine is so equipped.



12mm

Remove the gear housing and gasket.



Clean the gasket material from the cylinder block.



12mm

Caution : If a new housing or other than the original housing is installed, the timing pin assembly must be accurately located.



Install a new gasket and gear housing.


Torque Value: 25.5Nm [19 ft-lbs]



Flywheel Ring Gear and Rear Seal – Replacement

Preparatory Step:


- Remove the transmission



Ring Gear – Replacement

19mm


Remove the Flywheel.




Brass Drift Pin

Warning : Wear eye protection when you drive the gear from the flywheel. Do not use a steel drift pin.

Use the drift pin to drive the ring gear from the flywheel.



Heat the new ring gear for 20 minutes in an oven preheated to 127°C [260°F].



Warning : Wear protective glove when you install the heated gear.



Install the gear. The gear must be installed so the bevel on the teeth is toward the crankshaft side of the flywheel.




Flywheel – Installation

Caution : Never use the timing pin to hold the crankshaft.



Use two capscrews in the front of the crankshaft, or similar device, to hold the crankshaft when the flywheel capscrews are being tightened.



17mm Socket, Torque Wrench

Tighten the capscrews in the sequence shown.

Torque Value: 85Nm [64 ft-lbs]



In-Chassis Overhaul

The remaining procedures in this manual are organized for an in-chassis overhaul. An in-chassis overhaul includes:

- Inspecting the turbocharger
- Replacing piston rings
- Replacing connecting rod bearings
- Replacing crankshaft main bearings
- Grinding valves
- Testing injectors


This manual gives the procedures to replace the piston rings, rod bearing, main bearings and grinding the valves. The procedure to test the injectors and rebuild the turbocharger are given in the Shop Manual, Bulletin Number 3810206. Refer to pages 5-3 through 5-9 for inspecting the turbocharger. Segments of the procedures can also be used to replace individual components when required. The condition of the cylinder block and crankshaft is the limiting criteria for in-chassis overhaul. If there is reason to believe that either is severely damaged, the engine should be removed for major overhaul.

Prior to deciding on an in-chassis overhaul, inspect the air intake for evidence of ingestion of particles that could have severely damaged the cylinder walls. Check the oil and oil filter to be sure the lube system is not thoroughly contaminated with metal. Also check for rust in the coolant which can indicate build up in the passages in the cylinder block and require the block to be removed for cleaning. Also consider the condition of other components, particularly those that are more difficult to replace in-chassis; e.g. the camshaft rear sea, etc. The combination of in-chassis overhaul and time to repair those components may exceed the time required to remove the engine and perform an out of chassis overhaul.

The in-chassis overhaul procedures include prescribed checks of the hardware to determine if continued in-chassis work is practical. If the conditional limits are not met, the engine should be removed for completion of the overhaul.

Cylinder Head Removal

- Drain the coolant and oil
- Disconnect the radiator and heater hoses
- Remove the turbocharger and air crossover, if the engine is so equipped
- Remove the exhaust manifold
- Remove the fuel lines and injector nozzles
- Remove the valve covers
- Remove the rocker levers and push rods
- Remove the fuel filter




17 mm

Remove the cylinder head bolts in the sequence shown.



Remove the cylinder head and gasket from the cylinder block.

Note : Inspect the coolant passages. A large build up of rust and lime will require removal of the cylinder block for cleaning in a hot tank.



Inspect the cylinder bores for damage or excessive wear. Rotate the crankshaft so the piston is at BDC for the bores being inspected.

Measure the cylinder bores.

Limits

Diameter: Standard: 88.0 to 88.02

[3.464 to 3.465 in]

Out-of-Roundness: 0.03mm [0.0012 inch]

Refer to page 8-31 for the limits of the oversize cylinder bores.



Note : Do not proceed with in-chassis overhaul if the bores are damaged or worn beyond the above limits.



Check the top surface for damage caused by the cylinder head gasket leaking between cylinders. Check the top surface for flatness between each cylinder.




Limits

Variance: Standard: 0.03 mm [0.0012 in]


Worn Limit: 0.15 mm [0.006 in]

Note : Do not proceed with the in-chassis overhaul if the cylinder block head surface is damaged or not flat.




Main bearing Preliminary inspection


Remove the pan and suction tube.



Perform a visual inspection of the main bearings and crankshaft journals. Remove the No. 2 and 3 caps and check the journals for signs of overheating, deep scratches or other damage. If there is no damage, there is no need to pull the other caps at this time.




Inspect the main bearing caps for dents, cracks, or other damage.



Inspect the journals for deep scratches, indications of overheating and other damage.


Note : If the journals or main caps are damaged, the engine will need to be removed to complete the overhaul.



Piston and Rod Removal

Caution : Make sure the ridge reamer does not make a deep cut into the bore. Do not remove more metal than is necessary to remove the ridge.

If the cylinder bores have edges, use a ridge reamer to cut the ridge from the top of the cylinder bore.




Hammer, Steel Number Stamps

Mark the cylinder number onto each connecting rod cap.




Hammer, Steel Number Stamps

Mark the cylinder number onto the top of each piston.




14mm

Remove the capscrews, connecting rod cap and bearings.




Caution : Use care so that the cylinder bore or connecting rod is not damaged.

Use a hammer handle or similar object to push the piston and connecting rod through the cylinder bore. Put the assemblies in a rack for disassembly later.




Inspect the rod journals for deep scratches, indications of overheating and other damage.



Caution : Be sure to remove the tape covering the lube holes after the cleaning process is complete.




Check the bore cleanliness by wiping with a white, lint free, lightly oiled cloth. If grit residue is still present, repeat the cleaning process until all residue is removed. Wash the bores with solvent and blow the block dry with shop air.



Caution : Be sure to remove the covering from the piston cooling nozzles.




Remove the protective tape and cloth, and clean the crankshaft journals.



Use solvent and a brush to clean any residue that may have splashed on the camshaft.




Note : Inspect the camshaft lobes and tappet faces for signs of wear or damage.




Main Bearing Replacement


Remove all main bearing caps except the No.1 and 5 cap for 4 cylinder engine. The 4 cylinder engine is depicted in the illustration.



Inspect all caps and main bearing crankshaft journals.
(refer to page 171)




Determine the size of the bearing removed and obtain the same size for installation.
Refer to page 171 for the dimensions of the standard and undersize main bearing journals.




Caution : Do not lubricate the side that is against the cylinder block.

Apply a coat of Lubriplate 105 to the new upper bearings.




Use the pin to push the bearing shell into position. Use the pin to push against the end of the bearing with the tang. Push the bearing in slowly being sure it is aligned with the block. Make sure the tang on the bearing sets into the notch.

Note : Make sure the tang on the bearing sets into the notch in the bearing saddle.



Install the lower bearings into the caps. Apply a coat of Lubricate 105 to the bearings.



19mm



Caution : The crankshaft must rotate freely.




Install a main bearing cap after each upper bearing is installed to keep the bearing in place while the other uppers are installed.

Tighten the capscrews evenly and in sequence.

Step	Torque Value
1	39Nm [50 ft-lbs]
2	69Nm [52 ft-lbs]
3	98Nm [74 ft-lbs]

Check the bearing installations and the size of the bearings if the crankshaft does not rotate freely.




Note : The dimensions of the thrust bearings and crankshaft journal determine end play.

Measure the crankshaft end play


Dim. (A) End Play Limits

Min	Max
0.09mm [0.0035 in]	0.271mm [0.0107 in]




Piston and Rod – Disassembly

Remove the retaining rings.




Remove the piston pin.

Note : Heating the piston is not required.



Remove the piston rings.




Piston, Pin and Connecting Rod – Clean



Caution : Do not use bead blast to clean the pistons.

Soak the pistons in cold parts cleaner.
Soaking the pistons overnight will usually loosen the carbon deposits.



Caution : Do not clean the pistons and rods in an acid tank.



Wash the pistons and rods in a strong solution of laundry detergent in hot water.




Caution : Do not use a ring groove cleaner and be sure not to scratch the ring-sealing surface in the piston groove.



Clean the remaining deposits from the ring grooves with the square end of a broken ring.




Wash the pistons again in a detergent solution or solvent. Rinse the pistons. Use compressed air to dry.



Piston, Pin and Rod – Inspection

Inspect the piston for damage and excessive wear. Check the top, ring grooves, skirt and pin bore.




Measure the piston skirt diameter as illustrated.

Standard: 87.95 to 87.97 mm

[3.463 to 3.4634 in]

Worn Limit: 87.9 mm [3.46 in]






Use a new piston ring to measure the clearance in the ring groove.

Limits

Minimum Clearance

Top groove: 2.006 mm [0.079 in]

Oil Control: 3.002mm [0.1102 in]




Measure the pin bore

Diameter

30.008 mm [1.1814 in]

Worn Limit: 29.9 mm [1.177 in]



Inspect the piston pin for nicks, gouges and excessive wear.



Measure the pin diameter.

Diameter


30.0 mm [1.181 in]



Caution : The I-beam section cannot have dents or other damage. Damage to this part can cause stress risers which will progress to breakage.



Inspect the rod for damage and wear.




Measure the pin bore.

Maximum Diameter

30.038 mm [1.1826 in]

Worn Limit: 30.1 mm [1.185 in]




Bearing clearance can also be determined with Plastigage during engine assembly.



Piston to Connecting Rod – Installation

Caution : Be sure “Front” marking on piston and the numbers on the rod and cap are oriented as illustrated.



Install the retaining ring into the pin groove on the “Front” side of the piston.



Lubricate the pin and pin bores with engine oil.




Install the pin.

Note : Pistons do not require heating to install the pin, however, the piston does need to be at room temperature or above.




Install the second retaining ring.




Determine the piston diameter and obtain the appropriate ring set.



Piston Ring Gap – Check




Position each ring in the cylinder and use a position to square it with the bore.
A= 20 mm [0.0787 in]



Use a feeler gauge to measure the gap.

Ring	Limits	
	Minimum	Maximum
Top:		
	0.20 mm [0.0079 in.]	0.35 mm [0.0138 in.]
Intermediate:		
	0.25mm [0.0100 in.]	0.70 mm [0.0276 in.]
Oil Control:		
	0.20 mm [0.0079 in.]	0.40mm [0.0157 in.]




Piston Rings – Installation

Note : The top surface of all of the rings are identified:
Assemble with the word “Top” or the supplier mark up.



Position the oil ring expander in the oil control ring groove.




Install the oil control ring with the end gap opposite the ends on the expander.




Install the intermediate ring.



Install the top ring.




Position the rings.



Determine the size of the removed rod bearing and obtain a set of the same size.



Install the new bearings in the rods and caps and lubricate them with a light coat of Lubriplate 105.



Piston and Rod Assembly – Installation

Lubricate the cylinder bore with clean engine oil.



Generously lubricate the rings and piston skirts with clean engine oil.




75 to 125mm Ring Compressor




Caution : If using a strap-type ring compressor, make sure the inside of the strap does not hook on a ring gap and break the ring.


Compress the rings.



Bar the crankshaft so the rod journal for the piston to be installed is at Bottom Dead Center (BDC).




Push the piston into the bore until the top of the piston is approximately 50mm [2 inches] below the top of the bore.
Then, pull the connecting rod onto the crankshaft journal.




Note : The following series of illustrations show the engine in a vertical position. This is for clarity of illustration only.

Use clean engine oil to lubricate the threads and under the heads of the connecting rod capscrews.



Caution : The four digit number stamped on the rod and cap at the parting line must match and be installed towards the oil cooler side of the engine.

Install the rod cap and capscrews to the connecting rod.



12mm Socket, Torque Wrench




Caution : Tighten the connecting rod and capscrews evenly.

Torque Value:

Step 1 – 20 Nm [15 ft-lbs]


Step 2 – 34 Nm [26 ft-lbs]

Step 3 – 49 Nm [37 ft-lbs]



Caution : The crankshaft must rotate freely.

Check for freedom of rotation as the caps are installed. If the crankshaft does not rotate freely, check the installation of the rod bearings and the bearing size.



Caution : Do not measure clearance between the cap and crankshaft.




Measure the side clearance between the connecting rod and crankshaft.




Side Clearance Limits

Min	Max
0.15 mm	0.35 mm
[0.006 in]	[0.0138 in]



Install the suction tube and oil pan (refer to page 6-19).



Cylinder Head and Gasket – Installation




Caution : Make sure the gasket is correctly aligned with the holes in the cylinder block.

The cylinder block and head must be clean and dry. Position the gasket onto the dowels.



Carefully, put the cylinder head onto the gasket and cylinder block.

Note : Make sure the cylinder head is installed onto the dowels in the cylinder block.



Install the push rods and rocker levers (refer to page 179).
Lubricate the cylinder head capscrews. Use the illustrated torque sequence.



17mm

Torque Value:
Step 1 – 29 Nm [22 ft-lbs]
Step 2 – 59 Nm [44 ft-lbs]
Step 3 – 93 Nm [70 ft-lbs]



19mm

Caution: Be sure to lubricate the push rod sockets with clean engine oil.

Install the rocker lever pedestal capscrews.
Torque Value: 59 Nm [44 ft-lbs]



Adjust the valve clearance (refer to page 179).



Install the parts previously removed:


- Valve covers
- Injector nozzles
- Fuel lines
- Fuel filters
- Exhaust manifold
- Turbocharger, air crossover and aftercooler, if the engine is so equipped.

Observe the Following Check List During Final Assembly

	OK
● Correct injectors for the engine rating used and only one copper sealing washer installed?	_____
● Sealant applied to the capscrews that attach the intake manifold cover or aftercooler?	_____
● Turbocharger pre-lubed?	_____
● Engine filled with oil; oil filter filled with oil prior to installation so the engine has an immediate supply of oil?	_____
● Fuel filter (s) filled with fuel and the injection pump primed using the lever on the lift pump?	_____
● Aftercooler vent opened during coolant fill?	_____




Caution : It is extremely important that all air is vented prior to operating the engine.



Caution : Stop the engine immediately if any unusual sounds are heard.


Start the engine. If necessary, bleed the high pressure lines at the injectors until the engine runs smoothly.



Operate the engine at idle for 5 to 10 minutes and check for leaks and loose parts. Check the coolant and oil level.



Refer to page 226 through ? for test and performance requirements.



Cylinder Head – Disassembly

The following disassembly and assembly procedures are provided for inspection purposes only.

Refer to the Shop Manual, Bulletin No. 3810206, for complete rebuild instructions.

Mark the valve to identify their position.



Compress the valve spring and remove the valve stem collets. Use a magnet to remove the collets.



Release valve spring and remove the retainer and spring.



Caution : Keep the valves in a labeled rack.

Remove the remaining collets, retainers, springs and valves.



Remove the valve stem seals.




Cylinder Head – Clean and Inspect


Clean the carbon from the injector nozzle seat with a nylon brush.





Scrap the gasket material from all gasket surfaces.



Wash the cylinder head in hot soapy water solution. After rinsing, use compressed air to dry the cylinder head.



Polish the gasket surface with 400 grit paper.
Use an orbital sander or sanding block to keep a flat surface.



Inspect the valve guides for scuffing or scoring.
Measure the valve guide bore.

Maximum Diameter

8.025 mm [0.3160 in]

Worn Limit: 8.1 mm [0.319 in]




Inspect the head surface for nicks, erosion, or any other damage.

Check for head distortion as illustrated.


Standard: 0.03 mm [0.0012 in]

Worn Limit: 0.15 mm [0.0059 in]


Refer to the Salvage Manual if head distortion exceeds limits.



Polish the valve stem with crocus cloth.



Mark the valves again for location in the cylinder head.




Inspect for abnormal wear on the heads and stems.
Measure the valve stem diameter.

Maximum Diameter

7.960mm [0.3134 in]




If new valves are required, mark them for location in the cylinder head.




Valves – Grind

Re-face all reused valves. Check/replace bent valves.



Seat Angle


Intake: 30 Degrees
Exhaust: 45 Degrees




Measure rim thickness.

Minimum Thickness (T)


Standard: 1.2 mm [0.047 in]
Worn Limit: 0.5 mm [0.0197 in]



Check the valve stem tip for flatness.




If required, re-surface the valve stem tip.



Valve Seats – Grind


Note: The illustrated marks indicate valve seat have been ground previously.

Previously re-ground seat can be replace with service seats.




Calculating the Grinding Depth

Install the valves in their designated location and measure valve depth.




Note : The valve depth is the distance from the valve face to the head deck.

Record the depth of each valve as (A).




Grind the valve seat to remove scores, scratches and burns.



Seat Angle


Intake: 30 Degrees
Exhaust: 45 Degrees




Install the valves in their respective bores and measure depth again.



Note : Make sure the seats are clean before you measure the depth.




Record the depth of each valve as (B).
Calculate grinding depth (GD) as follows:
 $GD = (B) - (A)$




Dimension (GD)


0.20 mm [0.008 in]



Note : Identify re-ground valve seats.



Install the valves in their designated location and measure the depth.



Caution: Replace the valve if the depth is over the limit.

Check valve depth (C).


Valve Depth

Standard: 0.69 to 0.70 mm [0.0271 to 0.0279 in]


Worn Limit: 1.0 mm [0.0394 in]



Apply a light coat of valve lapping compound to each valve and lap each valve to its companion seat.



Remove the valves and clean lapping compound from the valves and seats.



Measure the valve seat width indicated by the lapped surface.

Valve Seat Width Limit

Intake:

Standard: 1.73 mm [0.0681 in]

Worn Limit: 2.23 mm [0.088 in]

Exhaust:

Standard: 2.12 mm [0.083 in]

Worn Limit: 2.62 mm [0.103 in]




Valve Springs – Inspection

Measure the valve spring.

Limits

Approx. Free Length (L): 46.1 mm [1.815 in.]



Check the valve spring tension.

A minimum load of 299.5 N. [67 lb] is required to compress the spring to a height of 29.85mm [1.175 in].




Cylinder Head – Assembly

Note : Clean all cylinder head components before assembling.




Install the valve stem seals.


Note : The intake and exhaust seals are the same.




Lubricate the stems with SAE 90W engine oil before installing the valves.



Compress the valve spring after assembling the spring and retainer.




Install new valve collets and release the spring tension.




Warning : Wear eye protection. If the collets are not correctly installed, they can fly out when the stems are hit with a hammer.

After assembly, hit the valve stems with a plastic hammer to make sure that the collets are seated.




Hydraulic Pump Drive Gear and Shaft - Inspect for Reuse (Just for D15S/18S/20SC-2)

Inspect the hydraulic pump gear for damaged, broken, or excessively worn teeth.



Rotate the gear, and inspect for rough spots in the bearing.
Inspect the bearing bore and shaft spline for excessive wear.




Balancer - Remove

Check the gear backlash before removing balancer. Refer to Section 1.

Remove the mounting capscrews.

Remove the balancer and shim or shim plate (1).

Remove the o-ring (2) in the oil passage.



Balancer - Install


Align the timing marks on the crankshaft drive gear and the balancer driven gear.



Install the shim or shim plate (1), balancer, and lightly lubricate the capscrews with clean 15W-40 engine oil.




Make sure that the oil supply passage is open and the o-ring (2) is installed..



Tighten the capscrews in a criss-cross pattern. Rotate the engine to make sure of free movement of components.


Torque Value: 28 n.m [21 ft-lb]



Note : Prevent movement of the adjoining gear when checking backlash or the reading will be the total of both gears.

Measure the balancer gear backlash.

Balancer Gear Backlash			
	mm		in
Crankshaft Drive Gear (A)-to-Balancer Drive Gear (B)	0.06	MIN	0.0024
Balancer Drive Gear (C)-to-Balancer Driven Gear (D)	0.14	MAX	0.0055
Balancer Drive Gear (C)-to-Balancer Driven Gear (D)	0.06	MIN	0.0024
Balancer Drive Gear (C)-to-Balancer Driven Gear (D)	0.14	MAX	0.0055



Measure the balancer end play.

Balancer Shaft End Play		
mm		in
0.05	MIN	0.002
0.25	MAX	0.0098

Engine Replacement and Testing

Engine Replacement

If the engine cannot be repaired in chassis, use the following guidelines for removal and installation of the engine.


Caution : Use the equipment manufacturer's recommendations and precautions for removal of chassis parts to gain access to the engine.




Engine Removal

Preparatory Steps:


- Disconnect the air intake and exhaust pipes.
- Disconnect the throttle linkage from the control lever.
- Do not remove the control lever from the injection pump.
- Disconnect all engine driven accessories.
- Disconnect the drive units from the flywheel.
- Drain the coolant.
- Drain the lubricating oil.
- Remove the chassis parts as necessary to lift the engine from the equipment




Disconnect all electrical connections. Put tags on the connections to identify their locations.



Disconnect all lines including fuel lines to the lift pump and fuel return. Use tags to identify the lines.




Put a cover or tape over all engine openings.



Use the lifting eyes to lift the engine. Apply tension to the hoist to hold the engine while you disconnect the engine mounts from the chassis. Lift the engine from the equipment. Dry Engine Weight: 169 kg

Note : Remove all accessories and brackets not previously removed to use with the replacement engine.



Engine Installation




Caution : Do not exceed the torque value for the engine supports.



Check the data plate to verify that the replacement engine is the same model and rating as the engine that was removed.


Note : Install all accessories and brackets that had been removed from the previous engine.



Use the lifting eyes to lift the engine. Keep tension on the hoist while you align the engine in the chassis and tighten the engine mounts.




Connect the engine and chassis parts in the reverse order of removal.




When connecting the cable/rod to the control lever, adjust the length so the lever has stop-to-stop movement.






Adjust the length of the cable/rod to the mechanical shut down lever so there is stop-to-stop movement.




Note : Make sure the air intake and exhaust pipe connections are tight and free of leaks.




Fill the engine with the required amount of lubricating oil.
6.5 Liters [1.85 gal]

Note : Check the oil level after the engine has run for 2 to 3 minutes. Oil held in the oil filter and oil passages will cause the oil level in the oil pan to lower.



Fill the cooling system with a mixture of 50% water and 50% ethylene-glycol base antifreeze. Refer to the equipment manufacture's specifications for radiator capacity.

Engine Only Coolant Capacity
3.0 Liters [0.7 gal]



Operate the engine at idle for 5 to 10 minutes and check for leaks and loose parts.

Engine Testing

Verify engine performance by performing an in-chassis check.

Operating Conditions for Run-In and Test

Measurement	Limit (s)
Coolant Temperature	100°C [212°F] Maximum
Lubricating Oil Temperature	120°C [248°F] Maximum
Lubricating Oil Pressure	294 kPa [42.6 PSI] Minimum
Air Inlet Temperature	25°C [77°F] Maximum
Air Inlet Restriction	250 mmHg Maximum
Boost Pressure	66cm [26 in.] Hg Minimum
Exhaust Temperature	630°C [1166°F] Maximum
Smoke	
Bosch Smoke Meter	2.5 Units Maximum
Celsco Smoke Meter	4% Opacity Maximum

Specifications

General Engine

General Engine Data	
- A2000, and A2300	Naturally Aspirated
Engine Weight (Dry) Less Flywheel and Electronics	
- A2000 and A2300	203 kg [448 lbs]
Compression Ratio	21:1
Bore	
- A2000	84 mm [3.31 in]
- A2300	88 mm [3.46 in]
Stroke	
- A2000, and A2300	94 mm [3.7 in]
Displacement	
- A2000	2.08 liters [127 C.I.D.]
- A2300	2.29 liters [139 C.I.D.]
Firing Order	
- A2000, and A2300	1-3-4-2
Valve Clearance	
- Intake	0.3 mm [0.012 in]
- Exhaust	0.3 mm [0.012 in]
Engine Rotation (Viewed From the Front of the Engine)	Clockwise

Fuel System

Maximum Fuel Inlet Restriction to Injection Pump (Clean Filter)	76.3 mm-Hg [3 in-Hg]
Maximum Fuel Drain Restriction	381 mm-Hg [15 in-Hg]
Maximum Fuel Inlet Temperature	65°C [149°F]
Minimum Engine Cranking Speed	180 rpm

Lubricating Oil System

Regulating Valve Opening Pressure	290 - 390 kPa [42 - 56 psi]
Lubricating Oil Capacity (Total System*)	
- A2000, and A2300	7 liters [7.5 qt]
Lubricating Oil Capacity (Standard Oil Pan Only*)	
- A2000, and A2300	6.5 liters [7.0 qt]
Lubricating Oil Pressure at Idle (Minimum Allowable)	69 kPa [10 psi]
Lubricating Oil Pressure at Rated (Minimum Allowable)	168 kPa [24 psi]
* Some applications use different oil pan capacities. Contact your local Cummins Distributor if you have questions.	

Cooling System

Coolant Capacity (Engine Only)	
- A2000, and A2300	3 liters [3.2 qt]
Standard Modulating Thermostat - Range	71 - 85°C [160 - 185°F]
Maximum Allowable Operating Temperature	100°C [212°F]
Minimum Recommended Operating Temperature	71°C [160°F]
Minimum Recommended Pressure Cap	48 kPa [7 psi]

Air Intake System

Maximum Intake Air Restriction	
- Dirty Filter	635 mm-H ₂ O [25 in-H ₂ O]
- Clean Filter	254 mm-H ₂ O [10 in-H ₂ O]
Minimum Dirt Holding Capacity	25 g/cfm

Exhaust System

Maximum Allowable Exhaust Restriction	
- A2000, and A2300	75 mm-Hg [3 in-Hg]

Electrical System

Recommended Battery Capacity	
- A2000, and A2300	
- 12 Volt Battery with Light Accessories	500 Cold Cranking Amps
- 12 Volt Battery with Heavy Accessories	650 Cold Cranking Amps
- 24 Volt Battery with Light Accessories	250 Cold Cranking Amps
- 24 Volt Battery with Heavy Accessories	325 Cold Cranking Amps
Maximum 12 Volt Starting System Resistance	0.001 ohm
Maximum 24 Volt Starting System Resistance	0.002 ohm
Minimum Cranking Speed	180 rpm

Drive Belt Tension

Belt Size	Belt Tension Gauge Part No.		Belt Tension New		Belt Tension Range Used*	
	Click-type	Burroughs	N	lbf	N	lbf
0.380 in	3822524		620	140	270 to 490	60 to 110
0.440 in	3822524		620	140	270 to 490	60 to 110
1/2 in	3822524	ST-1138	620	140	270 to 490	60 to 110
11/16 in	3822524	ST-1138	620	140	270 to 490	60 to 110
3/4 in	3822524	ST-1138	620	140	270 to 490	60 to 110
7/8 in	3822524	ST-1138	620	140	270 to 490	60 to 110
4 rib	3822524	ST-1138	620	140	270 to 490	60 to 110
5 rib	3822524	ST-1138	670	150	270 to 530	60 to 120
6 rib	3822525	ST-1293	710	160	290 to 580	65 to 130
8 rib	3822525	ST-1293	890	200	360 to 710	80 to 160
10 rib	3822525	3823138	1110	250	440 to 890	100 to 200
12 rib	3822525	3823138	1330	300	530 to 1070	120 to 240
12 rib K section	3822525	3823138	1330	300	890 to 1070	200 to 240

Note : This chart does not apply to automatic belt tensioners.

* A belt is considered used if it has been in service for ten minutes or longer.

* If used belt tension is less than the minimum value, tighten the belt to the maximum used belt value.

Capscrew Markings and Torque Values


General information

Caution : When replacing capscrews, always use a capscrew of the same measurement and strength as the capscrew being replaced. Using the wrong capscrews can result in engine damage.



Metric capscrews and nuts are identified by the grade number stamped on the head of the capscrew or on the surface of the nuts. U.S. Customary capscrews are identified by radial lines stamped on the head of the capscrew.

The following examples indicate how capscrews are identified:



NOTES:

1. Always use the torque values listed in the following tables when specific torque values are not available.
2. Do not use the torque values in place of those specified in other sections of this manual.
3. The torque values in the table are based on the use of lubricated threads.

4. When the ft-lb value is less than 10, convert the ft-lb value to in-lb to obtain a better torque with an in-lb torque wrench.
Example: 6 ft-lb equals 72 in-lb.

Capscrew Markings and Torque Values – Metric

Commercial Steel Class												
8.8					10.9				12.9			
Capscrew Head Markings												
												
Body Size	Torque				Torque				Torque			
Diameter	Cast Iron		Aluminum		Cast Iron		Aluminum		Cast Iron		Aluminum	
mm	N•m	ft-lb	N•m	ft-lb	N•m	ft-lb	N•m	ft-lb	N•m	ft-lb	N•m	ft-lb
6	9	5	7	4	13	10	7	4	14	9	7	4
7	14	9	11	7	18	14	11	7	23	18	11	7
8	23	17	18	14	33	25	18	14	40	29	18	14
10	45	33	30	25	65	50	30	25	70	50	30	25
12	80	60	55	40	115	85	55	40	125	95	55	40
14	125	90	90	65	180	133	90	65	195	145	90	65
16	195	140	140	100	280	200	140	100	290	210	140	100
18	280	200	180	135	390	285	180	135	400	290	180	135
20	400	290	—	—	550	400	—	—	—	—	—	—

Capscrew Markings and Torque Values – U.S Customary

SAE Grade Number Capscrew Head Markings These are all SAE Grade 5 (3 line) 5 8								
Capscrew Torque - Grade 5 Capscrew				Capscrew Torque - Grade 8 Capscrew				
Capscrew Body Size	Cast Iron		Aluminum		Cast Iron		Aluminum	
	N•m	ft-lb	N•m	ft-lb	N•m	ft-lb	N•m	ft-lb
1/4 - 20	9	7	8	6	15	11	8	6
1/4 - 28	12	9	9	7	18	13	9	7
5/16 - 18	20	15	16	12	30	22	16	12
5/16 - 24	23	17	19	14	33	24	19	14
3/8 - 16	40	30	25	20	55	40	25	20
3/8 - 24	40	30	35	25	60	45	35	25
7/16 - 14	60	45	45	35	90	65	45	35
7/16 - 20	65	50	55	40	95	70	55	40
1/2 - 13	95	70	75	55	130	95	75	55
1/2 - 20	100	75	80	60	150	110	80	60
9/16 - 12	135	100	110	80	190	140	110	80
9/16 - 18	150	110	115	85	210	155	115	85
5/8 - 11	180	135	150	110	255	190	150	110
5/8 - 18	210	155	160	120	290	215	160	120
3/4 - 10	325	240	255	190	460	340	255	190
3/4 - 16	365	270	285	210	515	380	285	210
7/8 - 9	490	360	380	280	745	550	380	280
7/8 - 14	530	390	420	310	825	610	420	310
1 - 8	720	530	570	420	1100	820	570	420
1 - 14	800	590	650	480	1200	890	650	480

Fraction, Decimal, Millimeter Conversions

Fraction	inch	Mm	Fraction	inch	mm
1/64	0.0156	0.397	33/64	0.5156	13.097
1/32	0.0313	0.794	17/32	0.5313	13.494
3/64	0.0469	1.191	35/64	0.5469	13.891
1/16	0.0625	1.588	37/64	0.5625	14.288
5/64	0.0781	1.984	39/64	0.5781	14.684
3/32	0.0938	2.381	41/64	0.5938	15.081
7/64	0.1094	2.778	43/64	0.6094	15.478
1/8	0.1250	3.175	45/64	0.6250	15.875
9/64	0.1406	3.572	47/64	0.6406	16.272
5/32	0.1563	3.969	49/64	0.6563	16.669
11/64	0.1719	4.366	51/64	0.6719	17.066
3/16	0.1875	4.763	53/64	0.6875	17.463
13/64	0.2031	5.159	55/64	0.7031	17.859
7/32	0.2188	5.556	57/64	0.7188	18.256
15/64	0.2344	5.953	59/64	0.7344	18.653
1/4	0.2500	6.350	61/64	0.7500	19.050
17/64	0.2656	6.747	63/64	0.7656	19.447
9/32	0.2813	7.144	1	0.7813	19.844
19/64	0.2969	7.541		0.7969	20.241
5/16	0.3125	7.938		0.8125	20.638
21/64	0.3281	8.334		0.8281	21.034
11/32	0.3438	8.731		0.8438	21.431
23/64	0.3594	9.128		0.8594	21.828
3/8	0.3750	9.525		0.8750	22.225
25/64	0.3906	9.922		0.8906	22.622
13/32	0.4063	10.319		0.9063	23.019
27/64	0.4219	10.716		0.9219	23.416
7/16	0.4375	11.113		0.9375	23.813
29/64	0.4531	11.509		0.9531	24.209
15/32	0.4688	11.906		0.9688	24.606
31/64	0.4844	12.303		0.9844	25.003
1/2	0.5000	12.700		1.0000	25.400

Conversion Factor: 1 inch = 25.4 mm

Newton-Meter to Foot-Pound Conversions

N•m	ft-lb	N•m	ft-lb	N•m	ft-lb
1	9 in-lb	55	41	155	114
5	44 in-lb	60	44	160	118
6	53 in-lb	65	48	165	122
7	62 in-lb	70	52	170	125
8	71 in-lb	75	55	175	129
9	80 in-lb	80	59	180	133
10	89 in-lb	85	63	185	136
11	97 in-lb	90	66	190	140
12	106 in-lb	95	70	195	144
14	124 in-lb	100	74	200	148
15	133 in-lb	105	77	205	151
16	142 in-lb	110	81	210	155
18	159 in-lb	115	85	215	159
20	15 ft-lb	120	89	220	162
25	18	125	92	225	165
30	22	130	96	230	170
35	26	135	100	235	173
40	30	140	103	240	177
45	33	145	107	245	180
50	37	150	111	250	184

Note : To convert from Newton-Meters to Kilogram-Meters divide Newton-Meters by 9.803.

Pipe Plug Torque Values




Size		Torque		Torque	
Thread	Actual Thread O.D.	In Aluminum Components		In Cast Iron or Steel Components	
in	in	N•m	ft-lb	N•m	ft-lb
1/16	0.32	5	45 in-lb	15	10
1/8	0.41	15	10	20	15
1/4	0.54	20	15	25	20
3/8	0.68	25	20	35	25
1/2	0.85	35	25	55	40
3/4	1.05	45	35	75	55
1	1.32	60	45	95	70
1-1/4	1.66	75	55	115	85
1-1/2	1.90	85	65	135	100





Weights and Measures – Conversion Factors





Quantity	U.S. Customary		Metric		From U.S. Customary To Metric Multiply By	From Metric To U.S. Customary Multiply By
	Unit Name	Abbreviation	Unit Name	Abbreviation		
Area	sq. inch	in ²	sq. millimeters	mm ²	645.16	0.001550
			sq. centimeters	cm ²	6.452	0.155
	sq. foot	ft ²	sq. meter	m ²	0.0929	10.764
Fuel Consumption	pounds per horsepower hour	lb/hp-hr	grams per kilowatt hour	g/kW-hr	608.277	0.001645
Fuel Performance	miles per gallon	mpg	kilometers per liter	km/l	0.4251	2.352
	gallons per mile	gpm	liters per kilometer	l/km	2.352	0.4251
Force	pounds force	lbf	Newton	N	4.4482	0.224809
Length	inch	in	millimeters	mm	25.40	0.039370
	foot	ft	millimeters	mm	304.801	0.00328
Power	horsepower	hp	kilowatt	kW	0.746	1.341
Pressure	pounds force per sq. inch	psi	kilopascal	kPa	6.8948	0.145037
	inches of mercury	in Hg	kilopascal	kPa	3.3769	0.29613
	inches of water	in H ₂ O	kilopascal	kPa	0.2488	4.019299
	inches of mercury	in Hg	millimeters of mercury	mm Hg	25.40	0.039370
	inches of water	in H ₂ O	millimeters of water	mm H ₂ O	25.40	0.039370
	bars	bars	kilopascals	kPa	100.001	0.00999
	bars	bars	millimeters of mercury	mm Hg	750.06	0.001333



Quantity	U.S. Customary		Metric		From U.S. Customary To Metric Multiply By	From Metric To U.S. Customary Multiply By
Temperature	fahrenheit	°F	centigrade	°C	$(°F - 32) \div 1.8$	$(1.8 \times °C) + 32$
Torque	pound force per foot	ft-lb	Newton-meter	N•m	1.35582	0.737562
	pound force per inch	in-lb	Newton-meter	N•m	0.113	8.850756
Velocity	miles/hour	mph	kilometers/hour	kph	1.6093	0.6214
Volume: liquid displacement	gallon (U.S.)	gal.	liter	l	3.7853	0.264179
	gallon (Imp*)	gal.	liter	l	4.546	0.219976
	cubic inch	in ³	liter	l	0.01639	61.02545
	cubic inch	in ³	cubic centimeter	cm ³	16.387	0.06102
Weight (mass)	pounds (avoir.)	lb	kilograms	kg	0.4536	2.204623
Work	British Thermal Unit	BTU	joules	J	1054.5	0.000948
	British Thermal Unit	BTU	kilowatt-hour	kW-hr	0.000293	3414
	horsepower hours	hp-hr	kilowatt-hour	kW-hr	0.746	1.341

SPECIAL TOOLS

Style	Tool No.	Tool name
	ST 434	Vacuum Gauge
	ST 537	Dial Depth Gauge
	ST 647	Standard Puller
	ST 1111-3	Manometer
	ST 1273	Pressure Gauge

Style	Tool No.	Tool name
	ST 1325	Dial guage attachment
	3162745	Injector/Connector Removal tool
	3163292	Valve spring compressor
	3375072	Dial bore gauge, kit
	3375432	Crack Detection Kit

Style	Tool No.	Tool name
	3376579	Tube(Filter) Cutter
	3376946	Injector nozzle tester
	3377161	Digital multimeter
	3377259	Fuel Pump Timing tool
	3377462	Digital optical tachometer

Style	Tool No.	Tool name
	3822476	Blow By tool, use with ST1111-3
	3822666	Digital Thermometer
	3823137	Piston ring expander