



Service Manual

9-speed Synchromesh transmissions

7/97

T 20538

General

Model designation

Example:	FSO-6109A
FS	- Standard prefix
O	- Overdrive
6	- Input torque code
1	- Series 1
09	- Number of forward gears
A	- Standard ratio set
B, C	- Alternative ratio sets


Transmission Identification

All transmissions are fitted with an identification plate on the left-hand side of the front case showing

1. Transmission serial number.
2. Transmission model.
3. Manufacturing date code.
4. Transmission specification number.

The transmission specification number is unique to each customer and gives precise details of the transmission design level. This number must be quoted when ordering replacement parts.

General description



1. Main section

2. Range change section

Features

The Eaton 9-speed transmissions have nine forward speeds and are part of a medium duty range of synchromesh transmissions. They have a simple shift pattern using a unique single rail selector mechanism. Direct drive or overdrive top gear versions are available. An epicyclic reduction gear with air operated synchromesh engagement is located between the 5-speed main section of the transmission and the output flange. With the reduction gear engaged, low (crawler) gear and 1st, 2nd, 3rd and 4th gears can be selected and engaged in the normal way. With the reduction gear locked out, 5th, 6th, 7th and 8th gears are similarly available. Single H or double H shift systems may be fitted. A non-synchromesh low gear is available as an option for 8209 transmissions.

The epicyclic reduction gear


The epicyclic reduction gear consists of three main components:

An annulus, a sun gear and a planet gear.

The annulus, which is the outer, internally toothed ring gear, is secured to the sliding sleeve of the range change synchroniser assembly.

The sun gear, which is splined and bolted to the transmission mainshaft and runs concentrically with, but independent of the annulus.

The planet gear, which runs in mesh with both the annulus and the sun gear. In this application it consists of a series of five planet gears, running independently on their axes by which they are attached to the planet gear carrier. The carrier is an integral part of the transmission output shaft.



ET-82/1

1. Annulus	2. Sun Gear	3. Planet Gears	4. Planet Gear Carrier
------------	-------------	-----------------	------------------------

Principle of Operation. If the annulus is held stationary and the sun gear is rotated, the planet gears are driven round the annulus at a speed governed by the size of the sun gear and planet gears relative to the annulus. The planet gears turn on their axes and force the carrier to rotate in the same direction as, but slower than, the sun gear. The output shaft, being an integral part of the carrier rotates with it.


Practical Application. In the Eaton 9-speed transmissions, the 'LOW RANGE' or reduction mode ratio is achieved by sliding the range change synchroniser sleeve and the annulus into mesh with a flange which is secured by a reaction plate to the transmission rear case.

This locks the annulus, and the output shaft therefore rotates in the same direction as, but slower than, the mainshaft.

In the 'HIGH RANGE' or direct drive mode the synchroniser sleeve is slid out of mesh with the reaction plate and into mesh with a flange splined to the planet gear carrier. As the annulus and the planet carrier are now locked together, the planet gears are no longer able to rotate, and the whole epicyclic assembly rotates as a single unit. The output shaft therefore runs at the same speed as the mainshaft.

With the single H shift system, a manually operated air switch on the gear lever knob engages 'high' or 'low' range as required.

Single H Shift Pattern



ET-27/1


An interlock pin between the two selector shafts and an air exhaust control valve prevent the range change operating unless the gear change selector shaft is in the neutral position.

With the double H shift system, a spring loaded detent is placed in the neutral gate between the 3/4 and


5/6 gear positions. As the gear lever is pushed past this detent to the 5th gear position, a slave valve automatically supplies air to shift the range change from low to high. The unique single rail selector mechanism engages 1st, 2nd, 3rd or 4th gears in the main section, but now with the range change in 'high' thus giving 5th, 6th, 7th and 8th gears.

When changing from 5th to 4th, past the detent, the slave valve operates to change from 'high' to 'low' range.

Double H Shift Pattern



Range changes are selected automatically as gear lever is moved over detent.



1. Left-hand horizontal	2. Left-hand vertical	3. Right-hand vertical	4. Right-hand horizontal
-------------------------	-----------------------	------------------------	--------------------------


The transmission may be mounted vertically or horizontally and in both positions the gear change remote control may be to the right or the left.

The synchroniser assemblies are of the baulk ring type with the ring cones manufactured separately from the gears. This allows the synchroniser rings and flanges to be renewed without the need to renew the gears themselves. Reverse gear is engaged by sliding the reverse/low sliding sleeve to engage with the flange on reverse gear but without the assistance of a synchroniser cone.


The transmission is fitted with a pressure fed lubrication system.

The oil is drawn through a strainer in the lower, left-hand side of the transmission by the twin rotor oil pump which is driven directly from the rear of the layshaft. The mainshaft is drilled throughout its entire length and cross drillings take the oil to all the mainshaft bearings, the input shaft bearing and the range change epicyclic planet gear bearings. Transmissions are available with the oil pump and case suitably modified in production to enable an oil cooler to be fitted.


Power flow in the gears (direct drive)




R




L



1




2




3




4




5



6



7



8

Specifications

Model	6109	8209
Nominal Torque	930 Nm	1100 Nm
For Engine Performance up to	197 kW/265 HP	205 kW/275 HP
Weight 1)	152 kg	152 kg
Length 2)	690 mm	690 mm
Oil Capacity	8.5 litres	8.5 litres
Clutch Housing	SAE Standard	
Power Take-off Openings	Left side (vertical installation), bottom right (horizontal installation): 2 SAE 6 bolt facings plus extended layshaft for Eaton PTO-ISO 7707	
PTO Drive Gears driven from 3):		
	engine speed	direction of rotation
- the reverse idler gear at:		
FS-6109A/FS-8209A	0.46	as engine
FSO-6109A/FSO-8209A	0.62	
- the extended layshaft or layshaft front gear at:		

Model			6109	8209
FS-6109A/FS-8209A			0.76	opposite
FSO-6109A/FSO-8209A			1.02	to engine
Gear	FS-6109A	%	FSO-6109A	%
	FS-8209A	Step	FSO-8209A	Step
8	1.00		0.75	
		34		33
7	1.34		1.00	
		37		38
6	1.85		1.38	
		37		37
5	2.48		1.86	
		40		40
4	3.55		2.65	
		34		33
3	4.77		3.55	
		37		38
2	6.55		4.90	
		37		37
1	8.81		6.59	
		40		40
Low	12.64		9.45	
Reverse	13.21		9.88	

- 1) including output coupling, low remote control; less clutch housing
- 2) front face of transmission case to rear face of output flange
- 3) recommended back lash is from 0.15 to 0.25 mm


Lubrication

Proper Oil Level

Before checking the oil level or refilling, ensure vehicle is on level ground. Make sure that the oil is level with the filler opening.

Draining Oil


Drain transmission while oil is warm. To drain oil remove the drain plug at the bottom of the case, or remove the strainer from the intermediate case (see below). Clean the drain plug before refitting.



Drain and Filler Plugs

Oil Strainer

Remove and clean the oil strainer. Clean the strainer in kerosene (paraffin) or suitable solvent and dry thoroughly. Renew the washer and the O-ring if necessary. When refitting, tighten to the correct torque (40 to 47 Nm).



1. Washer	2. Strainer
-----------	-------------

Refilling

Clean area round filler plug. Fill transmission to the level of the filler opening. The exact amount of oil depends on the transmission inclination. In every instance, fill to the level of the filler opening. Do not overfill - this causes oil to be forced out of the case past the output and input shaft seals.

Adding Oil

It is recommended that different types and brands of oil are not intermixed because of possible incompatibility.

Operating Temperature

It is important that the transmission operating temperature does not exceed 120°C for an extended period of time. Operating temperatures above 120°C cause breakdown of the oil and shorten transmission life. The following conditions in any combination can cause operating temperatures of over 120°C.

1. Operating consistently at road speeds under 32 km/h
2. High engine RPM
3. High ambient temperature
4. Restricted air flow around transmission
5. Exhaust too close to transmission
6. High horsepower, overdrive operation
7. High power PTO operation for extensive periods while stationary.

High operating temperatures may require more frequent oil changes and/or fitment of a cooler.

Towing

When towing the vehicle, the propeller shaft between the axle and transmission must be disconnected.

Recommended lubricants

Use only recommended lubricants to ensure smooth running.

Type	Grade	Temperature Range
Mild EP Gear Oil to Specification MIL-L-2105 or API-GL-4	SAE 80W SAE 90 SAE 80W/90	-26°C to 20°C -12°C to 37°C -26°C to 38°C
Heavy Duty Engine Oil to Specification MIL-L-2104C or MIL-L-46152 or API-SF or API-CD	SAE 50 SAE 40 SAE 30	Above -12°C Above -12°C Below -12°C

Caution: DO NOT use oil additives, friction modifiers or synthetic lubricants.

Service intervals

Lubrication Change and Inspection

Highway Use	
First 5,000 to 8,000 km	Change transmission oil on new units.
Every 16,000 km*	Inspect oil level. Check for leaks.
Every 80,000 km	Change transmission oil.
Off Highway Use	
First 30 hours	Change transmission oil on new units.
Every 40 hours*	Inspect oil level. Check for leaks.
Every 500 hours	Change transmission oil when severe dirt conditions exist.
Every 1000 hours	Change transmission oil (normal off-highway use).

Remove and clean oil strainer at each oil change.

Transmissions fitted with an oil cooler may additionally be fitted with a filter in the cooler line. Renew the


filter at every oil change.

* Or 2 months, whichever occurs first.

+ Or 12 months, whichever occurs first.

Torque tightening recommendations



Vertical installation



1. Clutch Housing, 10 studs - M18 81 Nm minimum. Installed with Loctite 242	2. Clutch housing, 10 nuts - M18 190 to 203 Nm With plain washers and lockwashers	3. Clutch housing, 10 capscrews - M18 190 to 203 Nm With plain washers and lockwashers
4. Clutch housing, 12 studs - M12 59 Nm minimum Installed with plain washers and lockwashers	5. Clutch housing, 12 nuts - M12 70 to 80 Nm. With plain washers and lockwashers	6. Clutch housing, 12 capscrews - M12 70 to 80 Nm. With plain washers and lockwashers
7. Front PTO cover, 6 capscrews - M10 35 to 39 Nm	8. Selector block tapered lockcrew 1 lockcrew - M10 35 to 39 Nm Patchlock or thread coated with Loctite 270	9. Front casing to intermediate casing 3/5 capscrews - M10 51 to 58 Nm. With plain washers
10. Front casing to intermediate casing 13/15 capscrews with plain nuts - M10 51 to 58 Nm	11. Rear casing to intermediate casing 15/18 capscrews with plain nuts - M10 51 to 58 Nm	12. PTO/Reverse idler gear cover 6 capscrews - M10 35 to 39 Nm


With plain washers under capscrews and nuts	With plain washers under capscrews and nuts	
13. Remote control housing end cover 4 capscrews - M8 20 to 24 Nm. With lockwashers	14. Overdrive selector fork pivot pins 2 capscrews - M8 20 to 24 Nm. With lockwashers	15. Slave valve - double H shift 2 socket headed capscrews - M6 20 to 24 Nm. With lockwashers Slave valve - single H shift, 2 capscrews - M6 20 to 24 Nm. With lockwashers Exhaust valve - single H shift, 2 capscrews - M16 16 to 22 Nm
16. Oil strainer, M40 3 1.5 thread 40 to 47 Nm	17. Sun gear retaining capscrew - M16 225 to 255 Nm Use new patchlock coated capscrew	18. Reaction plate, 4 socket headed countersunk screws - M8 24 to 27 Nm
19. Planet gear spindles 5 socket head locating grub screws - M6 5 to 8 Nm New grubscrew thread coated with Loctite 270	20. Oil pump, 8 capscrews - M10 35 to 40 Nm. With plain washers	

Vertical installation




1. Remote control shift lever 1 capscrew and nut - M8 20 to 27 Nm. With lockwasher or 1 capscrew and nut - M10 35 to 39 Nm. With lockwasher	2. Selector shaft detent cover 2 capscrews - M8 20 to 24 Nm. With lockwashers	3. Oil filler plug - M24 32 to 37 Nm
4. Layshaft front bearing cover, 4 capscrews - M12 69 to 78 Nm. With lockwashers	5. Input shaft front bearing cover 3 capscrews - M10 35 to 39 Nm. With lockwashers	6. Remote control housing detent cover 2 capscrews - M8 20 to 24 Nm. With lockwashers
7. Oil drain plug (magnetic) - M24 32 to 37 Nm	8. Speedometer pinion adaptor - M22 20 to 27 Nm. Copper washer	9. Speedometer housing, 4 capscrews - M10 35 to 39 Nm. With plain washers and lockwashers
10. Rear case cover (rear PTO) 4 capscrews - M12 69 to 78 Nm. With lockwashers	11. Reverse lamp switch - M16 16 to 22 Nm	12. Range indicator lamp switch - M16 16 to 22 Nm
13. Neutral switch - M16 16 to 22 Nm	14. Range change cylinder cover, 3 capscrews - M8 20 to 24 Nm. With plain washers and lockwashers	15. Range change piston nut - M16 95 to 115 Nm
16. Output shaft, locknut - M39 600 to 700 Nm. With nylon locking insert	17. Air filter/pressure regulator, 2 capscrews - M6 10 to 16 Nm. With lockwashers	18. Air filter cap, 11¼" M18 23 to 28.5 Nm
19. Air connections, 1/8" NPFT 7 to 10 Nm	20. Air supply, 3/8" NPFT 10 to 14 Nm	21. Remote control housing 4/6/8 capscrews - M10 35 to 39 Nm. Loctite 242

Horizontal installation



1. Remote control shift lever 1 capscrew and nut - M8 20 to 27 Nm. With lockwasher or 1 capscrew and nut - M10 35 to 39 Nm. With lockwasher	2. Selector shaft detent cover 2 capscrews - M8 20 to 24 Nm. With lockwashers	3. Oil filler plug - M24 32 to 37 Nm
4. Layshaft front bearing cover, 4 capscrews - M12 69 to 78 Nm. With lockwashers	5. Input shaft front bearing cover 3 capscrews - M10 35 to 39 Nm. With lockwashers	6. Remote control housing detent cover 2 capscrews - M8 20 to 24 Nm. With lockwashers
7. Oil drain plug (magnetic) - M24 32 to 37 Nm	8. Speedometer pinion adaptor - M22 20 to 27 Nm. Copper washer	9. Speedometer housing, 4 capscrews - M10 35 to 39 Nm. With plain washers and lockwashers
10. Rear case cover (rear PTO) 4 capscrews - M12 69 to 78 Nm. With lockwashers	11. Range change cylinder cover 3 capscrews - M8 20 to 24 Nm. With plain washers and lockwashers	12. Range change piston nut - M16 95 to 115 Nm
13. Output shaft, locknut - M39 600 to 700 Nm. With nylon locking insert	14. Air filter/pressure regulator, 2 capscrews - M6 10 to 16 Nm. With lockwashers	15. Air filter cap, 1 1/4" M18 23 to 28.5 Nm
16. Air connections 1/8" NPFT 7 to 10 Nm	17. Air supply 3/8" NPFT 10 to 14 Nm	18. Remote control housing 4/6/8 capscrews - M10 35 to 39 Nm. Loctite 242

Horizontal installation



1. Clutch Housing, 10 studs - M18 81 Nm minimum. Installed with Loctite 242	2. Clutch housing, 10 nuts - M18 190 to 203 Nm With plain washers and lockwashers	3. Clutch housing, 10 capscrews - M18 190 to 203 Nm With plain washers and lockwashers
4. Clutch housing, 12 studs - M12 59 Nm minimum Installed with plain washers and lockwashers	5. Clutch housing, 12 nuts - M12 70 to 80 Nm. With plain washers and lockwashers	6. Clutch housing, 12 capscrews - M12 70 to 80 Nm. With plain washers and lockwashers
7. Front PTO cover, 6 capscrews - M10 35 to 39 Nm	8. Selector block tapered lockcrew 1 lockcrew - M10 35 to 39 Nm Patchlock or thread coated with Loctite 270	9. Front casing to intermediate casing 3/5 capscrews - M10 51 to 58 Nm. With plain washers
10. Front casing to intermediate casing 13/15 capscrews with plain nuts - M10 51 to 58 Nm With plain washers under capscrews and nuts	11. Rear casing to intermediate casing 15/18 capscrews with plain nuts - M10 51 to 58 Nm With plain washers under capscrews and nuts	12. PTO/Reverse idler gear cover 6 capscrews - M10 35 to 39 Nm
13. Remote control housing end cover 4 capscrews - M8 20 to 24 Nm. With lockwashers	14. Overdrive selector fork pivot pins 2 capscrews - M8 20 to 24 Nm. With lockwashers	15. Slave valve - double H shift 2 socket headed capscrews - M6 20 to 24 Nm. With lockwashers

		Slave valve - single H shift, 2 capscrews - M6 20 to 24 Nm. With lockwashers Exhaust valve - single H shift, 2 capscrews - M16 16 to 22 Nm
16. Oil strainer, M40 3 1.5 thread 40 to 47 Nm	17. Sun gear retaining capscrew - M16 225 to 255 Nm Use new patchlock coated capscrew	18. Reaction plate, 4 socket headed countersunk screws - M8 24 to 27 Nm
19. Planet gear spindles 5 socket head locating grub screws - M6 5 to 8 Nm New grubscrew thread coated with Loctite 270	20. Oil pump, 8 capscrews - M10 35 to 40 Nm. With plain washers	21. Reverse lamp switch - M16 16 to 22 Nm
22. Range indicator lamp switch - M16 16 to 22 Nm	23. Neutral switch - M16 16 to 22 Nm	

Disassembly precautions

It is assumed in the detailed disassembly instructions that the lubricant has been drained and the necessary linkage and air lines have been removed from the chassis. Removal of the gear shift remote control housing assembly is included in the detailed instructions. However, this assembly may also be removed from the transmission before removing the unit from the vehicle. Follow each procedure closely in each section, making use of both the text and the pictures.

1. Cleanliness - Provide a clean place to work. It is important that no dirt or foreign material enters the unit during repairs. The outside of the unit should be carefully cleaned before starting the disassembly. Dirt is abrasive and can damage bearings.

2. Assemblies - When disassembling the various assemblies, such as the mainshaft, range change epicyclic, layshaft and remote control housing, place all parts on a clean bench in the same sequence as removed. This procedure will simplify reassembly and reduce the possibility of losing parts. When pulling off synchroniser hubs follow the procedures detailed in 'Disassembly' using a suitable press of adequate capacity. Failure to adhere to the recommended procedures may cause irreparable damage.

3. Snap rings - Remove snap rings with pliers designed for this purpose. New selective fit snap rings must be fitted as specified in 'Reassembly'.

4. Input shaft - The input shaft (Direct drive version only) can be removed without removing the layshaft or mainshaft. Take care not to misplace or lose the mainshaft spigot bearing.

5. Bearings - Carefully wash and re-lubricate all bearings as removed and protectively wrap until ready for use. Remove bearings with pullers designed for this purpose.

6. When pressing - Apply force to shafts, housings etc. with restraint. Movement of some parts is restricted. Do not apply force after the part being driven stops solidly. Use soft hammers for all disassembly work. Do not use pry bars or chisels to separate casing halves and housings or irreparable damage may be caused.

Inspection of expendable parts

Before reassembling the transmission, the individual parts should be carefully checked and any that are damaged should be rejected. These should be renewed. This inspection procedure should be carefully followed to ensure the maximum wear life from the rebuilt unit. The cost of a new part is generally a small fraction of the total cost of downtime and labour. The use of a questionable part may make additional repairs necessary before the next regularly scheduled overhaul. Recommended inspection procedures are set forth in the following check list:

A. Bearings

1. Wash all bearings in clean solvent. Check rollers and races for pits and spalled areas. Renew damaged bearings.
2. Lubricate undamaged bearings and check for axial and radial clearances. Renew bearings with excessive clearances.
3. Check fits of bearings in housing bores. If outer races turn too freely in the bores, the housing should be renewed. Check housing bores for signs of wear prior to taking this action. Renew housing if wear is seen as a result of bearing spin (see Item L).
4. Planet gear bearings consist of two tracks of 18 loose assembled rollers, i.e. 36 rollers per gear, separated by a spacer. If any rollers in a gear set are worn or damaged the whole set must be renewed.

B. Gears

1. Check gear teeth for pitting of the tooth faces. Gears with pitted teeth should be renewed.
2. Check the internal bearing surfaces for wear or the effects of overheating.
3. Check axial clearances of gears. Where excessive clearance is found, check gear, ring and hub for excessive wear. Maintain the specified axial clearance on mainshaft forward gears.

C. Bearing Sleeve - Mainshaft

1. Sleeves with groove formation, pits or which have either been overheated or worn out must be renewed.

D. Synchroniser Assemblies

1. Check to ensure all splines are free from excessive wear.
2. Check that the engagement dog teeth on the sliding sleeves, synchroniser flanges and synchroniser rings are free from chipping and burring.
3. Check that the synchroniser ring cones are not excessively worn or showing the effects of overheating. Check the clearance between the synchroniser ring and the synchroniser flange is between 1.9 mm maximum and 0.5 mm minimum.
4. Renew the springs, plungers and rollers.

E. Splines

1. Check splines on all shafts for wear. If synchroniser hubs, output drive flange or clutch hub have worn into the sides of the splines, the shafts in this condition must be renewed.

F. Thrust Washers

1. Check surfaces of all thrust washers. Washers scored, burnt or reduced in thickness should be renewed.

G. Range Change Planet Gears, Spindles and Needle Roller Bearings

1. If it is found necessary to dismantle the planet gears, retain each gear, spindle, rollers, spacers and washers in their respective set for reassembly in the same relative positions.

2. If uneven wear is found in the planet gears, check lubrication holes for blockage and renew all rollers.
3. Renew planet spindle grubscrews on reassembly.

H. Reverse Idler Gear

1. Check bearings and shaft for wear from action of roller bearings.

I. Clutch Release Parts

1. Check clutch release parts, yokes and bearing carrier. Check pedal shafts. Renew worn shafts and bearings.

J. Gear Selector Shaft Assembly

1. Check forks and keys for wear at contact points. Renew worn parts.
2. Check forks for alignment.
3. Check forks for excessive wear, renew worn forks.
4. Check lockscrew in selector block. A lockscrew with worn taper must be renewed.
5. Check condition and fit of selector key and interlock key in selector shaft. Worn or damaged keys must be renewed.

K. Gear Shift Remote Control

1. Check spring tension on cross shaft. Renew tension springs if shaft moves too freely.
2. If housing is dismantled, check cross shaft and inner lever and the bearing bushes for wear. Renew worn parts.
3. Check all seals and locating journals. Renew worn parts.

L. Bearing Covers

1. Check covers for wear from thrust. Renew covers worn or grooved from thrust of bearing outer race.
2. Check bores of covers for wear. Renew those worn oversize.

M. Oil Return Threads and Seals

1. Check oil seal in front bearing cover for damage and wear, renew if necessary.
2. Check oil seal in speedometer housing for damage or wear, renew if necessary.
3. Check oil seal tracks for wear and renew if worn or grooved.
4. Check the oil sealing rings in the muff ring for wear or breakage.

N. O-Rings

1. Renew all O-rings.

O. Oil Pump

Check the oil pump rotors and covers for scoring and wear. The complete pump assembly must be renewed if scored or excessively worn, or its serviceability is suspect in any way.

Reassembly precautions

Make sure that interiors of all housings are clean. It is important that dirt be kept out of transmission during reassembly. Dirt is abrasive and can damage polished surfaces of bearings and washers. Use certain precautions, as listed below, during reassembly.

- 1. Gaskets** - Use new gaskets where detailed only (neutral detent and remote control housing covers). All other locations, ensure mating faces are clean and undamaged and apply a continuous bead of

Loctite 5205 Flange Sealant to one face only. Do not apply excessive sealant or allow it to penetrate into the bearings.

2. Capscrews - Use thread sealant on all capscrews. The corresponding torque ratings are to be found in 'Torque Tightening Recommendations'.

3. O-Rings - Lubricate all O-rings lightly with silicone lubricant.

4. Initial Lubrication - Lubricate bearings with gearbox oil during reassembly.

5. Axial Clearances - Maintain the end float of mainshaft gears as detailed in the chart on the following page.

6. Bearings - Use of the correct special tools and bearing drivers is recommended for the installation of bearings. Heating the bearing inner tracks where instructed will aid installation.

7. Output Shaft Drive Flange - Tighten the nut to the correct torque.

Do not under any circumstances use an impact wrench to tighten the flange/yoke nut. Use only a hand operated torque wrench or a stall torque motor. Failure to carry out these instructions can cause damage to the locking medium of the nut.

During disassembly and again during reassembly prior to tightening the new nut, it is important to ensure that the output shaft does not slide through the bearing, or the assembled range change synchroniser roller, plungers and springs may be displaced.

A suitable spacer should be temporarily assembled under the nut to allow for the thickness of the nut locking insert to ensure the shaft is firmly held in the bearing until the nut can be torque tightened.

8a. Synchroniser Hubs - All synchroniser hubs are an interference fit on the mainshaft splines and must be heated to approximately 85°C before installation. Press fully home and hold under pressure for a short period to prevent creep while cooling.

8b. - All synchroniser flanges to be lubricated before assembly.

9. Layshaft - The shaft is only available as a complete assembly for service.

Gear End Floats

All dimensions in mm					
Gear	3rd	2nd	1st	Low	Reverse
Low Limit	0.31	0.35	0.35	0.35	0.27
High Limit	0.53	0.48	0.48	0.48	0.44
Range	0.22	0.13	0.13	0.13	0.17

Synchroniser Ring to Synchroniser Flange Clearance

Mainshaft Gears	
- Minimum	0.50
- Maximum	1.90
Range Change	
- Minimum	0.50
- Maximum	1.90

Oil Muff Sealing Ring Clearance

- Minimum	0.178
-----------	-------




Oil Pump Rotor Clearance





- Outer Rotor to Pump Body	0.50 (maximum)
- Inner to Outer Pump Lobes	0.50 (maximum)





Special tools






Some illustrations show the use of specialised tools. These tools are recommended for disassembly and reassembly of the transmission. They make repair easier, faster and prevent damage.




The following tools illustrated are available from V. L. Churchill Ltd.




	LC 105A Bearing remover.
	E 105-4 Countershaft bearing remover. Use with LC 105A.
	E 108 Driver.

	E 108-5 Replacer adaptor for auxiliary countershaft bearing and input bearing. Use with E 108.
	E 108-6 Mainshaft rear seal replacer adaptor.
	E 109 Driver.
	E 109-5 Selector control seal and bush installer. Use with E 109

	E 109-6 Countershaft bearing cup installer adaptor. Use with E 109.
	E 109-7 Input shaft seal installer adaptor. Use with E 109.
	E 109-8 Selector shaft bush installer adaptor. Use with E 109.
	E 109-9 Selector shaft plug installer adaptor. Use with E 109.



	E 109-10 Driver extension. Use with E 109.
	E 109-11 Countershaft bearing cone installer. Use with E 109
	E 109-12 Rear cover oil seal installer. Use with E 109.
	LC 113A Flange holding wrench.
	E 114 Rear mainshaft bearing pilot.

	E 115 Flange holding adaptor plate.
	E 116A Gear assembly lifting fixture.
	E 116-1 Adaptor gear assembly lifting fixture. Use with E 116.
	E 117 Reverse idler shaft retaining pin installer.


	E 118 Sun gear retainer.
	MS 284 Slide hammer.
	MS 284-1 Extractor set - bearing/bush.

Locally made tools

All dimensions in mm

	Mounting plates - 2 off.
 ET-31	Dummy planet gear spindle.

Tool for ball bearing removal.




1. 1 offhole 1.5 inches diameter 16 threads per inch Whitworth from to suit Sykes Picavant hydraulic ram No 150 000.

2. 8 holes 11 mm diameter

Air system

General description



1. Main section

2. Range change section

The Eaton nine-speed synchromesh transmissions consist of a four-speed plus low (crawler) gear and reverse gear main section, and an auxiliary, two-speed range change section. This provides either a direct drive 'high' range or 'low' range output through the medium of an epicyclic reduction gear.

All the forward gears in the main section have synchromesh engagement and are manually selected and engaged. A non-synchromesh low gear is available as an option for the 8209 transmission. The range change also has synchromesh engagement and is air operated. A shift cylinder, mounted in the rear transmission case, slides a synchroniser sleeve, which forms an integral part of the epicyclic annulus gear, into or out of mesh with the planet gear carrier or a reaction plate in the case giving high or low ratio accordingly.

Air to the high and low range ports on the shift cylinder is supplied via a slave valve. This is activated directly by the remote control shaft on the double H shift system, or by a manually operated selector valve in the gear lever knob on the single H shift system.


With the single H shift system, 'high' or 'low' range should be pre-selected before the gear lever is moved, the actual range change taking place only when the selector shaft is moved through the neutral position.

An exhaust air control valve works in conjunction with the interlock to prevent the range change operating prematurely after pre-selection.

With the double H shift system the range change is activated automatically as the gear lever is moved across a detent in the neutral gate between the 3/4 and 5/6 gear lever positions.


Air system maintenance

Single H shift



I = Low range	II = High range
---------------	-----------------


Double H Shift




In order to ensure that the transmission functions without problems and has a long life, the compressed air reservoirs on the vehicle must be drained regularly* and the filter on the transmission cleaned every 80,000 km (or 6 months).

*Please consult the Operating Instructions supplied by the vehicle manufacturer.

Range change shift air lines



Single H shift gear change air line connections




ET/87


Double H shift gear change air line connections

Filter pressure regulator

Filter maintenance



1. Filter pressure regulator	2. Filter element	3. Seal ring
4. O-ring	5. End cap	6. Plug



7. Air supply port	8. Outlet port *
9. Outlet seal plug *	10. Capscrew with lockwasher

* Alternative positions


Removal and disassembly

1. Remove end cap.
2. Remove filter insert from housing and clean. Cleaner: Soap and water solution, cold cleaner etc. then blow element from inside using compressed air.
3. Clean filter regulator housing.

Assembly and installation

1. Renew filter element, seal ring and O-ring if necessary.
2. Fit end cap, tighten to the correct torque.
3. Check filter regulator function. Unscrew seal plug (9), attach test connection with gauge. Recommended operating pressure 5.34 to 5.69 bar.

Selector valve removal and refitment



1. Cowl	2. Socket head screw	3. Base
4. Seal	5. Housing	6. Pressure pad
7. Anti-rattle spring	8. Plunger	9. Compression spring
10. Lever	11. Cap	12. Lock nut
13. Shift lever	- Lubricant (sachet)	

Removal and disassembly

1. Remove cowl.
2. Disconnect all air lines.
3. Loosen lock nut and unscrew selector valve from shift lever.
4. To disassemble the valve remove socket head screw (2).

Note: Take care not to break tang from cap.

5. Thoroughly clean inside of selector valve.

Refitment

1. Renew seal ensuring that it is fitted correctly.
 2. Smear sealing surface of base using lubricant supplied in Service Kit.
- Caution:** Do not use any other type of lubricant.
3. Reassemble valve and tighten socket headed screw to the correct torque.
 4. Screw selector valve onto shift lever and secure with locknut.

Note: Only screw down max. 17 mm, otherwise the housing will be deformed and the valve will leak.

5. Connect all air lines and test for leaks.

6. Refit cowl.

Torque:


Socket head screw (No. 2)	= 10 to 12 Nm.
Air connections	= 2.7 to 3.4 Nm.

Trouble shooting hints


- Check that valve functions correctly.
- Check all air connections for leaks.
- Remove valve from gear lever and check socket head screw (No. 2) for tightness.
- If leaks persist renew the seal (No. 4).

Slave valves

The changeover from 'low' range to 'high' range and vice versa is controlled on single H shift transmissions by means of the selector valve which in turn activates the slave valve, or on double H transmissions by direct mechanical activation of the slave valve by a cam/detent on the remote control shift lever.



Slave valve - Single H shift



Slave valve - Double H shift

Slave valve renewal

Removal

1. Drain the vehicle air reservoirs.
2. Disconnect the air lines from the slave valve.
3. Remove the slave valve either from the mounting bracket $\varnothing$ two capscrews, or from the remote control housing $\varnothing$ two socket headed capscrews.

4. Unscrew and remove the breather valves and elbow/adaptors from the valve, noting the position and port numbers for reassembly to the new valve.

Refitting


1. Clean off sealant from breather valves and elbow/adaptors, and ensure airways are clean and unrestricted. Renew breather valves if their serviceability is in doubt.

The slave valve supplies air to push the shift cylinder piston rearwards into the 'low' ratio position or forwards into the 'high' ratio position as required.

An interlock pin between the selector shaft and the shift cylinder piston shaft only allows the range shift to take place when the gear lever is in the neutral position. With single H shift transmissions this also allows for range changes to be pre-selected.

Additionally the single H system has an exhaust air control valve. This effectively provides a buffer of air on the reverse side of the piston preventing it from moving, until the gear change lever is moved to the neutral position, when this air is exhausted to atmosphere.

The valves are sealed maintenance free units and must be renewed if faulty.



Exhaust air control valve - Single H shift

2. Using PTFE tape or suitable Loctite sealer, install the breather valves, plugs and elbow/adaptors into the valve.


3. **Single H shift slave valve** - Assemble the valve to the mounting bracket, tighten the retaining capscrews to the correct torque.

Double H shift slave valve or single H shift exhaust air control valve - Using a new gasket assemble the slave to the remote control housing, tighten the two socket headed capscrews to the correct torque.

4. Reconnect the air lines, recharge the vehicle air reservoirs and check for correct function and to ensure freedom from air leaks.

Range change shift cylinder

Sectional view of range change shift cylinder



ET-79

1. O-ring	2. O-ring	3. O-ring
4. O-ring	5. O-ring	6. Low range air port
7. Low range	8. High range	9. High range air port

Operation

By switching the selector valve on the gear lever, or by moving the gear lever across the detent between 4th and 5th gears air is supplied by the slave valve to either the high range or low range air port.

Air pressure on the other side of the piston is exhausted to atmosphere through the slave valve. There is a constant air pressure acting against one side or other of the piston at all times.

Trouble shooting

Range change not operating - check air pressure/supply to and from regulator valve and from slave valve to range shift cylinder - See circuit diagrams.

Air leaks from O-rings 1 to 5 in sectional view will result in following faults.

1. External air leak around cover.

Slow or no shift into low range.

2. Air leak into transmission.

Slow or no shift into low range.

3. Slow or no change into high or low range & also air leak out of slave valve breather valves.


4. Slow or no change into high or low range & also air leak out of slave valve breather valves.

5. Air leak into transmission.


Slow or no shift into low range.

Note: O-rings numbered 1, 3 and 4 may be renewed without dismantling transmission.

Range change shift air circuit diagrams




Air circuit diagram - Single H shift - Low range (4th gear) engaged




ET-65

Air circuit diagram - Single H shift - High range preselected




ET-66


Air circuit diagram - Single H shift - Neutral engaged - Exhaust air pressure released - High range engaged



Air circuit diagram - Single H shift - High range (5th gear) engaged



Air circuit diagram - Double H shift - Low range



Air circuit diagram - Double H shift - High range


Single H

Some transmissions may be fitted with a revised air system as shown in the following pages.


The operation of the air system range change is unaltered, only the valves and pipework change.

The slave valve is replaced by an updated valve which connects the two exhaust lines internally and therefore has only a single port.

The exhaust control valve is a single poppet valve which functions in the same way as the former valve.




Slave valve




Exhaust control valve


Range change shift air circuit diagrams (continued)




Air circuit diagram - Single H shift - Low range (4th gear) engaged



Air circuit diagram - Single H shift - High range preselected




Air circuit diagram - Single H shift - Neutral engaged - Exhaust air pressure released - High range engaged




Air circuit diagram - Single H shift - High range (5th gear) engaged

Range change shift air circuit diagrams - with range inhibitor



Air circuit diagram - Single H shift - Low range (4th gear) engaged

1. Power on until preset road speed achieved




Air circuit diagram - Single H shift - High range (5th gear) engaged

1. No power when road speed exceeds preset speed; air supply interrupted

Shifting controls

Remote control, single H -


Exploded view




ET6109-11/2/1

1. Cross shaft	2. Inner striking lever	3. Parallel grooved pin
4. Poppet valve	5. Actuator pin	6. Breather
7. Housing	8. End cover	9. End cover
10. Spring washer M8	11. Screw M8 x 30	12. Expansion plug
13. Bolt M10 x 50	14. Outer lever	15. Spring washer M10
16. Nut M10 x 1.0	17. Boot	18. Oil seal
19. Bush	20. Detent plunger	21. Compression spring
22. Gasket	23. Detent cover	24. Spring washer M8
25. Screw M8 x 14	26. Bush	27. Circlip
28. Spring retainer	29. Compression spring	30. Booster spring
31. Spring retainer	32. Circlip	


Disassembly




1. Remove remote control assembly from the transmission.




2. Support the remote control assembly in a soft jawed vice and remove the exhaust control valve.




3. Note the position of the drop lever and remove the pinch bolt. Remove the drop lever and rubber boot.



4. Remove the reverse detent plunger cover and lift out the spring and plunger.




5. Remove the breather. Remove the four socket head cap screws and the end cover.




6. Remove the circlip and spring retainer. Withdraw the springs.

7. Remove the inner spring retainer and circlip.




8. Invert the housing, slide the remote control shaft and inner lever toward the left-hand end of the housing and carefully drift out the expansion plug.



9. Invert the housing. Align the grooved pin in the inner lever with the expansion plug hole and drift out the pin. Remove the shaft and inner lever.


Reassembly




1. If necessary renew the bearing bushes in the housing. Remove the old bushes using tool MS 284-1 and install the new bushes using tool E 109-5.




2. Renew the oil seal. Install the new seal using tool E 109-5.




3. Locate the inner lever into the housing, long grooved side and retaining pin hole toward the rear. Install the shaft through the housing and the lever from the oil seal end of the housing.




4. Align the inner lever on the shaft and install a new grooved pin, ensuring identification mark is in correct position.



5. Fit the inner circlip and spring retainer onto the selector shaft.




6. Locate the springs and outer retainer on the shaft. Fit outer circlip onto the shaft.




7. Fit the end cover with a new gasket.




8. Apply sealant to the capscrews and tighten to correct torque (20 to 24 Nm).



9. Support the housing assembly in the vice and install the reverse detent plunger and spring. Install the cover using a new gasket and tighten the retaining capscrews to the correct torque.




10. Align both levers and install the boot and outer lever, ball joint tapers facing outwards, on to the shaft. Fit the bolt, nut and washers and tighten to the correct torque. Apply a sealant and install a new expansion plug.



11. Fit the breather. Screw in the exhaust control valve and tighten to 16 to 22 Nm. Apply flange sealant and install remote control. Ensure that the inner lever locates over the selector block.


Remote control, double H

Exploded view




1. Cross shaft	2. Inner lever	3. Grooved pin
4. Screw	5. Valve	6. Gasket
7. Pin	8. Housing	9. Breather
10. Gasket	11. End cover	12. Spring washer
13. Screw	14. Plug	15. Outer lever
16. Bolt	17. Washer	18. Nut
19. Boot	20. Oil seal	21. Bush
22. Plunger - reverse detent	23. Spring - reverse detent	24. Gasket
25. Detent cover	26. Spring washer	27. Screw
28. Bush	29. Spring retaining cup	30. Spring (LH only)
31. Stop washer	32. Spacer	33. Spring
34. Bush	35. Washer	36. Screw


Disassembly




1. Use a 10 mm spanner to push the collar into the air fitting. Pull the pipe out of the fitting.




2. Remove the remote control assembly from the transmission.



3. Support the remote control assembly in a soft jawed vice as shown and remove the two socket headed capscrews retaining the slave valve. Remove the slave valve and gasket.




4. The slave valve may be fitted in the end cover of the remote control.



5. Remove the shift lever and boot. Note position of drop lever on cross shaft.




6. Remove the reverse detent plunger cover and lift out the spring and plunger.




7. Remove the breather. Remove the four socket headed capscrews and the end cover.

Caution: The spacer or sleeve may be pushed out by the spring.




8. Remove the capscrew from the end of the shaft and remove the retaining bush, spring and the spacer.


Note: A circlip is fitted on models with the slave valve fitted in the end cover.



9. Remove the sleeve, spring cap and stop washer.




10. Invert the housing, slide the remote control shaft and inner lever toward the left-hand end of the housing and carefully drift out the expansion plug.



11. Invert the housing. Align the grooved pin in the inner lever with the expansion plug hole and drift out the pin. Remove the shaft and inner lever.


Reassembly




1. If necessary renew the bearing bushes in the housing. Remove the old bushes using tool MS 284-1 and install the new bushes using tool E 109-5.




2. Renew the oil seal. Install the new seal using installer tool E 109-5.



3. Locate the inner lever into the housing, long grooved side and retaining pin hole toward the rear, and install the shaft through the housing and the lever from the oil seal end of the housing.




4. Align the inner lever on the shaft and install a new grooved pin, ensuring identification mark is in correct position.




5. Install the spring retaining cup on the shaft and the springs and stop washer in the housing.

Note: Install the spring retaining bush on to the end of the shaft.




6. Fit the spacer (left hand variants only), apply sealant (Loctite 242) to the retaining capscrew (or fit a new patch-lock screw) and tighten to the correct torque, compressing the spring(s).




7. Install the stop ring, and locate the end cover with a new gasket to the housing, compressing the spring(s) into the housing.




8. Apply sealant to the cap screws and tighten to the correct torque (20 to 24 Nm).




9. Support the housing assembly in the vice and install the reverse detent plunger and spring. Install the cover using a new gasket and tighten the retaining cap screws to the correct torque.



10. Align both levers and install the boot and outer lever, ball joint tapers facing outwards, on to the shaft. Fit the bolt, nut and washers and tighten to the correct torque. Apply a sealant and install a new expansion plug.



11. Apply sealant and fit the breather. Install the slave valve using a new gasket. Position the valve with the two outlet ports facing the left-hand side of the housing and tighten the socket headed bolts to the correct torque.




12. Apply flange sealant and install the remote control, making sure that the inner lever locates over the selector block. Fit and tighten the capscrews to the correct torque.

Transmission overhaul

Transmission case


Exploded view (horizontal transmission)



1. Front case	2. Plug	3. Gasket
4. Cover	5. Spring washer M10	6. Screw M10 x 20
7. Screw M10 x 20	8. Hose clamp	9. Lifting eye
10. Washer M10	11. Nut M10	12. Bolt M10 x 55
13. Washer M10	14. Nut M10	15. Washer M16
16. Plug M16	17. Plunger	18. Spring
19. Cover	20. Screw M8 x 14	21. Spring washer M8
22. Gasket	23. Screw	24. Oil trough
25. Bush	26. Dowel	27. Bolt M10 x 55
28. Screw M10 x 35	29. Washer M10	30. Spring washer M10
31. Lifting eye	32. Spring washer M12	33. Screw M12 x 25
34. Intermediate case	35. Bush	36. Gasket
37. Cover	38. Washer M10	39. Screw M10 x 20
40. Washer M24	41. Filler plug	42. Reverse light switch/range switch
43. Ball	44. Bolt M10 x 55	45. Washer M10
46. Nut M10	47. Spring washer M10	48. Bolt M10 x 30
49. Oil pump assembly	50. Dowel	51. Bush

52. Washer	53. Plug	54. Reverse light switch/range switch
55. Screw M10 x 20	56. Washer M10	57. Hose clamp
58. Plug	59. Washer	60. Spray bar
61. Lifting eye	62. Washer M10	63. Bolt M10 x 55
64. Oil strainer	65. Washer M40	

Exploded view (vertical transmission)




1. Screw M12 x 25	2. Spring washer M12	3. Bearing cover
4. Screw M8 x 20 (overdrive)	5. Washer M8 (overdrive)	6. Rotation pin (overdrive)
7. Front case assembly	8. Plug	9. Screw M8 x14
10. Spring washer M8	11. Cover	12. Gasket
13. Spring	14. Plunger	15. Screw M10 x 35
16. Spring washer M10	17. Washer M10	18. Lifting eye
19. Dowel	20. Bush	21. Bolt M10 x 55
22. Washer M10	23. Nut M10	24. Plug M24
25. Washer M24	26. Dowel	27. Bush
28. Reverse switch (or plug and washer)	29. Neutral switch (or plug and washer)	30. Detent ball
31. Intermediate case	32. Lifting eye	33. Interlock pin
34. Range switch (or plug and washer)	35. Bush	36. Washer
37. Bolt M10 x 30	38. Spring washer M10	39. Oil pump assembly
40. Cover	41. Spring washer M10	42. Screw M10 x 20
43. Oil strainer assembly	44. Washer	45. Bolt M10 x 55 or M10 x60
46. Washer M10	47. Nut M10 x 1.5	48. Cover
49. Spring washer M10	50. Screw M10 x 20	51. Washer M10
52. Bolt M10 x 40		

Disassembly


Caution: Drain the oil from the transmission and clean and refit the drain plugs and filler plugs.

Note: The transmission illustrated in this section is a standard ratio vertically installed unit. The procedure is the same for all transmissions but the physical size and number of teeth on some of the gears will vary from those illustrated on overdrive ratio models. Horizontally installed units have the remote control on the side of the transmission and alternative filler and drain plug positions.


It is recommended that the transmission is overhauled, mounted on the stand illustrated. If a stand is not available the transmission should be stood on wood blocks on the clutch housing until it is inverted. It should then be stood on the rear flange of the intermediate case on the blocks, taking great care not to damage the case flange, to complete the removal of the mainshaft.




1. Mark the hoses to ensure reassembly to the correct ports and disconnect the hoses from the transmission.




2. Remove the slave valve and mounting bracket (when mounted on the transmission). Protect the valve and hoses from dirt ingress.




3. Remove the filter/pressure regulating valve and mounting bracket.




4. If not already removed, remove the two casing flange bolts from each side of the transmission, adjacent to the mounting flanges, and secure the mounting plates to the flanges.




5. Using a hoist, mount the transmission onto the stand.



6. Ensure neutral is engaged and remove the remote control housing capscrews. Using a soft faced mallet if necessary, separate the housing from the transmission.




7. Remove the speedometer adaptor and drive pinion, when fitted, taking care not to damage the seal.



8. Using a flange holding wrench, slacken but DO NOT REMOVE the flange retaining nut. Break the retaining torque only.

Warning: Do not allow the output shaft to slide in the bearing or the range change synchroniser may spring apart.




9. Rotate the transmission on the stand to the vertical position, rear end uppermost.




10. Unscrew and remove the oil strainer, remove and discard the O-ring (if fitted) and washer.


Note: A plug/washer only may be fitted on some multi-purpose specification transmissions fitted with an integral strainer.




11. Remove the reverse lamp switch. Remove the range indicator and neutral switches, collect the ball from each bore as the switches are removed.



12. Use a magnet or tap the case gently to release the balls if necessary.




13. Remove the capscrews and nuts securing the rear end case to the intermediate case.



14. Attach a sling and hoist to the output drive flange.


Note: Attach the sling so as to lift the rear case as near vertically as possible.




15. Raise the hoist and separate the rear case from the intermediate case. Use a soft faced mallet if necessary to aid separation. Do not use pry bars or levers or the case flanges may be damaged.




16. Using tool E 118 to lock the sun gear, unscrew and remove the sun gear retaining bolt and the special washer.




17. Lift off the sun gear.




18. Lift out the muff ring taking care not to damage the two sealing rings.



19. Remove the capscrews securing the oil pump assembly to the transmission. On some multi-purpose specification transmissions, the oil strainer assembly and bracket must be removed.




20. Using a pry bar under the lugs provided, prise the pump off the locating dowels. Lift out the pump assembly.



ET6109-9/2/1

Reverse idler gear assembly


1. Thrust washer	2. Needle roller bearing	3. Spacer	4. Gear, reverse idler
5. Thrust washer	6. Shaft	7. Parallel groove pin	



21. Remove the rear PTO cover. Using the tool E 117, or an 8 mm punch, drive the reverse idler gear shaft roll pin inwards until the end is approximately 12 mm from the face of the hole. Do not allow the pin to 'bottom' against the shaft bore.



22. Screw the slide hammer MS 284 into the rear of the reverse idler gear shaft and withdraw the shaft from the case. Remove the pin from the shaft.




23. Remove the reverse idler gear and bearings and the two thrust washers from the case.



24. Remove the mainshaft bearing thrust washer to prevent loss and invert the transmission assembly on the stand.


Note: If a ball bearing is fitted, the thrust washer cannot be removed at this point.




25. Collect the range change/selector shaft interlock pin, located in the bore between the selector rods, as the transmission is inverted using a magnet if necessary.



26. Remove the detent spring cover plate, spring and plunger or screw-in detent assembly from the front case. Certain specifications have a range inhibitor valve fitted over the detent cover.




27. Rotate the gear selector shaft 90 degrees to the left (vertically mounted) or right (horizontally mounted) so that the case will not foul the selector block on removal.



28. On overdrive models, remove the capscrews retaining the two overdrive fork pivot pins and remove the pins.




29. Remove capscrews and nuts securing the front case to the intermediate case. Note the position of the shorter capscrews threaded into the case. Horizontal transmissions have a spray bar locating screw on the front face of the front case. Remove this screw before removing the front case.




30. Using a soft faced mallet to break the compound seal, separate the front half case (complete with the input shaft) from the intermediate case. Do not use pry bars or chisels to separate the case or the flanges may be damaged.


Note: If difficulty is experienced separating the two casing halves the input shaft synchroniser flange may have become fixed to the shaft. Should this occur, remove the input shaft cover and bearing outer snap ring, and while lifting the front case half, tap the input shaft with a soft faced mallet to drive the shaft and bearing through the case bore.




31. Remove the spigot bearing. On horizontal transmissions a restrictor is fitted to the roll pin in the end of the mainshaft.



32. On the overdrive models, to prevent loss or damage, disengage and remove the overdrive fork assembly from the 3rd/4th gear synchroniser sleeve and selector. Take care not to lose the selector pads.




33. On transmissions fitted with a ball bearing in the rear mainshaft position, use the locally made tool to release the inner race.




34. Assemble the tools E 116A and E 116-1 under the 3rd/4th gear synchroniser hub assembly and using the hoist raise the shaft approximately 10 to 20 mm. This allows the layshaft to tilt clear of the mainshaft.



35. Lift out the layshaft.




36. Raise the hoist and lift out the mainshaft and selector shaft as an assembly. Carefully lower onto a clean bench and remove the tool. Separate the selector shaft and forks from the mainshaft.




37. Drift out the mainshaft rear bearing from the case using a suitable tool. Do not allow the bearing to fall to the floor.




38. Drift out the layshaft rear bearing and bearing spacer (where fitted) using tool E 108-5.




39. Remove the capscrews securing the input shaft cover to the front case half. On direct drive models remove the input shaft and bearing assembly. Certain specifications have an O-ring seal/plate which must be removed before removing the input shaft cover.



40. On overdrive models remove the input shaft bearing outer snap ring, and carefully drive the input shaft and bearing through the case.




41. Use a soft faced mallet to drive the shaft through the case taking care not to allow the shaft to fall and become damaged.



42. Remove the layshaft front bearing retaining plate and graded spacer from the front case half. Drift out the layshaft front bearing cup using a suitable tool.

Rear case

Exploded view




ET6109-6/2/1

1. Screw M8 x 20	2. Reaction plate retainer	3. Reaction plate
4. Syncro flange, range	5. Circlip	6. Spacer
7. Dowel 16 dia x 30	8. Rear case	9. O-Ring
10. Bush	11. O-Ring	12. Range piston
13. Range piston O-Ring	14. Range bar O-Ring	15. Rangecover O-Ring
16. Nut M16	17. Range cylinder	18. Washer M10
19. Spring washer M10	20. Bolt M10 x 60	21. Speedo drive gear
22. Spacer/rotor	23. Adaptor bush/oil seal assembly	24. Washer
25. Speedo pinion	26. Bush	27. Speedo housing
28. Bearing	29. Rear cover, oil seal	30. Oil seal
31. Washer M10	32. Spring washer	33. Bolt M10 x 100
34. Output flange	35. Nyloc nut M39	36. Rear PTO cover
37. Spring washer M12	38. Screw M12 x 25	39. Planet carrier assembly
40. Syncro flange	41. Circlip	42. Syncro ring, range
43. Gear annulus	44. Range shift rod	45. Grooved pin
46. Range shift fork	47. Circlip	48. Sliding sleeve, range
49. Circlip	50. Syncro plunger	51. Sychro plunger

52. Compression spring	53. Fixed hub, syncro range	54. Bearing, synchro hub
55. Circlip	56. Circlip	

Disassembly




1. Support the rear case assembly on a suitable clean block or spacer under the range change epicyclic. Remove the capscrews securing the range change cylinder cover to the rear case and remove the cover.



2. Remove the nut retaining the range change piston to the shaft. Remove the piston.



3. Remove the output drive flange retaining nut and the drive flange. Note that the flange boss is a close fit in the bearing inner track.



4. Carefully lift the case allowing the output shaft to slide out of the bearing and the range change selector rod to slide out of the bush.




5. Remove the selector fork assembly from the synchroniser sliding sleeve. Lift off the electronic tachograph sensor ring and spacer or the speedometer drive gear and spacer (as fitted).




6. Lift off the synchroniser ring.




7. Put identifying marks on the synchroniser sliding sleeve in line with the synchroniser plungers, if not already marked, and remove the sleeve and annulus assembly.




8. Note the position of the spring plungers and rollers and remove them from the hub. Remove the snap ring securing the synchroniser hub bearing to the output shaft.




9. Invert the assembly and while restraining the hub, drop the end of the shaft onto a stout wood block to shock the hub and bearing assembly off the shaft.



10. Remove the snap ring securing the synchroniser flange to the planet carrier.




11. Remove the synchroniser flange.




12. Remove the four socket headed countersunk screws and special washers retaining the rear "low" synchroniser flange and reaction plate to the rear case.



13. Lift out the reaction plate and the rear (low) synchroniser flange.



14. Lift out the spacer plate. On some multi-purpose specification transmissions an additional oil seal may be fitted in the rear case.




15. If necessary remove the special snap ring from the synchroniser flange.




16. Remove the four capscrews retaining the oil seal carrier and the output shaft bearing housing, remove the oil seal carrier.



17. Remove the bearing housing.




18. If necessary drive the bearing out of the housing using a suitable drift.



19. If necessary remove the bearing retaining snap ring from the range change synchroniser hub and remove the bearing.



20. To separate the annulus from the sliding sleeve, insert a rivet or steel pin, approximately 2-2.3 mm diameter and 10 mm long, into at least three of the holes in the annulus ensuring they are abutting the internal snap ring.




21. Tighten a large (air cleaner) hose clip around the rivets or pins to compress the internal snap ring into the sliding sleeve.



22. Slide the sliding sleeve from the annulus.



23. Separate the range change selector fork from the piston rod by drifting out the grooved pin with a suitable punch.




24. Remove the rear PTO cover plate from the rear of the rear case. Unscrew the air supply adaptors from the rear case.

Planet gear carrier

Exploded view


Planet gear and bearings




ET6109-7/3/1

1. Planet gear spindle	2. Thrust washer	3. Thrust washer	4. Needle roller
5. Planet gear	6. Spacer	7. Grub screw	8. Output shaft and planet carrier

Disassembly




1. Remove the bearing spindle retaining screws from the planet gear carrier. The screws are peened so that the area around the screw has to be drilled out before the screw is removed.




2. Using a soft faced mallet and suitable drift, drive the bearing spindle out of the carrier in the direction illustrated.

Note: The spindle is shouldered and MUST NOT be driven the other way.




3. Slide the gear, bearing rollers, spacers and thrust washers from the carrier. Repeat these operations for the other four gears.


Reassembly




1. **Assembling original parts.** Place one thrust washer, grooved face downwards, and one shim on a flat plate. Place the dummy spindle into the washer and shim and load 18 rollers around the spindle using petroleum jelly to hold them in place.




2. Place the spacer over the dummy spindle and load a further 18 rollers around the spindle.




3. Carefully assemble the planet gear over the assembled dummy spindle. Place the second shim followed by the second thrust washer, grooved side up, over the dummy spindle and rollers.




4. **Assembling new roller bearing pack.** Take the new bearing pack and slide the rollers and plastic centre tube out of the outer tube, just sufficient to allow the rollers to be guided into the planet gear. Push the rollers and centre tube fully into the gear.




5. Without disturbing the centre tube, carefully prise out one end cap and assemble a shim and then a thrust washer, grooved side facing the planet carrier, over the centre tube. Repeat the operation at the other end of the gear assembly.



6. Support the output shaft in a soft jawed vice, planet carrier uppermost and slide the assembled gear into position in the carrier.




7. Slide in the gear assembly until the dummy spindle or tube aligns with the holes in the carrier. Support the dummy spindle, if used, to stop it falling out and insert the planet gear spindle, shouldered end uppermost, into the carrier.




8. Ensure the locating hole in the spindle aligns with the hole in the carrier and drive the spindle into the carrier using a soft faced mallet.

Note: There is a lubrication hole directly opposite the locating hole. Do not align the wrong holes.




9. Ensure the threads are clean and dry and install a new locating grub screw, using thread locking sealer Loctite 270. Tighten to the correct torque and repeen with a suitable drift. Repeat sub-operations 1-9 for the remaining gears.


Casing bushes - renewal



1. **Selector shaft bushes - front and intermediate cases.** Use an internal type extractor as illustrated to remove the bushes from the front and intermediate cases.




2. Renew the blanking cup plug (front case only) using the small end of tool E 109-9 and drive it in from the inside face. Drive in the new selector shaft bushes using the other end of the tool.



3. **Range change selector rod bush - intermediate case.** Remove the bush toward the rear using an internal type extractor.



4. Install the new bush until flush with the face of the case bore using tool E 109-5. The bush is prefinished to the correct size.



5. Remove any burrs from the edge of the bush using a fine file or slip stone and check the fit of the selector rod in the bore.



6. Range change selector rod bush - rear case. Drift out the rear bush complete with carrier from the rear case.



7. Install a new O-ring into the groove on the outer periphery of the bush carrier. Lubricate sparingly with silicone grease.



8. Install the bush carrier until the O-ring has just entered the case. Wipe off any surplus grease and apply sealer (Loctite 641) around the exposed part of the bush carrier and drive it into the case using tool E 109-5.




9. Install a new O-ring into the range change selector rod rear bush carrier. Lubricate with silicone grease.


Rear case reassembly




1. Support the range change selector fork and install the selector rod, threaded end to the plain side of the fork



2. Align the retaining pin holes so that with the threaded end of the selector shaft to the left, the interlock detents are facing you. Install a new grooved pin.



3. Install the snap ring into the range change synchroniser hub and place the bearing into the hub against the snap ring.



4. Install the second snap ring to retain the bearing in the hub.



5. Stand the annulus, plain end down, on a clean bench. Locate the snap ring in the synchroniser sleeve, place the sleeve in the annulus and align the snap ring so that the ends are positioned midway between any two holes in the annulus.




6. Compress the snap ring and push the sleeve into the annulus until the snap ring expands into the annulus locking the two parts together. If necessary use a hose clip to compress the snap ring.




7. Stand the output shaft assembly on a firm support or block approximately 100 mm thick and place the synchroniser flange over the locating splines. Install the retaining snap ring.



8. Place the synchroniser ring over the synchroniser flange. Press the cone firmly down and, using feeler gauges, measure the clearance between the ring and the flange. Renew the flange and ring if the clearance is not within specification.



9. Place the synchroniser hub and bearing assembly onto the shaft aligning the slots in the hub with the shoulders on the synchroniser ring. Use a soft mallet and drift or mandrel to ensure the bearing is fully home against the stop.




10. Install the retaining snap ring.




11. Install the plungers and springs in the slots and slide the annulus and sliding sleeve assembly over the planet gears, aligning the marks on the sleeve and the middle slot of each group of three in the hub.




12. Support the sleeve in the slightly raised position and install the rollers in the groove and resting against the heads of the plungers. Press the sleeve down to the neutral position.




13. Place the 'low' synchroniser ring into the synchroniser hub.




14. Support the rear case on wooden blocks and place the spacer ring into the recess in the rear case.




15. Install the large snap ring into the slot around the outer periphery of the low synchroniser flange.




16. Place the synchroniser flange and snap ring onto the spacer ring. On some multi-purpose specification transmissions an additional oil seal should be fitted in the rear case. This should not block off the oil feed hole in the output shaft.




17. Place the reaction plate over the synchroniser flange splines.




18. Install the four locating plates. Tighten the screws to the correct torque.




19. Locate the selector fork and shaft assembly into the synchroniser sleeve, threaded end of shaft uppermost.



20. Invert the partly assembled case, ensure that the selector shaft bore O-ring is in position and lubricated with silicone grease and locate the case over the output shaft and selector rod.



21. Place the speedometer drive gear or spacer over the output shaft.




22. Place the tachograph sensor ring or spacer over the output shaft.


Note: an equivalent thickness spacer must be used if either the speedo gear or sensor ring is not fitted.




23. Install the output shaft bearing in the housing using a soft faced mallet and a suitable tool.




24. Install a new oil seal into the carrier using tool E 109-12.




25. Apply sealant to the face of the case. Place the bearing and housing assembly over the shaft and against the case.



26. Apply sealant to the face of the bearing housing and install the oil seal and carrier assembly.




27. Apply sealant to the four capscrews and tighten to the correct torque.



28. Apply a smear of grease to the inner periphery of the oil seal and install the output drive flange. Temporarily place a spacer against the flange and fit the nut. Tighten firmly.

Note: Flange boss fits inside bearing track.




29. Apply sealant and fit the rear PTO aperture cover. Tighten the capscrews to the correct torque.

Input shaft

Exploded view

Input shaft assembly




ET6109-3/2/1

1. Circlip 65 mm diameter	2. Spacer	3. Bearing	4. Input shaft
---------------------------	-----------	------------	----------------

Disassembly



1. Support the input shaft and remove the snap ring. Remove the selective fit spacer.



2. Support the bearing on a press or using a suitable puller press the shaft through the bearing track. Remove the bearing thrust ring.

On horizontal specifications, a spacer is fitted behind the bearing.

Reassembly

Note: Heat the bearing assembly thoroughly to approximately 85°C before assembly. This greatly eases assembly and in most cases the bearing track will fit over the shaft without the need to drift it in place.



1. Support the heated bearing assembly, inner track downwards, on a suitable tube and install the input shaft through the bearing. Use the press, or a soft faced mallet to ensure the bearing is firmly against the gear.

Note: On horizontal specifications, refit the spacer before fitting the bearing.



2. Place the original spacer against the bearing and check that the snap ring fits into its groove without free play. Check at several places around the diameter of the shaft. If there is too much free play, or the snap ring does not fit into the groove, a new thicker or thinner spacer respectively is required in place of the original.

Graded spacers are available in the following thicknesses, colour coded as indicated in the table. See Parts List for part numbers.

Thickness (mm)	Colour coded stripes		
3.70	Red	Green	White
3.75	Yellow	Green	Blue
3.80	Blue	Green	White
3.85	Red	Green	Yellow
3.90	Green	Green	White
3.95	Red	Green	Red




3. When the correct thickness spacer has been selected and fitted, fit the new snap ring.

Layshaft

Exploded view

Layshaft assembly




1. Spacer 2.5/2.3 mm	2. Shim	3. Circlip
4. Taper roller bearing	5. countershaft assembly	6. Taper roller bearing


Disassembly



1. Support the shaft assembly and remove the graded circlip retaining the front taper roller bearing.



2. Use tools LC 105A and E 105-4. Remove the bearing cone and roller assembly




3. Support the shaft and remove the rear bearing cone and taper roller bearing assembly using the same puller and adaptor.

Reassembly




1. Heat the layshaft taper roller bearing inner races to 85°C. Support the shaft assembly forward end uppermost and place the heated inner cone and roller assembly onto the shaft. Use a suitable mandrel to make sure bearing is fully home.



2. From the range of graded fit circlips, select the circlip which fits into the groove with the minimum free play.

Circlips are available in the following sizes and Part Numbers.

Part Number	Thickness (mm)
8870370	2.12
8870371	2.07
8870372	2.02
8871536	1.97
8871537	1.92
8871538	1.87
8871539	1.82
8871540	1.77



3. Fit the circlip using circlip pliers.




4. Invert the layshaft assembly and fit the heated rear taper roller bearing inner race onto the shaft. Make sure the bearing is fully home using a suitable mandrel.

Mainshaft

Exploded view

Mainshaft exploded view



ET6109-2/2/1

1. Needle roller bearing	2. Circlip 40 dia. x2.02/2.07/2.12 mm	3. Synchro flange 3rd/4th
4. Synchro ring	5. Sliding sleeve 3rd/4th	6. Fixed hub 3rd/4th
7. Synchro roller	8. Synchro plunger	9. Compression spring
10. Mainshaft gear (3rd or overdrive)	11. Spacer	12. Needle roller bearing
13. Circlip 46 dia x 2.00 mm	14. Bearingsleeve, 2nd gear	15. Needle roller bearing
16. Mainshaft gear, 2nd	17. Synchro flange 1st/2nd	18. Synchro ring
19. Sliding sleeve 1st/2nd	20. Fixed hub 1st/2nd	21. Mainshaft gear, 1st
22. Spacer	23. Needle roller bearing	24. Spirol pin
25. Mainshaft	26. Needle roller bearing	27. Mainshaft gear, low
28. Synchro flange, low/rev	29. Synchro ring	30. Fixed hub, low/rev
31. Circlip 60 dia x 2.00/2.05/2.10	32. Sliding sleeve, low/rev	33. Circlip
34. Synchro flange, reverse	35. Mainshaft gear, reverse	36. Needle roller bearing
37. Thrust washer	38. Output bearing	39. Sealing ring
40. Oil muff	41. Sun gear	42. Sun gear retainer
43. Screw M16 x 45		

Note: All snap rings and the circlip on the shaft are graded for selective fit. Take care not to score the bearing surfaces of the mainshaft when removing the snap rings.


Note: End float of the gears on the shaft is established in manufacture by machining the components to fine tolerances. Before disassembly of the mainshaft the end floats should be checked to ascertain whether they are within the recommended limits.

Where end float is found to be excessive it is necessary to check the gears, mainshaft, synchroniser hubs and bearing sleeve for wear. See Inspection of expendable parts and renew where necessary.

Retain the synchroniser rings and flanges in their respective pairs for assembly in the same relative positions.


End float check

End float may be checked with the shaft assembled by using a dial gauge as shown.




1. Mount the mainshaft assembly vertically on a suitable stand. Locate the dial gauge on the gear, zero the gauge. Raise the gear by hand and record the reading.

Disassembly




1. Remove the hollow dowel pin from the shaft. Support the shaft and slide the 3rd/4th gear synchroniser sleeve upward until the three rollers are clear of the groove in the sleeve. Remove the rollers, the sleeve and the plungers and springs from the synchroniser fixed hub.


Note: On horizontal specifications a restrictor is fitted to the dowel pin.




2. Remove the 3rd/4th gear synchroniser hub retaining circlip.




3. Assemble the puller plates over the 3rd/4th gear synchroniser hub and the 3rd gear synchroniser ring and press off the hub, cone and ring, taking care not to damage the synchro ring teeth.



4. Lift off the third gear and 3rd gear needle roller bearing and spacer ring. Note the position of the spacer ring for reassembly.




5. Invert the shaft assembly in the press and using suitable puller plates under the reverse gear remove the gear, thrust washer and bearing track. Remove the reverse gear needle roller bearing.




6. Lift out the reverse gear flange from the synchroniser hub.


Note: There is no synchroniser ring for reverse gear.




7. Remove the large internal snap ring from inside the reverse/low synchroniser hub.



8. Slide the reverse/low gear synchroniser sleeve carefully rearwards until the three rollers are clear of the groove in the sleeve. Remove the rollers, the sleeve and the three plungers and springs from the synchroniser hub.




9. Remove the reverse/low synchroniser hub retaining snap ring.



10. Assemble puller plates under the low gear and support on the press.

Note: It is imperative that low gear is supported and that the remainder of the gears and shaft do not foul the press bed or supporting blocks when the shaft is being pressed through. Press the shaft through low gear and the low/reverse synchroniser hub.


On 8209 specifications with non-synchromesh crawler, there is a second snap ring on the other side of the hub. This snap ring should be left in place.



11. Remove the low gear needle roller bearing. Separate the low gear synchroniser hub, flange, ring and gear.




12. Invert the shaft and remove the 2nd gear bearing sleeve retaining snap ring.




13. Support the shaft on the press under 1st gear.

Note: It is imperative that 1st gear is supported and that the flange on the shaft does not foul the supporting blocks or press bed when the shaft is being pressed through. Press the shaft through 1st gear, 1st/2nd gear synchromesh hub and 2nd gear bearing sleeve.

Do not allow the shaft to drop through and become damaged or scored. Separate the gears, 2nd gear bearing and bearing sleeve and the synchroniser flanges and rings.




14. Remove the 1st gear needle roller bearing and bearing spacer ring.




15. Dismantle the 1st/2nd synchroniser hub as previously described in sub-operation 1.

Reassembly



Note: The following parts must be heated to the temperatures recommended prior to assembly. Place the parts on a hotplate or in a temperature controlled oven for not less than 30 minutes to make sure they are thoroughly heated before placing them in position. Once fitted and cooled the parts will shrink to an interference fit.


Synchroniser hubs (3 off)	85°C
2nd gear bearing sleeve	
Mainshaft rear bearing inner track	




1. Before assembling the synchroniser assemblies on the mainshaft, check the fit of each synchroniser ring to its flange. Place the synchroniser ring onto its mating flange and while holding the two parts firmly together, measure the clearance between the two rings using feeler gauges at several points around the circumference as shown. Renew both parts if the measurement is not within the specified limits.

Note: The reverse gear is fitted with a flange which engages with the sliding sleeve and which is similar in appearance to a synchroniser flange. The conical face however is not machine finished and


no synchroniser ring is fitted to the assembly for reverse gear.




2. Support the mainshaft rear end uppermost. Fit the low gear bearing.




3. Lubricate the bearing with clean gear oil and fit the low gear over the bearing.



4. Fit the low gear synchroniser flange to the gear and the synchroniser ring to the flange, where fitted.




5. Take the heated reverse/low synchroniser hub and place it over the splines, internal snap ring side uppermost and slots aligned with the shoulders on the synchroniser ring. Press fully home and hold under pressure for 3 to 4 minutes. If there is a second snap ring fitted on the hub, this snap ring should face downwards.



6. From the range of graded snap rings select the thickest one which fits into the groove with the minimum free play.




7. Install the snap ring in the groove taking care not to damage the mainshaft bearing surfaces.




8. Check that the gear end float is within the tolerances stated in the chart.



9. Assemble the three springs and plungers into the synchroniser hub. Place the synchroniser sleeve over the hub, pointed teeth downwards, and support it with the internal annular groove just above the hub. Position the three rollers as shown, resting on the heads of the plungers, and press downward on the sleeve.




10. Install the special snap ring into the synchroniser hub ensuring the tongues are properly located in the slots in the hub.




11. Install the reverse gear flange into the synchroniser hub.

Note: No synchroniser ring is fitted to reverse gear.




12. Lubricate reverse gear bearing and install the bearing and reverse gear onto the shaft and into the reverse gear flange.



13. Place the reverse gear thrust washer, chamfered side uppermost against the gear.


Note: Some 8209 specifications have an integral thrust washer on the rear bearing inner race.




14. Take the heated mainshaft rear bearing inner track and fit it over the shaft, flange against the thrust washer. Use a soft drift or flanged driver to ensure bearing is fully home against the washer.

Note: When cooled, the bearing track should be sufficiently tight on the shaft to retain the reverse gear on the shaft.


Note: Tool E 114 may be fitted at this stage as a precaution only to retain the bearing on the shaft. It must not be used to retain a loose bearing on the shaft. If the bearing is loose, the cause must be investigated and a new bearing and/or shaft fitted.




15. Invert the shaft in the vice, lubricate and install the 1st gear bearing and 1st gear.




16. Install the bearing spacer ring into the gear and against the bearing.




17. Install the 1st gear synchroniser flange over the gear and the synchroniser ring over the flange.




18. Support the mainshaft on the press. Place the heated 1st/2nd synchroniser hub over the splines on the shaft. Align the slots with the shoulders on the synchroniser ring and press the hub fully home.




19. Check that the gear end float is within the tolerances stated in the chart.



20. Assemble the three springs and plungers into the hub and install the 1st/2nd gear synchroniser sleeve and rollers as described in sub-operation 9.




21. Place the 2nd gear synchroniser ring and synchroniser flange onto the synchroniser hub assembly.



22. Lubricate the 2nd gear and bearing and position the gear into the synchroniser ring and the bearing into the gear.


Note: A smear of petroleum jelly applied to the outer edge of the bearing will support the bearing to stand proud of the gear and ease the alignment of the bearing sleeve in the next operation.



23. Take the heated 2nd gear bearing sleeve and locate it inside the bearing and over the shaft. Use the press to ensure the sleeve is firmly home against the synchroniser hub.




24. From the range of graded snap rings select thickest one which fits into the groove with the minimum free play.




25. Fit the snap ring into the groove taking care not to damage the mainshaft bearing surface.




26. Check that the gear end float is within the tolerances stated in the chart.




27. Lubricate the 3rd gear bearing and install the bearing and 3rd gear onto the shaft.




28. Place the 3rd gear bearing spacer ring into the gear against the bearing.




29. Position 3rd gear synchroniser flange and synchroniser ring onto 3rd gear.




30. Take the heated 3rd/4th synchroniser hub and place it, boss side downwards on the shaft. Ensure that the slots in the hub align with the shoulders on the synchroniser ring. Press the hub fully home and hold under pressure for 3 to 5 minutes.




31. From the range of graded circlips select the thickest one which fits into the groove with the minimum free play.




32. Fit the circlip into the mainshaft.



33. Check the gear end float using feeler gauges.



34. Assemble the three springs and plungers into the hub and install the synchroniser sleeve and rollers as described in sub-operation 9.



35. Fit the roll pin into the end of the shaft.


Selector shaft

Disassembly




1. Place selector assembly on bench with selector block to the left. Mark the front of the shaft and keys to aid reassembly.

On double H transmissions, remove the tapered capscrew from the selector block.



2. Hold the assembly by the selector block and withdraw the interlock key from the rear.

On double H transmissions hold the selector block and 1st/2nd fork and withdraw the selector shaft towards the right.




3. Remove the selector forks from the shaft. Remove the capscrew from the selector block and slide the block off the shaft.

Selector shaft - Single H


Exploded view

Selector shaft assembly (vertically mounted unit) - Single H



1. Rotation pin	2. Shift pad	3. Overdrive fork
4. Overdrive selector	5. Selector key	6. Selector shaft
7. Interlock key	8. Selector fork 3rd/4th	9. Pin
10. Locating screw	11. Selector block	12. Selector fork 1st/2nd
13. Selector fork, low/rev		

Reassembly




1. Place selector key into slot on the selector shaft with the three small lugs to the front.




2. Put the selector block onto the shaft and tighten the capscrew to 35 to 39 Nm.


Note: If reusing the screw apply Loctite 270 to the threads before fitting.



3. Place the forks in their respective positions on the selector shaft.



4. Support the selector shaft and slide in the interlock key from the rear.




5. On overdrive units the 3rd/4th fork is replaced by a selector. Check the fit of the selector before assembling the transmission.

Selector shaft - Double H

Exploded view

Selector shaft assembly (vertically mounted unit) - Double H



Overdrive assembly is similar to single H overdrive assembly

1. Pin	2. Tapered capscrew	3. Selector block
4. Selector fork 3rd/4th	5. Selector fork 1st/2nd	6. Selector fork low/rev
7. Selector key	8. Interlock key	9. Selector shaft

Reassembly




1. Hold the selector key, forward end to the left and place the 1st/2nd selector fork, crank to the left into the third slot in the key.



2. Place the selector block, pin uppermost and threaded hole facing (vertically mounted unit), into the second slot in the key.


Note: Horizontal Units: Place the selector block, with the groove uppermost and the thread hole facing, into the second slot in the key.




3. Place the 3rd/4th selector fork, crank to the left, into the first slot in the key. On overdrive transmissions, place the overdrive selector, ball pin end to the left, into the first slot in the selector key.



4. Place the low/reverse selector fork, crank to the right, into the last slot in the key.



5. Support the key and forks and pass the interlock key, forward end to the left, into position in the forks.



6. Still holding the key and forks insert the shaft, smaller segment between the slots facing towards you, first over the interlock key, then under the selector key and through the bosses of the forks.



7. Pass the shaft through the forks, and align the hole in the selector block with the hole in the shaft. Fit a new tapered capscrew and tighten to the correct torque. If a new screw is not available apply Loctite 270 to the screw threads before fitting.


Transmission case

Reassembly


Note: Before reassembling the transmission case ensure that each section case and covers are clean and that all gaskets and jointing/sealing materials are cleaned from the mating faces. When reusing patch lock bolts or fitting capscrews to through holes apply the recommended threadlock or sealant to the threads. If the new bushes are required to be installed follow the instructions in **Casing bushes - Renewal**.




1. Support the intermediate case on the stand, rear face uppermost. Using the tool E 109-6 install the layshaft rear bearing cup into the case. Drive in until almost flush with the rear face of the bearing bore.




2. Install the mainshaft rear bearing outer track and roller assembly snap ring groove outermost into the case using a suitable mandrel. Invert the case on the stand.




3. Fit tool E 114 over the rear end of the mainshaft. Retain in place with a large washer and the sun gear retaining bolt or suitable equivalent.




4. Locate the selector shaft assembly to the mainshaft. Using tools E 116A and E 116-1 and a hoist, lower the assembly into the case making sure the selector shaft enters the rear bush. Support the mainshaft and selectors approximately 20 mm above the normal installed position.




5. On overdrive transmissions locate the selector shaft assembly to the mainshaft without the 3rd/4th overdrive selector fork. This can be assembled later and avoids the risk of the fork pads dropping into the transmission.




6. Fit the 4th gear (overdrive 3rd gear) synchroniser ring and flange into the synchroniser hub and locate the layshaft into mesh with the mainshaft.



7. Lower the hoist and allow the mainshaft, layshaft and selector shaft to rest in their respective bearings and bushes. Ensure the selector block is positioned so that it will not foul the front case and remove the lifting tool.




8. On overdrive transmissions, install the fork pads into the 3rd/4th overdrive selector fork. Engage the fork and pads into the synchroniser sleeve, shorter offset to the right-hand side of the transmission as illustrated.




9. Manoeuvre the 3rd/4th overdrive fork into the selector ball end and rotate the selector until the centre line of the fork pivot pin holes is at approximately 90° to the centre line through the overdrive selector.




10. Lubricate and install the spigot bearing on the mainshaft.



11. Install the input shaft and bearing assembly into the front case. On direct drive models tap the shaft and bearing into the case, from the front, until the bearing snap ring abuts the case.




12. On overdrive transmissions, remove the bearing outer snap ring and install the shaft and bearing from the inside of the case outwards. Refit the snap ring. Tap the bearing back until the snap ring abuts the case.




13. Install the layshaft front bearing cup into the front case assembly using tool E 109-6.




14. If removed, install a new oil seal into the input shaft bearing front cover using the special tool. Press the seal firmly down to the shoulder ensuring the seal is not damaged.




15. Lubricate the shaft seal surface and apply flange sealant to the mating face of the front cover. Install the front cover and tighten the capscrews to the correct torque.




16. Apply sealer to the case mating flange ensuring that there is a continuous bead around the flange and the retaining capscrew holes.




17. Locate the front case onto the intermediate case making sure the selector shaft enters the front bush and that the locating teeth on the input gear engage with the teeth on the synchroniser flange. Rotate the input shaft slightly to ensure engagement.




18. Install the flange capscrews, nuts and washers and tighten to the correct torque.




19. On overdrive transmissions, using a suitable probe as illustrated, align the overdrive selector fork pivots with the holes in the case. Apply Loctite 5205 to the inside face of the pivot pin flanges and install the pins.




20. When aligning the right hand pin, use a screwdriver and lift the selector and fork through the remote control aperture. Tighten the capscrews to the correct torque.




21. Invert the case and remove the tool E 114.



22. Install the mainshaft bearing thrust spacer. If a ball bearing is fitted, heat inner race lightly and tap into position.



23. Remove the two screws and separate the pump halves. Check that the clearances between the rotors are within the recommended limits. Renew the pump if clearances exceed 0.50 mm.



24. Ensure that the mating faces of the pump halves are clean and reassemble the pump. DO NOT use sealant. Tighten the screws securely.


Note: Pumps fitted to transmissions NOT fitted with an oil cooler facility are identified by a notch (arrowed) in the edge of the cover.



25. Install the pump and tighten the capscrews to the correct torque. Refit the oil pump strainer and bracket on multi-purpose specification transmissions.




26. If removed, install the sealing rings on the oil muff collar. Check the clearance between the rings and collar as illustrated. Renew the rings if the clearance is less than the recommended tolerance (0.178 mm), or the rings are excessively worn or scored.



27. Lubricate the oil muff and locate it onto the rear of the mainshaft. Carefully compress the sealing rings and push the oil muff into the pump.



28. Install the sun gear onto the mainshaft.




29. Locate the special retaining washer against the sun gear and fit a new patchlock retaining capscrew.



30. Using tool E 118 to restrain the sun gear, tighten the capscrew to the correct torque.

Setting the bearing preload




31. Select the thickest shim and place it against the layshaft bearing cup. Place the spacer on top of the shim.


Note: The spacer must stand proud of the front face of the case when the bearing cup is fully seated against the bearing cone and roller assembly.

Shims are available in the following thicknesses:

Part Number	Thickness (mm)
F88891	0.051
F88892	0.127
F88893	0.254
F88894	0.508
Spacer	
8875879	2.40



32. Install the layshaft front bearing cover (without sealant). Fit the capscrews without spring washers. Carefully and evenly tighten the capscrews while rotating the input shaft backwards and forwards to settle the bearings. Tighten the capscrews until some resistance can be felt on the input shaft.




33. Back off the four capscrews to zero torque then retighten just sufficiently to nip the bearing cover plate. Using feeler gauges, measure the clearance between the cover plate and the case at several

points.


From the range of graded spacers select the thickness which will give the required preload to the layshaft bearings of 0.075 to 0.125 mm with new bearings of 0.00 to 0.05 mm with used bearings.

Example

Spacer thickness	2.40 mm
add shim	0.508
	2.908
subtract clearance	0.30
	2.608
add preload	0.05
	2.658
subtract spacer	2.40
	0.258
Shim required	0.254




34. Lubricate the layshaft bearing, install the graded spacer of the selected thickness, apply flange sealant and install the cover plate. Apply sealant and tighten the capscrews to the correct torque.




35. Invert the transmission again, rear end uppermost. Apply petroleum jelly to the reverse idler gear thrust washers and locate them into position in the transmission case.

Reverse idler gear assembly



1. Thrust washer	2. Needle roller bearing	3. Spacer	4. Gear, reverse idler
5. Thrust washer	6. Shaft	7. Parallel groove pin	




36. Install the bearings and bearing spacer into the reverse idler gear and locate the assembled gear between the thrust washers and into mesh with the layshaft and the mainshaft reverse gear.




37. Ensure the thrust washers, the gear and the pin holes are in alignment and install the reverse idler gear shaft. If the tool MS 284 is used (as illustrated) the shaft can be easily realigned if necessary during installation.


The idler shaft must be fitted with the larger diameter hole for the pin facing outwards.



38. Take care to ensure that the components are not dislodged as the shaft is driven home. Align the pin holes and install a new pin. Drive in until flush with case.



39. Install the reverse idler gear/PTO cover plate using Loctite sealant. Tighten the capscrews to the correct torque.




40. Lubricate the selector interlock pin and install it, rounded end first, into the range indicator switch bore hole. Push it right through until it is located in the selector shaft detent groove.


Note: The interlock pin must be installed now, before the rear case assembly is fitted.




41. Apply sealant to the intermediate case rear flange ensuring there is a continuous bead around the flange and the retaining capscrew holes.




42. Support the rear case assembly on a suitable sling and hoist as illustrated ensuring that the shaft is as near vertical as possible.



43. Lower the rear case over the intermediate case ensuring that the range change selector rod aligns with the bush in the intermediate case. Rotate the output flange slightly to aid alignment over the sun gear if necessary.



44. Install the flange capscrews, nuts and washers, tighten to the correct torque.




45. Install the strainer, using a new washer, into the transmission case.



46. Tighten the strainer to the correct torque




47. Apply silicone grease and fit new O-rings to the range change piston in the selector rod bore and the outer periphery.




48. Fit the piston, flat side outermost, onto the selector rod, fit and tighten the retaining nut to the correct torque.




49. Apply silicone grease and install a new O-ring into the groove in the range change cylinder cover.



50. Install the cover taking care not to damage the piston and cover O-rings or to score the cover. Tighten the retaining capscrews to the correct torque.




51. Install the speedometer drive pinion or sender adaptor, when fitted. Take care not to damage the integral oil seal fitted to the adaptor. Tighten the housing or sender adaptor to the correct torque.




52. Turn the transmission to the horizontal position. Remove the drive flange retaining nut and temporary spacer, install a new nut and using the flange holding wrench tighten to the correct torque. DO NOT use an impact wrench.


Note: DO NOT allow the output shaft to be knocked or driven inwards while the nut is slackened or removed or the range change synchroniser sleeve may be displaced and the rollers, plungers and springs fall out of the hub.




53. Rotate the selector block to position the pin uppermost. Install the neutral selector detent plunger and spring or screw-in assembly.




54. Fit the cover plate with a new gasket and tighten the capscrews to the correct torque.



55. Apply flange sealant and install the remote control making sure that the inner lever locates over the selector block.




56. Tighten the capscrews to the correct torque.




57. Install the reverse lamp switch, tighten to the correct torque.



58. Install the neutral switch and ball into the transmission case. Tighten the switch to the correct torque.



59. Install the range indicator lamp switch and ball into the transmission case. Tighten the switch to the correct torque.




60. Attach the hoist and remove the transmission from the stand. Remove the adaptor plates and refit the slave valve and filter regulator valve. Fit any remaining flange bolts and tighten to the correct torque.
61. Refit the air line connectors, if removed, using PTFE tape or suitable sealant, and reconnect the air lines.
62. Check manually that all gears can be engaged using the shift lever. It will be necessary to attach a temporary air supply to check the operation of the range change.

Changing the input shaft

Exploded view

Input shaft assembly



ET6109-3/2/1


1. Circlip 65 mm diameter	2. Spacer	3. Bearing	4. Input shaft
---------------------------	-----------	------------	----------------

In some cases in service it may be necessary to renew the input shaft either due to wear on the splines caused by the clutch or for implementing a change in clutch type or hub diameter.

The input shaft can be renewed **on direct drive transmissions** only without disassembling the transmission other than the removal of the clutch housing by carrying out the following detailed procedure.

Overdrive transmissions require the remote control and the front case assembly to be removed for access.

Disassembly



1. Remove the front bearing cover. Grasp the input shaft firmly and, using a soft mallet, joggle the shaft, gear and bearing out of the case.

Certain specifications have an O-ring seal/plate which must be removed before removing the input shaft front cover.



2. Support the input shaft and remove the snap ring. Remove the selective fit spacer.



3. Support the bearing on a press, or using a suitable puller, press the shaft through the bearing track, remove the bearing thrust spacer.

On certain specifications a spacer is fitted behind the bearing.


Reassembly

Note: Heat the bearing assembly thoroughly to approximately 85°C before assembly. This greatly eases assembly and in most cases the bearing track will fit over the shaft without the need to drift it in place.



1. Support the heated bearing assembly, inner track downwards on a suitable tube and install the input shaft through the bearing. Use the press or a soft faced mallet to ensure the bearing track is firmly against the gear.

Where applicable, refit spacer before installing the bearing.



2. Place the original spacer against the bearing and check that the snap ring will fit into its groove without free play. Check at several places around the diameter of the shaft. If there is too much free play, or the snap ring does not fit into the groove, a new thicker or thinner spacer respectively is required in place of the original.

Graded spacers are available in the following thicknesses, colour coded as indicated in the table.

Thickness mm	Colour coded stripes		
3.70	Red	Green	White
3.75	Yellow	Green	Blue
3.80	Blue	Green	White
3.85	Red	Green	Yellow
3.90	Green	Green	White
3.95	Red	Green	Red



3. When the correct thickness spacer has been selected and fitted, fit the new snap ring.




4. Check the mainshaft spigot bearing, renew if worn or damaged. Check that the lubrication is secure in the end of the shaft. Horizontal specifications have a restrictor fitted approximately 5 mm from the end of the roll pin.



5. Install the input shaft and bearing assembly making sure that the locating teeth on the input gear engage correctly with the teeth of the synchroniser ring.




6. Renew the input shaft oil seal. Install the new oil seal into the input shaft bearing front cover using the special tool and apply a light grease to the seal. Press the seal firmly down to the shoulder ensuring the seal is not damaged.



7. Apply flange sealant to the mating face and install the front cover. Tighten the capscrews to the correct torque.

Clutch housing


Disassembly




1. Support the transmission, disconnect the lubrication pipe and remove the lower inspection cover.




2. Using suitable pliers disconnect the clutch thrust race return springs.




3. Remove the clutch housing retaining nuts and washers.




4. Use a ring spanner through the inspection cover hole to undo the nuts behind the cross shaft.




5. Remove the clutch thrust race return spring anchor bolts.



6. Loosen the clutch housing using a soft faced mallet.



7. Lift off the clutch housing assembly.



8. Front of transmission with clutch housing removed.

Reassembly

1. Install the clutch housing assembly.
 2. Fit and tighten the clutch thrust race return spring anchor bolts to the proper torque.
 3. Fit and tighten the clutch housing retaining nuts to the proper torque.
 4. Reconnect the clutch thrust race return springs.
 5. Refit the lower inspection cover.
 6. Reconnect the lubrication pipe and tighten securely.
-