

STRALIS □ AT/AD

REPAIR MANUAL

MECHANICAL

ELECTRIC

ELECTRONIC

IVECO

STRALIS AT/AD

REPAIR MANUAL

IVECO

This publication describes the characteristics, the data, the correct methodology of the repairs that can be made on each individual component of the vehicle.

By complying with the instructions supplied and using the specific tools it is possible to perform any repair intervention correctly, within the specified time frames, while protecting the technicians against incidents.

Before starting any repair work, make sure that all accident prevention devices are ready at hand.

Check and wear the protective personal equipment provided for by the safety standards: goggles, helmet, gloves, shoes.

Check the efficiency of all processing, lifting and transport tools before using them.

The data contained in this publication might fail to reflect the latest changes which the Manufacturer may introduce at any time, for technical or sales purposes, or to meet the requirements of local legislation.

Copy, even partial, of text and drawings is forbidden.

Publication Edited by:
IVECO S.p.A.
T.C.O. - B.U. Customer Service
Lungo Stura Lazio, 15/19
10156 Torino (Italy)

Printed **603.93.141** - 1st Ed. 2003

Produced by:



B.U. TECHNICAL PUBLISHING
C.so Svizzera, 185
10149 Torino (Italy)

SPECIAL REMARKS

The workshop manuals for mechanical parts have been divided into Sections, each of which has a number and its relevant contents are indicated in the General Specifications. Each section features a main Unit (e.g. engine, gears etc.).


The subjects usually dealt with in each section are:

Technical data table, Driving torques, Equipment, Diagnostic, Removal and Fitting in place, Repair operations.

Where possible, the same sequence of procedures has been followed for easy reference.

Diagrams and symbols have been widely used to give a clearer and more immediate illustration of the subject being dealt with, (see next page) instead of giving descriptions of some operations or procedures.

Example



Ø 1 = housing for connecting rod small end bush

Ø 2 = housing for connecting rod bearings



Tighten to torque
Tighten to torque +
angular value

Furthermore, within each section, every heading or sub-heading concerning the operations to be carried out is preceded by a six digit number. This number is the Product Code that is to be found in the repair operation described in the REPAIR TIMES CHARTS and in the FAULT CODES.

For quick reference the indication of how to read this code is described below (see the Repair time charts also).

Product Code:



PRODUCT



UNIT



SUB-ASSEMBLY
COMPONENT

Example:

Product 50 = Frame;

Product 52 = Axles;

Product 53 = Gears etc.

Unit Code:



PRODUCT



UNIT



SUB-ASSEMBLY
COMPONENT

Figures three and four identify the ASSEMBLY within the PRODUCT

Example:

Product 50 = Frame;

Unit 01 = Chassis;

Unit 02 = Bumpers etc .

Sub-assembly Code:



PRODUCT



UNIT



SUB-ASSEMBLY
COMPONENT

Example:

Product 50 = Frame;

Unit 01 = Chassis;

Sub-assembly 40 = Chassis cross members etc.

Graphs and symbols

	Removal Disconnection
	Refitting Connection
	Removal Disassembly
	Fitting in place Assembly
	Tighten to torque
	Tighten to torque + angle value
	Press or caulk
	Regulation Adjustment
	Warning Note
	Visual inspection Fitting position check
	Measurement Value to find Check
	Equipment
	Surface for machining Machine finish
	Interference Strained assembly
	Thickness Clearance
	Lubrication Damp Grease
	Sealant Adhesive
	Air bleeding

	Intake
	Exhaust
	Operation
	Compression ratio
	Tolerance Weight difference
	Rolling torque
	Replacement Original spare parts
	Rotation
	Angle Angular value
	Preload
	Number of revolutions
	Temperature
	Pressure
	Oversized Higher than.... Maximum, peak
	Undersized Less than.... Minimum
	Selection Classes Oversizing
	Temperature < 0° Cold Winter
	Temperature > 0° Hot Summer

STRALIS AT/AD

Print 603.93.141 – 1st edition
Base – January 2003

UPDATE DATA

Section	Description	Page	Revision date

INDEX OF SECTIONS


	Section
General information	I
Engine	2
Clutch	3
Gearbox	4
Hydraulic retarder	5
Propeller shafts	6
Rear axles	7
Front axle	8
Front and rear suspensions	9
Wheels and tyres	10
Steering system	11
Pneumatic system - brakes	12
Bodywork and chassis frame	13
Maintenance	14

SECTION I**General**

	Page
VEHICLE IDENTIFICATION DATA	3
☐ Vehicle identification plate	4
☐ Production identification plate	4
COMPOSITION OF MODELS	5
P.I.C. NUMBER CODING	9
REPLENISHING FLUIDS	13



VEHICLE IDENTIFICATION DATA

The type and number of engine, type and number of chassis and manufacturer's plate comprise the vehicle identification data.




Manufacturer's plate

To identify the vehicle in accordance with the E.E.C. directive (under the front radiator cowling).



Chassis frame

Punching (front on right side member of chassis frame).



Engine

Plate on the left rear side of the crankcase

Vehicle Identification Plate

Plate legend

- a) Type-approval number marking (if applicable).
- b) Vehicle identification code number (V.I.N.).
- c) Total tractor weight.
- d) Total weight of tractor + trailer (if applicable).
- e) Permissible weight limit on 1st axle.
- f) Permissible weight limit on 2nd axle (if applicable).
- g) Permissible weight limit on 3rd axle.
- h) Permissible weight limit on 4th axle (if applicable).
- i) Specific identification of type.
- l) Wheelbase in mm.
- m) Engine type.
- n) Engine power.
- o) No. of axles.
- p) Place of manufacture.

- a)
- b)
- c)
- d)
- e)
- f)
- g)
- h)
- i)
- l)
- m)
- p)

○ IVECO MAGIRUS AG ○	
Kg	
Kg	
Kg	
Kg	
Kg	
Kg	
Kg	
Type	N° of axles
Wheelbase	Corrected absorption value
Engine type	Engine power KW
Made in	
IVECO	

Unit No
Part No
Serial No
P.I.C. No
Made in Germany-Iveco Magirus AG
9843 8247
IVECO




Permissible
grade of
smoke

Production identification plate

This plate shows the P.I.C. (production identification code number), which is needed when referring to the **spare parts catalogue** (electronic and/or microfiche catalogue). The P.I.C. is also given on the vehicle warranty card.

Note: When consulting the catalogues, use only the first 8 digits of the product identification code number.

COMPOSITION OF MODELS

CHASSIS CABS - 4x2 MODELS			AD 190 S 27	AT 190 S 27	AD 190 S 27/P	AT 190 S 27/P	AD 190 S 27/FP-D	AT 190 S 27/FP-D	AD 190 S 30	AD 190 S 30/P	AD 190 S 31	AT 190 S 31	AD 190 S 31/P	AT 190 S 31/P	AD 190 S 31/FP-D	AT 190 S 31/FP-D	AD 190 S 35	AT 190 S 35	AD 190 S 35/P	AT 190 S 35/P	AD 190 S 35/FP-D	AT 190 S 35/FP-D	AD 190 S 40	AT 190 S 40	AD 190 S 40/P	AT 190 S 40/P	AD 190 S 40/FP-D	AT 190 S 40/FP-D	AT 190 S 40/FP-CT	AD 190 S 43	AT 190 S 43	AD 190 S 43/P	AT 190 S 43/P	AD 190 S 43/FP-D	AT 190 S 43/FP-D	AT 190 S 43/FP-D	AT 190 S 43/FP-CT	
ASSEMBLIES																																						
	F2BE0681F (270 CV)		○	○	○	○	○	○																														
	F2BE0681E (300 CV)								○	○																												
	F2BE0681B (310 CV)										○	○	○	○	○	○																						
	F2BE0681A (350 CV)																	○	○	○	○	○	○															
	F3AE0681B (400 CV)																							○	○	○	○	○	○	○								
	F3AE0681D (430 CV)																								○	○	○	○	○	○			○	○	○	○	○	○
	Single disc 16"		○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○															
	Single disc 17"																							○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
	ZF 9 S 109 D.D.		○	○	○	○	○	○			○	○	○	○	○	○																						
	ZF 16 S 151 D.D.																	○	○	○	○	○	○															
	ZF 16 S 181 O.D.																																					
	ZF 16 S 181 D.D.																							○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
	ZF 16 S 221 O.D.																																					
	EuroTronic Automated 12 AS 2301 O.D.																																					
	EuroTronic Automated 12 AS 2301 D.D.				○	○	○	○						○	○	○	○				○	○	○	○			○	○	○	○	○			○	○	○	○	○
	Allison MD 3060 P - MD 3066 P		○							○	○				○																							
	FRONT AXLE:	5876/4 (F 8021)	⊗	⊗	⊗	⊗			⊗	⊗	⊗	⊗	⊗	⊗			⊗	⊗	⊗	⊗			⊗	⊗	⊗	⊗			⊗	⊗	⊗	⊗	⊗			⊗		
		5876/5 (F 8021)	●	●	●	●			●	●	●	●	●	●			●	●	●	●			●	●	●	●			●	●	●	●	●	●	●	●	●	
		5886/5 (F 9021)						○	○							○	○						○	○			○	○					○	○				
	ADDED AXLE:																																					
		Steering central	5876/4 (F 8021)																																			
		Rigid rear	55080/D1 (N 8071) *																																			
		Rigid rear	56082/D1 (N 9171) *																																			
		Steering rear	57080/D1 (N 8072) *																																			
	MERITOR MS 13-175/T - MS 13-175/D		○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
	MERITOR RT 160/I																																					
	451391 HR																																					
	ZF 8098		○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
	FRONT MECHANICAL	Front	□	□	□	□			□	□	□	□	□	□			□	□	□	○			□	□	□	□					□	□	□	□				
		Rear	□	□					□		□	□						□	□					□	□						□	□						
	PNEUMATIC	Front					○	○							○	○						○	○				○	○	○						○	○	○	○
		Rear			○	○	○	○		○				○	○	○	○				○	○	○	○			○	○	○	○	○			○	○	○	○	
		Added axle																																				

- ⊗

= With brake calliper assembly at 57° without parking brake
- = With brake calliper assembly at 0° with parking brake
- ◇

= With longitudinal and transversal bars
- = With parabolic leaf springs
- *

= TI with drum brakes

- T

= 4x2 tractor
- TX

= 6x2 C tractor (central added axle cannot be lifted)
- TY

= 6x2 P tractor (rear added axle can be lifted)
- TN

= 6x2 vehicles with mechanical rear suspensions and raisable rigid rear added axle
- TZ

= 6x4 tractor (bogie rear axle)
- P

= 4x2 – 6x2P – 6x2C vehicles with air suspension on rear axle and 6x2P vehicles with rigid rear axle that can be lifted with single wheels
- PT

= 6x2P vehicles with air suspension on rear axle and rigid rear added axle that can be lifted with twin wheels
- PS

= 6x2P vehicles with air suspension on rear axle and on steering rear added axle that can be lifted with single wheels
- FP

= 4x2 – 6x4 – 6x2P – 6x2C vehicles with front and rear air suspensions
- FS

= 6x2P vehicles with front and rear air suspensions, steering rear added axle can be lifted with single wheels
- 4x2

= Vehicles with two axles with rear driving axle
- 6x2P

= Vehicles with three axles with rear driving axle and rear added third axle that can be lifted
- 6x2C

= Vehicles with three axles with rear driving axle and central added third axle that cannot be lifted
- 6x4

= Vehicles with three axles with two rear driving axles (in tandem)
- CM

= Movable Boxes
- LT

= Tractor with lowered chassis frame
- CT

= Chassis cab with lowered chassis frame
- RR

= Rough Roads
- D





= Distribution
- HR

= Hub Reduction
- AT

= Active Time
- AD

= Active Day

COMPOSITION OF MODELS

CHASSIS CABS - 6x2 P MODELS			AD 260 S 27Y/P	AT 260 S 27Y/P	AD 260 S 27Y/PS	AT 260 S 27Y/PS	AD 260 S 27Y/FP-D	AT 260 S 27Y/FP-D	AD 260 S 27Y/FS-D	AT 260 S 27Y/FS-D	AD 260 S 30Y/PS	AT 260 S 30Y/PS	AT 260 S 30Y/FS-D	AD 260 S 31Y/P	AT 260 S 31Y/P	AD 260 S 31Y/PS	AT 260 S 31Y/PS	AD 260 S 31Y/FP-D	AT 260 S 31Y/FP-D	AD 260 S 31Y/FS-D	AT 260 S 31Y/FS-D	AD 260 S 35Y/P	AT 260 S 35Y/P	AD 260 S 35Y/PS	AT 260 S 35Y/PS	AD 260 S 35Y/FP-D	AT 260 S 35Y/FP-D	AD 260 S 35Y/FS-D	AT 260 S 35Y/FS-D	AD 260 S 27Y/PT	AT 260 S 27Y/PT	AD 260 S 27Y/TN	AT 260 S 27Y/TN	AD 260 S 31Y/PT	AT 260 S 31Y/PT	AD 260 S 31Y/TN	AT 260 S 31Y/TN	AD 260 S 35Y/PT	AT 260 S 35Y/PT	AD 260 S 35Y/TN	AT 260 S 35Y/TN						
ASSEMBLIES																																															
	F2BE0681F (270 CV)		○	○	○	○	○	○	○	○																						○	○	○	○												
	F2AE0681E (300 CV)										○	○	○																				○	○													
	F2BE0681B (310 CV)														○	○	○	○	○	○	○	○													○	○											
	F2BE0681A (350 CV)																						○	○	○	○	○	○	○	○											○	○	○	○			
	F3AE0681B (400 CV)																																														
	F3AE0681D (430 CV)																																														
	Single disc 16"		○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
	Single disc 17"																																														
	ZF 9S 109 D.D.		○	○	○	○	○	○	○	○	○	○			○	○	○		○	○	○	○										○	○	○	○	○											
	ZF 16S 151 O.D.																						○	○	○	○	○	○	○													○	○	○	○		
	ZF 16S 181 O.D.																							○	○	○	○	○	○	○																	
	ZF 16S 181 D.D.																																														
	ZF 16S 221 D.D.																																														
	EuroTronic Automated 12 AS 2301 D.D.																																														
	EuroTronic Automated 12 AS 2301 O.D.		○	○		○	○	○	○	○	○	○	○		○	○	○		○	○	○	○	○	○	○	○	○	○	○	○	○	○	○			○	○	○	○	○	○	○	○	○	○	○	
Allison MD 3060 P - MD 3066 P				○	○			○	○	○	○	○	○	○	○	○			○	○	○	○																									
	FRONT AXLE:	5876/4 (F 8021)	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗					⊗	⊗	⊗	⊗					⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗		
		5876/5 (F 8021)	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●					●	●	●	●					●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	
		5886/5 (F 9021)																	○	○	○	○					○	○	○	○																	
	ADDED AXLE:																																														
	Steering central	5876/2 (F 8021)																																													
	Rigid rear	55080/D1 (N 8071) *	○	○			○	○							○	○			○	○			○	○			○	○																			
	Rigid rear	56082/D1 (N 9171) *																														○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	
	MERITOR MS 13-175/T - MS 13-175/D		○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	
	MERITOR RT 160/I																																														
	451391 HR																																														
	ZF 8098		○	○	○	○	○	○	○	○	○			○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
	FRONT MECHANICAL	Front	□	□	□	□					□	□		□	□	□	□					□	□	□	□							□	□	□	□	□	□	□	□	□	□	□	□	□	□	□	□
		Rear																															□	□					□	□			□	□			
	PNEUMATIC	Front					○	○	○	○			○					○	○	○	○					○	○	○	○																		
		Rear	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○			○	○					○	○					
		Added axle	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○			○	○					○	○				

- ⊗

= With brake calliper assembly at 57° without parking brake
- = With brake calliper assembly at 0° with parking brake
- ◇

= With longitudinal and transversal bars
- = With parabolic leaf springs
- *

= T1 with drum brakes

- T

= 4x2 tractor
- TX

= 6x2 C tractor (central added axle cannot be lifted)
- TY

= 6x2 P tractor (rear added axle can be lifted)
- TN

= 6x2 vehicles with mechanical rear suspensions and raisable rigid rear added axle
- TZ

= 6x4 tractor (bogie rear axle)
- P

= 4x2 – 6x2P – 6x2C vehicles with air suspension on rear axle and 6x2P vehicles with rigid rear axle that can be lifted with single wheels
- PT

= 6x2P vehicles with air suspension on rear axle and rigid rear added axle that can be lifted with twin wheels
- PS

= 6x2P vehicles with air suspension on rear axle and on steering rear added axle that can be lifted with single wheels
- FP

= 4x2 – 6x4 – 6x2P – 6x2C vehicles with front and rear air suspensions
- FS

= 6x2P vehicles with front and rear air suspensions, steering rear added axle can be lifted with single wheels
- 4x2

= Vehicles with two axles with rear driving axle
- 6x2P

= Vehicles with three axles with rear driving axle and rear added third axle that can be lifted
- 6x2C

= Vehicles with three axles with rear driving axle and central added third axle that cannot be lifted
- 6x4

= Vehicles with three axles with two rear driving axles (in tandem)
- CM

= Movable Boxes
- HM

= Heavy Mission
- LT

= Tractor with lowered chassis frame
- CT

= Chassis cab with lowered chassis frame
- RR




= Rough Roads
- D

= Distribution
- AT

= Active Time
- AD

= Active Day

COMPOSITION OF MODELS

CHASSIS CABS - 6x2 P MODELS			AD 260 S 40Y/P	AT 260 S 40Y/P	AD 260 S 40Y/PS	AT 260 S 40Y/PS	AD 260 S 40Y/FP-D	AT 260 S 40Y/FP-D	AD 260 S 40Y/FS-D	AT 260 S 40Y/FS-D	AD 260 S 40Y/FS-CM	AT 260 S 40Y/FS-CM	AD 260 S 43Y/P	AT 260 S 43Y/P	AD 260 S 43Y/PS	AT 260 S 43Y/PS	AD 260 S 43Y/FP-D	AT 260 S 43Y/FP-D	AD 260 S 43Y/FS-D	AT 260 S 43Y/FS-D	AD 260 S 43Y/FS-CM	AT 260 S 43Y/FS-CM	AD 260 S 40Y/PT	AT 260 S 40Y/PT	AD 260 S 40Y/TN	AT 260 S 40Y/TN	AD 260 S 43Y/PT	AT 260 S 43Y/PT	AD 260 S 43Y/TN	AT 260 S 43Y/TN	
	F2BE0681F (270 CV)																														
	F2AE0681E (300 CV)																														
	F2BE0681B (310 CV)																														
	F2BE0681A (350 CV)																														
	F3AE0681B (400 CV)			○	○	○	○	○	○	○	○	○	○											○	○	○	○				
	F3AE0681D (430 CV)													○	○	○	○	○	○	○	○	○	○					○	○	○	○
	Single disc 16"																														
	Single disc 17"			○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
	ZF 9S 109 D.D.																														
	ZF 16S 151 O.D.																														
	ZF 16S 181 O.D.																														
	ZF 16S 181 D.D.			○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
	ZF 16S 221 D.D.																														
	EuroTronic Automated 12 AS 2301 D.D.																														
	EuroTronic Automated 12 AS 2301 O.D.			○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○			○	○		
	Allison MD 3060 P - MD 3066 P																														
	FRONT AXLE:		5876/4 (F 8021)	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗							⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	
	5876/5 (F 8021)			●	●	●	●	●	●	●	●	●	●	●	●	●	●						●	●	●	●	●	●	●	●	
	5886/5 (F 9021)																	○	○	○	○	○	○								
	ADDED AXLE:																														
	Steering central		5876/4 (F 8021)																												
	Rigid rear		55080/D1 (N 8071) *	○	○									○	○			○	○												
	Rigid rear		56082/D1 (N 9171) *																					○	○	○	○	○	○	○	○
	MERITOR MS 13-175/T - MS 13-175/D			○	○	○	○	○	○	○	○	○	○	○	○	○							○	○	○	○	○	○	○	○	
	MERITOR RT 160/I																														
	451391 HR																														
	ZF 8098			○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
	FRONT MECHANICA0L		Front	□	□	□	□						□	□	□	□							□	□	□	□	□	□	□	□	
	Rear																								□	□			□	□	
	PNEUMATIC		Front					□	□	□	□	◇	◇				□	□	□	□	◇	◇									
	Rear			○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○			○	○		
	Added axle			○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○			○	○		

- ⊗

= With brake calliper assembly at 57° without parking brake
- = With brake calliper assembly at 0° with parking brake
- ◇

= With longitudinal and transversal bars
- = With parabolic leaf springs
- *

= TI with drum brakes

- T

= 4x2 tractor
- TX

= 6x2 C tractor (central added axle cannot be lifted)
- TY

= 6x2 P tractor (rear added axle can be lifted)
- TN

= 6x2 vehicles with mechanical rear suspensions and raisable rigid rear added axle
- TZ

= 6x4 tractor (bogie rear axle)
- P

= 4x2 – 6x2P – 6x2C vehicles with air suspension on rear axle and 6x2P vehicles with rigid rear axle that can be lifted with single wheels
- PT

= 6x2P vehicles with air suspension on rear axle and rigid rear added axle that can be lifted with twin wheels
- PS

= 6x2P vehicles with air suspension on rear axle and on steering rear added axle that can be lifted with single wheels
- FP

= 4x2 – 6x4 – 6x2P – 6x2C vehicles with front and rear air suspensions
- FS

= 6x2P vehicles with front and rear air suspensions, steering rear added axle can be lifted with single wheels
- 4x2

= Vehicles with two axles with rear driving axle
- 6x2P

= Vehicles with three axles with rear driving axle and rear added third axle that can be lifted
- 6x2C

= Vehicles with three axles with rear driving axle and central added third axle that cannot be lifted
- 6x4

= Vehicles with three axles with two rear driving axles (in tandem)
- CM

= Movable Boxes
- LT

= Tractor with lowered chassis frame
- CT

= Chassis cab with lowered chassis frame
- RR

= Rough Roads
- D





= Distribution
- HR

= Hub Reduction
- AT

= Active Time
- AD

= Active Day

COMPOSITION OF MODELS

TRACTORS - MODELS			4x2																6x2 C				6x4							
			AD 440 S 31T/P	AT 440 S 31T/P	AD 440 S 35T/P	AT 440 S 35T/P	AD 440 S 35T/P-HR	AT 440 S 35T/P-HR	AD 440 S 40T/P	AT 440 S 40T/P	AD 440 S 40T/P-RR	AT 440 S 40T/P-RR	AD 440 S 40T/P-HR	AT 440 S 40T/P-HR	AT 440 S 40T/FP-CT	AT 440 S 40T/FP-LT	AD 440 S 43T/P	AT 440 S 43T/P	AD 440 S 43T/P-RR	AT 440 S 43T/P-RR	AD 440 S 43T/P-HR	AT 440 S 43T/P-HR	AT 440 S 43T/FP-CT	AT 440 S 43T/FP-LT	AD 440 S 40TX/P	AT 440 S 40TX/P	AD 440 S 43TX/P	AT 440 S 43TXP	AT 440 S 43TZ/P	
	F2BE0681F (270 CV)																													
	F2AE0681E (300 CV)																													
	F2BE0681B (310 CV)		○	○																										
	F2BE0681A (350 CV)				○	○	○	○																						
	F3AE0681B (400 CV)								○	○	○	○	○	○	○	○										○	○			
	F3AE0681D (430 CV)																○	○	○	○	○	○	○	○				○	○	○
	Single disc 16"																													
	Single disc 17"		○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
	ZF 9S 109 D.D.																													
	ZF 16S 151 O.D.		○	○	○	○	○	○																						
	ZF 16S 181 O.D.											○	○							○	○				○	○	○	○		
	ZF 16S 181 D.D.								○	○	○	○			○	○	○	○	○				○	○						
	ZF 16S 221 D.D.																													
	EuroTronic Automated 12 AS 2301 D.D.												○	○						○	○									
	EuroTronic Automated 12 AS 2301 O.D.		○	○	○	○	○	○	○	○					○	○	○	○	○				○	○	○	○	○	○		
	Allison MD 3060 P - MD 3066 P																													
	FRONT AXLE:		⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗		
	5876/4 (F 8021)		●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	
	5876/5 (F 8021)		●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	
	5886/5 (F 9021)																													
	ADDED AXLE:																													
	Steering central																								○	○	○	○		
	Rigid rear																													
	MERITOR MS 13-175/T - MS 13-175/D		○	○	○	○	○	○	○	○				○	○	○	○	○				○	○	○	○	○	○			
	MERITOR RT 160/I																												○	
	451391 HR												○	○						○	○									
	ZF 8098		○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	
	FRONT MECHANICAL		□	□	□	□	□	□	□	□	□	□	□			□	□	□	□	□	□			□	□	□	□	□		
	Rear																												□	
	PNEUMATIC													○	○							○	○							
	Front																													
	Rear		○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	
Added axle																														

- ⊗

= With brake calliper assembly at 57° without parking brake
- = With brake calliper assembly at 0° with parking brake
- ◇

= With longitudinal and transversal bars
- = With parabolic leaf springs
- *

= T1 with drum brakes

- T

= 4x2 tractor
- TX

= 6x2 C tractor (central added axle cannot be lifted)
- TY

= 6x2 P tractor (rear added axle can be lifted)
- TN

= 6x2 vehicles with mechanical rear suspensions and raisable rigid rear added axle
- TZ

= 6x4 tractor (bogie rear axle)
- P

= 4x2 – 6x2P – 6x2C vehicles with air suspension on rear axle and 6x2P vehicles with rigid rear axle that can be lifted with single wheels
- PT

= 6x2P vehicles with air suspension on rear axle and rigid rear added axle that can be lifted with twin wheels
- PS

= 6x2P vehicles with air suspension on rear axle and on steering rear added axle that can be lifted with single wheels
- FP

= 4x2 – 6x4 – 6x2P – 6x2C vehicles with front and rear air suspensions
- FS

= 6x2P vehicles with front and rear air suspensions, steering rear added axle can be lifted with single wheels
- 4x2

= Vehicles with two axles with rear driving axle
- 6x2P

= Vehicles with three axles with rear driving axle and rear added third axle that can be lifted
- 6x2C

= Vehicles with three axles with rear driving axle and central added third axle that cannot be lifted
- 6x4

= Vehicles with three axles with two rear driving axles (in tandem)
- CM

= Movable Boxes
- HM

= Heavy Mission
- LT

= Tractor with lowered chassis frame
- CT

= Chassis cab with lowered chassis frame
- RR

= Rough Roads
- D

= Distribution
- AT

= Active Time
- AD

= Active Day

P.I.C. NUMBER CODING**CAB LIVEABILITY****A****A****A****B****B****C****C****D****M**

= Stralis AD (Active Day)

N

= Stralis AT (Active Time)

TOTAL WEIGHT ON GROUND AXLES CONFIGURATION**A****A****A****B****B****C****C****D****C**

= 4x2; 18-20 ton.

D

= 4x2T; 19-20 ton.

E

= 6x2C; 26 ton.

F

= 6x2P; 26 ton.

G

= 6x2P; 26 ton.

H

= 4x2T; 19-20 ton.

J

= 6x2C; 26 ton.

K

= 6x4; 26 ton.

L

= 4x2P; 19-20 ton.

M

= 6x2P; 26 ton.

N

= 6x2P; 26 ton.

ENGINE**A****A****A****B****B****C****C****D****H**

E 270

L

E 400

K

E 430

P


E 310

Q


E 300

R

E 352

SUSPENSION TYPE - REAR AXLE TYPE - TYPE OF ADDITIONAL AXLE



- * = Suspensions with 5886/D front axle
- TWIN = Twin rear wheels
- CENT = Middle axle (6x2C vehicles)
- SING = Added axle with rear single wheels
- STER = Added axle with rear steering single wheels
- HR = Double reduction rear axle
- SR = Simple reduction rear axle

VERSION COMBINATION - USE


- Cartran = Car transport
- LOW TR = Lowered tractor
- STD = Standard use
- GRAV = Heavy duty use

WHEELBASE**A****A****A****B****B****C****C****D**

VERSION	WHEELBASE	VERSION	WHEELBASE	VERSION	WHEELBASE	VERSION	WHEELBASE	
T 6 × 2 C	3800	T 4 × 2	3650	6 × 2 P	3120	T 6 × 4	2800	I
						T 6 × 4	3200	2
				6 × 2 P C 4 × 2	3805	T 4 × 2 C 6 × 2 C	3800	3
						C 4 × 2 C 6 × 2 C 6 × 2 P	4200	4
						C 4 × 2 C 6 × 2 6 × 2 P	4500	5
						C 4 × 2 6 × 2 P	4800	6
						C 4 × 2 6 × 2 P	5100	7
						C 4 × 2 6 × 2 P	5700	8
				C 4 × 2	6300	6 × 2 P	6050	9
						C 4 × 2	5500	L
						C 4 × 2	6300	M

GEARBOX - BRAKES COMBINATION**CAB - DRIVE - BRAKES COMBINATION**

REPLENISHING FLUIDS

LUBRICANTS RECOMMENDED BY IVECO		PARTS TO BE FILLED UP	Quantity		
			Litres	Kg	
	Urania FE 5W30⁽¹⁾ Urania LD5 Urania Turbo LD		Engine F2B		
			Total capacity for first filling	28	25,2
			Capacity:		
			- engine sump min level	12.5	11,2
			- engine sump max level	23	21
			- quantity in circulation that does not flow back to the engine sump	5	4.5
			2.5	2.3	
			- quantity contained in the cartridge filter (which has to be added to the cartridge filter re-fill)		
	Urania FE 5W30⁽¹⁾ Urania LD5 Urania Turbo LD		Engine F3A		
			Total capacity 1 st filling	30	29.8
			Capacity:		
			- engine sump at minimum level	17	15.3
			- engine sump at maximum level	25	22.5
			- quantity in circulation that does not return to sump	7	6.3
			2.5	2.3	
			- quantity contained in cartridge filter (to add when changing the cartridge filter)		
	Tutela Truck FE-Gear¹ Tutela ZC 90		Gearbox		
			ZF 9 S 109 *	8	7.2
			ZF 16 S 151 *	11	10
			ZF 16 S 151 + Intarder *	18.5	16.65
			ZF 16 S 181 *	13	12
			ZF 16 S 181 + Intarder*	21.5	19.35
			ZF 16 S 221 *	13	12
			ZF 16 S 221 + Intarder*	21.5	19.35
			EuroTronic automated 12 AS 2301*	12	11
			EuroTronic automated 12 AS 2301* + intarder	23	21
	Tutela GI/A	Allison MD 3060 P - MD 3066 P	18	16	
	Tutela Truck FE-Gear¹ Tutela ZC 90	Power take off (Multipower)	2.5		

(1) IVECO recommends using these oils for reasons of fuel economy. IVECO provides new vehicles already with these types of lubricants. Also suited for cold climates (minimum temperature down to -30°C)

These quantities are not decisive. An exact check must be made by verifying the levels

(1) IVECO recommends using these oils for reasons of fuel economy. IVECO provides new vehicles already with these types of lubricants. Also suited for cold climates (minimum temperature down to -30°C)
These quantities are not decisive. An exact check must be made by verifying the levels

REPLENISHING FLUIDS

LUBRICANTS RECOMMENDED BY IVECO		PARTS FOR REPLENISHING		Quantity	
				Litres	kg
	Tutela Truck FE-Axle⁽²⁾ Tutela W140/M-DA Tutela W90/M-DA ³	Front hubs (single)			
		FRONT AXLE	5876/4-/5 (F8021)	0.35	0.32
		FRONT AXLE	5886/5	0.35	0.32
		ADDED AXLE::			
		Steering central	5876/4 (F 8021)	0.35	0.32
		Rigid rear	55080/DI (N 8071)	0.35	0.32
		Rigid rear	56082/DI (N 9171)	0.35	0.32
		Steering rear	57080/DI (N 8072)	0.35	0.32
	Tutela Truck FE-Axle⁽²⁾ Tutela W140/M-DA Tutela W90/M-DA ³	Bridge Meritor MS 13-175/T - MS 13-175/D:			
		☐ (mechanical suspension)		18.5	16.5
		☐ (pneumatic suspension)		17	15.5
		Bridge 451391 HR		16	14.5
		Rear axle Meritor in tandem RT 160E/I			
		- middle		18.5	16.6
		- rear		16.5	14.8
	Tutela GI/A		Power steering	2.7*	2.4
				13.5**	12
			* Excluding vehicles with steering rear axle		
			** For vehicles with steering rear axle only		
	Tutela TRUCK DOT SPECIAL		Clutch circuit (excluding vehicles with Euro Tronic gearbox)	0.5	0.45
	Water+Paraflu ¹¹	Cooling system			
		Engine F2B	Total capacity*	~34	~23.4
		Engine F2B with Intarder	Total capacity*	~50	~27
		Engine F3A	Total capacity*	~38	~39.6
		Engine F3A with Intarder	Total capacity*	~58	~57.6
			* = Protective anti-freeze (concentration 50% freezing point -35°C)		
	Tutela LHM		Cab tilting system	0.6	0.54

(2) Only on axles with disc brakes, IVECO recommends using these oils for reasons of fuel economy. IVECO provides new vehicles already with these types of lubricants. Also suited for cold climates (minimum temperature down to -30°C)

(3) Specific for cold climates

These quantities are not decisive. An exact check must be made by verifying the levels

International lubricant designation		FL products
Engine oil Meets the specifications: ACEA E4 with a totally synthetic base ACEA E5 with a mineral base ACEA E3 with a mineral base		URANIA FE 5W30 Urania LD5 Urania Turbo LD
Oil for differential gear and wheel hubs Meets the specifications: API GL5, MT-1 with a totally synthetic base API GL5 with a mineral base API GL5 with a mineral base		Tutela Truck FE-Axle Tutela W140/M-DA Tutela W90/M-DA
Oil for mechanical gearboxes Containing non-EP anti-wear additives Meets the specifications: API GL4 with a totally synthetic base API GL3 with a mineral base		Tutela Truck FE-Gear Tutela ZC90
Oil for power steering and hydrostatic transmissions A.T.F. DEXRON II D		Tutela GI/A
Grease for general greasing based on lithium soaps, N.L.G.I. consistency no. 2		Tutela MR 2
Specific grease for bearings and wheel hubs based on lithium soaps, N.L.G.I. consistency no. 3		Tutela MR 3
Clutch drive fluid Conforming to N.H.T.S.A. standards 116, ISO 4925, Std. SAEJ 1703, IVECO STANDARD 18-1820		Tutela TRUCK DOT SPECIAL
Mineral oil for hydraulic circuits In compliance with IVECO STANDARD 18-1823		Tutela LHM
Windscreen washer fluid , mixture of spirit, water and surfactants CUNA NC 956-11		Tutela PROFESSIONAL SC 35
Grease for central lubrication systems based on lithium soaps, with synthetic base, N.L.G.I. no. 2. Working temperatures: from -30°C to +140°C		Tutela COMAR 2
Concentrated protective fluid for radiators based on ethylene glycol containing corrosion inhibitors, conforming to the standard: IVECO-STANDARD 18-1830		Parafllu ¹¹

SECTION 2

Engine

	Page
☐ F2B Engine	3
☐ F3A Engine	113
☐ Hidrocar pressure take-off on timing system (P.T.O. - Optional)	223

F2B Engine


	Page
VIEWS OF THE ENGINE	8
GENERAL CHARACTERISTICS	13
ASSEMBLY CLEARANCE DATA	16
TIGHTENING TORQUES	22
TOOLS	28
DISMANTLING THE ENGINE ON THE BENCH	40
REPAIR OPERATIONS	47
CYLINDER BLOCK	47
☐ Checks and measurements	47
CYLINDER LINERS	48
☐ Fitting and checking protrusion	49
☐ Removal	49
☐ Replacing cylinder liners	49
CRANKSHAFT	50
☐ Measuring main journals and crank pins	51
PRELIMINARY MEASUREMENT OF MAIN AND BIG END BEARING SHELL SELECTION DATA . .	52
☐ Replacing the timing control gear and the oil pump	59
☐ Checking main journal installation clearance . . .	59
☐ Checking crankshaft end float	60
PISTON-CONNECTING ROD ASSEMBLY	61
☐ Removal	61
☐ Measuring the diameter of the pistons	62
☐ Conditions for correct gudgeon pin-piston coupling	62
☐ Piston rings	63
CONNECTING ROD	64
☐ Checking connecting rod alignment	65

	Page
☐ Mounting the connecting rod-piston assembly .	65
☐ Mounting the piston rings	65
☐ Fitting the connecting rod-piston assembly into the piston liners	66
☐ Piston protrusion check	66
☐ Checking assembly clearance of big end pins . .	67
CYLINDER HEAD	67
☐ Valve removal	67
☐ Checking the planarity of the head on the cylinder block	67
VALVE	67
☐ Removing deposits and checking the valves . . .	67
VALVE GUIDES	68
☐ Replacing of valve guides	69
☐ Replacing - Reaming the valve seats	69
REPLACING INJECTOR HOLDER CASES	69
☐ Removal	69
☐ Checking protrusion of injectors	71
TIMING GEAR	72
☐ Checking cam lift and pin alignment	72
☐ Camshaft	73
☐ Bushes	73
☐ Replacing camshaft bushes using beater 99360487	74
☐ Removal	74
☐ Assembly	74
VALVE SPRINGS	75
☐ Fitting the valves and oil seal ring	75
ROCKER SHAFT	76
☐ Rocker	76
☐ Shaft	76
ASSEMBLING THE ENGINE ON THE BENCH . .	77
DIAGRAM SHOWING THE UNDERBLOCK FIXING SCREWS TIGHTENING ORDER	79

	Page
☐ Fitting the connecting rod-piston assembly into the cylinder liners	80
ENGINE FLYWHEEL	83
☐ Fitting engine flywheel	83
☐ Fitting camshaft	84
☐ Fitting pump-injectors	85
☐ Fitting rocker-arm shaft assembly	85
☐ Camshaft timing	86
☐ Phonic wheel timing	88
☐ Intake and exhaust rocker play adjustment and pre-loading of rockers controlling pump injectors.	89
ENGINE COMPLETION	90
LUBRICATION	93
☐ Oil pump	95
☐ Overpressure valve	95
☐ Oil pressure control valve	96
☐ Heat exchanger	96
☐ By-pass valve	97
☐ Thermostatic valve	97
☐ Engine oil filters	97
COOLING	99
☐ Description	99
☐ Operation	99
☐ Water pump	101
☐ Thermostat	101
☐ Electromagnetic coupling	101
TURBOCHARGER	102
TURBOCHARGING	102
TURBO COMPRESSOR HOLSET HX 40V	104
☐ Actuator	107
☐ Solenoid valve for VGT control	107

	Page
FUEL FEED	108
☐ Replacing injectors-pump	109
☐ Injector-pump	109
☐ Fuel pump	109
☐ Injector Phases	110

Figure 1



78840

F2B ENGINE

VIEWS OF THE ENGINE

ENGINE

TYPE

PART NUMBER

F **2** **B** **E** **0** **6** **8** **I** **A** * **A** **0** **0** **I** -

Progressive production number

Version number within the B.o.M.

Only for exhaust gas level with
the same torque and power curves

Engine power output or torque level

Use (eg I = truck)

Fuel feed + injection (TCA, direct injection diesel engine)

Number of cylinders

Number of strokes and cylinders' position (eg 0 = 4 strokes,
vertical)

Engine

Engine family evolution (also irrespective of the
displacement)

Indicates the engine family


A 352 CV 131 kgm

B 310 CV 114 kgm

E 301 CV 113 kgm

F 273 CV 114 kgm

Figure 2



52244

F2BE068 IF: POWER-TORQUE CURVES

Max OUTPUT 200 kW

273HP


at 2400 rpm

Max TORQUE 1115 Nm

114 kgm

at 1000 to 1770 rpm

Figure 3




52243

F2BE0681E: POWER-TORQUE CURVES

Max OUTPUT 221 kW**301HP****at 2400 rpm****Max TORQUE 1110 Nm****113 kgm****at 1000 rpm**

Figure 4



47531

F2BE0681B: POWER-TORQUE CURVES

Max OUTPUT 228 kW

310HP


at 2400 rpm

Max TORQUE 1100 Nm

114 kgm

at 1000 to 1950 rpm

Figure 5

















47532



F2BE0681A: POWER-TORQUE CURVES

Max OUTPUT 259 kW**352HP****at 2400 rpm****Max TORQUE 1280 Nm****131 kgm****at 1080 to 1930 rpm**

GENERAL CHARACTERISTICS








	Type		F2BE0681A	F2BE0681B	F2BE0681E	F2BE0681F
	Cycle	Diesel 4 strokes				
	Feeding	Turbocharged with aftercooler				
	Injection	Direct				
	N. of cylinders	6 on-line				
	Diameter	mm	115			
	Stroke	mm	125			
	Total displacement	cm ³	7790			
Q	Compression ratio		16 ± 0.8			
	Max. power	KW (HP)	259 (352)	228 (310)	221 (301)	200 (273)
		rpm	2400	2400	2400	2400
	Max. torque	Nm (Kgm)	1280 (131)	1115 (114)	1110 (113)	1115 (114)
		rpm	1080 to 1930	1000 to 1950	1000	1000 to 1770
	Engine idling speed, no load	rpm	525 ± 25			
	Maximum engine speed, no load	rpm	2760 ± 20			






	Type	F2B
	VALVE TIMING opens before T.D.C. A closes after B.D.C. B opens before B.D.C. D closes after T.D.C. C	17° 31° 48° 9°
	For timing check Running X X mm mm mm mm	— — 0.35 to 0.45 0.35 to 0.45
	FEED	Through fuel pump - Filters
	Injection type Bosch	With electronically regulated injectors PDE 30 pump injectors controlled by overhead camshaft
	Nozzle type	—
	Injection order	1 - 4 - 2 - 6 - 3 - 5
	Injection pressure bar Injector calibration bar	1500









	Type	F2B
	SUPERCHARGING Turbocharger type:	Holset, with variable geometry HY 40 V
	LUBRICATION Oil pressure, engine hot (100 °C ± 5 °C): at idling speed bar at maximum speed bar	Forced by gear pump, pressure control valve, oil filter 1.5 5
COOLING		By centrifugal pump, regulating thermostat, viscostatic fan, radiator and heat exchanger
Water pump control		By belt
Thermostat: starts to open: fully open:		N. I ~ 85 °C —
	OIL FILLING Total capacity at 1st filling liters kg	28 25.5
	Capacity: - engine sump min level liters kg	12.5
	- engine sump max level liters kg	11.2
	- quantity in circulation that does not flow back to the engine sump liters kg	23 21 5
	- quantity contained in the cartridge filter (which has to be added to the cartridge filter refill) liters kg	2.5 2.3

Fiat lubricants
Urania Turbo LD
 (according to E3-96
 standard)
Urania Turbo
 (according to E2-96
 standard)

ASSEMBLY CLEARANCE DATA

		Type	F2B
CYLINDER BLOCK AND CRANK MECHANISM COMPONENTS			mm
		Cylinder sleeve bore upper $\varnothing 1$ lower	130.200 to 130.225 128.510 to 128.535
		Cylinder liners: outer diameter: upper $\varnothing 2$ lower length L	130.161 to 130.186 128.475 to 128.500
		Cylinder sleeve - crankcase bore upper lower	0.014 to 0.064 0.010 to 0.060
		Outside diameter $\varnothing 2$	
		Cylinder sleeve A* inside diameter $\varnothing 3$ B* Protrusion X	115.000 to 115.012 115.010 to 115.022 0.035 to 0.065
* Available dia. class			
		Pistons: measuring dimension X outside diameter $\varnothing 1$ A• outside diameter $\varnothing 1$ B•• outside diameter $\varnothing 2$	18 114.888 to 114.900 114.898 to 114.910 46.010 to 46.018 114.898 to 114.910
• Class A pistons supplied as spares. •• Class B pistons are fitted in production only and are not supplied as spares.			
		Piston - cylinder sleeve	0.100 to 0.124
		Piston diameter $\varnothing 1$	—
		Pistons protrusion X	0.32 to 0.99
		Gudgeon pin $\varnothing 3$	45.994 to 46.000
		Gudgeon pin - pin housing	0.010 to 0.024








		F2B	
		mm	
	X1*		2.71 to 2.74
	Piston ring grooves X 2		2.55 to 2.57
	X3		4.02 to 4.04
	*measured on Ø of 112 mm		
	Piston rings:		
	trapezoidal seal S1*		2.575 to 2.595
	lune seal S2		2.470 to 2.490
	milled scraper ring with slits and internal spring S3		3.975 to 3.990
*measured on Ø of 112 mm			
	Piston rings - grooves	1	0.115 to 0.165
		2	0.060 to 0.100
		3	0.030 to 0.065
	 > Piston rings		—
	Piston ring end gap in cylinder liners:		
	X1		0.35 to 0.50
	X2		0.70 to 0.96
	X3		0.30 to 0.60
	Small end bush housing Ø 1		49.975 to 50.000
	Big end bearing housing Ø 2	Rated value	77.000 to 77.030
	Selection classes Ø 2	1	77.000 to 77.010
		2	77.010 to 77.020
3		77.020 to 77.030	
	Small end bush diameter outside Ø 4		50.055 to 50.080
	inside Ø 3		46.015 to 46.030
	Big end bearing shell S		
	Red		2.000 to 2.010
	Green		2.011 to 2.020
	Yellow		2.021 to 2.030
	Small end bush - housing		0.055 to 0.105
	Piston pin - bush		0.015 to 0.036
	 > Big end bearing shells		0.127 - 0.254 - 0.508
	Connecting rod weight A		g. 2890 to 2920
	Class B		g. 2921 to 2950
	C		g. 2951 to 2980










		Type		F2B	
				mm	
	Measuring dimension X			125	
	Max. connecting rod axis misalignment tolerance	=		0.08	
	Main journals	Ø 1	Rated value	82.910 to 82.940	
	Selection class	{ 1 2 3	Rated value	82.910 to 82.919	
				82.920 to 82.929	
				82.930 to 82.940	
	Crankpins	Ø 2		72.915 to 72.945	
	Selection class	{ 1 2 3		72.915 to 72.924	
				72.925 to 72.934	
				72.935 to 72.945	
	Main bearing shells	S1			
	Red		3.000 to 3.010		
	Green		3.011 to 3.020		
	Yellow ●		3.021 to 3.030		
	Big end bearing shells	S2			
	Red		2.000 to 2.010		
	Green		2.011 to 2.020		
	Yellow ●		2.021 to 2.030		
	Main bearing housings	Ø 3	Rated value	89.000 to 89.030	
	Selection class	{ 1 2 3	89.000 to 89.009 89.010 to 89.019 89.020 to 89.030		
	Bearing shells - main journals			0.040 to 0.080	
	Bearing shells - big ends			0.035 to 0.075	
	Main bearing shells			0.127 - 0.254 - 0.508	
	Big end bearing shells			0.127 - 0.254 - 0.508	
	Main journal, thrust bearing	X1	39.96 to 40.00		
	Main bearing housing, thrust bearing	X2	32.94 to 32.99		
	Thrust washer halves	X3	3.38 to 3.43		
	Driving shaft shoulder			0.11 to 0.30	
	Alignment	{ = ○ /	1	≤ 0.05	
	Ovality		2	0.010	
			1 - 2		
	Taper		1 - 2	0.010	









● Fitted in production only and not supplied as spares

● Fitted in production only and not supplied as spares

11

 Type	F2B
CYLINDER HEADS - VALVE TRAIN	mm
 Valve guide housings in cylinder head  Ø 1	12.980 to 12.997
 Valve guide  Ø 2  Ø 3	8.023 to 8.038 13.012 to 13.025
 Valve guides - housings in the cylinder heads	0.015 to 0.045
  > Valve guide	—
 Valves:  Ø 4  α  Ø 4  α	7.985 to 8.000 60° 30' ± 7' 30" 7.985 to 8.000 45° + 15'
 Valve stem and its guide	0.023 to 0.053
 Housing in head for valve seat  Ø 1  Ø 1	41.985 to 42.020 40.985 to 41.020
 Outside diameter of valve seat; angle of valve seat in cylinder head:  Ø 2  α  Ø 2  α	42.060 to 42.075 60° - 30' 41.060 to 41.075 45° - 30'
 Recessing of valve  X 	0.5 to 0.8 1.6 to 1.9
 Between valve seat and head  	0.040 to 0.090

	Type	F2B
		mm
	Valve outside spring height:	
	free height H	62.6
	under a load of:	
	N 454 ± 22 H1	48.5
	N 840 ± 42 H2	36.5
	Injector protrusion X	0.7
	Camshaft bush housing fitted in the cylinder head: Ø 1 ⇒ 7 Ø	80.000 to 80.030
	Camshaft journal diameter: Ø 1 ⇒ 7 Ø	75.924 to 75.940
	Camshaft bushing outer diameter: Ø	80.090 to 80.115
	Camshaft bushing inner diameter: Ø	75.990 to 76.045
	Bushings and housings in engine block	0.060 to 0.115
	Bushings and journals	0.050 to 0.121
	Cam lift:	8.07 7.63 8.80 to 8.82
	Rocker shaft Ø 1	37.984 to 38.000

	Type	F2B
		mm
	Bushing housing in rocker arms 	41.000 to 41.016
		53.000 to 53.019
		42.000 to 42.016
	Bushing outer diameter for rocker arms: 	41.097 to 41.135
		53.105 to 53.156
		42.066 to 42.091
	Bushing inner diameter for rocker arms: 	38.025 to 38.041
		50.025 to 50.041
		38.015 to 38.071
	Between bushings and housings 	0.081 to 0.135
		0.086 to 0.156
		0.050 to 0.091
	Between rocker arms and shaft 	0.025 to 0.057
		0.225 to 0.057
		0.015 to 0.087
TURBOCHARGER		
Type		HOLSET, variable geometry
End float		—
Radial play		—

TIGHTENING TORQUES

PART			TORQUE	
			Nm	kgm
Under-basement fastening screws to cylinder block (see Figure 6) ♦				
Outer screws	First stage : pre-tightening	M10x1.25	25	2.5
Inner screws	Second stage : pre-tightening	M16x2	140	14
Inner screws	Third stage : angle closing	M16x2		60°
Inner screws	Fourth stage : angle closing	M16x2		60°
Outer screws	Fifth stage : angle closing	M10x1.5		90°
Pipe union for piston cooling nozzle			35 ± 2	3.5 ± 0.2
Intercooler fastening screws to cylinder block ♦ (see Figure 10)				
pre-tightening			11.5 ± 3.5	1.15 ± 0.35
tightening			19 ± 3	1.9 ± 0.3
Plug			125 ± 15	12.5 ± 1.5
Spacer and oil sump fastening screws (see Figure 11)			41.5 ± 3.5	4.1 ± 0.3
Gearcase fastening screws to cylinder block			41.5 ± 3.5	4.1 ± 0.3
			63 ± 7	6.3 ± 0.7
			9 ± 3	1.9 ± 0.3
Cylinder head fastening screw: (see Figure 7) ♦				
First stage	pre-tightening		50	5
Second stage	pre-tightening		100	10
Third stage	angle closing			90°
Fourth stage	angle closing			75°
Rocker arm shaft fastening screw ♦				
First stage	pre-tightening		40	4
Second stage	pre-tightening			60°
Locknut for rocker arm adjusting screw ♦			39 ± 5	3.9 ± 5
Screws for injector fastening brackets ♦			36.5	3.65
Shoulder plate fastening screws to head ♦			23.5	2.35
Engine support bracket fastening screws to cylinder head			74 ± 8	7.4 ± 0.8
Gear fastening screws to camshaft: ♦				
First stage	pre-tightening		50	5
Second stage	pre-tightening			50°
Phonic wheel fastening screws to distribution gear			8.5 ± 1.5	0.8 ± 0.1
Exhaust pipe fastening screws • (see Figure 8)				
pre-tightening			32.5 ± 7.5	3.2 ± 0.7
tightening			47 ± 2.5	4.7 ± 0.2
Engine brake actuator cylinder fastening screws			24.5 ± 2.5	2.4 ± 0.2
Connecting rod cap fastening screws: ♦				
First stage	pre-tightening		50	5
Second stage	pre-tightening			40°
Engine flywheel fastening screws: ♦				
First stage	pre-tightening	M16x1.5x58	100	10
Second stage	pre-tightening			60°
Engine flywheel fastening screws: ♦				
First stage	pre-tightening	M16x1.5x110	100	10
Second stage	pre-tightening			120°
Flywheel pulley fastening screws to crankshaft : ♦				
First stage	pre-tightening		70	7
Second stage	pre-tightening			50°
♦ Lubricate with oil MOLYKOTE before assembly				
• Lubricate with graphitized oil before assembly				

TIGHTENING TORQUES


PART	TORQUE	
	Nm	kgm
Damper flywheel fastening screws: ♦	115 ± 15	11.5 ± 1.5
Idler gear pin fastening screws: ♦		
First stage pre-tightening	30	3
Second stage pre-tightening	90°	
Idle gear link rod fastening screw	24.5 ± 2.5	2.4 ± 0.2
Oil pump fastening screw	24.5 ± 2.5	2.4 ± 0.2
Oil pump suction rose fastening screw	24.5 ± 2.5	2.4 ± 0.2
Front cover fastening screw to cylinder block ♦	19 ± 3	1.9 ± 0.3
Control unit fastening screw to cylinder block ♦	19 ± 3	1.9 ± 0.3
Supply pump fastening screw to gearcase ♦	19 ± 3	1.9 ± 0.3
Fuel filter support fastening screw to cylinder head ♦	37 ± 3	3.7 ± 0.3
Turbo-compressor fastening screws and nuts • (see Figure 9)		
pre-tightening	32.5 ± 7.5	3.2 ± 0.7
tightening	46 ± 2	4.6 ± 0.2
Water pump fastening screw to cylinder block	24.5 ± 2.5	2.4 ± 0.2
Pulley fastening screw to hub	55 ± 5	5.5 ± 0.5
Rocker arm cover fastening screws (see Figure 12)	9	0.9
Thermostat box fastening screws to cylinder head	24.5 ± 2.5	2.4 ± 0.2
Automatic tightener fastening screws to cylinder block	45 ± 5	4.5 ± 0.5
Fixed tightener fastening screws to cylinder block	105 ± 5	10.5 ± 0.5
Fan support fastening screws to cylinder block	24.5 ± 2.5	2.4 ± 0.2
Starter fastening screws	44 ± 4	4 ± 0.4
Air heater on cylinder head	30 ± 3	3 ± 0.3
Air compressor fastening screw to cylinder head	74 ± 8	7.4 ± 0.8
Air compressor control gear fastening nut	170	17 ± 1
Hydraulic power steering pump gear fastening nut	46.5 ± 4.5	4.6 ± 0.4
Air conditioner compressor fastening screw to support	24.5 ± 2.5	2.4 ± 0.2
Air conditioner compressor support fastening screw to cylinder block	44 ± 4	4.4 ± 0.4
Alternator support fastening screw to cylinder block	44 ± 4	4.4 ± 0.4
Alternator bracket fastening screw to cylinder block	24.5 ± 2.5	2.4 ± 0.2
Water pipe unions	35	3.5
Water temperature sensor	32.5 ± 2.5	3.2 ± 0.2
♦ Lubricate with oil MOLYKOTE before assembly		
• Lubricate with graphitized oil before assembly		

TIGHTENING TORQUES

PART	TORQUE	
	Nm	kgm
Engine brake solenoid valve fastening screws	32.5 ± 2.5	3.2 ± 0.2
Flywheel rev sensor fastening screw	8 ± 4	0.8 ± 0.2
Camshaft rev sensor fastening screw	8 ± 2	0.8 ± 0.2
P.D.E solenoid connector fastening screw	1.62 ± 0.3	0.1 ± 0.3
Overboost pressure sensor fastening screw	8 ± 2	0.8 ± 0.2
Absolute pressure sensor fastening screw	22.5 ± 2.5	2.2 ± 0.2
P.W.M. control valve fastening screw/nut	8 ± 2	0.8 ± 0.2
Fuel/coolant temperature sensor	35	3.5
Coolant temperature indicator	23.5 ± 2.5	2.3 ± 0.2
Filter clogging sensor	10	1
Oil temperature switch	25 ± 1	2.5 ± 0.1
Oil pressure sensor	25 ± 1	2.5 ± 0.1
Oil clogging sensor	55 ± 5	5.5 ± 0.5
Electric wire fastening screw	8 ± 2	0.8 ± 0.2
Heater fastening screw	12.5 ± 2.5	1.2 ± 0.2

UNDERBLOCK FIXING SCREWS TIGHTENING SEQUENCE**Figure 6**


FRONT SIDE



First phase:
preliminary tightening
of outer screws
(25 Nm)

44897


FRONT SIDE



Second phase:
preliminary tightening
of inner screws
(140 Nm)

44898


FRONT SIDE



Third phase:
angle tightening
of inner screws
60°

44898


FRONT SIDE



Fourth phase:
angle tightening
of inner screws
60°

44898


FRONT SIDE



Fifth phase:
angle tightening
of outer screws
90°

44899


Figure 7



44900

DIAGRAM OF CYLINDER HEAD FIXING SCREWS TIGHTENING SEQUENCE


Figure 8



45359

DIAGRAM OF EXHAUST MANIFOLD FIXING SCREWS TIGHTENING SEQUENCE

Figure 9




45360

DIAGRAM OF TURBOCHARGER FIXING SCREWS AND NUTS TIGHTENING SEQUENCE

SEQUENCE: Preliminary tightening 4 - 3 - 1 - 2
 Tightening 1 - 4 - 2 - 3


Figure 10



455361

DIAGRAM OF HEAT EXCHANGER FIXING SCREWS TIGHTENING SEQUENCE


Figure 11



45362

DIAGRAM OF ENGINE OIL SUMP FIXING SCREWS TIGHTENING SEQUENCE







Figure 12









45363

DIAGRAM OF ROCKER ARM CAP FIXING SCREWS TIGHTENING SEQUENCE







TOOLS

TOOL NO.	DESCRIPTION	
99305019		Full-optional tool-kit to rectify valve seat
99305047		Equipment for spring load check
99322230		Rotary telescopic stand
99340051		Extractor for crankshaft front gasket
99340052		Extractor for crankshaft rear gasket
99340205		Percussion extractor







TOOLS

TOOL NO.	DESCRIPTION	
99342148		Injector extractor
99342149		Extractor for injector-holder
99346245		Tool to install the crankshaft front gasket
99346246		Tool to install the crankshaft rear gasket
99348004		Universal extractor for 5 to 70 mm internal components
99350072		Box wrench for transmission gear support fixing screws






TOOLS

TOOL NO.	DESCRIPTION	
99350074		Box wrench for block junction bolts to the underblock
99360144		Skid retaining tools (12+6) for rocker arm adjusting screws during rocker arm shaft removal/ refitting
99360177		Injector housing plug
99360184		Pincers for removing and refitting circlips and pistons (105-160 mm)
99360264		Tool to take down-fit engine valves
99360288		Tool to remove valve guide







TOOLS

TOOL NO.	DESCRIPTION	
99360292		Tool to install gasket on valve guide
99360294		Tool to drive valve guide
99360314		Tool to remove cartridge filters
99360321		Tool to rotate engine flywheel
99360334		Tool for checking cylinder barrel projection.
99360335		Cylinder barrel compression cap (to be used with 99360334)







TOOLS

TOOL NO.	DESCRIPTION	
99360351		Tool to stop engine flywheel
99360487		Tool to take down and fit back camshaft bushes
99360500		Tool to lift crankshaft
99360551		Bracket to take down and fit engine flywheel
99360558		Tool to lift and transport rocker shaft
99360585		Balance for lifting and handling engine







TOOLS

TOOL NO.	DESCRIPTION	
99360605		Belt to insert piston in cylinder liner (60 - 125 mm)
99360612		Engine flywheel timing pin
99360613		Tool for timing of phonic wheel on timing gear
99360703		Tool to stop cylinder liners
99360706		Tool to extract cylinder liners
99360724		Tool to extract the cylinder liners (to be used with 99360723)







TOOLS

TOOL NO.	DESCRIPTION
99361035 	Brackets fixing the engine to rotary stand 99322230
99365054 	Tool for injector holder heading
99370415 	Tool to detect cylinder liner projections (use with 99395603)
99378100 	Tool for printing engine identification plates (to be used with special punches)
99378101 	Punches (A) for printing engine identification plates (to be used with 99378100)
99378102 	Punches (B) for printing engine identification plates (to be used with 99378100)

TOOLS

TOOL NO.	DESCRIPTION
99378105	 Punches (E) for printing engine identification plates (to be used with 99378100)
99378106	 Punches (F) for printing engine identification plates (to be used with 99378100)
99389834	 Dynamometric screwdriver to calibrate screws for injector solenoid valve
99390310	 Valve guide sleeker
99390772	 Tool to remove residues from injector holder
99390804	 Tool to thread injector holders to be extracted

TOOLS

TOOL NO.	DESCRIPTION	
99394014		Guide bush (to be used with 99394041 or 99394043)
99394041		Cutter to rectify injector holder housing (to be used with 99394015)
99394043		Reamer to rectify injector holder lower side (to be used with 99394015)
99395215		Gauge for centre distance check between camshaft and idle gear
99395216		Measuring pair for angular tightening with 1/2" and 3/4" square couplings
99395363		Complete square to check connecting rod squaring

TOOLS





TOOL NO.	DESCRIPTION
99395603	 Dial gauge (0 - 5 mm)
99395687	 Reaming gauge (50-178 mm)
99396033	 Centering ring of crankshaft front cap


Figure 13



78839

ENGINE - LONGITUDINAL SECTION

Figure 14




ENGINE - CROSS SECTION

78841

54010 DISMANTLING THE ENGINE ON THE BENCH

Figure 15




47562

Before dismantling the engine on the rotary stand 99322230, remove the following components:

- starter (2)
- turbocharger soundproofing shield (1)


Figure 16



47563

Remove the soundproofing shield (1) and plug (2)


Figure 17



47601

Fix the engine to the rotary stand 99322230, by means of brackets 99361035 (1), remove the fan.

Figure 18




73579

Using an appropriate tool (2), operate in the direction of the arrow, and remove the belt (1) driving the water pump, alternator and fan.

Take out the screws and remove the electromagnetic coupling (3).

Figure 19




60489

Remove the following components:

- thermostat unit (6) fitted with turbine actuator pressure sensor (7);
- alternator (2);
- pulley support (1);
- water pump (8) and piping;
- automatic belt tightener support (3);
- fixed belt tightener (9);
- damping flywheel (4) and pulley underneath it;
- automatic belt tightener (5);
- disconnect all the electric connections and the sensors.


Figure 20



60490

Fit the extractor 99340053 (2) and remove the engine crankshaft seal gasket (1), remove the cover (3).

Figure 21




60491

Remove the following components:

- water outlet line (2);
- oil delivery line (4);
- actuator air line (3);
- water delivery line (6);
- oil return line (7);
- turbocharger (5);
- exhaust manifold (1).


Figure 22



47564

Load the belt tensioner spring by tool (4), acting in the direction shown by the arrow, on the head of the screw fixing the roller. The screw cannot be untightened as the thread is counterclockwise. Remove the belt (3). By tool (2), act in the direction shown by the arrow and remove the fan, alternator and water pump control belt (1).

Figure 23




47565

Remove the following components:

- alternator (1);
- belt tightener support (2);
- air conditioner compressor (3);
- flywheel (4);
- water pump and piping (5);
- fan pulley spacer (6);
- thermostat unit (7).


Figure 24



45254

Install extractor 99340051 (2) and remove the seal gaskets (1). Unscrew the screws and remove the cover. Disconnect all electric connections and sensors.


Figure 25



47566

Remove the following components: oil supply lines (1); water cooling supply lines (3); water discharge lines (2); oil return lines (4); turbocharger (5); exhaust manifold (6).


Figure 26



47567


Unscrew the oil filter (1) by tool 99360314 (2). Unscrew the screws and remove the entire heat exchanger (3).

Figure 27



Remove the following components: intake manifold (6); support for fuel filter (1); fuel lines (2); fuel pump (3); compressor (4); control unit (5).


Figure 28



To remove the P.T.O. (if applicable):


- ☐ Disconnect the oil pipe (1).
- ☐ Unscrew the 4 screws (2) and (3).

Figure 29




Remove the rocker arm cover (1), take off the screws (2) and remove: the cover (3), the filter (5) and the gaskets (4 and 6). Take off the screws (8) and remove the blow-by case (7).

Figure 30




Unscrew the screws (2), by using the proper wrench and remove the gear (1) with the phonic wheel.

Figure 31




Unscrew the screws (1); tighten a screw in a reaction hole and remove the shoulder plate (3), remove the sheet gasket.

Figure 32



By means of a properly splined wrench, untighten screws (2) and remove the transmission gear (1)


Figure 33



47568

Stop the engine flywheel (3) rotation by means of tool 99360351 (1), untighten the fixing screws (2) and remove the engine flywheel.


Figure 34



45257

Apply extractor 99340052 (2) and pull out the seal gasket (1).


Figure 35



47569

Untighten the screws (1) and take down the gear box (2).


Figure 36



In sequence, take out the:

- ☐ if the P.T.O. control gear (1) is present;
- ☐ idle gear (2);
- ☐ oil pump gear (3).


Figure 37



45259

- ☐ Remove the check springs (2) of the exhaust brake lever;
- ☐ Untighten the fixing screws (1) of rocker arm shaft.


Figure 38



73533


- ☐ Using tool 99360144 (3), constrain the blocks (4) to the rockers (2).
- ☐ Apply tool 99360553 (1) to the rocker holder shaft (5) and remove the shaft (5) from the cylinder head.

Figure 39



- ☐ Remove the piping (1) for exhaust brake pins;
- ☐ Untighten screws and remove electric connections (2) from solenoid valves;
- ☐ Untighten fixing screws (3) of injector brackets (4).


Figure 40



- ☐ Remove injectors (2)

If this operations is difficult, use extractor 99342148 (1). Install plugs 99360177 instead of injectors.


Figure 41



Remove the camshaft and the fixing screws on cylinder heads


- ☐ By means of wire ropes, lift the cylinder head (1) and remove seals (2).

Figure 42




Untighten screws (2) and remove the engine oil sump (1) with spacer (3) and seal .

Figure 43




Untighten screws and remove suction rose (1).

Figure 44



Rotate the block (1) to the vertical position.


Figure 45



47575

Untighten screws (2) fixing the connecting rod cap (3) and remove it. Remove the connecting rod-piston assembly from the upper side. Repeat these operations for the other pistons.


Figure 46



47576

By means of proper and splined wrenches, untighten the screws (1) and (2) and remove the under-block (3).


Figure 47



47570

Remove the crankshaft (2) with tool 99360500 (1).

Figure 48



47571

Remove the crankshaft half-bearings (1), untighten the screws and remove oil spray nozzles (2). Take down cylinder liners as specified in the relative paragraph on page 49.




After disassembling the engine, thoroughly clean disassembled parts and check their integrity. Instructions for main checks and measures are given in the following pages, in order to determine whether the parts can be re-used.

REPAIR OPERATIONS

540410 CYLINDER BLOCK 540420 Checks and measurements

Figure 49 (Demonstration)




34994

Internal diameter of the cylinder liners is checked for ovalization, taper and wear, using a bore dial (1) centesimal gauge 99395687 (2) previously reset to ring gauge (3), diameter 115 mm.



If a 115 ring gauge is not available use a micrometer caliper.

Figure 50




47439

- 1 = 1st measuring
- 2 = 2nd measuring
- 3 = 3rd measuring

Carry out measurements on each cylinder liner at three different levels and on two (A-B) surfaces, to one another perpendicular, as shown in Figure 50.

Figure 51



47440

- A = Selection class $\varnothing$ 115 to 115.012 mm
- B = Selection class $\varnothing$ 115.010 to 115.022 mm


In case of maximum wear max 0.150 mm or maximum ovalization max 0.100 mm compared to the values indicated in the figure, the liners must be replaced as they cannot be ground, lapped or trued.



Cylinder liners are equipped with spare parts with "A" selection class.



Figure 52



47441

- A = $\varnothing$ 130.200 to 130.225 mm
- B = $\varnothing$ 128.510 to 128.535 mm
- C = $\varnothing$ 130.161 to 130.186
- D = $\varnothing$ 128.475 to 128.500 mm


The figure shows the outer diameters of the cylinder liners and the relative seat inner diameters.

The cylinder liners can be extracted and installed several times in different seats, if necessary.

540420 Replacing cylinder liners

Removal

Figure 56




47577

Place details 99360706 (1 and 2) and plate 99360724 (4) as shown in the figure, by making sure that the plate (4) is properly placed on the cylinder liners. Tighten the screw nut (1) and remove the cylinder liner (3) from the block.

Fitting and checking protrusion

Figure 57



16798


Always replace water sealing rings (3, 4 and 5). Install the adjustment ring (1) on the cylinder liner (2); lubricate lower part of liner and install it in the cylinder unit using the proper tool.



The adjustment ring (1) is supplied as spare parts in the following thicknesses: 0.08 mm - 0.10 mm - 0.12 mm.



Figure 58




77812

Check cylinder barrel protrusion with tool 99360334 (1-2-3-4) and tighten screw (1) to 170 Nm. With dial gauge 99395603 (5) placed on base 99370415 (6). Measure the cylinder barrel protrusion compared to the cylinder head supporting plane, it must be 0,035 to 0,065 mm (Figure 59); otherwise replace the adjusting ring (1, Figure 57) fitted with spare parts having different thickness.

Figure 59

0,035 ÷ 0,065




49017

CYLINDER LINER PROTRUSION


Figure 60

(Demonstration)



35012


When the installation is completed, block the cylinder liners (1) to the block (2) with studs 99360703 (3).

5408 CRANKSHAFT**Figure 61**


49018

MAIN DATA FOR THE CRANK SHAFT PINS AND THE HALF BEARINGS

Check the condition of the journals and the big end pins; there must no be signs of scoring, ovalization or excessive wear.
The data given refer to the normal diameter of the pins.

Figure 62

47537

X. Detail of main journals connections**Figure 63**


47538

Y. Detail of crank pins connections

540812 Measuring main journals and crank pins


Before grinding the crank pins using a micrometer (1), measure the main journals and the crank pins (2) and decide, on the basis of the undersizing of the bearings, the final diameter to which the pins are to be ground.

Figure 64



It is advisable to enter the values found in a table (Figure 66).

Figure 65




During grinding, pay attention to journal and crank pins values specified in figures 62 and 63.

 All journals and crank pins must also be ground to the same undersizing class, in order to avoid any alteration to shaft balance.

Figure 66

Fill in this table with the measurements of the main journals and the crank pins.

MAIN JOURNALS



CRANK PINS

PRELIMINARY MEASUREMENT OF MAIN AND BIG END BEARING SHELL SELECTION DATA

For each of the journals of the crankshaft, it is necessary to carry out the following operations:

MAIN JOURNALS:

- ☐ Determine the class of diameter of the seat in the crankcase.
- ☐ Determine the class of diameter of the main journal.
- ☐ Select the class of the bearing shells to mount.

CRANKPINS:


- ☐ Determine the class of diameter of the seat in the connecting rod.
- ☐ Determine the class of diameter of the crankpin.
- ☐ Select the class of the bearing shells to mount.

DEFINING THE CLASS OF DIAMETER OF THE SEATS FOR BEARING SHELLS ON THE CRANKCASE

On the front of the crankcase, two sets of numbers are marked in the position shown (Figure 67 at top).

- ☐ The first set of digits (four) is the coupling number of the crankcase with its base.
- ☐ The following seven digits, taken singly, are the class of diameter of each of the seats referred to (Figure 67 at bottom).
- ☐ Each of these digits may be **1**, **2** or **3**.

Figure 67



47535

Selecting the main and big end bearing shells



To obtain the required assembly clearances, the main and big end bearing shells need to be selected as described hereunder.



This operation makes it possible to identify the most suitable bearing shells for each of the journals (the bearing shells, if necessary, can have different classes from one journal to another).

Depending on the thickness, the bearing shells are selected in classes of tolerance marked by a coloured sign (red-green – red/black – green/black).


The following tables give the specifications of the main and big end bearing shells available as spares in the standard sizes (STD) and in the permissible oversizes (+0.127, +0.254, +0.508).

Figure 68

	STD	+0.127	+0.254	+0.508
red	2.000 to 2.010		2.127 to 2.137	2.254 to 2.264
red/black		2.063 to 2.073		
green	2.011 to 2.020		2.138 to 2.147	2.265 to 2.274
green/black		2.074 to 2.083		
yellow*	2.021 to 2.030			
yellow/black*		2.084 to 2.093		



	STD	+0.127	+0.254	+0.508
red	3.000 to 3.010		3.127 to 3.137	3.254 to 3.264
red/black		3.063 to 3.073		
green	3.011 to 3.020			
green/black		3.074 to 3.083		
yellow*	3.021 to 3.030			
yellow/black*		3.084 to 3.093		




* Fitted in production only and not supplied as spares

DEFINING THE CLASS OF DIAMETER OF THE MAIN JOURNALS AND CRANKPINS (Journals with nominal diameter)

Main journals and crankpins: determining the class of diameter of the journals.

Three sets of numbers are marked on the crankshaft in the position shown by the arrow (Figure 69 at top):

- ☐ The first number, of five digits, is the part number of the shaft.
- ☐ Under this number, on the left, a set of six digits refers to the crankpins and is preceded by a single digit showing the status of the journals (1 = STD, 2 = -0.127), the other six digits, taken singly, give the class of diameter of each of the crankpins they refer to (Figure 69 at top).
- ☐ The set of seven digits, on the right, refers to the main journals and is preceded by a single digit: the single digit shows the status of the journals (1 = STD, 2 = -0.127), the other seven digits, taken singly, give the class of diameter of each of the main journals they refer to (Figure 69 at bottom).

Figure 69

Selection of main half-bearings (nominal diameter pins)

After detecting, for each journal, the necessary data on block and crankshaft, select the type of half-bearings to be used, in compliance with the following table:

Figure 70

STD.

The diagram shows a cross-section of an engine block and a crankshaft. The crankshaft has four main journals. The engine block has four main bearing caps. The selection table below indicates the required half-bearing type for each journal and bearing cap.

	1	2	3
	1	2	3
	green	green	green
	green	green	green
	2	2	3
	red	green	green
	red	green	green
	3	2	3
	red	red	red
	red	red	red

Selection of main half-bearings (rectified pins)


If the journals have been rectified, the procedure described cannot be applied.

In this case, make sure that the new diameter of the journals is as specified on the table and install the only half-bearing type required for this undersizing.

Figure 7I

red/black =
mm 3.063 to 3.073

green/black =
mm 3.063 to 3.073

**-0.127**

82.784
82.793

1

green/black

green/black

82.794
82.803

2

red/black


red/black

82.804
82.814

3

red/black

red/black

**1****2****3**

green/black

green/black

green/black

green/black

green/black

green/black

green/black

green/black

red/black


red/black

red/black

red/black

-0.254

red =
mm 3.127 to 3.137



82,666
82,686

red



red

red


red

red

red

**1****2****3****-0.508**

red =
mm 3.254 to 3.264



82.412
82.432

red



red

red

red

red

red

**1****2****3**


SELECTING THE BIG END BEARING SHELLS
(JOURNALS WITH NOMINAL DIAMETER)

There are three markings on the body of the connecting rod in the position shown in the view from "A":

- 1 Letter indicating the class of weight:
A = 2890 to 2920 g.
B = 2921 to 2950 g.
C = 2951 to 2980 g.
- 2 Number indicating the selection of the diameter of the big end bearing seat:
1 = 77.000 to 77.010 mm
2 = 77.011 to 77.020 mm
3 = 77.021 to 77.030 mm
- 3 Numbers identifying the cap-connecting rod coupling.

The number, indicating the class of diameter of the bearing shell seat may be **1, 2 o 3**.
Determine the type of big end bearing to fit on each journal by following the indications in the table (Figure 73).



Figure 72



47557

Figure 73

STD.



Class	1	2	3
1	green	green	green
	green	green	green
2	red		green
	red		green
3	red	red	red
	red	red	red

Selection of connecting rod half-bearings (rectified pins)


If pins have been rectified, the procedure described must be applied.

In this case, (for each undersizing) determine the tolerance field the new big end pins belong to, and install the half-bearings identified according to the relative table.

Figure 74

red/black =
mm 2.074 to 2.083

green/black =
mm 2.063 to 2.073

-0.127

72.789
72.798

1

green/black

green/black

72.799
72.808

2

red/black


red/black

72.809
72.818

3

red/black

red/black

**1****2****3**

green/black

green/black

green/black

green/black

green/black

green/black

green/black

green/black

red/black


red/black

green/black

green/black

-0.254

red
mm 2.127 to 2.137
green =
mm 2.138 to 2.147



72.671
72.680

1

red

red

72.681
72.691

red

red

2

green

green

3

green

green

red


red

green

green

-0.508

red =
mm 2.254 to 2.264
green =
mm 2.265 to 2.274



72.417
72.426

1

red

red

72.427
72.437

red

red

2

green

green

3

green

green

red

red


green

green

540815 Replacing the timing control gear and the oil pump

Check that the teeth of the gears are not damaged or worn, otherwise remove them using the appropriate extractor.

Figure 75




After fitting the gear (1) on the crankshaft (2), heat it for ~15 minutes in an oven at temperature not higher than 180°C.

Let them cool down after the installation.

If changing the pin (3), after fitting it on, check it protrudes from the crankshaft as shown in the figure.

540811 Checking main journal installation clearance


Figure 76



Install the oil spray nozzles (2) and have the dowel coincide with the block hole (3).


Install the half-bearings (1) on the main bearings.

Figure 77



Using the hoist and hook 99360500 (1) mount the driving shaft (2).


Figure 78



Install the half-bearings (1) on the main bearings in the underblock (2).


Check the installation clearance between the main journals and the relative bearings as follows:

Figure 79



Place a piece of calibrated wire on the journal of the crankshaft (2), parallel to the longitudinal axis; install the underblock (1), by hoist and appropriate hooks.

Figure 80



☐ Lubricate inside screws (1) con UTDM oil, and tighten them by dynamometric wrench to 140 Nm torque, thus with 60° angle closing, following the diagram in Figure 81.

Figure 81





Diagram showing the tightening order of the screws fixing the lower under-block to the block

Figure 82




☐ Remove the under-block


The clearance between the main bearings and the journals is obtained by comparing the calibrated wire length (2) at the maximum deflection point, with the calibrated scale on the coating (1) containing the calibrated wire (1). Numbers shown on the scale specify the clearance in coupling millimeters. If the clearance obtained is different from the clearance required, replace the half-bearings and repeat this check.

Checking crankshaft end float

Figure 83



End float is checked by placing a magnetic dial gauge (1) on the crankshaft (2), as shown in the figure. If the value obtained is higher than specified, replace the rear thrust half-bearings and repeat this check.

5408 PISTON-CONNECTING ROD ASSEMBLY**Figure 84**

47580


PISTON CONNECTING ROD ASSEMBLY

1. Connecting rod body - 2. Half bearings - 3. Connecting rod cap - 4. Cap fastening screws - 5. Split ring - 6. Scraper ring with spiral spring - 7. Bevel cut sealing ring - 8. Trapezoidal sealing ring - 9. Piston pin - 10. Piston

Make sure the piston does not show any trace of seizing, scoring, cracking; replace as necessary.


Pistons are equipped with three elastic rings: a sealing ring, a trapezoidal ring and a scraper ring.

Pistons are grouped into classes A and B for diameter.

Removal**Figure 85**

49023


Removal of the piston split rings (2) using the pliers 99360184 (1).

Figure 86

49024

Remove the piston pin split rings (2) using the round tipped pliers (1).

Figure 87




49025

Remove the piston pin (1).
If removal is difficult use the appropriate beater.

Measuring the diameter of the pistons


Figure 88



47584

Using a micrometer (2), measure the diameter of the piston (1) to determine the assembly clearance; the diameter should be measured at the specified value.

Figure 89




32618

Measuring the gudgeon pin diameter (1) with a micrometer (2).

Conditions for correct gudgeon pin-piston coupling


Figure 90



49026

Lubricate the pin (1) and the relevant housing on the piston hubs with engine oil; piston must be inserted with a slight finger pressure and it should not come out by gravity.

Figure 91




MAIN DATA ON PISTONS, AND PISTONS RINGS

77816

* Values are determined on $\varnothing$ of 112 mm.

540842 Piston rings


Figure 92



16552

Check the thickness of the piston ring (2) using a micrometer (1).


Figure 93



16552

Check the clearance between the sealing rings (2) and the relative piston housings (1) using a thickness gauge (3).


Figure 94



3513

The sealing ring (2) of the 1° cavity is trapezoidal. Clearance "X" between the sealing ring and its housing is measured by placing the piston (1) with its ring in the cylinder barrel (3), so that the sealing ring is half-projected out of the cylinder barrel.

Figure 95



36134

Check the opening between the ends of the sealing rings (1), using a thickness gauge (2), entered in the cylinder barrel (3). If the distance between ends is lower or higher than the value required, replace split rings.

540830 CONNECTING ROD**Figure 96**


Data concerning the class section of connecting rod housing and weight are stamped on the big end.




When installing connecting rods, make sure they all belong to the same weight class.

DIAGRAM CONNECTING ROD MARKS

- 1 Letter indicating the weight class:
- A = 2890 to 2920 g.
 - B = 2921 to 2950 g.
 - C = 2951 to 2980 g.
- 2 Number indicating the selection of diameter for the big end bearing housing:
- 1 = 77.000 to 77.010 mm
 - 2 = 77.011 to 77.020 mm
 - 3 = 77.021 to 77.030 mm
- 3 Numbers identifying cap-connecting rod coupling



47557

Figure 97


44927

MAIN DATA - BUSH, CONNECTING ROD, PIN AND HALF-BEARINGS

* Values to be obtained after installing the bush

Checking connecting rod alignment

Figure 98




Checking axis alignment

Check the alignment of the axes of the connecting rods (1) with device 99395363 (5), proceeding as follows:

- ☐ Fit the connecting rod (1) on the spindle of the tool 99395363 (5) and lock it with the screw (4).
- ☐ Set the spindle (3) on the V-prisms, resting the connecting rod (1) on the stop bar (2).

Checking torsion

Figure 99




Check the torsion of the connecting rod (5) by comparing two points (A and B) of the pin (3) on the horizontal plane of the axis of the connecting rod.

Position the mount (1) of the dial gauge (2) so that this pre-loads by approx. 0.5 mm on the pin (3) at point A and zero the dial gauge (2). Shift the spindle (4) with the connecting rod (5) and compare any deviation on the opposite side B of the pin (3): the difference between A and B must be no greater than 0.08 mm.

Checking bending

Figure 100



Check the bending of the connecting rod (5) by comparing two points C and D of the pin (3) on the vertical plane of the axis of the connecting rod.

Position the vertical mount (1) of the dial gauge (2) so that this rests on the pin (3) at point C.

Swing the connecting rod backwards and forwards seeking the highest position of the pin and in this condition zero the dial gauge (2).

Shift the spindle (4) with the connecting rod (5) and repeat the check on the highest point on the opposite side D of the pin (3). The difference between point C and point D must be no greater than 0.08 mm.

Mounting the connecting rod - piston assembly


Carry out the steps for removal described on page 61 in reverse order.



The connecting rod screws can be reused as long as the diameter of the thread is not less than 13.4 mm.

Mounting the piston rings

Figure 101




To fit the piston rings (1) on the piston (2) use the pliers 99360184 (3).

The rings need to be mounted with the word "TOP" (4) facing upwards. Direct the ring openings so they are staggered 120° apart.

Fitting the connecting rod-piston assembly into the piston liners

Figure 102



Install half-bearings (1), selected as specified on page 66, on both the connecting rod and the cap.



As spares, class A pistons are provided and can be fitted also to cylinder barrels belonging to class B.

Fit the connecting rod-piston assemblies (1) into the piston liners (2) using band 99360605 (1, Figure 104). Check the following:

- ☐ the openings of the split rings are offset by 120°;

Figure 103





Figure 104



- ☐ all pistons belong to the same class, A or B;
- ☐ ideogram stamped on the piston crown is placed toward the engine flywheel, or the cavity, on the piston cover, corresponds to the position of the oil spray nozzles.

Piston protrusion check

Once assembly is complete, check piston protrusion from cylinder barrels: it must be 0.32-0.69 mm.

- ☐ 1 Connecting rod-piston assembly
- ☐ 2 Marking area on the piston crown of ideogram specifying the assembly position and the selection class
- ☐ 3 Connecting rod marking area (see fig. 96).


61831

540831 Checking assembly clearance of big end pins

To check the clearance proceed as follows:

Connect the connecting rods to the relative main journals, place a length of calibrated wire on the latter.

Figure 105



Install the connecting rod caps (1) with half-bearings; tighten the connecting rod cap fixing screws (2) to 50 Nm (5 kgm) torque. By tool 99395216 (3), tighten the screws further at 40° angle.


Remove the caps and check the clearance by comparing the width of the calibrated wire with the scale calibration on the envelope containing the wire.

540610 CYLINDER HEAD

Before taking down the cylinder head, check the seal using the appropriate tool; in case of leakage replace the cylinder head.

Valve removal

Figure 106




Install and fix tool 99360264 (2) with bracket (4); tighten by lever (1) until cotters are removed (3); remove the tool (2) and the upper plate (5), the spring (6) and the lower plate (7). Repeat the operation on all the valves. Turn the cylinder head upside down and remove the valves (8).

Checking the planarity of the head on the cylinder block

Figure 107

(Demonstration)



The planarity (1) is checked using a ruler (2) and a thickness gauge (3). If deformations exist, surface the head using proper surface grinder; the maximum amount of material to be removed is 0.2 mm.




After leveling, make sure that valve sinking and injector protrusion are as described in the relative paragraph.

540622 VALVE


Removing deposits and checking the valves

Figure 108



Remove carbon deposits using the metal brush supplied. Check that the valves show no signs of seizure or cracking. Check the diameter of the valve stem using a micrometer (see fig. 109) and replace if necessary.

Figure 109



47584


MAIN DATA - VALVES AND VALVE GUIDES

* Values to be obtained after installing the valve guides

Check, by means of a micrometer, that valve stem diameters are as specified; if necessary, grind the valves seat with a grinder, removing the minimum quantity of material.

540667 VALVE GUIDES

Figure 110



INSTALLATION DIAGRAM FOR VALVE GUIDES AND VALVES

47509

* Values to be obtained after installing the guide valves


Replacing of valve guides

Remove valve guides by means of tool 99360288. Install by means of tool 99360288 equipped with part 99360294, which determines the exact installation position of valve guides into the cylinder heads; if they are not available, install the valve guides in the cylinder head so that they project out by mm 16.3 to 16.7 (fig. 110). After installing the valve guides, smooth their holes with sleeker 99390310.

Replacing - Reaming the valve seats

To replace the valve seats, remove them using the appropriate tool.

Figure 111



Ream the valve seats (2) on cylinder head using tool 99305019 (1).



Valve seats must be reamed whenever valves or valve guides are replaced or ground.


After reaming the valve seats, use tool 99370415, to make sure that the valve position, with respect to the cylinder head surface, is the following:

- ☐ -0.5 to -0.8 mm (recessing) of exhaust valves;
- ☐ -1.6 to 1.9 mm (recessing) of discharge valves.

540613 REPLACING INJECTOR HOLDER CASES

Removal

Figure 112




To replace the injector case (2), act as follows:

- ☐ thread the case (2) with tool 99390804 (1).

Carry out operations described in figs. 112-115-116-117 by fixing tools to the cylinder head by means of bracket A.


Figure 113



45631

- fasten extractor 99342149 (2) to case (3), by tightening the nut (1), and pull out the case from cylinder head.


Figure 114



45633

- Remove any residue (1), with tool 99390772 (2), from the cylinder head groove.


Figure 115



45635

- Lubricate sealing rings (3) and fit them to the case (4); fix tool 99360554 (2) to the cylinder head by means of bracket A, install the new case, tighten the screw (1), upsetting the case lower part.


Figure 116



45632

- Adjust the casing hole (3) with borer 99394043 (1) and guide bushing 99394014 (2).


Figure I 17



- Through miller 99394041 (1) and bushing 99394014 (2), ream the injector seat in the case (3), check the injector protrusion from the cylinder head plane which must be 0.7 mm.


Checking protrusion of injectors

Figure I 18





Using dial gauge (1), check the protrusion of the injector (2) which must be 0.7 mm.

Figure I 19





INSTALLATION DIAGRAM FOR
INJECTOR CASE

44909

5412 TIMING GEAR**541211 Checking cam lift and pin alignment****Figure 120**



47506

Place the camshaft (4) on the tailstock (1) and check cam lift (3) using a centesimal gauge (2); values are shown in table on page 20.

Figure 121

47507


When the camshaft (4) is on the tailstock (1), check alignment of supporting pin (3) using a centesimal gauge (2); it must not exceed 0.030 mm. If misalignment exceeds this value, replace the shaft.

Figure 122

47505

In order to check installation clearance, measure bush inner diameter and camshaft pin (1) diameter; the real clearance is obtained by their difference.

If clearance exceeds 0.150 mm, replace bushes and, if necessary, the camshaft.


541210 Camshaft**Figure I23**

47504

MAIN DATA - CAMSHAFT AND TOLERANCES

The surfaces of shaft supporting pin and cams must be extremely smooth; if you see any sign of seizing or scoring, replace the shaft and the relative bushes.

TOLERANCES	TOLERANCE CHARACTERISTIC	SYMBOL
ORIENTATION	Perpendicularity	$\perp$
POSITION	Concentricity or coaxial alignment	$\odot$
OSCILLATION	Circular oscillation	$\nearrow$
IMPORTANCE CLASS ASSIGNED TO PRODUCT CHARACTERISTICS		SYMBOL
CRITICAL		$\odot$
IMPORTANT		$\oplus$
SECONDARY		$\ominus$

541213 Bushes**Figure I24**


47508

MAIN DATA - CAMSHAFT BUSHES AND RELATIVE BLOCK SEATS


* Bush inner diameter after installation

The bush surfaces must not show any sign of seizing or scoring; if they do replace them.

Measure the bush inner diameters with a baremeter and replace them, if the value measured exceeds the tolerance value. To take down and fit back the bushes, use the proper tool 99360487.


541213 Replacing camshaft bushes using beater 99360487**Figure 125**

A. Drift with seat for bushings to insert/extract. - B. Grub screw for positioning bushings. - C. Reference mark to insert seventh bushing correctly. - D. Reference mark to insert bushings 1, 2, 3, 4, 5, 6 correctly (red marks). - E. Guide bushing. - F. Guide line. - G. Guide bushing to secure to the seventh bushing mount. - H. Plate fixing yellow bushing to cylinder head. - I. Grip. - L. Extension coupling.

Removal**Figure 126**


The sequence for removing the bushings is 7, 6, 5, 4, 3, 2, 1. The bushings are extracted from the front of the single seats. Removal does not require the drift extension for bushings 5, 6 and 7 and it is not necessary to use the guide bushing. For bushings 1, 2, 3 and 4 it is necessary to use the extension and the guide bushings. Position the drift accurately during the phase of removal.

- 1 Position the bushing to insert on the drift (A) making the grub screw on it coincide with the seat (B) (Figure 125) on the bushing.
- 2 Position the guide bushing (E) and secure the guide bushing (G) (Figure 125) on the seat of the 7th bushing with the plate (H).
- 3 While driving in the bushing, make the reference mark (F) match the mark (M). In this way, when it is driven home, the lubrication hole on the bushing will coincide with the oil pipe in its seat.
The bushing is driven home when the 1st red reference mark (D) is flush with the guide bushing (G).

Figure 128


To insert the bushing (6), proceed as follows:

- ☐ Unscrew the grip (I) and the extension (N).
- ☐ Position the extension (N) and the guide bushing (E) as shown in the figure.
- ☐ Repeat steps 1, 2, 3.

Assembly**Figure 127**

Assemble the drift together with the extension.
To insert bushings 1, 2, 3, 4 and 5, proceed as follows:

Figure I29




To insert bushing (7), proceed as follows:

- ☐ Unscrew the grip (I) and the extension (N).
- ☐ Refit the guide (G) from the inside as shown in the figure.
- ☐ Position the bushing on the drift (A) and bring it close up to the seat, making the bushing hole match the lubrication hole in the head. Drive it home.
The 7th bushing is driven in when the reference mark (C) is flush with the bushing seat.

540665 VALVE SPRINGS


Figure I30



Before assembly, the flexibility of the valve springs has to be checked with the tool 99305047.


Compare the load and elastic deformation data with those of the new springs given in the following figure.

Figure I31




Fitting the valves and oil seal ring

Figure I32




Lubricate the valve stem and place the valves in the relevant valve guides; install the lower plates (3) using tool 99360292, fit the oil seal ring (1) on valve guides (2), then install the valves as shown:

Figure I33



- ☐ fit springs (6) and the upper plate (5);
- ☐ apply tool 99360264 (2) and block it with bracket (4); tighten the lever (1) until cotters are installed (3), remove tool (2).

5412 ROCKER SHAFT**Figure I34**

44925

The camshaft cams directly control rockers: 6 for injectors and 12 for valves.


Rockers slide directly on the cam profiles via rollers.

The other end acts on a bar directly supported by the two valves stems.

A pad is placed between the rocker adjusting screw and the bar.

Two lubrication holes are obtained inside the rockers.

The rocker shaft practically covers the whole cylinder head; remove it to have access to all the underlying components.


Shaft**Figure I35**

37,984
38,000

79171


MAIN DATA OF THE ROCKER ARM SHAFT

Check that the surface of the shaft shows no scoring or signs of seizure; if it does, replace it.

Rocker**Figure I36**

SECTION A-A


SECTION B-B



38,015
38,071


44914

The bush surfaces must not show any trace of scoring or excessive wear; otherwise, replace bushes or the whole rocker.

PUMP INJECTOR ROCKER**Figure I37**


SECTION A-A

SECTION B-B




38,025
38,041

44912

EXHAUST VALVES ROCKER**Figure I38**

SECTION A-A

SECTION B-B



50,025
50,041

44913


DISCHARGE VALVE ROCKER

ASSEMBLING THE ENGINE ON THE BENCH

Fix the engine block to the stand 99322230 by means of brackets 99361035.

Install the cylinder liners as described in page 49.

Figure I39




47586

Fit the oil spray nozzles (2), so that the dowel coincides with the block hole (3).

Place the half bearings (1) on the main bearings.


Figure I40



47570

Lubricate the half bearings, then install the crankshaft (2) by means of hoist and hook 99360500 (1).


Figure I41



49021

Place the half-bearings (1) on the main bearings in the underblock (2).


Figure I42



47595

By means of suitable equipment (1) apply silicone LOCTITE 5699 to the block, as shown in the figure.

Figure I43




47596

Sealant application diagram



Fit the underblock within 10' of the application of the sealant.


Figure I44



49022

Fit the underblock by means of a suitable hoist and hooks (1).


Figure I45



47581

Fit the underblock and, using a dynamometric wrench (2), close the splined outer (1) screws to 25 Nm torque, according to the diagram shown on page 79.

Figure I46



47579

Close the inner screws (1) to 140 Nm torque by means of a dynamometric wrench (3), then with two further angular phases $60^\circ + 60^\circ$, using tool 99395216 (4). Tighten again the outer screws (1, Figure I45) with 90° angular closing, using tool 99395215 (3, Figure I45).



DIAGRAM SHOWING THE UNDERBLOCK FIXING SCREWS TIGHTENING ORDER**Figure I 47**

Figure 148



Rotate the cylinder assembly placing it vertically. Lubricate the half-bearings (1) and fit them in the connecting rod and the cap.



Not finding it necessary to replace the connecting rod bearings, you need to fit them back in exactly the same sequence and position as in removal. If the big end bearings need to be replaced, choose them according to the description given from page 52 to page 58.



Do not make any adjustment on the bearing shells.

Fitting the connecting rod-piston assembly into the cylinder liners

Figure 149





Figure 150



Fit the connecting rod-piston assemblies (2) into the piston liners, using the band 99360605 (1, Figure 150). Check the following:

- ☐ the openings of the split rings are offset by 120°;
- ☐ all pistons belong to the same class, A or B;
- ☐ ideogram (2, Figure 149), stamped on the piston crown, is placed toward the engine flywheel, or the cavity, on the piston skirt, corresponds to the position of the oil spray nozzles




The pistons are supplied as spares in class A and can also be fitted in class B cylinder liners.

- 1 Connecting rod-piston assembly
- 2 Marking area of ideogram on the piston crown
- 3 Connecting rod marking area

61831


Figure I51



47594

Connect the connecting rods to the relative journals, fit the connection rod caps (1) with half bearings; tighten the fixing screws (2) of the connecting rod caps to 50 Nm torque (5 kgm). Using tool 99395216 (3), further tighten screws with 40° angle.


Figure I52



45255

By means of centering ring 99396033 (2), check the exact cover position (1), otherwise act as necessary and tighten the screws.


Figure I53



45256

Fit the sealing gasket (1), install the fitting tool 99346245 (2) and drive the sealing gasket (1) by screwing nut (3).


Figure I54



45266

Make sure that pistons 1-6 are exactly at the TDC. Place the sealing gasket (2) on the block. Fit the cylinder head (1) and tighten screws as shown in figs. I55, I56 and I57.


Figure I55



44900

Diagram showing the cylinder head fixing screws tightening order

Figure I56




45267

□ Preliminary tightening by means of a dynamometric wrench (1):

1st phase: 50 Nm (5 kgm)


2nd phase: 100 Nm (10 kgm)

Figure 157




- Angle closing by means of tool 99395216 (1):
 3rd phase: 90° angle
 4th phase: 75° angle

Figure 158



Fit the oil pump (4), intermediate gears (2) with rod (1) and tighten screws (3) in two phases:
 preliminary tightening 30 Nm
 angle closing 90°

Figure 159




Apply sealant LOCTITE 5699 to the gear box using the proper equipment (1).

The sealer string (1) diameter is to be $1,5 \pm 0,2$

⚠ Install the gear box within 10' of the application of the sealant.

Tighten the screws shown in the figure by means of a dynamometric wrench, in compliance with the following order and tightening torque:


Figure 160



Engines without power take-off

- ☆ no. 13 screws M12 x 1.75 x 80 tightening torque 63 Nm
- * no. 3 screws M10 x 1.5 x 35 tightening torque 42 Nm
- no. 1 screw M10 x 1.5 x 100 tightening torque 42 Nm
- △ no. 1 screw M10 x 1.5 x 180 tightening torque 42 Nm
- ▭ no. 2 screws M18 x 1.25 x 125 tightening torque 24 Nm


Figure 161



Engines with power take-off

- ☆ no. 10 screws M12 x 1.75 x 80 tightening torque 63 Nm
- no. 3 screws M10 x 1.5 x 35 tightening torque 42 Nm
- no. 1 screw M10 x 1.5 x 170 tightening torque 42 Nm
- △ no. 1 screw M10 x 1.5 x 180 tightening torque 42 Nm
- ▭ no. 2 screws M12 x 1.75 x 125 tightening torque 63 Nm
- no. 8 screw M10 x 1.5 x 120
- ◇ no. 2 screw M10 x 1.5 x 120 (apply to the thread LOCTITE 275)

Figure 162



Fit the sealing gasket (1), install the fitting tool 99346246 (2) and drive the sealing gasket by screwing the nut (3).

540850 ENGINE FLYWHEEL




If the teeth of the ring gear mounted on the engine flywheel, for starting the engine, are very damaged, replace the ring gear. It must be fitted after heating the ring gear to a temperature of approx. 200°C.

Fitting engine flywheel



The crankshaft has a locating peg that has to couple with the relevant seat on the engine flywheel.


Figure 163



DETAIL OF PUNCH MARKS ON ENGINE FLYWHEEL FOR PISTON POSITIONS

A. Hole on flywheel with one reference mark, corresponding to the TDC of pistons 3-4. - B. Hole on flywheel with one reference mark, corresponding to the TDC of pistons 1-6. - C. Hole on flywheel with one reference mark, corresponding to the TDC of pistons 2-5. - D. Hole on flywheel with two reference marks, position corresponding to 54°.


Figure 164



Position the flywheel (1) on the crankshaft, lubricate the thread of the screws (2) with engine oil and screw them down. Lock rotation with tool 99360351 (3). Lock the screws (2) in three phases.

First phase: pre-tightening with torque wrench (4) to a torque of 100 Nm (10 kgm).


Figure 165



Second phase: closing to angle of 60° with tool 99395216 (1).

Fitting camshaft

Figure I66



72436

Position the crankshaft with the pistons 1 and 6 at the top dead centre (T.D.C.).


This situation occurs when:

1. The hole with reference mark (5) of the engine flywheel (4) can be seen through the inspection window.
2. The tool 99360612 (1), through the seat (2) of the engine speed sensor, enters the hole (3) in the engine flywheel (4).

If this condition does not occur, turn the engine flywheel (4) appropriately.

Remove the tool 99360612 (1).

Figure I67




73843

Fit the camshaft (4), positioning it observing the reference marks (→) as shown in the figure.

Lubricate the seal (3) and fit it on the shoulder plate (2).

Mount the shoulder plate (2) with the sheet metal gasket (1) and tighten the screws (5) to the required torque.


Figure I68



45376

- Apply gauge 99395215 (1), check and record the position of the rod (3) for the transmission gear; tighten the screw (2) to the prescribed torque.

Figure I69




45269

- Remove the transmission gear (1) and tighten screws (2) by means of proper splined wrench, to the prescribed torque.



Replace the idle gear bushing (1) when wear is detected. After installing the bushing, adjust it to $j_{58.010 \pm 0.10 \text{ mm}}$.

Figure 170




Position the gear (2) on the camshaft so that the 4 slots are centred with the holes for fixing the camshaft, without fully locking the screws (5).

Using the dial gauge with a magnetic base (1), check that the clearance between the gears (2 and 3) is 0.073 – 0.195 mm; if this is not so, adjust the clearance as follows:

- ☐ Loosen the screws (4) fixing the idle gear (3).
- ☐ Loosen the screw (2, Figure 168) fixing the link rod. Shift the link rod (3, Figure 168) to obtain the required clearance.
- ☐ Lock the screw (2, Figure 168) fixing the link rod and screws (4, Figure 170) fixing the idle gear to the required torque.


Fitting pump-injectors

Figure 171



Fit the seals (1) (2) (3) on the injectors.

Figure 172



Mount:


- ☐ The injectors (2) and, using a torque wrench, lock the bracket fixing screws to a torque of 26 Nm.
- ☐ The exhaust brake cylinders (1) and (4) and, using a torque wrench, fix them to a torque of 19 Nm.
- ☐ The crosspieces (3) on the valve stem, all with the largest hole on the same side.

Fitting rocker-arm shaft assembly

Figure 173




Before refitting the rocker-arm shaft assembly, make sure that all the adjustment screws have been fully unscrewed.



Using tool 99360144 (3), fasten the blocks (4) to the rocker arms (2).

Apply the tool 99360553 (1) to the rocker arm shaft (5) and mount the shaft on the cylinder head.

Figure 174




45261

Lock the screws (2) fixing the rocker-arm shaft as follows:

- ☐ 1st phase: tightening to a torque of 40 Nm (10 kgm) with the torque wrench (1).
- ☐ 2nd phase: closing with an angle of 60° using the tool 99395216 (3).


Figure 175



60574

- ☐ Mount the engine brake lever retaining springs (3).
- ☐ Connect the pipe (2) to the engine brake cylinders (4) and to the cylinder with the engine brake solenoid valve (1).

Figure 176




71777

Mount the electric wiring (2), securing it on the electro-injectors with a torque screwdriver (1) to a torque of 1.36 - 1.92 Nm.

Camshaft timing

Figure 177



71776


Apply the tool 99360321 (6) to the gearbox (3).



The arrow shows the direction of rotation of the engine when running.

Using the above-mentioned tool, turn the engine flywheel (1) in the direction of rotation of the engine so as to take the piston of cylinder no.1 to approximately the T.D.C. in the phase of combustion. This condition occurs when the hole with one reference mark (4), after the hole with two reference marks (5) on the engine flywheel (1), can be seen through the inspection window (2).

Figure 178




71774

The exact position of piston no.1 at the T.D.C. is obtained when in the above-described conditions the tool 99360612 (1) goes through the seat (2) of the engine speed sensor into the hole (3) in the engine flywheel (4).

If this is not the case, turn and adjust the engine flywheel (4) appropriately.

Remove the tool 99360612 (1).

Figure 179



60573


Set the dial gauge with the magnetic base (1) with the rod on the roller (2) of the rocker arm that governs the injector of cylinder no.1 and pre-load it by 6 mm.

With tool 99360321 (6, Figure 177), turn the crankshaft clockwise until the pointer of the dial gauge reaches the minimum value beyond which it can no longer fall.

Reset the dial gauge.

Turn the engine flywheel anticlockwise until the dial gauge gives a reading for the lift of the cam of the camshaft of 4.90 ± 0.05 mm.

Figure 180




77259

The camshaft is in step if at the cam lift values of 4.90 ± 0.05 mm there are the following conditions:

- 1) The hole marked with a notch (5) can be seen through the inspection window
- 2) The tool 99360612 (1) through the seat (2) of the engine speed sensor goes into the hole (3) in the engine flywheel (4).


Figure 181



60575

If you do not obtain the conditions illustrated in Figure 180 and described in points 1 and 2, proceed as follows:


- 1) Loosen the screws (2) securing the gear (1) to the camshaft and utilize the slots (1, Figure 182) on the gear (2, Figure 182).
- 2) Turn the engine flywheel appropriately so as to bring about the conditions described in points 1 and 2 Figure 180, it being understood that the cam lift must not change at all.
- 3) Lock the screws (2) and repeat the check as described above.
- 4) Tighten the screws (2) to the required torque.

Figure 182

71778

When it is not possible to adjust advance through the slots (1) and the camshaft turns because integral with the gear (2); thus the cam lift reference value varies and it is necessary to proceed in the following way:

- 1) Fasten the screws (2, Figure 181) and rotate the engine flywheel clockwise by $\sim 1/2$ turn;
- 2) Turn the engine flywheel anticlockwise until the dial gauge gives a reading of the lift of the cam of the camshaft of 4.90 ± 0.05 mm
- 3) Take out the screws (2, Figure 181) and remove the gear (2) from the camshaft.

Figure 183

77259



Turn the flywheel (4) again to bring about the following conditions:

- ☐ Notch (5) visible through the lower inspection window;
- ☐ The tool 99360612 (1) inserted in the hole (3) in the engine flywheel (4) through the seat (2) of the engine speed sensor.

Mount the gear (2, Figure 182) with the 4 slots (1, Figure 182) centred with the fixing holes of the camshaft, locking the relevant screws to the required tightening torque. Check the timing of the shaft by first turning the flywheel clockwise to discharge the cam completely and then turn the flywheel anticlockwise until the dial gauge gives a reading of: 4.90 ± 0.05 mm

Check the timing conditions described in Figure 180.

Phonic wheel timing

Figure 184

77260


Turn the output shaft bringing cylinder piston 1 at compression stage to TDC; turn the flywheel by about $1/4$ turn in opposite direction than normal direction of rotation. Turn the flywheel again according to normal direction of rotation until the hole marked with the double notch (4) can be seen through the inspection hole set under the flywheel housing. Fit tool 99360612 (5) into the flywheel sensor seat (6).

Fit tool 99360613 (2), through the timing sensor seat, on the tooth obtained on the phonic wheel.

Should tool (2) fitting be difficult, slacken screws (3) and direct the phonic wheel (1) properly to position the tool (2) on the tooth. Tighten the screws (3).

Intake and exhaust rocker play adjustment and pre-loading of rockers controlling pump injectors.

Figure 185



44936A

ADJUSTMENT OF INTAKE, EXHAUST AND INJECTION ROCKERS

Adjustment of clearances between rockers and valve studs and preloading of pump injector rockers should be carried out with extreme care.

Take the cylinder where clearance must be adjusted to the bursting phase; its valves are closed while balancing the symmetric cylinder valves.

Symmetric cylinders are 1-6, 2-5 and 3-4.

In order to properly operate, follow these instructions and data specified on the table.

Adjustment of clearance between the rockers and rods controlling intake and exhaust valves:

- ☐ Using a polygonal wrench, loosen nut (1) locking the adjustment screw;
- ☐ Insert the thickness gauge blade (3);
- ☐ Tighten or untighten the adjustment screw with the appropriate wrench;
- ☐ Make sure that the gauge blade (3) can slide with a slight friction;
- ☐ Lock the nut (1), by blocking the adjustment screw.

Pre-loading of rockers controlling pump injectors:

- ☐ Using a polygonal wrench, loosen the nut locking the rocker adjustment screw (5) controlling the pump injector (6);

- ☐ Using an appropriate wrench (4), loosen the adjustment screw until the pumping element is at the end-of-stroke;
- ☐ Tighten the adjustment screw, with a dynamometric wrench, to 5 Nm tightening torque (0.5 kgm);
- ☐ Untighten the adjustment screw by 1/2 to 3/4 rotation;
- ☐ Tighten the locking nut.


FIRING ORDER **1-4-2-6-3-5**

Clockwise start-up and rotation	Adjusting cylinder valve no.	Adjusting clearance of cylinder valve no.	Adjusting pre-loading of cylinder injector no.
1 and 6 at P.M.S.	6	1	5
120°	3	4	1
120°	5	2	4
120°	1	6	2
120°	4	3	6
120°	2	5	3



In order to properly carry out the above-mentioned adjustments, follow the sequence specified in the table, checking the exact position in each rotation phase by means of pin 99360612, to be inserted in the 11th hole in each of the three sectors with 18 holes each.

Figure 186



Fit the distribution cover (1).

Fit the blow-by case (7) and its gasket and then tighten the screws (8) to the prescribed torque.
Install the filter (5) and the gaskets (4 and 6).




The filter (5) operation is unidirectional, therefore it must be assembled with the two sight supports as illustrated in the figure.

Fit the cover (3) and tighten the fastening screws (2) to the prescribed torque.



Apply silicone LOCTITE 5699 on the blow-by case (7) surface of engines fitted with P.T.O. according to the procedure described in the following figure.

Figure 187



Apply silicone LOCTITE 5699 on the blow-by case and form a string (2) of $\varnothing 1.5 \pm \begin{smallmatrix} 0.5 \\ 0.2 \end{smallmatrix}$ as shown in the figure.



Fit the blow-by case (1) within 10' from sealer application.

ENGINE COMPLETION

Complete the engine by installing or connecting the following components:

- ☐ thermostatic unit;
- ☐ belt tensioner, water pump, alternator;
- ☐ control belt;
- ☐ belt tensioner, conditioner compressor;
- ☐ control belt.

Figure 188





DIAGRAM FOR THE INSTALLATION OF FAN BELTS - WATER PUMP - ALTERNATOR AND CONDITIONER COMPRESSOR

1. Alternator - 2. Fan - 3. Water pump - 4. Crankshaft - 5. Conditioner compressor

Figure 189




To install belts (1-3), use the appropriate tools (2-4) to work on the tensioners, as shown by arrows.



Automatic tensioners do not require further adjustments after the installation.

- ☐ damping flywheel;
- ☐ fan;
- ☐ compressor;
- ☐ fuel pump;
- ☐ fuel filter and piping;
- ☐ pre-heating resistance;
- ☐ intake manifold;
- ☐ soundproof shields;
- ☐ heat exchanger;
- ☐ oil filter, lubricating the gasket;
- ☐ rockers caps;
- ☐ exhaust manifold;
- ☐ turbocharger and its oil and water piping;
- ☐ power take-off (P.T.O.) (if any) and related pipes;
- ☐ oil level stick and oil vapor vent;
- ☐ rotate the engine and install the oil rose pipe.

Figure I 90




47573


- ☐ place the gasket (4) on the oil sump (1), position the spacer (3) and fit the sump to the engine block by tightening screws (2) to the prescribed torque;
- ☐ electric connections and sensors;
- ☐ remove the engine from the stand and fit the starter;
- ☐ fill the engine with the oil quantity required.

5430 LUBRICATION

Engine lubrication is obtained with a gear pump driven by the crankshaft via gears.
A heat exchanger governs the temperature of the lubricating oil.
The oil filter, signalling sensors and safety valves are installed in the intercooler.

Figure 191




543010 Oil pump**Figure 192**

60560


The oil pump (1) cannot be overhauled. On finding any damage, replace the oil pump assembly.

See under the relevant heading for replacing the gear (2) of the crankshaft.

Overpressure valve**Figure 194**

77820


MAIN DATA TO CHECK THE OVERPRESSURE VALVE SPRING

Figure 193


77817

OIL PUMP CROSS-SECTION


I. Overpressure valve – Start of opening pressure 10.1 ± 0.7 bars

Oil pressure control valve**Figure 195**


The oil pressure control valve is located on the left-hand side of the crankcase.
Start of opening pressure 5 bars.

Figure 196


MAIN DATA TO CHECK THE OIL PRESSURE
CONTROL VALVE SPRING

543110 Heat exchanger**Figure 197****HEAT EXCHANGER**

The following elements are fitted on the intercooler: 1. Transmitter for low pressure warning lamp - 2. By-pass valve - 3. Oil temperature sensor - 4. Oil pressure sensor for single gauge - 5. Heat valve. Number of intercooler elements: 7

By-pass valve**Figure 198**

The valve quickly opens at a pressure of: 3 bars.


Thermostatic valve**Figure 199**

Start of opening:

☐ travel 0.1 mm at a temperature of $82 \pm 2^\circ\text{C}$.

End of opening:

☐ travel 8 mm at a temperature of 97°C .

Engine oil filters**Figure 200**

This is a new generation of filters that permit much more thorough filtration as they are able to hold back a greater amount of particles of smaller dimensions than those held back by conventional filters with a paper filtering element.

These high-filtration devices, to date used only in industrial processes, make it possible to:

- ☐ reduce the wear of engine components over time;
- ☐ maintain the performance/specifications of the oil and thereby lengthen the time intervals between changes.

External spiral winding

The filtering elements are closely wound by a spiral so that each fold is firmly anchored to the spiral with respect to the others. This produces a uniform use of the element even in the worst conditions such as cold starting with fluids with a high viscosity and peaks of flow. In addition, it ensures uniform distribution of the flow over the entire length of the filtering element, with consequent optimization of the loss of load and of its working life.

Mount upstream

To optimize flow distribution and the rigidity of the filtering element, this has an exclusive mount composed of a strong mesh made of nylon and an extremely strong synthetic material.

Filtering element

Composed of inert inorganic fibres bound with an exclusive resin to a structure with graded holes, the element is manufactured exclusively to precise procedures and strict quality control.

Mount downstream

A mount for the filtering element and a strong nylon mesh make it even stronger, which is especially helpful during cold starts and long periods of use. The performance of the filter remains constant and reliable throughout its working life and from one element to another, irrespective of the changes in working conditions.

Structural parts

The o-rings equipping the filtering element ensure a perfect seal between it and the container, eliminating by-pass risks and keeping filter performance constant. Strong corrosion-proof bottoms and a sturdy internal metal core complete the structure of the filtering element.

When mounting the filters, keep to the following rules:

- ☐ Oil and fit new seals.
- ☐ Screw down the filters to bring the seals into contact with the supporting bases.
- ☐ Tighten the filter to a torque of $35 \pm 40 \text{ Nm}$.

5432 COOLING

Description

The engine cooling system works with forced circulation inside closed circuit and can be connected to an additional heater (if any) and to the intarder intercooler. It consists mainly of the following components:

- an expansion reservoir whose plug (1) incorporates two valves – discharge and charge – controlling the system pressure.
- a coolant level sensor placed at the bottom of the expansion reservoir with two coupling points:
 - coupling point for sensor S1 6 litres
 - coupling point for sensor S2 3.7 litres
- an engine cooling unit to dissipate the heat taken by the coolant from the engine through the intercooler.
- a heat exchanger to cool down lubrication oil;
- a water pump with centrifugal system incorporated in the cylinder block;
- an electric fan consisting of a 2-speed electro-magnetic joint equipped with a neutral wheel shaft hub fitted with a metal plate moving along the axis and where the fan is installed. It is controlled electronically by the vehicle Multiplex system.
- a 3-way thermostat controlling the coolant circulation.

Operation

The water pump is actuated by the crankshaft through a poli-V belt and sends coolant to the cylinder block, especially to the cylinder head (bigger quantity). When the coolant temperature reaches and overcomes the operating temperature, the thermostat is opened and from here the coolant flows into the radiator and is cooled down by the fan. The pressure inside the system depending on the temperature variation is controlled by the discharge and charge valves incorporated in the expansion reservoir filling plug (1).

The discharge valve has a double function:

- keep the system under light pressure in order to raise the coolant boiling point;
- discharge the pressure surplus in the atmosphere as a result of the coolant high temperature.


The charge valve makes it possible to transfer the coolant from the expansion reservoir to the radiator when a depression is generated inside the system as a result of the coolant volume reduction depending on the fall in the coolant temperature.


Discharge valve opening:

- 1st breather 0.9 ^{+0.2}_{-0.1} bar
- 2nd breather 1.2 ^{+0.2}_{-0.1} bar

Charge valve opening -0.03 ⁺⁰_{-0.02} bar

Figure 201




543210 Water pump**Figure 202****WATER PUMP SECTION**


The water pump consists of: rotor, seal bearing and control pulley.



Make sure that the pump casing has no cracking or water leakage; otherwise, replace the entire pump.

543250 Thermostat**THERMOSTAT OPERATION VIEW****Figure 203**

 Water circulating in the engine


Figure 204

 Water issuing from thermostat

Check the thermostat works properly; replace it if in doubt.

Temperature of start of travel $84^{\circ}\text{C} \pm 2^{\circ}\text{C}$.

Minimum travel 15 mm at $94^{\circ}\text{C} \pm 2^{\circ}\text{C}$.

543210 Electromagnetic coupling**Figure 205****ELECTROMAGNETIC COUPLING SECTION**

The electro-magnetic joint action depends on:

- ☐ the coolant temperature;
- ☐ the climate control system fluid pressure (if any);
- ☐ the slowing down action of the interarder on (if any).

Coolant temperature for:

- ☐ engagement 93°C
- ☐ disengagement 88°C

With climate control system

Climate control system fluid pressure:

- ☐ 2nd speed engagement 22 bar

With interarder

With braking power below 41% of maximum power:

Coolant temperature for:

- ☐ 2nd speed engagement 93°C
- ☐ disengagement 88°C

With braking power over 41% of maximum power:

Coolant temperature for:

- ☐ 2nd speed engagement 85°C
- ☐ disengagement 80°C


Using a feeler gauge, check the gap between the anchor assembly (2) and the pulley (1), it must be no greater than 2.5 mm.

As to the description of the electro-magnetic joint operation and servicing, see the "Manual for electric/electronic system repairing" St. 603.93.191.

5424 TURBOCHARGING

The turbocharging system consists of:

- ☐ air filter;
- ☐ variable geometry turbocharger;
- ☐ "intercooler" radiator.

Figure 206

44916

TURBOCHARGING DIAGRAM**TURBOCHARGER****Operating principle**

The variable geometry turbocharger (VGT) consists of a centrifugal compressor and a turbine, equipped with a mobile device which adjusts the speed by changing the area of the passing section of exhaust gases to the turbine.

Thanks to this solution, gas velocity and turbine speed can be high even when the engine is idling.

If the gas is made to go through a narrow passage, in fact, it flows faster, so that the turbine rotates more quickly.

The movement of the device, choking the exhaust gas flowing section, is carried out by a mechanism, activated by a pneumatic actuator.


This actuator is directly controlled by the electronic control unit by a proportional solenoid valve.

The device is in maximum closing condition at idle speed.

At high engine operating speed, the electronic control system is activated and increases the passing section, in order to allow the in-coming gases to flow without increasing their speed.


A toroidal chamber is obtained during the casting process in the central body for the passage of the coolant.

Figure 207




CONTROL AIR SYSTEM DIAGRAM

- | | |
|----------------------------|-------------------------------|
| 1) Service tank | 4) VGT control solenoid valve |
| 2) Shut-off solenoid valve | 5) Actuator pressure sensor |
| 3) Air filter | 6) Turbine actuator |


TURBO COMPRESSOR HOLSET HX 40V**Figure 208**

71759

1. Air delivery to the intake manifold - 2. Compressor - 3. Air inlet - 4. Actuator -
5. Exhaust gas speed governor - 6. Exhaust gas inlet - 7. Exhaust gas outlet - 8. Turbine

CROSS-SECTION OF MINIMUM
FLOW

71733




CROSS-SECTION OF MAXIMUM FLOW

71734

CROSS-SECTION OF TURBOCHARGER


1. Air delivery to the intake manifold - 2. Compressor - 3. Air inlet - 4. Actuator - 5. Exhaust gas flow-rate adjustment ring -
6. Exhaust gas inlet - 7. Exhaust gas outlet - 8. Turbine - 9. Exhaust gas flow-rate control fork

Figure 209



60753


Figure 210



60754


1. Slide guide - 2. Compressor - 3. Slide rods - 4. Compressor fan - 5. Lubrication bushings -
 6. Exhaust gas flow-rate adjustment ring - 7. Exhaust gas fan - 8. Gas exhaust body -
 9. Locking rings - 10. Oil delivery - 11. Oil outlet - 12. Actuator drive shaft

Figure 211



71762

Figure 212




71763


1. Slide guide - 3. Slide rod - 11. Oil outlet - 12. Actuator drive shaft -
13. Actuator - 14. Exhaust gas flow-rate control fork

Actuator

Figure 213



- a Gradient characterized by the effect of the external spring (4).
- b Gradient characterized by the effect of the external (4) and internal (6) springs.



71834

1. Air inlet - 2. Gasket - 3. Piston - 4. External spring - 5. Internal spring control disc - 6. Internal spring - 7. O-ring - 8. Spring holder - 9. Limit stop - 10. Dust seal - 11. Control rod

Working principle

The actuator piston, connected to the drive rod, is controlled with the compressed air introduced through the air inlet (1) on the top of the actuator.

Modulating the air pressure varies the movement of the piston and turbine control rod. As the piston moves, it progressively compresses the external spring (4) until the base of the piston reaches the disc (5) controlling the internal spring (6).

On further increasing the pressure, the piston, via the disc (5), interferes with the bottom limit stop (10).

Using two springs makes it possible to vary the ratio between the piston stroke and the pressure. Approximately 85% of the stroke of the rod is opposed by the external spring and 15% by the internal one.

Solenoid valve for VGT control

This N.C. proportional solenoid valve is located on the left-hand side of the crankcase under the turbine.

The electronic control unit, via a PWM signal, controls the solenoid valve, governing the supply pressure of the turbine actuator, which, on changing its position, modifies the cross-section of the flow of exhaust gases onto the blades of the impeller and therefore its speed.


The VGT solenoid valve is connected to the electronic control unit between pins A18/A31.

The resistance of the coil is approx. 20-30 Ohms.

FUEL FEED

Fuel feed is obtained by means of a pump, fuel filter and pre-filter, 6 pump-injectors controlled by the camshaft by means of rockers and by the electronic control unit.

Figure 214




52877

1. Valve for return circuit, starts opening 0.2 bar - 2. Valve for return circuit, starts opening 3.5 bar

Fuel pump


Figure 215



73547

- A. Fuel inlet – B. Fuel delivery – C. By-pass nut –
D. Fuel return from the pump-injectors –
E. Pressure relief valve – Opening pressure: 5-8 bars

Figure 216




73548

CROSS-SECTION OF THE FUEL PUMP
I. Oil and fuel leakage indicator

Injector-pump

Figure 217



44908

1. Fuel/oil seal – 2. Fuel/diesel seal – 3. Fuel/exhaust gas seal

The injector-pump is composed of: pumping element, nozzle, solenoid valve.

Pumping element

The pumping element is operated by a rocker arm governed directly by the cam of the camshaft.

The pumping element is able to ensure a high delivery pressure. The return stroke is made by means of a return spring.

Nozzle

Garages are authorized to perform fault diagnosis solely on the entire injection system and may not work inside the injector-pump, which must only be replaced.

A specific fault-diagnosis program, included in the control unit, is able to check the operation of each injector (it deactivates one at a time and checks the delivery of the other five). Fault diagnosis makes it possible to distinguish errors of an electrical origin from ones of a mechanical/hydraulic origin. It indicates broken pump-injectors.

It is therefore necessary to interpret all the control unit error messages correctly.

Any defects in the injectors are to be resolved by replacing them.

Solenoid valve

The solenoid, which is energized at each active phase of the cycle, via a signal from the control unit, controls a slide valve that shuts off the pumping element delivery pipe.

When the solenoid is not energized, the valve is open, the fuel is pumped but it flows back into the return pipe with the normal transfer pressure of approximately 5 bars.

When the solenoid is energized, the valve shuts and the fuel, not being able to flow back into the return pipe, is pumped into the nozzle at high pressure, causing the needle to lift.

The amount of fuel injected depends on the length of time the slide valve is closed and therefore on the time for which the solenoid is energized.

The solenoid valve is joined to the injector body and cannot be removed.

On the top there are two screws securing the electrical wiring from the control unit.

To ensure signal transmission, tighten the screws with a torque wrench to a torque of 1.36 – 1.92 Nm (0.136 – 0.192 kgm).


775010 Replacing injectors-pump

Injectors have to be replaced with great care (for their removal see the description on pages 44 and 45, for fitting them see the description on pages 85 and 86).



If this job is done with the engine on the vehicle, before removing the injectors-pump drain off the fuel contained in the pipes in the cylinder head by unscrewing the delivery and return fittings on the cylinder head.

Figure 218




For each injector replaced, hook up to the MODUS station and, when asked by the program, enter the code punched on the injector (→) to reprogram the control unit.



When checking the clearance of the rocker arms, it is important to check the injector-pump pre-load.

Injector Phases

Figure 219



60669

1. Fuel valve - 2. Pumping element - 3. Fuel outlet -
4. Filling and backflow passage

Filling phase


During the filling phase the pumping element (2) runs up to the top position.

After passing the highest point of the cam, the rocker arm roller comes near the base ring of the cam.

The fuel valve (1) is open and fuel can flow into the injector via the bottom passage (4) of the cylinder head.

Filling continues until the pumping element reaches its top limit.

Figure 220



1. Fuel valve - 2. Pumping element - 3. Fuel outlet -
4. Filling and backflow passage


Injection phase

The injection phase begins when, at a certain point in the down phase of the pumping element, the solenoid valve gets energized and the fuel valve (1) shuts.

The moment delivery begins, appropriately calculated by the electronic control unit, depends on the working conditions of the engine.

The cam continues with the rocker arm to push the pumping element (2) and the injection phase continues as long as the fuel valve (1) stays shut.

Figure 221



1. Fuel valve - 2. Pumping element - 3. Fuel outlet -
4. Filling and backflow passage

Pressure Reduction phase

Injection ceases when the fuel valve (1) opens, at a certain point in the down stroke of the pumping element, after the solenoid valve gets de-energized.

The fuel flows back through the open valve (1), the injector holes and the passage (4) into the cylinder head.


The time for which the solenoid valve stays energized, appropriately calculated by the electronic control unit, is the duration of injection (delivery) and it depends on the working conditions of the engine.

F3A Engine

	Page
VIEWS OF THE ENGINE	115
TECHNICAL DESIGNATION	119
CHARACTERISTIC CURVES	120
GENERAL CHARACTERISTICS	122
ASSEMBLY CLEARANCE DATA	125
TIGHTENING TORQUE	131
TOOLS	137
DISMANTLING THE ENGINE ON THE BENCH	149
REPAIR OPERATIONS	156
CYLINDER BLOCK	156
☐ Checks and measurements	156
CYLINDER LINERS	157
☐ Replacing cylinder liners	158
CRANKSHAFT	159
☐ Measuring the main journals and crankpins . . .	160
☐ Preliminary measurement of main and big end bearing shell selection data	161
☐ Selecting the main and big end bearing shells . .	162
☐ Replacing the timing gear and oil pump	168
☐ Checking main journal assembly clearance	168
☐ Checking crankshaft end float	169
PISTON CONNECTING ROD ASSEMBLY	170
☐ Piston rings	172
CONNECTING RODS	173
☐ Bushings	174
☐ Checking connecting rods	174
☐ Mounting the connecting rod – piston assembly	175

	Page
☐ Mounting the piston rings	175
☐ Fitting the big end bearing shells	175
☐ Fitting connecting rod - piston assemblies in the cylinder liners	176
☐ Checking piston protrusion	176
☐ Checking crankpin assembly clearance	177
CYLINDER HEAD	177
☐ Removing valves	177
☐ Checking the planarity of the head on the cylinder block	177
☐ Valves	177
☐ Removing deposits and checking the valves ...	177
☐ Valve seats	178
☐ Checking clearance between valve-stem and associated valve guide	179
☐ Valve guides	179
☐ Replacing injector cases	179
☐ Checking injector protrusion	181
TIMING SYSTEM	182
☐ Bushings	183
☐ Camshaft	183
☐ Valve springs	185
☐ Fitting valves and oil seal	186
ROCKER SHAFT	186
☐ Rocker arms	187
☐ Shaft	187
ENGINE ASSEMBLY ON BENCH	188
☐ Fitting connecting rod - piston assemblies in cylinder liners	191
ENGINE FLYWHEEL	194


	Page
☐ Fitting engine flywheel	194
☐ Fitting camshaft	195
☐ Fitting pump-injectors	196
☐ Fitting rocker-arm shaft assembly	196
☐ Camshaft timing	197
☐ Phonic wheel timing	199
☐ Intake and exhaust rocker play adjustment and pre-loading of rockers controlling pump injectors	200
☐ Completing Engine Assembly	201
LUBRICATION	203
☐ Oil pump	205
☐ Overpressure valve	205
☐ Oil pressure control valve	206
☐ Heat exchanger	206
☐ By-pass valve	207
☐ Thermostatic valve	207
☐ Engine oil filters	207
COOLING	209
☐ Description	209
☐ Operation	209
☐ Water pump	211
☐ Thermostat	211
☐ Electromagnetic coupling	211
TURBOCHARGING	212
☐ Turbocharger HOLSET HY55V	212
☐ Actuator	216
☐ Solenoid valve for VGT control	216
FEEDING	218
☐ Fuel pump	219
☐ Injector-pump	219
☐ Replacing injectors-pump	219
☐ Injector Phases	220

VIEWS OF THE ENGINE**Figure 1**

73835

F3A ENGINE


Figure 2



73526

RIGHT-HAND SIDE VIEW OF THE ENGINE


Figure 3



73527

REAR VIEW OF THE ENGINE


Figure 4



73528

RIGHT-HAND SIDE VIEW OF THE ENGINE


Figure 5



73529

LEFT-HAND SIDE VIEW OF THE ENGINE

Figure 6




73834

VIEW OF THE ENGINE FROM ABOVE


TECHNICAL DESIGNATION

ENGINE



CHARACTERISTIC CURVES

Figure 7



73531

CHARACTERISTIC CURVES OF ENGINE F3AE 0681B

Max OUTPUT 294 kW

400 HP

at 2100 rpm


Max TORQUE 1900 Nm

194 kgm

at 1050 ÷ 1480 rpm

17

Figure 8
















73532



CHARACTERISTIC CURVES OF ENGINE F3A0681D

Max OUTPUT 316 kW**430 HP****at 2100 rpm****Max TORQUE 1900 Nm****194 kgm****at 1050 ÷ 1590 rpm**

GENERAL CHARACTERISTICS








	Type		F3AE0681B	F3AE0681D
	Cycle		4-stroke Diesel engine	
	Fuel feed		Turbocharged with aftercooler	
	Injection		Direct	
	No. of cylinders		6 in line	
	Bore	mm	125	
	Stroke	mm	140	
	Total displacement	cm ³	10300	
	Compression ratio		17 ± 0.8	
	Max output	KW (HP)	294 (400)	316 (430)
		rpm	2100	2100
	Max. torque	Nm (kgm)	1900 (194)	1900 (194)
		rpm	1050 ÷ 1480	1050 ÷ 1590
	Engine idling speed, no load	rpm	550 ±25	
	Maximum engine speed, no load	rpm	2550 ±20	








	Type	F3A	
 	VALVE TIMING opens before T.D.C. A closes after B.D.C. B		16° 32°
 	opens before B.D.C. D closes after T.D.C. C		50° 9°
	For timing check		
 	X { mm mm		-
Running			-
 	X { mm mm		0.35 to 0.45
			0.45 to 0.55
	FEED	Through fuel pump - filters	
	Injection type: Bosch	With electronically regulated injectors PDE 3I pump injectors controlled by overhead camshaft	
	Nozzle type	—	
	Injection order	1 - 4 - 2 - 6 - 3 - 5	
	Injection pressure	bar	1500
	Injector calibration	bar	290

	Type	F3A	
	SUPERCHARGING		
	Turbocharger type	Variable geometry Holset HY 55 V	
	LUBRICATION	Forced by gear pump, pressure control valve, oil filter	
	Oil pressure with hot engine (100°C ±5°C):		
	at idling speed	bar	1.5
	at maximum rpm	bar	5
	COOLING	By centrifugal pump, regulating thermostat, viscostatic fan, radiator and heat exchanger	
	Water pump control	By belt	
	Thermostat	N. 1	
	initial opening	~84°C ±2°C	
	maximum opening	94°C ±2°C	
	OIL FILLING		
	Total capacity at 1 st filling		
		litres	30
		kg	29.8
	Capacities		
	- engine sump min level	litres	17
		kg	15.3
	- engine sump max level	litres	25
		kg	22.5
	- quantity in circulation that does not flow back to the engine sump		
		litres	7
		kg	6.3
	- quantity contained in the cartridge filter (which has to be added to the cartridge filter refill)		
		litres	2.5
		kg	2.3









Fiat Lubrificanti
Urania Turbo LD
 (according to
 E3-96 standard)
Urania Turbo
 (according to
 E2-96 standard)

ASSEMBLY CLEARANCE DATA







	Type	F3A	
CYLINDER BLOCK AND CRANKMECHANISM COMPONENTS		mm	
	Bores for cylinder liners: upper Ø1 lower	142.000 to 142.025 140.000 to 140.025	
	Cylinder liners: external diameter: upper Ø2 lower length L	141.961 to 141.986 139.890 to 139.915 -	
	Cylinder liners - crankcase bores upper lower	0.014 to 0.064 0.085 to 0.135	
  	External diameter Ø2	-	
	Cylinder sleeve inside diameter Ø3A* inside diameter Ø3B* Protrusion X * Selection class	125.000 to 125.013 125.011 to 125.024 0.045 to 0.075	
	Pistons: measuring dimension X external diameter Ø1A● external diameter Ø1B○ pin bore Ø2	NUERAL 18 124.884 to 124.896 124.895 to 124.907	MAHLE - MONDIAL 18 124.881 to 124.893 124.892 to 124.904 50.010 to 50.018
	Piston - cylinder sleeve A* B* * Selection class	0.104 to 0.129 0.093 to 0.118	0.107 to 0.132 0.096 to 0.131
  	Piston diameter Ø1	-	
	Pistons protrusion X	0.23 to 0.53	
	Gudgeon pin Ø3	49.994 to 50.000	
	Gudgeon pin - pin housing	0.010 to 0.024	
● Class A pistons supplied as spares. ○ Class B pistons are fitted in production only and are not supplied as spares.			










	Type	F3A	
		mm	
	X1*	KS 2.94	MAHLE - PISTON 2.995 to 2.985
	X2		3.05 to 3.07
	X3		4.02 to 4.04
	* measured on Ø of 120 mm		
	Piston rings: trapezoidal seal	S1*	2.796 to 2.830
	lune seal	S2	2.970 to 3.000
	milled scraper ring with slits and internal spring	S3	3.970 to 3.990
	* measured on Ø of 120 mm		
	Piston rings - grooves	1	0.110 to 0.144
		2	0.050 to 0.100
		3	0.030 to 0.070
	 > Piston rings	-	
	Piston ring end gap in cylinder liners	X1	0.35 to 0.50
	dos cilindros	X2	0.60 to 0.75
		X3	0.35 to 0.65
	Small end bush housing	Ø1	54.000 to 54.030
	Big end bearing housing	Ø2	87.000 to 87.030
	- Class	1	87.000 to 87.010
	- Class	2	87.011 to 87.020
	- Class	3	87.021 to 87.030
	Small end bush diameter outside	Ø4	54.085 to 54.110
	inside	Ø3	50.019 to 50.035
	Big end bearing shell	S	
	Red		1.970 to 1.980
	Green		1.981 to 1.990
	Small end bush - housing		0.055 to 0.110
	Piston pin - bush		0.019 to 0.041
	 > Big end bearing	0.127 - 0.254 - 0.508	
	Connecting rod weight	A	g. 3973 to 4003
	Class	B	g. 4004 to 4034
		C	g. 4035 to 4065










● Fitted in production only and not supplied as spares

	Type	F3A	
		mm	
	Measuring dimension X	125	
	Max. connecting rod axis misalignment tolerance =	0.08	
	Main journals	Ø1	
	- nominal		92.970 to 93.000
	- class 1		92.970 to 92.979
	- class 2		92.980 to 92.989
	- class 3		92.990 to 93.000
	Crankpins	Ø2	
	- nominal		82.970 to 83.000
	- class 1		82.970 to 82.979
	- class 2		82.980 to 82.989
	- class 3		82.990 to 83.000
	Main bearing shells	S1	
	Red		2.965 to 2.974
	Green		2.975 to 2.984
	Yellow*		2.985 to 2.995
	Big end bearing shells	S2	
	Red		1.970 to 1.980
	Green		1.981 to 1.990
	Yellow*		1.991 to 2.000
	Main bearing housings	Ø3	
	- nominal		99.000 to 99.030
	- class 1		99.000 to 99.009
	- class 2		99.010 to 99.019
	- class 3		99.020 to 99.030
	Bearing shells - main journals		0.050 to 0.090
	Bearing shells - big ends		0.040 to 0.080
	Main bearing shells		0.127 - 2.254 - 0.508
	Big end bearing shells		0.127 - 2.254 - 0.508
	Main journal, thrust bearing	X1	45.95 to 46.00
	Main bearing housing, thrust bearing	X2	38.94 to 38.99
	Thrust washer halves	X3	3.38 to 3.43
	Crankshaft end float		0.10 to 0.30
	Alignment	≤ 1 - 2	≤ 0.025
	Ovalization	○ 1 - 2	0.010
	Taper	> 1 - 2	0.010

* Fitted in production only and not supplied as spares

	Type F3A
CYLINDER HEAD - VALVE TRAIN	
	mm 14.980 to 14.997
	Valve guide  Ø2  Ø3 9.015 to 9.030 15.012 to 15.025
	Valve guides - housings in the cylinder heads 0.015 to 0.045
 	Valve guide 0.2 - 0.4
	Valves:  Ø4 α 8.960 to 8.975 60° 30' ± 7' 30"  Ø4 α 8.960 to 8.975 45° 30' ± 7' 30"
	Valve stem and its guide 0.040 to 0.070
	Valve seat in head  Ø1 44.185 to 44.220  Ø1 42.985 to 43.020
	Outside diameter of valve seat; angle of valve seat in cylinder head:  Ø2 α 44.260 to 44.275 60° - 30'  Ø2 α 43.060 to 43.075 45° - 30'
	Recessing of valve  X  X 0.65 to 0.95 1.8 to 2.1
	Between valve seat and head  X  X 0.040 to 0.090

	Type	F3A	
		mm	
	Valve spring height:		
	free height H		75
	under a load of: N 500 ±25 H1		61
	N 972 ±48 H2		47.8
	Injector protrusion X		0.32 to 1.14
	Camshaft bushing housing in the cylinder head: 1 ⇒ 7 Ø		88.000 to 88.030
	Camshaft bearing journals: 1 ⇒ 7 Ø		82.950 to 82.968
	Outer diameter of camshaft bushings: Ø		88.153 to 88.183
	Inner diameter of camshaft bushings: Ø		83.018 to 83.085
	Bushings and housings in the cylinder head		0.123 to 0.183
	Bushings and bearing journals		0.050 to 0.135
	Cam lift:		
			9.30
			9.45
	Rocker shaft Ø1		
			41.984 to 42.000

	Type	F3A	
		mm	
	Bushing housing in rocker arms   	45.000 to 45.016	
		59.000 to 59.019	
		46.000 to 46.016	
	Bushing outer diameter for rocker arms   	45.090 to 45.130	
		59.100 to 59.140	
		46.066 to 46.091	
	Bushing inner diameter for rocker arms   	42.025 to 42.041	
		56.030 to 56.049	
		42.015 to 42.071	
	Between bushings and housings   	0.074 to 0.130	
		0.081 to 0.140	
		0.050 to 0.091	
	Between bushings of rocker arms and shaft   	0.025 to 0.057	
		0.025 to 0.057	
		0.015 to 0.087	
TURBOCHARGER Type End float Radial play		HOLSET HY 55 V, variable geometry - -	

TIGHTENING TORQUE

PART	TORQUE	
	Nm	kgm
Capscrews, undercrankcase to crankcase (see Figure 9) ♦		
M12x1.75 outer screws Stage 1: pretightening	30	3
M 17x2 inner screws Stage 2: pretightening	120	12
Inner screws Stage 3: angle		90°
Inner screws Stage 4: angle		45°
Outer screws Stage 5: angle		60°
Piston cooling nozzle union ♦	35 ± 2	3.5 ± 2
Capscrews, heat exchanger to crankcase ♦ (see Figure 13)		
pretightening	11.5	1.15
tightening	19	1.9
Spacer and oil sump capscrews ♦ (see Figure 14)		
pretightening	38	3.8
tightening	45	4.5
M 12x1.75 screws, gear case to crankcase ♦	63 ± 2	6.3 ± 0.7
Cylinder head capscrews (see Figure 10) ♦		
Stage 1: pretightening	60	6
Stage 2 pretightening	120	12
Stage 3: angle		120°
Stage 4: angle		60°
Air compressor capscrews	100	10
Rocker shaft capscrew ♦		
Stage 1: pretightening	100	10
Stage 2: angle		60°
Locknut, rocker adjusting screw ♦	39 ± 5	3.9 ± 0.5
Capscrews, injector securing brackets ♦	26	2.6
Capscrews, thrust plates to head ♦	19	1.9
Screw fastening the engine supporting bracket to the cylinder head		
Stage 1: pretightening	120	12
Stage 2: angle		45°
Screw fastening the engine supporting bracket to the flywheel case		
Stage 1: pretightening	100	10
Stage 2: angle		60°
Camshaft gear capscrews ♦		
Stage 1: pretightening	60	6
Stage 2: angle		60°
Screw fixing phonic wheel to timing system gear ♦	8.5 ± 1.5	0.8 ± 0.1
Exhaust manifold capscrews • (see Figure 11)		
pretightening	40 ± 5	4 ± 0.5
tightening	70 ± 5	7 ± 0.5
Capscrews, exhaust brake actuator cylinder ♦	19	1.9
Capscrews, connecting rod caps ♦		
Stage 1: pretightening	60	6
Stage 2: angle		60°
Engine flywheel capscrews ♦		
Stage 1: pretightening	120	12
Stage 2: angle		60°
Stage 3: angle		30°

♦ Before assembly, lubricate with engine oil

● Before assembly, lubricate with graphitized oil

PART		TORQUE		
		Nm	kgm	
Screws fixing damper flywheel: ♦				
First phase	pre-tightening	70	7	
Second phase	closing to angle		50°	
Screws fixing intermediate gear pins: ♦				
First phase	pre-tightening	30	3	
Second phase	closing to angle		90°	
Screw fixing connecting rod for idle gear		25 ± 2.5	2.5 ± 0.2	
Screws fixing oil pump		25 ± 2.5	2.5 ± 0.2	
Screw fixing suction strainer and oil pump pipe to crankcase		25 ± 2.5	2.5 ± 0.2	
Screws fixing crankshaft gasket cover		25 ± 2.5	2.5 ± 0.2	
Screws fixing fuel pump/filter		37 ± 3	3.7 ± 0.3	
Screw fixing control unit mount to crankcase		19 ± 3	1.9 ± 0.3	
Screw fixing fuel pump to flywheel cover box		19 ± 3	1.9 ± 0.3	
Screw fixing thermostat box to cylinder head		19 ± 3	1.9 ± 0.3	
Screw fixing rocker cover (see Figure 15)		8.5 ± 1.5	0.8 ± 0.1	
Screws and nuts fixing turbocharger • (see Figure 12)				
	pre-tightening	33.5 ± 7.5	3.3 ± 0.7	
	tightening	46 ± 2	4.6 ± 0.2	
Screws fixing water pump to crankcase		25 ± 2.5	2.5 ± 0.2	
Screws fixing spacer/pulley to fan		30 ± 3	3 ± 0.3	
Screw fixing automatic tensioner to crankcase		50 ± 5	5 ± 0.5	
Screw fixing fixed tensioner to crankcase		105 ± 5	10.5 ± 0.5	
Screws fixing fan mount to crankcase		100 ± 5	10 ± 0.5	
Screws fixing starter motor		74 ± 8	7.4 ± 0.8	
Screws fixing air heater to cylinder head		37 ± 3	3.7 ± 0.3	
Screw fixing air compressor		74 ± 8	7.4 ± 0.8	
Nut fixing gear driving air compressor		170 ± 10	17 ± 10	
Screw fixing automatic tensioner for belt driving air-conditioning compressor to crankcase		26 ± 2	2.6 ± 0.2	
Screw fixing alternator bracket to crankcase		L = 35 mm L = 60 mm L = 30 mm	30 ± 3 44 ± 4 24.5 ± 2.5	3 ± 0.3 4.4 ± 0.4 2.4 ± 0.2
Screws fixing hydraulic power steering pump		46.5 ± 4.5	4.65 ± 0.45	
Screws fixing air-conditioner compressor to mount		24.5 ± 2.5	2.5 ± 0.25	
Screws fixing guard		24.5 ± 2.5	2.5 ± 0.25	
Filter clogging sensor fastening		55 ± 5	5.5 ± 0.5	


- ♦ Before assembly, lubricate with engine oil
- Before assembly, lubricate with graphitized oil

PART	TORQUE	
	Nm	kgm
Pressure transmitter fastener	8 ± 2	0.8 ± 0.2
Water/fuel temperature sensor fastener	32.5 ± 2.5	3.2 ± 0.2
Thermometric switch/transmitter fastener	23 ± 2.5	2.5 ± 0.2
Air temperature transmitter fastener	32.5 ± 2.5	3.2 ± 0.2
Pulse transmitter fastener	8 ± 2	0.8 ± 0.2
Injector-pump connections fastener	1.36 ± 1.92	0.13 ± 0.19
Screw fixing electric cables	8 ± 2	0.8 ± 0.2
Screw fixing electric cables	8 ± 2	0.8 ± 0.2
Exhaust brake solenoid valve fastener	32	3.2
PWM solenoid valve fastener	9 ± 1	0.9 ± 0.1

- ◆ Before assembly, lubricate with engine oil
- Before assembly, lubricate with graphitized oil


DIAGRAMS OF TIGHTENING SEQUENCE FOR MAIN PARTS OF ENGINE**Figure 9**

FRONT SIDE




stage 1:
pretightening,
outer screws
(30 Nm)

FRONT SIDE




stage 2:
pretightening, inner
screws
(120 Nm)

FRONT SIDE




stage 3:
angle, inner
screws
90°

FRONT SIDE



stage 4:
angle, inner
screws
45°


FRONT SIDE



60°
stage 5:
angle, outer
screws

DIAGRAMS OF TIGHTENING SEQUENCE FOR SCREWS FIXING CRANKCASE BASE


Figure 10



60580

DIAGRAM OF CYLINDER HEAD FIXING SCREWS TIGHTENING SEQUENCE


Figure 11



60581

DIAGRAM OF EXHAUST MANIFOLD FIXING SCREWS TIGHTENING SEQUENCE

Figure 12



60582

DIAGRAM OF TURBOCHARGER FIXING SCREWS AND NUTS TIGHTENING SEQUENCE

SEQUENCE: Pretightening 4 - 3 - 1 - 2
Tightening 1 - 4 - 2 - 3

Figure 13




DIAGRAM OF TIGHTENING SEQUENCE FOR HEAT EXCHANGER SCREWS

Figure 14




DIAGRAM OF TIGHTENING SEQUENCE FOR ENGINE OIL SUMP SCREWS



Stage 1 from 1 to 16.

Stage 2 from 17 to 32

Figure 15
















DIAGRAM OF TIGHTENING SEQUENCE FOR SCREWS FIXING ROCKER COVER







TOOLS

TOOL NO.	DESCRIPTION
99305019	Full-optional tool-kit to rectify valve seat 
99305047	Spring load tester 
99322230	Rotary telescopic stand (range 2000 daN, torque 375 daNm) 
99340053	Extractor for crankshaft front gasket 
99340054	Extractor for crankshaft rear gasket 
99340205	Percussion extractor 







TOOLS

TOOL NO.	DESCRIPTION	
99342149		Extractor for injector-holder
99346250		Tool to install the crankshaft front gasket
99346251		Tool to install the crankshaft rear gasket
99348004		Universal extractor for 5 to 70 mm internal components
99350072		Box wrench for block junction bolts to the underblock
99360144		Tools (12 + 6) holding rocker adjustment screw blocks when removing/refitting the rocker shaft






TOOLS

TOOL NO.	DESCRIPTION
99360180	 Injector housing protecting plugs (6)
99360184	 Pliers for assembling and disassembling piston split rings (105-106 mm)
99360261	 Tool to take down-fit engine valves (to be used with special plates)
99360262	 Plate for take down-fit engine valves (to be used with 99360261)
99360295	 Tool to fit back valve guide (to be used with 99360481)
99360314	 Tool to remove oil filter (engine)







TOOLS

TOOL NO.	DESCRIPTION	
99360321		Tool to rotate engine flywheel (to be used with 99360325)
99360325		Spacer (to be used with 99360321)
99360328		Tool to install gasket on valve guide
99360334		Compression tool for checking the protrusion of cylinder liners (to be used with 99370415-99395603 and special plates)
99360336		Spacer (to be used with 99360334)
99360337		Cylinder liner compression plate (to be used with 99360334-99360336)







TOOLS

TOOL NO.	DESCRIPTION	
99360351		Tool to stop engine flywheel
99360481		Tool to remove valve guide
99360499		Tool to take down and fit back camshaft bushes
99360500		Tool to lift crankshaft
99360551		Bracket to take down and fit engine flywheel
99360553		Tool for assembling and installing rocker arm shaft







TOOLS

TOOL NO.	DESCRIPTION	
99360585		Swing hoist for engine disassembly assembly
99360605		Belt to insert piston in cylinder liner (60 - 125 mm)
99360612		Tool for positioning engine P.M.S.
99360613		Tool for timing of phonic wheel on timing gear
99360703		Tool to stop cylinder liners
99360706		Tool to extract cylinder liners (to be used with specific rings)







TOOLS

TOOL NO.	DESCRIPTION
99360726	 Ring (125 mm) (to be used with 99360706)
99361036	 Brackets fixing the engine to rotary stand 99322230
99365056	 Tool for injector holder heading
99370415	 Base supporting the dial gauge for checking cylinder liner protrusion (to be used with 99395603)
99378100	 Tool for printing engine identification plates (to be used with special punches)
99378102	 Punches (B) for printing engine identification plates (to be used with 99378100)

TOOLS

TOOL NO.	DESCRIPTION	
99378104		Punches (D) for printing engine identification plates (to be used with 99378100)
99389834		Torque screwdriver for calibrating the injector solenoid valve connector check nut
99390311		Valve guide sleeker
99390772		Tool for removing injector holding case deposits
99390804		Tool for threading injector holding cases to be extracted (to be used with 99390805)
99390805		Guide bush (to be used with 99390804)

TOOLS

TOOL NO.	DESCRIPTION	
99394015		Guide bush (to be used with 99394041 or 99394043)
99394041		Cutter to rectify injector holder housing (to be used with 99394015)
99394043		Reamer to rectify injector holder lower side (to be used with 99394015)
99395216		Measuring pair for angular tightening with 1/2" and 3/4" square couplings
99395218		Gauge for defining the distance between the centres of camshaft and transmission gear
99395363		Complete square to check connecting rod squaring

TOOLS





TOOL NO.	DESCRIPTION
99395603	 Dial gauge (0 - 5 mm)
99395687	 Reaming gauge (50 - 178 mm)
99396035	 Centering ring of crankshaft front gasket cap


Figure 16



73581

ENGINE - LONGITUDINAL SECTION

Figure 17




60584

ENGINE - CROSS SECTION

540110 DISMANTLING THE ENGINE ON THE BENCH

Before fixing the engine on the rotary stand 99322230 remove the following components:


Figure 18



On the engine right-hand side


- diesel cartridge filter (1);
- power steering system tank (2);
- electric connections;

Figure 19




- soundproofing shield (1);
- all the pipes connecting the compressor;

Figure 20




- compressor (1) fitted with power steering pump (2);

Figure 21



- remove the air conditioner control belt (1) using a fit tool (3) and acting in the direction shown by the arrow;
- disassemble the air conditioner (2) fitted with the engine support.


Figure 22



On the engine left-hand side


- engine support (1);

Figure 23



- oil pressure controlling valve (1).


Figure 24



73582

Secure the engine to the rotary stand 99322030 with the brackets 99361036 (1).

Figure 25




73579

Using an appropriate tool (2), operate in the direction of the arrow, and remove the belt (1) driving the water pump, alternator and fan.

Take out the screws and remove the electromagnetic coupling (3).

Figure 26




60489

Remove the following components:

- thermostat unit (6) fitted with turbine actuator pressure sensor (7);
- alternator (2);
- pulley support (1);
- water pump (8) and piping;
- automatic belt tightener support (3);
- fixed belt tightener (9);
- damping flywheel (4) and pulley underneath it;
- automatic belt tightener (5);
- disconnect all the electric connections and the sensors.


Figure 27



60490

Fit the extractor 99340053 (2) and remove the engine crankshaft seal gasket (1), remove the cover (3).


Figure 28



60491

Remove the following components: water outlet line (2); oil delivery line (4); actuator air line (3); water delivery line (6); oil return line (7); turbocharger (5); exhaust manifold (1).


Figure 29



60492


Unscrew the oil filters (1) using the tool 99360314.

Figure 30




- Unscrew the screws (1) and remove the heat exchanger (4);
- unscrew the screws (2) and remove the water line (3).

Figure 31



Remove the following components: fuel filter support (1); fuel pump (2) and lines; starter (3); engine starting button support (4); PWN valve air filter (5); suction manifold (6) fitted with resistance for engine pre-heating; control unit (7).


Figure 32



To remove the P.T.O. (if applicable):


- ☐ Disconnect the oil pipe (1).
- ☐ Unscrew the 4 screws (2) and (3).

Figure 33




Remove the rocker arm cover (1), take off the screws (2) and remove: the cover (3), the filter (5) and the gaskets (4 and 6). Take off the screws (8) and remove the blow-by case (7).

Figure 34




- Unscrew the screws (2) and remove the gear (1) fitted with phonic wheel.

Figure 35




- Unscrew the screws (1); tighten one screw in a reaction hole and remove the shoulder plate (2), remove the sheet gasket.

Figure 36




Unscrew the screws (2) and remove the transmission gear (1).

Figure 37




Stop the engine flywheel (3) rotation by means of tool 99360351 (1), unscrew the fixing screws (2) and remove the engine flywheel.

Figure 38




Apply the extractor 99340054 (2) and pull out the seal gasket (1).

Figure 39



Unscrew the screws (1) and take down the gearbox (2).


Figure 40



In sequence, take out the:


- ☐ if the P.T.O. control gear (1) is present;
- ☐ idle gear (2);
- ☐ oil pump gear (3).

Figure 41



- ☐ Release the check springs (3) of the exhaust brake lever.
- ☐ Unscrew the screws and cut-out solenoid valve electric connections (1).
- ☐ Remove exhaust brake pins (4) and slave cylinder (6) pipes (5).
- ☐ Unscrew the screws (2) fixing the rocker arm shaft.

Figure 42




73533

Using tool 99360144 (3), constrain the blocks (4) to the rockers (2).

Apply tool 99360553 (1) to the rocker holder shaft (5) and remove the shaft (5) from the cylinder head.


Figure 43



60513

- ☐ Unscrew the screws (2) fixing the brackets (3) and remove the injectors (1).
- ☐ Unscrew the screws (4) and remove the exhaust brake pins (5).
- ☐ Unscrew the screws and remove the slave cylinder (6).


Figure 44



60514

- ☐ Fit the plugs 99360180 (1) instead of injectors.
- ☐ Remove the camshaft (2).
- ☐ Unscrew the fixing screws on the cylinder head (3).


Figure 45



60515

- ☐ By means of metal ropes, lift the cylinder head (1).
- ☐ Remove the seal (2)


Figure 46



60516

Unscrew the screws (2) and remove the engine oil sump (1) fitted with spacer (3) and seal.


Figure 47



60517


Unscrew the screws and remove suction rose (1).

Figure 48



Rotate the block (1) to the vertical position.


Figure 49



Untighten screws (2) fixing the connecting rod cap (3) and remove it. Remove the connecting rod-piston (1) assembly from the upper side. Repeat these operations for the other pistons.

 Keep the big end bearing shells in their respective housings and/or note down their assembly position since, if reusing them, they will need to be fitted in the position found upon removal.

Figure 50




By means of proper and splined wrenches, untighten the screws (1) and (2) and remove the under-block.




Note down the assembly position of the top and bottom main bearing shells since, if reusing them, they will need to be fitted in the position found upon removal.

Figure 51



Using tool 99360500 (1), remove the crankshaft (2).

Figure 52



Remove the main bearing shells (1), unscrew the screws and take out the oil nozzles (2).

Remove the cylinder liners as described under the relevant subheading on page 158.




After disassembling the engine, thoroughly clean disassembled parts and check their integrity. Instructions for main checks and measures are given in the following pages, in order to determine whether the parts can be re-used.

REPAIR OPERATIONS

540410 CYLINDER BLOCK
540420 Checks and measurements

Figure 53 (Demonstration)




34994

Internal diameter of the cylinder liners is checked for ovalization, taper and wear, using a bore dial (1) centesimal gauge 99395687 (2) previously reset to ring gauge (3), diameter 125 mm.



If a 125 mm ring gauge is not available use a micrometer caliper.

Figure 54




60596

1 = 1st measuring
 2 = 2nd measuring
 3 = 3rd measuring

Carry out measurements on each cylinder liner at three different levels and on two (A-B) surfaces, to one another perpendicular, as shown in Figure 54.

Figure 55



60595

A = Selection class $\varnothing$ 125 – 125.013 mm

B = Selection class $\varnothing$ 125.011 – 125.024 mm


X = Selection class marking area

In case of maximum wear >0.150 mm or maximum ovalization >0.100 mm compared to the values indicated in the figure, the liners must be replaced as they cannot be ground, lapped or trued.



Cylinder liners are equipped with spare parts with "A" selection class.

Figure 56



60597

A = $\varnothing$ 142.000 to 142.025 mm

B = $\varnothing$ 140.000 to 140.025 mm

C = $\varnothing$ 141.961 to 141.986 mm

D = $\varnothing$ 139.890 to 139.915 mm


The figure shows the outer diameters of the cylinder liners and the relative seat inner diameters.

The cylinder liners can be extracted and installed several times in different seats, if necessary.

Check the state of the cylinder assembly machining plugs: if they are rusty or there is any doubt at all about their seal, change them.

CYLINDER LINERS


Figure 57



BLOCK WITH CYLINDER LINERS

60598

Figure 58




Selection class

{ A mm 125.000 to 125.013
 B mm 125.011 to 125.024

CYLINDER LINERS MAIN DATA

60600

Figure 59



DETAIL "X"


"Y" - Selection class marking area

60601

540420 Replacing cylinder liners

Refitting

Figure 60




Place details 99360706 (2) and plate 99360726 (4) as shown in the figure, by making sure that the plate (4) is properly placed on the cylinder liners.

Tighten the screw nut (1) and remove the cylinder liner (3) from the block.

Fitting and checking protrusion

Figure 61




Always replace water sealing rings (3, 4 and 5). Install the adjustment ring (1) on the cylinder liner (2); lubricate lower part of liner and install it in the cylinder unit using the proper tool.



The adjustment ring (1) is supplied as spare parts in the following thicknesses: 0.08 mm - 0.10 mm - 0.12 mm.

Figure 62



Check the protrusion of the cylinder liners, using tool 99360472 (2) and tightening screw (1) to 225 Nm torque. Using a dial gauge (3), measure the cylinder liner protrusion, from the cylinder head supporting surface, it must be 0.045 to 0.075 (Figure 63); otherwise, replace the adjustment ring (1, Figure 61) supplied as spare parts having different thicknesses.

Figure 63







Figure 64



When the installation is completed, block the cylinder liners (1) to the block (2) with studs 99360703 (3).

5408 CRANKSHAFT**Figure 65**

Upper main journal half bearings




Lower main journal half bearings


60602

MAIN DATA FOR THE CRANK SHAFT PINS AND THE HALF BEARINGS

Check the condition of the journals and the big end pins; there must not be signs of scoring, ovalization or excessive wear. The data given refer to the normal diameter of the pins.

Figure 66

60603

X. Detail of main journals connections**Figure 67**

60604

Y. Detail of crank pins connections

540812 Measuring the main journals and crankpins

Before grinding the crank pins using a micrometer (1), measure the main journals and the crank pins (2) and decide, on the basis of the undersizing of the bearings, the final diameter to which the pins are to be ground. The undersize classes are 0.127 - 0.254 - 0.508 mm.

Figure 68





Figure 70



During grinding, pay attention to journal and crank pins values specified in Figure 66 and Figure 67.



It is advisable to enter the values found in a table (Figure 69).



All journals and crank pins must also be ground to the same undersizing class, in order to avoid any alteration to shaft balance.

Figure 69

Fill in this table with the measurements of the main journals and the crank pins.

MAIN JOURNALS

	1	2	3	4	5	6	7
Ø MIN.							
Ø MAX.							

	1	2	3	4	5	6
Ø MIN.						
Ø MAX.						

CRANK PINS

36061

Preliminary measurement of main and big end bearing shell selection data

For each of the journals of the crankshaft, it is necessary to carry out the following operations:

MAIN JOURNALS:

- ☐ Determine the class of diameter of the seat in the crankcase.
- ☐ Determine the class of diameter of the main journal.
- ☐ Select the class of the bearing shells to mount.

CRANKPINS:


- ☐ Determine the class of diameter of the seat in the connecting rod.
- ☐ Determine the class of diameter of the crankpin.
- ☐ Select the class of the bearing shells to mount.

DEFINING THE CLASS OF DIAMETER OF THE SEATS FOR BEARING SHELLS ON THE CRANKCASE

On the front of the crankcase, two sets of numbers are marked in the position shown (Figure 71 at top).

- ☐ The first set of digits (four) is the coupling number of the crankcase with its base.
- ☐ The following seven digits, taken singly, are the class of diameter of each of the seats referred to (Figure 71 at bottom).
- ☐ Each of these digits may be **1**, **2** or **3**.

Figure 71



Selecting the main and big end bearing shells

 To obtain the required assembly clearances, the main and big end bearing shells need to be selected as described hereunder.



This operation makes it possible to identify the most suitable bearing shells for each of the journals (the bearing shells, if necessary, can have different classes from one journal to another).

Depending on the thickness, the bearing shells are selected in classes of tolerance marked by a coloured sign (red-green – red/black – green/black).


The following tables give the specifications of the main and big end bearing shells available as spares in the standard sizes (STD) and in the permissible oversizes (+0.127, +0.254, +0.508).

Figure 72

	STD	+0.127	+0.254	+0.508
red	1.970 to 1.980		2.097 to 2.107	2.224 to 2.234
red/black		2.033 to 2.043		
green	1.981 to 1.990		2.108 to 2.117	2.235 to 2.244
green/black		2.044 to 2.053		
yellow*	1.991 to 2.000			
yellow/black*		2.054 to 2.063		



	STD	+0.127	+0.254	+0.508
red	2.965 to 2.974		2.097 to 2.107	2.224 to 2.234
red/black		3.028 to 3.037		
green	2.975 to 2.984		2.108 to 2.117	2.235 to 2.244
green/black		3.038 to 3.047		
yellow*	2.985 to 2.995			
yellow/black*		3.048 to 3.058		




* Fitted in production only and not supplied as spares

DEFINING THE CLASS OF DIAMETER OF THE MAIN JOURNALS AND CRANKPINS (Journals with nominal diameter)

Main journals and crankpins: determining the class of diameter of the journals.



Three sets of numbers are marked on the crankshaft in the position shown by the arrow (Figure 73 at top):

- ☐ The first number, of five digits, is the part number of the shaft.
- ☐ Under this number, on the left, a set of six digits refers to the crankpins and is preceded by a single digit showing the status of the journals (1 = STD, 2 = -0.127), the other six digits, taken singly, give the class of diameter of each of the crankpins they refer to (Figure 73 at top).
- ☐ The set of seven digits, on the right, refers to the main journals and is preceded by a single digit: the single digit shows the status of the journals (1 = STD, 2 = -0.127), the other seven digits, taken singly, give the class of diameter of each of the main journals they refer to (Figure 73 at bottom).

Figure 73

SELECTING THE MAIN BEARING SHELLS (Journals with nominal diameter)

After reading off the data, for each of the main journals, on the crankcase and crankshaft, you choose the type of bearing shells to use according to the following table:

Figure 74**STD.****1****2****3****1**

green

green

green

green

green

green

2

red


green

green

red

green

green

**3**

red

red

green

red

red


green

SELECTING THE MAIN BEARING SHELLS (GROUND JOURNALS)

If the journals have been ground, the procedure described so far cannot be applied.

In this case, it is necessary to check that the new diameter of the journals is as shown in the table and to mount the only type of bearing shell envisaged for the relevant undersizing.

Figure 75



SELECTING THE BIG END BEARING SHELLS (JOURNALS WITH NOMINAL DIAMETER)


There are three markings on the body of the connecting rod in the position shown in the view from "A":

- 1 Letter indicating the class of weight:
 - A = 3973 to 4003 g.
 - B = 4004 to 4034 g.
 - C = 4035 to 4065 g.
- 2 Number indicating the selection of the diameter of the big end bearing seat:
 - 1 = 87.000 to 87.010 mm
 - 2 = 87.011 to 87.020 mm
 - 3 = 87.021 to 87.030 mm
- 3 Numbers identifying the cap-connecting rod coupling.

The number, indicating the class of diameter of the bearing shell seat may be **1, 2 or 3**.

Determine the type of big end bearing to fit on each journal by following the indications in the table (Figure 77).


Figure 76



47557

Figure 77

STD.







Class	1	2	3
1	green	green	green
	green	green	green
2	red	green	green
	red	green	green
3	red	red	red
	red	red	red





SELECTING BIG END BEARING SHELLS (GROUND JOURNALS)




If the journals have been ground, the procedure described so far cannot be applied.

In this case, it is necessary to check (for each of the undersizings) which field of tolerance includes the new diameter of the crankpins and to mount the bearing shells identified with the relevant table.

Figure 78

red/black = mm 2.044 to 2.053		-0.127						
		82.843 82.852	1	green/black	2	green/black	3	green/black
			green/black	green/black	green/black	green/black		
		82.853 82.862	2	red/black		green/black	green/black	
			red/black	green/black		green/black		
		82.863 82.873	3	red/black	red/black	green/black		
			red/black	red/black	green/black			


red = mm 2.097 to 2.107 green = mm 2.108 to 2.117		-0.254						
		82.726 82.735	1	red	2	green	3	green
			red	green	green			
		82.736 82.746	2	red		green	green	
			red	red		green		
			3	red	red	green		

red = mm 2.224 to 2.234 green = mm 2.235 to 2.244		-0.508						
		82.472 82.481	1	red	2	green	3	green
			red	green	green			
		82.482 82.492	2	red		green	green	
			red	red		green		
			3	red	red	green		

540815 Replacing the timing gear and oil pump

Check that the toothing of the gear is neither damaged nor worn; if it is, take it out with an appropriate extractor and replace it.

Figure 79



73534


When fitting the gear (1) on the crankshaft (2), heat it for no longer than 2 hours in an oven at a temperature of 180°C. After heating the gear (1), fit it on the shaft by applying a load of 6000 N to it, positioning it at the distance shown in Figure 79.

After cooling, the gear must have no axial movement under a load of 29100 N.

If changing the pin (3), after fitting it on, check it protrudes from the crankshaft as shown in the figure.

540811 Checking main journal assembly clearance

Figure 80




47579

Mount the oil nozzles (2), making the grub screw match the hole (3) on the crankcase.

Arrange the bearing shells (1) on the main bearing housings.


Figure 81



47578

Using the tackle and hook 99360500 (1), mount the crankshaft (2).

Figure 82




49021

Arrange the bearing shells (1) on the main bearing housings in the crankcase base (2).


Check the assembly clearance between the main journals of the crankshaft and their bearings, proceeding as illustrated on the following pages.

Figure 83



Set two journals of the crankshaft (2) parallel to the longitudinal axis, a section of calibrated wire. Using appropriate hooks and tackle, mount the crankcase base (1).

Figure 84



□ Lubricate the internal screws (1) with UTM oil and tighten them with a torque wrench (3) to a torque of 120 Nm, using tool 99395216 (4), to an angle of 90°, following the diagram of Figure 85.

Figure 85





DIAGRAM OF SEQUENCE FOR TIGHTENING THE SCREWS FIXING THE BOTTOM CRANKCASE BASE TO THE CRANKCASE

Figure 86




□ Remove the crankcase base.

The clearance between the main bearings and their journals is measured by comparing the width taken on by the calibrated wire (2) at the point of greatest crushing with the graduated scale on the case (1) containing the calibrated wire.


The numbers on the scale give the clearance of the coupling in millimetres. If you find the clearance is not as required, replace the bearing shells and repeat the check.

Checking crankshaft end float

Figure 87




End float is checked by placing a magnetic dial gauge (2) on the crankshaft (1), as shown in the figure. If the value obtained is higher than specified, replace the rear thrust half-bearings and repeat this check.


5408 PISTON CONNECTING ROD ASSEMBLY**Figure 88****PISTON CONNECTING ROD ASSEMBLY**

1. Connecting rod body - 2. Half bearings - 3. Connecting rod cap - 4. Cap fastening screws - 5. Split ring - 6. Scraper ring with spiral spring - 7. Bevel cut sealing ring - 8. Trapezoidal sealing ring - 9. Piston pin - 10. Piston

Make sure the piston does not show any trace of seizing, scoring, cracking; replace as necessary.


Removal**Figure 89**

Removal of the piston split rings (2) using the pliers 99360184 (1).

Figure 90

Remove the piston pin split rings (2) using the round tipped pliers (1).

Figure 91




49025

Remove the piston pin (1).
If removal is difficult use the appropriate beater.

Measuring the diameter of the pistons


Figure 92



47584

Using a micrometer (2), measure the diameter of the piston (1) to determine the assembly clearance; the diameter has to be measured at the value X shown:

Figure 93




32618

Measuring the gudgeon pin diameter (1) with a micrometer (2).

Conditions for correct gudgeon pin-piston coupling


Figure 94



49026

Lubricate the pin (1) and the relevant housing on the piston hubs with engine oil; piston must be inserted with a slight finger pressure and it should not come out by gravity.

Figure 95




MAIN DATA OF THE PISTON, SUPPLIED BY MONDIAL PISTON, PISTON RINGS AND PIN

* Values are determined on Ø of 120 mm.


540842 Piston rings

Figure 96




Check the thickness of the piston ring (2) using a micrometer (1).

Figure 97




Check the clearance between the sealing rings (2) and the relative piston housings (1) using a thickness gauge (3).

Figure 98



The sealing ring (2) of the 1st cavity is trapezoidal. Clearance "X" between the sealing ring and its housing is measured by placing the piston (1) with its ring in the cylinder barrel (3), so that the sealing ring is half-projected out of the cylinder barrel.

Figure 99



Check the opening between the ends of the sealing rings (1), using a thickness gauge (2), entered in the cylinder barrel (3). If the distance between ends is lower or higher than the value required, replace split rings.

540830 CONNECTING RODS**Figure I00**


Data concerning the class section of connecting rod housing and weight are stamped on the big end.




When installing connecting rods, make sure they all belong to the same weight class.

DIAGRAM OF THE CONNECTING ROD MARKS

- 1 Letter indicating the weight class:
 - A = 3973 to 4003 g.
 - B = 4004 to 4034 g.
 - C = 4035 to 4065 g.
- 2 Number indicating the selection of diameter for the big end bearing housing:
 - 1 = 87.000 to 87.010 mm
 - 2 = 87.011 to 87.020 mm
 - 3 = 87.021 to 87.030 mm
- 3 Numbers identifying cap-connecting rod coupling.




47557

Figure I01


44927

MAIN DATA - BUSH, CONNECTING ROD, PIN AND HALF-BEARINGS


* Values to be obtained after installing the bush.

540842 Bushings**Figure 102**

Check the bushing in the small end has not come loose and shows no sign of scoring or seizure; replace it if it does. The bushing (2) is removed and fitted with a suitable drift (1). When driving it in, make absolutely sure that the holes for the oil to pass through in the bushing and small end coincide. Using a boring machine, rebores the bushing so as to obtain a diameter of 50.019 – 50.035.


Checking connecting rods**Figure 103****Checking axis alignment**

Check the alignment of the axes of the connecting rods (1) with device 99395363 (5), proceeding as follows:
Fit the connecting rod (1) on the spindle of the tool 99395363 (5) and lock it with the screw (4).
Set the spindle (3) on the V-prisms, resting the connecting rod (1) on the stop bar (2).

Figure 104

Check the torsion of the connecting rod (5) by comparing two points (A and B) of the pin (3) on the horizontal plane of the axis of the connecting rod.

Position the mount (1) of the dial gauge (2) so that this pre-loads by approx. 0.5 mm on the pin (3) at point A and zero the dial gauge (2). Shift the spindle (4) with the connecting rod (5) and compare any deviation on the opposite side B of the pin (3); the difference between A and B must be no greater than 0.08 mm.

Checking bending**Figure 105**

Check the bending of the connecting rod (5) by comparing two points C and D of the pin (3) on the vertical plane of the axis of the connecting rod.


Position the vertical mount (1) of the dial gauge (2) so that this rests on the pin (3) at point C.

Swing the connecting rod backwards and forwards seeking the highest position of the pin and in this condition zero the dial gauge (2).

Shift the spindle (4) with the connecting rod (5) and repeat the check on the highest point on the opposite side D of the pin (3). The difference between point C and point D must be no greater than 0.08 mm.

Mounting the connecting rod – piston assembly


Figure 106



73536

The piston (1) has to be fitted on the connecting rod (2) so that the graphic symbol (4), showing the assembly position in the cylinder liner, and the punch marks (3) on the connecting rod are observed as shown in the figure.

Figure 107




74052

Fit the pin (2) and fasten it on the piston (1) with the split rings (3).

Mounting the piston rings

Figure 108




60614

To fit the piston rings (1) on the piston (2) use the pliers 99360184 (3).

The rings need to be mounted with the word "TOP" (4) facing upwards. Direct the ring openings so they are staggered 120° apart.

Fitting the big end bearing shells

Figure 109



49030

Fit the bearing shells (1), selected as described under the heading "Selecting the main and big end bearing shells", on both the connecting rod and the cap.

If reusing bearing shells that have been removed, fit them back into their respective seats in the positions marked during removal.

Fitting connecting rod - piston assemblies in the cylinder liners


With the aid of the clamp 99360605 (1, Figure 110), fit the connecting rod – piston assembly (2) in the cylinder liners, according to the diagram of Figure 111, checking that:

- ☐ The openings of the piston rings are staggered 120° apart.
- ☐ The pistons are all of the same class, A or B.
- ☐ The symbol punched on the top of the pistons faces the engine flywheel, or the recess in the skirt of the pistons tallies with the oil nozzles.



The pistons are supplied as spares in class A and can be fitted in class B cylinder liners.

Figure 110




60616

Checking piston protrusion

On completing assembly, check the protrusion of the pistons from the cylinder liners; it must be 0.23 – 0.53 mm.

Figure 111



60615


ASSEMBLY DIAGRAM OF CONNECTING ROD – PISTON ASSEMBLY IN CYLINDER LINER

1. Connecting rod – piston assembly – 2. Area of punch marking on the top of the piston, symbol showing assembly position and selection class – 3. Connecting rod punch mark area

540831 Checking crankpin assembly clearance

To check the clearance proceed as follows.
Connect the connecting rods to the relative main journals, place a length of calibrated wire on the latter.

Figure I 12



Mount the connecting rod caps (1) together with the bearing shells. Tighten the screws (2) fixing the connecting rod caps to a torque of 60 Nm (6 kgm). Using tool 99395216 (3), further tighten the screws with an angle of 60°.



The thread of the screws (2), before assembly, has to be lubricated with engine oil.

Remove the caps and determine the clearance by comparing the width of the calibrated wire with the graduated scale on the case containing the calibrated wire.


Upon final assembly: check the diameter of the thread of the screws (2), it must be no less than 13.4 mm; if it is, change the screw. Lubricate the crankpins and connecting rod bearings. Tighten the screws (2) as described above.

540610 CYLINDER HEAD

Before removing the cylinder head, check it is leakproof using appropriate equipment. Replace the cylinder head if there is any leakage.

Removing valves

Figure I 13




Install and fix tool 99360261 (2) with bracket (4); tighten by lever (1) until cotters are removed (3); remove the tool (2) and the upper plate (5), the spring (6) and the lower plate (7). Repeat the operation on all the valves.
Turn the cylinder head upside down and remove the valves (8).

Checking the planarity of the head on the cylinder block

Figure I 14

(Demonstration)



The planarity (1) is checked using a ruler (2) and a thickness gauge (3). If deformations exist, surface the head using proper surface grinder; the maximum amount of material to be removed is 0.3 mm.




After this process, you need to check the valve recessing and injector protrusion.

540622 Valves


Removing deposits and checking the valves

Figure I 15



Remove carbon deposits using the metal brush supplied. Check that the valves show no signs of seizure or cracking. Check the diameter of the valve stem using a micrometer (see Figure I 16) and replace if necessary.

Figure 116



60617

MAIN DATA OF VALVES AND VALVE GUIDES


* Measurement to be made after driving in the valve guides

Check with a micrometer that the diameter of the valve stems is as indicated. If necessary, grind the valve seats with a grinding machine, removing as little material as possible.

540661 Valve seats**Regrinding – replacing valve seats**

The valve seats are reground whenever the valves or valve guides are ground and replaced.

Figure 117



41032


Check the valve seats (2). If you find any slight scoring or burns, regrind them with tool 99305019 (1) according to the angles shown in Figure 116 and Figure 118. If it is necessary to replace them, using the same tool and taking care not to affect the cylinder head, remove as much material as possible from the valve seats so that, with a punch, it is possible to extract them from the cylinder head.

Heat the cylinder head to 80 – 100°C and, using a drift, fit in the new valve seats (2), chilled beforehand in liquid nitrogen. Using tool 99305019 (1), regrind the valve seats according to the angles shown in Figure 118.

After regrinding the valve seats, using tool 99370415 and dial gauge 99395603, check that the position of the valves in relation to the plane of the cylinder head is:

- -0.65 to -0.95 mm (recessing) intake valves;
- -1.8 to -2.1 mm (recessing) exhaust valves.

Figure 118



73537

MAIN DATA OF VALVE SEATS

1. Intake valve seat – 2. Exhaust valve seat


Checking clearance between valve-stem and associated valve guide

Using a dial gauge with a magnetic base, check the clearance between the valve stem and the associated guide. If the clearance is too great, change the valve and, if necessary, the valve guide.

540667 Valve guides

Replacing valve guides

Figure 119



* Measurement to be made after driving in the valve guides

The valve guides are removed with the drift 99360481. They are fitted with the drift 99360481 equipped with part 99360295.


Part 99360295 determines the exact position of assembly of the valve guides in the cylinder head. If they are not available, you need to drive the valve guides into the cylinder head so they protrude by 30.8-31.2 mm.

After driving in the valve guides, rebore their holes with the smoother 99390311.

540613 Replacing injector cases

Removal

Figure 120




To replace the injector case (2), proceed as follows:

- ☐ Thread the case (2) with tool 99390804 (1).


The steps described in Figs. 120 – 123 – 124 – 125 need to be carried out by fixing the tools, with the bracket A, to the cylinder head.

Figure 121



- Screw the extractor 99342149 (2) into the case (3). Screw down the nut (1) and take the case out of the cylinder head.


Figure 122



- Using the tool 99390772 (2) remove any residues (1) left in the groove of the cylinder head.


Assembly

Figure 123




- Lubricate the seals (3) and fit them on the case (4). Using tool 99365056 (2) secured to the cylinder head with bracket A, drive in the new case, screwing down the screw (1) upsetting the bottom portion of the case.

Figure 124



- Using the reamer 99394041 (1-2), re-bore the hole in the case (3).

Figure I25




60624

- Using grinder 99394041 (1-2), ream the injector seat in the case (3), check the injector protrusion from the cylinder head plane which must be 1.14 to 1.4 mm.

Checking injector protrusion


Figure I26



47585



Check injector protrusion (2) with the dial gauge (1). The protrusion must be 1.14 to 1.4 mm.

Figure I27





71720

INJECTOR CASE ASSEMBLY DIAGRAM

5412 Timing system**541211 Checking cam lift and pin alignment****Figure 128**



47506

Place the camshaft (4) on the tailstock (1) and check cam lift (3) using a centesimal gauge (2); values are shown in table on page 21.

Figure 129

47507


When the camshaft (4) is on the tailstock (1), check alignment of supporting pin (3) using a centesimal gauge (2); it must not exceed 0.035 mm. If misalignment exceeds this value, replace the shaft.

Figure 130

47505


In order to check installation clearance, measure bush inner diameter and camshaft pin (1) diameter; the real clearance is obtained by their difference.

If clearance exceeds 0.150 mm, replace bushes and, if necessary, the camshaft.

541210 Camshaft**Figure 131****MAIN DATA - CAMSHAFT AND TOLERANCES**

The surfaces of shaft supporting pin and cams must be extremely smooth; if you see any sign of seizing or scoring, replace the shaft and the relative bushes.

TOLERANCES	TOLERANCE CHARACTERISTIC	SYMBOL
ORIENTATION	Perpendicularity	$\perp$
POSITION	Concentricity or coaxial alignment	$\odot$
OSCILLATION	Circular oscillation	$\nearrow$
IMPORTANCE CLASS ASSIGNED TO PRODUCT CHARACTERISTICS		SYMBOL
CRITICAL		$\oplus$
IMPORTANT		$\ominus$
SECONDARY		$\ominus$

541213 Bushings**Figure 132****MAIN DATA OF CAMSHAFT BUSHES AND RELEVANT HOUSINGS ON CYLINDER HEAD**


* Bush inner diameter after installation

The bush surfaces must not show any sign of seizing or scoring; if they do replace them.

Measure the bush inner diameters with a baremeter and replace them, if the value measured exceeds the tolerance value. To take down and fit back the bushes, use the proper tool 99360499.

Replacing camshaft bushings with drift 99360499

Figure 133




71721

- A = Drift with seat for bushings to insert/extract.
- B = Grub screw for positioning bushings.
- C = Reference mark to insert seventh bushing correctly.
- D = Reference mark to insert bushings 1, 2, 3, 4, 5, 6 correctly (red marks).
- E = Guide bushing.
- F = Guide line.
- G = Guide bushing to secure to the seventh bushing mount.
- H = Plate fixing bushing G to cylinder head.
- I = Grip.
- L = Extension coupling.

Removal

Figure 134




71725

The sequence for removing the bushings is 7, 6, 5, 4, 3, 2, 1. The bushings are extracted from the front of the single seats. Removal does not require the drift extension for bushings 5, 6 and 7 and it is not necessary to use the guide bushing. For bushings 1, 2, 3 and 4 it is necessary to use the extension and the guide bushings. Position the drift accurately during the phase of removal.

Assembly

Figure 135



77795


Assemble the drift together with the extension.

To insert bushings 1, 2, 3, 4 and 5, proceed as follows:

- 4 position the bushing to insert on the drift (A) making the grub screw on it coincide with the seat (B) (Figure 133) on the bushing.
- 5 position the guide bushing (E) and secure the guide bushing (G) (Figure 133) on the seat of the 7th bushing with the plate (H).
- 6 while driving in the bushing, make the reference mark (F) match the mark (M). In this way, when it is driven home, the lubrication hole on the bushing will coincide with the oil pipe in its seat.

The bushing is driven home when the 1st red reference mark (D) is flush with the guide bushing (G).

Figure I36




71723

To insert the bushing (6), proceed as follows:

- ☐ Unscrew the grip (I) and the extension (N).
- ☐ Position the extension (N) and the guide bushing (E) as shown in the figure.
- ☐ Repeat steps 1, 2, 3.

Figure I37




71724

To insert bushing (7), proceed as follows:

- ☐ Unscrew the grip (I) and the extension (N).
- ☐ Refit the guide (G) from the inside as shown in the figure.
- ☐ Position the bushing on the drift (A) and bring it close up to the seat, making the bushing hole match the lubrication hole in the head. Drive it home. The 7th bushing is driven in when the reference mark (C) is flush with the bushing seat.

540665 Valve springs

Figure I38




70000

Before assembly, the flexibility of the valve springs has to be checked with the tool 99305047.

Compare the load and elastic deformation data with those of the new springs given in the following figure.

Figure I39




49034

MAIN DATA TO CHECK THE SPRING
FOR INTAKE AND EXHAUST VALVES

Fitting valves and oil seal


Figure 140



49033

Lubricate the valve stems and insert them in their respective valve guides. Mount the bottom plates (3) with the key 99360328 and the oil seal (1) on the valve guides (2). Then go ahead and mount the valves as follows:

Figure 141




47583

- ☐ Mount the springs (6) and the top plate (5).
- ☐ Fit the tool 99360261 (2) and secure it with the bracket (4). Screw down the lever (1) to be able to fit on the cotters (3). Take off the tool (2).

5412 ROCKER SHAFT

Figure 142



44925

The cams of the camshaft control the rocker arms directly: 6 for the injectors and 12 for the valves.


The rocker arms run directly on the profiles of the cams by means of rollers.

The other end acts on a crosspiece that rests on the stem of the two valves.

There is a pad between the rocker arm adjustment screw and the crosspiece.

There are two lubrication ducts inside the rocker arms.


The length of the rocker arm shaft is basically the same as that of the cylinder head. It has to be detached to be able to reach all the parts beneath.

Shaft**Figure 143**

73539


MAIN DATA OF THE ROCKER ARM SHAFT

Check that the surface of the shaft shows no scoring or signs of seizure; if it does, replace it.


Rocker arms**Figure 144**

Check the surfaces of the bushings, which must show no signs of scoring or excessive wear; if they do, replace the rocker arm assembly.

44914

PUMP INJECTOR ROCKER ARMS**Figure 145**

44912

INTAKE VALVE ROCKER ARMS**Figure 146**

44913


EXHAUST VALVE ROCKER ARMS

ENGINE ASSEMBLY ON BENCH

Fix the engine block to the stand 99361036 by means of brackets 99322230.

Install the cylinder liners as described in page 158.

Figure 147



47586


Mount the oil nozzles (2), making the grub screw coincide with the hole (3) in the crankcase.



Not finding it necessary to replace the main bearings, you need to fit them back in exactly the same sequence and position as in removal. If they have to be replaced, choose the main bearings according to the selection described on pages 53, 54, 55, 56, 57.

Arrange the bearing shells (1) on the main bearing housings.


Figure 148



47570

Lubricate the half bearings, then install the crankshaft (2) by means of hoist and hook 99360500 (1).


Figure 149



49021

Place the half-bearings (1) on the main bearings in the underblock (2).


Figure 150



47595

By means of suitable equipment (1) apply silicone LOCTITE 5699 to the block, as shown in the figure.

Figure 151




60632

Sealant application diagram.




Fit the underblock within 10' of the application of the sealant.

Figure I52




Mount the crankcase base (1) using appropriate tackle and hooks.

Figure I53



Mount the crankcase base and using a torque wrench (2), tighten the outside hex grooved screws (1) to a torque of 30 Nm following the sequence shown on page 190.

Figure I54



Using a torque wrench (3), tighten the inside screws (1) to a torque of 120 Nm. Then tighten them to an angle of 90° and 45° with tool 99395216 (4) with another two phases. Regrind the outside screws (1, Figure I53) with closure to an angle of 60° using tool 99395213 (4).

Figure 155





DIAGRAM OF TIGHTENING SEQUENCE OF CRANKCASE BASE FIXING SCREWS

Fitting connecting rod - piston assemblies in cylinder liners

Figure 156



Not finding it necessary to replace the connecting rod bearings, you need to fit them back in exactly the same sequence and position as in removal. If they have to be replaced, choose the connecting rod bearings according to the selection described from page 161 to page 167. Lubricate the bearing shells (1 and 3) and fit them on the connecting rod (2) and on the cap (4).



Do not make any adjustment on the bearing shells.

Figure 157





Figure 158



Turn the cylinder block, setting it upright.

Lubricate the pistons, piston rings and inside the cylinder liners.

With the aid of the clamp 99360605 (1) mount the connecting rod - piston assemblies (2) in the cylinder liners according to Figure 157. Check that:

- ☐ The number of each connecting rod corresponds to the cap coupling number.
- ☐ The symbol (2, Figure 157) punched on the top of the pistons faces the engine flywheel or the recess in the piston skirt tallies with the position of the oil nozzles.




The pistons are supplied as spares in class A and can also be fitted in class B cylinder liners.

- ☐ 1 Connecting rod - piston assembly.
- ☐ 2 Area of punch marking on the top of the piston with the symbol for the mounting position and selection class.
- ☐ 3 Area of connecting rod punch marking.

60615

Figure 159



47594


Connect the connecting rods to the relevant pins of the crankshaft, mount the connecting rod caps (1) together with the bearing shells. Tighten the screws (2) fixing the connecting rod caps to a torque of 60 Nm (6 kgm). Using tool 99395216 (3), tighten the screws further with an angle of 60°.



Before reusing the screws (2), measure the diameter of the thread; it must be no less than 13.4 mm; if it is, change the screw.

Lubricate the thread of the screws with engine oil before assembly.


Figure 160



60563

Using the centring ring 99396035 (2), check the exact position of the cover (1). If it is wrong, proceed accordingly and lock the screws (3).


Figure 161



60564

Key on the gasket (1), mount the key 99346250 (2) and, screwing down the nut (3), drive in the gasket (1).

Figure 162



60515


Check that the pistons 1-6 are exactly at the T.D.C. Put the gasket (2) on the crankcase.

Mount the cylinder head (1) and tighten the screws as shown in Figs. 163 – 164 – 165.



Lubricate the thread of the screws with engine oil before assembly.


Figure 163



61270

Diagram of the tightening sequence of the screws fixing the cylinder head.


Figure 164



60565

Pre-tightening with the torque wrench (1):
1st phase: 60 Nm (6 kgm).
2nd phase: 120 Nm (12 kgm).


Figure 165



60566

- Closing to angle with tool 99395216 (1):
 3rd phase: angle of 120°.
 4th phase: angle of 60°.


Figure 166



60567

Mount the oil pump (4), the intermediate gears (2) together with the link rod (1) and lock the screws (3) in two phases:
 pre-tightening 30 Nm.
 closing to angle 90°.

Figure 167




47592

Apply LOCTITE 5699 silicone on the gear housing, using appropriate tools (I), as shown in the figure.
 The sealer string (I) diameter is to be $1,5 \pm 0,5$



Mount the gear housing within 10 min. of applying the sealant.

Figure 168




60633

Using a torque wrench, tighten the highlighted screws with the following sequence and tightening torques:


☆	10 screws M12 x 1.75 x 100	63 Nm
⊙	2 screws M12 x 1.75 x 70	63 Nm
□	4 screws M12 x 1.75 x 35	63 Nm
△	1 screw M12 x 1.75 x 120	63 Nm
*	2 screws M12 x 1.75 x 193	63 Nm

Figure 169



60568

Key on the gasket (1), mount the keying device 99346251 (2) and, screwing down the nut (3), drive in the gasket.

540850 ENGINE FLYWHEEL**Fitting engine flywheel****Figure 170**

A = Hole on flywheel with one reference mark, corresponding to the TDC of pistons 3-4.


B = Hole on flywheel with one reference mark, corresponding to the TDC of pistons 1-6.

C = Hole on flywheel with one reference mark, corresponding to the TDC of pistons 2-5.


D = Hole on flywheel with two reference marks, position corresponding to 54°.



If the teeth of the ring gear mounted on the engine flywheel, for starting the engine, are very damaged, replace the ring gear. It must be fitted after heating the ring gear to a temperature of approx. 200°C.

Figure 171


The crankshaft has a locating peg that has to couple with the relevant seat on the engine flywheel.

Figure 172

Second and third phase: closing to angle of 60° + 30° with tool 99395216 (1).

Fitting camshaft

Figure 173



Position the crankshaft with the pistons 1 and 6 at the top dead centre (T.D.C.).


This situation occurs when:

1. The hole with reference mark (5) of the engine flywheel (4) can be seen through the inspection window.
2. The tool 99360612 (1), through the seat (2) of the engine speed sensor, enters the hole (3) in the engine flywheel (4).

If this condition does not occur, turn the engine flywheel (4) appropriately.

Remove the tool 99360612 (1).

Figure 174




Fit the camshaft (4), positioning it observing the reference marks (→) as shown in the figure.

Lubricate the seal (3) and fit it on the shoulder plate (2).


Mount the shoulder plate (2) with the sheet metal gasket (1) and tighten the screws (5) to the required torque.

Figure 175




- Apply the gauge 99395219 (1). Check and adjust the position of the link rod (3) for the idle gear. Lock the screw (2) to the required torque.

Figure 176



- Fit the idle gear (1) back on and lock the screws (2) to the required torque.

Figure 177



60572


Position the gear (2) on the camshaft so that the 4 slots are centred with the holes for fixing the camshaft, without fully locking the screws (5).

Using the dial gauge with a magnetic base (1), check that the clearance between the gears (2 and 3) is 0.073 – 0.195 mm; if this is not so, adjust the clearance as follows:

- ☐ Loosen the screws (4) fixing the idle gear (3).
- ☐ Loosen the screw (2, Figure 175) fixing the link rod. Shift the link rod (3, Figure 175) to obtain the required clearance.
- ☐ Lock the screw (2, Figure 175) fixing the link rod and screws (4, Figure 177) fixing the idle gear to the required torque.

Fitting pump-injectors


Figure 178



44908

Fit the seals (1) (2) (3) on the injectors.

Figure 179



Mount:


- ☐ The injectors (2) and, using a torque wrench, lock the bracket fixing screws to a torque of 26 Nm.
- ☐ The exhaust brake cylinders (1) and (4) and, using a torque wrench, fix them to a torque of 19 Nm.
- ☐ The crosspieces (3) on the valve stem, all with the largest hole on the same side.

Fitting rocker-arm shaft assembly

Figure 180



Before refitting the rocker-arm shaft assembly, make sure that all the adjustment screws have been fully unscrewed.




73533

Using tool 99360144 (3), fasten the blocks (4) to the rocker arms (2).

Apply the tool 99360553 (1) to the rocker arm shaft (5) and mount the shaft on the cylinder head.


Figure 181



Lock the screws (2) fixing the rocker-arm shaft as follows:


- ☐ 1st phase: tightening to a torque of 100 Nm (10 kgm) with the torque wrench (1);
- ☐ 2nd phase: closing with an angle of 60° using the tool 99395216 (3).

Figure 182



- ☐ Mount the engine brake lever retaining springs (3).
- ☐ Connect the pipe (2) to the engine brake cylinders (4) and to the cylinder with the engine brake solenoid valve (1).


Figure 183



Mount the electric wiring (2), securing it on the electro-injectors with a torque screwdriver (1) to a torque of 1.36 - 1.92 Nm.

Camshaft timing

Figure 184




Apply the tool 99360321 (7) and the spacer 99360325 (6) to the gearbox (3).



The arrow shows the direction of rotation of the engine when running.

Using the above-mentioned tool, turn the engine flywheel (1) in the direction of rotation of the engine so as to take the piston of cylinder no.1 to approximately the T.D.C. in the phase of combustion. This condition occurs when the hole with one reference mark (4), after the hole with two reference marks (5) on the engine flywheel (1), can be seen through the inspection window (2).

Figure 185




71774

The exact position of piston no.1 at the T.D.C. is obtained when in the above-described conditions the tool 99360612 (1) goes through the seat (2) of the engine speed sensor into the hole (3) in the engine flywheel (4).

If this is not the case, turn and adjust the engine flywheel (4) appropriately.

Remove the tool 99360612 (1).

Figure 186



60573


Set the dial gauge with the magnetic base (1) with the rod on the roller (2) of the rocker arm that governs the injector of cylinder no.1 and pre-load it by 6 mm.

With tool 99360321 (7) Figure 184, turn the crankshaft clockwise until the pointer of the dial gauge reaches the minimum value beyond which it can no longer fall.

Reset the dial gauge.

Turn the engine flywheel anticlockwise until the dial gauge gives a reading for the lift of the cam of the camshaft of 4.44 ± 0.05 mm.

Figure 187




77259

The camshaft is in step if at the cam lift values of 4.44 ± 0.05 mm there are the following conditions:

- 1) the hole marked with a notch (5) can be seen through the inspection window;
- 2) the tool 99360612 (1) through the seat (2) of the engine speed sensor goes into the hole (3) in the engine flywheel (4).

Figure 188




60575

If you do not obtain the conditions illustrated in Figure 187 and described in points 1 and 2, proceed as follows:

- 1) loosen the screws (2) securing the gear (1) to the camshaft and utilize the slots (see Figure 189) on the gear (1);
- 2) turn the engine flywheel appropriately so as to bring about the conditions described in points 1 and 2 Figure 187, it being understood that the cam lift must not change at all;
- 3) lock the screws (2) and repeat the check as described above.


Tighten the screws (2) to the required torque.

Figure 189

71778

When the adjustment with the slots (1) is not enough to make up the phase difference and the camshaft turns because it becomes integral with the gear (2); as a result, the reference value of the cam lift varies, in this situation it is necessary to proceed as follows:

- 1) lock the screws (2, Figure 188) and turn the engine flywheel clockwise by approx. 1/2 turn;
- 2) turn the engine flywheel anticlockwise until the dial gauge gives a reading of the lift of the cam of the camshaft of 4.44 ± 0.05 mm;
- 3) take out the screws (2, Figure 188) and remove the gear (1) from the camshaft.

Figure 190

72436

Turn the flywheel (4) again to bring about the following conditions:



- ☐ a notch (5) can be seen through the inspection window;
- ☐ the tool 99360612 (1) inserted to the bottom of the seat of the engine speed sensor (2) and (3).

Mount the gear (2) Figure 189 with the 4 slots (1) centred with the fixing holes of the camshaft, locking the relevant screws to the required tightening torque.

Check the timing of the shaft by first turning the flywheel clockwise to discharge the cylinder completely and then turn the flywheel anticlockwise until the dial gauge gives a reading of 44.4 ± 0.05 .

Check the timing conditions described in Figure 187.

Phonic wheel timing

Figure 191

77260

Turn the crankshaft by taking the piston of cylinder no. 1 into the compression phase at T.D.C.; turn the flywheel in the opposite direction to the normal direction of rotation by approximately 1/4 of a turn.


Again turn the flywheel in its normal direction of rotation until you see the hole marked with the double notch (4) through the inspection hole under the flywheel housing. Insert tool 99360612 (5) into the seat of the flywheel sensor (6).

Insert the tool 99360613 (2), via the seat of the phase sensor, onto the tooth obtained on the phonic wheel.

Should inserting the tool (2) prove difficult, loosen the screws (3) and adjust the phonic wheel (1) appropriately so that the tool (2) gets positioned on the tooth correctly. Go ahead and tighten the screws (3).

Intake and exhaust rocker play adjustment and pre-loading of rockers controlling pump injectors

Figure 192



60577

ADJUSTMENT OF INTAKE, EXHAUST AND INJECTION ROCKERS

The adjustment of clearance between the rockers and rods controlling the intake and exhaust valves, as well as the adjustment of pre-loading of the rockers controlling pump injectors, must be carried out carefully.

Take the cylinder where clearance must be adjusted to the bursting phase; its valves are closed while balancing the symmetric cylinder valves.

Symmetric cylinders are 1-6, 2-5 and 3-4.

In order to properly operate, follow these instructions and data specified on the table.

Adjustment of clearance between the rockers and rods controlling intake and exhaust valves:

- ☐ using a polygonal wrench, loosen nut (1) locking the adjustment screw;
- ☐ insert the thickness gauge blade (3);
- ☐ tighten or untighten the adjustment screw with the appropriate wrench;
- ☐ make sure that the gauge blade (3) can slide with a slight friction;
- ☐ lock the nut (1), by blocking the adjustment screw.

Pre-loading of rockers controlling pump injectors:

- ☐ using a polygonal wrench, loosen the nut locking the rocker adjustment screw (5) controlling the pump injector (6);

- ☐ using an appropriate wrench (4), loosen the adjustment screw until the pumping element is at the end-of-stroke;
- ☐ tighten the adjustment screw, with a dynamometric wrench, to 5 Nm tightening torque (0.5 kgm);
- ☐ untighten the adjustment screw by 1/2 to 3/4 rotation;
- ☐ tighten the locking nut.


FIRING ORDER **1-4-2-6-3-5**

Clockwise start-up and rotation	Adjusting cylinder valve no.	Adjusting clearance of cylinder valve no.	Adjusting pre-loading of cylinder injector no.
1 and 6 at TDC	6	1	5
120°	3	4	1
120°	5	2	4
120°	1	6	2
120°	4	3	6
120°	2	5	3



In order to properly carry out the above-mentioned adjustments, follow the sequence specified in the table, checking the exact position in each rotation phase by means of pin 99360612, to be inserted in the 11th hole in each of the three sectors with 18 holes each.

Figure 193



85480

Fit the distribution cover (1).
Fit the blow-by case (7) and its gasket and then tighten the screws (8) to the prescribed torque.
Install the filter (5) and the gaskets (4 and 6).




The filter (5) operation is unidirectional, therefore it must be assembled with the two sight supports as illustrated in the figure.

Fit the cover (3) and tighten the fastening screws (2) to the prescribed torque.



Apply silicone LOCTITE 5699 on the blow-by case (7) surface of engines fitted with P.T.O. according to the procedure described in the following figure.

Figure 194




85481

Apply silicone LOCTITE 5699 on the blow-by case and form a string (2) of $\varnothing 1,5 \pm_{0,2}^{0,5}$ as shown in the figure.



Fit the blow-by case (1) within 10' from sealer application.

Figure 195



60665


- ☐ Set the gasket (4) on the oil sump (1). Position the spacer (3) and mount the sump on the engine crankcase, screwing the screws (2) to the required torque.

Completing Engine Assembly

Complete the engine by fitting or hooking up the following parts:

- ☐ thermostat assembly;
- ☐ automatic tensioner, water pump, alternator;
- ☐ drive belt.

Figure 196



60578

ASSEMBLY DIAGRAM OF FAN – WATER PUMP – ALTERNATOR DRIVE BELT

1. Alternator – 2. Electromagnetic coupling –
3. Water pump – 4. Crankshaft

- ☐ damper flywheel;
- ☐ electromagnetic coupling;



The fittings of the cooling water and lubricating oil pipes of the turbocharger have to be tightened to a torque of:


- ☐ 35 ±5 Nm, water pipe fittings;
- ☐ 55 ±5 Nm, oil pipe female fitting;
- ☐ 20-25 Nm, oil pipe male fitting.

- ☐ oil dipstick;
- ☐ oil suction strainer;
- ☐ electrical connections and sensors;
- ☐ replenish the engine with the required amount of oil;
- ☐ remove the engine from the rotary stand and take off the brackets (99361036) fixing the engine.

Assemble:

- ☐ air conditioner compressor automatic belt tightener;
- ☐ control belt.


Figure 197



COMPRESSOR CONTROL BELT
ASSEMBLY DIAGRAM

1. Crankshaft - 2. Air conditioner compressor

Figure 198



When assembling the belts (1-3) operate on the belt tighteners using fit tools (2-4), acting in the direction shown by the arrows.





Belt tighteners are automatic and do not need further adjustment after assembly.

5430 LUBRICATION

Engine lubrication is obtained with a gear pump driven by the crankshaft via gears.
 A heat exchanger governs the temperature of the lubricating oil.
 It houses two oil filters, indicator sensors and safety valves.

Figure 199




543010 Oil pump**Figure 200**

60560


The oil pump (1) cannot be overhauled. On finding any damage, replace the oil pump assembly.

See under the relevant heading for replacing the gear (2) of the crankshaft.

Overpressure valve**Figure 202**

73540


MAIN DATA TO CHECK THE OVERPRESSURE VALVE SPRING

Figure 201

73541


OIL PUMP CROSS-SECTION

I. Overpressure valve – Start of opening pressure 10.1 ± 0.7 bars


Oil pressure control valve**Figure 203**

The oil pressure control valve is located on the left-hand side of the crankcase.


Start of opening pressure 5 bars.

Figure 204


MAIN DATA TO CHECK THE OIL PRESSURE CONTROL VALVE SPRING

543110 Heat exchanger**Figure 205****HEAT EXCHANGER**

The heat exchanger is fitted with: 1. Oil temperature sensor - 2. Oil pressure sensor for pressure gauge - 3. Transmitter for low pressure warning lamp - 4. By-pass valve - 5. Heat valve. Number of elements 9

By-pass valve**Figure 206**

The valve quickly opens at a pressure of: 3 bars.


Thermostatic valve**Figure 207**

Start of opening:

☐ travel 0.1 mm at a temperature of $82 \pm 2^\circ\text{C}$.

End of opening:

☐ travel 8 mm at a temperature of 97°C .

Engine oil filters**Figure 208**

This is a new generation of filters that permit much more thorough filtration as they are able to hold back a greater amount of particles of smaller dimensions than those held back by conventional filters with a paper filtering element.

These high-filtration devices, to date used only in industrial processes, make it possible to:

- ☐ reduce the wear of engine components over time;
- ☐ maintain the performance/specifications of the oil and thereby lengthen the time intervals between changes.

External spiral winding

The filtering elements are closely wound by a spiral so that each fold is firmly anchored to the spiral with respect to the others. This produces a uniform use of the element even in the worst conditions such as cold starting with fluids with a high viscosity and peaks of flow. In addition, it ensures uniform distribution of the flow over the entire length of the filtering element, with consequent optimization of the loss of load and of its working life.

Mount upstream

To optimize flow distribution and the rigidity of the filtering element, this has an exclusive mount composed of a strong mesh made of nylon and an extremely strong synthetic material.

Filtering element

Composed of inert inorganic fibres bound with an exclusive resin to a structure with graded holes, the element is manufactured exclusively to precise procedures and strict quality control.

Mount downstream

A mount for the filtering element and a strong nylon mesh make it even stronger, which is especially helpful during cold starts and long periods of use. The performance of the filter remains constant and reliable throughout its working life and from one element to another, irrespective of the changes in working conditions.

Structural parts

The o-rings equipping the filtering element ensure a perfect seal between it and the container, eliminating by-pass risks and keeping filter performance constant. Strong corrosion-proof bottoms and a sturdy internal metal core complete the structure of the filtering element.

When mounting the filters, keep to the following rules:

- ☐ Oil and fit new seals.
- ☐ Screw down the filters to bring the seals into contact with the supporting bases.
- ☐ Tighten the filter to a torque of 35-40 Nm.

5432 COOLING

Description

The engine cooling system works with forced circulation inside closed circuit and can be connected to an additional heater (if any) and to the intarder intercooler. It consists mainly of the following components:

- an expansion reservoir whose plug (I) incorporates two valves – discharge and charge – controlling the system pressure.
- a coolant level sensor placed at the bottom of the expansion reservoir with two coupling points:
 - coupling point for sensor S1 6 litres
 - coupling point for sensor S2 3.7 litres
- an engine cooling unit to dissipate the heat taken by the coolant from the engine through the intercooler.
- a heat exchanger to cool down lubrication oil;
- a water pump with centrifugal system incorporated in the cylinder block;
- an electric fan consisting of a 2-speed electro-magnetic joint equipped with a neutral wheel shaft hub fitted with a metal plate moving along the axis and where the fan is installed. It is controlled electronically by the vehicle Multiplex system.
- a 3-way thermostat controlling the coolant circulation.

Operation

The water pump is actuated by the crankshaft through a poli-V belt and sends coolant to the cylinder block, especially to the cylinder head (bigger quantity). When the coolant temperature reaches and overcomes the operating temperature, the thermostat is opened and from here the coolant flows into the radiator and is cooled down by the fan. The pressure inside the system depending on the temperature variation is controlled by the discharge and charge valves incorporated in the expansion reservoir filling plug (I).

The discharge valve has a double function:

- keep the system under light pressure in order to raise the coolant boiling point;
- discharge the pressure surplus in the atmosphere as a result of the coolant high temperature.


The charge valve makes it possible to transfer the coolant from the expansion reservoir to the radiator when a depression is generated inside the system as a result of the coolant volume reduction depending on the fall in the coolant temperature.

Discharge valve opening:

- 1st breather 0.9 $\begin{smallmatrix} +0.2 \\ -0.1 \end{smallmatrix}$ bar
- 2nd breather 1.2 $\begin{smallmatrix} +0.2 \\ -0.1 \end{smallmatrix}$ bar


Charge valve opening -0.03 $\begin{smallmatrix} +0 \\ -0.02 \end{smallmatrix}$ bar

Figure 209



543210 Water pump

Figure 210



CROSS-SECTION OF THE WATER PUMP

The water pump is composed of: impeller, bearing, seal and driving pulley.



Check that the pump body has no cracks or water leakage; if it does, replace the entire water pump.

543250 Thermostat

View of thermostat operation

Figure 211





Figure 212




Check the thermostat works properly; replace it if in doubt.

Temperature of start of travel $84^{\circ}\text{C} \pm 2^{\circ}\text{C}$.

Minimum travel 15 mm at $94^{\circ}\text{C} \pm 2^{\circ}\text{C}$.

543210 Electromagnetic coupling

Figure 213



ELECTROMAGNETIC COUPLING SECTION

Using a feeler gauge, check the gap between the anchor assembly (2) and the pulley (1), it must be no greater than 2.5 mm.

The electro-magnetic joint action depends on:

- ☐ the coolant temperature;
- ☐ the climate control system fluid pressure (if any);
- ☐ the slowing down action of the interarder on (if any).

Coolant temperature for:

- ☐ engagement 93°C
- ☐ disengagement 88°C

With climate control system

Climate control system pressure:

- ☐ 1st speed engagement 18 bar
- ☐ 2nd speed engagement 22 bar

With interarder

With braking power below 41% of maximum power:

Coolant temperature for:

- ☐ 2nd speed engagement 93°C
- ☐ disengagement 88°C

With braking power over 41% of maximum power:

Coolant temperature for:

- ☐ 2nd speed engagement 85°C
- ☐ disengagement 80°C


As to the description of the electro-magnetic joint operation and servicing, see the "Manual for electric/electronic system repairing" St. 603.93.191.

5424 TURBOCHARGING

The turbocharging system consists of:

- ☐ air filter;
- ☐ variable geometry turbocharger;
- ☐ "intercooler" radiator.

Figure 214



60675

TURBOCHARGING DIAGRAM

Turbocharger HOLSET HY55V

Operating principle

The variable geometry turbocharger (VGT) consists of a centrifugal compressor and a turbine, equipped with a mobile device which adjusts the speed by changing the area of the passing section of exhaust gases to the turbine.

Thanks to this solution, gas velocity and turbine speed can be high even when the engine is idling.

If the gas is made to go through a narrow passage, in fact, it flows faster, so that the turbine rotates more quickly.

The movement of the device, choking the exhaust gas flowing section, is carried out by a mechanism, activated by a pneumatic actuator.


This actuator is directly controlled by the electronic control unit by a proportional solenoid valve.

The device is in maximum closing condition at idle speed.

At high engine operating speed, the electronic control system is activated and increases the passing section, in order to allow the in-coming gases to flow without increasing their speed.


A toroidal chamber is obtained during the casting process in the central body for the passage of the coolant.

Figure 215




71759

1. Air delivery to the intake manifold - 2. Compressor - 3. Air inlet - 4. Actuator -
5. Exhaust gas speed governor - 6. Exhaust gas inlet - 7. Exhaust gas outlet - 8. Turbine



CROSS-SECTION OF MINIMUM FLOW

71733




CROSS-SECTION OF MAXIMUM FLOW

71734

CROSS-SECTION OF TURBOCHARGER


1. Air delivery to the intake manifold - 2. Compressor - 3. Air inlet - 4. Actuator - 5. Exhaust gas flow-rate adjustment ring -
6. Exhaust gas inlet - 7. Exhaust gas outlet - 8. Turbine - 9. Exhaust gas flow-rate control fork

Figure 216



60753


Figure 217



60754


1. Slide guide - 2. Compressor - 3. Slide rods - 4. Compressor fan - 5. Lubrication bushings -
 6. Exhaust gas flow-rate adjustment ring - 7. Exhaust gas fan - 8. Gas exhaust body -
 9. Locking rings - 10. Oil delivery - 11. Oil outlet - 12. Actuator drive shaft

Figure 218



71762

Figure 219




71763


1. Slide guide - 3. Slide rod - 11. Oil outlet - 12. Actuator drive shaft -
13. Actuator - 14. Exhaust gas flow-rate control fork

Actuator

Figure 220



- a Gradient characterized by the effect of the external spring (4).
- b Gradient characterized by the effect of the external (4) and internal (6) springs.



1. Air inlet - 2. Gasket - 3. Piston - 4. External spring - 5. Internal spring control disc - 6. Internal spring - 7. O-ring - 8. Spring holder - 9. Limit stop - 10. Dust seal - 11. Control rod

Working principle

The actuator piston, connected to the drive rod, is controlled with the compressed air introduced through the air inlet (1) on the top of the actuator.

Modulating the air pressure varies the movement of the piston and turbine control rod. As the piston moves, it progressively compresses the external spring (4) until the base of the piston reaches the disc (5) controlling the internal spring (6).

On further increasing the pressure, the piston, via the disc (5), interferes with the bottom limit stop (10).

Using two springs makes it possible to vary the ratio between the piston stroke and the pressure. Approximately 85% of the stroke of the rod is opposed by the external spring and 15% by the internal one.

Solenoid valve for VGT control


This N.C. proportional solenoid valve is located on the left-hand side of the crankcase under the turbine.

The electronic control unit, via a PWM signal, controls the solenoid valve, governing the supply pressure of the turbine actuator, which, on changing its position, modifies the cross-section of the flow of exhaust gases onto the blades of the impeller and therefore its speed.

The VGT solenoid valve is connected to the electronic control unit between pins A18/A31.

The resistance of the coil is approx. 20-30 Ohms.

Figure 221




CONTROL AIR SYSTEM DIAGRAM

71765

- | | |
|----------------------------|-------------------------------|
| 1) Services tank | 4) VGT control solenoid valve |
| 2) Shut-off solenoid valve | 5) Actuator pressure sensor |
| 3) Air filter | 6) Turbine actuator |

FEEDING

Fuel is supplied via a fuel pump, filter and pre-filter, 6 pump-injectors governed by the camshaft via rocker arms and by the electronic control unit.


Figure 222

71738

1. Valve for return circuit, starts opening at 3.5 bars - 2. Valve for return circuit, starts opening at 0.2 bars


Fuel pump

Figure 223



- A. Fuel inlet – B. Fuel delivery – C. By-pass nut –
D. Fuel return from the pump-injectors –
E. Pressure relief valve – Opening pressure: 5-8 bars


Figure 224



CROSS-SECTION OF THE FUEL PUMP
I. Oil and fuel leakage indicator

Injector-pump

Figure 225



1. Fuel/oil seal – 2. Fuel/diesel seal – 3. Fuel/exhaust gas seal

The injector-pump is composed of: pumping element, nozzle, solenoid valve.

Pumping element

The pumping element is operated by a rocker arm governed directly by the cam of the camshaft.

The pumping element is able to ensure a high delivery pressure. The return stroke is made by means of a return spring.

Nozzle

Garages are authorized to perform fault diagnosis solely on the entire injection system and may not work inside the injector-pump, which must only be replaced.

A specific fault-diagnosis program, included in the control unit, is able to check the operation of each injector (it deactivates one at a time and checks the delivery of the other five).

Fault diagnosis makes it possible to distinguish errors of an electrical origin from ones of a mechanical/hydraulic origin. It indicates broken pump-injectors.

It is therefore necessary to interpret all the control unit error messages correctly.

Any defects in the injectors are to be resolved by replacing them.

Solenoid valve

The solenoid, which is energized at each active phase of the cycle, via a signal from the control unit, controls a slide valve that shuts off the pumping element delivery pipe.

When the solenoid is not energized, the valve is open, the fuel is pumped but it flows back into the return pipe with the normal transfer pressure of approximately 5 bars.

When the solenoid is energized, the valve shuts and the fuel, not being able to flow back into the return pipe, is pumped into the nozzle at high pressure, causing the needle to lift.

The amount of fuel injected depends on the length of time the slide valve is closed and therefore on the time for which the solenoid is energized.

The solenoid valve is joined to the injector body and cannot be removed.

On the top there are two screws securing the electrical wiring from the control unit.

To ensure signal transmission, tighten the screws with a torque wrench to a torque of 1.36 – 1.92 Nm (0.136 – 0.192 kgm).


775010 Replacing injectors-pump

Injectors have to be replaced with great care (for their removal see the description on pages 45 and 46, for fitting them see the description on pages 88 and 89).



If this job is done with the engine on the vehicle, before removing the injectors-pump drain off the fuel contained in the pipes in the cylinder head by unscrewing the delivery and return fittings on the cylinder head.

Figure 226




For each injector replaced, hook up to the MODUS station and, when asked by the program, enter the code punched on the injector (→) to reprogram the control unit.



When checking the clearance of the rocker arms, it is important to check the injector-pump pre-load.

Injector Phases

Figure 227



60669

1. Fuel valve - 2. Pumping element - 3. Fuel outlet -
4. Filling and backflow passage

Filling phase


During the filling phase the pumping element (2) runs up to the top position.

After passing the highest point of the cam, the rocker arm roller comes near the base ring of the cam.

The fuel valve (1) is open and fuel can flow into the injector via the bottom passage (4) of the cylinder head.

Filling continues until the pumping element reaches its top limit.

Figure 228



1. Fuel valve - 2. Pumping element - 3. Fuel outlet -
4. Filling and backflow passage


Injection phase

The injection phase begins when, at a certain point in the down phase of the pumping element, the solenoid valve gets energized and the fuel valve (1) shuts.

The moment delivery begins, appropriately calculated by the electronic control unit, depends on the working conditions of the engine.

The cam continues with the rocker arm to push the pumping element (2) and the injection phase continues as long as the fuel valve (1) stays shut.

Figure 229



1. Fuel valve - 2. Pumping element - 3. Fuel outlet -
4. Filling and backflow passage

Pressure Reduction phase

Injection ceases when the fuel valve (1) opens, at a certain point in the down stroke of the pumping element, after the solenoid valve gets de-energized.

The fuel flows back through the open valve (1), the injector holes and the passage (4) into the cylinder head.

The time for which the solenoid valve stays energized, appropriately calculated by the electronic control unit, is the duration of injection (delivery) and it depends on the working conditions of the engine.

**Hydrocar pressure take-off
on timing system**

	Page
HYDROCAR PRESSURE TAKE-OFF ON TIMING SYSTEM - P.T.O. (OPTIONAL)	225
☐ Description	225
SPECIFICATIONS AND DATA	226
TIGHTENING TORQUES	227
ENGAGING POWER TAKE-OFF	228
REMOVING-REFITTING POWER TAKE-OFF ..	228


HYDROCAR PRESSURE TAKE-OFF ON TIMING SYSTEM - P.T.O. (OPTIONAL)

Description

This power take-off has one axle, moving by gears and engaging by a clutch that takes the drive from the gears of the timing system irrespective of the vehicle's clutch. It can be used with the vehicle either stationary or running and for continuous use it can be turned on/off with the engine running.

The PTO can be in the version for direct pump connection or with a flange for a universal shaft.

Figure 1




71835

A. ISO pump connection - 4 holes (option 5367) - B. DIN 10 flange connection (option 6366)

SPECIFICATIONS AND DATA


Figure 2



71836

P.T.O.* with ISO 4-hole pump connection (option 5367)

Figure 3



71837

P.T.O.* with DIN 10-hole flange connection (option 6366)

Weight (with flange connection)	kg	13
Weight (with pump connection)	kg	16
Transmission ratio to P.T.O.*		1/1.14
Direction of rotation		opposite to engine
Control		pneumatic
Max. continuous torque available	Nm	600


* P.T.O. = Power Take-Off



The engine speed, when taking off the maximum permissible torque of 600 Nm, must never be less than 1200 rpm.

TIGHTENING TORQUES

Figure 4




71838

	DESCRIPTION	TORQUE	
		Nm	(kgm)
1	Flanged head screw M10 × 1.5 × 120	53 ± 2.7	(5.3 ± 0.27)
2*	Flanged head screw M10 × 1.5 × 120	53 ± 2.7	(5.3 ± 0.27)
3	Screw M10 × 1.5 × 150	53 ± 2.7	(5.3 ± 0.27)
4	Screw fixing DIN flange	140 ± 5	(14 ± 0.5)
5	Nut fixing pump	85 ± 5	(8.5 ± 0.5)
6	Screw fixing pump flange	115 ± 5	(11.5 ± 0.5)

* Apply LOCTITE 275

ENGAGING POWER TAKE-OFF

Figure 5



71839


On turning the control knob **A** onto **I**, the air reaching the fitting **1** passes through the control valve **B** and from the fitting **2** supplies the clutch of the power take-off **C**, thereby making it possible for the drive to pass from the gears of the timing system to the P.T.O. The control knob **A** is in this phase locked on position **I**.

When turning off the power take-off, turning in the opposite direction, the knob locks and automatically returns onto **0**.

REMOVING-REFITTING POWER TAKE-OFF

Removal

Figure 6



71840


Disconnect the fitting (1) of the oil delivery pipe and the air fitting (2) of the clutch engagement control. Unscrew the eight fixing screws (3) and take off the power take-off (4).

Refitting



Perform these steps in reverse order, tightening the fixing screws to the required torque.

Figure 7



71772

To refit the PTO, both when replacing it and when reusing the previous one, it is necessary to replace the gasket.

Until the power take-offs are provided with plates stating the necessary dimension to calculate the correct thickness of the gasket, it is necessary to fit the gaskets of 1 ± 0.5 mm provided in kit form and overlap them.

This is to make the gears engage correctly.

In the future the power take-offs will have a plate stating a dimension that, when added to the one punched on the flywheel cover and using a specific table, will make it possible to calculate the type of gasket to fit exactly.

SECTION 3**Clutch**

	Page
DESCRIPTION	3
☐ Clutch	3
CHARACTERISTICS AND DATA	3
DIAGNOSTICS	6
TIGHTENING TORQUES	9
TOOLS	9
REMOVING AND REFITTING THE CLUTCH ..	10
☐ Removal	10
CHECKS	10
☐ Refitting	11
REMOVING-REFITTING THE THRUST BEARING	11
REPLACING THE SUPPORT BEARING OF THE CLUTCH SHAFT	11
REMOVING-REFITTING THE PEDAL UNIT	12
☐ Removal (vehicles with EuroTronic Automated gearbox)	12
☐ Removal (vehicles with ZF 16 S... gearbox)	13
☐ Refitting	14
PEDAL	14
UNIT REMOVAL-ASSEMBLY	14
CHECKING AND ADJUSTING STOPS ON CLUTCH PEDAL	15
HYDRAULIC CONTROL (VEHICLES WITH ZF 9 S 109 - ZF 16S 151/181/221 GEARBOXES)	16
CLUTCH ACTUATOR FOR ZF 16 S 151/181/221 GEARBOXES	17
☐ Fitting and adjusting the clutch wear indicator ..	17
PUSH ROD ADJUSTMENT	18

Page

☐ Operator cylinder (new clutch)	18
---	----

BLEEDING CLUTCH CIRCUIT	18
-----------------------------------	----

CLUTCH ACTUATOR FOR EUROTRONIC AUTOMATED GEARBOX	19
---	----

☐ Clutch actuator push rod adjustment (new clutch)	19
--	----







☐ Fitting the clutch actuator	19
--	----

☐ Replacing the clutch actuator	19
--	----





DESCRIPTION**Clutch**

For vehicles with transmission ZF 9S 109 - ZF 16S 151/181, the control is hydro-pneumatic and includes the main cylinder with incorporated oil reservoir and the clutch actuator. For vehicles with EuroTronic transmission, the clutch control is pneumatic and controlled by the gearshift electronic control unit







CHARACTERISTICS AND DATA

16" CLUTCH - With gearbox ZF 9S 109 - 16 S 151			
	Type		Single plate, dry
	Engagement mechanism		Pull actuated with diaphragm spring
	Driven plate		With friction linings
	Driven plate hub		With double flexible coupling
	Outside Ø of linings	mm	400
	Inside Ø of linings	mm	235
	Plate thickness (new)	mm	10 ± 0.3
	Driven plate max. run-out approx	mm	~ 0.2
	Loaded minimum on new disc-pushers	N	25000
	Loaded maximum with release	N	6950
	Minimum pressure plate lift	mm	1.7
	Withdrawal travel	mm	$12 + 2$
	Max. wear travel	mm	16
	Clutch control		Master cylinder with oil tank incorporated - slave cylinder with total take-up of driven plate wear
	Type of fluid		Tutela TRUCK DOT SPECIAL

CHARACTERISTICS AND DATA**16" CLUTCH - With gearbox EuroTronic 12 AS 2301**

	Type		Dry single plate
	Engagement mechanism		"Pull" with diaphragm spring
	Driven disc		With friction seal
	Driven disc hub		With double flexible coupling
	Seal outer Ø	mm	1
	Seal inner Ø	mm	220 ± 1
	Plate thickness (new)	mm	10 ± 0.3
	Max. off-centering of driven plate	mm	~ 0.2
	Load on thrust plate (new)	Min. N Max. N	27000 29700
	Loaded maximum with release (new)	N	6200
	Minimum rise thrust pad	mm	1.7
	Disengagement stroke	mm	12 ± 2
	Maximum depression stroke	mm	16
	Hydraulic operating system		Electro-pneumatic actuator controlled by the gearbox control unit

CHARACTERISTICS AND DATA

17" CLUTCH			
	Type		Dry single disc
	Engagement mechanism		Pull with diaphragm spring
	Driven disc		With friction linings
	Driven disc hub		With double torsion springs
	Gasket outside Ø	mm	430
	Gasket inside Ø	mm	240
	Disc thickness (new)	mm	10 ± 0.3
	Max. offset driven disc	mm	~0.4
	Load on thrust plate (new)	Min. N	33000
		Max. N	39200
	Loaded minimum on new disc-pusher	N	7600
	Minimum pressure plate lift	mm	1.7
	Disconnection stroke	mm	12
	Consumption stroke max.	mm	16
	Clutch control with gearbox ZF 9 S 109 - ZF 16 S 151/181/221		Master cylinder with oil reservoir built in – clutch actuator with total wear recovery of driven disc
	Type of oil		Tutela TRUCK DOT SPECIAL
	Clutch control with Euro Tronic gearboxes		Electro-pneumatic actuator controlled by the gearbox control unit

DIAGNOSTICS


Main operating faults in the clutch :

- 1 - Noise when the clutch pedal is depressed.
- 2 - Noise when the pedal is released
- 3 - The clutch snatches


- 4 - The clutch does not disengage
- 5 - The clutch slips
- 6 - Abnormal wear of driven plate linings.



For any actuator operation failure, on vehicles fitted with EuroTronic transmission, see the related transmission diagnosis.



3

THE CLUTCH SNATCHES

Oil or grease on engine flywheel or on driven plate linings

- YES →

Eliminate the problem causing the contamination; clean flywheel thoroughly then replace driven plate

NO



Pressure plate distorted

- YES →

Replace the clutch.

NO



Uneven wear of friction linings due to run-out of driven plate

- YES →

Replace the driven plate.

NO



Diaphragm spring weak or fingers broken

- YES →

Replace the driven plate.

4

THE CLUTCH DOES NOT DISENGAGE

Oil or grease on driven plate linings.

- YES →

Replace the driven plate.

NO



Transmission input spline damaged thus preventing driven plate from sliding

- YES →

Replace the shaft and also the driven plate if necessary

NO



Air in the hydraulic circuit (vehicles with EuroTronic transmission excluded).

- YES →

Bleed the circuit.

5

THE CLUTCH SLIPS

Driven plate linings worn or burnt

- YES →

Replace the driven plate.

NO



Diaphragm spring weak or fingers broken

- YES →

Replace the clutch.

NO



Oil or grease on driven plate linings.

- YES →

Eliminate the problem causing the contamination and replace driven plate

6

**ABNORMAL WEAR OF
DRIVEN PLATE LININGS**

Driver resting his foot on the clutch pedal while driving

- YES →

Driver must avoid the harmful habit and rest his foot on the clutch pedal only when necessary

NO



Disc ring strained.

- YES →

Replace disc ring.

NO



Diaphragm spring with weakened or broken fingers

- YES →

NO







Insufficient operator cylinder stroke.

- YES →

TIGHTENING TORQUES

PART	TORQUE	
	Nm	(kgm)
Flanged hex screw fixing pressure plate to flywheel	46.5 ± 4.5	(4.65 ± 0.45)
Nut for stud bolt fixing clutch casing to crankcase	46	(4.6)
Stud bolt fixing clutch casing to crankcase	19	(2)


TOOLS

TOOL NO.	DESCRIPTION
99306010 	Tool to bleed air from hydraulic clutch circuit
99348004 	Universal extractor, internal from 5 to 70 mm
99370264 	Guide pin to centre clutch disc
99370547 	Mount for removing and refitting clutch assembly (to fit onto the hydraulic jack)


505210 REMOVING AND REFITTING THE CLUTCH**Removal**

This operation comprises:


- ☐ Removing-refitting propeller shafts (see relevant section 505620).
- ☐ Removing-refitting gearbox (see relevant section 530210).

Figure 1

Insert the clutch centring pin 99370264 (1) into the bearing for the gearbox input shaft.

Figure 2

Fit the mount 99370547 (1) on the hydraulic jack and apply the mount to the pressure plate (3). Unscrew the screws (2) and remove the pressure plate from the engine flywheel.

Figure 3

Take out the clutch plate (2) together with the centring pin 99370264 (1).

CHECKS

The checks to make are as follows:

- ☐ The supporting surface of the driven disc, on the engine flywheel, must not be particularly worn or have too much scoring.
- ☐ The toothing of the ring gear of the engine flywheel must be neither deteriorated nor too badly worn.

If this is not the case, remove the engine flywheel (operation 540850).

In addition, check there is not even the slightest leakage of lubricant from the seal of the crankshaft rear cover: in which case, remove the flywheel as described under the relevant heading. Remove the rear cover together with the seal and replace it as described in section 2.

Check that the bearing or bushing supporting the gearbox input shaft mounted on the crankshaft is neither worn nor deteriorated, in which case it should be replaced.

Check the state of the pressure plate, the supporting surface of the driven disc must have no deformation, wear or sign of overheating and its spring or diaphragm must be sound.

Check the state of the driven disc:

- ☐ the friction linings must not be too worn, nor have any sign of overheating, nor be fouled with oil or grease.
- ☐ its hub must not have too much play on the gearbox input shaft.
- ☐ the torsion springs of the hub must not turn in their seats or be broken.


If you find any trouble at all, replace the part concerned. The clutch assembly is supplied as a spare in kit form.

The following are supplied singly:

- ☐ The driven disc and the thrust bearing.

In this case it is necessary to mount the new parts of the same supply as the torsion spring being reused.

Figure 4




Before fitting a new driven disc it is necessary to check its centring as follows:

Position the driven disc (1) on a lathe. Then, with the aid of a dial gauge with a magnetic base (2), check that the surface of the disc is not off centre anywhere.

The maximum permissible eccentricity of the driven disc is 0.20 mm.

Figure 5



If the disc is off centre, use a fork wrench (1) as shown in the figure.

Refitting


Fit the clutch assembly back on by performing the operations described for removal in reverse order and observing the following instructions:



- ☐ Thoroughly clean the supporting surface of the clutch plate of the engine flywheel with spirits or petrol. Any light scoring you find on it can be removed with abrasive cloth.
- ☐ Position the driven disc, always using the guide pin for perfect centring to prevent harmful stresses on the hub when refitting the gearbox.
- ☐ Position the clutch plate by matching the holes for the fixing screws with the ones on the engine flywheel.
- ☐ Mount and lock the fixing screws of the pressure plate to the required torque.
- ☐ Fit the gearbox back on after spreading the splined shaft with Molikote molybdenum disulphide grease.
- ☐ Adjust the push rod of the operator cylinder as described under the relevant heading (operation 505272).

505254 REMOVING-REFITTING THE THRUST BEARING

Figure 6



This operation comprises:

- ☐ Removing-refitting propeller shafts (see relevant section 505620).
- ☐ Removing-refitting gearbox (see relevant section 530210).

Using suitable pliers, open the snap ring (1), take the thrust bearing (2) out of the pressure plate.


Reverse these steps for fitting.



The new part has to be of the same supply as the pressure plate being reused.

540852 REPLACING THE SUPPORT BEARING OF THE CLUTCH SHAFT

Figure 7



This operation comprises:


- ☐ Removing-refitting propeller shafts (see relevant section 505620).
- ☐ Removing-refitting gearbox (see relevant section 530210).
- ☐ clutch removal/refitting (operation 505210).

Using the appropriate pliers remove the split ring.


Using the universal extractor 99348004 (1) remove the bearing (2).

For refitting, use the appropriate beater.


Refit the split ring.

502601 REMOVING-REFITTING THE PEDAL UNIT**Removal (vehicles with EuroTronic Automated gearbox)****Figure 8**


Remove the push-button panels (3 and 5) and the screw caps (4) from the instrument panel (1). Take out the screws (2 and 4), remove the instrument panel (1) and put it aside.

Figure 9


Disconnect the connections (1) of the windscreen wiper, (2) of the drive control system and (3) of the immobilizer.

Figure 10


Take out the screws (2), remove the heel rest (1) and lift the mat (3).

Figure 11

Remove the screws (1 and 3) and the guard (2).


Figure 12

Disconnect the piping (2). Take out the screws (3) and disconnect the steering control mount (1) from the pedal unit (4).

Figure 13


From outside the cab, lift the radiator cowl, extract the grommet (1) with the wiring from the pedal unit (7). Disconnect the piping (5) from the coupling (6). Disconnect the electric connections (2 and 3) from the control valve (4).

Figure 14



Take out the screws (4) fixing the cover (5) of the control valve (6). Gradually lift the cover (5) to discharge the pressurized air in the system. Take out the screws (1-3) fixing the wiring clamps (2) and pedal unit to the cab.

Figure 15




Take out the screw (2) fixing the bracket (1) supporting the piping and wiring and disconnect the pedal unit from the cab.

Removal (vehicles with ZF 16 S... gearbox)


This differs from removing the pedal unit on vehicles with the EuroTronic Automated gearbox in the following.

Figure 16




Disconnect the steering control mount as described in figures 8 – 9 – 10 – 11 – 12. Remove the bracket (1) stopping the clutch pedal. Take out the screws (2) fixing the master cylinder to the pedal unit.

Figure 17




Remove the bracket (1) stopping the brake pedal. Take out the three screws (2) fixing the control valve to the pedal unit.

Figure 18



Lift the radiator cowl, disconnect the piping (3-4) from the splitter control button (5). Disconnect the electric connection (1) of the master cylinder (2) and remove this, together with the oil reservoir, from the pedal unit (6). Complete disconnecting the pedal unit as described in figures 13 – 14 – 15.

Refitting**Figure 19**

For refitting, carry out the steps described for removal in reverse order. Then adjust the travel of the pedals as described under the relevant heading.



With each removal, the seals (1) of the coupling of the control valve cover (2) have to be replaced with new ones.

Tighten the screws and nuts to the required torque. After refitting, check and if necessary adjust the travel of the pedal as described under the relevant heading.

PEDAL**Unit removal-assembly****(see Figure 20)**


Take out the springs (11) to return the pedals (13*-15). Eject the spring pins (7) so as to free the levers (1* and 2) from the pedals (13* and 15), which you should then extract from the pedal unit mount (18). To replace the roller bearings (9), use:

- ☐ the percussion extractor 99340205 to remove them;
- ☐ a suitable drift to fit them.



The roller bearings and associated shafts have to be lubricated with TUTELA MR3 grease.

Complete assembly by carrying out the steps performed for removal in reverse order.

Figure 20


38808

1. Brake control lever – 2. Clutch control lever* – 3. Roller bearings – 4. Pin – 5. Fork – 6. Master cylinder* – 7. Spring pin – 8. Splitter control button* – 9. Roller bearings – 10. Washer – 11. Return spring – 12. Pedal cover – 13. Clutch pedal – 14. Control valve – 15. Brake pedal – 16. Brake pedal limit stop screw – 17. Brake pedal stop bracket – 18. Pedal unit mount – 19. Clutch pedal stop bracket – 20. Clutch pedal limit stop screw*

* Excluding vehicles with the EuroTronic Automated gearbox.

CHECKING AND ADJUSTING STOPS ON CLUTCH PEDAL (vehicles with ZF 9S 109 - ZF 16S 151/181/221 gearboxes)

Figure 21



39696

Clutch stop

Check the distance **A** between the pedal unit mount (1) and the end of the screw (2). It has to be 32.5 mm, turn the screw appropriately if it is not.

Idle travel of clutch pedal

Work the clutch pedal (8) to take the cap (6) into contact with the piston (5) of the master cylinder.

In this condition, check the distance **B** between the clutch pedal (8) and the screw (7) that has to be 1 - 2 mm, turn the screw (7) appropriately if it is not.

The distance **B** corresponds to the clearance of 0.5 - 1 mm between the cap (6) and the piston (5) in the condition of the clutch pedal (9) in contact with the screw (7).

Pedal control valve stroke

After adjusting the position of the bottom and top stop, adjust the travel of the piston of the pedal control valve (in the case of the ZF gearbox).

Take the clutch pedal (8) into contact with the bottom stop screw (2) and keep it in this position.

Press the button of the control valve (3) fully down and, keeping it pressed, position the angle bracket (4) so that between it and the button there is a distance of 0.5 - 1 mm.

This is to prevent the pedal control valve from stopping the clutch pedal.

HYDRAULIC CONTROL (Vehicles with ZF 9 S 109 - ZF 16S 151/181/221 gearboxes)

The hydraulic control is composed of:

- ☐ master cylinder with oil reservoir built in;
- ☐ clutch actuator with full recovery of driven disc wear.

Figure 22






Figure 23



85484

Figure 24



VIEW OF THE MASTER CYLINDER


CLUTCH ACTUATOR SECTION
FOR GEARBOX ZF 9S 109

CLUTCH ACTUATOR SECTION
FOR GEARBOX ZF 16S 151/181/221

5052 CLUTCH ACTUATOR FOR ZF 16 S 151/181/221 GEARBOXES


Fitting and adjusting the clutch wear indicator

Figure 25




Take out the plastic rod, rubber seal and metal clamp.
Turn the "worn clutch" mark (3) on the new actuator from the rest position to 90° anticlockwise or clockwise; it depends on the clutch supplier.
Position 1: wear/travel (Valeo) 25 mm.

Figure 26




Insert the plastic rod (1) against the actuator clamp.
Push the seal (2).

Figure 27




Retract the plastic rod (1) away from the actuator, the rubber seal (2) must not move.
Lock the seal (2) with the metal clamp (3).

Figure 28



Cut off the rear section of the plastic rod (1).

Figure 29



Insert the plastic rod (1) as far as the actuator clamp.




When the clutch plate wears, the plastic rod moves towards the mark.
If replacing the clutch, it is necessary to mount a new wear indicator KIT, setting it as described above.



Should any oil leaks from the main cylinder and/or the clutch actuator be detected, replace the involved component and bleed the hydraulic system.

505272 PUSH ROD ADJUSTMENT Operator cylinder (new clutch)

Figure 30



Carry out the following operations:
Measure the distance (A) between the bottom of the spherical cavity of the clutch lever and the actuator fixing surface. Press the spherical push rod to reach the stop (C).

Loosen the nut (D).

Screw or unscrew the push rod (F) to obtain the distance (B).

$$B = A - E$$

E = 26 mm (VALEO or BORG & BECK clutch)

E = 30 mm (FICHTEL & SACHS clutch)




It is necessary to observe this adjustment to make the worn plate indicator trip, which is located in the operator cylinder, close to the complete wear of the friction linings.

The plate wear (90% of the friction material) is indicated by a significant increase in load on the pedal when disengaging the clutch.

BLEEDING CLUTCH CIRCUIT


Figure 31



Bleed air from clutch hydraulic circuit after repairing clutch assembly or following periodic oil changes. Use air remover 99306010 for this purpose as follows:

- ☐ introduce compressed air into reservoir (5);
- ☐ fill reservoir (4) with Tutela TRUCK DOT SPECIAL fluid;
- ☐ replace clutch reservoir cover ($\Rightarrow$) with one of those provided with device 99306010 and connect device line to cover.

Figure 32



- ☐ apply a plastic pipe to bleed screw (2) of slave cylinder (I) and immerse the opposite end of the pipe in a recipient containing Tutela TRUCK DOT SPECIAL fluid. Undo bleed screw (I) by one turn, open (see Figure 31) cock (2) until pressure gauge (3) shows a reading of $1 \pm 1,2$ bars;
- ☐ when clutch fluid emerging from circuit is free of bubbles, tighten bleed screw and drain air from device reservoir (5) through valve (6).




When clutch fluid is changed, bleed master cylinder by loosening fitting (I, Figure 31) before bleeding clutch servo.

5052 CLUTCH ACTUATOR FOR EUROTRONIC AUTOMATED GEARBOX

505272 Clutch actuator push rod adjustment (new clutch)

Figure 33



The operator cylinder is equipped with a device to automatically recover the clearance due to the wear of the clutch plate. Therefore, it must only be adjusted when replacing the clutch plate or the clutch actuator (6).

Push the lever (1) down fully so as to cancel the disengaging travel with no load.

In the above conditions, measure the distance (A) between the bottom of the spherical cavity of the clutch lever and the clutch actuator (6) fixing surface of the box (2).

Extract the push rod (composed of parts 3, 4, 5) from the clutch actuator (6).

Unscrew the plug (7) to discharge the air under pressure from the piston so that the spring inside the working piston moves forwards as far as the stop.

Measure the distance B = distance between the front edge of the tapered front portion of the clutch actuator (6) and the fixing surface of the actuator.

Measure the distance C = depth of the tapered front portion of the piston.

Measure the length L of the push rod that has to be:

$$L = A - (B - C) + D$$

A-B-C = measurements made

D = 33 mm, fixed value of the maximum stroke of the actuator.

If you find a different value, loosen the nut (4) and use parts (3 and 5) to obtain the calculated length.

Tighten the nut (4) to a torque of 52 Nm (5.2 kgm) and fit the push rod back into the actuator (6).

Fitting the clutch actuator

Discharge the air under pressure from the actuator (6) by unscrewing the plug (7).

Move the piston of the actuator (6) back, overcoming the reaction of the spring, as far as its stop.

Screw the plug (7) back on to keep the piston in the retracted position.

Lubricate the spherical cavity of the lever (1) with TUTELA MR2 and position the push rod (3) in it.

Fasten the clutch actuator (6) to the front box (2), checking that the push rod (3) goes inside correctly and tighten the nuts to the required torque.

Unscrew the plug (7) so that the internal spring of the actuator (6) pushes the piston forwards and tighten the plug (7) to the required torque.

Hook up the electrical connector and the compressed air supply pipe.

Replacing the clutch actuator

Not having to replace the push rod (3), mount the new actuator as described in the above paragraph, without altering the distance L of the push rod (3).



Before connecting the air pipe, check that the clutch actuator (6) is correctly secured to the front box (2).



Lubricate the indicated points (→) with TUTELA MR2.

SECTION 4**5302 Gearboxes**

ZF 9 S 109 D.D.	I-42
ZF 16 S 151 D.D. - ZF 16 S 181 D.D./O.D. - ZF 16 S 221 D.D.	43-94
ZF 16 S 151 D.D. - ZF 16 S 181 D.D./O.D. - ZF 16 S 221 D.D. with intarder.	95-112
EUROTRONIC 12 AS 2301 D.D./O.D.	113-158
EUROTRONIC 12 AS 2301 D.D./O.D. with intarder	159-172
ALLISON MD 3060 PR - ALLISON MD 3066PR	173-196
EXTERNAL CONTROL	197-204
POWER TAKE-OFF	205-232
POWER TAKE-OFF	233-252

5302 Gearbox ZF 9 S 109 D.D.

	Page
GENERAL SPECIFICATIONS	3
☐ Description	3
SPECIFICATIONS AND DATA	5
DIAGNOSTICS	8
TIGHTENING TORQUE	11
EQUIPMENT	12
REMOVAL	15
☐ Removing the E.R.U.box	15
☐ Re-assembling the E.R.U.box	15
DISASSEMBLING THE E.R.U. BOX	16
DISASSEMBLING THE E.R.U.	16
CHECKS	18
ASSEMBLING THE E.R.U.	20
ASSEMBLING THE E.R.U.BOX	21
DISASSEMBLING THE GEARBOX	23
REMOVING THE INPUT SHAFT	26
REMOVING THE MAIN SHAFT	26
REMOVING THE TRANSMISSION SHAFT	29
REMOVING THE GEARCHANGE CASE OF GEARBOX	29
OIL PUMP	31
CHECKS	32
ASSEMBLING THE GEARCHANGE CASE	32
ASSEMBLING THE TRANSMISSION SHAFT	34
ASSEMBLING THE INPUT SHAFT	37
ASSEMBLING THE GEARBOX	37
ADJUSTING THE TRANSMISSION SHAFT BEARINGS	39
☐ Adjusting the main shaft bearings	40

GENERAL SPECIFICATIONS

Description of gearbox 9 S 109 D.D.

Gearbox ZF 9 S 109 D.D. is mechanical type with synchronized gear engagement, with the exclusion of pick up gear and reverse gear, featuring front engagement.

It is made up of a part featuring 4 forward gears with reverse gear, a pick up gear and a Epicyclic Reduction Gear Unit of planetary gears type on the rear part.

The E.R.U. unit (Epicyclic Reduction Gear Unit) enables splitting the number of gears of the four speed gearbox, thus, nine forward gears are available, pickup gear included, that can be engaged in sequence

The control is fitted with an air-operated "servoshift" device to improve speed selection and engagement.


The servoshift is a device comprising a mechanical/pneumatic module and a double-acting cylinder.

The advantages of this device are:

- ☐ Faster speed selection and engagement with less effort.
- ☐ It cushions the vibrations of the control linkage, reducing noise.
- ☐ Less synchronizing device stress.

The device works mechanically if the pneumatic system breaks down.


Figure 1



39464

LONGITUDINAL SECTION VIEW OF GEARBOX 9 S 109 D.D.

Figure 2







30980

GRAPHIC REPRESENTATION OF THE PNEUMATIC SYSTEM TO CONTROL THE E.R.U. IN GEARBOX 9 S 109 D.D.



Gearshifting in the four forward speed and pickup speed part and that in the E.R.U. is through double H mechanical control. E.R.U. switching is through pneumatic system when III-IV speed position is changed into that for V-VI speed selection or viceversa. The control system to switch the E.R.U is made up of a control valve (8) and a control cylinder (5) integral with the gearbox. The control valve (8) is controlled by the shaft (6), lets the air under pressure go through to feed the cylinder (5) only when the shaft (6) is in neutral position.

SPECIFICATIONS AND DATA






	GEARBOX	ZF 9 S 109 D.D.
	Type	Mechanical
	Gears	9 forward gears and 1 reverse gear
	Control for the four main gears E.R.U* control	Mechanical type Pneumatic type
	Power take off	On request
	Gear Engagement: 1 st - 2 nd - 3 rd - 4 th speeds and E.R.U. Pickup speed and Reverse speed Disengagement protection	Freering synchronizer Fast engage type Sliding sleeves locked by rollers and springs
	Gears	Helical toothing

E.R.U * = Epicyclic Reduction Gear Unit

SPECIFICATIONS AND DATA

		ZF 9 S 109 D.D.
	Gear ratios	
	Pickup speed	12.91
	First speed	8.96
	Second speed	6.37
	Third speed	4.71
	Fourth speed	3.53
	Fifth speed	2.54
	Sixth speed	1.81
	Seventh speed	1.34
	Eighth speed	1
	Reverse speed	12.20
	Type of Oil Quantity	Tutela Truck FE-Gear Tutela ZC 90 7.2 Kg. (8 lt)
	Bearings of main shaft and transmission shaft	Tapered Rollers
  	Assembling temperature for the transmission shaft gears	160 ÷ 180 °C
E.R.U.* = Epicyclic Reduction Gear Unit		

SPECIFICATIONS AND DATA


	Assembling temperature for fixed hubs and main/transmission shaft bearings	$\sim 100\text{ }^{\circ}\text{C}$
	Axial backlash: bearing in the E.R.U.* spider shaft split ring in the fixed hub of the E.R.U.* spring retaining ring of the shaft bearing spider in the E.R.U. spring retaining ring of the transmission shaft bearing	$0 \div 0.1\text{ mm}$
	Axial backlash for input shaft, first, 2nd, 3rd and 4th speed gear.	$0.2 \div 0.45$
	Axial backlash between spider shaft and planetary gears in the E.R.U.	$0.1 \div 0.7$
	Axial backlash for the bearings in main and transmission shafts at input side.	$0.18 \div 0.30$
	Value to check wear of: synchronizer rings for: - 1st/2nd/3rd/4th speed - splitter - - E.R.U.*	$\geq 0.8\text{ mm}$ $\geq 1.2\text{ mm}$
	Axial backlash for the reverse speed transmission gear	$0.2 \div 0.6$

E.R.U.* = Epicyclic Reduction Gear Unit

DIAGNOSTICS

Main operating troubles of the gearbox are the following:

- 1 - Noise
- 2 - Spontaneous speed disengagement and uneven engagement
- 3 - Difficult and bound speed engagement
- 4 - Faulty or inefficient pneumatic system



3

DIFFICULT AND BOUND GEAR ENGAGEMENT

Rod forks bound.

- YES →

Remove the gearbox and find cause of binding; carry out the required repair operations.

NO



Move of sliding sleeves hindered.

- YES →

Check and repair.

NO



Not suitable type of oil in the box.

- YES →

Drain the oil and fill with **Tutela ZC 90** or **Tutela Truck Fe-Gear** oil.

NO



Clutch engagement missing.

- YES →

Adjust or replace the control device.

4

PNEUMATIC CONTROL SYSTEM FAULTY OR INEFFICIENT *

Air pipe fittings faulty

- YES →

Check pipe fittings and replace where required.

NO



Air pipe bent and/or squeezed.

- YES →

Replace the pipe.


NO



Air leaks from the pipe

- YES →







Check that there are no leaks from pipes and pipe fittings; use an acoustic tester or suds. Replace or seal where required.









* Checks are to be carried out with the engine off and air tanks filled up.



TIGHTENING TORQUE

DESCRIPTION	TORQUE	
	Nm	Kgm
Hexagonal head screw M5	6	(0.6)
Bleeder in the gearbox	10	(1)
Diaphragm in the disengaging valve (according to version)	20	(2)
Hollow screws M 10 x 1 in "tecalan" pipes	20	(2)
Hexagonal screws M 8	25	(2.5)
Hollow screws M 12x 1.5 in "tecalan" pipes	35	(3.5)
Locking screws M 14 x 1.5 in the gearbox	38	(3.8)
Hollow screws M 14 x 1.5 in "tecalan" pipes	38	(3.8)
Locking screws M 16 x 1.5 in gear box and control box	45	(4.5)
Pressure switches in gearbox and covers	45	(4.5)
Safety nuts M10 x 1 in linkage and ball joint	46	(4.6)
Hexagonal nuts M 10 or hexagonal head screws	49	(4.9)
Locking screws M 18 x 1.5 in gear box and control box	50	(5)
Hexagonal nuts M 12 in the bearing linkage	50	(5)
Locking stop in gearbox and control box	50	(5)
Locking screw M 24 x 1.5 9 (bevel) in the gearbox	50	(5)
Pulse transmitter for the tachometer	50	(5)
Driving torque for the hexagonal head screws M 12 in the output flange	60	(6)
Hexagonal head screws M 12	86	(8.6)
Magnetic screw plug M 38 x 1.5 in the gearbox	140	(14)
Knuckle screw in the gearbox control case	160	(16)
Safety nut M 16 x 1.5 in splitter and epicyclic unit pistons	180	(18)
Knuckle screws for the epicyclic reduction gear unit	180	(18)

EQUIPMENT	
TOOL NO.	DESCRIPTION
99322205	 Revolving stand for overhauling units
99322225	 Units holder (to be used with stand 99322205)
99345097	 Thrust block for pullers
99347101	 Puller, large size (to be used with relevant special rings)
99347148	 Ring grips to remove fixed sleeves of 1st - 2nd speed (to be used with 99347101)
99360502	 Eyebolt to lift the reduction gear and transmission shaft box

EQUIPMENT	
TOOL NO.	DESCRIPTION
99370006	 Handle for interchangeable drivers
99370113	 Driver to fit the bushes in the gear control cover
99370449	 Hook to lift the main shaft
99370465	 Tool to set the safety plates of output flange screws
99370629	 Support for holding the gearbox during removing/refitting from/on vehicle
99371052	 Brackets to hold the gearbox during overhaul (to be used with 99322205-9932225)


EQUIPMENT

TOOL NO.	DESCRIPTION	
99374357		Connection tool for assembling ring. operations on front gearbox cover (to be used with 99370006)
99374139		Connection tool for assembling ring. operations on rear gearbox cover (to be used with 99370006)

533010 REMOVAL

Removing the E.R.U.box


Figure 3



Drain the lubricating oil from the gearbox and remove the side cover from the reverse speed transmission gear opening (4). Set the unit on the revolving stand 99322205 (3) c.w.support 99322225 (1) and brackets 99371048 (2).


Take note of the assembling position of pipe on the cylinder and remove the cylinder.

Figure 4




Set the gearbox vertical with the E.R.U. box turned upwards; remove the pin (1) and relevant gasket, the gear range indicator light switch (2) and relevant gasket and the ball (3).

Figure 5



Remove the nuts and screws that fasten the E.R.U box to the gearbox. Apply eyebolts 99360502 (1) to the flange, engage the eyebolts to the cables, then, use a hoister to remove the E.R.U. box (2) from the gearbox.

Figure 6




Check the conditions of planetary gears (1). If faults are found out, remove the spring retaining ring (2), set block 99345097 (6) on the main shaft (3) and use a puller (4) and clamp (5) to remove the planetary gears (1) from the main shaft (3).

Reassembling the E.R.U.box

Reverse the disassembling operations and comply with the instructions below.

If the planetary gears (1) are to be replaced, at assembling stage the new part shall be heated at 160 to 180° C for 15' and set on the main shaft (3) so that the oil holes (→) in the gear coincide with those in the shaft. Select a spring retaining ring, out of those supplied spare (2), featuring suitable thickness free from backlash when bedded in its seat. Paper and metal gaskets shall be replaced with new ones. Tighten screws and nuts to proper torque.

Figure 7



30983

After tightening to proper torque the screws to fasten flange (1) to main shaft, fit in place a new safety plate and upset tabs by use of tool 99370465 (2).


Remove the gearbox from the stand.

Install the side cover and provide it with new gasket.

Fill the gearbox with the required type and amount of oil.

DISASSEMBLING THE E.R.U. BOX

Figure 8



37594

Set the E.R.U. box on the bench. Lift the safety plate tabs (1) and remove the plate.


Remove the screws (2), the lock plate (3) and the sealing ring (4).

Withdraw the flange (6) from the E.R.U. shaft.



If withdrawing is difficult, use a puller (5) as shown in the figure.


Figure 9



37595

Disassemble the E.R.U. control cylinder (1). Remove the fork knuckle screws (2). Disengage the rod (4) from the fork and withdraw the rod from the box along with the piston (3).

Figure 10




37596

Withdraw the box (1) from the E.R.U. unit (2). Remove the cover (3), overturn the case and remove the bearing (5). Remove the tachometer transmission control (4).

DISASSEMBLING THE E.R.U.


Figure 11



37597

Remove the sliding sleeve (7), the fork (3) and relevant sliding shoes (2). From the shaft (1), remove: gear (4); coupling element (5) and synchronizer ring (6).

Figure 12




37598

Withdraw the sliding sleeve (1) from the hub (2) and check that pins (3) and relevant springs (4) do not come out from the hub.



Take note of the assembling position of the sliding sleeve so as to prevent uncorrect assembling of synchronizer rings.


Figure 13



37599

From the shaft (1), withdraw: bearing (2) c.w. hub (3), synchronizer ring (4), crown gear (6) coupling element (5). If the operation is difficult, use suitable puller.


Figure 14



37600

Remove the spring retaining ring (2); set the block (7) on the bearing (1); use puller (6) and clamp (8) to withdraw the hub (3) and the synchronizer ring (4) from the bearing, then withdraw the coupling element (5).


Figure 15



37601

Remove the spring retaining ring (1) and remove the bearing (2) from the support (3).


Figure 16



37602

Remove the spring retaining ring (1) and separate the crown gear (2) from the support (3).

Figure 17



37603

Fit the spring caps (4) in the pins (5) and use a bronze driver to remove the pins (5) from the spider (1). From the spider, withdraw: planet gears (2) c.w. shim rings (3) and roller bearings.



If even only one planet gear is to be replaced, also the remainder four ones shall be replaced as planet gears are not supplied single as spare.

CHECKS

BOX

The E.R.U. box shall be free from cracks.

The faying surfaces between: covers, gearbox, E.R.U. box shall not be damaged.

The seats of bearings shall not be damaged nor worn out.

EPICYCLIC GEARS

The bearing seats in the epicyclic gear shaft shall not be damaged nor worn out.

Toothings of gears in the crown gear shall not be damaged nor too much worn out.


EPICYCLIC GEAR ENGAGEMENT

Hubs-sleeves-synchronizers-coupling elements-forks

Splines between hubs and sliding sleeves shall not be damaged and the sliding sleeve movement play on the hub shall not be excessive.

Dowels in the sliding sleeve shall not be too much worn out.

Figure 18



30508

Check wear of synchronizer rings and relevant coupling elements by operating as follows:

set the synchronizer ring (1) on the coupling element (2);
rotate the parts to ensure proper coupling;
use a gauge and shims (3) on two opposite points to check gap X between coupling element and synchronizer ring. If value X is less than 0,8 mm, replace the synchronizer ring and/or the coupling element.



At assembling stage, do not mistake the components with each other.

The fork shall be free from damages and relevant dowels not loose in the radial race of the sliding sleeve.

Bearings


Ball or roller bearings shall be in perfect conditions, not affected by overheating or excessive wear.

Check proper efficiency by pressing the bearings with your hand while making them rotate to both directions at the same time: move shall be smooth and free from noise.

E.R.U. PNEUMATIC CONTROL

Check perfect conditions of air pipes and also proper efficiency of the distributor valve.

Figure 19



30990

The fork control rod (1) shall not be too much worn out nor warped.

The control cylinder (7) shall not be worn out or cracked.


The piston (3) shall not be cracked nor warped.

The rings (2 and 4) shall not be too much worn out.




At assembling stage, always replace: plate, retaining rings and washers, sealing rings and grommets, springs for sliding sleeve dowels and spring caps, self-locking nuts and all parts not perfectly efficient, marked, cracked or warped. Before assembling the two-lip seals, fill the gap between the two lips with TUTELA MR3.

Figure 20




COMPONENTS IN THE EPICYCLIC REDUCTION GEAR UNIT

30991

ASSEMBLING THE E.R.U.**Figure 21**

37604


Spread the rollers (6) with grease and set them c.w.rings (4) in the seats of planet gears (5). Set the planet gears (5) and relevant thrust rings (3) in the spider (7) and use a feeler gauge to check that backlash of gears is 0.10 to 0.70 mm. In case of different value, replace the thrust rings (3). Fit the pins (2) in the spider (7) and set them so as the "0" marked on the pins is turned to the spider holes for springs caps (1). Fit the spring caps so as they are bedded 0.5 mm lower than the spider, then call.

Figure 22

37605


Fit the bearing (2) in the support (3) by making use of suitable driver (4).

Fit in place the spring retaining ring (1) and check that the axial backlash is 0 to 0.1 mm. In case of higher value, select the suitable thickness ring out of those supplied spare.

Figure 23


37602

Fit the support (3) in the crown gear (2) and lock with spring retaining ring (1).

Figure 24

37606

Fit the coupling element (2) and relevant synchronizer ring (1) in the support (3).


Figure 25

37607

Heat the hub (1) at 85°C for 15', then fit it on the support shaft (4) by making use of suitable driver.

Fit the spring retaining ring (2) and use a feeler gauge (3) to check that the ring backlash in the seat is 0 to 0.1 mm. If this is not so, select the suitable ring out of those supplied spare.


Figure 26



37608

Fit the sliding sleeve (2) to the hub (1). Fit the pins (4) and relevant springs (3) in the seats in the hub. Use suitable screwdriver to press the pins (4) and set them under the sliding sleeve (2).


Figure 27



37609

Fit in place the synchronizer ring (1) and operate to comply with what is shown in the figure, lift the sliding sleeve (2) so as to enable proper bedding of pins (4 in Figure 26) under the sliding sleeve (2).

Figure 28




37610

Fit the components on the spider (1); install the coupling element (3) and the gear (2). Then, fit in place the sliding shoes (5) and relevant fork (4) on the sliding sleeve.

ASSEMBLING THE E.R.U. BOX ADJUSTING THE AXIAL BACKLASH OF THE REAR BEARING


Figure 29



37611

Install the tachometer transmission control (3) on the box (1). Slightly heat the box near the bearing seat (2) and fit in place the bearing.


Figure 30



37612

Use a depth gauge (1) to find the bearing (2) overhang from the box level (3): value Δ .

Figure 31




37613

Set the gasket (2) in the cover (3). Rest the depth gauge (1) on the gasket and find the depth of the bearing seat: value B . Thickness S of the adjusting ring is given by:

$$S = B - (A + C)$$

where: A and B are the values found, $C = 0$ to 0.1 mm, the prescribed axial backlash.


Figure 32



37614

Fill the inner space in the sealing ring (4) with grease TUTELA MR3 and fit the ring in the cover (3) by making use of the connection tool 99374139 (2) and handle 99370006 (1).


Figure 33



37615

Set the suitable thickness adjusting ring (2) on the bearing (3) and install the cover (1).


Figure 34



37616

Fit the box (2) on the spider (1). Partially install the flange (6) so as to enable suitable box (2) bedding on the spider shaft (1). Fit the sealing ring (5), the plate (4) and tighten the screws (3) nearing them to the plate (4).


Figure 35



37617

Rest the E.R.U. on one side and tighten the screws (3, Figure 34). Check that when assembling the unit (2) in the box (1) the pins (→) suitably go through the relevant holes in the box (1).

Figure 36




37618

Fit in place the rod (1) c.w. piston and check that milling of the rod is on the fork (3). Then, tighten the screws (2) and check that they suitably go through the fork knuckle hole (3).



Screw threads shall be previously spread with sealant SPM 4G 91 I 2F.

Figure 37




37619

Fit the sealing ring (2) on the control cylinder (1), then install the cylinder in the box. Re-fit in place the E.R.U. case in the gearbox as detailed in the relevant chapter.

530210 DISASSEMBLING THE GEARBOX


Remove the E.R.U.box as shown in the relevant chapter, then remove the gearbox as detailed hereinafter.
Disassembling the gearbox.

Figure 38




Remove the backup light switch (1) and withdraw the pin (2). Remove the fork knuckle screws (3). From E.R.U.side, remove the spring retaining ring (4) that fastens the Reverse speed transmission gear shaft (5).

Figure 39




Remove the cover (1) and the adjusting ring underneath, the oil pump (2) and the adjusting ring underneath, the front cover (3) c.w. the two outer rings of bearings.

Figure 40




Remove the input shaft (1) and also the coupling element and synchronizer ring. Remove the oil filter (2).

Figure 41




From output side: use a screwdriver to set the locking lever (1) so as to push the rod (2) inward. Then remove the locking plate (3) and the bearing plate (4).

Figure 42



Remove the fork (4) c.w. sliding shoes (5) and disengage it from the rod (2). Suitably position the lever (1, Figure 41), remove the rod (2), the rods (1 and 3) after having them disengaged from relevant forks, then remove the fork for I and II speed.


Figure 43



37625

Set the gearbox vertical, with the output side turned downward. Use a punch to remove the shaft (3) from the box, then withdraw the Reverse speed transmission gear (1) c.w. the two roller bearings (2).


Figure 44



37626

Screw eyebolt 99360502 (1) to the transmission shaft (2), engage the eyebolt to a hoister, move the main shaft (3) sideways, then remove the transmission shaft from the gearbox.


Figure 45



37627

Engage hook 99370449 (1) to the main shaft (2), engage the shaft to a hoister, then remove the main shaft (2) c.w. fork (3) from the gearbox.


Figure 46



37628

Remove the spring retaining ring (1), then remove the plate (2) and the locking fork (4). Keep the spring (3).


Figure 47



37629

Withdraw the outer rings of rear bearings of main (1) and transmission (2) shafts from the gearbox.

Figure 48



37630

Remove the outer rings of the front bearings of main (3) and transmission (1) shafts from the front cover (2).

Figure 49






Figure 50




31010 REMOVING THE INPUT SHAFT**Figure 51**


Use the puller (1) shown in the figure and clamp (2) to remove the cone (3) of the taper roller bearing from the input shaft (4).




This operation is to be carried out only where the bearing is to replace.

531020 REMOVING THE MAIN SHAFT**Figure 52**


Clamp the main shaft in a vice and remove the hook 99370449. Remove the sliding sleeve (1) that engages III and IV speeds and check that springs (2), pawls (3) and small blocks (4) do not come out. Keep these components.

Figure 53

Use the puller (1) shown in the figure, the thrust block 99345097 (2) and clamp (4) to remove the cone (3) of the taper roller bearing from the main shaft (5).


Figure 54

Remove the spring retaining ring (1). Use the puller (5) with relevant grips set under the synchronizer (3) and clamp (6) to remove the ring and hub (2). Remove the coupling element (4).

Figure 55


Remove the III speed gear (1) and relevant roller bearing (2).

Figure 56




Remove the spring retaining ring (1). Use puller (8), with the handles set under the coupling element (5), the clamp (9) and the thrust block 99345097 (7) to remove the bush (2) and the gear (3) with the coupling element (5). Remove the roller bearing (4) and the synchronizer ring (6).

Figure 57




Remove the sliding sleeve (1) that engages 2nd and 1st speed and check that the pawls (2 and 4) and the spring (3) do not come out. Keep such components.

Figure 58




Use puller 99347101 (4), grips and ring 99347148 (5) to remove the hub (1) of the sliding sleeve that engages 2nd and 1st speeds. Remove the synchronizer ring (2) and the coupling element (3).

Figure 59




Remove the 1st speed gear (1) and relevant roller bearing (2).

Figure 60




Upturn the main shaft (3). Remove the spring retaining ring (1). Use the puller (4), block 99345097 (5) and the clamp (6) to remove the planet gears (2).

Figure 61




Use the puller (3), the thrust block 99345097 (4) and the clamp (5) to remove the R speed gear (2) and the cone (1) of the taper roller bearing.

Figure 62




Remove the roller bearing (1) and the sliding sleeve (2) that engages R gear and pickup gear.
Remove the spring ring (3).

Figure 64




Use the puller (4), block 993450097 (5) and the clamp (6) to remove the hub (1) for the sliding sleeve that engages R speed gear and pickup speed gear. Remove the pickup speed gear (2) and the roller bearing (3).

Figure 63



MAIN SHAFT COMPONENTS

1. Main shaft - 2. Roller bearing - 3. Pickup speed gear - 4. Hub - 5. Engagement sliding sleeve - 6. Spring ring - 7. Roller bearing - 8. Reverse speed gear - 9. Taper roller bearing - 10. Planet gears - 11. Pipe - 12. 1st speed gear - 13. Coupling element - 14. Synchronizer ring - 15. Hub - 16. Pin - 17. Pin - 18. Spring - 19. 2nd speed gear - 20. Bush - 21. 3rd speed gear - 22. Pawl - 23. Small block - 24. Taper roller bearing

531030 REMOVING THE TRANSMISSION SHAFT**Figure 65**


30489

TRANSMISSION SHAFT COMPONENTS

1. Transmission shaft - 2. Taper roller bearing - 3. I-II speed gear - 4. III speed gear - 5. IV speed gear - 6. Spring retaining ring


Remove the cones from taper roller bearings (2) by using suitable tools.
Remove the spring retaining ring (6).

Use a hydraulic press (80 tons), then, one by one, remove the gears (5-4-3) from the transmission shaft (1).

530520 REMOVING THE GEARCHANGE CASE OF GEARBOX**Figure 66**

37657


Mark the assembling position of the lever (1) on the shaft (3), then remove it.
Withdraw the casing (2).
Remove the pin (4).

Figure 67

37658

Disassembly the cover (7), the valve (1), the cylinder (6) and relevant retaining ring (5), then, withdraw the springs (4) and the piston (3).
Remove the cover (2).


Figure 68



37659

Remove the plugs (1) and relevant washers and withdraw the springs (2). Remove: the pins (3), the spacers (4) and the levers (5).


Figure 69



37660

Remove the spring ring (2) from the shaft (1) and withdraw the washer (3) and the spring (4).


Figure 70



37661

Remove the spring ring (2) from the shaft (1) and withdraw the washer (3), the spring (4) and the washer (5).


Figure 71



37662

Disengage the spacer (1) from the shaft (2) after removing the spring pin (3).


Figure 72



37663

Position the shaft (1) so as the spring pins that connect the stop sectors (2 and 3) to the shaft are towards the hole (→). Use a punch to pull out the spring pins.

Figure 73




37664

Keep the three prongs (6) to prevent them from falling down and remove the shaft (8) and relevant nine pawls (7). Then, remove the spacer (1), the stop sectors (2 and 3) and the spacer (4) from the case (5).



Take note of the assembling position of pawls (6).

Figure 74




GEAR CHANGE CASE COMPONENTS

31029

OIL PUMP

Figure 75



37665

Remove the screws (1) and disassemble the components. Check that the bodies (2 and 5) are free from defects or damages.

Check that the inner rotor (3) and the outer rotor (4) are not too much worn out and also check that they are not too much loose in their seats. If any fault or trouble is found out, replace the oil pump.

CHECKS

CASE AND COVERS

The case and relevant covers shall not show cracks.
The faying surfaces between case and covers shall not be damaged nor warped.
The seats of bearings and that of the R speed transmission gear shall not be damaged nor too much worn out.
The covers shall not show cracks and the coupling surfaces shall not be warped nor damaged; the roller bearings shall not rotate in their seats; the assembling clearances of the shafts shall not be excessive; the shafts and relevant control components, the pawls, the spacer and the levers shall not be too much worn out and the springs shall not be broken nor have loosed proper flexibility.

GEAR SHAFTS

The bearing seats in the shafts shall not be damaged nor worn out. Toothings of gears shall not be damaged nor worn out.

HUBS, SLIDING SLEEVES AND FORKS

The splines on hubs and relevant sliding sleeves shall not be damaged. The sliding sleeve move on the hub shall be free. The sliding sleeve dowels shall not be damaged nor worn out. The forks shall be free from damages or defects and the backlash of relevant sliding shoes in the radial race of the sliding sleeve shall not exceed 1 mm.

BEARINGS

The roller bearings or roller cages shall be in perfect conditions and not show traces of wear or overheating.
While keeping the bearings pressed with your hand, make them rotate to both directions at the same time: the movement shall not be affected by binding or noise.




At assembling stage, always replace the safety plates and rings, the spring washers, the sealing rings and gaskets, the springs of the sliding sleeve dowels and all other springs that are showing having lost the required elasticity. Also replace the spring caps, the self-locking nuts and all those parts not perfectly efficient, scored, cracked or warped.

Before installing the two-lip sealing gaskets, fill the gap between the two lips with TUTELA MR3.

SYNCHRONIZERS AND COUPLING ELEMENTS

Figure 76



30508


Check wear of synchronizer rings and relevant coupling elements by operating as follows:
set the synchronizer ring (1) on the coupling element (2);
rotate the components to ensure proper coupling;
use a feeler gauge (3) at two opposite points to find gap X between the coupling element and the synchronizer ring. If the value X found is less than 0.8 mm for the gearbox, or less than 1.2 mm for the E.R.U., replace the synchronizer ring and/or the coupling element.



At assembling stage, do not mistake the components with each other.

ASSEMBLING THE GEARCHANGE CASE


Figure 77



37666

Use driver 993701131 (1) to disassemble the roller bearing (2) and then fit in place the new one.


Figure 78



37667

Fit the spacer (1), the stop sectors (2 and 3), the spacer (5) in the box (4). Fit the paws (7) on the shaft (8), then, let the shaft in the box and connect the prongs (6) to the shaft in the same position as that noted at disassembling. Also connect the shaft to the parts already installed in the box.


Figure 79



37668

Secure the stop sectors (2 and 3) and the spacer (4) to the shaft (5) through the spring caps (1).


Figure 80



37669

Install the washer (2), the spring (3), the washer (4) on the shaft (1) and secure through the spring ring (5). Then install the spring (6), the washer (7) and secure through the spring ring (8).


Figure 81



37659

Fit the levers (5) in place and also install the spacers (4) and pins (3). Let the springs (2) in the box and install the plugs (1) and relevant washers.


Figure 82



37670

Use driver 99370113 (1) to install the bush (5), the sealing ring (4) and the dustproofing (3) casing on the cover (2). The outer surfaces of the elements shall be spread with sealant.


Figure 83



37658

Fit in place the piston (3) and the springs (4), then, install the cylinder (6) and the sealing ring (5). Fit in place the covers (2 and 7) and the valve (1) c.w. relevant gaskets.

Figure 84




37657

Fit in place the pin (4). Install the casing (2) and the control lever (1) on the shaft (3) to comply with the position noted at disassembling.

ASSEMBLING THE TRANSMISSION SHAFT

Figure 85



24438

Accurately clean the surfaces of the coupling seats of gears and shaft.

Cool the shaft (1), if possible, or heat the gears at the temperature of 160°C to 180°C, then, use a hydraulic press to carry out the assembling sequence to install I-II speed gear (2), 3rd speed gear (3) and 4th speed gear (4) on the shaft.




The action of the press shall be kept for about 1' after every single gears is bedded.

Fit in place the spring ring (5) and check that the axial backlash of the ring in the seat is 0 to 0.1 mm.

If this is not so, select the proper thickness ring out of those supplied spare.

Heat the inner rings of front and rear bearings at about 85°C for 15', then, install them on the transmission shaft by using suitable driver.


Figure 86



31038

Clamp the main shaft (1) in a vice and fit in place the roller bearing (3) and the pickup speed gear (2) on the shaft.


Figure 87



30519

Heat the hub (2) of the sliding sleeve that engages R gear and pickup gear at the temperature of 100°C for about 15', then, fit it in place by using suitable driver (1).

Figure 88




31039

Check that the axial backlash of the ring in the seat is 0 to 0.1 mm. If this is not so, select the proper thickness ring out of those supplied spare.

Check that the axial backlash of the pickup gear (2) is 0.20 to 0.45 mm.


Figure 89



30521

Fit in place the sliding sleeve (3) that engages R gear and pickup gear, the roller bearing (2) and the R speed gear (1). Heat the taper roller bearing (5) at 85°C for about 15' and install it by using suitable driver (4). Check that the axial backlash of the R speed gear is 0.40 to 0.75 mm.


Figure 90



31040

Heat the planet gears (1) at 160 to 180 °C for about 15' and install so as to make the oil holes (→) on the planet gears coincide with those on the shaft (2).


Figure 91



30522

Check that the axial backlash of the spring ring (1) in the seat is 0 to 0.1 mm, otherwise select proper thickness ring out of those supplied spare, then, fit it into place.


Figure 92



30523

Upturn the shaft (4) in a vice and install: roller bearing (1), I speed gear (3) and coupling element (2).


Figure 93



30524

Install the synchronizer ring (2). Heat the hub (1) at the temperature of 85°C for approx 15', then install it by using suitable driver. Check that the projecting parts of the synchronizer ring (2) suitably fit the seats in the hub (1). Check that the backlash of the 1st speed gear (3) is 0.20 to 0.45 mm.


Figure 94



31041


Install the sliding sleeve (2) that engages I-II speeds. Fit the pins (3), the springs (4) and the pins (5) in the relevant seats on the hub (1). Set the elements under the sliding sleeve (2) by compressing them.

Figure 95




Install the synchronizer ring (3), the coupling element (2) and the roller bearing (1).

Figure 96




Install the II speed gear (1). Heat the bush (2) at the temperature of 85°C for 15', then, install by using suitable driver. Check that the axial backlash of the gear (1) is 0.20 to 0.45 mm.

Figure 97




Check that the axial backlash of the spring ring (1) in the seat is 0 to 0.1 mm. If this is not so, select the proper thickness ring out of those supplied spare, then install.

Figure 98




Install the roller bearing (4), the IV speed gear (3), the coupling element (2) and the synchronizer ring (1).

Figure 99



Heat the hub (1) at the temperature of 85°C for approx 15', then install it by using suitable driver. Check that the projecting parts of the synchronizer ring (2) suitably fit the seats in the hub (1).


Figure 100



Check that the axial backlash of the III speed gear (2) is 0.20 to 0.45 mm.

Check that the axial backlash of the spring ring (1) in the seat is 0 to 0.1 mm. If this is not so, select the proper thickness ring out of those supplied spare, then install.


Figure I01



31047

Fit the springs (3), the pins (4), the small blocks (5) in the relevant seats on the hub (1). Compress the small blocks and install the sliding sleeve (2) that engages the III-IV speed gear. Check that the small blocks suitably fit in place under the sleeve.

Figure I02




30788

Heat the taper roller bearing (1) at the temperature of 85°C for approx 15', then install it by using suitable driver.

ASSEMBLING THE INPUT SHAFT

Figure I03




30529

Heat the taper roller bearing (1) at the temperature of 85°C for approx 15', then install it by using suitable driver.

ASSEMBLING THE GEARBOX


Figure I04



31048

Fit the spring (1) in the gearbox. Install the plate (3) and the lever (4) and engage the end part of the lever to the spring (1). Secure the parts to the gearbox through the spring ring (2).


Figure I05



37672

Heat the seats of the cups of the taper roller bearings (1) for the main shaft (2) and transmission shaft in the gearbox, then fit the components in place.


Figure I06



37627

Apply tool 99370449 (1) to the main shaft (2) and engage to the hoister. Set the fork (3) on the shaft (2) and let the shaft in the gearbox.


Figure 107



37626

Screw the eyebolt 99360502 (1) to the transmission shaft (2). Engage the eyebolt to a hoister and shift the main shaft (3) sideways to let the transmission shaft in the gearbox.


Figure 108



37673

Set the gearbox to horizontal position. Use the screwdriver to suitably set the lever (1) so as to enable introducing the rod (5), then, connect the rod to the Reverse speed/pickup speed gear engaging fork. Secure the fork to the gearbox through the knuckle screws. Install the fork (3) and sliding shoes (4) on the sliding sleeve that engages I-II speeds. Position the lever (1) and fit in place the rod (5) on the sliding sleeve that engages I-III speed. Position the lever (1) and fit in place the rod (2) by engaging it to the fork (3). Secure the fork (3) to the gearbox through the knuckle screws.


Figure 109



37674

Set the fork (2) and sliding shoes (4) on the sliding sleeve (3) that engages III-IV speed engagement sliding sleeve (3). Position the lever (1, Figure 108) and fit the rod (1) in place by engaging it to the fork (2). Secure the fork to the gearbox through the knuckle screws. Engage 3rd speed. Then, install the bearing plate (5) and the retaining plate (6) and disengage 3rd speed.


Figure 110



37675

Fit in place the coupling element (1) and the synchronizer ring (3). Open the transmission shaft (4) and the main shaft (2), then, fit the input shaft (5) to the main shaft. Install the oil filter (6).


Figure 111



37676

Heat the bearing seats in the front cover (1) and fit in place the bearing rings (2 and 3).

Figure 112




37677

Fit the gasket (3) on the gearbox. Let the pipe (1) in the cover (2) and install on the gearbox.

ADJUSTING THE TRANSMISSION SHAFT BEARINGS

Figure 113




37678

Set the gasket (4) on the front cover (2).
Fit in place the outer ring (3) so as to make it rest on the bearing rollers free from backlash.

Rest the feeler gauge (1) on the gasket (4) and find the gap between the outer ring (3) and the gasket (4): value Δ .

Figure 114



37679


Use the feeler gauge (1) to find the gap between the oil pump (2) shouldering and the coupling plane (3) of the pump to the front cover: value $\underline{B}$.

Thickness S of the adjusting ring is given by:

$$S = (A - B) + C$$

where: A and B are the values found out, $C = 0.18$ to 0.30 mm, the prescribed pre-load.

Figure 115




37680

Fit in place the adjusting ring (2) featuring the thickness value found out during previous measuring and install the oil pump (1). Check that the engagement opening (→) coincide with that on the transmission shaft (3).


Adjusting the main shaft bearings

Figure 116



Bed the outer ring (2) so as to make it rest on the bearing rollers free from backlash. Use the feeler gauge (1) to find the projecting part of the ring (2) from the cover surface (3): value Δ .

Figure 117



Set the gasket (4) on the cover (3). Use the feeler gauge (1) to find the gap between the gasket and the faying surface (2) of the adjusting ring: value $\underline{B}$.


Thickness $\underline{S}$ of the adjusting ring is given by:

$$S = (B - A) + C$$

$C = 0.18$ to 0.30 mm, the prescribed preload.


Then, install the input shaft on the cover; use the connecting tool 99374357 and relevant handle 99370006 to drive the sealing ring into place.

Figure 118




Set the gasket (3) on the front cover (2) and the adjusting ring (4) on the bearing; install the input shaft (1) on the cover. Rotate the gearbox by 180° .

Figure 119



Heat the seats of the R speed transmission gear (1) shaft. Set the R speed transmission gear (1) c.w.the two roller bearings (2) in the gearbox.



Figure 120



Install the R speed transmission gear (1, Figure 119) shaft and check that it suitably fits the roller bearings (2, Figure 119). Install the spring ring (2).

Use the feeler gauge to check that the axial backlash of the gear (1) is 0.20 to 0.60 mm.

Figure 121



Re-install the E.R.U. (I) case as described in the relevant chapter.

Install the gear change case and connect the pipes through the suitable points noted at disassembling stage.

Fit in place the backup light switch.

Remove the gearbox from the revolving stand and install the side cover on the R speed transmission gear opening.

Fill the gearbox with lubricating oil and check that type and amount are to comply with specifications.


Install the gear change case and connect the pipes through the suitable points noted at disassembling stage.

Gearboxes:**ZF 16 S 181 D.D.****ZF 16 S 181 O.D.****ZF 16 S 221 D.D.**

	Page
LOCATION OF GEARBOX DESCRIPTION PLATE	45
DESCRIPTION	46
OPERATION	48
☐ Slow range	48
☐ Fast range	49
EPICYCLIC REDUCTION GEAR CONTROL ..	50
☐ Reduced speeds	50
☐ Normal speeds	51
SPECIFICATIONS AND DATA	52
TIGHTENING TORQUES	56
TOOLS.....	57
GEARBOX FAULT DIAGNOSIS.....	62
REMOVING-REFITTING THE GEARBOX	65
☐ Removal	65
☐ Refitting	66
OVERHAULING THE GEARBOX	67
☐ Servoshift gear box	67
☐ Removal	67
☐ Refitting	67
☐ Disassembly	67
☐ Assembly	69
☐ Removing the rear box	73
☐ Removing the epicyclic reduction gear unit (ERG)	73

Page

☐ Fitting the epicyclic reduction gear unit (ERG)	75
☐ Refitting the epicyclic reduction gear unit (ERG) rear box	78
☐ Removing the gearbox	78
☐ Removing the main shaft	81
☐ Removing the drive input shaft	84
☐ Synchronizing devices	85
CHECKS	85
☐ Gearbox	85
☐ Hubs - sliding sleeves - forks	85
☐ Bearings	85
☐ Shafts - gears	85
☐ BK-type single-cone synchronizing devices ...	85
☐ Removing the transmission shaft	85
☐ Fitting the drive input shaft	86
☐ Fitting the transmission shaft	86
☐ Fitting the main shaft	87
☐ Adjusting the main shaft	89
☐ Fitting the gearbox	90
☐ Oil pump	91
☐ Adjusting the transmission shaft bearing end float	91
☐ Drive input shaft cover	92
PNEUMATIC CONTROL OF GEARBOX	94

LOCATION OF GEARBOX DESCRIPTION PLATE**Figure 1**

ZAHNRADFABRIK FRIEDRICHSHAFEN AG.			
	TYP	16S151/181/221 *	
STUECKLISTEN-NR.		GETRIEBE-NR.	
B		C	
KUNDE	D		
BEST.-NR.			
UEBERS.	16.47-I	E	TACHO E/Z6F
GESAMT	I	n =	I MOTOR
HEBEN-			
ABTRIEB			
OEL MENGE IN LITER	G	OEL NACH ZF-SCHMIER- STOFFLISTE TE-ML	H

16=Number of forward gears

AS=Synchronized

151/181/221 input torque

- G= Quantity of oil
 H= Oil standards
 I= Number of turns of power take-off, if applicable
 F= Number of tachymeter teeth
 E= Gearbox ratio
 C= ZF serial number
 B= Progressive production number

DESCRIPTION

ZF 16 S 151 - 16 S 181 - 16 S 221 gearboxes in versions D.D. (direct drive) or O.D. (Multiplied) are made up of:

- ☐ A central box containing the main shaft, drive input shaft, transmission shaft and the gears for the four forward speeds and one reverse gear.
- ☐ A rear box containing the Epicyclic Reduction Gear Unit (ERG). Its function is to double the number of forward speeds by using epicyclic gears with helical toothing. This produces a range of gears that, starting with the four incoming speeds, makes it possible to have eight different ratios at the output (four normal speeds plus four reduced speeds).
- ☐ A front box containing the step-up gearing, called the "splitter", that makes it possible for each of the eight forward speeds and for the reverse gear to obtain an additional double selection. The "splitter" therefore halves the stagger between two successive ratios and each gear is divided into a slow ratio (L = slow ratio) and a fast ratio (S = fast ratio).

These gearboxes therefore have sixteen forward speeds with finely staggered ratios that can be engaged in succession and two reverse gears.

The synchronizing devices are the single-cone type.

Lubrication is made with a gear pump.

The double-H speed control is fitted with an air-operated "servoshift" device to improve speed selection and engagement.

The servoshift is a device comprising a mechanical/pneumatic module and a double-acting cylinder.

The advantages of this device are:

- ☐ Faster speed selection and engagement with less effort.
- ☐ It cushions the vibrations of the control linkage, reducing noise.
- ☐ Less synchronizing device stress.

The device works mechanically if the pneumatic system breaks down.

Figure 2





Figure 3



61225


DETAIL OF SERVOSHIFT SPEED CONTROL

1. Control valve lever - 2. Speed control lever - 3. Idle roller - 4. Exhaust - 5. Control piston - 6. Intake - 7. Cylinder - 8. Reaction spring - 9. Longitudinal tie rod connection lever

OPERATION

Slow range

Figure 4



PNEUMATIC DIAGRAM FOR PRE-SELECTION IN SLOW RANGE

The air from the services reservoir supplies the inhibitor valve (14) and the pre-selector (1) simultaneously, through the connecting pipe (15).

On shifting the pre-selector (1) downwards (position L of slow range), the air reaching the pre-selector (1) through the connecting pipe (16) supplies the double control valve (8).

The pressurized air, supplying the above-mentioned valve (8), pushes the pistons (4 and 9) to the left.


The movement of the pistons (4 and 9) makes it possible for the valve (7) to return to its seat and discharge the air contained in the left-hand chamber of the cylinder of the "splitter" (2) into the atmosphere through the connecting duct (12).

At the same time, the valve (6) moves and opens the passage for the air between the inlet duct (11) and the duct (3) connecting with the right-hand chamber of the cylinder of the splitter (2).

On pressing the clutch pedal, the air reaching the inhibitor valve (14) supplies the double control valve (8) through the connecting pipe (13).

The air reaching the valve (8) passes through the inlet duct (11) and, finding the passage clear, supplies the right-hand chamber of the cylinder of the "splitter" (2) through the connecting duct (3).

The piston of this cylinder, moving to the left, then drives the entire train downline, causing the slow range to be engaged.

Fast range**Figure 5**

71110

PNEUMATIC DIAGRAM FOR PRE-SELECTION IN FAST RANGE

The air from the services reservoir supplies the inhibitor valve (14) and the pre-selector (1) simultaneously, through the connecting pipe (15).

On shifting the pre-selector (1) upwards (position S of fast range), the air passage between the supply pipe (15) and the double control valve (8) is closed, setting the connecting pipe (16) in communication with the outlet pipe (17).

As a result of the air being discharged by the double control valve (8), the reaction of the spring (10) and of the springs (5) pushes the pistons (4 and 9) to the right.

The movement of the pistons (4 and 9) makes it possible for the valve (6) to return to its seat and discharge the air contained in the right-hand chamber of the cylinder of the "splitter" (2) into the atmosphere through the connecting duct (3).

At the same time, the valve (7) moves and opens the passage for the air between the inlet duct (11) and the duct (12) connecting with the right-hand chamber of the cylinder of the "splitter" (2).

On pressing the clutch pedal, the air reaching the inhibitor valve (14) supplies the double control valve (8) through the connecting pipe (13).


The air reaching the valve (8) passes through the inlet duct (11) and, finding the passage clear, supplies the right-hand chamber of the cylinder of the "splitter" (2) through the connecting duct (12).

The piston of this cylinder, moving to the right, then drives the entire train downline, causing the fast range to be engaged.

EPICYCLIC REDUCTION GEAR CONTROL

Reduced speeds

Figure 6



PNEUMATIC SYSTEM DIAGRAM OF REDUCED SPEED ENGAGEMENT

The air from the vehicle's pneumatic system is reduced to a pressure of 9.5 bars by the pressure reduction unit (I). It then supplies the inhibitor valve D.

Now, taking the control lever onto the reduced speed position (1st H), the body A, integral with the speed control rod, opens the valve E that, via the pipe F, supplies the cylinder G.


The piston of the cylinder G, moving to the right, activates the ERG.

At the same time, the valve B closes, making it possible for the air from the pipe C to discharge into the atmosphere.

The movement of the piston causes the contact of the electric switch to close, which turns on the indicator light in the cab with the tortoise symbol.



The reduced speeds can be used in both slow range and fast range conditions, depending on the position of the pre-selector.

Normal speeds**Figure 7**

71112

PNEUMATIC SYSTEM DIAGRAM OF NORMAL SPEED ENGAGEMENT

The air from the vehicle's pneumatic system is reduced to a pressure of 9.5 bars by the pressure reduction unit (I). It then supplies the inhibitor valve D.

Now, taking the control lever onto the normal speed position (2nd H), the body A, integral with the speed control rod, opens the valve B that, via the pipe C, supplies the cylinder G.

The piston of the cylinder G, moving to the right, deactivates the ERG.






At the same time, the valve E closes, making it possible for the air from the pipe F to discharge into the atmosphere.

The movement of the piston causes the contact of the electric switch to close, which turns off the indicator light in the cab.



The normal speeds can be used in both slow range and fast range conditions, depending on the position of the pre-selector.

SPECIFICATIONS AND DATA






GEARBOX		
	Type	Mechanical
	Torque at input 16 S 151 D.D. Nm ZF 16 S 181 D.D. Nm ZF 16 S 181 O.D. Nm ZF 16 S 221 D.D. Nm	1600 1900 2200 2200
	Speeds	16 forward speeds 2 reverse speeds
	Control of the four main speeds ERG control * Splitter control	Mechanical Pneumatic Pneumatic
	Power take-off	On request
	Gear engagement: Forward speeds Reverse gear Gear anti-disengagement	Free ring synchronizer Bk-type single cone 1 st -2 nd -3 rd -4 th -5 th -6 th speed Quick engagement Sliding sleeves held by pawls and springs.
	Gear wheels	Helical-toothed

* ERG = Epicyclic reduction gear unit










D.D. = Direct Drive

O.D. = Over Drive (Multiplied)

SPECIFICATIONS AND DATA


GEARBOX		ZF 16 S 151 D.D. ZF 16 S 181 D.D. ZF 16 S 221 D.D.	ZF 16 S 221 O.D. ZF 16 S 181 O.D.	
	Gear ratio			
	First	L	I: 16.47	I: 13.80
		S	I: 13.79	I: 11.55
	Second	L	I: 11.32	I: 9.59
		S	I: 9.48	I: 8.02
	Third	L	I: 7.79	I: 6.81
		S	I: 6.52	I: 5.70
	Fourth	L	I: 5.48	I: 4.58
		S	I: 4.58	I: 3.84
	Fifth	L	I: 3.59	I: 3.01
		S	I: 3.01	I: 2.52
Sixth	L	I: 2.47	I: 2.09	
	S	I: 2.07	I: 1.75	
Seventh	L	I: 1.70	I: 1.49	
	S	I: 1.42	I: 1.24	
Eighth	L	I: 1.20	I: 1.00	
	S	I: 1.00	I: 0.84	
Reverse gear	L	I: 15.42	I: 13.17	
	S	I: 12.91	I: 11.03	
(L = slow ratio; S = fast ratio)				
	Type of oil	Tutela Truck FE-Gear Tutela ZC 90		
	Quantity	Dry change		
	ZF 16 S 151	kg litres	10 11	
	ZF 16 S 181/221	kg litres	12 13	
	Transmission and main shaft bearings	tapered rollers		
	Drive output flange assembly temperature	Max. 70 °C		
 	Transmission shaft gear assembly temperature	160 ÷ 180 °C		
D.D. = Direct Drive O.D. = Over Drive (Multiplied)				

SPECIFICATIONS AND DATA

GEARBOX		ZF 16 S 151/181/221
	Main and transmission shaft bearing and fixed hub assembly temperature	100°
	End float: - ERG* planet wheel shaft bearing - ERG* fixed hub split ring - Transmission shaft bearing split ring	$0 \pm 0.1 \text{ mm}$
	End float of gear of drive input shaft, first, second and third speed	minimum 0.2 mm
	Fourth speed gear end float	minimum 0.05 mm
	End float between planet wheel holder and ERG* planet wheels	$0.4 \pm 1.3 \text{ mm}$
	End float of bearings of shafts: main and transmission on drive input side	$0.0 \pm 0.1 \text{ mm}$
	Main shaft rear bearing split ring end float	$0.0 \pm 0.05 \text{ mm}$
	Wear limit check distance of synchronizer rings: - first/second speed - third/fourth speed - ERG *	1.5 mm at 50 Nm (5 kgm) 0.8 mm 1.2 mm
	Reverse gear idler end float	$0.4 \pm 1.5 \text{ mm}$
	End float or pre-load of half rings of main and drive input shafts	from - 0.05 to + 0.05


* ERG = Epicyclic reduction gear unit

SPECIFICATIONS AND DATA

GEARBOX		ZF 16 S 151/181/221
	Distance for the clearance adjustment of the sliding blocks of the splitter control fork on the relevant sliding sleeve ☐ 16 S 151 D.D. ☐ 16 S 181 D.D./O.D. - 221 D.D.	94.1 mm 107.9 mm
	Clearance of the sliding blocks of the forks in the seats of the sliding sleeves	0.6 ÷ 1.2 mm
	Assembly distance of twin-lipped seal on rear cover	12.5 ^{+1.0} mm

TIGHTENING TORQUES







Figure 8



PART	TORQUE	
	Nm	kgm
1 Screws fixing splitter box	50	5
2 Screws fixing drive input shaft cover	46	4.6
3 Nut fixing oil pump	46	4.6
4 Screws fixing rear cover	50	5
5 Screws fixing drive output flange	120	12
6 Screws fixing PTO fitting cover	79	7.9
7 Screws fixing ERG* box	50	5
Screws fixing gearbox	43	4.3
Screws fixing valve to gearbox	23	2.3
Screws fixing ERG* cylinder to the box	50	5.0
Self-locking nuts fixing splitter control rods and ERG to pistons	150	15.0
Fixing screws		
- M18 x 1.5	35	3.5
- M22 x 1.5	50	5
- M24 x 1.5	60	6
Screw for reverse gear shaft retaining plate (if applicable)	86	8.6
Screws fixing fork on splitter control shaft	60	6
Screws fixing disengagement bearing control fork mount	150	15
Screws fixing RM gearbox bottom cover	49	4.9
Screws fixing gearbox side cover	23	2.3
Socket-head screws fixing pipes	35	3.5
Oil drain plugs	80	8.0
Oil drain plugs M38 x 1.5 with magnetic filter	140	14.0
Pressure switches / pulse transmitters	50	5.0
Screws fixing oil pump cover	46	4.6
Switches on gearbox	35	3.5
Screws fixing splitter control valve	9,5	0.9
Nut for screw fixing lever to gearbox control rod	5	4.9
Threaded pins for articulation of ERG* control fork	250◆	25◆
Oil vapour breather pipe	10	1
Push rods for positioning rods	50	5

ERG* = Epicyclic Reduction Gear unit


◆ = Apply LOCTITE 241 on the thread

TOOLS	
TOOL No.	DESCRIPTION
99322205	 Rotary stand for overhauling assemblies
99322225	 Stand for supporting assemblies (to be fitted on stand 99322205)
99340205	 Percussion extractor
99341003	 Single-acting bridge
99341004	 Single-acting bridge
99341012	 Pair of brackets


TOOLS

TOOL No.


DESCRIPTION

99341015

Clamp

99341019


Pair of tie rods with grips

99341020
99341021


Pair of tie rods with grips

99341022







Grips

99341024
99341025







Grips



99345058

Extractor reaction block



TOOLS		
TOOL No.	DESCRIPTION	
99345092		Extractor reaction block
99347092		Pin to extract gearbox front and rear centring pins (use with 99340205)
99360502		Rings to remove and refit reduction gear unit
99360515		Tool to extract and insert main shaft, transmission shaft and fork assembly
99370006		Grip for interchangeable drifts
99370007		Grip for interchangeable drifts

TOOLS

TOOL No.	DESCRIPTION
99370420	 Key for fitting gasket on gearbox front cover (use with 99370006)
99370449	 Tool to extract and insert main shaft
99370450	 Tool to adjust splitter control fork
99370465	 Tool to notch safety plates
99370629	 Mount to support gearbox when removing and refitting it on the vehicle
99371050	 Brackets to support gearbox when overhauling (use with 99322205 - 99322225)

TOOLS**TOOL No.****DESCRIPTION****99374093**Drift to mount external bearing races (91-134)
(use with 99370007)**99374421**

Key to fit gaskets on rear cover


99374370Key to fit oil deflector on direct drive shaft
(use 99370006)**99395604**

Dial gauge (0-10 mm)


GEARBOX FAULT DIAGNOSIS

Principal operational anomalies:

- 1 - Noise;
- 2 - Spontaneous gear disengagement and irregular engagement;
- 3 - Gear engagement hard and difficult.
- 4 - Pneumatic control system defective or inefficient.




(continue)



* The checks have to be made with the engine switched off and the air tanks full.

(continue)



530210 REMOVING-REFITTING THE GEARBOX**Removal**


To remove the gearbox, proceed as follows:

- ☐ Set the vehicle over a pit or on a lift.
- ☐ Disconnect the battery cables to prevent any short-circuiting.
- ☐ Disconnect the cable (11) using the connectors (→) and breaking the safety lead off the screw (10).
- ☐ Disconnect the connector (7) and the pipe (8) from the power take-off (if applicable).
- ☐ Disconnect the air pipes (4) and (5).
- ☐ Free the pipes (6) from the clamps (12).
- ☐ Undoing the fasteners (13), disconnect the tie rod (14) from the gearbox.
- ☐ Loosen the screw (2) and extract the lever (3) together with the tie rod (1) from the gearbox after marking its position for reassembly.
- ☐ Remove the fasteners (15) of the gearbox bell, accessible from above.



For gearboxes with the interarder, proceed as follows:


- ☐ Drain off the engine coolant and disconnect the pipes from the heat exchanger.
- ☐ If the cross member of the chassis frame prevents you from removing the gearbox, you need to drain off the oil from the interarder; take out the nuts and screws fixing the heat exchanger to the interarder, remove the stud bolts and detach the heat exchanger.

Figure 9

Working from under the vehicle:

- ☐ Disconnect the pipes (1) and (2), previously freed from the clamps.
- ☐ Unscrew the nuts (5) and tie the clutch cylinder (6) to the vehicle's chassis frame appropriately.
- ☐ Undoing the side fasteners (8), take off the cross member (7).
- ☐ Place a hydraulic jack equipped with the mount 99370629 (1, Figure 10) under the gearbox.
- ☐ Disconnect the propeller shaft (10) by undoing the screws (9) and tie it to the vehicle's chassis frame appropriately so it will not interfere with the removal of the gearbox.
- ☐ Complete removing the gearbox bell fasteners (4).
- ☐ Afterwards, extract the gearbox from the engine by bringing it suitably back out of the space occupied by the exhaust pipe (3). Then lower the jack and take out the gearbox.

Figure 10



45369

Refitting




Carry out the operations performed for removal in reverse order and tighten the fixing nuts and screws to the required torque.



For gearboxes with the interarder, proceed as follows:

- ☐ Refit the heat exchanger to the interarder, inserting new seals; fit the stud bolts and tighten the fixing screw and nuts to the required torque.
- ☐ Connect the coolant pipes to the heat exchanger and replenish the gearbox with the required amount of oil.
- ☐ Fill the engine cooling system as described in Section 2 Engine.

Figure 11



71752

530210 OVERHAULING THE GEARBOX



There follows a description of the operations for overhauling the ZF 16 S 151 gearbox that, unless stated otherwise, hold for the ZF 16 S 181/221 gearboxes too.

Thoroughly wash the outside of the gearbox and drain the oil off into a container.



To dispose of the lubricant and detergents, keep to the specific regulations.

Fit the supporting brackets 99371031 to the assembly.


Using ropes with hooks and a movable lift, position the assembly on the rotary stand 99322205 together with the mount 99322225.



Use the specific tools for overhauling. During removal, it is advisable to put the parts down in the working sequence made in order to make reassembly easier.

530220 Servoshift gear box Removal

Figure 12



Note down the assembly position of the pipes (3 and 4) and disconnect them from the gearbox (5) by unscrewing the fittings (2 and 6) together with the washers.

Unscrew the fixing screws (1) and remove the gearbox (5) together with the servoshift from the gearbox.




The servoshift cannot be overhauled. Replace it if you find any trouble.

Refitting

For refitting, carry out the steps described for removal in reverse order, fitting new seals and tightening the fixing screws (1) and fittings (2 and 6) to the required torque.


Disassembly

Figure 13



Unscrew the fitting (2) and disconnect the air pipe (3) from the distributor (4).


Figure 14



Unscrew the screws (1, Figure 13) and disconnect the servoshift (1) from the gearbox (2).

Take out the push rod (3) with the spring (4).

Figure 15




Mark the assembly position of the lever (7) on the rod (6). Loosen the nut (5) and remove the lever (7) from the rod (6).

Extract the cup (8).

Remove:

- ☐ The valve (3) after taking out the screws (4).
- ☐ The switches (1 and 9) with their washers and push rods (2 and 10).
- ☐ The plug (13) with its washer, the spring (12) and the push rod (11).


Figure 16



61229

Unscrew the screws (1) and take off the top cover (2).
Extract the pin (3).


Figure 17



61230

Take off the circlip (3) and extract the piston (2) together with the ring (1).

Figure 18




61259

Unscrew the plugs (2) with the washers, extract the springs (1) and remove the levers (6).

If necessary, take out the pins (3).

Unscrew the screws (4) and remove the cover (5).

Figure 19




61231

Remove the circlip (2) from the rod (1).

Use the washer (4) to limit the action of the spring (5) and remove the split ring (3), extract the washer (4), the spring (5) and the washer (6).


Figure 20



61232

Remove the circlips (1) and take out the pins (2) fastening the drive (4) to the rod (3).

Figure 21




61233

Move the sleeve (1) in the direction of the arrow.


Strike a punch on the top of the lever (6) to make it come out of the bearing (3) and pin (2), freeing the latter from the groove (4) in the rod (5).

Figure 22




Note down the assembly position of the levers (2 and 3) and take them out of the box (4) extracting the rod (1).

Figure 23



Using the male extractor 99348004, extract the bushing (2) and the seal (1) from the box (3).

Figure 24




Note down the assembly position of the locking element (1) and drive (2) and take them out of the box (4) after extracting the sleeve (3).

Assembly




When assembling, always replace the sealing elements with new parts: rings, copper washers, flat gaskets, o-rings and roller bearings with the pins. Check that the springs have not broken nor yielded.

Figure 25



Position the locking element (1) and the drive (2) in the box (4) as marked during removal and put on the sleeve (3).


Figure 26



Using a suitable drift, mount the bushing (2) in the box (3).

Using a suitable keying device, fit the seal (1) in the box (3). Lubricate the inside of the seal (1) with grease.


Figure 27



61234

Position the levers (2 and 3) in the box (4) as marked during removal and put on the rod (1).

Figure 28




36804

Move the sleeve (1) in the direction of the arrow.

Fit a new roller bearing (3) and pin (2) on the lever (6). Position the rod (5) so that the groove (4) corresponds with the roller (3) and pin (2).

Resting the lever (6) on a flat surface, carefully strike the bearing (3) and pin (2) so they go into a position flush with the top of the lever (6) and correctly enter the groove (4) in the rod (5).


Figure 29



61232

Fasten the drive (4) to the rod (3), putting on the pins (2) and mount new circlips (1) on these.

Figure 30




61231

On the rod (1), position: the washer (6), spring (5), washer (4) and fit on a new split ring (3).

Fit on a new circlip (2).

Figure 31




61259

Fit on the cover (5) with a new gasket, screw down the screws (4) and tighten them to the required torque.


Position the levers (6) on the pins (3). Screw down the plugs (2) with the new washers and springs (1) and tighten them to the required torque.

Figure 32




Fit a new ring (1) on the piston (2) and fit this in the box, securing it with the circlip (3).

Figure 33



Insert the pin (3) in the box.
Put the top cover (2) on with a new gasket.
Screw down the screws (1) and tighten them to the required torque.


Figure 34



Complete gearbox assembly by fitting:


- ☐ push rod (11), spring (12), plug (13) with a new seal;
- ☐ push rods (2 and 10), switches (1 and 9) with the new washers;
- ☐ cup (8), lever (7) on the rod (6) in the position marked during removal and tighten the nut (5) to the required torque.
- ☐ valve (3) and tighten screws (4) to the specified torque.

Figure 35




Position the push rod (3) with the spring (4) in the box (2).
Refit the servoshift (1) with a new gasket.

Figure 36



Screw down the screws (1) and tighten them to the required torque.
Connect the air pipe (3) to the distributor (4), screwing down the fitting (2) with new copper gaskets and tightening it to the required torque.


Figure 37



Refit the gearbox (5), screw down the fixing screws (1) and tighten them to the required torque.

Connect the pipes (3 and 4) to the box (5), in the position found at removal, with the fittings (2 and 6) together with the new washers.

Figure 38




61237

PARTS COMPRISING THE GEARBOX

Removing the rear box


Figure 39



Remove the gearbox (1) as described under the relevant heading.

Take note of the assembling position of pipes (3) on G.R.E. control cylinder (5), then disconnect the pipes by unscrewing adapters (6) complete with washers.

Figure 40




Unscrew the nut (2), extract the piston (3) together with the two rings and the vibration deadening from the ERG control rod (6).

Take off the ring (5). Using a screwdriver, remove the seal (4) of the rod (6).

Unscrew the push rod (1) for positioning the rod (6).


Figure 41



Unscrew the screws (1). Screw the eyebolts (3) onto the rear box. Using hooks (4) and a movable lift, detach the rear box (2) from the gearbox.


Removing the epicyclic reduction gear unit (ERG)

Figure 42




Take off the safety plate, unscrew the two screws (1). Take out the pressure plate (2) and the seal beneath.

Figure 43




Extract the drive output flange (3) using the extractor composed of: tie rods (2), bridge (1), reaction block 99345058 (4).

Figure 44



Unscrew the screws (2), take off the cover (1) and take out of this the bearing, adjustment ring and seal.


Figure 45



37332

Unscrew the pins (2 and 3) and remove the box (1) from the ERG unit.

Figure 46




37333

Extract the rod (3), fork (1) together with the sliding blocks controlling the ERG unit.

Remove the middle plate (2).


Figure 47



71115

Remove the coupling body (1) together with the fifth wheel bearing and synchronizer ring (2) from the hub for the sliding sleeve.


Figure 48



71116

Take the fifth wheel bearing (2) out of the coupling body (1).


Figure 49



61219

Taking care over the blocks (5) and the springs (3 and 4) coming out of the hub (2), take the sliding sleeve (1) out of the hub. Remove the circlip (6).


Figure 50



61252

With an extractor composed of bridge (1), brackets (2), reaction part (3) and clamp (4), extract the hub (6) for the sliding sleeve from the ERG shaft (5).

Figure 51




61220

Remove the synchronizer ring (1) and the coupling body (3) together with the plate (2) from the ring gear (4).

Levering under the coupling body (3), extract this from the plate (2).


Figure 52



71117


Remove the ring gear (1) from the planet wheel shaft (2).

Figure 53



COMPONENT PARTS OF THE EPICYCLIC REDUCTION GEAR UNIT


Figure 54



19527

Take off the ring (2) and separate the ring gear (3) from the mount (1).

Figure 55




71118

Take off the spacer (2), push the spring pins (4) inside the pins (3) and, with an appropriate drift, extract the pins (3) from the planet wheel shaft (1). Extract the planet wheels (7) together with the adjustment rings (5-8) and rollers (6) from the planet wheel shaft (1).


Fitting the epicyclic reduction gear unit (ERG)

To fit the epicyclic reduction gear unit, carry out the steps described for removal in reverse order. The operations and assembly phases requiring specific tools, clearance checks, adjustments or special precautions are described below. The tightening torques are given in the specific table.



61176

Figure 56




Before putting the synchronizing devices back together, check the wear of the synchronizer rings (1) and of the coupling bodies (3). Using a feeler gauge (2), measure the distance between the synchronizer ring (1) and the coupling body (3) at two opposite points. If the measured distance (X) is less than 1.2 mm, replace the synchronizer ring (1) or the coupling body (3).

Do not get the checked parts mixed up (it is recommended to mark them).



When fitting the internal rings of the bearings and the hub for the sliding sleeve, they will first need to be heated to approximately 100 °C for roughly 15 minutes.

Figure 57




Check that the end float between the planet wheel holder (1) and the planet wheels (4) is between 0.40 and 1.30 mm.

After checking the end float, fit the pins (2) of the bearings in the planet wheel holder (1), making the reference marks "0" punched on the pins tally with the holes (3) for the spring pins.

Fit the spring pins in the holes (3) and notch them.

Figure 58




Check the clearance between the ring (2) and its seat.

The clearance has to be between 0.0 and 0.1 mm.




The circlip (1) is supplied as a spare with a different thickness.

Figure 59



COMPONENT PARTS OF THE EPICYCLIC REDUCTION GEAR UNIT SYNCHRONIZING DEVICE


Figure 60



19565

Using the keying device 99374221 (1) fit the seal in the cover (2) of the drive output flange.


Figure 61



37343

Measure the depth of the bearing seat in the ERG box (1).


Figure 62



37344

Measure the thickness of the bearing (2).


Figure 63



37345

Measure the depth of the bearing seat in the cover (3) together with the gasket (4).

Figure 64



37346

Determine the thickness of the adjustment ring (5) so that between the bearing (2) and the box of the epicyclic reduction gear (1, Figure 61) there is an end float of 0.0 ± 0.1 mm.

EXAMPLE		mm
☐	Depth of bearing seat in box (1)	7.40+
☐	Depth of bearing seat in cover (3) together with gasket (4)	23.00=
☐	Total	30.40-
☐	Bedding of gasket (4)	0.05=
☐	Total	30.35-
☐	End float (0.0 - 0.1 mm), mean value	0.05=
☐	Total	30.30-
☐	Thickness of bearing	30.00=
☐	Total	0.30

The thickness of the adjustment ring (5) has to be 0.30 mm.


Refitting the epicyclic reduction gear unit (ERG) rear box

To refit the rear box of the epicyclic reduction gear unit, carry out the steps described for removal in reverse order.

The operations and assembly phases requiring specific tools, clearance checks, adjustments or special precautions are described below.

The tightening torques are given in the specific table.


Figure 65



Screw the eyebolts (3) onto the rear box (2), fit the ropes with hooks (4) and, with a movable lift, mount the rear box on the gearbox.

Tighten the screws (1) to the required torque.

Figure 66




After tightening the two screws fixing the drive output flange (2), fit the safety plate on them and notch it with tool 99370465 (1).

Take the gearbox off the stand and restore the oil level.

Removing the gearbox

Figure 67




Remove the rear box of the epicyclic reduction gear unit as described under the relevant heading.

Note down the assembly position of the switches (3) type 235N and (5) type 145N and unscrew them from the gearbox (6).

Remove the oil vapour breather pipe (1) and the plug (2).

Figure 68



Remove the splitter driving cylinder (3) together with the rings (4-5).



There may be 3 rings on the cylinder (3).


Take off the ring (9). Unscrew the nut (7) and remove the piston (8) from the rod (6).

Remove the spacer ring (2) from the main shaft (1).



The spacer ring (2) is only mounted on ZF 16 S 181 gearboxes.

Figure 69




Extract the reverse gear shaft (1).

! With some gearboxes, in order to extract the shaft (1), it is necessary to take out the screw fixing the plate fastening it to the gearbox.


Remove the tube (2) from the main shaft (3).

Figure 70




Unscrew the screws (1) and take off the cover (2).

Figure 71




Take out the reverse idler gear (1) together with the roller bearings (2 and 3).

Figure 72




Unscrew the nuts (1) and take off the drive input cover (2).

Figure 73



Take off the thrust washer (4), spring (3), thrust washer (2), adjustment ring (1) and gasket (5).


Figure 74



Unscrew the nuts (1) and remove the oil pump (2).


! To remove the oil pump (2), do not unscrew the screws (4). These screws secure the cover (3) to the pump body and are unscrewed when the part has been removed solely to overhaul the oil pump.

Figure 75



Remove the adjustment rings (1) from the tapered roller bearing (3). Take off the gasket (2).


Figure 76



Using the extractor 99340205, take out the pins (3) centring the front cover (1) with the gearbox (2).


Unscrew the screws (4) and the nuts fixing the front cover (1) to the gearbox (2).

Figure 77




Fit suitable hooks (1) onto the front cover (2) and, using a rope and lift, remove it from the gearbox (3).

Figure 78



Take the oil filter (4) out of the gearbox. Unscrew the two socket-head screws (2), take out the splitter control rod (1) and extract the fork (3) together with the sliding blocks from the sliding sleeve.

Figure 79




Position the tool 99360515 (2) on the drive input shaft (1) and its sleeves (3) on the rods (4).

Screw the screw (5) of the tool 99360515 (2) into the transmission shaft (8), adjust the nut (6) and the threaded bushing (7) so that the transmission shaft (8) stays aligned with the main shaft (9) when it is successively extracted.

Hook the tool 99360515 (2) onto the lift.

With a screwdriver in the hole (→) of the gearbox, push the bolt (2, Figure 81) so as to free the control rods (4) and at the same time extract the shaft - rod assembly from the gearbox.

Figure 80



61189

Tighten the main shaft (9) in a vice.


Unscrew the screw (5) and remove the transmission shaft (6).

Lift sleeves (3) from rods (4), remove tool (2) and take rods (4) off their respective sliding sleeves.

Remove the drive input shaft (1) from the main shaft (9).

Remove the synchronizer ring (8) and the coupling body (7).


Figure 81



37324

Remove the gear bolt (2) together with the spring from the gearbox (1). Using an appropriate drift, extract the two outer rings (3) and (4) of the bearings, ERG side, of the transmission and main shafts. Clean the lubricating oil delivery pipes with a jet of compressed air.

Figure 82



37325


Unscrew the 2 screws (1) and take out the splitter control valve (2).



Do not dismantle the splitter control valve (2), it cannot be overhauled. Replace it if you find any trouble.

Removing the main shaft


Figure 83



61190

Lift the notch of the retaining ring (1) and remove the half rings (2). Using a suitable extractor, remove the ring inside the tapered roller bearing (3), extract the thrust washer (4).


Figure 84



71120

Overturn the main shaft in the vice and take out the split ring (1).

Figure 85




71121

Take out the reverse gear (4) and the internal ring (6) of the bearing, ERG side, with an extractor composed of:

- ☐ grips (3);
- ☐ tie rods (2);
- ☐ bridge (1);
- ☐ reaction block 99345058 (7);
- ☐ clamp (5).

Extract the roller bearing of the reverse gear (4) from the main shaft.

Figure 86




71122

Extract the 1st speed gear (5), the coupling body (4) and the internal ring (3) of the bearing of the reverse gear with an extractor composed of:

- ☐ grips (6);
- ☐ tie rods (8);
- ☐ bridge (1);
- ☐ reaction block 99345058 (2);
- ☐ clamp (7).

Extract the 1st speed gear roller bearing from the shaft.


Figure 87



27464

Extract the coupling body (1).


Figure 88



71123

Remove the synchronizer ring (2) from the main shaft (1).


Figure 89



27466

Extract the sliding sleeve (2) together with the springs and thrust elements and take out the three connecting blocks (1).

Figure 90




71124

Extract the 2nd speed gear (5), coupling body, synchronizer ring, fixed sleeve (4) and bushing (3) with an extractor composed of: grips (6), tie rods (8), bridge (1), reaction block 99345058 (2), clamp (7).

Extract the 2nd speed gear roller bearing from the shaft.

Figure 91




61191

Using a hydraulic press, extract the 3rd speed gear (13), coupling body (12), synchronizer ring (11), synchronizer unit (6), synchronizer ring (5), coupling body (4), roller bearings (3), 4th speed gear (2) and roller bearing (1) from the main shaft and take out the roller bearing (14).

Dismantle the synchronizer unit (6): remove the sliding sleeve (10) from the hub (7), taking care over the pins (9) and springs (8) coming out in order to collect them.


Removing the drive input shaft

Figure 92




Tighten the drive input shaft (5) in the vice. Remove the sliding sleeve (2) from the hub (1) and taking care over the pins (3) and springs (4) coming out in order to collect them.

Figure 93




Take out the split ring (1) and remove the tube (2).

Figure 94



Take out the retaining ring (1) and the divided ring beneath.


Figure 95



Extract the coupling body (5), gear (6) and internal ring (3) of the drive input shaft bearing with an extractor composed of:

- ☐ grips (7);
- ☐ tie rods (8);
- ☐ bridge (1);
- ☐ reaction block 99345058 (2);
- ☐ clamp (4).


Figure 96



Extract the bearings (1 and 2) and the synchronizer ring (3).

Removing the transmission shaft

Figure 97



Take off the split ring (1) and using an appropriate extractor take out the internal ring (2) of the bearing on the splitter side.

Use the same method, after turning over the transmission shaft, to extract the internal ring of the bearing on the ERG side.



The two roller bearings of the transmission shaft are not interchangeable. Take care to put them aside separately and to mark them so they will not get swapped over during assembly.

Using a hydraulic press, extract the gears (3, 4 and 5) from the transmission shaft.

CHECKS Gearbox

The gearbox and its covers must have no cracks.

The surfaces of contact between the covers and gearbox must be neither damaged nor deformed, remove any remains of sealant from them.

The seats of the bearings, shafts and gear control rods must be neither damaged nor too worn.

Check that the holes, pipes and lubrication grooves are not obstructed by grease or foreign bodies.

Hubs - sliding sleeves - forks

The grooves on the hubs and sliding sleeves must not be damaged. The sliding sleeve has to slide freely on the hub. The blocks or pins for positioning the sliding sleeve must not be damaged or worn. The coupling teeth of the sliding sleeves must not be damaged. The forks must be integral and their blocks must have no end float, in the radial throat of the sleeve, greater than $0.6 \div 1.2$ mm.

Bearings

The roller bearings or roller cages must be in a perfect state of repair and show no signs of wear or overheating.

Shafts - gears

The bearing seats on the shafts must be neither damaged nor worn. The gear teeth must be neither damaged nor worn.

Synchronizing devices

Check the wear of the synchronizer rings as follows:




After the check, the synchronizer rings must be marked on the respective gears to prevent their position getting swapped over at the time of assembly.

☐ Visually check that the friction surface is not undulated.

BK-type single-cone synchronizing devices

Figure 98



61193

Position the synchronizer ring (1) on the coupling body (2).


Turn the synchronizer ring (1) so as to ensure correct coupling on the coupling body (2).

Using a feeler gauge, check the distance A on two diametrically opposite points.

It must be no less than:

- 0.8 for the gears and splitter;
- 1.2 for the epicyclic reduction gear unit.

Figure 99




61194

1. Coupling body - 2. Synchronizer ring - 3. Compression spring - 4. Pin - 5. Synchronizer hub - 6. Sliding sleeve.

Fitting the transmission shaft

To mount the transmission shaft, carry out the steps described for removal in reverse order. The operations and assembly phases requiring specific tools, clearance checks, adjustments or special precautions are described below.


Figure 100



Heat the gears (5, 4 and 3) to $160\text{ }^{\circ}\text{C} \pm 180\text{ }^{\circ}\text{C}$ for approximately 15 minutes and drive them onto the shaft using a press.

 For assembly, the internal rings of the tapered roller bearings must first be heated to approximately $100\text{ }^{\circ}\text{C}$ for roughly 15 minutes.

Mount the internal ring of the bearing (2) on the splitter side, the circlip (1) and check the clearance between the circlip (1) and its seat with a feeler gauge; the clearance has to be between 0.0 and 0.1 mm.




COMPONENT PARTS OF THE DRIVE INPUT SHAFT

Fitting the drive input shaft

To mount the drive input shaft, carry out the steps described for removal in reverse order.

The operations and assembly phases requiring specific tools, clearance checks, adjustments or special precautions are described below.



Figure 101



If you need to replace the ring (3) of the drive input shaft (4), to remove it use general tools, for assembly use the keying device 99374370 (2) and grip 99370006 (1).

Figure 102

Figure 103



27249

Using a feeler gauge, check the end float of the drive input gear (2), it must be at least 0.2 mm.

In addition, check the tolerance between the divided ring (1) and its seat, it has to be between $-0.05 \div +0.05$ mm.



The divided ring (1) is supplied as a spare with different thicknesses.


After mounting the divided ring (1), fit onto it the retaining ring and notch it at two diametrically opposite points.

Fitting the main shaft

To mount the main shaft and the drive input shaft, carry out the steps described for removal in reverse order.

The operations and assembly phases requiring specific tools, clearance checks, adjustments or special precautions are described below.

Figure 104



COMPONENT PARTS OF THE MAIN SHAFT

71125



Before assembly, heat the:

- internal rings of the bearings to approx. 100 °C
- bushings, hubs for sliding sleeves and toothed ring for the reverse gear coupling to 120 °C
- seats of the bearings on the box and cover to 60°C



During assembly, lubricate the gear roller bearings.




After mounting the gears, check their end float, which has to be:

- 1st-2nd speed gears 0.2 mm;
- 4th speed gear 0.05 mm;
- reverse gear 0.4 - 1.15 mm.

Figure 105



I



71120



The main shaft is shown in the version with the end with straight toothing.

Check the clearance between the split ring (I) and its seat with a feeler gauge. The clearance has to be between 0.0 and 0.1 mm.



The split ring (I) is supplied as a spare with different thicknesses.

Figure 106





1

2

3

4



61199

Mount the 4th speed gear as follows:

Heat the roller bearing (2) to 100°C. Fit it on the main shaft (1) with the lubrication holes (→) facing as shown in the figure and leave it to cool.

Mount the synchronizer ring (4) and the coupling body (3).



Figure 107



1

2

3




61200

Position the roller bearing (2) with the lubrication holes (→) facing as shown in the figure of the 4th speed gear (3), heat them to 100 °C and mount them assembled in this way on the main shaft (1).

Adjusting the main shaft

Figure 108



61203


Determine the thickness of the adjustment ring (4, Figure 109) of the coupling body (3, Figure 109) for the 4th speed gear as follows:

Measure the distance A between the end of the shaft (1) and the seat (2) supporting the tapered roller bearing.

Mount the thrust washer (3) and measure the distance B between this and the end of the main shaft (1).

The difference $A - B$ must be between $+0.07$ and -0.08 mm.

Figure 109



61204


Position the coupling body (3) together with the adjustment ring (4) on the 4th speed gear (1).

Measure the distance between the top of the coupling body (3) and the thrust washer (2).

It has to measure $4.6 - 0.4$ mm.

If you get a different value, replace the adjustment ring (4) with another one of suitable thickness.


Figure 110



61205

Assemble the adjustment ring (1) having a thickness set in the previous measurements.

Figure 111



61202

Mount the bearing (3), previously heated to 100°C .

Mount the divided ring (2) whose thickness produces an end float for it in its seat of $-0.05 \div +0.05$ mm.

Mount the retaining ring (1) and notch it at several points the same distance apart under the divided ring (2).

Fitting the gearbox

To mount the gearbox assembly, carry out the steps described for removal in reverse order. The operations and assembly phases requiring specific tools, clearance checks, adjustments or special precautions are described below.

The tightening torques are given in the specific table.



Any rings and seals, ring nuts, spring pins, safety plates and self-locking screws found to be worn and all parts that are not fully efficient or are scored, dented or deformed must be replaced at the time of assembly.




The flat gaskets should be fitted dry, without any jointing compound or grease.



Before fitting the twin-lipped seals, fill the gap between the two lips with TUTELA MR3.

Figure 112



61204

Tighten the main shaft (11) in a vice. Position the coupling body (10) on it together with the adjustment ring and synchronizer ring (9).



Mount the drive input shaft (1).

Mount the tool 99360515 (2) on the drive input shaft (1).

Couple the transmission shaft (8) with the main shaft (11). Tighten the screw (5) of the tool 99360515 (2) in the transmission shaft. Adjust the nut (6) and the threaded bushing (7) so that the transmission shaft (8) stays aligned with the main shaft (11).

Position the associated forks together with blocks and rods (4) on the sliding sleeves and position the sleeves (3) of the tool 99360515 (2) on the rods.

Figure 113




61206

Hook the tackle onto the tool 99360515 (1). Lift the shaft - rod assembly (2) as assembled beforehand and insert it in the gearbox. With a screwdriver inserted in the hole in the gearbox, push the bolt so that the rods can go into their respective seats.

Remove the tool 99360515 (1).

Figure 114




71126

Mount tool 99370450 (2) on the gearbox and for transmissions 16 S 181/221, a spacer (3) of the following thickness must be fitted:

- 16 S 181 = 13.8 mm
- 16 S 221 = 13.5 mm.

Insert the splitter drive fork control rod and secure it by means of nut (1).

Figure 115



Using the two socket-head screws (2), position the splitter control fork (1) so that the two sliding blocks (4) are centred in the throat of the sliding sleeve. Use a feeler gauge (3) for this purpose.


After making the adjustment, tighten the two screws (2) to the required torque.

Screw the splitter control rod setscrew onto the gearbox, tightening it to the required torque.

Take the adjustment tool 99370450 (2, Figure 114) out of the gearbox together with the spacer (3) after unscrewing the nut (1, Figure 114).

534010 Oil pump

Figure 116



To dismantle the oil pump: unscrew the screws (1), take the cover (2) off the pump body (5) and extract from this the external (3) and internal (4) rotors.

To reassembly, carry out these steps in reverse order.




Apply a light layer of LOCTITE 547 on the mating surface of the cover (2).

Tighten the screws (1) to the required torque.

Adjusting the transmission shaft bearing end float


Figure 117



Determine the thickness **S** of the rings (2, Figure 118) for adjusting the end float of the transmission shaft bearing (2) as follows:

- ☐ Turn the shafts and check that the outer ring (2) of the bearing rests without any clearance on the bearing rollers.
- ☐ Measure the distance **A** between the plane of the front box (1) and the outer ring (2) at two diametrically opposite points.

Figure 118



Measure the depth **B** of the seat of the bearing (2, Figure 117) on the pump body (1).


The thickness **S** of the adjustment ring (2) is determined by the following equation:

$$S = [B - (A - C)] - D$$

Where:

- **A - B**, measurements taken;
- **C**, thickness of gasket;
- **D**, end float of 0 - 0.1 mm.

Figure 119




61211

Position a new gasket on the front cover. Mount the oil pump (2) together with the adjustment ring (2, Figure 118).

Screw down the nuts (1) and tighten them to the required torque.

530511 Drive input shaft cover

Figure 120




61212

To replace the seals (1) and bushings (2), use general tools to remove - fit them.

To fit the seal (5) use the keying device 99370420 (4) and grip 99370006 (3).

Figure 121




62213

Determine the thickness **S** of the drive input shaft bearing adjustment ring as follows:

- ☐ Turn the drive input shaft and check that the outer ring (1) rests without any clearance or pre-load on the rollers of the internal ring of the bearing.
- ☐ Measure the protrusion of the bearing (1) from the plane of the front cover (2), distance **A**.

Figure 122



61214

- ☐ Measure the depth **B** of the seat of the bearing (1, Figure 121) on the cover (2).


The thickness **S** of the adjustment ring (1) is determined by the following equation:

$$S = [B - (A - C)] - D$$

Where:

- **A - B**, measurements taken;
- **C**, thickness of gasket;
- **D**, end float of 0 - 0.1 mm.

Figure 123




61215

Position a new gasket on the front cover (1). Mount the cover (1) together with the adjustment ring (1, Figure 48).

Screw down the nuts (2) and tighten them to the required torque.

Figure 124



71127

Turn over the gearbox.

Mount the tube (3) in the main shaft.

Mount the spacer (5) on the main shaft (4), position the seal (6) in the seat of the splitter driving cylinder.



Position the cut of the ring (7) by the hole (→).

Mount the seals (8 and 9) on the cylinder (6) and lubricate them.

Fit the cylinder (6) in the gearbox.


Position the tool 99370450 (1) on the gearbox (3) so as to keep the cylinder (6) in the seat. Supply the splitter control valve (2, Figure 82) with compressed air (max. 6.8 bars) and listen to check the internal piston works and there are no air leaks.

Take off the tool 99370450 (1).

Refit the epicyclic reduction gear unit box as described under the relevant heading.

Replenish the gearbox with lubricating oil of the required grade and quantity.

PNEUMATIC CONTROL OF GEARBOX

Figure 125

DIAGRAM OF PNEUMATIC CONTROL OF GEARBOX WITH SERVOSHIFT

1. Splitter control selector - 2. Inhibitor valve - 3. Pressure reduction unit - 4. Services reservoir - 5. Servo-clutch - 6. Double control valve - 7. ERG driving cylinder - 8. Switch signalling gearbox in neutral - 10. Control valve - 11. Distributor - 12. Servoshift - 13. Piping - 14. Piping

The splitter (slow speeds - fast speeds) and epicyclic reduction gear unit are air operated and controlled with the speed control lever.

The selector (1) pre-selects the L range (slow) and V range (fast) via the double control valve (6). They are inserted via the inhibitor valve (2) when the clutch pedal is pressed.

The epicyclic unit engages and disengages automatically when passing from the 1st H to the 2nd H and vice versa.

When the gearbox is in neutral, the driving cylinder (7) is operated by the pressurized air via the control valve (10).

The vehicle's pneumatic system supplies the services reservoir (4) and the distributor (11) through the pressure reduction unit (3).

Through the piping (13), the distributor (11) supplies the servo-clutch (5) that, if operated with the clutch pedal, supplies the servoshift (12) through the piping (14).

A switch (9) on the gearbox control turns on the reversing light when reverse gear is engaged.

The switch (8) signalling when the gearbox is in neutral is on the cover of the gear control.

Another switch on the ERG driving cylinder (7) turns on the indicator light in the cab (with the symbol of the tortoise) when the epicyclic reduction gear is engaged.

**ZF gearboxes
with INTARDER hydraulic retarder,
types:
16 S 151 D.D.
16 S 181 D.D.
16 S 221 D.D.**

	Page
SPECIFICATIONS AND DATA	97
TOOLS	98
☐ Removing the hydraulic retarder from the gearbox on the stand	105
☐ Refitting the hydraulic retarder	105
☐ Removing the epicyclic reduction gear unit (ERG)	106
☐ Removing the epicyclic reduction gear unit (ERG) rear box	106
☐ Component parts of the epicyclic reduction gear unit	109
☐ Fitting the epicyclic reduction gear unit (ERG)	110
☐ Refitting the epicyclic reduction gear unit (ERG) rear box	112



This sub-section gives the main topics that differ from the ones covered for the similar types of gearbox without the Intarder.




The technical data, tightening torques and procedure for overhauling the gearbox differ from the 16 S 151 D.D. - 16 S 181 D.D. - 16 S 221 D.D. gearbox in the following.

SPECIFICATIONS AND DATA

GEARBOX WITH INTARDER			16 S 151 D.D.	16 S 181 D.D. 16 S 221 D.D.
	Maximum braking torque	Nm	3000	
	Braking capacity	kW	420	
	Type of oil		Tutela Truck FE-Gear Tutela ZC 90	
	Quantity after overhauling gearbox and retarder drained completely	l	18,5	21,5
		kg	16,5	19,5







Figure 1









GEARBOX ASSEMBLY WITH RETARDER

71142

TOOLS


TOOL No.	DESCRIPTION
99322205	 Rotary stand for overhauling assemblies
99322225	 Stand for supporting assemblies (to be fitted on stand 99322205)
99340030	 Extractor fitted for hydraulic operation (use with 99341033 - 99341034)
99340205	 Percussion extractor
99341003	 Single-acting bridge
99341004	 Single-acting bridge

TOOLS	
TOOL No.	DESCRIPTION
99341012	 Pair of brackets
99341015	 Clamp
99341019	 Pair of tie rods with grips
99341020	 Pair of tie rods with grips
99341021	 Pair of tie rods with grips
99341022	 Grips


TOOLS

TOOL No.


DESCRIPTION

99341024


Grips

99341025


Grips

99341033


17.5 t hydraulic unit for extractor

99341034







50 t hydraulic pump

99342143







Pin to extract reverse gear shaft (use with 99340205)







99345058

Extractor reaction block

TOOLS	
TOOL No.	DESCRIPTION
99345092	 Extractor reaction block
99345097	 Reaction tool to extract sun gear and drive in main shaft oil pipe
99347092	 Pin to extract gearbox front and rear centring pins
99360515	 Tool to extract and insert main shaft, transmission shaft and fork assembly
99370006	 Grip for interchangeable drifts
99370007	 Grip for interchangeable drifts

TOOLS


TOOL No.	DESCRIPTION	
99370113		Drift to mount seal and/or bushings on gearbox
99370415		Dial gauge base to adjust transmission shaft bearing end float (use with 99395604)
99370420		Key for fitting gasket on gearbox front cover (use with 99370006)
99370449		Hook to lift main shaft
99370450		Tool to adjust splitter control fork
99370465		Tool to notch safety plates

TOOLS	
TOOL No.	DESCRIPTION
99370629	 Mount to support gearbox when removing and refitting it on the vehicle
99371050	 Brackets to support gearbox when overhauling (use with 99322205 - 99322225)
99374093	 Drift to mount external bearing races ($\varnothing 91 + 134$ mm) (use with 99370007)
99374221	 Key to fit gaskets on rear cover
99374370	 Key to fit oil deflector on direct drive shaft (use with 99370006)
99389819	 Torque wrench ($0 + 10$ Nm) with square 1/4" connection

TOOLS

TOOL No.


DESCRIPTION

99395604

Dial gauge (0÷10 mm)

Removing the hydraulic retarder from the gearbox on the stand

Figure 2




Fit the brackets 99371050 (3) onto the assembly.

Using ropes with hooks and a movable lift, put the assembly on the rotary stand 99322205 (2) together with the mount 99322225 (4).

Take off the plug (5) and drain the lubricating oil from the gearbox.

Take off the plug (1) and drain the lubricating oil from the hydraulic retarder.

Figure 3



Lift the notch of the safety plate (3) and take it off.

Take out the screws retaining the drive output flange (2), plate (4) and seal beneath.

Take out the screw (9) and extract the plug (7) with the seal (8), the oil filter (6) and magnet (5).

Set the gearbox upright.

Take out the screws (→) fixing the hydraulic retarder (1) to the epicyclic reduction gear unit (10). Sling the heat exchanger with a rope and, using the hydraulic lift, remove the hydraulic retarder (1) from the epicyclic reduction gear unit (10).




Recover the adjustment rings from the stator and from the epicyclic assembly shaft bearing.

To overhaul the hydraulic retarder, see SECTION 5, Intarder hydraulic retarder.

Refitting the hydraulic retarder

Figure 4



Set the adjustment rings on the ERG bearing and on the hydraulic retarder.

Fit the hydraulic retarder (1) back on the ERG box (10), tightening the screws (→) to the required torque.

Mount the magnet (5), oil filter (6), plug (7) with seal (8) and tighten the screws (9) to the required torque.

Fit the flange (2) on the ERG shaft.

Lubricate the seal and fit it on.


Position the retaining plate (4) and tighten the fixing screws to the required torque.

Fit the safety plate (3) on the screws and notch it with the tool 99370465.



Replace the sealing elements with new parts.

Figure 5




Fit on the retarder drain plug (1) and the gearbox oil drain plug (2).

Replenish the assembly with the required quantity and grade of oil.

Removing the epicyclic reduction gear unit (ERG) rear box


Figure 6



Remove the hydraulic retarder as described under the relevant heading.


Take off the fittings (→) and disconnect the pipes (1 and 3) from the cylinder (4). Remove the cylinder (4) from the ERG rear box (2).

Figure 7




Remove the nut (1) and extract the piston (2) from the rod (3).

Figure 8



Remove the seal (5), gasket (4), switch (3), push rod (2) and retaining push rod (6) from the ERG rear box (1).


Figure 9



Using the percussion extractor 99340205 (2) and part 99342143 (3), extract two of the three centring pins from the ERG rear box (1).

The arrows show the outside pins to extract; there is a third pin inside.

Figure 10




Take out the screws fixing the ERG rear box (1) to the gearbox (2). Fasten the retaining plate (3) to the shaft (4) with two screws. Using a rope and hydraulic lift, remove the ERG box (1) from the gearbox (2).

Removing the epicyclic reduction gear unit (ERG)



Here we describe the steps to remove and fit the ERG epicyclic reduction gear unit that differ from the ones given for gearboxes without the Intarder.


Figure 11



43803

Place the epicyclic reduction gear unit (2) on the workbench and remove the pins (1) for the articulation of the fork (8, Figure 12) controlling the ERG.

Figure 12



36804


Using the extractor composed of bridge (1), tie rods (3) and block (2) fitted onto the ERG box, as shown in the figure, extract the bearing (5) and the box (6) from the ERG shaft (4).



While extracting them, hold back the rod (7) to then take it out of the box (6) when it is freed from the fork (8).

Take the fork (8) with its blocks out of the sliding sleeve (9).

Figure 13




61216

Using the extractor composed of bridge (1), brackets (2), part (4) and clamp (3), extract the gear (6) from the ERG shaft (5).

Take off the plate (7) with the tube (8) for lubrication.


Figure 14



61217

Remove the fifth wheel bearing (2) from the gear (1).


Figure 15



61218

Take the synchronizer ring (1) out of the sliding sleeve hub.


Figure 16



61219

Taking care over the blocks (5) and springs (3 and 4) coming out of the hub (2), extract the sliding sleeve (1) from the hub and remove the seal (6).


Figure 17



61252

Using the extractor composed of bridge (1), brackets (2), reaction part (3) and clamp (4), extract the sliding sleeve hub (6) from the ERG shaft (5).

Figure 18




61220

Take off the synchronizer ring (1) and the coupling body (3) together with the plate (2).

Levering under the coupling body (3), extract it from the plate (2).


Figure 19



61221

COMPONENT PARTS OF THE EPICYCLIC REDUCTION GEAR UNIT SYNCHRONIZING DEVICE

Figure 20




61253

Component parts of the epicyclic reduction gear unit

Remove the epicyclic reduction gear unit as described for gearboxes with no Intarder.

Figure 21




71128

COMPONENT PARTS OF THE ERG CONTROL AND BOX

1. Gasket - 2. ERG - 3. Plate - 4. Bushing - 5. Fifth wheel bearing - 6. Gear - 7. Gasket - 8. Sliding blocks - 9. Fork - 10. Nozzle tube - 11. ERG box - 12. Pin for fork articulation with washer - 13. Gasket - 14. Cover - 15. Screw - 16. Ball bearing - 17. Adjustment ring - 18. Plug with seal - 19. Plug with seal - 20. Sensor - 21. Screw with washer - 22. Cylinder - 23. Seal - 24. Seal - 25. Nut - 26. Seal - 27. Spacer ring - 28. Piston - 29. Seal - 30. Rod - 31. Tube - 32. Pin.

Figure 22



61222

Remove the ball bearing (1) from the ERG box (2).

Unscrew the screws (3) and remove the cover (4).


Unscrew the screw (5).

Fitting the epicyclic reduction gear unit (ERG)

To mount the epicyclic reduction gear unit, carry out the steps described for removal in reverse order.

The operations and assembly phases requiring specific tools, clearance checks, adjustments or special precautions are described below.

Figure 23




43408

Determine the thickness **S** of the ERG ball bearing end float adjustment ring as follows:

- ☐ Measure the depth of the bearing seat in the ERG rear box (1): distance **A**.


Figure 24



43809

Measure the depth of the bearing seat in the retarder: distance **B**.

Figure 25



43810

- ☐ Measure the thickness of the bearing (1): distance **C**;
- ☐ Measure the thickness of the gasket between the retarder and the ERG box: distance **D**.


The thickness **S** of the adjustment ring to place between the ball bearing and the retarder is given by the following equation:

$$S = [(A + B + D) - C] - Y$$

Where,

- ☐ **A - B - C - D** = measurements made;
- ☐ **Y** = 0.1 mm: end float of the ball bearing (0.00 ÷ 0.10 mm).

Figure 26




61254

Position the plate (2) together with the tube (3) on the ERG (4).



Heat the gear (1) to a temperature of 160°C for no longer than 10 sec.
Fit the gear (1) on the ERG shaft (3).


Figure 27



43806

Heat the seat of the ball bearing (1) on the ERG rear box (2) to approx. 60°C and mount the ball bearing (1).


Figure 28



43812

Set the fork (2) with its blocks on the sliding sleeve (1).

Figure 29



61223

Place a new gasket (7) on the plate (6).

Partially fit the ball bearing (3) with the box (4) on the ERG shaft (2).


Insert the rod (9) into its seat in the box (4).

Position the fork (8) in the slot in the rod (9) and, keeping it in this position, complete the assembly of the ball bearing (3) on the shaft (2).



When fitting the bearing (3), guide the tube (5) with a punch (1) so it goes into its seat (→) in the box (4).

Figure 30




43802

Fasten the fork (8, Figure 12) to the box with the articulation pins (1) and tighten them to the required torque.

Refitting the epicyclic reduction gear unit (ERG) rear box

Figure 31



61224


Put a new gasket on the gearbox (2) and refit the ERG rear box (1).

Fit the two centring pins (→) and tighten the fixing screws (6) to the required torque.

Mount the cover (3) with a new gasket and tighten the screws (5) to the required torque.

Screw down the plug (4).

Figure 32




43800

Insert the push rod (2) into the gearbox and fit the switch (3) with the washer. Mount the retaining push rod (6).

Lubricate the seal (5), gasket (4) and mount them on the box (1).

Figure 33




43815

Change the seals (4 and 6), spacer ring (5) of the piston (3) and lubricate them.

Fit the piston (3) on the rod (1) and tighten the nut (2) to the required torque.

Figure 34



43802

Lubricate the inside of the cylinder (7), fit it on the box (1) and tighten the fixing screws (6) to the required torque.

Connect the pipes (2 and 4) to the cylinder (7), screwing down the fittings (3 and 5) with new washers and tightening them to the required torque.

Refit the hydraulic retarder and replenish the assembly with the required quantity and grade of oil.

Gearbox EuroTronic 12 AS 230I D.D./O.D.

	Page
DESCRIPTION	115
SPECIFICATIONS AND DATA	116
TIGHTENING TORQUES	119
TOOLS	120
OVERHAULING THE GEARBOX	125
☐ Checks	125
☐ Gearbox actuator	125
☐ Removal	125
☐ Refitting	126
☐ Removing the rear box	126
☐ Removing the rear box	127
☐ Removing the epicyclic reduction gear train (E.R.G.)	128
☐ Fitting the epicyclic reduction gear train (E.R.G.)	130
☐ Adjusting epicyclic reduction gear train bearing end float	131
☐ Adjusting main shaft end float	132
☐ Synchronizing device assembly for engaging normal or reduced gears	134
☐ Removal	134
☐ Fitting	134
☐ Removing the middle box	137
☐ Removing the main shaft	139
☐ Removing the drive input shaft	141
☐ Removing the splitter synchronizing device ...	142
☐ Fitting the splitter synchronizing device	143
☐ Fitting the drive input shaft	144

Page

☐ Fitting the main shaft	144
☐ Splitter control fork	147
☐ Disassembly - Assembly	147
☐ Gear control forks	147
☐ Removal	147
☐ Fitting	148
☐ Transmission shafts	149
☐ Disassembly - Assembly	149
☐ Fitting the middle box	149
☐ Fitting the front box	152
☐ Front cover	154
☐ Removal	154
☐ Fitting the front cover	154
☐ Adjusting drive input shaft bearing end float . .	154
☐ Adjusting transmission shaft bearing end float	155
☐ Clutch release lever	157

DESCRIPTION

The EuroTronic gearbox 12 AS 230I D.D./O.D. is mechanical with electro-pneumatic control.

The driver can choose whether to program gear selection/engagement manually or automatically. The shafts and gears have helical toothing that reduces operating noise.

The main shaft gear coupling is obtained with sleeves with front toothing.

The splitter and epicyclic reduction gear unit engagement is synchronized.


The speeds are selected with finely staggered ratios and can be engaged in succession with the coupling of the epicyclic reduction gear unit "ERG" and the "Splitter" slow or fast speed unit.

On engaging the "ERG", the speeds of the main shaft are doubled. The ratios obtained in this way are further doubled with the engagement of the "Splitter". Each single ratio is thus divided into a fast or slow ratio.

D.D. = Direct drive






O.D. = Over Drive (Multiplied)

Figure 1



000418t

SPECIFICATIONS AND DATA





	GEARBOXES	EuroTronic Automated	
	Type	12 AS 2301 D.D.	12 AS 2301 O.D.
	Torque activated Nm	Mechanical	
		1900	2500
	Forward gears Reverse gears	12 2	
	Type of running control	electronically-operated semi-automatic	
	Rear power takeoff	optional	
	Gear engagement: E.R.U.* and splitter engagement	by front engagement sleeves free ring synchroniser	
	Gears	constantly engaged straight toothed	
	Gear ratios 1 ^a 2 ^a 3 ^a 4 ^a 5 ^a 6 ^a 7 ^a 8 ^a 9 ^a 10 ^a 11 ^a 12 ^a 1 ^a RM 2 ^a RM	15.85 12.32 9.56 7.43 5.87 4.56 3.47 2.70 2.09 1.62 1.28 1.00 14.68 11.41	12.33 9.59 7.44 5.78 4.57 3.55 2.70 2.10 1.63 1.27 1.00 0.78 11.41 8.88

ERG* = Epicyclic Reduction Gearing

D.D. = Direct drive


O.D. = Over Drive (Multiplied)

SPECIFICATIONS AND DATA

		EuroTronic Automated 12 AS 230I D.D./O.D.
	Bearings - drive input shaft - ERG* shaft - transmission shafts	with balls with cylindrical rollers with tapered rollers
	Bearing end float: - drive input shaft - ERG* planet shaft - transmission shafts	$0 \div 0.1$ mm $0 \div 0.1$ mm $- 0.05 \div + 0.05$ mm
	End float: - main shaft - drive input shaft split ring	0.2 mm $0 \div 0.1$ mm
	Temperature for fitting bearings or bearing seats on the boxes	120 °C
	Forced lubrication with positive displacement pump flow rate (with 12 th speed engaged and oil at a temperature of 80°C) pressure with 12 th speed engaged at 2400 rpm and oil at a temperature of: 40°C 80°C Oil type litres kg	50 dm ³ /min 1.7 bar 1.2 bar Tutela Truck Fe-Gear Tutela ZC 90 12 11

ERG* = Epicyclic Reduction Gearing
D.D. = Direct drive
O.D. = Over Drive (Multiplied)


Figure 2



LONGITUDINAL CROSS-SECTION OF EUROTRONIC 12AS 2301 GEARBOX


TIGHTENING TORQUES

Figure 3




70824


DESCRIPTION		TORQUE	
		Nm	kgm
1	Screws fixing gearbox actuator	23	2.3
2	Screw fixing oil pump	10	1
3	Screws fixing drive input shaft cover	23	2.3
4	Screw fixing clutch uncoupling lever control pin: - M 12 8.8 - M 12 10.9	79 115	7.9 11.5
5	Screws fixing cover (spread LOCTITE 241 on the thread)	79	7.9
6	Screws fixing clutch actuator	23	2.3
7	Screw cap to discharge air from clutch actuator	22	2.2
8	Screws fixing rear box to middle box	46	4.6
9	Screws fixing flange retaining plate	120	12
10	Screws fixing rear cover	5	4.6
11	Speed sensor	45	4.5
12	Screws fixing middle box to front box	50	5
	Pin on rod (spread LOCTITE 262 on the thread)	23	2.3
	Oil vapour vent	10	1
	Screw plug M 10x1 on rear box	15	1.5
	Screw plug M 24x1 on rear box	60	6
	Screw M12 fixing power take-off bay cover	79	7.9
	Screw plug M 24x1.5 on middle box	60	6
	Screw fixing plates retaining fork joint pins on rear box	23	2.3

TOOLS**TOOL NO.****DESCRIPTION****99305121**


Hot air device

99322205

Rotary stand for overhauling assemblies

99322225


Mount to support assemblies (to fit onto stand 99322205)

99341003

Single-acting bridge






99341013

Reaction block






99341015

Clamp







TOOLS

TOOL NO.	DESCRIPTION	
99341018		Pair of brackets with hole
99345057		Extractor reaction block
99345078		Extractor to remove drive input shaft bearing (use with 99345105)
993450998		Inserter to fit bearing on main shaft, rear side and to insert rear flange of gearbox
99345105		Extractor for gearbox drive input shaft bearing (use with 99345078)
99347100		Small extractor (use with specific rings with 99347132)





TOOLS

TOOL NO.	DESCRIPTION	
99347132		Ring grips to extract gearbox transmission shaft bearings (use with 99345057 - 99347100)
99360323		Tool to turn drive input shaft when refitting the gearbox to the engine
99360526		Tool to extract and insert main shaft (use with 99360527) and to drive in gearbox drive input shaft bearing (use with 99345098)
99360527		Tool retaining gearbox main shaft forks (use with 99360526)
99366811		Set of M10 eyebolts (3) to remove and refit gearboxes
99370006		Grip for interchangeable drifts

TOOLS

TOOL NO.	DESCRIPTION	
99370007		Grip for interchangeable drifts
99370153		Tool for positioning main shaft when removing the transmission shafts and for retaining gearbox reverse gear pins
99370172		Tools (6) to mount gearbox epicyclic reduction gear train synchronizer rings
99370317		Reaction lever with extension to fasten drive output flange
99370415		Dial gauge base to adjust transmission shaft bearings (use with 99395604)
99370499		Guides (no. 3) to mount Splitter synchronizing device assembly

TOOLS

TOOL NO.	DESCRIPTION	
99370629		Mount to support gearbox when removing and fitting it back on the vehicle
99374092		Drift to mount outer races of bearings (69 + 91) (use with 99370007)
99374221		Driver to mount seals on back cover
99374336		Driver to fit seals on the front cover of the gearbox (use with 99370006)
99395604		Dial gauge (0 - 10 mm)

530210 OVERHAULING THE GEARBOX



Wash the assembly thoroughly before overhauling.

The specific and/or general tools must be used in the way for which they were designed.

To facilitate assembly, put the removed parts away on the specific tray in their order of removal.

Upon assembly, the following must always be replaced with new parts: the gaskets and seals, spring pins, safety plates and springs. Nuts and screws must be tightened to the prescribed torque with their thread dry and degreased.

Keep to the specific regulations when disposing of lubricant and detergents.

Checks

The gears, synchronizer rings, coupling bodies and sliding couplings must show no sign of failure or excessive toothing wear.

The main shaft must have no indentation, especially on the sliding surfaces of the gear rotation and coupling sleeves.

The reverse idle gear shafts must have a polished surface free from scoring.

The gearboxes must show no sign of cracking and the bearing seats must be neither damaged nor worn, so as to prevent the outer rings of the bearings from turning in their seats.

Check the shoulder spacers are neither worn nor damaged.

The gear coupling forks must show no sign of cracking and the relevant control rods must slide freely, but without any appreciable play, in their guide seats.

Check that the shoes of the drive forks are fully efficient.

Check that the holes, grooves and lubrication pipes are not obstructed by grease or foreign bodies.


Check the bearings are not worn, damaged or overheated.



The following described and illustrated overhaul operations regard transmission I6 A6 260I and, save different indications, are valid also for transmission I2 AS 230I.

530520 Gearbox actuator Removal

Figure 4




78649

Unscrew the ring nut (1 and 5) and disconnect the electric wiring (2) from the speed sensor (6 and 7).

Detach the wiring (2) from the clips (→) securing it to the middle box.

Remove the nuts (4) and detach the actuator (3) from the front box.

Figure 5




78650

Fasten the gearbox (1) to brackets 99322225 (3) on the rotating stand 99322205 (2).

Remove the plug and bleed the lubrication oil.

Figure 6



Take out the screws (2) and detach the actuator (1) with its gasket.




The electronic control unit is integrated in the actuator and these cannot be overhauled. See under the diagnosis heading for the check.

Check that the oil vapour vent (3) is not clogged; if it is, clean it.

Refitting

Figure 7




Set a new gasket (6) on the front case (7).

Lubricate the stems of the solenoid valves (3-4-5) with silicone grease and put them into a neutral position. Put the rods (8-9-10) into a neutral position. Fit the actuator (1) on the front box (7) verifying that the end of the stems of the solenoid valves is correctly positioned in the seats of the rods (8-9-10). Tighten the fixing screws (2) to the prescribed torque. After removing the gearbox from the stand used for overhaul, refit the clutch actuator (3, Figure 4) and make sure the wiring (2, Figure 4) is not damaged.

Removing the rear box

Figure 8



Disconnect speed actuators (1) as described in the relevant chapter.

Extract the springs (6-7-8) and the pawls (6).




The springs (7 and 8) are of equal length, the spring (6) is larger.

Remove the pin (4) from the rod (5).


Remove the switch (1) together with the gasket (2) and extract the cap (3).

Figure 9



Block rotation of the sleeve (1) by applying the lever 99370317 (3) and slightly loosen the screws (2).

Figure 10




Remove the screws (1) fixing the plates (2) fastening the pins (4) and extract these together with the seal (3) from the rear box (7).

Extract the two centring pins (5). Remove the screws (6).


Fit the eyebolt 99366811 to the sleeve (8) and, using special ropes and lifter, detach the rear box (7) from the middle one (9).

Figure 11



Remove the oil pipe (1). Note down the assembly position of the fork (3) and plugs (6) and remove them. Remove: the rod (2), synchronizing device assembly (4) and connecting sleeve (5).


Figure 12



Remove the adjustment ring (3) and the plate (1) together with the coupling body (2).


Removing the rear box

Figure 13




Remove the screws (3), disc (4) and seal (5) and extract the sleeve (2) from the spider shaft. Should extraction prove difficult, use an extractor (1) applied as illustrated in the figure.

Figure 14



Remove the screws (2) and take off the cover (1). Remove the spider shaft bearing end float adjustment ring (3).

Figure 15




45946

Using a press, extract the spider shaft (1) from the supporting roller bearing (2). Turn the rear box (3) upside-down and extract the roller bearing (2).

Removing the epicyclic reduction gear train (E.R.G.)


Figure 16



70836

Using a screwdriver, remove the circlip (3) fastening the ring gear with internal toothing (4) to the ring gear with external toothing (2) and remove them from the E.R.G. (1).


Figure 17



70837

Extract the toothed ring (2) from the ring gear with internal toothing (1).


Figure 18



70838

Using pliers (2), tighten the ends of the circlip (3) and remove the coupling body (4) from the E.R.G. shaft (1).

Figure 19




70839

Using a punch, extract the pins (5) from the spider shaft (6).

Remove the planetary gears (3) from the spider shaft (6), together with the rollers (2) and shim adjustment rings (1 and 4).


Figure 20



70840


Extract the toothed shaft (3) from the spider shaft (1) together with the rings (2).

Figure 21



Extract one of the pins (1) from the toothed shaft (2) and extract the rings (3) from this.


Figure 22



Using a suitable extractor, remove the roller bearing ring (1) from the spider shaft (2).


Using a punch, extract the disc (3) from the inside of the spider shaft (2).

Figure 23



PARTS COMPRISING THE E.R.G.


1. Circlip - 2. Ring gear with external toothing - 3. Toothed ring - 4. Ring gear with internal toothing - 5. Bearing - 6. Circlip - 7. Coupling body - 8. Disc - 9. Pins - 10. Ring - 11. Toothed spindle - 12. Disc - 13. Spider shaft - 14. Pin - 15. Shim adjustment ring - 16. Rollers - 17. Shim adjustment ring - 18. Planetary gear.

Fitting the epicyclic reduction gear train (E.R.G.)**Figure 24**

70844


Heat the inside ring (2) of the roller bearing to 120°C and fit it on the spider shaft (3).

Fit on the circlip (1). Fit on the disc (4).

Figure 25


70845

Drive the rings (1 and 3) onto the toothed spindle (2) and fit on the pin (4).

Figure 26


70840

Insert the spindle (3) together with the rings (2) onto the spider shaft (1).

Figure 27


70982

Smear grease into the hole of the planetary gear (5) and insert the rollers (3) with the associated shim adjustment rings (2 and 4). Fit the planetary gears (5) onto the spider shaft (6), fastening them to it with the pins (1).

Figure 28

70838


Using pliers (2), tighten the ends of the circlip (3) and fit the coupling body (4) onto the E.R.G. shaft (1).

Figure 29

70983

Fit the ring gear with internal tooting (5) onto the spider shaft (3) together with the toothed ring (4), and the ring gear with external tooting (2) and fasten the two ring gears with the circlip (1).


Figure 30



45951

Heat the seat of the bearing (1) of the rear box (2) to 120°C and mount the bearing (1).

Figure 31




45943

Rest the spider shaft (1) on an appropriate spacer.

Heat the inside ring of the bearing (2) to 120°C and drive it together with the rear box (3) onto the spider shaft (1).

Adjusting epicyclic reduction gear train bearing end float

Figure 32



70847

Determine the ball bearing end float adjustment thickness (3) by proceeding as follows:

- ☐ measure the depth of the seat on the cover (1) of the bearing (3), distance **A**;
- ☐ measure the protrusion of the bearing (3) from the surface of the rear box (2), distance **B**.

The thickness **S** of the adjustment ring is determined by the following equation:

$$S = (A - B) - C$$


Where:

A and **B** = measurements
C = end float 0 ± 0.1 mm

For example:

A = 5.4 mm
B = 5 mm
C = 0 ± 0.1 mm
S = $(5.4 - 5) - (0 \pm 0.1 \text{ mm}) = 0.3 \pm 0.4 \text{ mm}$


Figure 33



45954

Using the driver 99374221 (1), fit the seal (2) in the cover (3).

Figure 34




70848

Mount the adjustment ring (1), of the thickness determined in the preceding measurement, on the bearing (2, Figure 31) of the spider shaft (3).

Spread IVECO sealant 1905685 on the mating surface of the cover (4) with the box (5) and fit it onto the box, tightening the screws (2) to the prescribed torque.

Figure 35




70849

Heat the sleeve (1) to 90°C and fit it onto the spider shaft (1). Fit on a new seal (4), the disc (3) and screws (2) and tighten them to the prescribed torque.

Adjusting main shaft end float


Figure 36



70850

Position two calibrated blocks (2) on the rear box (4). Place a calibrated rule (1) on them and, using a depth gauge (3), measure the distance between the top side of the rule and the end of the spider shaft (5), distance A.

Figure 37



Fit the connecting sleeve (7) together with the circlip (5) on the main shaft (6).

Position two calibrated blocks (2) on the middle box (4) and place a calibrated rule (1) on them.



The calibrated blocks and rule must be the same ones used in the preceding measurement.

Using a depth gauge (3), measure the distance between the top end of the circlip (5) and the top side of the calibrated rule (1), distance **B**.



The thickness **S** of the main shaft end float adjustment ring is determined by the following equation:

$$S = (A - B) - 2$$

For your information (see Figure 39), subtracting the thickness of the calibrated blocks and rule:


- from the distance **A** gives the distance **X** corresponding to the distance between the end of the spider shaft (2) from the mating surface of the rear box (1).
- from the distance **B** gives the distance **Y** corresponding to the distance between the circlip (4) and the mating surface of the middle box (3).

Figure 38



70852

Figure 39



70853


Position the adjustment ring (2) (of the thickness determined in the preceding measurements) on the main shaft (5). Mount the connecting sleeve (1) and the tube (4).

Mount the plate (6) together with the coupling body (3).

Synchronizing device assembly for engaging normal or reduced gears

Removal

Figure 40




70854

1. Synchronizing device assembly - 2. Synchronizing device ring - 3. Sliding sleeve - 4. Pawl - 5. Spring - 6. Synchronizing device ring.

Put a cloth on the synchronizing device assembly (1) so that, when dismantling it, the springs (5) and pawls (4) are held back as they come out of their seats.

Fitting


Figure 41



70855

Put the springs (2) and pawls (3) into the seats of the synchronizing device rings (1) and fasten them with the tools 99370172 (4).


Figure 42



70856

Position the synchronizing device ring (2) on the synchronizing device ring (3) so that it is possible to fit the sliding sleeve (1) onto them. On completing assembly, remove the tools 99370172 (4).


Figure 43



70857

Fit the synchronizing device assembly (1) on the coupling body (3, Figure 39) with the ring groove (→) facing downwards.

Figure 44




70858

Position the fork (1) with the plugs (3) and the reliefs (2) facing as illustrated in the figure.

Fit on the rod (4) and connect it to the fork (1). Fit on the oil pipe (2).


Figure 45



70859

Take out the screws (1) and remove the cover (2) with its seal (3). Remove the screw (4) with the washer (5).

Figure 46




70860

Spread IVECO sealant 1905685 onto the mating surface of the middle box (6). Fit the eyebolts 99368811 (1) to the sleeve (2). Using ropes and a lifter, position the rear box (4) coaxially to the middle one (6).

Insert the rod (3) of appropriate diameter in the hole for the screw (4, Figure 45) and in the oil pipe (5) to guide this into its seat, while lowering the rear box (4). Lower the rear box (4), paying attention that the spider shaft, oil pipe (5) and rod (7) go into their seat correctly.

Figure 47




70831

Screw down the screws (6) without tightening them; insert the centring pins (5) and tighten the screws (6) to the prescribed torque.

Fit the fork joint pins (4) with fresh seals (3) and tighten the screws (1) fixing the fastening plates (2) to the prescribed torque.

Figure 48




70862

Fit the screw (4) with a new washer (5) and tighten it to the prescribed torque.

Fit the cover (2) with a fresh seal (3) and tighten the fixing screws (1) to the prescribed torque.

Block rotation of the sleeve (7) by applying the lever 99370317 (8) and tighten the fixing screws (6) to the prescribed torque.

Figure 49



70863


Fit the cap (3) and the switch (1) with a new gasket (2). Spread LOCTITE 262 onto the thread of the pin (4), screw it onto the rod (5) and tighten them to the prescribed torque.

Fit the pawls (9) and the springs (6-7-8).



The springs (7 - 8) are of equal length, the spring (6) is larger.


Figure 51



70864

COMPONENT PARTS OF THE REAR BOX OF THE EPICYCLIC REDUCTION GEAR TRAIN

Figure 50



78299

Refit the gear actuator (1) as described under the relevant heading.


Connect the electric wiring (2) to the speed sensor (6), tighten the fixing ring nut (5) and secure the wiring (2) to the box by inserting it in the clips (→).

Remove the transmission from the rotating stand.

Refit the clutch actuator (3) and tighten the nuts (4) to the prescribed torque.


Removing the middle box

Figure 52



Detach the gear actuator and the rear box as described under the relevant headings. Remove the E.R.G. drive rod (4), connecting sleeve (5), adjustment ring (3) and the plate (1) together with the coupling body (2).

Figure 53




Fit the plate 99370153 (1) to the middle box (2) so that the groove inside the plate coincides with the key (5) of the main shaft (6).

Fasten the pins (4) by fitting the brackets (3) of the plate 99370153 to the middle box (2).

Turn the gearbox through 180°.


Figure 54



Take out the screws (2) and remove the pin (3) in the joint of the clutch uncoupling lever (1) with this lever.


Remove the screws (4) fixing the front cover (5) to the front box.

Figure 55




Screw down two screws (1) into the front cover (2) and detach this from the front box (3).

Figure 56



Remove the cap (3), the spring (4) from the transmission shaft (5) and the adjustment rings (1-2-6).


Figure 57



70871

Remove the circlip (4) fastening the bearing (1) to the drive input shaft (3). Remove the circlip (2) from the bearing (1).


Figure 58



78303

Using the extractors 99345078 (1) and 99345105 (2), extract the ball bearing (4) from the drive input shaft (3).

Figure 59




78304

Remove the speed sensor (5) and the cap (4) beneath.

Take out the four centring pins (1).

Remove the screws (2) fixing the middle box (6) to the front box (3).


Figure 60



78306

Fit the eyebolt 99366811 (1) onto the front box (2). Using special ropes and a hoist, detach the front box (2) from the middle one (3).

Figure 61




78305

! To perform the following operations, the gearbox must be positioned as shown in Figure 62 in order to avoid any chance of the transmission shafts falling.

Take out the screws (1) and remove the brackets (2) of the plate 99370153. Extract the reverse gear pins (3) from the middle box (4).


Figure 62



70875

Remove the phonic wheel (2) from the drive input shaft (1). Extract the oil pipes (4-6) from the middle box (7). Spread apart the transmission shafts (3-5) and remove them from the middle box (7).


Figure 63



Fit tool 99360527 (1) onto the drive input shaft (9) and the rods (2 and 3); fit parts (6-7 and 8) of tool 99360526 (4) onto the drive input shaft (9).

Hook tool 899360526 (4) onto the lifter and extract the main shaft (5) together with the drive input shaft (9) and rods (2 and 3) from the supporting bearing.

Figure 64



Remove the reverse gears (3) together with the roller bearings (2).


Remove the plate 99370153 (4).

If replacement is necessary, remove the centring pins (1).



Before removing the pins (1) heat the seats of the box to ~ 90°C.

Figure 65




Turn the middle box (1) upside-down, remove the circlip (2) and, working from inside the box, remove the roller bearing (4).

Using a punch, and operating through the openings (→) of the middle box (1), remove the external rings (3) of the tapered roller bearings for transmission shafts.

Removing the main shaft

Figure 66




Clamp the main shaft (6) in a vice and remove tool 99360526 (1) and 99360527 (2).

Remove the rods (3 and 4) with the relevant forks.



To remove the fork (5), the ring of the synchronizing device has to be in the middle position.

Figure 67



Through the bay of the coupling sleeve (1), using suitable pliers, tighten the ends of the circlip (2) and remove the drive input shaft (3) from the main shaft (4), see Figure 68.

Remove the coupling sleeve (1) and the tube (2) from the main shaft (4).

Turn the main shaft (3) upside-down and remove the coupling sleeve (4) from it; remove the key (5) from the hole (→) in the shaft (3) and extract it.




To extract the shoulder spacers (6 - 8 * - 9 * - 11 - 13 - 15 - 16 - 18) it is necessary to turn them so that their toothing is with the grooves of the shaft (3).

Extract:

- ☐ spacer (6);
- ☐ reverse gear (7);
- ☐ spacers (8 and 9) *;
- ☐ gear (10) *;
- ☐ spacer (11);
- ☐ coupling sleeve (12);
- ☐ spacer (13);
- ☐ 2nd gear (14);
- ☐ spacers (15 and 16);
- ☐ gear (17);
- ☐ spacer (18);
- ☐ tube (19).


* 16 AS 260I only

Figure 68



70882


Figure 69



If necessary, remove the circlips (1) from the gears (7 - 10 - 14 - 17, Figure 68) and extract the toothed ring (2).


Removing the drive input shaft

Figure 70




Extract the ring (2), key (3) and gear (4) from the drive input shaft (1).

Figure 71



Turn the drive input shaft (1) upside-down, lift the notches (→) of the safety cover (2) and take it off.


Figure 72



Remove the half rings (2) from the drive input shaft (1) and extract from it:


- ☐ thrust washer (3);
- ☐ thrust bearing (4);
- ☐ bushing (6) together with circlip (5);
- ☐ thrust washer (7);
- ☐ thrust bearing (8);
- ☐ gear (9);
- ☐ thrust bearing (10);
- ☐ thrust washer (11);
- ☐ synchronizing device assembly (12).

Figure 73



If necessary, remove the circlips (1-3) from the gear (4) and extract the toothed ring (2).


Figure 74



COMPONENT PARTS OF THE DRIVE INPUT SHAFT

Removing the splitter synchronizing device

Figure 75



Put the synchronizing device assembly (1) on the workbench, cover it with a cloth to prevent the pins (8) and springs (7) getting lost during subsequent dismantling.

Holding back the synchronizing device ring (6), lift the synchronizing device ring (2); these will get freed: toothed ring (5), three clips (7) and three pins (8).


Remove the key (4) and extract the toothed sleeve (3) from the toothed ring (5).

Fitting the splitter synchronizing device

Insert the three springs (7) and three pins (8) in the synchronizing device ring (1) and keep them in their seat with the centring pins 99370499 (2).



Position the toothed ring (4) on the synchronizing device ring (6). Fit the synchronizing device ring (1) in the toothed ring (4) and on the synchronizing device ring (6) so that the centring pins 99370499 (2) drive onto the pins (5) of the synchronizing device ring (6). Press on the synchronizing device ring (1) uniformly so that the components of the assembly fit together correctly. Take out the centring pins (2).

Figure 77



70891

Figure 76



70759


Insert the toothed sleeve (1) in the toothed ring (2) so that the race between the two toothings corresponds to the inside tothing of the ring (2) and allows it to rotate.

Turn the sleeve (1) so that the hole in it coincides with one of the three bays (→) of the toothed ring (1).

Then insert the key (3) as shown in the figure.

Fitting the main shaft


Figure 78



On the drive input shaft (1), fit:


- ☐ synchronizing device assembly (15);
- ☐ thrust washer (14);
- ☐ thrust bearing (13);
- ☐ gear (10) together with circlips (9 and 12) and toothed ring (11);
- ☐ thrust bearing (8);
- ☐ thrust washer (7);
- ☐ bushing (6) with circlip (5);
- ☐ thrust bearing (4);
- ☐ thrust washer (3);
- ☐ half rings (2).

Figure 79



Fit on a new safety cover (2) and notch it (→) at three/four equidistant points. Turn over the drive input shaft (1).


Figure 80



On the drive input shaft (1), fit: gear (4), key (3) and thrust washer (2).


Fitting the drive input shaft

Figure 81



In the gears (4), fit: Reverse – 1st – 2nd – 3rd gears and toothed rings (2) and fasten them to the gears with the circlips (1 and 3).

Figure 82




78309

Clamp the main shaft (2) in a vice. Fit on the tube (1). Put the shoulder spacer (3) in the ring groove (→). Turn the spacer (3) so that its internal toothing rests on that of the main shaft (2).

Insert the key (4) in the spacer (3) so as to prevent rotation and keep it in position.


Figure 83



78310

Mount the 3rd speed gear (2), put the spacer (4) in the ring groove (→). Turn the spacer (4) so that its internal toothing rests on that of the main shaft (1). Insert the key (3) in the spacer (4) and keep it in position.


Figure 84



78311

Put the spacer (3) in the ring groove (→). Turn the spacer (3) so that its internal toothing rests on that of the main shaft (1). Insert the key (2) in the spacer and keep it in position.


Figure 85



78312

Mount the 2nd speed gear (2), put the spacer (4) in the ring groove (→). Turn the spacer (4) so that its internal toothing rests on that of the main shaft (1). Insert the key (3) in the spacer (4) and keep it in position.


Figure 86



78314

Fit on the 1st/2nd gear coupling sleeve (1) with the larger internal groove (→) turned to the side of the key (2).


Figure 87



78315

Put the spacer (3) in the ring groove (→). Turn the spacer (3) so that its internal tootinging rests on that of the main shaft (1). Insert the key (2) in the spacer (3) and keep it in position.

Figure 88




78316

For 16 AS 206I gearboxes only, fit on the gear (2). Put the spacer (5) in the ring groove (→) so that its internal tootinging rests on that of the main shaft (1). Put the spacer (4) in the ring groove (→) so that its internal tootinging rests on that of the main shaft (1).

Insert the key (3) in the spacers (4 and 5) and keep it in position.

Figure 89




78317

For all gearboxes, fit on the reverse gear (2). Put the spacer (4) in the ring groove (→) so that its internal tootinging rests on that of the main shaft (1).

Extract the key (3) and insert it from the top side of the shaft (1) in the groove on this and in all the spacers, so that its bent portion goes into the hole (→) of the shaft (1).


Figure 90



70902

Fit on the reverse gear coupling sleeve (3) with the bay (2) coinciding with the key (1).

Figure 91




70903

Turn over the main shaft (2) and fit on the sleeve (1) with the bay (4) coinciding with the key (5).

Fit on the tube (3).

Figure 92



70904


Using suitable pliers, tighten the ends of the circlip (2) and fit the drive input shaft (1) onto the main shaft (3).



Make sure that the circlip (2) gets correctly positioned in the seat of the main shaft (3).

Splitter control fork Disassembly - Assembly

Figure 93




70879

Extract the plugs (2) from the splitter synchronizing device coupling fork (1) and fit on the new plugs.

Gear control forks Removal

Figure 94




70905

Dismantle the gear control fork assembly (1), suitably adjusting the ring (3) to prevent the gears simultaneously coupling and extracting from the rod (7): the coupling fork (6)*, pin (7), coupling fork (5), fork (2) and ring (3).

* 16 AS 2601 gearbox only

Fitting


Figure 95



Insert the pin (1) in the seat on the rod (3). Drive the reverse gear coupling fork (2) onto the rod (3), adjusting it so that the pin (1) gets positioned in the bay (→) of the fork (2).

70760


Figure 96



Drive the ring (1) and the 1st/2nd gear coupling fork (3) onto the rod (2). Position the fork (3) in the ring (1) so that on turning it the bay (→) of the fork (3) is inserted in the ring (1).

70761

Figure 97




16 AS 260I gearbox only, drive the 3rd/4th gear coupling fork (1) onto the rod (2).

Position the fork (1) in the ring (3) so that on turning it the bay (→) of the fork (1) is inserted in the ring (3).

70762

Figure 98




Position the fork assembly (2*-3) and the ring (1) assembled in this way so that the bay (→) of the reverse gear coupling fork (4) is inserted in the ring (1).

70763

* **16 AS 260I gearbox only**

Transmission shafts Disassembly - Assembly

Figure 99




Remove the inside rings (1-3) of the roller bearings from the transmission shaft (2), using the extractor 99347100 (4), grips 993471132 (6) and plug 99345057 (5).

To fit the rings (1 - 3) on the shaft (2) it is necessary to first heat them to 120°C.

Fitting the middle box


Figure 100



Heat the seat (3) of the cylindrical roller bearing (1) to ~ 90°C, fit this and fasten it to the middle box with the circlip (2).


If removed, refit the centring pins (4) after heating the seats of the box to ~ 90°C.

Figure 101




Fit the plate 99370153 (2) onto the middle box (1).

Figure 102




From inside the box (1), heat the seats of the rings (4) to ~ 90°C, transmission shaft bearings. Fit on the rings (4) with driver 99370092 (3) and grip 99370007 (2).

Figure 103




Place the reverse gears (1) together with the roller bearings (2) in the middle box.

Figure 104




Fit the fork assembly (1) onto the main shaft (2), verifying that the forks are correctly positioned on their respective coupling sleeves.

Figure 105




Mount the splitter coupling fork (1) positioning the plugs (2) on the toothed coupling ring (3).

Figure 106



Fit tool 99360527 (1) onto the drive input shaft (8) and the rods (2 and 3). Fit parts (5-6-7) of tool 99360526 (4) onto the drive input shaft (8).


Figure 107



Hook the tool 99360526 (1) onto the lifter and fit the main shaft assembly (5) in the gearbox, verifying that the shaft (5) and the rods (3 and 4) get correctly inserted in their seats.


Remove the tools 99360526 (1) and 99360527 (2).

Figure 108



Mount the transmission shafts (1 and 3) so that on joining them to the main shaft (2) the marks stamped on them are aligned. Use the slots (→) of the phonic wheel (4) to check this.


Figure I09



To perform the following operations, the gearbox must be positioned as shown in Figure I10 in order to avoid any chance of the reverse gears falling.

Insert the pins (3) in the middle box (4) and in the reverse gears (1, Figure I03), fastening them to the box (4) with the brackets (2) of plate 99370153 and the screws (1).


Figure I10



With no gears engaged, the shafts must turn freely, otherwise the alignment of the marks (see Figure I08) will not be correct.


Fit on the oil pipes (1 and 2).

Figure I11



COMPONENT PARTS OF THE MIDDLE BOX


* For the I6 AS 260I gearbox only

Fitting the front box**Figure 112**

COMPONENT PARTS OF THE FRONT BOX

70918

Figure 113



70819


Remove the screw (1), lift the cover (2), remove the vents (3) and clean them or replace them.

Then reassemble the parts.

Carefully clean the oil filter (6) and fit it back in its seat.

If the plugs (4) have been removed, it is necessary to fit them back on with new seals (5).


Figure 114



70920

Heat the front box (1) to 90°C in correspondence with the seats for the external rings (2 and 3) of the tapered roller bearings and fit these on.

Figure 115



70921

Spread IVECO sealant 1905685 onto the mating surface of the middle box (5).

Fit the eyebolt 99368811 (1) onto the front box (2).


Using ropes and a hoist, lift the box (2) and position it coaxially to the middle box (5).

Insert the rods (6), of suitable diameter, into the seats in the front box (2) of the oil pipes (7 and 8) and into these too.

Lower the box (2) checking that the rods (3 and 4) and the oil pipes (7 and 8) are correctly inserted in their seat.

Remove the eyebolt (1) and the guide rods (6).

Figure 116




78304

Screw down the screws (2) fixing the front box (3) to the middle box (6). Insert the centring pins (1) and tighten the screws (2) to the prescribed torque.


Mount the cap (4) and the speed sensor (5), tightening it to the prescribed torque.

Figure 117



Using the tools 99345098 (1) comprising parts (3-4 and 5) and 99360526 comprising parts (6-7 and 8), fit the ball bearing (11) on the drive input shaft (9) and in the front box (10).

Figure 118




Fit the circlip (4) fastening the bearing (1) to the drive input shaft (3).

Fit the circlip (2) onto the bearing (1).


Front cover Removal

Figure 119



Remove the screws (3) and take off the drive input shaft cover (1) from the front cover (2).

Figure 120



Take out the screws (1) and, through the front cover (5), take out the oil pump comprising: cover (2), rotor (3) and stator (4).

Introduce compressed air through the hole (→) and expel through the front cover (5): the overrun brake piston (8) comprehensive of gasket (9), clutch plates with external toothing (6), clutch plates with internal toothing (7) and supporting ring (10).

Fitting the front cover


Recompose the front cover (5) by reversing the operations described for removal, without parts (6 - 7 - 8).



The gasket (9) must always be replaced.

Adjusting drive input shaft bearing end float


Figure 121



Determine the thickness S of the drive input shaft bearing adjustment ring by proceeding in the following way:

- ☐ check that the circlip (1) of the bearing (2) rests in its seat;
- ☐ measure the protrusion of the bearing (2) from the surface of the front box (3), distance A .

Figure 122



70986

- measure the depth of the seat on the front cover (1) of the bearing (2, Figure 121), distance B.

The thickness S of the adjustment ring is determined by the following equation:

$$S = (A - B) - C$$

Where:

A-B = measurements

C = end float $0 \div 0.1$ mm

For example:

A = 5.50 mm


B = 3.90 mm

C = $0 \div 0.1$ mm

S = $(5.50 - 3.90) - 0 \div 0.1 = 1.59 - 1.60$ mm

Adjusting transmission shaft bearing end float

Figure 123




70925

Determine the thickness S of the transmission shaft bearing end float adjustment rings by proceeding in the following way:

- turn the shafts and check that the external rings (1 - 3) of the bearings rest with no play on the rollers of the bearings;
- measure the distance between the surface of the front box (2) and the external rings (1 - 3);
 - external ring (1) pump side, distance A.
 - external ring (3) overrun brake side, distance B

Figure 124



70926

- measure the distance between the surface of the front cover (2) and the oil pump (1), distance C;
- mount the overrun brake disc supporting ring (3) in the seat on the front cover (2) and measure the distance between this and the surface of the cover (2), distance D.

The thickness S of the adjustment rings is determined by the following equation:

$$\bullet \text{ oil pump side } S = A + C + F$$

A - C = measurements

F = end float ± 0.05

For example:

$$S = 2 + 0.05 (\pm 0.05) = 2 \div 2.1$$

$$\bullet \text{ overrun brake side } S = B + D + F$$


B - C = measurements

F = end float ± 0.05

For example:

$$S = 1.95 + 0.15 (\pm 0.05) = 2.05 \div 2.15$$


Figure 125



70870

On the external rings of the bearings supporting the drive input and transmission shafts, mount the end float adjustment rings (1 - 2 and 6) of the thickness determined in the preceding measurements. Insert the spring (4) and the cap (3) in the transmission shaft (5).


Figure 126



70869

In the sequence shown in the figure, position: the supporting ring (3), clutch plates with internal tooting (2) and clutch plates with external tooting (1).


Figure 127



70927

Spread IVECO sealant I 905685 onto the surface of the front box (1) mating with the cover (2). Adjust the key of the oil pump shaft so that it coincides with the coupling milling of the transmission shaft. Fit on the cover (2) and tighten the screws (3) to the prescribed torque.


Figure 128



46007

Using the driver 99374336 (2) and grip 99370007 (1), fit the seal (3) in the drive input shaft cover (4).

Figure 129




70928

Lubricate the sealing surface of the seal with Unisilikon.

Spread IVECO sealant I 905285 onto the surface of the front box (1) mating with the cover (2). Mount the cover (2). Spread LOCTITE 241 onto the thread of the screws (3) and tighten them to the prescribed torque.

Clutch release lever


Figure I30



70929

The bushings (2 and 4) and seals (1 and 5) of the lever (3) are changed by using a suitable drift for removing – fitting new parts.


Figure I31



70930

Insert the joint pin (4) into the lever (2) and tighten the screws (3), fixing it to the front box (1), to the prescribed torque.

Figure I32




78301

Turn over the gearbox.

Remove the plate 99370153 (1) and the brackets (3) fastening the pins (4) from the middle box (2).

Figure I33



70865

Fit: the plate (1) together with the coupling body (2), adjustment ring (3), connecting sleeve (5) and rod (4).

Complete assembly of the gearbox by refitting the rear box and the speed actuator as described under the relevant headings.

On completing assembly, replenish the gearbox with the prescribed grade and quantity of lubricating oil.

**Gearbox EuroTronic
12 AS 230I D.D./O.D. with Intarder (IT)**

	Page
SPECIFICATIONS AND DATA	161
OVERHAULING THE GEARBOX	162
☐ Removing the hydraulic retarder	163
☐ Refitting the hydraulic retarder	163
☐ Adjusting epicyclic reduction gear train bearing end float	163
☐ Adjusting stator end float	164
☐ Removing the rear box	165
☐ Removing the E.R.G.	166
☐ Fitting the E.R.G.	167
EXPERIMENTAL TOOLS	172

EuroTronic Automated 12 AS 230I D.D./O.D. with intarder



This differs from the 12 AS 230I D.D./O.D. gearbox in the following:

SPECIFICATIONS AND DATA



	GEARBOX Type	EuroTronic Automated 12 AS 230I D.D./O.D. with intarder
	Maximum braking torque Nm	3000
	Braking capacity Kw	520
	Type of oil	Tutela Truck FE-Gear Tutela ZC 90
	Quantity after overhauling gearbox and retarder drained completely litres	21
	kg	19

Figure I




D.D. = Direct Drive
O.D. = Over Drive (Multiplied)

70831

530210 OVERHAULING THE GEARBOX

Removing the hydraulic retarder

Figure 2




78649

Unscrew the ring nut (1 and 5) and disconnect the electric wiring (2) from the speed sensor (6 and 7).

Detach the wiring (2) from the clips (→) securing it to the middle box.

Remove the nuts (4) and detach the actuator (3) from the front box.

Figure 3




78652

Fit spacers SP. 2396 (2) and fasten the gearbox (1) to brackets 99322225 (3) on the rotating stand 99322205 (4).

Drain off the lubricating oil by removing the plugs from the Intarder and from the gearbox.


Figure 4



70934

If applicable, remove the four nuts (2) fixing the heat exchanger (1) to the hydraulic retarder (3) and detach the heat exchanger (1).


Figure 5



70936

Remove the screw (1) and the washer (2) beneath. Extract the plug (3) with the seal (4), oil filter (5) and magnet (6).


Figure 6



78324


Block rotation of the sleeve (2) by applying the lever 99370317 (1) to it and remove the screws (3), disc (4) and underlying seal (5).

Figure 7




Using an extractor composed of the bridge 99341003 (3), brackets 99341018 (2) and reaction block 993410134 (4), remove the sleeve (1) from the shaft (5).

Figure 8



Remove the screws (1) fixing the hydraulic retarder (2) to the rear box (3).

Figure 9



Fit the eyebolt 99370565 (1) to the hydraulic retarder (2). With special ropes and lifter, detach the hydraulic retarder (2) from the rear box.


Remove the adjustment rings (3 and 4) and the gasket (6).

Refitting the hydraulic retarder

Before refitting, determine the thickness of the adjustment rings (3 and 4 Figure 9) as follows:

Adjusting epicyclic reduction gear train bearing end float


Figure 10



Determine the ball bearing end float adjustment thickness (1) by proceeding as follows:

- ☐ measure the protrusion of the bearing (1) from the surface of the rear box (2): distance A;

Figure 11



- ☐ measure the distance between the sealing surface (1) of the half box of the retarder and the supporting surface of the bearing (1, Figure 10): distance B;
- ☐ measure the thickness of the gasket between the retarder and gearbox: distance C.

The thickness S of the adjustment ring is given by the following equation:


$$S = [B + C - A] - G$$

where:

- ☐ B - C - A = measurements
- ☐ G = 0.1 mm: end float of the ball bearing (1 Figure 10) (0 ÷ 0.1 mm)

Adjusting stator end float

Figure 12



70946


Determine the thickness **S** of the stator end float adjustment ring:

- ☐ using a depth gauge (1) and calibrated rule (2), measure the distance between the sealing surface of the half boxes and the supporting surface of the stator (3): distance **A**;
- ☐ measure the thickness of the gasket between the retarder and gearbox: distance **B**.

The thickness **S** of the stator end float adjustment ring is given by the following sum: **S = A+B+C**

- ☐ **A** and **B** = measurements
- ☐ **C** = 0.05 mm: stator end float adjustment ring pre-load. (- 0.05 ÷ 0.05 mm)

Figure 13



78327


Fit the eyebolt 99370565 (1) to the hydraulic retarder (2) and lift it with a hoist.

Position the adjustment rings (3 and 5) of the thickness determined in the preceding measurements on the bearing (4) and on the seat (→) of the stator.

Fit a new gasket (6) on the rear box.

Mount the hydraulic retarder (2) on the rear box (7) making sure that the gasket (6) gets positioned correctly.


Figure 14



70948

Screw down the screws (2) fixing the hydraulic retarder (1) to the rear box (3) and tighten them to the prescribed torque.

Figure 15




70949

Heat the flange (2) to approx. 80°C and fit it onto the spider shaft (1).

Fit on a new seal (5), the disc (4), screw down the screws (3) and tighten them to the prescribed torque.


Figure 16



70954

Block rotation of the sleeve (1) by applying the lever 99370317 (3) and tighten the fixing screws (2) to the prescribed torque.

Figure 17




70936

Position the magnet (6) on the filter (5) and insert this into the hydraulic retarder. Fit the plug (3) with a new seal (4).

Screw down the fastening screw (1) with the washer (2).


Figure 18



70955

Fit two new seals (2) on the hydraulic retarder (3) and mount the heat exchanger (1) (if applicable).


Figure 19



70934

Screw down the four nuts (2) fixing the heat exchanger (1) to the hydraulic retarder (3) and tighten them to the prescribed torque.

Figure 20




70933

Connect the electric wiring (1) to the speed sensor (3) and tighten the ring nut (2).

Replenish the gearbox with the prescribed grade and quantity of lubricating oil.

Removing the rear box

Figure 21



70937


Disconnect the gear actuator, as described in the respective chapter.

Remove the hydraulic retarder as described under the relevant heading.

Remove the screws (4) fixing the plates (3) fastening the pins (6) and extract these together with the seals (5) from the central box (7).

Extract the two centring pins (2) and remove the screws (8) of fixing rear box (1).


Figure 22



Fit the eyebolt 99366811 (1) to the shaft (2) of the epicyclic reduction gear (2). Using special ropes and lifter, detach the rear box (3) from the middle box (4).


Removing the E.R.G.

Figure 23




Using a press, extract the E.R.G. spider shaft (1) from the supporting ball bearing (2). Turn the rear box (3) upside-down and extract the ball bearing (2).

Figure 24




Remove the screws (2) securing the gear (3) to the spider shaft (1).

Figure 25




Using an extractor composed of: bridge 99341004 (1), stays 99341012 (2), reaction block 99345056 (3) and clamp 99341015 (5), extract the gear (6) from the spider shaft (4).

Figure 26




Using a screwdriver, remove the circlip (3) fastening the ring gear with internal tothing (4) to the ring gear with external tothing (2) and remove them from the E.R.G. (1).

Figure 27



Extract the toothed ring (2) from the ring gear with internal tothing (1).


Figure 28



70838

Using pliers (2), tighten the ends of the circlip (3) and remove the coupling body (4) from the E.R.G. shaft (1).


Figure 29



70839

Using a punch, extract the pins (5) from the spider shaft (6). Remove the planetary gears (3) from the spider shaft (6), together with the rollers (2) and shim adjustment rings (1 and 4).


Figure 30



70840

Extract the toothed spindle (3) from the spider shaft (1) together with the rings (2).


Figure 31



70842

Using a suitable extractor, remove the roller bearing ring (1) from the spider shaft (2). Using a punch, extract the disc (3) from the inside of the spider shaft (2).

Figure 32




71841

Extract one of the pins (1) from the toothed spindle (2) and extract the rings (3) from this.

Fitting the E.R.G.

Figure 33




70844

Heat the inside ring (2) of the roller bearing to and fit it on the spider shaft (3).

Fit on the circlip (1). Fit on the disc (4).

Figure 34




PARTS COMPRISING THE E.R.G.

1. Circlip - 2. Ring gear with external toothings - 3. Toothed ring - 4. Ring gear with internal toothings - 5. Bearing - 6. Circlip - 7. Circlip - 8. Coupling body - 9. Pins - 10. Ring - 11. Toothed spindle - 12. Disc - 13. Spider shaft - 14. Pin - 15. Shim adjustment ring - 16. Rollers - 17. Shim adjustment ring - 18. Planetary gear - 19. Gear - 20. Screw.


70943

Figure 35




Drive the rings (1 and 3) onto the toothed spindle (2) and fit on the pin (4).

Figure 36




Insert the spindle (3) together with the rings (2) onto the spider shaft (1).

Figure 37




Smear grease into the hole of the planetary gear (5) and insert the rollers (3) with the associated shim adjustment rings (2 and 4). Fit the planetary gears (5) onto the spider shaft (6), fastening them to it with the pins (1).

Figure 38




On the spider shaft (3), fit the ring gear with internal toothing (5) together with the toothed ring (4), and the ring gear with external toothing (2) and fasten the two ring gears with the circlip (1).

Figure 39




Heat the gear (3) to $120^{\circ}\text{C} \pm 130^{\circ}\text{C}$ and fit it onto the spider shaft (1). Screw down the fixing screws (2) and tighten them to the prescribed torque.

Figure 40



Heat the seat of the bearing (1) of the rear box (2) to 90°C and mount the bearing (1).


Figure 41



48946

Rest the spider shaft (1) on an appropriate spacer. Heat the inside ring of the bearing (2) to approx. 100°C and drive it together with the rear box (3) onto the spider shaft (1).


Figure 42



78364

Take out the screws (1) and remove the cover (2) with its seal (3). Remove the screw (4) with the washer (5).

Figure 43



78329


Spread IVECO sealant 1905685 onto the mating surface of the middle box (7). Fit the eyebolt 99366844 (1) onto the shaft (2).

Using ropes and a lifter, position the rear box (4) coaxially to the middle one (7).

Insert a rod (3) of appropriate diameter in the hole for the screw (4, Figure 42) and in the oil pipe (5) to guide this into its seat while lowering the rear box (4).

Lower the rear box (4), paying attention that the spider shaft, oil pipe (5) and rod (6) go into their seat correctly.

Figure 44




70937

Screw down the screws (8) without tightening them; insert the centring pins (2) and tighten the screws (8) to the prescribed torque.

Fit the fork joint pins (6) with fresh seals (5) and tighten the screws (4) fixing the fastening plates (3) to the prescribed torque.

Figure 45




Fit the screw (4) with a new washer (5) and tighten it to the prescribed torque.

Fit the cover (2) with a fresh seal (3) and tighten the fixing screws (1) to the prescribed torque.

Then refit the hydraulic retarder (6) as described under the relevant heading.

EXPERIMENTAL TOOLS

This heading covers the working drawing for the experimental tool (S.P. 2396) used when overhauling the gearbox described in this section, which can be made by the repair shop.



Modification:

For the permissible errors on the dimensions without tolerance and for other general specifications, see **IVECO** STD 10-2311

MAT. Fe 360		COVER. /	DRAWN UTS (B)	N'DRAWING SP. 2396	
All proprietary rights reserved by IVECO. This drawing shall not be reproduced or in any way utilised, for the manufacture or the component or unit herein illustrated and must not be released to other parties, without written consent. Any infringement will be legally pursued.	ISO ≤ IT8 4 ≤ 30' Ra ≤ 0.4	Serie di 3 distanziali		APPROVED	EXPER. 2396
		per posizionamento cambio		DATE 12/09/2002	SIZE A4
		al cavalletto 99322205+99322225		SUPERSEDES	SHEET
		Tipo EUROTRONIC 2 + INTARDER		SCALE 1:1	
I.S. 18-0011		3		Q.TY	

02

5302 Gearboxes

Allison MD 3060 PR

Allison MD 3066 PR

	Page
DESCRIPTION	175
TECHNICAL DESIGNATION	178
☐ Identification plate	178
CHARACTERISTICS AND DATA	179
MAIN OPERATION ANOMALIES	180
TIGHTENING TORQUES	188
TOOLS	188
REMOVAL AND REFITTING OF THE TRANSMISSION	189
☐ Removal	189
☐ Refitting	189
DISCONNECTING AND CONNECTING GEARBOX CONTROL MODULE AGAIN ..	192
☐ Disconnecting	192
☐ Refitting	192
REPLACING SPEED SENSORS	192
☐ Replacing turbine speed sensor	192
☐ Engine revolutions sensor replacement	193
☐ Replacing the output speed sensor	193
REPLACING OIL LEVEL SENSOR	193
REPLACING OIL SUCTION FILTER	194
REPLACING THE SOLENOID VALVES	194
REPLACING PLANE GASKETS IN GEARBOX CONTROL MODULE	195
REPLACING PRESSURE SWITCH F3	196
REPLACING THE SEAL RING ON THE OUTPUT SHAFT	196

DESCRIPTION


Allison MD 3060 PR-MD 3066 PR gearboxes are automatics and provides six forward gears and one reverse gear through an hydrodynamic torque converter, two clutches, three brakes and three crown wheels.

The 5th and 6th gears are overgeared up.

The reverse gear has a ratio that is greater than the first gear that allows a better speed control on slopes.

They are fitted with a power takeoff device and an integrated retarder for noiseless and progressive braking.

Figure I



ALLISON AUTOMATIC GEARBOX

61402

Clutches are pressure-balanced on both piston sides to prolong the clutch life and for a more accurate control on the whole range of gearbox gears.

Planetary gears always being engaged are of the helical teeth type to allow a more silent gearbox operation.

The hydrodynamic torque converter, in addition to being mandatory for vehicle start-up, allows a gearbox operation without shakes reducing wear of members composing the vehicle kinematic chain.

The torsional forces emitted by the engine are absorbed due to the clutch/damper lockup so that they are not transmitted to gears and the remaining parts of the transmission. The wide lockup operation reduces fuel consumption and improves braking efficiency.


The gearbox is equipped with the power takeoff gear. (5 - Figure 2).

The power takeoff can be installed on the left or on the right side of the converter box (7 - Figure 3; 3 - Figure 4).

Gear selection is controlled by an electronic transmission control system with a microcomputer.

The closed-loop control logic employed by the electronic control system allows the transmission to adapt to changes in the load, terrain or ambient conditions and to automatically compensate for fluctuations in engine power output and for component wear.

Figure 2




ALLISON MD 3060 PR/3066 PR AUTOMATIC GEARBOX

61783

1. Exclusion clutch/torsional damper lockup - 2. Converter turbine - 3. Converter pump - 4. Converter box - 5. Power takeoff gear - 6. Front support - 7. Clutch box - 8. Clutch - 9. Main box - 10. Brake - 11. Front planetary gear - 12. Brake - 13. Central planetary gear - 14. Brake - 15. Rear planetary gear - 16. Retarder stator - 17. Retarder - 18. Retarder rotor - 19. Output shaft - 20. Main shaft - 21. Hydro-electric controls - 22. Clutch - 23. Oil pump - 24. Oil pump driving stub - 25. Front support sleeve - 26. Converter stator - 27. Turbine shaft.

Figure 3




61786

MD 3060 PR AUTOMATIC GEARBOX REAR RIGHT VIEW

1. Assembly pads - 2. Exchanger arrangement - 3. Pressure control socket - 4. Electric gearbox wiring connector - 5. Identifying plate - 6. Engine revolution sensor - 7. Power takeoff connection (available on both sides) - 8. Exhaust

Figure 4




61787

MD 3060 PR AUTOMATIC GEARBOX FRONT LEFT VIEW

1. Start-up crown - 2. Front torque converter cover - 3. Power takeoff connection (available on both sides) - 4. Pressure control socket - 5. Retarder accumulator - 6. Oil filling pipe and level rod (available on both sides) - 7. Retarder - 8. Assembly pads

TECHNICAL DESIGNATION

Figure 5



The first two letters (initials of "MEDIUM DUTY") and the first number denote the series.

The second figure can be "0" or "5". If it is "5" the transmission has higher gear ratios for the first, second and third gear.

The third figure corresponds to the number of available forward gears.


The fourth figure is different from "0" when the transmission has relevant building changes compared to the basic production model. For example, on transmission MD 3066 the final figure "0" is replaced by figure "6" because this type of transmission is fitted with a clutch having a higher number of discs to be used on Diesel engines with uprated power.

The letters refer to additional equipment, such as: power takeoff prearrangement, retarder, transfer case.

Identification plate





The identification plate is located on the right-hand side of the transmission at the rear.

Figure 6



To order new transmissions or to request information for technical service you should give all the three numbers.

CHARACTERISTICS AND DATA

	TRANSMISSION	ALLISON	
		MD 3060 PR	MD 3066 PR
	Type	Automatic	
	Forward runnings Reverse running	6 forward gears and 1 reverse gears	
	Power take-off	Optional	
	Gears	With always-engaged helical teeth	
	Gear ratios (*)	First 3.49 Second 1.86 Third 1.41 Fourth 1.00 Fifth 0.75 Sixth 0.65 Reverse 5.03	
	Gross absorption power (max)	205 kw	225 kw
	Gross absorption torque (max)	1085 Nm	1111 Nm
	Nominal speed (mix)	2000 rpm	
	Nominal speed (max)	2800 rpm	
	Lubrication circuit oil	Tutela GI/A 18 liter	

(*) The gear ratio does not include torque converter gearing up

MAIN OPERATION ANOMALIES

This paragraph lists main operation anomalies that are not identified by a diagnostic code.

For every problem, causes and related remedies are shown.




For the search of failures through a diagnostic code, refer to section "Electric/electronic system" of "Allison automatic gearboxes" Manual (printout No. 603.42.407)

- 4 - The gearbox does not insert a specific selection;
- 5 - The gearbox does not correctly perform the selections;
- 6 - No response from gear selector;
- 7 - Clutch slippage and vibration in all ranges;
- 8 - Low main pressure in all ranges;
- 9 - Low lubrication pressure;
- 10 - Overheatings in all ranges;
- 11 - Some oil emerges from filling pipe and/or exhaust;
- 12 - Intermittent noises (hum);
- 13 - Oil leakage from output shaft;
- 14 - Dirty oil.

The operation anomalies being examined in this section are as follows:

- 1 - The vehicle fails to start (engine is not started up);
- 2 - The gearbox does not perform forward range or reverse gear selections (it remains idle);
- 3 - The gearbox does not remain in forward gear or in reverse gear;



2

**THE GEARBOX DOES NOT PERFORM
FORWARD RANGE OR
REVERSE GEAR SELECTIONS
(IT REMAINS IDLE)**

Engine idle speed too high.

- YES →

Adjust engine idle speed to between 500 and 800 rpm.

NO



Fluid level low.

- YES →

Top up fluid to correct level.

NO



Connectors loose or dirty.

- YES →

Connect or clean.

NO



Speed sensors faulty.

- YES →

Replace speed sensors.

3

**THE GEARBOX DOES NOT REMAIN IN
FORWARD GEAR OR IN
REVERSE GEAR**

Fluid leaking from solenoid valve unit.

- YES →

Overhaul the solenoid valve unit.

NO



Faulty solenoid valve.

- YES →

Replace solenoid valve.

4

THE GEARBOX DOES NOT INSERT A SPECIFIC SELECTION

Incorrect fluid level.

- YES →

Adjust fluid level.

NO



Speed sensors faulty.

- YES →

Replace speed sensors.

NO



Fluid temperature sensor faulty.

- YES →

Replace fluid temperature sensor.

5

THE GEARBOX DOES NOT CORRECTLY PERFORM THE SELECTIONS

Engine idle speed too high.

- YES →

Adjust engine idle speed to between 500 and 800 rpm.

NO



Speed sensors faulty.

- YES →

Replace speed sensors.

NO





Speed sensors loose.


- YES →


Tighten speed sensor mounting bolts.

(To be continued)









13

**OIL LEAKAGE FROM
OUTPUT SHAFT**

Seal in output flange faulty or missing.

- YES →

Fit a new seal.

NO



Bolts of output flange loose.

- YES →

Tighten output flange bolts.

NO



O-ring of flange retaining plate damaged or missing.

- YES →

Replace flange retaining plate O-ring.

14

DIRTY OIL

Fluid and filters require changing.

- YES →

Change fluid and filters.

NO



Overheating.

- YES →

See point 10.

NO



Fluid filters/seals damaged.

- YES →

Replace filter/seals.

NO



Inferior quality fluid.




- YES →

Use recommended fluid.

TIGHTENING TORQUES

PART	TORQUE	
	Nm	(kgm)
Screws securing converter box to engine	49 to 58	(4.9 to 5.8)
Screws securing adapter - flexible plate	34	(3.4)
Hose fittings for gearbox-exchanger connection	54 to 68	(5.4 to 6.8)
Connection ring nut of external wiring to electric gearbox connector	2 to 3	(0.2 to 0.3)
Screws securing control module to gearbox	57 to 68	(5.7 to 6.8)
Oil filter covers screws	51 to 61	(5.1 to 6.1)
Oil drain plug	25 to 32	(2.5 to 3.2)
Turbine speed sensor securing screw	12 to 14	(1.2 to 1.4)
Engine revolution sensor securing screw	30 to 35	(3 to 3.5)
Output speed sensor securing screw	30 to 35	(3 to 3.5)
Suction filter cover securing screw	12 to 14	(1.2 to 1.4)
Screw securing valve bodies to control module	12 to 14	(1.2 to 1.4)
Screws connecting pressure switch to valve body	5 to 8	(0.5 to 0.8)
Electronic gearbox connector screws	5 to 7	(0.5 to 0.7)
Pressure plugs on gearbox bottom	10 to 13	(1 to 1.3)
Output flange screws	30 to 35	(3.0 to 3.5)
Vent	12 to 16	(1.2 to 1.6)

TOOLS

TOOL NO.	DENOMINATION	
99360322		Engine flywheel rotation tool
99370629		Gearbox bearing support during vehicle disconnection and re-connection
99374013		Keying device for sealing ring assembly

REMOVAL AND REFITTING OF THE TRANSMISSION

Removal

In order to disassemble the transmission, proceed as follows:

- ☐ place the vehicle over a ditch or a lift bridge;
- ☐ disconnect the battery leads in order to avoid possible short circuits;
- ☐ drain transmission oil at running temperature (71 to 93 °C) by removing the dump cap(6);
- ☐ close the heat exchanger cooling liquid taps.

From the upper part of the transmission, remove:

- ☐ hose clips (11), (14), (16) of hoses (12) and (15);
- ☐ electrical connections (↔) on the transmission and the accumulator (22);
- ☐ the delivery line (21) to the accumulator (22);

From the lower part of the transmission, remove:

- ☐ clamp (4), screw (5) and nut (18); then remove pipe (7);
- ☐ cross member (3) by removing screws (19);
- ☐ hose clamps (2) and (17), brackets (1) and (20) and remove hoses (12) and (15) from the oil cooler (position hose (12) in such a way that it does not impede removal of the transmission).
- ☐ disconnect the propeller shaft (10) from the transmission output flange.
- ☐ remove bolts (8) through access hole A, turning the fly-wheel with tool (9) 99360322 to bring each bolt into view.
- ☐ support the transmission on a hydraulic trolley jack equipped with support 99370629.
- ☐ remove screws (13) and carefully remove the transmission from the vehicle.

Refitting

Carry out the steps that were performed to disassemble backwards, and tighten screws and nuts to prescribed torque.

On completion of the refitting operation, restore the coolant and transmission fluid to their correct levels.

Figure 7





Figure 8

52121


DIAGRAM SHOWING CONNECTION BETWEEN TRANSMISSION AND ENGINE

- I. Engine flywheel - 2. Spacer - 3. Crankshaft - 4. Connection plate - 5. Transmission - 6. Connection plate adapter -
7. Converter housing - 8. Coupling flange - 9. Flywheel housing.

DISCONNECTING AND CONNECTING GEARBOX CONTROL MODULE AGAIN

Disconnecting

Figure 9



Position vehicle on a bridge.

Drain gearbox oil at operating temperature ($71^{\circ} + 93^{\circ}\text{C}$) removing the drain plug (2) of the control module (1). After having discharged the oil, re-assemble the plug (2) with a tightening torque equal to $25 \pm 32 \text{ Nm}$.

Disassemble oil filter covers (3) by unscrewing the 12 screws securing the gearbox control module. Remove filters and gaskets.

Disconnect the electric connector connecting external wiring to gearbox.

Hold gearbox control module with a proper hydraulic jack fitted with a support (module weighs 25 kg.).

Unscrew all the screws securing the gearbox control module to the main box.

By adequately operating, remove control module from gearbox compartment.

Refitting



To assemble gearbox control module, properly reverse operations described at disconnecting.

Comply with torque shown in table on page 188.

At the end of assembly check whether oil drain plug is well tightened, then introduce 18 litres of Tutela GI/A oil through filling pipe.





The below-described repair interventions deal only with replacement of faulty components: for possible diagnostics information pertaining there to, refer to Section "Electric/electronic system" of "Allison automatic gearboxes" Manual (printout No. 603.42.409).

REPLACING SPEED SENSORS

Replacing turbine speed sensor

Figure 10



To replace turbine speed sensor (2), disassemble gearbox control module complying with the previously described procedure.

Disconnect wiring from sensor (3).

Unscrew the two screws (1) connecting sensor to valve casings.


Install the new sensor by tightening screws (1) to a torque of 12 to 14 Nm.

Connect wiring (3) to sensor.

Assemble gearbox control module again according to the previously described procedure.

Engine revolutions sensor replacement

Figure 11



Disconnect wiring (3) of engine revolution sensor (2).


Remove sensor (2) by unscrewing the screw securing it to converter cover (1).

Install the new sensor by tightening the stop screw to a torque of 30 to 35 Nm.

Connect wiring (3) to sensor.

Replacing the output speed sensor

Figure 12



Disconnect wiring (3) from output speed sensor (2).


Remove sensor (2) by unscrewing the screw securing it to the rear cover (1).

Install a new sensor by tightening the stop screw to a torque of 30 to 35 Nm.

Connect wiring (3) to sensor.

REPLACING OIL LEVEL SENSOR

Figure 13



To replace oil level sensor (1) disassemble gearbox control module according to the procedure described in this Section on page 192.

Disconnect wiring from sensor (1).

Unscrew screws (2) and remove sensor.


Install the new sensor by tightening the connecting screws according to the prescribed torque.

Connect wiring to sensor (1).

Assemble gearbox control module again according to the procedure described in this Section on page 192.

REPLACING OIL SUCTION FILTER

Figure 14




52068

Disassemble gearbox control module according to the procedure described in this Section on page 192.

Disassemble filter cover (1) by unscrewing the screws securing it to oil sump (2).

Figure 15



52069

Remove cover (1) and replace filter (2), gasket (3) and seal (4).


Install cover (1) and tighten securing screws to a torque of 12 to 14 Nm.

Assemble gearbox control module again according to the procedure described in this Section on page 192.

REPLACING THE SOLENOID VALVES

Disassemble gearbox control module according to the procedure described in the present Section on page 192.

Figure 16



52070

- Solenoid valves (1), (2) and (3) belong to the N/C type (Normally Closed). To operate on these solenoid valves disconnect the wiring corresponding to the valves and disassemble valve casings (6) from the gearbox control module by unscrewing the screws connecting it to the oil sump (4).
- Solenoid valves (9) and (11) belong to the N/O type (Normally open); solenoid valve (10) belongs to the N/C type (Normally Closed). For operating on these solenoid valves, disconnect the wiring corresponding to the different valves and disassemble valve casings (7) from the gearbox control module by unscrewing the screws connecting it to the oil sump (4).
- To replace solenoid valve (8) (N/C type), disconnect wiring from all the solenoid valves and disassemble valve casing (6) and (7), by unscrewing the screws securing them to the oil sump (4). Remove separating plate dividing valve casings (6) and (7) from valve casing (5): Remove casing (5) from gearbox control module.



In the three case (a, b, c) proceed as follows with replacing the failed solenoid valve after disassembling the valve casing containing it:

- ☐ Remove the pin securing the solenoid valve from the valve casing bottom.
- ☐ Remove the failed solenoid valve from the valve casing.
- ☐ Install the new solenoid valve with the two O-rings in the kit.
- ☐ Use the pin to lock the solenoid valve.

After replacing the solenoid valve assemble the solenoid valve casings again by properly reversing the operations described in items a, b, c, and tighten screws to a torque of 12 to 14 Nm. Re-assemble the control module according to the procedure described in the present Section on page 192.

REPLACING PLANE GASKETS IN GEARBOX CONTROL MODULE

Figure 17



52071

Disassemble the gearbox control module according to the procedure described in this Section on page 192.

The control module is connected to the main gearbox box by interposing a plane gasket (1), that can be replaced once having disassembled the control module.

There is second plane gasket interposed between the oil sump (2) and the separating plate (3) on which the control module components are laying.

To replace this last gasket, proceed as follows after disassembling the control module from the remaining part of the gearbox:


- ☐ Disconnect all the internal wiring connectors (10);
- ☐ Disassemble electric connector (8) from control module;
- ☐ Disassemble the oil suction filter (9);

- ☐ Disassemble the oil level sensor (4);
- ☐ Disassemble the valve casings (5), (6), (7);
- ☐ Remove the separating plate (3);
- ☐ Replace the worn out gasket with a new one and position it on oil sump (2) with the help of guiding pins (11);

Assemble the control module again by properly reversing the above mentioned operations.

Comply with torque shown in table on page 188.

Connect control module again to the main gearbox seat complying with the procedure described in this Section on page 192.

REPLACING PRESSURE SWITCH F3**Figure 18**

Disassemble the control module according to the procedure described in this Section on page 192.

Disconnect connector (2) in pressure switch (1).


Remove pressure switch (1) by unscrewing the two screws connecting it to valve casing (3).

Install the new pressure switch and use the O-ring in the kit.

Tighten the securing screws to a torque of 5 to 8 Nm.

Connect the pressure switch connector again.

Assemble the control switch again according to the procedure described in this Section on page 192.

REPLACING THE SEAL RING ON THE OUTPUT SHAFT**Figure 19**

Disconnect the transmission shaft from gearbox flange (2).

Unscrew screws (1) connecting securing plate (3) to the gearbox output shaft.

Remove the safety plate, the securing plate, the O-ring and the gasket.

Remove flange (2) from the rear cover (4) and use a proper tool to remove the seal ring.

Clean the seal ring seat and remove any slag present.

Replace the seal ring and the O-ring. Use keying device 99374013 to insert the seal ring in its seat.

Assemble gearbox flange again by properly reversing the above mentioned operations.

Tighten screws (1) to a torque of 30 to 35 Nm.

Connect the transmission shaft to the gearbox again.


Transmission external control (except for vehicles equipped with Eurotronic – Allison gearshift)

	Page
TRANSMISSION EXTERNAL CONTROL	199
☐ Transmission tie rod adjustment	199
SIDE TIE ROD	200
☐ Removal	200
☐ Refitting	201
TELESCOPIC TIE ROD	201
☐ Removal	201
☐ Refitting	201
TRANSMISSION IDLER ARM	201
☐ Removal	201
☐ Disassembly	202
☐ Assembly	202
☐ Refitting	202
CROSS TIE ROD	203
☐ Refitting	203
☐ Removal	203

5050 TRANSMISSION EXTERNAL CONTROL

505020 Transmission tie rod adjustment

Figure 1



79132

Put the gearshift in neutral position and check that the angle is:

- ☐ 30° for transmission 9 S 109 (detail A);
- ☐ 90° for transmissions: 16 S 151/181/221 (detail B) installed on vehicles with engine F2B;
- ☐ 45° for transmissions 16 S 151/181/221 (detail B) installed on vehicles with engine F3A.


Should a different value be detected, detach lever (8) from bar (9) and orientate the lever as required.

In the such conditions:

- ☐ the idler arm (4) should form a 90° angle with the telescopic tie rod (3); otherwise release the nut (6) and turn the ball joint (7) until the prescribed angle is reached;

- ☐ observing the tie rod connection (5) and the ball joint (7) from the top they should form a straight line; if not, release the nuts (10 – 12) and turn the tie rod (11) as required
- ☐ the lever(1) should be completely perpendicular to the plane; if not, release the fastening nuts (2) and orientate the lever as required (1).

Figure 2




79133

TRANSMISSION COMPONENT DETAILS

505021 SIDE TIE ROD Removal

Figure 3




79134

Remove the nut (2) and disconnect the articulated head (3) from the side tie rod (1).
 Disconnect the articulated head (3) from the lever (4).
 Remove the nut (6) and disconnect the ball joint (5) from the lever (7).



If the ball joint (5) is to be replaced, first release the retaining nut (4) and then write down the number of turns needed to slacken it from the tie rod (1), so that the new element will be driven in with the same number of turns and the transmission adjustment will be maintained.


Figure 4



79135

Mark the universal joint (1) assembly position on the tie rod (4), release the nut (2) and remove the telescopic tie rod universal joint (1) from the tie rod (4).
 Remove the articulate head pin (5) fastening nut (3) of the idler arm (6).

Figure 5



Use press 99341015 (1) and a suitable plate (4) positioned as shown in the figure to remove the articulated head (3) from the tie rod (2) and the tie rod itself.


Refitting

Refit the side tie rod by reversing the removal procedure. Make sure the nuts are tightened to the prescribed torque and check that the tie rod adjustment corresponds to that described in the Transmission tie rod adjustment section.

505023 TELESCOPIC TIE ROD


Removal

Figure 6



Remove the screws (2) and disconnect the telescopic tie rod (3) from the gearshift lever (1).

Figure 7



Disconnect the hydraulic pipe (2) from the cylinder (1).



Close the hydraulic pipe (2) to prevent oil from coming out.

Mark the universal joint (3) assembly position on the tie rod (5). Release the nut (4) and remove the telescopic tie rod by taking off the universal joint (3) from the tie rod (4).




Refitting

Refit the telescopic tie rod by reversing the removal procedure. Make sure the nuts or the screws are tightened to the prescribed torque. At the end of refitting, restore the oil level in the cabin tilting cylinder.

TRANSMISSION IDLER ARM

Removal

Figure 8




Remove the side tie rod from the idler arm as shown in figures 3 and 4.

Remove the nut (1) and take off the washer (2), the spring (3), the washer (4), the idler arm (5), the washer (6) and the spring (7) from the support pin (8).

Should the support pin (8) be worn, change the support (8) by removing the engine fastening screw (9).

Disassembly

Figure 9



79140

Release the nut (2) and slacken the articulated head (1). Write down the number of turns needed to remove it from the idler arm (3).

Use the appropriate tool to take off the bushes (4) from the idler arm (3).




Assembly

Use the appropriate beater to fit the bushes (4) into the idler arm (3).

Drive in the articulated head (1) in the idler arm with the same number of turns written down at disassembly and tighten the nut (2) to the prescribed torque.

Figure 10



79141

Refitting

Apply grease Tutela MRM2 inside the idler arm housing (3) and refit it and its components on the support (4) by reversing the removal procedure. Tighten the fastening nut (5) to torque 118 ± 144 Nm.

Make sure distance A or B between the articulated head pin (1) centre and that of the support pin (4) has the following value.

$$A = 125^{+1.5}_{-0} \text{ (CT vehicles excluded)}$$

$$B = 115^{+1.5}_{-0} \text{ (only CT vehicles)}$$




The nut is self-locking and shall be replaced with a new one at every disassembly.

CROSS TIE ROD

Removal

Figure 11



Remove the articulated head (1 and 3) fastening nuts from their connecting points and take off the cross tie rod (2). Release the nuts (4 and 5) and slacken the articulated heads (1 and 3) for the number of turns required to remove them. Refit the new articulated heads by driving them on the tie rod with the same number of turns written down at disassembly and tighten the nuts (4 and 5) to the prescribed torque.

Refitting

Refit the cross tie rod by reversing the removal procedure and tighten the articulated head fastening nuts to the prescribed torque.

After refitting, check the tie rod adjustment as described in the related section.





Power take-off

	Page
ZF POWER TAKE-OFF	207
HIDROCAR POWER TAKE-OFF	227




Power take-off units may be fitted to vehicles on request.

ZF POWER TAKE-OFF SPECIFICATIONS AND DATA


ZF POWER TAKE-OFF For transmissions ZF 9 S 109			
TYPE		N71/lb-x	N71/lc
Order No.		42116212	42116213
PTO output rev ratio/engine rev no.: ☐ normal ☐ over-multiplied ☐ reduced		0.72 - -	
PTO output rev ratio / PTO input rev ratio		1	
Rated torque at PTO output with 1500 rev/min Nm		500	
Expected duration with rated torque and 1500 rev/min at output hours		500	
Transmission detectable torque Nm		1000	
Rotation direction		engine direction	
Type of motion output (vehicle travelling direction)		rear with flange with pump attachment	
Control		pneumatic	
Weight applied on barycenter N		70	45
Application		on transmission rear side	
POWER TAKE-OFF			
ZF TYPE		N71/2b-x	N71/2c-x
Order No.		42116214	42116215
PTO output rev ratio/engine rev no.: ☐ normal ☐ over-multiplied ☐ reduced		0.95 - -	
PTO output rev ratio / PTO input rev ratio		1.318	
Rated torque at PTO output with 1500 rev/min Nm		300	
Expected duration with rated torque and 1500 rev/min at output hours		500	
Transmission detectable torque Nm		1000	
Rotation direction		engine direction	
Type of motion output (vehicle travelling direction)		rear with flange with pump attachment	
Control		pneumatic	
Weight applied on barycenter N		110	90
Application		on transmission rear side	
TIGHTENING TORQUES			
ELEMENT	TORQUE		
	Nm	kgm	
M12 stud bolts for power take-off fastening*	20	2	
M12 nuts for power take-off or oil pump fastening stud bolts	79	7.9	
Flange fastening screw	50	5	
* Apply sealer TEROSONFLUID 307 on the threading to be screwed on the gearbox			

SPECIFICATIONS AND DATA

ZF POWER TAKE-OFF
For transmissions ZF 9 S 109

79006

TYPE	N109/10b		
Order No.	42116179	42116180	42116174
PTO output rev ratio/engine rev no.:			
☐ normal	0.88	1.08	1.421
☐ over-multiplied	1.14	1.40	1.83
☐ reduced	0.96	1.18	1.55
PTO output rev ratio / PTO input rev ratio	1.222	1.5	1.963
Rated torque at PTO output with 1500 rev/min Nm	400	340	270
Expected duration with rated torque and 1500 rev/min at output hours	500		
Transmission detectable torque Nm	-	-	-
Rotation direction	engine direction		
Type of motion output (vehicle travelling direction)	rear with flange		
Control	pneumatic		
Weight kg	23		
Weight applied on barycenter N	-		
Application	on transmission rear side		

ZF POWER TAKE-OFF
For transmissions ZF 9 S 109

79007





TYPE	N109/10c	
Order No.	42116175	42116176
PTO output rev ratio/engine rev no.:		
☐ normal	0.88	1.08
☐ over-multiplied	1.14	1.40
☐ reduced	0.96	1.18
PTO output rev ratio / PTO input rev ratio	1.222	1.5
Rated torque at PTO output with 1500 rev/min Nm	400	340
Expected duration with rated torque and 1500 rev/min at output hours	-	-
Transmission detectable torque Nm	-	-
Rotation direction	engine direction	
Type of motion output (vehicle travelling direction)	rear with flange	
Control	pneumatic	
Weight kg	23	
Weight applied on barycenter N	230	
Application	on transmission rear side	

TIGHTENING TORQUES

ELEMENT	TORQUE	
	Nm	kgm
M12 stud bolts for power take-off fastening*	20	2
M12 nuts for power take-off or oil pump fastening stud bolts	79	7.9
Flange fastening screw	50	5

* Apply sealer TEROSONFLUID 307 on the threading to be screwed on the gearbox


SPECIFICATIONS AND DATA

ZF POWER TAKE-OFF For transmissions: ☐ ZF I6 S I51/I81/22I ☐ ZF I6 S I51/I81/22I with Intarder					
TYPE		N7I/IB		N7I/IC	
Order No.		42116223		42116224	
PTO output rev ratio/engine rev no.:					
☐ normal		-		-	
☐ over-multiplied		0.91		1.09	
☐ reduced		0.77		0.91	
PTO output rev ratio / PTO input rev ratio		1		1	
Rated torque at PTO output with 1500 rev/min Nm		100		100	
Expected duration with rated torque and 1500 rev/min at output hours		500		500	
Transmission detectable torque Nm		-		-	
Rotation direction		engine direction		engine direction	
Type of motion output (vehicle travelling direction)		with flange		rear with pump attachment	
Control		pneumatic		pneumatic	
Weight kg		7		4.5	
Weight applied on barycenter N		70		45	
Application		on secondary shaft		on transmission side	
ZF POWER TAKE-OFF For transmissions: ☐ ZF I6 S I51/I81/22I ☐ ZF I6 S I51/I81/22I with Intarder					
TYPE		N7I/2b-x N7I/2b-y		N7I/2c-x N7I/2c-y	
Order No.		42116216		42116217	
PTO output rev ratio/engine rev no.:					
☐ normal		-		-	
☐ over-multiplied		1.21		1.21	
☐ reduced		1.01		1.01	
PTO output rev ratio / PTO input rev ratio		1.318		1.318	
Rated torque at PTO output with 1500 rev/min Nm		300		300	
Expected duration with rated torque and 1500 rev/min at output hours		500		500	
Transmission detectable torque Nm		1000		1000	
Rotation direction		engine direction		engine direction	
Type of motion output (vehicle travelling direction)		with flange		rear with pump attachment	
Control		pneumatic		pneumatic	
Weight kg		11		9	
Weight applied on barycenter N		110		90	
Application		on transmission		rear side	
TIGHTENING TORQUES					
ELEMENT		TORQUE			
		Nm		kgm	
M12 stud bolts for power take-off fastening*		20		2	
M12 nuts for power take-off or oil pump fastening stud bolts		79		7.9	
Flange fastening screw		50		5	
* Apply sealer TEROSONFLUID 307 on the threading to be screwed on the gearbox					

SPECIFICATIONS AND DATA

ZF POWER TAKE-OFF

For transmissions:

☐ ZF 16 S 151/181/221

TYPE	N221/I0b	N221/I0b	N221/I0b
Order No.	8851362	8851363	8851364
PTO output rev ratio/engine rev no.:			
☐ reduced	0.95	1.14	1.47
☐ over-multiplied	1.13	1.36	1.76
PTO output rev ratio / PTO input rev ratio	1.23	1.48	1.91
Rated torque at PTO output with 1500 rev/min Nm	870	730	560
Expected duration with rated torque and 1500 rev/min at output hours	500	500	500
Rotation direction	engine direction		
Type of motion output (vehicle travelling direction)	rear with flange		
Control	pneumatic		
Transmission detectable torque Nm	1000		
Application	on transmission rear side		
Weight kg	15		

TYPE	N221/I0b	N221/I0c	N221/I0c
Order No.	8851365	8851360	8851361
PTO output rev ratio/engine rev no.: ☐ reduced ☐ over-multiplied	1.68 2.01	0.95 1.13	1.14 1.36
PTO output rev ratio / PTO input rev ratio	2.19	1.23	1.48
Rated torque at PTO output with 1500 rev/min Nm	470	870	730
Expected duration with rated torque and 1500 rev/min at output hours	500	500	500
Rotation direction	engine direction		
Type of motion output (vehicle travelling direction)	rear with flange	rear with pump attachment	
Control	pneumatic		
Transmission detectable torque Nm	1000		
Application			


PTO = POWER TAKEOFF

TIGHTENING TORQUES

ELEMENT	TORQUE	
	Nm	kgm
Oil pump fastening nut	79	7.9
Flange fastening screw at motion output	50	5
M12 stud bolts for power take-off fastening*	20	2

* Apply sealer TEROSONFLUID 307 on the threading to be screwed on the gearbox

SPECIFICATIONS AND DATA



ZF POWER TAKE-OFF For transmissions: ☐ ZF I6 S I5I/I8I/22I with Intarder			
TYPE	N22I/I0b	N22I/I0b	N22I/I0b
Order No.	8851380	8851381	8851382
PTO output rev ratio/engine rev no.: ☐ reduced ☐ over-multiplied	0.95 1.13	1.14 1.36	1.47 1.76
PTO output rev ratio / PTO input rev ratio	1.23	1.48	1.91
Rated torque at PTO output with 1500 rev/min Nm	870	730	560
Expected duration with rated torque and 1500 rev/min at output hours	500	500	500
Rotation direction	engine direction		
Type of motion output (vehicle travelling direction)	rear with flange		
Control	pneumatic		
Transmission detectable torque Nm	1000		
Application	on transmission rear side		
Weight kg	15		
TYPE	N22I/I0b	N22I/I0c	N22I/I0c
Order No.	8851383	8851378	8851379
PTO output rev ratio/engine rev no.: ☐ reduced ☐ over-multiplied	1.68 2.01	0.95 1.13	1.14 1.36
PTO output rev ratio / PTO input rev ratio	2.19	1.23	1.48
Rated torque at PTO output with 1500 rev/min Nm	470	870	730
Expected duration with rated torque and 1500 rev/min at output hours	500	500	500
Rotation direction	engine direction		
Type of motion output (vehicle travelling direction)	rear with flange	rear with pump attachment	
Control	pneumatic		
Transmission detectable torque Nm	1000		
Application	on transmission rear side		
Weight kg	15		
PTO = POWER TAKEOFF			
TIGHTENING TORQUES			
ELEMENT	TORQUE		
	Nm	kgm	
Oil pump fastening nut	79	7.9	
Flange fastening screw at motion output	50	5	
M12 stud bolts for power take-off fastening*	20	2	
* Apply sealer TEROSONFLUID 307 on the threading to be screwed on the gearbox			

SPECIFICATIONS AND DATA

ZF POWER TAKE-OFF

For transmissions:

☐ EuroTronic Automated I2 AS 230I




79020

TYPE	N7I/IB	N7I/IC
Order No.	8866600	8866601
PTO output rev ratio/engine rev no.:	0.82	
☐ normal	-	
☐ over-multiplied	-	
☐ reduced	-	
PTO output rev ratio / PTO input rev ratio	1	
Rated torque at PTO output with 1500 rev/min	1000	
Expected duration with rated torque and 1500 rev/min at output hours	500	
Transmission detectable torque	1000	
Rotation direction	engine direction	
Type of motion output (vehicle travelling direction)	with flange rear with pump attachment	
Control	pneumatic	
Weight applied on barycenter	N	45
Application	To secondary shaft on transmission rear side	
Weight	kg	4.5

P.T.O. = POWER TAKE-OFF

Figure 1





48978

POWER TAKE-OFF APPLICATION FOR AUTOMATED EUROTRONIC GEARBOX

TIGHTENING TORQUES


ELEMENT	TORQUE	
	Nm	kgm
M12 stud bolts for power take-off fastening	20	2
M12 nuts for power take-off or oil pump fastening stud bolts	79	7.9
Nuts M12 to fasten oil pump (N7I/IC only, no roller bearing)	46	4.6

SPECIFICATIONS AND DATA

ZF POWER TAKE-OFF For transmissions: ☐ EuroTronic Automated I2 AS 230I			
TYPE		N71/2B	N71/2C
Order No.		8866603	8866604
PTO output rev ratio/engine rev no.:			
☐ normal		1.08	
☐ over-multiplied		-	
☐ reduced		-	
PTO output rev ratio / PTO input rev ratio		1.318	
Rated torque at PTO output with 1500 rev/min Nm		300	
Expected duration with rated torque and 1500 rev/min at output hours		500	
Transmission detectable torque		395	
Rotation direction		engine direction	
Type of motion output (vehicle travelling direction)		rear	
		with flange	with pump attachment
Control		pneumatic	
Weight applied on barycenter N		108	88
Application		To secondary shaft on transmission rear side	
Weight kg		11	9

PTO = POWER TAKE-OFF

Figure 2




POWER TAKE-OFF APPLICATION FOR AUTOMATED EUROTRONIC GEARBOX

TIGHTENING TORQUES

ELEMENT	TORQUE	
	Nm	kgm
M12 stud bolts for power take-off fastening	20	2
M12 nuts for power take-off or oil pump fastening stud bolts	76	7.6
Oil pump M12 fastening nuts (only N71/1C without roller bearing)	46	4.6


Figure 3



48989

SECTION OF POWER TAKEOFF N7I/IB


Figure 4



48990

SECTION OF POWER TAKEOFF N7I/IC


Figure 5



48991

SECTION OF POWER TAKEOFF N71/2B


Figure 6



48992

SECTION OF POWER TAKEOFF N72/C

Figure 7




48963

SHAFT CONNECTING ZF-TYPE POWER TAKEOFFS: N71/1B - 1C, N71/2B

1. Transmission secondary shaft - 2. Transmission tapered roller bearing - 3. Connection shaft - 4. Ball bearing - 5. Power takeoff.


SPECIFICATIONS AND DATA**ZF POWER TAKE-OFF**

For transmissions:

☐ EuroTronic Automated I2 AS 230I

TYPE	N AS/10b	N AS/10b	N AS/10b
Order No.	8866613	8866614	8866615
PTO output rev ratio/engine rev no.:			
☐ normal	1.95	1.79	1.41
☐ over-multiplied	-	-	-
☐ reduced	-	-	-
PTO output rev ratio / PTO input rev ratio	2.56	2.35	1.85
Rated torque at PTO output with 1500 rev/min Nm	300	330	430
Expected duration with rated torque and 1500 rev/min at output hours	500		
Transmission detectable torque	769	776	795
Rotation direction	engine direction		
Type of motion output (vehicle travelling direction)	rear with flange		
Control	pneumatic		
Weight applied on barycenter N	206		
Application	on secondary shaft on transmission side		
Oil quantity to be added to gearbox dm ³	1		

PTO = POWER TAKEOFF

Figure 8

48984

POWER TAKE-OFF APPLICATION DIAGRAM**TIGHTENING TORQUES**


ELEMENT	TORQUE	
	Nm	kgm
Studbolts M12 to fasten power takeoff	79	7.9
M8 screws	23	2.3
M10 screws	46	4.6
Flange M12 fastening screws	120	12

SPECIFICATIONS AND DATA

ZF POWER TAKE-OFF

For transmissions:


☐ EuroTronic Automated I2 AS 230I



TYPE		N AS/I0b+c
Order No.		8866617
MOTION OUTPUT 1		
Drive ratio		2.35
PTO output rev ratio / PTO input rev ratio:		1.79
Rated torque at PTO output with 1500 rev/min	Nm	330
Transmission detectable torque	Nm	776
MOTION OUTPUT 2		
Drive ratio		1.48
PTO output rev ratio / PTO input rev ratio:		1.12
Rated torque at PTO output with 1500 rev/min	Nm	670
Transmission detectable torque	Nm	993
Expected duration with rated torque and 1500 rev/min at output hours		500
Rotation direction		engine direction
Type of motion output (vehicle travelling direction)		rear with pump attachment and flange attachment
Control		pneumatic
Weight applied on barycenter	N	225
Application		on secondary shaft on transmission side
Oil quantity to be added to gearbox	dm ³	1

PTO = POWER TAKEOFF

Figure 9







48984

POWER TAKE-OFF APPLICATION DIAGRAM

TIGHTENING TORQUES


ELEMENT	TORQUE	
	Nm	kgm
Power take-off M12 fastening screws	79	7.9
M8 screws	23	2.3
M10 screws	46	4.6

SPECIFICATIONS AND DATA

ZF POWER TAKE-OFF (new version) For transmissions: ☐ ZF 9 S 109 ☐ ZF 16 S 151/181/221 ☐ EuroTronic Automated 12 AS 2301 D.D./O.D.		 	
TYPE		NH/lb	NH/lc
PTO output rev ratio / PTO input rev ratio: ☐ ZF 9 S 109 ☐ ZF 16 S 151/181/221 ☐ EuroTronic Automated 12 AS 2301 D.D. ☐ EuroTronic Automated 12 AS 2301 O.D.		0.72 0.91/0.77 0.82 1.35	
Torque measured on transmission: ☐ ZF 9 S 109 Nm ☐ ZF 16 S 151/181/221 - EuroTronic Automated Nm		800 (permanent) 1000 (permanent)	
Rotation direction		engine direction	
Type of motion output (vehicle travelling direction)		rear with flange with pump attachment	
Control		pneumatic	
Weight kg		68.5	68.5
Application		on secondary shaft on transmission side	
Oil quantity l		0.20	
ZF POWER TAKE-OFF (new version) For transmissions: ☐ ZF 9 S 109 ☐ ZF 16 S 151/181/221 ☐ EuroTronic Automated 12 AS 2301 D.D./O.D.		 	
TYPE		NH/4b	NH/4c
PTO output rev ratio / PTO input rev ratio: ☐ ZF 9 S 109 ☐ ZF 16 S 151/181/221 ☐ EuroTronic Automated 12 AS 2301 D.D. ☐ EuroTronic Automated 12 AS 2301 O.D.		0.92 1.17/0.98 1.05 1.22	
Transmission detectable torque Nm		430 < 1 hour	
Rotation direction		engine direction	
Type of motion output (vehicle travelling direction)		rear with flange with pump attachment	
Control		pneumatic	
Weight kg		7.5	5.5
Application		on secondary shaft on transmission side	
Oil quantity l		0.50	

SPECIFICATIONS AND DATA**ZF POWER TAKE-OFF (new version)**


For transmissions:

☐ ZF 9 S 109


TYPE		N109/10b		
PTO output rev ratio / PTO input rev ratio:		0.88	1.08	1.42
Transmission permanent detectable torque Nm		630	530	410
Rotation direction		engine direction		
Type of motion output (vehicle travelling direction)		rear with flange		
Control		pneumatic		
Weight kg		23		
Application		on transmission rear side		
Oil quantity l		l		

ZF POWER TAKE-OFF (new version)


For transmissions:

☐ ZF 9 S 109



TYPE		N109/10c		
PTO output rev ratio / PTO input rev ratio:				
Transmission detectable torque Nm		630		530
Rotation direction		engine direction		
Type of motion output (vehicle travelling direction)		rear with pump attachment		
Control		pneumatic		
Weight kg		23		
Application		on secondary shaft on transmission side		
Oil quantity l		l		

Figure 10

Section in position C for pump installation



Section in position D on motion output




POWER TAKE-OFF N109/10b-/10c

- A. Power take-off upper position
- B. Power take-off lower position

79088

SPECIFICATIONS AND DATA**ZF POWER TAKE-OFF (new version)**

For transmissions:


☐ ZF 16 S 151/181/221

79090

TYPE		N221/10b			
Order No.	K2	8870532	8870533	8870534	8870535
PTO output rev ratio / PTO input rev ratio:		1.13/0.95	1.35/1.14	1.09/1.75	2.00/1.68
Transmission permanent detectable torque	Nm	870	730	560	470
Rotation direction		engine direction			
Type of motion output (vehicle travelling direction)		rear with flange			
Control		pneumatic			
Weight	kg	15			
Application		on transmission rear side			
Oil quantity	l	l			

ZF POWER TAKE-OFF (new version)



For transmissions:

☐ ZF 16 S 151/181/221 with Intarder

79091

TYPE		N221/10b			
Order No.	K2	8870339	8870340	8870341	8870325
PTO output rev ratio / PTO input rev ratio:		1.13/0.95	1.35/1.14	1.09/1.75	2.00/1.68
Transmission permanent detectable torque	Nm	870	730	560	470
Rotation direction		engine direction			
Type of motion output (vehicle travelling direction)		rear with flange			
Control		pneumatic			
Weight	kg	15			
Application		on transmission rear side			
Oil quantity	l	l			

SPECIFICATIONS AND DATA

ZF POWER TAKE-OFF (new version) For transmissions: ☐ ZF I6 S I51/I81/221		 79090		 79097
TYPE		N221/I0c		N221/I0c-PL
Order No.	K2	8070536	8870537	8870538
PTO output rev ratio / PTO input rev ratio:		1.13/0.95	1.35/1.14	1.13/0.95
Transmission permanent detectable torque	Nm	870	730	730
Rotation direction		engine direction		
Type of motion output (vehicle travelling direction)		rear with pump attachment		
Control		pneumatic		
Weight	kg	15		
Application		on transmission rear side		
Oil quantity	l	l		


ZF POWER TAKE-OFF (new version) For transmissions: ☐ ZF I6 S I51/I81/221 with Intarder		 79091		
TYPE				
Order No.	K2	8070543	8870544	
PTO output rev ratio / PTO input rev ratio:		1.13/0.95	1.35/1.14	
Transmission permanent detectable torque	Nm	870	730	
Rotation direction		engine direction		
Type of motion output (vehicle travelling direction)		rear with pump attachment		
Control		pneumatic		
Weight	kg	15		
Application		on secondary shaft on transmission side		
Oil quantity	l	l		

Figure 11


N221/10b-/10c power take-off
with upper motion output

Figure 12


N221/10b-/10c power take-off
with lower motion output

Figure 13




Figure 14






Figure 15



Section in position D on motion output

Figure 16



Section in position C for installation

TRANSMISSIONS ZF 16 S 151/181/221


1. N221/10b-/10c power take-off with upper motion output
2. N221/10b-/10c power take-off with lower motion output
3. N221/10c-PL power take-off

TRANSMISSIONS ZF 16 S 151/181/221 with Intarder

4. N221/10b-/10c power take-off with lower motion output


SPECIFICATIONS AND DATA**ZF POWER TAKE-OFF**

For transmissions:

☐ EuroTronic Automated I2 AS 230I D.D./O.D.

TYPE	N AS/10	N AS/10	N AS/10	N AS/10b+c
Order No.	8866613	8866614	8866615	8866617
MOTION OUTPUT I				
Drive ratio	2.56	2.35	1.85	1.85
PTO output rev ratio / PTO input rev ratio:	1.95	1.79	1.41	1.41
Rated torque at PTO output with 1500 rev/min Nm	300	330	430	330
Transmission detectable torque Nm	769	776	795	776
MOTION OUTPUT 2				
Drive ratio	-	-	-	0.93
PTO output rev ratio / PTO input rev ratio:	1.12	1.12	1.12	1.12
Rated torque at PTO output with 1500 rev/min Nm	-	-	-	670
Transmission detectable torque Nm	-	-	-	993
Expected duration with rated torque and 1500 rev/min at output hours	500			
Rotation direction	engine direction			
Type of motion output (vehicle travelling direction)	rear with flange			flange attachment and with pump attachment
Control	pneumatic			
Weight applied on barycenter N	206			225
Application	To secondary shaft on transmission rear side			
Oil quantity to be added to gearbox dm ³	-			

PTO = POWER TAKEOFF


Figure 17

48984

POWER TAKE-OFF APPLICATION DIAGRAM

SPECIFICATIONS AND DATA**ZF POWER TAKE-OFF**

For transmissions:


☐ EuroTronic Automated I2 AS 230I D.D./O.D.



TYPE	N AS/10b	N AS/10b+c
Order No.	-	-
MOTION OUTPUT 1		
Drive ratio		
☐ I2 AS 230I D.D.	1.92	1.21
☐ I2 AS 230I O.D.	2.15	1.23
Transmission permanent detectable torque:		
☐ I2 AS 230I D.D. Nm	400	670
☐ I2 AS 230I O.D. Nm	490	720
MOTION OUTPUT 2		
Drive ratio		
☐ I2 AS 230I D.D.	1.92	1.29
☐ I2 AS 230I O.D.	2.15	1.73
Transmission permanent detectable torque:		
☐ I2 AS 230I D.D. Nm	400	400
☐ I2 AS 230I O.D. Nm	490	580
Expected duration with rated torque and 1500 rev/min at output hours	-	
Rotation direction	engine direction	
Type of motion output (vehicle travelling direction)	rear with pump attachment and attachment flange	
Control	pneumatic	
Weight kg	22	26
Application	To secondary shaft on transmission rear side	
Oil quantity to be added to gearbox dm ³	1.201	

PTO = POWER TAKEOFF

SPECIFICATIONS AND DATA

HYDROCAR POWER TAKE-OFF

HYDROCAR POWER TAKE-OFF For transmissions: ☐ ZF 9 S 109 ☐ ZF 16 S 151/181/221			
TYPE		I801	
Order No.		8870285	8851441 8851443
☐ ZF 9 S 109		•	
☐ ZF 16 S 151/181/221 O.D.			•
☐ ZF 16 S 151/181/221 O.D. with Intarder			•
Drive ratio		0.72	0.92/0.77 0.92/0.77
Detectable torque	Nm	590	590 590
Weight	kg	4.7	4.7 4.7
Rotation direction		engine direction	
Type of motion output (vehicle travelling direction)		rear with flange	
Control		pneumatic	



HYDROCAR POWER TAKE-OFF For transmissions: ☐ ZF 9 S 109 ☐ ZF 16 S 151/181/221		 	
TYPE		I802	
Order No.		8870291	8851445 8851448
☐ ZF 9 S 109		•	
☐ ZF 16 S 151/181/221 O.D.			•
☐ ZF 16 S 151/181/221 O.D. with Intarder			•
Drive ratio		0.93	1.2/1.0 1.2/1.0
Detectable torque	Nm	295	295 295
Weight	kg	8	8 8
Rotation direction		engine direction	
Type of motion output (vehicle travelling direction)		rear with pump attachment	
Control		pneumatic	

PTO = POWER TAKEOFF


CHARACTERISTICS AND DATA**HYDROCAR POWER TAKE-OFF**

For transmissions:

☐ ZF 12 AS 230I☐ ZF 12 AS 230I with Intarder

HYDROCAR POWER TAKE-OFF For transmissions: ☐ ZF 12 AS 230I ☐ ZF 12 AS 230I with Intarder				
TYPE	1801		1802	
Order No.	8851460	8851463	8851467	8851470
☐ ZF 12 AS 230I	.		.	
☐ ZF 12 AS 230I with Intarder		.		.
Drive ratio	0.82/0.76		1.06/0.98	
PTO output rev ratio / PTO input rev ratio	1		1.3	
Rated torque at PTO output with 1500 rev/min Nm	1000		295	
Expected duration with rated torque and 1500 rev/min at output hours	500			
Rotation direction	engine direction			
Type of motion output (vehicle travelling direction)	rear with control flange with flange with pump attachment			
Control	pneumatic			
Weight kg	4.7		8	
Weight applied on barycenter N	47		80	
Application	To secondary shaft on transmission rear side			

PTO = POWER TAKEOFF

Figure 18

48972


POWER TAKE-OFF APPLICATION FOR GEARBOX**TIGHTENING TORQUES**

ELEMENT	TORQUE	
	Nm	kgm
Oil pump fastening nut	85 ± 5%	8,5 ± 5%
Flange fastening screw at motion output	100 ± 5%	10 ± 5%
Power take-off fastening M10 screws	50 ± 2	5 ± 0.2

SPECIFICATIONS AND DATA

HYDROCAR POWER TAKE-OFF For transmissions: ☐ ZF 16 S 151/181/221			
TYPE		I865	
Order No.		8851452	8851451
Drive ratio		1.2/1.0	
PTO output rev ratio / PTO input rev ratio		1.30	
Rated torque at PTO output with 1500 rev/min	Nm	420	
Expected duration with rated torque and 1500 rev/min at output hours		500	
Rotation direction		engine direction	
Type of motion output (vehicle travelling direction)		rear with flange (A)	with pump attachment (B)
Control		pneumatic	
Weight	kg	17.5	15
Weight applied on barycenter	N	175	150
Application		To secondary shaft on transmission rear side	

PTO = POWER TAKEOFF

Figure 19



77472

TIGHTENING TORQUES

ELEMENT	TORQUE	
	Nm	kgm
Oil pump fastening nut	85 ± 5%	8.5 ± 5%
Flange fastening screw at motion output	100 ± 5%	10 ± 5%
Power takeoff fastening M10 screws	50 ± 2	5 ± 0.2


SPECIFICATIONS AND DATA**HYDROCAR POWER TAKE-OFF**

For transmissions:

☐ ZF 12 AS 2301

TYPE		1865 + K522	
Order No.		8851471	8851473
Drive ratio		1.06	1.2/0.98
PTO output rev ratio / PTO input rev ratio		1.30	
Rated torque at PTO output with 1500 rev/min	Nm	420	
Expected duration with rated torque and 1500 rev/min at output hours		500	
Rotation direction		engine direction	
Type of motion output (vehicle travelling direction)		rear	
		with flange	with pump attachment
Control		pneumatic	
Weight	kg	17.5	15
Weight applied on barycenter	N	175	150
Application		To secondary shaft on transmission rear side	

PTO = POWER TAKEOFF

Figure 20


77478

POWER TAKE-OFF APPLICATION FOR AUTOMATED EUROTRONIC GEARBOX


TIGHTENING TORQUES

ELEMENT	TORQUE	
	Nm	kgm
Oil pump fastening nut	85 ± 5%	8.5 ± 5%
Flange fastening screw at motion output	100 ± 5%	10 ± 5%
Power takeoff fastening M10 screws	50 ± 2	5 ± 0.2

CHARACTERISTICS AND DATA

HYDROCAR POWER TAKE-OFF			
TYPE		2421	2422
Order No.		8851479	8851480
MOTION OUTPUT 1			
Drive ratio		41/17	37/20
PTO output rev ratio / PTO input rev ratio:			
☐ EUROTRONIC AUTOMATED 12 AS 230I - ZF 16 S 181/221		1.79	1.41
☐ EUROTRONIC AUTOMATED 16 AS 260I		1.68	1.32
Nominal torque on PTO inlet at 1500 RPM	Nm	425	540
MOTION OUTPUT 2			
Drive ratio		40/27	37/30
PTO output rev ratio / PTO input rev ratio:			
☐ EUROTRONIC		1.12	0.94
☐ EUROTRONIC		1.05	0.88
Nominal torque on PTO inlet at 1500 RPM	Nm	730	890
Expected duration with rated torque and 1500 rev/min at output hours		500	
Rotation direction		engine direction	
Type of motion output (vehicle travelling direction)		rear with pump attachment and attachment flange	
Control		pneumatic	
Weight	kg	21.5	
Weight applied on barycenter	N	215	
Application		To secondary shaft on transmission rear side	

PTO = POWER TAKEOFF

Figure 21

77477

POWER TAKE-OFF APPLICATION FOR EUROTRONIC GEARBOX

Power take off (Optional 2395)


	Page
DESCRIPTION	235
FEATURES AND DATA	236
TIGHTENING TORQUE	237
EQUIPMENT	238
☐ Operation (power take off disengaged)	242
☐ Operation (power take off engaged)	243
REMOVING - REFITTING TOTAL POWER TAKE-OFF ASSEMBLY	244
☐ Removal	244
☐ Refitting	244
OVERHAULING	245
☐ Removing main box	245
☐ Removing drive assembly	245
☐ Removing bearing for shaft with gear wheel ..	245
☐ Removing oil pump	246
☐ Cleaning and checking parts	247
☐ Fitting the oil pump	247
☐ Fitting bearing for shaft with gear wheel	248
☐ Fitting drive assembly	248
☐ Adjusting drive output shaft tapered bearings ..	250
☐ Fitting the main housing	251
☐ Adjusting ball bearing	251



The power takeoff is fitted, on request, on the vehicles equipped with Cursor F2B engine

DESCRIPTION

The power take off is situated between the engine flywheel and the clutch assembly and is fitted with a non-synchronised pneumo-mechanical positive clutch to transfer the movement from the engine drive shaft to the pick up flange. Lubrication is ensured by an oil pump.

Figure 1**CROSS SECTION**

60239

FEATURES AND DATA





	Ratio revolutions - rpm	1 : 1.29
	Torque	900 Nm
	Direction of rotation	Same as engine
Type of engagement/release control		Electro - pneumatic
	Type of lubricant Quantity	ZC 90 - SAE 80 W/90 2.5 l
	Bearings for output shaft	2 tapered roller bearings
	Bearing settings	Using setting rings
	Distances setting rings	5.5 - 5.6 - 5.7 - 5.8 - 5.9 6 - 6.1 - 6.2 mm
	Bearing for control shaft	1 ball bearing
	Bearing settings	Using setting rings
	Thickness setting rings	3.95 - 4 - 4.05 - 4.10 - 4.15 - 4.20 4.25 - 4.30 mm
	Thickness safety split ring	3.60 - 3.65 - 3.70 - 3.80 3.85 - 3.90 mm

Figure 2









60240


TIGHTENING TORQUE

	DESCRIPTION	TORQUE	
		Nm	kgm
1	Plug	27,5	2.75
2	Screw M10x140	43	4.3
3	Screw	43	4.3
4	Screw M8x60	18	1.8
5	Joint	5.5	0.55
6	Screw for cover	22	2.2
7	Screw	82	8.2
8	Screw M10x1.5	10	1
9	Nut with flange for stud bolt	29	2.9
10	* Screws must be tightened in two stages: 1 st stage pre-torque 2 nd stage to angle	95 60°	9,5 60°
11	Screw M8x30	18	1.8
12	Screw M10x30	43	4.3
13	Nut M33x1.5	465	46.5
14	Screw M8x30	18	1,8


NOTE: Apply LOCTITE 242 on the plugs and joints in contact with the lubricant

EQUIPMENT


TOOL NO.	DESCRIPTION	
99322205		Revolving stand for overhauling units
99341002		Double-acting bridge
99341003		Double-acting bridge
99341009		Pair of brackets
99341015		Clamp
99341016		Pair of brackets with hole

EQUIPMENT**TOOL NO.****DESCRIPTION****99345049**


Counter block for pullers

99360503


Rings for lifting cylinder units

99363241

Plates (2) to measure gearbox main or transmission shaft bearing preload


99370317

Counter lever with extension to fasten flanges

99395216

Pair of meters for tightening to angle with 1/2'' and 3/4'' square coupling

Figure 3




COMPONENT PARTS OF THE POWER TAKE-OFF (DEMONSTRATION)

1. Bushing - 2. Flange - 3. Laminar coupling - 4. Screw and washer - 5. Roller bearing - 6. Seal - 7. Shaft for middle gear - 7a. Middle gear - 8. Bracket with nut - 9. Fitting with washers - 10. Seal - 11. Locating peg - 12. Bearing - 13. Screw - 14. Flywheel - 15. Box - 16. Stud bolt with nut - 17. Oil pump - 18. Bearing - 19. Screw washer and bracket - 20. Seal - 21. Oil filter - 22. Plug - 23. Cover - 24. Plug - 25. Screw - 26. Gear - 27. Screw with washer - 28. Pipe with fitting and washers - 29. Pipe with fitting and washers - 30. Screw - 31. Seal - 32. Pinion shaft - 33. Ball bearing - 34. Split ring - 35. Adjustment ring - 36. Seal - 37. Cover - 38. Screw - 39. Screw

71565

Figure 4




40776

EXPLODED VIEW OUTPUT UNIT COMPONENTS

1. Safety split ring - 2. Joint - 3. Choke ring - 4. Fork shaft - 5. Pin - 6. Screws - 7. Transmitter - 8. Washer - 9. Plug - 10. Housing - 11. Choke rings - 12. Joint - 13. Safety split ring - 14. Plug - 15. Vent - 16. Screws - 17. Nut - 18. Flange - 19. Seal - 20. Screws - 21. Cover - 22. Conical bearings - 23. Grooved transmission shaft - 24. Selector fork - 25. Sliding joint - 26. Roller bearings - 27. Screws - 28. Cover - 29. Setting ring - 30. Conical bearing - 31. Shoulder ring - 32. Gear wheel

Figure 5



40787

Operation (power take off disengaged)


A = Electro-pneumatic valve N.A. (usually open) with switch disengaged
 B = Electro-pneumatic valve N.C. (usually closed) with switch disengaged

With the switch in position **0** (disengaged) the electromagnets of the valves **A - B** are disconnected and therefore the circuit of the valve **A** remains open and that of valve **B** remains closed.

The air taken in enters valve **A** by link (2), leaves by link (3) and passes through the pipes to chamber **E**, moving the control rod with fork **D** in power take off position disengaged.

At the same time the air in chamber **C** passes through the piping to the link (6) and passes into the air by link (5).

Figure 6



40787

Operation (power take off engaged)


A = Electro-pneumatic valve N.A. (usually closed) with switch disengaged

B = Electro-pneumatic valve N.C. (usually open) with switch disengaged

With the switch in position **I** (engaged) the electromagnets of the valves **A - B** are excited and therefore the circuit of the valve **A** open and open that of valve **B**.

The air taken in through link (7) enters valve **B** leaves by link (6) and passes through the pipes to chamber **C**, moving the control rod with fork **D** in power take off position engaged.

At the same time the air in chamber **E** passes through the piping to the link (3) into valve **A** and passes into the air by link (4).

534501 REMOVING - REFITTING TOTAL POWER TAKE-OFF ASSEMBLY**Figure 7**

41019

Removal

This operation comprises:

- ☐ Removing - refitting propeller shafts (see relevant section 505620).
 - ☐ Removing - refitting gearbox (see relevant section 530210).
 - ☐ Removing - refitting clutch (see relevant section 505210).
- Take out the plug (1) and drain off the oil into a container. Loosen the nut (13) fixing the drive output flange (12). Take out the screws (11) and detach the bottom cover (10) together with the oil pump (17) and oil filter (18). Disconnect the electrical connections and the oil and air pipes from the drive (5). Take out the screws (14) and disconnect the drive (1) from the box (1). Take out the screws (15) and take off the flywheel (16) for the clutch coupling. Take out the screws (6) and disconnect the laminar coupling (8) from the engine flywheel (7). Remove the nuts for fixing the power take-off assembly and detach it from the engine.

Refitting

Provisionally mount the bottom cover (10). Screw down the screw (2) without the washer (3) in contact with the driven gear (4). Using a feeler gauge, measure the distance between the underside of the head of the screw (2) and the box (1), distance A.

Take out the screw (2), apply LOCTITE 242E on its thread and screw it back on, placing a washer in between with a thickness of:

$$S = A + B$$

where A is the distance measured

$$B = 0,3 \pm 0,1$$

corresponding to the distance between the end of the screw (2) and the driven gear (4).

Tighten the screw (2) to the required torque.



Screw (2) has a left-hand thread.


Take the bottom cover (10) back off. Refit the power take-off assembly by carrying out the steps described for removal in reverse order and observing the following:

- ☐ Lubricate the shaft (9) with MOLYCATÉ HSC grease.
- ☐ Apply LOCTITE 510 on the mating surfaces of the drive (5) and bottom cover (10).
- ☐ Apply LOCTITE 242E on the thread of the screws or plugs in contact with the oil.
- ☐ Tighten the screws/nuts to the required torque.
- ☐ The nut (13) fixing the drive output flange has to be tightened to a torque of 465 Nm (46.5 kgm) after mounting the drive assembly (5).
- ☐ Replenish the assembly with lubricating oil of the required grade and quantity.

OVERHAULING


Removing main box

Figure 8




Position the whole assembly on the rotary stand 99322205. Lock the rotation of the laminar coupling (2) with the reaction lever 99370317 (1) and using a suitable wrench unscrew the retaining screws (3). Remove the laminar coupling and the flange.

Figure 9



Unscrew the screws (1), take off the cover (2) together with the seal and recover the adjustment ring (3).


Figure 10



Using the eyebolt 993605003 (1) and lift, remove the shaft with the gear wheel (2).

534510 Removing drive assembly


Figure 11



Using an appropriate drift, drive out the shaft (2) and extract the middle gear (1). Take the seal out of the box.


Removing bearing for shaft with gear wheel

Figure 12




Using suitable pliers (1), remove the split ring (2).

Figure 13



Extract the ball bearing (4) with the extractor 99341003 (1), grips 99341009 (2) and reaction block 99345049 (3).


Figure 14



41025

Put the assembly in a vice, unscrew the nut (3), extract the flange (2), unscrew the screws and remove the cover (1).


Figure 15



41026

Unscrew the screws and take off the cover (2); recover the adjustment ring.
Take off the split ring and extract the fitting (1); unscrew the electric transmitter.


Figure 16



41027

Apply the extractor 99341002 (2) with the grips 99341016 (1) and extract the toothed output shaft (3).
Take out the gear (4).


Figure 17



41028

Drive out the spring pin (1), take out the shaft (2) and the drive fork (3).

Figure 18




41029

Put the toothed output shaft in a vice. Using the extractor 993441002 (1), grips 99341009 (2) and clamp 99341015 (3), extract the tapered roller bearing (4).

534532 Removing oil pump


Figure 19



60241

Extract the shaft together with the gear (3) from the oil pump (4). Unscrew the screws (1) securing the oil pump (4) and detach it from the cover (2).

Figure 20



71567

Take out the fixing screws (4) and remove the cover (3) from the pump casing (1).
Extract the gear shafts (5 and 6) from the pump casing (1).
Using a suitable extractor, remove the roller bearing (2) from the pump casing (1).

Cleaning and checking parts

After completing removal, immerse all the parts except for the bearings in a wash tank containing a solution of water and soda heated to a temperature of 80 to 85°C until the lubricant residues have dissolved.

Using a wire brush and scraper, get rid of any deposits on the parts, remains of gaskets and traces of Loctite and sealant from the mating surfaces, taking care not to damage them.

Wash again and dry the parts with compressed air.

Using a benchtop electric cleaning machine with wire brushes, remove any remains of Loctite and sealant from the threads of the screws.

To clean the bearings thoroughly, you need to put them in a bath of kerosene and, with the aid of a brush, eliminate all traces of lubricant.

Dry them with compressed air, bearing in mind that the jet of air must not cause the bearings to turn.

Then lubricate the bearings with oil of the same type used for the gears.


Keeping the bearings pressed down by hand while turning them slightly in both directions you should feel no roughness nor hear any noise as they move.

Carefully check that the rollers and cages, as well as the external and internal rolling races, are not worn.

Check all the parts to decide whether to reuse them or replace them.

Fitting the oil pump


Figure 21



71568

Key the roller bearing (2) onto the driven gear shaft (1).
Apply a press on the gear (1) so as to fit the roller bearing (2) in the pump casing (3).

Figure 22



71569

Mount the gear (6) in the pump casing so that the end of the shaft goes into the corresponding compartment of the shaft (2) of the driven gear (1) and the gear (7).




The gears need to be lubricated beforehand.

Put the cover (4) on the pump casing (3). Screw down the fixing screws (5) and tighten them to the required torque.



When handling the oil pump, take care the shaft (2) of the driven gear does not come out of the gear shaft (6).

Figure 23



60241


Put the oil pump (4) on the bottom cover (2) and secure it there with the screws (1), tightening them to the required torque.



When handling bottom cover (2), take care the shaft of the driven gear (3) does not come out of the oil pump gear shaft.

Fitting bearing for shaft with gear wheel

Figure 24




41035

Heat the internal ring of the bearing (2) to approx. 80°C and key it on the shaft (1).

Leave it to cool to pass on to the next step.

Figure 25




41036

Using a feeler gauge (2), measure the gap (1) between the bearing and the seat of the split ring. Then select the split ring that gives the less clearance possible.

Fitting drive assembly

Figure 26




41028

Put the box in a vice.

Fit on the fork (3), key on the shaft (2) and drive on the spring pin (1).


Figure 27



41037


Heat the internal ring of the bearing (2) to approx. 80°C and key it on the toothed shaft (1).

Figure 28




Put the gear (3) together with the sliding sleeve (2) in the box; insert the toothed shaft (1).

Figure 29



Fit on the external ring (1) for the bearing.

Figure 30




SECTION OF DRIVE ASSEMBLY

41039

Adjusting drive output shaft tapered bearings

Figure 31




41041

Using an appropriate drift, fit the seal (1) in the cover (2). Apply LOCTITE 410 on the supporting surface. Mount the cover (2) and tighten the screws to a torque of 18 Nm. Fit on the flange (3) and screw down the nut (4) by hand.



Tightening the nut (4) to a torque of 380 Nm (38 kgm) has to be done on the vehicle, after fitting the drive assembly on the main box.


Figure 32



41042

Take the box (4) out of the vice and turn it over. Fit the roller bearings (3), thrust washer (2) and tapered roller bearing (1) on the shaft.

Figure 33



41043


Fit the plates 99363241 (3) on the outer ring of the bearing. Tighten the screws (2) to a torque of 18 Nm (1.8 kgm), corresponding to an axial load of approx. 250 kg, and turn the output shaft.

Using a feeler gauge (1), measure the distance between the supporting surface and the outer ring of the bearing. The measurement will correspond to the thickness of the adjustment ring.



The thickness of the adjustment ring will have to be selected by rounding off.
For example, measurement 6 to 6.04 mm, select ring of thickness 6 mm.
measurement 6.05 to 6.09, select ring of thickness 6.1 mm.

Figure 34




41044

Mount the adjustment ring (1). Apply LOCTITE 510 sealant on the supporting surface (2). Mount the cover (3) and lock the screws to a torque of 18 Nm (1.8 kgm). Replace the seals on the fittings (2-12, Figure 4) then mount them and position the split rings (1-13, Figure 4). Screw on the transmitter (7, Figure 4).

Fitting the main housing

Figure 35




41045

Slightly heat the seat (↓) for the ball bearing on the box and mount the shaft (1) with the gear wheel together with the bearing.

Adjusting ball bearing


Figure 36



41046

Measure the distance (A, Figure 38) on the main box (2) with a feeler gauge (1).


Figure 37



41047

Measure the distance (B, Figure 38) on the cover (2) for the bearing with a feeler gauge (1).

Figure 38



41048

PARTIAL SECTION OF BEARING AND SHAFT WITH GEAR WHEEL

The value "C" of the adjustment ring is given by the following formula: $A - B = C$




If the value of "C" is the same as the nominal thickness of the adjustment ring (see table on page 236), fit the relevant ring.

Whereas, if "C" is different, fit the adjustment ring for the smaller value.

For example, "C" = 4.14 to 4.11 mm, fit the ring of 4.1 mm.


Figure 39



41049

Fit the middle gear (3) in the box, drive in (2) after replacing the seals (1).


Figure 40



41020

Fit the setting ring (3), apply LOCTITE 510 sealant to the contact surface; fit the cover (2) complete with choke ring and tighten the screws (1) to torque 22 Nm (2.2 kg).


Figure 41



41019

Fit the plate joint (2) with the flange, block it using tool 99370317 (1) and tighten the screws (3) to torque 95 Nm (9.5 kg). 1st stage.

Figure 42




41050

Fit tool 99395216 (1) to a box spanner and tighten the screws (2) by a further 60°, 2nd stage

SECTION 5

5342 Intarder - ZF hydraulic retarder

	Page
LOCATION OF INTARDER HYDRAULIC RETARDER DESCRIPTION PLATE	3
GENERAL INFORMATION	4
OPERATION	4
☐ Retarder engaged	5
☐ Retarder disengaged	6
LAYOUT OF MAIN SYSTEM COMPONENTS ON THE RETARDER	7
REMOVING AND REFITTING THE RETARDER ON THE ZF S 151/181/221-OD GEARBOX	8
☐ Removal	8
☐ Refitting	9
☐ Filling with oil	9
SPECIFICATIONS AND DATA	10
TIGHTENING TORQUES	11
TOOLS	12
FAULT DIAGNOSIS	14
OVERHAULING THE INTARDER HYDRAULIC RETARDER	18
☐ Hydraulic accumulator	18
☐ Removal	18
☐ Fitting	18
☐ Removing hydraulic retarder	18
☐ Checking the component parts of the hydraulic retarder	23
☐ Fitting the hydraulic retarder	24
☐ Stator end float adjustment	29

LOCATION OF INTARDER HYDRAULIC RETARDER DESCRIPTION PLATE**Figure 1**

		ZF FRIEDRICHSHAFEN AG MADE IN GERMANY	
MODEL	ZF - INTARDER*	IT 181/221	
PARTS LIST NO.	6085 001 002		— ZF bill of materials number
SERIAL NO.	000 031		— INTARDER part number
CUSTOMER SPEC.NO.	XXXXXX		— IVECO drawing number

72180

When requesting information, orders or repairs, you need to provide the above information.

GENERAL INFORMATION


The ZF Intarder is an auxiliary hydrodynamic brake integrated with the gearbox.

The braking effect is obtained via the oil contained in the retarder. It is operated by a seven-position lever mounted on the instrument panel. Depending on the position of the lever, the amount of oil necessary to obtain the required braking torque is sent between the rotor and stator.

The rotor increases the speed of the oil coming into the retarder that is slowed down as it hits the stator. This causes the temperature of the oil to increase.

It is cooled via an oil/water heat exchanger that is connected to the vehicle's cooling system. The resulting braking torque acts on the kinematic chain of the vehicle, slowing it down.

Figure 2



OPERATION

The retarder is controlled with a 7-position lever (⇒) located on the instrument panel to the right of the steering wheel. Next to the lever there is an indicator light that comes on when it is engaged.

The system is equipped with the constant speed function (Bremsomat).

With this function it is possible to maintain the vehicle speed when going downhill at a speed chosen by the driver.

In this case, the electronic control unit of the retarder automatically selects the necessary braking torque.

The constant speed function is only activated with the lever on "0" after saving the required speed. It can be saved on any of the 7 positions of the lever by briefly pressing the button on the lever.

When driving with the constant speed function, it is possible to decrease the speed of the vehicle with the retarder lever. As soon as the lever is brought back onto "0" the previously programmed speed is restored.


The constant speed function is turned off by pressing the button again.

The oil contained in the sump is sent by the pump into the hydraulic circuit of the retarder passing through a filter at a pressure of 12 bars. The supply circuit is protected by a relief valve at 14.5 bars. On operating the lever, the electronic control unit receives an electric signal that it processes and sends to the solenoid valve controlling the accumulator and to the proportional solenoid valve. The accumulator solenoid valve switches over, lets pressurized air pass that acts on the piston of the hydraulic accumulator, which sends the oil to the hydraulic circuit, shortening the retarder response time.

The proportional solenoid valve acts on the control valve, determining the control pressure.

The adjustment valve is controlled by the pressure of the oil from the control valve. Depending on the control pressure (max. 5.4 bars), they let the oil pass under pressure (max. 9.5 bars) to supply the rotor.

Figure 3



a. Rotor - b. Stator - c. Oil flow

The rotor is connected to the rear axle via the propeller shaft and the stator is connected to the chassis frame via the retarder box.

The oil in the compartments between the rotor and stator is set moving by the blades of the rotor, creating a flow of oil in a closed circuit between the movable and fixed parts of the retarder.

The oil, on hitting the blades of the stator, is slowed down, causing the rotor and therefore the vehicle to slow down. The decrease in speed of the flow of oil between the rotor and stator causes the kinetic energy to transform into heat energy.

To dissipate the heat, the oil passes through an oil/water heat exchanger.

In the exchanger, the heat of the oil is transferred to the cooling water and dissipated through the vehicle's cooling system.

A temperature sensor is fitted on the water outlet pipe of the heat exchanger. This sensor constantly sends the cooling water temperature to the electronic control unit, thereby ensuring the maximum permissible temperature needed for the engine to work properly is not exceeded.

If, for whatever reason, the temperature of the water rises and reaches the value set in the control unit, this will adjust the air pressure in the sump and decrease the braking torque, falling to the highest level of braking still permissible.


In addition, the electronic control unit receives the signal from the ABS system, when it comes into operation, that causes the retarder to disengage and the signal of the electronic transmitter of the turns of the retarder that makes it possible to use the constant speed function.

Setting the lever onto "0", the retarder turns itself off. The accumulator solenoid valve and the proportional solenoid valve de-energize. The control valve switches over, producing a control pressure of 0 bars so the adjustment valve and the pressure increase valve are set to discharge with just the action of the spring.

The switchover valve switches over under the action of the spring, discharging the supply circuit into the sump.

The oil circuit, via the pressure holding valve, takes on a pressure of approximately 1.5 bars. At the same time, the oil accumulator is again filled.

Figure 4



72170

HYDRAULIC SYSTEM WORKING DIAGRAM

Retarder engaged


On operating the lever (2), the electronic control unit (1) receives an ON electrical signal that it processes and sends to the solenoid valve (12) controlling the accumulator (10) that, by energizing, lets the air from the services reservoir (11) pass at a pressure of 9.5 bars, which acting on the piston of the hydraulic accumulator (10) sends the oil into the circuit, shortening the retarder response time.

The proportional solenoid valve (15), on energizing, acts on the valve (16), shifting the hydraulic slide valve, determining the control pressure in relation to the braking level.

This pressure, acting on the adjustment valve (14), sets the inlet pipe P in communication with the outlet pipes PI - R. As a result, the oil from the pressure relief valve (4) will shift the hydraulic slide of the valve (8), setting the pipe RI in communication with the rotor/stator via the heat exchanger (9).

The pressure holding valve (13), not being affected by the oil pressure, shuts off the oil outlet into the sump (7).

Figure 5



72171


Retarder disengaged

Setting the lever (2) in the rest position 0, the electronic control unit (1) receives no electric signal; therefore, it de-energizes both the solenoid valve (12) controlling the accumulator and the proportional solenoid valve (16).

The control valve (16) switches over, thereby causing the pressure to drop to 0 bars, so the adjustment valve (14) is made to discharge with just the action of the springs.


No longer being able to send the pressure P to the switchover valve (8), the spring switches over the slide valve, discharging the pressure of the Rotor - Stator circuit (6) into the sump (7) and thereby freeing the exchanger changeover circuit.

Through the holding valve (13) the oil circuit between the pump and heat exchanger (9) maintains a pressure of 1.5 bars, at the same time the oil accumulator fills up.

LAYOUT OF MAIN SYSTEM COMPONENTS ON THE RETARDER**Figure 6**

1. Electronic speed transmitter - 2. Proportional solenoid valve with control valve - 3. Adjustment valve -
 4. Plug - 5. Pressure holding valve - 6. Safety valve - 7. Pressure relief valve - 8. Switchover valve -
 9. Oil filter - 10. Electropneumatic valve - 11. Water temperature sensor - 12. Oil pump

70962

REMOVING AND REFITTING THE RETARDER ON THE ZF S 181/221-OD GEARBOX**Figure 7**

44316

**Removal**

Set the vehicle over the pit and carry out the following operations:

- ☐ Drain the coolant from the radiator through the plug (10).
- ☐ Drain off the oil by taking out the plug (7) on the retarder and the plug on the gearbox (oil passes between the retarder and the gearbox).

- ☐ Disconnect the pneumatic connection (8).
- ☐ Disconnect the electrical connections (2 - 3 - 4 - 9).
- ☐ Disconnect the sleeves (12 and 15) and remove the pipe (11).
- ☐ Disconnect the propeller shaft (13) from the drive output flange of the retarder.
- ☐ Remove the drive output flange.
- ☐ Unscrew the screw (6) and take out the plug (5) together with the oil filter.
- ☐ Unscrew the screw and nuts ($\Rightarrow$) and remove the heat exchanger (14).

After refitting:

- ☐ Replenish the lubricating oil as described under the relevant heading.
- ☐ Replenish the engine coolant as described under the relevant heading.



If the cross member of the chassis frame prevents you from removing the retarder, you need to take out the stud bolts for the nuts fixing the heat exchanger.

- ☐ Set the bracket 99370629 (1) on the hydraulic lift and fit the retarder on it.
- ☐ Take out the screws ($\Rightarrow$) fixing the retarder to the gearbox and remove it.



Recover the adjustment rings from the stator and from the epicyclic unit shaft bearing.

Refitting



Replace the sealing elements with new parts. For refitting, carry out the steps performed for removal in reverse order and keep to the required tightening torques.




If the stud bolts for the nuts fixing the heat exchanger were removed, for assembly it is necessary to apply LOCTITE 510 on their thread and tighten them to a torque of 18 Nm (1.8 kgm).



Filling with oil

Figure 8




Keep to the following procedure:

- ☐ Unscrew the screw of the oil filler hole (2).
- ☐ Add the amount of oil stated in the specifications and data table.
- ☐ Screw the filler hole screw back on.
- ☐ Have a test run on the road (at least 1 minute at a speed of at least 10 km/h). At the start of the run, briefly press the Intarder once (level 6) and then disengage it (level 0). In this way the gearbox oil gets distributed.
- ☐ After the road test, stop the vehicle **without operating the Intarder**.
- ☐ Stop the engine.
- ☐ Unscrew the overflow plug (1).
- ☐ Check the oil level again and, if necessary, add oil until it spills over.



The oil level of the gearbox with the ZF-Intarder has to be checked with the vehicle horizontal, the engine switched off and after the oil has cooled. Hot oil gives faulty readings and causes thermal expansion.







SPECIFICATIONS AND DATA


INTARDER		
	Maximum braking torque Nm	3000
Braking capacity: Intarder on gearbox:		
ZF 16 S /151181/221 kW		420
EuroTronic Automated kW		540
Air pressure	bar	6.3 ÷ 10.0
Weight	kg	69
Control		Electrohydraulic
Voltage	V	24

TIGHTENING TORQUES



PART	TORQUE	
	Nm	kgm
Screws fixing hydraulic accumulator to exchanger (M8 x 18 - M8 x 60)	23	2.3
Coolant drain plug (M18 x 1.5)	35	3.5
Coolant temperature sensor (M18 x 1.5)	40	4
Screws fixing solenoid valve (proportional) (M8 x 22)	23	2.3
Screws fixing electropneumatic valve controlling hydraulic accumulator (M8 x 60)	23	2.3
Oil drain plug (M24 x 1.5)	60	6
Screws closing pressure test points (M12 x 1.5)	25	2.5
Screw fixing safety valve (M12 x 1.5)	25	2.5
Screw fixing pressure relief valve (26 x 1.5)	70	7
Screw fixing switchover valve (M48 x 1.5)	150	15
Screw fixing adjustment valve (M26 x 1.5)	70	7
Screw fixing pressure increase valve (M30 x 1.5)	100	10
Screw fixing rotor driving gear (M12 x 80)	95	9.5
Screws fixing oil pump casing (M8 x 80) (M8 x 30)	23	2.3
Nuts fixing heat exchanger to rear half box	62	6.2
Screw fixing heat exchanger to rear half box (M8)	23	2.3

TOOLS

TOOL No.	DESCRIPTION	
99322205		Rotary stand for overhauling assemblies
99322225		Stand for supporting assemblies (to be fitted on stand 99322205)
99345058		Extractor reaction block
99370007		Grip for interchangeable drifts
99348002		Extractor
99370047		Tool pre-loading Intarder rotor shaft bearing to measure adjustment thickness

TOOLS**TOOL No.****DESCRIPTION****99370048**

Centring plate to fit rotor shaft on Intarder box


99374093Drift to mount external bearing races (91-134)
(use with 99370007)**99374221**

Key to fit gaskets on rear cover


FAULT DIAGNOSIS


Main retarder operating trouble:


- | | |
|---|---|
| <ul style="list-style-type: none"> 1 - No braking effect. 2 - Poor braking effect. 3 - Irregular braking effect. | <ul style="list-style-type: none"> 4 - Poor or no retarder disengagement. 5 - Indicator light comes on intermittently (lever on 1-6). 6 - Temperature control trips early. |
|---|---|



(continues)








534230 OVERHAULING THE INTARDER HYDRAULIC RETARDER


Figure 9



Using a rope and the movable lift, put the retarder (3) on the rotary stand 99322205 (4) together with the mount 99322225 (5). Unscrew the screws (2) and remove the electropneumatic valve (1).


Hydraulic accumulator Removal

Figure 10



Take out the screws (1) and disconnect the hydraulic accumulator (2).

Figure 11



Take out the screws (1) and remove the solenoid valve (2). Take out the screws (4 and 11) and remove the side covers (5 and 10). Extract the piston (7) from the body (8).

Fitting




For fitting, carry out the steps described for removal in reverse order with the precaution to fit new seals (3 - 6 - 9) and tighten the screws (1 - 4 - 11) to the required torque.




Removing hydraulic retarder

Figure 12




Take out the water temperature sensor (2). Take out the nuts (3 and 4) and remove the heat exchanger (1).

Figure 13



Take off the seals (3). Take out the screws (1) and remove the pump casing (2). Remove the rotor (5) and the ring (4) of the oil pump.


Figure 14



43988

Take the circlip (2) and the roller bearing (3) out of the pump casing (1).


Figure 15



70967

Take the seals (2 and 3) out of the rear box (1). Remove the circlip (4) and extract the roller bearing (5).

Figure 16




70968

From the rear half box (17):

- ☐ Take out the plug (1) with the washer (2) and extract the spring (3) and switchover valve (4).

- ☐ Take out the plug (6) with the washer (5).
- ☐ Take out the plug (7) with the washer (8) and extract the cup (9), springs (10 and 11) and the pressure relief valve (12).
- ☐ Take out the plug (13) with the washer (14) and extract the spring (15) and safety ball valve (16).

Figure 17



70969


From the rear half box (1):

- ☐ Take out the screw (5) and remove the proportional solenoid valve (4) with the seal (3) and the pressure control valve (2).
- ☐ The adjustment device (7) and extract the cup (8), spring (9) and pressure adjustment valve (10).



Do not take off the cover (6) so as not to tamper with the adjustment device (7).


Figure 18



70971

Take out the screws (2) and remove the rear half box (1) from the front half box (3).


Figure 19



Take off the gasket (1).

Lift the notches in the safety cover (2) and remove the half rings (3) from the shaft of the rotor (4).


Figure 20



Take the plug (2) with the washer (3) out of the front box (1); extract the spring (4) and the valve (5).

Take out the plug (6) with the washer (7).


Figure 21



COMPONENT PARTS OF THE REAR BOX

1. Plug - 2. Washer - 3. Spring - 4. Switchover valve - 5. Gasket - 6. Rear half box - 7. Washer - 8. Plug - 9. Screw -
10. Pressure adjustment valve - 11. Spring - 12. Cup - 13. Adjustment device - 14. Cover - 15. Screw -
16. Proportional solenoid valve - 17. Seal - 18. Pressure control valve - 19. Screw - 20. Screw - 21. Screw -
22. Oil pump cover - 23. Grub screw - 24. Seal - 25. Roller bearing - 26. Rotor - 27. Ring gear - 28. Seal -
29. Split ring - 30. Roller bearing - 31. Washer - 32. Plug - 33. Safety ball valve - 34. Spring - 35. Washer -
36. Plug - 37. Pressure relief valve - 38. Spring - 39. Spring - 40. Cup - 41. Washer - 42. Plug

Figure 22




Remove the plug and check that the spring (24, Figure 34) of the friction reducing valve is present.




For hydraulic retarders without friction reducing valves, proceed as follows.

Figure 23




Transfer the front half box (1) together with the rotor and stator to the press. Put the half box on mounts (2) and take the rotor shaft together with the stator (3) out of the internal ring (4) of the tapered roller bearing and extract this from the half box (1).

Figure 24




Unscrew the screw (1) and take off the washer (2).

Figure 25



Transfer the rotor and stator assembly to the bench and lock it in the vice. Using the bridge 99341003 (1), tie rods 99341009 (2) and reaction block 99345058 (3), extract the gear (4).

Figure 26




Transfer the rotor and stator assembly to the press. Put the stator (1) on the mounts and extract the rotor (2).




For hydraulic retarders equipped with a friction reducing valve, proceed as follows.

Figure 27




Remove the bolt (1) and the washer (2); using yoke 99341003 (3), and block 99345058 (4), extract the gear (5).

Figure 28




Using the yoke (1), rods (2) and block (3), withdraw the stator (4) from the rotor (5) and from the half casing (6).

Figure 29




Withdraw the pins (1) and remove the half rings (2).

Figure 30



Remove the plug (1) and withdraw from the half casing (6): the spring (2), the pistons (3 and 4) and the spring (5).


Figure 31



Take the front half-casing (1), complete with the rotor, to a press. Position the half casing on the supports (2) and (3) and withdraw the rotor shaft (3) from the inner race (4) of the taper roller bearing and remove the latter from the half-casing (1).


For all types of retarder, proceed as follows.

Figure 32



Using a punch, extract the external ring (2) of the bearing from the front half box (1).

Figure 33



Using a punch (1), extract the external race (2) of the bearing from the stator (3).

Checking the component parts of the hydraulic retarder



Carefully clean the single parts comprising the retarder and check their state of wear for them to be reused.




Clean the threads of the plugs and their seats of remains of sealant.



Check the mating surfaces are not deformed and moisten the sliding surfaces.

Replace all the sealing and safety elements and the valve springs with new parts.

Figure 34




1. Screw - 2. Washer - 3. Gear - 4. Tapered roller bearing - 5. Stator - 6. Seal - 7. Split ring - 8. Rotor - 9. Split ring - 10. Front box - 11. Seal - 12. Safety cover - 13. Half rings - 14. Tapered roller bearing - 15. Valve - 16. Spring - 17. Washer - 18. Plug - 19. Plug - 20. Washer - 21. Pins - 22. Half rings - 23. Spring - 24. Piston - 25. Piston - 26. Spring - 27. Washer - 28. Plug.
- A = Components of the friction reducing valve: (if present)

78337


Fitting the hydraulic retarder

Figure 35



Heat the hole of the stator (4) to approximately 80°C. Using the keying device 99374093 (2) and grip 99370007 (1), mount the external race (3) of the tapered roller bearing.


Figure 36



Fit the new split rings (2 and 3) on the shaft (1) of the rotor.


For hydraulic retarders without friction reducing valves only.

Figure 37




Lock the rotor (3) in the vice as shown in the figure. Mount the stator (2). Heat the internal ring of the bearing (1) to approximately 100°C and mount it in its seat.

Figure 38




Heat the gear (3) to approximately 85°C and fit it on the shaft of the rotor (4). Fit the washer (2) and provisionally tighten the check screw. After cooling, lock the check screw to the required torque with a torque wrench (1). Fit a new seal (5) on the stator (4).

Figure 39



Fit the rotor shaft centring plate 99370048 (3) to the front half box (2). Heat the half box (2) to 90 ± 100°C and position the rotor and stator assembly (1) on the half box (2) as shown in the figure.


Figure 40



Using a press, drive the rotor and stator assembly (1) down to the stop in the front half box (4) so that the arrows (3 and 4) are aligned. A misalignment of 1 mm is permissible. Keep the assembly (2) under the action of the press for 5 minutes to ensure it gets bedded. Remove the centring plate (3, Figure 39).


For hydraulic retarders with friction reducing valves, proceed as follows.

Figure 41




Attach the rotor shaft locating plate 99370048 (3) to the front half-casing (2). Position the rotor assembly (1) complete with circlips in the half casing (2).

Figure 42




Install in the half casing (6) the spring (5), the pistons (3 and 4) and the spring (2); fit a new gasket to the plug (1) and tighten to a torque of 50 Nm.

Figure 43




Position the half rings (2) in the half casing (4) so that the projecting parts engage the grooves in the pistons (1) and fix them to the half casing with the pins (3).

Figure 44



Position the assembled half casing (2) in the press. Heat the seating of the stator (1) to 80 °C. Fit the stator (1) with a new oil seal in the front half casing (2), making sure that the arrows (3 and 4) are aligned. An alignment error of up to 1 mm is permissible. Keep the stator (2) under the press for 5 minutes to ensure it is fully bedded down. Remove the locating plate (3, Figure 41).


Figure 45



Heat the gear (3) to approx. 85 °C and fit it on the rotor shaft. Fit the washer (2) and provisionally tighten the retaining bolt (1). Once the gear (3) has cooled, tighten the retaining bolt to the prescribed torque.

For both types of hydraulic retarder

Figure 46




43984

Transfer the assembly to the bench and lock (2) the gear mounted on the rotor shaft in a vice so as to support the assembly.

Heat the seating of the outer race (1) of the taper roller bearing and install the outer race.


Figure 47



43985

Heat the internal ring of the bearing (1) to approximately 85°C and mount it on the shaft of the rotor (2).

Figure 48




70975

Leave the bearing to cool and fit the front half box (5) on the rotary stand 99322205 (3) together with the mount 99322225 (4).

Fit the tool 99370047 (2) for pre-loading the bearing. Pre-load the bearing so that the rolling torque that can be measured with the torque wrench (1) is 2 ± 0.5 Nm.

Using a feeler gauge (6) measure the thickness of the half rings (2, Figure 49): distance A.

Figure 49




71272

Insert the half rings (2) of the thickness measured beforehand.

Mount the cover (1).

Dent cap (1) using a suitable tool.

Figure 50




70973

Apply sealant on the thread of the plug (6) and screw it down with a new washer (7) and tighten it to the required torque.

Insert the valve (5) and the spring (4) into the front box (1).

Apply sealant on the thread of the plug (2), screw it down with a new gasket (3) and tighten it to the required torque.


Figure 51



70971

Put a new gasket on the front box (3).
Mount the rear box (1), screw down the screws (2) and tighten them to the required torque.

Figure 52



70969


In the rear box (1), insert:

- ☐ Pressure adjustment valve (10), spring (9) and cup (8). Apply sealant on the thread of the adjustment device (7), screw it down with a new washer, tightening it to the required torque.
- ☐ Pressure control valve (2) and mount the proportional solenoid valve (4) with a new seal (3). Screw down the screws (5) and tighten them to the required torque.



Do not take off the cover (6) so as not to tamper with the adjustment device (7).

Figure 53



70698


In the rear box (17), insert:

- ☐ Safety ball valve (16), spring (15) and plug (13) with washer (14).
- ☐ Pressure relief valve (12), springs (10-11), cup (9) and screw down the plug (7) with the washer (8).
- ☐ Screw down the plug (6) with the washer (5).
- ☐ Switchover valve (4), spring (3) and screw down the plug (1) with the washer (2).



Before mounting the plugs (13-7-5 and 1), apply sealants on their threads.
The plugs have to be tightened to the required torque.


Figure 54



70967

Fit the roller bearing (5) and circlip (4) in the rear half box (1). Position the seals (2 and 3) on it.


Figure 55



43988

Mount the roller bearing (3) in the pump casing (1) and secure it with the circlip (2).


Figure 56



70966

Mount the ring gear (4), the rotor (5) and the pump casing (2). Screw down the screws (1) and tighten them to the required torque. Position the seals (3).


Figure 57



71287

Refit the heat exchanger (1) to the hydraulic retarder and tighten the fixing nuts (3 and 5). Mount the temperature sensor (2). Mount the seal (4).


Figure 58



70963

Refit the hydraulic accumulator (1) together with the electropneumatic valve (3). Screw down the screws (2 and 4) and tighten them to the required torque.

Figure 59




44003

Using installation tool 99374221 (1), install a new oil seal (2) in the hydraulic retarder casing.

Stator end float adjustment

Figure 60



70946

Determine the thickness **H** of the stator end float adjustment ring.

- ☐ With a depth gauge (1) and calibrated rule (2), measure the distance between the supporting surface of the stator (distance **A**).
- ☐ Measure the thickness of the gasket between the retarder and the gearbox (distance **B**).

The thickness **H** of the stator end float adjustment ring is given by the following equation:

$$H = A + B + C$$

Where,

- ☐ **A** and **B** = measurements made
- ☐ **C** = 0.05 mm: pre-load of stator end float adjustment ring (-0.05 - +0.05 mm).

Refit the hydraulic retarder as described under the relevant heading of gearbox overhauling.


SECTION 6**Propeller shafts**

	Page
CHARACTERISTICS AND DATA	3
DIAGNOSTIC	5
TIGHTENING TORQUES	7
TOOLS	7
REMOVING AND REASSEMBLING THE PROPELLER SHAFT	8
☐ Removal	8
☐ Reassembly	8
CHECKING THE PROPELLER SHAFT ON THE VEHICLE	9
REMOVING AND FITTING BACK THE UNIVERSAL JOINTS	10
REMOVING AND REASSEMBLING THE SUPPORT	10

CHARACTERISTICS AND DATA

TRACTORS	WHEELBASE							
	Gearbox type	Shaft type	2800		3200		3650	3800
			L mm min. max	L mm min. max	L mm min. max.	L mm min. max.	L mm min. max.	L mm min. max.
4x2	ZF 9 S 109	KLEIN GWB	-	-	-	-	1800 ÷ 1910	1975 ÷ 2085
4x2	ZF 16 S 151	KLEIN GWB	-	-	-	-	1775 ÷ 1885 1875 ÷ 1985	1950 ÷ 2060 2050 ÷ 2160
6x4	ZF 16 S 221	KLEIN GWB	650 ÷ 790	775 ÷ 885	650 ÷ 790	1175 ÷ 1285	-	-
4x2	ZF 16 S 181D.D.	KLEIN GWB	-	-	-	-	1700 ÷ 1810	1875 ÷ 1985
6x2C			-	-	-	-	-	1875 ÷ 1985
4x2	ZF 16 S 181O.D.	KLEIN GWB	-	-	-	-	1800 ÷ 1910	1975 ÷ 2085
4x2	EuroTronic Automated 12 AS 2301 D.D.	KLEIN GWB	-	-	-	-	1800 ÷ 1910 1875 ÷ 1985	1975 ÷ 2085 2050 ÷ 2160
6x2C			-	-	-	-	-	1975 ÷ 2085
6x4			650 ÷ 790	875 ÷ 985	650 ÷ 790	1275 ÷ 1385	-	-
4x2	EuroTronic Automated 12 AS 2301 O.D.	KLEIN GWB	-	-	-	-	1875 ÷ 1985	2050 ÷ 2160


Figure 1



85482

SLIDING PROPELLER SHAFT

Figure 2



85483

CONNECTING PROPELLER SHAFT WITH FLEXIBLE MOUNT

Universal joint working angle 25°.


CABS 4x2		WHEELBASE																															
		3805		4200		4500		4800		5100		5500		5700		6300		6700															
Gearbox type	Shaft type	L mm	L2 mm	L mm	L' mm	L2 mm	L mm	L' mm	L2 mm	L mm	L' mm	L2 mm	L mm	L' mm	L2 mm	L mm	L' mm	L2 mm	L mm	L' mm	L2 mm	L mm	L' mm	L2 mm	L mm								
		min. max		min. max			min. max			min. max			min. max			min. max			min. max			min. max			min. max								
WT MD 3060	KLEIN GKN	2000 ÷ 2110		1080	2415 ÷ 2525		-	1530	2690 ÷ 2800		-	1755	2990 ÷ 3100		-	-	-	-	1755	3885 ÷ 3995		1835	1135	2645 ÷ 2755		1835	1135	3045 ÷ 3155					
WT MD 3066																	-																
ZF 9 S 109	KLEIN GKN	1810 ÷ 1910		890 1070	2225 ÷ 2335		-	1340	2500 ÷ 2610		-	1745	2980 ÷ 3090		-	-	-	-	1565	3615 ÷ 3805		1650	1135	2645 ÷ 2755		1645	1135	3045 ÷ 3155					
		1825 ÷ 1935			2405 ÷ 2515		-	1520	2680 ÷ 2790		-	1565	2800 ÷ 2910		-	1745	3305 ÷ 3415		-	1745	3845 ÷ 3985		1645	1135	2645 ÷ 2755		1650	1135	3045 ÷ 3155				
		1975 ÷ 2085					-	-	2505 ÷ 2615		-	-	2820 ÷ 2930		-	-	3130 ÷ 3240		-	-	3890 ÷ 4000		1825	1135	2645 ÷ 2755		1825	1135	3045 ÷ 3155				
		2000 ÷ 2110					-	-	2685 ÷ 2795		-	-	3000 ÷ 3110		-	-	3310 ÷ 3420		-	-	3710 ÷ 3820		1830	1135	2645 ÷ 2755		1830	1135	3045 ÷ 3155				
ZF 16 S 151	KLEIN GKN	1755 ÷ 1885		1040 -	2375 ÷ 2485		-	1310	2470 ÷ 2580		-	1720	2955 ÷ 3065		-	1720	3265 ÷ 3375		-	1540	3670 ÷ 3780		1800	1135	2645 ÷ 2755		1620	1135	3045 ÷ 3155				
		1950 ÷ 2060			2200 ÷ 2310		-	1490	2650 ÷ 2760		-	1540	2755 ÷ 2885		-	1540	3085 ÷ 3195		-	1720	3680 ÷ 3790		-	1720	3850 ÷ 3960		1620	1135	3045 ÷ 3155				
ZF 16 S 181	KLEIN GKN	1875 ÷ 1985		-	2275 ÷ 2385		1510	-	1050 ÷ 1160		1735	-	1125 ÷ 1235		1735	-	1450 ÷ 1560		1735	-	1850 ÷ 1960		1735	-	2025 ÷ 2135		1215 1735	- -	1400 ÷ 1510 1400 ÷ 1510		- -	- -	-
EuroTronic Automated 12 AS 2301	KLEIN GKN	1975 ÷ 2085		- 1060	2375 ÷ 2485 2395 ÷ 2505		1615 -	- 1515	1050 ÷ 1160 2675 ÷ 2785		1840	- 1735	1125 ÷ 1235 2970 ÷ 3080		1840	- 1735	1450 ÷ 1560 3280 ÷ 3390		1840	- 1735	1850 ÷ 1960 3695 ÷ 3805		1840 -	- 1735	2025 ÷ 2135 3865 ÷ 3975		1215 1840 1815	- - 1135	1400 ÷ 1510 1400 ÷ 1510 2645 ÷ 2755		1815	1135	3045 ÷ 3155

CABS 6x2p		WHEELBASE																											
		3120		3805		4200		4500		4800		5100		5700		6050													
Gearbox type	Shaft type	L mm	L mm	L' mm	L2 mm	L mm	L' mm	L2 mm	L mm	L' mm	L2 mm	L mm	L' mm	L2 mm	L mm	L' mm	L2 mm	L mm	L' mm	L2 mm	L mm	L' mm	L2 mm						
		min.	max	min.	max	min.	max	min.	max	min.	max	min.	max	min.	max	min.	max	min.	max	min.	max	min.	max						
WT MD 3060	KLEIN GKN	1350 ÷ 1460		2000 ÷ 2110		-	1080	2415 ÷ 2525		-	1530	2690 ÷ 2800		-	1565	2800 ÷ 2910 3010 ÷ 3120		-	1755	3315 ÷ 3425		-	1755	3885 ÷ 3995		1835	1135	2420 ÷ 2530	
WT MD 3066																													
ZF 9 S 109	KLEIN GKN	1325 ÷ 1435 1350 ÷ 1460		2000 ÷ 2110		-	1070	2405 ÷ 2515		-	1520	2680 ÷ 2790		-	1745	2980 ÷ 3090		-	1745	3305 ÷ 3415		-	1745	3875 ÷ 3985		1825	1135	2420 ÷ 2530	
				1825 ÷ 1935		-	890	2225 ÷ 2335		-	1340	2500 ÷ 2610		-	-	3000 ÷ 3110		-	1565	3125 ÷ 3235		-	1565	3695 ÷ 3805		1645	1135	2420 ÷ 2530	
				1975 ÷ 2085		-	-	2405 ÷ 2515		-	-	2685 ÷ 2795		-	-	2820 ÷ 2930		-	-	3310 ÷ 3420		-	-	3890 ÷ 4000		1830	1135	2420 ÷ 2530	
				1810 ÷ 1910		-	-	2505 ÷ 2615		-	-	2505 ÷ 2615		-	-	3130 ÷ 3240		-	-	3710 ÷ 3820		-	-	3710 ÷ 3820		1650	1135	2420 ÷ 2530	
ZF 16 S 151	KLEIN GKN	-		1950 ÷ 2060 1755 ÷ 1885		-	-	2200 ÷ 2310 2390 ÷ 2500		-	-	2660 ÷ 2770 2470 ÷ 2580		-	-	2975 ÷ 3085 2755 ÷ 2885		-	-	3290 ÷ 3400 3085 ÷ 3195		-	1720 1540	3850 ÷ 3960 3670 ÷ 3780		1800 1620	1135	2420 ÷ 2530 2420 ÷ 2530	
ZF 16 S 181	KLEIN GKN	-		1875 ÷ 1985		-	-	2300 ÷ 2410		1510	-	1065 ÷ 1175		1735	-	1150 ÷ 1260		1735	-	1450 ÷ 1560		1735	-	2025 ÷ 2135		1215 1735	- -	1200 ÷ 1310 1200 ÷ 1310	
EuroTronic Automated 12 AS 2301	KLEIN GKN	-		1975 ÷ 2085		-	-	2410 ÷ 2520 2400 ÷ 2510		- 1615	1515 -	2675 ÷ 2785 1065 ÷ 1175		- 1840	- -	2990 ÷ 3100 1150 ÷ 1260		1840 -	- -	1450 ÷ 1500 3300 ÷ 3410		1840 -	- 1735	2025 ÷ 2135 3865 ÷ 3975		1215 1840 1815	- - 1135	1200 ÷ 1310 1200 ÷ 1310 2420 ÷ 2530	


DIAGNOSTIC

Main operating faults in the drive shaft :

- I - Drive noise and vibration




(continues)




TIGHTENING TORQUES

COMPONENT	TORQUE	
	Nm	kgm
Ring nut to fasten the flange to the propeller shaft: M 40X1.5	350 + 50	35 + 5
M 55X1.5	380 + 70	38 + 7
Screw fastening the flange to the propeller shaft: M 20X160	450 ± 34	45 ± 3.4
Nut for screw fastening propeller shaft flanges	133.5 ± 13.5	13.3 ± 1.3
Nut for M12 screw fastening flexible support bracket to chassis	92 ± 9	9.2 ± 1

TOOLS

TOOL NO.	DESCRIPTION
99370618	 Support to remove-fit back the propeller shaft

505620 REMOVING AND REASSEMBLING THE PROPELLER SHAFT**Figure 3**

49255

LAY-OUT OF A TRANSMISSION COMPOSED OF:
Front propeller shaft (3) - Support (2) - Sliding rear shaft (1)

Removal

Always remove the rear propeller shaft first before overhauling a transmission.

Place a hydraulic jack, fitted with support 99370618, underneath the rear propeller shaft. Remove the nuts fastening the flanges and disconnect the propeller shaft; as for the front propeller shaft, also remove the support fastening the shaft to the chassis.


Reassembly

Follow the above mentioned procedure backwards, checking for the following:

- ☐ Rear propeller shaft
 - make sure the arrows on the sliding sleeve and shaft are aligned;
- ☐ Front propeller shaft
 - make sure the holes in the front flange match those in the rear flange;
 - do not re-use the nuts of the flange fastening screws; replace them;
 - make sure the flange fastening screws match the flange holes on the universal joint end;
 - make sure nuts and screws are tightened to the required torque;
 - make sure the sliding propeller shaft flange is connected to the input shaft flange.

CHECKING THE PROPELLER SHAFT ON THE VEHICLE

Figure 4



33808

The propeller shafts are supplied by the supplier as assemblies ready to be mounted.

They are statically and dynamically balanced.


The plates welded to the transmission shafts are balancing plates.

If the plates are missing, it will be necessary to re-balance the shaft.

Working on the transmission shaft and, at the same time, but in the opposite direction, on the sliding sleeve (arrows) check that there is no clearance between the grooves.

Working on the forks of the sleeves (arrows) check that the spiders are not worn. If they are, replace them as described previously.

Figure 5



38824

FRONT PROPELLER SHAFT COMPONENTS

1. Front fork flange - 2. Grease nipple - 3. Split ring - 4. Spider - 5. Propeller shaft - 6. Ring nut
7. Washer - 8. Rear flange - 9. Support

REMOVING AND FITTING BACK THE UNIVERSAL JOINTS

Using suitable pliers, remove the split ring (3, Figure 6). Beat the fork flange (1) with a hammer until the bearing starts coming out of its housing, i.e. Until the spider (4) interferes with the fork. Turn the component upside down and repeat the above operations.

Manually remove one of the two bearings. Remove the fork (1) and use a punch to remove the other bearing.

Repeat this procedure to remove bearings from the other fork and free the spider (4).

To reassemble, repeat the above mentioned procedure backwards.


REMOVING AND REASSEMBLING THE SUPPORT

Using a suitable wrench, remove the ring nut (6, Figure 5) and the following components from the propeller shaft:

- ☐ washer (7);
- ☐ rear flange (8);
- ☐ support (9).

To reassemble, repeat the above mentioned procedure backwards.

Figure 6



38825

FRONT PROPELLER SHAFT COMPONENTS

I. Front fork flange - 2. Grease nipple - 3. Split ring - 4. Spider - 5. Front half-propeller shaft - 6. Ring nut (for KLEIN supply only)
- 7. Rear fork flange - 8. Rear half-propeller shaft


SECTION 7**5250 Rear axles**

	Page
FAULT DIAGNOSIS	3
REMOVING-REFITTING THE REAR AXLE	5
☐ Removal	5
☐ Refitting	5
REMOVING-REFITTING THE DIFFERENTIAL FROM THE REAR AXLE ON THE VEHICLE .	6
☐ Removal	6
☐ Refitting	6
REAR AXLE MERITOR MS 13-175 WITH DISC BRAKES	7
REAR AXLE MERITOR MS 13-175 WITH DRUM BRAKES	43
REAR AXLE 451391	61
AXLE IN TANDEM MERITOR RT 160 E/I	97
☐ RP 160 E (R 2478) (INTERMEDIATE)	99
☐ RR 167 E (R 0878) (REAR)	147


FAULT DIAGNOSIS

The main rear axle operating faults are as follows:

- 1 - Wheel hub noise;
- 2 - Noise;
- 3 - Noise on release;
- 4 - Noise during acceleration;
- 5 - Cornering noise.



(cont'd)



REMOVING-REFITTING THE REAR AXLE

Removal

There follows a description of the operations for removing and refitting the rear axle with disc brakes that, by analogy, can be considered good for the rear axle with drum brakes too.


- ☐ Set the vehicle on level ground and lock the front wheels.
- ☐ Loosen the nuts fixing the wheels.
- ☐ Lift the vehicle at the rear and put the chassis frame on two stands.
- ☐ Put the hydraulic trolley 99321024 under the wheels, take out the nuts fixing the wheels and remove them.
- ☐ Cut the clamps holding the wiring and air piping to the reaction triangle.
- ☐ Disconnect the three brake air pipes (33) from the bracket (30).
- ☐ Take out the screws (31) and disconnect the reaction triangle (32) from the axle housing.
- ☐ Extract the speed sensors (1) from the brake calliper supporting flange (2) (det. A).
- ☐ Take out the screws (12) and extract the brake lining wear sensor (13) (det. B).
- ☐ Disconnect the air pipe (16) and the electrical connection (29) from the differential locking control device.
- ☐ Take out the screws (27) fixing the propeller shaft flange (28).
- ☐ With an appropriate rope, secure the propeller shaft to the vehicle's chassis frame.
- ☐ Disconnect the brackets (5) for the levelling valve tie rods (35) from the mounts (17).
- ☐ Using a hydraulic lift, apply the mount 99370617 (21) to the axle housing.
- ☐ Take out the fixing screws (10) and disconnect the stabilizer bar (8) from the mounts (9).
- ☐ Loosen the screws (7) fixing the cap (6) retaining the stabilizer bar (8) to the anchor bar (4).
- ☐ Turn the stabilizer bar and secure it with a suitable rope to the chassis frame so as not to obstruct removing the rear axle.
- ☐ Take out the nuts (14) and disconnect the longitudinal tie rods (15).
- ☐ Take out the nuts (11) and disconnect the shock absorbers (3) from the axle mount (17).
- ☐ Disconnect the air vent pipe (34) from the axle.
- ☐ Take out the nuts (26) and disconnect the air springs (18) from the mounts (17).
- ☐ Lower the hydraulic lift and extract the rear axle from the vehicle.
- ☐ Disconnect the mounts (17) from the axle housing, removing the nuts (22) for the fixing brackets (23).
- ☐ Take out the screws (25) and disconnect the wiring and air pipes of the differential case.
- ☐ Fully unscrew the screws (24) to release the brake cylinder (20).
- ☐ Remove the nuts (19) and disconnect the brake cylinder (20) from the axle housing.

Refitting

For refitting, carry out the operations described for removal in reverse order, keeping to the required tightening torques for the screws and/or nuts. Afterwards, check that:

- ☐ There is no air leakage from the air pipes.
- ☐ The lubricating oil of the axle housing is at the right level.
- ☐ The differential locking indicator lamp works properly; if it does not, proceed as described under the relevant heading.

Figure 1



REMOVING-REFITTING THE DIFFERENTIAL FROM THE REAR AXLE ON THE VEHICLE



Removal

- ☐ Set the vehicle on level ground and lock the front wheels.
- ☐ Drain the oil from the axle housing through the drain plug.
- ☐ Take out the screws (7) and disconnect the propeller shaft (8) from the differential flange.
- ☐ Secure the propeller shaft to the vehicle's chassis frame with an appropriate rope.
- ☐ Disconnect the electrical connection (4) for the switch (5) signalling differential locking and the air pipe (3) from the differential locking control device.
- ☐ Disconnect the screws (1) fixing the drive shafts (2) and extract them from the axle housing.
- ☐ Using the hydraulic jack, put the mount 993770616 (10, det. B) under the differential and constrain the brackets (11) of this mount to the flange (12) of the differential sleeve (det. B).
- ☐ Unscrew the screws (6) and nuts (9) fixing the differential assembly to the axle housing.
- ☐ Remove the plugs (det. B) from the threaded holes and screw appropriate screws into them so as to extract the differential from the axle housing.



Refitting

For refitting, carry out the operations described for removal in reverse order, keeping to the following instructions:

- ☐ The self-locking nuts have to be replaced with new parts for each removal.
- ☐ After thoroughly cleaning the parts, apply sealant paste onto the threads of the screws fixing the differential case and the drive shafts.
- ☐ Tightening sequence diagram (differential case to axle housing) (det. A)
1 – 2 – 3 – 4 nuts;
10 – 9 – 14 – 5 – 7 – 11 – 13 – 6 – 8 – 12 screws.
- ☐ Tighten the screws and nuts fixing the differential case to the rear axle at the required torque and in the sequence indicated in the diagram.

After refitting:


- ☐ Screw the drain plug on and restore the level of oil with the required quantity and grade.
- ☐ Check there is no leakage from the air pipe of the differential locking device and that it engages.
- ☐ Check that the differential locking indicator light in the cab works correctly; if it does not, keep to the instructions described in the relevant section.

Instructions to adjust and check the operation of the transmitter controlling differential locking and divider engagement.

The operation of the transmitter (two-function type) to control differential and divider engagement is adjusted and checked with the axle mounted on the vehicle and proceeding as described below:

- ☐ With differential locking, screw down the transmitter to close the contacts and check the indicator light in the cab comes on.
- ☐ The moment the indicator light in the cab comes on, screw down the transmitter one more turn.
- ☐ Tighten the lock nut to lock the transmitter at a torque of 40 Nm (4 kgm).
- ☐ Release the divider and differential locking engagement control and check that the contacts are closed (in this condition, the indicator light in the cab must be off).

Figure 2



5250 Rear Axle MERITOR MS 13-175 with disc brakes

	Page
DESCRIPTION	9
CHARACTERISTICS AND DATA	10
TIGHTENING TORQUES	11
TOOLS	13
OVERHAULING THE REAR AXLE ASSEMBLY .	18
OVERHAULING THE WHEEL HUBS	18
☐ Removal	18
☐ Replacing wheel hub bearings	20
☐ Checking the parts forming the wheel hubs ...	20
☐ Replacing the wheel fixing pins	20
REMOVING AND REFITTING THE DIFFERENTIAL	24
☐ Removal	24
☐ Refitting	24
REPAIRING THE DIFFERENTIAL	25
☐ Removing the differential	25
☐ Removing the gearcase	26
REMOVING THE BEVEL PINION FROM THE SUPPORT	28
☐ Differential component check	28
☐ Fitting the gear housing	29
FITTING THE MOUNT ON THE BEVEL PINION	30
☐ Reassembling the differential housing	32
ADJUSTING THE CAP GAP	34
CORRECTING THE CROWN WHEEL AND PINION CONTACTS (after assembly)	37
WORK ON THE VEHICLE	40
REPLACING THE BEVEL PINION MOUNT SEAL	40
☐ Disassembly	40
☐ Assembly	41

DESCRIPTION

The rear axle is the load bearing type with a single reduction. It is composed of a pressed sheet steel box appropriately strengthened.

The differential consists of a group of hypoid gears of coarse pitch type.

The pinion is supported by two tapered roller bearings (pinion unit) and by a third cylindrical roller bearing.

The position of the bevel pinion, in relation to the ring bevel gear, is adjusted by changing the thickness of the pack of rings between the differential case and the bevel pinion mount.


The gearing box is supported by two tapered roller bearings and can be adjusted axially with two threaded ring nuts.

The rear axle is equipped with a differential locking device.

The bearings of the wheel hubs are the UNIT-BEARING type with permanent lubrication and need no adjustment.

The brakes are of disc type with KNORR float calipers.

Figure 1



84400

VIEW OF THE MERITOR MS 13-175 REAR AXLE ASSEMBLY

CHARACTERISTICS AND DATA









	Rear axle Type	Load bearing with single reduction Meritor MS 13-175
	Bevel pinion bearings	2 with tapered rollers and 1 with cylindrical rollers
	DIFFERENTIAL ASSEMBLY Bevel gear pair reduction ratio	2.64 (14/37) - 2.85 (13/37) - 3.08 (12/37) 3.36 (11/37) - 4.11 (9/37) - 4.63 (8/37)
	Clearance between pinion and ring gear mm	0.26 to 0.50
	Adjustment of clearance between pinion and ring gear	With adjustment rings
	Bevel pinion position in relation to ring gear	With adjustment shims
	Cap gap mm	0.15 to 0.33
	Cap gap adjustment	With adjustment rings
	Rolling torque between planetary gears and crown wheels Nm kgm	68 max. 6.8 max.
	 Thicknesses of adjustment rings between bevel pinion mount and differential case mm	0.125 - 0.200 - 0.500
	Wobble of ring gear supporting surface on half box mm	0.13 max.
	WHEEL HUBS	
	Wheel hub bearings	Two Unit Bearing type
	Wheel hub bearing end float adjustment	Not adjustable Tightening to torque with threaded nut
	Axle oil	TUTELA TRUCK FE-AXLE
	Quantity Litres (kg)	18.5 (16.5)
	Dry weight kg	-
	Maximum capacity GRW kg	13000

Figure 2




TIGHTENING TORQUES

49302

PART		TORQUE	
		Nm	kgm
1	Screw fixing differential case to axle housing	1 st phase torque 2 nd phase angle	100 ± 5 80° to 90°
2	Screw fixing differential half boxes	1 st phase torque 2 nd phase angle	100 ± 5 110° to 120°
3	Screw fixing bevel ring gear to half box	1 st phase torque 2 nd phase angle	100 ± 5 80° to 90°
4	Nut locking bevel pinion		1350 to 1670 135 to 167
5	Screw fixing bevel pinion mount	1 st phase torque 2 nd phase angle	100 ± 5 60° to 70°
6	Nut locking sensor		35 to 45 3.5 to 4.5
	Screw fixing caps to differential case		650 to 810 65 to 81
	Oil drain plug		47 4.7

Figure 3



TIGHTENING TORQUES







84401


PART	TORQUE	
	Nm	Kgm
1 Nut fixing wheels	732 to 599	73.2 to 59.9
2 Screw fixing drive shaft flange	235 to 289	23.5 to 28.9
3 Ring nut retaining wheel hub bearing	834 to 1030	83.4 to 103
4 Screw fixing brake disc to wheel hub	268 to 295	26.8 to 29.5
5 Screw fixing brake calliper to mount	554 to 677	55.4 to 67.7
6 Nut for screw fixing brake calliper mount	275 to 304	27.5 to 30.4

* Spread with sealant type IVECO I905685 (LOCTITE 14780)


A TIMKEN bearing

B SKF bearing


TOOLS		
TOOL NO.		DESCRIPTION
99305121		Heater
99322205		Rotary stand for unit overhauling
99322215		Stand for axle overhauling
99322225		Unit holder (to be mounted on stand 99322205)
99341003		Single-acting lift
99341009		Pair of brackets

TOOLS**TOOL NO.****DESCRIPTION****99341015**

Clamp

99341017


Pair of brackets with holes

99345049


Reaction block for puller tools

99345053


Reaction block for puller tools

99348001


Puller tool with clamping device

99355025


Wrench for differential gearcase bearing adjustment ring nuts

TOOLS**TOOL NO.****DESCRIPTION****99355088**


Wrench (60 mm) for differential bevel pinion nut
(to be used with 99370317)

99355180

Wrench (105 mm) for wheel hub bearing adjustment nut

99363204


Tool to extract gaskets

99370317

Reaction lever and extension for flange lock







99370509

Hook to remove differential gearcase half-housing

99370616


Support to remove-fit back differential

TOOLS

TOOL NO.	DESCRIPTION	
99370617		Universal support to remove-fit back rear axles
99370700		Guide to assemble wheel hub
99370706		Tool to fit wheel hub bearing
99370708		Tool for removing wheel hub bearing
99371047		Stand to hold differential half-housing when tightening crown wheel screws (to be used with 99322205 - 99322225)
99374244		Installing tool for assembling bevel pinion seal ring

TOOLS**TOOL NO.****DESCRIPTION****99389816**

4 x torque multiplier, with square connection, 3/4" in, 1" out
(maximum torque 2745 Nm)

99389819

Torque wrench (0 - 10 Nm) with 1/4" square fitting


525010 OVERHAULING THE REAR AXLE ASSEMBLY



The following operations can also be performed with the assembly mounted on the vehicle: removing refitting drive shafts – removing refitting drums – removing refitting differential.

Before putting the rear axle assembly on the stand for overhauling, drain off the oil by unscrewing the bottom plug of the differential case.

Figure 4




Put the rear axle (1) on the overhaul stand 99322215 (2).

525030 OVERHAULING THE WHEEL HUBS


Removal

Figure 5




Remove the split pin (4), washer (3), pin (2) and plate (1) holding the brake linings.

Figure 6




Remove the plug (3), turn the adjustment unit (2) anticlockwise, with a spanner, to make the pistons move back into the calliper body.

Figure 7




Remove the brake linings (1) making the calliper body (2) float appropriately.

Figure 8



Take out the screws (2) and remove the brake calliper (1) from the supporting flange (3).


Figure 9



72744

Put a container under the wheel hub to collect the oil. Lock rotation of the wheel hub (1) with the retaining tool 99370317 (3). Take out the screws (2) and extract the drive shaft (4).


Figure 10



72745

Lift the notching of the ring nut (5). Using the wrench 99355180 (1) and multiplier 99389816 (2), remove the ring nut (5) holding the wheel hub bearing. Take out the retaining ring (4).


Figure 11



72746

Remove the wheel hub (1). If this proves difficult, use the extractor comprising: brackets 99341017 (2), bridge 99341003 (3), block 99345053 (4), applied as shown in the figure.


Figure 12



72747

If the brake calliper supporting plate (1) is damaged, remove it from the axle housing by taking out the bolts (2).

Figure 13




72748

Take out the screws (2) and remove the wheel hub (1) from the brake disc (3).


Examine the state of wear of the brake disc (3) as described in the "BRAKE AIR SYSTEM" section.

Figure 14




72749

The phonic wheel (1) is removed from the wheel hub (2) with general tools.


529621 Replacing wheel hub bearings**Figure 15**

Using a hydraulic press and tool 99370708 (1) take out the wheel hub, spacer (3) and bearing (2).

Figure 16

Position the bearing (2) with the seal (4) turned as shown in the figure on the wheel hub (3).

Using the press and tool 99370706 (1) mount the bearing (2): bearing drive-in load 25,000 to 85,000 N.

Figure 17

Fit the spacer ring (2) in the wheel hub (1) and check on two diametrically opposite points that, after assembly, the ring (2) is sunk below the face of the wheel hub by 0.0 to 0.145 mm.

Checking the parts forming the wheel hubs

Thoroughly clean the single parts comprising the wheel hub. Examine the drive shafts and check there is no deformation.




Check the wheel fixing pins: if there is any deformation or damage to the thread, replace them, using a press to extract them.



Check the threads of the nuts to adjust the hub bearings and the threads on the ends of the axle housing; change the nuts if necessary.

Replace all the sealing elements with new parts.


525035 Replacing the wheel fixing pins**Figure 18**

Using general tools, drive the pins (2) out of the hub (1). Make sure the supporting surface for the heads of the pins has no burrs.

Carefully drive in the pins, applying a load no greater than 2500 kg on their heads.


Afterwards, check that the obliquity is no greater than 0.3 mm.

Figure 19




If the plate (1) were disassembled, fit it back on the axle housing and tighten the nuts (2) for the fixing screws (3) to the required torque.

Figure 20




Screw the tool 99370700 (2) onto the sleeve (1) of the axle housing. Lubricate the tool external surface (1) with the oil prescribed for the wheel hubs.

Figure 21




Heat the phonic wheel (1) to approx. 150°C and fit it on the wheel hub (2).
On completing assembly, make sure the phonic wheel (1) rests correctly in the seat of the hub.

Figure 22




Fit the wheel hub on the sleeve of the axle housing and, using a dial gauge (1) with a magnetic base, check that the radial runout of the phonic wheel (2) is no greater than 0.2 mm. Remove the wheel hub.

Figure 23




Mount the brake disc (3) on the wheel hub (1) and screw down the screws (2).

Figure 24




Sling the brake disc (1) with a rope, hook this onto a lift and fit the wheel hub (2) on the sleeve of the axle housing. Remove the tool 99370700 (3).

Figure 25




Position the retaining ring (4) so as to insert the tab into the groove of the sleeve, then screw on the ring nut (5). Using the wrench 99355180 (1), multiplier 99389816 (2) and the torque wrench (3), tighten the ring nut (5) to the required torque.

Figure 26




After tightening, using an appropriate tool, notch and bend the ring nut as shown in the figure so it cannot be unscrewed. The arrow shows the direction of unscrewing the ring nut.

Figure 27




Lock rotation of the wheel hub (3) with the tool 99370317 (4) and tighten the screws (2) fixing the brake disc (1) to the wheel hub to the required torque.

Figure 28




Spread IVECO I905685 (LOCTITE I4780) sealant onto the flange contact surfaces of the drive shaft – wheel hub and insert the drive shaft into the axle housing. Screw down the screws (2) fixing the drive shaft (3) to the wheel hub (1) and tighten them with the torque wrench (4) to the required torque. Remove the tool 99370317 (5).

Figure 29




Position the brake calliper (1) on the flange (3) and tighten the fixing screws (2) to the required torque.

Figure 30




Mount the brake linings (1) in the brake calliper (2).

Figure 31



Mount the brake lining retaining plate (1).
Mount the pin (2), washer (3) and secure them with the split pin (4).

Figure 33




Provisionally mount the plug (1) for the brake lining wear adjustment screw.



After refitting the rear axle on the vehicle, check the efficiency of the brake lining wear recovery device, as described in the relevant section and replace the plug (1) with a new one.

On completing assembly, fill the axle housing with the required quantity and grade of lubricating oil.

Figure 32




WHEEL HUB COMPONENT PARTS

1. Screw – 2. Drive shaft – 3. Ring nut – 4. Retaining ring – 5. Spacer ring – 6. Bearing –
7. Wheel hub – 8. Phonic wheel – 9. Brake disc – 10. Axle sleeve

526210 REMOVING AND REFITTING THE DIFFERENTIAL (with axle on stand 99322215)

Figure 34




Removal

Extract the drive shafts as described on page 21, unscrew the screws and nuts fixing the differential case (1); screw three screws, which in this case act as extractors, into the threaded holes and extract the differential from the axle housing (2).


Refitting

Figure 35




Spread the contact surface of the axle housing with IVECO 1905685 (LOCTITE 14780) sealant, after cleaning the contact surface.

Figure 36



Insert the differential into the axle housing, screw down the nuts (2) and screws (3) together with the safety washers and tighten them, with a torque wrench (1), to the required torque and in the sequence shown in Figure 37. Mount the drive shafts as described on page 23. Pour the required amount of oil into the axle housing.

Figure 37




Tightening sequence diagram (differential case to axle housing)
(1 - 2 - 3 - 4 - Nuts)
(10 - 9 - 14 - 5 - 7 - 11 - 13 - 6 - 8 - 12 - Screws)

526210 REPAIRING THE DIFFERENTIAL


Removing the differential

Figure 38




Remove the differential (1) as described in Figure 34. Secure it to the stand 99322205 (3) with the mount 99322225 (2).

Figure 39




Unscrew the transmitter (1); unscrew the screws (2) and remove the parts 3 – 4 – 5.

Figure 40




Push the split pins (1 →) outwards and extract the sliding sleeve (2). Take out the spring (3), fork (4) and split pin (5).

Figure 41




Unscrew the ring nut (1) for adjusting the bearing. Using an appropriate wrench, unscrew and remove the screws (2) with their washers; repeat this process on the opposite side. Remove the supporting bearing caps (3).

Figure 42



Using the hook 99370509 (1) extract the gearing housing (2) together with the ring bevel gear and outer rings (3).


Figure 43



49226

Using tool 99370317 (2), lock the flange (1).
Using wrench 9955088 (3) and multiplier (4), loosen the bevel pinion nut.

Figure 44



49227


Remove the nut (1) and extract the flange (2).
Remove the screws (3) fastening the bevel pinion support to the differential housing (4).
Remove the complete bevel pinion support (5) from the differential carrier. Remove the shims (6) for adjusting the pinion position in relation to the crown wheel and use a micrometer to measure the overall thickness.



Check that the seal ring is intact (O-ring), change it if damaged.

Removing the gearcase


Figure 45



49228

Using a suitable puller (1), extract the bearing (2).


Figure 46



49228A


Turn the gearcase upside down and remove the bearing (1).
(This is a destructive operation).

Figure 47



49229


Place the gearcase on tool 9971047 (1).
Remove the locknuts (2) fastening the ring bevel gear (3) to the gearcase.
Using a bronze beater, remove the ring bevel gear.

Figure 48

Mark the mounting positions of the two half casings (2 and 3) and spider.
Remove the screws (1) and lift the half casing (2) off the unit.

Figure 49

Remove components (2 - 3 - 4 - 5 - 6 - 7 - 8 - 9) from the half casing (1).




GEARCASE COMPONENTS

1. Half casing - 2. Half casing - 3. Crown wheel - 4. Planetary gear - 5. Spider - 6. Shoulder washer - 7. Planetary gears - 8. Crown wheel - 9. Shoulder washer

49234A

526249 REMOVING THE BEVEL PINION FROM THE SUPPORT


Figure 50



49230

Using tool 99348001, extract the bearing (1) from the bevel pinion (2).

Figure 51




72765

Drive the bevel pinion (2) out of the mounting (1) (under a press).



The mounting (1) is supplied as a spare part together with preassembled tapered roller bearings and seals (3 and 4).

Figure 52



49232

Using a suitable tool (1), extract the bearing (2).

Differential component check



Carefully clean all differential components. Lubricate the bearings and rotate the roller cage; it should rotate freely and smoothly.




Inspect the ring bevel gear and half casing contact surfaces, making sure the ring bevel gear perfectly adheres. Warped surfaces may cause ring bevel gear fastening screw vibration, thus undermining the unit operation.

Make sure the slotted section fastening the flange to the pinion is not worn. If it is, replace the pinion.


Fitting the gear housing

Figure 53




Place the half casing (3) on tool 99371047. Insert the crown wheel shoulder washer (2) into the half casing, then fit the crown wheel (1).

Figure 54



Fit the spider (6), complete with planetary gears (5) and shoulder washers (3), to the half casing (2). If the spider has not been replaced, make sure the marks made on removal match. Fit the second crown wheel (2) complete with shoulder washer (1).


Figure 55



Fit the half casing (2). Make sure the marks made on removal match. Insert the screws (1) and tighten as follows:


- ☐ 1st phase: tightening with a torque wrench (3) to a torque of 100 Nm (10 kgm).

Figure 56




- ☐ 2nd stage: tighten the screws (1) by means of tool 99395216 (3) at 110° to 120° angle. Heat the bearing (2) at 100°C for approx. 15 min. in a convection furnace and fit it, using a suitable beater.

Figure 57



Heat the ring bevel gear (1) to a temperature of 100°C + 150°C in an air circulation oven and position it in its seat, in the gear housing, checking it turns freely and making the holes coincide for the screws fixing the ring bevel gear-gear housing by fitting the 4 manoeuvring screws.

Figure 58




Let the ring bevel gear cool, then place the gearcase upside down on the tool.

Insert the screws (1) and tighten as follows:

- ☐ 1st stage: tighten to 100 Nm (10 kgm) torque by means of a torque wrench (2);
- ☐ replace the 4 manoeuvre screws with new ones and apply the same specified torque.

Figure 59




49236A

2nd phase: closing, with tool 99395216 (I) with an angle of 80 to 90°.

Heat the bearing (2) to a temperature of 100°C for approx. 15 min. in an air circulation oven and drive it in with an appropriate drift.

526249 FITTING THE MOUNT ON THE BEVEL PINION


Figure 60



72766

The bevel pinion mount (1) is supplied as a spare together with the tapered roller bearings (2 and 3) and the seals (4 and 5).


Figure 61



49237

Heat the bearing (2) to a temperature of 100°C for 15 min. in an air circulation oven and mount it on the bevel pinion (1).


Figure 62



72767

Using a press and a suitable tube (1) positioned on the inner ring of the roller bearing (4), fit the mount (2) on the bevel pinion (3).

Figure 63



72768


Heat the bearing (1) to a temperature of 100°C for 15 min. in an air circulation oven and mount it on the bevel pinion (2).

Lock the bearing by notching the bevel pinion at 10 equidistant points as shown in the figure. This should be done conscientiously with a suitable punch.



The diameter of the impression has to be between 3.40 to 4.10 mm, corresponding to a depth of 0.30 to 0.44 mm respectively, using a load of 4000 kg with a ball with a 10 mm diameter.


Figure 64



49239

Place the transmission fitting flange (1), complete with baffle (2), and fit it using a suitable beater. The use of a vice is recommended. Temporarily tighten the lock nut.


Figure 65



49240

If the same pinion-crown wheel unit previously removed is reinstalled, fit the relative adjusting shims (2) and bevel pinion support with the seal ring (O-ring) (1) to the differential housing (3). Make sure the lubrication oil slot is properly aligned.

Figure 66



19416

Before assembling a new pinion-crown wheel unit, it is mandatory to understand the meaning of the marks stamped on both pinion and crown wheel, in order to find out the proper pinion position.

1. Part number
2. Tooth play number
3. Pinion-crown wheel unit coupling number
4. Adjustment number, to define the thickness of the shims to be fitted between pinion support and differential housing (this number is called CP in the following examples)
5. Pinion-crown wheel unit date of manufacturing and testing (month and year)
6. Pinion-crown wheel unit rated backlash.

Part and tooth play numbers are marked on the pinion threaded end.

On crown wheels, the same numbers are generally marked on the front face.

As an alternative, they may be found on the crown wheel outer diameter.

For any pinion-crown wheel unit, the crown wheel part number shall always be even (for instance, 36786), whereas the corresponding pinion part number shall be odd (for instance, 36787).

The tooth play number (for example, 10-41) means the pinion features 10 teeth and crown wheel 41, corresponding to 4.10 : 1 transmission ratio.



Never use pinion-crown wheel units bearing different numbers.

Each crown wheel has an adjustment number specifying the rated mounting clearance.

Use this number to calculate the thickness of the adjusting shims to be fitted between pinion support and differential housing.

This number (for example, C.P. +0.1, or C.P. -0.1 mm), is stamped on the crown wheel outer diameter.

To calculate the thickness of the adjusting shims to be fitted between pinion support and differential housing, proceed as follows:

1. Measure the thickness of the shims fitted on the pinion-crown wheel unit to be replaced. Use a micrometer or gauge and note the measurement.
2. Read the C.P. stamped on the crown wheel to be replaced. If positive (+), subtract this number from the previously taken measurement (see "1"). If the number represents a negative value (-) add it to the measurement taken (see "1").

Note the result.



The measurement obtained at "2" shall be used to calculate the thickness of the adjusting shims to be fitted between pinion support and differential housing, in relation to the new pinion-crown wheel unit to be installed.

3. Read the C.P. stamped on the new crown wheel. Add or subtract this value (add if +, subtract if -) to/from the previously taken measurement (see item "2").

The obtained value indicates the thickness of the new shims to be fitted.

Refer to the following examples, covering all possible combinations.

Examples of calculation

Example 1:

Original shim thickness	mm 0.75
Crown wheel C.P. + 0.05	- 0.05
Result	mm 0.70
New crown wheel C.P. + 0.10	+ 0.10
New shim thickness to be used	mm 0.80

Example 2:

Original shim thickness	mm 0.65
Crown wheel C.P. - 0.05	+ 0.05
Result	mm 0.70
New crown wheel C.P. + 0.15	+ 0.15
New shim thickness to be used	mm 0.85

Example 3:

Original shim thickness	mm 0.70
Crown wheel C.P. + 0.05	- 0.05
Result	mm 0.65
New crown wheel C.P. - 0.05	- 0.05
New shim thickness to be used	mm 0.60

Example 4:

Original shim thickness	mm 0.85
Crown wheel C.P. - 0.10	+ 0.10
Result	mm 0.70
New crown wheel C.P. - 0.15	- 0.15
New shim thickness to be used	mm 0.80




Spare parts shims, to be fitted between pinion support and differential housing, are provided with the following thickness: 0.125 - 0.200 - 0.500 mm.

A number, specifying the rated backlash between pinion and crown wheel after manufacturing, is stamped on all units. This number is found on the crown wheel outer diameter.

Reassembling the differential housing

Figure 67




49241

Insert the screws (2) and tighten to the prescribed torque, using a torque wrench (1).

- ☐ 1st step: tighten using the torque wrench (1) to a torque of 100 Nm (10 kgm);
- ☐ 2nd step: tighten the screw (2) using tool 9935216 with an angle of 60° ÷ 70°.

Figure 68



49242


Turn the unit by 90°.

Using tool 99370317 (5), lock the flange (3). Using wrench 99355088 (2), multiplier (4) and torque wrench (1), tighten the pinion lock nut to the prescribed torque (1350 to 1370 Nm). Place the caps, making sure reference tabs match. Tighten the screws, complete with washers, to the prescribed torque by means of a torque wrench.



Check that the multiplication factor of the multiplier (4) is correct.

Figure 69




20670

Then, slightly push the bearing outer rings (1), to make sure they slide smoothly within their housings.

Remove the screws, complete with washers, and caps.

Figure 70




49225

Position the external rings (3) of the bearings

Using hook 99370509 (1), lift the previously assembled gearcase (2) and place it onto the differential housing.


Figure 71



49244

Position the caps (2), suitably settle them using a hammer and insert the screws (3), complete with washers. Tighten the screws to the prescribed torque, using a torque wrench (1).

Figure 72



49245

Lubricate the conical roller bearings (1), manually tighten the ring nuts (2) until they touch the external bearing rings; tighten the screws (3, Figure 71) to the prescribed torque.


ADJUSTING THE CAP GAP

Adjusting and checking retraction of the caps can be done with two methods:

1st METHOD

1. Use wrench 99355025 (3, Figure 74) to tighten the adjustment lock rings (4) of the bearings until eliminating the pinion-crown wheel clearance and end float. At the same time check that the crown wheel does not force on the pinion;
2. using a suitable micrometer positioned diagonally and centrally in points (X-Y-arrows, Figure 73); measure and note the distance of the caps;

Figure 73




3. further tighten the two adjustment lock rings (4, Figure 74) to obtain a retraction of the caps (2, Figure 74), measured on Axis X or on axis Y as described in point "2" of: 0.15 to 0.33 mm which corresponds to a preload on the bearings of 1.7 to 3.9 Nm (0.17 to 0.39 kgm).

2nd METHOD


- A. Diagonally and centrally on the outer machined seats of both caps (2, Figure 74) position two dial gauges (1) with magnetic base as shown in Figure 74;

Figure 74



- B. proceed as described in point "1";
- C. after eliminating the end float further tighten the two adjustment lock rings (4, Figure 74) to obtain a retraction of the caps (2) of 0.15 to 0.33 mm, which corresponds to the sum of the readings on the dial gauges (1).

Figure 75




Adjust the axial clearance between the teeth of the pinion - crown wheel unit which must be 0.26 to 0.50 mm proceeding as follows:

- ☐ stop the bevel pinion from turning using tool 99370317;
- ☐ position the magnetic-based dial gauge (1) as illustrated;
- ☐ using wrench 99355025 (3) slacken the adjustment lock ring on the crown wheel side and tighten, to the same extent, the adjustment lock ring (2) of the opposite side. The purpose of this is to leave the previously-adjusted cap retraction unchanged;
- ☐ proceed as described until obtaining the specified clearance.

The clearance should be checked on 4 points the same distance apart.


Figure 76



Use a magnetic-based dial gauge (1) to check that the crown wheel (2) does not have any upper wobble above 0.20 mm. If it does, disassemble the differential unit and find the cause.


Refit and repeat the adjustment operations described previously.

Figure 77



Apply a light layer of Prussian blue on the crown wheel. Turn the pinion and measure the impression of the contact of the pinion teeth on the crown wheel teeth. The following figures show possible contacts and how to correct any errors.

Figure 78



19452

Contacts too much on crown wheel teeth bottom land


Conditions C-D. Indicates that the pinion is fastened too deeply and needs further adjustment.

To adjust the exact position of the pinion shims should be added under the pinion support to obtain the exact contact.

Condition C. Measure the clearance and restore it after adding shims.

Condition D. After adding shims, take the clearance towards minimum.

Figure 79



19453


Contacts too much towards the crown wheel teeth top land

Conditions A-B. Indicates that the pinion is fastened too much towards the outside and therefore needs further adjustment. To adjust the exact position of the pinion, remove shims under the pinion support to obtain the exact contact.

Condition A. After removing the shims, take the clearance towards maximum.

Condition B. Measure the clearance and restore it after removing shims.

Figure 80



Clearance reduction



Clearance increase

19454

THEROETICAL CONTACT AREA

1. Release, concave side of tooth
2. Top land
3. Pulling, convex side of tooth
4. Heel

PULLING. Central tending towards the top land on the tooth face and central on the tooth profile.



RELEASE. Central tending to the heel on the tooth face and central on the tooth profile.

Indicates that the pinion is fastened correctly.



The contact position can be further changed by changing the pinion-crown wheel clearance.

Condition E. Lower the clearance.

Condition F. Increase the clearance.

CORRECTING THE CROWN WHEEL AND PINION CONTACTS (AFTER ASSEMBLY)**Figure 81****THEORETICAL CONTACTS****PULLING
(CONVEX SIDE OF RING GEAR)****RELEASE
(CONCAVE SIDE OF RING GEAR)**


- PULLING : CENTRAL TENDING TOWARDS THE TOP LAND ON THE TOOTH FACE AND CENTRAL ON THE TOOTH PROFILE
- RELEASE : CENTRAL TENDING TOWARDS THE HEEL ON THE TOOTH FACE AND CENTRAL ON THE TOOTH PROFILE

CONDITION "A"**PULLING
TIP****RELEASE
TIP**


- PULLING RELEASE : CONTACTS TOO MUCH AT TIP
- PULLING : CONTACT TOO MUCH AT TOP LAND
- RELEASE : CONTACT TOO MUCH AT HEEL
- CORRECTIVE ACTION : REMOVE SHIMS AND INCREASE CLEARANCE TO MAXIMUM

CONDITION "B"

TIP




TIP




- PULLING - RELEASE : CONTACTS TOO MUCH AT TIP
- CORRECTIVE ACTION : MEASURE THE CLEARANCE AND RESTORE THE CLEARANCE

CONDITION "C"

TIP




TIP




- PULLING - RELEASE : CONTACTS TOO MUCH ON BOTTOM LAND
- CORRECTIVE ACTION : MEASURE THE CLEARANCE, ADD SHIMS AND RESTORE CLEARANCE

60676


Figure 82

CONDITION "D"

- PULLING - RELEASE : CONTACTS TOO MUCH ON BOTTOM LAND
- PULLING; : CONTACT TOO MUCH AT HEEL
- RELEASE : CONTACT TOO MUCH AT TOP LAND
- CORRECTIVE ACTION : ADD SHIMS AND REDUCE CLEARANCE TO MINIMUM

CONDITION "E"


- PULLING : CONTACT TOO MUCH AT HEEL
- RELEASE : CONTACT TOO MUCH AT TOP LAND
- CORRECTIVE ACTION : REDUCE CLEARANCE

CONDITION "F"

- PULLING : CONTACT TOO MUCH AT TOP LAND
- RELEASE : CONTACT TOO MUCH AT HEEL
- CORRECTIVE ACTION : INCREASE CLEARANCE


60677

Figure 83




Replace the safety split pin (1) and fold it; repeat this operation on the opposite side.

Figure 84




Place the pin (4) into its housing.
Fit the fork (2) and spring (3) to the pin (4) and push it in all the way. Fit the piston (5), complete with ring and cover (6), then fit the sliding sleeve (1) and spring plugs (7).

WORK ON THE VEHICLE**REPLACING THE BEVEL PINION MOUNT SEAL****Disassembly****Figure 85**


61481

Slacken the nuts (1) fastening the flange. Disconnect the transmission shaft (2), fastening it to the frame.

Figure 86


61482

Prevent the flange (1) from turning using retainer tool 99370317 (2). Using wrench 99355088 (3) and the multiplier (4) slacken the nut for the bevel pinion and withdraw the flange (4).

Figure 87


61483

Using a suitable tool raise the outer edge of the ring (1) in two opposed points

Figure 88

61484

Using the two levers (2) remove the inner ring (1).


Figure 89

61485

With tool 99363204 (2) positioned as shown in the figure, remove the seal (1) from the bevel pinion mount.

Assembly

Thoroughly clean the seat of the seal of all debris and traces of oil.

Figure 90

61486

Position the new seal (1).

Apply the keying device 99374244 (2), screw a manoeuvring nut onto the bevel pinion and mount the seal down to the stop.

Unscrew the manoeuvring nut, take out the keying device 99374244 (2), fit the flange back on and screw down a new nut, locking it with a torque wrench and multiplier to the required torque.

Fit the propeller shaft back on and tighten the fixing nuts to the required torque.

**5250 Rear axle
MERITOR MS 13-175
with drum brakes**

	Page
DESCRIPTION	45
CHARACTERISTICS AND DATA	46
TIGHTENING TORQUES	49
TOOLS	51
OVERHAULING THE REAR AXLE ASSEMBLY	56
OVERHAULING THE WHEEL HUBS	56
Removal	56
Wheel hub component check	57
REPLACING THE WHEEL HUB BOLTS	58
Wheel hub reassembly	58
REMOVING AND REASSEMBLING THE DIFFERENTIAL	60
Removal	60
Axle casing check	60

DESCRIPTION

The rear axle is the load bearing type with a single reduction. It is composed of a pressed sheet steel box appropriately strengthened.

The differential consists of a group of hypoid gears of coarse pitch type.

The pinion is supported by two tapered roller bearings and by a third cylindrical roller bearing.

The position of the bevel pinion, in relation to the ring bevel gear, is adjusted by changing the thickness of the pack of rings between the differential case and the bevel pinion mount.


The gearing box is supported by two tapered roller bearings and can be adjusted axially with two threaded ring nuts.

The rear axle is equipped with a differential locking device.

The bearings of the wheel hubs are the UNIT-BEARING type with permanent lubrication and need no adjustment.

The brakes are of SIMPLEX drum type.

Figure 1



72769

VIEW OF THE MERITOR MS 13-175 REAR AXLE ASSEMBLY

CHARACTERISTICS AND DATA










	Rear axle Type	Load bearing with single reduction Meritor MS 13-175
	Bevel pinion bearings	2 with tapered rollers and 1 with cylindrical rollers
	DIFFERENTIAL ASSEMBLY Bevel gear pair reduction ratio	2.80 (15/42) - 2.93 (14/41) - 3.07 (14/43) - 3.21 (14/45) - 3.42 (12/41) - 3.73 (11/41)
	Clearance between pinion and ring gear mm	0.26 to 0.50
	Adjustment of clearance between pinion and ring gear	With adjustment rings
	Bevel pinion position in relation to ring gear	With adjustment shims
	Cap gap mm	0.15 to 0.33
	Cap gap adjustment	With adjustment rings
	Rolling torque between planetary gears and crown wheels Nm kgm	68 max. 6.8 max.
	Thicknesses of adjustment rings between bevel pinion mount and differential case mm	0.125 - 0.200 - 0.500
	Wobble of ring gear supporting surface on half box mm	0.13 max.
	WHEEL HUBS	
	Wheel hub bearings	Two Unit Bearing type
	Wheel hub bearing end float adjustment	Not adjustable Tightening to torque with threaded nut
	Axle oil	TUTELA WI 40/M-DA
	Quantity Litres (kg)	18.5 (16.5)
	Dry weight kg	625
	Maximum capacity GRW kg	13,000


Figure 2



49302

DIFFERENTIAL CROSS-SECTION

Figure 3




72770

WHEEL HUB CROSS-SECTION

A = T.MKEN bearing

B = SKF bearing

Figure 4




49302

TIGHTENING TORQUES

PART		TORQUE	
		Nm	kgm
1	Screw fixing differential case to axle housing	1 st phase torque 2 nd phase angle	100 ± 5 10 ± 0.5 80° to 90°
2	Screw fixing differential half boxes	1 st phase torque 2 nd phase angle	100 ± 5 10 ± 0.5 110° to 120°
3	Screw fixing bevel ring gear to half box	1 st phase torque 2 nd phase angle	100 ± 5 10 ± 0.5 80° to 90°
4	Nut locking bevel pinion		1350 to 1670 135 to 167
5	Screw fixing bevel pinion mount	1 st phase torque 2 nd phase angle	100 ± 5 10 ± 0.5 60° to 70°
6	Nut locking sensor		35 to 45 3.5 to 4.5
	Screw fixing caps to differential case		650 to 810 65 to 81
	Oil drain plug		47 4.7

Figure 5



72771

TIGHTENING TORQUES


PART	TORQUE	
	Nm	kgm
1 Screw fixing drum	42 to 67	4.2 to 6.7
2 Screw fixing drive shaft flange	235 to 289	23.5 to 28.9
3 Ring nut for wheel hub bearings	834 to 1030	83.4 to 103
4 Nut for screw fixing brake mount	275 to 304	27.5 to 30.4
● Screw fixing speed sensor mount	5 to 7	0.5 to 0.7

* Spread with sealant type IVECO I905685 (LOCTITE 14780)



● Spread LOCTITE 245 on the thread

A = TIMKEN bearing


B = SKF bearing

TOOLS**TOOL NO.****DESCRIPTION****99305121**


Heater

99322205Rotary stand for overhauling assemblies
(capacity 1000 daN, torque 120 daN/m)**99322215**


Stand for axle overhauling

99322225


Unit holder (to be mounted on stand 99322205)

99341003


Single-acting lift

99341009


Pair of brackets

TOOLS**TOOL NO.****DESCRIPTION****99341015**

Clamp

99341017


Pair of brackets with holes

99345049


Reaction block for puller tools

99345053







Reaction block for puller tools

99348001







Puller tool with clamping device

99355025

Wrench for differential gearcase bearing adjustment ring nuts


TOOLS	
TOOL NO.	DESCRIPTION
99355088	 Wrench (60 mm) for differential bevel pinion nut (to be used with 99370317)
99355180	 Wrench (105 mm) for wheel hub bearing adjustment nut
99363204	 Tool to extract gaskets
99370317	 Reaction lever and extension for flange lock
99370509	 Hook to remove differential gearcase half-housing
99370616	 Support to remove-fit back differential

TOOLS

TOOL NO.	DESCRIPTION	
99370617		Universal support to remove-fit back rear axles
99370700		Guide to assemble wheel hub
99370706		Tool to fit wheel hub bearing
99370708		Tool for removing wheel hub bearing
99371047		Stand to hold differential half-housing when tightening crown wheel screws (to be used with 99322205 - 99322225)
99374244		Installing tool for assembling bevel pinion seal ring

TOOLS**TOOL NO.****DESCRIPTION****99389816**

4 x torque multiplier, with square connection, 3/4" in, 1" out (maximum torque 2745 Nm).

99389819

Torque wrench (0 - 10 Nm) with 1/4" square fitting

525010 OVERHAULING THE REAR AXLE ASSEMBLY

This section covers the overhaul operations that differ from the ones described for the Meritor MS 13-175 rear axle with disc brakes.


The adjustment data, tightening torques and tools are the ones specified in this section.



The following operations can also be performed with the assembly mounted on the vehicle: removing refitting drive shafts – removing refitting drums – removing refitting differential.

Before putting the rear axle assembly on the stand for overhauling, drain off the oil by unscrewing the bottom plug of the differential case.

Figure 6




Put the rear axle (1) on the overhaul stand 99322215 (2).

525030 OVERHAULING THE WHEEL HUBS

Removal


Figure 7



Put a container under the wheel hub to collect the oil. Lock rotation of the wheel hub (2) with the retaining tool 99370317 (3).


Undo the screws fixing the drive shaft (4) with the wrench (1).

Figure 8



Take the drive shaft (1) out of the wheel hub (2).


Figure 9



Using an appropriate tool, straighten the bending on the ring nut (2) preventing it from unscrewing.

Using the wrench 99355180 (1), unscrew the ring nut (2) locking the wheel hub bearing. Take out the retaining ring (3). Undo the screws (4), screw reaction screws into the threaded holes (6) in order to extract the brake drum (5).

Figure 10




Screw tool 99370700 (1) onto the sleeve and extract the wheel hub (2). This operation is carried out by hand, since bearings float on the sleeve.




Tool 99370700 (1) is used to safeguard the sleeve thread.

Figure 11



The phonic wheel (1) is only removed if it has to be replaced. To remove it, use a suitable lever.

Figure 12



Using the suitable tool 99370708 (1) and a vice, extract the bearing (2), along with the related adjustment ring (3).

Wheel hub component check



Carefully clean all wheel hub components. Inspect half-shafts, making sure they are not warped.

Inspect wheel clamping bolts: if the thread is damaged, replace them. To extract the bolts, use a vice.


The bearing rotation must be free and smooth.

Inspect the threads of wheel hub bearing adjustment nuts and axle casing ends; if needed, replace the nuts.

Replace all sealing elements with new ones.

525035 REPLACING THE WHEEL HUB BOLTS

Figure 13



49211

Before replacing wheel hub bolts (3) with new ones, make sure the bolt head supporting surface is free from slags, burrs or nicks.

Insert the new bolts by applying a load on their heads not exceeding 2,500 Kg.


After inserting the bolts, make sure they fit completely.

Wheel hub reassembly

Before replacing the wheel hub cap (2, Figure 13), apply a layer of putty having 40 to 240°C heat resistance to the cap contact surface and hub housing.

To reassemble the phonic wheel (1, Figure 13), pre-heat the wheel to 150°C; when the phonic wheel has been fitted, make sure it is perfectly rested on the hub housing.

Figure 14



72772

Put the bearing (2) on the wheel hub (3) with the seal (4) positioned as shown in the figure.


Fit the bearing (2) using a press and tool 99370706 (1).



The force for driving in the bearing with the press has to be 25,000 to 85,000 N.

Make sure the bearing is properly inserted with the wheel hub shoulder.


Figure 15



49213


Screw tool 99370700 (1) on the sleeve and assemble the wheel hub (2), complete with bearing. Remove tool 99370700 (1) and place the seal ring (3), inserting the tab into the sleeve slot, then screw the ring nut (4).

Figure 16



49214

Using wrench 99355180 (1), multiplier (2) and torque wrench (3), tighten the ring nut (4, Figure 15) to the prescribed torque 834 to 1030 Nm).


Figure 17

49213A

After tightening, using an appropriate tool, notch and bend the ring nut as shown in Figure 17 so it cannot be unscrewed.

The arrow shows the direction of unscrewing the ring nut.

Using a fit tool key the spacer ring (5, Figure 19) and check that a play of 0 ± 0.145 mm between wheel hub outer side and spacer side, making two measures at 180° .

Figure 18

49216

Lock the wheel hub with tool 99370317 (7).


Fit the drum (1) to the wheel hub (6) and fasten it by tightening the screws (2) to the prescribed torque.

Apply sealant IVECO 1905685 (LOCTITE 14780) to both half-shaft flange and wheel hub contact surfaces.

Fit the screws (3) fastening the half-shaft (5) to the wheel hub (6) and tighten them with torque wrench (4) to the prescribed torque.

After these operations, replenish the axle housing with oil up to the right level.

Figure 19




49217A

WHEEL HUB COMPONENTS

1. Screw - 2. Half-shaft - 3. Ring nut - 4. Safety ring - 5. Spacer ring - 6. Bearing - 7. Wheel hub -
8. Wheel hub cap - 9. Brake drum - 10. Axle sleeve

526210 REMOVING AND REASSEMBLING THE DIFFERENTIAL (with axle on stand 99322215)

Figure 20



49218

Removal

Take down the half-shafts as described at page 60, remove the screws fastening the differential housing (1), insert three screws, which are used as pullers, into the threaded holes and remove the differential from the axle casing (2).

Axle casing check

Carefully check axle casing alignment. Warping, it may cause abnormal stress and noise.



To perform the checks on the axle housing it is necessary to remove the wheel hubs.

5250 Rear axle 451391 (R 8284)

	Page
DESCRIPTION	63
SPECIFICATIONS AND DATA	64
TIGHTENING TORQUES	65
TOOLS	67
REAR AXLES ASSEMBLY OVERHAUL	73
☐ Disassembly	73
☐ Epicycloid reduction gear disassembly	73
☐ Wheel hub disassembly	74
CHECKING THE WHEEL HUB AND EPICYCLOID REDUCTION GEAR UNIT PARTS	76
WHEEL HUB ASSEMBLY	77
☐ Assembling the epicycloid reduction gear	79
REMOVING-REFITTING THE DIFFERENTIAL ..	82
REPAIRING THE DIFFERENTIAL	84
☐ Disassembly	84
☐ Gear housing disassembly	85
☐ Removing the bevel pinion support	86
CHECKING THE DIFFERENTIAL PARTS	88
☐ Gear housing assembly	89
☐ Assembling the bevel pinion support	90
☐ Procedure to follow to determine the thickness of the bevel pinion rolling torque adjusting ring	90
☐ Differential housing assembly	92
☐ Gear housing bearings rolling torque adjustment	93

DESCRIPTION

The rear axle is of the double reduction type; the first reduction is provided by the bevel pinion/ring bevel gear, whereas the second reduction is by means of an epicycloid unit on the wheel hubs.

The differential housing (with ring bevel gear) is supported by taper roller bearings, which can be adjusted by means of two threaded ring nuts.

The bevel pinion is supported by two taper roller bearings and a third straight roller bearing.


The bevel pinion can be adjusted by means of adjustment rings located between the two taper roller bearings.

The axle is provided with a pneumatic device for differential locking.

The axle shafts start from the differential and transmit drive to the epicycloid reduction units.

The drum brake is of the Simplex type.

Figure 1



71548

REAR AXLE 451391

SPECIFICATIONS AND DATA








	Type of axle: Load-bearing, double reduction with pneumatically controlled differential locking	451391/2D (R8284)
	Bevel pinion bearings	2 taper rollers and 1 straight roller
	Bevel gear reduction unit ratio	27/32 (1.185) - 29/37 (1.276) - 27/37 (1.370) - 28/37 (1.321) - 24/35 (1.458) - 23/36 (1.565) - 21/34 (1.619) - 19/33 (1.737) - 21/40 (1.905) - 17/35 (2.059)
	Epicycloid reduction unit/wheels ratio	3.2
	Bevel pinion bearing rolling torque without seal Nm	1.5 ÷ 3.5
	Bevel pinion bearing rolling torque adjustment	with adjustment rings
	Thickness of bevel pinion bearing rolling torque adjustment rings mm	10 - 10.02 - 10.04 - 10.06 - 10.08 - 10.10 - 10.12 - 10.14 - 10.16 - 10.18 - 10.20 - 10.22 - 10.24 - 10.26 - 10.28 - 10.30 - 10.32 - 10.34 - 10.36 - 10.38 - 10.40 - 10.42 - 10.44 - 10.46 - 10.48 - 10.50
	Thickness of bevel pinion/ring bevel gear position adjustment rings mm	3.3 - 3.4 - 3.5 - 3.6 - 3.7 - 3.8 - 3.9 - 4.0 - 4.1 - 4.2 - 4.3 - 4.4 - 4.5 - 4.6 - 4.7
	Clearance between pinion and ring bevel gear mm	0.20 ÷ 0.33
	Adjustment of clearance between pinion and ring bevel gear	with ring nuts
	WHEEL HUBS	
	Wheel hub bearings	2 taper rollers
	Wheel hub bearings rolling torque: new bearings with surface protection Nm	6 ÷ 7 + (12 ÷ 16)
	Wheel hub bearings rolling torque: run in bearings and new, lubricated seals Nm	6 ÷ 7 + (5 ÷ 7)
	Wheel hub bearings rolling torque: run in bearings and seals Nm	6 ÷ 7 Nm + (2.5 ÷ 4.5 Nm)
	Drive shaft end float mm	0.5 ÷ 1
	Axle oil	TUTELA WI 40/MDA 16 14.5
	G.R.W. maximum load kg	13.000

Figure 2



39383


TIGHTENING TORQUES

PART	TORQUE	
	Nm	kgm
1 Nut fixing bevel pinion	700 ± 50	70 ± 5
2 Screw fixing bevel pinion support to differential housing	165 ± 15	16.5 ± 1.5
3 Screw fixing differential housing to axle housing	160 ± 10	16 ± 1
4 Screw fixing differential housing to axle housing ♦	160 ± 10	16 ± 1
5 Screw fixing bevel pinion support to differential housing •	280 ± 15	28 ± 1.5
6 Screw fixing ring bevel gear to gear housing	300 ± 10	30 ± 1
7 Screw fixing safety plate to gear housing cover	60 ± 6	6 ± 0.6
8 Pressure switch	61 ± 6	6.1 ± 0.6
9 Cheese headed screw fixing control cylinder	25 ± 2	2.5 ± 0.2
10 Oil filler cap	-	-
11 Self-locking screw	120 ± 10	12 ± 1

• apply LOCTITE AVX

♦ apply LOCTITE 573

Figure 3



84399

TIGHTENING TORQUES







PART	TORQUE	
	Nm	kgm
1 Countersunk screw fixing drum	25 ± 3	2.5 ± 0.3
2 Nut fixing wheel	615 ± 35	61.5 ± 3.5
3 Screw fixing cover to side pinion support □	50 ± 5	5 ± 0.5
4 Countersunk screw	50 ± 5	5 ± 0.5
5 Screw fixing load bearing sleeve	295 ± 30	29.5 ± 3

- apply LOCTITE 510 on the contact surface
- apply LOCTITE 573 on thread
- apply LOCTITE 573 on mating surface
- * apply MOLYKOTE on the nut contact surface
- ◆ Tyres I 4.00R20 GEMELLI/TRILEX







TOOLS

TOOL No.	DESCRIPTION
99305121	Hot air device
99322205	Rotating stand for assembly overhaul
99322215	Stand for axles overhaul
99322225	Support for assemblies (to be fitted onto stand 99322205)
99341003	Single-acting bridge
99341015	Press







TOOLS

TOOL No.	DESCRIPTION
99341020	 Pair of tie rods for grips
99341023	 Grips
99345055	 Reaction block for extractors
99354001	 Wrench for differential gear housing bearing adjustment ring nuts
99354207	 Wrench (94.5 mm) for wheel hub bearings adjusting nut
99355081	 Wrench (60 mm) for differential bevel pinion nut (use with 99370317)







TOOLS

TOOL No.	DESCRIPTION	
99356001		Wrench for adjusting wheel brake jaws
99370005		Grip for interchangeable punches
99370006		Interchangeable grip for punches
99370007		Interchangeable grip for punches
99370317		Reaction lever with extension for flange retaining
99370509		Hook to extract differential gear half-housing


TOOLS

TOOL No.	DESCRIPTION
99370616 	Mounting for removal and refitting of differential
99370617 	Universal mounting to support axles during removal and refitting
99371022 	Pair of differential support brackets for use during overhaul (use with 99322205-99322225)
99372211 	Tool for removal and refitting of brake jaws retaining springs
99374013 	Key to fit flow divider drive infeed shaft seal (use with 99370006)
99374093 	Punch to fit external races of bearings (use with 99370007)

TOOLS

TOOL No.	DESCRIPTION	
99374094		Punch to fit external races of bearings (diameter 134 - 215 mm use with 99370007)
99374161		Key for assembly of wheel hub internal seals
99374451		Tool for axle shaft disassembly-assembly
99389819		Torque wrench from 0 to 10 Nm with 1/4" square connection
99389821		Torque wrench from 0 to 70 Nm with 3/8" square connection
99395026		Tool to check rolling torque of hubs (use with torque wrench)

TOOLS

TOOL No.	DESCRIPTION
99395027	 Tool for differential bevel pinion shim measurement (to be used with 99395603)
99395603	 Dial gauge (0÷5 mm)

525010 REAR AXLES ASSEMBLY OVERHAUL



Disassembly



The drive shafts - brake drums and jaws - air breather - wheel hubs differential and epicycloid reduction units removal-refitting operations, can all be carried out with the units fitted on the vehicle.

Before positioning the axle assembly on the overhaul stand, drain off the oil by unscrewing the lower plug on the axle housing.


Figure 4



39627

Position the axle assembly on stand 99322215.

Figure 5



39628

Block the differential locking device sliding sleeve with a screw. Remove the control cylinder threaded coupling (2) and replace with a screw (1) (M 14 x 1.5). Rotate the axle mechanism to facilitate engagement between the sliding sleeve and the engagement sleeve; this will avoid involuntary sleeve movement whilst the drive shaft is being extracted.




Position a container under the wheel hub to recover the oil.



Before extracting the axle shaft make sure that the screw has been tightened (2, Figure 5).

Epicycloid reduction gear disassembly


Figure 6



71534

Unscrew the screws (1), remove the cover (3) and drain off the oil into the container.


Figure 7



40338

Using an Allen wrench (2) unscrew the two screws (1) fixing the drum; replace with the reaction screws (5). Tighten the reaction screws and remove the drum (4) from the hub and, using a sling (3), raise and remove.


Figure 8



40054

Unscrew the 3 side pinion (3) fixing screws; tighten the reaction screws (1) and, using a sling (2), remove the support (3).


Figure 9



40055

Remove the bevel gear (1) from the mounting.
Remove the shoulder pin (2).


Figure 10



39635

Using suitable pliers, remove the safety ring (2), extract the gear unit (3) from the drive shaft.


Figure 11



39636

Fit tool 99374451 (1) in the shoulder pin seat and extract the drive shaft (2) from the load bearing sleeve.
Remove the spacer ring (3).

Figure 12




40056

Extract the support pins (2) from the side pinion support (1).
Remove the side pinions (3) from the support (1) and recover the rollers and the spacer rings.

Wheel hub disassembly


Figure 13



39637

Using a punch, remove the notch (1) on the adjusting nut.


Figure 14



39638

Using Allen wrench 99354207 (1), unscrew the adjusting nut.


Figure 15



39639

Extract the bevel gear mounting (2), together with the bearing and wheel hub (3), from the load bearing sleeve (1).

Figure 16




39640

Check the surface of the ring (1), on which the hub seal ring rotates, is not damaged or worn, if necessary, replace the ring (1).

Using the extractor [comprising bridge 99341003, grips 99341023, tie rods 99341020, press 99341015 (5) and reaction block 99345055 (4)], extract the ring (replacing if necessary) and/or the internal ring (2) of the sleeve (3) taper bearing.

Figure 17




39641

Check the load bearing sleeve (2). If damaged, replace as follows.

Unscrew the screws (1), remove the brake support plate (3) and the axle casing sleeve (2).


Figure 18



39642

Using a punch inserted through the holes on the bevel gear support, extract the external taper roller bearing (2) from the bevel gear support (1).


Figure 19



39643

Using a universal bronze punch (1), extract the external ring (2) for the internal bearing. The seal ring will also be extracted. Proceed in the same way to extract the external bearing external ring. If necessary, disassemble the phonic wheel.

Figure 20



Check the oil manifold (1) and replace if damaged. Extract with a punch inserted in the slots on the hub (3). Remove the seal ring (2).

39644

CHECKING THE WHEEL HUB AND EPICYCLOID REDUCTION GEAR UNIT PARTS



Carefully clean the wheel hub parts. Check the drive shafts for deformation. If necessary, straighten the drive shafts using a hydraulic press; if this does not provide satisfactory results, replace the drive shafts. Check the studs fixing the wheel: if the threads are damaged or deformed they must be replaced. Work under a press to extract and re-assemble the studs. On completion of assembly operations, check that the orthogonal deviation is no greater than 0.3 mm. Lubricate the bearings and make sure that the roller support cage rotates freely, rotation should be smooth, without hardening.



Check the threads on the hub bearings adjustment nuts and on the load bearing sleeves; replace the nuts if necessary. Check the oil manifold and replace if damaged.


Replace all seals with new parts.

Carefully clean all the epicycloid gear unit parts. Visually check the toothing on the bevel gear support, the bevel gear, the crown wheel gears and the open gear unit.

Check the spacer rings, distance ring, bearing rollers and support pins.

Replace any damaged or worn parts.


Figure 21



40430

WHEEL HUB PARTS

1. Brake drum – 2. Adjusting nut and screw – 3. Cover – 4. Seal – 5. Pin and roller for side pinions – 6. Side pinion support – 7. Adjusting nut – 8. Ring bevel gear support – 9. Side pinion – 10. Shoulder pin – 11. Ring bevel gear – 12. Drive shaft – 13. Breather – 14. Bracket – 15. Shoulder pin – 16. Axle housing – 17. Load bearing sleeve – 18. Brake unit – 19. Phonic wheel – 20. Oil sump – 21. Support ring – 22. Seal ring – 23. Seal ring – 24. Bearing – 25. Wheel hub – 26. Bearing – 27. Stud


525030 WHEEL HUB ASSEMBLY**Figure 22**

If the studs (3) need to be replaced, before fitting new studs, make sure that the contact surface on the head is free of slag, burr, blisters.


After fitting, check that the studs are fully inserted on the hub and that the right angle error does not exceed 0.3 mm.

If the oil collecting sump (2) needs to be replaced, before assembly, smear the contact surface on the hub/sump and hub/hub seat with LOCTITE 573 sealing compound.


Refit the phonic wheel (1) and, on completion, make sure that phonic wheel is positioned perfectly in the hub seat. Using a 1/100ths feeler gauge, check that the right angle error does not exceed 0.2 mm.

Figure 23


Using punch 99374093 (2) and a press, fit the external ring on the external bearing (3), stopping approx. 5 mm from the fully fitted position; complete fitting operations manually, using grip 99370007 (1).

Figure 24

Complete fitting operations manually, using grip 99370007, then turn the hub over and carry out the same operation with the external ring of the internal bearing.


Figure 25

Using a hydraulic press and key 99374161 (1), with the ring (2) positioned as shown in the drawing, fit the brown internal seal ring (3) on the wheel hub (4).

Figure 26

Using a hydraulic press and key 99374161 (1), with the ring (2) positioned as shown in the drawing, fit the blue seal ring (3) on the wheel hub (4).


Figure 27



39648

Position the seal ring on the load bearing sleeve. Fit the load bearing sleeve (3), the brake support plate (4) and dust seal disk. Smear the screws (1) and tighten to the correct value with a torque wrench (1).


Figure 28



40375

Smear LOCTITE 573 on the seat (⇒) of the load bearing sleeve (3) on the seal rings support ring (2). Heat the ring (2) with an electric drier and key on the load bearing sleeve (3). Heat the taper bearing internal ring (1) to 100°C and fit on the load bearing sleeve.


Figure 29



71540

Fit the brake shoes as described in the brake air system section. Lubricate the lip of the seal rings and sleeve. Fit the hub (1) on the load bearing sleeve (2). Lubricate the seal ring (3) and fit on the wheel hub.


Figure 30



40377

Using an electric drier, heat the taper roller bearing (1) to 100°C and fit on the bevel gear support (2) with a punch.


Figure 31



39650

Fit the bevel gear support (3) and the taper roller bearing (2) on the load bearing sleeve (4).


Figure 32



40070

Apply a thin layer of MOLYKOTE on the contact surface of the adjusting nut and tighten with wrench 99354207 (1) until the hub rotates with difficulty. Release the hub with a few blows from a hammer in the direction of the axis and in both directions.

Figure 33



40071

Position tool 99395026 (1) and, using a torque wrench (2), read the wheel hub rolling torque.




Whilst reading the wheel hub rolling torque, hub rotation must not exceed 40 rpm.

Wheel hub rolling torque values vary according to the following conditions:

- ☐ new bearings with surface protection $6 \div 7 + (12 \div 16) \text{ Nm}$
- ☐ run in bearings and new, lubricated seals $6 \div 7 + (5 \div 7) \text{ Nm}$
- ☐ run in bearings and seals $6 \div 7 + (2.5 \div 4.5) \text{ Nm}$


Figure 34



40072

Once the required rolling torque has been achieved, secure the adjusting nut (2) with a punch in the two grooves on the load bearing sleeve (1).

Figure 35




40069

Position the spacer ring (2) on the load bearing sleeve.

Assembling the epicycloid reduction gear

Figure 36




39636

Using tool 99374451 (1) introduce the drive shaft (2) on the load bearing sleeve (3).



The double toothed short half shaft is to be fitted in the bearing shaft on the differential locking side.


Figure 37



39653

Position the gear unit (3) on the grooved section of the drive shaft and the safety ring (1) in the seat. Drive the shoulder pin (2) into the seat on the drive shaft.


Figure 38



39654

Position the bevel gear (1) with the external bevel facing outwards and then fit on the bevel gear support.

Figure 39



26916


Smear the rollers (1) with grease and position, together with the three spacer rings (2) on the side pinion (4), as shown in the drawing.

Position the side pinion (4) and the spacer washer (5) in the side pinion support.

Introduce the support pin (3) from the cover side, pushing it fully into position.

Repeat the same operation for the remaining two side pinion units.

Figure 40




39655

Smear a thin layer of LOCTITE 573, or Reinzoplast, on the contact surfaces of the side pinion support (2) and the wheel hub (1).

Push the side pinion support (2) onto the hub by moving the drive coupling flange in both directions to facilitate tothing engagement. Make sure that the fixing holes on the side pinion support and the hub coincide.

Position the three cheese-headed screws (4) and tighten to a torque of 50 ± 5 Nm with a torque wrench (3).


Figure 41



39656

Fit the brake drum (1) on the side pinion support. Secure the brake drum with the two cheese-headed screws (2) and tighten to a torque of 50 ± 5 Nm with a torque wrench (3).

Figure 42




40073

Smear a thin layer of LOCTITE 510 on the cover (3) and side pinion support (4) contact surfaces.

Position the cover so that the bevels of the support pins coincide with the holes on the cover.

Smear LOCTITE 573 sealing compound on the screw (1) thread and tighten to a torque of 50 ± 5 Nm with a torque wrench (2).


Figure 43



DIFFERENTIAL UNIT PARTS

1. Electric transmitter - 2. Seal and coupling ring - 3. Cover - 4. Seal ring - 5. Piston - 6. Fork - 7. Springs - 8. Bearing - 9. Cover - 10. Plate - 11. Screw - 12. Cover - 13. Washer - 14. Side pinion - 15. Shoulder washer - 16. Half-housing - 17. Bearing - 18. Ring - 19. Ring nut - 20. Oil baffle - 21. Ring bevel gear - 22. Seal ring - 23. Differential unit - 24. Flange - 25. Dust seal - 26. Seal ring - 27. Bearing - 28. Bearing - 29. Pinion support - 30. Bearing - 31. Adjusting ring - 32. Pinion - 33. Bearing - 34. Housing - 35. Screw - 36. Crown wheel - 37. Cross pins - 38. Screw - 39. Ring nut - 40. Sleeve - 41. Sliding sleeve - 42. Screw - 43. Screw - 44. Screw - 45. Bearing - 46. Ring - 47. Nut

Figure 44



26924


The end float on the drive shaft (1) must be between 0.5 and 1 mm. To carry out this adjustment fully tighten the adjusting screw (2), then unscrew by half a turn and secure with the hex nut (3).



The flat face of the hex nut must be positioned towards the seal ring (4).

526210 REMOVING-REFITTING THE DIFFERENTIAL


Figure 45



39658

Remove the screws (1) fixing the differential housing to the axle housing.


Figure 46



71534

Position a container under the wheel hub (1); unscrew the screws (2), remove the cover (3) and drain off the oil.


Figure 47



39659

Fit tool 99374451 (1) in the shoulder pin seat thread, then extract the drive shaft (2) from the load bearing sleeve.


Figure 48



39660

Using eyebolts, raise the pinion support (1) with a sling and unscrew the four screws (2) fixing the differential housing.


Figure 49



39661


Using eyebolts (1) and a sling, raise the differential housing (2).

Figure 50




Fit the sliding sleeve (1) on the drive shaft (2) with double tooting.

Figure 51




Smear LOCTITE 573 (1) sealing compound on the contact surface. When assembling the differential housing, make sure that the differential lock engagement fork is correctly introduced on the sliding sleeve.

Figure 52



Position the seal ring and assemble the differential housing (1). Apply LOCTITE 573 on the threads of the external screws (2). Using a torque wrench, tighten the external (2) and internal (3) screws to the correct torque.

Figure 53




Smear LOCTITE 573 (1) sealing compound on the contact surface.



Apply a bead of LOCTITE 510 around the oil passage holes.

Figure 54




Position the bevel pinion support (1) on the differential housing (2). Using a torque wrench, tighten the screws (3) to the correct torque.



Apply LOCTITE 573 on the threads of the screws (3) that pass through the holes.

Figure 55




Smear a thin layer of LOCTITE 510 on the cover (3) and crown wheel support (4) contact surfaces. Position the cover so that the bevels of the support pins coincide with the holes on the cover. Smear LOCTITE 573 sealing compound on the screw (1) thread and tighten to the correct torque with a torque wrench (2).

REPAIRING THE DIFFERENTIAL

Disassembly


Figure 56



39667

Position the differential housing with the gear housing cover (1) facing upwards, on rotating stand 99322205 (2), together with support 99322225 and pair of brackets 99371022 (3). Provisionally fit the bevel pinion support (4).


Figure 57



39668

Unscrew the screws (1) and remove the safety plate (2). Repeat the same operation on the opposite side.


Figure 58



39669

Heat the points indicated by the arrows with drier 99305121 and unscrew the screws (2) fixing the cover (secured with LOCTITE).


Figure 59



39670

Raise the gear housing cover (1).


Figure 60



39671

Using hook 99370509 (1), raise the gear housing (2), together with the taper roller bearings and bearing external rings.


Figure 61



39672

Rotate the differential housing through 90°. Remove the safety notch on the fixing nut. Apply reaction lever 993701317 (2) to the drive coupling flange and, using Allen wrench 99355081 (1), loosen the fixing nut.


Figure 62



39673

Unscrew the screws and washers of the differential housing (3) bevel pinion support (1). Fit the reaction screws (2) and extract the differential housing support.


Figure 63



39674

Using a universal punch, extract the bevel pinion taper roller bearing (1) from the seat on the differential housing.


Figure 64



39675

Unscrew the 2 sunken hex screws (1) and remove the differential locking device control cylinder (2).

Figure 65




39676

Extract the piston (2), together with the seal ring (3), the engaging fork (1) and the compression spring (4).

Gear housing disassembly


Figure 66



39677

Remove the circlip (1) and extract the differential lock engaging sleeve (3) from the gear housing cover (2).


Figure 67



40086

Using extractor 99348001 (1-2) and reaction block 99345055 (3), extract the taper roller bearing from the gear housing. Repeat the same operation on the opposite side.


Figure 68



39679

Loosen and extract the screws (1) fixing the ring bevel gear (3) and cover (2) to the half-housing (4).


Figure 69



39680

Counter-mark the cover and gear housing ($\Rightarrow \Leftarrow$). Remove the gear housing cover (1) and release the ring bevel gear (2).


Figure 70



39681

Remove the crown wheel (2), together with the shoulder washer (3), from the gear housing (1).

Figure 71



39682

Using a punch, first extract the long pin (4) and then the two short pins (3).




The exact position of the pins is marked on the spider body (2) by a long stripe for the long pin, and by two short stripes for the short pins.

Remove the spider (2) and the four side pinions (1) with the relative shoulder washers.

Remove the crown wheel and the shoulder washer.

Removing the bevel pinion from the support


Figure 72



39683


Remove the fixing nut and the drive coupling flange (1). If flange extraction proves difficult, use a universal extractor.

Figure 73




Remove the bevel pinion (1), intermediate bearing and adjusting rings from the support. This operation should be carried out under a press; if not, use an extractor (2).

Figure 74




Remove the bearing adjustment ring (2) from the bevel pinion (1).

Figure 75




Using universal extractor 99348001 (1), extract the intermediate taper roller bearing (3) from the bevel pinion (2).

Figure 76




Extract the pinion position adjusting ring (2) from the bevel pinion (1).

Figure 77



Extract the rear straight roller bearing internal ring (2) from the bevel pinion (1). This is a destructive operation.

Figure 78



Using a punch, extract the external rings (3 and 2) for the front and intermediate bearings from the support (1).

CHECKING THE DIFFERENTIAL COMPONENTS

Carefully clean all of the individual differential components. Lubricate the bearings and make sure that the roller support cage rotates freely, rotation should be smooth, without hardening.



Carefully clean all the threads to ensure exact adjustments and precise tightening torque values.


Check that the grooved section on the pinion flange is not excessively worn. Replace the pinion if necessary.



If either the bevel gear or pinion need to be changed, both parts must be replaced as they are provided as coupled spare parts.


Gear housing assembly

Figure 79




Secure the gear housing (1) in a vice and position the crown wheel (2) in its seat, together with the shoulder washer (3).

Figure 80



Assemble the four side pinions (I) with the shoulder washers and insert the spider (2).

Figure 81




Insert the long pin (I) and the two short pins.




First insert the long (through) pin. The exact position of the pins is marked on the spider body by a long stripe for the long pin, and by two short stripes for the short pins.

Figure 82




Position the crown wheel (2) and shoulder washer (3) on the side pinion gear unit. Fit the cover (I) on the gear housing by making the marks (made during disassembly operations) coincide.

Figure 83




Heat the ring bevel gear (2) to approx. 80°C, fit in position in the gear housing (1) and secure with two fixing screws.

Figure 84



Fit the remaining screws (2) and tighten with a torque wrench (I) to 300 ± 10 Nm (30 ± 1).

Figure 85




39696

Using an electric heater, heat the support bearing (2) for 15' at a temperature of 100°C and fit on the gear housing cover using a punch (1). Repeat the same operation on the other bearing.

Assembling the bevel pinion support

Figure 86




39697

Fit a new oil baffle on the pinion support (1) Using punch 99374093 (2), fit the intermediate bearing external ring and the front bearing external ring in the support in their respective seats.

Procedure to follow to determine the thickness of the bevel pinion rolling torque adjusting ring


Figure 87



39572

Using a feeler gauge (1) measure and note the thickness of the adjusting ring on disassembly (value A).

Figure 88



39698

Secure tool 99395027 (6) in a vice and fit the following parts:

- ☐ the bearing (5) on the pinion-side;
- ☐ the previously measured adjusting ring (4) and the bearing (3).


Fully tighten the ring nut (2).

Position part (1) of tool 99395027 (6) on the bearing (3), fitted with a zero-set dial gauge on the end of the tool (6).

Then remove:

- ☐ the part (1),
- ☐ the ring nut (2),
- ☐ the bearing (3),
- ☐ the adjusting ring (4) on the tool (6).


Figure 89



39699

Position the support (4) on the bearing (5, Figure 88) and the bearing (3) on the support. Tighten the ring nut (2) by hand and check the rolling torque, as indicated in Figure 90.

Figure 90



39700

Position the complete support on two parallel blocks; using the torque wrench (1) applied on tool 99395027 and read the rolling torque. This value should be 1.5 to 3.5 Nm; if not, adjust by means of the ring nut (2, Figure 87).

Position the part (1, Figure 79), with the dial gauge zero-set, on the bearing (3) and read the eventual deviation (value B).

Thickness **S** on the adjusting ring is provided by the following formula:

Where:

A = thickness of the adjusting ring assembled for dial gauge zero-setting;

B = deviation value read;

C = 0.05 mm coefficient which takes into account the expansion of the bearings as a result of the assembly negative allowance on the bevel pinion.

First example:

A = 10.12 mm

B = + 0.13 mm

C = 0.05 mm

$$S = 10.12 - (+ 0.13) + 0.05 =$$

$$S = 10.12 - 0.13 + 0.05 = 10.04 \text{ mm.}$$

Second example:

A = 10.12 mm

B = - 0.13 mm


C = 0.05 mm

$$S = 10.12 - (- 0.13) + 0.05 =$$

$$S = 10.12 + 0.13 + 0.05 = 10.35 \text{ mm.}$$

On completion of the operation, remove the parts of tool 99395027.

Figure 91



39701

Fit the adjusting ring (2), in order to position the pinion in relation to the bevel gear, on the bevel pinion (1). The thickness of the adjusting ring is determined by the reference value (3) marked on the bevel pinion.


See the table in Figure 92.

Figure 92

Value marked on the bevel pinion	Total thickness of adjusting ring
0	4.6
0.1	4.5
0.2	4.4
0.3	4.3
0.4	4.2
0.5	4.1
0.6	4.0
0.7	3.9
0.8	3.8
0.9	3.7
1.0	3.6

Summary table to determine the thickness of the bevel pinion position adjusting ring.


Figure 93



39702


Heat with an electric drier to 100°C and insert the rear straight rollers bearing internal ring (1) on the bevel pinion (2).

Figure 94




Heat the intermediate bearing (1) for approx. 15' at a temperature of 100°C and fit on the bevel pinion (2); fit the adjusting ring (3) with the same thickness as previously noted (page 29-30).

Figure 95



Fit the previously assembled support (1) on the bevel pinion (2), fitting the front bearing. Using key 99374013 (3) and grip 99370006, insert the oil seal ring (4).


Figure 96



Assemble the drive coupling flange (1) with a punch and tighten the fixing nut by hand.


Differential housing assembly

Figure 97




Using a punch, fit the rear straight rollers bearing (1) in position on the differential housing.

Figure 98




Provisionally assemble the bevel pinion support (2) on the differential housing (3), insert 2 screws (4) and washers in diametrically opposing positions. Using a torque wrench (1), tighten to a torque of 160 ± 10 Nm (16 ± 1 kgm).

Figure 99



Block the drive coupling flange rotation using reaction lever 99370317 (1) and, using Allen wrench 99355081 (2), the multiplier (3) and a torque wrench (4) tighten the fixing nut to a torque value of 700 ± 50 Nm (70 ± 5 kgm).


Figure 100



39671

Using hook 99370509 (1), position the gear housing (2) together with the roller bearings on the differential housing.

Figure 101



39709


Correctly fit the cover (3) making the marks (made during disassembly operations) coincide. Provisionally tighten the screws (2) and check that the adjusting ring nuts (4) screw-in easily.

Remove the screws (2), smear the threads with LOCTITE AVX and then re-tighten with a torque wrench (1) to a torque of 280 ± 15 Nm.

Gear housing bearings rolling torque adjustment

The rolling torque reading is carried out when there is a clearance between the teeth on the bevel gear pair. However, the total rolling torque value varies according to the reduction bevel gear pair ratio (see table in Figure 103).

Figure 102



39712


Using torque wrench 99389819 (1) and the appropriate Allen wrench, check that the total rolling torque value corresponds with the value indicated in Figure 103.

Figure 103

No. of teeth	Ratio	Total rolling torque (Nm)
17/35	2.059	$a + (1.5 - 2.4)$
19/33	1.737	$a + (1.6 - 2.6)$
21/34	1.619	$a + (1.9 - 3.1)$
23/36	1.565	$a + (1.9 - 3.2)$
24/35	1.458	$a + (2.1 - 3.4)$
28/37	1.321	$a + (2.3 - 3.8)$
27/32	1.185	$a + (2.5 - 4.2)$
21/40	1.905	$a + (1.6 - 2.6)$
27/37	1.370	$a + (2.2 - 3.6)$
29/37	1.276	$a + (2.4 - 3.9)$

$$a = 7.5 \div 9.5 \text{ Nm}$$

Figure 104



39711


If the torque value is different from that indicated in Figure 104, adjust the adjustment ring nuts (2) with wrench 99354001 (1) until the required torque is obtained.

Adjust the end float between the teeth on the bevel gear pair as follows:

- ☐ Read the clearance value between the teeth in Figure 105.


Figure 105

No. of teeth	Ratio	Clearance between teeth
17/35	2.059	$0.2 \div 0.33$
19/33	1.737	$0.2 \div 0.33$
21/34	1.619	$0.2 \div 0.33$
23/36	1.565	$0.2 \div 0.33$
24/35	1.458	$0.2 \div 0.33$
28/37	1.321	$0.2 \div 0.33$
27/32	1.185	$0.2 \div 0.33$
21/40	1.905	$0.2 \div 0.33$
27/37	1.370	$0.2 \div 0.33$
29/37	1.276	$0.2 \div 0.33$

Figure 106


- ☐ Position a magnetic dial gauge (I) as shown in the drawing.
- ☐ Prevent the bevel pinion from rotating with reaction lever 99370317, reverse the direction of rotation of the bevel gear and, using a gauge (I), read the clearance between the teeth on the two gear units.

If not, using the wrench 99354001 (I, Figure 107), adjust the adjusting ring nut.

Figure 107

In order to prevent the previously measured rolling torque from varying, during adjustments of the coupling clearance between the pinion and the bevel gear teeth, tighten the ring nut with the wrench 99354001 (I) by the same amount as the ring nut on the opposite is loosened.

On completion of operations, check that the two adjusting ring nuts are suitably positioned to allow the safety plate to be fitted.


Figure 108

Using a brush, apply a light covering of Prussian blue on the teeth of the bevel gear.

Rotate the pinion and check the coloured contact marks that the pinion teeth have made on the bevel gear teeth.


The following drawings illustrate possible contact marks and the operations required in order to correct the faults.

Figure I 09




The contact marks should be on both the leading face (1) and the pushing face (2), more or less in the centre between the teeth. When working without a load, both contact zones should be slightly out of position in relation to the external diameter of the bevel gear.

Figure I 10




If the mark on the leading face (towards the external diameter) and on the pushing face (towards the internal diameter) is out of position, the pinion is located too close to the bevel gear.
- Solution: decrease the thickness of the adjusting ring (2, Figure 91) between the intermediate bearing and the bevel pinion.

Figure I 11




If the mark on the leading face is positioned towards the internal diameter, and on the pushing face it is located towards the external diameter of the bevel gear, the pinion is located too far away from the bevel gear axis.
- Solution: increase the thickness of the adjusting ring (2, Figure 91) between the intermediate bearing and the bevel pinion.

Figure I 12




Assemble the engaging sleeve (1) on the gear housing toothing and, with a screwdriver, position the circlip (2) in the groove.

Figure I 13




Fit the differential lock engagement assembly comprising: the control cylinder, the piston (2), the engaging fork (1) and the compression spring (3).

Figure I 14



Introduce the compression spring (1) in the differential housing. Fit the engaging fork (2) so that fork (a) travel limit corresponds with travel limit (b) on the differential housing.

Figure 115



Fit a new seal ring (1) on the control piston (2) and smear with grease.

Introduce the control piston (2) on the engaging fork (3) in the compression spring, then fit the assembly in the gap on the differential housing.

Disassemble the bevel pinion support.

Fitting the differential on the axle housing.

1. Fit the sliding sleeve on the drive shaft.
2. Fit the gear housing assembly, taking care that the fork engages in the groove on the sliding sleeve.
3. Tighten the screw whilst pushing the drive shaft so that the sliding sleeve engages on the differential engaging sleeve.
4. Apply LOCTITE 573 on the threads and under the heads of the screws and tighten to the correct torque with a torque wrench.
5. Apply LOCTITE 573 on the contact surface, refit the pinion support and tighten the screws to the correct torque.

**Axles in Tandem
MERITOR RT 160 E/I**

Page

AXLE IN TANDEM MERITOR RT 160 E/I:

☐ INTERMEDIATE MERITOR RP 160 E	99
☐ REAR MERITOR RR 167 E	147

Axles in Tandem (Intermediate) Meritor RP 160 E (R 2478)

	Page
DESCRIPTION	101
SPECIFICATIONS AND DATA	101
TIGHTENING TORQUES	103
TOOLS	107
EXPERIMENTAL TOOLS	114
SERVICING INTERMEDIATE AXLE ASSEMBLY RP 160 E (R 2478)	117
AIR BREATHER REMOVAL-REFITTING	117
SERVICING WHEEL HUBS	117
☐ Checking wheel hub components	118
ASSEMBLING WHEEL HUBS	119
REMOVING DIFFERENTIAL GEAR – TRANSFER BOX (with rear axle on stand 99322215)	122
REFITTING DIFFERENTIAL GEAR – TRANSFER BOX (with rear axle on stand 99322215)	122
REPAIRING INTER-AXLE UNIT	123
☐ Dismantling inter-axle unit	123
☐ Checking inter-axle unit components	125
☐ Fitting inter-axle unit	125
☐ Adjusting differential lock and inter-axle control pin end-stop	127
☐ Adjusting drive input shaft bearing end float ..	128
REPAIRING MAIN DIFFERENTIAL – DISMANTLING DIFFERENTIAL CASING ...	128
☐ Dismantling gear cage	132
☐ Checking differential components	132
☐ Assembling gear cage	133

Page

ASSEMBLING DIFFERENTIAL CASING 134

☐ Calculating bevel pinion position
in differential casing 134

COMPUTATIONAL EXAMPLES 135

☐ Determining the thickness of the bevel pinion
bearing clearance adjustment rings 135

☐ Adjusting the cap gap 138

CORRECTING THE CROWN WHEEL
AND PINION CONTACTS (AFTER ASSEMBLY) 140

REMOVING-SERVICING-REFITTING
INTER-AXLE OUTPUT SHAFT 143

DESCRIPTION

The intermediate axle is of the full-floating, single-reduction type and consists of a steel case housing the inter-axle differential and the main differential.

Drive is transmitted from the inter-axle differential to the main differential by means of two helical gears. The inter-axle differential consists of a drive input shaft on which the following components are splined: front bearing cage, oil pump, drive gear with forward planetary gear and the differential gear assembly.

The rear planetary gear is housed in the axle housing and is splined on the drive output shaft.

A sliding sleeve for differential lock is fitted to the rear planetary gear; it is controlled by an air mechanism through a fork.

The adjustment of the end float of the tapered roller bearings is made using shims between the front mount and the gearing mount: the primary differential gear is composed of a pair of bevel reduction gears with helical toothing (pinion-ring gear) and a gear housing (planetary gears).

The driven gear is splined on the pinion and is mounted on two taper roller bearings.

Adjustment of the bevel drive set is by shims located between the two taper roller bearings.





In addition, the position of the bevel pinion can be adjusted in relation to the ring bevel gear by varying the thickness of the pack of rings between the underhead tapered bearing and the bevel pinion mount.













The gear cage supported on two taper roller bearings and is adjusted for end play by means of two adjusting nuts.

The rear axle is fitted with an air-controlled differential lock device.

Wheel hubs are mounted on two taper roller bearings floating on the sleeve and adjusted by means of a threaded nut.


SPECIFICATIONS AND DATA

	Axle type: Full-floating, single reduction with air-controlled differential lock device	RP 160 E (R 2478)	
DIFFERENTIAL			
	Final bevel gear ratio (number of teeth: pinion/crown wheel) Standard on models:	3.07 (14/43) 3.21 (14/45) 3.42 (12/41) 3.73 (11/41) 3.91 (11/43) 4.30 (10/43)	
	Bevel drive pinion bearings	2 taper roller	
	Bevel drive pinion bearing rolling torque		
	New bearings	Nm	1.00 ÷ 5.00
		kgm	0.10 ÷ 0.50
	Used bearings	Nm	1.68 ÷ 3.39
		kgm	0.160 ÷ 0.339
	Bearing drive pinion preloading adjustment	By shims	
	Shim thickness range or bevel pinion bearing preloading adjustment	11.45 - 11.48 - 11.50 - 11.53 11.55 - 11.65 - 11.75 - 11.85	
	Bevel drive pinion to crown wheel end play	mm	0.26 ÷ 0.50

	Bevel pinion to crown wheel end play adjustment	By ring nuts
	Cap divergency	0.05 ÷ 0.23
	Differential carrier bearing rolling torque Nm kgm	1.7 ÷ 3.9 0.17 ÷ 0.39
	Cap divergency adjustment	By ring nuts
	Rolling torque between planetary gear and differential gears Nm kgm	Max. 6.8 Max. 6.8
	Bevel drive pinion setting as to differential carrier	By shims
	Thickness range for shims located between intermediate bearing ring and differential carrier	0.076 - 0.127 - 0.254
INTER-AXLE DIFFERENTIAL UNIT		
	Inter-axle differential bearings	2, taper roller
	Inter-axle differential bearing end play mm	0.05 ÷ 0.20
	End play adjustment	By shims
	Inter-axle differential bearing shim thickness range mm	0.076 - 0.127 - 0.254
	WHEEL HUBS	
	Wheel hub bearings	2, taper roller
	Wheel hub bearing end play mm	0.00 ÷ 0.05
	Wheel hub bearing rolling torque Nm kgm	Max. 2.45 Max. 0.25
	Wheel hub bearing end play adjustment	by ring nut
	Rear axle oil Quantity: air suspension litres (kg) Cantilever suspension litres (kg)	TUTELA WI 40/M-DA 20 (18) 22 (20)

TIGHTENING TORQUES


Figure 1



84394


PART	TORQUE	
	Nm	(kgm)
1 Screw fixing input shaft mount M12x1.75	100 ÷ 145	(10.1 ÷ 14.7)
2 Nut fixing flange to input shaft M45x1.5	815 ÷ 1085	(83 ÷ 110.6)
3 Nut fixing parts on bevel pinion M 50x2	1220 ÷ 2035	(124.3 ÷ 207.4)
4 Screw fixing bevel pinion cover M 10 x 1.5	40 ÷ 70	(4 ÷ 7.1)
5 Screw fixing mesh filter M 26x1.5	65 min.	(6.6 min)
6 Screw fixing oil pump to mounting	30 ÷ 45	(3 ÷ 4.5)
7 Screw fixing caps: to differential gear housing M 22x2.5	650 ÷ 810	(66.2 ÷ 82.5)
8 Nut fixing output shaft M39x1.5	610 ÷ 880	(62.1 ÷ 89.7)
9 Screw fixing output shaft bearing mount	47 ÷ 68	(4.7 ÷ 6.9)
10 Transfer box differential locking cylinder M 60x2	109 ÷ 136	(11.1 ÷ 13.8)
11 Fastening screw for planetary gear half-case	60 ÷ 75	(6.1 ÷ 7.6)

Figure 2



PART	TORQUE	
	Nm	(kgm)
10 Nut locking transmitter M 16x2	35 ÷ 75	(3.5 ÷ 7.6)
11 Differential locking cylinder M 60x2	109 ÷ 136	(11.1 ÷ 13.8)
12 Screw fixing half boxes M 16x2	300 ÷ 420	(30.5 ÷ 42.8)
13 Self-locking nut fixing bevel ring gear to the half box M 16x1.5	265 ÷ 355	(27 ÷ 36.1)
14 Oil filter coupling M 22x2.5	55 ÷ 80	(5.6 ÷ 8.1)

Figure 3




77212

SECTION ON THE REAR AXLE WHEEL HUB IN TANDEM RT 160E/1

PART	TORQUE	
	Nm	(kgm)
1 Screw fixing drive shaft to wheel hub M14 x 1.5	207.9 ÷ 256.9	(21.2 ÷ 26.2)
2 Nut fixing wheels	600 ⁺⁵⁰ ₋₂₀	(60 ⁺⁵ ₋₂)
3 Nut for screw securing brake mounting	275.5 ÷ 304	(28 ÷ 31)
4 Ring nut locking wheel hub adjustment nut	392.3	(40 ÷ 2)



Figure 4



77473







SECTION ON THE REAR AXLE WHEEL HUB IN TANDEM RT 160E/I


SECT. C-C




77211

VARIANT WITH ANTI-SKID DEVICE


TOOLS		
TOOL NO.	DESCRIPTION	
99305121		Heater
99322205		Rotary stand for unit overhauling (capacity 1000 daN, torque 120 (daN/m)
99322215		Axle overhaul stand
99322225		Unit holder (to be mounted on stand 99322205)
99341003		Single-acting lift
99341012		Pair of brackets

TOOLS**TOOL NO.****DESCRIPTION****99341015**


Clamp

99341016


Pair of brackets with holes

99345029


Threaded block (use with 99345098)

99345055






Reaction block for puller tools

99345098




Installation tool for assembly of bearing and cylindrical gear on the differential bevel pinion shaft (use with 99345029)







99345103

Wheel hub fitting tool






TOOLS	
TOOL NO.	DESCRIPTION
99348001	 Puller tool with clamping device
99355025	 Wrench for differential gearcase bearing adjustment ring nuts
99355069	 Wrench (75 mm) for differential bevel pinion nut (to be used with 99370317)
99355088	 Wrench (60 mm) for differential bevel pinion nut (to be used with 99370317)
99355131	 Wrench (55 mm) for the nut of the drive input flange of the transfer box (use with 99370317)
99355167	 Wrench (114 mm) for wheel hub bearing adjustment nut

TOOLS

TOOL NO.	DESCRIPTION	
99360311		Oil filter wrench
99370005		Hand-grip for interchangeable drift punches
99370007		Hand-grip for interchangeable drift punches
99370317		Reaction lever and extension for flange lock
99370509		Hook to remove differential gearcase half-housing
99370616		Support to remove-fit back differential

TOOLS	
TOOL NO.	DESCRIPTION
99370617	 Universal support to remove-fit back rear axles
99371047	 Stand to hold differential half-housing when tightening crown wheel screws (to be used with 99322205 - 99322225)
99374093	 Drift punch for installation of bearing outer races (91 ÷ 134) (use with 99370007)
99374094	 Drift punch for installation of bearing outer races (134 ÷ 215) (use with 99370007)
99374134	 Installer, wheel hub inner seal
99374162	 Installer, transfer case input shaft seal

TOOLS

TOOL NO.	DESCRIPTION
99374163	 Installer, transfer case output shaft seal
99381125	 Pliers for removal of circlips on transfer box shaft
99389816	 4 x torque multiplier, with square connection, 3/4" in, 1" out (maximum torque 2745 Nm)
99389819	 Torque wrench (0 - 10 Nm) with 1/4" square fitting
99395026	 Tool for measuring hub rolling drag torque (use with torque wrench)
99395027	 Tool for determining thickness of differential bevel pinion adjustment shims (use with 99395693)

TOOLS

TOOL NO.


DESCRIPTION

99395603

Dial gauge (0÷5 mm)

EXPERIMENTAL TOOLS

This heading covers the technical working drawings of the experimental tools (S.P.), used when overhauling the rear axle described in this section, that can be made in your repair shop.






6 / Sm. 0.5x45°

*Stampigliare : **IVICO 99xxxxx**
Cod. Fornitore : **C.F.**
(Marchio **IVICO** 1-5 P IVECO STD.10-0804)

Modification:—

For the permissible errors on the dimensions without tolerance and for other general specifications, see **TABLE** STD 10-2311

general specifications, see ISO 10-2317 MAT.	Rame COVER: 1	Attrezzo ritegno corona	DRAWN UTS (B)	N'DRAWING
			APPROVED	EXPER. 2373 SIZE A3
			DATE 13/05/2002	SHEET
			SUPERSEDES	
All proprietary rights reserved by IVECO This drawing shall not be reproduced or in any way utilized, for the manufacture of the component or unit herein illustrated and must not be released to other parties, without written consent. Any infringement will be legally pursued.	ISO 30° R 0.4	1:5. 10-0011 h	SCALE 1:1	IVECO
	+		Q.TY 1	
	SUPERSEDES			
				



6 / Sm. 0.5x45°

*Stampigliare : **IVECO** 99999999 25
Cod. Fornitore : **C.F.** 25
(Marchio **IVECO** 1-5 P IVECO STD.10-0804)

For the permissible errors on the dimensions without tolerance and for other general specifications, see **FIGURE** STD 10-2311

MAT. Vedi dis. COVER. Fosfat. Estrattore	ISO 9001	15.10.2011	SCALE 1:2 Q.TY 1	DRAWN UTS (B) APPROVED DATE 18/03/2002 SUPERSEDES	N'DRAWING
	ISO 9001	15.10.2011			
	ISO 9001	15.10.2011			
	ISO 9001	15.10.2011			
	ISO 9001	15.10.2011			

525010 SERVICING INTERMEDIATE AXLE ASSEMBLY RP 160 E (R 2478)




Removal/installation operations concerning the following units: axle shafts, brake shoes and drums, air breather, differential can be performed with the unit on the vehicle.

Before placing the axle assembly on the stand, loosen the bottom plug and drain the oil.

525013 AIR BREATHER REMOVAL-REFITTING

Figure 5



77221


Set the rear axle assembly on the stand 99322215, Check that the air breather (1) is not clogged; if it is, remove it, clean it carefully and fit it back on.



The identification data of the rear axle assembly RP 160E (R 2478) are given on the plate (2).

525030 SERVICING WHEEL HUBS


Figure 6



77222

Lock the differential gear, operating as follows: unscrew the screw (7) and screw it down in the hole (8): screw down the screw fully to get the differential lock to go in.

Figure 7




19341



Place a container under the wheel hub to recover the oil.

Unscrew the screws (3) fixing the drive shaft (2) and extract it from the hub (1).


Figure 8



19349


Remove the screws fixing the drum (1) to the wheel hub (2) and screw them down in the holes (→) to extract the drum (1).

Figure 9



Using the wrench 99355167 (1) unscrew the lock nut (2) locking the bearing adjustment nut (4). Extract the retaining ring nut (3), unscrew the bearing adjustment nut (4) and take out the bearing (5).

Figure 10




Disassemble the wheel hub (1). In case of difficulty, use the puller comprised of: arms 99341016 (2), yoke 99341003 (3) and block 99345055 (4), applied as shown in the figure.




When putting aside the wheel hub, take care not to damage the phonic wheel (1, Figure 11).

Figure 11



Only dismantle the phonic wheel (1) if it is to be replaced. Do so using a suitable lever.

Figure 12



If the phonic wheel (1, Figure 11) is not to be dismantled, do not use it as a support.

Use a general purpose bronze drift (1) to remove inner bearing cup (2).

Sealing ring (3) will also be expelled.

Proceed in the same way to remove the outer bearing cup.

Checking wheel hub components



Clean every single hub component thoroughly. Examine axle drive shafts and make sure they are free from any distortion.



Check wheel mounting bolts: if their threads are distorted or damaged replace without hesitation on a power press.

Lubricate bearings and rock roller cages; rotation must be smooth without any sign of binding.


Check condition of wheel bearing adjuster nut and axle sleeve end threads: if necessary, change the nuts.

Check the oil slinger: if damaged, replace.

Discard old seals and fit new ones.

525030 ASSEMBLING WHEEL HUBS

Figure 13



36298


Ensure the rest surface of screw heads is free from burrs, slags or nicks before fitting new screws (3).

The load to be applied to screw heads for driving them into their seats must not exceed 2300 Kg.

When driving operation is completed, screws should abut perfectly on the wheel hub face : maximum squareness tolerance 0,2 mm.

If the oil slinger (2) was removed in order to be replaced, coat oil slinger and hub mating face with sealing compound that can resist heat to temperatures of 40 to 250°C.

Figure 14



36299


Fit taper roller bearing outer races in wheel hub using handle 99370007 (1) and drift (2): 99374094 for outer bearing race (3) and 99374094 for inner bearing race.



When fitting race (3) do not use phonic wheel (1) as a support base.

Press fit until bearings are 5 mm from abutting end and then complete operation by hand.

Figure 15



40326

Refit phonic wheel (2), if necessary, by heating to a temperature of 150°C. Ensure phonic wheel is perfectly bedded onto hub seat after installation.

Check squareness of phonic wheel (2) as follows.

Position wheel hub (4) with taper roller bearings on base of column drill. Interpose a spacer between base and outer bearing race (5) so that wheel hub may turn.

Rest a plate (7) on the internal bearing roller ring (3).


Turn handle (8) to raise base so that drill chuck comes into contact with plate (7) and bearings (3 and 5) are slightly pre-loaded.



Turn wheel hub to settle bearings when pre-loading.

Position magnetic base dial gauge with flat base stylus as shown in figure and turn wheel hub. Check that maximum squareness error for phonic wheel (2) does not exceed 0,2 mm.


Figure 16



62665

Place the tapered roller bearing (1) in the outer ring (2). Using the keying device 99374134 (3) fit the gasket (under a press) in the wheel hub.

Figure 17




77225

Lubricate the bearing seat on the sleeve and the wheel hub seal (1) with TUTELA W 140/M-DA oil.

Position the tapered roller bearing in the wheel hub (1) and, using the tool 99345103 (2) applied as in the figure, fit the wheel hub (1) onto the sleeve.

Figure 18



36304

Tighten nut (1). Then adjust wheel hub bearing end play as follows.


Use wrench 99355167 (2) to tighten nut (1) to a torque of 98.1 Nm (10 Kgm).



Tighten nut by turning hub simultaneously in both directions to settle bearings.

Loosen nut (1) to obtain an end play of $0.2 \div 0.3$ mm.

Figure 19




19366

Fit the lock ring (2).

If the nut (1) for the locating dowel does not match any of the lock ring holes (2) (see →), progressively undo the adjusting nut (1) until the lock ring can be inserted. (Consider also the end play specification obtained with the previous operation).


Figure 20



36305


Tighten nut (1) and torque it to 392.3 Nm (40 ± 2 Kgm) using wrench 99355167 (2).

Figure 21



Place a magnetic base dial gauge (1) on wheel hub (3); rest gauge stylus on sleeve (2) and check wheel hub end play. It should not be over $0.00 \div 0.05$ mm.

Figure 22




36307

Apply tool 99395026 (1) to the wheel hub pins and, using a torque wrench, check that the rolling torque is no greater than: 2.45 Nm (0.25 kgm).

This torque must correspond to a maximum end float of the bearings of 0.05 mm.

Figure 23



36309

Fit the drum (1) onto the wheel hub (2).

Smear "Type B" sealing compound on both contact surfaces between the drive shaft and the wheel hub.


Insert the drive shaft (4), screw down the screws (3) fixing the drive shaft (4) to the hub (2) and tighten them, using a torque wrench, to the prescribed torque.

Repeat this operation on the opposite side.

After these operations, replenish the axle housing with TUTELA W 140/M-DA oil of the prescribed quantity and proceed to check the transmitter for signalling differential locking works properly.

Check the efficiency of the ABS sensors as described in the "Fault-Diagnosis Guide" manual.

Figure 24




77226

COMPONENTS OF WHEEL HUB

1. Screw - 2. Drive shaft - 3. Nut - 4. Safety ring - 5. Nut - 6. External tapered roller bearing - 7. Wheel hub - 8. Internal roller bearing - 9. Seal - 10. "Phonic" wheel - 11. Drum brake - 12. Oil sump - 13. Rear axle sleeve.


526210 REMOVING DIFFERENTIAL GEAR – TRANSFER BOX (with rear axle on stand 99322215)

Figure 25




Lock the differential gear, operating as follows: unscrew the screw (7) and screw it down in the hole (8); screw down the screw fully to get the differential lock to go in.

Figure 26



Use retainer 99370317 (3) to stop flange (1) rotation. Unscrew drive flange (1) retaining nut using wrench 99355131 (2) and torque adaptor (4). Remove screws (5) and disconnect axle housing output shaft mounting (6).

Figure 27




Loosen differential carrier (1) retaining screws. Screw in three screws to be used as extractors and separate differential carrier from axle housing by means of eyebolts and metal ropes.



Use mounting 99370616 for differential carrier removal with axle assembled on vehicle.

REFITTING DIFFERENTIAL GEAR – TRANSFER BOX (with rear axle on stand 99322215)


Figure 28



Coat the axle housing to differential mating face with sealant. Insert differential in axle housing. Tighten nuts (1) and screws with lock washers to the specified torque using a torque wrench (2).


Fit differential axle shafts as described in 525030 operation. Backout screw (3) to release the differential lock device. Insert screw (3) in its seat on cylinder cover and tighten plug and washer in the threaded hole previously occupied by the screw (3).

Figure 29




Turn the axle housing by 90°. Insert support (1) with drive output shaft (2) in the axle housing and tighten screw to the specified torque.

Figure 30



Stop flange (1) rotation by means of retainer 99370317 (4). With wrench 99355131 (2) and torque adaptor (3) tighten output shaft flange (1) retaining nut to the specified torque. Once assembly operations are completed, pour the specified quantity of TUTELA W140/M-DA oil into the axle housing. Then check efficiency of differential lock connection sending unit.


Figure 31



Detach the transfer box differential gear housing as described under the relevant heading. Position the transfer box differential gear housing (1) on the rotary stand 99322205 (2) together with the mount 99322225 (3).


Unscrew the screws (4) and remove the guard. Using tool 99360311 unscrew the oil filter (5).

Figure 32



Stop flange (1) rotation with tool 99370317 (2). Undo flange retaining nut using wrench 99355088 (3) and torque adaptor (4).

Figure 33




Remove nuts fixing mounting (1) to differential carrier and take it out together with input shaft, oil pump, gear and inter-axle differential.

Remove shims (2).

Separate the differential housing as described in the relative chapter.


Figure 34



77231

Remove cylinder (1) complete with inter-axle differential lock piston (2) and withdraw yoke (4) drive pin (3).


Figure 35



36352

Remove the spring (1) and strip yoke (2), sleeve (3) and rear planetary gear (4).


Figure 36



36353

Use a punch to expel cup (1) of rear planetary gear bearing (4, Figure 35).


Figure 37



36354

Use extractor 99348001 (1) and reaction block (2) to dismantle cone of rear planetary gear (4) roller bearing.


Figure 38



84395

Tighten drive input shaft in a vice. Remove snap ring (1) and take out differential gear assembly (2), gear (3) and thrust ring (4).


Figure 39



84396


If the planetary gear unit is to be removed, use a punch to mark a reference point (1) on both half-cases, in order to make them match during assembly. Slacken the screws (2) and split the two half-cases. Remove the cross unit, take off the four gears, the pinions and the four thrust washers from the cross unit.

Figure 40




Remove nut (1) and separate flange (2) from drive input shaft (3) by means of a suitable extractor.

Figure 41




Use a press to extract the drive input shaft (1) from bearing cage (2) and oil pump (3).

Figure 42



Remove screws (1), separate oil pump (2) from bearing cage (3) and take out bearing (4).

Figure 43



Remove spring (2), oil pressure relief valve (1) and cup (3) of bearing (4, Figure 42) from bearing cage (4).

Checking inter-axle unit components

Accurately clean each single component and check for wear in view of their possible re-use.




Make sure all screw, stud and ring nut threads are cleaned accurately so that clearance and torque specifications are not effected.

Always renew sealing rings, retaining rings and washers.


Fitting inter-axle unit

Figure 44




Tighten the drive input shaft (1) in a vice and install the oil pump (3). Heat the bearing (2) to 100°C for 15 minutes and fit it on using a drift.

Figure 45




Using the drift 99374093 (2) and under the action of a press, partially fit the external ring (3) of the bearing (4, Figure 42) in the mount (4). Complete driving it in manually with the aid of the grip 99370007 (1).

Figure 46




Fit sealing ring (3) with tool 99374162 to bearing cage (4). Install bearing cage (4) on oil pump (5) so that exhaust (→) matches the valve seat (2). Insert spring (1) in the seat for oil pressure relief valve and fit the plug. Use a feeler gauge to check distance X between sealing ring (3) and mounting (4) at four equi-distant points. Distance X should be between $0.38 \div 0.76$ mm.

Figure 47



Fit the planetary gear unit (previously removed) on the basis of the following procedure: apply the specific grease used for the other parts of the planetary gear unit in the rear axle case. Fit the gears, the pinions and the thrust washer on the cross unit. Put the pinion/cross unit in one of the half-cases (1). Place the other half-case on that with the cross unit. Make sure that the marks (2) are aligned. Apply Loctite and fit four of the cylinder head screws (3). Fit the other cylinder head screws (3) after applying Loctite on the threading and tighten them to a torque of $60 \div 75$ Nm ($6,1 \div 7,6$ kgm).

Figure 48




Smear the thrust ring (4) with grease and arrange it under gear (3);

- ☐ secure the gear on the drive input shaft (6);
- ☐ then differential gear assembly (2) and fasten by means of snap ring (1).

Turn the input shaft (6) upside down and spline flange (5) onto it.


Fit washer (7) and screw in retaining nut (8) without fully tightening it.

Figure 49




Use drift 99374093 (2) and handle 99370007 (1) to fit bearing (2, Figure 50) cup (3) in the rear-axle differential carrier.

Figure 50




Heat bearing (2) to 100°C for 15 minutes and fit on rear side gear shaft (1).

Figure 51



Place rear side gear (4) complete with sleeve (3) and fork (2) on bearing cup (3, Figure 49). Then fit spring (1) on fork (2).


Figure 52



Mount the spindle (1) governing the transfer box differential locking, lubricate the new seal (2) and fit it on the piston (3) and insert this into the cylinder (4). Apply sealant on the thread of the cylinder (4). Screw this into the differential gear housing, tightening it to the prescribed torque.

Adjusting drive input shaft bearing end float

Figure 53



Proceed as follows to adjust shaft bearing end play:


- ☐ fit the drive input shaft into the inter-axle differential carrier;
- ☐ tighten screws (2) without washers;
- ☐ turn the input shaft in both directions to bed bearings; at the same time, tighten screws (2) without locking them;
- ☐ use a feeler gauge (4) to measure, at four equally-spaced points, the gap between bearing cage (3) and carrier rest face;
- ☐ thickness **S**, corresponding to the shim pack necessary for adjusting bearing end play is calculated as follows:

$$S = A + B$$
- ☐ where **A** is the mean value resulting from the four measurements taken earlier;
- ☐ **B** = 0.013 is the mean value of bearing end play (0.05 ÷ 0.20 mm);
- ☐ remove screws (2) and raise the drive input shaft by 6 ÷ 12 mm.
- ☐ fit the shim pack of the correct thickness.



The shim pack must consist of at least three shims, with the thickest in the middle. Shims are supplied as spares in the following range of thickness: 0.076 - 0.127 - 0.254 mm.


Figure 54



Fit new oil filter (5), fit guard (4) and secure it to differential carrier together with bearing cage (3) by screws (2). Check input shaft bearing (1) end play using a dial gauge. End play should be 0.05 to 0.20 mm. In case of a different reading, replace the shim pack with another one of the appropriate thickness.

Adjusting differential lock and inter-axle control pin end-stop

Figure 55




Adjust shaft (2) end-stop as follows:

- ☐ loosen capscrew (1);
- ☐ let 6 bar compressed air into the cylinder (3);
- ☐ tighten capscrew (1) until in contact with shaft (2);
- ☐ furtherly tighten capscrew (1) by 1/4 to 1/2 turn and lock jam nut (4);
- ☐ Use tool 99370317 to lock flange rotation (1, Figure 54) and tighten the retaining nut to the specified torque.

526210 REPAIRING MAIN DIFFERENTIAL - DISMANTLING DIFFERENTIAL CASING


Figure 56



Take out the switch (1) signalling differential locking, unscrew the screw (2) to cut in manual differential locking, the cylinder (3) together with the ram (4) and the seal (5) and extract the spindle (6).


Using a punch, eject the ram (4) from the cylinder (3).

Figure 57




Release the coupling (1) with a rubber skirt and remove it from the fork (2).

Figure 58




Take out the spring (1) and the fork (2) from inside the differential gear housing.

Figure 59




Remove split pin (3) and roll pin (1); dismantle caps (2) and bearing adjusting nuts (4).

Figure 60




Use a sling hook to extract the gear cage (1) complete with crown wheel and bearings.

Figure 61




Stop rotation of flange (1) by means of retainer 99370317 (2); with wrench 99355088 (3) and torque adaptor (4) loosen flange (1) retaining nut. Remove cover (5).

Figure 62




Remove nuts retaining bearing cage (1) to differential carrier. Pull out bearing cage complete with input shaft, oil pump, gear and inter-axle differential. Remove shims (2).

Figure 63




Remove the cylinder (1) together with the piston (2) of the differential locking-transfer box and extract the pin (3) governing the fork (4).

Figure 64




Remove drive shaft (3, Figure 56). Remove spring (1) and strip fork (2), sleeve (3) and rear planetary gear (4).

Figure 65



Block rotation of the bevel pinion with the tool S.P. 2373 (1); with wrench 99344069 (2) and the multiplier (3) remove the nut fastening the bearings to the bevel pinion and the washer beneath.


Figure 66



Apply on the housing a special extractor S.P. 2346, (5) and extract the pinion from the parts: spacer (1), gear (2), spacer (3) and bearing (4).


Then remove the above-mentioned parts from the housing.

Figure 67




Dismantle carrier bearing cups (1, 2, 3) using a drift.

Figure 68




Place tool 99348001 (2) under the taper roller bearing (1) and pull it off the bevel pinion using a press.

Figure 69




77240


INTER-AXLE DIFFERENTIAL COMPONENTS - EXPLODED VIEW

Dismantling gear cage**Figure 70**


Use hook (1) to raise the gear cage assembly and position on stand 99371047 (3).

Figure 71

Unscrew nuts (1) and remove them with screws. Drive out bevel crown wheel (2).


Figure 72

Use tool 99348001 (1) and reaction block 99345055 (2) to remove bearing (3) and bearing (4).

Figure 73

Mark the two casing halves (2 and 3) and the spider as indicated in the figure.

Unscrew screws (1) joining the casing halves. Lift the casing half (2).

Figure 74

Remove differential gear (2) with the associated thrust washer (1). Remove spider (6) with the four planetary gears (5) complete with thrust washers (3). Take the spider/planetary gear assembly apart. Remove the other differential gear with its thrust washer from the half cage (4).

Checking differential components

Thoroughly clean the individual parts making up the differential. Lubricate the bearings and spin the roller cages freely; these should rotate evenly without tight spots.

Check the seating surfaces of the bevel crown wheel and the bedding surface of the half cage so that the crown wheel adheres to it perfectly; distortion of these faces would cause vibration of the crown wheel attachment screws, compromising the satisfactory operation of the unit.



Thoroughly clean threads of screws, studs and ring nuts to prevent clearance or torque settings from being altered.

Check that there is no excessive wear in the splined portion for fitting the flange to the pinion; if there is, replace the pinion.


Check the planetary gears and associated thrust washers, the spider and differential gears and thrust washers. Replace all seals and gaskets, the locking pin for the adjustment ring nut and all lock washers.



If it should be necessary to replace the crown wheel or pinion, both must be replaced as the parts are supplied as matched pairs.

Assembling gear cage


Figure 75



19397

Heat the support bearing (2) for the opposite side of the locking differential in a circulating air oven to a temperature of 100°C for about 15' and fit it to the gear cage (3) using a suitable drift (1).


Figure 76



19391

Position half cage (2) on fixture 99371047. Position differential gear thrust washer (1) in the half cage (2) and then fit differential gear.


Figure 77



19383

Fit spider (6) complete with planetary gears (5) and associated thrust washers (3) to half cage (4). Position second differential gear (2) with thrust washer (1).

Figure 78




36323

Lock the differential with the parts (1); fit on the half box (3). Check that the marks made at the time of removal coincide. Apply a few drops of "LOCTITE 270" on the thread of the screws (2). Tighten the screws (2) to the prescribed torque.



It is always advisable to renew screws (2).


Figure 79



34850


Heat bearing (1) in a circulating air oven to a temperature of 100°C for about 15' and fit it to the gear cage (2) using a suitable drift.

Figure 80



Heat bevel crown wheel (1) in a circulating air oven to a temperature of 100°C for about 15' and position it on its seating on the gear cage, ensuring that the holes for the bevel crown wheel/gear cage attachment screws are lined up.

Figure 81



Allow the bevel crown wheel to cool before positioning the screws. Use torque wrench (1) to tighten self locking nuts (2) to the specified torque.




With self-locking nut and screw 310 ± 15 Nm;
With screw, washer and nut:
first stage (pre-tightening) 100 Nm
second stage (angular tightening) 100°

ASSEMBLING DIFFERENTIAL CASING

Calculating bevel pinion position in differential casing

Figure 82



If a new final drive set is installed, it will be necessary to know the meaning of the markings on pinion and crown wheel in order to position the pinion correctly:

1. part number;
2. tooth combination number.
This number (example: 12/41) indicates that the pinion has 12 teeth and the crown wheel 41;
3. pinion/crown wheel pair set number.
All final drive sets are available as pairs: therefore pinion and crown wheel bear the same number which is stamped on head end for pinions and the outer face for crown wheels;



Never use a pinion and crown wheel set unless both components have the same number.

4. variation number needed to determine the thickness of the shim pack interposed between pinion bearing cage and differential carrier (in the example below, this number is identified as CP).

Every crown wheel is marked with a variation number which indicates the nominal assembly distance. Use this number to calculate the thickness of the shim pack that is interposed between pinion bearing cage and differential carrier.

The variation number (CP + 0,1 or CP - 0,1) is stamped on crown wheel outer face.

5. Pinion/crown wheel set manufacturing and inspection month and year.
6. Specified pinion/crown wheel set clearance.

Part number and tooth combination number are stamped on threaded end of all pinions. Number may alternatively be located on outer diameter of crown wheel. On any pinion/crown wheel set, crown wheel will always bear an even stamped category number (e.g. 36786), whereas corresponding pinion will bear an odd number (e.g. 36787).

To determine the thickness of the shim pack to be interposed between bearing cage and differential carrier proceed as follows:

1. measure the thickness of the shim pack removed with the old final drive gear set. Use a micrometer or other suitable gauge and record the value found;
2. read the CP marked on pinion to be replaced: if it is a plus (+) number or a minus (-) number respectively subtract or add it from the value obtained under 1. above;

Take note of the result.



The value obtained in 2. will be used to calculate the thickness of the shim to be interposed between pinion bearing cage and differential carrier for correct new final drive assembly.

3. read the CP marked on the new pinion.
Either add or subtract this value - depending on whether the sign is a plus or a minus - to or from the value noted under 2. above.
The result indicates the thickness which the new shim pack should have.

Refer to the following examples which cover all the possible calculation cases.


COMPUTATIONAL EXAMPLES

Case 1:	mm
Original shim pack thickness	0.76
CP marked on pinion +2	+0.05
Resulting value	0.81
CP marked on new pinion +5	-0.12
Thickness for new shim pack	0.69
Case 2:	
Original shim pack thickness	0.76
CP marked on pinion -2	-0.05
Resulting value	-0.71
CP marked on new pinion +5	-0.12
Thickness for new shim pack	-0.59
Case 3:	
Original shim pack thickness	-0.76
CP marked on pinion + 2	+0.05
Resulting value	0.81
CP marked on new pinion -5	+0.12
Thickness for new shim pack	0.93
Case 4:	
Original shim pack thickness	-0.76
CP marked on pinion -2	-0.05
Resulting value	0.71
CP marked on new pinion -5	+0.12
Thickness for new shim pack	0.83



The difference between the value of the thickness of the new pack and that of the old one must be added to or subtracted from, depending on the case, the thickness of the adjustment ring (6, Figure 84).


Figure 83



Place the bevel pinion position adjustment rings (4) in the box and, using grip 99370007 (1) and drift 99374094 (2), mount the external ring (3) for the bevel pinion bearing. Fit remaining bearing cups using drift 99374093.

Determining the thickness of the bevel pinion bearing clearance adjustment rings

Figure 84



Measure the thickness of the adjustment ring (6) found on removal and note down the value (dimension A). Tighten the tool 99395027 (8) in a vice and place the following on it:


- ☐ the bearing (7) on the pinion side;
- ☐ the ring (6) previously measured.
- ☐ the gear (5);
- ☐ the spacer (4);
- ☐ the bearing (3).

Screw down the ring nut (2) and tighten it fully. Position part (1) of tool 99395027 (8), equipped with a dial gauge, on the bearing (3) and reset the dial gauge on the end of the tool (8).

Then remove:


- ☐ the part (1);
- ☐ the ring nut (2);
- ☐ the bearing (3);
- ☐ the spacer (4);
- ☐ the gear (5);
- ☐ the ring (6) the bearing (7) from the tool (8).

Figure 85



Insert the tool 99394027 (8, Figure 84) in the differential gear housing, comprehensive of the bearing (7, Figure 84), ring (6), gear (5), spacer (4), bearing (3). Screw down the ring nut (1) on the tool 99394027.


Figure 86



Screw down the ring nut (2, Figure 87) tightening it until, with a dynamometer, you measure a rolling torque of:

- ☐ 1.10 to 5.00 Nm if the bearings are new,
- ☐ 1.68 to 3.39 Nm if the bearings have already been used.

Figure 87



Reposition part (1) of tool 99395027, with the dial gauge previously reset on the bearing (3) and measure any difference (dimension B).

The thickness **S** of the ring, or of the adjustment rings, is given by the following formula:

$$S = A - (\pm B) + C$$

where:

- A** = Thickness of the adjustment ring(s) fitted to reset the dial gauge;
- B** = Value of the difference measured;
- C** = 0.2 mm coefficient that takes account of the expansion of the bearings due to the interference of assembly on the bevel pinion.

First example:

$$A = 13.12 \text{ mm}$$

$$B = + 0.13 \text{ mm}$$

$$C = 0.2 \text{ mm}$$

$$S = 13.12 - (+ 0.13) + 0.2 =$$

$$S = 13.12 - 0.13 + 0.2 = 13.19 \text{ mm.}$$

Second example:

$$A = 13.12 \text{ mm}$$

$$B = - 0.13 \text{ mm}$$


$$C = 0.2 \text{ mm}$$

$$S = 13.12 - (- 0.13) + 0.2 =$$

$$S = 13.12 + 0.13 + 0.2 = 13.45 \text{ mm.}$$


Remove from the box the tool 99395027 (8, Figure 84) and take out the bearings, spacers and gear as shown in the figure.

Figure 88




Heat the bearing (2) to 100°C for 15 min. and, with a specific drift, fit it on the bevel pinion.

Figure 89



Insert the bevel pinion (3) in the box, simultaneously keying onto it the adjustment ring (1) of the thickness determined in the preceding measurements and the gear (2); screw the part 99345029 (4) onto the bevel pinion (3).

Figure 90




77242

Block rotation of the bevel pinion with the tool S.P. 2373 (5). Screw down the inserter 99345098 (4) onto the part (4, Figure 89) and fully drive in the gear (3). Remove the inserter (4).

Fit on the spacer ring (1). Heat the bearing (2) to 100°C for 15 min. and fit it onto the pinion.

Screw the inserter (4) back onto the part (4, Figure 89) and take the bearing (2) into contact with its seat.

Figure 91




77237

Block rotation of the bevel pinion with the tool S.P. 2373 (1). Screw down the nut fastening the bevel pinion bearings and tighten it to the prescribed torque.



To tighten the nut use the wrench 99355069 (2) torque wrench and multiplier 99389816 (3).

Figure 92



20670


Position the caps taking care to make the reference marks coincide.

Insert the screws, together with the washers, and tighten them, using a torque wrench, to the prescribed torque.

Then check that the external rings of the bearings slide, with a light pressure, in their respective seats without sticking.

Again unscrew the fastening screws with the washers and remove the caps.


Figure 93



94191

Using the hook (1), lift the gear housing (2) previously assembled and position it on the differential casing (3).


Figure 94



77245

Position the caps (2), screw down the screws (1) with the washers and tighten them to the prescribed torque.

Figure 95



77246

Lubricate taper roller bearings (1) and fit outer races. Screw in adjustment ring nuts (2).


Adjusting the cap gap

Adjusting and checking retraction of the caps can be done with two methods:

1st METHOD

1. Use wrench 99355025 (3, Figure 97) to tighten the adjustment lock rings (4) of the bearings until eliminating the pinion-crown wheel clearance and end float. At the same time check that the crown wheel does not force on the pinion;
2. using a suitable micrometer positioned diagonally and centrally in points (X-Y-arrows, Figure 97); measure and note the distance of the caps;

Figure 96




60636

3. further tighten the two adjustment lock rings (4, Figure 97) to obtain a retraction of the caps (2, Figure 97), measured on Axis X or on axis Y as described in point "2" of: 0.15 to 0.33 mm which corresponds to a preload on the bearings of 1.7 to 3.9 Nm (0.17 to 0.39 kgm).

2nd METHOD

- A. Diagonally and centrally on the outer machined seats of both caps (2, Figure 97) position two dial gauges (1) with magnetic base as shown in Figure 97;


Figure 97



77247

- B. proceed as described in point "1";
- C. after eliminating the end float further tighten the two adjustment lock rings (4) to obtain a retraction of the caps (2) of 0.15 to 0.33 mm, which corresponds to the sum of the readings on the dial gauges (1).

Figure 98




49248

Adjust the axial clearance between the teeth of the pinion - crown wheel unit which must be 0.25 to 0.50 mm proceeding as follows:

- ☐ stop the bevel pinion from turning using tool 99370317;
- ☐ position the magnetic-based dial gauge (1) as illustrated;
- ☐ using wrench 99355025 (3) slacken the adjustment lock ring on the crown wheel side and tighten, to the same extent, the adjustment lock ring (2) of the opposite side. The purpose of this is to leave the previously-adjusted cap retraction unchanged;
- ☐ proceed as described until obtaining the specified clearance.

The clearance should be checked on 4 points the same distance apart.

Figure 99




49246

Use a magnetic-based dial gauge (1) to check that the crown wheel (2) does not have any upper wobble above 0.20 mm. If it does, disassemble the differential unit and find the cause.

Refit and repeat the adjustment operations described previously.


Figure 100



19451

Apply a light layer of Prussian blue on the crown wheel. Turn the pinion and measure the impression of the contact of the pinion teeth on the crown wheel teeth. The following figures show possible contacts and how to correct any errors.

Figure 101



19452

Contacts too much on crown wheel teeth bottom land


Conditions C-D. Indicates that the pinion is fastened too deeply and needs further adjustment.

To adjust the exact position of the pinion shims should be added under the pinion support to obtain the exact contact.

Condition C. Measure the clearance and restore it after adding shims.

Condition D. After adding shims, take the clearance towards minimum.

Figure 102



19453


Contacts too much towards the crown wheel teeth top land

Conditions A-B. Indicates that the pinion is fastened too much towards the outside and therefore needs further adjustment. To adjust the exact position of the pinion, remove shims under the pinion support to obtain the exact contact.

Condition A. After removing the shims, take the clearance towards maximum.

Condition B. Measure the clearance and restore it after removing shims.

Figure 103



19454

THEROETICAL CONTACT AREA

1. Release, concave side of tooth
2. Top land
3. Pulling, convex side of tooth
4. Heel

PULLING. Central tending towards the top land on the tooth face and central on the tooth profile.



RELEASE. Central tending to the heel on the tooth face and central on the tooth profile.

Indicates that the pinion is fastened correctly.



The contact position can be further changed by changing the pinion-crown wheel clearance.

Condition E. Lower the clearance.

Condition F. Increase the clearance.

CORRECTING THE CROWN WHEEL AND PINION CONTACTS (AFTER ASSEMBLY)**Figure 104****THEORETICAL CONTACTS****PULLING
(CONVEX SIDE OF RING GEAR)****RELEASE
(CONCAVE SIDE OF RING GEAR)**


- PULLING : CENTRAL TENDING TOWARDS THE TOP LAND ON THE TOOTH FACE AND CENTRAL ON THE TOOTH PROFILE
- RELEASE : CENTRAL TENDING TOWARDS THE HEEL ON THE TOOTH FACE AND CENTRAL ON THE TOOTH PROFILE

CONDITION "A"**PULLING
TIP****RELEASE
TIP**


- PULLING RELEASE : CONTACTS TOO MUCH AT TIP
- PULLING : CONTACT TOO MUCH AT TOP LAND
- RELEASE : CONTACT TOO MUCH AT HEEL
- CORRECTIVE ACTION : REMOVE SHIMS AND INCREASE CLEARANCE TO MAXIMUM

CONDITION "B"

TIP




TIP




- PULLING - RELEASE : CONTACTS TOO MUCH AT TIP
- CORRECTIVE ACTION : MEASURE THE CLEARANCE AND RESTORE THE CLEARANCE

CONDITION "C"

TIP




TIP




- PULLING - RELEASE : CONTACTS TOO MUCH ON BOTTOM LAND
- CORRECTIVE ACTION : MEASURE THE CLEARANCE, ADD SHIMS AND RESTORE CLEARANCE

60676


Figure 105

CONDITION "D"

- PULLING - RELEASE : CONTACTS TOO MUCH ON BOTTOM LAND
- PULLING: : CONTACT TOO MUCH AT HEEL
- RELEASE : CONTACT TOO MUCH AT TOP LAND
- CORRECTIVE ACTION : ADD SHIMS AND REDUCE CLEARANCE TO MINIMUM

CONDITION "E"


- PULLING : CONTACT TOO MUCH AT HEEL
- RELEASE : CONTACT TOO MUCH AT TOP LAND
- CORRECTIVE ACTION : REDUCE CLEARANCE

CONDITION "F"

- PULLING : CONTACT TOO MUCH AT TOP LAND
- RELEASE : CONTACT TOO MUCH AT HEEL
- CORRECTIVE ACTION : INCREASE CLEARANCE

60677

Figure 106




77248

Fit on the spring pin (1) and the split pin (3) to lock the ring nuts (2-4).



If the spring pin or the split pin do not coincide with their respective seats on the ring nuts, slightly turn these so it is possible to insert the spring pin or the split pin,


Figure 107



77236

Fit on the spring (1) and the fork (2) from inside the differential casing.


Figure 108



77249

Position the fork (2) in the groove of the coupling (1) and fit this on the tothing (3) of the differential gear.

Figure 109



77234


Mount the spindle (6). Lubricate the new seal (5) and fit it on the piston (4) and insert this into the cylinder (3). Apply sealant on the thread of the cylinder (3) and screw it down into the differential casing, tightening it to the prescribed torque.

Screw down the screw (2) so as to provisionally prevent the differential gear unlocking.

Remove the differential casing from the mounting and fit it back on the axle housing as described under the relevant heading.


Mount the differential locking - transfer box (Figure 52, page 135) and adjust it as described under the heading, "Adjusting differential locking-transfer box pin limit switch."

Figure 110



Position on the differential casing the adjustment rings (2) of the thickness determined under the heading "Adjusting drive input shaft bearing end float" and fit on the mount (1) comprehensive of the reduction gear transfer box.

Figure 111




Block rotation of the flange (1) using tool 99370317 (2); with wrench 99355088 (3) and multiplier (4) tighten the nut fastening the flange (1) to the prescribed torque.

Fit on the cover (5) with a new gasket.

Remove the differential casing – transfer box from the mounting 99322228 and fit it back on the axle housing as described under the relevant heading.

526082 REMOVING-SERVICING-REFITTING INTER-AXLE OUTPUT SHAFT


Figure 112



Stop rotation of flange (1) with retainer 99370317 (3). With wrench 99355131 (2) and torque adaptor (4) loosen shaft flange (1) retaining nut.


Removing retaining nuts (5) and separate shaft bearing cage (6) from axle housing.

Figure 113




Tighten the drive output shaft (3) in a vice; remove the nut securing flange (2) to drive output shaft (3) and dismantle flange (2) from shaft (3) using an extractor.

Figure 114



Remove sealing ring (1) from bearing cage (2) and take out snap ring (3) retaining bearing cup (4) and snap ring (5).


Figure 115



36390

Extract the drive output shaft (5) complete with bearings (2 and 3) and bearing cup (1) from bearing cage (4). Use a suitable extractor to remove bearings (2 and 3) from the drive output shaft (5).


Figure 116



36391

Use a punch to drive bearing (3, Figure 115) cup (1) off bearing cage (2).


Figure 117



36392

With drift 99374093 (2) partially press fit bearing cup (3) in bearing cage (4). Complete bearing cup fitting using drift 99374093 and handle 99370007 (1).

Figure 118



36393

Reverse the removal operation sequence to reassemble the output shaft unit.

After fitting the O-ring (3) with tool 99374163, use a feeler gauge to check distance X between sealing ring (3) and mounting at four equi-distant points. Distance X must be between 0.38 ± 0.76 mm.


Tighten nut (2) fastening flange (1) to the drive output shaft (4) to the specified torque. Then check that end play is between 0.025 ± 0.102 mm using a magnetic base dial gauge (3) positioned on shaft (4).

If reading is other than specified, replace the snap ring (5, Figure 114) with one of the correct thickness.



Snap rings are supplied in the following thickness range: 3.94 - 4.01 - 4.09 - 4.17 - 4.24 - 4.32 - 4.39 - 4.47 - 4.55 - 4.62.

Figure 119




36346

Rotate the axle housing by 90° .

Fit bearing cage (1) complete with drive output shaft (2) in the axle housing and tighten nuts to the specified torque.

Figure 120



36394

DRIVE OUTPUT SHAFT COMPONENTS

Axles in Tandem (Rear)
MERITOR RR 167 E (R 0878)

	Page
DESCRIPTION	149
CHARACTERISTICS AND DATA	149
TIGHTENING TORQUES	151
TOOLS	153
OVERHAULING REAR AXLE ASSEMBLY RR 167 E (R 0878)	159

DESCRIPTION

The rear axle is the load-bearing type with a single reduction; it is composed of a box formed of suitably strengthened sheet steel. The differential gear comprises a gear train with hypoid toothing.

The pinion is supported by two tapered roller bearings and by a third cylindrical roller bearing.







The position of the bevel pinion can be adjusted in relation to the ring bevel gear by varying the thickness of the pack of rings between the differential casing and the bevel pinion mount.

The gear housing is supported by two tapered roller bearings and it is axially adjustable by two threaded ring nuts.

The rear axle is equipped with an air-operated device for locking the differential.


The wheels hubs are supported by two tapered roller bearings floating on the sleeve and adjustable with a threaded nut.

CHARACTERISTICS AND DATA

	Rear axle Type	RR 167 E (R 0878)
	Bevel pinion bearings	2 with tapered rollers and 1 with cylindrical rollers
	DIFFERENTIAL ASSEMBLY Bevel gear pair reduction ratio	3.07 (14/43) - 3.21 (14/45) - 3.42 (12/41) - 3.73 (11/41) - 3.91 (11/43) - 4.30 (10/43)
	Clearance between pinion and ring gear mm	0.26 to 0.50
	Adjustment of clearance between pinion and ring gear	With adjustment rings
	Bevel pinion position in relation to ring gear	With adjustment shims
	Cap gap mm	0.15 to 0.33
	Cap gap adjustment	With adjustment rings
	Rolling torque between planetary gears and crown wheels Nm kgm	68 max. 6.8 max.
	 Thicknesses of adjustment rings between bevel pinion mount and differential case mm	0.125 - 0.200 - 0.500
	Wobble of ring gear supporting surface on half box mm	0.13 max.

	WHEEL HUBS	
	Wheel hub bearings	Two with tapered rollers
	Wheel hub bearing end float adjustment mm	0.00 ± 0.05
	Wheel hub bearing end float adjustment	max 2.45 max 0.25
	Rear axle oil	TUTELA WI 40/M-DA
	Quantity	
	air suspensions Litres (kg)	18 (16)
	Cantilever suspension Litres (kg)	19 (17)

Figure 1




49302

TIGHTENING TORQUES







PART		TORQUE	
		Nm	kgm
1	Screw fixing differential case to axle housing	1 st phase torque 2 nd phase angle	100 ± 5 10 ± 0.5 80° to 90°
2	Screw fixing differential half boxes	1 st phase torque 2 nd phase angle	100 ± 5 10 ± 0.5 110° to 120°
3	Screw fixing bevel ring gear to half box	1 st phase torque 2 nd phase angle	100 ± 5 10 ± 0.5 80° to 90°
4	Nut locking bevel pinion		1350 to 1670 135 to 167
5	Screw fixing bevel pinion mount	1 st phase torque 2 nd phase angle	100 ± 5 10 ± 0.5 60° to 70°
	Nut locking sensor		35 to 45 3.5 to 4.5
6	Screw fixing caps to differential case		650 to 810 65 to 81
	Oil drain plug		47 4.7


Figure 2




SECTION ON THE REAR AXLE WHEEL HUB IN TANDEM RT 160E

PART	TORQUE	
	Nm	(kgm)
1 Screw fixing drive shaft to wheel hub M14 x 1.5	207.9 ÷ 256.9	(21.2 ÷ 26.2)
2 Nut fixing wheels	600 ⁺⁵⁰ ₋₂₀	(60 ⁺⁵ ₋₂)
3 Nut for screw securing brake mounting	275.5 ÷ 304	(28 ÷ 31)
4 Ring nut locking wheel hub adjustment nut	392.3	(40 ± 2)


TOOLS	
TOOL NO.	DESCRIPTION
99305121	 Heater
99322205	 Rotary stand for overhauling assemblies (capacity 1000 daN, torque 120 daN/m)
99322215	 Stand for axle overhauling
99322225	 Unit holder (to be mounted on stand 99322205)
99341003	 Single-acting lift
99341009	 Pair of brackets

TOOLS**TOOL NO.****DESCRIPTION****99341012**


Pair of brackets

99341015


Clamp

99341016


Pair of brackets with holes

99345049







Reaction block for puller tools

99345055






Reaction block for puller tools






99345103


Wheel hub fitting tool

TOOLS	
TOOL NO.	DESCRIPTION
99348001	 Puller tool with clamping device
99355025	 Wrench for differential gearcase bearing adjustment ring nuts
99355088	 Wrench (60 mm) for differential bevel pinion nut (to be used with 99370317)
99355167	 Wrench (114 mm) for wheel hub bearing adjustment nut
99363204	 Tool to extract gaskets
99370005	 Hand-grip for interchangeable drift punches

TOOLS

TOOL NO.	DESCRIPTION	
99370007		Hand-grip for interchangeable drift punches
99370317		Reaction lever and extension for flange lock
99370509		Hook to remove differential gearcase half-housing
99370616		Support to remove-fit back differential
99370617		Universal support to remove-fit back rear axles
99371047		Stand to hold differential half-housing when tightening crown wheel screws (to be used with 99322205 - 99322225)


TOOLS	
TOOL NO.	DESCRIPTION
99374093	 Drift punch for installation of bearing outer races (91 ÷ 134) (use with 99370007)
99374094	 Drift punch for installation of bearing outer races (134 ÷ 215) (use with 99370007)
99374134	 Installer, wheel hub inner seal
99374244	 Installing tool for assembling bevel pinion seal ring
99389816	 4 x torque multiplier, with square connection, 3/4" in, 1" out (maximum torque 2745 Nm).
99389819	 Torque wrench (0 - 10 Nm) with 1/4" square fitting

TOOLS**TOOL NO.****DESCRIPTION****99395026**

Tool for measuring hub rolling drag torque (use with torque wrench)

525010 OVERHAULING REAR AXLE ASSEMBLY RR 167 E (R 0878)

Figure 3



36396

For the operations:

- ☐ overhauling the wheel hubs (555030), follow the directions given for the Meritor rear axle RP 160 E.
- ☐ removing-refitting differential with rear axle on stand (526210);
- ☐ repairing differential (526210).

Follow the directions given and illustrated for the Meritor rear axle MS 13-175.

SECTION 8

5206 Axles

In this section

5206 Front axles

FRONT AXLE	
5876/4 (F 802I)	
5876/5 (F 802I)	
5886/5 (F 902I)	
STEERING CENTRAL ADDED AXLE	
5876/2 (F 802I)	3

5258 Additional rear axle

ADDITIONAL RIGID REAR AXLE 55080/DI	3I
ADDITIONAL RIGID REAR AXLE 55080/TI	4I
RIGID REAR ADDED AXLE WITH HYDRAULIC LIFTING 56082/DI	5I
RIGID REAR ADDED AXLE WITH HYDRAULIC LIFTING 56082/TI	59
STEERING REAR ADDED AXLE 57080/DI	73
STEERING REAR ADDED AXLE 57080/TI	10I
WHEEL GEOMETRY	III

Front axle
5876/4 (F 8021)
5876/5 (F 8021)
5886/5 (F9021)
Steering central added axle
5876/2 (F 8021)

	Page
DESCRIPTION	5
SPECIFICATIONS AND DATA	6
FAULT DIAGNOSIS	8
TIGHTENING TORQUES	11
TOOLS	13
REMOVING AND REFITTING AXLE	17
☐ Removal	17
☐ Refitting	17
REMOVING AND REFITTING AXLE	18
☐ Vehicles with pneumatic front suspension and longitudinal bars	18
☐ Removal	18
☐ Refitting	19
VEHICLE CHECKS	20
☐ Tie rods	20
☐ Swivel heads	20
CHECKING SWIVEL HEAD PLAY	20
FRONT AXLE ASSEMBLY OVERHAUL	21
REMOVING - REFITTING WHEEL HUBS	21
☐ Removal	21
☐ Replacing wheel hub bearings	22
☐ Replacing wheel fixing pins	23
☐ Refitting wheel hubs	23
☐ Checking wheel hub bearing end float	23

Page

☐ Measuring rolling torque	24
REMOVING AND REFITTING TRANSVERSE TIE ROD	24
REPLACING TRANSVERSE TIE ROD SWIVEL HEADS	25
LONGITUDINAL TIE ROD LEVER REMOVAL/ REFITTING	25
CROSS TIE ROD LEVER REMOVAL/REFITTING	25
REMOVING AND REFITTING PIN FOR STUB AXLE	25
☐ Removal	25
☐ Replacing kingpin bearing	26
☐ Checking and adjusting clearance between stub axle and axle	27
CHECKING AND MEASURING THE AXLE BODY	28
☐ Checking levelness of leaf spring supporting surfaces with respect to the holes for the kingpins . . .	28
☐ Checking angle of holes for kingpins	29

DESCRIPTION

The front axle is a steel structure with a double-T cross-section at the end of which the stub axles are articulated.

The stub axle articulation is made with tapered pins integral with the axle body and by means of four bearings with rollers driven in with interference in the holes of the stub axle overhangs.

The wheel hubs are supported by two tapered roller bearings, set right, lubricated with oil, mounted on the shank of the stub axle.


The bearings need no adjustment; their end float is obtained by tightening the retaining ring nut to torque.

The disc brake is the "KNORR" type.

The brake calliper is fitted with:


- ☐ an angle of 57° on axles 5876/4 and 5876/2 without parking brake;
- ☐ an angle of 0° on axle 5876/5 - 5886/5 with parking brake.

Figure I



72774








VIEWS OF FRONT AXLE 5876/4 AND STEERING CENTRAL ADDED AXLE 5876/2












72775

VIEW OF FRONT AXLE 5876/5 - 5886/5

SPECIFICATIONS AND DATA


	Type of axle	5876/4 - 5876/5 - 5876/2 (F 8021) - 5886/5 (F9021)
	KINGPINS	
	Kingpin angle	7°
	Diameter of roller bearing seats on the stub axle: - top seat Ø 1 mm - bottom seat Ø 2 mm	51.967 to 51.986 59.967 to 59.986
	Outside diameter of roller bearings for stub axle: - top bearings Ø 3 mm - bottom bearings Ø 4 mm	52 60
	Stub axle bearings mm	0.014 to 0.033
	Inside diameter of roller bearings for stub axle: - top bearings Ø 5 mm - bottom bearings Ø 6 mm	43 53
	Diameter of pin for stub axle - top Ø 7 mm - bottom Ø 8 mm	42.984 to 43.000 52.981 to 53.000
	Top bearings - pin mm	0 to 0.016
	Bottom bearings - pin mm	0 to 0.019
	Clearance between axle and stub axle top shim adjustment X1 mm Gap between axle and stub axle bottom shim adjustment X2 mm	0.10 to 0.35 0.25

	Type of axle	5876/4 - 5876/5 - 5876/2 (F 8021) - 5886/5 (F9021)								
	Adjustment plates X1; X2									
	 > 0.25 mm	S mm	0.25 to 1.75							
	WHEEL HUBS									
	Wheel hub bearings	2 with tapered rollers								
	Hub bearing axle clearance	mm	max 0.16							
	Wheel hub clearance	by tightening retaining ring nut to torque								
	Bearing pre-load rolling torque	daNm	0.50 max.							
	Oil for wheel hub bearings Quantity per hub	Litres (kg)	Tutela W 140/M DA ~0.35 (0.32)							
	WHEEL GEOMETRY									
	Camber (vehicle with no load)	1°								
	Caster angle (vehicle with no load)	1° 24''								
	Wheel toe-in (unloaded vehicle)	mm	4x2 - 6x2 vehicles				6x2 C vehicles			
	Adjusting tolerance	mm	+ 1 ± 0.75 ± 2				1 st axle		2 nd axle	
	Checking tolerance	mm					0 ± 0.75 ± 2		0 ± 0.75 ± 2	
	Steering angle:	4x2 - 6x2 vehicles				6x2 C vehicles				
		5876/4/5		5886/5		5876/2				
						Internal α		External β		
		Internal α	External β	Internal α	External β	1 st axle	2 nd axle	1 st axle	2 nd axle	
Vehicles with mechanical front suspension		52°	36°	-	-	52°	25°	36°	16°	
Vehicles with pneumatic front suspension and longitudinal bars		50°	35°	50°	35°	-	-	-	-	
Vehicles with pneumatic front suspension and leaf springs		47°	33°	47°	33°	-	-	-	-	
Axle weight		kg	-							
Maximum load capacity		kg	7500							


FAULT DIAGNOSIS

The main operating trouble of the front axle:

- 1 - Steering hardness;
- 2 - Wobbling;
- 3 - Noise.



2

WOBBLING

Caster abnormal.

- YES →

Check the assembly of the axle, repair or replace any deformed parts.

NO



Front axle misaligned.

- YES →

Restore the alignment and tighten to torque the nuts of the brackets fixing the leaf springs on the axle.

NO



Wheel toe-in abnormal.

- YES →

Adjust the toe-in correctly.

NO



Ball joints of the steering tie rods inefficient.

- YES →

Replace the defective parts.

NO



Wheel hub bearing clearance abnormal.

- YES →

Adjust the end float after making any necessary replacements.

NO

Wheels off centre:
rim centred, buckled
tyre fitted on rim incorrectly.

- YES →

Replace the faulty rim.
Deflate and centre the tyre on the rim.


NO



Wheels unbalanced.


- YES →

Balance the wheels.



TIGHTENING TORQUES


Figure 2



CROSS-SECTION OF FRONT AXLE 5876/4 – 5876/2 - WHEEL SIDE

PART	TORQUE	
	Nm	kgm
1 Flanged screw fixing transverse tie rod lever onto stub axle	1325 ± 75	(135 ± 7.6)
2 Flanged screw fixing longitudinal lever onto stub axle	953.5 ± 75	(135 ± 7.6)
3 Flanged hex screw fixing bottom fifth wheel cover onto stub axle	117 ± 6	(11.7 ± 0.6)
4 Self-locking hex screw M20x1.5 fixing brake callipers	615.5 ± 61.5	(61.5 ± 6.1)
5 Nut fixing wheels	665.5 ± 66.5	(66.6 ± 6.6)
6 Hex screw fixing brake disc to wheel hub	281.5 ± 13.5	(28.1 ± 1.3)
7 Self-locking hex screw M16x1.5 fixing brake calliper mount to stub axle	313.5 ± 15.5	(31.3 ± 1.5)
8 Ring nut fixing wheel bearing	515.5 ± 24.5	(51.5 ± 2.4)
9 Tapered threaded plug for wheel hub cover	57.5 ± 2.5	(5.8 ± 0.2)
10 Cylindrical screw with recessed hex locking ring nut adjusting wheel bearings	27.5 ± 2.5	(2.7 ± 0.2)
11 Cover for wheel hub •	130 ± 10	(13 ± 1)
- Castellated nut for kingpin*	300	(30)
• Apply LOCTITE 574 sealer		
* Minimum torque - Maximum torque, tighten to the first notch corresponding to the split pin hole		

TIGHTENING TORQUES

Figure 3


84539







CROSS-SECTION OF FRONT AXLE 5876/5 - 5886/5 - WHEEL SIDE

PART	TORQUE	
	Nm	(kgm)
1 Flanged screw fixing transverse tie rod lever onto stub axle	1325 ± 75	(135 ± 7.6)
2 Flanged screw fixing longitudinal lever onto stub axle	1325 ± 75	(135 ± 7.6)
3 Flanged hex screw fixing bottom fifth wheel cover onto stub axle	117 ± 6	(11.7 ± 0.6)
4 Self-locking hex screw M20x1.5 fixing brake callipers	615.5 ± 61.5	(61.5 ± 6.1)
5 Nut fixing wheels	665.5 ± 66.5	(66.6 ± 6.6)
6 Hex screw fixing brake disc to wheel hub	281.5 ± 13.5	(28.1 ± 1.3)
7 Self-locking hex screw M16x1.5 fixing brake calliper mount to stub axle	313.5 ± 15.5	(31.3 ± 1.5)
8 Ring nut fixing wheel bearing	515.5 ± 24.5	(51.5 ± 2.4)
9 Tapered threaded plug for wheel hub cover	57.5 ± 2.5	(5.8 ± 0.2)
10 Cylindrical screw with recessed hex locking ring nut adjusting wheel bearings	57.5 ± 2.5	(5.8 ± 0.2)
11 Cover for wheel hub •	130 ± 10	(13 ± 1)
12 Screw fixing top cover to stub axle	11.1 ± 2	(1.1 ± 0.2)







- Castellated nut for kingpin*







• Apply LOCTITE 574 sealer



* Minimum torque - Maximum torque, tighten to the first notch corresponding to the split pin hole

TOOLS	
TOOL No.	DESCRIPTION
99305354 	Portable optical equipment to check wheel geometry
99321024 	Hydraulic trolley to remove and refit wheels
99322215 	Stand for overhaul
99347047 	Tool to remove kingpin
99347068 	Extractor for steering tie-rod head pins
99354207 	Wrench for wheel hub cover


TOOLS

TOOL No.	DESCRIPTION	
99370006		Grip for interchangeable drifts
99370007		Grip for interchangeable drifts
99370317		Reaction lever with extension
99370628		Mount to remove and refit front axle
99370715		Guide for mounting wheel hub
99374093		Drift to mount outer bearing races (use with 99370007)

TOOLS		
TOOL No.	DESCRIPTION	
99374132		Key to mount internal wheel hub gasket (use with 99370006)
99374173		Parts to mount kingpin gaskets (use with 99370007)
99374405		Tool to drive in kingpin
99374530		Drift to remove and refit kingpin bearings (use with 99370007)
99388001		Wrench (80 mm) for wheel hub bearing adjustment nut
99388002		Wrench for screws securing longitudinal tie-rod and transverse tie-rod bar lever on stub axle

TOOLS**TOOL No.****DESCRIPTION****99389805**Torque multiplier x 4 with square attachment input 1/2" output 3/4"
(max 1350 Nm)**99389819**

Torque wrench (0-10 Nm) with square connection 1/4"

99395026

Tool to check rolling torque of hubs (use with torque wrench)

520610 REMOVING AND REFITTING AXLE Removal



Position the vehicle on level ground and chock the rear wheels.

Remove front wheel securing nuts

Using a hydraulic jack, raise the front of the vehicle and rest it on two support stands.

Unscrew wheel securing nuts and use hydraulic trolley 99321024 to remove the wheels.

Use extractor 99347068 (2) to remove the tie-rod (3) ball joint of arm (1).

Disconnect:

- ☐ air delivery lines from the membrane brake cylinders;
- ☐ electric cable (9) from the ABS transmitters;
- ☐ electric cable (11) for the brake lining wear indicators if fitted.

Position a hydraulic jack fitted with support 99370628 under axle (8).

Unscrew nuts (5) and remove brackets (4) attaching the leaf spring and the stabilizing bar (7) fixing supports (6) to the axle. Rotate the stabilizing bar (7) so as to prevent it from interfering with the next operation.

Lower the hydraulic jack and pull out the axle (8).


Refitting



Using a hydraulic jack fitted with support 99370628, raise the axle so that the leaf spring coupling pins are inserted into holes in the spring seating faces on the axle.

Refit by performing removal operations in reverse order, and fasten screws and nuts to prescribed torque.

Figure 4



520610 REMOVING AND REFITTING AXLE

Vehicles with pneumatic front suspension and longitudinal bars



Removal

Position the vehicle on level ground and lock the rear wheels.

Loosen the fixing nuts of the front wheels. Put a hydraulic jack fitted with mount 99370628 under the axle (34).

Lift the vehicle at the front and rest it on two stands. Again using the hydraulic jack and mount 9937628, support the axle so that the longitudinal bars (3) and (5) are parallel with the chassis frame.

Unscrew the wheel fixing nuts and, using the hydraulic trolley 99321024, take off the wheels.

Remove the cabin accessing platform, if needed. Take out the bolts (7) and detach the board mount (8).

Disconnect the steering tie rod (9) as follows: Take out the split pin (22) and the nut (21) (det. A).

Using the extractor 99347068 (23) disconnect the swivel head of the tie rod (19) of the lever (20).

Disconnect:

- ☐ The diaphragm brake cylinder air delivery pipes(28);
- ☐ Extract the speed sensor (17) from the brake calliper supporting flange (18);
- ☐ Take out the screws (30) and extract the brake lining wear sensor (31) (det. B);
- ☐ Take out the fixing screws (13) and remove the bracket (14) anchoring the levelling valve tie rod (27);
- ☐ Take out the screw (24) and remove the shock absorber (29) from the mount (16);
- ☐ Take out the screws (15) and remove the air spring (26) from the mount;
- ☐ Remove the screw (11) and disconnect the stabilizer bar (12) from the connecting rod (10);
- ☐ Take out the screws (6) and disconnect the bottom rod (5) from the mounts (4). Repeat these operations for the top rod (3);
- ☐ Repeat the above operations for the opposite side;
- ☐ Take out the screws (25) and disconnect the transverse bar (1) from the mounts (2);
- ☐ Lower the hydraulic jack and take the axle out from under the vehicle;
- ☐ Take out the screws (33) and disconnect the stabilizer bar (32) from the axle (34) (det. C);
- ☐ Take out the screws (35) and disconnect the mounts (36) from the axle (34) (det. C).

Figure 5





Figure 6



61555

Refitting



For refitting, carry out the steps described for removal in reverse order while observing the following:

The connection of the swivel head shanks (2) of the longitudinal rods (1) to the mounts of the chassis frame and of the axle has to be made when there is a distance X between the mounts (5) and structural members (6) of $X = 154 \text{ mm}$.

The connection of the swivel head shanks (3) of the Panhard bar (4) has to be made when there is a distance X between the mounts (5) and structural members (6) of $X = 224.5 \text{ mm}$.

- ☐ Tighten the nuts or the screws to the required torque.
- ☐ The self-locking nuts must not be reused.
- ☐ Check the state of the flexible pads, and change them if they have deteriorated (operation 500417).
- ☐ Using a hydraulic jack fitted with the mount 99370628, lift the axle so that the leaf spring mating pins go into the holes made on the leaf supporting surfaces on the axle.
- ☐ Check and if necessary adjust the geometry of the front wheels.

VEHICLE CHECKS

Tie rods

Check bolts and nuts retaining clamps to track rods and drag links are not damaged and are tightened to specified torque. Track rods and drag links should not be damaged or worn. The threaded part should be in good condition.

Swivel heads

Clean the swivel heads of the tie rods: transverse and longitudinal.

This needs to be done with dry canvas or raw cotton, never use solvents.


Check that the various components of the swivel head have no points of corrosion deeper than 1 mm; in particular, check the sheet metal cover near the roller.

Check the protective cover:

- ☐ It needs to be secured to the body and to the pin of the articulation with split rings and it must not turn.
- ☐ It must be neither deteriorated nor damaged.
- ☐ Press on the protective cover and check that grease comes out.
- ☐ Check that the nut and split pin have not deteriorated.

CHECKING SWIVEL HEAD PLAY

Figure 7



Put the vehicle on the lift or over the pit and do not lift the wheels.

Using a gauge, measure the distance between the body of the swivel head and the end of the pin, making three measurements in the following conditions:

- ☐ wheels straight **measurement X;**
- ☐ wheels turned left **measurement X₁;**
- ☐ wheels turned (fully to the right) **measurement X₂.**

Calculate the play **A** according to the following formula:

$$A = B - X$$

where **B** is the larger of the measurements **X₁** and **X₂**.

This play must be no greater than 2 mm.

If you find the play to be greater or any of the problems listed in the checks, replace the part concerned as described under the relevant section heading.

520610 FRONT AXLE ASSEMBLY OVERHAUL




There follows a description of the operations to overhaul the axle 5876/4 that, unless stated otherwise, hold for the axles 5876/5 - 5876/2 - 5886/5 too.

Using a lift, position and secure the axle assembly on the stand 99322215 for overhaul.

520620 REMOVING - REFITTING WHEEL HUBS

Removal


Figure 8



Remove the brake pliers as described in the "BRAKE AIR SYSTEM" Section.


Turn the wheel hub so that the screw plug (1) goes down, unscrew the plug (1).

Figure 9




Using the reaction lever 99370317 (3), lock the rotation of the wheel hub and, using wrench 99354207 (2), unscrew the oil cover (1). Bleed oil completely.

Figure 10



Undo the screw (4), take out the adjustment nut (3) with the wrench 99388001, extract the washer (2), the outer bearing and remove the wheel hub (1) together with the spacer and internal bearing.

Figure 11




Examine the state of wear of the brake disc (3) as described in the "BRAKE AIR SYSTEM" section.

To remove the brake disc (3), take out the screws (1) and disconnect it from the wheel hub (2).

520621 Replacing wheel hub bearings

Figure 12



40362


Using general tools, remove the following from the wheel hub (1): seal (2), phonic wheel (3) and bearing (4).

Using a specific drift, drive the outer rings of the bearings out of the wheel hub.



Check that the seats of the outer rings of the bearings in the wheel hub are not dented after driving them out.

Figure 13




71553

Using the drift 99374093 (2), under a press, drive the outer ring of the front bearing into the hub without going right down to the bottom. Repeat this operation on the opposite side for the outer ring of the rear bearing.

Complete driving home the outer rings of the bearings manually with the drift 99374093 (2) and grip 99370007 (1).


Figure 14



40363

Lubricate the inner bearing with the oil prescribed for wheel hubs (1) and place it on the wheel hub.


Figure 15



40364

Using the drift 99374132 (1) and grip 99370006 (2), mount the seal (3).

Figure 16




40365

The phonic wheel (1) needs to be mounted after heating it to a temperature of approx. 150°C, checking after assembly that the "phonic" wheel rests on the seat of the hub properly.

Using a dial gauge, check that the inclination of the phonic wheel is no greater than 0.2 mm.

Replacing wheel fixing pins

Figure 17




Using general tools, drive the pins (1) out of the hub (2). Make sure that the surface supporting the heads of the pins has no burrs.

Drive in the pins carefully, apply a load no greater than 2500 kg on their head.

Afterwards, check that the inclination error is no greater than 0.3 mm.

Refitting wheel hubs

Figure 18




Screw tool 99370715 (1) to the steering knuckle pin and lubricate its outer surface with the oil prescribed for wheel hubs. Carefully key the wheel hub (2) onto the kingpin so as not to damage the seal (3, Figure 15).

Fit on the spacer (3), inner ring (4) of the tapered roller bearing. Unscrew the tool 99370715 (1).

Key on the washer (5) and screw down the stop nut (6).


Figure 19



Using the wrench 99388001 (1) tighten the nut (6, Figure 18) to the required torque.

Checking wheel hub bearing end float

Figure 20



Strike the wheel hub axially a few times with a mallet and turn it in both directions to free the rollers of the bearings.

Apply the magnetic base (1) with the dial gauge (2) onto the wheel hub.

Set the pointer of the dial gauge (2) at right angles to the shank of the stub axle (4).

Reset the dial gauge with a pre-load of 1.5-2 mm.

With the aid of a lever, move the wheel hub axially and measure the end float that has to be 0.16 mm (maximum value).




If the end float is not as required, replace the bearing assembly and repeat the check.

Check the required end float, lock the screw (5) holding the adjustment ring nut (3) to the required torque.

Measuring rolling torque

Figure 21



40367

Fit the tool (1) 99395026 onto the pins of the wheel hub and using the torque wrench (2) 99389819 check that the rolling torque of the wheel hub is 5 Nm.




Deposit a sealing bead (Loctite type 574) exclusively on the hub cover ledge surface and protect the threaded part.



Tighten to torque the hub cover (1, Figure 22).

Figure 22




78322

Rotate the wheel hub until when hub cover (1) is positioned as shown in the figure. Restore the prescribed quantity of oil into the hub cover (1) through filling hole (2). Tighten the plug on the hub cover (1) to the set torque.

520635 REMOVING AND REFITTING TRANSVERSE TIE ROD


Figure 23



40370

Straighten out and take off the split pin (1). Free the nut (2) and partly unscrew it so as to prevent the tie rod falling when it is freed.

Figure 24



40371

Using the extractor (1) 99347068, free the swivel head (3) from the lever (2). Repeat this operation on the opposite side; fully unscrew the nuts and disconnect the transverse tie rod.



For refitting, carry out the operations performed for removal in reverse order.



Tighten the nuts fixing the tapered pins to the required torque.




Check that the position of the notches on the nuts coincide with the transverse holes of the tapered pins. If the split pins will not go in, progressively increase the tightening torque of the nuts till they go in properly (angle less than 60°).



520635 REPLACING TRANSVERSE TIE ROD ROD SWIVEL HEADS

Figure 25



Lock the screw (4), loosen the nut (3) and unscrew the articulation (2) from the transverse tie rod (1).



To make it easier to refit the transverse tie rod and then adjust the wheel toe-in, note down the number of turns needed to unscrew each single articulation so as to screw the new ones on with the same number of turns.

Screw the new articulation into the tie rod and lock it in position by tightening the locking nut (3) to the required torque.



The nut (3) has to be tightened with the clamp (5) positioned in one of the set-ups shown in the figure.




Refit the transverse tie rod.



Check and if necessary adjust the toe-in of the front wheels as described under the section heading "Wheel Geometry".

520631 LONGITUDINAL TIE ROD LEVER REMOVAL/REFITTING


Figure 26



Using wrench 99388002 (1, Figure 27) unscrew the screws (2) and remove the lever (1). To refit it, carry out the operations in reverse order, locking the fixing screws to the required torque.

520632 CROSS TIE ROD LEVER REMOVAL/REFITTING

Figure 27




Using wrench 99388002 (1), unscrew the screws (2) and remove the lever (1). To refit it, carry out the operations in reverse order, locking the screws to the required torque.

520611 REMOVING AND REFITTING PIN FOR STUB AXLE


Removal

Figure 28



Undo the screws (2) and detach the mount (1).

Figure 29




For axles 5876/4 – 5876/2 only

Using specific pliers (1) take out the retaining ring (2) and remove the cover (3) with the grease nipple.

For axles 5876/5 - 5886/5 only

Take out the screws (4) and remove the top cover (5) and seal (6).


Figure 30



36421

Undo the screws (4) and remove the bottom cover (3), adjustment plates (2) and fifth wheel (1).

Figure 31




36422

Using the tool 99347047 (1) and part (2), free the kingpin (3); remove the tool and take out the pin.

520615 Replacing kingpin bearing

Figure 32



60887

The kingpin bearings (5) are replaced by using parts (1-2-3) of drift 99374530 and grip 99370007 (4) to disassemble and assemble them.




The parts mentioned in the following text are shown in Figure 32.

Use part (1) and grip (4) to remove the seal (8) and roller bearings (6-7) on the top side.

Use part (3) and grip (4) to remove the seal (9) and roller bearings (10-11) on the bottom side.

Figure 33



60889


Fitting roller bearing (7): use parts (1 and 2) and grip (4).

Fitting roller bearing (6): use part (2) and grip (4).

Fitting roller bearing (8): use parts (3 and 2) and grip (4).

Fitting roller bearing (9): use part (2) and grip (4).

Figure 34




60890

Using the drift 99374173 (4) and grip 99370007 (3), fit the seals (2 and 5) in the stub axle (1).



Before driving in the pin, you need to make sure the tapered seat on the axle and the surface of the pin are thoroughly clean and dry to avoid films of oil that would make it easier for the pin to turn in its seat while driving it home.


Figure 35



Position the stub axle (2) on the axle (1) and insert the pin into its seat. Fit the tool 99374405 (3) onto the stub axle and secure it with the same fixing screws as the bottom cover, locking them to an adequate torque.

Drive the pin into the tapered seat of the axle, screwing down the pressure screw (4) to a torque of 15 to 16 daNm. Remove the tool 99374505 (3) from the stub axle.


Figure 36



Lubricate the fifth wheel (1) with TUTELA MR2 grease. Position the bottom cover (3) together with the fifth wheel (1) and adjustment shims (2). Tighten the fixing screws (4) to the required torque.

Repeat the same operations for the opposite stub axle.

Figure 37



For axles 5876/4 – 5876/2 only


Insert the top cover (2) in its seat together with the relevant gasket. Position the grease nipple (3) as shown in the figure; then, insert the retaining ring (1) making sure the ring expands correctly.

For axles 5876/5 -5886/5 only

Fit the top cover (5) with a new seal (6) and tighten the fixing screw (4) to the required torque.


Checking and adjusting clearance between stub axle and axle

Figure 38



Lift the stub axle to bring it into contact with the bottom shim adjustment of the axle and, using a feeler gauge (1), check the clearance between the top shim adjustment of the stub axle and the axle that needs to be between 0.10 and 0.35 mm.

Figure 39




Check the clearance between the top shim adjustment of the stub axle and the axle. Check with a feeler gauge (1) that there is a gap between the bottom shim adjustment of the stub axle and that of the axle of no less than 0.25 mm.

520618 CHECKING AND MEASURING THE AXLE BODY


Checking levelness of leaf spring supporting surfaces with respect to the holes for the kingpins

Figure 40



Fit the two rods (1) with the cones (3) into the kingpin holes. Press on the cones and lock them in position with the screws on the rods. Insert the two centring grub screws (2) into the seats of the leaf spring supporting surface (4).

Figure 41



Fit the sliding bar (2) on the rods (4) of the goniometers, adjusting the length so that the shaped ends are inserted in contact with the rods (1).


Lock the screw of the clamp (7) and the screws (3) fixing the goniometers to the rods (4).

Fit the bases (5) with goniometers on the surfaces (6), inserting them in the centring grub screws.



Before fitting the bases with goniometers, check that the supporting surfaces have no sign of paint or roughness.

Figure 42




Check the angle of deformation, if any, on the graduated sectors of the goniometers shown by the arrows. Clearly, the pointers of the goniometers detect no angular movement when the levelness of the supporting surfaces of

the leaf springs with respect to the holes of the kingpins is correct.

Remove the sliding bar and the bases with goniometers used for the test.


Checking angle of holes for kingpins

Figure 43



Fit the mounts (3) with goniometers onto the rods (1) and screw down the screws (2) without locking them. Insert the transverse tie rod (4) and fully screw down the screws (2) fixing the mounts in contact with the rods (1).

Figure 44



Read off the angle of the holes for kingpins on the relevant graduated sectors (2), shown by the pointers (1).

The angle of the holes for kingpins has to be $7^{\circ} \pm 0^{\circ}3'$.

**Rigid rear added axle
55080/DI (N 8071)**

	Page
DESCRIPTION	33
CHARACTERISTICS AND DATA	34
TIGHTENING TORQUE	35
TOOLS	36
REMOVING-REFITTING	38
☐ Removal	38
☐ Refitting	39
REPAIRS	39

DESCRIPTION


The front axle is a steel structure with a tubular cross-section at the end of which the wheel hubs are keyed.

The wheel hubs are supported by two tapered roller bearings, set right, lubricated with oil.

The bearings need no adjustment; their end float is obtained by tightening the retaining ring nut to torque.

The disc brake is the "KNORR" type. The brake calliper is mounted on the axle with an angle of 57°.





Figure 1




72781

VIEW OF FRONT AXLE 55080/DI


CHARACTERISTICS AND DATA

	Axle type	Rigid, 8 tonnes, can be lifted, with single wheels 55080/DI (N 8071)
	WHEEL HUBS	
	Wheel hub bearings	2 with tapered rollers
	Hub bearing axle clearance mm	max 0.16
	Wheel hub clearance	by tightening retaining ring nut to torque
	Bearing pre-load rolling torque daNm	max 0.50
	Oil for wheel hub bearings Quantity of oil per hub Litres	Tutela TRUCK FE-AXLE 0.35 (0.32 kg)
G.A.W. permissible maximum capacity kg		8000


TIGHTENING TORQUE**Figure 2**

84542


PART		TORQUE	
		Nm	(kgm)
1	Wheel fixing nut	600 $\begin{smallmatrix} +50 \\ -20 \end{smallmatrix}$	$\left(60 \begin{smallmatrix} +5 \\ -2 \end{smallmatrix} \right)$
2	Hex screw fixing brake disc to wheel hub	281.5 ± 13.5	(28.1 ± 1.3)
3	Ring nut fixing wheel bearings	515 ± 30	(51.5 ± 3)
4	Tapered threaded plug for wheel hub cover	57.5 ± 7.5	(5.8 ± 0.7)
5	Cover for wheel hub	130 ± 10	(13.3 ± 1)
6	Screw fixing nut (3)	27.5	(2.75)
7	Screw fixing brake calliper mount	275 to 304	(27.5 to 30.4)
8	Screw fixing brake calliper	615 ± 61	(61.5 ± 6.1)

TOOLS**TOOL NO.****DESCRIPTION****99321024**


Hydraulic jack for wheel removal and refitting

99322215


Overhauling stand

99354207


Wrench for wheel hub cover

99370006







Handle for interchangeable beaters


99370007

Handle for interchangeable beaters

99370317

Reaction lever with extension to retain flanges

TOOLS		
TOOL NO.		DESCRIPTION
99370715		Guide for mounting wheel hub
99374093		Beater to fit back bearing outer races (91-134) (to be used with 99370007)
99374132		Installer to fit back wheel hub internal gasket (to be used with 99370006)
99388001		Wrench (80 mm) for wheel hub bearing adjustment nut
99389819		Torque wrench (0 -10 Nm) with square socket 1/4"
99395026		Tool for testing hubs rolling torque (to be used with torque wrench)

520710 REMOVING-REFITTING**Figure 3**


38011

Removal

Place vehicle on flat ground and chock front wheels.
 Loosen rear wheel retaining bolts.
 Use hydraulic jack to raise vehicle at rear and support by resting rear axle on stands.
 Unscrew wheel retaining bolts and remove wheels using hydraulic trolley 99321024.
 Support additional rear axle using stand 99370628 and hydraulic lift.

Remove jointed mount (5) of additional axle wishbone.
 Remove nut (3) and take out bolt.
 Disconnect stabiliser bar (1) and turn so that it does not foul during removal of vehicle axle.
 Remove wishbone (2).

Figure 4



38012

Disconnect: the air delivery pipes (5) from the diaphragm brake cylinders (4), the electric cable (3) for the brake lining wear indicator.

Remove the nut (8) and take out the bottom fixing screw of the shock absorber (7).

Remove the nuts (2) fixing the air springs (1) to the axle.

Lower the hydraulic jack and take the axle (6) out from under the vehicle.

Refitting

Reverse operations described for removal to refit. Tighten bolts and/or nuts to specified torque.

After fitting, check that:

- ☐ There is no air leakage from the air pipes.
- ☐ The lubricating oil in the wheel hubs is at the right level.

REPAIRS

The wheel hub overhaul procedure is similar to the one described for the axle 5876/4 (F 8021) to which you should refer.

The adjustment data, tightening torques and equipment are as stated in this section.

**Rigid rear added axle
55080/TI (N 8071)**

	Page
DESCRIPTION	43
CHARACTERISTICS AND DATA	44
TIGHTENING TORQUE	45
TOOLS	46
REMOVING-REFITTING WHEEL HUBS	48
☐ Removal	48
☐ Replacing wheel hub bearings	49
☐ Replacing wheel fixing pins	50
☐ Refitting wheel hubs	50

DESCRIPTION


The front axle is a steel structure with a tubular cross-section at the end of which the wheel hubs are keyed.

The wheel hubs are supported by two tapered roller bearings, set right, lubricated with oil.

The bearings need no adjustment; their end float is obtained by tightening the retaining ring nut to torque.

The drum brake is the "Perrott" type.





Figure 1




77481

VIEW OF FRONT AXLE 55080/DI

CHARACTERISTICS AND DATA

	Axle type	Rigid, 8 tonnes, can be lifted, with single wheels 55080/DI (N 8071)
	WHEEL HUBS	
	Wheel hub bearings	2 with tapered rollers
	Hub bearing axle clearance mm	max 0.16
	Wheel hub clearance	by tightening retaining ring nut to torque
	Bearing pre-load rolling torque daNm	max 0.50
	Oil for wheel hub bearings Quantity of oil per hub Litres (kg)	Tutela W 140/M DA 0.35 (0.31)
G.A.W. permissible maximum capacity kg		8000







TIGHTENING TORQUES**Figure 2**






84543

PART	TORQUE	
	Nm	(kgm)
1 Wheel securing nut	600 $^{+50}_{-20}$	(60 $^{+5}_{-2}$)
2 Wheel bearing securing ring nut	133.5 $\pm$ 13.5	(13 $\pm$ 1.3)
3 Plug for wheel hub cover	57.5 $\pm$ 25	5.8 $\pm$ 0.2
4 Cover for wheel hub *	130 $\pm$ 10	(13 $\pm$ 10)
5 Nut (2) fastening screw	27.5	(2.75)

* Apply Loctite 574 on the wheel hub/cover contact surface

TOOLS

TOOL NO.	DESCRIPTION	
99321024		Hydraulic truck to remove and fit back the wheels
99322215		Stand for overhauling
99354207		Wrench for wheel hub cup
99370006		Handle for interchangeable beaters
99370007		Handle for interchangeable beaters
99370715		Guide for mounting wheel hub

TOOLS	
TOOL NO.	DESCRIPTION
99374093	 Beater to fit back bearing outer races (to be used with 99370007)
99374132	 Installer to fit back wheel hub internal gasket (to be used with 99370006)
99388001	 Wrench (80 mm) for wheel hub bearing adjustment nut
99389819	 Torque wrench (0 - 10 Nm) with square socket 1/4"
99395026	 Tool for testing hubs rolling torque (to be used with torque wrench)


520620 REMOVING - REFITTING WHEEL HUBS



The wheel hub removal/refitting was carried out on a steering axle, but it is valid also for the additional axle 55080/TI because the procedure is very similar.

Removal


Figure 3



84544

Turn the wheel hub so that the screw plug (1) goes down, unscrew the plug (1).


Figure 4



40539

Using the reaction lever 99370317 (2), block rotation of the wheel hub and, using the wrench 99354207 (3), unscrew the oil cover (4) and drain off all the oil. Remove the screws (1) fixing the drum to the wheel hub.


Figure 5



40360

Insert the two screws (1) into the drum. Progressively screw them down in order to extract the drum from the wheel hub.

Figure 6




40361

Loosen the screw (1), take out the adjustment nut (2) with the wrench 99388001, extract the washer (3), the outer bearing (4) and remove the wheel hub together with the spacer and internal bearing.

520621 Replacing wheel hub bearings

Figure 7



40362


Using general tools, remove the following from the wheel hub (1): seal (2), phonic wheel (3) and bearing (4).

Using a specific drift, drive the outer rings of the bearings out of the wheel hub.



Check that the seats of the outer rings of the bearings in the wheel hub are not dented after driving them out.

Figure 8




71553

Using the drift 99374093 (2), under a press, drive the outer ring of the front bearing into the hub without going right down to the bottom. Repeat this operation on the opposite side for the outer ring of the rear bearing.

Complete driving home the outer rings of the bearings manually with the drift 99374093 (2) and grip 99370007 (1).


Figure 9



40363

Lubricate the inside bearing (1) with the oil prescribed for the wheel hubs and place it in the seat of the wheel hub.


Figure 10



40364

Using the drift 99374132 (1) and grip 99370006 (2), mount the seal (3).

Figure 11




40365

The phonic wheel (1) needs to be mounted after heating it to a temperature of approx. 150°C, checking after assembly that the "phonic" wheel rests on the seat of the hub properly.

Replacing wheel fixing pins


Figure 12



Using general tools, drive the pins (1) out of the hub (2). Make sure that the surface supporting the heads of the pins has no burrs. Drive in the pins carefully, apply a load no greater than 2500 kg on their head. Afterwards, check that the inclination error is no greater than 0.3 mm.

Refitting wheel hubs


Figure 13



Screw the tool 99370715 onto the kingpin and lubricate the outer surface of the kingpin with TUTELA W140/M-DA oil. Carefully key the wheel hub (2) onto the kingpin so as not to damage the seal. Fit on the spacer (3), inner ring (4) of the tapered roller bearing. Unscrew the tool 99370715 (1).

Key on the washer (5) and screw down the stop nut (6). Using the wrench 99388001 and a torque wrench, tighten the nut (6) to the required torque. Check the end float as described for axle 5876/4 and tighten the screw (7) to the required torque.

Figure 14



Fit the drum brake (1) onto the wheel hub (2). Screw down the fixing screws (3) and tighten to the required torque. Measure the rolling torque as described for axles 5876/4/5/2 - 5886/5.




Deposit a sealing bead (Loctite type 574) exclusively on the hub cover ledge surface and protect the threaded part.



Tighten to torque the hub cover (1, Figure 15).

Figure 15



Rotate the wheel hub until when hub cover (1) is positioned as shown in the figure. Restore the prescribed quantity of oil into the hub cover (1) through filling hole (2). Tighten the plug on the hub cover (1) to the set torque.

**Rigid rear added axle
with hydraulic lifting
56082/DI (N 9171)**

	Page
DESCRIPTION	53
CHARACTERISTICS AND DATA	54
TIGHTENING TORQUE	55
TOOLS	56
REMOVING-REFITTING	57
REPAIRS	57

DESCRIPTION


The front axle is a steel structure with a tubular cross-section at the end of which the wheel hubs are keyed.

The wheel hubs are supported by two tapered roller bearings, the Unit Bearing type with permanent lubrication.

The bearings need no adjustment; their end float is obtained by tightening the retaining ring nut to torque.

The disc brake is the "KNORR" type. The brake calliper is mounted on the axle with an angle of 57° .

Figure I



72783

VIEW OF FRONT AXLE 56082/DI

CHARACTERISTICS AND DATA




	Axle type	Rigid, 10 tonnes, can be lifted, with twin wheels 56082/1 (N 9171)
	WHEEL HUBS	
	Wheel hub bearings	2, Unit-Bearing type
	Hub bearing axle clearance mm	max 0.16
	Wheel hub clearance	by tightening retaining ring nut to torque
	Oil for wheel hub bearings	Tutela TRUCK FE-AXLE
	Quantity of oil per hub Litres	0.35 (0.32 kg)
	G.A.W. permissible maximum capacity kg	10,000

Figure 2



72784

TIGHTENING TORQUE

PART	TORQUE	
	Nm	kgm
1 Wheel fixing nut	600 $\begin{smallmatrix} +50 \\ -20 \end{smallmatrix}$	$\left(60 \begin{smallmatrix} +5 \\ -2 \end{smallmatrix} \right)$
2 Screw fixing drive shaft flange ●	80 to 100	8 to 10
3 Ring nut retaining wheel hub bearing	834 to 1030	83.4 to 103
4 Screw fixing brake disc to wheel hub	268 to 295	26.8 to 29.5
5 Nut for screw fixing brake calliper to mount	554 to 677	55.4 to 67.7
6 Nut for screw fixing brake calliper mount	275 to 304	27.5 to 30.4






✱ Spread with sealant type IVECO I 905685 (LOCTITE I 4780)

● Apply LOCTITE 243 sealant on the thread





A = TIMKEN bearing

B = SKF bearing

TOOLS

TOOL NO.	DESCRIPTION	
99321024		Hydraulic trolley to remove and refit wheels
99322215		Stand for overhauling
99341003		Single-acting lift
99341017		Pair of brackets with holes
99345053		Reaction block for puller tools
99355180		Wrench (105 mm) for wheel hub bearing adjustment nut

TOOLS

TOOL NO.	DESCRIPTION	
99370700		Guide to assemble wheel hub
99370706		Tool to fit wheel hub bearing
99370708		Tool to drive out wheel hub bearing
99389816		4 x torque multiplier, with square connection, 3/4" in, 1" out (maximum torque 2745 Nm).
99389818		Dynamometric wrench (150 - 800 Nm) with square 3/4" coupling

REMOVING-REFITTING

By analogy, follow the descriptions already given for the rear added axle type 55080 (N 8071).

REPAIRS

The wheel hub overhaul procedure is very similar to that described for rear axle MS 13-175 with disc brakes, that you are strongly recommended to observe.

The adjusting values, the tightening torques and the tools used are those shown in the section.

For the hydraulic component operation description and data refer to what described for axle 56082/DI.

Rigid rear added axle with hydraulic lifting 56082/TI (N 9171)

	Page
DESCRIPTION	61
CHARACTERISTICS AND DATA	62
TIGHTENING TORQUE	63
TOOLS	64
REMOVING-REFITTING	65
REPAIR OPERATIONS	65
VEHICLES WITH MECHANICAL SUSPENSION AND HYDRAULIC LIFTING	66
☐ Location of main system components	66
☐ Hydraulic system circuit diagram	67
FAULT DIAGNOSIS	68
SPECIFICATIONS	70
ELECTRO-HYDRAULIC PUMP	71
☐ Removal	71
☐ Refitting	71
LIFTING CYLINDERS (VEHICLES WITH MECHANICAL SUSPENSION)	72
☐ Removal	72
☐ Refitting	72

DESCRIPTION


The front axle is a steel structure with a tubular cross-section at the end of which the wheel hubs are keyed.

The wheel hubs are supported by two tapered roller bearings, the Unit Bearing type with permanent lubrication.

The bearings need no adjustment; their end float is obtained by tightening the retaining ring nut to torque.

The drum brake is the "Perrott" type.




Figure 1



84545


VIEW OF FRONT AXLE 56082/TI

CHARACTERISTICS AND DATA

	Axle type	Rigid, 10 tonnes, can be lifted, with twin wheels 56082/TI N 9171
	WHEEL HUBS	
	Wheel hub bearings	2, taper rollers
	Wheel hub bearing end play mm	max 0.16
	Wheel hub clearance	adjusted through retaining ring nut torque tightening
	Oil for wheel hub bearings Quantity for each wheel hub	Tutela W 140/M DA 0.35 (0.32 kg)
G.A.W. permissible maximum capacity kg		10.000

TIGHTENING TORQUE

Figure 2



84546

PART	TORQUE	
	Nm	(kgm)
1 Half-shaft fastening screw to wheel hub M 16x3	80 to 100	(8 to 10)
2 Wheel hub bearing retaining ring nut	834 to 1030	(83.4 ± 103)
3 Wheel fastening nut	600 ⁺⁵⁰ / ₋₂₀	(60 ⁺⁵ / ₋₂)
4 Nut for brake support fastening screw	275.5 to 304	(28 to 31)






- Apply LOCTITE 243 sealant on the thread

A = TIMKEN bearing





B = SKF bearing

* Spread with sealant type IVECO I905685 (LOCTITE I4780)

TOOLS

TOOL NO.	DESCRIPTION	
99321024		Hydraulic trolley to remove and refit wheels
99322215		Stand for overhauling
99341003		Single-acting lift
99341017		Pair of brackets with holes
99345053		Reaction block for puller tools
99355180		Wrench (105 mm) for wheel hub bearing adjustment nut

TOOLS

TOOL NO.	DESCRIPTION	
99370700		Guide to assemble wheel hub
99370706		Tool to fit wheel hub bearing
99370708		Tool to drive out wheel hub bearing
99389816		4 x torque multiplier, with square connection, 3/4" in, 1" out (maximum torque 2745 Nm).
99389818		Torque wrench (150 - 800 Nm) with 1/4" square fitting.


REMOVING-REFITTING

By analogy, follow the descriptions already given for the rear added axle type 55080 (N 8071).

REPAIR OPERATIONS

The wheel hub overhaul procedure is very similar to that described for rear axle MS 13-175 with drum brakes, that you are strongly recommended to observe.

The adjustment data, tightening torques and tools are the ones given in this section.


VEHICLES WITH MECHANICAL SUSPENSION AND HYDRAULIC LIFTING**Location of main system components****Figure 3**

51473

1. ELECTRO-HYDRAULIC PUMP - 2. LIFTING CYLINDERS

Hydraulic system circuit diagram

Figure 4




1. HYDRAULIC CYLINDERS - 2. PRESSURE SWITCH (closing pressure 30 bar) - 3. PRESSURE SWITCH (opening pressure 30 bar) - A. SOLENOID VALVE - B. SOLENOID VALVE - C. SAFETY VALVE (200 + 10 bar) - D. PRESSURE SWITCH (opening pressure 175 bar) - E. CHECK VALVE - F. HYDRAULIC PUMP - G. OIL FILTER - H. OIL RESERVOIR - I. ELECTRIC MOTOR.

51474

FAULT DIAGNOSIS

Main malfunctions of the auxiliary rear axle with hydraulic lifting:

1. The 3rd axle fails to lift or fails to lower.
2. No automatic lowering of 3rd axle when load exceeds 11.5 tonnes and no pull-away assist function.



(continued overleaf)

No tachometer consensus.

- YES →

- ☐ Check the tachometer 5a fuse.
- ☐ Check the tachometer grounding point.
- ☐ Change the tachometer.

2

**NO AUTOMATIC LOWERING
OF 3RD AXLE WHEN LOAD EXCEEDS
11.5 TONNES AND NO
PULL-AWAY ASSIST FUNCTION**






Malfunction of electro-hydraulic pump.

- NO →

Replace electro-hydraulic pump.

SPECIFICATIONS

Electro-hydraulic pump (mechanical suspension)  60185	Power supply Maximum pressure Nominal reservoir capacity	24 V 210 ± 10 bar 3 L
Lifting cylinder (mechanical suspension)  40454	Nominal pressure Stroke length	180 bar 290 ± 1.5 mm
Lifting system hydraulic fluid Tutela GI/A	Quantity of fluid required for lifting system for vehicles with mechanical suspension	5.5 L

52760 ELECTRO-HYDRAULIC PUMP**Removal****Figure 5**

51480

Disconnect the electrical connections (⇒).

Disconnect pipes (2), draining the fluid contained in the pipes.

Undo the retaining bolts and remove the electro-hydraulic pump unit (1) complete with reservoir.

Refitting


Refitting is the reverse of removal. Adhere to specified torque values.



Fill the fluid reservoir up to the correct level.

520751 LIFTING CYLINDERS (VEHICLES WITH MECHANICAL SUSPENSION) Removal

Figure 6



51481

Check that the 3rd axle is lowered.

Disconnect pipes (1) from cylinders (2), draining the fluid from the pipes.

Unscrew the nut and remove pin (3).

Perform the above operations on both cylinders.

Refitting



Refitting is the reverse of removal. Adhere to specified torque values.



Fill the fluid reservoir up to the correct level.

Steering rear added axle 57080/DI (N 8072)

	Page
DESCRIPTION	75
CHARACTERISTICS AND DATA	76
TIGHTENING TORQUES	78
TOOLS	79
REPAIRS	83
PNEUMATIC LIFT	83
GENERAL	83
LOCATION ON THE VEHICLE OF THE MAIN COMPONENTS OF THE HYDRAULIC SYSTEM	84
HYDRAULIC SYSTEM	85
HYDRAULIC SYSTEM WORKING DIAGRAM .	86
VEHICLES WITH PNEUMATIC REAR SUSPENSIONS AND PNEUMATIC LIFTING	87
☐ Location on the vehicle of the main components . .	87
☐ Pneumatic working diagram, rear air suspensions and air lift for added axles with single wheels .	88
FAULT DIAGNOSIS	88
TIGHTENING TORQUES (Steering and lifting device linkage)	92
CHARACTERISTICS AND DATA	93
☐ Steering and third axle hydraulic system	93
MAIN HYDRAULIC SYSTEM COMPONENTS .	94
HYDRAULIC ACCUMULATOR	94
☐ Nitrogen pressure checking and recharging . .	94
OPERATOR CYLINDER	94
☐ Disassembly	95

Page

☐ Assembly	95
☐ Checking cylinder oil sealing on the vehicle	95
CENTRING CYLINDER	95
☐ Disassembly	96
☐ Assembly	96
☐ Checking cylinder oil sealing on the vehicle	96
ADDITIONAL AXLE PNEUMATIC LIFTING DEVICE REMOVAL AND REFITTING	97
☐ Removal	97
☐ Refitting	97
AIR BLEEDING FROM THE HYDRAULIC CIRCUIT	98
☐ Filling up and bleeding the power steering hydraulic circuit (circuit 1)	99
☐ Filling up and bleeding the power steering hydraulic circuit (circuit 2)	99

DESCRIPTION

The front axle is a steel structure with a tubular cross-section at the end of which the stub axles are articulated.


The stub axle articulation is made with tapered pins integral with the axle body and by means of four bearings with rollers driven in with interference in the holes of the stub axle overhangs.

The wheel hubs are supported by two tapered roller bearings, set right, lubricated with oil, mounted on the shank of the stub axle.

The bearings need no adjustment; their end float is obtained by tightening the retaining ring nut to torque.

The disc brake is the "KNORR" type. The brake calliper is mounted on the axle with an angle of 57°.









Figure 1











72785

VIEW OF STEERING REAR AXLE 57080/DI


CHARACTERISTICS AND DATA

	Type of axle		Steering liftable single wheels
	STUB AXLE PINS		
	Inclination of kingpin		7°
	Diameter of roller bearing housings on the stub axle: - upper housing Ø 1 mm - lower housing Ø 2 mm		51.967 to 51.986 59.967 to 59.986
	Outside diameter of roller bearings for stub axle: - upper bearings Ø 3 mm - lower bearings Ø 4 mm		52 60
	Stub axle bearings	mm	0.014 to 0.033
	Inside diameter of roller bearings for stub axle: - upper bearings Ø 5 mm - lower bearings Ø 6 mm		43 53
	Diameter of king pin - top end Ø 7 mm - bottom end Ø 8 mm		42.984 to 43.000 52.981 to 53.000
	Upper bearings/pin	mm	0 to 0.016
	Lower bearings/pin	mm	0 to 0.019
	Play between axle and upper facing of stub axle X1 mm		0.10 to 0.15
	Clearance between axle and lower facing of stub axle X2 mm		0.25

 Shims to adjust X1, X2 0.25 mm S mm	0.25 to 1.75	
 WHEEL HUBS		
 Wheel hub bearings	2, taper rollers	
 Wheel hub bearing end play mm	max 0.16	
 Wheel hub play adjustment	by tightening retaining ring nut to torque	
 Rolling torque Bearing preloading daNm	0.50	
 Oil for wheel hub bearings Litre	Tutela TRUCK FE-AXLE 0.33 (0.30 kg)	
 WHEEL GEOMETRY		
 Wheel camber (vehicle with static load)	1°	
 Wheel caster (vehicle with static load)	0°	
 Wheel toe-in (vehicle unladen) mm	LEFT WHEEL 0	RIGHT WHEEL - 2
Adjustment tolerance mm	± 0.75	
Check tolerance mm	± 2	
 Steering angle: Inner α Outer β	20° 13°	
Axle weight kg	-	
Maximum capacity (GRW) kg	8000	

TIGHTENING TORQUES

Figure 2









84547







PART	TORQUE	
	Nm	(kgm)
1 Flanged screw fixing transverse tie rod lever onto stub axle	1325 ± 75	(135 ± 7.6)
2 Flanged screw fixing longitudinal lever onto stub axle	1325 ± 75	(135 ± 7.6)
3 Castellated nut for kingpin	300 *	30 *
4 Flanged hex screw fixing bottom fifth wheel cover onto stub axle	117 ± 6	(11.7 ± 0.6)
5 Self-locking hex screw M20x1.5 fixing brake callipers	615.5 ± 61.5	(61.5 ± 6.1)
6 Nut fixing wheels	665.5 ± 66.5	(66.6 ± 6.6)
7 Hex screw fixing brake disc to wheel hub	281.5 ± 13.5	(28.1 ± 1.5)
8 Self-locking hex screw M16x1.5 fixing brake calliper mount to stub axle	313.5 ± 15.5	(31.35 ± 15.5)
9 Ring nut fixing wheel bearing	515.5 ± 24.5	(51.5 ± 2.4)
10 Threaded plug for wheel hub cover	57.5 ± 7.5	(5.8 ± 0.2)
11 Cylindrical screw with recessed hex locking ring nut adjusting wheel bearings	27.5 ± 2.5	(2.7 ± 0.2)
12 Cover for wheel hub •	130 ± 10	(132 ± 0.1)







* Minimum torque – peak torque, tighten to the first cut coinciding with the hole for the split pin

• Apply Loctite 574 on the wheel hub/cover contact surface






TOOLS	
TOOL NO.	DESCRIPTION
99305354 	Wheel geometry portable optical testing equipment
99305446 	Hand pump for filling and bleeding hydraulic system
99305450 	Set of couplings (2) for hydraulic pump 99305446
99321024 	Hydraulic truck to remove and fit back the wheels
99322215 	Overhauling stand
99347047 	Puller for king pin

TOOLS

TOOL NO.	DESCRIPTION	
99347068		Puller for steering rod ball joints
99354207		Wrench for wheel hub cap
99366918		Equipment for hydraulic accumulator check and charging
99370006		Handle for interchangeable beaters
99370007		Handle for interchangeable beaters
99370317		Reaction lever with extension to retain flanges

TOOLS		
TOOL NO.		DESCRIPTION
99370628		Stand for axle removal and installation
99370715		Guide for fitting wheel hub
99374093		Beater to fit back bearing outer races (to be used with 99370007)
99374132		Installer to fit back wheel hub internal gasket (to be used with 99370006)
99374173		Elements to fit kingpin gasket (to be used with 99370007)
99374405		Tool to fit kingpin

TOOLS


TOOL NO.	DESCRIPTION
99374530	 Drift to remove and refit kingpin bearings (use with 99370007)
99388001	 Wrench (80 mm) for wheel hub bearing adjustment ring nut
99388002	 Wrench for screws fastening the track rod arm and the drag link arm to the stub axle
99389819	 Torque wrench (0-10 Nm) with 1/4" square fitting
99395026	 Tool for testing hubs rolling torque (to be used with torque wrench)

REPAIRS

Keep to the procedure described in the chapter AXLE 55080/D as for wheel hub overhauling. Adjustment data, tightening torques and tools are the one shown in this chapter.

PNEUMATIC LIFT GENERAL

Figure 3



73040

This system enables the driver to lift the additional axle when the vehicle operating conditions require it and to move the load to the driving axle during pickup in condition of poor grip of the vehicle (assistance during pickup).

All the above operations, however, are bound to specific conditions of operation and relevant system safety connected to it.

Lifting, lowering and assistance during pickup are controlled from a button strip in the cabin, located on the central dashboard.

Axle lifting prevents tire sliding on ground, during vehicle manoeuvres.

The device for assistance during pickup allows to totally or partially transfer the load on the additional axle to the driving axle so that, in the above describe grip conditions and in compliance with local laws, friction on the ground is increased.


The functions of lifting and aid in the pickup phase can be performed at speeds under 30 km/h with a load on the driving axle of under 11.5 tonnes, otherwise the system will automatically lower the added axle.

In order to ensure a greater safety during straight running, rear axle steering starts when the wheels of the front axle have exceeded a steering angle of 5° only.

The transmission of steering power from the front axle to the additional rear axle is hydrostatic, thanks to a slave cylinder fitted on the front and to a centring cylinder fitted on the additional rear axle. A hydraulic accumulator stores and keeps the oil in the system, depending on the centring cylinder movements, without volume losses.

LOCATION ON THE VEHICLE OF THE MAIN COMPONENTS OF THE HYDRAULIC SYSTEM

Figure 4





84548

1. Lamp - 2. Oil tank - 3. Oil pump - 4. Hydraulic accumulator - 5. Pressure gauge - 6. Centring cylinder - 7. Pressure control intakes - 8. Slave cylinder - 9. Power steering system

HYDRAULIC SYSTEM**Figure 5**

(Illustrative)




HYDRAULIC SYSTEM WORKING DIAGRAM**Figure 6**

1. Oil tank with low oil level switch - 2. Hydraulic pump - 3. Centring cylinder - 4. Pressure gauge (2 bar) - 5. Hydraulic accumulator - 6. Slave cylinder - 7. Power steering system - V. Cap

VEHICLES WITH PNEUMATIC REAR SUSPENSIONS AND PNEUMATIC LIFTING


Location on the vehicle of the main components

Figure 7



1. Electropneumatic distributor - 2. Level sensor - 3. Rear axle air spring - 4. Pressure sensor - 5. Sensor pressure -
6. Air spring for additional axle lifting - 7. Additional axle air spring - 8. Check valve - 9. Pressure sensor

73043

Pneumatic working diagram, rear air suspensions and air lift for added axles with single wheels**Figure 8**

60909

1. Light indicator (air spring suspension low pressure) - 2. Pressure gauge (opening pressure 8 bar) - 3. Check valve - 4. Pressure control intake - 5. Axle electropneumatic distributor - 6. Rear axle air spring - 7. Axle suspension pressure gauge - 8. Air spring for additional rear axle - 9. Pressure gauge for additional rear axle suspension - 10. Check valve* - 11. Pressure gauge for additional rear axle lift - 12. Air spring for additional rear axle lift - 13. Level sensor - 14. Controlled pressure valve - 15. Manual condense bleeder - 16. 30 litres air tank


* Both must be fitted on the vehicle with connection 1 downward.

FAULT DIAGNOSIS


Main operating faults of the additional steering rear axle:

1. Partial or total reduction of the third axle steering.
2. Total or partial lack of realignment of the third axle.
3. Irregular wear of the third axle tyres.

4. Power steering system oil lamp lighted.
5. Third axle hydraulic system low oil pressure lamp lighted.
6. Third axle hydraulic system low oil pressure lamp off in presence of fault.
7. The third axle does not lift or lower or does not assist at pickup.



(continue)



5

**THIRD AXLE HYDRAULIC
SYSTEM LOW OIL PRESSURE
LAMP LIGHTED**

Third axle circuit oil low pressure

- YES →

Refill the system

NO



Pressure gauge irregular operation

- YES →

Check wiring and replace the pressure gauge if necessary

NO



Oil leakage inside the rear cylinder

- YES →

Replace the rear cylinder

6

**THIRD AXLE HYDRAULIC
SYSTEM LOW OIL PRESSURE
LAMP OFF IN PRESENCE OF FAULT**Lamp burnt
(Check with "lamp test")

- YES →

Replace the lamp

NO



Transmitter irregular operation

- YES →

Replace the transmitter

NO



Wiring irregular operation

- YES →

Check wiring and replace faulty components

7

**THE THIRD AXLE DOES NOT LIFT
OR LOWER OR DOES NOT ASSIST
AT PICKUP**


Leakage or breaking in the hydraulic system piping

- YES →

Close or replace loosened or damaged connections.
Replace broken or damaged pipes

NO



Lift air spring damaged

- YES →

Replace air spring

NO



Fault of mechanical components

- YES →

Replace faulty mechanical components

NO



Fault on the electric system





- YES →

- ☐ Fault memory reading
- ☐ Pressure sensor parameter reading
- ☐ Check the wiring
- ☐ Replace faulty components

TIGHTENING TORQUES (Steering and lifting device linkage)

PART	TORQUE	
	Nm	(kgm)
Nut fastening slave cylinder and centring cylinder ball joint	300	(30)
Steering linkage castellated nut	250	(25)
Nut for screw fastening air spring	92 ± 9	(9.2 ± 0.9)
Nut fastening spring supporting sheet to chassis	146.5 ± 14.5	(14.7 ± 1.5)
Nut for screw fastening rear axle support	92 ± 9	(9.2 ± 0.9)
Nut for screw fastening plate to support	92 ± 9	(9.2 ± 0.9)


CHARACTERISTICS AND DATA**Steering and third axle hydraulic system**

Power steering system 	Ball-circulation ZF 8098 with built-in pressure relief valve	
	Operating pressure variable	150 + 15 bar
	steering centre Reduction ratio variable maximum steering	22.2:1 26.2:1
Power steering pump 	Type	ZF
	Minimum no. of revolutions rpm	~ 500
	Maximum no. of revolutions rpm	~ 3500
	Maximum pressure (without pressure relief valve) bar	165
	Delivery (controlled) dm ³ /min	20
Slave cylinder 	Useful stroke	98 mm
	Length between wheel bases in straight running position	890 ± 1 mm
Centring cylinder 	Useful stroke	180 mm
	Length between wheel bases in straight running position	1000 mm
Hydraulic accumulator 	Nitrogen pre-load pressure	8.5 ± 1 bar
Oil Tutela GI/A	Quantity	4 to 5 litres
	Circuit pressure (during straight running)	12 + 1 bar

MAIN HYDRAULIC SYSTEM COMPONENTS

501476 HYDRAULIC ACCUMULATOR

Figure 9




38948

This component supplies the hydraulic pressure necessary to keep the third axle wheels aligned on a straight.

Nitrogen pressure checking and recharging


Figure 10



50724

Discharge the oil pressure from the circuit, working as described on page 96, Figure I8. Remove the protective lid (1).

Figure 11




50725

Fit the adapter (4) to tool 99366918 (5). Fit tool (5) complete with adapter (4) onto the accumulator (3).

Make sure that discharge valve (2) is closed. Open the hydraulic accumulator nitrogen pressure checking and recharge valve (3) by working on the knob (1) and read the pressure on the pressure gauge. Close the checking and recharge valve. Discharge the nitrogen pressure from tool (5) by opening valve (2).

Figure 12



50726

If the reading on the pressure gauge is lower than 8.5 bar, connect the tool to the nitrogen cylinder piping (3).

Make sure that the discharge valve (2) is closed, open the checking and recharge valve by working on the knob (1). Open the nitrogen cylinder and charge the hydraulic accumulator (4) up to the required value of 8.5 ± 1 .


Having charge the accumulator, close the nitrogen cylinder and the checking and recharge valve.

Open the discharge valve (2) to release the nitrogen pressure from the tool.

Finally, disconnect the tool, fit back the plug and the protective lid.

501471 OPERATOR CYLINDER

Figure 13




60182

Controls the operation of the centring cylinder as a function of front axle steering.

Disassembly

Figure 14




50728

First of all discharge the pressure and then the oil from the third axle control circuit as described on page 96, Figure 18. Empty out the oil from the front axle circuit by disconnecting the delivery pipe to the power steering system. Disconnect the pipes (→) from the cylinder (3). Disconnect the pipes from the ABS solenoid valve. Remove the cotter pins (1 and 5) the nuts (2 and 4) and take down the cylinder (3).

Assembly

Figure 15



50729

- A = 12 to 15 mm
- B = 98 mm
- C = 82 to 89 mm


Adjust dimensions A and C on the cylinder. Fit back the cylinder to the vehicle by reversing the order of the disassembly operations described above. Recharge and bleed the power steering circuit according to the procedure described on page 99 (circuit 1), with the third axle control circuit discharged and making sure that the measurements given in the figure are respected; if they are not, adjust them. To change dimensions A and B you can work on the ground part (1) after releasing the retaining screw. Recharge and bleed the third axle hydraulic control system as described on page 99 (circuit 2).



To ensure flawless system operation, measurement B must be absolutely complied with the vehicle in straight travelling conditions.

Checking cylinder oil sealing on the vehicle

Figure 16



50730


Steer to nearly full lock in one direction. Lock the wheels in this position. Discharge the hydraulic pressure from the 3rd axle system as described on page 96, Figure 18. Discharge the oil from the power steering hydraulic system. Disconnect the pipes (→) from the cylinder (1). Introduce oil into fitting B, on the cylinder, at a pressure of ca 10 bar, and make sure that no oil comes out from fittings A and D. Introduce oil into fitting D, on the cylinder, at a pressure of ca 10 bar, and make sure that no oil comes out from fittings E, C and B (4). Having completed these checks, restore travelling conditions and recharge and bleed the hydraulic system as described on page 99.



The letters appearing in the figure are stamped on the cylinder.


501475 CENTRING CYLINDER

Figure 17




50731

Controls third axle steering as a function of vehicle travelling conditions and front axle steering.

Disassembly**Figure 18**

Remove the plug (8).
Connect a pipe to fitting (6) as shown in Figure 22; discharge the hydraulic pressure by working on fitting (7).
Disconnect the pipes (→) from the cylinder (3) and empty out the oil.
Remove the cotter pins (1 and 5) the nuts (2 and 4) and take down the cylinder (3).

Assembly**Figure 19**

- A = 16 to 22 mm
B = 186 mm
C = 102 to 109 mm


Adjust dimensions A and C on the cylinder.
Fit back the cylinder to the vehicle by reversing the order of the disassembly operations described above.
Arrange the vehicle in straight travelling position and make sure that the measurements given in the figure are respected; if they are not, adjust them.
To change dimensions A and B you can work on the ground part (1) after releasing the retaining screw.



To ensure flawless system operation, measurement B must be absolutely complied with the vehicle in straight travelling conditions.

Recharge and bleed the third axle hydraulic control system as described on page 97.

Do the wheel geometry as described under the relevant heading.

Checking cylinder oil sealing on the vehicle**Figure 20**

Arrange the vehicle in straight travelling conditions and lock the 3rd axle wheels in this position.

Open plug V and make sure no oil comes out.

Remove the plug (1)

Connect a pipe to fitting (Z) as shown in Figure 22, discharge the hydraulic pressure by means of fitting (2).

Disconnect the pipes (→).

Introduce oil into fitting X, on the cylinder, at a pressure of ca 10 bar, and make sure that no oil comes out from fittings Y and W.

Having completed these checks, restore travelling conditions and recharge and bleed the hydraulic system as described on page 97.




The letters appearing in the figure are stamped on the cylinder.

ADDITIONAL AXLE PNEUMATIC LIFTING DEVICE REMOVAL AND REFITTING

Removal

Figure 21



73044




The operations described below have been carried out on a vehicle fitted with additional steering rear axle, but also apply to vehicles with single and twin wheel additional non-steering axle.

Position the vehicle on an even surface.
Lift the vehicle from the rear and position two supporting stands under the chassis.
Discharge air pressure and disconnect air spring feeding piping (3).
Remove the nuts (4 and 8) and the air spring (6).
Remove the nuts (7) and the supporting sheet (5).
Remove the nuts (2) and the support (1).


Refitting



Carry out the operations described for removal in the reverse order to refit and comply with prescribed tightening torques.

5014 AIR BLEEDING FROM THE HYDRAULIC CIRCUIT**Figure 22**

73045



501430 Filling up and bleeding the power steering hydraulic circuit (circuit 1)

Bleed the air from the power steering circuit, working as follows:

- ☐ fill up the circuit tank with the required oil type;
- ☐ rotate the engine with the starter motor and top up with oil continuously, to prevent the pump from taking in air;
- ☐ top up the oil until the level is not below the upper mark of the dipstick;
- ☐ start the engine and have it run at idling speed while checking that the oil does not drop below the upper mark of the dipstick;
- ☐ rotate the steering wheel several times from the lock to lock so as enable the air to come out from the power steering cylinder, until no air bubbles can be seen in the oil flowing into the tank;
- ☐ accelerate the engine as much as possible, stop it and make sure that the oil level in the reservoir does not rise by more than 1 to 3 cm.

501475 Filling up and bleeding the power steering hydraulic circuit (circuit 2)

Set the vehicle in steering centre position. Take down the ABS valve and the operator cylinder (1) from the frame and hang up the cylinder vertically.

Connect hydraulic pump 99305446 (2, Figure 22) by means of fittings 99305450 to line L₃ as shown in Figure 22; connect a pipe (6, Figure 22) to fitting z (L₃) on the centring cylinder (5) and introduce it into a special container.

By means of hydraulic pump (2) introduce oil into the system up to a pressure of ca 20 bar.

Open the bleeder valve (4) and empty out the oil mixed with air while keeping the pressure at ca 15 bar.

Let the oil flow out until you can see there is no air left.

Repeat this step on fittings X and W of the centring cylinder (5).

Repeat the same step on the control taps (3, Figure 22) with the following bleeding order: L₁ - L₂. connecting the bleeding piping to the pressure intakes by means of one of 99305450 unions. set the system to 12 + 1 bar and fit back the slave cylinder (1, Figure 22) and the ABS valve.

**Steering rear added axle
57080/TI (N 8072)**

	Page
DESCRIPTION	103
CHARACTERISTICS AND DATA	104
TIGHTENING TORQUES	106
TOOLS	107
REPAIR OPERATIONS	110

DESCRIPTION

The front axle is a steel structure with a tubular cross-section at the end of which the stub axles are articulated.


The stub axle articulation is made with tapered pins integral with the axle body and by means of four bearings with rollers driven in with interference in the holes of the stub axle overhangs.

The wheel hubs are supported by two tapered roller bearings, set right, lubricated with oil, mounted on the shank of the stub axle.

The bearings need no adjustment; their end float is obtained by tightening the retaining ring nut to torque.

The drum brake is the "Perrott" type.









Figure I












77485

VIEW OF STEERING REAR AXLE 57080/TI

CHARACTERISTICS AND DATA

	Type of axle	Steering liftable single wheels
	STUB AXLE PINS	
	Inclination of kingpin	7°
	Diameter of roller bearing housings on the stub axle: - upper housing Ø 1 mm - lower housing Ø 2 mm	51.967 to 51.986 59.967 to 59.986
	Outside diameter of roller bearings for stub axle: - upper bearings Ø 3 mm - lower bearings Ø 4 mm	52 60
	Stub axle bearings mm	0.014 to 0.033
	Inside diameter of roller bearings for stub axle: - upper bearings Ø 5 mm - lower bearings Ø 6 mm	43 53
	Diameter of king pin - top end Ø 7 mm - bottom end Ø 8 mm	42.984 to 43.000 52.981 to 53.000
	Upper bearings/pin mm	0 to 0.016
	Lower bearings/pin mm	0 to 0.019
	Play between axle and upper facing of stub axle X1 mm	0.10 to 0.15
	Clearance between axle and lower facing of stub axle X2 mm	0.25

	Shims to adjust X1, X2		
	>	0.25 mm	S mm
	WHEEL HUBS		
	Wheel hub bearings		2, taper rollers
	Wheel hub bearing end play	mm	max 0.16
	Wheel hub play adjustment		by tightening retaining ring nut to torque
	Rolling torque Bearing preloading	daNm	0.50
	Oil for wheel hub bearings	Litre	Tutela W 140/M DA 0.33 (0.30 kg)
	WHEEL GEOMETRY		
	Wheel camber (vehicle with static load)		1°
	Wheel caster (vehicle with static load)		0°
	Wheel toe-in (vehicle unladen)	mm	LEFT WHEEL 0
	Adjustment tolerance	mm	± 0.75
	Check tolerance	mm	± 2
	Steering angle: Inner Outer	α β	20° 13°
	Axle weight	kg	-
	Maximum capacity (GRW)	kg	8000







TIGHTENING TORQUES**Figure 2**

84601







PART	TORQUE	
	Nm	(kgm)
Flanged screw for attachment of track rod arm to stub axle	1325 ± 75	(135 ± 7.6)
1 Flanged screw for attachment of drag link arm to stub axle	1325 ± 75	(135 ± 7.6)
2 Castellated nut for ball joint pin	300 *	30 *
3 Hexagonal head flanged screw for attachment of the lower thrust bearing cap to stub axle	117 ± 6	(11.7 ± 0.6)
4 Wheel securing nut	600 ⁺⁵⁰ ₋₂₀	(60 ⁺⁵ ₋₂)
5 Wheel bearing securing ring nut	515.5 ± 24.5	(51.5 ± 2.4)
6 Plug for wheel hub cover	57.5 ± 2.5	
7 Hexagonal socket head screw for locking the wheel bearing adjustment ring nut	27.5 ± 2.5	(2.7 ± 0.2)
8 Wheel hub cap •	1330 ± 10	(13 ± 1)







* Minimum torque – peak torque, tighten to the first cut coinciding with the hole for the split pin


- Apply Loctite 574 on the wheel hub/cover contact surface

TOOLS	
TOOL NO.	DESCRIPTION
99305354 	Wheel geometry portable optical testing equipment
99305446 	Hand pump for filling and bleeding hydraulic system
99305450 	Set of couplings (2) for hydraulic pump 99305446
99321024 	Hydraulic truck to remove and fit back the wheels
99322215 	Overhauling stand
99347047 	Puller for king pin


TOOLS

TOOL NO.	DESCRIPTION	
99347068		Puller for steering rod ball joints
99354207		Wrench for wheel hub cap
99366918		Equipment for hydraulic accumulator check and charging
99370006		Handle for interchangeable beaters
99370007		Handle for interchangeable beaters
99370317		Reaction lever with extension to retain flanges


TOOLS	
TOOL NO.	DESCRIPTION
99370628	 Stand for axle removal and installation
99370715	 Guide for fitting wheel hub
99374093	 Beater to fit back bearing outer races (to be used with 99370007)
99374132	 Installer to fit back wheel hub internal gasket (to be used with 99370006)
99374173	 Elements to fit kingpin gasket (to be used with 99370007)
99374405	 Tool to fit kingpin

TOOLS**TOOL NO.****DESCRIPTION****99374530**


Drift to remove and refit kingpin bearings (use with 99370007)

99388001


Wrench (80 mm) for wheel hub bearing adjustment ring nut

99388002

Wrench for screws fastening the track rod arm and the drag link arm to the stub axle

99389819

Torque wrench (0-10 Nm) with 1/4" square fitting

99395026Tool for testing hubs rolling torque
(to be used with torque wrench)**REPAIR OPERATIONS**

For the procedure for overhauling the wheel hubs, follow the directions given under the heading AXLE 55080/TI with drum brakes.

The adjustment data, tightening torques and tools are the ones given in this section.

For a description of operation, characteristics and data and the repair procedures for the hydraulic and pneumatic components, follow the directions given under the heading axle 57080/DI.

Wheel geometry

	Page
GENERAL INFORMATION	113
☐ Steering wheel angles	113
FRONT WHEEL GEOMETRY (4x2 vehicles)	114
☐ Positioning clips and headlights	114
☐ Electronic compensation of rim eccentricity ..	115
☐ Wheel alignment	115
☐ Checking wheel toe-in	116
☐ Checking wheel deviation	116
☐ Checking camber	116
☐ Checking kingpin angle and caster	117
☐ Checking rear axle alignment	118
VEHICLE WHEEL GEOMETRY WITH CENTRAL ADDED AXLE (6X2 C)	118
☐ Checking rear axle alignment	120
☐ Vehicle wheel geometry with steering rear added axle and pneumatic lifting	120

GENERAL INFORMATION

Steering wheel angles


To ensure satisfactory road holding performance, low tyre wear and to allow driving wheels in the steering stage to return spontaneously to straight ahead running position, front wheels are given the following fitting angles:

- ☐ camber;
- ☐ kingpin angle;
- ☐ caster;
- ☐ toe-in.

These angles, suitably calculated, produce the right balance of the forces created when the vehicle is moving, in different load conditions, which tend to alter the position of the wheels on the ground.

Figure 1

Camber




32956

The camber (α) is the angle formed by the axis passing through the centre line of the wheel and the vertical to the ground when observing the vehicle from the front. The angle is positive (A) when the top of the wheel tilts outwards, negative (B) when the top of the wheel tilts inwards.

Kingpin angle

Figure 2



32957

The kingpin angle (β) is the angle formed by the axis passing through the kingpin and the vertical to the ground when observing the vehicle from the front.


When the extension of the kingpin axis approaches the wheel at its point of contact with the ground (opposite to the camber), the angle is positive; it is extremely difficult, if not impossible, to have a negative kingpin angle.

The camber (α) and kingpin angle (β) make it possible for the axes of the wheel and kingpin to come as close as possible to the centre of support of the tyre on the ground.

This produces low tyre consumption and a low steering torque.

Caster

Figure 3




32958

The caster (γ) is the angle formed by the kingpin axis with the vertical to the ground when observing the vehicle from the side. If the extension of the kingpin axis falls forwards to the point where the wheel rests on the ground, in the direction of travel of the vehicle, the caster is by convention positive (A); it is negative (B) if it falls behind the point where the wheels rest on the ground, and zero if it is exactly vertical to the point where the wheels rest on the ground.

This angle makes it possible to keep the front wheels straight when the vehicle is travelling in a straight line and for them to return straight on their own after the position they take in a bend as soon as the driver lets go of the steering wheel.

Wheel toe-in


Figure 4



32813

The toe-in is the result of the difference between the distances A and B (in mm) measured on the horizontal axis of the rims, when observing the vehicle from above. This produces light driving and low tyre consumption. Toe-in is positive if B is greater than A.


Figure 5



32814

Toe-in is negative if B is less than A.

Figure 6



32815

Toe-in will be zero if B is equal to A.

FRONT WHEEL GEOMETRY
(4X2 vehicles)

Before moving on to the checks, it is necessary to make a preliminary inspection of some parts of the vehicle that may affect wheel geometry. If any trouble is found, it will have to be rectified in order to avoid incorrect measurements. The checks to make are the following:

- ☐ tyre pressure;
- ☐ wheel hub bearing clearance;
- ☐ clearance between steering tie-rod pins and levers on stub axles;
- ☐ efficiency of shock absorbers;
- ☐ wheel rims, which must have no buckling out of tolerance.


Check the wheel geometry with the instrument 99305354.



The checks and any work on the wheel geometry must be done with the vehicle with a static load. Periodically make sure the light clusters are set correctly.

Positioning clips and headlights


Figure 7



32973

Set the vehicle with its wheels in the position of straight-line travel on a flat surface. Lift the rear of the vehicle and place the boards (3) under the wheels. Lower the vehicle, brake the rear wheels and fit on the hook (1) with the rule (2).


Figure 8



32974

Lift the front of the vehicle and place oscillators (1) under the wheels, locking them with the clamps (2).


Figure 9



32975

Position the self-centring clip (2), fitted with appropriate fixing pins (1), on the rim of the wheel. Using the knob (3), lock the clip on the wheel, checking it is properly anchored.

Figure 10




32976

Fit the measuring unit (3) on the clips (1) and fasten it with the screw (2). Repeat these steps on the other wheel.

Electronic compensation of rim eccentricity

Figure 11



32977

Connect the plugs of the measuring unit to the transformer and turn on the switch. Loosen the locking screw of the measuring unit and lift the lens shield. Press the "off centre" button (3) for at least two seconds, five lines will appear on the display (1).

Turn the wheel slowly by hand and project the light signal onto the corresponding scale of the rule (5).

Measure and note down the minimum and maximum travel of the light signal: e.g., 12 and 8.

Calculate the mean travel: $12 + 8 = 20 : 2 = 10$ and position the wheel on the mean value calculated, marking its position.

Press the "off centre" button (3) again till the wheel toe-in LED (2) comes on and the digital indicator (1) shows an artificial value.


Repeat these steps on the other wheel.



Take care the laser beam does not hit anyone's eyes: it would severely damage their sight.

Lower the vehicle so that the wheels, in the marked position, rest completely in the middle of the oscillating plates, and free these from their bases, taking out the pins (4).

Figure 12




84602

Press the brake pedal and lock it in position with the tool (1) positioned against the seat, thereby keeping the vehicle braked for the entire cycle of measurement.

Wheel alignment

Figure 13




32979

Level the measuring units (3) with the spirit level (1) and lock them in position with the screw (2).

Move the rules (4) until they are centred by the light signal emitted by the measuring unit and note down the values given.


Figure 14



If the values are not the same, turn the wheels until the pointers of the light signals are on two equal values (A), exactly the mean value of the two readings made beforehand. This produces perfect wheel alignment.

Checking wheel toe-in

Figure 15



With the measuring units still level and the wheels perfectly aligned, using the lever (1), move the lens shield.

Using the lever (2), direct the pointer of the light signal onto the millimetre scale of the rule (3) corresponding to the diameter of the rim.

Repeat these steps on the opposite measuring unit and read off the value of the toe-ins given in mm on the millimetre scales.

The algebraic sum of these two measurements must give the required value.



The toe-in is adjusted with the transverse tie rod so as, for each wheel, to have a toe-in equal to half the required value.

Checking wheel deviation

The deviation is checked while reading the toe-in.

The partial value of the toe-in measured on the rule (3) has to be equal to the value measured on the rule on the other wheel.

If, however, there is a difference in these values, e.g. -2 and +3, the total toe-in is +1 and is therefore correct, but at the same time it indicates a deviation between the wheels (one wheel further forward than the other) of 5 lines.


This number of lines is calculated with the algebraic sum of the values measured: $+3 - (-2) = 5$, or more simply by counting the lines between the two values.

Each line corresponds to a deviation of 2 mm.

When the deviation is greater than 10 lines (20 mm), it is necessary to make additional checks, to verify the state of the leaf springs (whether one of these has given way, or whether the chassis or axle are out of shape).

Checking camber

Figure 16




With the front wheels aligned with the rear ones and the measuring units level, press the camber button (3); the LED (2) will come on and the display (1) will show the value of the camber, that has to be 1°.



The camber is a fixed value that cannot be adjusted. Therefore, if you find the value is not as required, detach and remove the axle to make the relevant checks and replacements if necessary.


Checking kingpin angle and caster

Figure 17




Still with the front wheels aligned with the rear ones, loosen the knurled knobs (2) and reset the graduated sector (3) on the pointer (1) of the oscillating plate.

Figure 18




Turn the wheels 20° inwards and press the kingpin angle button (3) twice; the LED (2) will come on and the display (1) will show nine horizontal lines.

Figure 19



Turn the wheels 20° outwards and press the kingpin angle button (2) again; the display (1) will show the value of the kingpin angle that has to be 7°.

Figure 20




Without moving the wheel, press the caster button (3). The LED (1) will come on and the display (2) will show the value of the caster, which has to be the required value.



The caster and kingpin angle are fixed values that cannot be adjusted.

Therefore, if you find the values are not as required, detach and remove the axle to make the relevant checks and replacements if necessary.

Figure 21



With the wheels turned straight, reset the graduated sectors (5) on the pointer (2) of the oscillating plates (4).


If the steering angles to be measured are greater than 30°, it is necessary to use the 20° mark (1) on the oscillating plate and the corresponding one of the graduated sector as "0°" reference indices.

Turn the wheels to reach a required angle (internal or external wheel angle).

Then check that the steering angle (external or internal wheel angle) of the opposite wheel corresponds to the required value, remembering to use the corresponding scale with the sign shown on the oscillating plate to read off the angle.

Checking rear axle alignment


Figure 22



71743

Fit the rule (4) on the front wheels, checking the slide (2) is exactly in the middle of the two annular grooves of the shaft (3). Fit the measuring units on the rear wheels as described above for the wheels of the front axle.

Figure 23




38671

Project the light signal on the rule (1) and note down the value shown.

Repeat this measurement on the other wheel and check that the value shown is the same as the one noted down; if it is not, thoroughly check over the assembly of the rear axle on the vehicle: if you find no trouble, check the chassis has not lost its shape, following the procedures described in the "Bodywork - Chassis" section.

VEHICLE WHEEL GEOMETRY WITH CENTRAL ADDED AXLE (6X2 C)

Figure 24



38657


Detach the swivel head (2) of the rear longitudinal tie rod (3) from the steering lever (1) of the central axle with the extractor 99347068.



Check the distance between the centre distances of the swivel heads of the tie rod (3). It must be 832 ± 10 mm. If it is not, loosen the screw fixing the collar and turn the tie rod (3) appropriately.

Provisionally fit the swivel head (2) back onto the lever (1) and screw down the fixing nut without fully locking it.


Figure 25



38658

Lift the vehicle, position the oscillating plates (1 and 4) of the device 99305123 under the wheels of the steering axles, locking them with the specific clamps (2) and place the boards (3) under the rear wheels.


Figure 26



38659

Check front axle wheel geometry using device 99305123 (1) according to procedure described and illustrated for 4X2 vehicles.


Figure 27



71745

After checking and adjusting the toe-in, if necessary, set the wheels straight and check the steering box is in the "steering centre" position, that is the notch ← of the shaft (1) coincides with the notch ⇒ of the steering box (2).


Figure 28



84603

Lock the steering wheel with the tool (1).

Figure 29



71746


Check that the distance between the centre distances of the swivel head (1) and of the fork (5) of the middle longitudinal tie rod (3) is 2159 ± 2 mm.

If this is not so, disconnect the swivel head (1) from the lever (2) with the extractor, loosen the collar (4) and turn the tie rod (3) appropriately to get the required distance; then, fit the swivel head (1) back onto the lever (2).



Each turn of the tie rod (3) corresponds to a change in its length of 0.75 mm.

Figure 30




38663

Disconnect the swivel heads (1, Figure 29) from the steering lever (2, Figure 29) from the central axle.

Fit the light cluster (1) of the device 99305123 onto the wheels of the central axle, repeat the checks and, if necessary, adjust the toe-in as done for the front axle.

Figure 31




With the wheels straight and the steering box in the "steering centre" position, check that the pin of the swivel head (2) goes exactly into the tapered hole of the lever (1). If it does not, loosen the collar (3) fixing the swivel head to the tie rod and turn the swivel head appropriately to achieve the above condition.

In this way, the wheels of the central axle will be aligned with those of the front axle (permitted alignment tolerance 0 ± 0.5 mm). Fit the swivel head back onto the respective lever permanently by tightening the nuts to the required torque.

Checking steering angles


Figure 32



After resetting the graduated sectors on the pointers of the oscillating plates (1), turn the wheels so that the left front wheel is positioned on the internal steering angle and check that the other wheels are turned by the required angle. Repeat the check on the steering angles, positioning the left front wheel on the external steering angle.

Vehicle wheel geometry with steering rear added axle and pneumatic lifting

Figure 33




Lift the vehicle, position the oscillating plates (1) of appliance 99305354 under the wheels of the steering axles, locking the plates with the clamps (2) and place the boards (3) under the wheels of the rear axle.

Check the wheel geometry of the front axle with appliance 99305354 according to the procedure described and illustrated for 4x2 vehicles.

After making the check and any adjustment of the toe-in, set the wheels straight.

Figure 34




With the steering housing in the "drive centre" position, apply the optical assembly of the appliance 99305354 to the wheels of the rear added axle.

Lift the added axle and adjust the wheel rims; lower the added axle.

Check the wheel toe-in of the third axle as described for the front axle of the 4x2 vehicles.

Finding a different value to the one given in the characteristics and data table, adjust the toe-in as follows.

Figure 35

Loosen the collars (1) fixing the swivel heads (2) at the ends of the transverse tie rod (3) and turn this to accomplish the required wheel toe-in.

Continue checking the camber, kingpin angle, caster and steering angle as described for the 4x2 vehicles.

	Page
SUSPENSIONS	3
DESCRIPTION	3
☐ Mechanical front suspension	3
☐ Pneumatic front suspension	3
☐ Pneumatic rear suspension	3
☐ Rear mechanical suspension	3
SPECIFICATIONS AND DATA	4
MECHANICAL FRONT SUSPENSION ASSEMBLY DRAWING	14
REAR MECHANICAL SUSPENSION ASSEMBLY	18
"CANTILEVER" REAR SUSPENSION (vehicles 6X2)	20
☐ Procedure for assembly of the slipper block and mounting brackets for the longitudinal bars ...	20
☐ Tightening the U-bolts clamping the leaf spring to the central pivot	20
☐ Removing the central support	21
☐ Removing the central support shaft	21
☐ Replacing the bracket	21
☐ Replacing the half bearings	21
☐ Reassembling the bracket	22
☐ Reassembling the central support shaft	23
☐ Reassembling the central support	23
☐ Front shock absorbers	25
☐ Additional axle shock absorbers	26
☐ Rear shock absorbers	27
AIR SUSPENSION	28
☐ Chassis frame lifting, lowering and self-levelling with remote control	28
☐ Saving Levels	28
AIR SUSPENSION SYSTEM DIAGRAMS	29

SECTION 9

5004 Suspensions

	Page
☐ Rear air suspension main diagram for 4X2P vehicles	29
☐ Working diagram of pneumatic rear suspensions for 4x2T/P tractors	30
☐ Suspension diagram for tractors and cabin vehicles 4x2T/FP	31
☐ Working diagram of air suspensions for 6x2Y/FP/FS-D/FP-D vehicles	32
☐ Working diagram of air suspensions for 6x2Y/FP/FS-D/FP-D vehicles (without lifting the additional axle)	33
☐ Working diagram of air suspensions for 6x2Y/FP/FS-CM vehicles	34
☐ Working diagram of air suspensions for 6x2Y/FP/FS-CM vehicles (without lifting the additional axle)	35
☐ Working diagram of rear air suspensions for 6x2Y/PT vehicles	36
☐ Working diagram of rear air suspensions for 6x2Y/PT vehicles (without lifting the additional axle)	37
☐ Working diagram of rear air suspensions for 6x2Y/PS vehicles	38
☐ Working diagram of rear air suspensions for 6x2Y/PS vehicles (without lifting the additional axle)	39
☐ Working diagram of air suspensions for 6x2TX/P vehicles	40
☐ Working diagram of pneumatic rear suspensions for 6x4 TZ/P vehicles	41
CHARACTERISTICS AND DATA	42
☐ Pneumatic System	42
MAIN COMPONENTS OF THE PNEUMATIC SYSTEM	43
☐ Controlled pressure valve	43
☐ Fault Diagnosis	43
☐ Level sensor	43
☐ Electro-Pneumatic Control Valve	44
☐ Load detector pressure sensor	45

Page

☐ Low air pressure switch	45
☐ Air spring	45
☐ ECAS Control Unit	45
FAULT DIAGNOSIS	46
☐ Diagnosis Instruments	46
☐ Cluster Diagnosis	47
TOOLS	52
TIGHTENING TORQUES	56
☐ Mechanical front suspension	56
☐ Pneumatic front suspension	57
☐ Pneumatic front suspension with bars	58
☐ Central added axle pneumatic suspensions 6x2 C vehicles	59
☐ Pneumatic rear suspension 4x2 – 6x2 C vehicles	60
☐ Pneumatic rear suspension 6x2 P/PT/FT vehicles	61
☐ Pneumatic rear suspension 6x2 P/FP/FS vehicles	62
☐ Pneumatic rear suspension 6x2 P/PS vehicles	63
☐ Pneumatic rear suspension 6x4 P vehicles	64
REMOVAL-REFITTING OF FRONT LEAF SPRING	65
☐ Removal	65
☐ Refitting	65
REMOVING-REFITTING FRONT SUSPENSION BARS	66
☐ Removing longitudinal bars	66
☐ Removing transverse bar	66
☐ Refitting	66
REAR SUSPENSIONS	67
☐ Removal	67
☐ Refitting	67
REMOVING-REFITTING THE REAR AXLE LONGITUDINAL SUSPENSION ARM	68

Page

REMOVING-REFITTING THE REAR ADDED AXLE LONGITUDINAL SUSPENSION ARM .	68
REMOVING-REFITTING THE REAR AXLE TRIANGULAR SUSPENSION ARM	68
REMOVING-REFITTING THE REAR ADDED AXLE TRIANGULAR SUSPENSION ARM ...	68
☐ Removal	68
☐ Refitting	68
REPLACING THE SUSPENSION ARM FLEXIBLE PIN	69
☐ Removal	69
☐ Refitting	69
STABILIZER BAR	70
FRONT STABILIZER BAR	70
CENTRAL ADDED AXLE STABILIZER BAR (6x2 C vehicles)	70
REAR STABILIZER BAR	70
REAR ADDED AXLE STABILIZER BAR (6x2P vehicles)	70
☐ Removal	70
☐ Refitting	70
RUBBER BUSHINGS	73
☐ Replacing front stabilizer bar rubber bushings ..	73
☐ Replacing rear stabilizer bar rubber bushings ..	73
SHOCK ABSORBERS	74
☐ Removal-refitting	74
☐ Front axle shock absorbers (6x2 C vehicles)	74
☐ Central added axle shock absorbers	74
☐ Rear axle shock absorbers	74
☐ Rear added axle shock absorbers (6x2 P vehicles)	74
☐ Removal	74
☐ Refitting	74
CHASSIS FRAME ADJUSTMENT	75

5004 SUSPENSIONS

DESCRIPTION

The vehicle's suspension, depending on the version, may be:

- ☐ pneumatic
- ☐ mixed (front mechanical and rear pneumatic)
- ☐ mechanical.

Mechanical front suspension

The front suspension comprises:

- double-acting hydraulic shock absorbers;
- stabilizer bar;
- parabolic leaf springs

Pneumatic front suspension

The front suspension comprises:

- double-acting hydraulic shock absorbers;
- stabilizer bar;
- parabolic leaf springs and air springs (for Full Pneumatic vehicles and for the central added axle of the 6x2C vehicles only);
- air springs with longitudinal bars (only for vehicles 6x2P mobile boxes CM).

Pneumatic rear suspension

The rear suspension comprises:

- stabilizer bars;
- double-acting hydraulic shock absorbers;
- air springs.







Rear mechanical suspension

The rear suspension consists of:







- hydraulic shock absorbers with double effect;
- stabilising bar;
- parabolic leafsprings (cantilever type only for vehicles 6x2).

SPECIFICATIONS AND DATA






FRONT SUSPENSION: 4X2 – 6X2P - 6X4 MODELS

		mm
	8 tonnes parabolic leaf springs	No. 2
	Spring length (measured at eye centres)	1900 $\begin{smallmatrix} + 0 \\ - 6 \end{smallmatrix}$
	Leaf thickness (measured at centre) ☐ master leaf ☐ 2 nd - 3 rd leaf	25 26
	Distance between leaves	3
	Leaf width	90
	Inside diameter of master leaf eye (bushing seat)	60.1 $\div$ 60.2
	D = outside diameter of bushing d = inside diameter of bushing	62.0 $\div$ 62.8 20.2 $\div$ 20.5
NEW LEAF SPRING CHECK DATA		
	Flexibility mm/KN	4.41






FRONT SUSPENSION: 4X2 – 6X4 MODELS

		mm
	7.5 tonnes parabolic leaf springs	No. 2
	Spring length (measured at eye centres)	1900 $\begin{smallmatrix} + 0 \\ - 6 \end{smallmatrix}$
	Leaf thickness (measured at centre) (1 st and 2 nd leaf)	25
	Distance between leaves	3
	Leaf width	90
	Inside diameter of master leaf eye (bushing seat)	60.1 $\div$ 60.2
	D = outside diameter of bushing d = inside diameter of bushing	62.0 $\div$ 62.8 20.2 $\div$ 20.5
NEW LEAF SPRING CHECK DATA		
	Flexibility mm/KN	5.2




FRONT SUSPENSION: 4X2 – 6X2P – 6X2C MODELS

		mm
	7.5 tonnes parabolic leaf springs	No. 2
	Spring length (measured at eye centres)	1895 $\begin{smallmatrix} +0 \\ -5 \end{smallmatrix}$
	Leaf thickness (measured at centre) (1 st and 2 nd leaf)	30
	Distance between leaves	3
	Leaf width	90
	Inside diameter of master leaf eye (bushing seat)	60.1 $\pm$ 60.2
	D = outside diameter of bushing d = inside diameter of bushing	62.0 $\pm$ 62.8 20.2 $\pm$ 20.5
NEW LEAF SPRING CHECK DATA		
	Flexibility mm/KN	4.98







FRONT SUSPENSION: 4X2 – 6X2P – 6X2C MODELS

		mm
	8 tonnes parabolic leaf springs	No. 2
	Spring length (measured at eye centres)	$1895 \begin{smallmatrix} +0 \\ -5 \end{smallmatrix}$
	Leaf thickness (measured at centre) (1 st ⇒ 2 nd leaf)	30
	Leaf width	90
	Inside diameter of master leaf eye (bushing seat)	$60.1 \div 60.2$
	D = outside diameter of bushing d = inside diameter of bushing	$62.0 \div 62.8$ $20.2 \div 20.5$
NEW LEAF SPRING CHECK DATA		
	Flexibility mm/KN	4.7







FRONT SUSPENSION: 4X2 - 6X2P MODELS

		mm
	8 tons semi-elliptic leaf springs:	No. 2
	Spring length	1900 $\begin{smallmatrix} + 0 \\ - 6 \end{smallmatrix}$
	Leaf thickness (measured at centre)	15
	Leaf width	90
NEW LEAF SPRING CHECK DATA		
	Flexibility mm/KN	4.35






FRONT SUSPENSION: 4X2 – 6X2 MODELS **(vehicles with lowered chassis frame and air suspension)**

		mm
	7.5 tonnes parabolic leaf springs	No. 2
	Spring length (measured at eye centres)	1875 $\begin{smallmatrix} + 2 \\ - 4 \end{smallmatrix}$
	Leaf thickness (measured at centre) 1 st leaf 2 nd leaf	40 25
	Distance between leaves	3
	Leaf width	90
	Inside diameter of master leaf eye (bushing seat)	60.1 $\div$ 60.2
	D = outside diameter of bushing d = inside diameter of bushing	62.0 $\div$ 62.8 20.2 $\div$ 20.5
NEW LEAF SPRING CHECK DATA		
	Flexibility mm/KN	9.8




SUSPENSION FOR CENTRAL ADDITIONAL AXLE MODELS 6X2C **(vehicles with air suspension)**

		mm
	Parabolic leaf springs	N° 2
	Spring length (measured to eye centres)	898.5 ± 1.5
	Leaf thickness (measured at centre) 1st leaf 2nd leaf	28 32
	Distance between leaves	-
	Leaf width	90
	Inside diameter of master leaf eye (bushing seat)	$60 \div 60.074$
	D = outside diameter of bushing d = inside diameter of bushing	- $20.2 \div 20.5$






REAR SUSPENSION: 6X2P MODELS


		mm
	12+8 tonnes parabolic leaf springs	No. 2
	Spring length (measured at eye centres)	1610 ± 2
	Leaf thickness (measured at centre) (1 st ⇒ 3 rd leaf)	31
	Leaf width	100
	Inside diameter of master leaf eye (bushing seat)	60.1 ÷ 60.2
	D = outside diameter of bushing d = inside diameter of bushing	62.0 ÷ 62.8 20.2 ÷ 20.5
NEW LEAF SPRING CHECK DATA		
	Flexibility mm/KN	0.8

REAR SUSPENSION: 4X2 MODELS

		mm
	13 tonnes parabolic leaf springs	No. 2
	Spring length (measured at eye centres)	1800 ± 3
	Leaf thickness (measured at centre) (1 st ⇒ 3 rd leaf) (4 th leaf)	21 40
	Leaf width	96 ± 1
	Inside diameter of master leaf eye (bushing seat)	60.1 ÷ 60.2
NEW LEAF SPRING CHECK DATA		
	Flexibility mm/KN	1.8


REAR SUSPENSION: 4X2 MODELS

		mm
	13 tonnes semi-elliptic leaf springs	No. 2
	Spring length (measured at eye centres)	1575 ± 3
	Leaf thickness (measured at centre) (1 st $\Rightarrow$ 10 th leaf)	15
	Leaf width	100
	Inside diameter of master leaf eye (bushing seat)	$60.1 \div 60.2$
	D = outside diameter of bushing d = inside diameter of bushing	$62.0 \div 62.8$ $20.2 \div 20.5$
NEW LEAF SPRING CHECK DATA		
	Flexibility mm/KN	1.69

MECHANICAL FRONT SUSPENSION ASSEMBLY DRAWING**Figure 1**

49253


FRONT SUSPENSION WITH PARABOLIC LEAF SPRING: 4x2 – 6x2P – 6x2C VEHICLES

Figure 2

72858

FRONT SUSPENSION WITH PARABOLIC LEAF SPRING: 4x2 – 6x2P – 6x4 VEHICLES


Figure 3



72859


FRONT AIR SUSPENSION WITH PARABOLIC LEAF SPRING:
6x2P with lowered chassis frame – Large volume vehicles

Figure 4




84505

FRONT SUSPENSION WITH SEMI-ELLIPTIC LEAF SPRINGS: 4x2 - 6x2P VEHICLES

REAR MECHANICAL SUSPENSION ASSEMBLY**Figure 5**


72215

REAR SUSPENSION WITH PARABOLIC LEAF SPRINGS: 4x2 VEHICLES

Figure 6

84504

REAR SUSPENSION WITH SEMI-ELLIPTIC LEAF SPRINGS FOR VEHICLES 4X2

“CANTILEVER” REAR SUSPENSION (Vehicles 6X2)**Procedure for assembly of the slipper block and mounting brackets for the longitudinal bars****Figure 7**

36836

- ☐ Apply MODILAC grease to the threads of the slipper block (1);
- ☐ apply resin for box frames to bolt contact surfaces and holes in the bracket (2);
- ☐ after having aligned the parts, pre-tighten bolts (3) in cross-wise sequence to a torque of 100 Nm;
- ☐ finally tighten bolts (3) to a torque of 420 Nm.

Tightening the U-bolts clamping the leaf spring to the central pivot

Tighten the leaf spring (4 and 6) clamping nuts (5 and 7) as follows:

- ☐ tighten nuts (5) to a torque of 300 to 500 Nm
- ☐ tighten nuts (7) to a torque of 750 to 900 Nm
- ☐ tighten nuts (5) to a torque of 750 to 900 Nm


500440 Removing-reassembling the central support

500442 Removing-reassembling the central support shaft

500443 Replacing the bearings

500449 Removing-reassembling the bracket
Removing the central support

Figure 8



Lift the rear of the vehicle and rest the chassis and axles on stands.


Remove the wheels.

Remove the leaf spring.

Remove the split ring (6) and cap (5).

Remove the screws (4), plate (3) and adjusting shims (2) underneath.


Figure 9



Using puller 99348002 (5) and counter block 99345055 (4), pull out the central support (1) from the shaft (3), together with outer half bearing (2).

Removing the central support shaft

Figure 10



Loosen the screw (6) by approx. 1 turn.




Do not remove the screw (6) and plate (5), since in the next operation this prevents violent ejection of the shaft (2) from the bracket.

Fit the pipe (3) of hydraulic pump 99341035 (1) to the bracket hole (1); operate the pump until the shaft (2) is released from the bracket (1).

Remove the screw (6) and plate (5) and pull out the shaft (2) from the bracket (1).

Replacing the bracket


Figure 11



Remove the drag links (2 and 3) and take down the bracket (1). To replace the upper bracket (1, Figure 14), take out the screws (⇒) and remove the bracket from the side members.


Replacing the half bearings

Figure 12



Using a hydraulic press, remove the inner half bearing (2) from the shaft bearing (1).

Figure 13




39078A

To remove the half bearing outer rings (4 and 5) from the central support (3) use a suitable beater.

To reassemble, use beater 99347094 (2) and, with a press, partially insert the rings into the central support (3).

Completely reassemble using a hammer, fitted with 99370007 handgrip (1).

Figure 15




39080

Using tool 99374119 (1), fit the seal ring (2) to the central support (3).

Then, reinstall the guard ring (4).

Reassembling the bracket

Figure 14



39079


Fasten lower bracket (10) to upper bracket (1) and tighten the screws to the prescribed torque, following the direction of arrow **B**.

If the bracket (1) has also been removed, proceed as follows:

- ☐ tighten 2-3-4-5-6-7-8-9 screws in this order until the components completely adhere;
- ☐ tighten the screws to the prescribed torque, following the direction of arrow **A** and then arrow **B**;
- ☐ re-tighten to the prescribed torque, following the direction of arrow **A**;
- ☐ Tightening torque for lower bracket (10) to bracket (1) fastening screws is 395 to 590 Nm;
- ☐ Tightening torque for upper bracket to chassis fastening screws is 215 to 325 Nm.

Reassembling the central support shaft


Figure 16



39081

Insert the shaft (1) into the bracket (2), with the holes positioned as shown in the figure; place the plate (4) on the bracket (2) and fasten it to the shaft (1) with screw (3).


Figure 17



39082

Tighten the screws (⇒) in the shaft holes (1); place a ruler (2) on the holes and make sure A and B ends are the same distance from the ground. If they are not, reposition the shaft (1).

Figure 18




39083

Lock the shaft (1) and tighten the screw (3, Figure 16) to 50 Nm torque. Measure distance A between shaft end (1) and bracket (2).

The measured value must range among the values listed in Figure 19 table.

Figure 19



39084

Keeping the shaft (2) locked, operate hydraulic pump 99341035 (3) and at the same time tighten screw (1) until the shaft (2) is at level B. This is equal to A-C, where A is the distance previously measured and C is the value indicated in the table.

Distance B must range among the values listed in the table.

A	217.5 to 220.5
B	213.5 to 216.5
C	4.5 + 0.5




Towards the end of the shaft assembly process, the oil pressure ranges between 800 and 1300 bars.

After B value is found, open the back flow valve on hydraulic pump 99341035 and wait at least 10 minutes before tightening the screw (1) to 830 to 665 Nm (83 to 66.5 kgm) torque. Remove pump 99341035 pipe from the bracket and close the oil filling hole with a suitable plug.

Reassembling the central support


Figure 20



39385

Lubricate the seal ring (⇒) with TUTELA MR3 grease and fit it to the shaft (2). Using tools 99346238 (3), 99363296 (4), 99363245 (5), 99346004 (6), fitted on the shaft (2) as shown, fit the inner half bearing (1) to the shaft.

Figure 21




Fit the central support (1) to the shaft (4). Using tools 99346243 (3), 99363296 (5), 99363245 (6), 99346004 (7) and 99346001 (8), fitted on the shaft (4) as shown, fit the inner ring (2) to the outer half bearing on the shaft.



Towards the end of the above mentioned operations, hammer the central support (1), to settle the half bearing inner rings into their seats. Remove the ring fitting tools from the shaft.

Figure 22




Find adjusting washer (1) **S** thickness for the half bearing end play as follows:

- ☐ Place the plate (2) and tighten the screws ($\Rightarrow$) to 30 Nm torque;
- ☐ Remove the screws ($\Rightarrow$) and plate and measure the distance between shaft end (3) and half bearing inner ring (4):
shaft (3) overhang value **A**
shaft (3) cavity value **-A**;
- ☐ Measure the plate shoulder surface cavity (1), Figure 23, value **B**.

Adjusting washer **S** thickness is $S = B + C - (\pm A)$, where **A** and **B** are the distances previously measured and **C** is the half bearing end play (0.1 to 0.3 mm). Select adjusting washers (1) of suitable thickness and reassemble washers and plate (2); then, tighten the fastening screws ($\Rightarrow$) to 240 Nm torque.


Figure 23



Fit back the leaf spring and tighten the mounting bracket nuts as explained before.

Make sure the central support is free to partially rotate. If it is not, increase the adjusting washer shim by 0.1 mm.

Figure 24








CENTRAL SUPPORT COMPONENTS





1. Seal ring - 2. Seal ring - 3. Central support - 4. Inner bearing outer ring - 5. Inner bearing inner ring - 6. Outer bearing outer ring - 7. Outer bearing inner ring - 8. Seal ring - 9. Split ring - 10. Plug - 11. Cap - 12. Screw - 13. Plate - 14. Adjusting washers - 15. Shaft - 16. Protection ring.

Fit the seal ring (8), previously lubricated with TUTELA MR3 grease, and cap (11), with the plug (10) facing upwards. Fasten the cap (11) to the central support (3) with split ring (9). Remove the plug (10) and fill with "ZC 90" until oil seeps out from the hole (approx. 0.5 lt.). Complete suspension reassembly.





Front shock absorbers


SHOCK ABSORBERS  Vehicles: 4x2 ..P 6x2P ..P 4x2 ..T/P 6x2C	Length L: Open Closed Stroke	FICHTEL & SACHS 754 ± 3 434 ± 3 320	ARVIN 753 ± 3 436 ± 3 317
SHOCK ABSORBERS  Vehicles: 4x2 .. - 6x2P 4x2 ..P - 6x2P ..P 4x2 ..T/P - 6x4 ..T/P	Length L: Open Closed Stroke	MANNESMANN SACHS 754 ± 3 434 ± 3 320	ARVIN 754 ± 3 432 ± 3 322
SHOCK ABSORBERS  Vehicles: 4x2 ..FP-D 6x2P ..FP-D 4x2 ..FP 4x2 ..T/FP	Length between the eye centres: Open Closed Stroke	MANNESMANN SACHS 492 ± 3 322 ± 3 170	WAY- ASSAUTO 495 ± 3 325 ± 3 170
SHOCK ABSORBERS  Vehicles: 4x2 ../FP 6x2P ../FP	Length L: Open Closed Stroke	MANNESMANN SACHS 811 ± 3 471 ± 3 340	WAY- ASSAUTO 804 ± 3 470 ± 3 334
SHOCK ABSORBERS CENTRAL ADDED AXLE  Vehicles: 4x2 - 6x2P	Length L: Open Closed Stroke	MANNESMANN SACHS 778 ± 3 448 ± 3 330	ARVIN 777 ± 3 452 ± 3 325

Additional axle shock absorbers

SHOCK ABSORBERS REAR ADDED AXLE  Vehicles: 6x2P ../P 6x2P ../FP-D	Length between the eye centres: Open Closed Stroke	MANNESMANN SACHS 820 ± 3 500 ± 3 320	ARVIN 820 ± 3 520 ± 3 300
SHOCK ABSORBERS REAR ADDED AXLE  Vehicles: 6x2P ../FP	Length between the eye centres: Open Closed Stroke	MANNESMANN SACHS 930 ± 3 550 ± 3 380	ARVIN 922 ± 3 553 ± 3 369
SHOCK ABSORBERS REAR ADDED AXLE  Vehicles: 6x2P	Length between the eye centres: Open Closed Stroke	MANNESMANN SACHS 840 ± 3 500 ± 3 340	ARVIN 839 ± 3 500 ± 3 339
SHOCK ABSORBERS REAR ADDED AXLE  Vehicles: 6x2P	Length between the eye centres: Open Closed Stroke	MANNESMANN SACHS 729 ± 3 439 ± 3 290	
SHOCK ABSORBERS CENTRAL ADDED AXLE  Vehicles: 6x2C	Length between the eye centres: Open Closed Stroke	MANNESMANN SACHS 653 ± 3 395 ± 3 240	WAY- ASSAUTO 635 ± 3 400 ± 3 235


Rear shock absorbers

SHOCK ABSORBERS  Vehicles: 4x2 ../FP - 4x2 ../P 4x2 ../FP-D - 6x2P ../P 6x2 ../FP-D - 6x2C - 6x4	Length between the eye centres: Open Closed Stroke	MANNESMANN SACHS 652 ± 3 402 ± 3 250	ARVIN 652 ± 3 404 ± 3 248
SHOCK ABSORBERS  Vehicles: 4x2 ../FP-D 6x2 ../FP-D	Length between the eye centres: Open Closed Stroke	MANNESMANN SACHS 776 ± 3 466 ± 3 310	WAY- ASSAUTO 776 ± 3 469 ± 3 307
SHOCK ABSORBERS  Vehicles: 4x2	Length L: Open Closed Stroke	FICHEL & SACHS 720 ± 3 410 ± 3 310	WAY- ASSAUTO 720 ± 3 412 ± 3 308
SHOCK ABSORBERS  Vehicles: 6x2P	Length between the eye centres: Open Closed Stroke	MANNESMANN SACHS 752 ± 3 452 ± 3 300	ARVIN 752 ± 3 457 ± 3 295
SHOCK ABSORBERS  Vehicles: 4x2	Length L: Open Closed Stroke	MANNESMANN SACHS 762 ± 3 432 ± 3 330	
SHOCK ABSORBERS  Vehicles: 4x2 ../T/P - 4x2 ../T/FP	Length between the eye centres: Open Closed Stroke	SACHS 652 ± 3 402 ± 3 250	ARVIN MERITOR 652 ± 3 404 ± 3 248

AIR SUSPENSION SYSTEM DIAGRAMS**Rear air suspension main diagram for 4X2P vehicles****Figure 26**


79503

1. Check valve - 2. Rear axle electropneumatic distributor - 3. Rear level sensor - 4. Pressure control intake -
 5. Rear axle air spring - 6. Pressure relief valve with limited return - 7. Condensate hand bleeder - 8. 20 lt. air reservoirs -
 9. Pressure gauge (opening pressure 8 bar) - 10. MUX electric system.

Working diagram of pneumatic rear suspensions for 4x2T/P tractors**Figure 27**


73706

1. Check valve – 2. Rear axle electro-pneumatic control valve – 3. Rear level sensor – 4. Pressure test point – 5. Rear axle air spring – 6. Controlled pressure valve with limited return (opening pressure 8.5 bars) – 7. Manual condensate bleed valve – 8. 20-litre air tanks – 9. Pressure switch (opening pressure 8 bars) – 10. MUX electric system.

Suspension diagram for tractors and cabin vehicles 4x2T/FP**Figure 28**

73707

1. Front level sensor – 2. Front axle air spring – 3. Front electro-pneumatic control valve – 4. Rear electro-pneumatic control valve – 5. Rear level sensor – 6. Pressure test point – 7. Rear axle air spring – 8. Check valve – 9. Controlled pressure valve with limited return (opening pressure 8.5 bars) – 10. Manual condensate bleed valve – 11. 20-litre air tanks – 12. Pressure switch (opening pressure 8 bars) – 13. MUX electric system.


Working diagram of air suspensions for 6x2Y/FP/FS-D/FP-D vehicles**Figure 29**

73712

1. Front level sensor – 2. Front axle air spring – 3. Front axle electro-pneumatic control valve – 4. Rear and added third axle electro-pneumatic control valve – 5. Pressure test point – 6. Rear axle air spring – 7. Rear level sensor – 8. Rear axle suspension pressure switch – 9. Rear added axle suspension pressure switch – 10. Rear added axle air spring – 11. Check valve – 12. Rear added axle lift pressure switch – 13. Rear added axle lift air spring – 14. Controlled pressure valve with limited return (opening pressure 8,5 bars) – 15. Manual condensate bleed valve – 16. 30-litre air tank – 17. 80-litre air tank – 18. Pressure switch (opening pressure 8 bars) – 19. MUX electric system – 20. Check valve.


Working diagram of air suspensions for 6x2Y/FP/FS-D/FP-D vehicles (without lifting the additional axle)

Figure 30



1. Front level sensor – 2. Front axle air spring – 3. Front electro-pneumatic control valve – 4. Rear and added third axle electro-pneumatic control valve – 5. Pressure test point – 6. Rear axle air spring – 7. Rear level sensor – 8. Rear axle suspension pressure switch – 9. Rear added axle suspension pressure switch – 10. Rear added axle air spring – 11. Check valve – 12. Controlled pressure valve with limited return (opening pressure 8.5 bars) – 13. Manual condensate bleed valve – 14. 30-litre air tank – 15. Pressure switch (opening pressure 8 bars) – 16. MUX electric system – 17. Check valve.

79502


Working diagram of air suspensions for 6x2Y/FP/FS-CM vehicles**Figure 31**

73712

1. Front level sensor – 2. Front axle air spring – 3. Front axle electro-pneumatic control valve – 4. Rear and added third axle electro-pneumatic control valve – 5. Pressure test point – 6. Rear axle air spring – 7. Rear level sensor – 8. Rear axle suspension pressure switch – 9. Rear added axle suspension pressure switch – 10. Rear added axle air spring – 11. Check valve – 12. Rear added axle lift pressure switch – 13. Rear added axle lift air spring – 14. Controlled pressure valve with limited return (opening pressure 8,5 bars) – 15. Manual condensate bleed valve – 16. 30-litre air tank – 17. 80-litre air tank – 18. Pressure switch (opening pressure 8 bars) – 19. MUX electric system – 20. Check valve.


Working diagram of air suspensions for 6x2Y/FP/FS-CM vehicles (without lifting the additional axle)

Figure 32



73710

1. Front level sensor – 2. Front axle air spring – 3. Front axle electro-pneumatic control valve – 4. Rear and added third axle electro-pneumatic control valve – 5. Pressure test point – 6. Rear axle air spring – 7. Rear level sensor – 8. Rear axle suspension pressure switch – 9. Rear added axle suspension pressure switch – 10. Rear added axle air spring – 11. Check valve – 12. Controlled pressure valve with limited return (opening pressure 8.5 bars) – 13. Manual condensate bleed valve – 14. 30-litre air tank – 15. 80-litre air tank – 16. Pressure switch (opening pressure 8 bars) – 17. MUX electric system – 18. Check valve.

Working diagram of rear air suspensions for 6x2Y/PT vehicles**Figure 33**


73713

1. MUX electric system – 2. Pressure switch (opening pressure 8 bars) – 3. Check valve – 4. Pressure test point – 5. Rear axle electro-pneumatic control valve – 6. Rear axle air spring – 7. Rear axle suspension pressure switch – 8. Rear added axle air spring – 9. Rear added axle suspension pressure switch – 10. Check valve * - 11. Rear added axle lift pressure switch – 12. Rear added axle lift air spring – 13. Level sensor – 14. Controlled pressure valve with limited return – 15. Manual condensate bleed valve – 16. 30-litre air tanks.

* (Both need to be fitted on the vehicle with the connection 1 facing downwards.)

Working diagram of rear air suspensions for 6x2Y/PT vehicles (without lifting the additional axle)


Figure 34



79501

1. MUX electric system – 2. Pressure switch (opening pressure 8 bars) – 3. Check valve – 4. Pressure test point – 5. Rear axle electro-pneumatic control valve – 6. Rear axle air spring – 7. Rear axle suspension pressure switch – 8. Rear added axle air spring – 9. Check valve * - 10. Rear added axle suspension pressure switch – 11. Level sensor – 12. Controlled pressure valve with limited return – 13. Manual condensate bleed valve – 14. 30-litre air tanks.

* (Both need to be fitted on the vehicle with the connection 1 facing downwards.)

Working diagram of rear air suspensions for 6x2Y/PS vehicles**Figure 35**


73714

1. MUX electric system – 2. Pressure switch (opening pressure 8 bars) – 3. Check valve – 4. Pressure test point – 5. Rear axle electro-pneumatic control valve – 6. Rear axle air spring – 7. Rear axle suspension pressure switch – 8. Rear added axle air spring – 9. Rear added axle suspension pressure switch – 10. Check valve * – 11. Rear added axle lift pressure switch – 12. Rear added axle lift air spring – 13. Level sensor – 14. Controlled pressure valve with limited return (opening pressure 8.5 bars) – 15. Manual condensate bleed valve – 16. 30-litre air tanks.

* (Both need to be fitted on the vehicle with the connection 1 facing downwards.)

Working diagram of rear air suspensions for 6x2Y/PS vehicles (without lifting the additional axle)


Figure 36



73715


1. MUX electric system – 2. Pressure switch (opening pressure 8 bars) – 3. Check valve – 4. Pressure test point – 5. Rear axle electro-pneumatic control valve – 6. Rear axle air spring – 7. Rear axle suspension pressure switch – 8. Rear added axle air spring – 9. Rear added axle suspension pressure switch – 10. Check valve * – 11. Level sensor – 12. Controlled pressure valve with limited return – 13. Manual condensate bleed valve – 14. 30-litre air tanks.

* (Both need to be fitted on the vehicle with the connection 1 facing downwards.)

Working diagram of air suspensions for 6x2TX/P vehicles**Figure 37**

73716

1. Check valve – 2. Rear and second steering axle electro-pneumatic control valve – 3. Central added axle suspension pressure switch – 4. Second steering axle air spring – 5. Pressure test point – 6. Rear axle air spring – 7. Rear level sensor – 8. Pressure sensor – 9. 15-litre air tank – 10. Manual condensate bleed valve – 11. Controlled pressure valve with limited return (opening pressure 8.5 bars) – 12. 20-litre air tanks – 13. Pressure switch (opening pressure 8 bars) – 14. MUX electric system.

Working diagram of pneumatic rear suspensions for 6x4 TZ/P vehicles**Figure 38**

73719

1. Check valve – 2. Rear axle electro-pneumatic control valve – 3. Rear level sensor – 4. Rear axle air spring – 5. Pressure test point – 6. Controlled pressure valve with limited return (opening pressure 8.5 bars) – 7. Manual condensate bleed valve – 8. 30-litre air tanks – 9. Pressure switch (opening pressure 8 bars) – 10. MUX electric system.


CHARACTERISTICS AND DATA**Pneumatic System**

DESCRIPTION	
Controlled pressure valve	
☐ Type: KNORR-BREMSE DR 4248 - WABCO 434 100 299	
Opening pressure	8,5 $\begin{smallmatrix} +0 \\ -0,3 \end{smallmatrix}$ bar
Electro-pneumatic control valves	
☐ Type: WABCO:	
• 472 880 020 – 4 x 2 FP – 6 x 2p FP - 4 x 2 FP tractors	
• 472 880 030 – 4 x 2 P Tractors (for rear axle)	
• 472 880 001 – 4 x 2 FP/P – 4 x 2 FP tractors	
• 472 880 103 – 6 x 2p P/FP	
• 472 880 100 – 6 x 2 C Tractors	
Supply voltage	24V
Nominal current	0.32A - 0.34A
Working pressure	5 ± 13 bar
Level sensors	
☐ Type: WABCO 441 050 012	
Supply voltage	Pulse 5 to 16 V
Measuring principle	Inductive
Current input	Max 90 mA
Working range of lever	Max 100°
Check valve	
☐ Type: VOSS 56900209	
Maximum working pressure	12 bar
Suspension pressure switch	
☐ Type: WABCO 441 040 015	
Supply voltage	8 ÷ 32 V
Current input	Max 30 mA
Measuring range	0 ÷ 10 bar
Permissible overpressure	16 bar
Tightening torque	27 ± 2 Nm
Low air pressure switch	
☐ Type: TDS FI3046 S	
Working voltage	12/24 V
Permissible electric load	0.001 ÷ 1 A
Maximum working pressure	12 bar
Tightening torque	30 ± 2 Nm
Opening pressure	8 ± 0,2 bar
Manual condensate bleed valve	
☐ Type: VOSS 52089975	
Maximum working pressure	13 bar
Air tanks	
Tanks	30 Litres
Tanks	20 Litres
Tanks	15 Litres
Electronic control unit	
☐ WABCO 446170201 (4 x 2, 6 x 4 P vehicles)	
☐ WABCO 446170202 (6 x 2 vehicles)	
Supply voltage	24 Volt

MAIN COMPONENTS OF THE PNEUMATIC SYSTEM

793824 Controlled pressure valve

Figure 39



This limited return valve fulfils two functions:


- ☐ It cuts off the flow of compressed air supplying the tanks when the pressure in the tanks falls under a certain level (setting) after a breakdown or due to excessive drawing;
- ☐ It supplies these tanks as soon as the braking system reaches a value ensuring fully efficiency for the brakes.

Fault Diagnosis

TROUBLE	POSSIBLE CAUSE	REMEDY
Exhaust leak	Leakage from diaphragm	Overhaul the appliance, replacing worn parts
Air leak from joint of half-bodies	Leakage from the diaphragm fitting	
Delivery leak (into the atmosphere) with supply at a lower pressure than the setting	Leakage from the inlet valve or its seat	Overhaul the appliance, replacing worn parts.

Level sensor

Figure 40



The sensor comprises a coil, secured on the chassis frame, in which a piston moves that is connected via a cam to the lever, which is anchored to the vehicle axle.

With a change in height between the chassis frame and vehicle axis, the lever turns, moving the piston that accordingly changes the inductance of the coil wired to the electronic control unit.


The level sensor constantly informs the electronic control unit on the change in attitude of the chassis frame with the road surface.

Electro-Pneumatic Control Valve

The electro-pneumatic control valve comprises a set of electromagnetic valves whose concentration reduces both the volume of the structure and the use of connections.

The solenoid valves are controlled directly by the electronic control unit and make it possible to increase, decrease or hold the volume of air in the pneumatic cells.

Figure 41




73808

FRONT AXLE ELECTRO-PNEUMATIC CONTROL VALVE

for 4x2 – 6x2 – FP chassis cabs and 4x2 - FP tractors

Figure 42




73809

REAR AXLE ELECTRO-PNEUMATIC CONTROL VALVE

for 4x2 P tractors

Figure 43




73810

REAR AXLE ELECTRO-PNEUMATIC CONTROL VALVE

for 4x2 FP tractors and 4x2 P/FP trucks

Figure 44




73811

REAR AXLE ELECTRO-PNEUMATIC CONTROL VALVE

for 6x2 P chassis cabs

Figure 45




73813

REAR AXLE ELECTRO-PNEUMATIC CONTROL VALVE

for 6x2 TxP tractors

Load detector pressure sensor

Figure 46




52722

The pressure switches of the suspensions are located on the rear pneumatic cells.

The pressure switches transduce pressure into an electric signal to inform the control unit of the load weighing on the axles concerned to permit automatic lifting, lowering and pickup aids.

Low air pressure switch

Figure 47




52723

The pressure switch is located near the service air tank on the delivery pipe for the air suspensions.

Its function is to signal a low supply pressure (< 8 bars) via the optical indicator on the instrument panel.

5007 Air spring

Figure 48




30106

This flexible element is designed to contain pressurized air and is capable of changing its extension irrespective of the load applied.

ECAS Control Unit

Figure 49



73819

The electronic control unit keeps the vehicle's chassis frame at a constant height off the ground according to the data stored in it or set by the driver.

FAULT DIAGNOSIS

SECTION I

ECAS system troubleshooting can be performed with the Cluster or with the diagnosis instruments Modus, IWT and IT 2000.

Diagnosis with the cluster makes it possible to estimate the situation of faults in the system in advance, while the diagnosis instruments are essential to perform thorough diagnosis and operate on the single faults correctly.

Each single instrument displays the diagnosis and repair help.

Diagnosis Instruments

MODUS (Maintenance and Diagnostic System)

A computerized fault-diagnosis station dedicated to diagnosing the brake systems, air suspensions, engines and systems controlled electronically.

The station is equipped with auxiliary functions, such as: programming electronic control units, consulting the spare parts catalogue and service time schedules.

The vehicle has a 30-pin diagnosis socket to interface with the instrument.

IWT (IVECO Wiring Tester)

The IVECO Wiring Tester expands and integrates MODUS.

This instrument is made by IVECO to improve fault diagnosis of vehicle electric and electronic systems.

The vehicle has a 30-pin diagnosis socket to interface with the instrument; the connection between the instrument and the diagnosis socket must be made with the cable identified as no. 4.

IT 2000 (IVECO Electronic Tester)

This makes it possible to take immediate action on the vehicle, identifying it with the chassis number.

It saves the results of diagnostics actions performed.

It can be used as a portable Personal Computer, too, being fitted for remote diagnosis.

By using MODUS as the mother station it is possible to update and configure the IT 2000.

IT 2000 interfaces with the vehicle via a 30-pin diagnosis socket.




The diagnosis socket is in the central panel right lower side (in the cabin).

Cluster Diagnosis

It is possible to access the fault memory with the "menu" function key 2 on the steering wheel.

Figure 50



74375

With the ignition key on MAR (+15), press the "menu" function key 2; the display will show a dialogue menu containing a list of the available functions (e.g., Hi-Fi, phone, diagnostics, etc.).

With the 1 and 1 function keys, select the diagnosis function and confirm the selection with the "OK" function key 2.


Select the ECAS system with the select/confirm keys 1 and 2.

Select the ECAS system with the select/confirm keys 1 and 2.

The cluster will display the first diagnostics screen.

After selecting the system, EuroTronic is displayed on a red or green background depending on whether there is any trouble.

Figure 51




74380

The diagnosis information shown on the cluster is split up on two screens:

- ☐ On the first one, it is possible to consult and scroll through all saved/present trouble.
- ☐ On the second one, it is possible to delete the intermittent errors (when you have the relevant password).

FIRST SCREEN

Figure 52



74380

The information on the single faults is arranged on four columns with the following content:

DTC	FMI	OC	ACT
Displays the fault code number	Indicates the type of fault	Fault frequency meter	Fault active/not active status
Two digits (hexadecimal)	Two digits (hexadecimal)	Three digits (hexadecimal)	One character (Y = Yes, N = No)

Troubleshooting via DTC-FMI codes described under the relevant section completes the above information. Each pair of DTC-FMI codes is associated with a description of the fault, the possible system reaction and recommended repairs with the relevant checks.

SECOND SCREEN


Deleting Errors

To select the second screen, press "page" on the steering wheel.

The fault display is eliminated as follows:

- ☐ Press "+", on the request to confirm deletion, press OK.
- ☐ Enter the required password (see the ENTERING PASSWORD paragraph).
- ☐ Press OK to confirm.


Figure 53



74386

Entering the Password

Figure 54



74378a

Select the first number of the password with the and keys.

Press OK to confirm each number.

Press to delete the last number selected.


On completing the password, select the key symbol to confirm.


SECTION 2

Main suspension faults of a mechanical nature:

- 1 - Noisy suspension.
- 2 - Vehicle pulls to one side.

- 3 - Excessive flexibility of suspension.
- 4 - Squeaking, knocking, excessive noise in general.





4

SQUEAKING, KNOCKING, EXCESSIVE NOISE IN GENERAL

Leaf spring mountings loose

- YES →

Check mountings and if necessary renew loose shackle pins

NO



Leaf spring pack loose due to broken centre bolt

- YES →

Overhaul the leaf springs and renew the centre bolt and self-locking nut

NO



Leaf spring pack loose due to breakage of pins securing the spring clamps

- YES →

Check leaf spring clamps and renew the pins.

NO



Wheel bearings worn

- YES →

Renew bearings, if necessary.

NO



Excessive wear or play of bearings at central pivot of cantilever suspension


- YES →

Renew bearings and/or adjust axial clearances of bearings.


TOOLS

TOOL No.


DESCRIPTION

99305117


Instrumentation to check pneumatic circuits

99321024


Hydraulic trolley to remove and refit wheels

99327002


Modus station

99327500







Iveco Wiring Tester







99331016


Unitester case with multimeter and current pincers

99331100


Iveco Tester case

TOOLS	
TOOL No.	DESCRIPTION
99341035 	High pressure pump for assembling suspension pin and bracket
99345055 	Reaction block for puller tools
99346001 	Base installing tool (use with specific bushes)
99346004 	Threaded bush (use with 99346001 and 99363245)
99346049 	Tool for removing and refitting rubber pads on stabiliser bar and leaf spring
99346238 	Sleeve for fitting inner oblique bearing inner race (use with specific bushes)


TOOLS	
TOOL No.	DESCRIPTION
99346243 	Sleeve for fitting outer oblique bearing inner race (use with specific bushes)
99346247 	Reference pads for ECAS suspension calibration
99346248 	Reference pads for ECAS suspension calibration (Low Tractor only). Use with 99346247 for rear axles.
99348002 	Puller tool with adjustable tie-rods
99363245 	Threaded bush (use with 99346001 and 99346004)
99363296 	Tool to be applied on bearing holder pin for assembling oblique bearing inner ring (use with 99346001 - 99346994 - 99346238 - 99346243 - 99363245)

TOOLS**TOOL No.****DESCRIPTION****99370007**

Interchangeable grip for drifts

99374094

Drift for fitting bearing outer rings (134 to 215) (use with 99370007)


99374119

Installing tool for fitting seal on spring support

TIGHTENING TORQUES


Mechanical front suspension

Figure 55




61551

PART		TORQUE	
		Nm	kgm
1	M14 flanged nut for bolt securing front mounting to chassis frame	200 to 160	20 to 16
2	M20 × 1.5 flanged nut for bolt fixing front and rear leaf spring	780 to 640	78 to 64
3	M18 screw fixing stabilizer bar to link rod	715 to 585	71.5 to 58.5
4	M12 socket-head screw fixing flexible connection to axle	122 to 100	12.2 to 10
5	M20 × 1.5 nut with collar for brackets: fixing leaf spring to axle	510 to 410	51 to 41
6	M16 flanged nut for bolt fixing bottom shock absorber	165 to 135	16.5 to 13.5
7	M20 × 1.5 flanged nut for bolt fixing shackle to rear mounting	780 to 640	78 to 64
8	M14 × 1.5 nut fixing top shock absorber	70 to 57	7 to 5.7
9	M20 flanged nut for bolt fixing stabilizer bar to mounting	480 to 395	48 to 39.5

Pneumatic front suspension**Figure 56**

PART		TORQUE	
		Nm	kgm
1	M14 flanged nut for bolt securing front mounting to chassis frame	200 to 160	20 to 16
2	M20 x 1.5 flanged nut for bolt fixing front and rear leaf spring	780 to 640	78 to 64
3	M18 screw fixing stabilizer bar to link rod	715 to 585	71.5 to 58.5
4	M12 socket-head screw fixing flexible connection to axle	122 to 100	12.2 to 10
5	M20 X 1.5 flanged nut for brackets: fastening of leaf spring to axle	510 to 410	51 to 41
6	M16 flanged nut for bolt fixing bottom shock absorber	165 to 135	16.5 to 13.5
7	M16 screw fixing air spring	249 to 204	24.9 to 20.4
8	M20 x 1.5 flanged nut for bolt fixing shackle to rear mounting	780 to 640	78 to 64
9	M14 x 1.5 flanged nut fixing top shock absorber for bolt fixing top shock absorber	70 to 57	7 to 5.7
	M16 flanged nut for bolt fixing top shock absorber	165 to 135	16.5 to 13.5
10	M20 flanged nut for bolt fixing stabilizer bar to mounting	480 to 395	48 to 39.5


Pneumatic front suspension with bars**Figure 57**

74373

PART		TORQUE	
		Nm	kgm
1	M18 screw fixing longitudinal rods to mountings	420 to 344	42 to 34.4
2	M20 nut for pin fixing link rod to chassis frame and to stabilizer bar	480 to 395	48 to 39.5
3	M14 screw fixing flexible anchor to axle	197 to 161	19.7 to 16.1
4	M12 screw fixing air spring to mounting	133 to 109	13.3 to 10.9
5	M20 x 1.5 nut for bolt fixing anchoring mount to axle	510 to 417	51 to 41.7
6	M20 screw fixing shock absorber to axle	285 to 233	28.5 to 23.3
7	M16 nut for bolt fixing Panhard bar to mountings	227 to 186	22.7 to 18.6
8	M14 x 1.5 nut fixing shock absorber to chassis frame	70 to 57	7 to 5.7

Central added axle pneumatic suspensions
6x2 C vehicles

Figure 58




73802

PART		TORQUE	
		Nm	kgm
1	M14 flanged nut for bolt fixing front mounting to chassis frame	200 to 160	20 to 16
2	M20 × 1.5 flanged nut for bolt fixing front leaf spring	780 to 640	78 to 64
3	M18 screw fixing stabilizer bar to link rod	715 to 585	71.5 to 58.5
4	M12 socket-head screw fixing flexible connection to axle	122 to 100	12.2 to 10
5	M20 × 1.5 nut with collar for brackets: fixing leaf spring to axle	510 to 410	51 to 41
6	M16 flanged nut for bolt fixing bottom and top shock absorber	165 to 135	16.5 to 13.5

Pneumatic rear suspension 4x2 – 6x2 C vehicles

Figure 59




61552

PART		TORQUE	
		Nm	kgm
1	M18 x 1.5 screw fixing triangular arm to bracket	385 to 320	38.5 to 32
2	M18 x 1.5 nut for bolt fixing longitudinal rod to bracket	460 to 375	46 to 37.5
3	Nut fixing air springs to the mounting	101 to 83	10.1 to 8.3
4	M18 x 1.5 nut for screw fixing longitudinal rod	460 to 375	46 to 37.5
5	M24 x 2 nut with collar for brackets fixing rear axle to rear mounting	900 to 750	90 to 75
6	M20 nut for screw fixing top and bottom shock absorber	250 to 210	25 to 21
7	M20 nut for pin fixing stabilizer bar to mounting: - 16750725 - 16984735 - 8161193	480 to 395 685 to 560 777 to 636	48 to 39,5 68,5 to 56 77,7 to 63,6
8	M12 nut for bolt fixing stabilizer bar to link rod	200 to 165	20 to 16.5
9	M20 nut for pin fixing link rod to mounting: - 16750725 - 16984735 - 8161193	480 to 395 685 to 560 777 to 636	48 to 39,5 68,5 to 56 77,7 to 63,6
10	M16 x 1.5 screw fixing triangular arm to rear axle housing	320 to 260	32 to 26

Pneumatic rear suspension
6x2 P/PT/FT vehicles

Figure 60




REAR SUSPENSION ASSEMBLY DRAWING

73803

PART		TORQUE	
		Nm	kgm
1	M18 screw fixing triangular arm to rear axle housing	320 to 260	32 to 26
2	M20 flanged nut fixing stabilizer bar on air spring mounting and fixing link rod on chassis frame bracket	777 to 636	77.7 to 63.6
3	Nut for bolt fixing flexible anchoring to link rod	200 to 165	20 to 16.5
4	Nut fixing air spring to mounting	101 to 83	10.1 to 8.3
5	M24 nut with collar for brackets fixing rear axle to suspension mounting	900 to 750	90 to 75
6	M18 x 1.5 nut fixing longitudinal rods	460 to 375	46 to 37.5
7	M20 nut fixing top and bottom shock absorber for rear axle	250 to 210	25 to 21
8	M20 nut fixing top and bottom shock absorber for added axle	250 to 210	25 to 21
9	M20 nut with collar for brackets fixing added axle and rear axle to suspension mounting	510 to 410	51 to 41
10	M20 nut for pin fixing stabilizer bar to added axle	480 to 395	48 to 39.5
11	Nut for bolt fixing stabilizer bar flexible anchoring to link rod	200 to 165	20 to 16.5
12	M20 nut for pin fixing link rod to chassis frame bracket	480 to 395	48 to 39.5
13	Nut fixing air spring	101 to 83	10.1 to 8.3
14	M16 self-locking nut fixing triangular arm to added axle	310 to 250	31 to 25
15	M18 screw fixing triangular arm to bracket	385 to 320	38.5 to 32

Pneumatic rear suspension
6x2 P/FP/FS vehicles

Figure 61




REAR SUSPENSION ASSEMBLY DRAWING

PART		TORQUE	
		Nm	kgm
1	M16 screw fixing triangular arm to rear axle housing	320 to 260	32 to 26
2	M20 flanged nut fixing stabilizer bar on air spring mounting and fixing link rod on chassis frame bracket	685 to 580	68.5 to 58
3	Nut for bolt fixing flexible anchoring to link rod	200 to 165	20 to 16.5
4	Nut fixing air spring to mounting	101 to 83	10.1 to 8.3
5	M24 nut with collar for brackets fixing rear axle to suspension mounting	900 to 750	90 to 75
6	M18 x 1.5 nut fixing longitudinal rods	460 to 375	46 to 37.5
7	M20 nut fixing top and bottom shock absorber for rear axle	250 to 210	25 to 21
8	M20 nut for pin fixing stabilizer bar to added axle	480 to 395	48 to 39.5
9	M24 nut fixing top and bottom shock absorber for added axle	440 to 360	44 to 36
10	Nut for bolt fixing stabilizer bar flexible anchoring to link rod	200 to 165	20 to 16.5
11	M20 nut for pin fixing link rod to chassis frame bracket	480 to 395	48 to 39.5
12	Nut fixing air spring	101 to 83	10.1 to 8.3
13	M16 self-locking nut fixing triangular arm to added axle	310 to 250	31 to 25
14	M18 screw fixing triangular arm to bracket	385 to 320	38.5 to 32

Pneumatic rear suspension
6x2 P/PS vehicles

Figure 62




REAR SUSPENSION ASSEMBLY DRAWING

PART		TORQUE	
		Nm	kgm
1	M16 screw fixing triangular arm to rear axle housing	320 to 270	33 to 27
2	M20 flanged nut fixing stabilizer bar on air spring mounting and fixing link rod on chassis frame bracket	685 to 560	68.5 to 56
3	Nut for bolt fixing flexible anchoring to link rod	200 to 165	20 to 16.5
4	Nut fixing air spring to mounting	101 to 83	10.1 to 8.3
5	M24 nut with collar for brackets fixing rear axle to suspension mounting	704 to 576	70 to 57.6
6	M18 x 1.5 nut fixing longitudinal rods	460 to 375	46 to 37.5
7	M20 nut fixing top and bottom shock absorber for rear axle	250 to 210	25 to 21
8	M20 nut for pin fixing stabilizer bar to added axle	480 to 395	48 to 39.5
9	M24 nut fixing top and bottom shock absorber for added axle	440 to 360	44 to 36
10	Nut for bolt fixing stabilizer bar flexible anchoring to link rod	200 to 165	20 to 16.5
11	M20 nut for pin fixing link rod to chassis frame bracket	480 to 395	48 to 39.5
12	Nut fixing air spring	101 to 83	10.1 to 8.3
13	M16 self-locking nut fixing triangular arm to added axle	310 to 250	31 to 25
14	M18 screw fixing triangular arm to bracket	385 to 320	38.5 to 32

Pneumatic rear suspension
6x4 P vehicles

Figure 63



PART		TORQUE	
		Nm	kgm
1	M18 screw fixing triangular arm to rear axle housing	330 to 270	33 to 27
2	M20 flanged nut fixing stabilizer bar on air spring mounting and fixing link rod on chassis frame bracket	685 to 560	68.5 to 56
3	Nut for bolt fixing flexible anchoring to link rod	200 to 165	20 to 16.5
4	Nut fixing air spring to mounting	101 to 83	10.1 to 8.3
5	M20 nut with collar	900 to 750	90 to 75
6	M24 nut with collar for brackets fixing rear axle to suspension mounting	704 to 576	70.4 to 57.6
7	M20 nut fixing top and bottom shock absorber for rear axle	250 to 210	25 to 21
8	M18 x 1.5 nut fixing longitudinal rods	460 to 375	46 to 37.5
9	M18 screw fixing triangular arm to bracket	385 to 320	38.5 to 32

500410 REMOVAL-REFITTING OF FRONT LEAF SPRING



Removal

Park the vehicle on level ground and chock the rear wheels. Loosen the front wheel nuts. Using a hydraulic jack, raise the front of the vehicle and support it on two stands. Unscrew the wheel nuts and using hydraulic trolley 99321024, remove the wheels.

Position a hydraulic jack to support the axle when the leaf spring is detached. Then, lower the hydraulic jack supporting the axle until the tension on the leaf spring is relieved. Remove the lower access step (15) as follows: Working from underneath the vehicle, remove the bolts (12) securing the U-bolts (13) to the bracket. At the side, remove the screw and the nut (16) with the front bumper and extract the access step assembly (15). Take out the screw (21) fixing the leaf spring (20) to the rear shackle (22).



If the screw (21) is fitted with its head on the outer side of the vehicle, it will first be necessary to remove the side access step – air filter assembly (detail B) used to help remove the front suspension. Proceed as described below: Remove the bolts (6) and (7) located inside the battery compartment. Take out the screws (24) fixing the handrail and the bottom (4) and top (10) screws fixing the handrail and the steps to the vehicle. Remove the access steps and the handrail. Disconnect the batteries and remove them from the battery compartment. Remove the bolt (5) and nuts (8). Take out the screw (1) fixing the air pipe. Disconnect the air sensor (9). Remove the bracket bolts (3) and loosen the air hose retaining strap (2) (detail A). Remove the air cleaner complete with its hoses. Remove the fastening (11) from the front mounting (14). Unscrew the four nuts (17) and extract the U-bolts (18). Disengage the shock absorber (23) front the suspension via the fastening (19). Remove the leaf spring (20).




Refitting

Carry out the removal operations in reverse order, observing the prescribed torque settings.



To secure the leaf spring on two connections to the chassis frame it is necessary to load it so as to stretch it to align the holes, using appropriate tools and with the opposition of the load of the vehicle and the hydraulic lifts.

Figure 64



REMOVING-REFITTING FRONT SUSPENSION BARS



Removing longitudinal bars

Park the vehicle on level ground and chock the rear wheels.
Loosen the front wheel nuts.
Put a hydraulic jack equipped with mount 99370628 under the axle.
Lift the vehicle at the front, rest it on two stands and, with the hydraulic jack and mount 9937628, support the axle so that the longitudinal bars (3) and (8) are parallel to the chassis frame.
Remove the cab access steps. Take out the bolts (6) and remove the access step mount (7).
Take out the screws (5) and disconnect the bottom bar (8) from the mount (4). Repeat these operations for the top bar (3).
Repeat the above for the opposite side.



Removing transverse bar

Take out the screws (9) and remove the transverse bar (1) from the mounts (2) and (10).




Refitting


For refitting, perform the operations described for removal in reverse order, keeping to the following instructions:

the swivel head shanks (14) and (15) of the longitudinal bars (3) and (8) need to be connected to the mountings (4) and (12) when there is a distance $X = 154$ mm between the mountings (12) and the structural members (13);
the swivel head shanks (11) of the transverse bar (1) need to be connected when there is a distance $X = 224.5$ mm between the mountings (12) and structural members (11);

- ☐ tighten the nuts or screws to the required tightening torque;
- ☐ the self-locking nuts must not be reused;
- ☐ check the state of the flexible pads and replace them if deteriorated (operation 500417).

Figure 65



500730 REAR SUSPENSIONS**Removal****Figure 66**

The following operations have been performed on a 4x2 T/P vehicle, but they are to be considered good for the other vehicles too.

Park the vehicle on level ground.

Raise the vehicle at the rear and place two stands under the chassis frame.

Remove the wheels, unscrew the screws (13) and disconnect the linkage (3) of the level sensor (1).

Unscrew the nuts (10) and disconnect the reaction bar (11). Unscrew the nuts (2) and (8) and remove the shock absorber (4).

Unscrew the nuts (5) fastening the air springs.

Unscrew the nuts (9), take out the associated U-bolts and remove the arm (12) supporting the air springs.

Unscrew the screw (7) and remove the stabilizer bar (6) from the air spring mounting (12).

Refitting

For refitting, perform the operations described for removal in reverse order, keeping to the following instructions:



72895

- 528913 REMOVING-REFITTING THE REAR AXLE LONGITUDINAL SUSPENSION ARM
 528914 REMOVING-REFITTING THE REAR ADDED AXLE LONGITUDINAL SUSPENSION ARM
 528918 REMOVING-REFITTING THE REAR AXLE TRIANGULAR SUSPENSION ARM
 528919 REMOVING-REFITTING THE REAR ADDED AXLE TRIANGULAR SUSPENSION ARM



Removal


Take out the nuts or screws (⇒) fixing the longitudinal (2, Figure 68) or triangular (1, Figures 48-49) suspension arms and remove them.



Refitting


For refitting, carry out the steps described for removal in reverse order, tightening the nuts or screws to the required torque.

Figure 67



TRIANGULAR SUSPENSION ARM FITTED
ON 6x2 C VEHICLES


Figure 68



LONGITUDINAL AND TRIANGULAR SUSPENSION ARMS FITTED ON 6x2 P VEHICLES

REPLACING THE SUSPENSION ARM FLEXIBLE PIN


Figure 69



38700

LONGITUDINAL SUSPENSION ARM

Figure 70



79479

TRIANGULAR SUSPENSION ARM

Removal

Using a suitable press and drift, compress the flexible part of the pin (1) in order to remove the circlip (2) and the underlying ring (3) with pincers.

Withdraw the pin (1) from the suspension arm (4).

Refitting

Carry out the removal operations in reverse order, bearing in mind that the pin mounting face must be positioned at 90° to the longitudinal axis of the suspension arm. The circlip opening must be oriented as shown in the detail in the figure.

- 5289 STABILIZER BAR**
528930 FRONT STABILIZER BAR
528940 CENTRAL ADDED AXLE STABILIZER BAR (6x2 C vehicles)
528960 REAR STABILIZER BAR
528970 REAR ADDED AXLE STABILIZER BAR (6x2P vehicles)

Removal

Remove the stabilizer bar by removing the nuts or screws securing the fixing pins and the cap retaining bolts.





Check the bushings and/or rubber mountings and renew them if they show signs of wear or deterioration.

Refitting

Refit by carrying out the removal operations in reverse order; tighten nuts/bolts to the specified torques.





Position the half bushings (4) so that the joint is located as shown in the figure.

Figure 71

38694

ASSEMBLY DRAWING FOR FRONT STABILIZER BAR

1. Upper hanger bracket - 2. Link rod - 3. Stabilizer bar - 4. Rubber bushing (in two halves) - 5. Front axle - 6. Cap.


Figure 72

73701

ASSEMBLY DRAWING FOR FRONT STABILIZER BAR: 4x2 - 6x2P VEHICLES WITH AIR SUSPENSION AND LONGITUDINAL BARS

1. Link rod - 2. Upper hanger bracket - 3. Stabilizer bar - 4. Rubber bushing (in two halves) - 5. Front axle - 6. Cap.

Figure 73




ASSEMBLY DRAWING FOR REAR STABILIZER BAR: 4x2 – 6x2C – 6x4 VEHICLES

1. Upper hanger bracket - 2. Link rod - 3. Stabilizer bar - 4. Rubber bushing (in two halves) - 5. Rear axle - 6. Cap.

72238

Figure 74




ASSEMBLY DRAWING FOR REAR AXLE ANTI-ROLL BAR: 6x2 VEHICLES

1. Upper hanger bracket - 2. Link rod - 3. Anti-roll bar - 4. Rubber bush (in two halves) - 5. Front axle.

72237

Figure 75




ASSEMBLY DRAWING FOR REAR ANTI-ROLL BAR: 4x2 VEHICLES

1. Upper hanger bracket - 2. Link rod - 3. Anti-roll bar - 4. Rubber bush (in two halves) - 5. Rear axle - 6. Cap.

38695


Figure 76



ASSEMBLY DRAWING OF REAR STABILIZER BAR FOR 6x2P VEHICLES
AND INTERMEDIATE STABILIZER BAR FOR 6x4 VEHICLES

1. Upper hanger bracket - 2. Link rod - 3. Rubber bushing (in two halves) - 4. Cap - 5. Stabilizer bar - 6. Mounting - 7. Rear axle.


Figure 77



ASSEMBLY DRAWING OF REAR STABILIZER BAR FOR REAR STEERING ADDED AXLE: 6x2P VEHICLES

1. Upper hanger bracket - 2. Link rod - 3. Rubber bushing (in two halves) - 4. Cap - 5. Stabilizer bar - 6. Added axle.

Figure 78



ASSEMBLY DRAWING OF STABILIZER BAR FOR REAR RIGID ADDED AXLE: 6x2P VEHICLES
WITH AIR SUSPENSION

1. Upper hanger bracket - 2. Link rod - 3. Rubber bushing (in two halves) - 4. Cap - 5. Stabilizer bar - 6. Added axle.


RUBBER BUSHINGS

528933 Replacing front stabilizer bar rubber bushings

528933 Replacing rear stabilizer bar rubber bushings


The rubber bushings (4 and 8, Figure 79), (4, Figure 80) and (6, Figure 81) are changed by using tool 99346049 to remove and fit them.

Figure 79




FRONT STABILIZER BAR COMPONENT PARTS
1. Bushing – 2. Mounting – 3. Stabilizer bar – 4. Rubber bushing – 5. Screw – 6. Link rod – 7. Bolt – 8. Rubber bushing – 9. Mounting – 10. Nut – 11. Screw

Figure 80



REAR STABILIZER BAR COMPONENT PARTS
1. Half bushing – 2. Stabilizer bar – 3. Bolt – 4. Rubber bushing – 5. Nut – 6. Mounting – 7. Suspension arm – 8. Suspension arm cap

Figure 81



REAR STABILIZER BAR COMPONENT PARTS
1. Mounting – 2. Nut – 3. Stabilizer bar – 4. Bushing – 5. Pin – 6. Suspension arm – 7. Half bushing – 8. Suspension arm cap

5009 SHOCK ABSORBERS**Removal-refitting****500910 Front axle shock absorbers
(6x2 C vehicles)****500920 Central added axle shock absorbers****500940 Rear axle shock absorbers****500950 Rear added axle shock absorbers
(6x2 P vehicles)****Removal**


Remove the shock absorber by removing the upper and lower mounting nuts or screws.

Inspect the rubber bushings; if worn or deteriorated, renew them.


Check shock absorber efficiency using suitable test equipment.

**Refitting**


Carry out the removal operations in reverse order; tighten bolts and nuts to specified torques.

Figure 82FRONT AXLE SHOCK ABSORBER
WITH MECHANICAL SUSPENSION


38689

Figure 83FRONT AXLE AND CENTRAL ADDED AXLE SHOCK
ABSORBER WITH AIR SUSPENSION

38690

Figure 84

38692

REAR AXLE SHOCK ABSORBER
WITH AIR SUSPENSION**Figure 85**

38693

REAR ADDED AXLE SHOCK ABSORBER


CHASSIS FRAME ADJUSTMENT

The chassis frame is adjusted using tools:

- ☐ 99346247, if the vehicle is a standard one;
- ☐ 99346248, if the vehicle has a lowered chassis frame.

And by adjusting the tie rods of the levelling valves to get the distances X shown in the figures.

Figure 86




73814

FRONT AIR SUSPENSION

X = 65 mm, standard version

X = 55 mm, lowered version

Figure 87




73815

FRONT AIR SUSPENSION WITH LONGITUDINAL BARS: 4x2 – 6x2 P VEHICLES

X = 195 mm

Figure 88




73816

PNEUMATIC STEERING CENTRAL ADDED AXLE SUSPENSION
WITH PARABOLIC LEAF SPRINGS, REAR AIR SUSPENSION: 6x2 C VEHICLES

X = 60 mm


Figure 89



73818

REAR AIR SUSPENSION: 6x2 PS-FS VEHICLES,
STEERING ADDED AXLE THAT CAN BE LIFTED WITH SINGLE WHEELS
Y = 60 mm


Figure 90



73817

REAR AIR SUSPENSION: 6x2 P/FP VEHICLES
FIXED ADDED AXLE THAT CAN BE LIFTED WITH SINGLE WHEELS
X = 60 mm


Figure 91



78162

REAR AIR SUSPENSIONS: 6x2 PT - FT VEHICLES
X = 60 mm

Figure 92



78163

REAR AIR SUSPENSIONS: 6x4 VEHICLES
X = 60 mm

SECTION 10**5025 Wheels and tyres**

	Page
DESCRIPTION	3
CHARACTERISTICS AND DATA	3
☐ Tyre inflation pressures	3
TOOLS	4
FAULT DIAGNOSIS	4
STATIC BALANCING OF THE WHEELS	7
CORRECTING RESIDUAL STATIC IMBALANCE	8
TYRE PRESSURE	8
HOW TYRE BEHAVIOUR DEPENDS ON PRESSURE	9

DESCRIPTION

The wheel rim represents the rigid structure of the wheel and is identified by the following dimensions:

- ☐ diameter of the rim, measured at the base of the circumferential groove (that is, on the surface on which the air chamber rests);
- ☐ width of the circumferential groove in the wheel rim (that is, the distance between the surfaces on which the cover rests);

The tyre has the following functions:

- ☐ to absorb the greater part of the jolts caused by roughness of the road surface by exploiting the elasticity of air;

- ☐ to generate on the ground the motive force supplied by the engine necessary for the vehicle to move;
- ☐ to ensure the maximum grip and stability of contact between the tyre and the road, with satisfactory life;
- ☐ to withstand the forces generated by sudden braking, hard acceleration and by the thrust of centrifugal force on bends;
- ☐ to ensure the stability of the vehicle even at high speeds; to ensure the steerability of the vehicle.

CHARACTERISTICS AND DATA

WHEELS		
	Disc type, with specific continuous rims.	22.5" x 8.25 22.5" x 9 22.5 x 11.75 20 x 8.5

Tyre inflation pressures



When checking tyre pressures, adhere to the values given in the booklet "Use and Maintenance".


TOOLS


TOOL	DESCRIPTION
99305037	Electronic unit for balancing the front wheels on the vehicle

FAULT DIAGNOSIS


Main tyre faults :

- 1 - Excessive wear
- 2 - Irregular wear
- 3 - Vehicle pulls to one side






(continued)



502511 STATIC BALANCING OF THE WHEELS

Figure 1




The front wheels can be balanced on the vehicle using the electronic unit 99305037; this has the great advantage of balancing the wheel together with the other rotating masses.

The operation must be carried out as follows :

- ☐ Raise the front of the vehicle and make sure that the wheels rotate freely
- ☐ Position the imbalance detector (1) under the axle close to the wheel being examined, arranging the height so that the spin-up wheel of unit 99305037 (2) is in contact with the tyre; position a support stand under the opposite side of the axle and lower the hydraulic jack

Figure 2



16997

- ☐ Connect the cable (3) of the imbalance detector to unit 99305037
- ☐ Make a reference mark on the tyre by drawing a radial mark with chalk or using a strip of gummed paper
- ☐ Turn switch (2) to static balancing position and sensitivity switch (4) to notch no. 5 on the graduated scale
- ☐ Turn on switch (5) for instrument light (1) and strobe lamp switch (8).
- ☐ Turn the spin-up switch (6) of unit 99305037 to the first speed position so as to make the wheel rotate.


Turn up the spin switch (6) to second speed and place the balancing machine against the tyre.

While the wheel is being spun, it will be found that the stroboscopic effect on the wheel will make the reference mark appear stationary; the pointer of the instrument (1), moving from the value zero, reaches a maximum value on the scale and then returns to zero.

When the pointer has begun to fall back, withdraw the balancing machine, turn off the spin-up switch (6) completely and brake the motor by means of the brake lever (7). The wheel continues to revolve due to inertia and the reference mark made on the tyre moves; the point to which the reference mark has moved should therefore be noted.

Read off from the instrument (1) the value shown by the pointer, multiply it by 10, to obtain the value of the balance weight to be fitted to the rim.

Figure 3



16998


Fit the balance weight calculated in this way as shown in the figure. If during the test, the pointer of the instrument (I, Figure 2) remains in the green area of the box, the wheel is balanced.



If the weight required to balance the wheel is more than 600 to 800 grams, divide the weight in half and position the two parts so formed with one half on the inside and one half on the outside of the rim, making sure that they are in the same position.

CORRECTING RESIDUAL STATIC IMBALANCE

Figure 4



23885

To correct the residual imbalance, repeat the operations already carried out above; depending to the new reading on the instrument (I, Figure 2), refer to the diagram in Figure 4 and proceed as follows to adjust:

- ☐ If the weight is in the zone marked with letter A, this means that it is too light, and in that case weight must be added as indicated by the instrument (I, Figure 2).
- ☐ If the weight is in the bottom zone marked with letter C, this means that it is too heavy and in that case the weight must be reduced as shown by the measuring instrument.
- ☐ If the weight is found to be in the zones marked with letters B or D, do not remove or add any weight but instead move it 5 cm upwards in the direction of the arrows, see Figure 4.

502510 TYRE PRESSURE

Tyre pressures must be checked with the tyres cold.

Carefully make sure that the pressure is correct since, if it is higher than required, a harsh ride and excessive wear of the centre of the tread will result, while if it is lower, the load is not distributed over the whole tread but is concentrated at either side, causing premature wear of these areas and also damaging the internal structure of the tyre.

Unequal pressures between tyres affects the driving stability of the vehicle and impairs operating safety.

Abnormal wear of the tyres may appear in various areas of the tyre treads.

HOW TYRE BEHAVIOUR DEPENDS ON PRESSURE

Schematic views to demonstrate how tyre behaviour and performance depends on pressure.



(The value shown inside each figure indicates the tyre pressure, whereas the performance refers to the tyre life).

Figure 5





Figure 8



It is advisable to change the tyre pair fitted to one axle when bands - due to block wear - are visible over the entire tread width (see dotted areas on pictures).

Figure 6






Figure 7



Tyres are provided with wear indicators (A and B) in connection with mark TWI on PIRELLI tyres and with the MICHELIN mark on Michelin tyres. Replacement is compulsory when such indicators are reached.

SECTION II


5014 Steering

	Page
DESCRIPTION	3
SPECIFICATIONS AND DATA	4
FAULT DIAGNOSIS	5
TIGHTENING TORQUES	10
TOOLS	11
REMOVING-REFITTING THE POWER STEERING SYSTEM	13
☐ Removal	13
☐ Refitting	15
☐ Removing-Fitting the Steering Lever	15
STEERING CONTROL	16
REMOVING-REFITTING THE STEERING CONTROL ASSEMBLY	17
☐ Removal	17
☐ Refitting	19
☐ Changing the pneumatic cylinder	19
☐ Removal	19
☐ Refitting	20
BLEEDING THE POWER STEERING SYSTEM	22
MEASURING STEERING BOX PLAY AT THE STEERING WHEEL	22
CHECKING THE MAXIMUM PRESSURE OF THE POWER STEERING SYSTEM	22
☐ Setting the automatic hydraulic steering limit ..	22

DESCRIPTION

The ZF 8098 power steering box is a recirculating ball unit; it is essentially comprised of a housing, the integral mechanical steering linkage, the control valve and the power cylinder.



Figure 1



27199

ZF 8098 POWER STEERING BOX

SPECIFICATIONS AND DATA


	Steering system	Hydraulic	
	Power steering	ZF8098 recirculating ball type with integral pressure limiting valve and hydraulic device with automatic adjustment to limit the steering angle	
	Variable working pressure	150+ 15 bar	
	Variable reduction ratio	vehicles	
		Chassis cab and tractor 6x2 C	Excluding tractors 6x2 C
		straight ahead	22.2 : 1
		full lock	17 : 1
	Power steering pump		ZF
	Minimum	rpm	500
	Maximum	rpm	3500
	Maximum pressure (without limiting valve)	bar	150
	Capacity	dm ³ /min	16

* vehicles: 6x2 p / FS-PS


FAULT DIAGNOSIS

Main power steering operating faults :


- | | |
|--|---|
| 1 - Steering stiff when turning right and left | 5 - Torsional vibration of the steering wheel |
| 2 - Steering stiff only when turning left or right | 6 - Excessive play at the steering wheel |
| 3 - Steering stiff when the wheel is turned quickly | 7 - Loss of fluid |
| 4 - When steering, heavy jolts are felt at the wheel | 8 - Insufficient pressure in the circuit |



(Continued)



4

**WHEN STEERING, HEAVY JOLTS
ARE FELT AT THE WHEEL**

Play in universal joint

- YES →

Replace the universal joint

NO



Internal failure of steering unit

- YES →

Send steering unit to a ZF service centre

NO



Insufficient fluid in system

- YES →

Top up fluid and bleed system

NO



Wheel geometry incorrect

- YES →

Check and adjust according to the characteristic data given in the "AXLE" section

NO



Wheels out of balance

- YES →

Balance in accordance with instructions given in the section "Wheels and tyres"

NO



Steering rod joints loose on the arms

- YES →

Replace any worn parts

NO



Irregular pump operation

- YES →

Replace pump


NO



Leakage of fluid from power steering circuit couplings

- YES →

Check coupling seals for serviceability, and replace any which are worn



7

LOSS OF FLUID

Tank cover not secured

- YES →

Secure cover

NO



Deterioration of gaskets and seals

- YES →

Replace worn gaskets and seals, top up fluid and bleed

In every case it is necessary to establish where and why hydraulic fluid is being lost, eliminate the cause and, with the engine running, top up fluid to upper mark on dipstick.

8

**INSUFFICIENT PRESSURE
IN THE CIRCUIT**

Pump not operating correctly

- YES →

Overhaul or replace the hydraulic pump.

NO



Fluid leaking from couplings in power steering circuit

- YES →

Check coupling and seals for serviceability, replacing any which are worn

NO








Insufficient oil level in the tank


- YES →

Top up oil level and bleed circuit


TIGHTENING TORQUES

PART	TORQUE	
	Nm	(kgm)
Flanged hexagonal nut for steering support + pitman arm	226.5±22.5	(22.6±2.3)
Flanged hexagonal head screw for fixing steering gear stand	278±28	(27.8±2.8)
Hexagonal head screw for steering box	527.5±52.5	(52.7±5.3)
Calibrated hexagonal head screw for steering box		
Castellated nut for steering linkage and hydraulic circuit (*)	300	(30)
Self-locking nut for universal joint	55±5	(5.5±0.5)
Calibrated screw for universal joint	55±5	(5.5±0.5)
Fixing flange for track rod and drag link arm	80±10	(8±1)
Hexagonal nut for lever on the steering box	575±55	(57.5±5.5)
Nut for screw fastening steering support	146.5±14.5	(14.6±1.5)
▲ Self-braking flanged hexagonal nut for steering gear stand	226.5±22.5	(22.6±2.3)
▲ Hexagonal head screw for fixing the steering gear stand	248±25	(24.8±2.5)
□ Hexagonal nut with flange for pitman's arm	226.5±22.5	(22.6±2.3)
□ Hexagonal head flanged screw for pitman's arm	278±28	(27.8±2.8)
□ Castellated nut for hydraulic cylinder (*)	400	(40)
□ Castellated nut for steering linkage (*)	250	25
□ Fixing flange for track rod and drag link arm	170±10	(17±1)
□ Fixing flange for drag link bar	80±10	(8±1)
(*) If at the prescribed torque the notch does not correspond to the hole, keep tightening until the split pin can be inserted.		
▲ 4x2 vehicles - 6x2 vehicles with additional rear lifting axle - □ 6x2 vehicle with third steering axle - 6x2C vehicles		


TOOLS	
TOOL NO.	DESCRIPTION
99305446	 Hand pump for hydraulic system filling and drain
99305450	 Series of connections (2) for 99305446 hydraulic pump
99347042	 Steering wheel puller
99347068	 Puller for steering rod ball joints
99355032	 Wrench for power steering fixing screws

TOOLS**TOOL NO.****DESCRIPTION****99374393**

Tool with pressure gauges for checking the power steering hydraulic pressure

99374398

Graduated sector and scale steering wheel play control (to be used with 99374393)


99374399

Couple of expanders for locking the wheels (to be used with 99374393-99374398)

541430 REMOVING-REFITTING THE POWER STEERING SYSTEM

Removal

Figure 2




Set the vehicle with its wheels straight. Tilt the cab.
Put a container under the power steering box and take the cover off the fluid reservoir.
Unscrew the fittings (1-2-6-7), detach the pipes (4 and 5) and drain off the oil. Take out the screw (3) fixing the power steering box to the mounting.
For vehicles with a steering rear added axle only.




For vehicles with a steering added rear axle, before disconnecting the pipes, it is necessary to discharge the pressure from the system as described under the relevant heading.

Figure 3




Disconnect the oil pipe (1).
Disconnect the operating cylinder (3) from the lever (2), removing the split pin and the connecting nut.

Figure 4




Remove the split pin (1) and unscrew the nut (2).

Figure 5




Using an extractor 99347068 (2), disconnect the tie rod (1) from the lever (3).
For vehicles with a central added axle only.

Figure 6



Take out the split pins; unscrew the retaining nuts and remove the relay lever (1).

For all vehicles**Figure 7**


If the vehicle is fitted with a cabin tilting electro-hydraulic control, proceed as follows.

Take out the screws (2), disconnect the F.F.C. (Front Frame Computer) control unit (3) from the chassis frame; take off the cover (1) and reconnect the control unit (3) to the chassis frame. Lower the cab.

Disconnect the corrector (4) from the F.F.C. control unit (3).



After disconnecting the connector (4) it is no longer possible to lift the cab.


Figure 8

Disconnect the pipe (3) from the motor pump (1) for the headlight washer and put a plug (2) into its fitting to prevent the fluid from draining out of the reservoir. Take off the covers (4). Remove the four nuts (5) fixing the bumpers (6) to the cab.

Support the bumper (6) appropriately and detach it from the cab by removing the nuts securing it to the side brackets.




With the bumper moved away from the cab, take out the screw fixing the earth cable to the chassis frame.

Figure 9

Put a wooden plug (2) between the bar (1) and the structural member of the chassis frame. Disconnect the pipe (4) from the air spring (3).

Disconnect the air spring (3) from the chassis frame by taking out the bolt (5).

Engage the steering lock by taking the ignition key out.

Figure 10

Mark the assembly position of the universal joint (1) on the power steering box. Take out the bolt (2) and disconnect the universal joint (1) from the shaft of the power steering system (3).

Support the power steering box (3) appropriately, take out the screws (4) and detach it from the chassis frame.



So as not to change the setting of the automatic hydraulic steering limit, do not turn the shaft of the power steering box with a torque greater than 25 Nm.

Refitting



Carry out the steps performed for removal in reverse order.



Lubricate the screws fixing the power steering box to the mounting with oil.



Tighten the screws to the required tightening torques.

Bleed the air from the circuit as described on page 22 of this section.




If replacing the power steering system, after fitting it back onto the vehicle, it is necessary to set the automatic hydraulic steering limit setting as described under the relevant heading.

Removing-Fitting the Steering Lever



If it is necessary to replace the power steering system with a new one, before fitting it on the mounting, carry out the following operations.

Figure 11




33690

Secure the power steering box in a vice.
Fit the steering lever (3), making the reference marks (1) cut on the driving shaft (2) and on the lever (3) tally.



So as not to change the setting of the automatic hydraulic steering limit, do not turn the shaft (2) of the power steering box with a torque greater than 25 Nm.


Figure 12



33691

Check the angular travel of the lever that has to be 47° in both directions.


Figure 13



33692


Keeping the lever (3) stationary to prevent turning the power steering shaft, lock the nut (2) fixing the lever with a torque wrench (1) to a torque of 575 Nm.

Figure 14



33693

Using a suitable punch, notch the collar of the nut (1).

50140 STEERING CONTROL**Figure 15**

72848

The steering control is equipped with a pneumatic device to adjust the angle and height of the steering wheel. The position of the steering wheel is adjusted by pressing the push-button on the floor of the cab:

- ☐ Press the button (3) on the floor: the pressurized air of the services system is sent to the steering wheel adjustment assembly (2) releasing it.


- ☐ Manoeuvre the steering wheel (1) into the required position (longitudinal travel along the axis of the steering column 60 mm, angular travel to the vertical 40°).

- ☐ Release the button on the floor.

501410 REMOVING-REFITTING THE STEERING CONTROL ASSEMBLY


Removal

Figure 16




Lift the cowl of the cab. Set the wheels straight and check that the steering box is in the "straight ahead" position, so the reference mark $\Leftarrow$ of the shaft (1) coincides with the reference mark $\Rightarrow$ of the steering box (2).

Figure 17




Engage the steering lock by taking the ignition key out. Take the cover (1) off the steering wheel (2).

Figure 18




Disconnect the connection (4) of the earth cable. Remove the nut (1), mark the assembly position of the steering wheel (3) on the shaft (2) and remove the steering wheel (3).

Figure 19



Take out the screws (1 and 3) and take off the side guards (2, 4).

Figure 20




Remove the interconnecting box (2) from the steering control mounting (4), keeping strictly to the procedures described hereunder. This is to prevent damaging the spiralled cable in the box, during assembly, and to avoid a wrong reading of the steering wheel angle.

Disconnect the electric connections (5 and 6). Take the key (5, Figure 18) out of the steering wheel (3, Figure 18). Fasten the cover (1) of the interconnecting box (2) to the box by inserting the key (7) in the slots (8 and 9). This prevents the cover (1) and the box (2) from turning on each during disassembly and this condition is maintained until assembly. If there is no key (7), use a screw and nut of suitable length and diameter.


Take hold of the interconnecting box (2), lift it carefully so that the retaining spring pins (3) come out of the mounting (4) and put it aside.

Figure 21




Remove the push-button panels (3 and 5) and the caps for the screws (4) from the instrument panel (1). Take out the screws (2 and 4), remove the instrument panel (1) and put it aside.

Figure 22




Disconnect the connections (1) of the windscreen wiper, (2) of the drive control system, (3) of the immobilizer.

Figure 23




Take out the screws (2), remove the sill board (1) and lift the mat (3).

Figure 24




Remove the screws (1 and 3) and the guard (2).

Figure 25




Mark the assembly position of the shaft (2, Figure 18) on the mounting (3) and on the universal joint (4). Loosen the screw (1) and extract the universal joint (4) from the top shaft. Disconnect the pipe (2).

Figure 26



Take out the 3 screws (1) and remove the steering control mounting (3) from the pedal board (2).


Figure 27



From outside the cab, loosen the screw (2) and disconnect the bottom shaft (1) from the power steering (3) shaft. Take out the screws (4) and remove the bottom shaft (1) together with the guard (5).

Refitting

Figure 28



To refit, carry out the operations described for removal in reverse order, tightening the screws and/or nuts to the required torque.




The interconnecting box (1) is supplied as a spare with the stop key assembled as illustrated in the figure.

After fitting it on the steering control mounting, it is necessary to turn the key (2) so as to cause it to break at the point shown by the arrow and put the key in the steering wheel housing, see Figure 18.

Changing the pneumatic cylinder Removal


Figure 29



Remove the steering gear assembly as described under the relevant heading (operation 501410).

Remove the damper (1) by taking out the fixing nuts (2 and 3).

Figure 30



Screw a suitable coupling (5) into the air supply hole of the cylinder (3) and introduce air at a pressure of 8 ÷ 12 bars.




The air pressure must be maintained throughout removal: this is a necessary condition to make sure the pneumatic cylinder (3) gets released.

Shift the steering gear shaft-assembly (6) completely outwards (→).

Mark the assembly position of the screw (7) on the mount (9). Remove the nut (1), extract the screw (7) with the washers (2 and 8) and remove from the mount (9) the pneumatic cylinder (3) the adjustment washer (4) and the steering gear shaft assembly (6).

Refitting

Figure 31




77554

PARTS COMPRISING THE STEERING GEAR ASSEMBLY

1. Pneumatic cylinder - 2. Adjustment washer - 3. Coupling - 4. Mount - 5. Washer - 6. Screw - 7. Damper -
8. Steering gear shaft assembly - 9. Nut - 10. Washer - 11. Nut.

Figure 32




77553

Determine the thickness of the adjustment washer (2, Figure 31) as follows.

Measure the distance A between the sliding surfaces of the mount (1) with a suitable instrument (precision class 0.05 mm).


Figure 33



77555

Position the steering gear shaft mount (2) in the mount (1). Measure the distances B and C between the internal surface of the mount (2) and the sliding surface (of the above) of the mount (1) with a suitable instrument (3) (precision class 0.05 mm).

Figure 34



Screw a suitable coupling (2) into the air supply hole of the new cylinder (3) and introduce air at a pressure of $8 \div 12$ bars.




The air pressure must be maintained throughout the following measurement and assembly.

Place the pneumatic cylinder (3) on the plane and put the adjustment washer (1) on its piston; measure the distance (D) with a suitable instrument (4, precision class 0.05 mm).

$S = A - (B + C + D + 0.2)$, where A - B - C - D are the distances measured and 0.2 is the clearance.

Figure 35




Put mount (2) in mount (1) and fit on the cylinder (4 supplied with air at a pressure of $8 \div 12$ bars) positioning it with the pin (5) in the guiding groove of the mount (2). Choose the adjustment washer (3) from the ones supplied as spares, with the thickness calculated in the preceding measurement.



Washer thickness: 4.6 - 4.7 - 4.8 - 4.9 - 5.0 - 5.1 - 5.2 - 5.4 mm.

Lubricate the washer (3) with grease and insert it between the cylinder (4) and the mount (1).

Figure 36



Fit on a new screw (7) with the washer (8) positioning it at the point marked during removal.


From the opposite side, fit on the washer (2). Apply Loctite 270 on the thread of the new nut (1) and screw it onto the screw (3) to determine a clearance of 0.1 ± 0.2 mm between the washer (2) and the mount (3).

Check the travel of the mount (8) of the steering gear shaft on the mount (3) in all directions.

Set the steering gear shaft mount (6) in the position of the start of travel (minimum height of the steering wheel).

Remove the air coupling (4) from the pneumatic cylinder (5).

Figure 37



Fit on the damper (1), screw down the fixing nuts (2 and 3) tightening them to a torque of 23 Nm.

Check the locking of the cylinder (4): applying a tractive force of 300 N (30 kg) to the steering gear shaft, in the direction of the driver, this must not move in relation to the mount (3). Then refit the steering gear assembly to the vehicle as described under the relevant heading.

501430 BLEEDING THE POWER STEERING SYSTEM

For all vehicles

To bleed the power steering system, proceed as follows.

Fill the power steering fluid reservoir with the prescribed fluid (Tutela GI/A).

Turn the engine over with the starter motor and top up the fluid continually to prevent air being drawn into the pump.

Top up the fluid until the level remains constant above the minimum mark on the dipstick.

Start the engine and run it idling, checking that the level of the fluid does not fall under the minimum level marked on the dipstick.

Turn the steering wheel from lock to lock several times to force any air out of the power steering cylinder until no more bubbles appear in the fluid in the reservoir.

Accelerate to maximum rpm, then stop the engine and check that the fluid level does not rise more than 1 to 3 cm.


*** For vehicles with a steering third axle with pneumatic lifting.**

See the description on page 98 under the heading "STEERING REAR ADDED AXLE WITH PNEUMATIC LIFTING" in section 8 of this manual.

501430 MEASURING STEERING BOX PLAY AT THE STEERING WHEEL

Check there is no mechanical play in the steering linkage. Lock the left-hand wheel in the straight-ahead position using the expanders 99374399; raise the axle.

Figure 38



Attach the fixed pointer (2) to the windscreen with suction cups, and attach the graduated scale 99374398 (1) to the steering wheel.

Position the pressure tester 99374393 (3) (0 to 10 bar and 0 to 160 bar; pressure gauges connected by a shunt valve). Connect the pipe of the pressure tester to the fitting on the power steering delivery pipe.

Top up the fluid level if necessary.

Start the engine and run at idle speed. Record the pressure reading shown on the 0 to 10 bar gauge. Slowly turn the steering wheel to the left until the previous pressure reading is increased by 1 bar. Hold the steering wheel in this position and record the value in mm reached on the graduated scale 99374398. Now turn the steering wheel to the right until the pressure reading is again increased by 1 bar, and note the value in mm on the graduated scale 99374398. Add together

the two values in mm obtained for left and right steering; the total should not exceed 40 mm.

Lower the axle.

CHECKING THE MAXIMUM PRESSURE OF THE POWER STEERING SYSTEM


Using the pressure tester 99374393, connected as described above, and the driver's side wheel locked, start the engine and run at idle. Apply a steering force of 10 ± 20 kg to the steering wheel and record the pressure reading on the 0 to 160 bar gauge. Repeat the operation applying the same steering force in the opposite direction; if the readings obtained are lower than specified, locate the source of the problem.



The maximum pressure is given on the data plate attached to the ZF steering box.

Setting the automatic hydraulic steering limit

Figure 39



This adjustment is made after fitting the power steering system on the vehicle, with the vehicle unloaded and the front wheels raised or set on revolving platforms. In addition, it is necessary to steer both right and left as follows.

Make sure the gearbox is in neutral.

Start the engine and run at a speed of ≤ 1500 rpm.

Turn the steering wheel in one direction to bring the stop screw (2) on the stub axle (3) into contact with the axle (1).

In this position, apply an additional force on the steering wheel to determine the automatic setting. Repeat this procedure steering in the opposite direction.

If there is a reduction in the travel of the steering control lever, it is necessary to replace the steering limiting screw concerned with a new one, or both screws if the trouble involves the opposite travel as well.

The screws are located on the top and bottom sides of the power steering box. Make the adjustment as described above.

Check

Connect a pressure gauge (minimum full-scale value 200 bar) to the pressure test fitting on the delivery line from the pump to the power steering and apply a steering force at the steering wheel of 50 ± 20 Nm (corresponding to 200 ± 80 N on a 500 mm diameter steering wheel), turning the wheel to the full lock position. The pressure reading should be within the range of 35 to 70 bar. If the pressure is too high, replace the adjustment screws with new ones and repeat the adjustment procedure. If the pressure is too low, check that the hydraulic system is operating properly and that there are no leaks.

SECTION 12**Air system - Brakes**

	Page
SYMBOLS FOR AIR/HYDRAULIC SYSTEM CIRCUIT DIAGRAMS (TANKS AND ACCUMULATORS)	5
SYMBOLS FOR AIR/HYDRAULIC SYSTEM CIRCUIT DIAGRAMS (VALVES)	6
SYMBOLS FOR AIR-HYDRAULIC SYSTEM DIAGRAMS (TANKS AND ACCUMULATORS)	12
SYMBOLS FOR AIR/HYDRAULIC SYSTEM CIRCUIT DIAGRAMS (CONVERTERS, CYLINDERS AND CALLIPERS)	13
SYMBOLS FOR AIR/HYDRAULIC SYSTEM CIRCUIT DIAGRAMS (CALLIPERS AND CYLINDERS) .	14
SYMBOLS FOR AIR/HYDRAULIC SYSTEM CIRCUIT DIAGRAMS (SEMI-COUPPLINGS AND COUPLING CONNECTORS)	15
SYMBOLS FOR AIR/HYDRAULIC SYSTEM CIRCUIT DIAGRAMS (SEMI-COUPPLINGS AND COUPLING CONNECTORS)	16
SYMBOLS FOR AIR/HYDRAULIC SYSTEM CIRCUIT DIAGRAMS (INDICATORS AND SWITCHES)	17
SYMBOLS FOR AIR/HYDRAULIC SYSTEM CIRCUIT DIAGRAMS (BRAKES)	18
PIPINGS AND FITTINGS	19
☐ In general	19
☐ Rigid pipings reflanging	19
☐ Rigid pipings bending	20
☐ Rigid pipings cutting	20
☐ Flexible pipings replacement with traditional fittings	21
☐ Flexible pipings replacement with quick connection fittings	22
EBS (ELECTRONIC BRAKE SYSTEM)	24
☐ EBS Benefits	24
☐ Tractor and trailer compatibility at any time . . .	24
☐ Complete fault-diagnosis structures	24
OPERATING LOGIC	25

Page

BRAKE SYSTEM	26
AUXILIARY BRAKE INTEGRATION	27
"ABS-EBL" SYSTEM (ANTI-LOCK BRAKE SYSTEM – ELECTRONIC BRAKE LIMITER)	28
☐ "ABS" (Anti-Lock Brake System)	28
☐ EBL (Electronic Brakes Limiter)	29
☐ Operating Logic	29
☐ EBS working diagram for 4x2 vehicles (tractors)	30
☐ EBS working diagram for 4x2 vehicles (models: AT440S../FP-CT/FP-LT)	31
☐ EBS working diagram for 6x2 vehicles (tractors)	32
☐ EBS working diagram for 6x2 vehicles (trucks)	33
☐ EBS working diagram for 6x2 vehicles (trucks)	34
☐ ABS-EBL working diagram for 4x2 vehicles (trucks and tractors)	38
☐ ABS-EBL working diagram for 6x2C vehicles	39
☐ ABS-EBL working diagram for 6x4 vehicles	40
☐ ABS-EBL working diagram for stand alone 4x2 vehicles (trucks)	41
☐ ABS-EBL working diagram for 6x2 vehicles (trucks)	42
☐ ABS-EBL working diagram for stand alone 6x2 vehicles (trucks)	44
DESCRIPTION	45
☐ Service braking	45
☐ Emergency braking	45
☐ Exhaust brake	45
☐ Parking brake	45
BRAKES	45
☐ Drum Brakes	45
☐ Disc Brakes	45
FAULT DIAGNOSIS	46









Page

☐ Diagnosis Instruments	46
☐ Cluster Diagnosis	47
TIGHTENING TORQUES	61
TOOLS	64
SPECIFICATIONS AND DATA - PNEUMATIC SYSTEM	73
SPECIFICATIONS AND DATA - BRAKES	79
CHECKS ON MAIN COMPONENTS OF BRAKE SYSTEM	82
MAIN COMPONENTS OF THE BRAKING SYSTEM	84
☐ Compressor	84
☐ Head locking screw tightness	84
☐ Fault diagnosis	85
☐ A.P.U. (Air Processing Unit)	85
☐ Duplex control valve (vehicles without EBS) ..	86
☐ Duplex control valve with electric transmitter (vehicles with EBS)	86
☐ Fault Diagnosis (vehicles without EBS)	86
☐ Relay valve (vehicles without EBS)	87
☐ Proportional relay valve for front axle (vehicles with EBS)	87
☐ Fault Diagnosis (vehicles without EBS)	87
☐ Coupling heads	87
☐ Rear axle electro-pneumatic modulator (for vehicles with EBS)	88
☐ Fault Diagnosis	88
☐ Redundancy valve (for 4x2 and 6x2 trucks) ...	89
☐ ABS-EBS solenoid valve	89
☐ Dual stop valve	89
☐ Triple servo control valve (vehicles without EBS)	89

















	Page
☐ Predominance control	90
☐ Fault Diagnosis	90
☐ Trailer servo control valve (vehicles with EBS)	91
☐ Pressure test point valve	91
☐ Parking brake hand control valve (vehicles suited to towing)	91
☐ Fault Diagnosis (parking brake control valve)	91
☐ Parking brake control manual distributor (standby vehicles)	92
☐ Manual control valve to slow down the trailer (optional extra)	92
☐ Fault Diagnosis (parking brake control valve)	92
☐ Controlled pressure valve	93
☐ Fault Diagnosis	93
☐ Check valve (vehicles suited to towing)	93
☐ Low-pressure switch	93
☐ Electro-pneumatic valve for ASR	94
☐ Speed sensor	94
☐ Phonic wheels	94
☐ Electronic control unit	94
☐ Pressure sensor	94
☐ Diaphragm brake cylinder (for front and added front axle disc brake)	95
☐ Diaphragm brake cylinder (for front and added front axle drum brake)	95
☐ Combined brake cylinder (for front and rear disc brake)	95
☐ Combined brake cylinder (for front and rear drum brake)	95
☐ Combined cylinder emergency brake release device	96
☐ Repairs	96
☐ Fault Diagnosis	96
DISC BRAKES KNORR TYPE (CALIPER SN7)	97
☐ Operation	98
CHECKS	98

	Page
☐ Checking the automatic play recovery system efficiency	98
☐ Brake caliper components	99
☐ Check of braking seals thickness	100
OVERHAULING FRONT DISC BRAKES	101
☐ Replacing brake linings	101
☐ Removing and refitting brake callipers	104
☐ Removal	104
☐ Refitting	105
☐ Removing and refitting wheel hubs	105
☐ Removal	105
☐ Refitting	106
BRAKE CALIPER OVERHAUL	107
☐ Disassembly	107
☐ Component part cleaning and check	108
☐ Assembly	108
OVERHAULING REAR DISC BRAKES	110
☐ Replacing brake linings	110
OVERHAULING BRAKE DISCS	113
TURNING AND GRINDING BRAKE DISCS	113
DRUM BRAKES	114
OVERHAULING THE DRUM BRAKES	115
☐ Removing the rear drum brakes	115
☐ Turning drums	119
☐ Replacing brake linings	120
☐ Assembly	120














SYMBOLS FOR AIR/HYDRAULIC SYSTEM CIRCUIT DIAGRAMS (TANKS AND ACCUMULATORS)

DESCRIPTION	SYMBOL	
HYDRAULIC FLOW		
AIR FLOW		
ELECTRICAL LINE		
ABLE TO ROTATE		
CROSSOVER OF CONNECTED LINES		
PRESSURE TEST POINT		
QUICK-CONNECTION COUPLING		
COCK		
COCK WITH OUTLET		
SILENCER		
COMPRESSOR		
ENERGY SAVING COMPRESSOR		
VACUUM PUMP		
HYDRAULIC PUMP		
HYDRAULIC HAND PUMP		












SYMBOLS FOR AIR/HYDRAULIC SYSTEM CIRCUIT DIAGRAMS (VALVES)

DESCRIPTION	SYMBOL	
CONDENSATE SEPARATOR		
FILTER		
DEHUMIDIFIER		
DEHUMIDIFIER		
DEHUMIDIFIER WITH BUILT-IN REGULATOR		
AUTOMATIC CONDENSATE DRAIN VALVE		
CONTROLLED CONDENSATE DRAIN VALVE		
HAND CONDENSATE DRAIN VALVE		
CONTROLLED ANTI-ICING UNIT		
AUTOMATIC ANTI-ICING UNIT		
PRESSURE REGULATOR WITH INDEPENDENT CIRCUIT		
PRESSURE CONTROLLER		
PRESSURE CONTROLLER		
PRESSURE CONTROLLER (GOVERNOR)		
PRESSURE LIMITING VALVE		













SYMBOLS FOR AIR/HYDRAULIC SYSTEM CIRCUIT DIAGRAMS (VALVES)

DESCRIPTION	SYMBOL	
PROPORTIONAL REDUCING VALVE		
MATCHING VALVE		
FOUR CIRCUIT PROTECTION VALVE		
THREE CIRCUIT PROTECTION VALVE		
TWO CIRCUIT PROTECTION VALVE		
NON-RETURN AIR INLET VALVE		
LIMITED RETURN AIR INLET VALVE		
SAFETY VALVE		
CHECK VALVE		
CHECK VALVE		
DOUBLE SHUT-OFF VALVE		
DIFFERENTIAL DOUBLE SHUT-OFF VALVE		
THROTTLE VALVE WITH QUICK RETURN		
THROTTLE VALVE		













SYMBOLS FOR AIR/HYDRAULIC SYSTEM CIRCUIT DIAGRAMS (VALVES)

DESCRIPTION	SYMBOL	
DUMP VALVE		
BRAKE CONTROL VALVE		
BRAKE CONTROL VALVE		
BRAKE CONTROL VALVE		
PARKING BRAKE CONTROL VALVE		
PARKING BRAKE CONTROL VALVE		
BRAKE VALVE		
CONTROL VALVE		
CONTROL VALVE		
RETARDER CONTROL VALVE		
SERVO CONTROL VALVE		













SYMBOLS FOR AIR/HYDRAULIC SYSTEM CIRCUIT DIAGRAMS (VALVES)

DESCRIPTION	SYMBOL	
SERVO CONTROL VALVE		
SERVO CONTROL VALVE FOR SINGLE LINE		
TRAILER BRAKING TRIPLE CONTROL VALVE		
TRAILER BRAKING TRIPLE CONTROL VALVE WITH BUILT-IN SERVO SWITCHING		
LOAD PROPORTIONING VALVE		
DUAL LOAD PROPORTIONING VALVE		
LOAD PROPORTIONING VALVE WITH BY-PASS		
LOAD PROPORTIONING VALVE WITH BUILT-IN RELAY		
LOAD PROPORTIONING VALVE WITH BUILT-IN RELAY WITH AIR CONTROL		



SYMBOLS FOR AIR/HYDRAULIC SYSTEM CIRCUIT DIAGRAMS (VALVES)

DESCRIPTION	SYMBOL	
LOAD PROPORTIONING VALVE WITH AIR CONTROL		
LOAD PROPORTIONING VALVE WITH AIR CONTROL		
PROPORTIONAL REDUCING VALVE		
SLAVED PROPORTIONAL REDUCING VALVE		
STROKE LIMITING VALVE		
LEVELLING VALVE		
LEVELLING VALVE		
LEVELLING VALVE WITH BUILT-IN TRAVEL LIMITER		
HAND OPERATED SUSPENSION RAISING CONTROL VALVE		
















SYMBOLS FOR AIR/HYDRAULIC SYSTEM CIRCUIT DIAGRAMS (VALVES)

DESCRIPTION	SYMBOL	
PROPORTIONAL CONTROL VALVE		
HAND OPERATED SUSPENSION CONTROL VALVE WITH ELECTRICAL MONITORING		
ELECTROPNEUMATIC VALVE		
ELECTROPNEUMATIC VALVE		
ELECTROPNEUMATIC VALVE		
HYDRAULIC MODULATOR FOR ABS		
AUGMENTER VALVE		




SYMBOLS FOR AIR-HYDRAULIC SYSTEM DIAGRAMS (TANKS AND ACCUMULATORS)

DESCRIPTION	SYMBOL	
COMPRESSED AIR TANK		
BRAKE FLUID RESERVOIR		
AIR SPRING		











SYMBOLS FOR AIR/HYDRAULIC SYSTEM CIRCUIT DIAGRAMS (CONVERTERS, CYLINDERS AND CALLIPERS)

DESCRIPTION	SYMBOL	
VACUUM BRAKE SERVO		
VACUUM BRAKE SERVO		
DUAL CIRCUIT MASTER CYLINDER		
SINGLE CIRCUIT MASTER CYLINDER		
AIR/HYDRAULIC CONVERTER		
AIR/HYDRAULIC CONVERTER		
HYDRAULIC BRAKE CYLINDER		
SLAVE CYLINDER		
BRAKE CYLINDER		
SPRING CYLINDER		
COMBINED BRAKE CYLINDER		
FIXED DISC BRAKE CALLIPER		









**SYMBOLS FOR AIR/HYDRAULIC SYSTEM CIRCUIT DIAGRAMS
(CALLIPERS AND CYLINDERS)**

DESCRIPTION	SYMBOL	
FLOATING DISC BRAKE CALLIPER		
FLOATING DISC BRAKE CALLIPER WITH PARKING		
MECHANICAL FLOATING DISC BRAKE CALLIPER		
SERVO CLUTCH		
SERVO CLUTCH		





SYMBOLS FOR AIR/HYDRAULIC SYSTEM CIRCUIT DIAGRAMS (SEMI-COUPPLINGS AND COUPLING CONNECTORS)

DESCRIPTION	SYMBOL	
"ISO" SEMI-COUPLING		
"ISO" SEMI-COUPLING		
"CUNA" SEMI-COUPLING		
"CUNA" SEMI-COUPLING		
"NATO" SEMI-COUPLING		













SYMBOLS FOR AIR/HYDRAULIC SYSTEM CIRCUIT DIAGRAMS
(SEMI-COUPPLINGS AND COUPLING CONNECTORS)

DESCRIPTION	SYMBOL	
		
SEMI-COUPLING		
SEMI-COUPLING		
SEMI-COUPLING		

SYMBOLS FOR AIR/HYDRAULIC SYSTEM CIRCUIT DIAGRAMS (INDICATORS AND SWITCHES)

DESCRIPTION	SYMBOL	
PRESSURE GAUGE		
PRESSURE GAUGE		
PRESSURE SENDING UNIT		
LAMP		
MECHANICAL SWITCH		
PRESSURE SWITCH		
LOW PRESSURE SWITCH		
AUDIBLE WARNING		
SENSOR		

SYMBOLS FOR AIR/HYDRAULIC SYSTEM CIRCUIT DIAGRAMS (BRAKES)

DESCRIPTION	SYMBOL	
SINGLE CYLINDER HYDRAULIC BRAKE		
TWIN CYLINDER HYDRAULIC BRAKE		
DUAL SERVO HYDRAULIC BRAKE		
DUAL SERVO HYDRAULIC BRAKE WITH PARKING BRAKE		
SINGLE CAM OPERATED BRAKE		
TWIN DUAL CAM OPERATED BRAKE		

799512 PIPINGS AND FITTINGS


In general

Hydraulic system pipings for industrial vehicles are currently of two types:

- Flexible ones made of polyamide with single-layered or double-layered structure and in the following diameters (Ø 6-8-10-12-16 mm) equipped with spares in meters.
- Rigid metal pipings in the following diameters (Ø 4.75-6.35-8-10-12 mm). Pipings from Ø 4.75 to Ø 10 mm are supplied as spares in straight 4-5-6 m crop ends, while those exceeding 10 mm are supplied as spares already cut, bent and reflanged.

Rigid pipings reflanging

Figure 1




31971

RIGID PIPINGS REFLANGING REPRESENTATION

Reflanging type A


Figure 2



31972

Arrange on a press 99386523 (3) small blocks (1) so that the punched numbers, showing the piping number to be worked, are facing the matrix die (2). The choice of the matrix die (2) depends on the diameter of the piping to be reflanged. Moreover, on every matrix die (2) the diameter of the piping is punched for which the same one can be used.


Figure 3



31973

Burr piping (1), insert union (2) and place it between small blocks (3) abutting pin (5). Lock piping (1) with screw (4).

Figure 4




31974

Take back pin (4) to its neutral position. Screw screw (1) till matrix die (2) comes to abut against small blocks (3) thereby shaping the piping (5) end.

Reflanging type B

Figure 5




31975

Assemble matrix die (2) on press 99386523 (1). For the reflanging process comply with what has been stated above for reflanging type A.

Reflanging type C


Figure 6



31976

Key on piping (1) nut (2) and ring (3).

Figure 7




31977

Assemble union (2) and tighten so that ring (3, Figure 6) is locked on piping (1).

Rigid pipings bending


Figure 8



31978

Assemble tool (1) 99386523 choosing parts (2) and (3) depending on the diameter of pipings to be bent.


Figure 9



31979

Place piping (1) into tool (3) and operating on lever (2) bend the piping.

Figure 10




31980

In order to free piping (2) from tool (3), operate on lever (1).

Rigid pipings cutting

Figure 11



31981

Place piping (2) into tool (3) 99386523 and tighten screw (1). Keeping piping (2) still, rotate tool (3) till the piping is completely cut.

After having cut the piping, burr and shape the end as previously described.




Rotating tool (3) around piping (2), screw (1) is loosened. In order to completely cut the piping, it is then necessary to tighten screw (1) when it loosening.

Flexible pipings replacement with traditional fittings

Strictly comply with the following instructions:

Figure 12




- ☐ Use homologated pipes only;
- ☐ Check the spare pipe status, on which no cracks, cuts or nickings must be detected;
- ☐ Cut the pipe at 90° with respect to the axis through a suitable pipe-cutting pliers 99387050 at the necessary length;

Insert on the pipe in the following order:

- ☐ nut (3), pressure ring (2) (its greater thickness must be facing nut (3) and reinforcement bush (1));
- ☐ the bush must be in perfect conditions (it must not have either distortions or hammering traces).

Figure 13



REINFORCEMENT BUSH ASSEMBLY

- A = CORRECT ASSEMBLY
B = WRONG ASSEMBLY

- ☐ Key the reinforcement bush with tool 99372219 guaranteeing the contact between its flange and the pipe end;
- ☐ make sure that the pipe end penetrates into the suitable rake groove obtained in the flange.

- ☐ Carry out abutment ring reflanging upon assembly on the vehicle or work bench on a fitting.
- ☐ The exerted pressure and the final distance from front pressure ring edge to reinforcement bush edge must be those mentioned in the table below.




In case of a bad assembly, never use the pipe after having extracted bush and abutment ring.

	Pipe mm	Distance between bush edge and ring mm (*)	Assembling pressure N/mm ²
Double-layered	6 x 1	from 1 to 1.5	0.040
	8 x 1	from 2 to 2.5	0.050
Single-layered	10 x 1.5	from 2 to 2.5	0.050
	12 x 1.6	from 2 to 2.5	0.060
	16 x 2.34	from 3 to 3.5	0.060

(*) See reference h, Figure 14.

Figure 14



1. Reinforcement bush - 2. Pressure ring -
3. Nut - 4. Fitting - 5. Pipe -
h. Distance between bush edge and ring edge (see table).

Insert the thereby-prepared piping end into the fitting body till the reinforcement bush flange rests within the suitable seat:

- ☐ For closing the nut on the fitting, initially screw it manually and then complete the tightening with a suitable box wrench (complete series 99372221) inserted into the dynamometric wrench, to be calibrated according to the required tightening torque.

Assembly of piping on vehicle is carried out by taking into account some important solutions:

- ☐ Bendings must comply with minimum radiusses, in order to avoid throttlings.


Pipings diameter mm	Minimum bending radius mm
6 x 1	approx. 40
8 x 1	approx. 50
10 x 1.5	approx. 60
12 x 1.6	approx. 75
16 x 2.34	approx. 100



Make sure that pipings are not in contact with sharp edges or with cutting metallic parts or with heat sources, but that are distant therefrom by a minimum safety distance of 15 mm.

- ☐ Moreover, when crossing chassis longitudinal members or metallic parts, check that passage holes are coated with rubber fairlead rings and that these latter ones are in good conditions;
- ☐ Avoid that the pipe slides along cutting edges that would risk to create nicks;
- ☐ Having to fix the piping onto already existing ducts, take into account the supplementary heat to which it can be subjected (hydraulic power steering duct): in such case, the piping must be protected with guards;
- ☐ At the end of the connection, verify that the piping, between keying and securing, is not stretched, but must be slightly loosened to recover higher temperature variations, particularly for short lengths;
- ☐ Before assembling, accurately clean the pipings by blowing compressed air in order to guarantee system operation.

Figure 15



13132

- ☐ Protect the pipes in case of grinding or welding operations on the vehicle; for such purpose, an adhesive plate is applied in the cabin and shows the precautions to be observed with utmost care to avoid damages.




For better safety and work comfortability, it is advisable to detach the pipings during such operations.

At the end of the assembly, check the perfect seal of all gaskets (unions, fittings, etc.).

Flexible pipings replacement with quick connection fittings

Rotating fittings

Figure 16




39306

Screw the fitting in the threaded seat provided on the pneumatic valve and lock it at the tightening torque shown in the table.

Swinging fittings

Figure 17




39307

- ☐ Check that the sealing ring (1) is into its suitable seat;
- ☐ screw the fitting till it is felt that the sealing gasket abuts onto the valve;
- ☐ adequately swing the fitting and keeping the swingable part still, lock the hexagonal nut at the tightening torque mentioned in the table.

Rotating and swinging fittings

FITTING THREADING	TIGHTENIG TORQUE (Nm ± 10%)
M 10 x 1.0 mm	22
M 12 x 1.5 mm	24
M 14 x 1.5 mm	28
M 16 x 1.5 mm	35
M 22 x 1.5 mm	40


Figure 18



33977

- ☐ Use homogated pipes only;
- ☐ Check the spare pipe status, on which no cracks, cuts or nicking must be detected;
- ☐ Cut the pipe at 90° with a max 15° error with respect to the axis through the suitable pipe-cutting pliers 99387050 at the necessary length;

Figure 19



33976

A = Marking to identify pipe end-of-stroke


- ☐ Strongly and indelibly mark with ink two reference notches on both diametrically-opposed pipe faces for an angle $\geq 75^\circ$, placed at the distances of L_1 and L_2 to guarantee a correct assembly.



Dimensions L_1 and L_2 change depending on the pipe diameter and must be measured from the longest pipe part (see Figure 18).

D (mm)	L ⁰ _{+0.5} (mm)	L ₁ ^{-0.5} ₊₁ (mm)	L ₂ ^{-0.5} ₊₁ (mm)
6	19.8	17	22
8	20.5	18	23
12	25	22	28
16	27.1	24	30


Figure 20



33938

- ☐ Manually insert pipe (2) into fitting (1), with a force varying from 30 to 120 N depending on pipe diameter, so that the notch L_1 is placed inside the fitting while the notch L_2 is visible.

Figure 21



33978

In case of disassembling of fittings (1) from pneumatic components, check the sealing ring (2) status, and if necessary replace it.

FITTING THREADING	SEALING RINGS DIMENSIONS
M 10 x 1.0	10.1 x 1.6
M 12 x 1.5	11.0 x 2.0
M 14 x 1.5	-
M 16 x 1.5	15.0 x 2.0
M 22 x 1.5	-



Every time a piping is detached from a quick connection fitting, it is necessary to replace the fitting itself. Quick connection fittings are supplied complete as spares.



Quick connection and threaded fittings, as well as flexible pipings used with quick connection fittings and flexible pipings used with threaded fittings, are not interchangeable.

EBS (ELECTRONIC BRAKE SYSTEM)

The increase in competition in the transport sector has had the effect, among others, of constantly increasing the basic requirements of braking systems.

The introduction of the EBS electronic brake system is the logical answer to these new needs.

It is an integrated and permanent electronic control system for the brake system of the tractor and trailer.

It supplements the ABS, ASR and EBL functions.

The system is composed of a pneumatic system and an electric system containing the following components:

Duplex control valve with electric transmitter, proportional relay valve for front axle, ABS for front axle, rear axle electro-pneumatic modulator, trailer servo control valve.

The EBS system dialogues with the control units of the other assemblies:

Engine, Ecas, retarder and gearbox via the CAN line (VDB, Vehicle Data Bus).

EBS Benefits

Lower servicing costs.

The EBS combines many functions. The aim is to cut maintenance costs while maximizing braking safety – that is minimizing brake lining wear.

An individual control according to the lining wear parameters on both the front and rear axles harmonizes lining wear. Distributing the load homogeneously between all the brakes of the wheels reduces total consumption. In addition, the frequency of servicing and changing the linings coincide. The costs of inactivity are drastically reduced.

Depending on the servicing a vehicle needs along with other factors, the owner may be able to make considerable savings. A comparison of the maintenance costs, for the brake system, of a vehicle with EBS and one with a conventional brake system highlights significant savings.

Tractor and trailer compatibility at any time

Harmonizing the braking processes of the entire tractor-trailer combination, especially if the combinations are frequently changed, often with conventional means, is not satisfactory.

An inadequate balance, such as with a trailer whose braking is not sufficiently effective, will cause uneven wear of the brake linings.

The EBS will recognize all the incompatibilities between tractor and trailer, harmonizing braking automatically. When the brakes work in the best conditions, not only are brake maintenance costs optimized, but safety and comfort are optimum too.

Complete fault-diagnosis structures

The EBS provides the owner of the vehicle with constantly updated information on the state of the brake system and the basic brakes. This makes it possible to schedule servicing in advance. The EBS monitors all the fundamental components and functions of the brake system.

Any defect recognized by the system is accurately highlighted. The maintenance specialist can therefore rectify the error at issue.

The high degree of safety ensured by the EBS is due to several factors:

- ☐ Lower pressure accumulation and response times for the brakes on the front, rear and trailer axles.
- ☐ Better ABS function.
- ☐ Tractor/trailer always balanced in every moment.
- ☐ Constant monitoring of the service brake system. In the event of reduced brake performance, the EBS will be able to warn the driver.
- ☐ The integrated ASR function permits optimum vehicle stability and drive optimization.


OPERATING LOGIC

The purpose of the electronic control unit is to slow down the vehicle as quickly as possible, ensuring its stability and avoiding the tendency for the wheels to lock.

To achieve this aim, while braking, the electronic control unit will be informed of the:


- ☐ required deceleration via the sensors inside the duplex control valve;
- ☐ pressures made available via the pressure sensors in the components;
- ☐ reaction on slowing down due to the pressures made available via the speed sensor signals.

The continuous monitoring and processing of this information, in relation to the set aim, will cause the modulating valves to activate appropriately and optimize the braking action accordingly.



BRAKE SYSTEM

In a dynamic situation the effect on the vehicle will be managed in this way:

Figure 22

77208

Ca. Front axle load – Cp. Rear axle load – Cr. Load on fifth wheel – Da. Front axle braking force –
 Dp. Rear axle braking force – Dm. Braking force at graduated release – Ds. Semitrailer braking force –
 Ffa. Resultant of braking/front axle load – Ffp. Resultant of braking/rear axle load – Ffm. Resultant of braking/load
 at graduated release – Ffs. Resultant of braking/semitrailer load – a. Braking angle – Rr. Reaction on the fifth wheel –
 Dec. Required deceleration – g. Acceleration due to gravity – z. Braking ratio


Generally, the EBS will tend to apply a braking force in proportion to the load on the axles, that is to maintain the same angle "a" for all the axles:

$$\frac{D_a}{C_a} = \frac{D_p}{C_p} = \frac{D_s (D_m)}{C_s (C_r)} = \tan \alpha \cong \alpha = \frac{\text{dec}}{g} = z$$

This, as may be seen, also holds for the semitrailer control.

If the reaction on the fifth wheel "Rr" is not as expected, the system automatically increases or decreases the predominance at the graduated release and "Ffm" accordingly so as to ensure the best compatibility between the tractor and semitrailer in compliance with current type-approval standards, as may be seen in the following compatibility diagram.

Figure 23



000987t


AUXILIARY BRAKE INTEGRATION

Commercial vehicles are normally fitted with auxiliary brakes for slowing down without causing wear, such as the exhaust brake and intarder.

On vehicles equipped with the EBS, these devices can be integrated to ensure the vehicle slows down sooner and more effectively. The exhaust brake/intarder action percentage is set by the driver with the lever.

The exhaust brake will be applied up to a speed of 1000 rpm, while the action of the retarder will cause the following action depending on the position of the lever:

Figure 24



001685t

Position 0 – disengaged

Position 1 – E.B. 100%

Position 2 – E.B. 100% + Intarder 25% (20% *)

Position 3 – E.B. 100% + Intarder 50% (40% *)

Position 4 – E.B. 100% + Intarder 75% (60% *)

Position 5 – E.B. 100% + Intarder 100% (80% *)

Position 6 – E.B. 100% + Intarder 100%

These applications, always possible, will be signalled to the driver by the relevant indicator lights coming on.

* Vehicles with mechanic gearbox.



On vehicles without the optional Intarder, the auxiliary brake lever has just three positions: off, E.B. 50%, E.B. 100%.

On vehicles fitted with a EuroTronic gearbox, with the auxiliary brake lever on position 6, slowing down will be more effective with the automatic gear shift down.

Switching the engine off for longer than one minute involving a change in load, tyres or ratios at the rear axle causes the adjustment data to be lost and so a fresh period of data acquisition will be necessary for the system to be able to reactivate auxiliary brake integration if no vehicle parameter is changed the integration will be immediately available.

If manually activating the auxiliary brakes, the next time the brake pedal is pressed will implement integration.

On releasing the brake pedal, if the manual action is compatible with the calculated action it will be kept active.

If activating the auxiliary brakes, both manual and integrated, causes the rear axle to slow down too much and a tendency for it to lock, the EBS control unit, on detecting this situation via the speed sensors, will immediately disengage them or turn on the auxiliary brake Slip Control.

“ABS-EBL” SYSTEM (ANTI-LOCK BRAKE SYSTEM – ELECTRONIC BRAKE LIMITER)

EBL function controls rear axle wheel “skidding” by comparing it to front axle wheel speed.

On the basis of wheel r.p.m.'s and braking pressure (detected by the sensor upstream from rear axle ABS modulators), the central unit calculates vehicle speed, rear axle wheel “skidding” and minimum acceleration expected.

“ABS” (Anti-Lock Brake System)

The braking of a moving vehicle and the according deceleration and stopping distances depend above all on the grip between the surfaces of the tyres and the road.

With a fully efficient braking system, a further improvement in braking can only be achieved by acting on the friction of the tyres or on the grade of the road surface.

Even in these optimum conditions, absolute braking safety is anyhow not guaranteed when faced with especially tricky situations, such as poor grip due to a wet or icy road surface: the driver is forced to moderate use of the brakes in order to avoid partially locking one or more wheels, with the risk of skidding dangerously.

The function of the “ABS” is therefore to ensure vehicle stability (in all braking conditions), preventing the wheels from locking irrespective of the state of the road surface, so as to ensure the available grip is made full use of.

Even in the case of emergency braking, the system makes it possible to keep direction, that is to turn the steering wheel to avoid obstacles with no risk of skidding.

In short, the anti-lock brake system (ABS):

- ☐ Prevents the wheels locking when the vehicle is braking, no matter what grip is available on the road.
- ☐ Shortens stopping distances.
- ☐ Provides safety for the driver who can keep the vehicle's stability and direction.

EBL (Electronic Brakes Limiter)

The EBL function checks the rear axle wheel "slip", comparing it with the speed of the wheels of the front axle.

The control unit input data are the wheel speed and braking pressure measured by the pressure sensor installed upstream from the rear axle ABS modulators.

On the basis of these values, the control unit calculates the speed of the vehicle, the vehicle's deceleration, the rear axle wheel "slip" and the minimum deceleration contemplated.

The EBL function is activated (the rear ABS modulators maintain the set pressure) when the driver applies an excessive braking force for the conditions of load on the vehicle, in short when the rear axle slip and vehicle deceleration thresholds are exceeded.

Operating Logic


The purpose of the electronic control unit is to slow down the vehicle as quickly as possible, ensuring its stability and avoiding the tendency for the wheels to lock.


To achieve this aim, while braking, the electronic control unit will be informed of the:

- ☐ braking intensity required by the driver via the rear axle pressure sensor,
- ☐ reaction on slowing down due to the pressures made available via the speed sensor signals.

The continuous monitoring and processing of this information, in relation to the set aim, will cause the rear axle modulating valves to activate appropriately and optimize the braking action accordingly.


Figure 25



EBS working diagram for 4x2 vehicles (tractors)**Figure 26**


79504

1. Compressor – 2. Air processing unit 10.5 bars – 3. Front axle air tank 20 l. – 4. Parking air tank 20 l. – 5. Rear axle air tank 30 l. – 6. Manual discharge valve – 7. Air test point – 8. Rear axle low pressure switch for ASR – 6.6 bars – 9. Parking system one-way valve – 10. Trailer system low pressure switch – 5.5 bars – 11. Semitrailer half-couplings – 12. Trailer brake servo control valve – 13. Rear axle combined cylinder – 14. Rear axle disc brake assembly – 15. Rear axle phonic wheel – 16. Rear axle speed sensor – 17. Rear axle brake control electro-pneumatic modulator – 18. Duplex control valve – 19. EBS electronic control unit – 20. Front axle brake control relay solenoid valve – 21. Front axle ABS solenoid valves – 22. Front axle diaphragm brake cylinder – 23. Front axle phonic wheel – 24. Front axle speed sensor – 25. Front axle disc brake assembly – 26. Parking control relay valve – 27. Parking manual control valve – 28. Trailer slowing manual control valve – 29. Handbrake low pressure switch turned on – 6.6 bars – 30. Front axle parking brake - A. To the air suspension system – B. To the service system - * Optional extra

EBS working diagram for 4x2 vehicles (models: AT440S.. /FP-CT/FP-LT)**Figure 27**


79505

1. Compressor – 2. Air processing unit 10.5 bars – 3. Front axle air tank 20 l. – 4. Parking air tank 20 l. – 5. Rear axle air tank 30 l. – 6. Manual discharge valve – 7. Air test point – 8. Rear axle low pressure switch for ASR – 6.6 bars – 9. Parking system one-way valve – 10. Trailer system low pressure switch – 5.5 bars – 11. Semitrailer half-couplings – 12. Half coupling – 13. Trailer brake servo control valve – 14. Rear axle combined cylinder – 15. Rear axle disc brake assembly – 16. Rear axle phonic wheel – 17. Rear axle speed sensor – 18. Rear axle brake control electro-pneumatic modulator – 19. Duplex control valve – 20. EBS electronic control unit – 21. Front axle brake control relay solenoid valve – 22. Front axle ABS solenoid valves – 23. Front axle diaphragm brake cylinder – 24. Front axle phonic wheel – 25. Front axle speed sensor – 26. Front axle disc brake assembly – 27. Parking control relay valve – 28. Parking manual control valve – 29. Trailer slowing manual control valve – 30. Handbrake low pressure switch turned on – 6.6 bars – 31. Front axle parking brake - A. To the air suspension system – B. To the service system - * Optional extra

EBS working diagram for 6x2 vehicles (tractors)**Figure 28**

79506

1. Compressor – 2. Air processing unit 10.5 bars – 3. Front axle air tank 20 l. – 4. Parking air tank 20 l. – 5. Rear axle air tank 30 l. + 15 l. – 6. Manual discharge valve – 7. Air test point – 8. Rear axle low pressure switch for ASR – 6.6 bars – 9. Parking system one-way valve – 10. Trailer system low pressure switch – 5.5 bars – 11. Semitrailer half-couplings – 12. Trailer brake servo control valve – 13. Rear axle combined cylinder – 14. Rear axle disc brake assembly – 15. Rear axle phonic wheel – 16. Rear axle speed sensor – 17. Load ratio relay valves for intermediate axle braking – 18. Intermediate axle diaphragm cylinder – 19. Intermediate axle disc brake assembly – 20. Intermediate axle ASR exclusion solenoid valve – 21. Intermediate axle suspension air springs – 22. Intermediate axle load ratio dual stop valve – 23. Rear axle braking control electro-pneumatic modulator – 24. Duplex control valve – 25. EBS electronic control unit – 26. Front axle brake control relay solenoid valve – 27. Front axle ABS solenoid valves – 28. Front axle diaphragm brake cylinder – 29. Front axle disc brake assembly – 30. Front axle phonic wheel – 31. Front axle speed sensor – 32. Parking control relay valve – 33. Parking manual control valve – 34. Trailer slowing manual control valve – 35. Handbrake low pressure switch turned on – 6.6 bars – 36. Front axle parking brake –
- A. To the air suspension system – B. To the service system – * Optional extra.

EBS working diagram for 6x2 vehicles (trucks)**Figure 29**

79507


1. Compressor – 2. Air processing unit 10,5 bars – 3. Front axle air tank 20 l. – 4. Parking air tank 20 l. – 5. Rear axle air tank 30 l. + 15 l. – 6. Manual discharge valve – 7. Air test point – 8. Rear axle low pressure switch for ASR – 6,6 bars – 9. Parking system one-way valve – 10. Trailer system low pressure switch – 5,5 bars – 11. Rear axle braking redundancy valve – 12. Semitrailer half-couplings – 13. Trailer brake servo control valve – 14. Rear axle combined cylinder – 15. Rear axle disc brake assembly – 16. Rear axle phonic wheel – 17. Rear axle speed sensor – 18. Rear axle braking control electro-pneumatic modulator – 19. Duplex control valve – 20. EBS electronic control unit – 21. Front axle brake control relay solenoid valve – 22. Front axle ABS solenoid valves – 23. Front axle diaphragm brake cylinder – 24. Front axle disc brake assembly – 25. Front axle phonic wheel – 26. Front axle speed sensor – 27. Parking control relay valve – 28. Parking manual control valve – 29. Trailer slowing manual control valve – 30. Handbrake low pressure switch turned on – 6,6 bars – 31. Front axle parking brake – A. To the air suspension system – B. To the service system – * Optional extra.

EBS working diagram for 6x2 vehicles (trucks)**Legend**

1. Compressor
2. Air processing unit - 10.5 bars
3. Air processing unit - 12.5 bars
4. Front axle air tank - 20 l.
5. Parking air tank - 20 l.
6. Rear axle air tank - 30 l. + 20 l.
7. Manual discharge valve
8. Air test point
9. Rear axle low pressure switch for ASR – 6.6 bars
10. Parking system one-way valve
11. Trailer system low pressure switch – 5.5 bars
12. Semitrailer half-couplings
13. Trailer brake servo control valve
14. Rear axle braking redundancy valve
15. Load ratio relay valve for added axle braking
16. Added axle diaphragm brake cylinder
17. Added axle disc brake assembly
18. Added axle ASR exclusion solenoid valve
19. Added axle suspension air springs
20. Added axle load ratio dual stop valve
21. Rear axle combined cylinder
22. Rear axle disc brake assembly
23. Rear axle phonic wheel
24. Rear axle speed sensor
25. Rear axle brake control electro-pneumatic modulator
26. Duplex control valve
27. EBS electronic control unit
28. Front axle brake control relay solenoid valve
29. Front axle ABS solenoid valves
30. Front axle diaphragm brake cylinder
31. Front axle disc brake assembly
32. Front axle phonic wheel
33. Front axle speed sensor
34. Parking control relay valve
35. Parking manual control valve
36. Trailer slowing manual control valve
37. Handbrake low pressure switch turned on – 6.6 bars
38. Front axle parking brake
- A. To the air suspension system
- B. To the service system
- * Optional extra
- For CM vehicles only


EBS working diagram for 6x2 vehicles (trucks)

Figure 30



Layout of EBS components on the vehicle (tractor variant)

Figure 31




84503

1. Electronic control unit – 2. Duplex control valve with electric transmitter – 3. Parking manual control valve –
 4. Half-couplings – 5. Air tanks – 6. Rear axle electro-pneumatic modulator – 7. Parking relay valve – 8. Air tank –
 9. Spring brake cylinder – 10. Trailer servo control valve – 11. A.P.U. – 12. Diaphragm brake cylinder –
 13. ABS solenoid valve – 14. Compressor – 15. Proportional relay valve for front axle


Layout of EBS components on the vehicle (6x2 truck variant)

Figure 32




84506

1. Rear axle combined cylinder – 2. Front axle diaphragm brake cylinder – 3. Trailer braking servo control valve –
 4. Front axle diaphragm brake cylinder – 5. Electro-pneumatic control valve for rear axle ECAS suspensions –
 6. Dual stop valve – 7. Relay valves – 8. Solenoid valves excluding added axle ASR – 9. Rear axle braking cylinder
 electro-pneumatic modulator – 10. Rear axle braking redundancy valve.

ABS-EBL working diagram for 4x2 vehicles (trucks and tractors)**Figure 33**


1. Compressor - 2. Air processing unit - 10.5 bars - 3. Front axle air tank - 20 l. - 4. Parking air tank - 20 l. - 5. Rear axle air tank - 30 l. - 6. Manual discharge valve - 7. Air test point - 8. Parking manual control valve - 9. Handbrake low pressure switch turned on - 6.4 bars - 10. Parking control relay valve - 11. Trailer slowing manual control valve - 12. Trailer brake servo control valve - 13. Trailer system low pressure switch - 6.4 bars - 14. Trailer half couplings for tractors - 15. Trailer half couplings for trucks - 16. Parking system one-way valve - 17. Duplex control valve - 18. Rear axle combined cylinder - 19. Rear axle drum brake assembly - 20. Rear axle phonic wheel - 21. Rear axle speed sensor - 22. Rear axle ABS solenoid valves - 23. EBL pressure sensor - 24. Dual stop valve - 25. Rear axle brake control relay valve - 26. ASR control solenoid valve - 27. Controlled pressure valve with no return for ASR - 7.5 bars - 28. ABS electronic control unit - 29. Front axle brake control relay valve - 30. Front axle ABS solenoid valve - 31. Front axle diaphragm brake cylinder - 32. Front axle disc brake assembly - 33. Front axle phonic wheel - 34. Front axle speed sensor - 35. Front axle parking brake - 36. Brake light control microswitch - 37. Microswitch for EDC control unit - A. To the air suspension system - B. To the service system - * Optional extra.

79509

ABS-EBL working diagram for 6x2C vehicles**Figure 34**


79510

1. A.P.U. unit - 2. Manual condensate bleeding valve - 3. 30-litre air reservoir - 4. 20 -litre air reservoir - 5. 15-litre air reservoir - 6. Pressure check socket - 7. Retaining valve - 8. Manual control distributor for parking brake - 9. Low pressure switch - 10. Manual control distributor for trailer brake (optional) - 11. Three-control servo-distributor - 12. Low pressure switch - 13. Half-coupling "ISO" - 14. Stop light control microswitch - 15. EDC control unit microswitch - 16. Phonic wheel - 17. Rev sensor - 18. Combined brake cylinder - 19. Drum brake assembly - 20. Membrane brake cylinder - 21. Relay valve - 22. ABS solenoid valve - 23. Pressure sensor - 24. Electronic control unit - 25. Duplex distributor - 26. Membrane cylinder - 27. Disc brake assembly - 28. Axle parking brake - 29. Compressor - A. To air suspensions - B. To services - * Optional.

ABS-EBL working diagram for 6x4 vehicles**Figure 35**

77086


1. Compressor - 2. Air Processing Unit – 10.5 bar - 3. Front axle air tank – 20 l - 4. Parking air tank – 20 l
 5. Rear axle air tank – 30 l - 6. Manual exhaust valve - 7. Rear axle air tank - 20 l - 8. Pneumatic control drive - 9. Parking control manual distributor - 10. Low pressure switch for hand brake in – 6.4 bar - 11. Parking control relay valve - 12. Manual distributor for slowing down trailer - 13. Servo distributor to control trailer braking - 14. Trailer system low pressure switch – 6.4 bar - 15. Trailer half couplings for tractors - 16. Trailer half couplings for trucks - 17. Parking system single-acting valve - 18. Duplex distributor - 19. Combined rear axle cylinder - 20. Rear axle drum brake assembly - 21. Combined front axle cylinder - 22. Front axle drum brake assembly - 23. Rear axle phonic wheel - 24. Rear axle speed sensor - 25. Rear axle ABS solenoid valves - 26. EBL pressure sensor - 27. ABS electronic central unit - 28. Rear axle braking control relay valve - 29. Double cutoff valve - 30. Non-return pressure-controlled valve for ASR - 7 bar - 31. Solenoid control valve for driving ASR - 32. Front axle braking control relay valve - 33. Front axle ABS solenoid valve - 34. Front axle membrane brake cylinder - 35. Front axle phonic wheel - 36. Front axle speed sensor - 37. Front axle disk brake assembly - 38. Stop lights control micro switch - 39. EDC central unit micro switch - A. To pneumatic suspension system - B. To services system - * Optional.

ABS-EBL working diagram for stand alone 4x2 vehicles (trucks)**Figure 36**


1. Compressor - 2. Air processing unit - 10.5 bars - 3. Air tank - 20 l. - 4. Air tank - 30 l. - 5. Manual discharge valve - 6. Air test point - 7. Parking manual control valve - 8. Handbrake low pressure switch turned on - 6.4 bars - 9. Parking system one-way valve - 10. Duplex control valve - 11. Rear axle combined cylinder - 12. Rear axle drum brake assembly - 13. Rear axle phonic wheel - 14. Rear axle speed sensor - 15. Rear axle ABS solenoid valves - 16. EBL pressure sensor - 17. Dual stop valve - 18. Rear axle brake control relay valve - 19. ASR control solenoid valve - 20. Controlled pressure valve with no return for ASR - 7.5 bars - 21. ABS electronic control unit - 22. Front axle brake control relay valve - 23. Front axle ABS solenoid valve - 24. Front axle diaphragm brake cylinder - 25. Front axle disc brake assembly - 26. Front axle phonic wheel - 27. Front axle speed sensor - 28. Front axle parking brake - 29. Brake light control microswitch - 30. Microswitch for EDC control unit - A. To the air suspension system - B. To the service system - * Optional extra.

ABS-EBL working diagram for 6x2 vehicles (trucks)**Legend**

1. Compressor
2. Air processing unit - 10.5 bars
3. Air processing unit - 12.5 bars
4. Front axle air tank - 20 l.
5. Parking air tank - 20 l.
6. Rear axle air tank – 30 l. + 20 l.
7. Manual discharge valve
8. Air test point
9. Parking manual control valve
10. Handbrake low pressure switch turned on – 6.4 bars
11. Parking control relay valve
12. Trailer slowing manual control valve
13. Trailer brake servo control valve
14. Trailer system low pressure switch – 6.4 bars
15. Trailer half-couplings
16. Parking system one-way valve
17. Duplex control valve
18. Load ratio relay valve for added axle braking
19. Diaphragm cylinder\
20. Added axle drum brake assembly
21. Rear axle combined cylinder
22. Rear axle drum brake assembly
23. Rear axle phonic wheel
24. Rear axle speed sensor
25. Added axle suspension air springs
26. Added axle load ratio dual stop valve
27. Rear axle ABS solenoid valves
28. EBL pressure sensor
29. ABS electronic control unit
30. Rear axle brake control relay valve
31. Dual stop valve
32. Controlled pressure valve with no return for ASR – 7 bars
33. ASR control solenoid valve
34. Front axle brake control relay valve
35. Front axle ABS solenoid valve
36. Front axle diaphragm brake cylinder
37. Front axle phonic wheel
38. Front axle speed sensor
39. Front axle disc brake assembly
40. Front axle parking brake
41. Brake light control microswitch
42. Microswitch for EDC control unit
- A. To the air suspension system
- B. To the service system
- * Optional extra
 - For CM vehicles only
- Version with ASR
- ▲ Version without ASR

ABS-EBL working diagram for 6x2 vehicles (trucks)**Figure 37**

79512

ABS-EBL working diagram for stand alone 6x2 vehicles (trucks)**Figure 38**

1. Compressor - 2. Air processing unit - 10.5 bars - 3. Air tank - 30 l. - 4. Manual discharge valve - 5. Air tank - 20 l. - 6. Air test point - 7. Parking manual control valve - 8. Handbrake low pressure switch turned on - 9. Parking control relay valve - 10. Parking system one-way valve - 11. Duplex control valve - 12. Load ratio relay valve for added axle braking - 13. Diaphragm cylinder - 14. Added axle drum brake assembly - 15. Rear axle combined cylinder - 16. Rear axle drum brake assembly - 17. Rear axle phonic wheel - 18. Rear axle speed sensor - 19. Added axle suspension air springs - 20. Added axle load ratio dual stop valve - 21. Rear axle ABS solenoid valves - 22. EBL pressure sensor - 23. ABS electronic control unit - 24. Rear axle brake control relay valve - 25. Dual stop valve - 26. Controlled pressure valve with no return for ASR - 7 bars - 27. ASR control solenoid valve - 28. Front axle brake control relay valve - 29. Front axle ABS solenoid valve - 30. Front axle diaphragm brake cylinder - 31. Front axle phonic wheel - 32. Front axle speed sensor - 33. Front axle disc brake assembly - 34. Front axle parking brake - 35. Brake light control microswitch - 36. Microswitch for EDC control unit - A. To the air suspension system - B. To the service system - * Optional extra - ■ Version with ASR - ▲ Version without ASR.

DESCRIPTION

Service braking

Pedal-operated, pneumatic, with electric control acting on all the wheels and on the trailer.

It is composed of two independent sections, one for activating the braking elements of the front axle, the other for activating the braking elements of the rear axle.

The division of the air system, if one section breaks down, permits the other to remain efficient.

Emergency braking

Emergency braking makes it possible to slow down the vehicle and stop it within a safety distance, even if the braking system has broken down.

It should be interpreted as a partial service brake that, thanks to the dual circuit, anyhow acts on one of the two axles.

Exhaust brake

The "exhaust brake" function is controlled by the EDC control unit that, depending on the required braking capacity, governs this function in combination with the EBS and Intarder systems (where applicable).

Parking brake

This comprises the pneumatic control of the manual control valve, a spring cylinder acting on the rear wheel brakes, locking them (on some versions the parking brake acts on the front brakes too).

In the event of the supply failing, this system automatically brakes the vehicle.

BRAKES

The front and rear brakes, depending on the version, may be disc or drum brakes.

Disc Brakes

For the disc brakes, the discs are keyed onto the wheel hubs and equipped with ventilation fins that permit lowering the high temperature generated under the braking action.

The brake linings are fitted with a wear indicator connected to an indicator light on the dashboard to signal brake lining wear.

The phonic wheels of the ABS device are keyed onto the wheel hubs.

The versions with disc brakes are equipped with:

- ☐ brake calipers type KNORR SN7;
- ☐ disc brakes Ø 432 x 45 mm.

Drum Brakes

For the drum brakes, each braking assembly is composed of a body housing the adjustment pins, control pins and wedge units. The wedge units are operated by the stem of the cylinders that in their turn are operated by compressed air.

The wedge unit rollers, as they travel, cause the control pins to expand that, overcoming the resistance of the shoe return springs, bring the shoes up to the drum to actuate braking. The adjustment and control pins are made integral with the brake body by two pins that fit into a side slot. When the braking action ends, there is no air pressure in the diaphragm section of the combined brake cylinders and so the action of the wedge unit return and shoe return springs take the wedge units back into the starting position.

The brake linings are fitted with a wear indicator.

The phonic wheels of the ABS device are keyed onto the wheel hubs.

The versions with drum brakes are the SIMPLEX type, model:

- ☐ PERROT Ø 410 x 180 mm; Ø 410 x 200 mm.
- ☐ ROCKWELL Ø 410 x 200 mm.

FAULT DIAGNOSIS

SECTION I

ABS-EBS system troubleshooting can be performed with the Cluster or with the diagnosis instruments Modus, IWT and IT 2000.

Diagnosis with the cluster makes it possible to estimate the situation of faults in the system in advance, while the diagnosis instruments are essential to perform thorough diagnosis and operate on the single faults correctly.

Each single instrument displays the diagnosis and repair help.

Diagnosis Instruments

MODUS (Maintenance and Diagnostic System)

A computerized fault-diagnosis station dedicated to diagnosing the brake systems, air suspensions, engines and systems controlled electronically.

The station is equipped with auxiliary functions, such as: programming electronic control units, consulting the spare parts catalogue and service time schedules.

The vehicle has a 30-pin diagnosis socket to interface with the instrument.

IWT (IVECO Wiring Tester)

The IVECO Wiring Tester expands and integrates MODUS.

This instrument is made by IVECO to improve fault diagnosis of vehicle electric and electronic systems.

The vehicle has a 30-pin diagnosis socket to interface with the instrument; the connection between the instrument and the diagnosis socket must be made with the cable identified as no. 4.

IT 2000 (IVECO Electronic Tester)

This makes it possible to take immediate action on the vehicle, identifying it with the chassis number.

It saves the results of diagnostics actions performed.

It can be used as a portable Personal Computer, too, being fitted for remote diagnosis.

By using MODUS as the mother station it is possible to update and configure the IT 2000.

IT 2000 interfaces with the vehicle via a 30-pin diagnosis socket.




The diagnosis socket is positioned in central panel lower side in the cab (at passenger side).

Cluster Diagnosis

It is possible to access the fault memory with the "menu" function key 2 on the steering wheel.

Figure 39



74375

With the ignition key on MAR (+ I 5), press the "menu" function key 2; the display will show a dialogue menu containing a list of the available functions (e.g., Hi-Fi, phone, diagnostics, etc.).

With the 1 and 1 function keys, select the diagnosis function and confirm the selection with the "OK" function key 2.


Select the ABS-EBS system with the select/confirm keys 1 and 2.

Select the ABS-EBS system with the select/confirm keys 1 and 2.

The cluster will display the first diagnostics screen.

After selecting the system, EuroTronic is displayed on a red or green background depending on whether there is any trouble.

Figure 40




74388

The diagnosis information shown on the cluster is split up on two screens:

- ☐ On the first one, it is possible to consult and scroll through all saved/present trouble.
- ☐ On the second one, it is possible to delete the intermittent errors (when you have the relevant password).

FIRST SCREEN

Figure 41



74389

The information on the single faults is arranged on four columns with the following content:

DTC	FMI	OC	ACT
Displays the fault code number	Indicates the type of fault	Fault frequency meter	Fault active/not active status
Two digits (hexadecimal)	Two digits (hexadecimal)	Three digits (hexadecimal)	One character (Y = Yes, N = No)

Troubleshooting via DTC-FMI codes described under the relevant section completes the above information. Each pair of DTC-FMI codes is associated with a description of the fault, the possible system reaction and recommended repairs with the relevant checks.

SECOND SCREEN


Deleting Errors

To select the second screen, press "page" on the steering wheel.

The fault display is eliminated as follows:

- ☐ Press "+", on the request to confirm deletion, press OK.
- ☐ Enter the required password (see the ENTERING PASSWORD paragraph).
- ☐ Press OK to confirm.


Figure 42



74390

Entering the Password

Figure 43



74378a

Select the first number of the password with the ▲ and ▼ keys.

Press OK to confirm each number.

Press ◀ to delete the last number selected.


On completing the password, select the key symbol to confirm.

SECTION 2


Main operating trouble of the brake system:

- | | |
|---|---|
| <ul style="list-style-type: none"> 1 – Poor or abnormal system charge. 2 – Poor or abnormal service braking of the rear axle. 3 – Poor or abnormal service braking of the front axle. 4 – Poor or abnormal trailer service braking. 5 – Poor or no parking braking. 6 – Poor or no trailer parking braking. | <ul style="list-style-type: none"> 7 – Parking brake release delayed. 8 – Trailer parking brake release delayed. 9 – The vehicle skids when braking. 10 – Insufficient trailer retarder braking. 11 – Early wear of the brake linings. 12 – Brake system warning light on. 13 – Parking brake indicator light on with lever in driving position. 14 – Noisy brakes. |
|---|---|

Electric and electronic components diagnosis must be through Modus and IWT.



(continued)



(continued)

3

**POOR OR ABNORMAL SERVICE
BRAKING OF THE FRONT AXLE**

Air system pipes leak or burst

- YES →

Close or replace the worn or damaged fittings. Replace the burst or damaged pipes.

NO



Inefficient operation of the Duplex control valve

- YES →

Overhaul or replace the Duplex control valve.

NO



Brake linings worn and/or vitrified

- YES →

Overhaul or replace the brake linings.

NO



Inefficient operation of the front brakes

- YES →

Overhaul the front brakes.

NO



Inefficient operation of the relay valve

- YES →

Overhaul or replace the relay valve.

NO



Inefficient operation of the diaphragm brake cylinders

- YES →

Overhaul or replace the diaphragm brake cylinders.


NO

Inefficient operation of the automatic clearance
recovery device


- YES →

Replace the complete brake calliper.


(continued)




(continued)




(continued)




(continued)



(continued)





11

**EARLY WEAR
OF THE BRAKE LININGS**

Inefficient operation of the Duplex control valve

- YES →

Overhaul or replace the Duplex control valve.

NO



Inefficient operation of the brakes

- YES →

Overhaul the brakes.

NO



Inefficient operation of the triple control servo control valve

- YES →

Overhaul or replace the triple control servo control valve

NO



Inefficient operation of the relay valve

- YES →

Overhaul or replace the relay valve.

12

**BRAKE SYSTEM
WARNING LIGHT ON**

Air system pipes leak or burst

- YES →

Close or replace the worn or damaged fittings. Replace the burst or damaged pipes.

NO




Inefficient operation of the A.P.U.


- YES →

Overhaul or replace the A.P.U.

(continued)



(continued)



TIGHTENING TORQUES

PART	TORQUE	
	Nm	(kgm)
Compressor		
Nut fixing pulley	200	(20.4)
Combined brake cylinder (for disc brakes)		
Nuts for bolts fixing cylinder to brake calliper	180 ± 30	(18.3 ± 0.3)
Manual brake release screw (type 14 – front disc brakes)	max 35	(max 3.6)
Manual brake release screw (type 20/27 – rear disc brakes)	max 70	(max 7.1)
Fixing fittings	40 ± 5	(4 ± 0.5)
Combined brake cylinder (for drum brakes)		
Manual brake release screw	315 ± 15	(32.1 ± 1.5)
Ring nut fixing brake cylinder	30 ± 1	(3 ± 0.1)
Fixing fittings	40 ± 5	(4 ± 0.5)
Diaphragm brake cylinder (for disc brakes)		
Nut for fixing cylinder to brake calliper	180 ± 30	(18 ± 3)
Fixing fittings	40 ± 5	(4 ± 0.5)
Diaphragm brake cylinder (for drum brakes)		
Ring nut fixing brake cylinder	315 ± 15	(32.1 ± 1.5)
Nut fixing clamp retaining cylinder cover	8 ± 1	(0.8 ± 0.1)
Fixing fittings		
☐ BENDIX cylinder	17.5 ± 2.5	(1.7 ± 0.2)
☐ KNORR-BREMSE cylinder	40 ± 5	(4 ± 0.5)
☐ WABCO cylinder	45 ± 5	(4.5 ± 0.5)
Front axle disc brakes 5876-57080/DI		
Self-locking hex screw M20 × 1.5 fixing brake callipers	615.5 ± 61.5	(62.7 ± 6.2)
Nut fixing wheels	665.5 ± 66.5	(67.8 ± 6.7)
Self-locking hex screw to fix brake disc to wheel hub	281.5 ± 13.5	(28.7 ± 1.3)
Self-locking hex screw M16 × 1.5 to fix brake calliper mount to stub axle	313.5 ± 15.5	(32 ± 1.6)
Threaded plug for wheel hub cover	55 ± 5	(5.5 ± 0.5)
Ring nut fixing wheel bearings	515.5 ± 24.5	(52.6 ± 2.5)
Cylindrical head screw with hex socket to lock wheel bearing adjustment clamp	27.5 ± 2.5	(2.8 ± 0.2)
Cover for wheel hub ♦	130 ± 10	(13 ± 1)
Front axle disc brakes 55080/DI		
Nut fixing wheel	600 ⁺⁵⁰ / ₋₂₀	(61.2 ⁺⁵ / ₋₂)
Hex screw to fix brake disc to wheel hub	281.5 ± 13.5	(28.7 ± 1.3)
Threaded plug for wheel hub cover	55 ± 5	(5.5 ± 0.5)
Nut fixing wheel bearings	515.5 ± 24.5	(52.6 ± 2.5)
Cover for wheel hub ♦	130 ± 10	(13 ± 1)
Screw fixing nut	27.5	(2.8)
Screw fixing mount	289.5 ± 14.5	(29.5 ± 1.5)
Screw fixing brake calliper	615 ± 61	(62.7 ± 6.2)
♦ Spread a bead of sealant solely on the mating surface of the hub cover, using the specific metering device. Protect the threaded part. Use LOCTITE sealant type 574.		


TIGHTENING TORQUES

PART	TORQUE	
	Nm	(kgm)
Added rear axle disc brakes 56082/I		
Nut fixing wheels	665 ± 61.5	(67.8 ± 6.2)
Screw fixing drive shaft flange • *	90 ± 10	(9.2 ± 1)
Ring nut fastening wheel hub bearing	932 ± 98	(95 ± 10)
Screw fixing brake disc to wheel hub	281.5 ± 13.5	(28.7 ± 1.3)
Nut for screw fixing brake calliper to mount	615.5 ± 61.5	(62.7 ± 6.2)
Nut for screw fixing brake calliper mount	289.5 ± 14.5	(29.5 ± 1.5)
• Apply LOCTITE 243 sealant onto the thread * Spread the drive shaft / wheel hub contact surface with sealant type IVECO I905685 (LOCTITE I4780)		
MS I3-I75 rear axle disc brakes		
Nut fixing wheels	665.5 ± 61.5	(67.8 ± 6.2)
Screw fixing drive shaft flange *	262 ± 27	(26.7 ± 2.7)
Ring nut fastening wheel hub	932 ± 98	(95 ± 10)
Screw fixing brake disc to wheel hub	281.5 ± 13.5	(28.7 ± 1.3)
Screw fixing brake calliper to mount	615.5 ± 61.5	(62.7 ± 6.2)
Nut for screw fixing brake calliper mount	289.5 ± 14.5	(29.5 ± 1.5)
* Spread the flange / wheel hub contact surface with sealant type IVECO I905685 (LOCTITE I4780)		
MS I3-I75 rear axle drum brakes		
Nut fixing wheels	665.5 ± 61.5	(67.8 ± 6.2)
Screw fixing drum	54.5 ± 12.5	(5.5 ± 1.2)
Screw fixing drive shaft flange *	262 ± 27	(26.7 ± 2.7)
Ring nut fastening wheel hub	932 ± 98	(95 ± 10)
Nut for screw fixing brake mount	289 ± 14.5	(29.5 ± 1.5)
Screw fixing speed sensor mount •	6 ± 1	(0.6 ± 0.1)
RT I60 E/I rear axle drum brakes		
Nut fixing wheel	600 ⁺⁵⁰ ₋₂₀	(61.2 ⁺⁵ ₋₂)
Screw fixing drive shaft flange *	232.4 ± 24.5	(23.2 ± 2.5)
Ring nut fastening wheel hub ■	392.3	(40)
Nut for screw fixing brake mount	289 ± 14.5	(29.5 ± 1.5)
* Spread the flange / wheel hub contact surface with sealant type IVECO I905685 (LOCTITE I4780)		
Added axle drum brakes 56082/I		
Nut for screw securing brake mounting	290 ± 14.5	(29 ± 1.5)
Tapered threaded plug for wheel hub cover	27 ± 2	(2.7 ± 2)
Ring nut for wheel hub bearings *	392.3	(40)
* See adjustment on rear axle section.		


TIGHTENING TORQUES

PART	TORQUE	
	Nm	(kgm)
Added axle drum brakes 55080		
Screw fixing drum	40 ± 4	(4 ± 0.4)
Ring nut for wheel hub bearings	515.5 ± 24.5	(51.5 ± 2.4)
Cover for wheel hub ♦	130 ± 10	(13 ± 1)
Plug on hub cover	50 ± 5	(5 ± 0.5)
Added axle drum brakes 57080		
Screw fixing drum	40 ± 4	(4 ± 0.4)
Nut for screw securing brake mounting	313.5 ± 15.5	(31 ± 1.5)
Ring nut for wheel hub bearings	515.5 ± 24.5	(51.5 ± 2.4)
Cover for wheel hub ♦	130 ± 10	(13 ± 1)
Plug on hub cover	50 ± 5	(5 ± 0.5)
♦ Spread a bead of sealant solely on the mating surface of the hub cover, using the specific metering device. Protect the threaded part. Use LOCTITE sealant type 574.		
Rear axle drum brakes 451391/I		
Screw fixing drum	50 ± 5	(5 ± 0.5)
Screw fixing drive shaft flange *	50 ± 5	(5 ± 0.5)
Brake support clamping screw	295 ± 30	(29.5 ± 3)
Nut fixing wheels	600 ⁺⁵⁰ ₋₂₀	⁺⁵ ₋₂


* Apply LOCTITE 573 sealant onto the thread

TOOLS**TOOL NO.****DESCRIPTION****99301001**


Grinding and turning machine for brake discs and drums

99301005


Brake disc turning device

99301006


Brake shoe turning device

99305079







Brake shoe turning device

99305087







Rivet press


99305117

Instrument to check air circuits


TOOLS	
TOOL NO.	DESCRIPTION
99321024	 Hydraulic trolley to remove and refit wheels
99322215	 Stand for overhauling front and rear axles
99341003	 Single-acting bridge
99341016	 Pair of brackets with hole
99341017	 Pair of brackets with hole
99345049	 Reaction block for extractors

TOOLS


TOOL NO.	DESCRIPTION	
99345053		Reaction block for puller tools
99345055		Reaction block for puller tools
99345103		Wheel hub fitting tool
99348001		Extractor with locking device
99354207		Wrench for wheel hub sumps
99355167		Wrench (114 mm) for wheel hub bearing adjustment nut

TOOLS**TOOL NO.****DESCRIPTION****99355175**


Wrench (105 mm) for wheel hub bearing adjustment nut

99355180


Wrench (105 mm) for wheel hub bearing adjustment nut

99356001

Wheel brake shoes adjusting wrench







99356006Wrench to remove and refit brake cylinder ring nut
(use with 99389817)**99370005**







Grip for interchangeable drifts

99370006







Grip for interchangeable drifts







TOOLS

TOOL NO.	DESCRIPTION	
99370007		Grip for interchangeable drifts
99370317		Reaction lever with extension to fasten flanges
99370700		Guide to fit wheel hub
99370706		Tool to drive in wheel hub bearing
99370708		Tool to drive out wheel hub bearing
99372211		Tool to remove and refit brake shoe retainer springs





TOOLS	
TOOL NO.	DESCRIPTION
99372213	 Tool for turning brake drum (use with 99301001)
99372228	 Hub for positioning dismantled floating shoe turning tools on lathe 99301001
99372230	 Tool for turning dismantled floating shoes (Rockwell 410) (use with 99301001 – 99372228)
99372231	 Tool for turning dismantled floating shoes (Perrot 410) (use with 99301001 – 99372228)
99372237	 Tool to mount brake caliper sliding bush guard
99372238	 Tool to extract brake caliper thrust units

TOOLS

TOOL NO.	DESCRIPTION	
99372239		Tool to mount thrust units with brake caliper guard
99372240		Tool to remove and refit brake caliper sliding bush guide bushings (use with 99372237)
99372242		Tool for notching brake caliper sliding bush guide bushing
99372243		Tool for mounting thrust pressure inner seals (use with 99372239) and for mounting the brass bush of brake caliper guide pin (use with 99372240 and with the screw of 99372237)
99372244		Tool for mounting the rubber bush of brake caliper guide pin (use with the screw of 99372237)
99372245		Tool for dismounting the rubber bush of brake caliper guide pin (use with the screw of 99372237)

TOOLS		
TOOL NO.		DESCRIPTION
99373004		Key to remove brake cylinder gasket (Rockwell)
99374132		Installer, wheel hub inner seal (use with 99370006)
99374134		Installer, wheel hub inner seal
99387050		Cutters for polyamide pipes
99388001		Wrench (80 mm) for wheel hub bearing adjustment nut
99389816		Torque multiplier x 4, with square fitting, 3/4" in, 1" out (maximum torque 2745 Nm)

TOOLS

TOOL NO.	DESCRIPTION	
99389817		Torque wrench (60-32 Nm) with 1/2" square fitting
99389819		Torque wrench from 0 to 0.9 kgm with 1/4" square fitting
99395026		Tool to check rolling torque of wheel hubs (use with torque wrench)
99395684		Dial gauge with magnetic base

SPECIFICATIONS AND DATA - PNEUMATIC SYSTEM

DESCRIPTION						
Compressor						
☐ WABCO 412 352 008					Single cylinder	
Capacity					352 cm ³	
Bore					85 mm	
Stroke					62 mm	
Head cooling					Water	
Max. continuous rpm					3000 r.p.m.	
Max. working pressure					14 bar	
☐ KNORR-BREMSE 2W460R					Twin cylinder	
Capacity					464 cm ³	
Bore					86 mm	
Stroke					40 mm	
Head cooling					Water	
Max. continuous rpm					3060 r.p.m.	
Max. working pressure					14 bar	
A.P.U.						
☐ KNORR ZB 4592 - ZB 4593						
Safety valve opening pressure					13.0 ± 4 bar	
Max. working pressure					13.0 bar	
Disconnecting pressure					10.5 ± 0.2 bar	
Duty temperature					-40 to +80 °C	
☐ KNORR ZB 4597						
Safety valve opening pressure					14.5 ± 4.0 bar	
Max. working pressure					13.0 bar	
Disconnecting pressure					12.5 ± 0.2 bar	
Duty temperature					-40 to +80 °C	
Air tanks						
4 x 2 vehicles	Tank capacity				Total capacity	Working pressure
	15l	20l	30l	80l		
190 S.. P/FP-CT		2	1		70	10.5
190 S.. /FP-D		1	1		50	10.5
440 S.. T/P/FP - LT/FP-CT		2	1		70	10.5
6x2 P vehicles 260 S.. YP/YPS/YPT/YFP/YFS/YTN		3	1		90	10.5
260 S.. Y/FP-D/FS-D		2	1		70	10.5
6x2 C vehicles 440 S.. TX/P	1	2	1		85	10.5
6x4 vehicles 440 S.. TZ/P		3	1		90	10.5

DESCRIPTION

Manual discharge valve

Maximum working pressure	13 bar
--------------------------	--------

ABS duplex control valve☐ **KNORR - BREMSE DX 60 A**

Supply pressure	10.5 bar
-----------------	----------

Working pressure	10.5 bar
------------------	----------

EBS duplex control valve☐ **WABCO 480001300**

Working pressure	10 bar
------------------	--------

Maximum working pressure	13 bar
--------------------------	--------

Relay valve☐ **KNORR - BREMSE AC574AXY**

Maximum working pressure	10.2 bar
--------------------------	----------

Automatic and graduated release coupling heads☐ **BOSCH - KNORR - BREMSE - WABCO**

Working pressure	8.5 bar
------------------	---------

EBS rear axle electro-pneumatic graduated release (chassis cabs only)☐ **WABCO 480103025 - 480130020**

Maximum working pressure	13 bar
--------------------------	--------

Terminal voltage	24 ⁺⁸ Volt - 9,5
------------------	--------------------------------

Max. terminal current	5A / 10 bar
-----------------------	-------------

EBS rear axle electro-pneumatic graduated release (tractors only)☐ **WABCO 480 103 024 - 480130020**

Maximum working pressure	13 bar
--------------------------	--------

Terminal voltage	24 ⁺⁸ Volt - 9,5
------------------	--------------------------------

Max. terminal current	5A / 10 bar
-----------------------	-------------

EBS rear axle redundancy solenoid valve (chassis cabs only)☐ **WABCO 480 205 102**

Maximum working pressure	10.2 bar
--------------------------	----------

Voltage	24 Volt
---------	---------

ABS-EBS solenoid valve☐ **WABCO 472 195 055 0**

Maximum working pressure	13 bar
--------------------------	--------

Voltage	24 Volt
---------	---------

☐ **KNORR BREMSE**

Maximum working pressure	10 bar
--------------------------	--------

Voltage	24 Volt
---------	---------

DESCRIPTION	
EBS trailer servo control valve	
☐ WABCO 480 204 001 0	
Supply pressure	8.5 bar
Max. working pressure	13 bar
Voltage	24 ± 8 Volt - 6,5
Max. permanent voltage between orifice 6.4 and 6.5	8 Volt
Max. current	1.4A / 8 bar
Outlet pressure	8 bar
Parking brake control valve (vehicles suited for towing)	
☐ KNORR - BREMSE DPM 60 EY	
Supply and working pressure	8.5 bar
Travel of control lever (discharge) with start of emergency braking (point of resistance)	67°
Parking braking	73°
Test braking to check supply to triple control valve	86°
Parking brake control valve (standby vehicles)	
☐ KNORR - BREMSE DPM 61 EY	
Supply and working pressure	8.5 bar
Travel of control lever (discharge) with start of emergency braking (point of resistance)	67°
Parking braking	73°
Test braking to check supply to triple control valve	
EBS proportional relay valve (for front axle)	
☐ WABCO 480 202 003	
Supply pressure	13 bar (max)
Outlet pressure	12 bar
Dual stop valve (for vehicles with ABS/EBL)	
☐ WABCO 434 208 029	
Supply pressure	10 bar
ABS trailer triple servo control valve	
☐ WABCO 973 009 0130 - KNORR - BREMSE AC 597 B	
Supply pressure	8.5 bar
Predominance	0.2 bar
Differential control pressure (pipes 41 and 22)	2.5 + 0.5 bar - 0.3
Pressure test point valve	
Maximum working pressure	12.5 bar

DESCRIPTION	
ASR control normally-closed solenoid valve	
☐ WABCO 472 170 606 0	
Working pressure	5.5 ÷ 11 bar
Maximum supply pressure	13 bar
Voltage	24 Volt
Current	0.69 Amp
ASR control exclusion normally-open solenoid valve	
☐ WABCO 472 173 226 0	
Working pressure	0 ÷ 11 bar
Maximum supply pressure	13 bar
Voltage	24 Volt
Current	0.69 A
ABS electronic control unit	
☐ BOSCH 446 004 320	
Supply voltage	24 Volt
EBS electronic control unit	
☐ WABCO 446 135 018	24 Volt
Diaphragm brake cylinder (for front disc brake)	
☐ Type 20: KNORR - BREMSE IC 7223 I	
Maximum working pressure	10.7 bar
Minimum stroke	64 mm
☐ Type 20: KNORR - BREMSE IC 72233	
Maximum working pressure	10.7 bar
Minimum stroke	64 mm
☐ Type 22: KNORR - BREMSE IC 72235	
Maximum working pressure	10.7 bar
Minimum stroke	64 mm
☐ Type 24: KNORR - BREMSE IC 72237	
Maximum working pressure	10.7 bar
Minimum stroke	64 mm
Combined brake cylinder (for front disc brake)	
☐ Type 20 - 22 - 24: KNORR - BREMSE Z 003479	
☐ Type 22 - 24: KNORR - BREMSE Z 003480	
Maximum working pressure	
- fitting 11	10.7 bar
- fitting 12	8.5 bar
Minimum stroke	64 mm

DESCRIPTION

Diaphragm brake cylinder (for drum brake)☐ **Type I8: BENDIX C 654 I80 29**

Maximum working pressure	8.5 bar
Minimum stroke	53 mm

☐ **Type I8: WABCO 423 073 209 0**

Maximum working pressure	8 bar
Minimum stroke	53 mm

Diaphragm brake cylinder (for added axle disc brake)☐ **Type I2: KNORR - BREMSE IC 7256 I**

Maximum working pressure	10.7 bar
Minimum stroke	57 mm

☐ **Type I4: KNORR - BREMSE IC 72563**

Maximum working pressure	10.7 bar
Minimum stroke	57 mm

Diaphragm brake cylinder (for added axle drum brake)☐ **Type I0.5: KNORR - BREMSE IB 85629**

Maximum working pressure	8.5 bar
Minimum stroke	53 mm

☐ **Type I0.5: BENDIX IC 654 I05 38**

Maximum working pressure	8.5 bar
Minimum stroke	53 mm

☐ **Type I0.5: WABCO 423 I4I 2090**

Maximum working pressure	8 bar
Minimum stroke	51 mm

☐ **Type I2: BENDIX C 654 I20 70**

Maximum working pressure	8.5 bar
Minimum stroke	50 mm

☐ **Type I2: KNORR - BREMSE IB 9I644**

Maximum working pressure	8.5 bar
Minimum stroke	50 mm

DESCRIPTION

Combined brake cylinder (for rear disc brake)☐ Type 20/27 KNORR - BREMSE IC 68086

Maximum working pressure

- fitting 11 10.7 bar

- fitting 12 8.5 bar

Minimum stroke 64 mm

Combined brake cylinder (for rear drum brake)☐ Type 18/24 HF KNORR - BREMSE IC 559 76

Maximum working pressure 8.5 bar

Minimum stroke 53 mm

☐ Type 20/24 HF KNORR - BREMSE IC 559 78

Maximum working pressure 8.5 bar

Minimum stroke 53 mm

Pressure sensor☐ WABCO 441 040 015

Supply voltage 8 - 32 Volt

Measurement range 0 - 10 bar

Low-pressure switch☐ F 130 46 S - F 130 47 STrip pressure 6.6 ± 0.2 bar**On-off valve**☐ WABCO 434 205 061

Working pressure 10 bar









Controlled pressure valve☐ WABCO 434 100 199 - KNORR - ASR BREMSE 119 435 47 - BENDIX VPG 4MOpening pressure $7^{+0.1}_{-0.3}$ bar**One-way valve**☐ PEL 50 473 - C

Working pressure 12 bar











Backpressure 0.2 bar







Trailer automatic and handbrake engaging low-pressure switch☐ F 130 48Trip pressure 5.5 ± 0.2 bar

SPECIFICATIONS AND DATA - BRAKES

 DISC BRAKES: FRONT AXLE CENTRAL ADDED AXLE REAR AXLE (Vehicles with EBS) REAR ADDED AXLE	5876/4/5 - 5886/5 5876/2/4 MS 13-175 55080/DI (DN8071) - 57080/DI (N8072) 56082/DI (N9171)	
 Brake calliper cylinders: - number - diameter Ø mm	2 68	
 Brake lining thickness: - normal S mm - minimum permissible S mm	21 2	
 Brake disc diameter Ø mm	432	
 Brake disc thickness: - normal S mm - minimum permissible S mm	45 37 (4 mm each side)	
Operating clearance G mm	0.5 to 1	
 WHEEL HUBS	FRONT AXLES 58/76/2/4/5 - 55080/DI-57080/DI 5886/5	56082/DI
 Wheel hub bearings	2 with tapered rollers	2 with tapered rollers Unit-Bearing
 Hub bearing end float mm	max 0.16	-
 Hub bearing end float adjustment	Not adjustable Tightening ring nut to torque	
 Rolling torque da Nm	0.50 max.	
 Oil for wheel hub bearings Tutela W 140/M-DA (Tutela TRUCK FE-AXLE for vehicles with rear disk brakes) Litres Quantity of oil for each hub kg	0.33 (•) 0.30 (•)	- -

- For MS 13-175 rear axle see rear axle section.

PERROT DRUM BRAKES (vehicles without EBS)		AXLES 55080 57080	REAR AXLE RT 160/I ADDED AXLE 56082/I	REAR AXLE MS13-175
	Drum diameter: - Nominal Ø mm - 1 st uprating Ø mm - 2 nd uprating Ø mm	410 to 410.4 412 414		
	Brake lining thickness: - Nominal S mm - 1 st uprating S mm - 2 nd uprating S mm - minimum permissible S ₁ * mm	21.3 22.3 23.3 4.7		
* In correspondence with the last rivet, on the opposite side of the pin, of the shoe with wear sensor.				
	Diameter of brake linings: - Nominal S mm - 1 st uprating S mm - 2 nd uprating S mm	407.5 to 409 409.5 to 411 411.5 to 413		
	Width of brake linings: L mm	180 200 (56082/I)		200
	Clearance between brake linings and drum G mm	0.5 to 1.45		
	Maximum error of concentricity in the drum diameter after turning E mm	0.04		
	WHEEL HUBS			
	Wheel hub bearings	Two with tapered rollers		2 with tapered rollers (Unit Bedring)
	Hub bearing end float mm	0.16 max	0.00 to 0.05	Not adjustable
	Hub bearing end float adjustment	With ring nut		Tightening to torque with ring nut
	Wheel hub bearing rolling torque	daNm 0.50 max.	Nm 2.45 max.	-
	Oil for wheel hub bearings Tutela W 140/M DA Litres Quantity of oil for each hub kg	0.33 0.30	0.75 (56082/I) 0.69 (56082/I)	(•) (•)
• See rear axle section.				

ROCKWELL REAR DRUM BRAKES		Rear axle 451391
	Drum diameter: - Nominal Ø mm - 1 st oversize Ø mm - 2 nd oversize Ø mm	410 to 410.4 412 to 412.4 414 to 414.4
	Brake lining thickness: - Nominal S mm - 1 st oversize S mm - 2 nd oversize S mm - Minimum permitted S ₁ * mm	22.1 23.1 24.1 5
*Aligned with last rivet, from opposite side of cylinder from shoe with wear sensor.		
	Brake lining diameter: - Nominal Ø mm - 1 st oversize Ø mm - 2 nd oversize Ø mm	407.5 to 408.5 409.5 to 410.5 411.5 to 412.5
	Brake lining width: L mm	200
	Clearance between brake linings and drum G mm	1 to 1.25
	Max. error of concentricity of drum diameter after skimming E mm	0.04




CHECKS ON MAIN COMPONENTS OF BRAKE SYSTEM

Since the vehicle system is type approved to European code standards, it is vital to periodically check its efficiency and that of the relevant components with the device 99305117.


These checks should be carried out with the vehicle stationary, using the compressed air of the tanks filled by the compressor, with the engine started.




Always lock the vehicle before doing any work. Periodically check the pressure gauges, comparing them with a sample pressure gauge.

DEVICE	DESCRIPTION	TASK
	Compressor	Check the tightness of fittings and compressor fixing; make sure the cooling fins are not dirty.
	A.P.U. (Air Processing Unit)	Using a bleed valve or loosening a screw plug (with integrated bleed hole), check whether the air drier works properly. In this case, the air needs to come out of the tank without there being any trace of condensation water.
	Air tanks for: ☐ Front axle ☐ Rear axle ☐ Parking + trailer ☐ Services ☐ For regeneration	Check the seal and corrosion protection. Drain the condensate off from the tanks via the drain valve.
	Duplex control valve	Check that the pedal gasket is not worn, that the brake control linkage is properly tightened and lubricated, not out of shape. Check that the lever housings are neither worn nor oxidized.
	Pneumatic pressure test points	Check the safety caps are on
	Parking brake control valve	Apply the parking brake control valve till it trips; the pressure gauge on the test point has to show pressure discharge down to 0 bar in 1 sec.
	Parking brake control valve (with check position)	At the same time, at the automatic coupling pipe, the pressure gauge has to show a pressure of 7.5 bars.


(continued)

**Diaphragm cylinder**


Check its fixing, integrity and seal.
The bleed hole must be facing downwards and must not be clogged.

**Combined cylinder**

Check its fixing, integrity and seal.
The bleed hole must be facing downwards and must not be clogged.

**Relay valve**


Check its operation and seal, evaluating how fast the brake cylinders act.

**Servo control valve with triple control for trailer braking, with modulated servo diverter incorporated**


Fill the tank. Connect one pressure gauge to the automatic coupling head and one to the graduated coupling head.
A pressure of 1 bar, sent by the twin control valve, must at the graduated coupling head correspond to a pressure of from 0.8 to 1.5 bars. Make a full braking (vehicle stationary).
The coupling head must have available the required braking pressure or a pressure decreased by 0.5 bars. Apply the parking brake; at the graduated coupling head, the pressure must stay unchanged or decreased by 0.5 bars.

**Coupling heads**

Check there is no dirt or damage in the coupling guides.
After coupling is made, press the brake pedal and check the seal and stability between the coupling heads introducing air at 8.5 bars.
Check there is no air leakage from the coupling gaskets.


**Disc brake calliper
Brake disc
Brake linings**

Check the wear of the brake linings, scoring and wear of the brake disc, efficiency of the pistons, wear of the dust caps.

**Drum brakes**

When the pressure on the pedal stops, the shoes need to return to the rest position quickly and evenly on all the wheels.
Check the clearance between shoes and drum.
Check the thickness of the brake linings.

(continued)



Pipes and fittings

Seal of pneumatic system
with engine off and under
activation pressure

Seal of pneumatic system in the
partial braking range with 3 bars

Check the metal pipes are in a perfect state, with no dents or cranks; the polyamide pipes must have no cracking or cuts. Check moreover they are far from sharp edges of the bodywork and chassis that could damage them. Check that all the pipe brackets are firmly secured, their slackening causes vibration with the ensuing risk of breakage. Check that the polyamide pipes have not come into contact with oil or mineral grease, rubber solvents. Press forcefully on the brake pedal and check the pipes do not swell. Check there is no leakage from the various fittings or it will be necessary to tighten them fully, but taking care not to cause any abnormal torsion on the pipes. In all the above cases it is necessary to replace the relevant parts if there is even the slightest doubt about their efficiency. Apart from their conditions, it is advisable to replace the flexible hoses after considerable mileage or after a lengthy period of using the vehicle in order to prevent sudden bursting due to ageing and fatigue.


This check is carried out by introducing air pressure into the system of no less than 5 bars, spreading fairly dense soapy water over the couplings and fittings with a soft brush and seeing there is no leakage. Air leakage corresponding to a soap bubble of $\varnothing 25$ mm in 5 seconds is tolerated, or anyhow a max. fall in pressure within 10 min. of 2% of the disengagement pressure = $0.22 + 0.02$ bars.

For 3 min. the pressure has to remain stable in the pneumatic system. This check should be made with the parking brake disengaged.

MAIN COMPONENTS OF THE BRAKING SYSTEM

790510 Compressor

Figure 44




73820

It produces compressed air needed to supply the pneumatic system. Depending on the version, it may be a single- or twin-cylinder compressor.

Head locking screw tightness

Figure 45



73821

60732

A = single-cylinder compressor

B = twin-cylinder compressor


Following the order shown in the figure, tighten the screws fixing the cylinder head to the required torque.

Fault diagnosis

TROUBLE	POSSIBLE CAUSE	REMEDY
Oil leakage from the flange on the outside	Incorrect tightening torque	Lock the screws to the required values.
	Flange seal surfaces not perfectly flat.	Check the sealing surfaces, replace any defective parts or make them level.
	Gasket broken. Shaft gasket damaged.	Change the gasket. Change the gasket.
Oil leakage from the head	Scraper ring worn (noted because the seal seat is shiny). Defective assembly of the scraper ring.	Replace the piston assembly. It should be fitted with the word TOP facing the head of the compressor. Fit at 120° to each other.
	Scraper ring and piston rings all on the same vertical line.	Grind the cylinder and mount an uprated piston.
	Cylinder scored or ovalized.	Grind the cylinder and mount an uprated piston.
Total lack of compression	Compression or intake valve deteriorated.	Replace deteriorated parts.
	Piston rings all on the same vertical line.	Mount rings at 120° to each other.
	Perforation of the piston or breakage of parts connected to the piston.	Replace the piston assembly.
	Gaskets damaged.	Replace the gaskets.
	Energy-saving device in open position during intake.	Replace the cylinder head.
Poor efficiency	Piston rings worn.	Replace the piston (together with piston rings).
	Air leakage between cylinder and head.	Replace the gasket and lock the screws with the required torque.
	Energy-saving device, intake or compression valves deteriorated.	Replace the deteriorated parts.
	Excessive clearance between piston and cylinder.	Grind the cylinder and mount an uprated piston.
	Particles of carbonized oil between the intake and compression valves.	Clean the valves.
Mechanical noise	Too much clearance between the small end and pin, between the pin and hole in the piston, between the shaft and big end, between the shaft and bushings and between the piston and cylinder.	Check the tolerance of the couplings at issue.
	Too much clearance between the piston and cylinder.	Grind the cylinder and mount an uprated piston.
	Too much incrustation between the piston and cylinder head caused by burnt oil.	Clean the incrustated parts and replace the valves.
Water blow-by	Head gasket or coupling faces scored and uneven.	Replace the damaged parts.

A.P.U. (Air Processing Unit)

Figure 46



73913

Its function is to keep the air clean and at the right moisture level in the system.


In addition, it has to distribute and keep the pressure needed for the operation of the connected systems at the outlet.

On CM (Movable Body) vehicles, the component is used with a setting of 12.5 bars, while versions below this one have a setting of 10.5 bars.

The A.P.U. contains two pressure sensors connected with an MUX system to display the front/rear axle pressure on the Cluster.

793110 Duplex control valve (vehicles without EBS)

Figure 47




73914

It takes air from the tanks and distributes it to the braking elements.

It is self-limited, that is it limits the delivery of air at a set maximum pressure, the outcome of which is a greater availability of energy and a constant maximum braking pressure irrespective of the pressure swings in the tanks. Vehicles fitted out as trucks have duplex control valves mounted with the function of correcting the braking force of the operator elements of the front axle according to the correction made by the load apportioning valve.

Duplex control valve with electric transmitter (vehicles with EBS)

Figure 48



73915

The duplex control valve generates electric and pneumatic signals needed to control the brake system.


Under normal circumstances the component works with the electric circuit only, while the pneumatic circuit is activated when the electric circuit is out of service.

Fault Diagnosis (vehicles without EBS)

TROUBLE	POSSIBLE CAUSE	REMEDY
Air leaks from the outlet hole	Leaks from the outlet pipes due to wear of the gaskets	Overhaul the device, replacing the worn parts.
Control valve with abnormal self-limitation	Self-limitation higher or lower than as required	Set the device using the specific screw.
Vibration during braking	Spring wear Air leakage due to piston gaskets in the two sections	Overhaul the device, replacing the worn parts. Overhaul the device, replacing the worn parts.
Abnormal operation of the brake light switch	It fails to close the electric circuit	Replace the switch.
	It fails to open the electric circuit	Replace the switch.

793331 Relay valve (vehicles without EBS)

Figure 49




36743

The device allows to speed up compressed air release from combined cylinder section, so cutting down braking time.

Proportional relay valve for front axle (vehicles with EBS)

Figure 50



73916

This component modulates the pressure to the cylinders of the front axle.


It comprises a proportional solenoid valve, a pneumatic relay and a pressure sensor.

Fault Diagnosis (vehicles without EBS)

TROUBLE	POSSIBLE CAUSE	REMEDY
Air leaks from the outlet with the control pipe exhausting	Leakage from the introduction or from the seals.	Overhaul the device, replacing any defective parts.
Air leaks from the outlet with supply in the control pipe	Leakage from the piston gasket or from the exhaust valve.	Overhaul the device, replacing any defective parts.


798510 Coupling heads

Figure 51



52871


The version for the "Graduated" pipe is equipped with a red cover and a safety projection (1), while the version for the "Automatic" pipe is equipped with a yellow cover and a side safety projection (2). The safety projections are used to avoid coupling errors.

Rear axle electro-pneumatic modulator (for vehicles with EBS)**Figure 52**

60934

Its task is to modulate the pressure to the brake cylinders of the rear axle.

It has an electronic control unit that controls the rear speed sensors and the wear of the brake linings of the rear axle. This electronic control unit communicates over the CAN network with the E.B.S. control unit.

Figure 53


73917

A = Diagram of rear axle electro-pneumatic modulator (for 4x2 and 6x2 truck versions).

B = Diagram of rear axle electro-pneumatic modulator (for tractor versions).


Fault Diagnosis

TROUBLE	POSSIBLE CAUSE	REMEDY
Air leaks from the outlet with the control valve lever in the brake release position	Piston, outlet valve, seals worn or defective.	Clean thoroughly, check the rubber parts and the seats are sound.
Air leaks from the outlet with the control valve lever in the emergency or parking braking position	Piston and associated seal defective or deteriorated.	Clean thoroughly, check the parts and overhaul the device, replacing the defective parts.
Air leaks from the cover of the control valve lever	Plate, gasket, seals worn.	Clean the parts thoroughly, check the surfaces of the gasket and seals, check the integrity of the rubber parts and the relevant seats. Overhaul the device, replacing the defective or worn parts, and restore the mating faces if necessary.
Control valve lever hard to turn	Interference inside the control valve.	Clean thoroughly and check all the component parts. Overhaul the device, replacing defective parts. During assembly, grease all the sliding parts in moderation. If you find any defects or wear such as to jeopardize operation, replace the complete device.

Redundancy valve (for 4x2 and 6x2 trucks)**Figure 54**


73918

This component has the task of ensuring the rear axles brake even if the EBS is entirely out of service.

ABS-EBS solenoid valve**Figure 55**


35805

This component modulates the air pressure in the brake circuits. When the electronic control unit detects a tendency for one of the wheels to lock, the valve shuts off the supply to the brake cylinder, preventing the wheel from locking.

Dual stop valve**Figure 56**

73919

On vehicles with an ABS/EBL system, this component has the task of sending the rear axle braking control relay valve the control pressure from the duplex control valve (normal working function). With the ASR function active, this component will send the activation pressure from the ASR solenoid valve. In addition, it is used on 6x2 vehicles to transmit the pressure in the air springs, to the added axle braking control relay valve, according to the load. On vehicles with the EBS, it has the task of sending the pressure of the front axle braking relay valves according to the load bearing on the air springs of the added axle.

793332 Triple servo control valve (vehicles without EBS)**Figure 57**

33986

The device controlled by the two independent circuits of the duplex control valve and the spring brake circuit of the tractor controls trailer braking.


It incorporates a device making it possible to brake the trailer even in the event of control pipe failure.

Predominance control

It is equipped with a predominance adjustment device.

KNORR - BREMSE AC 597 B

Figure 58




The operations to carry out to adjust the predominance of the servo control valve type KNORR - BREMSE AC 597 B are performed in the following order:

- ☐ undo the screw (2) from the silencer body;
- ☐ insert an Allen wrench into the hole through the silencer body and turn the hexagonal hole of the body (1);
- ☐ turning it CLOCKWISE increases the predominance;
- ☐ turning it ANTICLOCKWISE decreases the predominance.

WABCO 9730090130

Figure 59



The operations to carry out to adjust the predominance of the servo control valve type WABCO 973 009013 are performed in the following order:


- ☐ Remove the screws (2) and take off the cover (3).
- ☐ Turn the screw (1) to adjust the predominance.
- ☐ Turning it CLOCKWISE decreases the predominance.
- ☐ Turning it ANTICLOCKWISE increases the predominance.

Fault Diagnosis

TROUBLE	POSSIBLE CAUSE	REMEDY
Air leaks from the outlet when at rest	Leaks from the gaskets.	Overhaul the device, replacing the worn parts.
	Exhaust valve and seat defective	Overhaul the device, replacing the worn parts.
Outlet pressures not as required	Air leaks from the gaskets.	Overhaul the device, replacing the worn parts.
	Pistons and seats worn or defective. Springs yielded.	Overhaul the device, replacing the worn parts. Overhaul the device, replacing the worn parts.

Trailer servo control valve (vehicles with EBS)

Figure 60




73920

This valve has the job of ensuring all braking levels (service, parking, emergency) and adjusting trailer predominance.

Pressure test point valve

Figure 61




71953

The pressure test points are in the pipes or tanks of the pneumatic system in order to make it easier to hook up pressure gauges for fault diagnosis.

794310 Parking brake hand control valve (vehicles suited to towing)

Figure 62




79514

This device provides emergency and parking braking for the tractor and trailer.

Additionally, it makes it possible to check the braking effect of the tractor. This is vital when the vehicle is parked on a steep slope.


Fault Diagnosis (parking brake control valve)

TROUBLE	POSSIBLE CAUSE	REMEDY
Air leaks from the outlet with the control lever: in the release position	Exhaust valve, seat or seal defective	Check and overhaul the device, replacing any defective parts
in the braking position	Control valve, seals and valve to control component worn	Thoroughly clean the various parts comprising it
Difficulty in turning the control lever	Interference in the control valve	Overhaul the device and moisten all the sliding parts

793336 Parking brake control manual distributor (standby vehicles)**Figure 63**

79515

The apparatus, inserted into tractor parking brake circuit, allows to actuate vehicle help and parking braking by releasing the air in spring cylinders.

Manual control valve to slow down the trailer (optional extra)**Figure 64**

73922


This component, in the parking circuit between the manual control valve and the trailer servo control valve, makes it possible to activate braking to slow down just the semitrailer according to the control given by the driver. It is an optional fitting and is anyhow bound by the current type-approval regulations in the various countries.

Fault Diagnosis (parking brake control valve)

TROUBLE	POSSIBLE CAUSE	REMEDY
Air leaks from the outlet with the control valve lever in the brake release position	Piston, outlet valve, seals worn or defective.	Clean thoroughly, check the rubber parts and the seats are sound.
Air leaks from the outlet with the control valve lever in the emergency or parking braking position	Piston and associated seal defective or deteriorated.	Clean thoroughly, check the parts and overhaul the device, replacing the defective parts.
Air leaks from the cover of the control valve lever	Plate, gasket, seals worn.	Clean the parts thoroughly, check the surfaces of the gasket and seals, check the integrity of the rubber parts and the relevant seats. Overhaul the device, replacing the defective or worn parts, and restore the mating faces if necessary.
Control valve lever hard to turn	Interference inside the control valve.	Clean thoroughly and check all the component parts. Overhaul the device, replacing defective parts. During assembly, grease all the sliding parts in moderation. If you find any defects or wear such as to jeopardize operation, replace the complete device.

Controlled pressure valve

Figure 65




Its job is to break off the flow of air to the ASR solenoid valve when the pressure of the rear axle system falls under 7.5 bars after a breakdown or too much air being drawn off.

Fault Diagnosis

TROUBLE	POSSIBLE CAUSE	REMEDY
Vent at outlet	Diaphragm leaks	Overhaul the device, replacing any worn parts
Air leaks from the join between the two half-bodies	Leakage from the diaphragm fitting	
Vent on delivery (into the atmosphere) with supply at a lower pressure than the setting	Leakage from inlet valve or its seat	Overhaul the device, replacing any worn parts

793319 Check valve (vehicles suited to towing)


Figure 66




This permits compressed air to pass in the direction shown by the arrow on the valve body, preventing its backflow.

Low-pressure switch

Figure 67




The purpose of this component is to warn the driver, with indicator lights on the CLUSTER, and the electronic control unit of low pressure in the system.

526724 Electro-pneumatic valve for ASR**Figure 68**

35384

This device brakes the driving wheels, via the brake anti-lock modulator, whenever a tendency for one or more driving wheels to skid is detected.


The valve is normally closed. When the electronic control unit detects a tendency to skid of one or more driving wheels, it sends a signal to the solenoid valve, which energizes and lets air pass to the brake anti-lock modulators that brake the wheels. The solenoid valve de-energizes when the wheels have reached the right degree of friction on the road surface.

526713 Speed sensor**566712 Phonic wheels****Figure 69**

35383

The speed sensors and phonic wheels have the job of detecting the speeds of the respective wheels.

The phonic wheel is housed on the wheel hub and turns at the same speed as the wheel. It generates alternating voltages in the sensors by induction. The frequency of these voltages is in proportion to the speed of rotation of the respective wheel. These voltage signals are transmitted to the control unit to be suitably processed. A sensor and a phonic wheel are fitted for each wheel. This arrangement makes it possible to control an individual braking pressure for each wheel during adjustment, optimizing travelling stability and braking distance.

526711 Electronic control unit**Figure 70**

73925


A = ABS – EBL electronic control unit

B = EBS electronic control unit

Its purpose is to control the brake system, producing deceleration in relation to the parameters detected by the various system components.

The electronic control unit is equipped with a highly advanced self-diagnosis system and it is able to identify and save any trouble, even of an intermittent nature, occurring to the system during operation, in relation to the environmental conditions, ensuring the most correct and reliable repairs.

Compared to the ABS control unit, the EBS control unit is able to govern auxiliary deceleration systems (exhaust brake and Retarder), optimizing the action so as to ensure better system operation and moreover reduce brake lining wear.

Pressure sensor**Figure 71**


52722

In ABS/EBL systems, its job is to inform the electronic control unit of the extent of action required by the driver.

In EBS systems, this component is integrated in the front axle, rear axle and trailer control valves.

794911 Diaphragm brake cylinder (for front and added front axle disc brake)

Figure 72




73926

This device transmits the force given by the compressed air, as the brake pedal is pressed, to the mechanical service braking device. If there is any trouble, it is necessary to replace the entire cylinder.

Diaphragm brake cylinder (for front and added front axle drum brake)

Figure 73



35798


This device transmits the force given by the compressed air, as the brake pedal is pressed, to the mechanical service braking device. If there is any trouble, it is necessary to replace the entire cylinder.



Should the component have to be replaced, follow the PIC instructions of the relevant vehicle to identify the actual sizing.

794922 Combined brake cylinder (for front and rear disc brake)

Figure 74




73927

This device is composed of two parts: a diaphragm brake for service braking and a spring brake for parking and emergency braking if the braking system fails.

Combined brake cylinder (for front and rear drum brake)

Figure 75



36744


This device is composed of two parts: a diaphragm brake for service braking and a spring brake for parking and emergency braking if the braking system fails.



Should the component have to be replaced, follow the PIC instructions of the relevant vehicle to identify the actual sizing.

Combined cylinder emergency brake release device

Figure 76




36745

If it were not possible to supply the spring section of the combined cylinder (2) pneumatically, it is possible to release the vehicle brake manually to permit towing. To release the vehicle brake you need to unscrew the screw (1) fully.

Repairs

Figure 77



36476

Before detaching the combined cylinder from the vehicle, carry out the manual brake release procedure for the combined cylinder as described above.




Before removal, it is recommended to thoroughly clean the outer parts of dirt and other debris that on getting inside could damage the cylinder.

If there is any trouble with the spring section of the cylinder, do not dismantle it as this can be dangerous.

Fault Diagnosis

TROUBLE	POSSIBLE CAUSE	REMEDY
Air leaks from the outlet or retaining clamp	Diaphragm punctured or broken.	Replace the diaphragm
	Diaphragm lip broken.	
	Retaining clamp locking screws loose.	Tighten the screw
Air leaks from the diaphragm section supply	Deterioration of the parts forming the spring section	Overhaul the device, replacing any worn parts.

5274 DISC BRAKES KNORR TYPE (CALIPER SN7)**Figure 78**

78397

78396

SEC. AA

1. Dry bush - 2. Threaded hose - 3. Piston - 4. Washer - 5. Spring split pin - 6. Pin - 7. Retaining plate - 8. Supporting plate - 9. Guide pin - 10. Guide bush - 11. Sliding pin - 12. Plug - 13. Dragging device - 14. Wear sensor - 15. Rear axle - 16. Chain - 17. Spring - 18. Cover - 19. Adapter - 20. Chain gear - 21. Adjusting device - 22. Cover - 23. Brass bush - 24. Sliding pin - 25. Sliding bush - 26. Inner protection - 27. Ring - 28. Brake lining - 29. Brake disc body - 30. Lever - 31. Cam bearing.

Operation (See previous figure)

Braking stage

During braking, the diaphragm cylinder rod presses down on the lever (30).

The force is transferred to the axle (15) by the bearing in an off - centered position (31)

Through the threaded sleeves (2) and pistons (3), the force is conveyed to the inner braking lining (28).

Once the play between brake linings (28) and brake disc (29) has been recovered, the force is conveyed to the outer brake lining (28), due to brake caliper displacement.

The brake linings (28) pressing on the brake disc (29) produce the braking power.

Releasing stage

As soon as the pressure on the brake is reduced, the pressure spring (17), the rear axle (15) along with threaded sleeves (2) and lever (32) go back to their original positions.

Automatic play recovery

The brake is equipped with automatic adjustment device, which keeps the operating play between brake linings and brake disc constant.


Every time the brake is operated, the adjustment device (21), which is integral with the lever (32), is automatically started. If worn brake linings and brake discs increase the operating play, the adjustment device (21) and drag link (13) turn the threaded sleeves (2) so to recover said increase in play.

The operating clearance should be between 0.6 and 1.1 mm; lower clearances might cause overheating problems.

CHECKS

Checking the automatic play recovery system efficiency


Figure 79



40570

Remove the lock nuts and wheels, using hydraulic stand 99321024 (1).

Figure 80



78622


Remove the plug (4) using the tab (3) and make sure the adapter (2) is not lost.



Never turn the adjusting pinion (1) without fitting the adapter (2) first. If the adapter cut torque is overcome, the adapter gets broken.

Try again with a new adapter and if also in this case it gets broken, the caliper should be replaced because there is an inner damage.

Figure 81




60759

Using a suitable wrench (1), rotate the adjustment pinion counterclockwise by 2-3 with the adapter (2, Figure 80) installed turns, thus increasing the play between brake linings and brake disc.


Operate the brakes for about 5-10 times and make sure the wrench (1) moves clockwise with small increments, up to complete recover of play between braking linings and brake disc.

Otherwise, i.e. if the wrench does not turn, turns just once or turns in both directions, this means the automatic play recovery system is faulty. Replace the caliper, following the procedure given subsequently, then fit back the wheels.

Brake caliper components**Figure 82**

78628


1. Combined brake cylinder - 2. Membrane brake cylinder - 3. Rubber bushes - 4. Sliding pins - 5. Plug - 6. Adjusting unit cover - 7. Adapter - 8. Guide pin - 9. Cover - 10. Sliding pin - 11. Brass bushes - 12. Carrying plate - 13. Protection cowl - 14. Ring - 15. Inner seals - 16. Bushes - 17. Plungers - 18. Brake caliper - 19. Guide pin - 20. Braking seal - 21. Spring - 22. Split pin - 23. Washer - 24. Pintle - 25. Check plate.

Check of braking seals thickness**Figure 83**

78625


1. Brake caliper - 2. Sliding bush - 3. Rubber bush - A. Bush position with new seals - A₁. Bush position with worn out braking seals (perform an accurate check with wheels dismounted).

The condition of braking seals can be visually determined without dismounting wheels, by checking that $A > 1 \text{ mm}$. Otherwise, it is needed to dismount the wheels and perform an accurate check as described below.

5274 OVERHAULING FRONT DISC BRAKES**527417 Replacing brake linings****Figure 84**


40569

Set the vehicle on flat ground and lock the rear wheels. Loosen the nuts (1) fixing the front wheels. Lift the vehicle at the front with a hydraulic lift and set it on two stands (2).

Figure 85


40570

Unscrew the fixing nuts and with the aid of the hydraulic trolley 99321024 (1) remove the wheels.

For vehicles without EBS**Figure 86**

49157

Remove the screw (1) and the wear sensor cable retaining plate (2).

Figure 87


49158

Disconnect the electrical connection (1) from the calliper body.

Remove the split pin (2), pin (3) and brake lining retaining plate (4).



No lifting devices are to be fixed to plate (4).

For vehicles with EBS**Figure 88**

60860


Remove the split pin (1), pin (2) and brake lining retaining plate (3).



If plate (3) is damaged or worn out, it must be replaced.

No lifting devices are to be fixed on plate (3).

Figure 89




Remove the plug (3). Turn the adjustment device (1) operating on the adapter counterclockwise with a wrench, to insert the pistons within the caliper body and extract brake linings (4), suitably moving the caliper body (3).



Never operate directly on the registration pinion (1) without having first of all fitted the adapter (2). If the cutting torque of the adapter is exceeded, this will break.
Test with a new adapter. If this also breaks, the caliper must be replaced because it is damaged.

For vehicles without EBS


Figure 90



Press (→) on the spring (1) and remove it. Remove the wear sensors (2) from the brake linings (3).

For vehicles with EBS


Figure 91



Press (→) on the spring (1) and remove it. If necessary, replace it with a new one.

For all vehicles

Figure 92



Remove dirt and rust from around the edge of the brake disc with a scraper or an old screwdriver (2) resting on the calliper body, turning the disc (1).

Finish the job with abrasive cloth. Remove the remains with the aid of an aspirator, or rags and a brush.

Do not use petrol or other petroleum products that could cause trouble for the brakes.

Use only methylated spirit or isopropyl alcohol.

Carefully clean the surfaces of the braking area of the brake disc.



Visually check the conditions of the dust caps, if deformed or broken it is necessary to replace them.



This requires removing the brake calliper, so it is recommended to remove the brake calliper body together with the bearing plate for a thorough overhaul.

Check that the calliper slides freely on its guides.

If you find any trouble on a single brake calliper it is wise to overhaul both brake callipers completely.


Remove the dirt from the brake calliper with a wire brush, without damaging the dust caps.

Clean the sliding surfaces of the brake linings.


Check the conditions of the brake disc and make sure it is not corroded, scored or grooved. Light surface cracks are acceptable, but it is necessary to grind the brake disc as described under the relevant section heading. On the contrary, if it is worn, replace the brake disc.

If one needs to be replaced, it is recommended to replace both brake discs.


Check the state of the springs and wear sensors, replace them if necessary.

For vehicles without EBS**Figure 93**

Insert the wear sensor (2) into its seat on the brake lining (3). Mount the spring (1) in the opposite sequence to that for disassembly.

For vehicles with EBS**Figure 94**


Mount the spring (1) in the opposite sequence to that for disassembly.

For all vehicles**Figure 95**

Insert the new linings in the brake calliper (1) and check they slide freely in their seats.




If you find it necessary to replace the pair of brake linings, always replace them with a full set for each axle.

Figure 96


Using the wrench (1), act on the adaptator retriever pin to get a play not lower than 0.7 mm between brake lining and brake disk, which can be measured using the thickness gauge (2). Replace the cover (4) and lubricate it with white grease RENOLIT HLT2.




Make sure that the outer protecting plug and the seal ring are correctly fitted, in order to prevent water leaks inside the play automatic retriever.

For vehicles without EBS**Figure 97**


Make the electrical connection (1) and secure it to the calliper body. Mount the plate (4), pin (3) and split pin (2).

For vehicles with EBS**Figure 98**

Mount the plate (3), pin (2) and split pin (1).

For vehicles without EBS**Figure 99**


Mount the wear sensor cable retaining plate (1).
Using the hydraulic trolley 99321024, fit on the wheels. Lower the vehicle. Lock the nuts fixing the wheels to the required torque.
Fit the safety cap onto the wheel hubs.
Proceed as described on the opposite side.
After repairing the vehicle brakes, press the brake pedal repeatedly, while the vehicle is moving, in both directions, in order to wear in the brake linings.

527413 Removing and refitting brake callipers
Removal
For vehicles without EBS
Figure 100

To remove the brake linings, keep to the above description in the paragraph for replacing brake linings. Remove the clamps (2). Disconnect the diaphragm cylinder supply pipe (1). Unscrew the nuts (4) and remove the diaphragm cylinder (3).




Nuts (4) are to be discarded.

For vehicles with EBS**Figure 101**

To remove the brake linings, keep to the above description in the paragraph for replacing brake linings. Remove the clamps (2). Disconnect the diaphragm cylinder supply pipe (1). Unscrew the nuts (4) and remove the diaphragm cylinder (3). Disconnect the electrical connection (5) of the calliper body.



Nuts (4) are to be discarded.

For all vehicles**Figure 102**

49167

Remove the screws (3) and disconnect the brake caliper (1) together with the bearing plate (2).




Be very careful in removing and carrying the caliper (1) as it is heavy and floating on the support plate (2). Keep the caliper only on the outer side. Never put your fingers between the caliper (9) and the supporting plate.

Refitting

For refitting, carry out the steps described for removal in reverse order, keeping to the required tightening torques.


520620 Removing and refitting wheel hubs

Removal

Figure 103


77206

Rotate wheel hub in order to take screw plug (1) downwards; unscrew the plug and drain oil into a suitable tank.

Figure 104


36407

Block rotation of the wheel hub appropriately and, using the wrench 99354207 (1), unscrew the oil cover (2). Drain off all the oil.

Figure 105

36408

Undo the safety screw (3). With the wrench 99388001, unscrew the adjustment ring nut (2), remove the washer (4), outer bearing (1) and remove the brake disc together with the wheel hub, spacer and internal bearing.

Figure 106

38596

Visually check the diameter of the gasket ring (1) has no accidental dents or scratches.

Replace the internal gaskets of the wheel hubs and, if necessary, the ring (1), keeping to the description given in the "Front axle" section.

Using the adjustment ring nut, check that the thread (2) has no stiffness. If it has, use appropriate means to get rid of the stiffness.

Remove the opposite brake assembly, keeping the components separate.

Refitting



Make sure the surfaces of all the parts inside the hub are thoroughly clean, with no waste or burrs.



Lubricate the bearings with Tutela W 140/M-DA oil (Tutela TRUCK Fe-Axle for vehicles with rear disk brakes).




Key the wheel hub on the stub axle together with the brake disc. Insert the internal spacer onto the stub axle then position the external bearing and thrust washer.



Screw down and lock the adjustment ring nut to the required torque.

Figure 107




36411

Strike the wheel hub a few times with a mallet in an axial direction, turn it in both directions to free the bearing rollers. Fit the magnetic base (1) together with the dial gauge (2) on the wheel hub. Set the pointer of the dial gauge (3) at right angles to the shank of the stub axle.

Reset the dial gauge with a pre-load of 1.5 ± 2 mm. With the aid of a lever, move the wheel hub axially and measure the end float, which must be 0.16 mm (maximum value).

On obtaining the required end float, lock the screw (5) retaining the adjustment ring nut (4) to the required torque.

Figure 108



36412

Apply tool (1) 99395026 on wheel hub stud bolts and use torque meter 99389819 (2) to check whether the wheel hub rolling torque is at the set value.




Deposit a sealing bead (Loctite type 574) exclusively on the hub cover ledge surface and protect the threaded part.



Tighten to torque the hub cover (1, Figure 109).

Figure 109




79068

Rotate the wheel hub until when hub cover (1) is positioned as shown in the figure. Restore the prescribed quantity of oil into the hub cover (1) through filling hole (2). Tighten the plug on the hub cover (1) to the set torque.

BRAKE CALIPER OVERHAUL


Disassembly

Figure I 10




Place the brake caliper on the bench and block it in a vice. Remove the cover (1) and make a hole in it with a Parker screw.

Figure I 11




Refit the supporting plate (1) and remove the fastening screws (2).

Figure I 12




Remove the sliding bushes (1).

Figure I 13



Use tool 99372245 (2) (to be used with screw in tool 99372237) to disassemble the rubber sleeve (1).


Figure I 14



Take the caliper to the press.

Insert the appropriate beater in the brass bush housing (1) (See arrow A). Use the press to remove the bush (1).

Figure 115



60742

Place the caliper on the bench and block it in a vice. Use the wrench (4) to operate the clearance recovery device so that the piston (1) comes out of the caliper body for a maximum of 30 mm (value A).

Take off the dust-guard from the caliper body and use tool 99372238 (5) to remove the thrust pressing devices (1) of the caliper together with the protection casings (3).



Value A must not be overcome because threaded hoses (2) are synchronised. If the threaded hoses (2) reach their over-travel, they lose synchronism and the brake caliper must be replaced. The brake caliper inner parts must never be removed.

For this reason you are recommended not to slacken or to remove the cover retaining screws..

Component part cleaning and check

To wash metal parts, use a solution of hot water with Fiat LCD detergent. Use a metal brush to remove dirt from the caliper body and then a little brush to remove the residuals and to clear accurately the guide pin and the sliding bush housings.

Use a synthetic brush with the right dimensions to remove the grease left on the sliding bush housings.

Clean the caliper body accurately with compressed air.

Use a piece of cloth soaked with isopropyl alcohol or similar to clean the sliding bushes accurately.

Check the wear conditions of the sliding bushes and their housings on the brake caliper body. Make sure they are not damaged or worn, especially the sliding surfaces. Fit the bushes in their housings and check they slide regularly.

Fit the bushes in their housings, check they slide correctly, otherwise replace or restore their housings on the caliper body, if needed.



Regular braking depends mainly on the brake caliper sliding on the guide pins.


Check the wear conditions of the brake lining retaining pins and the related safety pins. If they are worn or damaged, replace the worn parts.

It is advisable to replace all rubber and plastic parts and the brass bush even if they do not seem damaged or worn at sight.

Assembly

Make sure all the brake caliper components are perfectly clean. Possible abrasive residuals should be removed with a cloth soaked in isopropyl alcohol or similar.


Figure 116



79126

Use tool 99372239 (4) (see figure A) to fit the protection casings (2). Use the same tool 99372239 (4) fitted on the other side (see figure B) to insert the pistons (1). Use the wrench (3) to operate the clearance recovery device and adjust the pistons (1).


Figure 117



79127

Use tool 99372244 (2) (to be used with the screw in tool 99372237) to assemble the rubber sleeve (1).


Figure 118



79128

Use tool 99372243 (1) (to be used with tool 99372240 and use screw in tool 99372237) to assemble the brass bush (2) in its seat, by blocking its rotation by means of a suitable tool (3) (punch or screwdriver).


Figure 119



79129

Place the caliper under the press. Use the press to fit the brass bush (1) in its housing until it comes out of the lower side by 1 mm.

Figure 120




60745

Use the appropriate tool 99372242 (2) to carry out bruising in the point (→) next to the caliper body groove, in order to prevent the brass bush (1) from moving.

Make sure there are no burrs in the bush housing, otherwise remove them. Apply white grease RENOLIT HLT2 on the bush.

Figure 121



79130

Place the caliper on the bench and block it in the vice. Fit the protection casing (2) by means of tool (1) 99372237.




Reverse the removal order to fit the sliding bushes and the supporting plate.

5274 OVERHAULING REAR DISC BRAKES

527417 Replacing brake linings

Figure 122



39950


Park the vehicle on level ground. Put the parking brake lever into the off position and loosen the nuts fixing the rear wheels. Using a hydraulic jack, lift the vehicle at the rear and rest it on the special stands. Using the hydraulic trolley 99321024 (1), take off the wheels.



Overhaul braking unit, observing – in dismantling and overhauling the brake caliper – the procedure described for front disk brakes, since it is similar.

Examine the state of wear of the brake disc surfaces. If you find different values to the ones given in the characteristics and data table, remove it as follows.


Figure 123



39951

Fully unscrew the screw (2) to manually release the combined cylinder (1) and detach it from the brake caliper.


Figure 124



72744

Place a container under the wheel hub to collect the oil. Block wheel hub (1) rotation with the retaining tool 99370317 (3). Take out the screws (2) and extract the drive shaft (4).


Figure 125



72745

Lift the notch on the ring nut (5). With wrench 99355175 (1) and multiplier 99389816 (2), take off the ring nut (5) holding the wheel hub bearing. Remove the retaining ring (4).


Figure 126



72746


Remove the wheel hub (1). Should this prove difficult, use the extractor comprising the brackets 99341017 (2), bridge 99341003 (3) and block 99345049 (4) fitted as shown in the figure.

Check the state of the wheel hub bearing, rear axle housing sleeve and calliper mounting plate. Replace any worn or damaged parts as described under "Overhauling the wheel hubs" of rear axle MS 13-I 75 with disc brakes.

Figure 127

72748

Take out the screws (2) and remove the wheel hub (1) from the brake disc (3). Turn and grind the brake disc as described in the section or replace it if necessary.


Figure 128

72749

The phonic wheel (1) is removed from the wheel hub (2) with general tools.


To assemble the phonic wheel, heat it to approx. 150°C and fit it on the wheel hub (2).

On completing assembly, make sure the phonic wheel (1) rests correctly on the hub seat.

Figure 129


72755

Screw the tool 99370700 (2) onto the sleeve (1) of the rear axle housing. Lubricate the outside of the tool (1) with Tutela Truck Fe-Axle.

Figure 130

72757


Fit the wheel hub (3) on the sleeve of the rear axle housing and with the dial gauge (1) with a magnetic base check that the error of concentricity of the phonic wheel (2) is no greater than 0.2 mm. Remove the wheel hub (3).

Figure 131

72748

Fit the brake disc (3) onto the wheel hub (1) and screw down the screws (2).


Figure I32



72758

Sling the brake disc (1) with a rope and hook this onto a lift. Fit the wheel hub (2) onto the sleeve of the rear axle housing. Remove the tool 99370700 (3).


Figure I33



72759

Position the retaining ring (4) so as to insert the tab into the groove in the sleeve. Lastly, screw down the ring nut (5). Using wrench 99355175 (1), the multiplier 99389/816 (2) and the torque wrench (3), tighten the ring nut (5) to the required torque.


Figure I34



74371

After tightening with a specific tool, make the cut and bend to prevent the ring nut unscrewing, as shown in the figure. The arrow shows the direction of unscrewing the ring nut.


Figure I35



72760

Block rotation of the wheel hub (2) with tool 99370317 (4) and tighten the screws (3) fixing the brake disc (1) to the wheel hub to the required torque.


Figure I36



72761

Spread IVECO I905685 sealant (LOCTITE I4780) onto the contact surfaces, drive shaft flange and wheel hub and insert the drive shaft into the rear axle housing. Screw down the screws (2) fixing the drive shaft (3) to the wheel hub and tighten with the torque wrench (4) to the required torque. Remove the tool 99370317 (5).

Figure I37




39954

After overhauling and refitting the braking assembly, fit the cylinder (1) following the procedure described for the front brake cylinder.

Supply the cylinder (1) by pressing the service brake and tighten the fixing ring nut to the required torque with the wrench 99356006. Restore operation of the cylinders (1) governing the parking brake by fully screwing down the screw (2).

Figure 138



40564


Using the hydraulic trolley 99321024 fit on the wheels. Lower the vehicle. Lock the nuts fixing the rims to the required tightening torque according to the diagram shown in the figure. Proceed as described on the opposite side.

On completing this process, start the engine to recharge the pneumatic system.

Drive the vehicle in both directions, press the brake pedal repeatedly, to let the brake linings settle in.

527411 OVERHAULING BRAKE DISCS

Figure 139




38597

Examine the state of wear of the surfaces of the brake discs. Finding other values to the ones given in the characteristics and data, turn and grind the brake discs or, if necessary, replace them. Remove the screws (1) and detach the hub (2) from the disc (3). Replace the disc (3) and refit it following the reverse procedure to the one described above.

527411 TURNING AND GRINDING BRAKE DISCS


Figure 140



35707

- ☐ Key onto the shaft of the lathe 99301001 (2) the brake disc (1) together with the hub.
- ☐ Key onto the shaft a set of spacers that eliminate the end float of the assembly; screw on the locking nut and fit the mount of the lathe shaft.
- ☐ Position the tool holder (3) in line with the brake disc (1), then adjust the depth of the tools.
- ☐ Proceed with turning and grinding the brake disc (1), operating with one or more passes to remove material depending on the scoring found.

Figure 141




35704

Using the specific grinding tool 99301001 (1) fitted to the lathe 99301001, grind both working surfaces of the brake disc.




When grinding, move the sector wheel forwards gradually, to remove all remains of turning.

DRUM BRAKES**Figure 142**

60867

VIEW OF PERROT DRUM BRAKES

Figure 143

52875


VIEW OF SIMPLEX TYPE DRUM BRAKES (ROCKWELL)

5272 OVERHAULING THE DRUM BRAKES

For Perrot and Rockwell type drum brakes


527230 Removing the rear drum brakes

Figure I44



Set the vehicle on level ground. Take the covers off the nuts fixing the wheel and loosen the nuts.
Lift the vehicle at the rear and put it on stands.
Position the hydraulic trolley 99321024 under the wheels.
Take out the nuts fixing the wheels and take them off.
Fully unscrew the manual brake release screw (2) of the combined cylinder (1).


Figure I45



Take out the screws fixing the brake drum (1) to the wheel hub (2). Screw two appropriate screws (⇒) into the holes in the drum and take this out of the wheel hub.


For Perrot type drum brakes

Figure I46




Disconnect the electrical connection (1) for the cable signalling brake lining wear.

Figure I47




Take out the shoe return springs (2).
Remove the top shoe (1).

Figure I48



Free the brake wear indicator cable (1) from the clips of the brake plate (3) and take the cable out of the guard (2).
Remove the bottom shoe (5).
Take out the semicircular plugs (4).


Figure 149



Disconnect the pipes (1 and 2) from the fittings (3 and 4) and remove these from the combined cylinder (5). Using wrench 99356006 (7), loosen the ring nut (6). Turning the combined cylinder (5) anticlockwise, remove it from the brake body.


For Rockwell type brakes

Figure 150



Unlock shoe (1) return springs (2) using pliers 9935711. Remove shoe (1) and disconnect the electrical connection by unscrewing brake lining wear indicator cable fastening nut set on it.


Figure 151



Disconnect the brake cylinder (2) feeding pipes (1). Using wrench 99356006 (3) loosen the ring nuts and remove the brake cylinder (2).


For Perrot type brakes

Figure 152




Extract the wedge-shaped control unit (1) from the brake body (2).

Figure 153



Remove the protective caps (4) from the brake body (6) and extract the adjustment units comprising parts (1, 2, 3, 4 and 5).


Figure 154



Unscrew guide screws (6 and 7) and take parts (1, 2, 3, and 4) off brake body (5).

For Rockwell type brakes


Figure I55



40869

Take away the wedge units (1) controlling the brake housing (2).


Figure I56



40870

Take away the adjusting units (1 and 3) from the brake housing (2).


Figure I57



60217

Remove the guide screws (2) and remove the thrust pins (1) with the adjustment bushes and relevant springs.
Remove thrust pins (3).
Remove the wheel and the whole braking unit on the opposite side. Keep components separate.

Figure I58



40872

Check the wear on the pin seats of the brake housing (1), if they are scored or very worn replace the faulty brake housings.

For Rockwell and Perrot type brakes

Check the wear on the drums to decide whether they can be re-used.

Measure the drum diameters with a gauge without bending the arms.

Measure the diameter in several points to establish the ovality and wear, also taking into consideration the depth of scores on the braking surface.

Allowed tolerance for ovality and/or eccentricity is 0.25 mm

If the braking surface scoring or wear cannot be repaired by turning, or if there are evident signs of overheating, replace the drum (see Specifications and data table).

Check the conditions of the brake shoes, if they are cracked replace them.

If the brake lining surfaces show signs of grease, find the cause and remove it.

The minimum thickness admitted for the brake linings is 4.7 mm, measured at the last rivet of the shoe with the wear sensor on the side opposite the cylinder.


If a value that is under, or only just over the specified thickness, replace.

Check the integrity and/or efficiency of the brake lining wear indicator cable.

Check the integrity and/or efficiency of the shoe return springs.

For Perrot type brakes

Figure 159



35711


Take apart the automatic adjustment units.

Carefully clean all the single parts forming the braking assemblies. Check the state of wear of the adjustment bushing teeth (2 and 3), seeing they (2) slide properly when screwing onto the adjustment pins (1).

Check the state of the springs (4) and thrust pins (5).

Check the seats of the thrust pins (5) on the brake body; replace the brake body if you find any scoring, dents or too much wear.

Figure 161




71786

Take seal (1) off thrust pin (2). Check wear conditions for thrust pin (2) and surfaces of sloping planes (3) subjected to the operation of shoe opening drive rollers.

For Rockwell type brakes

Figure 160




38357

Disassemble the automatic adjustment unit.

Unscrew the adjustment bushes (3) from the adjustment pins (2) and then remove the seals (1).

Check the wear condition of the adjustment bush outer helical toothing and check whether bushes are sliding freely on the relevant adjustment pins when screwing.

Figure 162




38360

Check the condition of the pressure pin teeth (3), of the relevant compression springs (2) and of the copper washers (1).

For Rockwell type brakes

Figure I 63



35713

Check that the wedge assemblies run smoothly and the parts are not scratched.




If the parts forming the wedge units are worn, you need to replace the entire wedge unit.

527231 Turning drums

Measure the diameter of the drums with a sliding gauge without angling the arms. Measure the diameter at several points to determine the roundness and state of wear.

Figure I 64



40520

Fit the tool 99372213 (2) in the brake drum (1). Key this assembly onto the shaft of the lathe 99301001 (3). Fit a set of spacers onto the shaft eliminating the end float of the assembly. Screw down the locking nut and fit on the lathe mount. Fit the anti-vibration band onto the brake drum. Turn the drums, removing the necessary amount of material in several stages to eliminate the flaws found.

After turning, remove the brake drum from the lathe and clean it carefully.




The highest permitted diameter for the drums is given on the drum itself.

This limit must never be exceeded as this would impair the braking effect and the strength of the drums.



Couple the appropriate brake linings for each single drum according to the oversize.

Each of the vehicle's axles must be equipped with linings of the same type.


527233 Replacing brake linings**Figure I65**

Remove the worn brake linings from the shoes with the compressed air press 99305087 (1).



From the bottom shoes or the tongues of the clip (6) freeing the bushing (7). Now remove the lining wear gauge (8) with the associated cable.

Put the entire shoes (4) on the adjustable plate (5). With the chisel (2) in the operating head of the press (1), cut off the heads of the rivets (3). Eject the rivets from the shoes. Thoroughly clean the shoes by washing and blowing.

Figure I66

Fit the supporting pin (5) on the mobile mount (4) of the press. Rivet the brake linings (3) onto the shoes (2) using the drift (1) inserted in the operating head of the press.




The right way to rivet the brake linings is to start from the middle and gradually move towards the outside of the braking sectors.

Fit on the lining wear cable by carrying out the procedures described for removal in reverse order.


Assembly

For Perrot type drum brakes

Figure I67

Grease the parts (1, 2 and 3) and insert them, in sequence, onto the thrust pin (4).


Grease the inside of the brake body (5) and fit the thrust pins (4) fastening them with the guide pins (6 and 7).

Figure I68

Reassemble the adjustment units, greasing the sliding surfaces properly.

For Rockwell type drum brakes

Figure 169



38364

Fit the seals (2) on the units of the adjustment pins (1). Grease the thread of the pins (1).

Fully screw down the adjustment bushings (3) and grease them thoroughly on the outside diameter.


Grease the inside diameter of the thrust pins (4).



When repairing the brakes, replace the seals of the reaction and thrust pins.

To lubricate the components, use Rockwell RBSK 0253 grease.


Figure 170



36755

Fit thrust pins (1) inclined by 15° towards the main shoe and thoroughly grease inside support diameters.

Figure 171



60220

Screw component (1) and fit it in the thrust pin (6). Grease the interior of the brake body (5) and fit thrust pins (6) so that the slot is facing the guide pins (4).


Grease and fit complete guide pins (4) in brake body seats (5); check whether washers (2) are fitted and screw some turns.



Guide pins (4) shall be fitted so that prongs (3) can slide in the proper brake body hole seats (5).

For Rockwell and Perrot type brakes

Figure 172




36755

Inset the adjustment units (1) into the brake body (3), facing the clip as shown in the figure.

Fit the protective cap (2) into the groove of the brake body (3).

For Perrot type brakes

Figure 173




40523

Fully screw down the adjustment units (2) and unscrew by one turn. This implements automatic brake lining wear recovery. Align the milling of the plug (1) for the linings with the slot of the clip (3).

For Rockwell type brakes


Figure 174



60222

Fit thrust pins (1) into brake body (2).

Figure 175




71787

Using the key 99373002 (1), drive the metal rings of the seals onto the brake assembly (2).

For Perrot and Rockwell type brakes

Figure 176




40524

Using device 99301006 (2), turn the brake linings (1).

For Perrot type brakes


Figure 177



40525

Position the semicircular plugs (5) on the shoe supporting pin (4) and mount the bottom shoe (6). Insert the lining wear indicator cable into the clips (⇒) and into the hole in the brake (1); insert the return springs (3 and 7) onto the shoe (6).

Figure 178




40514

Mount the top shoe (1) and hook the spring (2) onto it and then the spring (7, Figure 177).

For Rockwell type brakes


Figure 179



Electrically connect brake lining wear indicator cable (2), aiding the fastening nut on the shoe. Fit shoes (1) into the proper seat, "Anchor" writing marked on the shoe shall be set near the thrust pins and be faced towards the operator. Hook shoe return springs by tool 99372211 (3).


For Rockwell and Perrot type brakes

Figure 180




If you have device 99305079 (2) instead of 99301006 (2, Figure 176), turn the brake linings (1).

Figure 181




Unscrew the adjustment units (1 and 2) to the same extent to obtain the diameter A, 2 mm less than the diameter of the brake drum to mount.

Figure 182




Fit the brake drum (1) and secure it to the wheel hub (2) with the screws (3).

Figure 183



Grease the wedge-shaped control unit (1). Insert it in its seat, taking care that the rollers (⇒) are positioned in the sliding race.

Figure 184




36757

Screw the ring nut (1) by hand onto the sleeve (2) as far as it will go.

Apply non-hardening sealant type LOCTITE 573 on the first few threads of the sleeve.

Figure 185



40531

Screw the combined cylinder (5) fully down into its seat. Check that the holes for the supply fittings are in the same position found on removal; if they are not, unscrew the combined cylinder appropriately.


Mount the fittings (3 and 4) and connect the supply pipes (1 and 2).

Supply the diaphragm sections of the combined cylinder by applying the service brake.

With the wrench 99356006, tighten the ring nut (7) to the required torque. Connect the brake lining wear indicator cable electrical connection (6).

Restore the operation of the combined cylinder (5) screwing down the screw (8) fully.

Figure 186



40564

Mount the wheels and tighten the fixing nuts to the required torque according to the diagram shown in the figure.

On completing this process, start the engine to recharge the pneumatic system.

Drive the vehicle in both directions, press the brake pedal repeatedly, to let the brake linings settle in and recover the clearance between the brake linings and the drum.

SECTION 13

5501 Bodywork
5001 Chassis frame

	Page
CAB	3
☐ General information	3
CAB TILTING	3
☐ Cab mechanic suspension	4
☐ Cab driving position adjustment	4
☐ Adjusting the levelling valve linkage	5
☐ Cab pneumatic suspension	5
CAB AIR-CONDITIONING	6
☐ General	6
VENTILATION	6
☐ Description	6
AIR-CONDITIONING AND HEATING	7
☐ Description	7
☐ Air-conditioning	7
☐ Air-conditioning controls assembly	7
☐ Manual	7
☐ Heating and ventilation	7
☐ Heating	7
COMPONENT LAYOUT (WEBASTO AIR CONDITIONER)	8
HEATER ASSEMBLY COMPONENT LAYOUT (WEBASTO)	9
☐ Outside temperature sensor	10
☐ Compressor	10
☐ Condenser and safety pressure switches	11
☐ Geared motors	12
☐ Evaporator temperature sensor	13
☐ Expansion valve	13

	Page
PROCEDURE FOR EMPTYING AND REFILLING THE AIR-CONDITIONING SYSTEMS WITH R134A REFRIGERANT	14
☐ R134A refrigerant recovery and refilling station (99305146)	14
SAFETY STANDARDS	15
CONTROL FASCIA	16
OPERATION FLOW CHART	18
RECOVERING REFRIGERANT FROM THE VEHICLE SYSTEM	19
CREATING A VACUUM IN THE SYSTEM	21
RESTORING OIL IN THE SYSTEM	23
FILLING THE SYSTEM WITH REFRIGERANT ...	24
CHECKING THE PRESSURES IN THE SYSTEM ..	26
OPERATIONS PRIOR TO DISCONNECTING THE STATION FROM THE SYSTEM	26
LEAK FINDER FOR AIR-CONDITIONING SYSTEMS WITH HFC R134A (9905147)	26
REPAIR OPERATIONS	27
HEATER	27
☐ Removal	27
☐ Refitting	27
ADDITIONAL AIR HEATER SYSTEM	28
☐ Removal	28
☐ Refitting	28
DEFROST CONTROL MOTOR	28
☐ Removal	28
☐ Refitting	29
AIR RECIRCULATION DOOR CONTROL MOTOR	30
☐ Removal	30
☐ Refitting	30
ELECTRIC FAN	30
☐ Removal	30
☐ Refitting	30

	Page
HEATER RADIATOR	30
☐ Removal	30
☐ Refitting	31
POLLEN FILTER	32
☐ Removal	32
☐ Refitting	32
AIR-CONDITIONER COMPRESSOR	32
☐ Removal	32
☐ Refitting	32
AIR-CONDITIONER CONDENSER	33
☐ Removal	33
☐ Refitting	33
OUTSIDE AIR TEMPERATURE SENSOR	33
☐ Removal	33
☐ Refitting	33

5501 CAB General information

The cab is of an advanced type, hydraulically tilting by manual control.

Tilting angle 60°.

Construction in pressed and welded steel.

Protection: Box opening anticorrosive protection.

Door and outer panel inner side framework coated with galvanised metal sheet.

TYPE OF CAB

VEHICLES	CAB LENGTH	LOW ROOF	INTERMEDIATE HEIGHT ROOF
STRALIS AT	LONG	●	●
STRALIS AD	SHORT	●	


Cab suspension type:

☐ mechanic

☐ pneumatic on request only on AT vehicles with middle to high roof.

CAB TILTING

Figure 1




85697

CAB TILTING SYSTEM COMPONENT PARTS

1. Hand driven pump - 2. Cab lifting cylinder - 3. Hydraulic actuator to release gearbox control telescopic tie rod (only for mechanic gearbox) - 4. Cab hitching up lock

Cab mechanic suspension

Figure 2



85698

1. Cross member - 2. Rubber block - 3. Rear shock absorber regulator - 4. Rear shock absorber - 5. Bracket - 6. Support - 7. Front shock absorber - 8. Front shock absorber regulator - 9. Torsion bar - 10. Brackets - 11. Torsion bar

Cab driving position adjustment

With cab under static load condition, check length X_2 of front shock absorbers (7) and length X_1 of rear shock absorbers (4).



By static load it is only meant the load that is determined by the type of cab fitting.


Such length as measured between the center distances of shock absorber eyelets, must result to be :

$$\begin{aligned} X_1 &= 400 \text{ mm} \\ X_2 &= 380 \text{ mm} \end{aligned}$$

If different values are found, rotate the regulator (3 and/or 8) of relevant shock absorbers with a suitable wrench.



The regulator is provided with 5 marks, each mark, starting from the central reference mark, corresponding to a length shift of 4 mm.

Cab pneumatic suspension**554275 Adjusting the levelling valve linkage****Figure 3**


85700

LOCATION OF CAB SUSPENSION COMPONENTS

1. Service supply – 2. Rear shock absorber – 3. Front levelling valve – 4. Front shock absorber – 5. Tie rod for valve (3)
6. Torsion bar – 7. Rear levelling valve – 8. Tie rod for valve (7) – 9. Stabilizer bar.

Check and/or adjust length X_1 of tie rods (5) and length X_2 of tie rod (8). Such length, measured between the center distances of articulated pins, must be:

$$X_1 = 94 \pm 1 \text{ mm} - X_2 = 83 \pm 1 \text{ mm} -$$

Figure 4

74094

CAB SUSPENSION PNEUMATIC SYSTEM WORKING DIAGRAM

1. Right-hand front air spring – 2. Front levelling valve – 3. Right-hand rear air spring – 4. Left-hand rear air spring
5. Rear levelling valve – 6. Left-hand front air spring – A. Service supply (8.5 bars)

CAB AIR-CONDITIONING

General

The purpose of the air-conditioning system is to make the cab comfortable as regards the following parameters:

- ☐ temperature and relative humidity of outside air;
- ☐ temperature and relative humidity in the cab.

The system subjects the air to thermodynamic transformations that affect its temperature, relative humidity and purity. This is accomplished by:


- ☐ **ventilation**, or introducing air taken from the outside (therefore with the temperature and humidity of the surrounding environment) into the cab;
- ☐ **air-conditioning**, or cooling and de-humidifying the air, with the possibility of heating it afterwards as preferred so as to change the temperature and humidity in the cab.

VENTILATION Description

Ventilation is the function of drawing in fresh air from the outside, cleaned of pollen and dust by a special filter, or recycling the air in the cab.

This system is composed of a shell, designed to house the electric fan unit, air ducts, fresh air intake and recycled air intake. The electric fan has several speeds to draw in and circulate large masses of air.

Figure 5



85701

CAB INTERNAL VENTILATION DIAGRAM

AIR-CONDITIONING AND HEATING

Description

This is accomplished by integrating an air-conditioning and a heating system.

This integration makes it possible to change the temperature and humidity in the cab.

Air-conditioning

Air-conditioning is accomplished by taking advantage of the high capacity of some gases to lower temperature considerably in their phase of expansion, thereby making it possible to absorb heat from the cab.

This condition is obtained by two different levels of pressure (high, when the refrigerant fluid is in its liquid state, and low, when the fluid is in its gaseous state) that are established and maintained during operation of the system.

Heating

Heating is accomplished by a radiator, in the heater unit, in which the engine coolant circulates.


Special doors allow air to pass through the radiator only when the heating function is activated.

The main components of the air-conditioning and heating system comprise:

- ☐ compressor;
- ☐ condenser;
- ☐ the dehumidifier filter (incorporated in the condenser);
- ☐ three-level pressure switch;
- ☐ expansion valve;
- ☐ evaporator;
- ☐ heater/fan unit;
- ☐ pollen filter.

Air-conditioning controls assembly

Figure 6




85702

Manual

Heating and ventilation

1. Air temperature control knob, with extreme positions to cut in the HI and LO functions (max and min air temperature / turn to the left for fresh air – turn to the right for warm air).
2. Electric fan knob with relative working speeds and operation selection;
 - off (0);
 - manual operation (1-2-3-4).
3. Air inlet control knob:


- ☐ face zone air;
 - ☐ face and feet zone air;
 - ☐ feet zone air;
 - ☐ feet and windshield zone air;
 - ☐ windshield zone air.
4. Switch to turn on air recirculation: it prevents air flowing in from outside.
 5. Switch to turn on the air-conditioner.

COMPONENT LAYOUT (WEBASTO AIR CONDITIONER)**Figure 7**

85703

Legend


- 42045 Outside temperature transmitter
- 82000 Heater assembly
- 42608 Coolant pressure switches
- 25332 Compressor actuation remote-control switch
- 84019 Compressor
- 86116 Body Computer
- 72021 30-pin diagnosis connector

HEATER ASSEMBLY COMPONENT LAYOUT (WEBASTO)**Figure 8**

85704

A. Recirculation geared motor (Ric) - E. Evaporator temperature sensor - F. Blown air temperature sensor - G. Modulates blower control - H. Expansion valve.


Outside temperature sensor

Figure 9

77566

Positioned on the front of the vehicle (driver's side) so as to be affected by a temperature closer to reality.

Compressor

Figure 10


77145

	NIPPONDENSO
	ND10 PA 17
Coolant	R134A
Type of lubricant oil	ND80
Coolant quantity in system	700g
Oil quantity in compressor	200 cc.

The compressor is situated in the engine bay between the radiator fan and the alternator.


Condenser and safety pressure switches

Figure 11




77245

Figure 12



74247



77560


The dehumidifier filter is integrated in the condenser that is found on the front of the vehicle.

The refrigeration system uses R134a fluid highlighted on the plate on its casing.


The safety pressure switch assembly with four levels is fitted on the condenser outlet pipe.

The two pressure switches, which are of the N/C and N/O type, make it possible to keep the pressure in the system constant from a minimum of 2.5 (N/O) to a maximum of 25 bars (N/C); with values outside this range the system is deactivated.


Whereas, the two pressure switches of the N/O type are used to disconnect the engine cooling fan coil when the system pressure is in the interval 18 + 22 bars. This is accomplished by an earth signal that the two pressure switches supply to the Body Computer control unit.

Geared motors**Figure 13**

77571

Figure 14

77572



77573

Pin-out

PIN	CABLE COLOUR	SIGNAL
1	White	+/- 24V
2	Purple	+/- 24V
3	Blue	0V
4	Orange	0 ÷ 5V
5	Green	+ 5V
6	---	Free

The recirculation reduction unit is located on Heater/Conditioner unit.

It is directly activated by the electronic central unit with rated voltage (24 V) and it has 20 to 40 mA absorption.


Maximum absorption, on arriving at end of stroke, reaches 200 mA at power supply put off by the central unit.

The potentiometer it is provided with is used for return signal and, on first power on, the central unit detects and stores end of stroke values used to split operation range.

N.B. If the reduction unit is being replaced, it is NECESSARY to RESET system.

Evaporator temperature sensor

Figure 15



77793

The sensor inside the evaporator causes the compressor to turn on and off, allowing temperatures from 2°C (off) to 3.5°C (on) for VALEO and from 5°C (off) to 10°C (on) for WEBASTO.

The figure shows the same characteristics of the outside temperature sensor except for the connection.

Expansion valve


Figure 16

The expansion valve is the type with a block, its job is to lower the pressure of the fluid at the outlet of the condenser (and therefore of the filter) to a pre-set value so that the same fluid, circulating in the evaporator, can be drawn up by the compressor in a totally gaseous form.

It is therefore possible to state that the expansion valve fulfils three basic functions:

- METERING
- MODULATING
- CHECKING

This is fitted on the Heater/Air-conditioner assembly near the blower control module.



77575

PROCEDURE FOR EMPTYING AND REFILLING THE AIR-CONDITIONING SYSTEMS WITH R134A REFRIGERANT

R134A refrigerant recovery and refilling station (99305146)

This station has been made to be used on all air-conditioning/heating systems for motor vehicles using R134A gas.

By connecting the station to a refrigerating system the gas it contains can be recovered, cleaned and made ready to be reloaded into the system or be transferred to an external container. In addition, it is possible to see the amount of oil taken from the system, restore it and "empty" the system.

To be operative, the station needs to absorb approximately 3 kg of refrigerant.

For prompt use it is advised to have at least 2 kg of refrigerant in the filler cylinders and to keep the station as level as possible.




This procedure does not describe the phases of loading and unloading refrigerant to and from external and internal containers or maintenance. Therefore, please refer to the operating and maintenance manual of the appliance.

The station is composed of:

- 1 control panel;
- 2 container to restore any oil recovered when unloading;
- 3 flexible hoses;
- 4 container to collect any oil recovered from the system;
- 5 filler cylinder with graduated scale revolving.

Figure 17



50631

SAFETY STANDARDS



This station is exclusively for professionally trained operators who must be familiar with refrigerating systems, refrigerant gases and the damage pressurized equipment can cause, therefore:

- ☐ always wear gloves and goggles when working with refrigerant gases. Contact of refrigerant liquid with the eyes can cause blindness;
- ☐ avoid all contact with skin (low boiling point -30°C can cause frostbite);
- ☐ never inhale the vapours of refrigerant gases;
- ☐ before connecting the station with a system or external container, check that all the valves are closed;
- ☐ before disconnecting the station, check that the cycle is over and all the valves are closed. This will prevent dispersing refrigerant gas into the atmosphere;

- ☐ never expose the unit or operate it in acidic or wet environments or close to open containers of inflammable substances;
- ☐ the unit must operate in places with good ventilation;
- ☐ never alter the settings of the safety valves and control systems;
- ☐ never use bottles or other storage containers that are not approved and are not fitted with safety valves;
- ☐ never load any container over 80% of its maximum capacity;
- ☐ never leave the unit powered if it is not to be used immediately. Cut off the mains power supply when it is not planned to use the equipment.

The station is equipped with special fittings to avoid contamination with systems using R12. Do not attempt to adapt this unit for use with R12.

CONTROL FASCIA

Figure 18





Figure 19

50634




50632

Control fascia diagram legend

M1	Low pressure gauge
M2	High pressure gauge
M3	Filler cylinder pressure gauge
LOW	Low-pressure valve
HIGH	High-pressure valve
REF	Refrigerant filler and drain valve
V1	Valve on low-pressure pipe
V2	Valve on high-pressure pipe
V3	Oil injection valve for A/C system
V5	Oil drainage valve
V9	A/C system washing refrigerant service valve
I0	Moisture indicator
VS	Safety and drainage valve
L3	Alarm warning light
L4	Maximum level warning light
L5	Minimum level warning light
A	Unit process / bottle heater switch
LA1	Unit process indicator light
LA2	Bottle heater indicator light
B	Refrigerant process / vacuum process switch
LB1	Refrigerant process indicator light
LB2	Vacuum process indicator light
C	Recovery recycle cycle / Filling switch
LC1	Recovery recycle cycle indicator light
LC2	Filling indicator light
D	Vacuum / vacuum test switch
LD1	Vacuum indicator light
LD2	Vacuum test indicator light

Filler cylinder legend

- 1 Pressure values in bar (vertical lines, revolving top cylinder).
- 2 Weight of load in grams (oblique lines, revolving top cylinder) 50 g division between lines.
- 3 Tank level viewer (internal cylinder).

OPERATION FLOW CHART

RECOVERING REFRIGERANT FROM THE VEHICLE SYSTEM

Before starting to disconnect the pipes from the air-conditioner, check whether it is possible to do the repairs without discharging the gas.


If this is not possible, the following operations must be carried out:

- ☐ connect the pipe marked **HIGH** under the pressure gauge to the evaporator inlet (the inlet is the one on the

pipe with a smaller diameter (H) connecting the drier filter with the evaporator);

- ☐ connect the pipe marked **LOW** under the pressure gauge to the evaporator outlet (the outlet is the one on the pipe with a larger diameter (L) connecting the evaporator with the drier);
- ☐ open the valves **V1** and **V2**;
- ☐ open the **LOW** and **HIGH** cocks;

Figure 20



77049

- ☐ connect the station to the electricity mains (220 V - 50 Hz);
- ☐ press the switch **A** (Process Unit) onto position **I**.
The respective indicator light **LA I** will come on;
- ☐ press the switch **B** (Refrigerant Process) onto position **I**;
- ☐ the respective indicator light **LB I** will come on;
- ☐ press the switch **C** (Recovery Recycle) onto position **I**.
The recovery and recycling operation will start automatically. The respective indicator light **LC I** will come on to signal the operation in progress.
On completing this operation the unit will automatically stop and the indicator light **LC I** go out. Wait for a few minutes so that any pockets of refrigerant at low pressure remaining in the system can increase their pressure, by absorbing heat, and be able to be recovered. The station will automatically repeat the recovery cycle if the above conditions occur;


- ☐ put the switches **A**, **B** and **C** back onto position **0**;
- ☐ close the **V1**, **V2**, **LOW** and **HIGH** valves.



If the refrigerant reaches the maximum level (maximum level indicator light **L4** on), the recovery cycle must be stopped immediately by pressing switch **C** onto position **0** and transferring the refrigerant from the filler cylinder to a suitable external bottle.

- ☐ Continue the operations following the instructions given on the following pages.

Figure 21



50636

CREATING A VACUUM IN THE SYSTEM

This operation should be carried out if all the repairs have been performed and the system components have been properly refitted. This operation is the phase prior to refilling, therefore proceed as follows:

 Do not run the vacuum cycle when there is even minimal pressure in the station or system.


- ☐ connect the pipes to the specific system connections and open the **V1-V2/LOW** and **HIGH** valves;
- ☐ press the switch **A** (Process Unit) onto position 1. The respective indicator light **LA1** will come on;
- ☐ press the switch **B** (Vacuum Process) onto position 2. The respective indicator light **LB2** will come on;
- ☐ press the switch **D** (Vacuum) onto position 1. The system will automatically start being evacuated and the respective indicator light **LD1** will come on to signal the operation in progress.

After a few minutes of operation (10 at most) if the system has no leaks the indicator light **LD2 VACUUM TEST** will also come on. From this time on, evacuation should be continued for at least two hours to obtain a good evacuation;

 The indicator light **LD2 vacuum test** fails to come on if there is a leak. Stop evacuation, eliminate the leak and repeat the evacuation procedure.

- ☐ at the end of the time programmed for evacuation, press the switch **D** (vacuum test) onto position 2 and leave the system in this state for 3-5 minutes. The indicator light **LD2 VACUUM TEST** is on if the system has a good seal. The indicator light **LD2 VACUUM TEST** goes out if there is a leak. Eliminate the leak and repeat the evacuation cycle;
- ☐ put the switches **D** and **B** back onto position 0 and proceed with the following phase.

Figure 22



50637

It is possible that at the end of each recovery cycle the station may have recovered lubrication oil from the compressor, which should be drained off into a specific graduated container (I).

- 1 Slowly open the valve **V5** (Oil Discharge).
- 2 When all the oil has been discharged into the container (I) close the valve **V5**.


- 3 Quantify and **record** the amount of oil discharged.

- 4 Eliminate the recovered oil correctly.

This oil cannot be reused.

The same amount of new oil as has been removed must be added to the system.

Figure 23



50638

RESTORING OIL IN THE SYSTEM

If during the recovery and recycle phase, oil from the system has been removed, it must now be replenished:

- ☐ take the metering device supplied with the right amount of lubricant for the system concerned, or previously measured;
- ☐ connect the metering device (1) to the lubricant injection valve **V3**;
- ☐ open the valve **V3** and then carry out the system vacuum phase for a few moments;
- ☐ open the valve mounted on the metering device container (1). The oil will be drawn into the system;
- ☐ close the valve **V3** and the valve on the metering device container when the required quantity of lubricant has been drawn in;


- ☐ disconnect the metering device (1) from the injection valve **V3** and fit the protective cap back on;



Keep the oil containers well sealed in order to avoid contamination. In particular, remember that oil is extremely hygroscopic:

- ☐ never open the oil injection valve **V3** if the system has positive pressure;
- ☐ oil should only be injected with a vacuum in the system;
- ☐ the oil level must never fall under the suction pipe (air would get into the system).

Figure 24



50639

FILLING THE SYSTEM WITH REFRIGERANT

Before refilling, it is wise to be aware of some important rules:

- ☐ know the quantity of refrigerant to use (it is normally written on an adhesive plate affixed on the vehicle);
- ☐ the filler cylinder is equipped with a minimum level check that prevents introducing incondensable gas into the system.
This is why the last approx. 600 g of refrigerant it contains cannot be used;
- ☐ therefore, before filling, check that the cylinder contains a sufficient quantity for filling (maximum quantity that can be used 3800 g);
- ☐ if the pressure inside the filler cylinder indicated on the pressure gauge (2) is greater than as required, which can be seen on the filler cylinder window approx. 10 bar max, discharge the excess pressure through the valve (1) on the pressure gauge assembly to bring it down to the right level, reading the value on the pressure gauge.




To transfer refrigerant from an external bottle to the filler cylinder and vice versa, refer to the equipment manual.

Considering that the amount of refrigerant depends on its pressure, to know the actual weight it is necessary to turn the outside of the filler cylinder so the line of the diagram matches the level viewer. In this way we can know the exact quantity of refrigerant in the cylinder (starting weight).

When calculating the weight of the refrigerant, in addition to the 600 g that cannot be used, remember to increase the load by approximately 100 g (this is the weight of refrigerant contained in the station-system connecting pipes). The right quantity of refrigerant to introduce into the system will therefore be given by: 600 g + 100 g + (quantity referred to the system capacity).

Always check before filling that the indicator on the "console" shows the refrigerant contains no moisture, in which case the indicator will be bright green. If this is not so, replace the filters in the station as instructed in the equipment manual.

Figure 25



50640

When the cylinder contains the necessary quantity for filling (both pipes must already be connected to the system connectors since the vacuum operation has already been performed), proceed as follows:


- ☐ close the **LOW** valve, keep the **HIGH** and **V1 - V2** valves open;
- ☐ press the switch **B** (Refrigerant process) onto position 1, the indicator light **LBI** will come on;
- ☐ press the switch **C** (Charge) onto position 2, the respective indicator light **LC2** will come on and refrigerant will flow from the station into the system;



When filling, if the level of refrigerant in the cylinder falls under the required quantity the system will stop and the Minimum Level indicator light (L5) will come on.

- ☐ having loaded 200 ÷ 500 g of refrigerant, depending on the size of the system, stop filling by moving the switch **C** (Charge) onto position 0;
- ☐ check the system is properly sealed with the electronic leak finder;
- ☐ complete filling the system until the **pre-calculated residual weight** in the cylinder is reached;
(Residual weight = Total weight - System capacity weight)
- ☐ complete filling, move the switches **C - B** and **A** onto position 0 (A had been moved for the vacuum). Check again there is no leakage;
- ☐ close the **HIGH** valve.

Figure 26



50641

CHECKING THE PRESSURES IN THE SYSTEM

After filling, leave the pipes connected and carry out the following check:

- ☐ close the **HIGH** and **LOW** valves, **V1** and **V2** open;
- ☐ turn on the engine, switch on the air-conditioner and check on the pressure gauges **M1** and **M2** that the pressures correspond, normally: low pressure no less than 1 bar, high pressure 15 ÷ 18 bar, depending on the system specifications.

OPERATIONS PRIOR TO DISCONNECTING THE STATION FROM THE SYSTEM


Always observing the above safety rules, carry out the following operations:

- ☐ check that all the valves are closed: **LOW - HIGH, V1 - V2**;
- ☐ disconnect the pipes of valves **V1 - V2** and put the caps back onto the system valves;
- ☐ Check the system again with the leak finder.



Normally, with the air-conditioner switched on, air should come out of the vents at a temperature lower than 5°C and after a period of operation to stabilize the temperature of the ducts.

Figure 27



50642

LEAK FINDER FOR AIR-CONDITIONING SYSTEMS WITH HFC R134A (9905147)

Tool L-780A makes it possible to identify leakage of HFC 134A gas from the system extremely accurately in the order of 3.3 g a year with the switch on maximum sensitivity.

This instrument requires no settings, the operator only needs to select the desired sensitivity.

The instrument warns the operator of any gas leakage with a buzzer and a LED that flashes in proportion to the concentration of gas.

In addition, the LED indicates the battery is flat if it goes out.

Operating temperature is between 0 °C and 50 °C.

The instrument is equipped with a flexible probe to reach particularly difficult fittings or parts.


The two levels of sensitivity are:

- ☐ low sensitivity = 16.5 g/year;
- ☐ high sensitivity = 3.3 g/year.



Before checking vehicles, wait for the engine to cool, the hot parts can falsify the test.

Figure 28




50643

REPAIR OPERATIONS

553210 HEATER Removal


Figure 29



To remove the heater assembly, it is necessary to:


- drain off the engine coolant;
- detach the fascia covering (552211).
- ☐ Lift the radiator cowl.
- ☐ Unscrew the fixing screws (1) and separate the pollen filter cover (2) to access the underlying fasteners.

Figure 30




- ☐ Disconnect the retaining clamps (1) and the water pipes (2).
- ☐ Unscrew the screws (4) fixing the low and high pressure piping (5) to the body, and screws (3) near the water pipes.
- ☐ Apply special plugs on the high and low pressure pipes and on the expansion valve.

Figure 31



- ☐ Working from inside the cab, unscrew the screws (1) fixing the air ducts (2) to the heater (3).
- ☐ Disconnect the air ducts (2) from the heater (3).

Figure 32




- ☐ Unscrew the screws (2) fixing the heater (5) to the cross member on the cab.
- ☐ Detach the clamps (1) of the wiring bundles.
- ☐ Disconnect the connectors (4) and detach the relative electric wiring (3).
- ☐ Detach the heater (5) from the vehicle.



Refitting


Refit by carrying out the steps described for removal in reverse order. At the end, check that:

- ☐ the engine coolant is at the right level;
- ☐ the system and components involved in the described procedure work properly.

507570 ADDITIONAL AIR HEATER SYSTEM**Removal****Figure 33**


77126

- ☐ Lift the radiator cowl.
- ☐ Tilt up the cab.
- ☐ Unscrew the screws (7) of the clamps (6) and disconnect the fuel pipe (5).
- ☐ Unscrew the screws (1).
- ☐ Disconnect the clamps (2) and detach the inlet and outlet pipes (3).
- ☐ Unscrew the nuts (4) fixing the additional heater to the floor of the cab.

Figure 34

77127

- ☐ Lower the cab.
- ☐ Close the radiator cowl.
- ☐ Working from inside the cab, detach the cushion (1) and lift the door (2) of the additional heater compartment.

Figure 35

77128

- ☐ Disconnect the electrical connection (1).
- ☐ Detach the clamp (3) and free the pipe (2) from the heater (4).
- ☐ Detach the additional heater (4) from the vehicle.

Refitting


Refit by carrying out the procedures described for removal in reverse order.

553254 DEFROST CONTROL MOTOR**Removal****Figure 36**

77129


- ☐ Undo the fasteners and detach the air diffuser openings (1).
- ☐ Working through the seat of the air diffuser openings, unscrew the screws (2) fixing the air pipe (3).
- ☐ Remove the bottom covering of the instrument panel as described in operation (552211).

Figure 37




- ☐ Undo the fasteners and take off the moulding (2) to get to the underlying screws.
- ☐ Unscrew the fixing screws (1) and remove the connection (3) of the moulding (2).

Figure 38




- ☐ Open the glove compartment (3).
- ☐ Detach the tie rods (1).
- ☐ Unscrew the nuts (2) and detach the glove compartment.

Figure 39



- ☐ Unscrew the screws (2) fixing the Body Control (1).
- ☐ Remove the Body control (1) and set it aside.

Figure 40



- ☐ Take off the press-on plugs fixing the air pipe to the cross member under the fascia.
- ☐ Unscrew the fixing screw and take out the air pipe.
- ☐ Disconnect the power supply connector (2).
- ☐ Unscrew the fixing screws (1).
- ☐ Detach the DEFROST control motor (3) from the vehicle.

Refitting




Refit by carrying out the procedures described for removal in reverse order.

553153 AIR RECIRCULATION DOOR CONTROL MOTOR

Removal

Figure 41



77131

- ☐ Detach the glove compartment, unscrew the fixing screws, remove the Body Control and set it aside as described in removing the "DEFROST CONTROL MOTOR."
- ☐ Disconnect the power supply connector (2).
- ☐ Unscrew the fixing screws (1).
- ☐ Detach the air recirculation door control motor (3).


Refitting

- ☐ Refit by carrying out the procedures described for removal in reverse order.

553212 ELECTRIC FAN

Removal

Figure 42




77135

Perform the removal procedure:

- ☐ Central instrument panel (OP. 553710).
- ☐ Disconnect the connector (2).
- ☐ Take off the fixing clips (1), unscrew the screws (3) and detach the covers (4) and (5).

Figure 43



77136

- ☐ Detach the electric fan (1) from its seat.


Refitting

- ☐ Refit by carrying out the procedures described for removal in reverse order.

553215 HEATER RADIATOR

Removal

Figure 44




77137

Before proceeding to detach the heater radiator, it is necessary to:


- ☐ Turn the ignition key onto "Key On" and switch over the air temperature onto "LOW".
- ☐ Drain off the engine coolant.
- ☐ Detach the pollen filter and cover (Figure 49).
- ☐ Detach the Body Control.
- ☐ Detach the bottom covering of the fascia on the passenger side.
- ☐ Detach two passenger air openings.
- ☐ Detach the air delivery pipe from the central body to the rh door opening.
- ☐ Disconnect the retaining clamps (1) and separate the water pipes (2).

Figure 45




- ☐ Operating through the control unit compartment at the bottom of the fascia covering, unscrew the screw (2) fixing the clevis (1) and free the heater water pipes (3).

Figure 46




- ☐ Take off the clips and detach the pipe (3).
- ☐ Unscrew the screws (4) fixing the radiator to the heater.
- ☐ Detach the connectors (1), (2) indicated to facilitate the outflow from the heater radiator.

Figure 47



- ☐ Detach the connectors (1), (2) indicated to facilitate the outflow from the heater radiator.

Figure 48




- ☐ Extract the heater radiator (1) with due caution from the glove compartment bay.

Refitting



Refit by carrying out the procedures described for removal in reverse order.


553261 POLLEN FILTER**Removal****Figure 49**

77142

Lift the radiator cowl, take off the cover (1) and remove the pollen filter (2).


Refitting

Refit by carrying out the procedures described for removal in reverse order.

553239 AIR-CONDITIONER COMPRESSOR**Removal****Figure 50**


77143

- ☐ Discharge the air-conditioning system by following the procedure described under the relevant heading.
- ☐ Working from under the vehicle, unscrew the fixing screws (1) and remove the inlet and outlet pipes (2) from the compressor.

Figure 51

77144

- ☐ Loosen the automatic tightener and take off the compressor belt.
- ☐ Disconnect the power supply connector (2).
- ☐ Unscrew the fixing screws (1).

Figure 52

77145

- ☐ Detach the compressor (1) from the vehicle.


Refitting

Refit by carrying out the procedures described for removal in reverse order. Check the state of the seal. If they are damaged or worn, they must be changed.

553232 AIR-CONDITIONER CONDENSER

Removal

Figure 53



77146

- ☐ Lift the radiator cowl and discharge the air-conditioning system by following the procedure described above.
- ☐ Unscrew the nut (6) and detach the condenser pipes (5).
- ☐ Unscrew the nut (4) fixing the pipe bracket (3).
- ☐ Unscrew the fixing screws (1) and remove the condenser (2) from the vehicle.

Refitting




Refit by carrying out the operations described for removal in reverse order, verifying the integrity and correct position of the seals on the pipes. If they are damaged, they must be changed.

553242 OUTSIDE AIR TEMPERATURE SENSOR

Removal


Figure 54



77147

- ☐ Lift the radiator cowl and disconnect the connector (1) and free the wiring (2) of the sensor (3) from the retaining clamps (4).

Figure 55



77148

- ☐ Detach the outside air temperature sensor (1) from its seat.

Refitting



Refit by carrying out the procedures described for removal in reverse order.

SECTION 14**Scheduled maintenance**

	Page
VEHICLE WITH MOTOR CURSOR 8 (F2B) . . .	3
MAINTENANCE	3
☐ Maintenance services chart	3
CHECKS AND/OR MAINTENANCE WORK . .	4
OFF-PLANE OPERATIONS	5
MAINTENANCE WORK	9
M1 SERVICE	9
M2 SERVICE	11
M3 SERVICE	15
M4 SERVICE	15
EPI SERVICE	15
T1 SERVICE	16
T2 SERVICE	16
T3 SERVICE	16
T4 SERVICE	16
T5 SERVICE	17
T6 SERVICE	17
VEHICLE WITH MOTOR CURSOR 10 (F3A) . .	19
MAINTENANCE	19
☐ Maintenance services chart	19
CHECKS AND/OR MAINTENANCE WORK . .	20
OFF-PLANE OPERATIONS	21
MAINTENANCE WORK	25
M1 SERVICE	25

Page

M2 SERVICE	29
EXTRA PLAN MAINTENANCE	31
EP1 SERVICE	31
EP2 SERVICE	31
EP3 SERVICE	31
T1 SERVICE	32
T2 SERVICE	32
T3 SERVICE	33
T4 SERVICE	34

VEHICLE WITH MOTOR Cursor 8 (F2B)**MAINTENANCE****Maintenance services chart**

The Extra Plan operations (designated with the letters EP) are complementary to standard services.

They are maintenance operations to be carried out at regular time or mileage intervals and concern optional components that are not present on all models.

Important! The correlation between kilometres and months only applies in cases where the distance travelled by the vehicle corresponds roughly to the specified average annual mileage. This is indicated only in order to suggest a hypothetical maintenance programme. Note that the time intervals specified for Extra Plan operations are to be adhered to regardless of the actual mileage covered.



The kilometre frequency for engine lubrication is in relation to a percentage of sulphur in diesel of under 0.5%.

NOTE: If using diesel with a percentage of sulphur above 0.5%, the oil-change frequency has to be halved.

Use engine oil: **ACEA E4 (URANIA FE 5 W 30) - ACEA E3 (URANIA TURBO LD)**
ACEA E5 (URANIA LD5)



- ☐ If ACEA E2 engine oil is used, the engine oil shall be changed every 40.000 km.
- ☐ In the case of very low annual mileage of less than 80,000 km/year, the engine oil and filters must be changed every 12 months.
- ☐ If mineral oil is used in the gearbox, the interval between gearbox oil changes is to be reduced to 150,000 km.
- ☐ In case of low annual mileage, the transmission (automatic transmission excluded) and rear axle oil shall be changed at least every 2 years.
- ☐ The filter dryer of the pneumatic system must in any case be renewed every year.
- ☐ In the case of very low annual mileage, general greasing must be carried out at least once a year.
- ☐ In the case of very low annual mileage, change the anti-pollen filters at least once a year.
- ☐ Premature clogging of the air cleaner is generally due to the operating conditions. The filter should therefore be renewed whenever clogging is signalled by the sensor regardless of the prescribed time interval, which should in any case be respected in the absence of any specific indications.

To schedule the work, keep to the following chart:

OILS	SERVICES				EXTRA PLAN	PROGRAMMED OPERATIONS					
	M1	M2	M3	M4		T1	T2	T3	T4	T5	T6
ACEA E3 (Urania Turbo LD)											
ACEA E5 (Urania Turbo)	Every 80,000 km 1600 hours	Every 160,000 km 3200 hours	Every 240,000 km 4800 hours	Every 480,000 km 9600 hours	Every 40,000 km 800 hours	Every 6months	Every* year	Every** year	Every year	Every 2 years	Every 3 years
ACEA E4 (Urania FE 5 W30)											

* Before winter

** Before summer



The extra plan and scheduled operations must preferably be performed at the same time as a maintenance service and specifically.

CHECKS AND/OR MAINTENANCE WORK

Type of operation		M1	M2	M3	M4
		Every 80,000 km 1 600 hours	Every 1 60,000 km 3 200 hours	Every 240,000 km 4 800 hours	Every 480,000 km 9 600 hours
Engine					
9	Change engine oil	•	•	•	•
7	Change engine oil filters	•	•	•	•
20	Change fuel filter	•	•	•	•
22	Check blow-by filter conditions through clogging indicator	•	•	•	•
25	Check clutch wear fan electro-magnetic joint	•	•	•	•
1-2	Check control belt conditions	•	•		
19	Change or clean filter of steering column hydraulic system	•	•	•	•
8	Change air filter of turbo-compressor valve with variable geometry (VGT)		•		•
18	EDC system engine check-up through MODUS or IT2000		•		•
21	Check valve clearance and adjust it if needed			•	•
1	Change control belt of engine auxiliary parts			•	•
2	Change air conditioner compressor control belt			•	•
3	Change air conditioner automatic compressor backstand			•	•
Chassis and mechanical units					
17	Change fuel pre-filter	•	•	•	•
13	Change air system drier filter (every year)	•	•	•	•
5	Check clutch hydraulic system fuel level	•	•	•	•
16	Clean mechanical transmission oil breather		•		•
16	Change mechanical transmission oil		•		•
16	Change oil in transmission with ZF Intarder		•		•
16	Change ZF Intarder oil filter		•		•
15	Change rear axle oil		•		•
15	Clean rear axle oil breather		•		•
14	Change rear axle reducer oil		•		•
11	Change axle wheel hub oil		•		•
6	Check headlight orientation		•		•
10	Check drive case and support fastening		•		•
Miscellaneous					
•	Chassis general lubrication (every year)	•	•	•	•
•	Transfer operations	•	•	•	•
•	Road test	•	•	•	•

OFF-PLANE OPERATIONS**EPI - EVERY 40.000 Km**

Or every year, or every 1,000 hours in vehicles for waste collection and carry out the following operations.

16	Change Allison automatic transmission oil and filters
16	Clean Allison automatic transmission oil breather

T1 - EVERY SIX MONTHS

(especially at the beginning of spring) and possibly when a maintenance service is performed, carry out the following operations:

•	Check pollen filter conditions. In case of low annual mileage, change them once a year at the beginning of spring.
24	Wash radiator guard grid.

T2 - EVERY YEAR

and possibly before winter when a maintenance service is performed, carry out the following operations:

4	Check antifreeze quantity in engine cooling water
---	---

T3 - EVERY YEAR

and possibly before summer when a maintenance service is performed, carry out the following operations:

23	Check possible radiator clogging
----	----------------------------------

T4 - EVERY YEAR

and possibly when a maintenance service is performed, carry out the following operations:

•	Change "Multipower" (if any) total power take-off oil
---	---

T5 - EVERY TWO YEARS

and possibly when a maintenance service is performed, carry out the following operations:

23	Change engine coolant
12	Change air filter dry cartridge even if there is no clogging signal
22	Change engine Blow-by filter cartridge even if there is no clogging signal


T6 - EVERY THREE YEARS

and possibly when a maintenance service is performed, carry out the following operations:

5	Change clutch hydraulic control fluid
---	---------------------------------------

* Vehicles with Allison – EuroTronic transmission excluded

Figure I




MAINTENANCE WORK

M1 SERVICE

9. Change engine oil


Figure 2



Take out the oil level dipstick (1).
From underneath the vehicle, remove the soundproofing guard.
Unscrew the plug (3) from the oil sump and drain the engine oil off into a specific container.
Screw the plug back on under the sump and tighten it to the required torque.
Fill in with the prescribed oil quantity and quality (see the CAPACITIES table in the GENERAL INFORMATION section) from the tie rod cover pipe union (2).

7. Change engine oil filters

Figure 3



Drain the oil as described in point 4. "Changing engine oil."
Remove the oil filter (1) with tool 99360314 (2).




Before refitting the new cartridges, moisten the seal with engine oil.

Screw the oil filters (1) on by hand to bring them into contact with the mount and then tighten by 3/4 of a turn to the prescribed torque and proceed as described in point 4. "Changing engine oil."

22. Check state of blow-by filter with clogging indicator


Figure 4



- ☐ Check the state of the filter (3) with the clogging indicator (1).
If the red zone appears it is necessary to change it as described in the T5 service.

25. Check electromagnetic coupling clutch wear


Figure 5



Using a feeler gauge, check the gap between the anchor assembly (2) and the pulley (1), it must be no greater than 2.5 mm.

1-2. Check miscellaneous drive belts


Figure 6



Visually check that the belts (1-2) are neither worn nor deteriorated; if they are, change them as described in the M2 service.

19. Change or clean hydraulic steering system filter

Figure 7



Before taking off the cover (1), thoroughly clean the tank.

This will prevent foreign impurities from coming into contact with the oil of the hydraulic system.

Take the cover (1) off the tank and take out the oil filter (3).

Remove the coupling device (2) from the oil filter (3) and replace the filter.


Take off the plug (1) (after unhooking the transmitter) of the hydraulic power steering tank and check that with the engine running and the wheels travelling in a straight line, the oil level reaches the top reference mark on the dipstick.

With the engine stationary and wheels in a straight line, the oil level has to exceed the top reference mark of the dipstick by 1 or 2 cm; if necessary, top up the level by taking off the cover (1).

22. Check state of engine blow-by filter through clogging indicator.

17. Change pre-filter

Figure 8



Unscrew the pre-filter (1) and replace it.


Before refitting the new cartridge, moisten the seal with diesel or engine oil. Screw the cartridge on by hand until it is in contact with the mounting and then tighten by 3/4 of a turn to the required tightening torque.



When replacing the cartridge, it must not have been pre-filled. This is to prevent impurities getting into circulation that could damage the injector/pump system components. Bleed the air from the fuel circuit as described on the previous pages.

17. Change fuel filter

Figure 9



Remove the fuel filter (1) with tool 99360314.


Before refitting the new cartridge, moisten the seal with diesel or engine oil.

Screw the new one on by hand, taking care to check that the rubber seal and the mating surface are clean and in a perfect state of repair. Screw the cartridge on by hand until it is in contact with the mounting and then tighten by 3/4 of a turn to the required tightening torque.

Bleed the air from the supply system as described in the following paragraph.

Bleeding air from the fuel circuit

Figure 10




- ❑ Open the bleed screws, connecting them with tubes to run off the bled fluid into suitable containers to prevent dirtiness:
 - 1 = located on the pre-filter mount (on the chassis frame);
 - 3 = located on the filter mount (on the engine);
 - 4 = located on the front of the cylinder head.
- ❑ Work the hand pump (2) on the pre-filter till you see fuel with no air in it coming out of the bleed screw (1) (retighten the screw when the operation is over). Keep on pumping until you see fuel with no air in it come out of the bleed screw (3) on the filter as well (then retighten the screw) and from the screw (4) on the front of the cylinder head (retighten the screw when the operation is over) and tighten them to the required torque.

The circuit has now been bled. Start up the engine and run it for a few minutes at idling speed to get rid of all remaining air.

 Never let the fuel soil the drive belt: alternator, pump, water, etc.

13. Change pneumatic system drier filter

Figure 11




Discharge the pressure from the compressed air system. With the right tool, remove the drier filter (1) from its mounting and fit the new part. Screw on by hand until there is contact with the mounting and then tighten by 3/4 of a turn to the required torque.

 If on removal you find there is too much oil in the drier or in the intake pipe, check the conditions of the compressed air as described under the relevant heading.

5. Check clutch fluid level (vehicles with ZF 16 S 181/221 gearbox only)

Figure 12



Check the level of the clutch fluid. Top it up if it is too low (see the FLUIDS table in the GENERAL section).

 The clutch fluid is poisonous and corrosive: if you accidentally come into contact with it, wash immediately with water and a neutral soap.


- **Chassis general lubrication (to be carried out every year)**
- **Manoeuvring**
- **Road test**

M2 SERVICE

 The M2 service comprises the operations of the M1 service plus the ones listed here.

8. Change variable geometry turbocharger (VGT) valve air filter

Figure 13




Using a suitable tool, unscrew the filter (1) and replace it. Before fitting the new cartridge, moisten the seal with diesel or engine oil. Screw it on by hand until it is in contact with the mounting and then tighten by 3/4 of a turn to the required tightening torque.

18. Check-up on EDC system with MODUS or IT2000

16. Change gearbox oil

Figure 14




The figure shows ZF 16 S 151 transmission.

- ☐ With the gearbox warm, take off the plug(s) (1) and drain the oil into a specific container.
- ☐ The oil should be drained off taking care not to soil the cross member beneath as it is near the outlet on some types of gearbox.
- ☐ It is therefore wise to use a tool to convey the oil away.
- ☐ Pour in fresh oil through the hole closed by the plug (2) (for the quantity, see under the FLUIDS heading of the GENERAL section).
- ☐ Tighten the plugs to the required torque.

(ZF 12 AS 2301 / 16 AS 2601 gearbox)


Figure 15



- ☐ With the gearbox warm, take off the plug(s) (1) and drain the oil into a specific container.
- ☐ The oil should be drained off taking care not to soil the cross member beneath as it is near the outlet on some types of gearbox.


23. Change oil and filter of ZF 16 S 151/181/221 gearbox + Intarder

Figure 16



- ☐ With the gearbox warm, take off the plugs (1) and drain the oil into a specific container.


Figure 17



Remove the oil filter as follows:

- ☐ unscrew the screw (5) fixing the filter;
- ☐ take off the cover and filter (1);
- ☐ remove the cover from the filter and replace it. Take care not to lose the magnetic pad (4) on the outer edge of the filter, as it has to be repositioned on the new filter;
- ☐ check the state of the o-ring (2) and replace it, if necessary;
- ☐ grease the o-ring (3) inserted in the assembly opening of the new filter;
- ☐ couple the new filter with its cover and insert it into its seat as far as it will go. Secure the screw (5).

Figure 18




72572

- ☐ Screw the plugs back on and tighten them to the required torque.
- ☐ Pour in fresh oil through the hole closed by the plug (7) until oil comes out of the hole of plug (6) and screw the plugs back on to the required torque. (The filling quantity is given under the FLUIDS heading of the GENERAL section.)
- ☐ Clean the gearbox oil vapour breather.

Change oil and filter of ZF Eurotronic Automated gearbox with Intarder

Figure 19



72573


- ☐ With the gearbox warm, take off the plugs (1) and drain the oil into a specific container.
- ☐ Remove the Intarder filter following the procedure described in the above paragraph.
- ☐ Screw the plugs (1) back on and tighten them to the required torque. Pour in fresh oil through the hole of plug (2) until oil comes out of the hole of plug (3). (See the FLUIDS table in the GENERAL section.)
- ☐ Screw the plugs back on to the required torque.
- ☐ Clean the gearbox oil vapour breather.



Have a short test run on the roads (at least one minute at least 10 km/h), briefly operating the Intarder just once (level 6) and then disengage it (level 0). At the end of the test, stop the vehicle without operating the Intarder. Stop the engine, check the level again (plug 2) and top up, if necessary.

16. Clean gearbox oil bleed

Figure 20




72566

The figure shows ZF 16 S 151 transmission. Remove the oil vapour breather (1) and clean it thoroughly. Then fit it back on, checking it is in the right position, and tighten it to the required torque.

15. Change rear axle oil

15. Clean rear axle oil breather

Figure 21




40657

The lubricating oil has to be drained with the oil warm. Place a container under the plug (1), remove the plug and drain off the oil.

Fit the plug (1) back on, remove the plug (2) and pour the required grade and quantity of lubricating oil in through the hole. Remove the oil vapour bleed and clean it thoroughly.

11. Change front, middle or rear axle wheel hub oil (where applicable)

Figure 22




For the wheel hubs with the cover illustrated in the figure, proceed as follows:

- ☐ turn the wheel hub so as to bring the plug (1) downward; unscrew the plug and drain off the oil into an appropriate container;
- ☐ then turn the hub and take the hole closed by the plug (1) back upward and replenish with fresh oil; for the quantity, see CHARACTERISTICS AND DATA in the "AXLES" section;
- ☐ screw the plug down to the prescribed torque.



Use no chlorothene based solvents to clean the cover.

Figure 23



For the wheel hub with the cover illustrated in the figure, proceed as follows:

- ☐ remove the plug (1) and draw up the oil with a suitable string;
- ☐ fill the wheel hub with new oil (for the quantity and type of oil, see CHARACTERISTICS AND DATA in the "AXLES" section).

The oil level is checked through the window in the plug (1) with max. and min. on the cover in a horizontal position.

10. Check steering box fixing and mounting






Check that the fastenings of the steering box and mounting are tightened to the required torque.



6. Check headlight adjustment

Figure 24



72585

- ☐ Set the vehicle unladen with its tyres at the required pressure on level ground facing a light wall.
- ☐ Mark two crosses on the wall corresponding to the centres of the two headlights.
- ☐ Turn the switch onto 0.
- ☐ Set the vehicle at 10 metres and turn on the low beam. The distance between the crosses and the points P, which correspond to the angle of the headlights, has to be 12.5 cm.

1. Light beam adjustment screw in horizontal direction.
2. Light beam adjustment screw in vertical direction.

M3 SERVICE




The M3 service includes M1 operations without 1-2. check control belts; 16. change oil and oil filter in transmission with Intarder. Add also the following operations.

1-2. Change miscellaneous drive belts

3. Change air conditioner automatic compressor backstand

Figure 25



ASSEMBLY DIAGRAM OF BELTS FOR FAN – WATER PUMP – ALTERNATOR AND AIR-CONDITIONER COMPRESSOR

1. Fan – 2. Alternator – 3. Drive belt – 4. Drive belt automatic tensioner – 5. Compressor drive belt
6. Air-conditioner compressor – 7. Screw –
8. Air-conditioner compressor automatic tensioner –
9. Crankshaft – 10. Water pump

To remove and refit the belts (3-5) you need to apply suitable tools to the tensioners (4-8) in the direction shown by the arrows.

After removing the control belts (3 and 5), take off the screw (7) and change the backstand (8).

Fasten screw (7) and tighten it to the specified torque.



The backstands are automatic and so no further adjustments are planned after assembly.



21. Check valve clearance and adjust if necessary

To carry out these operations correctly, refer to the procedures described in the relative chapter of the "ENGINE" section.

M4 SERVICE




The M4 service includes M2 operations without 1-2. "Check control belt conditions". Add also operation 21. "Check valve clearance and possible adjustment", 1-2. Change control belts and 3. "Change air conditioner automatic compressor backstand".

EPI SERVICE

16. Change Allison automatic transmission oil and filters

Figure 26



Place the vehicle on a bridge.

Remove the draining plug (2) of the check module and drain the transmission oil at operating temperature (71° to 93°C). Once the oil has been drained, refit the plug (2) to a tightening torque corresponding to 25 to 32 Nm.

Slacken the 12 check module fastening screws (3) and remove the oil filter covers (4). Remove the filters (5) and the gaskets (6 - 7 - 8).


For refitting, reverse the removal procedure and attain to the following prescriptions.

Lubricate the new O-rings before assembly. Tighten the screws to the prescribed torque.

Once assembly has been completed, make sure the oil draining plug (2) is well tightened and then pour 18 litres of Tutela GI/A oil through the filling pipe.

16. Clean Allison automatic transmission oil breather

Remove the oil vapour breather (1) and clean it accurately, then refit it in the correct position and tighten it to the prescribed torque.

T1 SERVICE**Change pollen filter****Figure 27****Every six months**

Check the state of clogging of the pollen filter (1).

It is reached by lifting the front radiator cowling and unscrewing the six supporting screws.




Excessive clogging of the pollen filters can cause a reduction in the flow rate of air into the cab and therefore less ventilation.

This will be highlighted especially by a significant reduction in the efficiency of the windscreen defrosting function.

24. Wash radiator grille

Lift the cab radiator cowling and carefully clean the radiator grille.

T2 SERVICE**4. Check percentage of antifreeze in the engine coolant****Figure 28**

The plug (1) must never be taken out for any reason whatsoever.

With the engine warm, the cooling system is in overpressure, therefore take care when taking off the cap (2).

Take off the cap (2) and draw off a sample of the coolant from the expansion tank (3) with the densimeter 99395858.

Depending on the temperature of the liquid, check the percentage of antifreeze in the liquid on the scale of the instrument. The percentage has to be higher than 40% and must not exceed 50%.

If necessary, restore the percentage of antifreeze, bearing in mind that the liquid needs to be replaced every 2 years.




For vehicles fitted with an additional heater, the percentage of antifreeze must never exceed 50%.

T3 SERVICE**23. Check possible radiator clogging**

Check that the engine coolant radiator is not clogged, otherwise clean it accurately.

T4 SERVICE

- **Replacing "Multipower" total power take off oil (is available)**

Figure 29

Set the vehicle horizontal and stop the engine.


Position a suitable container to collect the oil.

- ☐ Unscrew the drain plug (2).
- ☐ Unscrew the filter (1) and clean it thoroughly.


To restore the oil level, screw the filter (1) and drain plug (2) back on to the required torque, checking the state of the seals.

Replace them if they have deteriorated. Then:

- ☐ Unscrew the plug (3) and add the required amount of oil (see FLUIDS in GENERAL INFORMATION).
- ☐ Screw the plug back on to the required torque.


T5 SERVICE**23. Change engine coolant****12. Change the cartridge of the dry air filter and clean its conditioner****Figure 30**

- Unhook the clamps (1) (or, depending on the version, unscrew the nut) and take off the bottom cover (2).

Figure 31

- Unscrew the nut (4) and take out the cartridge of the filter (3).

Before fitting the new cartridge, clean its housing thoroughly.

22. Renewal of the blow-by filter**Figure 32**

To renew the blow-by filter (2), remove the screws (3) and the cover (4), withdraw the filter (2) along with its gaskets (1 and 5).

Carefully clean the seating of the filter and the cover (4).



The filter only operates in one flow direction and therefore must be installed with the reinforcing bars visible (→) as shown in the figure.

Fit a new filter (2) with new (1 and 5). Refit the cover and tighten the fixing screws (3) to the prescribed torque.


T6 SERVICE**5. Change the clutch fluid and make air bleeding (only versions with mechanical transmission)**

Drain off the clutch control fluid and change it (see Fluids table in GENERAL section).



The clutch fluid is poisonous and corrosive: if you accidentally come into contact with it, wash immediately with water and a neutral soap.

Figure 33




After changing the fluid, bleed the hydraulic clutch control system.

Use the air bleeding tool 99306010 as follows:

- ☐ charge reservoir (5) with compressed air;
- ☐ fill reservoir (4) with Tutela TRUCK DOT SPECIAL fluid
- ☐ replace the cap (⇒) of the clutch fluid reservoir with one of the caps supplied with the tool 99306010 and connect the pipe to the cap.

Figure 34



40355

- ☐ Attach a plastic tube to the bleed screw (2) on the slave cylinder (1) and immerse the opposite end of the tube in a container containing Tutela TRUCK DOT SPECIAL fluid, unscrew the bleed screw (1) by one full turn, open the valve (2) (see Figure 16) until a pressure reading of 1 to 1.2 bar is obtained on the pressure gauge (3);
- ☐ when the clutch fluid flowing through the tube is uniform and free of air bubbles, close the bleed screw and discharge the air from the reservoir (5) through valve (6).



Whenever the clutch fluid is changed, it will also be necessary to bleed the clutch master cylinder by loosening the fitting (1, Figure 33) before bleeding the clutch servo.

VEHICLE WITH MOTOR Cursor 10 (F3A) MAINTENANCE

Maintenance services chart

The Extra Plan operations (designated with the letters EP) are complementary to standard services.

They are maintenance operations to be carried out at regular time or mileage intervals and concern optional components that are not present on all models.

Important! The correlation between kilometres and months only applies in cases where the distance travelled by the vehicle corresponds roughly to the specified average annual mileage. This is indicated only in order to suggest a hypothetical maintenance programme. Note that the time intervals specified for Extra Plan operations are to be adhered to regardless of the actual mileage covered.



The kilometre frequency for engine lubrication is in relation to a percentage of sulphur in diesel of under 0.5%.
NOTE: If using diesel with a percentage of sulphur above 0.5%, the oil-change frequency has to be halved.

Use engine oil: **ACEA E4 (URANIA FE 5 W 30) - ACEA E3 (URANIA TURBO LD)
ACEA (URANIA LD5)**



- ☐ If class ACEA E3 engine oil is used, the engine oil and filters must be changed every 100,000 km.
- ☐ If class ACEA E2 engine oil is used, the engine oil and filters must be changed every 50,000 km.
- ☐ In the case of very low annual mileage of less than 150,000 km/year, the engine oil and filters must be changed every 12 months.
- ☐ If mineral oil is used in the gearbox, the interval between gearbox oil changes is to be reduced to 150,000 km.
- ☐ In the case of very low annual mileage of less than 150,000 km/year, the engine oil and filters must be changed at least every 2 years.
- ☐ If mineral oil is used in the axle with disc brakes, the interval between oil changes is to be reduced to 200,000 km as for the axle with drum brakes.
- ☐ In the case of very low annual mileage of less than 150,000 km/year, the oil in axles with disc brakes must be changed at least every 3 years.
- ☐ In the case of very low annual mileage of less than 150,000 km/year, the oil in axles with drum brakes must be changed at least once every 2 years.
- ☐ The filter dryer of the pneumatic system must in any case be renewed every year.
- ☐ In the case of very low annual mileage, general greasing must be carried out at least once a year.
- ☐ In the case of very low annual mileage, change the anti-pollen filters at least once a year.
- ☐ Premature clogging of the air cleaner is generally due to the operating conditions. The filter should therefore be renewed whenever clogging is signalled by the sensor regardless of the prescribed time interval, which should in any case be respected in the absence of any specific indications.

To schedule the work, keep to the following chart:

OILS	SERVICES		EXTRA PLAN			PROGRAMMED OPERATIONS			
			EPI	EP2	EP3	T1	T2	T3	T4
Engine (1) Urania FE5W30	M1	M2	Fuel filter renewal	Check and adjust valve clearances and injectors	Change axle oil	Every 6 months	Every year	Every 2 years	Every 3 years
Gearbox (1) Tutela Truck FE-Gear									
Axle with disc brakes (1) Tutela Truck FE-Axle									
Rear axle with drum brakes (2) Tutela WI40/M-DA	Every 150,000 km	Every 300,000 km	Every 100,000 km	After the first 150,000 km and subsequently every 300,000 km	Axle with disc brakes (1) every 45,000 km Axle with drum brakes (2) every 200,000 km				

(1) IVECO recommends use of these lubricants in order to obtain fuel economy benefits. New IVECO vehicles are supplied with these lubricants. The recommended oil change intervals refer to the use of these types of oil.

(2) In this case, new vehicles are supplied by IVECO with mineral oil in the axle.

CHECKS AND/OR MAINTENANCE WORK

Type of operation		M1	M2
		Every 150,000 km	Every 300,000 km
Engine			
9	Change engine oil	•	•
8	Change engine oil filters	•	•
24	Check state of blow-by filter (with clogging indicator)	•	•
2	Check electromagnetic coupling clutch wear	•	•
1-3	Check miscellaneous drive belts	•	•
19	Change or clean hydraulic steering system filter	•	•
20	Check-up on engine EDC system with MODUS or IT2000	•	•
21	Change VGT variable geometry turbocharger valve air filter		•
1-3	Change miscellaneous drive belts		•
Chassis and mechanical assemblies			
18	Change fuel pre-filter	•	•
17	Clean gearbox oil bleed	•	•
5	Check clutch fluid level (*)	•	•
14	Change pneumatic system drier filter (every year)	•	
16	Change transmission oil (to be carried out at least every two years in case of low mileage)	•	•
15 16	Clean rear axle oil breather	•	•
12	Change the axle wheel hub oil: front, central or rear (if any)	•	•
11	Check steering box fixing and mounting	•	•
10	Check headlight adjustment	•	•
17	Change transmission oil (to be carried out at least every two years in case of low mileage)		•
17	Change oil and filter in transmission with ZF + Intarder (to be carried out at least every two years in case of low mileage)		•
Chassis and mechanical assemblies			
•	Chassis general lubrication (to be carried out every year)	•	•
•	Transfer operations	•	•
•	Road test	•	•

(*) Only for versions with mechanical transmission

OFF-PLANE OPERATIONS**EPI - EVERY 100.000 Km**

and possibly when a maintenance operation is carried out

23	Change fuel filter
----	--------------------

EP2 - In the initial period at 150,000 km and then every 300,000 km

and possibly when a maintenance operation is carried out

22	Check and adjust valve clearance and injectors
----	--

EP3 (1) - Every 200,000 km (rear axle with drum brakes)**Every 450,000 km (rear axle with disc brakes)**

and possibly when a maintenance operation is carried out

15	Change rear axle oil
----	----------------------

16	Change oil and filter shutter and intermediate axle differential
----	--

T1 - Every 6 months – Especially at the beginning of spring

and possibly when a maintenance operation is carried out

•	Check pollen filter conditions (2)
---	------------------------------------

6	Wash radiator guard grid
---	--------------------------

T2 - Every year – Before winter

and possibly when a maintenance operation is carried out

4	Check coolant density
---	-----------------------

T3 - Every two year

and possibly when a maintenance operation is carried out

7	Change engine coolant
---	-----------------------

13	Change cartridge and clean air filter container
----	---

24	Change Blow-by filter
----	-----------------------

T4 - Every two year

and possibly when a maintenance operation is carried out


5	Change oil and bleed clutch hydraulic control
---	---

(1) The rear axles with drum brakes contain mineral-base oil; those with disc brakes contain synthetic-base oil.

(2) Change filters once a year in case of low annual mileage.

(3) Early air filter clogging is usually due to environmental conditions. For this reason, the filter should be changed if clogging is signalled by the related sensor, regardless of the prescriptions that shall be observed if no specific indications have been provided.

Figure 35




MAINTENANCE WORK

MI SERVICE

9. Change engine oil

Figure 36



Take out the oil level dipstick (1).

From underneath the vehicle, remove the soundproofing guard.


Unscrew the plug (2) from the oil sump and drain the engine oil off into a specific container.

Screw the plug back on under the sump and tighten it to the required torque.

Pour oil into the engine through the filling-pipe (2) of the required grade and quantity (see FLUIDS table in the GENERAL section).

8. Change engine oil filters

Figure 37



Drain the oil as described in point 4. "Changing engine oil."

Remove the oil filter (1) with tool 99360314.




Before refitting the new cartridges, moisten the seal with engine oil.

Screw the oil filters (1) on by hand to bring them into contact with the mount and then tighten by 3/4 of a turn to the prescribed torque and proceed as described in point 4. "Changing engine oil."

24. Check state of blow-by filter with clogging indicator

Figure 38




Check the state of the filter (3) with the clogging indicator (1).


If the red zone appears it is necessary to change it as described in the T2 service.

2. Check electromagnetic coupling clutch wear

Figure 39




Using a feeler gauge, check the gap between the anchor assembly (2) and the pulley (1), it must be no greater than 2.5 mm.

1-3. Check miscellaneous drive belts**Figure 40**

77470

Visually check that the belts (1-2) are neither worn nor deteriorated; if they are, change them as described in the M2 service.

21. Change or clean hydraulic steering system filter**Figure 41**

72564

Before taking off the cover (1), thoroughly clean the tank.


This will prevent foreign impurities from coming into contact with the oil of the hydraulic system.

Take the cover (1) off the tank and take out the oil filter (3).

Remove the coupling device (2) from the oil filter (3) and replace the filter.

Take off the plug (1) (after unhooking the transmitter) of the hydraulic power steering tank and check that with the engine running and the wheels travelling in a straight line, the oil level reaches the top reference mark on the dipstick.

With the engine stationary and wheels in a straight line, the oil level has to exceed the top reference mark of the dipstick by 1 or 2 cm; if necessary, top up the level by taking off the cover (1).

20. Check-up on EDC system with MODUS or IT2000**18. Change pre-filter****Figure 42**


74088

Unscrew the pre-filter (1) and replace it.

Before refitting the new cartridge, moisten the seal with diesel or engine oil. Screw the cartridge on by hand until it is in contact with the mounting and then tighten by 3/4 of a turn to the required tightening torque.



When replacing the cartridge, it must not have been pre-filled. This is to prevent impurities getting into circulation that could damage the injector/pump system components. Bleed the air from the fuel circuit as described on the previous pages.


17. Clean gearbox oil bleed (ZF 16 S 151/181/221 gearbox)**Figure 43**

72566

Remove the oil vapour breather (1) and clean it thoroughly. Then fit it back on, checking it is in the right position, and tighten it to the required torque.

5. Check clutch fluid level (vehicles with ZF I 6 S 181/221 gearbox only)

Figure 44



74089


Check the level of the clutch fluid. Top it up if it is too low (see the FLUIDS table in the GENERAL section).



The clutch fluid is poisonous and corrosive: if you accidentally come into contact with it, wash immediately with water and a neutral soap.

14. Change pneumatic system drier filter

Figure 45



Discharge the pressure from the compressed air system.

With the right tool, remove the drier filter (I) from its mounting and fit the new part.


Screw on by hand until there is contact with the mounting and then tighten by 3/4 of a turn to the required torque.



If on removal you find there is too much oil in the drier or in the intake pipe, check the conditions of the compressed air as described under the relevant heading.

15. 16. Clean rear axle oil vent


Figure 46



Check that the air breather (I) is not clogged; if it is, remove it, clean it carefully and fit it back on.

12. Change front, middle or rear axle wheel hub oil (where applicable)

Figure 47




For the wheel hubs with the cover illustrated in the figure, proceed as follows:

- ☐ turn the wheel hub so as to bring the plug (1) downward; unscrew the plug and drain off the oil into an appropriate container;
- ☐ then turn the hub and take the hole closed by the plug (1) back upward and replenish with fresh oil; for the quantity, see CHARACTERISTICS AND DATA in the "AXLES" section;
- ☐ screw the plug down to the prescribed torque.



Use no chlorothene based solvents to clean the cover.

Figure 48



For the wheel hub with the cover illustrated in the figure, proceed as follows:

- ☐ remove the plug (1) and draw up the oil with a suitable string;
- ☐ fill the wheel hub with new oil (for the quantity and type of oil, see CHARACTERISTICS AND DATA in the "AXLES" section).

The oil level is checked through the window in the plug (1) with max. and min. on the cover in a horizontal position.

11. Check steering box fixing and mounting






Check that the fastenings of the steering box and mounting are tightened to the required torque.



10. Check headlight adjustment

Figure 49



- ☐ Set the vehicle unladen with its tyres at the required pressure on level ground facing a light wall.
- ☐ Mark two crosses on the wall corresponding to the centres of the two headlights.
- ☐ Turn the switch onto 0.
- ☐ Set the vehicle at 10 metres and turn on the low beam. The distance between the crosses and the points P, which correspond to the angle of the headlights, has to be 12.5 cm.

1. Light beam adjustment screw in horizontal direction.
2. Light beam adjustment screw in vertical direction.

- **General chassis greasing**
- **Manoeuvring**
- **Road test**


M2 SERVICE



The M2 service includes M1 operations without 1-3. "Check control belt conditions". Add also the following operations.

17. Change gearbox oil (ZF 16 S 181/221 gearbox)


Figure 50



- ☐ With the gearbox warm, take off the plug(s) (1) and drain the oil into a specific container.
- ☐ The oil should be drained off taking care not to soil the cross member beneath as it is near the outlet on some types of gearbox.
- ☐ It is therefore wise to use a tool to convey the oil away.
- ☐ Pour in fresh oil through the hole closed by the plug (2) (for the quantity, see under the FLUIDS heading of the GENERAL section).
- ☐ Tighten the plugs to the required torque.

(ZF 12 AS 230I / 16 AS 260I gearbox)


Figure 51



- ☐ With the gearbox warm, take off the plug(s) (1) and drain the oil into a specific container.
- ☐ The oil should be drained off taking care not to soil the cross member beneath as it is near the outlet on some types of gearbox.


17. Change oil and filter of ZF 16 S 181/221 gearbox + Intarder

Figure 52



- ☐ With the gearbox warm, take off the plugs (1) and drain the oil into a specific container.


Figure 53



Remove the oil filter as follows:

- ☐ unscrew the screw (5) fixing the filter;
- ☐ take off the cover and filter (1);
- ☐ remove the cover from the filter and replace it. Take care not to lose the magnetic pad (4) on the outer edge of the filter, as it has to be repositioned on the new filter;
- ☐ check the state of the o-ring (2) and replace it, if necessary;
- ☐ grease the o-ring (3) inserted in the assembly opening of the new filter;
- ☐ couple the new filter with its cover and insert it into its seat as far as it will go. Secure the screw (5).

Figure 54




72572

- ☐ Screw the plugs back on and tighten them to the required torque.
- ☐ Pour in fresh oil through the hole closed by the plug (7) until oil comes out of the hole of plug (6) and screw the plugs back on to the required torque. (The filling quantity is given under the FLUIDS heading of the GENERAL section.)
- ☐ Clean the gearbox oil vapour breather.

Change oil and filter of ZF Eurotronic Automated gearbox with Intarder

Figure 55



72573


- ☐ With the gearbox warm, take off the plugs (1) and drain the oil into a specific container.
- ☐ Remove the Intarder filter following the procedure described in the above paragraph.
- ☐ Screw the plugs (1) back on and tighten them to the required torque. Pour in fresh oil through the hole of plug (3) until oil comes out of the hole of plug (2). (See the FLUIDS table in the GENERAL section.)
- ☐ Screw the plugs back on to the required torque.
- ☐ Clean the gearbox oil vapour breather.



Have a short test run on the roads (at least one minute at least 10 km/h), briefly operating the Intarder just once (level 6) and then disengage it (level 0). At the end of the test, stop the vehicle without operating the Intarder. Stop the engine, check the level again (plug 2) and top up, if necessary.

21. Change variable geometry turbocharger (VGT) valve air filter

Figure 56




72577

Using a suitable tool, unscrew the filter (1) and replace it. Before fitting the new cartridge, moisten the seal with diesel or engine oil. Screw it on by hand until it is in contact with the mounting and then tighten by 3/4 of a turn to the required tightening torque.

1.3. Change miscellaneous drive belts

Figure 57



72586


ASSEMBLY DIAGRAM OF BELTS FOR FAN – WATER PUMP – ALTERNATOR AND AIR-CONDITIONER COMPRESSOR

- 1. Alternator – 2. Fan – 3. Water pump – 4. Crankshaft
- 5. Air-conditioner compressor automatic tensioner
- 6. Air-conditioner compressor – 7. Compressor drive belt
- 8. Drive belt automatic tensioner – 9. Drive belt

To remove and refit the belts (7-9) you need to apply suitable tools to the tensioners (5-8) in the direction shown by the arrows.




The tensioners are automatic, so there should be no further adjustment after assembly.

EXTRA PLAN MAINTENANCE**EPI SERVICE****23. Change fuel filter****Figure 58**

Remove the fuel filter (1) with tool 99360314. Before refitting the new cartridge, moisten the seal with diesel or engine oil.

Screw the new one on by hand, taking care to check that the rubber seal and the mating surface are clean and in a perfect state of repair. Screw the cartridge on by hand until it is in contact with the mounting and then tighten by 3/4 of a turn to the required tightening torque.

Bleed the air from the supply system as described in the following paragraph.

Bleeding air from the fuel circuit**Figure 59**

- Open the bleed screws, connecting them with tubes to run off the bled fluid into suitable containers to prevent dirtiness:

- 1 = located on the pre-filter mount (on the chassis frame);
- 3 = located on the filter mount (on the engine);
- 4 = located on the front of the cylinder head.

- Work the hand pump (2) on the pre-filter till you see fuel with no air in it coming out of the bleed screw (1) (retighten the screw when the operation is over). Keep on pumping until you see fuel with no air in it come out of the bleed screw (3) on the filter as well (then retighten the screw) and from the screw (4) on the front of the cylinder head (retighten the screw when the operation is over) and tighten them to the required torque.


The circuit has now been bled. Start up the engine and run it for a few minutes at idling speed to get rid of all remaining air.



Never let the fuel soil the drive belt: alternator, pump, water, etc.

EP2 SERVICE**22. Check valve clearance and adjust if necessary**

To carry out these operations correctly, refer to the procedures described in the relative chapter of the "ENGINE" section.


EP3 SERVICE**15. Change rear axle oil****Figure 60**

The lubricating oil has to be drained with the oil warm. Place a container under the plug (1), remove the plug and drain off the oil.

Fit the plug (1) back on, remove the plug (2) and pour the required grade and quantity of lubricating oil in through the hole. Remove the oil vapour bleed and clean it thoroughly.

16. Change intermediate axle oil filter (6x4 vehicles)

Figure 61



Using tool 99360314, remove the oil filter (I) from the differential of the intermediate axle.


Before fitting the new oil filter on, moisten the seal with lubricating oil.

Screw the filter on by hand until it is in contact with the mounting and then tighten it by 3/4 of a turn.

T1 SERVICE

- Check pollen filters

Figure 62



Every six months

Check the state of clogging of the pollen filter (I).

It is reached by lifting the front radiator cowling and unscrewing the six supporting screws.



Excessive clogging of the pollen filters can cause a reduction in the flow rate of air into the cab and therefore less ventilation.

This will be highlighted especially by a significant reduction in the efficiency of the windscreen defrosting function.


6. Wash radiator grille

Lift the cab radiator cowling and carefully clean the radiator grille.

T2 SERVICE

4. Check percentage of antifreeze in the engine coolant

Figure 63



The plug (I) must never be taken out for any reason whatsoever.

With the engine warm, the cooling system is in overpressure, therefore take care when taking off the cap (2).

Take off the cap (2) and draw off a sample of the coolant from the expansion tank (3) with the densimeter 99395858.

Depending on the temperature of the liquid, check the percentage of antifreeze in the liquid on the scale of the instrument. The percentage has to be higher than 40% and must not exceed 50%.


If necessary, restore the percentage of antifreeze, bearing in mind that the liquid needs to be replaced every 2 years.



For vehicles fitted with an additional heater, the percentage of antifreeze must never exceed 50%.


T3 SERVICE**7. Change engine coolant**

Carry out the procedure described under the relevant subheading of the "ENGINE" section.

24. Renewal of the blow-by filter**Figure 64**


72563

To renew the blow-by filter, remove the screws and the cover, withdraw the filter (3) along with its gaskets. Carefully clean the seating of the filter and the cover. Fit a new filter with new gaskets. Refit the cover and tighten the fixing screws (2) to the prescribed torque. The filter only operates in one flow direction and therefore must be installed with the reinforcing bars visible as shown in the figure.

13. Change the cartridge of the dry air filter and clean its container**Figure 65**

72590


- ☐ Unhook the clamps (1) (or, depending on the version, unscrew the nut) and take off the bottom cover (2).

Figure 66

72591

- ☐ Unscrew the nut (4) and take out the cartridge of the filter (3).


Before fitting the new cartridge, clean its housing thoroughly.

T4 SERVICE**5. Changing the clutch fluid and bleeding the hydraulic clutch control system (versions with ZF 16S 181/221 gearbox only)****Figure 67**

Drain off the clutch control fluid and change it (see Fluids table in GENERAL section).




The clutch fluid is poisonous and corrosive: if you accidentally come into contact with it, wash immediately with water and a neutral soap.

Figure 68

After changing the fluid, bleed the hydraulic clutch control system.

Use the air bleeding tool 99306010 as follows:

- ☐ charge reservoir (5) with compressed air;
- ☐ fill reservoir (4) with Tutela TRUCK DOT SPECIAL fluid
- ☐ replace the cap (⇒) of the clutch fluid reservoir with one of the caps supplied with the tool 99306010 and connect the pipe to the cap.

Figure 69

- ☐ Attach a plastic tube to the bleed screw (2) on the slave cylinder (1) and immerse the opposite end of the tube in a container containing Tutela TRUCK DOT SPECIAL fluid, unscrew the bleed screw (1) by one full turn, open the valve (2) (see Figure 52) until a pressure reading of 1 to 1.2 bar is obtained on the pressure gauge (3);
- ☐ when the clutch fluid flowing through the tube is uniform and free of air bubbles, close the bleed screw and discharge the air from the reservoir (5) through valve (6).



Whenever the clutch fluid is changed, it will also be necessary to bleed the clutch master cylinder by loosening the fitting (1, Figure 68) before bleeding the clutch servo.

STRALIS AT/AD

REPAIR MANUAL

ELECTRIC/ELECTRONIC SYSTEM

IVECO

This publication describes the characteristics, the data, the correct methodology of the repairs that can be made on each individual component of the vehicle.

By complying with the instructions supplied and using the specific tools it is possible to perform any repair intervention correctly, within the specified time frames, while protecting the technicians against incidents.

Before starting any repair work, make sure that all accident prevention devices are ready at hand.

Check and wear the protective personal equipment provided for by the safety standards: goggles, helmet, gloves, shoes.

Check the efficiency of all processing, lifting and transport tools before using them.

The data contained in this publication might fail to reflect the latest changes which the Manufacturer may introduce at any time, for technical or sales purposes, or to meet the requirements of local legislation.

Copy, even partial, of text and drawings is forbidden.

Publication Edited by:
IVECO S.p.A.
T.C.O. - B.U. Customer Service
Lungo Stura Lazio, 15/19
10156 Torino (Italy)

Printed **603.93.191** - 1st Ed. 2003

Produced by:



B.U. TECHNICAL PUBLISHING
C.so Svizzera, 185
10149 Torino (Italy)

STRALIS AT/AD

Print 603.93.191 – 1st edition
Base – January 2003

UPDATE DATA

Chapter	Description	Page	Revision date

GENERAL LIST OF CONTENTS

CHAPTER

INTRODUCTION

GENERAL

I

COMPONENTS

II

ELECTRONIC SYSTEMS

III

DIAGNOSIS

IV

CIRCUIT CHARTS

V

BLOCK DIAGRAMS

VI

Introduction

	Page
GENERAL WARNINGS FOR ELECTRICAL/ . . . ELECTRONIC COMPONENTS	3
COMPONENT CODE	5
VARIATIONS WITH RESPECT TO STRALIS “AS”	10

General warnings for electrical/electronic components



Do not ever disconnect the batteries from the system with the engine running.

Do not start the engine without first having connected the batteries in a permanent manner.

- Before working on the vehicle, immobilise the wheels with chocks.
- Do not use fast chargers to start the engine. Engine starting can be performed either by means of separate batteries or by means of a special truck.
- Incorrect polarisation of the power supply voltage for the electronic control units (e.g. erroneous battery polarisation) may damage the components irreversibly.
- If you have to disconnect the batteries from the system, always disconnect the frame ground cable from the negative terminal of the batteries first.
- Before connecting the batteries to the system, make sure that the system is suitably insulated.
- Disconnect the batteries from the system before recharging them by means of an external unit.
- Disconnect the external recharging unit from the power mains before removing the unit's pliers from the battery terminals.
- At temperatures of over 80 °C (drier ovens), take down the ECU's.
- At the connection stage, tighten the flanged nuts of the connectors (temperature and pressure sensors, etc.) to the required torque. Check the exact polarity of the battery terminals when starting the engine by means of the auxiliary truck.
- Before working on the vehicle's electrical/electronic system disconnect the positive pole of the battery.
- Before disconnecting the connector from an electronic control unit, isolate the system.
- Do not cause sparks to check whether a circuit is live.
- Do not use a test bulb to check the continuity of a circuit. Only use the appropriate testing devices.
- Do not directly power the components associated with electronic control units with the nominal power rating of the vehicle.
- Make sure that the wirings of electronic devices (length, type of cable, location, grouping, connection of screen braiding, earthing, etc.) conform with the IVECO system and that they are carefully restored after repair or maintenance work. To avoid the possible malfunctioning of the electronic systems on board, the wirings of additional devices must follow a different path than that of the above-mentioned systems.
- Do not connect the negative terminals of additional systems to the negative terminals of electronic systems.
- In the event of electric welding on the vehicle, disconnect all the electronic control units and/or disconnect the power cable from the battery positive terminal and connect it to the frame earth.
- Connectors are viewed from the cable side.



Key storage procedures are affected by electromagnetic disturbances such as cell phones and the like.

Therefore, during key memorization:

1. Ensure there are no sources of disturbance in the cab or close to the keys.
2. Keys not inserted in the panel must be at a distance of at least 1 meter.




When working on electronic control units, plug connections and electrical connections to the components, measurements can be made only on suitable testing lines, by means of special plugs and plug-type bushes. Do not under any circumstances make use of improper devices such as metal wires, screwdrivers, clips and the like. In addition to the risk of causing a short circuit, this might damage plug-type connections and this would then give rise to contact problems.

Practical tips


The negative leads connected to a system grounding point must be as short as possible and connected to one another in "star" configuration; make sure that they are tightened in an orderly and adequate manner (Fig. 1, ref. M).

Furthermore, for electronic components, the instructions to be followed very carefully are:

- ECU's must be connected to the system ground if they are provided with a case.
- ECU negative cables must be connected both to a system grounding point, such as for instance the dash compartment ground (with no "serial" or "chain" connections) and to the negative terminal(s) of the battery/batteries.
- Even though they are not connected to the system ground/battery negative terminals, analogue ground elements (sensors) must have excellent insulation. As a result, special care must be devoted to the eddy resistances of the cable terminals: oxidation, seam-folding defects, etc.
- The metal braid of shielded circuits must be in electrical contact at either end with system components.
- Only one end of the shielding braid must be connected to the system ground.
- In the presence of jointing connectors, the non-shielded portion, **d**, must be as short as possible in the proximity of the connectors (Fig. 2).
- The cables must be arranged so as to run parallel to the reference plane, i.e., as close as possible to the frame/body structure.
- Additional electromechanical systems must be connected with the greatest care to the system ground and must not be placed alongside the cables of electronic components.



1 "STAR" CONNECTIONS OF NEGATIVE CABLES TO THE SYSTEM GROUND M



2 SHIELDING BY MEANS OF A METAL BRAID OF A CABLE LEADING TO AN ELECTRONIC COMPONENT - C. CONNECTOR - d. DISTANCE → 0.

Component Code

03000	Self-rectifying alternator with built in voltage regulator
08000	Starter Motor
12015	Motor for outside air intake door
12023	Window shade motor
12032	Cab hydraulic release pump motor
20000	Starter battery
22000	Horn
25200	Relay for starter
25201	Relay, preheating
25202	Relay, G.C.R. energizing
25203	Relay, G.C.R. opening
25204	Relay, remote starting enablement, cab unlatched
25205	Relay, engine stopping
25206	Relay, rich mixture control
25207	Relay, alternator D+ earthing
25208	Relay, remote start enablement, gear engaged
25209	Relay for cutting off various components during starting stage
25210	Relay, starting enablement with transmission in neutral
25211	Relay with delayed opening contact for keeping G.C.R. energized
25212	Relay with delayed closing contact for keeping RTE energized
25213	Relay for supply of users connected to ignition switch through battery positive
25222	Relay for allowing connection of thermal starter
25310	Relay for allowing connection of internal heating with power load inhibiting relay
25322	Relay for connection of auxiliary heater (1st speed)
25327	Relay for connection of air-conditioning system
25332	Relay for connection of air-conditioning system
25544	Topflap engine polarity reverse contactor for LD
25545	Topflap open/close comand contactor for LD
25722	Cab hydraulic release pump switch (lowering)
25723	Cab hydraulic release pump switch (raising)
25866	Relay for terminal 58
25874	Relay for connection of power loads with engine running
25897	Relay for connection of side transmission power takeoff
25898	Relay for connection of rear transmission power takeoff
25900	General current relay
25924	EDC connecting relay "Main Relay"
30001	Dipped and main beam headlamp with side light
30011	Fog light
32002	Front direction indicator
33001	Side direction indicator
34000	Multifunctional rear light
34011	Trailer light
35000	Number plate light
37000	Front/rear dimensions light
37001	Front dimensions light
39003	Courtesy light for steps
39009	Courtesy light for reading lights
39017	Courtesy light for adjustable cabin interior light
39030	Cab side opening lighting lamp
39034	White and red internal light unit
40011	Electronic Tachograph

40032	Sender unit for tachometer and tachograph
40046	Inductive type chassis height sensor (rear axle)
40047	Inductive type chassis height sensor (front axle)
42030	Sender unit for engine oil pressure gauge
42045	Sender unit for outdoor temperature gauge
42102	Switch signalling handbrake applied
42108	Switch for trailer retarder signal
42111	Switch signalling trailer braking system failure
42116	Switch for low air pressure indicator in EBS system
42200	Switch signalling pneumatic suspension system failure
42351	Switch signalling air filter blocked
42374	EDC clutch switch
42381/A	Drive axle RH pressure sensor (ECAS)
42382/a	Lift axle RH pressure sensor (ECAS)
42389	Air pressure sensor on third axle pneumatic lifting system
42551	Switch signalling oil filter blocked
42608	Coolant pressure signalling 3-switch assembly
42700	Fuel filter clogged indicator switch
44031	Fuel level gauge sender unit with reserver warning light contact
44035	Insufficient windscreen washer fluid level gauge control
44036	Insufficient radiator coolant level gauge control
44037	Insufficient power assisted steering fluid level gauge control
44043	Engine oil level gauge sender unit
47032	Sender unit for engine oil temperature thermometer
47041	Water temperature sender for retarder control unit
47042	Fuel temperature sensor
47043	Engine fan temperature sensor
48035	Engine rpm sensor
48042	Engine rpm sensor (on timing gear)
48043	Turbocharger speed sensor
50005	Multiplex instruments unit module
52005	Switch with built in w/l for heated rear view mirrors
52009	Switch with built in w/l for trailer light
52024	Switch with built in w/l for additional headlamps
52056	Switch with built-in w/lamp for ASR cutout
52059	Automatic transmission speed selector
52070	Switch for engaging side power takeoff
52071	Switch for engaging rear power takeoff
52090	Suspension levelling switch (ECAS)
52092	Switch for engine or cab heater
52093	Switch for tail hatch locking safety
52093	Switch for tail hatch locking safety
52094	Switch for spot light
52200	Switch for electric or pneumatic horns
52302	Switch with built in w/l for hazard warning lights
52304	Switch for fog lights and rear fog lights inhibitor
52307	Switch for exterior lights
52312	Switch controlling headlamp alignment adjustment
52324	Engine brake connecting switch
52326	White and red internal lights switch
52502	Ignition switch for services with starting
53006	Switch for starting from engine compartment
53007	Switch for stopping engine from engine compartment

53030	Switch for controlling starting assistance
53061	Cab hydraulic release consensus switch
53062	Cab hydraulic release pump switch (lowering)
53063	Cab hydraulic release pump switch (raising)
53300	Switch for driver's side electric window
53302	Switch for passenger side electric window
53053	Test pushbutton coupling, automatic transmission
53054	Limit switch button on side doors
53055	Unstable switch for interior lights
53306	Switch controlling sun roof motor
53309	Switch for 3rd axle raising system
53311	Switch for controlling window blind
53315	Switch with built in telltale to turn on foglights
53316	Current general contactor switch
53501	Switch signalling vehicle stopped
53503	Switch signalling reversing lights
53507	Switch signalling reduced gears engaged
53508	Switch for antistarting with reduced gears
53509	Switch for switching on interior lights
53510	Switch for switching on step lights
53511	Switch signalling cabin unlatched
53512	Switch for antistarting engine device with handbrake off
53521	Switch for signalling longitudinal differential lock
53547	Switch for secondary signal from brake pedal to EDC control unit
53567	Switch for signalling side power takeoff engaged
53568	Switch for signalling rear power takeoff engaged
53591	Switch for signalling failure of the hydraulic circuit with auxiliary steering third axle
53593	Switch to light cab side opening lamp
53593	Tool compartment light switch
53602	Switch indicating incomplete sunshade closing
53801	Switch signalling Rockwell axle differential lock engaged
53802	Switch signalling Rockwell axle differential lock engaged (3rd axle)
54030	4 function steering column switch unit
54033	6 function steering column switch unit
61011	3A 1-diode holder container
61104	Air braking system drier resistor
61121	Resistance for engine preheating
61126	Termination resistor for CAN bus
64000	Electric windscreen washer pump
68000	Radio equipment
68001	Speaker
68003	Preamplifier
68005	Feeder 24 V 12 V
68007	City Band (C.B.)
70000	6 fuse carrier
70058	1-way 20A fuse carrier
70601	6-fuse holder
70602	6-fuse holder
70603	6-fuse holder
70604	6-fuse holder
70605	6-fuse holder
72006	Coupling with 7 poles for electrical connection of trailer ABS
72010	15-pole coupling for electrical connection to trailer
72021	30-pole connector for the electrical connection to the diagnostic equipment located outside the vehicle
72025	2-pole 12 V connection for general power supply

72026	2-pole 12 V connection for telephone
78016	Engine fan solenoid valve
78050	Engine brake solenoid valve
78052	ABS/EBS solenoid valve
78053	ASR solenoid valve
78054	Solenoid valve for engaging retarder
78055	Solenoid valve for retarder oil accumulator
78057	EBS front axle air pressure control proportional valve
78058	EBS trailer air pressure control proportional valve
78059	Duplex valve for EBS
78060	Solenoid valve to exclude third-axle braking with ASR
78061	Redundant solenoid valve for rear-axle braking in the event of EBS control unit failure
78203	Solenoid valve for pneumatic horns
78227	Solenoid valve for radiator water recirculation
78238	Rear axle solenoid valve assembly for chassis alignment
78239	Front axle solenoid valve assembly for chassis alignment
78243	Rear axle electropneumatic distributor
78247	Solenoid valve for electronic injection
78248	Solenoid valve for variable geometry turbine order
72049	3-pole coupling for rear-view mirror motor
72050	Unipolar current outlet
78251	Solenoid valve for engaging transmission side power takeoff
78252	Solenoid valve for engaging transmission rear power takeoff
80000	Motor for right electric window
80001	Motor for left electric window
82000	Windscreen defrosting control unit
82005	Auxiliary air heater
82010	Air-conditioning system electronic control unit
84000	Water boiler
84009	Internal temperature sensor
84010	Metering device
84019	Electromagnetic pulley
85000	Cigar lighter
85001	
85003	Heated rearview mirror (trailer)
85004	Heated rearview mirror (wheel)
85005	Heated rearview mirror
85006	Electrically adjustable heated rear view mirror
85007	Wheel electrically adjustable heated rear view mirror
85008	Trailer electrically adjustable heated rear view mirror
85010	Rear view mirror control
85023	Electric latch
85065	Remote control for aligning suspensions and raising 3rd axle
85150	EDC MS6 control unit
85152	Accelerator load sensor (EDC)
85153	Coolant temperature sensor (EDC)
85154	Turbofan air temperature sensor (EDC)
85155	Turbofan air temperature sensor (EDC)
85158	Turbofan air temperature sensor (EDC)
85159	Temperature and ambient air pressure sensor for E.D.C.
86002	Sensors for front brake shoe wear
86003	Sensors for rear brake shoe wear
86004	Automatic transmission electronic control unit
86013	Sensor for signalling water in fuel filter
86015	Retarder electronic control unit
86023	Vehicle raising/lowering control unit Ecas
86030	Sensor detecting heat irradiation

86053	Multiplex control and signal unit from bed positions
86116	Multiplex body computer control unit
86117	Multiplex front frame computer control unit
86118	Multiplex rear frame computer control unit
86119	Multiplex Driver Door Module Control Unit
86120	Multiplex Passenger Door Module Control Unit
86123	Multiplex control unit for interface with steering control shaft
86124	Cab with multiplex function electronic control unit
88000	ABS system electronic control unit
88001	ABS system sensor
88005	Electronic control unit for EBS system
88006	EBS rear axle air pressure control modulator
88007	Potentiometric sensor for front wheel shoe position indicator
88008	Potentiometric sensor for rear wheel shoe position indicator
88010	Rear axle brake application pressure sensor

VARIATIONS WITH RESPECT TO STRALIS "AS"

Stralis AT/AD is different from As model mainly due to the absence of the three units DDM, PDM, CM.

The only function that can be found on AT/AD models (previously managed by PDM and DDM) is rearview mirrors heating. Drive is given by switch 52005 (rearview mirrors heating connection) placed on central panel (on AS it was placed on panel in driver side door).

Electric windscreen washer pump drive and headlight washer pump connection functions on AT/AD are managed by FFC unit (same unit being present on AS) since CABIN MODULE being present on AS on AT/AD is optional. These functions go back under CM module competence when this latter one is present. The "insufficient windscreen washing liquid level indicator" signal is directly present on BODY COMPUTER.

The mechanical pump is used for cabin overturning, therefore all components related to electric pump are removed. For cabin disconnection signals, the two parallelly-connected switches 53511 are not present, while instead there is only one of them that is connected through connector ST31.

General current remote control switch TGC is optional, when it is not present it is replaced by general current switch IGC (52600). In this case there are two Main Relays (25924).

Two lighting lamps for cigarette compartment have been added.

On AT there are: tooling compartment light, control switch and BED MODULE unit (OPT, as an alternative the control panel on rear wall).

The two central spots have been replaced by a single central roof lamp, white and red lights are replaced by white side roof lamps.

Parking brake hand lever on AT/AD models has been moved next to central dashboard.

As a result of these changes, there are modifications also on instrument-holder dashboard and central dashboard.

General

	Page
GENERAL DESCRIPTION OF THE MULTIPLEX SYSTEM	3
POWER NETWORK	22
MASS POINTS	23
LIST OF ST JUNCTION CONNECTOR ON .. BOARD THE VEHICLE	27

GENERAL DESCRIPTION OF THE MULTIPLEX SYSTEM

Connection of all the various centers can be by grouping them together into one central unit, too complex a solution, or by creating a communications web capable of completing all necessary data transfers fast and reliably.


Fast data transfer is essential for managing vehicle operation and reliability must be guaranteed for applications tied to safety, transmission, brake, engine and electronic center control as there must be no transmission issue especially in the presence of electromagnetic influences.

Many issues involving a vehicle's electrical circuits have to do with connection technology and can be identified in connector contact corrosion or oxidization, cable connection, insulating sheath wear or faulty assembly.

Another cause could be sensor and actuator operating defects. Vehicle downtime is reduced when fewer cables are used, with consequent operating cost cutting.


Cabling with fewer components enables performing easier electronic system diagnosis.

Conventional control



The electrical system currently installed on the vehicle requires that each user item be controlled directly by its switch, which necessarily requires the presence of cables with several conductors that involve the risks mentioned above.

Multiplex control




Unlike the system mentioned above, each switch in this setup is connected to a unit. A different coded value for each switch is communicated to the CAN communication line Databus. The signal is decoded by a Demultiplexer unit, which supplies the power required to the user unit involved.

Different transmission classes exist, according to Databus data transmission speed, as follows:

- ☐ class A: low speed for vehicle lighting and windshield wiper motor control
- ☐ class B: medium speed for air conditioning and audio systems
- ☐ class C: high speed for ABS control systems and the like

The advantages of the Multiplex system can be summarized into lesser costs due to shorter cables, increased functionality, sensor sharing by part of the various systems and better on-board diagnostic functions, offset by greater costs versus a conventional system and more training required.



73681

All centers are connected via a Control Area Network CAN line. The MULTIPLEX structure is very flexible; centers can be removed or added without interrupting the operation of others.

If node 2 sends a message, interaxed node 3 accepts the message while node 1 ignores it. Units can share the information of several sensors.

IVECO Multiplex system structure

The Multiplex system used on this new vehicle range consists of a series of electronic centers connected to one another via CAN lines. The entire system can be divided into four different areas respectively dedicated to vehicle system control, such as ABS, EDC and the like, to basic electrical/electronic systems for lights, windshield wiper, electrically operated glasses and the like, information systems for the operator such as radio, telephone and the like, and to display and control of the entire Body Computer, Cluster and the like multiples system.


Vehicle systems		Basic systems	
EDC	= Engine Diesel Control	BC	= Body Computer
EBS	= Electronic Brake System	DDM	= Driver Door Module
ECAS	= Electronic Control Air Suspension	PDM	= Passenger Door Module (OPT)
INTARDER	= Retarder	FFC	= Front Frame Computer (OPT)
IMMOBILIZER		RFC	= Rear Frame Computer
REV COUNTER		BM	= Bed Module (OPT)
EUROTRONIC	= Transmission	CM	= Cabin Module (OPT)
BC	= Body Computer	CLIMATE	= Conditioner (OPT)
IC	= Instrument Cluster	HEATING	= Heater (OPT)
30-POLE	= Diagnosis connector		

Information systems		Control display	
RADIO		BC	= Body Computer
TELEPHONE		SWI	= Steering Wheel Interface
		IC	= Instrument Cluster

The CAN lines used to connect vehicle centers are dedicated cables enabling the exchange of large amounts of data among the various systems.

The Multiplex uses four: VDB, BCB, ICB, IDB.

VDB	Vehicle Data Bus	= CAN line for vehicle systems
BCB	Body Control Bus	= CAN line for basic system
ICB	Instrument Cluster Bus	= CAN line for display and control
IDB	Infotainment Data Bus	= CAN line for information

CAN lines

73652/A


A. Black/gray/green sheath - **B.** White/green twisted wires

The cables used for the various CAN lines in the vehicles are twisted, to eliminate electrical disturbances on the signals. Sheath are identified by different colors, as follows:

- ☐ BLACK VDB
- ☐ GRAY BCB
- ☐ GREEN ICB / IDB

CAN line efficiency tests

Measurements are required to test CAN line efficiency, to perform which connector J2 must be disconnected from the BODY COMPUTER and a multimeter inserted in the related pins.



- Pin 1 - 2 ICB line
- Pin 3 - 4 VDB line
- Pin 10 - 12 BCB line

Values to detect during measurements (VDB - BCB)

0 Ω	~ 60 Ω	~ 120 Ω	O.L.
0 CAN line in short circuit	CAN line OK	One resistor cut	CAN line cut

Values to detect during measurements (ICB)

0 Ω	~ 120 Ω	O.L.	O.L.
0 CAN line in short circuit	CAN line OK	Resistor cut	CAN line cut

“LIMP HOME” function

An emergency procedure called LIMP HOME guaranteeing the following functions is activated in case of CAN BCB line cutting:

Body Computer

- Front position and profile lights
- Switch lighting
- Instrument lighting
- +15 putouts
- Low speed wiper
- Windshield heating

DDM and PDM

Rearview mirror heating

FFC


- Left and right dipped headlights
- Left and right front direction indicators
- Fan control output
- +15 output

RFC

- Left and right rear position lights
- Left and right rear direction indicators
- Left and right rear trailer direction indicators
- +15 output


Vehicle Data Bus VDB communication line

Enables dialog between the various vehicle electronic systems and cab to be compared to the I0 CAN line. The centers connected to it are: EDC, Transmission, Intarder, EBS, Ecas, Immobilizer, Rev counter. This line also dialogs with the Cluster and the Body Computer.



73683

Interconnections between 30 poles and diagnosis system centers




73684

Features


- | | |
|--------------------------------------|---------|
| - Data transmission speed in BIT/SEC | 250,000 |
| - Number of ECUs connected | 3 ÷ 8 |
| - Cable colour | black |

Vehicle Data Bus "VDB" CAN linea



A. EDC center 6.2 - **B.** EuroTronic II - **C.** Rev counter - **D.** Instrument Cluster (IC) - **E.** Immobilizer - **F.** Body Computer - **H.** Intarder - **I.** ECAS - **L.** EBS - * Without EuroTronic - ** With EuroTronic

73755/A

“VDB” components on the vehicle

73995


Ref.	Description
1	Rev counter
2	Immobilizer
3	Cluster
4	30-pole diagnosis connector
5	Body Computer
6	VDI
7	EBS
8	Intarder
9	ECAS
10	EDC 6.2
11	Eurotronic / (Allison)

Body Control Bus BCB communication line

Enables communication among the various electronic systems on the vehicle. This line does not directly involve the centers on the VDB line but those for the various on-board services.


Technical features

- Data transmission speed in BIT/SEC 62,500
- Number of ECUs connected 6 ÷ 9
- Cable colour gray




50247

Body Control Bus "BCB" can line



A. Rear Frame Computer (RFC) - **B.** Front Frame Computer (FFC) - **C.** Water additional heater - **D.** Climate Control - **E.** Passenger Door Module (PDM) - **F.** Air additional heater - **G.** Bed Module (BM) - **H.** Cabin Module (CM) - **I.** Cab Module - **L.** Body Computer -
 *Without water additional heater - ** Without air additional heater

73757

“BCB” components on the vehicle

73990


Ref.	Description
1	Bed Modul
2	DDM
3	Conditioner
4	FFC
5	Body Computer
6	Cabin Module
7	PDM
8	Heater
9	RFC

Instruments Cluster Bus ICB communication line

Enable dialog between the center located on the steering column and the BODY COMPUTER, CLUSTER. All information from the steering wheel can thus reach user equipment.


Technical features

- Data transmission speed in BIT/SEC 250,000
- Number of ECUs connected 3 ÷ 7
- Cable colour green




50246

Instrument Cluster Bus “ICB” CAN line



A. Instrument Cluster (IC) - B. Steering Wheel Interface (SWI) - E. Body Computer

"ICB" components on the vehicle



73992


Ref.	Description
1	SWI center
2	Cluster
3	Body Computer

Infotainment Data Bus IDB communication line

Enables communication among the various accessory electronic systems on the vehicle. The radio, telephone and navigator send messages via the IDB that are displayed on the CLUSTER.


Technical features

- | | |
|--------------------------------------|---------|
| - Data transmission speed in BIT/SEC | 100,000 |
| - Number of ECUs connected | 2 ÷ 4 |
| - Cable colour | green |



50245

“IDB” components on the vehicle




73993

Ref.	Description
1	Radio
2	Cluster
3	Telephone
4	Monitor (navigator)

Example of data transmission

Multiplex function: left direction indicator on



50243

Actuating the direction indicator controls supplies a low level signal to the interface SWI center, which transfers it to the ICB communication line enabling communication between the CLUSTER and the BODY COMPUTER so the signal sent previously reaches these two components and enables switch on the direction indicator warning light on, located on the Cluster and sent via the Body Computer to another communication line, called BCB, to other two RFC and FFC centers enabling switching on the direction indicators. The RFC controls the rear left direction indicator and the FFC the front left one.

POWER NETWORK



Never disconnect the batteries from the system with the engine running.

When needing to disconnect the batteries from the system, always firstly disconnect the frame earth cable from the negative terminal of the batteries.

Before connecting the batteries to the system, make sure that the system is well insulated.

Disconnect the batteries from the system when charging them.

The purpose of the electric system is to generate, regulate, store and distribute the energy needed to make the vehicle components work.

For this reason the supply of the base electric system is ensured by a generator (28V - 60A -90A alternator) and two batteries, each with 12 V 110 Ah (143 Ah - 170 Ah) connected in series.

A mobile fuse holder containing a 20 Amp fuse is located close to the batteries. This fuse supplies:

- Fuse holder 70601/C
- Body Computer (J1-8)
- Cluster (B20)
- Tachograph (A1)
- Diagnosis connector (Pin 27)

This fuse is not present on the ADR version.

Power cable section:

- battery direct cable = 16 mm²
- fuse cables = 4 mm²


Attain to what detected on the vehicle for the remaining sections.

Negative network

The batteries are connected to the frame earth with a brown 70 mm² cable, at earth point M1 on the left sidemember (Fig. II.3).


The starter motor is connected to the frame earth (M2) through a 70 mm² cable, fastened on the right sidemember, near the actual motor. The same cable serves for connecting the whole engine unit to the frame earth.

The same electric, negative equipotentiality of the chassis is made available to the vehicle cab by means of a stranded wire connected to the cab front and the front right side member.




6633

II.3 EARTH POINT OF BATTERIES ON LEFT SIDEMEMBER



6632

II.4 STARTER MOTOR AND ENGINE EARTH POINT

MASS POINTS

73685

M1. Battery mass - **M2.** Starter motor mass - **M3.** Upper cab mass - **M4.** Right inner cab mass - **M5.** Left inner cab mass - **M6.** Front right frame mass - **M7.** Engine mass - **T1 - T2.** Equipotential braid


Electrical equipotential braid

Though generally protected against the influence of on-board equipment voltage, electronic components nevertheless remain particularly sensitive electromagnetic compatibility issues, of different nature such as:


- generated by the vehicles
- external.

A suitable size flexible electrolytic copper braid has been provided on the vehicles to minimize these phenomena and return main cab and frame structures to the equipotential state.

Check that the braid is properly attached to the frame and the cab, in the event of defective cab grounding.




74201



49846

M6


MASS POINT ON THE LEFT FRONT FRAME



49844


T2

MASS POINT ON THE RIGHT FRONT FRAME



49849

MASS POINT BEHIND THE BODY COMPUTER




73754

MASS POINT BEHIND THE CLUSTER


LIST OF ST JUNCTION CONNECTOR ON BOARD THE VEHICLE

ST01	Start switch
ST02	SWI center
ST05	+15 (Body Computer)
ST13	Bed Module
ST31	Reading light/tool box light/refrigerator
ST08	DDM center
ST09	PDM center
ST14	Cluster/Cab Module/Cruise Control (internal) Body Comp
ST30	TGC
ST36	TGC
ST06	Rev counter
ST07	Sunshield/Cab Module/ceiling light
ST15	Radio speakers/ceiling light/sliding roof
ST4011	VDI
ST10	(Equippers) Positive (58)
ST25/26/27	Intarder/ECAS/EBS (CAN line)
ST20/19	Conditioner
ST79 (6 ways)	EDC brake secondary switch/(only for ABS) EDC clutch switch
ST79 (12 ways)	Wiper outside temperature transmitter/coolant pressure switches/radiator water circulation E.V
ST79 (1 way)	Horn
ST56	15 alternator
ST63	BCB Line
ST11	VDB Line
ST52	RSU
ST53	15 for equippers (FFC)
ST50	Left front light positive
ST73	Front brake pad wear warning
ST52	Positives for equippers
ST80	Backup ignition switch/anti-start switch with gear selected/downshifted gears on warning switch
ST72	35 axle brake wear/transversal differential lock
ST71	35 axle brake pad wear
ST90	Side PDF on warning switch/rear PDF on warning switch
ST77	SIDE MARKER LAMP
ST78	SIDE MARKER LAMP
ST82	Engine oil temperature thermometer – engine oil pressure sensor – engine fan temperature sensor - oil level – clogged oil filter – fuel filter
ST87	Windscreen washer electric pump - Headlights washer pump


Connectors location

84587


ST 02 Steering Wheel Interface ISW connection

Ref.	Function	Connector view	Cable colour code
1	CAN L (ICB) line	 77796	GREEN
2	CAN H (ICB) line		WHITE
3	Mass		0000
4	Negative for horn		1116
5	Negative from I5 - ST I/2 key switch		0987
6	Direction indicator ideogram lighting positive		4442
7	+30 positive		7906
8	Negative from 50 - ST I/3 key switch		0900
9	Free		


ST 06 Tachograph connection

Ref.	Function	Connector view	Cable colour code
1	Tachograph transmitter insulated negative	 77797	0058
2	Tachograph transmitter speed signal		5517
3	Tachograph transmitter inverted signal		5516
4	Tachograph transmitter power supply		5514
5	EDC speed impulse		5155
6	CAN VDB (H) line		WHITE
7	CAN VDB (L) line		GREEN
8	Cluster signal		5540
9	Accelerator pedal sensor (idling switch)		0158
10	+15 tachograph power supply		8871
11	Ideogram lighting		4442
12	+30 tachograph power supply after 70058 fuse		7768
13	K line		2997
14	Cluster signal		5518
15	Mass		0066


ST 07 Junction connection

Ref.	Function	Connector view	Cable colour code
1	Front overall dimension light positive		3339
2	Voltage reduction positive		7772
3	Preamplifier sound speaker signal		1183
4	Preamplifier sound speaker signal		1184
5	12 V reading light positive		4412
6	12 Volt positive		7712
7	White ceiling light positive		4423
8	Step lighting positive		4445
9	Blue ceiling light positive		4410
10	Red ceiling light positive		4422
11	Sunshield negative		0974
12	Sunshield closed signal		8065
13	Sunshield motor positive		8063
14	Sunshield motor positive		8064
15	-		-


ST 08 Driver Door Module DDM centre connection

Ref.	Function	Connector view	Cable colour code
1	Centre power supply positive		7991
2	Module recognition mass		0000
3	Pavilion sound speaker signal		1188
4	Pavilion sound speaker signal		1186
5	K line for diagnosis		2991
6	CAN H (BCB) line		WHITE
7	CAN L (BCB) line		GREEN
8	Centralised closing feedback		0064
9	Centralised closing lock		0065


ST 14 Fitter connection

Ref.	Function	Connector view	Cable colour code
1	53006 engine start push button signal predisposition		8892
2	Engine stop push button signal predisposition		0151
3	Cabin Module Pin J2-6 predisposition		1165
4	Cabin Module Pin J2-12 predisposition		5515
5	Cabin Module Pin J2-5 predisposition		6656
6	Pin A-8 cluster		5543
7	Pin A-20 cluster		5541
8	0 V engine off output/24 V engine running condition signal		7778
9	Idling transmission signal		8050
10	Backup signal		2268
11	Power supply positive (under key)		8871
12	Cruise Control predisposition		8156
13	Cruise Control predisposition		8157
14	Cruise Control predisposition		8154
15	Cruise Control predisposition		8155
16	Cruise Control predisposition		0152
17	Mass		0000
18	P.T.O. I control signal predisposition		0132
19	Negative from Economy Power switch		0166
20	P.T.O. I control signal predisposition		0131
21	Positive from battery (after TGC)		7772


ST 15 Sound speaker – Ceiling lights – Sunroof

Ref.	Function	Connector view	Cable colour code
1	Mass		0000
2	Sunroof closing positive		7011
3	Sunroof opening positive		7010
4	Reading light positive		4412
5	White ceiling light positive		4423
6	Red ceiling light positive		4422
7	-		-
8	Left sound speaker		1186
9	Left sound speaker		1188
10	Right sound speaker		1183
11	Right sound speaker		1184
12	-		-


ST 19 Conditioner – Heater

Ref.	Function	Connector view	Cable colour code
1	K line		2295
2	Ideogram lighting positive		4442
3	With ST 20 - 3		0506
4	With ST 20 - 4		8087
5	1st speed remote control switch supplementary heater on positive		8884
6	Engine coolant recirculation heater remote control switch positive		7778
7	Positive under key		8871
8	-		-
9	Mass		0000
10	Supplementary heater on negative		0501
11	Positive with engine running		7786
12	-		-

ST 20 Conditioner


Ref.	Function	Connector view	Cable colour code
1	K line		2296
2	Instrument lighting positive		4442
3	With ST 19 - 3		0506
4	With ST 19 - 4		8087
5	1st speed remote control switch heater on positive		8884
6	Compressor on remote control switch signal from pressure switches		9933
7	Compressor on remote control switch signal from centre		9933
8	Positive with engine running		7778
9	Mass		0000
10	Compressor control positive		9993
11	Positive under key		8871
12	Positive after TGC		7551
13	Positive after TGC		7550
14	Positive under key		8891
15	Radiator coolant recirculation electro valve negative from centre		9552
16	Radiator coolant recirculation electro valve positive		7550
17	-		-
18	-		-

ST 25 Intarder




77805

ST 27 Ecas



77806


ST 26 EBS




77807

Ref.	Function	Cable colour code
1	CAN VDB (L) line	GREEN
2	CAN VDB (H) line	WHITE
3	ST 25 Cluster (A-I8)	554I
4	ST 27 K line	2294
5	ST 26 K line	2299


ST 35 Automatic conditioner connection

Ref.	Function	Connector view	Cable colour code
1	CAN "BCB" (H) line		WHITE
2	CAN "BCB" (L) line		GREEN
3	K line		2296
4	Positive after TGC		7551
5	-		-
6	Heater unit electro fan positive		7551
7	-		-
8	-		-
9	Mass		0000
10	-		-
11	-		-
12	-		-
13	-		-
14	-		-
15	-		-


ST 35/I Manual conditioner connection

Ref.	Function	Connector view	Cable colour code
1	-		-
2	-		-
3	-		-
4	-		-
5	-		-
6	-		-
7	-		-
8	Environment thermostat signal		9993
9	Conditioner on remote control switch negative		0555
10	Ideogram lighting positive		4442
11	Internal heating consent from remote control switch positive		8004
12	Conditioner on remote control switch positive		8097
13	-		-
14	Top flap remote control switch positive		8801
15	-		-


ST 40 VDI connection

Ref.	Function	Connector view	Cable colour code
40/1	1 Pin 12 diagnosis connector K line		2262
	2 Mass		0000
	3 -		-
	4 Positive after TGC		7797
	5 CAN "VDB" (H) line		WHITE
	6 CAN "VDB" (L) line		GREEN
40/2	1 -		2202
	2 CAN "VDB" (H) line		WHITE
	3 CAN "VDB" (L) line		GREEN
	4 -		1102
	5 Mass		0000
	6 -		-


ST 79/I EDC brake secondary switch connection (only ABS)

Ref.	Function	Connector view	Cable colour code
1	EDC main relay on remote control switch positive		7155
2	Stop light positive		8158
3	Pedal pressed warning positive		8153
4	Positive from EDC main relay on remote control switch		7155
5	-		-
6	-		-


ST 79/3 External temperature transmitter/windshield wiper/coolant pressure switch group/radiator water recirculation E.V./EDC clutch switch connection

Ref.	Function	Connector view	Cable colour code
1	Mass		0000
2	Conditioner coolant pressure warning switch positive		9993
3	Positive from conditioner coolant pressure warning switch		9993
4	Radiator coolant recirculation pressure switch positive		7550
5	Positive to EDC clutch switch		7150
6	Positive from EDC clutch switch		8160
7	High speed windshield wiper unit positive		8881
8	Low speed windshield wiper unit positive		8882
9	Windshield wiper unit positive		8880
10	Windshield wiper unit positive		8873
11	Radiator coolant recirculation electro valve control		9552
12	Negative from engine coolant pressure warning switch		0583
13	Negative from engine coolant pressure warning switch		0582
14	Positive from external temperature sensor		7373
15	Negative from external temperature sensor		0550


ST 06/I User connection

Ref.	Function	Connector view	Cable colour code
1	Preamplifier left sound speaker positive		1188
2	Preamplifier left sound speaker negative		1186
3	Sunroof closing control power supply		7011
4	Sunroof opening control power supply		7010
5	Horn electro valve positive		1133
6	CAN (IDB) H line		WHITE
7	CAN (IDB) L		GREEN
8	Ideogram lighting positive		4442
9	Positive under key		8871
10	-		-
11	-		-
12	-		-


ST 09 PDM centre connection

Ref.	Function	Connector view	Cable colour code
1	Centre power supply positive	 78245	7990
2	Mass – bridge with J 1.8 - J 2.10 for passenger module recognition		0000
3	Right sound speaker positive		1184
4	Right sound speaker negative		1183
5	K line for diagnosis		2290
6	CAN H (BCB) line		WHITE
7	CAN L (BCB) line		GREEN
8	Centralised closing lock		0064
9	Centralised closing		0065

ST 30 ADR predisposition connection

Ref.	Function	Connector view	Cable colour code
1	A1 tachograph	 78246	7768
2	A5 tachograph		0066
3	Positive from battery after 70601/3 - 20A		7768
4	Mass		0000
5	Positive from battery after 20A fuse		7972
6	Positive from battery after 20A fuse		7972

ST 31 Service connection


Ref.	Function	Connector view	Cable colour code
1	Tool compartment lighting switch positive		4448
2	Reading ceiling light positive		4412
3	Mass		0000
4	Refrigerator mass		0000
5	24 V refrigerator positive		7735
6	Bed module power supply positive		7906
7	Mass		0000
8	CAN (H) BCB line		WHITE
9	CAN (L) BCB line		GREEN
10	12 V telephone connection positive		7712
11	Telephone connection mass		0000
12	-		-

Components

	Page
REMOTE CONTROL/FUSE HOLDER CENTER	3
SUPPLEMENTARY REMOTE SWITCHES	5
SUPPLEMENTARY FUSES	8
INSTRUMENT-HOLDER DASHBOARD	10
CENTRAL DASHBOARD CONTROLS	11
CONTROLS ON THE STEERING WHEEL	12
REARVIEW MIRRORS AND WINDOW REGULATOR CONTROL ADJUSTMENT	13
LIGHT CONTROL	14
DIAGNOSIS CONNECTOR	18
"VDI" ELECTRONIC CENTER	19
WALL PASS	20
ALTERNATOR	25
STARTER MOTOR	27

REMOTE CONTROL/FUSE HOLDER CENTER

Fuses



74001

Black color fuse holder (70601)

Position

- | | |
|---|--|
| 1 | - Clamp 15 for air conditioning/heated ore-filter |
| 2 | - Food heater + Fridge / IC / BM (OPT) /Diagnosis connector |
| 3 | - Rev counter / IC / BM / diagnosis connector |
| 4 | - SWI |
| 5 | - Cigarette lighter / 24V/12V Voltage reducer / Preamplifier |
| 6 | - Overturned cabin / Headlights attitude / Drier resistance / Presence of water in fuel filter / SHUT-OFF solenoid valve |

Delivery (A)

- | |
|----|
| 5 |
| 10 |
| 3 |
| 3 |
| 20 |
| 5 |

Red color fuse holder (70602)

Position

- | | |
|---|---|
| 1 | - Eurotronic |
| 2 | - Eurotronic |
| 3 | - Internal VDI lighting / Tooling compartment lighting (AT) |
| 4 | - EBS / ABS |
| 5 | - ABS |
| 6 | - EBS / ABS |

Delivery (A)

- | |
|------------|
| 10 |
| 10 |
| 5 |
| 5 |
| 5 (15 EBS) |
| 15 |


Natural color fuse holder (70603)

Position

- | | |
|---|----------------------------------|
| 1 | - Operator door module (Opt) |
| 2 | - Operator door module (Opt) |
| 3 | - Rev counter / IC / Immobilizer |
| 4 | - EDC |
| 5 | - Body Computer |
| 6 | - Body Computer |

Delivery (A)

- | |
|----|
| 20 |
| 20 |
| 15 |
| 20 |
| 25 |
| 25 |



74001

Black color fuse holder (70604)**Position**

- | | |
|---|--|
| 1 | - Conditioning system |
| 2 | - Conditioning system |
| 3 | - Conditioning system |
| 4 | - Supplementary heating |
| 5 | - Supplementary heating |
| 6 | - CM (Cabin Module) / Opt / Mirror heating |

Delivery (A)

15
15
5
15
5
20

Natural color fuse holder (70605)**Position**

- | | |
|---|---|
| 1 | - EDC |
| 2 | - Vehicle leveling |
| 3 | - Frame level adjustment |
| 4 | - Retarder with CAN |
| 5 | - Retarder with CAN |
| 6 | - Heated seat / centralized lubrication |

Delivery (A)

10
5
7,5
10
10
7,5

Black color fuse holder (70401)**Position**

- | | |
|---|-------------------------|
| 1 | - Equippers |
| 2 | - Equippers |
| 3 | - Equippers |
| 4 | - 12V internal lighting |
| 5 | - |
| 6 | - |

Delivery (A)

3
5
7,5
5
-
-


Black color fuse holder (70402)**Position**

- | | |
|---|---------------------|
| 1 | - Heated windshield |
| 2 | - Heated windshield |
| 3 | - Heated prefilter |
| 4 | - |
| 5 | - |
| 6 | - |

Delivery (A)

30
30
20
-
-
-

SUPPLEMENTARY REMOTE SWITCHES




74001


Ref.	Description	Component code
A	-	-
B	-	-
C	EuroTronic PTO 1	25898
D	Manual conditioner remote switch	25545
E	Water heater remote switch	25325
F	EuroTronic PTO 2 (NA2)	25897
G	Manual conditioner remote switch	25544
H	-	-
I	Manual conditioner remote switch	25874
K	Manual conditioner remote switch	25310
L	-	-
M	Manual conditioner remote switch	25322
N	Manual conditioner remote switch	25332
O	-	-
P	Manual conditioner remote switch	25327
R	Manual conditioner remote switch	25332
S	-	-

Remote switch plate


- Press the two release push buttons (A) on the passenger side object holder. Tilt the drawer forward.
- Loosen the two support lock screws (B); tilt the assembly forward taking care not to cause cable removal from their seats.
- Tilt the fuse holder forward to access remote switch holder (C).



49850




49848



49849

Remote switches

Positioned behind the BODY COMPUTER.




73672


Ref.	Description	Component code
GA	Heater prefilter remote switch	25825
GB	50A (clamp 15) remote switch	25213
GC	50 40A start remote switch	25200
GD	EDC (main relay) general remote switch	25924
GE	Windshield heating	25818/A
GF	Windshield heating	25818/B

SUPPLEMENTARY FUSES (70000)

Positioned on the vehicle left side close to the batteries and the TGC. Levering on the two springs on cover (A) accesses fuse holder inside.




73656




49847

A. Supplementary fuse holders




49731

Ref.	Function	Delivery A
1	R.F.C. (right rear light power)	30
2	R.F.C. (left rear light power)	30
3	F.F.C. (right front light power)	30
4	F.F.C. (left front light power)	30
5	ABS/EBS PTO	30
6	-	-

INSTRUMENT-HOLDER DASHBOARD

79492

Ref.	Description
1	Revolution counter
2	Engine cooling liquid temperature indicator
3	Fuel level indicator
4	Tachograph display
5	Headlights attitude drive
6	External lights switch
7	Fog light connection switch
8	Supplementary headlights connection switch
9	Rear fog light connection switch
10	Optical indicators assembly
11	Optical indicators assembly
12	Display
13	Optical indicators assembly
14	Load plane light connection switch (fifth wheel light)
15	ABS connection switch
16	Heated windscreen connection switch (OPT)
17	ASR connection switch
18	Emergency lights connection switch
19	-
20	Parking brake
21	-
22	Free (on cabin overturning consent AS)


CENTRAL DASHBOARD CONTROLS

79493

Ref.	Description
1	ABS engine brake connection switch
2	Third axle lifting/lowering button (OPT)
3	Pickup help button (OPT)
4	Power takeoff switch 1 (OPT)
5	Electric trapdoor control (OPT)
6	Sunshade curtain control (OPT)
7	Central roof lamp cabin lights
8	Multipower power takeoff control (OPT)
9	Roof side roof lamps cabin lights control
10	Fuel heater (OPT)
11	Rearview mirrors heating (before it was embedded into the door)
12	Switch for immediately connecting supplementary water heater (OPT)
13	Engine/cabin pre-heating selector (OPT)
14	Switch for connecting supplementary air heater (OPT - for manual version only)
15	Power takeoff 2 (OPT)
16	Supplementary water heater thermostat (OPT)
17	Key switch for ECO - POWER function
18	Heating/venting or air conditioner controls (OPT)
19	12V current outlet
20	Rotating lamps switch (OPT)
21	Pneumatic horns
22	General current remote control switch
23	Lighter
24	30-pole outlet for diagnosis / * Differential locking

CONTROLS ON THE STEERING WHEEL

The steering wheel features some keys that enable selecting and controlling certain functions.




Left hand side:

- 4. KEY ▲
- KEY ▼
- 5. KEY +
- KEY -

Right hand side:

- 1. MEBU KEY/OK
- 2. PAGE PUSH BUTTON
- 3. ESCAPE KEY

74202

REARVIEW MIRRORS AND WINDOW REGULATOR CONTROL ADJUSTMENT (OPT)

79494

Ref.	Description
1	Rearview mirror orientation control
2	Mirror selector control
3	Driver window regulator
4	Passenger window regulator


Key 2 on AS was placed on the left and in its place there was the mirror heating key that on AT/AD is placed on central dashboard as series.

Adjustment functions for rearview mirrors and window regulator control are managed by DDM and FDM units, and consequently they are present as optionals.

External rearview mirrors heating


By pressing the related button, the rearview mirrors heating is activated and the related icon is displayed on the display. To deactivate such function, press the button again. The icon will not be displayed any more. It is possible to select this function also with moving vehicle. Heating has a maximum length of 30 minutes.

LEFT LIGHT CONTROL 54033




Ref.	Description
1	Windshield wiper (top speed)
2	Windshield wiper (slow speed)
3	Windshield wiper (intermittent)
4	Windshield wiper (one stroke)
5	-
6	Dipped lights on
7	Light flashes
8	Mass
9	Washer electrical pump control
10	-
11	-
12	-
13	-
14	-
15	Right direction indicator
16	Left direction indicator

RIGHT LIGHT CONTROL 54030



Ref.	Description
1	Intarder (Position 4)
2	Speed Limiter
3	Cruise Control (set/acceleration)
4	Cruise Control (Resume)
5	Intarder (Position 1)
6	Intarder (Position 3)
7	Intarder (Position 2)
8	Cruise Control (deceleration)
9	Intarder (Position 5)
10	Intarder (Position 6)
11	-
12	-
13	-
14	-
15	-
16	-



001690t

RIGHT MULTIFUNCTION LEVER

The multifunction lever located on the right side of the steering column enables insertion of the engine brake function and the retarder when installed.

The former is selected by moving the lever to positions 1 and 2 and remains on even when the same lever is used to select the retarder function at positions 3, 4, 5 and 6 related to available braking power ratings.

When the engine brake function is selected the control lever signal is transmitted to the (Steering Wheel Interface) S.W.I. center.


Which activates the engine brake warning light on Instrument Cluster IC, and via Body Computer B.C. sends the request for engine brake to the EDC, EBS and automated EuroTronic center (when present).

When the operator selects the engine brake manually, selection is displayed in the Cluster with a blinking warning light, which goes to steady when the engine brake is turned on. In the manual mode, engine brake action is also conditioned by accelerator pedal release. In the automatic mode, the engine brake is activated by the EDC center on receipt of a request from the EBS center.

In this condition, the EDC center pilots the engine brake electro valve and the VGT actuator to the fully closed position.


Engine brake control and intarder

Vehicles with Intarder mechanical gearshift



001690t


Vehicles with Intarder EuroTronic transmission



001690t


(*) The intarder can be more effective with automatic downshifting managed by the transmission electronic control centre.

Vehicles with mechanical gearshift or Eurotronic transmission in the manual mode without Intarder



001690t


Vehicles with Eurotronic transmission in the automatic mode without Intarder



001690t

DIAGNOSIS CONNECTOR

Framatone PIN			
System	Pin	Funct.	Cable colour code
EDC + IMMOBILIZER	1	-	-
	2	K	2298
ABS/EBS+ECAS	3	-	-
	4	K	2299
	5	-	-
	6	K	2293
Multiplex units (BC/FFC/RFC...)	7	-	-
	8	K	2295
Air conditioner	9	-	-
Heater	10	K	2296
Connection	11	+ 15	8802
VDI	12	K	2262
Cluster tachograph	13	-	-
	14	K	2994
	15	-	-
	16	-	-
EUROTRONIC	18	-	-
EOL	19	-	7079
INTARDER	20	-	3397
	21	-	-
	22	-	-
Phase signal	23	Phase	5198
	24	-	-
Starting signal	25	Modus	0900
	26	Modus	0000
Positive	27	+ 30	7797
Engine revolutions	28	n	5584
Speed signal	29	n	5540
Vehicle mass	30	31	0000




FRONT VIEW

On the lower right part under central dashboard, there is a 30-pin diagnosis connector for performing the diagnosis of electronic systems on the vehicle.

“VDI” ELECTRONIC CENTER


An electronic center called “VDI” is available as an optional. It enables reading the data of other centers present without interfering with them.
These data, such as engine rpm and the like, cannot be identified via the K line for each electronic center present.




73659

73671

Ref. Description			Ref. Description		
A	I	Mass	B	I	Line K
	2	30-pole CAN line L		2	Mass
	3	30-pole CAN line H		3	Free
				4	+30
				5	CAN line L
				6	CAN line K

WALL PASS

73656



73658

73657

- Connector **A (E/Right)** - White (**Green/Right**) (Free)
- Connector **B (D/Right)** - Brown (**Blue/Right**) (ECAS)
- Connector **C** - Yellow (EBS/ABS/ASR)
- Connector **D (B/Right)** - Blue (**Brown/Right**) (EuroTronic/PTO/Intarder)
- Connector **E (A/Right)** - Green (**White/Right**) (EDC/ADR)

The new bayonet connectors make signal continuity much more reliable than with the previous system.

Brown wall class “B”

Pin	Function	Cable colour code
1	Frame height sensor mass	0400
2	Ecas rear axle frame height induction sensor	5421
3	Ecas rear axle frame height induction sensor	5422
4	Ecas rear axle electro-pneumatic distributor	9442
5	Ecas front axle compressed air distributor	9413
6	Ecas front axle frame height induction sensor	5410
7	Ecas electro pneumatic distributor mass	9400
8	Electro pneumatic distributor	9423
9	Ecas rear axle electro-pneumatic distributor	9423
10	Ecas rear axle electro-pneumatic distributor	9424
11	Ecas rear axle electro-pneumatic distributor	9424
12	Ecas rear axle electro-pneumatic distributor	9447
13	Ecas rear axle electro-pneumatic distributor	9446
14	Ecas 3rd axle lift/lower switch	5443
15	Ecas 3rd axle lift/lower switch	5441
16	Ecas 3rd axle lift/lower switch	5442
17	Ecas 3rd axle lift/lower switch	5444
18	Ecas third axle compressed air lifter air pressure sensor	5445
19	15-pole trailer connector (Pin 12)	6442
20	VDB CAN line L	GN/VE
21	VDB CAN line H	WS/BI
22	Engine fan electro valve control	9166
23	Rev counter speed sensor power	5514
24	Tachograph speed sensor signal	5516
25	Tachograph speed sensor signal	5517
26	Rev counter speed sensor mass	0058
27	VGT turbine piping air lock electro valve +15 power (Shut-Off)	8360
28	Negative from R.F.C. key switch	0987
29	Heater drier power/trailer voltage 15 clamp	8840
30	TGC On maintenance relay excitation (Shut-off)	8035
31	TGC Off maintenance relay excitation (On)	8045
32	Free	-
33	Diagnosis K line for R.F.C.	2999
34	PTO on signal (sensor)	0132
35	Current outlet for ABS/EBS trailer (CAN SB Line)	BI/MA
36	Current outlet for ABS/EBS trailer (CAN SB Line)	BI/VE
37	ABS/EBS IC signal trailer power connection	6671
38	ABS/EBS clamp 15 trailer power connection	8847
39	30 clamp for 15-pole connection for trailer electrical connection	7790
40	Positive for tachograph, Body Computer, Cluster, Bed Module	7972

Yellow wall pass “C”

Pin	Cable colour code	EBS Function	Cable colour code	ABS Function
1	6025	Front wheel brake wear sensor/pin 1	—	Free
2	6024	Front wheel brake wear sensor/pin 2	6245	Rear wheel brake wear sensor/pin 5
3	0026	Front wheel brake wear sensor/pin 3	8847	Rear axle safety/pin +
4	5571	Right front axle speed sensor	5571	Right front axle speed sensor
5	5571	Right front axle speed sensor	5571	Right front axle speed sensor
6	9920	EV electro valve/ right front axle pin 3	9920	EV electro valve/ right front axle pin 3
7	0118	AV/EV electro valve/ right front axle pin 3	—	Free
8	9918	AV electro valve/ right front axle pin 1	9918	AV electro valve/ right front axle pin 1
9	8075	Connector ST81/pin 1 clamp 15	8075	Connector ST81/pin 1
10	3375	Connector ST81/pin 2 clamp 58	3375	Connector ST81/pin 2
11	9262	Electro valve for brake cylinder/pin 1 (only on 6x6)	5573	Right rear axle speed sensor
12	0047	Engine brake switch/pin 1	5573	Right rear axle speed sensor
13	6046	Trailer air pressure proportional valve / pin 1	9930	EV electro valve / Right rear axle pin 3
14	0026	Trailer air pressure proportional valve / pin 2	—	Free
15	6047	Trailer air pressure proportional valve / pin 3	9928	AV electro valve / Right rear axle pin 1
16	9046	Trailer air pressure proportional valve / pin 4	—	Free
17	0046	Trailer air pressure proportional valve / pin 5	—	Free
18	9217	Rear axle breaking redundant electro valve /pin 1 (only on tractor)	—	Free
19	0217	Rear axle breaking redundant electro valve /pin 2 (only on tractor)	—	Free
20	—	Free	—	Free
21	—	Free	—	Free
22	—	Free	—	Free
23	—	Free	—	Free
24	GN/VE	Rear air pressure modulator /pin 4	0260	Electro valve for ASR /pin 2
25	WS/BI	Rear air pressure modulator /pin 3	9260	Electro valve for ASR /pin 1
26	7740	Rear air pressure modulator /pin 1	—	Free
27	9960	Front axle air proportional valve /pin 5	—	Free
28	0099	Front axle air proportional valve /pin 4	—	Free
29	6697	Front axle air proportional valve /pin 3	9929	AV electro valve /left rear axle pin 1
30	0026	Front axle air proportional valve /pin 2	—	Free
31	6696	Front axle air proportional valve /pin 1	9931	EV electro valve /left rear axle pin 3
32	9919	AV electro valve /left front axle pin 1	9919	AV Electro valve /left rear axle pin 1
33	0122	AV/EV electro valve / left front axle pin 2	—	Free
34	9921	EV electro valve / left front axle pin 3	9921	EV electro valve / left rear axle pin 3
35	5570	Left front axle speed sensor	5570	Left rear axle speed sensor
36	5570	Left front axle speed sensor	5570	Left rear axle speed sensor
37	0026	Front wheel brake wear sensor/pin 3	5572	Left rear axle speed sensor
38	6026	Front wheel brake wear sensor/pin 2	5572	Left rear axle speed sensor
39	6027	Front wheel brake wear sensor/pin 1	—	Free
40	0000	Mass	0000	Mass

Blue wall pass “D”





Pin	Function	Cable colour code
1	TGC opening signal	8802
2	EuroTronic mass	0000
3	Electrical selector with automatic transmission (power supply from centre)	6100
4	Electrical selector with automatic transmission CAN line L	GN/VE
5	Electrical selector with automatic transmission CAN line H	WS/BI
6	EuroTronic power (+30)	7101
7	EuroTronic diagnosis line K	2297
8	VDB automatic transmission electronic center CAN line L	GN/VE
9	VDB automatic transmission electronic center CAN line H	WS/BI
10	VDB automatic transmission electronic center CAN line L	GN/VE
11	VDB automatic transmission electronic center CAN line H	WS/BI
12	EuroTronic P.T.O. 1 (positive)	9131
13	EuroTronic P.T.O. 2 (positive)	9132
14	Retarder water temperature transmitter	0309
15	Retarder water temperature transmitter	5309
16	Retarder oil accumulator electro valve	9311
17	Retarder oil accumulator electro valve	0311
18	Retarder on electro valve (proportional electro valve)	9130
19	Retarder on electro valve (proportional electro valve)	0310

Green wall pass “E”

Pin	Function	Cable colour code
1	VDB CAN line L	GN/VE
2	VDB CAN line H	WS/BI
3	BCB CAN line L	GN/VE
4	BCB CAN line L	WS/BI
5	F.F.C. diagnosis line K	2998
6	F.F.C. clamp 15 ignition switch	0987
7	Clamp 15 generator power	8876
8	Relay power for engine preheat resistor consent	7150
9	EDC center main relay control	0155
10	EDC center power from main relay	7155
11	EDC center power from main relay	7155
12	Signal from EDC center clutch switch	8160
13	Clamp 15 power for EDC center	8015
14	Accelerator pedal sensor	5157
15	EDC center signal for engine synchronization	5198
16	B7 rev counter signal	5155
17	Signal from primary stop light switch for EDC center	8153
18	EDC diagnosis line K	2298
19	Accelerator pedal sensor	5158
20	BCB CAN line L	GN/VE
21	BCB CAN line H	WS/BI
22	Accelerator pedal sensor	0157
23	Starter motor (clamp 50)	8888
24	Valeo compressor electromagnet	9993
25	Brake signal from EDC center	8158
26	Accelerator pedal sensor	0159
27	Accelerator pedal sensor mass	0158
28	Free	-
29	Electro pump power light wipers	8821
30	Coolant level optical indicator	5520
31	Engine start signal from EDC centers	8892
32	Coolant low level indicator	5527
33	Horn positive	1116
34	EDC center Blink Code signal for I.C.	6150
35	Windshield wiper control signal	8886
36	Engine fan electro valve positive	9166
37	ADR voltage limiter rev counter clamp 30e	5579
38	ADR voltage limiter rev counter mass	0079
39	Free	—
40	ADR switch on	0178


28 V - 40 A ÷ 90 A "BOSCH" ALTERNATOR

03000



Characteristics


Rated voltage	28 V
Rated power	90 A
Current at environment temperature 1800 RPM/40 A	
At 25 °C and rated voltage	6000 RPM/90 A
Direction of rotation	clockwise, seen from pulley
Weight	7.8 kg



8535


PERSPECTIVE VIEW WITH CORRESPONDING ELECTRICAL CONNECTIONS

Ref.	Function	Cable colour code
L 15 (IG) S	To F.F.C. center clamp J2/B24 To remote switch 25213 clamp 87 (via fuse F6-70601) Positive (+30)	7009 8876 7777
B+	Clamp S alternator Positive +30 power positive +30 positive to starter motor Positive +30	7777 7777 7777

24V - 5,5 kW "Nippondenso" STARTER MOTOR**08000**


4956

TECHNICAL VIEW



4957


CHARACTERISTIC CURVES



4958

WIRING DIAGRAM

Characteristics		Specific Power (20 °C)	Test cond.	Characteristics
Rated power	5,5 kW	Loadless	23V	120A MAX (3800rpm MIN.)
System voltage	24V	Load	16V (49 N-m)	690A MAX. (900rpm MIN.)
Engagement system	Positive approach control	Stall	6V	1260A MAX. (73.5 N-m MIN.)
Adjusted time	30 sec.			
Direction of rotation	clockwise, seen from end of pinion			
Weight	approx. 10,5 kg			
Operating voltage	16V MAX. (20°C)			
Water resistance	Water spray test to JIS D0203 'SI'			



6658


PERSPECTIVE VIEW WITH ASSOCIATED ELECTRICAL CONNECTIONS

Connector	Function	Cable colour code
+30	+30 positive for starter motor power from battery positive clamp (via the T.G.C.)	7777
+30	+30 positive to the alternator	7777
+30	+30 positive to remote switch for engine preheat on consent	7777
+50	+50 positive for key switch	8888

Elektronik systems

	Page
MULTIPLEX SYSTEM	3
☐ Cluster	5
☐ Body Computer	12
☐ Front Frame Computer (FFC)	24
☐ Rear Frame Computer (RFC)	27
☐ Driver Door Module (DDM)	31
☐ Passenger Door Module (PDM)	31
☐ Cabin Module (CB)	34
☐ Steering Wheel Interface (SWI)	36
☐ Spiraled contact	39
☐ Bed Module	44
AUTOMATIC AIR CONDITIONER	46
MANUAL AIR CONDITIONER	61
HYDRONIC D 10 WATER HEATER	66
IMMOBILIZER	73
EDC	77
EBS	108
ABS - EBL	126
ECAS SUSPENSIONS	151
EUROTRONIC AUTOMATED	172
INTARDER	191

LOCATION OF MULTIPLEX SYSTEM COMPONENTS ON BOARD THE VEHICLE




A. Cluster - B. Bed Module - C. R.F.C. center - D. Fuse holder on frame - E. Operator door center (D.D.M.) - F. F.F.C. center - G. Cab Module - H. Wall pass - I. Body Computer - L. Passenger door center (PDM) - * OPT


Cluster

Proceed as follows to remove the Cluster:


- Use a screwdriver for leverage inside the two slots in the two groups of switches (A) located in the upper panel.
- Remove the two protection caps.
- Loose the four panel retainer screws (B).
- Move the panel as far outwards as possible after relocating the steering wheel far from the panel.
- Disconnect the two Cluster attaching screws.
- Loosen the four retainer screws (C).




84588



84588




49837

Cluster (optical indicators)


73664

Ref.	Description
1	External lights
2	Supplementary lights
3	Flood lights
4	General anomaly/breakdown warning
5	General alarm
6	Fog lights
7	Rear fog lights
8	* Decelerator
9	* Engine brake
10	Stationary vehicle suspensions
11	Third axle raised
12	Start help
13	Mirror heating
14	Longitudinal differential lock tandem
15	Longitudinal differential lock transversal rear
16	Left direction indicator
17	Longitudinal differential lock
18	Longitudinal differential lock transversal front
19	Rotating lights
*	Blinking light with function requested by the operator and fixed light with the function activated



73663

Ref.	Description
20	First PTO
21	Second PTO
22	Instrument panel breakdown (Cluster)
23	Right direction indicator
24	Immobilizer
25	Analogic rev counter
26	Hour/temperature display
27	Hour/temperature display push button
28	Coolant temperature
29	Instrument lighting intensity
30	Parking brake on
31	Emergency light
32	Brake system breakdown
33	Display
34	Fuel level
35	Km/mile indicator display push button
36	Rev counter anomaly
37	Total/partial/Km/mile counter display
38	Analogic rev counter
39	Reset

Cluster pin out

49837

Ref.	A - Black	Component code	B - Blue	Component code
1	Link K - Diagnosis	72021	-	-
2	-	-	-	-
3	CAN H (VDB) Line	-	-	-
4	CAN L (VDB) Line	-	-	-
5	-	-	-	-
6	-	-	-	-
7	-	-	-	-
8	Predisposition	ST14	-	-
9	Tachograph speed signal	72021	-	-
10	CAN H (ICB) Line	-	-	-
11	CAN L (ICB) Line	-	EDC signal input	8515D
12	-	-	-	-
13	CAN H (IDB) Line	-	-	-
14	CAN L (IDB) Line	-	-	-
15	-	-	-	-
16	Rev counter signal	40011	-	-
17	Rev counter signal	40011	-	-
18	Speed signal (intarder)	ST25	Power from fuse	70601
19	-	-	Mass	-
20	Predisposition	ST14	Power from fuse	70601

Display operation

Display varies subject to the following:

- Key on MAR with engine off
- Key on MAR with engine started and vehicle stationary
- Key on MAR at vehicle speed over 15 Km/h
- Key out

Key in MAR with engine off

Turning the key to MAR displays control of main vehicle systems.

Their presence is indicated in green, if all is OK, or yellow in case of a light anomaly/breakdown, or red in case of a serious anomaly/breakdown, with activation of a buzzer.

After acknowledging the error, the operator presses key OK on the steering wheel and the icon appears in the lower display layer.

Yellow color (light anomaly/breakdown):

Proceed with caution and contact a Service Network workshop as soon as possible.

Red color (serious anomaly/breakdown):

Park the vehicle on the roadside in a non-dangerous area or contact the Dealer or the 24 hour Client Center number in unusual hours or in a decentralized area.

Two menus are available:

- TRAVEL MENU
- DIALOG MENU

External mirrors and lights can also be adjusted.

When the key is inserted, the present electronic systems perform a test by activating the related lights, enabling the operator to check their efficiency (and learn of the existence of vehicle systems).

The list of systems present on the vehicle and their status can be displayed with the Multiplex system during Start-Up, by receiving the diagnostic message from the various centers.

System Check Ok or System Check Failed information is provided at Start-Up Test end.

The defective system then sends its diagnostic message that is displayed with the icon of the defect under review.

The Multiplex system can indicate vehicle and electronic system errors. In case of an error detected by the Body Computer, it sends the Instrument Cluster a message containing the following information, via the CAN line:

- the status of the light associated to the defect (red for a serious and yellow for a slight anomaly)
- the error code

At receipt of the error message, the Instrument Cluster displays the following in the central display area:


- the colored icon related to the defective component or center
- the related error code

It also advises the operator by activating the Buzzer. After recognizing the error, the operator presses key "OK" and the central display area returns showing the previous information (virtual tool or menu).

The icon related to the error detected is stored in the lower layer of the display or with a specific warning.

No options such as to distract attention or options not related to an operation useful for vehicle operation are available during operation, which is why the Menus available in case of a moving vehicle are reduced to the base essential and scanning of the various displays is obtained simply with the "Menu" key (without reading the list of options).

With the vehicle stationary, scanning of the complete set of menus available is enabled with keys "Arrow up" and "Arrow down".

Display structure

73662

TITLE

- ☐ Speed set by Cruise Control
- ☐ Speed Limiter set
- ☐ Supplementary heater enabled
- ☐ Battery voltage
- ☐ Radio/RDS information
- ☐ Telephone/ EMS message information
- ☐ Gears (downshifted/normal gears), suggested gears, auto/manual mode.

CENTRAL SECTION


- ☐ Engine oil pressure
- ☐ Engine oil level
- ☐ Consumption indicator
- ☐ Turbo pressure
- ☐ Engine oil temperature
- ☐ Reservoir, trailer, service air pressure
- ☐ Front / rear / trailer brake wear (vehicles with EBS)
- ☐ Light setting adjustment
- ☐ Mirror positioning
- ☐ Failure messages

LOWER SECTION

- ☐ Alarms
- ☐ Active functions indications (intarder, etc.)

Optical status indicators on display

The corresponding icon appears at activation of the following functions or occurrence of the following anomalies.




Meaning	Symbol	Colour	Meaning	Symbol	Colour
Pre-heating		yellow	ASR on	ASR	yellow
Cab unhooked		red	ASR off	ASR	yellow
Door open		red	Reduced ABS operation		yellow
Low front axle brake air pressure		red	Automatic chains		yellow
Low rear axle brake air pressure		red	Trailer without EBS/ABS		yellow
Low trailer brake air pressure		red	Tipper body		yellow
Loading deck light (tractor only)		yellow	Instrument Cluster trouble	IC	red
Windscreen defroster		yellow	Low hydraulic pressure of third steering axle		red
Minimum engine coolant level		yellow	Low engine coolant level		red
High engine coolant temperature		yellow	Very high engine coolant temperature		red
Low windscreen washer reservoir level		yellow	Low fuel level		yellow
Front axle brake wear		red	Rear axle brake wear		red
Added axle brake wear		red	Trailer ABS/EBS fault		yellow
Low level first power steering circuit		yellow	Low level second power steering circuit		yellow
Oil filter clogged		yellow	Air filter clogged		yellow
Fuel filter clogged		yellow	Water in fuel filter		yellow
Low engine oil level		red	Engine oil level too high		yellow
Low engine oil pressure		red	High engine oil temperature		red
Low parking brake air pressure		red	Low air suspension pressure		red
Low trailer brake air pressure		red	Brake wear on a specific wheel		yellow

After recognizing the error, the operator must press OK on the steering wheel and the icon appears in the lower display section.

Body computer

The Body Computer is the Multiplex system central unit. Its function is to manage the peripheral units present and is located inside the instrument panel on the passenger side in the interconnection center.



Input signals

74001

- | | |
|---------------------------------|-------------------------------|
| - vehicle external lighting | - parking brake |
| - interior compartment lighting | - tilted cab |
| - horn | - PTO |
| - windshield wiper | - electrical cavity |
| - engine start | - external temperature sensor |
| - coolant level | - windshield heating |
| - automatic snow chains | - vehicle external lighting |

Output signals


- | | |
|---------------------------------|----------------------|
| - interior compartment lighting | - windshield heating |
| - horn | - battery sectioning |
| - windshield wiper | - electrical cavity |
| - starter motor | - equipper outputs |

BC replacement operation sequence:


1. Turn key OFF
2. Press instrument panel button TGC OFF
3. Wait for about 15seconds for the TGC to open – check that the TGC does not work when actuating the windshield wiper to be sure the TGC is open.
4. Disconnect J1
5. Disconnect other connectors in any order
6. Complete necessary operations
7. Reconnect connectors other than J1 in any order
8. Reconnect J1
9. Turn key ON

Proceed as follows to remove the Body Computer:


- Press the two release push buttons (A) on the passenger side object holder drawer.
- Lift the two Body Computer (B) lock straps.
- Draw the center carefully forward to avoid removing the connection cables.
- Disconnect the connectors on the back.




49850



49848




49845

Body Computer perspective view


The connector pin configuration is seen from the wiring side

50242


Connector “J1”




49372




Ref.	Description	Component code	Cable color code
1	Positive from fuse (after TGC)	70603	7905
2	Positive from fuse (after TGC)	70603	7905
3	Positive from fuse (after TGC)	70603	7905
4	Positive from fuse (after TGC)	70603	7905
5	Frame mass	-	0000
6	Frame mass	-	0000
7	Frame mass	-	0000
8	Positive from fuse (direct to battery)	70058	7972
9	Free	-	-
10	TGC closing signal	25900	8035

Connector “J2”


49372




Ref.	Description	Component code	Cable color code
1	CAN – H line (ICB)	-	Ws/Bi
2	CAN - L line (ICB)	-	Gn/Ve
3	CAN - H line (VDB)	-	Ws/Bi
4	CAN - L line (VDB)	-	Gn/Ve
5	Diagnosis K line	72021	2995
6	Negative from coolant pressure warning switch	42608	0583
7	Free	-	-
8	Free	-	-
9	Free	-	-
10	CAN - H line (BCB)	-	Ws/Bi
11	Free	-	-
12	CAN - L line (BCB)	-	Gn/Ve

Connector “J3”

49372




Ref.	Description	Component code	Cable color code
1	Signal from external light switch	52307	2237
2	Positive for internal ceiling light	39034	4423
3	Negative from internal light switch	52326	0941
4	Free	-	-
5	Negative from external air temperature sensor	42045	0550
6	TGC opening signal (OPT)	25900	8045
7	Free	-	-
8	Positive from external air temperature sensor	42045	7573
9	Negative from switch to open TGC	53316	0946
10	Positive for solenoid valve pneumatic horn	78203	1133
11	Positive for front profile lights	37001	3339
12	Signal for sliding roof opening (OPT)	12015	7010
13	Signals for rotating lights (OPT)	32010	-
14	Signal for sliding roof closing (OPT)	12015	7011 - 0971

Connector “J4”


49372

Ref.	Description	Component code	Cable color code
1	Positive for step light ceiling lamp	39003	4445
2	Negative from TGC closing switch (OPT)	53316	0945
3	Negative from engine brake predisposition switch	52324	0082
4	Free	-	-
5	Predisposition for supplementary heater (ST 19 - pin 10)	-	0501
6	Horn control	54033	1116
7	Negative for passenger side door closing	85023	0065
8	Negative for operator side door closing	85023	0065
9	Positive for start remote switch	25200	8888
10	Positive for start from engine bay	53006	8892
11	Negative from radiator coolant low level sensor	44036	5527
12	Signal from radiator coolant low level sensor	44036	5520
13	ST19 connector (Pin 11)	ST19	7786
14	Free	-	-
15	Negative for passenger side door opening	85023	0064
16	Rotating light control (OPT)	52015	-


Connector “J5”



49372




Ref.	Description	Component code	Cable color code
1	Diagnosis connector (50)	72021	0900
2	Negative from hand brake switch on	42102	6662
3	Negative from hand brake anti-start switch off	53512	8892
4	-	-	-
5	Back-up signal	ST14 - 10	2268
6	Transmission idling signal	ST14 - 9	8050
7	Negative from released cab warning switch	53511	0096
8	Signal for rotating lights (OPT)	32010	-

Connector “J6A”


49372

Ref.	Description	Component code	Cable color code
A	1 Negative from sliding roof closing switch	53306	0971
	2 Negative from coolant pressure warning switch	42608	0582
	3 Free	-	-
	4 Predisposition for signal from P.T.O.1 switch	ST14 - 19	0131
	5 Predisposition for signal from P.T.O.2 switch	ST14 - 20	0132
	6 Negative from Economy Power mode switch	52077	0166
	7 Free	-	-
	8 Negative from electrical or compressed air warning switch	52200	1119
	9 Predisposition for signal from engine stop switch	ST14-2	0151
	10 Free	-	-
	11 Free	-	-
	12 Free	-	-
	13 Signal from light setting control switch	52312	9936
	14 Free	-	-
	15 Low windscreen washer liquid level signal	-	5521
	16 Free	-	-
	17 Free	-	-
	18 Free	-	-
	19 Free	-	-
	20 Free	-	-

Connector “J6B”

49372

Ref.	Description	Component code	Cable color code
B	1 Predisposition for signal from engine start switch	ST 14 - 1	8892
	2 Free	-	-
	3 Cruise Control predisposition (OFF)	ST14 - 14	8154
	4 Cruise Control predisposition (RESUME)	ST14 - 15	8155
	5 Negative from P.T.O. on warning switch	53567	0132
	6 Free	-	-
	7 Free	-	-
	8 Negative from cab release consent switch	-	-
	9 Cruise Control predisposition	ST 14-16	0152
	10 Free	-	-
	11 Cruise Control predisposition (SET+)	ST14 - 12	8156
	12 Cruise Control predisposition (SET-)	ST 14 - 13	8157
	13 Free	-	-
	14 Free	-	-
	15 Free	-	-
	16 Negative from sliding roof control switch	53306	0970

Connector "J7"


Ref.	Description	Component code	Cable color code
1	User positive under key	25213	8802
2	Free	-	-
3	Positive for equipment supply (+15)	ST14 - 11	8871
4	Positive for remote control switch engine water introduction	25325	7778
5	Signal from external lights switch	52307	3333
6	Negative from front fog light switch	52304	2228
7	Brake pedal switch	78059	0077
8	Negative from rear fog light switch	53315	2284
9	Positive +15 30 pole	72021	8802
10	Negative from circle light switch	52009	2224
11	Negative for operator side door opening	85023	0064
12	Negative from supplementary light switch	52024	2229
13	Negative from operator side internal light switch	53509	0003
14	Negative from key switch (15)	52502	0987
15	Negative from passenger side internal light switch	53509	0003
16	Positive from windshield wiper unit	65000	8880
17	Negative from emergency light control switch	52302	1113
18	Negative from key switch (50)	52502	0900
19	Positive for instrument lighting	-	4442
20	Positive from windshield wiper unit	65000	8873
21	Positive for windshield wiper unit (low speed)	65000	8882
22	Positive for windshield wiper unit (high speed)	65000	8881

F.F.C. - R.F.C. (Front Frame Computer - Rear Frame Computer)


These are Peripheral Electronic Units used to pilot most electrical utilities.
They can be connected directly to loads such as lights, sensors and electrical motors.

The F.F.C. is located on the vehicle front below the cab and the R.F.C. is located in the frame center.


They differ by a code (F for Front and R for Rear) and a different assembly hole (*).



73660

F.F.C. (Services / Engine)


73656




49843

Located on the right frame beam in the vehicle front under the cab. Proceed as follows to remove the electronic center:

- overturn the cabin
- loosen the three center (A) / cover support screws;
- disconnect the two connectors without removing cables from the connector seat.

Connector “J1”


Ref.	Description	Component code	Cable color code
1	Positive for right dipped light	30001	2223
2	Positive for right dipped light	30001	2221
3	Positive for headlight washer pump	66005	8821
A 4	Free	-	-
5	Positive for left flood	30001	2219
6	Positive for supplementary flood lights	30010	2229
7	Positive for front fog lights	30011	2228
8	Positive for left dipped light	30001	2231
1	Free	-	-
2	Positive for light setting actuator	30100	9937
3	Free	-	-
4	Free	-	-
5	Free	-	-
6	Free	-	-
7	Positive for right side and front direction lights	32002-33001	1123
8	Positive for windscreen washer electric pump	64000	8886
9	Free	-	-
10	Free	-	-
11	Free	-	-
12	Free	-	-
13	Free	-	-
14	Free	-	-
15	Signal for light setting actuator	30100	9936
B 16	Positive for right front position light	30001	3330
17	Free	-	-
18	Negative for light connector actuator	30100	9935
19	Free	-	-
20	Free	-	-
21	Free	-	-
22	Free	-	-
23	Free	-	-
24	Positive for left side and front direction lights	32002- 33001	1129
25	Free	-	-
26	Free	-	-
27	Free	-	-
28	Free	-	-
29	Free	-	-
30	Free	-	-
31	-	-	-
32	Positive for left front position lights	30001	3339

Connector "J2"


Ref.	Description	Component code	Cable color code
1	Positive from fuse for left light power	70000	7904
2	Positive from fuse for left light power	70000	7904
3	Positive from fuse for right light power	70000	7903
A 4	Positive from fuse for left light power	70000	7904
5	Positive from fuse for right light power	70000	7903
6	Positive for engine fan electromagnet 2 nd gear	47043	5166
7	Frame mass	-	0000
8	Positive from fuse for right light power	70000	7903
1	CAN - H line (BCB)	-	Ws/Bi
2	CAN - L line (BCB)	-	Gn/Ve
3	CAN - H line (BCB)	-	Ws/Bi
4	CAN - L line (BCB)	-	Gn/Ve
5	Free	-	-
6	K line (diagnosis connector)	72021	2998
7	Negative from switch to key	52502	0987
8	Positive for engine oil level sensor	44043	5506
9	Negative (return) from engine oil pressure sensor	42030	0050
10	Free	-	-
11	Negative from clogged fuel filter warning switch	42700	5531
12	-	44037	-
13	Free	-	-
14	Free	-	-
15	Negative (return) from engine oil temperature sensor	47032	5504
B 16	Positive for engine oil pressure sensor	42030	5508
17	Positive for power (equippers)+I5	-	8871
18	Negative from front pad wear warning sensors	86002	6664
19	Negative from engine stop switch (from engine bay)	53007	0151
20	Negative from clogged fuel filter switch	42551	6618
21	Signal from engine oil pressure sensor	42030	5507
22	Free	-	-
23	Negative from hydraulic fluid low level indicator	44037	5525
24	Signal from the alternator	03000	7009
25	Positive for engine fan electro valve	78016	9166
26	Positive for horn	22000	1116
27	Free	-	-
28	Free	-	-
29	-	53504	-
30	Negative from starter switch from engine bay	53006	8892
31	Negative from engine oil temperature sensor	47032	5504
32	Positive from engine oil pressure sensor	44043	5505

R.F.C.

Located in the vehicle center on the right side. Follow the F.F.C. center instructions for removal.



A. R.F.C. electronic center


**R.F.C. (frame)
ConneCtor "J1"**

Ref.	Description	Component code	Cable color code
1	Free	-	-
2	Positive for +15 supply (RSU connector) 10A	ST52	8871
3	Positive for right profile light / trailer	33004	3330
A 4	Positive for left profile light / trailer	33004	3339
5	Positive for +15 supply (3A connector)	-	8075
6	RSU connector	ST52	3333
7	Positive for trailer backup lights	72010	2226
8	Positive for total P.T.O electro valve insertion on transmission	78208	9954
1	Free	-	-
2	Free	-	-
3	Negative on anti-start switch with gears meshed	53508	8050
4	Negative on backup light switch	53503	2268
5	Negative on downshifted gear warning switch	53507	9992
6	Negative on clogged air filter warning switch	42351	6663
7	Positive for trailer right director indicators	72010	1185
8	Free	-	-
9	Positive for air drier filter resistor	61104	5562
10	Signal for air drier filter resistor insertion	44031	5561
11	Negative on trailer brake system defect warning switch	42111	6689
12	Free	-	-
13	Positive for brake air drier filter resistor	61104	5560
14	Positive from fuel level sensor	44031	5557
15	Free	-	-
B 16	Positive for circle light	34011	2224
17	Positive (return) from fuel level sensor	44031	5555
18	Free	-	-
19	Free	-	-
20	Free	-	-
21	Free	-	-
22	Free	-	-
23	Free	-	-
24	Positive for trailer left director indicators	72010	1180
25	Free	-	-
26	Free	-	-
27	Free	-	-
28	Free	-	-
29	Free	-	-
30	Signal from water warning in gas oil filter	86019	5530
31	Negative from rear P.T.O warning switch inserted	53568	0131
32	Positive for trailer rear fog lights	72010	2283


D.D.M. / P.D.M. / Cab module (Opt)

The three centers are identical.

The D.D.M. is located inside the operator door; the P.D.M. inside the passenger door and the CABIN MODULE is in the center bay on the right under-instrument panel (together with the ABS and ECAS).



50239




49723

II CAB MODULE manages functions related to the operator cab.

Inputs	Outputs
Rearview mirror heating	Rearview mirror heating
Rearview mirror adjustment	Rearview mirror adjustment
Window lifter	Window lifter
Centralized lock	Centralized lock

The only difference between D.D.M. and P.D.M. is that the P.D.M. J2/10 pin is connected to the J1/8 pin with a jumper to recognise the passenger module.

D.D.M. / P.D.M.

49838

These centers manage all the functions appertaining to the two vehicle doors, namely:

- mirror adjustment
- window lifter
- centralized lock.

They are located inside the vehicle door and removal is as follows:

- remove the door lining;
- disconnect the three electrical connectors (B);
- loosen the two center lock screws (A) to the door.

Disassembly operations are the same for both doors.

P.D.M.


CONNECTOR J1		
Pin	Cable	Function
1	-	Free
2	-	Free
3	-	Free
4	9965	Centralized lock motor control (CDL)
5	9964	Centralized lock motor control (CDL)
6	8863	Window lifter motor control
7	8865	Window lifter motor control
8	0000	Mass – Bridge with (J2-I0) for module recognition
9	0064	Centralized door lock
10	0065	Centralized door lock
11	0000	Negative for centralized door lock release push button
12	0000	Negative for main rearview mirror heating
13	0000	Negative for wide angle rearview mirror heating
14	0000	Negative for approach rearview mirror heating
15	2990	K line for diagnosis
16	7990	Center power positive

CONNECTOR J2		
Pin	Cable	Function
1	Ws/Bi	CAN H line (BCB)
2	8838	Approach rearview mirror control (vertical)
3	8839	Approach rearview mirror control (horizontal)
4	8851	Wide angle rearview mirror control (return)
5	8852	Wide angle rearview mirror control (vertical)
6	8857	Main rearview mirror control (return)
7	Gv/Ve	CAN L line (BCB)
8	8853	Wide angle rearview mirror control (horizontal)
9	8836	Approach rearview mirror control (return)
10	0000	Mass – Bridge with (J1-8) for passenger side ECU recognition
11	8859	Main rearview mirror control (horizontal)
12	8858	Main rearview mirror control (vertical)


CONNECTOR J3		
Pin	Cable	Function
1	0962	Negative from passenger side glass lifter push button
2 ÷ 9	-	Free
10	4442	Positive for passenger side glass lifter push button light
11	0961	Negative from passenger side glass lower push button
12	0960	Negative for passenger side glass control push button + lighting
13 ÷ 20	-	Free

D.D.M.

CONNECTOR J1		
Pin	Cable	Function
1	-	Free
2	-	Free
3	8830	Free
4	9965	Centralized door lock motor control
5	9964	Centralized door lock motor control
6	8863	Window lifter motor control
7	8865	Window lifter motor control
8	0000	Mass
9	0064	Centralized door lock
10	0065	Centralized door lock
11	0000	Negative for Centralized door lock
12	0000	Negative for main rearview mirror heating
13	-	Free
14	0000	Free
15	2991	K line for diagnosis
16	7991	Positive for center power
CONNECTOR J2		
Pin	Cable	Function
1	Ws/Bi	CAN H line (BCB)
2	-	Free
3	-	Free
4	-	Free
5	-	Free
6	8806	Main rearview mirror control (return)
7	Gv/Ve	CAN L line (BCB)
8	-	Free
9	-	Free
10	-	Free
11	8809	Main rearview mirror control (horizontal)
12	8808	Main rearview mirror control (vertical)
CONNECTOR J3		
Pin	Cable	Function
1	0962	Negative from passenger side window lifter push button
2	0966	Negative from passenger side window lower push button
3	0967	Negative from operator side window lifter push button
4	-	Free
5	-	Free
6	0953	Negative from right rearview mirror control push button (movement to the right)
7	0954	Negative from left rearview mirror control push button (movement to the left)
8	0951	Negative from right rearview mirror control push button (movement downwards)
9	0952	Negative from left rearview mirror control push button (movement upwards)
10	4442	Positive for passenger/operator side window push button lighting
11	0961	Negative from passenger side window lower push button
12	0960	Negative for passenger side window control push button + lighting
13	0951	Negative for operator side window control push button + lighting
14	-	Free
15	0950	Negative for rearview mirror control joystick push buttons
16	0600	Negative for rearview mirror control joystick push button lighting
17	-	Free
18	-	Free
19	4442	Positive for rearview mirror control joystick push button lighting
20	-	Free


C.B. (Cab module) Opt

73667



50239

A. Location on the vehicle

Connectors


49723

CONNECTOR J1		
Pin	Cable	Function
1 - 2 - 3	-	Free
4	-	Free
5	-	Free
6	8886	Wiper pump
7	8821	Light wiper pump
8	0000	Mass
9 ÷ 14	-	Free
15	2993	K line
16	7993	Power
CONNECTOR J2		
Pin	Cable	Function
1	-	CAN H line (BCB)
2 ÷ 4	-	Free
5	6656	ST 14 - 5
6	1165	ST 14 - 3
7	-	CAN L line (BCB)
8 ÷ 11	-	Free
12	5515	ST 14 - 4
CONNECTOR J3		
Pin	Cable	Function
1 ÷ 2	-	Free
3	5521	Wiper fluid level sensor
4 ÷ 5	-	Free
6	-	Free
7	-	Free
8	-	Free
9 ÷ 20	-	Free


S.W.I. (Steering wheel / steervator interface)

The function of this electronic center located on the steering column is to group together all controls from the two steervator levers and the steering wheel.

It is connected to the vehicle electronic system via a CAN line.




UPPER VIEW



FRONT VIEW

50240


SWI functions




50241

Inputs	Outputs
Key switch	Messages on CAN line
Cruise Control keys	
Programmed speed limitation	Control lighting
INTARDER lever	
Flood/dipped lights	
Direction indicators	
Windshield wiper	
Controls on steering wheel	

Connectors



A / B



C / D


50240

A – Right lever		B – Left lever		C – Steering wheel		D	
1	Cruise Control (Resume)	1	-	1	Display page selection	1	+ 30
2	Cruise Control (Set/Acc.)	2	-	2	Display cursor movement (high)	2	-
3	Speed Limiter	3	Wiper electro pump controls	3	Horn	3	CAN H
4	Intarder (pos.2)	4	Wiper (top speed)	4	Lever lighting (output)	4	CAN L
5	Intarder (pos.4)	5	Direction indicators (right)	5	Mass	5	Mass
6	Intarder (pos.6)	6	Mass	6	Menu selection / confirmation	6	Lever lighting (input)
7	AUX 1	7	Flood lights on	7	Main display return (instruments)	7	-
8	Cruise Control (deceler.)	8	Light flashes	8	Display cursor movement (low)	8	Horn (output)
9	Intarder (pos.1)	9	Wiper (one stroke)	9	Control (-)	9	AUX 2
10	Intarder (pos.3)	10	Wiper (intermittent)	10	Control (+)	10	Mass
11	Intarder (pos.5)	11	Wiper (low speed)				
12	Mass	12	Direction indicators (left)				


SPIRALED CONTACT

Located below the steering wheel.

Its function is to collect all controls present on the steering wheel and send them to the SWI center.




49837




49724

ROTOR UPPER VIEW



49725


STATOR LOWER VIEW

STEERING COLUMN (COMPONENT LOCATION)

74000

A. S.W.I center. - B. Steervator - C. Spiraled contact - D. Start block

NOTE. Follow the procedures described in the following pages in case of spiraled contact disassembly.




72850

Carefully follow the procedures described hereunder to replace the spiraled contact, to avoid damaging the spiraled cable contained in its box when disassembling and aligning the steering wheel incorrectly.

Disconnect mass cable connection (4).

Remove nut (1) and mark steering wheel assembly position on shaft (2) and remove the steering wheel.




74000

Disconnect electrical connections (6 and 7) from the S.W.I.

Secure contact rotor (9) to its container by inserting key (10) into slots (11 and 12), to prevent rotor (9) and stator (8) from rotating during disassembly.

Keep this situation until assembly. In the lack of a key, use an adequate size nut and bolt.

Carefully raise the contact so elastic retainer pins (13) are removed from support (14). Store it carefully.




72857

Invert the sequence of operations described above for reassembly.

The spiraled contact is supplied spare with its stop key (15) assembled as shown in the figure. After assembly on the steering wheel control support, rotate the key to cause breakage at the point indicated by the arrow and return it to steering wheel seat (5).

B.M. (BED MODULE) OPT

The B.C. is located above the bed against the cab wall.



The B.C. identifies its presence but CANNOT be diagnosed.


Its functions are as follows

(variable configuration according to vehicle accessories):

- ☐ Indication of hours and minutes
- ☐ Internal cab light on/off (white/night lights selection)
- ☐ Doors open/closed
- ☐ Electrical windows open/closed
- ☐ Electrical cavity open/closed
- ☐ Sunshields up/down
- ☐ Radio CD on/off
- ☐ Radio volume adjustment
- ☐ Radio tuning
- ☐ Alarm clock function
- ☐ Supplementary heater on/off
- ☐ Temperature adjustment (only with connected supplementary heater). (Automatic)
- ☐ Heater ignition length adjustment (max. 9 hours)

NOTE Press the switch on the instrument panel before adjusting heater temperature.

**CONTROL PANEL ON REAR WALL
(ALTERNATIVE TO BED MODULE)**



79495

Ref.	Description
1	12V current outlet
2	Left window regulator
3	Electric trapdoor
4	Central roof lamp cabin lights
5	Right window regulator

BED MODULE unit or CONTROL PANEL on rear wall can be present only on AT model (long cabin).


AUTOMATIC AIR CONDITIONER

In automatic version the system is managed by an electronic unit placed in the lower part of central dashboard and integrates control knobs.

The electronic unit is connected to vehicle **CAN BCB** line and is equipped with a very advanced diagnostic system.

The main objective of the unit is adjusting internal cabin temperature (set by the driver) depending on external temperature measured by a suitable sensor.

The system provides for the chance of a completely automatic management, but anyway for the user it is always possible, if he so wishes, to modify the main system operating parameters.



73668 B

1. Required temperature adjusting knob
2. Fan speed adjusting knob
3. Air flow distribution knob
4. Recirculation function button with embedded led
5. Compressor control button with embedded led
6. Internal temperature sensor

After having set the desired internal temperature, by placing the other two knobs next to letter **A**, the unit is able to automatically check the following functions:

- Air temperature to unions.
- Fan speed
- Air flows distribution
- Supplementary heater connection if external temperature is $< 5^{\circ}\text{C}$.

In this position the unit does **NOT automatically activate** either compressor or recirculation function: connection of both of them is manually managed by the driver.

"RECIRCULATION" FUNCTION

Connection of this function is **completely manual** and is obtained through a suitable button that allows closing the external air intake by placing the baffle at 95% of internal air and 5% of external air.

The unit **automatically deactivates** this function after about 20 minutes if the compressor is disconnected and after 30 minutes if the compressor is connected.

"COMPRESSOR CONTROL" FUNCTION

Connection of this function is completely manual and is obtained through a suitable button that allows connecting the compressor clutch after a quality check of fluid in the system through safety pressure switches and evaporator temperature by means of the suitable sensor.

The unit does **NOT** automatically connect the compressor.

"SUPPLEMENTARY HEATER CONTROL" FUNCTION


With moving engine the unit automatically connects the supplementary AIR and/or WATER heater only if the external temperature is $< 5^{\circ}\text{C}$.

With off engine the heater connection depends on driver's setting.

In both cases, the supplementary heater connection is signalled to the driver on Cluster display.

AUTOMATIC AIR CONDITIONER


Automatic air conditioner block diagram



73700

42045. Water temperature transmitter - **82000.** Windscreen electric defroster assembly - **82010.** Air conditioner control electronic unit - **86030.** Sun radiation measuring sensor - **84009.** Vented internal temperature measuring sensor - **42608.** Cooling liquid pressure signaling pressure switches - **25332.** Compressor connection remote control switch - **78227.** 3-way solenoid valve for radiator water recirculation - **84019.** Compressor


Components **82010** - **82000** are placed in the same control assembly.

Component location

77561

42045. External temperature transmitter - **82000.** Windshield defroster unit - **82010.** Conditioner electronic control centre - **86030.** Sun ray detection sensor - **84009.** Internal temperature detection sensor - **42608.** Coolant pressure warning pressure switches - **25332.** Compressor on remote control switch - **78227.** Radiator coolant recirculation electro valve - **84019.** Compressor - **86116.** Body Computer - **72021.** 30-pole connector for diagnosis

Windscreen electric defroster assembly components location




A. Floor reduction gear - B. Windshield defrost reduction gear motor - C. Recirculation reduction gear motor - D. Mixing reduction gear motor - E. Blown temperature sensor - F. Evaporator temperature sensor - G. Blower control module - H. Expansion valve

77562

External temperature sensor


Located on the driver side vehicle front so it is invested by external temperature, as close as possible to reality. Its resistance at 25 °C = ~ 10 Kohm



77566

Main interior temperature sensor

Located on the right inside the control module and ventilated by a motor enabling air circulation and preventing erroneous temperature readings between values measured and the cab. Its resistance at 25 °C = ~ 10 Kohm




77567

Evaporator temperature sensor

The sensor placed inside the evaporator generates compressor connection and disconnection.


Disconnection to avoid dispenser freezing occurs at a temperature $< 2\text{ }^{\circ}\text{C}$, while connection at a temperature $> 5,5\text{ }^{\circ}\text{C}$. Its resistance at $25\text{ }^{\circ}\text{C} = \sim 3,28\text{ Kohm}$



77559

Blown air temperature sensor


Located downstream the heat exchanger, it gives the temperature of air inlet into the cab and enables the centre to adjust more properly. Its resistance at $25\text{ }^{\circ}\text{C} = \sim 10\text{ Kohm}$



77574



Sun ray sensor

It is a photodiode placed on vehicle dashboard to point out luminous intensity that the cabin receives from outside.




A) Sensor

77563



77564



77565


Reduction gear motors

The four automatic system units are located in the heater/conditioner inside the cab, according to their functions. Their electrical features are the same.


They are activated directly by the electronic centre at 24 V rated voltage and absorb from 20 to 40 mA. Motor resistance = $\sim 112 \text{ Ohm}$.

Maximum absorption at travel end is 200 mA, when the centre cuts supply off.


Their potentiometer is used as a return signal and when first lit, the centre detects and stores end travel values to divide the operating field. It is supplied at 5V, its resistance = $\sim 5 \text{ Kohm}$.



77571



77572



77573

Pin-out


Pin	Cable colour	
1	White	+/- 24V
2	Violet	+/- 24V
3	Blue	0V
4	Orange	0 ÷ 5V
5	Green	+ 5V
6	-	Free

NOTE If a ratio motor is replaced, it is MANDATORY to carry out the system RESET by disconnecting and reconnecting vehicle batteries.

Blower control module

This electronic circuit located in the heater/conditioner unit adjusts double fan radial blower speed with some 200 different rates in the automatic mode and 8 in the manual mode.

The module is driven by the unit with a signal from 0 to 5 Volts while fans with a voltage from 0 to 24 Volts.



74244

A. Blower control module

Pin	Cable	Function
1	0000	Negative direct from the battery
2	7555	Centre control positive
3	7551	Positive direct from the battery


Solenoid valve (3 ways)

This one-directional NA unit is supplied by a battery-directed positive.


The electronic centre adjusts its duty cycle by supplying a mass.

This three-way valve performs all dosing and by-pass functions.


It is supplied by a battery-directed positive and is piloted by the negative supplied by the centre monitoring the duty cycle.



77569




77568



77570

Compressor



77144

	NIPPODENSO
	ND 10 PA 17
Coolant	R134a
Lube oil	ND80
Quantity of coolant	700g
Quantity of oil	200cc.

R134a coolant is anyhow exclusively used in the STRALIS range

Drier filter and safety pressure switches


The drier filter is integral with the condenser located on the vehicle front.

The cooling system uses R134a coolant as specified on its cover plate.


The 4-level safety pressure switch unit is installed on the condenser return line.

The two type NC and NA pressure switches keep system pressure constant from a minimum of 2.5 (for the NA) to a maximum of 25 bars (for the NC). The system is cut off when values are outside this range.


The two NA pressure switches are to cutout the engine cooling fan coil when system pressure is between 18 and 22 bars. This is achieved by means of a mass signal the two switches transmit to the Body Computer control centre.



74245



74247



77560



Expansion valve

Its function is to lower liquid pressure from the condenser to a preset value so by circulating inside the evaporator the coolant can be sucked as a gas by the compressor.

It thus completes three basic functions:

- DOSING
- MODULATING
- MONITORING

It is installed on the heater/conditioner unit close to the blower control module.




77575

The expansion valve is of the union type and is placed between drier filter and evaporator.


Its task is checking and batching the cooling fluid flow in order to obtain the maximum refrigerating power from the system and to lower the cooling liquid pressure (upon exiting the filter) to a pre-established value, so that the fluid itself, by then circulating into the evaporator, can be sucked by the compressor in a completely gaseous state.

In this valve there are two cooling fluid passages:


- The lower one that allows the cooling fluid to pass from drier filter (5) to evaporator (2). Along this path a spring (4) is placed that, suitably calibrated, allows obtaining such a temperature jump (overheating) as to ensure that the cooling fluid, upon entry the evaporator, is completely in a gaseous state. Moreover there is also a modulating element, in this case a ball (3) housed in the calibrated duct, that checks the cooling fluid flow rate to the evaporator.
- The upper one that allows the cooling fluid to pass from evaporator (1) to compressor (6). Along this path instead there is a temperature sensor (7) that, depending on the temperature upon exiting the evaporator, allows obtaining a control action on the cooling fluid flow rate, through the modulating and overheating checking element (3), through the spring (4).



77565

Conditioner control centre

74239



74248


Pin	Cable	Function
1	-	-
2	7550	Positive direct from the battery
3	-	-
4	2296	K line for diagnosis
5	Ws/Bi	CAN - H (BCB) line
6	9993	Outgoing positive compressor electromagnetic clutch signal
7	7568	Mixer reduction gear motor power supply
8	7566	Recirculation reduction gear motor power supply
9	0562	Floor reduction gear motor power supply
10	7564	Windshield defrost reduction gear motor power supply
11	-	-
12	0550	Sensor and reduction gear motor mass
13	7572	Evaporator temperature reference signal
14	7574	Sun ray sensor signal
15	7565	Recirculation potentiometer reference voltage
16	7561	Floor potentiometer reference voltage
17	-	-
18	2290	Internal temperature sensor motor signal
19	-	-
20	7555	Outgoing positive blower control module signal
21	0000	Negative direct from the battery
22	9552	Outgoing negative electro valve signal
23	-	-
24	-	-
25	Gn/Ve	CAN - L (BCB) line
26	0568	Mixer reduction gear motor power supply
27	7569	Internal temperature sensor motor power supply
28	0566	Recirculation reduction gear motor power supply
29	-	-
30	0564	Windshield defrost reduction gear motor power supply
31	7562	Floor reduction gear motor power supply
32	7575	Internal temperature sensor signal
33	7571	Blow air temperature reference signal
34	7567	Recirculation potentiometer reference voltage
35	7563	Windshield defrost potentiometer reference voltage
36	7560	5-Volt Mix / Floor / Rec / Defrost potentiometer signal
37 ÷ 40	-	-

MANUAL AIR CONDITIONER

Manual version

In the manual version the refrigerating circuit and heater checks occur by means of a device with leverages and knobs placed in the lower part of the central dashboard.

The system is checked by an electronic unit but by means of knob controls used for the following functions:



1. Heating water cock control
2. Internal fans speed
3. Air flows distribution
4. Compressor control switch
5. Recirculation function switch

73668 C

CONTROLS DESCRIPTION

WATER COCK CONTROL

The knob rotation adjusts water cock position and consequently the amount circulating inside the cabin radiator. If supplementary **WATER** heater is present, this knob controls three microswitches used for the following functions:

- 20%** supplementary heater water pump activation
- 60%** top flap closing motor activation (TOP FLAP)
- 80%** supplementary heater connection

If supplementary **AIR** heater is present, this knob controls two microswitches used for the following functions:

- 60%** top flap closing motor activation (TOP FLAP)
- 85%** supplementary heater connection

NOTE The **motor** for **TOP FLAP** function is present only in manual version, since in automatic version this function is performed through a bowden cable connected to air mixing motor (MIX).

- Maximum heating = TOP FLAP closed
- Maximum cooling = TOP FLAP open

INTERNAL FAN SPEED

This knob is composed of a multiple switch that controls three adjusting resistances for different motor speeds.

AIR FLOWS DISTRIBUTIONS

This control through bowden cables allows distributing the air flows in the desired cabin areas.

RECIRCULATION FUNCTION SWITCH

This button allows, through a specific motor, closing the external door with a percentage of 95% of internal air and 5% of external air.

The motor has no position sensors since it works only under the two all-closed or all-opened conditions.

On the button there is a yellow-coloured led that signals its connection.

There is no time limit for this function.


COMPRESSOR CONTROL SWITCH

This button allows connecting the air conditioner compressor.

The clutch closure is constrained by safety system pressure switches and by fixed-calibration evaporator thermostat. Such thermostat, of the mechanical type, adjusts the temperature inside the evaporator in order to disconnect the compressor clutch upon reaching $\sim 2^{\circ}\text{C}$ and reconnect it at $\sim 5.5^{\circ}\text{C}$.

The compressor operation is constrained by the manual connection of at least one fan speed.

A yellow-amber-coloured led is present on the button and signals the compressor connection.

Block diagram

42045. External temperature sensor - 82000. Windscreen defroster assembly - 84009. Internal temperature sensor - 42608.
Cooling fluid safety pressure switches - 25332. Compressor connection remote control switch - 84019. Compressor

RATIO MOTORS

In manual system **there are two ratio motors** placed on heater assembly
They are composed of a motor without potentiometers and have the same electric characteristics.


The ratio motors are used to perform the following functions:

RECIRCULATION (RIC)

TOP FLAP (TOP FLAP)

MOTORS

- They are supplied at **24 V**.
- Motor resistance is **~112 Ohm**.
- No-load absorption is **about 30 mA**.
- Limit absorption is **about 200 mA**.

Air conditioner fuses remote control switches

73668 C

Black-coloured fuse-holder (70604)

Position	Description	Delivery A
1	Air conditioning system	15
2	Air conditioning system	15
3	Air conditioning system	5
4	Supplementary heating	15
5	Supplementary heating	5
6	CM (Cabin Module)	20

Ref.	Description	Component code
D	Manual conditioner remote control switch	25545
E	Water heated remote control switch	25325
G	Manual conditioner remote control switch	25544
I	Manual conditioner remote control switch	25874
K	Manual conditioner remote control switch	25310
M	Manual conditioner remote control switch	25322
N	Manual conditioner remote control switch	25332
P	Manual conditioner remote control switch	25327
R	Manual conditioner remote control switch	25332

HYDRONIC D 10 WATER HEATER

System operation

By connecting the burner, the electronic unit controls water pump, fuel batching pump, burner motor and ignition spark plug.

The water pump circulates the cooling liquid in the cooling circuit of the engine to be heated.

The burner motor sucks and inserts the right amount of air necessary for combustion.

The ignition spark plug heats air and burns fuel injected by the batching pump.

Purpose of the batching pump is taking and injecting fuel onto spark plug.

After 90 seconds, the unit, through the flame sensors, checks that the exhaust gases temperature value is included between **500 and 600 °C**, (ignition has correctly occurred).

Upon reaching about **700 °C** the unit disconnects the spark plug and the burner works in self-combustion.

If the flame sensor does not measure the above temperature, thereby the burner is not turned on, the unit repeats the ignition procedure. If it does not start again, the unit turns the burner off and it will then be mandatory to manually switch it on again.

If the heater does not start for three consecutive times, it is blocked.

The unit checks, through water temperature sensor and overheating sensor, whether combustion and burner correctly operate.

The **water temperature sensor** is used by the unit to adjust the burner working power (maximum, medium, minimum and stand by).

In the manual version, upon reaching **55 °C**, the system connects the fans inside the cabin.

The **overheating sensor** is used by the unit to turn the burner off in case of excessive water temperature (about **115 °C**).


The burner operating time is determined by driver's settings.

Upon turning off, the burner performs a washing phase that lasts for about 3 minutes in order to be ready for the following starting.

The heater is connected with its own control logic in the air conditioning system and is therefore equipped with an electronic unit with related connector.

The unit is directly assembled onto the heater.

The heater can be directly driven by the automatic air conditioning system, by the version with manual control or through the Bed Module unit.

COMPONENTS LOCATION**Key**


A	Thermostat 65 °C
50005	Cluster
52002	Heater connecting switch
52092	Cabin/engine heating switch
72021	30-pole diagnosis connector
78237	Two-way solenoid valve (D+)
84000	Supplementary water heater
84005	Heater control electronic unit
84014	Fuel batching pump
86053	Bed Module
86116	Body Computer

SYSTEM COMPONENTS

- 1) Burner motor
- 2) Flame sensor
- 3) Combustion chamber
- 4) Burner control unit
- 5) Ignition spark plug
- 6) Water temperature sensor
- 7) Flame pipe
- 8) Heat exchanger
- 9) Overheating sensor
- 10) Water pump
- 11) Silencer
- 12) Air suction pipe
- 13) Fuel batching pump
- 14) Bed Module unit
- 15) Automatic Webasto air conditioner electronic unit
- 16) Cabin/engine heating and heater connecting switch
- 17) Air conditioner control dashboard for manual version
- 18) Cluster

Connection to circuit

- WE.** Water inlet
WA. Water outlet
V. Comburent air inlet
B. Fuel supply
A. Exhaust gases outlet



65 °C THERMOSTAT

It is assembled on the right vehicle side near the burner and has been inserted in order to allow quickly heating the cabin when the engine is off.

It is equipped with a temperature-sensitive membrane calibrated at 65 °C.

With temperature < 65 °C water will only circulate in cabin (small circuit).

With temperature > 65 °C the thermostat switches its position, allowing water to circulate both in cabin and in engine, heating them both (big circuit).

3-WAY SOLENOID VALVE

In the WEBASTO air conditioning system there is a single 3-way solenoid valve that performs the function of batching and bypassing cooling water from engine to radiator inside the cabin.

The valve is placed next to the front left side of the engine (driver side).

It is of the Normally Open type at rest and is supplied by a direct battery positive.

The electronic unit, by providing it with a mass, adjusts its working cycle (Duty-Cycle).

WATER PUMP

The water pump is directly assembled on the lower part of the burner.

It is used to circulate the engine cooling water in the circuit.

The supply voltage is **24 Volt**.

The minimum flow rate is **about 500 l/h**.

FUEL BATCHING PUMP

It is assembled on the chassis next to fuel tanks with a slant of 15° to facilitate air drain. It is used to take and inject gas oil inside the burner.

The unit supplies the pump with a pulse signal.

For a correct operation the internal delivery pipe diameter must be **2 mm** and must not exceed the length of **5 meters**.

It embeds a small fuel filter and a unidirectional check valve.

The fuel flow rate is **about 0.2 l/min**.

WATER TEMPERATURE SENSOR

It is a **PTC sensor** assembled on heat exchanger; it measures different water temperatures in order to adjust the burner power and, only in manual version, upon reaching **55 °C**, it allows connecting the fans.

The sensor resistance at **20 °C** is **~950 Ohm**.

FLAME SENSOR

It is a **PTC sensor** assembled inside the combustion chamber next to the exhaust gas outlet and measures the current temperature, in order to disconnect the spark plug in case the burner has not been turned on.

It disconnects the spark plug at an exhaust gas temperature of about **700 °C**

The sensor resistance at **20 °C** is **~1080 Ohm**.

IGNITION SPARK PLUG

It is a **resistance** placed inside the combustion chamber.

The unit supplies it with pulses through an internal electronic regulator.

The rated operating voltage is **18 Volt** to allow its operation also with battery voltages of ~ 22 Volt.

The resistance at **20 °C** must be **< 2 Ohm**.

OVERHEATING SENSOR

It is a **temperature sensor** assembled on the heat exchanger, it measures the different water temperatures to possibly disconnect the burner upon reaching about **115 °C**

In case of intervention the sensor restores itself autonomously. It is not of the manual restoring type.

The sensor resistance at **20 °C** is **~ 10 K Ohm**.

BURNER MOTOR

It is embedded into the assembly in the rear burner part.

The rotation speed is managed by the unit by means of an integrated electronic regulator.

It embeds an inductive sensor that measures the engine rotation speed.

ELECTRONIC UNIT

It is directly assembled on heater body and is interfaced with vehicle through a 14-pin connector.

It is connected to **CAN BCB** line.

It has a very advanced diagnostic system and transmits possible error codes on vehicle Cluster.

Pin	Cable	Function
A1	7506	Positive from water cock knob manual version (25% position)
A2	7711	Positive from boiler activating switch
A3	Ws/Bi	CAN H line
A4	7775	Positive for ambient thermostat control (manual version)
B1	Gn/ve	CAN H line
-	-	-
B3	2296	Diagnosis K line
B4	6605	Positive for cabin/engine heating key warning light
-	-	-
C2	7708	Direct positive from battery
C3	0000	Direct negative
C4	7783	Positive for fuel batching pump control
-	-	-
-	-	-

IMMOBILIZER

Description and operation

Vehicles are provided with an immobilizer engine lock that is activated automatically by removing the starter key, to increase protection against theft. Keys are provided with an electronic transponder that transmits a coded signal to an ICU centre that only enables engine start at code recognition.

General features

System composition

The system can be summarised as consisting of the following main components:

- Immobilizer central unit ICU
- 2 steering lock keys with integrated transponder
- Antenna on the ignition circuit breaker
- EDC fuel flow actuator
- Code-card with mechanical and electronic PIN code

Installation

The system requires the following installation steps for proper operation:

- Learning key use
- Learning actuation function

At operation end, the immobilizer centre is enabled to recognise any mishandling by recognising its univocally and inseparable components.

Operating principle

With the key on START, the transponder contained inside the keys generates a code received by the immobilizer centre remote control switch via the antenna.


The immobilizer centre sends the code received by the antenna to the EDC centre, whose actuator decodes and compares it with data stored during the installation process. Ignition is enabled if the code is found to be exact.

Three keys are provided, two of which with a transponder integrated into the handle and a mechanical one without a transponder.

If the engine is started with the latter key, a request for an electronic code password is displayed on the cluster.

Follow the instructions given on diagnosis tool displays for key hang-up.

Componentry




49523

Componentry

Ref.	Description
1	Immobilizer control centre
2	Code-card
3	Electronic key
4	Antenna
5	Cluster
6	Electro injectors
7	EDC injection control electronic centre
8	IMMOBILIZER down warning light
9	Body Computer

Immobilizer electronic centre




74251

Ref.	Description
1 A 2 3	Antenna Antenna -
1 2 3 B 4 5 6 7 8	CAN - L (VDB) line K line for 30-pole Pin 2 diagnosis connector Immobilizer down warning light cluster CAN - H (VDB) line - Mass +15P power supply positive under key -

Emergency start procedure

It enables engine start when the key cannot be recognised or the IMMOBILIZER centre is down. Entering the electronic code shown on the CODE CARD and operating the steering wheel push buttons can start the engine.



- 1) Turn the key to START.
- 2) The display shown in the figure appears.
- 3) Select the first digit of the ELECTRONIC CODE with push buttons ARROW UP and ARROW DOWN (A).
- 4) Confirm the digit selected with OK (C).
- 5) Continue with the remaining digits of the ELECTRONIC CODE.
- 6) When the entire ELECTRONIC CODE is entered, select (B) and confirm with OK (C).

EDC

Engine management - EDC System

The MS6.2 electronic center manages the following main functions:

Fuel injection

Accessory functions such as cruise control, speed limiter, PTO and the like

Turbine geometry variations

Engine brake cut-it

Self-diagnosis

Recovery

It also enables:

Interfacing with other on-board electronic systems

Diagnosis

Fuel dosing

Fuel dosing is calculated based on:

- accelerator pedal position
- engine rpm
- quantity of air admitted.

The result can be corrected based on:

- water temperature

or to prevent:

- noise
- fumes
- overloads
- overheating
- turbine over rpm

Pressure can be adjusted in case of:

- engine brake actuation
- actuation of external devices such as ASR, speed limiter and the like
- serious defects involving load reduction or engine stop.

After determining the mass of air introduced by measuring its volume and temperature, the center calculates in mg per delivery the corresponding mass of fuel to be injected into the cylinder involved, with account also taken of gas oil temperature.

The mass of fuel thus calculated is first transformed into volume (in mm³ per delivery) and then in flywheel degrees, that is to say injection duration.

Delivery correction based on water temperature

When cold, the engine encounters greater operating resistance, mechanical friction is high, oil is still very viscous and operating plays are not optimized yet.

Fuel injected also tends to condense on cold metal surfaces.

Fuel dosing with a cold engine is therefore greater than when hot.

Delivery correction to prevent noise, fumes or overloads

Behaviors that could lead to the defects under review are well known, so the designer has added specific instructions to the center to prevent them.

De-rating

In the event of engine overheating, decreasing delivery proportionally to the temperature reached by the coolant changes injection.

Turbine rpm adjustment

Turbine speed is adjusted continuously and corrected by acting on geometry, if so required.

Injection lead electronic control

Injection lead, or the start of fuel delivery expressed in degrees, can differ from one injection to the next, even from one cylinder to another and is calculated similarly to delivery according to engine load, namely, accelerator position, engine rpm and air admitted. Lead is corrected as required:

- during acceleration
- according to water temperature

and to obtain:

- reduced emissions, noise abatement and no overload
- better vehicle acceleration

High injection lead is set at start, based on water temperature.

Delivery start feedback is given by injection electro valve impedance variation.

Speed adjuster

The electronic speed adjuster features both regulator characteristics:

- minimum and maximum
- all rpm levels

It remains stable in ranges where conventional mechanical adjusters become imprecise.

Engine start

Cylinder 1 step and recognition signal synchronization (flywheel and drive shaft sensors) takes place at first engine turns. Accelerator pedal signal is ignored at start. Star delivery is set exclusively based on water temperature, via a specific map. The center enables the accelerator pedal, when it detects flywheel acceleration and rpm such as to consider the engine as started and no longer drawn by the starter motor.

Cold start

Pre-post reheating is activated when even only one of the three water, air or gas oil temperature sensors records a temperature of below 10 °C. The pre-heat warning light goes on when the ignition key is inserted and stays on for a variable period of time according to temperature, while the intake duct input resistor heats the air, then starts blinking, at which point the engine can be started.

The warning light switches off with the engine revving, while the resistor continues being fed for a variable period of time to complete post-heating. The operation is cancelled to avoid uselessly discharging the batteries if the engine is not started within 20 ± 25 seconds with the warning light blinking. The pre-heat curve is also variable based on battery voltage.

Hot start

On inserting the ignition key the warning light goes on for some 2 seconds for a short test and then switches off when all reference temperatures are above 10 °C. The engine can be started at this point.

Run Up

When the ignition key is inserted, the center transfers data stored at previous engine stop to the main memory (Cf. After run), and diagnoses the system.

After Run

At each engine stop with the ignition key, the center still remains fed by the main relay for a few seconds, to enable the microprocessor to transfer some data from the main volatile memory to an non-volatile, cancelable and rewritable (Eeprom) memory to make tem available for the next start (Cf. Run Up).

These data essentially consists of:

- miscellaneous settings, such as engine idling and the like
- settings of some components
- breakdown memory

The process lasts for some seconds, typically from 2 to 7 according to the amount of data to be stored, after which the ECU sends a command to the main relay and makes it disconnect from the battery.

This procedure must never be interrupted, by cutting the engine off from the battery cutout or disconnecting the latter before 10 seconds at least after engine cutout.

In this case, system operation is guaranteed until the fifth improper engine cutout, after which an error is stored in the breakdown memory and the engine operates at lower performance at next start while the EDC warning light stays on.

Repeated procedure interruptions could in fact lead to center damage.

Cut-off

This is the delivery cutout function during deceleration, engine braking and the like.

Cylinder Balancing

Individual cylinder balancing contributes to increasing comfort and operability.

This function enables individual personalized fuel delivery control and delivery start for each cylinder, even differently between each cylinder, to compensate for injector hydraulic tolerances.

Delivery flow differences between the various injectors cannot be assessed directly by the center, this information being supplied by entering the code for each injector via the Modus.

Synchronization search

The center can anyhow recognize the cylinder to inject fuel into even in the absence of a signal from the camshaft sensor.


If this occurs when the engine is already started, combustion sequence is already acquired, so the center continues with the sequence it is already synchronized on; if it occurs with the engine stopped, the center only actuates one electro valve. Injection occurs inside that cylinder within 2 shaft revs at the utmost so the center is only required to synchronize on the firing sequence and start the engine.

The center is mounted directly on the engine via a heat exchanger to enable cooling via elastic pads that minimize engine-induced vibration, to reduce the number of connections, the length of cables connecting with the injectors and all disturbances to the signal transmitted.


It is connected to the vehicle via two 35-pole connectors:
connector "A" for components present on the engine
connector "B" for cab components.

An internal environment pressure sensor is provided for further improved injection system management.

The center is provided with an advanced self-diagnosis system capable of identifying and storing any intermittent environmental anomaly to the system during vehicle operation to ensure the most correct and efficient repair.


F3A components on engine

ENGINE RIGHT SIDE VIEW




ENGINE LEFT SIDE VIEW

A. ENGINE RPM SENSOR ON DISTRIBUTION SHAFT - B. ENGINE REHEAT RESISTOR - C. ENGINE AIR INTAKE TEMPERATURE SENSOR - D. OVER-FEED PRESSURE SENSOR - E. ALTERNATOR - F. ENGINE OIL LEVEL SENSOR (OPTIONAL) - G. EDC (MS6) CENTER - H. ENGINE MASS POINT - I. STARTER MOTOR - J. FUEL TEMPERATURE SENSOR - K. TURBINE SPEED SENSOR - L. ENGINE RPM ON FHYWHELL SENSOR - M. VARIABLE GEOMETRY TURBINE CONGROL ELECTRO VALVE - N. TURBINE ACTUATOR PRESSURE SENSOR - O. CLOGGED FUEL FILTER WARNING SWITCH - P. LOW OIL PRESSURE TRANSMITTER - Q. OIL PRESSURE TRANSMITTER - R. EDC WATER TEMPERATURE SENSOR - S. WATER TEMPERATURE SENSOR - T. CONNECTOR ON ENGINE EAD FOR CONNECTION TO INJECTOR ELECTRO VALVES - U. ENGINE BRAKE ELECTRO VALVE

F2B (Cursor 8) components on engine

7871

ENGINE RIGHT-HAND SIDE VIEW




7872

ENGINE LEFT-HAND SIDE VIEW

A. ENGINE RPM SENSOR ON CAMSHAFT - B. RESISTANCE FOR ENGINE WARMING - C. ENGINE INTAKE AIR TEMPERATURE SENSOR - D. BOOSTING PRESSURE SENSOR - E. ALTERNATOR - F. ENGINE OIL LEVEL SENSOR (OPTIONAL) - F/I. AIR CONDITIONER COMPRESSOR - G. EDC (MS6) CONTROL UNIT - H. EARTH POINT ON ENGINE - I. STARTER MOTOR - J. FUEL TEMPERATURE SENSOR - K. TURBINE SPEED SENSOR - L. ENGINE SPEED ON FLYWHEEL SENSOR - M. SOLENOID VALVE FOR VARIABLE GEOMETRY TURBINE CONTROL - N. TURBINE ACTUATOR PRESSURE SENSOR - O. FUEL FILTER CLOGGED SIGNALLING SWITCH - P. LOW OIL PRESSURE TRANSMITTER - Q. OIL PRESSURE TRANSMITTER - R. WATER TEMPERATURE FOR EDC - S. WATER TEMPERATURE SENSOR - T. CONNECTOR ON ENGINE HEAD FOR CONNECTION WITH INJECTOR SOLENOID VALVES - U. ENGINE BRAKE SOLENOID VALVE

EDC system operating diagram




74204

Ref.	Description	Component code
1	Cluster (optical indicators, engine coolant temperature, preheating, engine brake, Speed Limiter, rpm counter)	50005
2	Automatic trasmissione electronic centre	86004
3	Tachograph	40011
4	EDC remote control switch	25294
5	Turbine rpm sensor	48043
6	V.T. air pressure sensor	85154
7	VGT control electro valve	78248
8	Engine brake electro valve	78050
9	Electro injectors	78247
10	30-pole diagnosis connectors	72021
11	Engine preheat resistor on remote control switch	25222
12	Engine preheat resistor	61121
13	Distribution rpm sensor	48042
14	Engine rpm sensor	48035
15	Air pressure sensor	85158
16	Air temperature sensor	85155
17	Coolant temperature sensor	85153
18	Fuel water temperature sensor	47042
19	Accelerator load sensor	85152
20	Manual gearshift clutch switch	42374
21	FFC Multiplex centre	86117
22	Engine fan electro valve	78116
23	Direction indicator	54030
24	SWI Multiplex centre	86123
25	Conditioner coolant pressure warning pressure switch unit	42608
26	EBS centre	88005
27	Body Computer Multiplex centre	86116



The EDC installed on this new vehicle range is very similar to the previous one, the difference being, as specified on the general diagram shown in the figure above, the introduction of new centres interfacing with the EDC centre via different can lines (VDB: EDC con Cluster, Body Computer, EBS, Eurotronic).

A speed dependant compressed air or electrical control engine cooler fan controlled via a VDB can line by an FFC centre is also provided (F3A).

A fan is available for F2B.

EDC 6.2 electronic center


Connector "A" engine



Connector "B" frame/cab

PIN OUT Center

Pin	Connector "A" (Engine area)	Cable color code
1	Flywheel sensor	B
2	Distribution flywheel sensor	B
3	Engine brake control electro valve	M
4	Turbofan air temperature sensor	N
5	Coolant temperature sensor	S
6	Fuel temperature sensor	B/R
7	Turbo compressor speed sensor	B
8	-	-
9	-	-
10	-	-
11	Fuel temperature sensor	C/N
12	Over feed pressure sensor	V
13	Flywheel sensor	M
14	Distribution flywheel sensor	M
15	Air pressure in turbine actuator sensor	Z
16	Turbo compressor speed sensor	M
17	Air over feed pressure sensor	B
18	Variable geometry turbine control electro valve	M
19	Air pressure in turbine actuator sensor	H
20	-	-
21	Air over feed temperature sensor	C
22	Coolant temperature sensor	G
23	Air over feed temperature sensor	R
24	Electronic injection electro valve (1-2-3)	R
25	Electronic injection electro valve (4-5-6)	N
26	Electronic injection electro valve (4)	L
27	Electronic injection electro valve (5)	H
28	Electronic injection electro valve (6)	Z
29	-	-
30	-	-
31	Variable geometry turbine control electro valve	B
32	Engine brake control electro valve	L
33	Electronic injection electro valve (3)	V
34	Electronic injection electro valve (2)	G
35	Electronic injection electro valve (1)	B


CONNECTOR A

000576t

Color code	
B	White
BG	Beige
C	Orange
G	Yellow
H	Gray
L	Blue
M	Brown
N	Black
R	Red
S	Pink
V	Green
Z	Violet

Pin	Connector "B" (cab/frame area)	Cable color code
1	Mass	0150
2	Mass	0150
3	Positive (under main relay)	7155
4	Positive (under main relay)	7155
5	-	7155
6	Cluster (PIN B11)	6150
7	-	7155
8	-	7155
9	To the connector for connection with engine start PIN 23 diagnostics	5198
10	Preheat resistor input consent remote switch	0096
11	CAN Line connection (VDB)	-
12	CAN Line connection (VDB)	-
13	To connector for hookup with diagnostics (PIN 2)	2298
14	Free	-
15	Positive (+ 15) from Body Computer (J7/I)	8015
16	Load sensor on accelerator for EDC (PIN 2)	5158
17	Load sensor on accelerator for EDC (PIN 5)	0159
18	-	-
19	Free	-
20	Switch on EDC clutch (only mechanical gearshift)	8160
21	-	-
22	-	-
23	Load sensor on accelerator for EDC (PIN 1)	5157
25	Load sensor on accelerator for EDC (PIN 4)	0158
26	Brake pedal warning switch (PIN 3)	8153
27	EDC cutin remote switch (Main relay)	0155
28	-	-
29	Rev counter (pin B7)	5155
30	-	-
31	PIN 2 brake pedal switch (only with ABS)	7155
32	-	-
33	-	-
34	-	-
35	Load sensor on accelerator for EDC (PIN 3)	0157

CONNECTOR B



000576t

Pump injector (78247)

It mainly consists of three components as follows:

- A) Electro valve
- B) Pump unit
- C) Sprayer


These three parts **CANNOT** be replaced individually and are **NOT** subject to overhaul.

The pump is actuated mechanically at each cycle by a rocker arm and compresses the fuel contained in the pressure chamber.

The sprayer features the same assembly and operation as a conventional injector; it is opened by the fuel under pressure and injects it fine pulverized into the combustion chamber.

An electro valve controlled directly by the electronic center sets delivery modalities based on the control signal.

An injector holder houses the lower part of the pump injector in the cylinder head.



001694t

The electro valve is of the N.A. type.

Coil resistance is $\sim 0.56 \div 0.57$ Ohm.

Maximum operating voltage is $\sim 12 \div 15$ Amp.

Based on voltage absorbed by the electro valve, the electronic center can identify whether injection was correct or mechanical problems exist. It can also detect injector errors ONLY with the engine running or during starts.

They are connected to the electronic center with a positive common to groups of three injectors:

Cylinder 1 - 2 - 3 injector to pin A 24

Cylinder 4 - 5 - 6 injector to pin A 25.

Injectors are individually connected to the center between pins:

A24 / A35 cylinder 1 injector

A24 / A34 cylinder 2 injector


A24 / A33 cylinder 3 injector

A25 / A26 cylinder 4 injector


A25 / A28 cylinder 5 injector

A25 / A27 cylinder 6 injector


Injectors are connected to the center with connector ST - E mounted on the engine front with a twisted cable, to avoid possible electromagnetic interference problems, so junctions or repairs on it must NOT be performed.



000690t




ST - E



000691t

Pin	Cable	Function	Center Pin
A	B	Injector 1 control	A35
B	G	Injector 2 control	A34
C	-	-	-
D	-	-	-
E	V	Injector 3 control	A33
F	R	Injector 1/2/3 supply	A24
G	L	Injector 4 control	A26
H	Z	Injector 5 control	A28
I	M	Engine brake control electro valve	A3
L	C	Engine brake electro valve supply	A32
M	H	Injector 6 control	A27
N	N	Injector 4/5/6 supply	A25



000692t

Engine coolant temperature sensor (85153)

This N.T.C. type sensor located on the water outlet sump on the engine head left measures coolant temperature for the various operating logics with a hot or cold engine and identifies injection enrichment requirements for a cold engine or fuel reduction requirements for a hot engine.


The coolant temperature signal is used for display on the Cluster and to control the fan.

It is connected to electronic center pins A5/A22

Sensor behavior as a function of temperature:


- 10 °C	8,10 ÷ 10,77 kOhm
+ 20 °C	2,28 ÷ 2,72 kOhm
+ 80 °C	0,29 ÷ 0,364 kOhm

At 60 to 90 °C, voltage at A5 and A22 ranges from 0.6 to 2.4V.




TECHNICAL VIEW

8527



WIRING DIAGRAM

000602t



PERSPECTIVE VIEW

000693t

Connector	Function	Cable colour
2	To EDC center pin A 5	—
3	To EDC center pin A 22	—

Fuel temperature sensor (47042)


Features

Vendor


BOSCH
35 Nm

Maximum torque


This N.T.C. type sensor located on the fuel filter on the engine left side detects fuel temperature and enables the electronic center to measure fuel density and volume for delivery correction.




TECHNICAL VIEW



WIRING DIAGRAM



PERSPECTIVE VIEW



RESISTANCE BEHAVIOR

Connector	Function	Cable colour
2	To EDC center pin A 6	—
3	To EDC center pin A 11	—

Air temperature transmitter on manifold (85155)

Features


Vendor

BOSCH
35 Nm


Maximum torque

The device must carry Vendor identification, unit part number and manufacture date.


Together with the overfeed pressure sensor, this N.T.C. type sensor located on the intake manifold input downstream the intercooler on the engine left supplied the electronic center with the parameters required to identify proper air delivery values.




TECHNICAL VIEW



WIRING DIAGRAM



PERSPECTIVE VIEW



RESISTANCE BEHAVIOR

Connector	Function	Cable colour
1	To EDC center pin A 21	—
3	To EDC center pin A 4	—

Overfeed pressure transmitter (85154)



Features

Vendor	BOSCH
Code	B 281022 018
Operating pressure range	50 ÷ 400 kPa
Maximum torque	10 Nm

This pressure strain gauge transducer located on the intake to the intake manifold downstream the intercooler on the engine left side measures air overfeed pressure to the intake manifold.

This measurement, together with the air temperature sensor finding, enables the electronic center to exactly define the amount of air admitted to the cylinders so as to pilot injectors by adjusting fuel supply, limit noxious emissions and improve fuel consumption and engine performance.

The sensor is provided with an internal temperature correction electronic circuit to optimize pressure measurement as a function of admitted air temperature.



Connector	Function	Cable colour
1	To EDC center pin A 12	—
2	To EDC center pin A 23	—
3	To EDC center pin A 17	—

Flywheel pulse transmitter (48035)

Features


Vendor	BOSCH
Torque	8 ± 2 Nm
Resistance	880 ÷ 920 Ω

This induction type sensor located on the flywheel generates signals obtained from the magnetic flow lines that close through 54 holes in three series of 18 in the flywheel.


The electronic center uses this signal to detect the various engine ratings and pilot the electronic rev counter.

The rev counter does not operate in the absence of this signal.


This sensor's air gap is NOT ADJUSTABLE.



TECHNICAL VIEW




WIRING DIAGRAM



PERSPECTIVE VIEW

3 x 18



HOLES ON FLYWHEEL

8520

Connector	Function	Cable colour
1	To EDC center pin A 1	—
2	To EDC center pin A 13	—
3	Shields	—

Distribution pulse transmitter (48042)

Features

Vendor

BOSCH

Torque

8 ± 2 Nm

Resistance


880 ÷ 920 Ω

This induction type sensor located on the camshaft generates signals obtained from the magnetic flow lines that close through the 6 plus 1 phase teeth of a sound wheel mounted on the shaft.


The electronic center uses the signal generated by this sensor as an injection step signal.

Though electrically identical to (48035) engine rpm sensor mounted in the camshaft in is NOT interchangeable with it as it cable is shorter and it features a larger diameter.


This sensor's air gap is NOT ADJUSTABLE.



TECHNICAL VIEW




WIRING DIAGRAM



PERSPECTIVE VIEW

000606t



6 + 1



REFERENCE ON SOUND WHEEL

8520

Connector	Function	Cable colour
1	To EDC center pin A 2	—
2	To EDC center pin A 14	—
3	Shields	—

Pre-post reheat resistor (61121)

000025t


A. Pre/post reheat resistor / 0.7 Ohm

This resistor located between the cylinder head and the intake duct is used to heat air in pre/post reheat operations. By inserting the key switch, when even only one of the water, air or gas oil temperature sensors record less than 10 °C, the electronic center activates pre/post reheating and switches on the warning light on the cab instrument panel for a variable period according to temperature, after which the light starts blinking to inform the operator that the engine can be started.

The warning light goes off after engine start but the resistor continues being supplied for a variable period of time to complete post reheating.


The operation is cancelled to prevent uselessly discharging the battery if the engine is not started within 20/25 seconds with the warning light blinking.

When reference temperature is above 10 °C, actuating the ignition key makes the warning light go on for some 2 seconds to complete the test and then turns it off to indicate the engine can be started.

VGT control card


0001695t

1. Service reservoir - 2. Shut-off electro valve - 3. Air filter - 4. VGT electro valve - 5. Actuator position sensor - 6. Turbine actuator - 7. EDC center

Variable geometry Holset turbo compressor (series HY)


71732

1. Intake duct air delivery - 2. Compressor - 3. Air intake - 4. Actuator - 5. Exhaust gas speed adjustment - 6. Exhaust gas intake - 7. Exhaust gas outlet - 8. Turbine



71733

MINIMUM FLOW SECTION




71734

MAXIMUM FLOW SECTION

1. Air delivery to intake manifold - 2. Compressor - 3. Air intake - 4. Actuator - 5. Exhaust gas delivery adjustment ring - 6. Exhaust gas intake - 7. Exhaust gas outlet - 8. Turbine

Operating principle

Exhaust gas section with engine under load



0001698t

The VGT variable geometry turbo compressor consists of a centrifugal compressor and a turbine provided with a mobile device that adjusts the rate of exhaust gas to the turbine rate by changing the gas passage cross section.


This solution enables keeping gas and turbine rates high even when the engine is operating at low rpm.

Making gasses pass through a reduced cross section in fact increases their rate so the turbine too rotates faster.

Movement of the exhaust gas intake cross section partialization device is obtained by means of a mechanism controlled by a compressed air actuator, which is controlled by a proportional electro valve.


The device is fully closed at low rpm, while at high engine rpm the electronic control system increases cross section to enable incoming gasses to flow without increasing their speed.

A thoroidal chamber is cast into the central body for coolant passage.

Engine components (VGT)

A. Actuator - B. Turbine rpm sensor - C. Turbo compressor - D. VGT actuator position sensor -
E. VGT activator control electro valve

Actuator



001228t

1. Air intake - 2. Washer - 3. Piston - 4. External spring - 5. Internal spring control disc - 6. Internal spring - 7. O-Ring - 8. Spring holder - 9. Run end - 10. Dust cover - 11. Control rod

Operating principle

The actuator piston connected to the control rod is piloted through the compressed air admitted from air intake 1 on the top of the actuator.


Modulating air pressure varies piston and turbine control rod movement.

During its movement, the piston progressively compresses external spring 4 until the piston base reaches internal spring 6 control disc 5.

By further increasing pressure, the piston compresses the internal spring through disc 5 until run end, which is reached when disc 5 interferes with lower run end 10.

Use of the two springs enables changing the ratio between pressure and piston travel. About 85% of rod travel is contrasted by the external spring, the remaining 15% being contrasted by the internal one.

VGT control electro valve



001696t

This is an N.C. type proportional electro valve mounted on the engine front, behind the fan.

Through a PWM signal, the electronic center pilots this electro valve to adjust turbine actuator feed pressure; actuator position changes modify the exhaust gas intake cross section on the fan blades and thus its speed.

The VGT electro valve is connected between electronic center pins A18/A31.

Coil resistance is $\sim 20 \div 30$ Ohm.

Turbine rpm sensor (48043)

This is an inductive sensor positioned on the impeller shaft.

It generates signals obtained from the magnetic flow lines, which close through a notch obtained on the shaft itself. The signal generated by this sensor is used by the electronic control unit to verify that the turbine revs number does not exceed the maximum value.



To control the revs number, the control unit acts on variable geometry.

If the revs number keeps on increasing until it reaches excessive r.p.m. values, the electronic control unit will detect an anomaly.

The gap of this sensor **CANNOT BE ADJUSTED**.


It is connected on electronic control unit pins A7 / A16.

The sensor resistance value is 400 Ohm.





Wiring diagram

000589t

VGT actuator position sensor (85158)

Perspective view



Connection diagram

000590t

It is a pressure sensor located on the VGT control electro valve outlet duct, which measures actuator supply pressure. The electronic center uses this signal to detect VGT position and change it if so required.

It is connected to electronic center pins A15/A17/A19.

Fan with electromagnetic junction (F3A)

The fan features two possible rotation speeds controlled by the Front Frame Computer center by exciting the compressed air electro valve for slow speed and by coil (I I) for second speed.

When neither low nor second speed is activated, the fan is drawn slowly by friction forces present (neutral position).

The parameters/systems that may require fan action via the BC center are as follows:

- ☐ Coolant temperature
- ☐ Conditioning system coolant pressure
- ☐ Intarder

Low speed is activated when:

- ☐ Engine coolant temperature reaches 80 °C and the intarder is cut in at deceleration power under 41% of maximum.
- ☐ Conditioner coolant pressure reaches 18 bars.


Second speed is activated when:

- ☐ Conditioner coolant pressure reaches 22 bars.
- ☐ Engine coolant temperature reaches 80 °C and the intarder is cut in at deceleration power over 41% of maximum.
- ☐ Engine coolant temperature is over 88 °C.

When second speed activation is required, the system pilots the fan for 5 seconds at low speed, then second speed is cut in.


This operating logic enables increasing belt and fan component reliability in time.

When fan low speed remains cut in for over 1 minute, the system activates second speed until control parameters return below action limits.



001675t


1. Pulley - 2. Fan hub - 3. Permanent magnets - 4. Blades - 5. Fan - 6. Shaft - 7. Return spring - 8. Piston - 9. Floating ring - 10. Air supply pipe - 11. Coil

Fan cut out (neutral position) (F3A)

001676t

When fan action is not required for proper engine operation, the Front Frame Computer center pilots the compressed air electro valve to move piston (8), displaces permanent magnets (3) from fan hub (2). The magnetic field generated by magnets (3) is not enough to move fan hub (2) by induction.

The fan may rotate slowly due to friction present.


Fan with low speed cut in (F3A)

001677t

When low speed action is required, the Front Frame Computer center discharge air from duct (10) through the compressed air electro valve; piston (8) moves and draws permanent magnets (3) towards fan hub (2). Piston travel is ensured by return spring (7) and blades (4).

The shaft rotates at the same speed as pulley (1) and the effect of the magnetic field generated by magnets (3) is to make fan hub (2) rotate at the maximum speed of 650 rpm.

For F2B the first speed is always connected since there are no pneumatic solenoid valve nor air exhaust system inside the assembly.


Fan with second speed cut it (F3A / F3B)

001678t

When low speed is not enough to properly cool the engine, the Front Frame Computer center pilots second speed cut-in by exciting coil (11).

The magnetic field generated by the coil attracts fan hub (2) floating ring (9) to pulley (1) making the two units solidal.

In this condition fan speed is the same as pulley speed.

Fan control diagram (F3A)

001697t

1. Engine brake switch - 2. Steering Wheel Interface - 3. Instrument Cluster - 4. Fan electro valve - 5. Front Frame Computer - 6. Body Computer - 7. Fan electro valve - 8. Conditioner pressure switches - 9. Conditioner - 10. EDC - 11. Water temperature sensor - * The pressure switches involved in fan control are the (18-22 bar) conditioner coolant pressure warning ones.

Defect identification

Defect	Cause
The fan always rotates at low speed	- Air supply pipe clogged - Air supply pipe broken
The fan does not rotate above 650 rpm (low speed)	- Center output does not pilot the coil - Interruption of the center to coil wire - Coils short-circuited - Improper mechanical parts sliding
The fan always rotates at second speed	- The center output always pilots the coil - Improper mechanical parts sliding

THE EBS ELECTRONIC BRAKE SYSTEM

Increased competition in the transportation business has also caused increased basic braking system requirements, logically satisfied with the introduction of EBS electronic control braking systems.

It is a permanent integrated management braking system for tractor and trailers that integrates ABS, ASR and EBL systems.

The system consists of a compressed air and an electrical system containing the following components:

Electrical transmitter duplex distributor, front axle proportional relay valve, front axle ABS valve, axle electrical and compressed air modulator and trailer control servo distributor.

The EBS system dialogs with the centers of the other units:

Engine, Ecas, transmission decelerator via the CAN line (VDB Vehicle Data Bus).

Advantages of the EBS

Reduced maintenance costs.

The EBS combines several different functions, the objective being to minimize maintenance costs at maximized braking safety and minimizing brake pad wear.

Individual controls to front and rear axle pad wear parameters harmonize pad wear and homogeneous load distribution to all wheel brakes minimizes overall consumption. Additionally, maintenance intervals and pad replacement also coincide. This dramatically reduces downtime costs.

Owners can achieve substantial savings according to maintenance required for a motor vehicle and other factors. Comparison of brake system maintenance costs for a vehicle with EBS and one with a conventional braking system underscores great cost cutting.

Tractor and Trailer Compatibility at all times

Especially when changed frequently often with conventional systems, harmonizing the braking processes of the entire tractor and trailer combination is unsatisfactory.

Inadequate balance, such as a trailer with scant braking efficiency, causes unequal brake pad wear.

The EBS identifies all tractor and trailer incompatibility and automatically harmonizes braking. Brake maintenance costs are not only optimized but safety and comfort are also maximized when brakes operate in the best possible conditions.

Complete Diagnostic Structures

The EBS offers vehicles owners constantly updated information on braking system and basic brake component conditions. This enables prior organization of maintenance periods. The EBS monitors all braking system functions and basic components.

All defects identified by the system are carefully displayed, so maintenance specialists can readily correct them.

The high degree of safety the EBS guarantees is due to several factors, as follows:

- ☐ Reduced front and rear tractor and trailer axle response and pressure accumulation times.
- ☐ Improved ABS function.
- ☐ Tractor and trailer balanced at all times.
- ☐ Constant service braking system monitoring. The EBS warns the operator of reduced brake efficiency.
- ☐ The integrated ASR function enables optimum motor vehicle stability and optimized traction.


Operating logic


The objective of the electronic center is to slow the vehicle down as fast as possible ensuring stability and avoiding the tendency to block wheels.

The center is informed of the following to reach this objective:

- ☐ desired deceleration via internal duplex distributor sensors;
- ☐ pressure data retrieved via internal component pressure sensors;
- ☐ deceleration reaction due to pressure data retrieved via speed sensor signals.

Continued data monitoring and processing to the objective set identifies modulating valve activation and braking action optimization.






Ref.	Description	Component code
1	Direction right lever	54030
2	Push buttons on the steering wheel	-
3	Steering Wheel Interface	86123
4	Cluster	50005
5	Body Computer	86116
6	3rd axle right wear sensor	88011
7	3rd axle right wear sensor	88011
8	APU	61104
9	RFC	86118
10	Stop signal	34000
11	EDC centre	85150
12	Engine brake electro valve	78050
13	VGT electro valve	78248
14	Eurotronic centre	86004
15	Intarder centre	86015
16	EBS centre	88005
17	Duplex distributor	78059
18	7-pole trailer connection junction	72006
19	ASR cutout low pressure switch	-
20	Redundancy valve	78061
21	Axle electrical/compressed air modulator	88006
22	Right axle speed and wear sensors	88008
23	Left axle speed and wear sensors	88008
24	ASR 3rd axles cutout electro valve	78060
25	ASR function limit switch	52056
26	Trailer servo distributor	78058
27	Left axle speed and wear sensors	88007
28	Left ABS electro valve	78052
29	Proportional relay valve	78057
30	Right ABS electro valve	78052
31	Right axle speed and wear sensors	88007
32	30-pole diagnosis connector	72021

Component location on the vehicle (tractor variant)

Tractors




001996t

1. Electronic center - 2. Duplex distributor with electrical transmitter - 3. Manual stop distributor - 4. Coupling half-joints - 5. Air reservoirs - 6. Electrical compressed air axle modulator - 7. Stop relay valve - 8. Air reservoir - 9. Spring brake cylinder - 10. Trailer control servo distributor - 11. APU - 12. Membrane brake cylinder - 13. ABS electro valve - 14. Compressor - 15. Axle proportional valve

The diagram illustrates the EBS system architecture for a truck chassis. At the bottom, a row of control units includes the **EBS** (Electronic Brake System) unit, **TRANSMISSION**, **ECAS** (Electronic Control Air Suspension), **RETARDER**, and **ENGINE**. Below these is the **BODY COMPUTER** and a **CLUSTER** (instrument panel). The **EBS** unit is connected to a battery and a network of lines that branch out to various components. On the left, components include a **SERVICES** section with a **COMPRESSED AIR SUSPENSION** tank, and a **4/23** valve. On the right, there are two **43** valves, a **21** valve, and a **2** valve. The diagram uses a color-coded system: red lines for **1** (brake pressure), blue lines for **2** (brake pressure), green lines for **3** (brake pressure), and yellow lines for **4** (brake pressure). The components are connected to the **EBS** unit via these lines, with some components having multiple connections. The **CLUSTER** is connected to the **BODY COMPUTER** and the **EBS** unit.


Base - January 2003

EBS location diagram for carriage variant

001680t


Basic EBS compressed air system diagrams

EBS 4x2 Tractors



001988t

1. 465-cc E.S. two-cylinder compressor - 2. 10.5 bar air Processing Unit - 3. 20-l axle air reservoir - 4. 20-l stop air reservoir - 5. 30-l axle air reservoir - 6. Manual discharge valve - 7. Compressed air PTO - 8. 6.6-bar ASR axle low pressure switch - 9. Stopping system one-way valve - 10. 5.5 bar trailer system low pressure switch - 11. Semi-trailer coupling half-joints - 12. Trailer braking control servo distributor - 13. Axle combined cylinder - 14. Axle disc brake assembly - 15. Axle sound wheel - 16. Axle speed sensor - 17. Axle braking control electrical compressed air modulator - 18. Duplex distributor - 19. EBS electronic center - 20. Axle braking control electrical compressed air relay valve - 21. Axle ABS electro valves - 22. Axle membrane filter cylinder - 23. Axle sound wheel - 24. Axle speed sensor - 25. Axle disc brake assembly - 26. Stopping control relay valve - 27. Stopping control hand distributor - 28. Trailer deceleration hand distributor - 29. 6.6 bar hand brake on low pressure switch - A. To the compressed air suspension system - B. To the services system - * Optionals

EBS 6x2 TXP Tractors

001989t


1. 465-cc E.S. two-cylinder compressor - 2. 10.5 bar air Processing Unit - 3. 20-l axle air reservoir - 4. 20-l stop air reservoir - 5. 30-l + 15-l axle air reservoir - 6. Manual discharge valve - 7. Compressed air PTO - 8. 6.6-bar ASR axle low pressure switch - 9. Stopping system one-way valve - 10. 5.5 bar trailer system low pressure switch - 11. Semi-trailer coupling half-joints - 12. Trailer braking control servo distributor - 13. Axle combined cylinder - 14. Axle disc brake assembly -

15. Axle sound wheel - 16. Axle speed sensor - 17. Intermediate axle braking load ratio relay valve - 18. Intermediate axle membrane cylinder - 19. Intermediate axle disc brake assembly - 20. Intermediate axle ASR actuation cutout electro valve - 21. Intermediate axle suspension air springs - 22. Intermediate axle load ratio double check valve - 23. Axle braking control electrical compressed air modulator - 24. Duplex distributor - 25. EBS electronic center - 26. Axle braking control electrical compressed air relay valve - 27. Axle ABS electro valves - 28. Axle membrane filter cylinder - 29. Axle disc brake assembly - 30. Axle sound wheel - 31. Axle speed sensor - 32. Stopping control relay valve - 33. Stopping control hand distributor - 34. Trailer deceleration hand distributor - 35. 6.6 bar hand brake on low pressure switch - A. To the compressed air suspension system - B. To the services system - *Optionals

EBS 4x2 Carriages (Legenda)

Ref.	Description
1	465-cc E.S. two-cylinder compressor
2	10.5-bar Air Processing Unit
3	12.5-bar Air Processing Unit
4	20-l axle air reservoir
5	20-l stopping air reservoir
6	30-l axle air reservoir
7	Manual discharge valve
8	Compressed air PTO
9	6.6-bar ASR axle low pressure switch
10	Stopping system one-way valve
11	5.5-bar trailer system low pressure switch
12	Axle braking redundancy valve
13	Semi-trailer coupling half-joints
14	Trailer brake control servo distributor
15	Axle combined cylinder
16	Axle disc brake assembly
17	Axle sound wheel
18	Axle speed sensor
19	Axle braking control electrical compressed air modulator
20	Duplex distributor
21	EBS electronic center
22	Axle braking control relay electro valve
23	Axle ABS electro valve
24	Axle membrane brake cylinder
25	Axle disc brake assembly
26	Axle sound wheel
27	Axle speed sensor
28	Stopping control relay valve
29	Stopping control manual distributor
30	Trailer deceleration hand distributor
31	6.6-bar hand brake on low pressure switch
A	To the compressed air suspension system
B	To the services system
*	Optionals
●	Only for CM vehicles


EBS 4x2 Carriages



001987t

EBS 6x2 Carriages (Legenda)


Ref.	Description
1	465-cc E.S. two-cylinder compressor
2	10.5-bar Air Processing Unit
3	12.5-bar Air Processing Unit
4	20-l axle air reservoir
5	20-l stopping air reservoir
6	30-l + 20-l axle air reservoir
7	Manual discharge valve
8	Compressed air PTO
9	6.6-bar ASR axle low pressure switch
10	Stopping system one-way valve
11	5.5-bar trailer system low pressure switch
12	Trailer coupling half-joints
13	Trailer braking control servo distributor
14	Axle braking redundancy valve
15	Added axle braking load ratio relay valve
16	Added axle membrane brake cylinder
17	Added axle disc brake assembly
18	Added axle ASR cutout electro valve
19	Added axle suspension compressed air springs
20	Added axle load ratio double check valve
21	Axle combines cylinder
22	Axle disc brake assembly
23	Axle sound wheel
24	Axle speed sensor
25	Axle braking control electrical compressed air modulator
26	Duplex distributor
27	EBS electronic center
28	Axle braking control relay electro valve
29	Axle ABS electro valve
30	Axle membrane brake cylinder
31	Axle disc brake assembly
32	Axle sound wheel
33	Axle speed sensor
34	Stopping control relay valve
35	Stopping control manual distributor
36	Trailer deceleration manual distributor
37	6.6-bar hand brake on low pressure switch
A	To the compressed air suspension system
B	To the services system
*	Optionals
●	Only for CM vehicles

EBS 6x2 Carriages


001986t

Wall pass

This new wall pass was introduced to maximize contact reliability.



002061t



Connector **A** – White (free)

Connector **B** – Brown (ECAS)

Connector **C** – Yellow (EBS/ABS/ASR)

Connector **D** – Blue (EuroTronic/PTO/INTARDER)


Connector **E** – Green (EDC/ADR)

73658

Wall pass "C" Yellow

Pin	Cable color code	EBS function	Cable color code	ABS function
1	6025	Front wheel brake wear sensor /pin1	—	Free
2	6024	Front wheel brake wear sensor /pin2	6245	Rear axle safety sensor /pin5
3	0026	Front wheel brake wear sensor /pin3	8847	Rear axle safety sensor /pin+
4	5571	Front right axle speed sensor	5571	Front right axle speed sensor
5	5571	Front right axle speed sensor	5571	Front right axle speed sensor
6	9920	Electro valve EV /pin3 front right axle	9920	Electro valve EV /pin3 right front axle
7	0118	C AV /EV /pin2 front right axle	—	Free
8	9918	Electro valve AV /pin1 front right axle	9918	Electro valve AV /pin1 right front axle
9	8075	Connector ST81 /pin1 terminal 15	8075	Connector ST81 /pin1
10	3375	Connector ST81 /pin2 terminal 58	3375	Connector ST81 /pin2
11	9262	Electro valve for brake cylinder /pin1 (only on 6x6)	5573	Rear right axle speed sensor
12	0047	Engine brake switch /pin1	5573	Right front axle
13	6046	Trailer air pressure proportional valve /pin1	9930	Electro valve EV /pin3 rear right axle
14	0026	Trailer air pressure proportional valve /pin2	—	Free
15	6047	Trailer air pressure proportional valve /pin3	9928	Electro valve AV /pin1 rear right axle
16	9046	Trailer air pressure proportional valve /pin4	—	Free
17	0046	Trailer air pressure proportional valve /pin5	—	Free
18	9217	Redundant electro valve for axle braking /pin2 (only on truck)	—	Free
19	0217	Redundant electro valve for axle braking /pin2 (only on truck)	—	Free
20	—	Free	—	Free
21	—	Free	—	Free
22	—	Free	—	Free
23	—	Free	—	Free
24	GN/VE	Rear air pressure modulator /pin4	0260	Electro valve for ASR /pin2
25	WS/BI	Rear air pressure modulator /pin3	9260	Electro valve for ASR /pin1
26	7740	Rear air pressure modulator /pin1	—	Free
27	9960	Front axle air pressure proportional valve /pin5	—	Free
28	0099	Front axle air pressure proportional valve /pin4	—	Free
29	6697	Front axle air pressure proportional valve /pin3	9929	Electro valve AV /pin1 left rear axle
30	0026	Front axle air pressure proportional valve /pin2	—	Free
31	6696	Front axle air pressure proportional valve /pin1	9931	Electro valve EV /pin3 left rear axle
32	9919	Electro valve AV /pin1 front left axle	9919	Electro valve AV /pin1 left rear axle
33	0122	Electro valve AV /EV /pin2 front left axle	—	Free
34	9921	Electro valve EV /pin3 front left axle	9921	Electro valve EV /pin3 left rear axle
35	5570	Speed sensor front left axle	5570	Speed sensor left rear axle
36	5570	Speed sensor front left axle	5570	Speed sensor left rear axle
37	0026	Front wheel brake wear sensor /pin3	5572	Speed sensor left rear axle
38	6026	Front wheel brake wear sensor /pin2	5572	Left rear axle
39	6027	Front wheel brake wear sensor /pin1	—	Free
40	0000	Mass	0000	Mass

EBS electronic center



This component manages the brake system by identifying deceleration settings based on parameters detected by the various system components.


It is enabled to pilot auxiliary braking systems such as the engine brake and the retarder by optimizing their operation, to guarantee best system operation and minimize brake pad wear.

The electronic center is provided with an advanced self-diagnosis system and can identify and store any intermittent system operating anomaly subject to environmental conditions and ensure proper and reliable repair.

The EBS electronic center communicates via a "VDB" CAN Line with the axle electro-pneumatic modulator center, trailers provided with an EBS braking system and with the engine, retarder, transmission, ECAS and BODY COMPUTER, CLUSTER electronic centers.

It communicates with axles and trailers with an EBS braking system via an SB can line.

Pin-out center EBS



Connector X1

Pin	Cable	Function
1	GN/VE	CAN line "L"
2	---	---
3	WS/BI	CAN line "H"
4	---	---
5	---	---
6	0048	Negative from ASR switch
7	8847	Power positive under key
8	7710	Power positive direct from battery
9	7720	Power positive direct from battery
10	---	---
11	0000	Mass
12	0000	Mass
13	2299	K line for diagnosis connector (pin 4)
14	---	---
15	---	Safety bridge pin 12 / 18
16	6672	---
17	---	---
18	---	---

Connector X2

Pin	Cable	Function
1	GN/VE	Rear axle modulator CAN line "L" (pin 4)
2	---	---
3	GN/VE	Trailer connector CAN line "L" (pin 7)
4	WS/BI	Rear axle modulator CAN line "H" (pin 3)
5	---	---
6	WS/BI	Trailer connector CAN line "H" (pin 6)
7	7740	Positive for rear axle modulator (pin 1)
8	---	---
9	0047	Negative from system low pressure switch
10	9046	Positive for trailer control proportional electro valve (pin 4)
11	0046	Negative for trailer control proportional electro valve (pin 5)
12	---	---
13	6046	Positive for trailer control valve pressure sensor (pin 1)
14	6047	Signal from trailer control valve pressure sensor (pin 3)
15	---	---

Connector X3

Pin	Cable	Function
1	9918	Positive for front right ABS discharge electro valve (pin 1)
2	9920	Positive for front right ABS power electro valve (pin 3)
3	0118	Negative for front right ABS electro valve (pin 2)
4	5571	Right front sensor
5	5571	Right front sensor
6	---	---
7	6024	Positive for right front wheel wear sensor (pin 2 - GE/GI - pin B)
8	6025	Signal from right front wheel wear sensor (pin 1 - SW/NE - pin A)
9	---	---

Connector X4

Pin	Cable	Function
1	0099	Negative for axle proportional relay electro valve (pin 4)
2	9960	Positive for axle proportional relay electro valve (pin 5)
3	0026	Negative for pressure and wear sensors
4	6026	Positive for front left wheel wear sensor (pin 2 - GE/GI - pin B)
5	6027	Signal from front left wheel wear sensor (pin 1 - SW/NE - pin A)
6	6697	Signal from axle proportional relay pressure valve sensor (pin 3)
7	5570	Left front sensor
8	5570	Left front sensor
9	6696	Positive for axle proportional relay pressure valve sensor (pin 1)
10	9919	Positive for front left ABS discharge electro valve (pin 1)
11	9921	Positive for front left ABS power electro valve (pin 3)
12	0122	Negative for front left ABS electro valve electro valve (pin 2)

Connector X5

Pin	Cable	Function
1	6028	Positive for duplex distributor position 2 sensor (pin 1)
2	6018	Signal from duplex distributor position 2 sensor (pin 4)
3	0088	Braking on/off signal from duplex distributor switch 2 (pin 3)
4	6029	Positive for duplex distributor position 1 sensor (pin 1)
5	6019	Signal from duplex distributor position 1 sensor (pin 4)
6	0089	Braking on/off signal from duplex distributor switch 1 (pin 3)

ABS-EBL ANTI – LOCK BRAKE SYSTEM - ELECTRONIC BRAKE LIMITER SYSTEM

The ABS – EBL braking system is available as an alternative to the EBS system on 4x2 e 6x2 vehicles.

ABS Anti – Lock Brake System

Braking a moving vehicle and its deceleration and stopping distance are essentially dependant on adherence between tire and road surface. Improved braking with an efficient braking system can only be achieved by acting on tire friction features or road surface quality.

Even in optimum conditions, absolutely safe braking is not guaranteed when critical situations have to be coped with, such as low adherence due on a wet or iced road surface, which obliges the vehicle operator to moderate braking action to prevent possible wheel locks and consequent dangerous loss of vehicle control.

The ABS therefore has the function of ensuring vehicle stability in any braking condition by preventing wheel locks independently of road surface conditions and guarantee full exploitation of available adherence.


The system enables maintaining direction control even in emergency braking and acting on the steering wheel to avoid obstacles with danger of vehicle control loss.

In essence, the ABS system:

- prevents wheel locks during vehicle braking in and road adherence conditions
- reduces stop distances
- offers operator safety for stability and vehicle control maintenance.

Electronic Brakes Limiter EBL

The EBL function controls rear axle wheel skidding by comparing it with front wheel speed. Data entering the center are wheel rpm and braking pressure measured by the pressure sensor installed upstream the rear axle ABS modulators. The center uses these data to calculate vehicle speed and deceleration, rear axle wheel skid and minimum deceleration required. The EBL function is activated with rear ABS modulators maintaining set pressure when the operators applies excess braking force than required for vehicle load conditions, in essence when vehicle deceleration and rear axle skid thresholds are passed.




Ref.	Description	Component code
1	Direction right lever	54030
2	Push buttons on the steering wheel	-
3	Steering Wheel Interface	86123
4	Cluster	50005
5	Engine brake switch	-
6	Duplex distributor	53501
7	Body Computer	86116
8	FFC	86117
9	RFC	86118
10	Stop signal	34000
11	Axle pad wear	86002
12	Axle pad wear	86003
13	3rd axle pad wear	-
14	APU	61104
15	EDC centre	85150
16	Engine brake electro valve	78050
17	VGT electro valve	78248
18	Eurotronic centre	86004
19	Intarder centre	86015
20	ABS/ABL centre	88000
21	Right rear sensor and sound wheel	88001
22	Right rear ABS electro valve	78052
23	EBL pressure sensor	88010
24	Left rear ABS electro valve	78052
25	Left rear sensor and sound wheel	88001
26	7-pole trailer junction connection	72006
27	ASR activation electro valve	78053
28	ABS function limit switch	-
29	ASR function limit switch	52056
30	Left front sensor and sound wheel	78052
31	ABS left front electro valve	78052
32	ABS right front electro valve	78052
33	Right front sensor and sound wheel	88001
34	30-pole diagnosis connector	72021

Operating logic


The objective of the electronic center is to slow down the vehicle as fast as possible, guarantee its stability and avoid the tendency to lock wheels. When braking, the center is informed of the following to reach these objectives:

- braking intensity required by the operator via the rear axle pressure sensor
- slowing reaction due to pressures made available via signals from the speed sensors.


Ongoing monitoring and processing of these data referred to the objective set required activation of rear axle modulating valves and consequent braking optimization.



ABS electronic center



000846t




001014t

Manages the braking system by setting deceleration to the parameters measured by the various system components.

It communicates with on-board electronic systems via a CAN line and is connected through two polarized connectors.

Though offering the possibility of a blink code displayed via the ASR warning light for preliminary diagnosis, the electronic center is provided with an advanced self-diagnosis system capable of identifying and storing any intermittent anomaly to an operating system subject to environmental conditions, and ensuring proper and reliable repair.

Pin – out ABS center


000846t

Connector X1

Pin	Function	Cable
1	CAN line "L"	GN/VE
2	Axle braking detection pressure signal sensor	6245
3	CAN line "H"	WS/BI
4	Mass	0000
5	Negative from switch ABS	0049
6	Negative from switch ASR	0048
7	Power positive under key	8847
8	Power positive direct from battery	7710
9	Mass	0000
10	K line for diagnosis connector (pin 4)	2299
11	L line for diagnosis connector (pin 3)	1199
12	Safety bridge pin 9 / 15	---
13	Negative for ASR warning on (Blink – Code)	6672
14	Negative for third brake cutout	0029
15	Negative for defective ABS warning	6670

Connector X2


Pin	Function	Cable
1	Positive for front right ABS power electro valve	9920
2	Positive for rear left ABS power electro valve	9931
3	Positive for front left ABS power electro valve	9921
4	Positive for front right ABS discharge electro valve	9918
5	Positive for rear left ABS power electro valve	9929
6	Positive for front left ABS power electro valve	9919
7	Negative for ASR axle electro valve	0260
8	Positive for rear right ABS power electro valve	9930
9	Positive for rear right ABS discharge electro valve	9928
10	Front right sensor	5571
11	Rear right sensor	5572
12	Front left sensor	5570
13	Front right sensor	5571
14	Rear left sensor	5572
15	Front left sensor	5570
16	Positive axle ASR electro valve	9260
17	Rear right sensor	5573
18	Rear right sensor	5573

ABS-EBL compressed air system basic diagrams**ABS-EBL 4x2 Carriages**

001985t


ABS-EBL system for 4x2 Carriages (Legend)

Ref.	Description
1	Two-cylinder compressor ES – 465 cc
2	Air Processing Unit - 10,5 bar
3	Air Processing Unit – 12,5 bar
4	20 l Axle air reservoir
5	20 l Axle parking reservoir
6	20 l Axle air reservoir
7	Manual discharge valve
8	Compressed air control PTO
9	Parking hand control distributor
10	Hand brake low 6.4 bar pressure switch on
11	Parking control relay valve
12	Trailer slowing hand distributor
13	Trailer braking control servo distributor
14	Trailer low 6.4 bar pressure switch
15	Trailer coupling half-junctions
16	Parking system one-way valve
17	Duplex distributor
18	Combined axle cylinder
19	Axle drum brake assembly
20	Axle sound wheel
21	Axle speed sensor
22	Axle ABS electro valves
23	EBL pressure sensor
24	Double stop valve
25	Axle braking control relay valve
26	ASR control electro valve
27	ASR 7.5 bar controlled pressure check valve
28	ABS electronic center
29	Axle braking control relay valve
30	ABS axle electro valve
31	Axle cylinder membrane brake
32	Axle disc brake assembly
33	Axle sound wheel
34	Axle speed sensor
35	Axle drum brake assembly
36	Stop light control micro switch
37	EDC center micro switch
A	To the compressed air suspension system
B	To the service system
*	Optional
●	Only for CM vehicles

ABS-EBL system for 6x2 Carriages

ABS-EBL system for 6x2 Carriages (Legenda)

Ref.	Description
1	465 cc two-cylinder ES compressor-
2	10.5 bar air Processing Unit
3	12.5 bar air Processing Unit
4	20 l axle air reservoir
5	20 l parking air reservoir
6	30 l + 20 l axle air reservoir
7	Manual discharge valve
8	Compressed air control PTO
9	Parking control hand distributor
10	Hand brake low 6.4 bar pressure switch on
11	Parking control relay valve
12	Trailer slowing hand distributor
13	Trailer braking control servo distributor
14	Trailer low 6.4 bar pressure switch
15	Trailer coupling half-junctions
16	Parking system one-way valve
17	Duplex distributor
18	Additional axles brake load ratio relay valves
19	Membrane cylinder
20	Additional axle drum brake assembly
21	Combined axle cylinder
22	Axle drum brake assembly
23	Axle sound wheel
24	Axle speed sensor
25	Added axle suspension air springs
26	Added axle load ration double stop valve
27	Axle ABS electro valves
28	EBL pressure sensor
29	ABS electronic center
30	Axle brake control relay valve
31	Double stop valve
32	ASR 7 bar controlled pressure check valve
33	ASR control electro valve
34	Axle brake control relay valve
35	ABS axle electro valve
36	Axle membrane cylinder brake
37	Axle sound wheel
38	Axle speed sensor
39	Axle disc brake assembly
40	Axle drum brake assembly
41	Stop light control micro switch
42	EDC center micro switch
A	To the compressed air suspension system
B	To the service system
*	Optional
●	Only for CM vehicles
■	Version with ASR
▲	Version without ASR

A.P.U. (Air processing unit)

001681t


It consists of a drier provided with a filter regeneration timer and a 4-way protection valve incorporating a pressure reducer.

The purpose of the drier is to purify and dry compressed air by adjusting system pressure to its rated value.


The 4-way protection valve distributes air con the various circuits ensuring their operating pressure even in the event of breakdowns.

This component is used in all systems and is rated at 10.5 ± 0.2 bars; for mobile bowl CM vehicle setting is 12.5 ± 0.2 bars.

The APU contains two sensors connected to the MUX system for axle pressure display on the Cluster.



TECHNICAL VIEW



WIRING DIAGRAM

Compressed air connections

- 1 - Power from the compressor
- 24 - PTO
- 25 - Output for 10.5 bar compressed air suspension
- 23 - To the compressor for Energy Saving control
- 3 - Venting to outside air
- 21 - To the 10.5 bar axle reservoir
- 22 - To the 10.5 bar axle reservoir
- 23 - To the 8.5 bar parking brake manual distributor and trailer recharge and parking air reservoir
- 24 - To the 8.5 bar service reservoir

Drier electrical connections

- 6.1 - Negative for thermostatic resistance
- 6.2 - Positive for thermostatic resistance

4-way protection valve electrical connections

- 6.2 - Rear circuit air pressure signal
- 6.3 - Positive for power
- 6.4 - Negative
- 6.5 - Front circuit air pressure signal
- 6.6 - Positive for power
- 6.7 - Negative


Duplex distributor 78059

This non self-limited coaxial component consists of an electrical and a compressed air section, the former consisting of two switches and two position sensors generating the braking signals the center needs to manage the system.

These signals are redundant to guarantee top reliability.

The compressed air section distributes pressure to the front axle braking circuit and to the trailer control servo distributor.

These pressures are always available but are mostly used in case of electrical/electronic system breakdown.




000828t

Compressed air connection


- 11 - Axle reservoir supply
- 12 - Axle reservoir supply
- 22 - Axle proportional relay valve output
- 3 - Discharge

Electrical connections:

- 61.1 Positive for sensor 1 (ECU X5 pin 4)
- 61.2 Negative for sensor/switch
- 61.3 Negative from switch (ECU X5 pin 6)
- 61.4 Signal from sensor 1 (ECU X5 pin 4)
- 62.1 Positive for sensor 2 (ECU X5 pin 1)
- 62.2 Negative for sensor/switch
- 62.3 Negative from switch (ECU X 5 pin 3)
- 62.4 Signal from sensor 1 (ECU X5 pin 2)
- 62.5 Negative stop light relay

Duplex distributor (ABS/EBL systems)


000854t



000990t

This non self-limited coaxial component consists of a compressed air and an electrical section, the former distributing braking control pressure to the front axle, the rear axle and the trailer control servo distributor.

The electrical section ensures sending the braking signal to the EDC center and to the stop light control relay.



000792t

Compressed air connections:


- 11 - Power from the axle reservoir
- 12 - Power from the axle reservoir
- 21 - Valve output to servo distributor relay valve and trailer control
- 22 - Valve output to axle relay
- 3 - Vent to outside air

Electrical connections:

- 1 - Positive for stop lights/EDC
- 2 - Input positive
- 3 - Positive for EDC
- 4 - Input positive


Proportional relay valve for axle 78057

This component consists of a proportional electro valve, a compressed air control relay and a pressure sensor. It sends the front axle the braking pressure calculated by the center according to braking requested.




60935

PERSPECTIVE VIEW



000804t

WIRING DIAGRAM



000831t

Compressed air connections

- 1 - Axle reservoir power
- 2 - ABS axle valve output
- 3 - Discharge
- 4 - Safety control from the duplex distributor

Electrical connections


- 6.1 - Positive for sensor 1 (ECU X4 pin 9)
- 6.2 - Negative for sensor (ECU X4 pin 3)
- 6.3 - Sensor signal (ECU X4 pin 6)
- 6.4 - Negative for electro valve (ECU X4 pin 1)
- 6.5 - Positive for electro valve (ECU X4 pin 2)

Electro valve ABS 78052


This normally open electro valve consists of a power coil and a discharge.

It is used to modulate braking pressure when wheel tendency to lock is detected by the speed sensor.

Vehicles with the EBS system feature two of them to control the front axle.




PERSPECTIVE VIEW



000805t

WIRING DIAGRAM



000821t

Compressed air connections

- 1 Proportional relay power
- 2 Axle brake cylinder output
- 3 Discharge

Electrical connections

Right wheel

- 6.1 Positive for discharge coil (ECU X3 pin 1)
- 6.2 Common negative (ECU X3 pin 3)
- 6.3 Positive for power coil (ECU X3 pin 2)

Left wheel

- 6.1 Positive for discharge coil (ECU X4 pin 10)
- 6.2 Common negative (ECU X4 pin 12)
- 6.3 Positive for power coil (ECU X4 pin 11)

Axle electro-pneumatic modulator (88006)

This component consists of an electrical circuit, two N.C. power electro valves, two N.A. discharge electro valves and two pressure sensors.

The electrical circuit receives and processes signals from the axle speed, pressure and basket wear sensors and transmits them to the electronic center dedicated CAN line, which can perform the following, depending on information received from the electronic center:


Modulate braking pressure (EBS function)

Limit pressure based on load (EBL function)

Modulate pressure based on load (EBL function)


Lock wheels (ABS function)

Modulate braking pressure to prevent wheel slip (ASR function)




60934

PERSPECTIVE VIEW



002057t

WIRING DIAGRAM



000823t

Compressed air connections

- 11 - Power from axle reservoir
- 12 - Power from axle reservoir
- 21 - Output for left axle brake cylinder
- 22 - Output for right axle brake cylinder
- 3 - Venting to outside air

Electrical connections:


- 61.1 - Power positive (ECU X2 pin 7)
- 61.2 - Common negative
- 61.3 - CAN line (ECU X2 pin 4)
- 61.4 - CAN line (ECU X2 pin 1)
- 62.1 - Right wheel speed signal
- 62.2 - Right wheel speed signal
- 63.1 - Left wheel speed signal
- 63.2 - Left wheel speed signal
- 66.1 - Right wear sensor positive (pin A)
- 66.2 - Right wear sensor negative (pin B)
- 66.3 - Right wear sensor signal (pin C)
- 67.1 - Left wear sensor positive (pin A)
- 67.2 - Left wear sensor negative (pin B)
- 67.3 - Left wear sensor signal (pin C)

Axle electro-pneumatic modulator (for 4x2 e 6x2 carriages)

This component consists of an electrical circuit, two N.C. power electro valves, two N.A. discharge electro valves, two pressure sensors and two stop double electro valves.


The electrical circuit receives and processes signals from the axle speed, pressure and basket wear sensors and transmits them to the electronic center dedicated CAN line, which can perform the following, depending on information received from the electronic center:

- Modulate braking pressure (EBS function)
- Limit pressure based on load (EBL function)
- Modulate pressure based on load (EBL function)
- Lock wheels (ABS function)
- Modulate braking pressure to prevent wheel slip (ASR function)
- Guarantee compressed air braking in electrical system breakdown conditions




60934

PERSPECTIVE VIEW



002052t

WIRING DIAGRAM




002053t

Compressed air connections:


- 11 - Power from the axle reservoir
- 12 - Power from the axle reservoir
- 13 - Power from the redundancy valve
- 21 - Output for the left axle brake cylinder
- 22 - Output for the right axle brake cylinder
- 3 - Vent to the outside air

Electrical connections:

- 61.1 - Power positive (ECU X2 pin 7)
- 61.2 - Common negative
- 61.3 - CAN line (ECU X2 pin 4)
- 61.4 - CAN line (ECU X2 pin 1)
- 62.1 - Right wheel speed signal
- 62.2 - Right wheel speed signal
- 63.1 - Left wheel speed signal
- 63.2 - Left wheel speed signal
- 66.1 - Right wear sensor positive (pin A)
- 66.2 - Right wear sensor positive (pin B)
- 66.3 - Right wear sensor signal (pin C)
- 67.1 - Left wear sensor positive (pin A)
- 67.2 - Left wear sensor negative (pin B)
- 67.3 - Left wear sensor signal (pin C)


Redundancy valve (for 4x2 e 6x2 carriages)

002055t



002110t

This component consists of an electro valve and a power relay valve: Its purpose is to guarantee rear axle braking even in total EBS system breakdown conditions.



002056t

Compressed air connections


- 1 - Power from axle reservoir
- 2 - Output for axle modulator
- 3 - Vent to outside air
- 42 - Control from distributor

Electrical connections:

- 6.1 - Power positive (ECU X2 pin 8)
- 6.2 - Negative (ECU X2 pin 12)


Trailer control servo distributor (78058)

The purpose of this component is to supply compressed air power to the trailer and its braking in various operating conditions. It guarantees service braking via the electronic center electrical control, safety braking in electrical control breakdown conditions via compressed air pressure from the duplex distributor, parking braking via the hand distributor control and emergency braking in duct breakdown conditions via the integrated modulated servo switch device.




60933

PERSPECTIVE VIEW



000807t

WIRING DIAGRAM



000827t

Compressed air connections:

- 11 - Power from the reservoir
- 21 - Output for the automatic half-shaft
- 22 - Output for the moderable half-shaft
- 42 - Control from the duplex distributor
- 43 - Control from the manual distributor
- 3 - Discharge

Electrical connections:

- 6.1 - Positive for sensor (ECU X2 pin 13)
- 6.2 - Negative for sensor (ECU X4 pin 3)
- 6.3 - Signal from sensor (ECU X2 pin 14)
- 6.4 - Electro valve negative (ECU X2 pin 10)
- 6.5 - Electro valve positive (ECU X2 pin 11)

Sound wheel and speed sensor 88001

Sensors continuously supply the electronic center with all the data it requires to properly pilot the electro valves.

Signals are obtained from magnetic flow lines that close through the teeth of a toothed wheel facing the sensor and rotating together with the wheel.


Passage from full to empty due to the presence or absence of the tooth causes sufficient magnetic flow variation to create induced electromagnetic force at sensor terminals and thus an alternating electrical signal that is sent to the electronic center.

The clearance between the sensor and wheel, called air gap, must obviously be at a pre-set value of $0.8 \div 1.6$ mm for proper signals to be sent. Resistance of each sensor at connection terminals is between 1 and 2 kW.


The toothed wheel is called sound wheel because the signal it generates has the same frequency as a sound wave.

The frequency of this signal serves to define wheel rotation speed.

Frequency variations, or the speed at which signals follow one another, define acceleration and deceleration rates.




000840t



000841t


SOUND WHEEL (A) AND SENSOR (B) PERSPECTIVE VIEWS




A. Magnetic flow lines

000842t

Low pressure switch



000856t




000841t

- ☐ Hand brake engaged - N.C. 6.6 ± 0.2 bars
- ☐ Low trailer pressure recharge - N.C. 6.6 ± 0.2 bars


A normally closed 6.6 ± 0.2 bar switch is also mounted on the axle reservoir to inform the electronic center of any axle circuit low pressure so as to inhibit differentiated axle braking in the ASR function.

Brake pad wear sensor 88007 / 88008

The signal is sent via the CAN line to the cluster that informs the operator of braking pad wear status with a display.



A. Signal - B. Positive - C. Negative - D. Wear warning control pin




Representation of the electrical signal the sensor sends to the electronic center depends on percent brake pad wear.

A	B	C
S	+	-
S / U		


WIRING DIAGRAM
S. Signal - + Power - (-) Mass

The signal generated by the induction sensor is sent to the EBS center, which sends it via the CAN (VDB) line to the cluster for display and information to the operator on brake pad wear status.

DISPLAY PRESENTATION



CLUSTER (DISPLAY)



BRAKE PAD WEAR

ECAS SUSPENSIONS

Compressed air suspensions

Compressed air suspensions feature high flexibility, high vibration damping and with system self-adjustment constant frame to road level clearance independently of vehicle load, that can be changed as well as vehicle load height with a special push button provided for this purpose.

In addition to the known advantages offered by compressed air suspension, the ECAS system also features:

- minimized air consumption
- prompt response to adjustment
- simple systems
- top safety level
- complete system diagnosis.

The **Electronically Controlled Air Suspension ECAS** system provides automatic vehicle compressed air suspension rated level monitoring.

All the above operations are subject to operating conditions and connected system safety devices.

The ECAS electronic provides automatic frame ground clearance control via the real values supplied by the sensors, which are compared with stored rated data. In the event of setting deviations or variations, the electronic center pilots the electro-pneumatic units through which it corrects real levels versus those stored previously by the operator.

The system is provided with remote control for frame lifting/lowering and leveling and operations are possible both with the vehicle stationary and moving.

This unit also enables other frame setting level storage and retrieval when required by operating conditions.


Vehicle lifting, lowering and leveling before load and unload operations are via the remote control located on the operator seat side.

The remote control can be extracted from its support so these operations can also be performed from ground level.

When unloading heavy loads or containers with a crane, the frame can be lowered completely.

Do not stop the engine when warning light (10) goes on.


If warning light (9) goes on when the vehicle moves, stop the vehicle and turn the ignition key to STOP; return it to MAR after about 7 seconds. Contact the Service Network if warning light (9) does not go off after some two seconds.



Ref.	Description	Component code
1	Steering wheel	-
2	Steering Wheel Interface	86123
3	Body Computer	86116
4	Cluster	50005
5	Rear Frame Computer	86118
6	Low pressure sensor	42200
7	Right rear axles level sensor	40046
8	Electronic tachograph	-
9	Right engine axle sensor	42381/A
10	Left engine axle sensor	42381/B
11	ECAS electronic centre	86023
12	Axle electro valve unit	-
13	3rd axle compressed air lift sensor	42389
14	Right 3rd axle air pressure sensor	42382/A
15	Left 3rd axle air pressure sensor	42382/B
16	Left axle level sensor	40046/B
17	Start support control switch	53030
17a	3rd axle left switch remote control	53309
18	Suspension remote control	85065
19	Axle level sensor	40046/A
20	Axle electro valve unit	78239
21	Diagnosis connector	72021
22	EBS electronic centre	88005

Compressed air suspension system diagrams**Rear compressed air suspension system diagram for 4x2 P tractors**


Rif.	Description
1	Limited return controlled pressure valve
2	Manual discharge valve
3	Suspension air reservoirs
4	One-direction valve
5	Electro-pneumatic distributor
6	Compressed air PTO
7	Left axle air springs
8	Right axle air springs
9	Remote control
10	Self-leveling switch
11	Electrical power under key
12	Electrical power direct from battery
13	30-pole diagnosis connector
14	CAN line connection
15	Electronic center
16	Level sensor
17	8 bar low pressure switch
A.	From the APU
*	Optional



002014t


Front/rear compressed air suspension system diagram for 4x2 FP tractors, 4x2 P/FP and 6x4 P carriages

Ref.	Description
1	Limited return controlled pressure valve
2	Manual discharge valve
3	Suspension air reservoirs
4	One-directional valve
5	Left axle level sensor
6	Electro-pneumatic axle distributor
7	Compressed air PTO
8	Left axle air spring
9	Left rear axle air spring
10	Right rear axle air spring
11	Left axle air springs
12	Left axle level sensor
13	Remote control
14	Self-leveling switch
15	Electrical power under key
16	Electrical power direct from battery
17	30-pole diagnosis connector
18	CAN line connection
19	Electronic center
20	Axle level sensor
21	Electro-pneumatic axle distributor
22	Right axle air spring
23	Left axle air spring
24	8 bar low pressure switch
25	Pressure sensor
A	From the APU
*	Optional
●	Only for FP vehicles
■	Only for 6x4 vehicles



Rear compressed air suspension diagram for 6x2 TxP tractors


Ref.	Description
1	Limited return controlled pressure valve
2	Suspension air reservoirs
3	Manual discharge valve
4	One-directional valve
5	Left axle level sensor
6	Electro-pneumatic distributor
7	Left axle intermediate pressure sensor
8	Left axle intermediate air spring
9	Left axle air springs
10	Left axle pressure sensor
11	Right axle pressure sensor
12	Left axle air springs
13	Left axle intermediate air spring
14	Left axle level remote control sensor
15	Self-leveling switch
16	Electrical power under key
17	Electrical power direct from battery
18	30-pole diagnosis connector
19	CAN line connection
20	Electronic center
21	Right axle intermediate pressure sensor
22	Right axle level sensor
23	bar low pressure switch
24	Compressed air PTO
A	From the APU
*	Optional



002012t


Front/rear compressed air suspension system diagram for 6x2 P-FP-PS-FS-PT-FT carriages

Ref.	Description
1	8 bar low pressure switch
2	Compressed air PTO
3	One-directional valve
4	Left axle level sensor
5	Left axle pressure sensor
6	Limited return controlled pressure valve
7	Suspension air reservoirs
8	Manual discharge valve
9	Left axle air springs
10	Electro-pneumatic distributor
11	Additional left axle air spring
12	Additional left axle pressure sensor
13	Additional left axle air spring
14	Additional axle pressure sensor
15	Re-suction one-directional valve
16	Additional right axle pressure sensor
17	Additional right axle pressure sensor
18	Additional right axle air spring
19	Remote control
20	Self-leveling switch
21	Electrical power under key
22	Electrical power direct from battery
23	30-pole diagnosis connector
24	CAN line connection
25	Electronic center
26	Right axle level sensor
27	Axle level sensor
28	Right axle air spring
29	Right axle pressure sensor
30	Axle electro-pneumatic distributor
31	Left axle air spring
32	Axle pressure sensor
A	From the APU
*	Optional
●	Only for FP vehicles
■	Only for PT - FT vehicles




ECAS electronic center

Vendor WABCO
Voltage 18 ÷ 30 Vdc
Heat range -40 to 75 °C




73667



001716t

ECAS electronic center

ECAS center for 4x2 P tractore rear compressed air suspension system


001717t

Connector X1

Pin	Cable	Function
1	GN/VE	CAN "L" line
2	---	--
3	WS/BI	CAN "H" line
4	---	--
5	8445	Positive from manual leveling push button (Optional)
6	---	--
7	7440	Power positive direct from battery
8	6402	Remote control communication line (pin 3)
9	2294	K line for diagnosis connector (pin 4)
10	8810	Power positive under key
11	6403	Remote control communication line (pin 4)
12	0000	Mass
13	8810	Remote control power positive (pin 1)
14	---	--
15	0402	Negative for remote control (pin 2)
16	---	--
17	---	--
18	---	--

Connector X2

Pin	Cable	Function
1	---	--
2	---	--
3	---	--
4	9400	Positive for bridge electro valve (pin 2)
5	---	--
6	---	--
7	0400	Negative for level sensor (pin 2)
8	5421	Positive for level sensor (pin 1)
9	---	--
10	---	--
11	9423	Negative for power electro valve (pin 1)
12	---	--
13	9424	Negative for rear frame management electro valve (pin 3)
14	---	--
15	---	--

ECAS center for 4X2 FP tractor and 4X2 P/FP and 6X4 P carriage front/rear compressed air suspension system


001714t

Connector X1

Pin	Cable	Function
1	GN/VE	CAN "L" line
2	---	--
3	WS/BI	CAN "H" line
4	---	--
5	8445	Positive from manual leveling push button (Optional)
6	---	--
7	7440	Power positive direct from battery
8	6402	Remote control communication line (pin 3)
9	2294	Diagnosis connector K line (pin 4)
10	8810	Power positive under key
11	6403	Remote control communication line (pin 4)
12	0000	Mass
13	8810	Remote control power positive (pin 1)
14	---	--
15	0402	Remote control negative (pin 2)
16	---	--
17	---	--
18	---	--

Connector X2

Pin	Cable	Function
1	---	--
2	---	--
3	---	--
4	9400	Positive for axle (pin 4 and pin 2) electro valve
5	5422	Positive for left axle level sensor (pin 1)
6	---	--
7	0400	Negative for level sensor (pin 2)
8	5421	Positive for right axle level sensor (pin 1)
9	5410	Positive for axle level sensor (pin 1)
10	9425	Negative for left rear frame management electro valve (pin 3)
11	9423	Negative for power electro valve (pin 1)
12	---	--
13	9424	Negative for right rear frame management electro valve (pin 2)
14	---	--
15	9413	Negative for front frame management electro valve (pin 1)

ECAS center for 6x2 TXP tractor rear compressed air suspension system**Junction X1**


Pin	Cable	Function
1	GN/VE	CAN "L"line
2	---	--
3	WS/BI	CAN "H"line
4	8445	--
5	8445	Positive from manual leveling push button (Optional)
6	8460	Positive from start support push button
7	7440	Power positive direct from battery
8	6402	Remote control communication line(pin 3)
9	2294	Diagnosis connector K line (pin 4)
10	8810	Power positive under key
11	6405	Remote control communication line(pin 4)
12	0000	Mass
13	8810	Remote control power positive (pin 1)
14	---	--
15	0402	Negative for remote control (pin 2)
16	---	--
17	---	--
18	---	--

Junction X2

Pin	Cable	Function
1	8403	Positive for pressure sensors
2	5443	Signal from right engine axle pressure sensor (pin 3)
3	---	--
4	9400	Positive for axle electro valve (61-62 / pin 4 and 2)
5	5422	Positive for left axle level sensor (pin 1)
6	5444	Signal from left engine axle pressure sensor (pin 3)
7	0400	Negative for level and pressure sensors (pin 2)
8	5421	Positive for right axle level sensor (pin 1)
9	5410	--
10	9425	Negative for left frame management electro valve (61 - pin 3)
11	9423	Negative for power electro valve (61 - pin 1)
12	9446	Negative for right added axle management electro valve (62 - pin 1)
13	9424	Negative for right added axle management electro valve (61 - pin 2)
14	9447	Negative for left added axle management electro valve (62 - pin 3)
15	9413	--

Junction X3

Pin	Cable	Function
1	9442	--
2	---	--
3	5442	Signal from left added axle pressure sensor (pin 3)
4	5441	Signal from right added axle pressure sensor (pin 3)
5	5445	--
6	---	--
7	---	--
8	---	--
9	---	--

ECAS center with pin-out 6x2 P – PT – FT - FP carriage rear/front axle compressed air suspension system**Connector X1**

Pin	Cable	Function
1	GN/VE	CAN "L" line
2	---	--
3	WS/BI	CAN "H" line
4	8445	Signal from 3rd axle lift/lower push button
5	8445	Positive from manual leveling push button (Optional)
6	8460	Positive from start support push button
7	7440	Power positive direct from battery
8	6402	Remote control communication line (pin 3)
9	2294	Diagnosis connector K line (pin 4)
10	8810	Power positive under key
11	6403	Remote control communication line (pin 4)
12	0000	Mass
13	8810	Remote control power positive (pin 1)
14	---	--
15	0402	Negative for remote control (pin 2)
16	---	--
17	---	--
18	---	--

Connector X2

Pin	Cable	Function
1	8403	Positive for pressure sensors (pin 1)
2	5443	Signal from right engine axle pressure sensor (pin 3)
3	---	--
4	9400	Positive for axle electro valve (61-62 / pin 4 and 2)
5	5422	Positive for left axle level sensor (pin 1)
6	5444	Signal from engine left axle pressure sensor (pin 3)
7	0400	Negative for level and pressure sensors (pin 2)
8	5421	Positive for right axle level sensor (pin 1)
9	5410	Positive for axle level sensor (pin 1)
10	9425	Negative for rear left axle management electro valve (61 - pin 3)
11	9423	Negative for power electro valve (61 - pin 1)
12	9446	Negative for right added axle management electro valve (62 - pin 1)
13	9424	Negative for rear right axle management electro valve (61 - pin 2)
14	9447	Negative for left added axle management electro valve (62 - pin 3)
15	9413	Negative for front/rear frame management electro valve (pin 1)

Connector X3


Pin	Cable	Function
1	9442	Negative for added axle lifting electro valve (62 - pin 1)
2	---	--
3	5442	Signal from left added axle pressure sensor (pin 3)
4	5441	Signal from right added axle pressure sensor (pin 3)
5	5445	Signal from lifter air spring pressure sensor (pin 3)
6	---	--
7	---	--
8	---	--
9	---	--

Electro-pneumatic axle distributor for 4x2 – 6x2 – FP tractors


This component is used on all integral suspension vehicles. It consists of a control electro valve and two compressed air distributors for managing both axles sides.

A calibrated hole is provided to prevent pressure overflow between the air springs and consequently stabilize the axles on the internal connection between the two outputs.


The distributor is connected to the system via a 3-pole connector (A).



002103t



002029t



002042t

Rif.	Description
1	Electro valve control negative (6.1)
2	Positive (6.4)
4	--


Electro-pneumatic axle for 4x2 P tractors

It consists of two control electro valves "A" and "B" and three compressed air distributors.


Electro valve "A" manages the input/output distributor.

Electro valve "B" manages the frame setting distributor.


The electro-pneumatic distributor is connected to the system via a 4-pole connector.



002103t



002035t



002042t

Ref.	Description
1	Electro valve "A" control negative
2	Common positive
3	Electro valve "B" control negative
4	---

Electro-pneumatic axle distributor for 4x2 FP tractors and 4x2 P/FP – 6x4 P carriages


It consists of three control electro valves "A", "B" and "C" and the same number of compressed air distributors.

Electro valve "A" manages the input/output distributor.


Electro valve "B" manages the right frame setting distributor.

Electro valve "C" manages the left frame setting distributor.


The electro-pneumatic distributor is connected to the system via a 4-pole connector (A).



002105t



002035t



002044t

Ref.	Description
1	Electro valve "A" control negative
2	Electro valve "B" control negative
3	Electro valve "C" control negative
4	Common positive

Electro-pneumatic axle distributor for 6x2 TXP tractors

It consists of six control electro valves "A", "B", "C", "E", "F" and the same number of compressed air distributors.

Electro valve "A" manages the input/output distributor.


Electro valve "B" manages the right frame setting distributor.

Electro valve "C" manages the left frame setting distributor.

Electro valve "E" manages the right added axle setting distributor.

Electro valve "F" manages the left added axle setting distributor.

The electro-pneumatic distributor is connected to the system via two 4-pole connectors (I) (II).



“I”

Ref.	Description
1	Electro valve "A" control negative (61.1)
2	Electro valve "B" control negative (61.2)
3	Electro valve "C" control negative (61.3)
4	Common positive (61.4)

“II”


Ref.	Description
1	Electro valve "E" control negative (62.1)
2	Common positive (62.2)
3	Electro valve "F" control negative (62.3)
4	Common positive (62.4)

Electro-pneumatic axle distributor for 6x2 carriages


The component consists of six control electro valves “A”, “B”, “C”, “D”, “E”, “F” and the same number of compressed air distributors.

- Electro valve “A” manages the input/output distributor.
- Electro valve “B” manages the right frame setting distributor.
- Electro valve “C” manages the left frame setting distributor.
- Electro valve “D” manages the right added axle setting distributor.
- Electro valve “E” manages the left added axle setting distributor.
- Electro valve “F” manages the lift control distributor.


The electro-pneumatic distributor is connected to the system via two 4-pole connectors (I) (II).



002107t



002035t



002046t

“I”

Ref.	Description
1	Electro valve “A” control negative (61.1)
2	Electro valve “B” control negative (61.2)
3	Electro valve “C” control negative (61.3)
4	Common positive (61.4)

“II”


Ref.	Description
1	Electro valve “F” control negative (62.1)
2	Electro valve “D” control negative (62.2)
3	Electro valve “E” control negative (62.3)
4	Common positive (62.4)

EUROTRONIC AUTOMATIC TRANSMISSION

General

The new generation of Automated EuroTronic transmissions is IVECO's response to new Customer expectations and changed needs. The design of gearshifts with a new inspected and test transmission technology concept combined with advanced electronics has generated a system that guarantees:

- ☐ Economic efficiency
- ☐ Reliability
- ☐ Environmental acceptability



VIEW OF THE AUTOMATED EUROTRONIC TRANSMISSION

These modern and completely automated transmission systems with highly integrated components have already been developed for EDC M6.2 center ELECTRONIC CONTROL DIESEL ENGINES.

The system automates gear selection and meshing by automatically controlling the clutch and engine during gear shifting.

The operator decides when to shift gears by actuating a selector lever with no need to release the accelerator pedal.

Unlike previous versions, the Automated EuroTronic enables the operator to use COMPLETELY AUTOMATIC gear shifting management.

The system enables automatic vehicle start and completely eliminates the clutch pedal. On receipt of vehicle and operator signals, the electronic center controls all components involved, optimizes maneuvers and manages safety.

	PRODUCTIVITY				Comfort	Safety
	Con- sumption	Average com- mercial speed	Maintenance courses	Payload		
Operating comfort and less physical and mental stress	•	•			•	•
Precise and fast gear shifting	•	•			•	
Optimized use	•		•			
No use errors	•	•	•		•	•
Selection of maximum rpm for engine brake use	•	•			•	•
Reduced tare				•		
Longer linkage line life (the clutch especially)			•			
Noise abatement (Db)					•	
Automatic gear shifting	•	•			•	

Design features

The entire transmission shaft and universal joint assembly is relieved of considerable load as gear shifting operations and procedures are automated. The main Automated EuroTronic countershaft gearbox consists of the following:

- ☐ A couple of low and high speed gears (SPLITTER)
- ☐ 4 forward speeds + 1 reverse

The auxiliary box consists of a G.R.E. epicyclical reduction gear mounted at the back to double the number of gear ratios of the main gearbox and enable 16 forward and 2 reverse speeds.

Description

Automated EuroTronic is a completely automatic transmission featuring a regulated dry clutch that eliminates the clutch pedal. It consists of a reduced noise emission main gearbox with a planetary and split group.

The main unit meshes with front teeth and only the planetary and split group are synchronized.

The 16-speed Automated EuroTronic features sixteen forward and two reverse speeds.

The Instrument cluster supplied the operator with all necessary system information, such as gear meshed, disturbances and the like.

The insert module and the clutch regulator unit are the most important structural elements for complete transmission automation.

The former consists of the transmission electronic system, switching valves, cylinder and sensors.

The transmission electronic system processes all input signals and inserts the speed via the electromagnetic valve and the switching cylinder.


The clutch regulator is set electro-pneumatically and performs all friction actuation operations. In the manual mode, the operator can easily select speeds with the speed selector lever.

In the automatic mode, the operator only has to actuate the accelerator or brake pedal.

Speeds are selected automatically by the system.

To respect anti-pollution regulations, all gears are helical teeth, which enabled abating noise level about 79 db.

Transmission/clutch connection diagram with the compressed air system



002000t


1. Pressure limiter valve - 2. Normal purge valve - 3. 10-l reservoir - 4. Air pressure switch - 5. Pressure control socket - 6. 5-l reservoir - 7. Distributor element - 8. Controlled pressure valve - 9. Reservoir - 10. Normal purge valve - 11. APU Air Processing Unit - 12. Compressor.

F = Clutch

C = Transmission

Display on the Instrument Cluster

The information required by the operator is displayed by the system on the Instrument Cluster central display.



001713t

The symbols displayed by the system are as follows:

	System self-diagnosis		Clutch overload
	Gear in neutral		Duct disc wear
	Accelerator pedal pressed before turning the ignition key		Transmission in the manual mode
	Slow reverse selected		Transmission in the automatic mode, with clear display Transmission with the automatic mode pre-selected but not active with shadowed display (moving at low speed)
	Fast reverse selected		Speed number selected (12 th)
	Low system air pressure		Transmission in the manual mode, lower speeds recommended by the system Recommended ratios (as many as 3) are displayed with bars

LIMP - HOME

The Limp Home function enables removing the vehicle when the system presents serious anomalies it cannot manage automatically. It cannot move the vehicle when purely mechanical anomalies are present. The operator can activate the Limp Home function as follows:

1. Key switch on stop
2. Key switch on +I5
3. Press the blue color push button on the gear shift lever within 5 seconds
4. Keep the blue color push button pressed for at least 5 seconds.

The operator can select the speed at which to start with gearshift lever, and can select as many as 7 speeds forward and 2 reverse with the 16 speed transmissions and 5 and 2 respectively with the 12-speed one. Selection is managed by the system via an internal delay reaction time and not through the speed with which the gearshift lever sensors identify lever movements.

Speed selection must be slow to allow the system to implement each individual speed, as the Cluster displays individual speeds with a delay of a few seconds.


The speeds that can be set with the Limp Home function can only be selected with the vehicle stationary.

After start speed selection, pressing the function push button for at least 2 seconds makes the system control timed clutch engagement. To prevent the engine from stopping, the clutch disengages automatically when the speed output from the transmission is below a reference threshold. If the clutch sensor is not operating properly, the clutch can only be engaged/disengaged manually with the Function push button.

The system disregards any gearshift lever movement during vehicle movement. In particular, push button function operation is excluded when engine rpm is over 950 and reactivated at under this rating.

Clutch management can thus also be manual with the function push button on the gearshift lever of the brake pedal when engine rpm is under/equal to 950. When the vehicle is stopped with the Limp Home function, the clutch is managed automatically if possible or manually as described above.


At vehicle stop, the system keeps the Limp Home function active with the start speed set previously and the function remains active until system RESET is completed.

Eurotronic Automated transmission operation diagram

002840t

1. Multifunction lever - 2. Steering Wheel Interface - 3. Instrument Cluster - 4. Backup lights - 5. Rear Frame Computer - 6. Body Computer - 7. Door open switch - 8, 9. PTO on request switches - 10. Tachograph - 11. Intarder centre - 12. EBS centre - 13. EDC centre - 14. External buzzer - 15. PTO electro valves - 17. PTO on warning switches - 18. Proportional electro valve - 19. Water temperature sensor - 20. Engine cutout electro valve - 21. Accelerator pedal - 22. ON/OFF electro valve - 23. Brake pedal Duplex distributor - 24. VGT electro valve - 25. Gearshift/transmission electronic centre - 26. Diagnosis connection

Location of main components



002109t

1. Clutch actuator - 2. Tachograph gearshift/transmission outgoing speed sensor - 3. Gearshift/transmission outgoing speed sensor for sensor - 4. Gearshift idling position sensor - 5. Frame side centre connector - 6. Vehicle Data Bus VDB CAN line - 7. System internal CAN line - 8. Gearshift/transmission electronic centre - 9. Gearshift/transmission side centre connector

ELECTRONIC CENTER

It is integrated into the gearshift actuator.



Automatic transmission management enables automating speed selection and meshing with automatic clutch and engine control.


It interfaces with the other on-board electronic systems such as the EDC, EBS, INTARDER and Instrument Cluster via a CAN V.D.B. Vehicle Data Bus line.

From connection with the EDC system the transmission electronic center can detect accelerator pedal position, fuel delivery, engine rpm and engine brake and kick-down activation.

The center inside houses center temperature, transmission oil temperature and low air pressure sensors to improve system operation.

Function AL is enabled at <5.8 bar pressure and disabled at > 6 bars. The Automated EuroTronic transmission electronic center offers the possibility of a Cluster displayed error code for preliminary diagnosis and is also provided with an advanced self-diagnosis system capable of identifying and storing any even intermittent anomaly dependent on environmental condition the system may have encountered during operation, to ensure more correct and reliable repair.






CAB SIDE CONNECTOR (x1)

SENSOR SIDE/CLUTCH ACTUATOR CONNECTOR (x2)

PIN	Cable	Description	Pin	Cable	Description
1	8802	Power from Body Computer (J 3/6)	1	—	—
2	2297	Positive 30-pole connector for ground diagnosis	2	—	—
3	SB	CAN line to speed selector PIN 8	3	—	—
4	7101	Positive from fuse 70602	4	—	—
5	7101	Positive from fuse 70602	5	—	—
6	SB	CAN line to speed selector PIN 7	6	—	Gearshift speed sensor mass
7	—	Free	7	—	Signal electrovalve Y17 (slow opening)
8	WS/BI	CAN VDB line	8	—	Signal electrovalve Y16 (fast opening)
9	—	Free	9	—	Signal electrovalve Y15 (slow closing)
10	—	Free	10	—	Clutch position sensor analogic signal
11	6100	Positive from speed selector PIN 15	11	—	Gearshift/transmission outgoing speed sensor signal
12	GN/VE	CAN VDB line	12	—	Signal electrovalve Y14 (fast closing)
13	—	—	13	—	—
14	—	—	14	—	—
15	—	—	15	—	Clutch position sensor power supply
16	0050	Negative	16	—	Y15 - Y17 electro valve mass
17	0050	Negative	17	—	Y14 - Y16 electro valve mass
18	—	—	18	—	—
19	—	—	19	—	Gearshift/transmission speed sensor power supply
20	—	—	20	—	Clutch position sensor mass

SPEED SELECTOR

The speed selector is an electronic component located inside the cab to the operator's side, which receives a series of signals from some system components such as the P.T.O. request switches, the engine brake request switch, the door opening push button and the like, and informs the electronic center that in its turn decides the various operating strategies to implement. It communicates with the electronic center via a CAN V.D.B. Vehicle Data Bus line and is powered at a 24 Volts by the center and vehicle batteries via +15. The latter is also used with a special procedure to enable error code display.



PIN-OUT CONNECTOR

Pin	Cable	Function
1	-	-
2	-	-
3	-	-
4	0136	Negative signal for PTO 2 remote switch cutin
5	-	-
6	-	-
7	SB	CAN line for communication with the transmission electronic center
8	SB	CAN line for communication with the transmission electronic center
9	-	PTO 1 on return signal
10	-	-
11	-	PTO 2 on return signal
12	-	-
13	0134	Negative signal for PTO 1 remote switch cutin
14	8101	Power under key (+ 15)
15	6100	Power from transmission electronic center
16	0050	Mass

SB = System Bus

TRANSMISSION ACTUATOR

The transmission actuator is mounted on the top of the main gearbox. It consists of a series of electro valves, control cylinder and sensors. The electronic center powers the various electro valves to selected gear ratios available by using sensor signals as a feedback. Actuator operating pressure is 7 bars.

Actuator components

Y1	Inertia brakes control electro valve
Y2	Fast Splitter control electro valve
Y3	Slow Splitter control electro valve
Y4	Speed selection control electro valve
Y5	Speed selection control electro valve
Y6	Gear meshing control electro valve
Y7	Gear meshing control electro valve
Y8	Downshifted speed epicyclical unit control electro valve
Y9	Normal speed epicyclical unit control electro valve
Y10	Compressed air supply electro valve
B2	Transmission input rpm sensor
B4	Selected speed sensor
B5	Selector position sensor
B6	Normal and downshifted speed epicyclical unit position sensor
B7	Splitter position sensor





**The actuator cannot be overhauled. For actuator removal, transmission must be on NEUTRA.
The transmission neutral warning switch is located on the gearshift.**

Electro valves are of the N.C. on/off type powered at 24 Volt with ~64.2 Ohm resistance at 20 °C.

Induction type transmission input rpm sensor B2 features ~1 Kohm resistance and identified rpm with a 40-teeth sound wheel. This signal is compared with the engine rpm measured by the E.D.C. center; if the two values are NOT identical the transmission center is enabled to detect clutch slide.

Induction type sensors B4, B5, B6 and B7, respectively selector position, epicyclical unit and splitter, are an integral part of the control cylinders and feature ~ 69 Ohm resistance at 20 °C.

The automatic system pressure sensor located downstream the reduction gear is also integrated inside the center.

LOCATION ON THE VEHICLE

CLUTCH ACTUATOR

The clutch actuator is located on the lower part of the clutch bell.

It consists of four electro valves, an actuator cylinder and a clutch run position sensor and is suitable to actuate 17.5" single-disc clutches via a 2.09 ratio lever.

In the load mode as detected by the accelerator pedal sensor signal from the E.D.C. center, the electronic center powers the various electro valves for slow or fast clutch engagement and release.

The center uses the clutch run position sensor to calculate clutch wear at each vehicle start, to enable fast approaches and overcome empty runs.

Actuator components

- Y14 - Fast clutch engagement electro valve
- Y15 - Slow clutch engagement electro valve
- Y16 - Fast clutch release electro valve
- Y17 - Slow clutch release electro valve
- S - Clutch run position sensor
- T - Air vent cap

Actuator operating pressure is 11 bars.

Internal channel diameters are as follows:

- 2.5 mm for fast engagement/release;
- 1.5 mm for slow engagement/release.

Actuation times at start, subject to load, slope and accelerator pedal position, are as follows:



- Initial engagement: ~ 1 sec.
- Modulated release: ~ 4 sec.

The times change as follows during gear changes to enable fast and precise synchronization:

- Modulated opening: ~ 0.6 sec.
- Complete opening: ~ 0.3 sec.
- Modulated closing: ~ 1 sec.

Actuator features

- Operating fluid: air (min. 6 bar max 11.5 bar)
- Power: 24 Volt
- Load on lever in operating conditions: 382 kg
- Operating temperature: 40 °C + - 120 °C
- Cylinder diameter: 100 mm
- Piston travel: 70 mm




Clutch actuator Pin-out

The N.C. on/off type electro valves are powered at 24 Volt with $\sim 14 \div 20$ Ohm resistance.

The sensor is powered by the center at 5 Volts and the return signal is between 0.5 and 4.5 Volt.

The clutch actuator is connected to the system via a 10-pole connector.



A. 20-pole connector - B. Output transmission rpm sensors

Pin	Function
1	-
2	-
3	-
4	-
5	-
6	Transmission speed sensor mass
7	Y17 electro valve signal (slow opening)
8	Y16 electro valve signal (fast opening)
9	Y15 electro valve signal (slow closing)
10	Clutch position sensor analogic signal (0.5)
11	Transmission output speed sensor signal
12	Y14 electro valve signal (fast closing)
13	-
14	-
15	Clutch position sensor power
16	Y15 - Y17 electro valve mass
17	Y14 - Y16 electro valve mass
18	-
19	Transmission speed sensor power
20	Clutch position sensor mass




Accelerator pedal

Release pedal NA integrated into the position sensor is used to detect engine idling position and enable clutch engagement at vehicle start.

The signal reaches the EDC electronic center via the CAN VDB Vehicle Data Base line and is sent to the Automated EuroTronic transmission center.


Kick Down is activated with the accelerator pedal in automatic function mode travel. The Kick Down function is activated when accelerator pedal lever (I) move the potentiometer to position 100%, which does not correspond to pedal mechanical travel end.

Stiffened travel end is only mechanical and is used to transmit the feeling Kick Down inserted to the operator.




WALL PASS

This new wall pass has been introduced to maximize contact reliability.



00206t



- | | |
|--------------------|---|
| Connector A | - White (free) |
| Connector B | - Brown (ECAS) |
| Connector C | - Yellow (EBS/ABS/SDR) |
| Connector D | - Blue (EuroTronic/PTO/INTARDER) |
| Connector E | - Green (EDC/ADR) |

Blu "D" Wall pass

Pin	Function	Cable colour code
1	Supply system gearbox Eurotronic terminal 15 after fuse	8101
2	Earth Eurotronic	0000
3	Electric selector with automatic gearbox	6100
4	Line CAN - L electric selector with automatic gearbox	GN/VE
5	Line CAN - H electric selector with automatic gearbox	WS/BI
6	Supply for Eurotronic 2 from terminal 30	7101
7	Line - K fault-diagnosis Eurotronic 2	2297
8	Line CAN - L electronic control unit for automatic gearbox (VBD)	GN/VE
9	Line CAN - H electronic control unit for automatic gearbox (VBD)	WS/BI
10	Line CAN - L electronic control unit for automatic gearbox (VBD)	GN/VE
11	Line CAN - H electronic control unit for automatic gearbox (VBD)	WS/BI
12	P.T.O.1 Eurotronic	9131
13	P.T.O.2 Eurotronic	9132
14	Water temperature transmitter for Retarder	0309
15	Water temperature transmitter for Retarder	5309
16	Solenoid valve for Retarder oil accumulator	9311
17	Solenoid valve for Retarder oil accumulator	0311
18	Solenoid valve to turn on Retarder	9130
19	Solenoid valve to turn on Retarder	0310

INTARDER

Operation

The intarder is operated with the 7-position selector located in the right direction indicator (1). INTARDER cut-in indication is managed by the CLUSTER (2) via a specific warning.

The system is provided with a Brensomat constant velocity function used for vehicles without EBS. This function enables keeping a vehicle on a downhill slope moving at the speed as selected by the operator. In this case, the intarder electronic centre automatically selects the braking torque required.

The constant velocity function is only activated in position "0" after storing the speed desired.

Storage can be at any of the 7 selector positions by briefly pressing the push button provided; with higher pressure storing speed at that moment and lower pressure decrease of speed set. The speed programmed previously is restored as soon as the selector is returned to position "0".

Pressing the push button once again disables the constant velocity function. The oil contained in the sump is sent to the intarder hydraulic circuit via a filter and the circuit is protected by a safety valve.

By acting on selector (1), electronic centre (4) receives via SWI (3) an electrical signal that it processes and sends to electro valve (7) controlling the accumulator and proportional electro valve (5).

The accumulator control electro valve switches and lets air under pressure pass through its piston to send oil to the hydraulic circuit and reduce action time.

The proportional electro valve acts on the control valve to set its pressure. The adjustment valve is piloted by control valve oil pressure. The rotor is connected to the rear axle via the transmission shaft and the stator is connected to the frame through the intarder case.

The oil contained in the areas between the rotor and the stator is moved by the rotor blades to create a closed circuit oil flow between mobile and fixed parts.


By impacting the stator blades, oil causes rotor and therefore vehicle braking. Reduced oil flow speed between the rotor and the stator transforms kinetic energy into heat, to dissipate which oil passes through an oil/water heat exchanger, where oil heat is transmitted to cooling water and dissipated through the vehicle cooling system.

The heat exchanger water discharge pipe is provided with a temperature sensor (6) that continually sends cooling water temperature data to the electronic centre to ensure maximum temperature allowed for proper engine operation is not exceeded.

If water temperature rises to reach the safety limit for any reason whatsoever, the centre pilots sump control air adjustment to reduce braking torque.

The electronic centre receives a signal from the ABS/EBS system that causes intarder cutout when actuated and it also receives a signal from electronic tachograph (8) enabling constant velocity function use. This signal is sent via a VDB can line.

Switching to position "0" cuts the intarder off and deactivates the proportional and accumulator control electro valves.



002926t

1. Engine brake/Intarder selector - 2. Instrument Cluster - 3. Steering Wheel Interface centre - 4. Intarder electronic centre - 5. Proportional electro valve - 6. Water temperature sensor - 7. Accumulator on/off control electro valve - 8. Electronic tachograph

Hydraulic system diagram

Description

The oil contained in the sump is sent to the intarder hydraulic circuit by a pump through a filter and a 12.5 bar pressure limiter valve.

Intarder on


When the intarder is actuated with control (2), the centre supplies electro valve (19) controlling accumulator (10), whose piston is piloted by the service air system at 9.5 bar pressure to send oil faster to the rotor/stator unit.

When excited, proportional electro valve (16) acts on valve (16) by moving its hydraulic spool and moves function control pressure to braking level.

Pressure acts on adjustment valve (14), to create communication between input duct P and output ducts P I - R.

Thus, oil from pressure limiter electro valve (4) moves the hydraulic spool of valve (8) and puts duct R₀₁ 0 into communication with the motor/stator via heat exchanger (9).

Pressure (13) is not affected by oil pressure and closes oil discharge into sump (7).




002924t

Speed storage and use

By inserting Cruise Control, the system automatically maintains vehicle advance speed without having to use the accelerator pedal.

If vehicle speed increases over 2 Km/h more than the speed set, such as when travelling downhill for instance, the engine brake is activated automatically to slow the vehicle down and maintain the speed reached. The intarder is also activated if speed increases by over 3 Km/h.



002868t


Its function can only be activated when the following conditions are satisfied:

- ☐ engine brake/intarder lever cut out;
- ☐ vehicle on the move with gear selected;
- ☐ vehicle speed over 20 Km/h;
- ☐ brake pedal released;
- ☐ clutch pedal released.

Control	Vehicle speed adjustment
ON+	Speed increase
ON-	Speed decrease
RESUME	Last stored speed selection
OFF	Speed adjustment cancellation


Adjustment is cut out when the brake or clutch pedal is actuated. The same applies when the minimum speed set is not reached. Top speed is stored in the programme inside the electronic control module and cannot be changed.

1. Basculating push button ON has the following functions:
 - a) when pressed once, it activates the function and keeps the speed set at that moment by the accelerator pedal. The accelerator pedal can then be released and the vehicle keeps moving at the cruise speed set.
 - b) with the function already activated, it increases vehicle speed without having to use the accelerator pedal.
2. Basculating push button ON has the following function: with the function activated, it decreases vehicle speed.
3. The Cruise Control lever actuated OFF towards the steering wheel deactivates the function (CC display shaded).
4. Actuating the steering wheel lever once again (RESUME) the value stored is reactivated (CC display clear).


Assembly

002788t

1. Instrument Cluster - 2. Steering Wheel Interface - 3. Engine brake on multi function lever - 4. Body Computer - 5. Tachograph - 6. EDC centre - 7. EBS centre - 8. EuroTronic centre - 9. Intarder centre - 10. Diagnosis connection - 11. Engine brake electro valve - 12. VGT electro valve - 13. Accelerator pedal - 14. Brake pedal Duplex distributor - 15. Proportional electro valve - 16. ON-OFF electro valve - 17. Water temperature sensor

Centre disposition

A. Intarder centre




73667

003178t

Pin	Cable	Function
1	9311	ON/OFF electro valve positive
3	0310	Proportional electro valve negative
4	9310	Proportional electro valve positive
9	5309	Water temperature transmitter positive
12	3393	30-pole diagnosis connection
14	2293	30-pole diagnosis connection
22	-	CAN VDB (H) line
27	0000	Cab mass
28	0000	Cab mass
34	0311	Oil accumulator electro valve negative
37	0309	Water temperature transmitter negative
45	-	CAN VDB (L) line
53	8300	+15 power supply
54	7300	+30 power supply
8	5541	Cluster

Pins not mentioned were not used



002856t

Blu "D" Wall pass

Pin	Function	Cable colour code
1	TGC opening signal	8802
2	Eurotronic 2 centre mass	0000
3	Eurotronic 2 centre speed selector power supply	6100
4	CAN - L line from Eurotronic 2 centre to SB speed selector	GN/VE
5	CAN - H line from Eurotronic 2 centre to SB speed selector	WS/BI
6	+30 power supply positive direct from the battery (+30)	7101
7	K diagnosis line	2297
8	CAN - L VDB line	GN/VE
9	CAN - H VDB line	WS/BI
10	CAN - L VDB line	GN/VE
11	CAN - H VDB line	WS/BI
12	Positive for P.T.O.1 electro valve from relay	9131
13	Positive for P.T.O.2 electro valve from relay	9132
14	Intarder water temperature sensor	0309
15	Intarder water temperature sensor	5309
16	Intarder on/off electro valve	9311
17	Intarder on/off electro valve	0311
18	Intarder proportional electro valve	9130
19	Intarder proportional electro valve	0310

Diagnosis


DRAFT


Circuit charts

	Page
Card 1: Battery positive	3
Card 2: Positive after TGC (+30)	4
Card 3: Positive after TGC (+30)	5
Card 4: Positive after TGC (+30)	6
Card 5: Services supply (+15)	7
Card 6: Services supply (+15)	8
Card 7: BC unit (J7)	9
Card 8: BC unit (J6)	10
Card 9: BC unit (J4-J5)	11
Card 10: BC unit (J2-J3)	12
Card 11: SWI unit	13
Card 12: FFC unit (J2)	14
Card 13: FFC unit (J1)	15
Card 14: RFC unit (J1)	16
Card 15: RFC unit (J2)	17
Card 16: CM unit	18
Card 17: DDM-BM unit	19
Card 18: PDM unit	20
Card 19: IC unit	21
Card 20: CAN-ICB/IDB line	22
Card 21: CAN-SB (EBS/ABS) line	23
Card 22: CAN-BCB line	24
Card 23: VDI unit / CAN-VDB line	25
Card 24: ECAS 4x2 FP	26
Card 25: ECAS 6x4 P	27
Card 26: ECAS 6x2 P/FP	28
Card 27: ECAS 4x2 Tractor	29

	Page
Card 28: ECAS 6x2C	30
Card 29: ZF retarder	31
Card 30: ABS	32
Card 31: EBS	33
Card 32: EuroTronic II	34
Card 33: Immobilizer	35
Card 34: Manually controlled air conditioning system	36
Card 35: Automatically controlled air conditioning system	37
Card 36: Automatically controlled supplementary water heater ..	38
Card 37: Manually controlled supplementary water heater	39
Card 38: Manually controlled supplementary air heater	40
Card 39: EDC (Connector A) for F3A engines ..	41
Card 40: EDC (Connector A) for F2B engines ..	42
Card 41: EDC (Connector B)	43
Card 42: PTO with mechanical gearbox	44
Card 43: Radioreceiver	45

Card 1: Battery positive




Card 2: Positive after TGC (+30)


85579


The diagram illustrates a complex electronic circuit, possibly a medical device, featuring a variety of components and their interconnections. Key elements include:


- Power Section:** A transformer (70401) with a 7.5A secondary winding (7772) and a 5A secondary winding (4412). A 20A fuse (70603) is connected to the 7772 line. A 20A fuse (70601) is connected to the 4412 line. A 10A fuse (70605) is connected to the 7772 line.
- Control and Timing Section:** Includes a 25924 timer, a 42374 timer, and a 68005 timer. A 68003 timer is also present. A 68005 timer is connected to a 2A 12V regulator (68005).
- Signal Processing Section:** Includes a 68003 timer, a 68005 timer, and a 68005 timer. A 68003 timer is connected to a 2A 12V regulator (68005).
- Output Section:** Includes a 68003 timer, a 68005 timer, and a 68005 timer. A 68003 timer is connected to a 2A 12V regulator (68005).
- Other Components:** A 68003 timer, a 68005 timer, and a 68005 timer. A 68003 timer is connected to a 2A 12V regulator (68005).

The diagram is a detailed schematic showing the internal wiring and component values for a complex electronic system. It includes a power section with a transformer and fuses, a control section with various timers and regulators, and an output section with a motor and other components. The components are interconnected through a network of wires, with labels indicating component values and connections.


Card 4: Positive after TGC (+30)


Card 6: Services supply (+15)

Card 7: BC unit (J7)


Card 9: BC unit (J4-J5)

Card 10: BC unit (J2-J3)





Card II: SWI unit


Card 12: FFC unit (J2)





Card I3: FFC unit (J1)




Card 15: RFC unit (J2)




Card I6 CM unit


Card 17: DDM-BM unit


Card 18: PDM unit




Card 19: IC unit




Card 21: CAN-SB (EBS/ABS) line


Card 23: VDI unit / CAN-VDB line

[illegible]


Card 25: ECAS 6x4 P



Card 27: ECAS 4x2 Tractor




Card 28: ECAS 6x2C




85605

Card 29: ZF retarder



Card 30: ABS



Base - January 2003




The diagram illustrates the wiring for a vehicle immobilizer system. The main components and their connections are as follows:


- 86116 BODY COMPUTER:** Connected to the power source (0000) and ground (m1, m5, m6) via terminals J7 and J2. It also controls the 52502 relay and the 70603 sensor.
- 50005 I.C. (Immobilizer Control):** Receives signals from the 86116 BODY COMPUTER and the 70603 sensor. It controls the 52502 relay and the 72021 switch.
- 85130 IMMOB. (Immobilizer):** Receives signals from the 50005 I.C. and the 72021 switch. It controls the 52502 relay and the 70603 sensor.
- 52502 Relay:** Controls the 70603 sensor and the 72021 switch. It is connected to the power source (0000) and ground (m1, m5, m6).
- 70603 Sensor:** Receives signals from the 86116 BODY COMPUTER and the 50005 I.C. It controls the 52502 relay and the 72021 switch.
- 72021 Switch:** Receives signals from the 50005 I.C. and the 85130 IMMOB. It controls the 52502 relay and the 70603 sensor.


The diagram also shows the connection of the 52502 relay to the 70603 sensor and the 72021 switch. The 70603 sensor is connected to the 86116 BODY COMPUTER and the 50005 I.C. The 72021 switch is connected to the 50005 I.C. and the 85130 IMMOB. The 52502 relay is connected to the power source (0000) and ground (m1, m5, m6).


Card 34: Manually controlled air conditioning system




Card 35: Automatically controlled air conditioning system




Card 36: Automatically controlled supplementary water heater

Card 37: Manually controlled supplementary water heater



Card 40: EDC (Connector A) for F2B engines


Card 4l: EDC (Connector B)



Print 603.93.191




Card 43: Radioreceiver



Block diagrams

	Page
Chart 1: Start-up – recharge warning light	3
Chart 2: EDC power supply- Immobilizer warning light - EDC Blink code (warning light) – Fur wheel drive on warning light	4
Chart 3: Cruise Control – Accelerator pedal sensor (potentiometer) - Pre-post heating warning light	5
Chart 4: Intarder	6
Chart 5: Voltmeter – Rev counter - Engine water temperature - Fuel level	7
Chart 6: Engine oil pressure – engine oil level – Window winder level - Hydraulic power steering fluid level - Engine water level	8
Chart 7: Chock wear indicator - Pad wear indicator - Reduced gear on indicator- Clogged oil filter indicator- Clogged air filter indicator	9
Chart 8: Differential block - Water presence in fuel indicator	10
Chart 9: Exterior lights	11
Chart 10: Exterior lights	12
Chart 11: Exterior lights – Reverse light	13
Chart 12: Hazard lights – Headlight beam orientation	14
Chart 13: Internal lights	15
Chart 14: Windscreen wiper – Horn - Hour counter	16
Chart 15: TGC	17
Chart 16: Sunroof – Windscreen washer	18
Chart 17: Tachograph	19
Chart 18: Engine electric fan	20
Chart 19: Rearview mirror control - Power windows	21

	Page
Chart 20: Central door lock	22
Chart 21: Ecas (warning lights) - ABS (warning lights)	23
Chart 22: EBS (warning lights) - Heated windscreen - PTO	24
Chart 23: Retarder (warning light) - Cabin tilting	25
Chart 24: Brake air pressure - ECAS - Outside temperature	26
Chart 25: Trip odometer / total odometer - speed limiter	27
Chart 26: Engine oil temperature – Beacon lights – Sun visor	28

Chart I: Start-up – recharge warning light

FUNCTION	CABIN	CROSSWALL	FRAME
A EDC MS6 POWER SUPPLY			
B EDC MS6 BLINK CODE AND IMMOBILIZER VISUALIZATION			
C AUTOMATIC SNOW CHAIN INSERTION DISPLAY			
D IMMOBILIZER DISPLAY	SEE SECTION B		
E INTEGRAL TRACTION INSERTION DISPLAY			


Chart 3: Cruise Control – Accelerator pedal sensor (potentiometer) - Pre-post heating warning light

Chart 4: Intarder




Chart 5: Voltmeter – Rev counter - Engine water temperature - Fuel level





Chart 6: Engine oil pressure – Engine oil level – window winder level - Hydraulic power steering fluid level - Engine water level


Chart 7: Chock wear indicator - Pad wear indicator - Reduced gear on indicator- Clogged oil filter indicator - Clogged air filter indicator


Chart 8: Differential block - Water presence in fuel indicator

Chart 9: Exterior lights






Chart 10: Exterior lights

78378

Chart II: Exterior lights – Reverse light



78379


Chart 12: Hazard lights – Headlight beam orientation

Chart 13: Internal lights





Chart 14: Windscreen wiper – Horn - Hour counter

79568


Chart 15: TGC


Chart 16: Sunroof – Windscreen washer

Chart 17: Tachograph





Chart 18: Engine electric fan

78386

Chart 19: Rearview mirror control - Power windows





Chart 20: Central door lock

Chart 21: ECAS (warning lights) - ABS (warning lights)





Chart 22: EBS (warning lights) - Heated windscreen - PTO

78390

Chart 23: Retarder (warning light) - Cabin tilting





Chart 24: Brake air pressure - ECAS - Outside temperature

78392

Chart 25: Trip odometer / Total odometer - Speed limiter





Chart 26: Engine oil temperature – Beacon lights – Sun visor

79580