

SHOP MANUAL

KOMATSU

PC300, 300LC-6 PC350, 350LC-6

MACHINE MODEL	SERIAL NUMBER
PC300-6	30001 and up
PC300LC-6	30001 and up
PC350-6	10001 and up
PC350LC-6	10001 and up

- This shop manual may contain attachments and optional equipment that are not available in your area. Please consult your local Komatsu distributor for those items you may require. Materials and specifications are subject to change without notice.
- PC300, 350-6 mount the SAA6D108-2 engine.
For details of the engine, see the 108-2 Series Engine Shop Manual.

CONTENTS

No. of page

01	GENERAL	01-1
10	STRUCTURE AND FUNCTION	10-1
20	TESTING AND ADJUSTING	20-1
30	DISASSEMBLY AND ASSEMBLY	30-1
40	MAINTENANCE STANDARD	40-1
90	OTHERS	90-1

020706

LIST OF REVISED PAGES

LIST OF REVISED PAGES

The affected pages are indicated by the use of the following marks. It is requested that necessary actions be taken to these pages according to the table below.

Mark	Indication	Action required
○	Page to be newly added	Add
●	Page to be replaced	Replace
()	Page to be deleted	Discard

Pages having no marks are those previously revised or made additions.

LIST OF REVISED PAGE

Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision
●	00- 1	③		01- 5			10-20			10-51			10-80	
	00- 2	②		01- 6			10-22			10-52			10-81	
●	00- 2-1	③		01- 7			10-23			10-53			10-82	
●	00- 2-2	③		01- 8			10-24			10-54	①		10-83	
●	00- 2-3	③		01- 9			10-25			10-55			10-84	
●	00- 2-4	③		01-10			10-26			10-56			10-85	
○	00- 2-5	③		01-11			10-27			10-57			10-86	
	00- 3			01-12			10-28			10-58			10-87	
	00- 4						10-29			10-59			10-88	
	00- 5						10-30			10-60			10-89	
	00- 6			10- 1			10-31			10-61			10-90	
	00- 7			10- 2			10-32			10-62			10-91	
	00- 8			10- 3			10-33			10-63			10-92	
	00- 9			10- 4			10-34			10-64			10-93	
	00-10			10- 5			10-35			10-65			10-94	
	00-11			10- 6			10-36			10-66	①		10-95	
	00-12			10- 7			10-38			10-67			10-96	
	00-13			10- 8			10-39			10-68			10-98	①
	00-14			10- 9			10-40			10-69			10-99	
	00-15			10-10			10-41			10-70			10-100	
	00-16			10-12			10-42			10-72			10-101	
	00-17			10-13			10-43			10-73			10-102	
				10-14			10-44			10-74			10-103	
				10-15			10-45			10-75			10-104	
	01- 1			10-16			10-46			10-76			10-105	
	01- 2			10-17			10-47			10-77			10-106	
	01- 3			10-18			10-49			10-78			10-107	①
	01- 4			10-19			10-50			10-79			10-108	

LIST OF REVISED PAGES

LIST OF REVISED PAGES

Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision
	30-34	②		30-74	②		30-94	②		30-134	②		40-24	
	30-35	②		30-75	②		30-95	②		30-135	②		40-25	
	30-36	②		30-76	②		30-96	②		30-136	②		40-26	
	30-37	②		30-77	②		30-97	②		30-137	②		40-27	
	30-38	②		30-78	②		30-98	②		30-138	②		40-28	
	30-39	②		30-79	②		30-99	②		30-139	②		40-29	
	30-40	②		30-80	②		30-100	②		30-140	②		40-30	
	30-41	②		30-81	②	●	30-101	③		30-141	②		40-31	
	30-42	②		30-82	②		30-102	②		30-142	②		40-32	
	30-43	②		30-83	②		30-103	②		30-143	②		40-33	
	30-44	②		30-84	②		30-104	②		30-144	②		40-34	
	30-45	②		30-85	②		30-105	②		30-145	②		40-35	
	30-46	②		30-86	②		30-106	②		30-146	②		40-36	
	30-47	②		30-87	②		30-107	②		30-147	②		40-38	
	30-48	②		30-88	②		30-108	②		30-148	②		40-39	
	30-49	②	○	30-88-1	③	●	30-109	③		30-149	②		40-40	
	30-50	②	○	30-88-2	③		30-110	②		30-150	②		40-41	
	30-51	②	○	30-88-3	③		30-111	②		30-151	②		40-42	
	30-52	②	○	30-88-4	③		30-112	②					40-43	
	30-53	②	○	30-88-5	③		30-113	②						
	30-54	②	○	30-88-6	③		30-114	②		40- 1				
	30-55	②	○	30-88-7	③		30-115	②		40- 2			90- 1	
	30-56	②	○	30-88-8	③		30-116	②		40- 4			90- 3	
	30-57	②	○	30-88-9	③		30-117	②		40- 5			90- 5	②
	30-58	②	○	30-88-10	③		30-118	②		40- 6			90- 7	
	30-59	②	○	30-88-11	③		30-119	②		40- 8			90- 9	
	30-60	②	○	30-88-12	③		30-120	②		40- 9			90-11	
	30-61	②	○	30-88-13	③		30-121	②		40-10			90-13	
	30-62	②	○	30-88-14	③		30-122	②		40-12			90-13-1	
	30-63	②	○	30-88-15	③		30-123	②		40-13			90-15	
	30-64	②	○	30-88-16	③		30-124	②		40-14			90-17	
	30-65	②	○	30-88-17	③		30-125	②		40-15			90-19	
	30-66	②	○	30-88-18	③		30-126	②		40-16			90-21	
	30-67	②	○	30-88-19	③		30-127	②		40-17			90-23	
	30-68	②	○	30-88-20	③		30-128	②		40-18			90-25	
	30-69	②		30-89	②		30-129	②		40-19			90-27	
	30-70	②		30-90	②		30-130	②		40-20			90-29	
	30-71	②		30-91	②		30-131	②		40-21			90-31	
	30-72	②		30-92	②		30-132	②	●	40-22	③		90-33	
	30-73	②		30-93	②		30-133	②		40-23			90-35	

020706

SAFETY

SAFETY NOTICE

PRECAUTIONS DURING WORK

11. When removing the oil filler cap, drain plug or hydraulic pressure measuring plugs, loosen them slowly to prevent the oil from spurting out.
Before disconnecting or removing components of the oil, water or air circuits, first remove the pressure completely from the circuit.
12. The water and oil in the circuits are hot when the engine is stopped, so be careful not to get burned.
Wait for the oil and water to cool before carrying out any work on the oil or water circuits.
13. Before starting work, remove the leads from the battery. Always remove the lead from the negative (–) terminal first.
14. When raising heavy components, use a hoist or crane.
Check that the wire rope, chains and hooks are free from damage.
Always use lifting equipment which has ample capacity.
Install the lifting equipment at the correct places. Use a hoist or crane and operate slowly to prevent the component from hitting any other part. Do not work with any part still raised by the hoist or crane.
15. When removing covers which are under internal pressure or under pressure from a spring, always leave two bolts in position on opposite sides. Slowly release the pressure, then slowly loosen the bolts to remove.
16. When removing components, be careful not to break or damage the wiring. Damaged wiring may cause electrical fires.
17. When removing piping, stop the fuel or oil from spilling out. If any fuel or oil drips onto the floor, wipe it up immediately. Fuel or oil on the floor can cause you to slip, or can even start fires.
18. As a general rule, do not use gasoline to wash parts. In particular, use only the minimum of gasoline when washing electrical parts.
19. Be sure to assemble all parts again in their original places.
Replace any damaged parts with new parts.
 - When installing hoses and wires, be sure that they will not be damaged by contact with other parts when the machine is being operated.
20. When installing high pressure hoses, make sure that they are not twisted. Damaged tubes are dangerous, so be extremely careful when installing tubes for high pressure circuits. Also, check that connecting parts are correctly installed.
21. When assembling or installing parts, always use the specified tightening torques. When installing protective parts such as guards, or parts which vibrate violently or rotate at high speed, be particularly careful to check that they are installed correctly.
22. When aligning two holes, never insert your fingers or hand. Be careful not to get your fingers caught in a hole.
23. When measuring hydraulic pressure, check that the measuring tool is correctly assembled before taking any measurements.
24. Take care when removing or installing the tracks of track-type machines.
When removing the track, the track separates suddenly, so never let anyone stand at either end of the track.

FOREWORD

GENERAL

This shop manual has been prepared as an aid to improve the quality of repairs by giving the serviceman an accurate understanding of the product and by showing him the correct way to perform repairs and make judgements. Make sure you understand the contents of this manual and use it to full effect at every opportunity.

This shop manual mainly contains the necessary technical information for operations performed in a service workshop. For ease of understanding, the manual is divided into the following chapters; these chapters are further divided into the each main group of components.

STRUCTURE AND FUNCTION

This section explains the structure and function of each component. It serves not only to give an understanding of the structure, but also serves as reference material for troubleshooting.

TESTING AND ADJUSTING

This section explains checks to be made before and after performing repairs, as well as adjustments to be made at completion of the checks and repairs.

Troubleshooting charts correlating "Problems" to "Causes" are also included in this section.

DISASSEMBLY AND ASSEMBLY

This section explains the order to be followed when removing, installing, disassembling or assembling each component, as well as precautions to be taken for these operations.

MAINTENANCE STANDARD

This section gives the judgement standards when inspecting disassembled parts.

NOTICE

The specifications contained in this shop manual are subject to change at any time and without any advance notice. Use the specifications given in the book with the latest date.

FOREWORD

HOISTING INSTRUCTIONS

HOISTING INSTRUCTIONS

HOISTING

! Heavy parts (25 kg or more) must be lifted with a hoist, etc. In the **DISASSEMBLY AND ASSEMBLY** section, every part weighing 25 kg or more is indicated clearly with the symbol .

- If a part cannot be smoothly removed from the machine by hoisting, the following checks should be made:
 - 1) Check for removal of all bolts fastening the part to the relative parts.
 - 2) Check for existence of another part causing interference with the part to be removed.


WIRE ROPES

- 1) Use adequate ropes depending on the weight of parts to be hoisted, referring to the table below:

Wire ropes (Standard "Z" or "S" twist ropes without galvanizing)	
Rope diameter (mm)	Allowable load (tons)
10	1.0
11.2	1.4
12.5	1.6
14	2.2
16	2.8
18	3.6
20	4.4
22.4	5.6
30	10.0
40	18.0
50	28.0
60	40.0

- ★ The allowable load value is estimated to be one-sixth or one-seventh of the breaking strength of the rope used.
- 2) Sling wire ropes from the middle portion of the hook.

Slinging near the edge of the hook may cause the rope to slip off the hook during hoisting, and a serious accident can result. Hooks have maximum strength at the middle portion.




SAD00479

- 3) Do not sling a heavy load with one rope alone, but sling with two or more ropes symmetrically wound onto the load.

! Slinging with one rope may cause turning of the load during hoisting, untwisting of the rope, or slipping of the rope from its original winding position on the load, which can result in a dangerous accident.

- 4) Do not sling a heavy load with ropes forming a wide hanging angle from the hook. When hoisting a load with two or more ropes, the force subjected to each rope will increase with the hanging angles. The table below shows the variation of allowable load (kg) when hoisting is made with two ropes, each of which is allowed to sling up to 1000 kg vertically, at various hanging angles.

When two ropes sling a load vertically, up to 2000 kg of total weight can be suspended. This weight becomes 1000 kg when two ropes make a 120° hanging angle. On the other hand, two ropes are subjected to an excessive force as large as 4000 kg if they sling a 2000 kg load at a lifting angle of 150°.



SAD00480

COATING MATERIALS

The recommended coating materials prescribed in Komatsu Shop Manuals are listed below.

Category	Komatsu code	Part No.	Q'ty	Container	Main applications, features
Adhesive	LT-1A	790-129-9030	150 g	Tube	Used to prevent rubber gaskets, rubber cushions, and cork plugs from coming out
	LT-1B	790-129-9050	20 g (x2)	Plastic container	Used in places requiring an immediately effective, strong adhesive. Used for plastics (except polyethylene, polypropylene, tetrafluoroethylene, and vinyl chloride), rubber, metal, and non-metal.
	LT-2	09940-00030	50 g	Plastic container	- Features: Resistance to heat, chemicals - Used for anti-loosening and sealant purposes for bolts and plugs.
	LT-3	790-129-9060 (Set of adhesive and hardening agent)	Adhesive :1 Kg Hardening agent: :500 g	Can	Used as adhesive or sealant for metal, glass, plastic
	LT-4	790-129-9040	250 g	Plastic container	Used as sealant for machined holes
	(Loctite 648-50)	79A-129-9110	50 cc	—	- Features: Resistance to heat, chemicals - Used at joint portions subject to high temperature
Gasket sealant	LG-1	790-129-9010	200 g	Tube	Used as adhesive or sealant for gaskets and packings of power train case, etc.
	LG-3	790-129-9070	1 Kg	Can	- Features: Resistance to heat - Used as sealant for flange surfaces and bolts at high temperature locations, used to prevent seizure - Used as sealant for heat resistant gasket for high temperature locations such as engine precombustion chamber, exhaust pipe
	LG-4	790-129-9020	200 g	Tube	- Features: Resistance to water, oil - Used as sealant for flange surface, thread - Also possible to use as sealant for flanges with large clearance - Used as sealant for mating surfaces of final drive case, transmission case
	LG-5	790-129-9080	1 Kg	Plastic container	- Used as sealant for various threads, pipe joints, flanges - Used as sealant for tapered plugs, elbows, nipples of hydraulic piping
	LG-6	09940-00011	250 g	Tube	- Features: Silicon based, resistance to heat, cold - Used as sealant for flange surface, thread - Used as sealant for oil pan, final drive case, etc.
	LG-7	09920-00150	150 g	Tube	- Features: Silicon based, quick hardening type - Used as sealant for flywheel housing, intake manifold, oil pan, thermostat housing, etc.
Rust prevention lubricant	LM-G	09940-00051	60 g	Can	Used as lubricant for sliding parts (to prevent squeaking)
Molybdenum disulphide lubricant	LM-P	09940-00040	200 g	Tube	- Used to prevent seizure or scuffing of the thread when press fitting or shrink fitting - Used as lubricant for linkage, bearings, etc.
Lithium grease	G2-LI	SYG-350LI SYG-400LI SYG-400LI-A SYG-160LI SYGA-160CNLI	Various	Various	General purpose type
Calcium grease	G2-CA	SSG2-400CA SYG2-350CA SYG2-400CA-A SYG2-160CA SYGA-16CNCA	Various	Various	Used for normal temperature, light load bearing at places in contact with water or steam
Molybdenum disulphide grease	—	SYG2-400M	400 g (10 per case)	Bellows type	Used for places with heavy load

STANDARD TIGHTENING TORQUE

STANDARD TIGHTENING TORQUES OF BOLTS AND NUTS

The following charts give the standard tightening torques of bolts and nuts. Exceptions are given in section of **DISASSEMBLY AND ASSEMBLY**.

1 Kgm = 9.806 Nm

Thread diameter of bolt	Width across flats	 SAD00481	 SAD00482
		kgm	Nm
6	10	1.35 ± 0.15	13.2 ± 1.4
8	13	3.2 ± 0.3	31.4 ± 2.9
10	17	6.7 ± 0.7	65.7 ± 6.8
12	19	11.5 ± 1.0	112 ± 9.8
14	22	18.0 ± 2.0	177 ± 19
16	24	28.5 ± 3	279 ± 29
18	27	39 ± 4	383 ± 39
20	30	56 ± 6	549 ± 58
22	32	76 ± 8	745 ± 78
24	36	94.5 ± 10	927 ± 98
27	41	135 ± 15	1320 ± 140
30	46	175 ± 20	1720 ± 190
33	50	225 ± 25	2210 ± 240
36	55	280 ± 30	2750 ± 290
39	60	335 ± 35	3280 ± 340

- ★ This torque table does not apply to the bolts with which nylon packings or other nonferrous metal washers are to be used, or which require tightening to otherwise specified torque.

FOREWORD

STANDARD TIGHTENING TORQUE


TIGHTENING TORQUE OF SPLIT FLANGE BOLTS

Use these torques for split flange bolts.

Thread diameter of bolt	Width across flats	Tightening torque	
		kgm	Nm
10	14	6.7 ± 0.7	65.7 ± 6.8
12	17	11.5 ± 1	112 ± 9.8
16	22	28.5 ± 3	279 ± 29

TIGHTENING TORQUE FOR FLARED NUTS

Use these torques for flared part of nut.



SAD00483

Thread diameter of nut part	Width across flats of nut part	Tightening torque	
		kgm	Nm
14	19	2.5 ± 0.5	24.5 ± 4.9
18	24	5 ± 2	49 ± 19.6
22	27	8 ± 2	78.5 ± 19.6
24	32	14 ± 3	137.3 ± 29.4
30	36	18 ± 3	176.5 ± 29.4
33	41	20 ± 5	196.1 ± 49
36	46	25 ± 5	245.2 ± 49
42	55	30 ± 5	294.2 ± 49

FOREWORD**ELECTRIC WIRE CODE****ELECTRIC WIRE CODE**

In the wiring diagrams, various colors and symbols are employed to indicate the thickness of wires. This wire code table will help you understand WIRING DIAGRAMS.

Example: 5WB indicates a cable having a nominal number 5 and white coating with black stripe.

CLASSIFICATION BY THICKNESS

Nominal number	Copper wire			Cable O.D. (mm)	Current rating (A)	Applicable circuit
	Number of strands	Dia. of strands (mm)	Cross section (mm ²)			
0.85	11	0.32	0.88	2.4	12	Starting, lighting, signal etc.
2	26	0.32	2.09	3.1	20	Lighting, signal etc.
5	65	0.32	5.23	4.6	37	Charging and signal
15	84	0.45	13.36	7.0	59	Starting (Glow plug)
40	85	0.80	42.73	11.4	135	Starting
60	127	0.80	63.84	13.6	178	Starting
100	217	0.80	109.1	17.6	230	Starting

CLASSIFICATION BY COLOR AND CODE

Priority	Circuits		Charging	Ground	Starting	Lighting	Instrument	Signal	Other
	Classi- fication								
1	Pri- mary	Code	W	B	B	R	Y	G	L
		Color	White	Black	Black	Red	Yellow	Green	Blue
2	Auxi- liary	Code	WR	—	BW	RW	YR	GW	LW
		Color	White & Red	—	Black & White	Red & White	Yellow & Red	Green & White	Blue & White
Code		WB	—	BY	RB	YB	GR	LR	
Color		White & Black	—	Black & Yellow	Red & Black	Yellow & Black	Green & Red	Blue & Red	
Code		WL	—	BR	RY	YG	GY	LY	
Color		White & Blue	—	Black & Red	Red & Yellow	Yellow & Green	Green & Yellow	Blue & Yellow	
Code		WG	—	—	RG	YL	GB	LB	
Color		White & Green	—	—	Red & Green	Yellow & Blue	Green & Black	Blue & Black	
6		Code	—	—	—	RL	YW	GL	—
		Color	—	—	—	Red & Blue	Yellow & White	Green & Blue	—

CONVERSION TABLE

METHOD OF USING THE CONVERSION TABLE

The Conversion Table in this section is provided to enable simple conversion of figures. For details of the method of using the Conversion Table, see the example given below.

EXAMPLE

- Method of using the Conversion Table to convert from millimeters to inches

1. Convert 55 mm into inches.

- Locate the number 50 in the vertical column at the left side, take this as (A), then draw a horizontal line from (A).
- Locate the number 5 in the row across the top, take this as (B), then draw a perpendicular line down from (B).
- Take the point where the two lines cross as (C). This point (C) gives the value when converting from millimeters to inches. Therefore, 55 mm = 2.165 inches.

2. Convert 550 mm into inches.

- The number 550 does not appear in the table, so divide by 10 (move the decimal point one place to the left) to convert it to 55 mm.
- Carry out the same procedure as above to convert 55 mm to 2.165 inches.
- The original value (550 mm) was divided by 10, so multiply 2.165 inches by 10 (move the decimal point one place to the right) to return to the original value. This gives 550 mm = 21.65 inches.

Millimeters to inches

1 mm = 0.03937 in

	0	1	2	3	4	5	6	7	8	9
0	0	0.039	0.079	0.118	0.157	0.197	0.236	0.276	0.315	0.354
10	0.394	0.433	0.472	0.512	0.551	0.591	0.630	0.669	0.709	0.748
20	0.787	0.827	0.866	0.906	0.945	0.984	1.024	1.063	1.102	1.142
30	1.181	1.220	1.260	1.299	1.339	1.378	1.417	1.457	1.496	1.536
40	1.575	1.614	1.654	1.693	1.732	1.772	1.811	1.850	1.890	1.929
50	1.969	2.008	2.047	2.087	2.126	2.165	2.205	2.244	2.283	2.323
60	2.362	2.402	2.441	2.480	2.520	2.559	2.598	2.638	2.677	2.717
70	2.756	2.795	2.835	2.874	2.913	2.953	2.992	3.032	3.071	3.110
80	3.150	3.189	3.228	3.268	3.307	3.346	3.386	3.425	3.465	3.504
90	3.543	3.583	3.622	3.661	3.701	3.740	3.780	3.819	3.858	3.898

FOREWORD

CONVERSION TABLE

Millimeters to Inches

1 mm = 0.03937 in

	0	1	2	3	4	5	6	7	8	9
0	0	0.039	0.079	0.118	0.157	0.197	0.236	0.276	0.315	0.354
10	0.394	0.433	0.472	0.512	0.551	0.591	0.630	0.669	0.709	0.748
20	0.787	0.827	0.866	0.906	0.945	0.984	1.024	1.063	1.102	1.142
30	1.181	1.220	1.260	1.299	1.339	1.378	1.417	1.457	1.496	1.536
40	1.575	1.614	1.654	1.693	1.732	1.772	1.811	1.850	1.890	1.929
50	1.969	2.008	2.047	2.087	2.126	2.165	2.205	2.244	2.283	2.323
60	2.362	2.402	2.441	2.480	2.520	2.559	2.598	2.638	2.677	2.717
70	2.756	2.795	2.835	2.874	2.913	2.953	2.992	3.032	3.071	3.110
80	3.150	3.189	3.228	3.268	3.307	3.346	3.386	3.425	3.465	3.504
90	3.543	3.583	3.622	3.661	3.701	3.740	3.780	3.819	3.858	3.898

Kilogram to Pound

1 kg = 2.2046 lb

	0	1	2	3	4	5	6	7	8	9
0	0	2.20	4.41	6.61	8.82	11.02	13.23	15.43	17.64	19.84
10	22.05	24.25	26.46	28.66	30.86	33.07	35.27	37.48	39.68	41.89
20	44.09	46.30	48.50	50.71	51.91	55.12	57.32	59.53	61.73	63.93
30	66.14	68.34	70.55	72.75	74.96	77.16	79.37	81.57	83.78	85.98
40	88.18	90.39	92.59	94.80	97.00	99.21	101.41	103.62	105.82	108.03
50	110.23	112.44	114.64	116.85	119.05	121.25	123.46	125.66	127.87	130.07
60	132.28	134.48	136.69	138.89	141.10	143.30	145.51	147.71	149.91	152.12
70	154.32	156.53	158.73	160.94	163.14	165.35	167.55	169.76	171.96	174.17
80	176.37	178.57	180.78	182.98	185.19	187.39	189.60	191.80	194.01	196.21
90	198.42	200.62	202.83	205.03	207.24	209.44	211.64	213.85	216.05	218.26

FOREWORD
CONVERSION TABLE
Liter to U.S. Gallon
 $1\ell = 0.2642 \text{ U.S. Gal}$

	0	1	2	3	4	5	6	7	8	9
0	0	0.264	0.528	0.793	1.057	1.321	1.585	1.849	2.113	2.378
10	2.642	2.906	3.170	3.434	3.698	3.963	4.227	4.491	4.755	5.019
20	5.283	5.548	5.812	6.076	6.340	6.604	6.869	7.133	7.397	7.661
30	7.925	8.189	8.454	8.718	8.982	9.246	9.510	9.774	10.039	10.303
40	10.567	10.831	11.095	11.359	11.624	11.888	12.152	12.416	12.680	12.944
50	13.209	13.473	13.737	14.001	14.265	14.529	14.795	15.058	15.322	15.586
60	15.850	16.115	16.379	16.643	16.907	17.171	17.435	17.700	17.964	18.228
70	18.492	18.756	19.020	19.285	19.549	19.813	20.077	20.341	20.605	20.870
80	21.134	21.398	21.662	21.926	22.190	22.455	22.719	22.983	23.247	23.511
90	23.775	24.040	24.304	24.568	24.832	25.096	25.361	25.625	25.889	26.153

Liter to U.K. Gallon
 $1\ell = 0.21997 \text{ U.K. Gal}$

	0	1	2	3	4	5	6	7	8	9
0	0	0.220	0.440	0.660	0.880	1.100	1.320	1.540	1.760	1.980
10	2.200	2.420	2.640	2.860	3.080	3.300	3.520	3.740	3.950	4.179
20	4.399	4.619	4.839	5.059	5.279	5.499	5.719	5.939	6.159	6.379
30	6.599	6.819	7.039	7.259	7.479	7.699	7.919	8.139	8.359	8.579
40	8.799	9.019	9.239	9.459	9.679	9.899	10.119	10.339	10.559	10.778
50	10.998	11.281	11.438	11.658	11.878	12.098	12.318	12.528	12.758	12.978
60	13.198	13.418	13.638	13.858	14.078	14.298	14.518	14.738	14.958	15.178
70	15.398	15.618	15.838	16.058	16.278	16.498	16.718	16.938	17.158	17.378
80	17.598	17.818	18.037	18.257	18.477	18.697	18.917	19.137	19.357	19.577
90	19.797	20.017	20.237	20.457	20.677	20.897	21.117	21.337	21.557	21.777

FOREWORD

CONVERSION TABLE

kgm to ft. lb

1 kgm = 7.233 ft. lb

	0	1	2	3	4	5	6	7	8	9
0	0	7.2	14.5	21.7	28.9	36.2	43.4	50.6	57.9	65.1
10	72.3	79.6	86.8	94.0	101.3	108.5	115.7	123.0	130.2	137.4
20	144.7	151.9	159.1	166.4	173.6	180.8	188.1	195.3	202.5	209.8
30	217.0	224.2	231.5	238.7	245.9	253.2	260.4	267.6	274.9	282.1
40	289.3	296.6	303.8	311.0	318.3	325.5	332.7	340.0	347.2	354.4
50	361.7	368.9	376.1	383.4	390.6	397.8	405.1	412.3	419.5	426.8
60	434.0	441.2	448.5	455.7	462.9	470.2	477.4	484.6	491.8	499.1
70	506.3	513.5	520.8	528.0	535.2	542.5	549.7	556.9	564.2	571.4
80	578.6	585.9	593.1	600.3	607.6	614.8	622.0	629.3	636.5	643.7
90	651.0	658.2	665.4	672.7	679.9	687.1	694.4	701.6	708.8	716.1
100	723.3	730.5	737.8	745.0	752.2	759.5	766.7	773.9	781.2	788.4
110	795.6	802.9	810.1	817.3	824.6	831.8	839.0	846.3	853.5	860.7
120	868.0	875.2	882.4	889.7	896.9	904.1	911.4	918.6	925.8	933.1
130	940.3	947.5	954.8	962.0	969.2	976.5	983.7	990.9	998.2	1005.4
140	1012.6	1019.9	1027.1	1034.3	1041.5	1048.8	1056.0	1063.2	1070.5	1077.7
150	1084.9	1092.2	1099.4	1106.6	1113.9	1121.1	1128.3	1135.6	1142.8	1150.0
160	1157.3	1164.5	1171.7	1179.0	1186.2	1193.4	1200.7	1207.9	1215.1	1222.4
170	1129.6	1236.8	1244.1	1251.3	1258.5	1265.8	1273.0	1280.1	1287.5	1294.7
180	1301.9	1309.2	1316.4	1323.6	1330.9	1338.1	1345.3	1352.6	1359.8	1367.0
190	1374.3	1381.5	1388.7	1396.0	1403.2	1410.4	1417.7	1424.9	1432.1	1439.4

FOREWORD

CONVERSION TABLE

kg/cm² to lb/in²

1kg/cm² = 14.2233 lb/in²

	0	1	2	3	4	5	6	7	8	9
0	0	14.2	28.4	42.7	56.9	71.1	85.3	99.6	113.8	128.0
10	142.2	156.5	170.7	184.9	199.1	213.4	227.6	241.8	256.0	270.2
20	284.5	298.7	312.9	327.1	341.4	355.6	369.8	384.0	398.3	412.5
30	426.7	440.9	455.1	469.4	483.6	497.8	512.0	526.3	540.5	554.7
40	568.9	583.2	597.4	611.6	625.8	640.1	654.3	668.5	682.7	696.9
50	711.2	725.4	739.6	753.8	768.1	782.3	796.5	810.7	825.0	839.2
60	853.4	867.6	881.8	896.1	910.3	924.5	938.7	953.0	967.2	981.4
70	995.6	1010	1024	1038	1053	1067	1081	1095	1109	1124
80	1138	1152	1166	1181	1195	1209	1223	1237	1252	1266
90	1280	1294	1309	1323	1337	1351	1365	1380	1394	1408
100	1422	1437	1451	1465	1479	1493	1508	1522	1536	1550
110	1565	1579	1593	1607	1621	1636	1650	1664	1678	1693
120	1707	1721	1735	1749	1764	1778	1792	1806	1821	1835
130	1849	1863	1877	1892	1906	1920	1934	1949	1963	1977
140	1991	2005	2020	2034	2048	2062	2077	2091	2105	2119
150	2134	2148	2162	2176	2190	2205	2219	2233	2247	2262
160	2276	2290	2304	2318	2333	2347	2361	2375	2389	2404
170	2418	2432	2446	2460	2475	2489	2503	2518	2532	2546
180	2560	2574	2589	2603	2617	2631	2646	2660	2674	2688
190	2702	2717	2731	2745	2759	2773	2788	2802	2816	2830
200	2845	2859	2873	2887	2901	2916	2930	2944	2958	2973
210	2987	3001	3015	3030	3044	3058	3072	3086	3101	3115
220	3129	3143	3158	3172	3186	3200	3214	3229	3243	3257
230	3271	3286	3300	3314	3328	3343	3357	3371	3385	3399
240	3414	3428	3442	3456	3470	3485	3499	3513	3527	3542

FOREWORD**CONVERSION TABLE****Temperature**

Fahrenheit-Centigrade Conversion ; a simple way to convert a Fahrenheit temperature reading into a Centigrade temperature reading or vice versa is to enter the accompanying table in the center or boldface column of figures.

These figures refer to the temperature in either Fahrenheit or Centigrade degrees.

If it is desired to convert from Fahrenheit to Centigrade degrees, consider the center column as a table of Fahrenheit temperatures and read the corresponding Centigrade temperature in the column at the left.

If it is desired to convert from Centigrade to Fahrenheit degrees, consider the center column as a table of Centigrade values, and read the corresponding Fahrenheit temperature on the right.

$$1^{\circ}\text{C} = 33.8^{\circ}\text{F}$$

°C		°F	°C		°F	°C		°F	°C		°F
-40.4	-40	-40.0	-11.7	11	51.8	7.8	46	114.8	27.2	81	117.8
-37.2	-35	-31.0	-11.1	12	53.6	8.3	47	116.6	27.8	82	179.6
-34.4	-30	-22.0	-10.6	13	55.4	8.9	48	118.4	28.3	83	181.4
-31.7	-25	-13.0	-10.0	14	57.2	9.4	49	120.2	28.9	84	183.2
-28.9	-20	-4.0	-9.4	15	59.0	10.0	50	122.0	29.4	85	185.0
-28.3	-19	-2.2	-8.9	16	60.8	10.6	51	123.8	30.0	86	186.8
-27.8	-18	-0.4	-8.3	17	62.6	11.1	52	125.6	30.6	87	188.6
-27.2	-17	1.4	-7.8	18	64.4	11.7	53	127.4	31.1	88	190.4
-26.7	-16	3.2	-7.2	19	66.2	12.2	54	129.2	31.7	89	192.2
-26.1	-15	5.0	-6.7	20	68.0	12.8	55	131.0	32.2	90	194.0
-25.6	-14	6.8	-6.1	21	69.8	13.3	56	132.8	32.8	91	195.8
-25.0	-13	8.6	-5.6	22	71.6	13.9	57	134.6	33.3	92	197.6
-24.4	-12	10.4	-5.0	23	73.4	14.4	58	136.4	33.9	93	199.4
-23.9	-11	12.2	-4.4	24	75.2	15.0	59	138.2	34.4	94	201.2
-23.3	-10	14.0	-3.9	25	77.0	15.6	60	140.0	35.0	95	203.0
-22.8	-9	15.8	-3.3	26	78.8	16.1	61	141.8	35.6	96	204.8
-22.2	-8	17.6	-2.8	27	80.6	16.7	62	143.6	36.1	97	206.6
-21.7	-7	19.4	-2.2	28	82.4	17.2	63	145.4	36.7	98	208.4
-21.1	-6	21.2	-1.7	29	84.2	17.8	64	147.2	37.2	99	210.2
-20.6	-5	23.0	-1.1	30	86.0	18.3	65	149.0	37.8	100	212.0
-20.0	-4	24.8	-0.6	31	87.8	18.9	66	150.8	40.6	105	221.0
-19.4	-3	26.6	0	32	89.6	19.4	67	152.6	43.3	110	230.0
-18.9	-2	28.4	0.6	33	91.4	20.0	68	154.4	46.1	115	239.0
-18.3	-1	30.2	1.1	34	93.2	20.6	69	156.2	48.9	120	248.0
-17.8	0	32.0	1.7	35	95.0	21.1	70	158.0	51.7	125	257.0
-17.2	1	33.8	2.2	36	96.8	21.7	71	159.8	54.4	130	266.0
-16.7	2	35.6	2.8	37	98.6	22.2	72	161.6	57.2	135	275.0
-16.1	3	37.4	3.3	38	100.4	22.8	73	163.4	60.0	140	284.0
-15.6	4	39.2	3.9	39	102.2	23.3	74	165.2	62.7	145	293.0
-15.0	5	41.0	4.4	40	104.0	23.9	75	167.0	65.6	150	302.0
-14.4	6	42.8	5.0	41	105.8	24.4	76	168.8	68.3	155	311.0
-13.9	7	44.6	5.6	42	107.6	25.0	77	170.6	71.1	160	320.0
-13.3	8	46.4	6.1	43	109.4	25.6	78	172.4	73.9	165	329.0
-12.8	9	48.2	6.7	44	111.2	26.1	79	174.2	76.7	170	338.0
-12.2	10	50.0	7.2	45	113.0	26.7	80	176.0	79.4	175	347.0

01 GENERAL


Specification drawings	01- 2
Specifications	01- 4
Weight table	01- 8
Fuel, coolant and lubricants	01-12

020706

SPECIFICATION DRAWINGS

PC300, 300LC-6

Unit: mm




SAP00130

- ★ The figures in () indicate the PC300LC.
- ★ The values marked ※ are for shovel operations.

020706

PC350, 350LC-6

Unit: mm



SAP00131

★ The figures in () indicate the PC350LC

GENERAL

SPECIFICATIONS

SPECIFICATIONS

Machine model			PC300-6	PC300LC-6
Serial Number			30001 and up	30001 and up
Bucket capacity (m ³)			1.2	1.2
Operating weight (kg)			30,800	31,900
Performance	Working ranges	Max. digging depth (mm)	7,380	7,380
		Max. vertical wall depth (mm)	6,480	6,480
		Max. digging reach (mm)	11,100	11,100
		Max. reach at ground level (mm)	10,920	10,920
		Max. digging height (mm)	10,210	10,210
		Max. dumping height (mm)	7,110	7,110
	Max. digging force (using power max. function) (kN(kg))		187.2 (19,100)	187.2 (19,100)
	Swing speed (rpm)		10.0	10.0
	Swing max. slope angle (deg.)		21.0	21.0
	Travel speed (km/h)		Lo: 3.7 Mi: 4.5 Hi: 5.5	Lo: 3.7 Mi: 4.5 Hi: 5.5
	Gradeability (deg.)		35	35
	Ground pressure [standard triple grouser shoe width] (MPa(kg/cm ²))		0.063 (0.64) [600 mm]	0.051 (0.52) [700 mm]
	Dimensions	Overall length (for transport) (mm)	10,935	10,935
		Overall width (mm)	3,190	3,290
		Overall width of track (mm)	3,190	3,290
		Overall height (for transport) (mm)	3,255	3,255
		Overall height to top of cab (mm)	3,130	3,130
		Ground clearance of counterweight (mm)	1,186	1,186
		Min. ground clearance (mm)	498	498
		Tail swing radius (mm)	3,300	3,300
		Min. swing radius of work equipment (mm)	4,310	4,310
		Height of work equipment at min. swing radius (mm)	8,440	8,440
		Length of track on ground (mm)	3,700	4,030
		Track gauge (mm)	2,590	2,590
		Height of machine cab (mm)	2,580	2,580

020706

GENERAL

SPECIFICATIONS

Machine model		PC300-6	PC300LC-6
Serial Number		30001 and up	30001 and up
Engine	Model	SAA6D108-2	
	Type	4-cycle, water-cooled, in-line, vertical, direct injection, with turbocharger and aftercooler (air cooled)	
	No. of cylinders – bore x stroke (mm)	6 – 108 x 130	
	Piston displacement (cc)	7,145	
	Performance	Flywheel horsepower (kW(HP)/rpm)	172.8 (231.7)/2,050
		Max. torque (Nm(kgm)/rpm)	897 (91.5)/1,500
		Max. speed at no load (rpm)	2,250
		Min. speed at no load (rpm)	900
		Min. fuel consumption (g/kW.h(g/HP.h))	205 (151)
	Starting motor		24V, 7.5 kW
	Alternator		24V, 33A
	Battery		12V, 170 Ah x 2
	Radiator core type		CWX-4
Under-carriage	Carrier roller		2 on each side
	Track roller		7 on each side
	Track shoe		8 on each side
Hydraulic system	Hydraulic pump	Type x No.	Variable displacement piston type x 2; gear type x 1
		Delivery (ℓ/min.)	Piston type: 251 x 2, gear type: 42
		Set pressure (MPa(kg/cm ²))	Piston type: 34.8 (355), gear type: 2.9 (30)
	Control valve	Type x No.	6-spool + 1-spool type x 1
		Control method	Hydraulic
	Hydraulic motor	Travel motor	Piston type (with brake valve, shaft brake): x 2
		Swing motor	Piston type (with safety valve, shaft brake): x 2
	Hydraulic cylinder		Double-acting piston
	Hydraulic tank		Box-shaped, sealed
	Hydraulic filter		Tank return side
	Hydraulic cooler		Air cooled

GENERAL

SPECIFICATIONS

Machine model			PC350-6	PC350LC-6
Serial Number			10001 and up	10001 and up
Bucket capacity (m ³)			1.2	1.2
Operating weight (kg)			32,300	33,400
Performance	Working ranges	Max. digging depth (mm)	7,380	7,380
		Max. vertical wall depth (mm)	6,400	6,400
		Max. digging reach (mm)	11,080	11,080
		Max. reach at ground level (mm)	10,890	10,890
		Max. digging height (mm)	10,070	10,070
		Max. dumping height (mm)	7,030	7,030
	Max. digging force (using power max. function) (kN(kg))		187.2 (19,100)	187.2 (19,100)
	Swing speed (rpm)		10.0	10.0
	Swing max. slope angle (deg.)		21.0	21.0
	Travel speed (km/h)		Lo: 3.7 Mi: 4.5 Hi: 5.5	Lo: 3.7 Mi: 4.5 Hi: 5.5
	Gradeability (deg.)		35	35
	Ground pressure [standard triple grouser shoe width] (MPa(kg/cm ²))		0.066 (0.67) [600 mm]	0.063 (0.64) [700 mm]
Dimensions	Overall length (for transport) (mm)		11,030	11,030
	Overall width (mm)		3,190	3,190
	Overall width of track (mm)		3,190	3,190
	Overall height (for transport) (mm)		3,255	3,255
	Overall height to top of cab (mm)		3,130	3,130
	Ground clearance of counterweight (mm)		1,186	1,186
	Min. ground clearance (mm)		498	498
	Tail swing radius (mm)		3,300	3,300
	Min. swing radius of work equipment (mm)		4,350	4,350
	Height of work equipment at min. swing radius (mm)		8,510	8,510
	Length of track on ground (mm)		3,700	4,030
	Track gauge (mm)		2,590	2,590
	Height of machine cab (mm)		2,580	2,580

020706

GENERAL

SPECIFICATIONS

Machine model		PC350-6	PC350LC-6
Serial Number		10001 and up	10001 and up
Engine	Model	SAA6D108-2	
	Type	4-cycle, water-cooled, in-line, vertical, direct injection, with turbocharger and aftercooler (air cooled)	
	No. of cylinders – bore x stroke (mm)	6 – 108 x 130	
	Piston displacement (cc)	7,145	
	Performance	Flywheel horsepower (kW(HP))/rpm	172.8 (231.7)/2,050
		Max. torque (Nm(kgm))/rpm	897 (91.5)/1,500
		Max. speed at no load (rpm)	2,250
		Min. speed at no load (rpm)	900
		Min. fuel consumption (g/kW.h(g/HP.h))	205 (151)
	Starting motor		24V, 7.5 kW
	Alternator		24V, 33A
	Battery		12V, 170 Ah x 2
	Radiator core type		CWX-4
Under-carriage	Carrier roller		2 on each side
	Track roller		7 on each side
	Track shoe		Assembly-type triple grouser
Hydraulic system	Hydraulic pump	Type x No.	Variable displacement piston type x 2; gear type x 1
		Delivery (ℓ/min)	Piston type: 251 x 2, gear type: 42
		Set pressure (MPa(kg/cm ²))	Piston type: 34.8 (355), gear type: 2.9 (30)
	Control valve	Type x No.	6-spool + 1-spool type x 1
		Control method	Hydraulic
	Hydraulic motor	Travel motor	Piston type (with brake valve, shaft brake): x 2
		Swing motor	Piston type (with safety valve, shaft brake): x 2
	Hydraulic cylinder		Double-acting piston
	Hydraulic tank		Box-shaped, sealed
	Hydraulic filter		Tank return side
	Hydraulic cooler		Air cooled

GENERAL

WEIGHT TABLE

WEIGHT TABLE

Unit: kg

Machine model	PC300-6	PC300LC-6
Serial Number	30001 and up	30001 and up
Engine assembly	1,100	1,100
• Engine	785	785
• Damper	14.7	14.7
• Hydraulic pump	200	200
Radiator, oil cooler assembly	165	165
Hydraulic tank, filter assembly (excl. hydraulic oil)	226	226
Fuel tank (excl. fuel)	218	218
Revolving frame	2,621	2,621
Operator's cab	287	287
Operator's seat	29	29
Counterweight	5,420	5,420
Swing machinery	380	380
Control valve (standard)	256	256
Swing motor	81	81
Travel motor	173 x 2	173 x 2
Center swivel joint	37	37
Track frame assembly	7,970	8,560
• Track frame	4,695	5,182
• Swing circle	487	487
• Idler	166	166
• Idler cushion	257 x 2	257 x 2
• Carrier roller	31 x 4	31 x 4
• Track roller	52 x 14	52 x 16
• Final drive (incl. travel motor)	629 x 2	629 x 2

020706

GENERAL

WEIGHT TABLE

Unit: kg

Machine model	PC300-6	PC300LC-6
Serial Number	30001 and up	30001 and up
Track shoe assembly		
Standard triple grouser shoe (600 mm)	3,600	3,840
Standard triple grouser shoe (700 mm)	3,940	4,220
Wide triple grouser shoe (800 mm)	4,300	4,560
Boom assembly	2,478	2,478
Arm assembly	1,615	1,615
Bucket assembly	1,014	1,014
Boom cylinder assembly	296 x 2	296 x 2
Arm cylinder assembly	425	425
Bucket cylinder assembly	263	263
Link assembly	320	320
Boom pin	76 + 15 x 2 + 56 + 17 + 42	76 + 15 x 2 + 56 + 17 + 42
Arm pin	13 + 17	13 + 17
Bucket pin	30 x 2	30 x 2
Link pin	27 x 2	27 x 2

020706

GENERAL

WEIGHT TABLE

Unit: kg

Machine model	PC350-6	PC350LC-6
Serial Number	10001 and up	10001 and up
Engine assembly	1,100	1,100
• Engine	785	785
• Damper	14.7	14.7
• Hydraulic pump	200	200
Radiator, oil cooler assembly	165	165
Hydraulic tank, filter assembly (excl. hydraulic oil)	226	226
Fuel tank (excl. fuel)	218	218
Revolving frame	2,741	2,741
Operator's cab	287	287
Operator's seat	29	29
Counterweight	6,320	6,320
Swing machinery	380	380
Control valve (standard)	256	256
Swing motor	81	81
Travel motor	173 x 2	173 x 2
Center swivel joint	37	37
Track frame assembly	8,045	8,670
• Track frame	4,770	5,295
• Swing circle	487	487
• Idler	166	166
• Idler cushion	257 x 2	257 x 2
• Carrier roller	31 x 4	31 x 4
• Track roller	52 x 14	52 x 16
• Final drive (incl. travel motor)	629 x 2	629 x 2

020706

GENERAL

WEIGHT TABLE

Unit: kg

Machine model	PC350-6	PC350LC-6
Serial Number	10001 and up	10001 and up
Track shoe assembly		
Standard triple grouser shoe (600 mm)	3,600	3,840
Standard triple grouser shoe (700 mm)	3,940	4,220
Boom assembly	2,580	2,580
Arm assembly	1,747	1,747
Bucket assembly	1,274	1,274
Boom cylinder assembly	296 x 2	296 x 2
Arm cylinder assembly	447	447
Bucket cylinder assembly	263	263
Link assembly	320	320
Boom pin	76 + 15 x 2 + 56 + 17 + 42	76 + 15 x 2 + 56 + 17 + 42
Arm pin	13 + 17	13 + 17
Bucket pin	30 x 2	30 x 2
Link pin	27 x 2	27 x 2

020706

FUEL, COOLANT AND LUBRICANTS

RESERVOIR	KIND OF FLUID	AMBIENT TEMPERATURE								CAPACITY (ℓ)		
		-22 -30	-4 -20	14 -10	32 0	50 10	68 20	86 30	104°F 40°C	Specified	Refill	
Engine oil pan	Engine oil			SAE 30					31	28		
				SAE 10W								
				SAE 10W-30							32 (When bypass filter is installed)	29 (When bypass filter is installed)
				SAE 15W-40								
Swing machinery case									13	13		
Final drive case (each side)									10	9.5		
Damper case									0.75	—		
Idler (1 each)									0.22 – 0.24	0.22 – 0.24		
Track roller (1 each)									0.25 – 0.28	0.25 – 0.28		
Carrier roller (1 each)									0.45 – 0.50	0.45 – 0.50		
Hydraulic system		Hydraulic oil			SAE 10W				380	205		
					SAE 10W-30							
					SAE 15W-40							
	HO46-HM (★)											
Fuel tank	Diesel fuel				ASTM D975 No. 2						540	—
	ASTM D975A No.1											
Cooling system	Coolant	Add antifreeze							32	—		

020706

GENERAL**FUEL, COOLANT AND LUBRICANTS****NOTE:**

- (1) When fuel sulphur content is less than 0.5%, change oil in the oil pan every periodic maintenance hours described in this manual. Change oil according to the following table if fuel sulphur content is above 0.5%.

Fuel sulphur content	Change interval of oil in engine oil pan
0.5 to 1.0%	1/2 of regular interval
Above 1.0%	1/4 of regular interval

- (2) When starting the engine in an atmospheric temperature of lower than 0°C, be sure to use engine oil of SAE10W, SAE10W-30 and SAE15W-40, even though an atmospheric temperature goes up to 10°C more or less in the day time.
- (3) Use API classification CD as engine oil and if API classification CC, reduce the engine oil change interval to half.
- (4) There is no problem if single grade oil is mixed with multigrade oil (SAE10W-30, 15W-40), but be sure to add single grade oil that matches the temperature in the table on the left.
- (5) We recommend Komatsu genuine oil which has been specifically formulated and approved for use in engine and hydraulic work equipment applications.
- ★ For the HO46-HM, use the oil recommended by Komatsu.

ASTM: American Society of Testing and Material

SAE: Society of Automotive Engineers

API: American Petroleum Institute



Specified capacity: Total amount of oil including oil for components and oil in piping.

Refill capacity: Amount of oil needed to refill system during normal inspection and maintenance.

10 STRUCTURE AND FUNCTION


Parts related to engine	10- 2
Radiator, oil cooler	10- 4
Power train	10- 5
Final drive	10- 6
Swing circle	10- 7
Swing machinery	10- 8
Track frame, recoil spring	10- 9
Track shoe	10- 10
Hydraulic piping drawing	10- 12
Hydraulic circuit drawing	10- 13
Hydraulic tank, hydraulic filter	10- 14
Hydraulic pump	10- 15
Control valve	10- 38
Suction safety valve	10- 47
CLSS	10- 49
Swing motor	10- 92
Center swivel joint	10- 96
Travel motor	10- 98
Valve control	10-107
Work equipment, swing PPC valve	10-108
Travel PPC valve	10-112
PPC valve for service valve	10-116
PPC safety lock valve	10-120
PPC accumulator	10-120
PPC shuttle valve, travel junction valve .	10-121
EPC solenoid valve	10-128
For LS select, boom Hi 2-stage safety valve, merge/flow divider, travel speed, swing brake	10-128
For LS valve control	10-130
Boom holding valve	10-133
Hydraulic cylinder	10-136
Work equipment	10-137
Actual electric wiring diagram	10-138
Electric circuit diagram	10-140
Engine control	10-142
Electronic control system	10-148
Machine monitor system	10-171
Front window auto pull-up system	10-178

PARTS RELATED TO ENGINE



SDP00134

020706




1. Drive plate
2. Torsion spring
3. Stopper pin
4. Friction plate
5. Damper assembly

6. Air cleaner
7. Intake connector
8. Muffler
9. Rear engine mount
10. Front engine mount

Outline

- The damper assembly is a wet type
- Oil capacity: 0.75 ℓ

RADIATOR, OIL COOLER



020706

SAP00138

1. Reservoir tank
2. Oil cooler
3. Radiator
4. Fan
5. Radiator inlet hose
6. Radiator outlet hose


7. Radiator cap
8. Net
9. Shroud
10. Cushion
11. O-ring
12. Collar

Specifications

Radiator: CWX-4

Oil cooler: SF-4

POWER TRAIN




SBP00140

- 1. Idler
- 2. Center swivel joint
- 3. Control valve
- 4. Final drive
- 5. Travel motor
- 6. Engine

- 7. Hydraulic pump
- 8. Travel speed solenoid valve
- 9. Swing brake solenoid valve
- 10. Swing machinery
- 11. Swing motor
- 12. Swing circle


FINAL DRIVE



1. Level plug
2. Drain plug
3. No. 1 planetary gear (No. of teeth: 41)
4. No. 1 sun gear (No. of teeth: 10)
5. No. 2 sun gear (No. of teeth: 19)
6. No. 1 planetary carrier
7. No. 2 planetary carrier
8. Cover
9. Ring gear (No. of teeth: 92)
10. Hub
11. Sprocket
12. Floating seal
13. Travel motor
14. No. 2 planetary gear (No. of teeth: 35)

Specifications

Reduction ratio: $-\left(\frac{10+92}{10}\right) \times \left(\frac{19+92}{19}\right) + 1$
 $= - 58.589$




A-A

SAP00141

020706

SWING CIRCLE



SAP00143

1. Swing circle inner race (No. of teeth: 90)
2. Ball
3. Swing circle outer race


- a. Inner race soft zone S position
- b. Outer race soft zone S position

Specifications


$$\text{Reduction ratio: } - \frac{90}{13} = - 6.923$$

Amount of grease: 33 ℓ (G2-LI)

SWING MACHINERY



1. Swing pinion (No. of teeth: 13)
2. Cover
3. Case
4. Coupling
5. No. 2 planetary gear (No. of teeth: 31)
6. Ring gear (No. of teeth: 84)
7. No. 1 planetary gear (No. of teeth: 31)
8. Cover
9. Swing motor
10. Oil level gauge
11. No. 1 sun gear (No. of teeth: 21)
12. No. 1 planetary carrier
13. No. 2 sun gear (No. of teeth: 21)
14. No. 2 planetary carrier
15. Drain plug



A-A

Specifications


Reduction ratio: $\frac{21+84}{21} \times \frac{21+84}{21}$
 = 35.000

SAP00145

020706

TRACK FRAME, RECOIL SPRING

★ The diagram shows the PC300-6



SAP00147

- 1. Idler
- 2. Track frame
- 3. Carrier roller
- 4. Final drive
- 5. Track roller
- 6. Track shoe
- 7. Center guard
- 8. Recoil spring
- 9. Front guard

- The dimensions and number of track rollers may differ according to the model, but the basic structure is the same.
- No. of track rollers.

Model	No. of rollers (each side)
PC300, 350-6	7
PC300LC-6, PC350LC-6	8

TRACK SHOE

Standard shoe

Model	PC300-6	PC350-6	PC300LC-6	PC350LC-6
Item				
Shoe width (mm) (triple shoe)	600	600	700	600
Link pitch (mm)	216	216	216	216
No. of shoes (each side)	45	45	48	48

Selection of track shoe

- Select the most suitable track shoe from the following table

	PC300-6		PC350-6		PC300LC-6		PC350LC-6	
	Specifications	Category	Specifications	Category	Specifications	Category	Specifications	Category
Standard	600 mm triple	A	600 mm triple	A	700 mm triple	B	600 mm triple	A
Option	700 mm triple	B	700 mm triple	B	600 mm triple	A	700 mm triple	A
Option	800 mm triple	B			800 mm triple	B		

Category	Use	Precautions when using
A	Rocky ground, normal river soil	Travel in Lo speed when traveling on rough ground with obstacles such as large boulders and fallen trees.
B	Normal soil, soft land	- Cannot be used on rough ground where there are large obstacles such as boulders and fallen trees. - Travel in Hi speed only on flat ground; when it is impossible to avoid traveling over obstacles, lower the travel speed to approx. half of Lo speed.
C	Extremely soft ground (swampy ground)	- Use only for ground where "A" and "B" sink and are impossible to use. - Cannot be used on rough ground where there are large obstacles such as boulders and fallen trees - Travel in Hi speed only on flat ground; when it is impossible to avoid traveling over obstacles, lower the travel speed to approx. half of Lo speed.
D	Paved surface	The shoes are flat, so they have low gradeability
E	Paved surface	The shoes are made of rubber, so be careful when traveling on rough ground


★ Categories "B" and "C" are wide shoes, so there are restrictions on their use. Therefore, before using, check the restrictions and consider carefully the conditions of use before recommending a suitable shoe width. If necessary, give the customer guidance in their use.

★ When selecting the shoe width, select the narrowest shoe possible within the range that will give no problem with flotation and ground pressure.
If a wider shoe than necessary is used, there will be a large load on the shoe, and this may lead to bending of the shoe, cracking of the links, breakage of the pins, loosening of the shoe bolts, or other problems.

HYDRAULIC PIPING DRAWING

★ For details of this page, see Section 90.

1. Bucket cylinder
2. Arm cylinder
3. Boom cylinder
4. Center swivel joint
5. Swing motor
6. Oil cooler
7. Control valve
8. PPC shuttle valve
9. Hydraulic filter
10. Hydraulic pump
11. L.H. travel motor
12. Hydraulic tank
13. PPC safety lock valve
14. L.H. PPC valve
15. R.H. PPC valve
16. Travel PPC valve
17. Boom holding valve
18. Accumulator
19. Solenoid valve assembly
- 19A. LS select solenoid valve
- 19B. Boom Hi 2-stage safety solenoid valve
- 19C. Merge/flow divider solenoid valve
- 19D. Travel speed solenoid valve
- 19E. Swing brake solenoid valve




50000-40

★ For details of this page, see Section 90.



HYDRAULIC TANK, HYDRAULIC FILTER



SDP00153

1. Hydraulic filter
 - 1a. Bypass valve
 - 1b. Strainer
 - 1c. Element
 - 1d. Cooler check valve
2. Hydraulic tank
3. Oil filler cap
4. Sight gauge
5. Hydraulic oil level sensor
6. Suction strainer

Specifications

Tank capacity: 315 ℓ





Amount of oil inside tank: 207 ℓ (at H level)

Safety valve

- Relief cracking pressure: 0.017 ± 0.007 MPa
(0.17 ± 0.07 kg/cm²)
- Suction cracking pressure: $0 - 0.0005$ MPa
($0 - 0.005$ kg/cm²)
- Bypass valve set pressure: 0.103 ± 0.02 MPa
(1.05 ± 0.2 kg/cm²)

020706

HYDRAULIC PUMP



SDP00155


1. Front main pump
2. Rear main pump
3. Relief valve
4. Rear TVC, LS valve
5. Front TVC, LS valve
6. Control pump

- a. Port Pd1F (pump drain)
- b. Port PAF (front delivery)
- c. Port PAR (rear delivery)
- d. Port PGS (control pump suction)
- e. Port PGA (control pump delivery)
- f. Port PLS1F (front LS pressure)
- g. Port PLS1R (rear LS pressure)
- h. Port Psig (LS control pressure EPC pressure)
- i. Port Ps (pump suction)
- j. Port PP2F (front No. 2 pump delivery pressure)
- k. Port PP2R (rear No. 2 pump delivery pressure)

Outline

This pump consists of two variable displacement swash plate type piston pumps, TVC, LS valves, control pump, and relief valve.

1. MAIN PUMP (HPV125 + 125)





020706

SAP00157

- a. Port PD1F (pump drain)
- b. Port PAF (front pump delivery)
- c. Port PAR (rear pump delivery)
- d. Port Pen1F (front control pressure)
- e. Port PARF (rear delivery pressure)


- f. Port PARR (rear delivery pressure)
- g. Port Pen1R (rear control pressure)
- h. Port PS (suction)
- i. Port PAFF (front delivery pressure)
- j. Port PSvd (control pump drain)



1. Shaft (front)
2. Cradle
3. Case (front)
4. Rocker cam
5. Shoe
6. Piston

7. Cylinder block
8. Valve plate
9. End cap
10. Shaft (rear)
11. Case (rear)
12. Servo piston

SAP00159



SAP00161

Function


- The engine rotation and torque transmitted to the pump shaft is converted into hydraulic energy, and pressurized oil is discharged according to the load.
- It is possible to change the delivery amount by changing the swash plate angle.

Structure

- Cylinder block (7) is supported to shaft (1) by spline S, and shaft (1) is supported by the front and rear bearings.
- The tip of piston (6) is a concave ball, and shoe (5) is caulked to it to form one unit. Piston (6) and shoe (5) form a spherical bearing.
- Rocker cam (4) has flat surface A, and shoe (5) is always pressed against this surface while sliding in a circular movement. Rocker cam (4) brings high pressure oil at cylindrical surface B with cradle (2), which is secured to the case, and forms a static pressure bearing when it slides.
- Piston (6) carries out relative movement in the axial direction inside each cylinder chamber of cylinder block (7).
- The cylinder block seals the pressure oil to valve plate (8) and carries out relative rotation. This surface is designed so that the oil pressure balance is maintained at a suitable level. The oil inside each cylinder chamber of cylinder block (7) is sucked in and discharged through valve plate (8).

Operation**1. Operation of pump**

- Cylinder block (7) rotates together with shaft (1), and shoe (5) slides on flat surface **A**. When this happens, rocker cam (4) moves along cylindrical surface **B**, so angle α between center line **X** of rocker cam (4) and the axial direction of cylinder block (7) changes. (Angle α is called the swash plate angle.)




SLP00163


- Center line **X** of rocker cam (4) maintains swash plate angle α in relation to the axial direction of cylinder block (7), and flat surface **A** moves as a cam in relation to shoe (5). In this way, piston (6) slides on the inside of cylinder block (7), so a difference between volume **E** and **F** is created inside cylinder block (7). The suction and discharge is equal to this difference **F - E**.

In other words, when cylinder block (7) rotates and the volume of chamber **E** becomes smaller, the oil is discharged during that stroke. On the other hand, the volume of chamber **F** becomes larger, and as the volume becomes bigger, the oil is sucked in.

- If center line **X** of rocker cam (4) is in line with the axial direction of cylinder block (7) (swash plate angle = 0), the difference between volumes **E'** and **F'** inside cylinder block (7) becomes 0, so the pump does not carry out any suction or discharge of oil.




SLP00164



SLP00165

2. Control of discharge amount




SAP00166

020706

- If swash plate angle α becomes larger, the difference in volumes **E** and **F** becomes larger and discharge volume **Q** increases.
- Swash plate angle α is changed by servo piston (12).
- Servo piston (12) moves in a reciprocal movement ($\leftrightarrow$) according to the command from the control valve.
- This straight line movement is transmitted through rod (13) to rocker cam (4), and rocker cam (4), which is supported by the cylindrical surface to cradle (2), moves in a rocking movement on the cylindrical surface in ($\updownarrow$ direction).
- With servo piston (12), the area receiving the pressure is different on the left and right, so main pump discharge pressure (self pressure) **PP** is always connected to the chamber receiving the pressure on the small diameter piston side (the self-pressure is brought in). Output pressure **Pen** of the LS valve is brought to the chamber receiving the pressure at the large diameter piston end. The relationship in the size of self-pressure **PP** and the pressure at the small diameter piston end, and the ratio between the area receiving the pressure at the small diameter piston end and the large diameter piston end controls the movement of servo piston (12).

2. TVC, LS VALVE






- a. Port Pen1 (signal pressure output)
- b. Port Pa2 (rear pump delivery pressure inlet port)
- c. Port Pa1 (front pump delivery pressure inlet port)

- d. Port PLS1 (control valve LS pressure inlet port)
- e. Port Psig1 (LS control EPC pressure inlet port)
- f. Port PP2 (pump pressure No. 2 port)

SAP00168

020706



SAP00169

LS valve

1. Locknut
2. Plug
3. Spring
4. Spool

5. Sleeve
6. Piston
7. Plug


TVC valve

8. Solenoid
9. Piston
10. Sleeve
11. Spring


12. Spring
13. Piston
14. Lever
15. Valve body

Function**1. LS valve**

- The LS valve detects the load and controls the discharge amount.
- This valve controls main pump discharge amount Q according to differential pressure $\Delta PLS (=P2P-PLS)$ (the difference between main pump pressure $P2P$ and control valve outlet port pressure PLS) (called the LS differential pressure).
- Main pump pressure $P2P$ coming from the control valve inlet port, pressure PLS (called the LS pressure) coming from the control valve output, and pressure $Psig$ (called the LS selector pressure) from the proportional solenoid valve enter this valve. The relationship between discharge amount Q and differential pressure ΔPLS , (the difference between main pump pressure $P2P$ and LS pressure PLS) ($=P2P-PLS$) changes as shown in the diagram on the right according to LS selector pressure $Psig$.
- When $Psig$ changes between 0 – 2.9 MPa (0 – 30 kg/cm²), the spring load changes according to this, and the point for switching the pump discharge amount changes at the rated central value between 1.0 – 2.5 MPa (10.0 – 25.0 kg/cm²).

**2. TVC valve**

- When pump discharge pressure $PP1$ (self-pressure) and $PP2$ (other pump pressure) are high, the TVC valve controls the pump so that no more oil than the constant flow (in accordance with the discharge pressure) flows even if the stroke of the control valve becomes larger. In this way it carries out equal horsepower control so that the horsepower absorbed by the pump does not exceed the engine horsepower.
- In other words, if the load during the operation becomes larger and the pump discharge pressure rises, it reduces the discharge amount from the pump; and if the pump discharge pressure drops, it increases the discharge amount from the pump. The relationship between the average of the front and rear pump discharge pressures $(PP1 + PP2)/2$ and pump discharge amount Q is shown on the right, with the current given to the TVC valve solenoid shown as a parameter. However, in the heavy-duty operation mode, there are cases where it is given the function of sensing the actual speed of the en-



gine, and if the speed drops because of an increase in the load, it reduces the pump discharge amount to allow the speed to recover. In other words, when the load increases and the engine speed drops below the set value, the command to the TVC valve solenoid from the controller increases according to the drop in the engine speed to reduce the pump swash plate angle.


STRUCTURE AND FUNCTION

HYDRAULIC PUMP

Operation


1. LS valve

1) When control valve is at NEUTRAL position



SLP00172

- The LS valve is a three-way selector valve, with pressure **PLS** (LS pressure) from the outlet port of the control valve brought to spring chamber **i**, and main pump discharge pressure **P2P** brought to chamber **j** of plug (6).
- The size of the force of this LS pressure **PLS** + force **F** of spring (3) and the main pump pressure (self pressure) **P2P** determines the position of spool (4). However, the size of the output pressure **Psig** (the LS selection pressure) of the EPC valve for the LS valve entering port **e** also changes the position of spool (4). (The set pressure of the spring changes.)
- Before the engine is started, servo piston (1) is pushed to the right by spring (7) installed to rod (2). (See the diagram on the right)
- When the engine is started and the control lever is at the NEUTRAL position, LS pressure **PLS** is 0 MPa (0 kg/cm²). (It is intercon-




A-A

SAP00173

ected with the drain circuit through the control valve spool.) At this point, spool (4) is pushed to the left, and port **d** and port **c** are connected. Pump pressure **PP** enters the large diameter end of the piston from port **h**, and the same pump pressure **PP** also enters the small diameter end of the piston, so the swash plate is moved to the minimum angle by the difference in area of piston (1).


2) Operation in maximum direction for pump discharge amount



SLP00174

- When the difference between main pump pressure **P2P** and LS pressure **PLS**, in other words, LS differential pressure ΔPLS , becomes smaller (for example, when the area of opening of the control valve becomes larger and pump pressure **PP** drops), spool (4) is pushed to the right by the combined force of LS pressure **PLS** and the force of spring (3).
- When spool (4) moves, port **b** and port **c** are joined and connected to the TVC valve. When this happens, the TVC valve is connected to the drain port, so circuit **c - h** becomes drain pressure **PT**. (The operation of the TVC valve is explained later.)
- For this reason, the pressure at the large piston diameter end of servo piston (1) becomes drain pressure **PT**, and pump pressure **PP** enters the small diameter end, so servo piston (1) is pushed to the right. Therefore, rod (2) moves to the right and moves the swash plate in the direction to make the discharge amount larger.
- If the output pressure **Psig** of the EPC valve for the LS valve enters port **e**, this pressure creates a force to move piston (5) to the left. If piston (5) is pushed to the left, it acts to make the set pressure of spring (3) weaker, and the difference between **PLS** and **P2P** changes when ports **b** and **c** of spool (4) are connected.


3) Operation in minimum direction for pump discharge amount



SLP00175

- The following explains the situation if servo piston (1) moves to the left (the discharge amount becomes smaller). When LS differential pressure ΔPLS becomes larger (for example, when the area of opening of the control valve becomes smaller and pump pressure PP rises), main pump discharge pressure $P2P$ pushes spool (4) to the left.
- When spool (4) moves, main pump pressure PP flows from port **d** to port **c**, and from port **h**, it enters the large piston diameter end.
- Main pump pressure PP also enters the small piston diameter end, but because of the difference in area between the large piston diameter end and small piston diameter end of servo piston (1), servo piston (1) is pushed to the left. As a result, rod (2) moves in the direction to make the swash plate angle smaller.
- If LS selection pressure $Psig$ enters port **e**, it acts to make the set pressure of spring (3) weaker.

4) When servo piston is balanced





SLP00176

- Let us take the area receiving the pressure at the large piston diameter end as A_1 , the area receiving the pressure at the small diameter end as A_0 , and the pressure flowing into the large piston diameter end as P_{en} . If main pump discharge pressure P_{2P} of the LS valve and the combined force of force F of spring (3) and LS pressure P_{LS} are balanced, and the relationship is $A_0 \times P_P = A_1 \times P_{en}$, servo piston (1) will stop in that position, and the swash plate will be kept at an intermediate position. (It will stop at a position where the opening of the throttle between port b and port c and between port d and port c of spool (4) is approximately the same. At this point, the pressure of port c is approx. $1/2$ pump pressure P_P .)
- At this point, the relationship between the area receiving the pressure at both ends of piston (1) is $A_0 : A_1 = 1 : 2$, so the pressure applied to both ends of the piston when it is balanced becomes $P_P : P_{en} = 2 : 1$.
- The position where spool (4) is balanced and stopped is the standard center, and the force of spring (3) is adjusted so that it is determined when $P_{2P} - P_{LS} = 2.5 \text{ MPa}$ (25 kg/cm^2). However, if P_{sig} (the output pressure of $0 - 2.9 \text{ MPa}$ ($0 - 30 \text{ kg/cm}^2$) of the EPC valve of the LS valve) is applied to port e , the balance stop position will change in proportion to pressure P_{sig} between $P_{2P} - P_{LS} = 2.5 - 1.0 \text{ MPa}$ ($25 - 10 \text{ kg/cm}^2$).

020706

2. TVC valve

1) When governor, pump controller are normal



SBP00178

- ★ Other pump pressure
This is the pressure of the pump at the opposite end.
For the front pump, it is the rear pump pressure
For the rear pump, it is the front pump pressure

a. When the load on the actuator is small and pump pressures PP1 and PP2 are low

① Action of solenoid (1)

- Command current x from the governor, pump controller flows to solenoid (1). This command current changes the internal force pushing solenoid push pin (11).
- On the opposite side to the force pushing this solenoid push pin (11) is the spring set pressure of springs (3) and (4) and pump pressure PP1 and other pump pressure PP2 (see ★). Piston (2) stops at a position where the combined force pushing piston (2) is bal-


anced, and the pressure (pressure of port c) output from the TVC valve changes according to this position.

- The size of command current x is determined by the nature of the operation (lever operation), the selection of the working mode, and the set value and actual value for the engine speed.

② Action of spring

- The spring load of springs (3) and (4) in the TVC valve is determined by the position of the swash plate.
- When servo piston (9) moves, cam (7), which is connected to rod (8), also moves. When this happens, lever (6) is rotated by the angle of cam (7), and piston (5) moves to the right or left.
- If piston (5) moves to the right, spring (3) is compressed; and if it moves further to the right, spring (4) contacts seat (10), so both spring (3) and spring (4) function. In other words, the spring load is changed by piston (5) extending or contracting springs (3) and (4).
- If command current **x** input to solenoid (1) changes further, the pushing force of solenoid push pin (11) changes, and the spring load of springs (3) and (4) also changes according to the value of the solenoid command current.
- Port **c** of the TVC valve is connected to port **e** of the LS valve (see 1. LS valve). Self pressure **PP1** enters port **b** and the small piston diameter end of servo piston (9), and the other main pump pressure **PP2** enters port **a**.
- When pump pressures **PP1** and **PP2** are small, piston (2) is on the right. At this point, port **c** and port **d** are connected, and the pressure entering the LS valve becomes drain pressure **PT**.
If port **h** and port **e** of the LS valve are connected (see 1. LS valve), the pressure entering the large piston diameter end from port **f** becomes drain pressure **PT**, and servo piston (9) moves to the right. In this way, the pump discharge amount moves in the direction of increase.
- As servo piston (9) moves further, piston (5) is moved to the left by rod (8), cam (7), and lever (6). Springs (3) and (4) expand and the spring force becomes weaker. When the spring force becomes weaker, piston (2) moves to the left, so the connection between port **c** and port **d** is cut, and the pump discharge pressure port **b** is connected to port **c**. As a result, the pressure at port **c** rises, and the pressure at the large piston diameter end also rises, so the movement of piston (9) to the right is stopped. In other words,

the stop position for piston (9) (= pump discharge amount) is decided at the point where the force of springs (3) and (4) and the pushing force from the solenoid and the pushing force created by pressures **PP1** and **PP2** acting on piston (2) are in balance.




b. When load on actuator is small and pump discharge pressure is high

- When the load is large and pump discharge pressures **PP1** and **PP2** are high, the force pushing piston (2) to the left becomes larger and piston (2) moves to the position shown in the diagram above. When this happens, as shown in the diagram above, with the pressurized oil flowing from port **c** to the LS valve, part of the pressurized oil from port **b** flows out to port **d** and becomes approximately half of main pump pressure **PP1**.
- When port **h** and port **e** of the LS valve are connected (see 1. LS valve), the pressure from port **f** enters the large piston diameter end of servo piston (9), and servo piston (9) stops.
- If main pump pressures **PP1** and **PP2** increase further and piston (2) moves further to the left, main pump pressure **PP1** flows to port **c** and acts to make the discharge amount the minimum. When piston (9) moves to the left, piston (5) is moved to the right by cam (7) and lever (6). For this reason, springs (3) and (4) are compressed and push back piston (2). Because of this force, piston (2) cuts off the connection from port **b** to port **c**, and port **c** and port **d** are connected. As a result, the pressure at port **c** (= **f**) drops, and piston (9) stops moving to the left. The position in which piston (9) stops when this happens is further to the left than the position when main pump pressures **PP1** and **PP2** are low.


STRUCTURE AND FUNCTION

HYDRAULIC PUMP

- The relation of pump pressures $PP1 + PP2$ and the position of servo piston (9) forms a bent line because of the double-spring effect of springs (3) and (4). The relationship between pump pressures $PP1 + PP2$ and pump discharge amount Q is shown in the figure on the right.




- If command current x sent to solenoid (1) increases further, the relationship between pump pressures $PP1$ and $PP2$, and pump discharge amount Q is proportional to the pushing force of the solenoid and moves in parallel. In other words, if the pushing force of solenoid (1) is added to the force pushing to the left because of the pump pressure applied to the piston (2), the relationship between P and Q moves from A to B in accordance with the increase in x .




020706

2) When governor, pump controller is abnormal and TVC prolix switch is ON



a. When load on main pump is light


- If there is a failure in the governor, pump controller, turn TVC prolix switch ON to switch to the resistor side. In this case, the power source is taken directly from the battery. But if the current is used as it is, it is too large, so use the resistor to control the current flowing to solenoid (1).
- When this is done, the current becomes constant, so the force pushing solenoid push pin (11) is also constant.
- If main pump pressures **PP1** and **PP2** are low, the combined force of the pump pressure and the force of solenoid (1) is weaker than the spring set force, so piston (2) is balanced at a position to the right.
- At this point, port **c** is connected to the drain pressure of port **d**, and the large piston diameter end of servo piston (9) also becomes the drain pressure **PT** through the LS valve. When this happens, the pressure at the small piston diameter end is large, so servo piston (9) moves in the direction to make the discharge amount larger.



020706

b. When load on main pump is heavy

- In the same way as in the previous item, when the TVC prolix switch is ON, the command current x sent to solenoid (1) becomes constant. For this reason, the force of solenoid push pin (11) pushing piston (2) is constant.
- If main pump pressures **PP1** and **PP2** increase, piston (2) moves further to the left than when the main pump load is light, and is balanced at a position towards the left.
- In this case, the pressure from port **b** flows to port **c**, so servo piston (9) moves to the left (to make the discharge amount smaller) by the same mechanism as explained in Item 2.1)-b, and stops at a position further to the left than when the load on the pump is light. In other words, even when the TVC prolix switch is ON, the curve for the pump pres-




SAP00383

sure **P** and discharge amount **Q** is determined as shown in the diagram for the value of the current sent to the solenoid through the resistor.

- The curve when the TVC prolix switch is ON is curve **B**, which is to the left of curve **A** for when the governor, pump controller is normal.

3. CONTROL PUMP (BAR-020)



SBP00184

Specifications


Type: BAR-020

Theoretical delivery: 20.9 cc/rev

Max. delivery pressure: 3.2 MPa (33kg/cm²)

- a. Suction port
- b. Delivery port

RELIEF VALVE



1. Adjustment screw
2. Locknut
3. Sleeve
4. Main valve spring
5. Pilot piston
6. Main valve

Function

The relief valve is assembled in the body of the control pump, and when the PPC valve is at neutral, the oil sent from the pump is relieved through this valve.

(It sets the maximum pressure in the circuit during operations.)


Operation

- Chamber **A** is the pump circuit and chamber **C** is the drain circuit. The oil passes through the orifice in the main valve and fills chamber **B**.

Set pressure:


$3.2 \begin{smallmatrix} 0 \\ -0.1 \end{smallmatrix}$ MPa (at 33 ℓ/min)

$(33 \begin{smallmatrix} 0 \\ -1 \end{smallmatrix} \text{ kg/cm}^2 \text{ (at 33 ℓ/min)})$



SBP00186

- If any abnormal pressure is generated, and the differential pressure $[\pi/4(D^2 - d^2) \times \text{pressure of chamber A}]$ created by the difference in the area of **d** and diameter **D** reaches the pressure set by the main valve spring, the main valve opens, and the oil in chamber **A** is released to chamber **C**. This suppresses the rise in the pressure in chamber **A**.




SBP00187

020706

CONTROL VALVE

10-spool valve (STD + service valve x 3)

★ For details of this page, see Section 90.



020706

SAP00188

STRUCTURE AND FUNCTION**CONTROL VALVE**

1. 6-spool valve
2. Boom, arm Hi valve
3. Cover 1
4. Cover 2
5. Merge/flow divider valve
6. Service valve
7. Service valve
8. Service valve


- a. Port PP1 (from front main pump)
- b. Port PP2 (from rear main pump)
- c. Port A6 (to arm cylinder head)
- d. Port B6 (to arm cylinder bottom)
- e. Port A5 (to L.H. travel motor)
- f. Port B5 (to L.H. travel motor)
- g. Port A4 (to swing motor)
- h. Port B4 (to swing motor)
- i. Port A3 (to boom cylinder bottom)
- j. Port B3 (to boom cylinder head)
- k. Port A2 (to R.H. travel motor)
- l. Port B2 (to R.H. travel motor)
- m. Port A1 (to bucket cylinder bottom)
- n. Port B1 (to bucket cylinder head)
- o. Port A-1 (to boom cylinder bottom)
- p. Port B-1 (to arm cylinder bottom)
- q. Port A-2 (to attachment)
- r. Port B-2 (to attachment)
- s. Port A-3 (to attachment)
- t. Port B-3 (to attachment)
- u. Port A-4 (to attachment)
- v. Port B-4 (to attachment)
- w. Port T1 (to travel junction valve)
- x. Port T2 (to travel junction valve)
- y. Port T3 (to travel junction valve)
- z. Port T4 (to travel junction valve)

Outline

- This control valve consists of a 7-spool valve (the 6-spool valve + Hi valve) and 3 sets of service valves. The merge/flow divider valve is installed to this.
- All the valves are connected by a bolt to form one unit, and the passages are internally connected, so the structure is compact and is very easy to service.
- This control valve is designed to assist only the boom and arm valves with their large flow using the Hi valve, so it has a simple structure.

- aa. Port PLS1 (to front pump control)
- ab. Port PLS2 (to rear pump control)
- ac. Port PPS1 (to front pump control)
- ad. Port PPS2 (to rear pump control)
- ba. Port T (to tank)
- bb. Port Ts (to tank)
- cc. Port Ps (from merge/flow divider solenoid valve)
- dd. Port BP (from LS select solenoid valve)
- ee. Port PTR1 (to travel junction valve)
- ef. Port PTR2 (to travel junction valve)
- ff. Port CP (from 2-stage safety valve selector solenoid valve)
- pa. Port P12 (from arm PPC valve)
- pb. Port P11 (from arm PPC valve)
- pc. Port P10 (from L.H. travel PPC valve)
- pd. Port P9 (from L.H. travel PPC valve)
- pe. Port P8 (from swing PPC valve)
- pf. Port P7 (from swing PPC valve)
- pg. Port P6 (from boom PPC valve)
- ph. Port P5 (from boom PPC valve)
- pi. Port P4 (from R.H. travel PPC valve)
- pj. Port P3 (from R.H. travel PPC valve)
- pk. Port P2 (from bucket PPC valve)
- pl. Port P1 (from bucket PPC valve)
- pm. Port P-2 (from boom PPC valve)
- pn. Port P-1B (from arm PPC valve)
- po. Port P-1A (from arm PPC valve)
- pp. Port P-4 (from service PPC valve)
- pq. Port P-3 (from service PPC valve)
- pr. Port P-6 (from service PPC valve)
- ps. Port P-5 (from service PPC valve)
- pt. Port P-8 (from service PPC valve)
- pu. Port P-7 (from service PPC valve)
- gf. Port SA (pressure sensor mount port)
- gg. Port SB (pressure sensor mount port)

Main structure of 10-spool valve (1/3)




020706


SAP00189

- | | |
|------------------------|------------------------------------|
| 1. Spool (arm Lo) | 10. Spool (service) |
| 2. Spool (L.H. travel) | 11. Spool (service) |
| 3. Spool (swing) | 12. Spool return spring |
| 4. Spool (boom Lo) | 13. Main relief valve (bucket) |
| 5. Spool (R.H. travel) | 14. Main relief valve (arm Lo) |
| 6. Spool (bucket) | 15. Unload valve (bucket) |
| 7. Spool (boom Hi) | 16. Unload valve (arm Lo) |
| 8. Spool (arm Hi) | 17. Piston (arm Lo stroke control) |
| 9. Spool (service) | |


(2/3)



J-J



EE-EE









MM-MM

1. LS shuttle valve
2. LS select valve
3. Merge/flow divider valve (main)
4. Return spring
5. Merge/flow divider valve (for LS)
6. Return spring
7. LS bypass valve




SAP00190

(3/3)



SAP00191

020706




SAP00193

1. Pressure compensation valve
2. Safety-suction valve
3. Safety-suction valve (for large flow)
4. Safety-suction valve (2-stage)
5. Check valve for regeneration circuit (arm)
6. Check valve for regeneration circuit (boom)

9-spool valve (STD + service valve x 2)


- ★ For details of the names of the ports and the main structure, see 10-SPOOL VALVE
- ★ For details of this page, see Section 90.



020706

SAP00195

- ★ For details of the names of the ports and the main structure, see 10-SPOOL VALVE
- ★ For details of this page, see Section 90.




STRUCTURE AND FUNCTION

CONTROL VALVE

7-spool valve (STD)

- ★ For details of the names of the ports and the main structure, see 10-SPOOL VALVE
- ★ For details of this page, see Section 90.




020706

SAP00197

SUCTION SAFETY VALVE

FOR SERVICE VALVE




1. Suction valve
2. Main valve
3. Piston
4. Piston spring
5. Poppet
6. Poppet spring
7. Suction valve spring
8. Sleeve
9. Adjustment screw
10. Locknut

SBP00198

Part No.	Set pressure	Use
709-70-74800	20.6 MPa (210 kg/cm ²) at 190ℓ/min	For breaker (Okada)
709-70-75100	20.1 MPa (205 kg/cm ²) at 5ℓ/min	For breaker (Mitsubishi Krupp)
709-70-75300	16.7 MPa (170 kg/cm ²) at 190ℓ/min	For breaker (Matsuda)
709-70-74600	24.5 MPa (250 kg/cm ²) at 5ℓ/min	For crusher (Okada)

CLSS

Outline of CLSS



SBP00199

Outline

- CLSS stands for Closed center Load Sensing System, and has the following features.

Features


- Fine control not influenced by load
- Control enabling digging even with fine control.
- Ease of compound operation ensured by flow divider function using area of opening of spool during compound operations.
- Energy saving using variable pump control

Structure


- The CLSS consists of a main pump (2 pumps), control valve, and actuators for the work equipment.
- The main pump consists of the pump itself, the TVC valve and LS valve.

Basic principle**1) Control of pump swash plate angle**

- The pump swash plate angle (pump discharge amount) is controlled so that LS differential pressure ΔP_{LS} (the difference between pump pressure P_P and control valve outlet port LS pressure P_{LS}) (load pressure of actuator) is constant.
(LS pressure $\Delta P_{LS} = \text{Pump discharge pressure } P_P - \text{LS pressure } P_{LS}$)



SBP00200



SAP00384


- If LS differential pressure ΔP_{LS} becomes lower than the set pressure of the LS valve (when the actuator load pressure is high), the pump swash plate moves towards the maximum position; if it becomes higher than the set pressure of the LS valve (when the actuator load pressure is low), the pump swash plate moves towards the minimum position.

2) Pressure compensation

- A pressure compensation valve is installed to the outlet port side of the control valve to balance the load.

When two actuators are operated together, this valve acts to make pressure difference ΔP between the upstream (inlet port) and downstream (outlet port) of the spool of each valve the same regardless of the size of the load (pressure).

In this way, the flow of oil from the pump is divided (compensated) in proportion to the area of openings **S1** and **S2** of each valve.




SBP00201

Operation for each function of CLSS

Hydraulic circuit diagram for system

★ For details of this page, see Section 90.




020706

- 1A. Main relief valve (bucket group)
- 1B. Main relief valve (arm group)
- 2A. Unload valve (bucket group)
- 2B. Unload valve (arm group)
- 3. Pressure compensation valve
- 4. Safety-suction valve
- 5. Safety-suction valve (for large flow)
- 6. Safety-suction valve (2-stage)
- 7. Bucket spool
- 8. LS shuttle valve
- 9. R.H. travel spool
- 10. Suction valve
- 11. Boom Lo spool
- 12. Check valve (for boom regeneration circuit)
- 13. Swing spool
- 14. L.H. travel spool
- 15. Arm Lo spool
- 16. Check valve (for arm regeneration circuit)
- 17. Boom Hi spool
- 18. Arm Hi spool
- 19. LS select valve
- 20. Merge/flow divider valve
- 21. LS bypass valve
 - A. To bucket cylinder
 - B. To R.H. travel motor
 - C. To boom cylinder
 - D. To swing motor
 - E. To L.H. travel motor
 - F. To arm cylinder
 - G. To travel junction valve
 - H. To travel junction valve

020706

SYSTEM DIAGRAM


- ★ This shows actuator (6A) at stroke end relief in the merge mode.



SAP00204

- | | | |
|-----------------------------|-------------------|---------------------|
| 1A. Main pump | 5A. Control valve | 9A. Tank passage |
| 1B. Main pump | 5B. Control valve | 9B. Tank passage |
| 2A. Main relief valve | 6A. Actuator | 10A. Valve |
| 2B. Main relief valve | 6B. Actuator | 10B. Valve |
| 3A. Unload valve | 7A. Pump passage | 11A. Spring |
| 3B. Unload valve | 7B. Pump passage | 11B. Spring |
| 4. Merge/flow divider valve | 8A. LS circuit | 12. LS bypass valve |
| | 8B. LS circuit | |

1. When unload valve is actuated




SBP00205

Function

- When all the control valves are at neutral, the oil discharged when the pump is at the minimum swash plate angle is drained. When this happens, the pump pressure becomes a pressure that matches the set load of springs (11A, 11B) inside the valve (**P₁** pressure). The **LS** pressure is drained from LS bypass valve (12), so **LS** pressure $\approx$ tank pressure $\approx$ 0 MPa (0 kg/cm²).
- When operated (for operations in the discharge range for the minimum swash plate angle), the discharge pressure of the oil discharged with the pump at the minimum swash plate angle is **LS** pressure + **P₁** pressure. In other words, the LS control differential pressure (ΔP_{LS}) of the oil discharged at the minimum swash plate angle is the **P₁** pressure.
- When the unload operation is carried out, the differential pressure (pump discharge pressure – LS circuit pressure) is greater than the pump LS control pressure, so a signal is sent to move the pump swash plate to the minimum angle.

Operation

- The pressure in pump passages (7A, 7B) is received by the end face of valves (10A, 10B). The control valve is at neutral, so the pressure in LS circuits (8A, 8B) is 0 MPa (0 kg/cm²).
- The pressurized oil in pump passages (7A, 7B) is stopped by valves (10A, 10B). There is no way for the pressurized oil discharged by the pump to escape, so the pressure rises. When this pressure becomes larger than the



SBP00206

020706

2. At LS relief


(1) Cut-off control actuated

Function

- When cut-off control is being carried out on the pump by the TVC valve, the pump swash plate angle is at the minimum.
- The relief valve acts to relieve the oil flow when the pump is at the minimum swash plate angle in order to maintain the overall balance.

Operation


- When the cylinder reaches the end of its stroke, main relief valves (2A, 2B) open and pump discharge amount **Q** is relieved to tank passages (9A, 9B).
- When pump delivery pressure **PP** comes close to the relief pressure, the governor, pump controller sends a signal to the solenoid of the TVC valve and carries out the cut-off function to make pump discharge amount **Q** the minimum.
- The spool is at the end of its stroke, so there is no flow of oil upstream or downstream from the spool. As a result, pump delivery pressure **PP** and LS pressure **PLS** are almost the same pressure, and LS differential pressure ΔPLS becomes 0.
- LS differential pressure ΔPLS is lower than the LS set pressure of the LS valve, so the LS valve acts to try to move the pump swash plate angle to the maximum. However, because of the structure, the action of the TVC valve is given priority over the action of the LS valve, so the pump is held at the minimum swash plate angle by the cut-off function of the TVC valve.



(2) Cut-off canceled (power max. mode, fine control mode, travel)


Function, operation

- In the power max. mode, fine control mode, or travel mode, the torque cut-off signal is not given, so the torque moves on the pump output curve.
- When this happens, the pump discharge amount is relieved from the relief valve, so the overall balance is maintained.



3. Introduction of LS pressure

- ★ The diagram shows the condition for arm IN.



SLP00210

1. Main pump
2. Main spool
3. Pressure compensation valve
4. Valve
5. Ball valve
6. LS circuit
7. LS shuttle valve


Function

- The upstream pressure (= spool meter-in downstream pressure) of pressure compensation valve (3) is introduced and goes to shuttle valve (7) as the **LS** pressure. When this happens, it is connected to port **B** of the actuator through valve (4), and **LS** pressure $\approx$ actuator load pressure. Introduction hole **a** inside the spool has a small diameter, so it also acts as a throttle.

Operation

- When spool (2) is operated, the pump pressure passes through introduction hole **a**, enters port **C**, and is taken to the LS circuit. When the pump pressure rises and reaches the load pressure of port **B**, ball valve (5) opens.

4. LS bypass valve



SLP00211


1. Main pump
2. Main spool
3. Pressure compensation valve
4. LS shuttle valve
5. LS bypass valve
6. LS circuit

Function

- The residual pressure in LS circuit (6) is released from orifices **a** and **b**.
- This reduces the speed of the rise in the LS pressure, and prevents any sudden change in the oil pressure. Furthermore, a pressure loss is generated by the circuit resistance between throttle **c** of main spool (2) and LS shuttle valve (4) according to the bypass flow from LS bypass valve (5). As a result, the effective LS differential pressure drops, and the dynamic stability of the actuator is increased.

020706

5. Pressure compensation valve



SLP00212

1. Main pump
2. Valve
3. Shuttle valve

4. Piston
5. Spring
6. LS shuttle valve

Function

- 1) **During independent operation and at maximum load pressure (during compound operations, when load pressure is higher than other work equipment)**
 - The pressure compensation valve acts as a load check valve.

Operation

- If the pump pressure (LS pressure) is lower than the load pressure at port **C**, shuttle valve (3) inside pressure compensation valve piston (4) moves to interconnect spring chamber **E** and port **C**. From this condition, the force of spring (5) acts to move piston (4) and valve (2) in the direction of closing.


Reference: Integrated pressure compensation valve

- When high peak pressure is generated in the actuator circuit or when peak pressure is generated repeatedly over a continuous period (such as when using a breaker), valve (2) may hit valve chamber seat **s** and generate a high stress. To prevent this, an integrated pressure compensation valve combining valve (2) and piston (4) is used. On


this machine, this is employed for the bucket valve (at the cylinder bottom) and service valve.

With the integrated compensation valve, as a basic rule, port **C** and spring chamber **E** are not interconnected, so even if a high peak pressure is generated at port **C**, valve (7) does not hit the valve chamber.

(However, the system is designed so that port **C** and spring chamber **E** are interconnected just before the bucket valve is seated.)



SAP00387



SLP00213

020706


2) When receiving compensation (during compound operations, when load pressure is lower than other work equipment)

- The pressure compensation valve is closed by the LS pressure of port **D**, and the spool meter-in downstream pressure of port **B** becomes the same as the maximum pressure of the other work equipment. The spool meter-in upstream pressure of port **A** is the pump pressure, so spool meter-in differential pressure (upstream pressure (pressure of port **A**) – downstream pressure (pressure of port **B**)) becomes the same for all spools that are being operated. In this way, the pump flow is divided in proportion to the area of the meter-in opening.

Operation

- Spring chamber **E** is interconnected with port **D**. Piston (4) and valve (2) are actuated by the LS circuit pressure from the other work equipment at port **F** in the direction of closing (to the right). In other words, the valve upstream pressure of port **B** (= spool meter-in downstream pressure) is controlled by the **LS** pressure.

6. Shuttle valve inside pressure compensation valve




SLP00214

1. Main pump
2. Valve
3. Shuttle valve inside pressure compensation valve
4. Piston

Function

When holding pressure at port A > LS pressure in spring chamber B.

- Shuttle valve (3) is pushed to the right by the pressure of port A, and the circuit between ports A and C is shut off. In this condition, the holding pressure at port A is taken to spring chamber B, and pushes piston (4) to the left to prevent piston (4) and valve (2) from separating.




SLP00215

020706

< For travel >


- No holding pressure is generated at port A in the travel circuit, so a pressure compensation valve without a shuttle valve is used.




SBP00216

Reference: When there is no shuttle valve

- If there is no shuttle valve, piston (4) and valve (2) will separate. In this condition, if another actuator is operated, the piston acts as an accumulator, so there is a time lag.



SAP00217



SLP00218

< Area ratio of pressure compensation valve >

The condition of the flow division changes according to the ratio of the areas of portion **A1** and portion **A2** of the pressure compensation valve.

Area ratio = $A2/A1$


- When area ratio = 1: Spool meter-in downstream pressure = Max. load pressure, and oil flow is divided in proportion to area of opening of spool.
- When ratio is more than 1: Spool meter-in downstream pressure > Max. load pressure, and a smaller oil flow is divided than the proportion between the areas of opening of the spool.
- When ratio is less than 1: Spool meter-in downstream pressure < Max. load pressure, and a larger oil flow is divided than the proportion between the areas of opening of the spool.

Area ratio for each part of work equipment

	Port A		Port B	
	Area ratio	Throttle diameter (mm)	Area ratio	Throttle diameter (mm)
Bucket	★0.93 (CURL)	φ2.0	0.88 (DUMP)	φ2.0
L.H./R.H. travel	0.98	φ1.0	0.98	φ1.0
Boom	0.98 (RAISE) (both Lo and Hi valves)	φ1.0	0.98 (LOWER)	φ2.0
Swing	0.88	φ2.0	0.88	φ2.0
Arm	0.90 (OUT)	φ2.0	0.93 (IN) (both Lo and Hi valves)	φ2.0
Service (for 2-spool valve)	★0.94	φ2.0	★0.94	φ2.0
Service (for 1-spool valve)	★0.98	φ2.0	★0.98	φ2.0

★ Integrated pressure compensation valve

7. Boom regeneration circuit



SLP00220

1. Main pump
2. Main spool
- 3A. Pressure compensation valve
- 3B. Pressure compensation valve
- 4A. Suction valve (with safety)
- 4B. Suction valve
5. Check valve
6. LS shuttle valve
7. Drain circuit
8. Regeneration circuit

Function


1) Cylinder head pressure < cylinder bottom pressure (free fall, etc.)

- A return flow circuit is provided from the cylinder bottom to the cylinder head so that when the boom is lowered, the return flow can be used to increase the flow of oil from the pump to the cylinder bottom.

Operation

- When the cylinder head pressure < cylinder bottom pressure, part of the pressurized oil from the cylinder bottom passes through the notch in spool (2), goes through port B, and enters drain circuit (7). The rest of the oil goes from port C, enters regeneration circuit (8), opens check valve (5), and passes through ports C and D to flow back to the cylinder head.

020706




020706

S LP00221

2) Cylinder head pressure > Cylinder bottom pressure (digging operations, etc.)

- Check valve (5) in regeneration circuit (8) acts to shut off the flow from the cylinder head to the cylinder bottom.

9. Merge/flow divider valve



SLP00223

1. Main spool
2. Spring
3. LS spool
4. Spring
5. LS circuit (bucket)
6. LS circuit (arm)
7. LS circuit (arm)
8. LS circuit (bucket)


Function

- This acts to merge or divide (send each to its own control valve group) oil flows **P1** and **P2** of pressurized oil discharged from the two pumps.
- At the same time, it also carries out merging and dividing of the LS circuit pressure.

Operation

1) When merging pump flow (when pilot pressure **PS** is OFF)

- Pilot pressure **PS** is OFF, so main spool (1) is pushed fully to the left by spring (2), and ports **E** and **F** are interconnected. Therefore, pressurized oil flows **P1** and **P2** discharged from the two pumps are merged at ports **E** and **F**, and are sent to the control valve that demands the oil.
- In the same way, LS spool (3) is also pushed fully to the left by spring (4), so the ports are connected as follows.
Connected ports: **A** ↔ **D**, **B** ↔ **C**
- Therefore, the **LS** pressure supplied from the spools of each control valve to LS circuits (5), (6), (7), and (8) is all sent to the pressure compensation valve and other valves.



020706

2) When dividing pump flow (when pilot pressure PS is ON)

- When pilot pressure **PS** is ON, main spool (1) is moved to the right by the **PS** pressure, and ports **E** and **F** are disconnected. Therefore, the pressurized oil discharged from each pump is sent to its own control valve group.

Pressure **P1**: To bucket, R.H. travel, boom group

Pressure **P2**: To swing, L.H. travel, arm group


- In the same way, LS spool (3) is also moved to the right by the **PS** pressure, and the ports are connected as follows.

Connected ports: **B** ↔ **D**, others are not connected.

Therefore, LS circuits (5), (6), (7), and (8) are all connected to their own control valve group.

10. LS select valve

- ★ The diagram shows the situation when the swing and left travel are operated at the same time. (BP pressure ON)



1. Valve
2. Spring
3. Piston
4. Piston
5. Swing spool
6. L.H. travel spool
7. Arm spool
8. LS shuttle valve
9. LS circuit

Function

- This valve is used to increase the ease of operating the work equipment. It prevents high pressure from being generated when the swing is operated. It also prevents the high LS pressure from the swing circuit from flowing into any other LS circuit when the swing is operated together with the work equipment.



Operation

1) When pilot pressure BP is OFF


- Pilot pressure **BP** is OFF, so piston (3) is pushed to the left by spring (2). If the swing is then operated, swing LS pressure **P1** passes through swing spool (5) and enters port **A**. It pushes valve (1) to the left and connects ports **A** and **B**. Therefore, swing LS pressure **P1** flows to LS shuttle valve (8).

2) When pilot pressure BP is ON

- When pilot pressure **BP** is ON, piston (3) is moved to the right against spring (2) by the **BP** pressure. It pushes valve (1) to the right and closes the circuit between ports **A** and **B**. As a result, swing LS pressure **P1** stops flowing to LS shuttle valve (8), and even if swing LS pressure **P1** rises to a high pressure, it does not influence any other LS circuit.



11. 2-stage safety valve (installed to boom cylinder head)



SAP00228

Function

- The set pressure of the safety valve can be set to two stages and the low pressure setting can be made smaller. Because of this, when digging with boom, even if high pressure is brought to bear on the boom cylinder, it is possible to let the boom escape without operating the control lever. This makes it possible to carry out operations with high efficiency and with little vibration of the chassis.

Operation

- The set pressure of the safety valve is determined by the load pressure of spring (1).

1) When pilot pressure **P** is OFF: high pressure setting

- Pilot pressure **P** is OFF, so piston (2) is pushed to the left by spring (3). (Installed load of spring (1) < installed load of spring (3)).

When this happens, the installed load of spring (1) becomes the maximum, and the set pressure is set to high pressure.


In addition, passage **B** is connected to the drain circuit through passage **C** and chamber **D**.

2) When pilot pressure **P** is ON: low pressure setting


- When pilot pressure **P** is ON, the pilot pressure goes to portion **A** through passage **B**, and piston (2) acts on the diameter of portion **A** receiving the pressure ($d_2 - d_1$). Piston (2) is moved to the right against spring (3) by this pilot pressure.

It moves the full stroke until it contacts holder (4). As a result, spring (1) extends, the installed load becomes the minimum, and the set pressure is set to low pressure.

In addition, an amount of oil equivalent to the piston stroke passes through passage **C** and chamber **D**, and is drained.



SAP00229




SAP00230

020706

- ★ The diagram shows the situation when all work equipment is at neutral.
- ★ The valves and circuits that are not connected with the explanation of the operation of the CLSS hydraulic system have been omitted.
- ★ For details of this page, see Section 90.

OPERATION OF CLSS SYSTEM AS A WHOLE

1. When all work equipment is at neutral



SAP00231

1. Hydraulic tank
- 2A. Main pump (front)
- 2B. Main pump (rear)
- 3A. TVC valve (front)
- 3B. TVC valve (rear)
- 4A. LS valve (front)
- 4B. LS valve (rear)
- 5A. Merge/flow divider valve (main)
- 5B. Merge/flow divider valve (for LS)
6. Bucket spool
7. R.H. travel spool
8. Boom Lo spool
9. Swing spool
10. L.H. travel spool
11. Arm Lo spool
12. Boom Hi spool
13. Arm Hi spool
14. Pressure compensation valve (with shuttle valve)
15. Pressure compensation valve (with shuttle valve, integrated type) (bucket CURL)
16. Pressure compensation valve (without shuttle valve) (travel)
17. Safety-suction valve
18. Safety-suction valve (bucket CURL)
19. 2-stage safety-suction valve (boom LOWER)
20. Plug
21. LS shuttle valve (bucket)
22. LS shuttle valve (R.H. travel)
23. LS shuttle valve (boom)
24. LS shuttle valve (L.H. travel)
25. LS shuttle valve (arm)
26. Check valve (for boom regeneration circuit)
27. Check valve (for arm regeneration circuit)
- 28A. Main relief valve (bucket group)
- 28B. Main relief valve (arm group)
- 29A. Unload valve (bucket group)
- 29B. Unload valve (arm group)
30. LS select valve
31. LS check valve
32. LS bypass valve

Note: Groups of control valves by main pump circuit

Bucket group: Bucket, R.H. travel, boom Lo, boom Hi, Arm Hi

Arm group: Swing, L.H. travel, arm Lo

Operation

- When the levers are at neutral, the pump is at the minimum swash plate angle, and the oil flow is drained from unload valves (29A, 29B).
- The LS pressure is connected to hydraulic tank (1) by LS bypass valve (32). The LS differential pressure ΔP_{LS} (unload pressure – tank pressure) at this point is $\Delta P_{LS} > \text{pump LS control pressure}$, so the pump swash plate angle is the minimum.

★ For details of this page, see Section 90.



Connection of ports when pump flow is merged
Connected ports: A - D, B - C

020706

Operation


- When the bucket CURL is operated, unload valves (29A, 29B) are closed.
- The swash plate of the main pump is controlled (LS control) to match the area of the meter-in opening of bucket spool (6), so the pump swash plate is balanced at a position which matches the oil flow demanded by the spool meter-in.
(ΔP_{LS} = pump LS control pressure)

020706

3. Pump flow merged, boom RAISE operated independently

(Boom Lo valve + boom Hi valve)

★ For details of this page, see Section 90.



SAP00233


020706

Operation

- When the boom RAISE is operated, unload valves (29A, 29B) are closed.
- The swash plate of the main pump is controlled (LS control) to match the total area of the meter-in opening of boom Lo spool (8) and boom Hi spool (12).
(ΔP_{LS} = pump LS control pressure)
- When the spool meter-in opening comes near the maximum, both pumps are at the maximum swash plate angle.
(When the pump discharge is the maximum, the maximum area of opening of the spool is also large, so the LS differential pressure is smaller than the LS control pressure and the swash plate angle is always at the maximum.)
($\Delta P_{LS} <$ pump LS control pressure)

020706

- 10-78




Operation

- When the arm IN is operated, unload valves (29A, 29B) are closed.
- The swash plate of the main pump is controlled (LS control) to match the total area of the meter-in opening of arm Lo spool (11) and arm Hi spool (13).
(ΔP_{LS} = pump LS control pressure)
- When the spool meter-in opening comes near the maximum, both pumps are at the maximum swash plate angle.
(When the pump discharge is the maximum, the maximum area of opening of the spool is also large, so the LS differential pressure is smaller than the LS control pressure and the swash plate angle is always at the maximum.)
($\Delta P_{LS} <$ pump LS control pressure)

020706

5. Pump flow merged, arm OUT operated independently
(Return circuit arm Lo + arm Hi)
★ For details of this page, see Section 90.




Operation

- When the arm OUT is operated, unload valves (29A, 29B) are closed.
- The swash plate of the main pump is controlled (LS control) to match the area of the meter-in opening of arm Lo spool (11), so the pump swash plate is balanced at a position which matches the oil flow demanded by the spool meter-in.
(ΔP_{LS} = pump LS control pressure)
- When this happens, the oil from the cylinder bottom is divided, sent to the Lo and Hi spools, and then returned, so it is possible to keep the pressure loss in the circuit small.

020706

6. Pump flow divided, travel operated independently
★ For details of this page, see Section 90.



Operation

- Pilot pressure **PA** of merge/flow divider valve (5A) ON

1)

- When the STRAIGHT TRAVEL is operated, a flow of oil is supplied from the main pump to match the stroke of the left and right travel spools (10) and (7).

Flow of oil from main pump (2A):

To L.H. spool (10) (arm group)

Flow of oil from main pump (2B):


To R.H. spool (7) (bucket group)

- The straight travel is compensated by the travel junction valve.

2)

- From the condition in 1) above, if the lever on the side being steered is returned (the oil flow becomes small) or the lever on the other side is operated in the opposite direction (the direction of travel is reversed), the oil flow from the pump is being divided, so the left and right travel circuits are controlled independently and the machine is steered.

7. Pump flow merged, arm IN + boom RAISE operated simultaneously
★ For details of this page, see Section 90.



020706

Operation

1)


- When the arm and boom are operated simultaneously, the swash plate angle for both pumps becomes the maximum.
- When this happens, the load pressure at the boom RAISE side is higher than at the arm side, so the LS pressure passes through ports **E** and **F** of boom Lo spool (8), enters boom LS shuttle valve (23) and is sent to the LS circuit. This LS pressure is transmitted to port **G** of pressure compensation valve (14), and acts to increase the set pressure of the pressure compensation valve. Because of this, the pressure between port **H** of arm Lo spool (11) and port **I** of pressure compensation valve (14) rises, and the spool meter-in LS differential pressure (pump pressure – LS pressure = ΔPLS) becomes the same as that at the boom end.

2)

- Because of the above operation, the oil flow is divided in proportion to the total area of opening of boom Lo spool (8) and boom Hi spool (12), and the total area of opening of arm Lo spool (11) and arm Hi spool (13).
- Meter-in LS differential pressure ΔPLS during boom RAISE + arm IN is $\Delta PLS < \text{pump LS control pressure}$, so the main pump swash plate angle is set to maximum.

020706

8. Pump flow merged, swing + boom RAISE operated simultaneously
★ For details of this page, see Section 90.




SAP00238


020706

Operation

- When the boom RAISE is being operated in the heavy-duty digging mode the swing is operated simultaneously, the pilot pressure of LS select valve (3) is turned ON.
- When this happens, the LS select valve is shut off, and the high pressure generated when the swing is operated does not flow to the LS circuit, so the LS circuit pressure becomes the boom pressure.
The swash plate of the main pump is controlled (LS control) by the difference in pressure between the boom and LS pressure.
- In addition, the pump pressure is determined by the boom pressure, so even if the swing drive pressure is high, the pump can deliver an ample flow of oil regardless of the pump output curve.




9. Pump flow divided (pump pressure: 19.6 MPa (200 kg/cm²) or above), travel + boom RAISE operated simultaneously
★ For details of this page, see Section 90.



Operation

- When the travel and boom RAISE are operated simultaneously (such as when raising the boom before traveling up a steep slope), if the pump pressure rises to 19.6 MPa (200 kg/cm²), the merge/flow divider valve pilot is turned ON and the pump flow is divided.
- In addition, the boom Hi spool does not move because of the travel **PPC** pressure. The flow of oil to the boom at this point is restricted, so the travel pressure is maintained and it is possible to carry out compound operations easily.

10. Pump flow divided (pump pressure: 19.6 MPa (200 kg/cm²) or above), travel + arm IN operated simultaneously
★ For details of this page, see Section 90.




Operation

- When the travel and arm IN are operated simultaneously (such as when using the digging action of the arm to help the machine travel up a steep slope), if the pump pressure rises to 19.6 MPa (200 kg/cm²), the merge/flow divider valve pilot is turned ON and the pump flow is divided.
- In addition, the stroke of the arm Lo spool is restricted by the travel **PPC** pressure. The flow of oil to the arm at this point is restricted, so the travel pressure is maintained and it is possible to carry out compound operations easily.

SWING MOTOR

KMF160AB-3



- a. Port T1 (to tank)
- b. Port B (from swing brake solenoid valve)
- c. Port MA (from control valve)
- d. Port MB (from control valve)
- e. Port S (from lift check valve)
- f. Port T2 (to port S)

Specifications


Model:	KMF160AB-3
Theoretical delivery:	160.7 cc/rev
Safety valve set pressure:	28.4 ^{+0.5} MPa at 244 ℓ/min (290 ⁺⁵ kg/cm ² at 244 ℓ/min)
Rated speed:	1,680 rpm
Brake releasing pressure:	1.8 ± 0.4 MPa (18.4 ± 4 kg/cm ²)

SDP00242


020706

STRUCTURE AND FUNCTION


SWING MOTOR



C - C



A - A



B - B

SDP00244

1. Output shaft
2. Oil seal
3. Case
4. Plate
5. Disc
6. Brake piston
7. Spring
8. Housing

9. Piston assembly
10. Cylinder block
11. Spring
12. Center shaft
13. Valve plate
14. Suction valve spring
15. Suction-safety valve

SUCTION-SAFETY VALVE

Function

- When the swing is stopped, the outlet port circuit of the motor is closed by the control valve, but the motor continues to be turned by the inertia of the swing. As a result, the pressure at the outlet port of the motor becomes abnormally high and there is danger that the motor will be damaged.
- The safety valve is installed to prevent this problem. It acts to release the abnormally high pressure oil from the outlet port of the motor to port **S**, and also functions as a swing brake.
- The suction valve supplies an amount of oil equivalent to the amount of oil released by the safety valve. It sends this oil from port **S** to the inlet port of the motor to prevent any cavitation.

Operation


1. When starting swing

- If the swing control lever is operated to swing to the right, the pressurized oil from the pump passes through the control valve and is supplied to port **MA**.
- When this happens, the pressure at port **MA** rises and the starting force is generated in the motor, so the motor starts to turn. The oil from the outlet port of the motor flows from port **MB** through the control valve and returns to the tank.


2. When stopping swing

- When the swing control lever is returned to the neutral position, no more pressurized oil is supplied from the pump to port **MA**. At the same time, the oil from the outlet port of the motor returns from the control valve to the tank, and the circuit is closed.
- The pressure at port **MB** rises, and rotating resistance to the motor is generated, so the brake starts to take effect. If the pressure at port **MB** rises to the set pressure of safety valve (1), safety valve (1) opens and releases the pressurized oil at port **MB** to port **S**.
- No pressurized oil is supplied at port **MA**, but the swing continues, so negative force is generated.

When this negative pressure drops to the set pressure of suction valve (2), suction valve (2) opens and oil is supplied from port **S** to prevent cavitation.



SAP00245




SAP00246

Operation of swing brake**1) Swing brake solenoid valve de-energized**

If the swing brake solenoid valve is de-energized, the flow of pressurized oil from the control pump is shut off, and port **B** is connected to the tank circuit.

As a result, brake piston (6) is pushed down by brake spring (7), pushes disc (5) and plate (4) together, and the brake is applied.




SBP00247

2) Swing brake solenoid valve energized





When the swing brake solenoid valve is energized, the valve is switched, and pressurized oil from the control valve enters port **B** and flows to brake chamber **a**.

The pressurized oil entering chamber **a** overcomes brake spring (7) and pushes brake piston (6) up. As a result, disc (5) and plate (4) are separated and the brake is released.



SBP00248

CENTER SWIVEL JOINT



SBP00249


1. Cover
2. Body
3. Slipper seal
4. O-ring
5. Shaft

- A1. From control valve port B2
 A2. To R.H. travel motor port PB
 B1. From control valve port B5
 B2. To L.H. travel motor port PA
 C1. From control valve port A2
 C2. To R.H. travel motor port PA

- D1. From control valve port A5
 D2. To L.H. travel motor port PB
 E1. From travel speed EPC valve
 E2. To L.H. and R.H. travel motors port P
 T1. To tank
 T2. From L.H. and R.H. travel motors port T

TRAVEL MOTOR

HMV160ADT-2



SDP00250





- a. Port PB (from control valve)
- b. Port PA (from control valve)
- c. Port T (to tank)
- d. Port P (from travel speed solenoid valve)

Specifications

Model:	HMV160ADT-2
Theoretical delivery:	Min 110.1 cc/rpm Max 160.8 cc/rpm
Set pressure:	34.8 MPa (355 kg/cm ²)
Rated speed:	Min. capacity 2,225 rpm Max. capacity 1,524 rpm
Brake releasing pressure:	1.2 ± 0.4 MPa (12 ± 4 kg/cm ²)
Travel speed switching pressure:	0.8 $\pm_{0.1}^{0.4}$ MPa (Differential pressure) (8 $\pm_{1}^{4}$ kg/cm ²) (Differential pressure))

STRUCTURE AND FUNCTION


TRAVEL MOTOR



SDP00251

- | | |
|-----------------|----------------------|
| 1. Output shaft | 9. Regulator valve |
| 2. Motor case | 10. Spring |
| 3. Ball | 11. Brake spring |
| 4. Rocker cam | 12. Brake piston |
| 5. Piston | 13. Plate |
| 6. Cylinder | 14. Disc |
| 7. Valve plate | 15. Regulator piston |
| 8. End cover | 16. Spring |

- | |
|--------------------------|
| 17. Check valve spring |
| 18. Check valve |
| 19. Counterbalance valve |
| 20. Spool return spring |
| 21. Safety valve |
| 22. Slow return valve |


Operation of motor**1) At low speed (motor swash plate angle at maximum)**

020706

SAP00252

- The solenoid valve is de-energized, so the pilot pressure oil from the control pump does not flow to port **P**. For this reason, regulator valve (9) is pushed fully to the right by spring (10).
- Because of this, it pushes slow return valve (22), and the main pressure oil from the control valve going to end cover (8) is shut off by regulator valve (9).
- Fulcrum **a** of rocker cam (4) is eccentric to point of application **b** of the combined force of the propulsion force of the piston of cylinder (6), so the combined force of the piston propulsion force acts as a moment to angle rocker cam (4) in the direction of the maximum swash plate angle.
- At the same time, the pressurized oil at regulator piston (15) passes through orifice **c** in regulator valve (9) and is drained to the motor case.
- As a result, rocker cam (4) moves in the maximum swash plate angle direction, the motor capacity becomes maximum, and the system is set to low speed.

2) At high speed (motor swash plate angle at minimum)



020706


SAP00253

- When the solenoid valve is energized, the pilot pressure oil from the control pump flows to port **P**, and pushes regulator valve (9) to the left.
- Because of this, the main pressure oil from the control valve passes through passage **d** in regulator valve (9), enters regulator piston (15), and pushes regulator piston (15) to the right.
- As a result, rocker cam (4) moves in the minimum swash plate angle direction, the motor capacity becomes minimum, and the system is set to high travel speed.

Operation of parking brake**1) When starting to travel**


- When the travel lever is operated, the pressurized oil from the pump actuates counterbalance valve spool (19), opens the circuit to the parking brake, and flows into chamber **a** of brake piston (12). It overcomes the force of spring (11), and pushes piston (12) to the right.

When this happens, the force pushing plate (13) and disc (14) together is lost, so plate (13) and disc (14) separate and the brake is released.

**2) When stopping travel**

- When the travel lever is placed in neutral, counterbalance valve spool (19) returns to the neutral position and the circuit to the parking brake is closed.

The pressurized oil in chamber **a** of brake piston (12) is drained to the case from the orifice in the brake piston, and brake piston (12) is pushed fully to the left by spring (11). As a result, plate (13) and disc (14) are pushed together, and the brake is applied. A time delay is provided by having the pressurized oil pass through a throttle in slow return valve (22) when the brake piston returns, and this ensures that the brake is applied after the machine stops.



Operation of brake valve


- The brake valve consists of a check valve, counterbalance valve, and safety valve in a circuit as shown in the diagram on the right. (Fig. 1)
- The function and operation of each component is as given below.

1) Counterbalance valve, check valve
Function

- When traveling downhill, the weight of the machine makes it try to travel faster than the speed of the motor. As a result, if the machine travels with the engine at low speed, the motor will rotate without load and the machine will run away, which is extremely dangerous. To prevent this, these valves act to make the machine travel according to the engine speed (pump discharge amount).


Operation when pressurized oil is supplied

- When the travel lever is operated, the pressurized oil from the control valve is supplied to port **PA**. It pushes open check valve (18a) and flows from motor inlet port **MA** to motor outlet port **MB**. However, the motor outlet port is closed by check valve (18b) and spool (19), so the pressure at the supply side rises. (Fig. 2).
- The pressurized oil at the supply side flows from orifice **E1** in spool (19) and orifice **E2** in the piston to chamber **S1**. When the pressure in chamber **S1** goes above the spool switching pressure, spool (19) is pushed to the right. As a result, port **MB** and port **PB** are connected, the outlet port side of the motor is opened, and the motor starts to rotate. (Fig. 3).




(Fig. 1)

SAP00262



(Fig. 2)

SAP00263



(Fig. 3)


SAP00264

Operation of brake when traveling downhill

- If the machine tries to run away when traveling downhill, the motor will turn under no load, so the pressure at the motor inlet port will drop, and the pressure in chamber **S1** through orifices **E1** and **E2** will also drop. When the pressure in chamber **S1** drops below the spool switching pressure, spool (19) is returned to the left by spring (20), and outlet port **MB** is throttled.

As a result, the pressure at the outlet port side rises, resistance is generated to the rotation of the motor, and this prevents the machine from running away.

In other words, the spool moves to a position where the pressure at outlet port **MB** balances the pressure at the inlet port and the force generated by the weight of the machine. It throttles the outlet port circuit and controls the travel speed according to the amount of oil discharged from the pump. (Fig. 4)




(Fig. 4)

SBP00265

2) Safety valve (2-direction operation, 2-stage set safety valve)**Function**

- When travel is stopped (or when traveling downhill), the circuits at the inlet and outlet ports of the motor are closed by the counterbalance valve. However, the motor is rotated by inertia, so the pressure at the outlet port of the motor will become abnormally high and will damage the motor or piping. The safety valve acts to release this abnormal pressure and send it to the inlet port side of the motor to prevent damage to the equipment.




(Fig. 5)

SBP00266

Operation in both directions**1) When pressure in chamber MB has become high (when rotating clockwise)**

- When the travel is stopped (or when traveling downhill), chamber **MB** in the outlet port circuit is closed by the check valve of the counterbalance valve, but the pressure at the outlet port rises because of inertia. (Fig. 5)
- If the pressure goes above the set pressure, the force produced by the difference in area between **D1** and **D2** [$\pi 4(D1^2 - D2^2) \times \text{pressure}$] overcomes the force of the spring and moves the poppet to the left, so the oil flows to chamber **MA** in the circuit on the opposite side. (Fig. 6).



(Fig. 6)


SBP00267

STRUCTURE AND FUNCTION

TRAVEL MOTOR

2) When pressure in chamber MA has become high (when rotating counterclockwise)


- When the travel is stopped (or when traveling downhill), chamber MA in the outlet port circuit is closed by the check valve of the counterbalance valve, but the pressure at the outlet port rises because of inertia. (Fig. 7)



(Fig. 7)

SBP00268

- If the pressure goes above the set pressure, the force produced by the difference in area between D1 and D3 [$\pi/4(D3^2 - D1^2) \times \text{pressure}$] overcomes the force of the spring and moves the poppet to the left, so the oil flows to chamber MB in the circuit on the opposite side. (Fig. 8)




(Fig. 8)

SBP00269

Operation of mechanism for varying set pressure

1) When starting travel (high-pressure setting)

- When the travel lever is operated, the pressurized oil from the pump actuates counterbalance valve spool (19), and opens the pilot circuit to the safety valve. The oil passes from chamber G to passage H and flows into chamber J, pushes the piston to the right, and compresses the spring to make the set load larger. Because of this, the set pressure of the safety valve is switched to the high pressure setting, and a large draw-bar pull is made available.



(Fig. 9)


SBP00270

2) When stopping travel (low-pressure setting)

- When the travel lever is placed at neutral, the pressure in chamber **PA** drops and counterbalance valve spool (19) returns to the neutral position. While the counterbalance valve spool is returning to the neutral position, the pressurized oil in chamber **J** passes through passage **H**, and escapes to chamber **PA** from chamber **G**. The piston moves to the left, and the set load becomes smaller. Because of this, the set pressure of the safety valve is switched to the low-pressure setting and relieves the shock when reducing speed.

[Set pressure of safety valve]


When starting, } : High-pressure when traveling }	When stopping: Low-pressure setting
37.7 MPa (385 kg/cm ²)	27.4 MPa (280 kg/cm ²)



SBP00271

020706

VALVE CONTROL



020706


SBP00272

- | | |
|-------------------------------|-------------------------------|
| 1. Travel PPC valve | 9. Hydraulic pump |
| 2. L.H. travel lever | 10. LS control EPC valve |
| 3. R.H. travel lever | 11. PPC shuttle valve |
| 4. Right PPC valve | 12. Left work equipment lever |
| 5. Right work equipment lever | 13. PPC safety lock valve |
| 6. Accumulator | 14. Left PPC valve |
| 7. Solenoid block | 15. Safety lock lever |
| 8. Control valve | |

Lever positions

- | | |
|---------------|------------------|
| ① NEUTRAL | ⑩ Swing left |
| ② Boom RAISE | ⑪ NEUTRAL |
| ③ Boom LOWER | ⑫ Travel REVERSE |
| ④ Bucket DUMP | ⑬ Travel FORWARD |
| ⑤ Bucket CURL | ⑭ LOCK |
| ⑥ NEUTRAL | ⑮ FREE |
| ⑦ Arm IN | |
| ⑧ Arm OUT | |
| ⑨ Swing right | |

WORK EQUIPMENT, SWING PPC VALVE








SBP00273

- a. Port P (from control pump)
- b. Port T (to tank)
- c. Port P2 (L.H.: Arm IN/R.H.: Boom RAISE)

- d. Port P4 (L.H.: Left swing/R.H.: Bucket DUMP)
- e. Port P1 (L.H.: Arm OUT/R.H.: Boom LOWER)
- f. Port P3 (L.H.: Right swing/R.H.: Bucket CURL)

STRUCTURE AND FUNCTION

WORK EQUIPMENT, SWING PPC VALVE




1. Spool
2. Metering spring
3. Centering spring
4. Piston
5. Disc
6. Nut (for connecting lever)

7. Joint
8. Plate
9. Retainer
10. Body
11. Filter

SBP00274

Operation**1) At neutral**

Ports **A** and **B** of the control valve and ports **P1** and **P2** of the PPC valve are connected to drain chamber **D** through fine control hole **f** in spool (1). (Fig. 1)



(Fig. 1)

SBP00275

2) Fine control (neutral → fine control)


When piston (4) starts to be pushed by disc (5), retainer (9) is pushed. Spool (1) is also pushed by metering spring (2) and moves down.

When this happens, fine control hole **f** is shut off from drain chamber **D**. At almost the same time, it is connected to pump pressure chamber **Pp**, and the pilot pressure of the control pump is sent from port **A** through fine control hole **f** to port **P1**.

When the pressure at port **P1** rises, spool (1) is pushed back. Fine control hole **f** is shut off from pump pressure chamber **Pp**. At almost the same time, it is connected to drain chamber **D**, so the pressure at port **P1** escapes. As a result, spool (1) moves up and down until the force of metering spool (2) is balanced with the pressure of port **P1**.

The relationship of the positions of spool (1) and body (10) (fine control hole **f** is in the middle between drain hole **D** and pump pressure chamber **Pp**) does not change until retainer (9) contacts spool (1).

Therefore, metering spring (2) is compressed in proportion to the travel of the control lever, so the pressure at port **P1** also rises in proportion to the travel of the control lever. In this way, the spool of the control valve moves to a position where the pressure of chamber **A** (same as pressure at port **P1**) and the force of the return spring of the control valve spool are balanced. (Fig. 2)



(Fig. 2)

SBP00276

020706


3) Fine control (control lever returned)

When disc (5) starts to be returned, spool (1) is pushed up by the force of centering spring (3) and the pressure at port **P1**.

Because of this, fine control hole **f** is connected to drain chamber **D**, and the pressurized oil at port **P1** is released.

If the pressure at port **P1** drops too much, spool (1) is pushed down by metering spring (2), so fine control hole **f** is shut off from drain chamber **D**. At almost the same time, it is connected to pump pressure chamber **Pp**, so the pressure at port **P1** supplies the pump pressure until the pressure recovers to a pressure equivalent to the position of the lever.

When the control valve returns, oil in drain chamber **D** flows in from fine control hole **f'** of the valve on the side that is not moving. It passes through port **P2** and goes to chamber **B** to charge the oil. (Fig. 3)




(Fig. 3)

SBP00277

4) At full stroke

Disc (5) pushes down piston (4), and retainer (9) pushes down spool (1). Fine control hole **f** is shut off from drain chamber **D**, and is connected to pump pressure chamber **Pp**. Therefore, the pilot pressure oil from the control pump passes through fine control hole **f** and flows to chamber **A** from port **P1** to push the control valve spool.


The return oil from chamber **B** passes from port **P2** through fine control hole **f'** and flows to drain chamber **D**. (Fig. 4)



(Fig. 4)

SBP00278


TRAVEL PPC VALVE




- a. Port P (from control pump)
- b. Port T (to tank)
- c. Port P1 (L.H. travel FORWARD)
- d. Port P3 (R.H. travel FORWARD)
- e. Port P2 (L.H. travel REVERSE)
- f. Port P4 (R.H. travel REVERSE)

SBP00279


020706




A - A



B - B



C - C



D - D


SBP00280

1. Piston
2. Plate
3. Collar
4. Body

5. Valve
6. Metering spring
7. Centering spring
8. Bolt

OPERATION**1) At neutral**

Ports **A** and **B** of the control valve and ports **P1** and **P2** of the PPC valve are connected to drain chamber **D** through fine control hole **f** in spool (1). (Fig. 1)



(Fig. 1)

SBP00281

2) Fine control (neutral → fine control)


When piston (4) starts to be pushed by disc (5), retainer (9) is pushed. Spool (1) is also pushed by metering spring (2) and moves down.

When this happens, fine control hole **f** is shut off from drain chamber **D**. At almost the same time, it is connected to pump pressure chamber **PP**, and the pilot pressure of the control pump is sent from port **A** through fine control hole **f** to port **P1**.

When the pressure at port **P1** rises, spool (1) is pushed back. Fine control hole **f** is shut off from pump pressure chamber **PP**. At almost the same time, it is connected to drain chamber **D**, so the pressure at port **P1** escapes. As a result, spool (1) moves up and down until the force of metering spool (2) is balanced with the pressure of port **P1**.

The relationship of the positions of spool (1) and body (10) (fine control hole **f** is in the middle between drain hole **D** and pump pressure chamber **PP**) does not change until retainer (9) contacts spool (1).

Therefore, metering spring (2) is compressed in proportion to the travel of the control lever, so the pressure at port **P1** also rises in proportion to the travel of the control lever. In this way, the spool of the control valve moves to a position where the pressure of chamber **A** (same as pressure at port **P1**) and the force of the return spring of the control valve spool are balanced. (Fig. 2)



(Fig. 2)

SBP00282

020706


3) Fine control (control lever returned)

When disc (5) starts to be returned, spool (1) is pushed up by the force of centering spring (3) and the pressure at port **P1**.

Because of this, fine control hole **f** is connected to drain chamber **D**, and the pressurized oil at port **P1** is released.

If the pressure at port **P1** drops too much, spool (1) is pushed down by metering spring (2), so fine control hole **f** is shut off from drain chamber **D**. At almost the same time, it is connected to pump pressure chamber **PP**, so the pressure at port **P1** supplies the pump pressure until the pressure recovers to a pressure equivalent to the position of the lever.

When the control valve returns, oil in drain chamber **D** flows in from fine control hole **f'** of the valve on the side that is not moving. It passes through port **P2** and goes to chamber **B** to charge the oil. (Fig. 3)




(Fig. 3)

SBP00283

4) At full stroke

Disc (5) pushes down piston (4), and retainer (9) pushes down spool (1). Fine control hole **f** is shut off from drain chamber **D**, and is connected to pump pressure chamber **PP**. Therefore, the pilot pressure oil from the control pump passes through fine control hole **f** and flows to chamber **A** from port **P1** to push the control valve spool.


The return oil from chamber **B** passes from port **P2** through fine control hole **f'** and flows to drain chamber **D**. (Fig. 4)




(Fig. 4)

SBP00284


SERVICE PPC VALVE



1. Pin
2. Cam
3. Ball
4. Piston
5. Cover
6. Sleeve
7. Centering spring
8. Metering spring
9. Spool
10. Body



- a. Port **T** (to tank)
- b. Port **P** (from control pump)
- c. Port **A** (to service valve P-1)
- d. Port **B** (to service valve P-2)




SBP00285

020706

STRUCTURE AND FUNCTION**SERVICE PPC VALVE****OPERATION****At neutral**


- The pressurized oil from the control pump enters from port **P** and is blocked by spool (9).
- Ports **A** and **B** of the control valve and ports **a** and **b** of the PPC valve are connected to drain port **T** through fine control hole **X** of spool (9).



SBP00286

When operated


- When cam (2) is moved, metering spring (8) is pushed by ball (3), piston (4), and sleeve (6), and spool (9) is pushed down by this.
- As a result, fine control hole **X** is shut off from the drain circuit. At almost the same time, fine control portion **Y** is connected with port **a**, and the pressurized oil from port **P** flows from port **a** to port **A** of the control valve.



SBP00287


STRUCTURE AND FUNCTION**SERVICE PPC VALVE**

- When the pressure at port **a** becomes higher, spool (9) is pushed back by the force acting on the end of the spool. When fine control portion **Y** closes, fine control hole **X** is connected to the drain circuit at almost the same time.
- As a result, spool (9) moves up and down to balance the force at port **a** and the force at metering spring (8).
- Therefore, metering spring (8) is compressed in proportion to the amount the control lever is moved. The spring force becomes larger, so the pressure at port **a** also increases in proportion to the amount the control lever is operated.
- In this way, the control valve spool moves to a position where the pressure of port **A** (the same as the pressure at port **a**) is balanced with the force of the return spring of the control valve spool.



SBP00288


PPC SAFETY LOCK VALVE



SBP00289

1. Lever
2. Body
3. Seat
4. Ball
5. End cap

PPC ACCUMULATOR




SBP00290

1. Gas plug
2. Shell
3. Poppet
4. Holder
5. Bladder
6. Oil port

Specifications

Actual gas volume: 300 cc

PPC SHUTTLE VALVE, TRAVEL JUNCTION VALVE



SDP00291

1. PPC shuttle valve
2. Travel junction valve

Outline

- The PPC shuttle valve and travel junction valve form a combined structure.

020706

STRUCTURE AND FUNCTION


PPC SHUTTLE VALVE, TRAVEL JUNCTION VALVE

- a. Port P11 [to control valve (swing)]
- b. Port P21 [to control valve (swing)]
- c. Port P31 [to control valve (bucket)]
- d. Port P41 [to control valve (bucket)]
- e. Port P51 [to control valve (boom)]
- f. Port P61 [to control valve (arm)]
- g. Port PLS (from LS select valve)
- h. Port P71 [to control valve (arm)]
- i. Port P81 [to control valve (boom)]
- j. Port PA1 [to control valve (R.H. travel)]
- k. Port PB1 [to control valve (L.H. travel)]
- l. Port PC1 [to control valve (L.H. travel)]
- m. Port P91 [to control valve (R.H. travel)]
- n. Port P12 (from swing PPC valve)
- o. Port P22 (from swing PPC valve)
- p. Port P32 (from bucket PPC valve)
- q. Port P42 (from bucket PPC valve)
- r. Port P52 (from boom PPC valve)
- s. Port P62 (from arm PPC valve)
- t. Port P72 (from arm PPC valve)
- u. Port P82 (from boom PPC valve)
- v. Port PA2 (from R.H. travel PPC valve)
- w. Port PB2 (from L.H. travel PPC valve)
- x. Port PC2 (from L.H. travel PPC valve)
- y. Port P32 (from R.H. travel PPC valve)
- z1. Port PR (to travel junction valve)
- z2. Port PF (to travel junction valve)
- aa. Port A1 (mount port for swing pressure switch)
- ba. Port A8 (mount port for bucket DUMP pressure switch)
- bb. Port A2 (mount port for bucket CURL pressure switch)
- ca. Port A4 (mount port for arm OUT pressure switch)
- cb. Port A3 (mount port for arm IN pressure switch)
- da. Port A5 (mount port for boom RAISE pressure switch)
- db. Port A7 (mount port for boom LOWER pressure switch)
- ee. Port A6 (mount port for travel pressure switch)

020706

STRUCTURE AND FUNCTION

PPC SHUTTLE VALVE, TRAVEL JUNCTION VALVE



SDP00293


1. Body
2. Plug
3. Ball

020706

STRUCTURE AND FUNCTION

PPC SHUTTLE VALVE, TRAVEL JUNCTION VALVE

TRAVEL JUNCTION VALVE




1. Body
2. Plug
3. Spring
4. Spool

- a. Port T1 (from L.H. travel control valve)
- b. Port T2 (from R.H. travel control valve)
- c. Port T3 (from L.H. travel control valve)
- d. Port T4 (from R.H. travel control valve)
- e. Port Pf (from PPC shuttle valve)
- f. Port PR (from PPC shuttle valve)

SBP00294

STRAIGHT-TRAVEL SYSTEM



SBP00295

020706

Function

- A travel junction valve is installed between the travel valve and travel motor to compensate for any difference in the oil flow to the left and right travel circuits when traveling in a straight line.
- Because of this, the flow of oil to the left and right travel motors when traveling in a straight line is almost the same, so there is no travel deviation.
- The travel junction valve interconnects the travel circuits when the straight-travel is operated independently or when the straight travel + another actuator are operated simultaneously.
- When steering, if the difference in the movement of the travel levers is more than approx. 10 mm, the travel junction valve is switched, and the left and right travel circuits are shut off.

STRUCTURE AND FUNCTION


PPC SHUTTLE VALVE, TRAVEL JUNCTION VALVE

Operation

- A: PPC output pressure (R.H. travel REVERSE or L.H. travel FORWARD)
- B: PPC output pressure (R.H. travel FORWARD or L.H. travel REVERSE)


When traveling in a straight line in forward or reverse

- When traveling forward (or in reverse), there is no difference in the pilot pressure from the PPC shuttle valve (the output pressure of each PPC valve), so the spool is balanced in the middle. In this condition, the R.H. FORWARD and L.H. FORWARD, and R.H. REVERSE and L.H. REVERSE are interconnected through the spool.




When steering in forward or reverse

- When the steering is operated in forward (or reverse), if the difference in the pilot pressure from the PPC shuttle valve becomes greater than the switching pressure (spring force), the spool moves to the right or left and the left and right forward and left and right reverse passages are separated. Because of this, a difference in pressure is created in the left and right circuits, and the steering can be operated.



EPC SOLENOID VALVE

For LS select, boom Hi 2-stage safety valve, merge/flow divider, travel speed, swing brake



1. LS select solenoid valve
2. Boom Hi 2-stage safety valve solenoid valve
3. Merge/flow divider solenoid valve
4. Travel speed solenoid valve
5. Swing brake solenoid valve


- a. To tank
- b. From control pump
- c. To PPC valve
- d. From shuttle valve
- e. To LS select valve
- f. To boom control valve
- g. To merge/flow divider valve
- h. To L.H. and R.H. travel motors
- i. To swing motor
- j. To accumulator

SBP00298

020706

STRUCTURE AND FUNCTION

EPC SOLENOID VALVE




SBP00299

1. Connector
2. Variable core
3. Coil
4. Cage
5. Spool
6. Block
7. Spring

Operation**When solenoid is de-energized**


- The signal current does not flow from the controller, so solenoid (3) is de-energized. For this reason, spool (5) is pushed to the right by spring (6). As a result, the circuit between ports **P** and **A** closes and the pressurized oil from the control pump does not flow to the actuator. At the same time, the pressurized oil from the actuator flows from port **A** to port **T**, and is then drained to the tank.



SBP00300


When solenoid is energized

- When the signal current flows from the controller to solenoid (3), solenoid (3) is energized. For this reason, spool (5) is pushed to the left. As a result, the pressurized oil from the control pump flows from port **P** through the inside of spool (5) to port **A**, and then flows to the actuator. At the same time, port **T** is closed, and this stops the oil from flowing to the tank.



SBP00301

FOR LS VALVE CONTROL



020706

SBP00302

- 1. Body
- 2. Spool
- 3. Spring
- 4. Push pin

- 5. Coil
- 6. Plunger
- 7. Connector


- a. Port C (to LS valve)
- b. Port T (to tank)
- c. Port P (from control pump)

STRUCTURE AND FUNCTION

EPC SOLENOID VALVE

Function

- The EPC valve consists of the proportional solenoid portion and the hydraulic valve portion.
- When it receives signal current i from the governor and pump controller, it generates the EPC output pressure in proportion to the size of the signal, and outputs it to the LS valve.




SAP00303

Operation**1. When signal current is 0 (coil de-energized)**

- There is no signal current flowing from the controller to coil (5), coil (5) is de-energized.
- For this reason, spool (2) is pushed to the right by spring (3).

As a result, port **P** closes and the pressurized oil from the control pump does not flow to the LS valve.


At the same time, the pressurized oil from the LS valve passes from port **C** through port **T** and is drained to the tank.



SBP00304


2. When signal current is very small (coil energized, fine control)

- When a very small signal current flows to coil (5), coil (5) is energized, a propulsion force is generated, and this pushes plunger (6) to the left.
- Push pin (4) pushes spool (2) to the left, and pressurized oil flows from port **P** to port **C**.
- When the pressure at port **C** rises and the load of spring (3) + the force acting on surface **a** of spool (2) becomes greater than the propulsion force of plunger (6), spool (2) is pushed to the right. The circuit between port **P** and port **C** is shut off, and at the same time, port **C** and port **T** are connected.
- As a result, spool (2) moves up and down so that the propulsion force of plunger (6) is balanced with the load of spring (3) + pressure of port **C**.
- Therefore, the circuit pressure between the EPC valve and the LS valve is controlled in proportion to the size of the signal current.




3. When signal current is maximum (coil energized, operated fully)

- When the signal current flows to coil (5), coil (5) is energized.
- When this happens, the signal current is at its maximum, so the propulsion force of plunger (6) is also at its maximum. For this reason, spool (1) is pushed fully to the left by push pin (4).
- As a result, the flow of pressurized oil from port **P** flows at its maximum to port **C**, and the circuit pressure between the EPC valve and LS valve becomes the maximum. At the same time, port **T** closes and stops the oil from flowing to the tank.



020706

BOOM HOLDING VALVE



SAP00307

1. Safety-suction valve
2. Pilot spring
3. Pilot spool
4. Poppet spring
5. Poppet


STRUCTURE AND FUNCTION

BOOM HOLDING VALVE

Operation

1) At boom RAISE


When the boom is raised, the main pressure from the control valve pushes poppet (5) up. Because of this, the main pressure from the control valve passes through the valve and flows to the bottom end of the boom cylinder.



2) Boom lever at HOLD

When the boom is raised and the control lever is returned to HOLD, the circuit for the holding pressure at the bottom end of the boom cylinder is closed by poppet (5). At the same time, the oil flowing into poppet (5) through orifice a of poppet (5) is closed by pilot spool (3).

As a result, the boom is held in position.



020706


3) At boom LOWER

When the boom is lowered, the pilot pressure from the PPC valve pushes pilot spool (3) and the pressurized oil in chamber **b** inside the poppet is drained.

When the pressure at port **Cy** rises because of the pressurized oil from the bottom end of the boom cylinder, the pressure of the pressurized oil in chamber **b** is lowered by orifice **a**.

If the pressure in chamber **b** drops below the pressure at port **V**, poppet (5) opens, the pressurized oil flows from port **Cy** to port **V**, and then flows to the control valve.

If any abnormal pressure is generated in the circuit at the bottom end of the boom cylinder, safety valve (1) is actuated.



SBP00310


HYDRAULIC CYLINDER

Specifications

Unit: mm

Item	Boom		Arm		Bucket	
	PC300-6	PC350-6	PC300-6	PC350-6	PC300-6	PC350-6
Outside diameter of piston rod	100	100	110	110	100	100
Inside diameter of cylinder	140	140	160	160	140	140
Stroke	1,480	1,480	1,685	1,825	1,285	1,285
Max. stroke	3,610	3,610	4,080	4,360	3,275	3,275
Min. stroke	2,130	2,130	2,395	2,535	1,990	1,990

WORK EQUIPMENT




SBP00311

1. Arm
2. Bucket cylinder
3. Arm cylinder
4. Boom
5. Boom cylinder
6. Bucket

ACTUAL ELECTRIC WIRING DIAGRAM

★ For details of this page, see Section 90.




SBP00312

STRUCTURE AND FUNCTION


ACTUAL ELECTRIC WIRING DIAGRAM

020706

★ For details of this page, see Section 90.



1. Working lamp
2. Front pump pressure sensor
3. Rear pump pressure sensor
4. Radiator water level sensor
5. Engine speed sensor
6. Front pump TVC solenoid
7. Rear pump TVC solenoid
8. Window washer tank
9. Hydraulic oil level sensor
10. LS control EPC valve
11. Horn (high tone)
12. Horn (low tone)
13. Battery relay
14. Battery
15. Right head lamp
16. Fuel level sensor
17. Swing pressure switch
18. Bucket DUMP pressure switch
19. Bucket CURL pressure switch
20. Arm IN pressure switch
21. Boom LOWER pressure switch
22. Arm OUT pressure switch
23. Travel pressure switch
24. Boom RAISE pressure switch
25. Swing brake solenoid valve
26. Travel speed solenoid valve
27. Pump merge/divider solenoid valve
28. Boom Hi 2-stage safety solenoid valve
29. LS select solenoid valve
30. Engine water temperature sensor
31. Intake air heater
32. Engine oil pressure sensor
33. Starting motor
34. Air conditioner compressor
35. Engine oil level sensor
36. Alternator



SBP00314

(1/3)

Radio connector

Page

ASS'Y



SAP00717

020706



10-141



STRUCTURE AND FUNCTION


ELECTRIC CIRCUIT DIAGRAM

(3/3)



020706

ENGINE CONTROL



020706

SBP00320

1. Battery relay
2. Battery
3. Starting switch
4. Fuel control dial
5. Governor motor
6. Starting motor
7. Governor, pump controller
8. Fuel injection pump


Function

- The engine can be started and stopped simply by using the starting switch.
- A dial-type engine control is used to control the engine speed. The governor, pump controller receives the control signal from the fuel control dial, sends a drive signal to the governor motor, and controls the angle of the governor lever in the fuel injection pump.

1. Operation of system


Starting engine

- When the starting switch is turned to the START position, the starting signal flows to the starting motor, and the starting motor turns to start the engine. When this happens, the governor and pump controller checks the signal from the fuel control dial and sets the engine speed to the speed set by the fuel control dial.




Engine speed control

- The fuel control dial sends a signal to the governor and pump controller according to the position of the dial. The governor and pump controller calculates the angle of the governor motor according to this signal, and sends a signal to drive the governor motor so that it is at that angle. When this happens, the operating angle of the governor motor is detected by the potentiometer, and feedback is sent to the governor and pump controller, so that it can observe the operation of the governor motor.




Stopping engine

- When governor and pump controller detects that the starting switch is turned to the STOP position, it drives the governor motor so that the governor lever is set to the NO INJECTION position.
- When this happens, to maintain the electric power in the system until the engine stops completely, the governor and pump controller itself drives the battery relay.



2. Components of system


Fuel control dial




SBP00324

Function

- The fuel control dial is installed at the bottom of the monitor panel. A potentiometer is installed under the knob, and when the knob is turned, it rotates the potentiometer shaft. When the shaft rotates, the resistance of the variable resistor inside the potentiometer changes, and the desired throttle signal is sent to the governor and pump controller. The shaded area in the graph on the right is the abnormality detection area and the engine speed is set at low idling.



020706

Governor motor

SBP00326

Function

- The motor is rotated and the governor lever of the fuel injection pump is controlled by the drive signal from the governor and pump controller.
A stepping motor is used for the motor which provides the power.
- In addition, a potentiometer for giving feed-back is installed to allow observation of the operation of the motor.
- The rotation of the motor is transmitted to the potentiometer through a gear.



Operation**Motor stationary**

- Both A phase and B phase of the motor are continuous, and a holding torque is generated in the motor.

Motor rotating

- A pulse current is applied to the A phase and B phase from the governor and pump controller to give synchronous rotation with the pulse.

Governor, pump controller



020706

SAP00327

STRUCTURE AND FUNCTION

ENGINE CONTROL

Input and output signals

CN-1

Pin No.	Name of signal	Input/output
1	Battery relay drive output	Output
2	Pump merge/divider solenoid/NC	Output
3	Swing holding brake solenoid	Output
4	NC	
5	NC	
6	GND	Input
7	Power source (+24V)	Input
8	LS divider solenoid/LS cut-off solenoid	Output
9	Travel selector solenoid	Output
10	2-stage relief solenoid	Output
11	NC	
12	GND	Input
13	Power source (+24V)	Input

CN-2

Pin No.	Name of signal	Input/output
1	Solenoid power source (+24V)	Input
2	Governor motor phase A (+)	Output
3	Governor motor phase A (-)	Output
4	Governor motor phase B (+)	Output
5	Governor motor phase B (-)	Output
6	NC	
7	LS-EPC solenoid (+)	Output
8	TVC solenoid 1 (+)	Output
9	TVC solenoid 2 (+)	Output
10	NC	
11	PGND	Input
12	Solenoid power source (+24V)	Input
13	NC	
14	NC	
15	NC	
16	NC	
17	LS-EPC solenoid (-)	Output
18	TVC solenoid 1 (-)	Output
19	TVC solenoid 2 (-)	Output
20	NC	
21	PGND	Input

CN-3


Pin No.	Name of signal	Input/output
1	Engine water temperature sensor	Input
2	Fuel level sensor	Input
3	Pump F pressure input	Input
4	Throttle potentiometer input	Input
5	NC	
6	Pressure sensor power source (+24V)	Output
7	Potentiometer power source (+5V)	Output
8	Starting switch (ACC)	Input
9	Knob switch	Input
10	Hydraulic oil temperature sensor (monitor panel)	Input
11	Hydraulic oil temperature sensor (thermistor type)	Input
12	Battery charge (alternator terminal R)	Input
13	Pump R pressure input	Input
14	Feedback potentiometer input	Input
15	NC	Input
16	Pressure sensor GND	Input
17	Potentiometer GND	Input
18	Starting switch (terminal C)	Input
19	Automatic greasing controller abnormality	Input
20	Hydraulic filter sensor	Input
21	PPC pressure	Input
22	Boom RAISE pressure switch	Input
23	Arm IN pressure switch	Input
24	S-NET(+)	Input, output
25	Model selection 1	Input
26	Model selection 3	Input
27	Model selection 5	Input
28	Swing prolix switch	Input
29	Overload sensor	Input
30	Boom LOWER pressure switch	Input
31	Arm OUT pressure switch	Input
32	S-NET(+)	Input, output
33	Model selection 2	Input
34	Model selection 4	Input
35	Kerosene mode selection	Input
36	Swing lock switch	Input

CN-5

Pin No.	Name of signal	Input/output
1	Engine speed sensor GND	Input
2	Engine speed sensor	Input
3	GND	Input
4	GND	Input
5	Swing pressure switch	Input
6	Service valve pressure switch	Input
7	Engine oil pressure sensor H	Input
8	Radiator water level sensor	Input
9	Hydraulic oil level sensor	Input
10	Engine speed sensor GND	Input
11	Bucket CURL pressure switch	Input
12	Bucket DUMP pressure switch	Input
13	Travel pressure switch	Input
15	Engine oil pressure sensor L	Input
16	Engine oil level sensor	Input
17	Air cleaner clogging sensor	Input

ELECTRONIC CONTROL SYSTEM


CONTROL FUNCTION



020706


★ For details of the self-diagnostic function, see TROUBLESHOOTING.

TOTAL SYSTEM DIAGRAM



020706

1. Pump & Engine Mutual control system




SBP00329


Function

- There are five modes available for selection with the working mode switch on the monitor panel. These modes are the heavy-duty operation mode (H/O), general operation mode (G/O), finishing operation mode (F/O), lifting operation mode (L/O), and the breaker mode (B/O). It is possible to select the most suitable engine torque and pump absorption torque to match the nature of the work.
- The governor and pump controller detects the actual engine speed and the speed set by the engine governor through the fuel control dial in accordance with the pump absorption torque set for each mode, and carries out control so that the pump absorbs all of the torque at each output point of the engine.


Engine torque curve



Engine horsepower curve






Pump output curve



1) Control method in each mode

Heavy-duty operation mode



- Matching point in heavy-duty operation mode: Rated output point




Mode	Model	PC300, 350-6
Heavy-duty		173 kW (232 HP)/2,050 rpm

- When the load on the pump rises and the pressure rises, the engine speed goes down. When this happens, the pump discharge amount is reduced, and the engine speed is controlled so that it becomes near the rated output point.

If the reverse happens and the pressure goes down, the system is controlled so that the pump discharge amount is increased until the engine speed becomes near the rated output point.

By repeating this control, the engine can always be used at near the rated output point.

General, breaker, finishing operation mode






- Matching point

Mode	G/O	B/O	F/O
Partial output point	90%	85%	80%

Mode	Model	PC300, 350-6
G/O		154 kW (207 HP)/1,850 rpm
B/O		147 kW (197 HP)/1,850 rpm
F/O		136 kW (182 HP)/1,700 rpm

- When the load on the pump rises and the pressure rises, the engine speed goes down. When this happens, mutual control of the engine and pump is used to control the system so that the pump absorption torque follows the equal horsepower curve of the engine, and the engine speed is lowered while keeping the torque constant.




In this way, the engine is used in a range which provides good fuel efficiency

Lifting operation mode

- Matching point in lifting operation mode:
60% partial output point

Mode	Model	PC300, 350-6
L/O		103 kW (138 HP)/1,500 rpm

- When the lifting operation mode is selected, the engine speed is automatically lowered to the partial position. In this condition, control is carried out in the same way as for the general operation, finishing, and breaker operation modes to match the load on the pump. In this way, the fuel consumption is reduced and the fine control ability is improved.



Power max. mode, travel

- Matching point in power max. mode:
Rated output point

Mode	Model	PC300, 350-6
Power max.		173 kW (232 HP)/2,050 rpm

- When the pump load increases, the engine speed drops. When this happens, the pump discharge is reduced to prevent the engine speed from going down and to ensure that the engine is used at near the rated output point. The cut-off at relief is canceled and the oil flow at relief is increased.


2) Control function when TVC prolix switch is ON



- Even if any abnormality should occur in the controller or sensor, the TVC prolix switch can be turned ON to provide an absorption torque more or less equivalent to the general operation mode, thereby allowing the machine to maintain its functions.

In this case, it is designed to allow a constant current to flow from the battery to the TVC valve, so oil pressure sensing is carried out only by the TVC valve.

2. Pump and valve control function




020706

Function


- Optimum matching under various working conditions with the fine control mode function which reduces the hydraulic loss and improves the ease of fine control.

1) LS control function


- The switching point (LS set differential pressure) for the pump discharge amount inside the LS valve is changed by changing the output pressure from the LS EPC valve to the LS valve according to the engine speed and operating condition of the actuator.
- Because of this, the timing for starting the discharge amount from the pump can be optimized, to give excellent ease of compound operation and fine control.

**2) Cut-off function**

- If the load becomes large during the operation and the pump discharge pressure rises to a point close to the relief pressure, the pump pressure sensor detects this, and the controller sends a signal to the TVC valve to reduce the discharge amount in order to reduce the relief loss.

**3) Cut-off cancel function**

- The cut-off cancel function stops the actuation of the cut-off function in order to ensure the flow of oil from the pump near the relief pressure, thereby preventing any drop in speed.
- The relief pressure when the cut-off function is actuated is 33.8 MPa (345 kg/cm²), but when the cut-off is canceled, the relief pressure rises to approx. 34.8 MPa (355 kg/cm²). Because of this, the hydraulic pressure is increased by one stage.



- Switches and cut-off functions

	Working mode switch		Swing lock switch		Knob switch	
	Heavy digging	Digging	ON	OFF	ON	OFF
Cut-off function	Actuated	Actuated	Canceled	Actuated	Canceled	Actuated

- ※ When the swing lock switch is set to ON, hydraulic oil is quickly warmed, also when the swing lock switch is set to ON, the function is canceled. Under these conditions, when work equipment is relieved, hydraulic oil temperature goes up more quickly, and warming time is shortened.


4) Fine control mode function

- When the finishing mode is selected as the working mode, the pump LS valve is controlled, and the pump discharge amount is reduced to improve the ease of fine control and the precision when finishing.
- Relationship between working mode and pump discharge amount (for independent operation)

Actuator	Boom		Arm	Bucket		Swing	Breaker
	RAISE	LOWER		CURL	DUMP		
Working mode							
Heavy-duty operation (H/O)	100	30	100	75	60	55	—
General operation (G/O)							
Finishing operation (F/O)	80	30	80	60	50	45	—
Lifting mode (L/O)	75		75	55	45	40	—
Breaker (B/O)	100	30	100	75	60	55	45

- ★ In each working mode, the full flow of the pump at the set engine speed is taken as 100%.

3. Power max. function, swift slow-down function



SBP00354

Function

- This function provides an increase in the digging power for a certain time or switches the working mode to the fine operation to reduce the speed. It is operated using the L.H. knob switch to momentarily match the operating conditions.
- ★ The power max. function and swift slow-down function are operated with the same switch. Only one of these functions can be selected at any time; they cannot both be operated together.

1) Power max. function

- During digging operations, when that extra bit of digging power is needed (for example, when digging up boulders), the L.H. knob switch can be pressed to raise the hydraulic pressure by approx. 10% and increase the digging force.
- If the L.H. knob switch is pressed ON when the working mode is at H/O or G/O, each function is automatically set as follows.



Working mode	Engine, pump control	Cut-off function	Actuating time
Heavy-duty operations	Matching at rated output point	Canceled	Automatically canceled after 8.5 sec


2) Swift slow-down function

- During normal operations, if it is desired to carry out lifting operations or finishing operations for a moment, the working mode can be switched to L/O by operating the L.H. knob switch.
- If the L.H. knob switch is pressed ON when the working mode is at H/O or G/O, each function is automatically set as follows.



Working mode	Actuating time
Lifting operation	While switch is kept pressed

4. Auto deceleration system



SBP00355

Function


- If all the control levers are at neutral when waiting for work or waiting for a dump truck, the engine speed is automatically reduced to a midrange speed to reduce fuel consumption and noise.
- If any lever is operated, the engine speed returns immediately to the set speed.

Operation**Control levers at neutral**

- If the engine is running at above the deceleration actuation speed (approx. 1400 rpm), and all the control levers are returned to neutral, the engine speed drops immediately to approx. 100 rpm below the set speed to the No. 1 deceleration position.
- If another 4 seconds passes, the engine speed is reduced to the No. 2 deceleration position (approx. 1400 rpm), and is kept at that speed until a lever is operated.

When control lever is operated


- If any control lever is operated when the engine speed is at No. 2 deceleration, the engine speed will immediately rise to the speed set by the fuel control dial.



SAP00356

020706

5. Automatic warming-up and engine overheating prevention function




SBP00357

Function


- If the water temperature is low, this automatically raises the engine speed to warm up the engine after it is started. (Automatic warming-up function).
In addition, if the water temperature rises too high during operations, it reduces the load of the pump to prevent overheating. (Engine overheating prevention function)

1) Engine automatic warming-up function

- After the engine is started, if the engine coolant temperature is low, the engine speed is automatically raised to warm up the engine.


**2) Engine overheat prevention function**

- This function protects the engine by lowering the pump load and engine speed to prevent overheating when the engine coolant temperature has risen too far.
- This system is actuated when the water temperature is 105°C and above.




6. Swing priority function

- There is a SWING PRIORITY mode switch on the monitor panel. This switch can be turned ON or OFF to change the matching of the boom RAISE and SWING operations. The oil flow is divided and sent to the swing to match the swing angle to allow compound operations to be carried out easily.
Swing priority mode OFF: 90° swing and loading of dump truck
Swing priority mode ON: 180° swing and loading of dump truck




SAP00783



SBP00359

- The change in the matching between the boom RAISE and SWING is carried out by changing the signal to the LS select valve.
When swing priority mode is OFF
Solenoid: ON
LS select valve: merged
When swing priority mode is ON
Solenoid: OFF
LS select valve: divided



SBP00360

STRUCTURE AND FUNCTION**ELECTRONIC CONTROL SYSTEM****1) Swing lock, swing holding brake function**

- The swing lock (manual) can be locked at any desired position, and the swing holding brake (automatic) is interconnected with the swing, so it prevents any hydraulic drift after the swing is stopped.

- Swing lock switch and swing lock, swing holding brake

Lock switch	Lock lamp	Function	Operation
OFF	OFF	Swing holding brake	When swing lever is placed at neutral, swing brake is applied after approx. 5 sec; when swing lever is operated, brake is canceled and swing can be operated freely
ON	ON	Swing lock	Swing lock is actuated and swing is held in position. Even when swing lever is operated, swing lock is not canceled and swing does not move.


※ Operation of swing lock prolix switch

- If any abnormality should occur in the controller, and the swing holding brake is not actuated normally and the swing cannot be operated, the swing lock prolix switch can be operated to cancel the swing lock and allow the swing to be operated.
- ★ Even when the swing lock prolix switch is turned ON, the swing lock switch stays ON and the swing brake is not canceled.
- ★ When the swing brake is canceled, the swing has only a hydraulic brake operated by the safety valve, so if the swing is stopped on a slope, there may be hydraulic drift.

Swing lock prolix switch	ON (when controller is abnormal)		OFF (when controller is normal)	
Swing lock switch	ON	OFF	ON	OFF
Swing brake	Swing lock applied	Swing lock canceled	Swing lock applied	Swing holding brake applied


2) Hydraulic oil quick warm-up function when swing lock switch is ON

- When the swing lock switch is turned ON, the pump cut-off is canceled. If the work equipment is relieved in this condition, the hydraulic oil temperature will rise more quickly and the warming-up time can be reduced.



SBP00362

8. Travel control system



SBP00363

Function

- When traveling, the pump control is carried out, and the travel speed can be selected manually or automatically to give a travel performance that suits the nature of the work or the jobsite.

1) Pump control function when traveling

- If the travel is operated in any working mode other than the heavy-duty operation mode, this increases the pump absorption torque while keeping the working mode and engine speed as they are.
- ★ For details, see PUMP & ENGINE MUTUAL CONTROL.

2) Travel speed selection function


- Manual selection using travel speed switch
If the travel speed switch is set to Lo, Mi, or Hi, the governor and pump controller controls the pump flow and motor volume at each speed range as shown on the right to switch the travel speed.
- Automatic selection according to engine speed
If the engine speed is reduced to below 1,350 rpm by the fuel control dial:
 - If the machine is traveling in Lo, it will not shift even if Mi or Hi are selected.
 - If the machine is traveling in Mi, it will not shift even if Hi is selected.
 - If the machine is traveling in Hi, it will automatically shift to Lo.
- Automatic selection according to pump discharge pressure

If the machine is traveling with the travel speed switch at Hi, and the load increases, such as when traveling up a steep hill, if the travel pressure continues at 32.3 MPa (330 kg/cm²) for more than 1.0 sec, the pump volume is automatically switched and the travel speed changes to Lo.

(The travel speed switch stays at Hi.)

The machine continues to travel in Lo, and when the load is reduced, such as when the machine travels again on flat ground or goes downhill, and the travel pressure stays at 21.6 MPa (220 kg/cm²) or less for more than 1.0 sec, the pump volume is automatically switched and the travel speed returns to Hi.


Travel speed switch	Lo (Low speed)	Mi (Mid-range speed)	Hi (High speed)
Pump flow (%)	80	60	100
Motor volume	Max.	Min.	Min.
Travel speed (km/h)	3.7	4.5	5.5




SAP00364

9. Components of system

1) Engine speed sensor



1. Wire
2. Magnet
3. Terminal
4. Housing
5. Connector




SBP00365

Function

- The engine speed sensor is installed to the ring gear portion of the engine flywheel. It counts electrically the number of gear teeth that pass in front of the sensor, and sends the results to the governor and pump controller.
- This detection is carried out by a magnet, and an electric current is generated every time the gear tooth passes in front of the magnet.

2) PPC hydraulic switch



1. Plug
2. Switch
3. Connector



Specifications

Composition of points:

N.O. points

Actuation (ON) pressure:

0.5 ± 0.1 MPa

(5.0 ± 1.0 kg/cm²)



Reset (OFF) pressure:

0.3 ± 0.05 MPa

(3.0 ± 0.5 kg/cm²)



Function

- There are 8 switches installed to the PPC shuttle valve. The operating condition of each actuator is detected from the PPC pressure, and this is sent to the governor and pump controller.



SBP00366

3) Pump pressure sensor




SBP00367

Function


- This sensor is installed to the inlet port circuit of the control valve. It converts the pump discharge pressure to a voltage and sends this to the governor and pump controller.

Operation

- When the pressurized oil entering from the pressure introduction portion pressurizes the diaphragm of the pressure detection portion, the diaphragm deflects and changes shape.
- A gauge layer is installed to the face opposite the diaphragm, and the resistance of the gauge layer converts the deflection of the diaphragm into an output voltage and sends it to the amp (voltage amplifier).
- The voltage is further amplified by the amplifier and is sent to the governor and pump controller.
- Relationship between P pressure (MPa (kg/cm²)) and output voltage (V).
 $V = 0.008 \times P + 1.0$




SAP00368



SAP00369

4) TVC prolix resistor



SBP00370

1. Resistor
2. Connector

Specification

Resistance: 8.5 Ω

Function

- This resistor acts to allow a suitable current to flow to the TVC solenoid when the TVC prolix switch is ON.
- No current flows when the TVC prolix switch is OFF.

5) Fuel control dial, governor motor, governor and pump controller

- ★ See ENGINE CONTROL

6) Monitor panel

- ★ See MONITORING SYSTEM


7) TVC valve

- ★ See HYDRAULIC PUMP

8) LS control EPC valve

- LS select solenoid valve
- Boom Hi 2-stage safety valve solenoid valve
- Merge/flow divider valve solenoid valve
- Travel speed solenoid valve
- Swing brake solenoid valve
- ★ See EPC SOLENOID VALVE

MACHINE MONITOR SYSTEM




SBP00701

Function

- The machine monitor system uses the sensors installed to all parts of the machine to observe the condition of the machine. It processes this information swiftly, and displays it on a panel to inform the operator of the condition of the machine. The content of the information displayed on the machine can broadly be divided as follows.
 - Monitor portion**
This gives an alarm if any abnormality occurs in the machine.
 - Gauge portion**
This always displays the condition of the machine (coolant temperature, fuel level).
- The monitor panel also has various built-in mode selector switches, and functions as the control panel for the machine control system.

1. Monitor panel



SAP00702

Outline

- The monitor panel consists of the switches for the monitor display functions, mode selector, and electrical components. It has a built-in CPU (Central Processing Unit), and processes, displays, and outputs the information. The monitor display panel uses a liquid crystal display (LCD). The mode switches are flat sheet switches.

Input and output signals

CN-P01

Pin No.	Name of signal
1	N/W signal
2	N/W GND
3	ND
4	NC
5	Swing lock
6	Buzzer stop
7	Buzzer output
8	Lamp
9	Key ON signal
10	Terminal BR
11	N/W signal
12	N/W GND
13	NC
14	NC
15	NC
16	NC
17	NC
18	Preheating
19	Start signal
20	NC


CN-P02

Pin No.	Name of signal
1	GND
2	NC
3	NC
4	NC
5	NC
6	NC
7	NC
8	+VB
9	GND
10	NC
11	NC
12	NC
13	NC
14	NC
15	NC
16	+VB

STRUCTURE AND FUNCTION



MACHINE MONITOR SYSTEM

DISPLAY MONITOR




1. Clock (displays error code when error occurs)
2. Service meter (displays telephone number when error occurs)
3. Coolant temperature gauge
4. Fuel gauge
5. Engine oil level caution lamp
6. Hydraulic oil level caution lamp
7. Preheating pilot lamp
8. Swing holding brake pilot lamp
9. Charge level caution lamp
10. Air cleaner clogging caution lamp
11. PPC oil pressure caution lamp
12. Overload caution lamp
13. Coolant level caution lamp
14. Engine oil pressure caution lamp
15. Fuel level caution lamp
16. Coolant temperature caution lamp

Content of display

Symbol	Display item	Display range	When engine is stopped	When engine is running
 SAP00519	Coolant level	Below low level	Flashes when abnormal	Flashes and buzzer sounds when abnormal
 SAP00520	Engine oil pressure	Below 1,500 rpm: below 0.05 MPa (0.5 kg/cm ²) Above 1,500 rpm: below 0.15 MPa (1.5 kg/cm ²)	Lights up when normal (goes out when engine starts)	Flashes and buzzer sounds when abnormal
 SAP00521	Air cleaner clogging	When clogged	OFF	Flashes when abnormal
 SAP00522	Charge level	When charging is defective	Lights up when normal (goes out when engine starts)	Flashes when abnormal
 SAP00523	Engine oil level	Below low level	Flashes when abnormal	OFF
 SAP00524	Hydraulic oil level	Below low level	OFF	Flashes when abnormal
 SDP00688	Over load	Above high level	OFF	Flashes when abnormal
 SDP00689	PPC oil pressure	Below low level	OFF	Flashes when abnormal
 SDP00582	Parking	When swing is locked	Lights up when swing lock switch is ON, flashes when swing lock prolix switch is ON	
 SAP00526	Preheating	During preheating	Lights up for 30 seconds when starting switch is at HEAT, then flashes for 10 seconds to indicate that preheating is completed	
 SAP00703	Coolant temperature	Flashes when above 102°C, flashes and buzzer sounds when above 105°C		 SAP00529
 SAP00704	Fuel level	Flashes when below low level		 SAP00530

MODE SELECTION SWITCHES




- 1. Working mode switch
- 2. Auto deceleration switch
- 3. Swing priority mode switch
- 4. Travel speed switch
- 5. Power max./Swift slow-down switch

SAP00705

- The switch portion consists of five mode selection switches, and the condition of the machine changes each time that any switch is pressed. The LED above the switch lights up to display the present condition of the machine.

Switch actuation table

Switch	Item	Action
 SDP00692	WORKING MODE	H/O ↔ G/O ↔ F/O ↔ L/O ↔ B/O
 SDP00693	KNOB BUTTON	 (POWER UP) (SPEED DOWN) SDP00694
 SDP00695	AUTO DECEL	ON ↔ OFF
 SDP00696	TRAVEL SPEED	Hi ↔ Mi ↔ Lo
 SAP00706	SWING PRIORITY MODE	OFF ↔ ON


★ The bold letters indicate the default position of the switch when the starting switch is turned ON.

2. Sensors

- The signals from the sensors are input directly to the monitor panel.
- The contact type sensors are always connected at one end to the chassis GND.

Name of sensor	Type of sensor	When normal	When abnormal
Coolant level	Contact type	ON (closed)	OFF (open)
Engine oil level	Contact type	ON (closed)	OFF (open)
Hydraulic oil level	Contact type	ON (closed)	OFF (open)
Engine oil pressure	Contact type	OFF (open)	ON (closed)
Coolant temperature	Resistance type	—	—
Fuel level	Resistance type	—	—
Air cleaner clogging	Contact type	OFF (closed)	ON (open)

Coolant level sensor




1. Sub-tank
2. Float
3. Sensor
4. Connector

SAP00375


STRUCTURE AND FUNCTION

MACHINE MONITOR SYSTEM

Engine oil level sensor Hydraulic oil level sensor




1. Connector
2. Bracket
3. Float
4. Switch




SBP00376

Engine oil pressure sensor (both Lo and Hi)




1. Plug
2. Contact ring
3. Contact
4. Diaphragm
5. Spring
6. Terminal




Composition of circuit

SBP00378

Coolant temperature sensor




1. Connector
2. Plug
3. Thermistor



SBP00379

020706


Fuel level sensor



1. Float
2. Connector
3. Cover
4. Variable resistor


SBP00380

Air cleaner clogging sensor



SBP00381

FRONT WINDOW AUTO PULL-UP SYSTEM



SBP00382

1. Front window assembly
2. Bracket assembly (tension roller)
3. Right block (roller support)
4. Right geared cable
5. Right return cable
6. Controller
7. Control switch
8. Right lock assembly
9. Right tightening motor
10. Limit switch (front)
11. Right bracket assembly (slide link)
12. Harness
13. Right rail

14. Rear cover
15. Bracket (for motor mount)
16. Cable assembly
17. Motor assembly (for lifting)
18. Motor output shaft
19. Geared cable assembly
20. Spoiler cover
21. Limit switch (rear lock)
22. Rear lock
23. Left block (dovetail)
24. Left block (return cable guide)
25. Left block (return cable holder)
26. Left cover (return cable holder)

Function

- An electric motor is used for the front glass (top) of the operator's cab. This makes it possible to open, close, or tighten simply by operating the switch.

Operation

1. Opening front window

- 1) Press the UP control switch.
- 2) When left and right front locks (8) are actuated in the OPEN direction, front window (1) is moved to the LOWER position by slide link (11). When the release operation is completed, the movement of front lock (8) stops.
- 3) After the movement of front lock (8) has been completed, operate lift motor (17) to the OPEN direction. Geared cable (19), which is meshed with motor output shaft (18), will move and pull up front window (1).
- 4) Front window (1) is set at the OPEN position, and lift motor (17) stops operating at the point where rear lock (12) is engaged.

2. Closing front window

- 1) Press the DOWN control switch, and push the release lever of rear lock (22) at the same time.
- 2) Lift motor (17) moves in the CLOSE direction and moves front window (1) down.
- 3) When front window (1) has moved down fully, lift motor (17) stops.
- 4) When the movement of lift motor (17) has been completed, front locks (8) are moved in the tightening direction by left and right tightening motors (9). When the tightening is completed, the motor stops.

20 TESTING AND ADJUSTING

Standard value table for engine related parts ...	20- 2	Testing and adjusting hydraulic pressure in work equipment, swing, travel circuit.....	20- 31
Standard value table for chassis related parts ..	20- 3	Testing and adjusting TVC valve output pressure (servo piston input pressure)	20- 34
Standard value table for electrical parts	20-11	Testing and adjusting LS valve output pressure (servo piston input pressure) and LS differential pressure	20- 36
Tools for testing, adjusting, and troubleshooting	20-20	Testing and adjusting control pump circuit oil pressure	20- 39
Measuring engine speed	20-21	Testing solenoid valve output pressure	20- 41
Measuring exhaust color	20-22	Measuring PPC valve output pressure and testing PPC shuttle valve	20- 43
Adjusting valve clearance	20-23	Adjusting work equipment, swing PPC valve ..	20- 45
Measuring compression pressure	20-24	Testing travel deviation	20- 46
Measuring blow-by pressure	20-24	Testing locations causing hydraulic drift of work equipment	20- 47
Testing and adjusting fuel injection timing	20-25	Measuring oil leakage	20- 49
Measuring engine oil pressure	20-26	Releasing remaining pressure in hydraulic circuit	20- 51
Testing and adjusting alternator belt tension	20-27	Testing clearance of swing circle bearing	20- 52
Testing and adjusting water pump belt tension	20-27	Testing and adjusting track shoe tension.....	20- 53
Testing and adjusting belt tension for air conditioner compressor.....	20-28	Bleeding air	20- 54
Adjusting engine speed sensor	20-28	Troubleshooting	20-101
Measuring air supply pressure (boost pressure)	20-29		
Testing and adjusting governor motor lever stroke	20-30		

- ★ Note the following when making judgements using the standard value tables for testing, adjusting, or troubleshooting.
- 1. The standard value for a new machine given in the table is the value used when shipping the machine from the factory and is given for reference. It is used as a guideline for judging the progress of wear after the machine has been operated, and as a reference value when carrying out repairs.
- 2. The service limit value given in the tables is the estimated value for the shipped machine based on the results of various tests. It is used for reference together with the state of repair and the history of operation to judge if there is a failure.
- 3. These standard values are not the standards used in dealing with claims.

- ⚠ **When carrying out testing, adjusting, or troubleshooting, park the machine on level ground, inset the safety pins, and use blocks to prevent the machine from moving.**
- ⚠ **When carrying out work together with other workers, always use signals and do not let unauthorized people near the machine.**
- ⚠ **When checking the water level, always wait for the water to cool down. If the radiator cap is removed when the water is still hot, the water will spurt out and cause burns.**
- ⚠ **Be careful not to get caught in the fan, fan belt or other rotating parts.**


STANDARD VALUE TABLE FOR ENGINE RELATED PARTS

Applicable model			PC300, 350-6	
Engine			SAA6D108-2	
Item	Measurement conditions	Unit	Standard value for new machine	Service limit value
Engine speed	High idling	rpm	2,250 ± 50	2,250 ± 50
	Low idling		900 ⁺⁵⁰ ₀	900 ± 50
	Rated speed		2,050	—
Rated speed	Air supply pressure (boost pressure)	mmHg	900 – 1,100	900 – 1,100
Exhaust gas color	At sudden acceleration	Bosch index	Max. 5.5	7.5
	At high idling		Max. 1.5	2.5
Valve clearance (normal temperaure)	Intake valve	mm	0.34	—
	Exhaust valve		0.66	—
Compression pressure (SAE oil)	Oil temperature: 40 – 60°C Engine speed: 250 – 300rpm	MPa (kg/cm ²)	Min. 2.7 (28)	2.3 (23)
Blowby pressure (SAE oil)	(Water temperature: Operating range) At rated output	mmH ₂ O	Max. 150	300
Oil pressure	(Water temperature: Operating range) At high idling (SAE30)	MPa (kg/cm ²)	0.40 – 0.64 (4.0 – 6.5)	0.24 (2.4)
	At high idling (SAE10W)		—	—
	At low idling (SAE30)		Min. 0.1 (1.0)	0.08 (0.8)
	At low idling (SAE10W)		Min. 0.08 (0.8)	0.05 (0.5)
Oil temperature	Whole speed range (inside oil pan)	°C	80 – 110	120
Fuel injection timing	Before top dead center	(degree)	17 ± 0.75	17 ± 0.75
Belt tension	<i>Fan</i> Deflection when pressed with finger force of approx. 58.8N (6 kg)	Crankshaft pulley - alternator	3	6 – 10
		Fan pulley - water pump	3	6 – 10
		Crankshaft pulley - air conditioner compressor	15 – 18	15 – 18

020706

STANDARD VALUE TABLE FOR CHASSIS RELATED PARTS

★ The Standard value for new machine and Service limit value in the table below are all values when measured in the heavy-duty mode.

Applicable model				PC300, 350-6					
Category	Item	Measurement conditions	Unit	Standard value for new machine			Service limit value		
Engine speed	At 2-pump relief	- Engine water temperature: Within operating range - Hydraulic oil temperature: 45 – 55°C - Engine at full throttle - In H/O mode - Arm IN relief	rpm	When swing lock switch is OFF: 2,200 ± 100			When swing lock switch is OFF: 2,200 ± 100		
				When swing lock switch is ON: 2,100 ± 50			2,100 ± 100		
	At 2-pump relief + power max.	- Engine at full throttle - In H/O mode - Arm IN relief + power max. ON		2,030 ± 50			2,030 ± 100		
	Engine speed when auto-deceleration is actuated	- Auto-deceleration switch ON - Fuel control dial at MAX. - Control levers at neutral.		1,400 ± 100			1,400 ± 100		
Spool stroke	Boom Lo control valve		mm	ℓ	a	b	ℓ	a	b
	Boom Hi control valve								
	Arm Lo control valve								
	Arm Hi control valve								
	Bucket control valve			—	9.5 ± 0.5	9.5 ± 0.5	—	9.5 ± 0.5	9.5 ± 0.5
	Swing control valve								
	Left travel control valve								
	Right travel control valve								
Travel of control levers	Boom control lever	- Center of lever knob - Read max. value to end of travel - Engine stopped - Exclude play at neutral.	mm	85 ± 10			Max. 95 Min. 75		
	Arm control lever			85 ± 10			Max. 95 Min. 75		
	Bucket control lever			85 ± 10			Max. 95 Min. 75		
	Swing control lever			85 ± 10			Max. 95 Min. 75		
	Travel control lever			115 ± 12			Max. 127 Min. 103		
	Play of control lever	Work equipment, swing		Max. 10			Max. 15		
		Travel		Max. 20			Max. 30		

TESTING AND ADJUSTING





STANDARD VALUE TABLE FOR CHASSIS RELATED PARTS

Applicable model					PC300, 350-6			
Category	Item	Measurement conditions		Unit	Standard value for new machine	Service limit value		
Operating effort of control levers	Boom control lever	· Engine at full throttle · Oil temperature: 45 – 55°C · Fit push-pull scale to center of control lever knob or tip of pedal to measure · Measure max. value to end of travel		N (kg)	15.7 ± 3.9 (1.6 ± 0.4)	Max. 24.5 (2.5)		
	Arm control lever				15.7 ± 3.9 (1.6 ± 0.4)	Max. 24.5 (2.5)		
	Bucket control lever				12.8 ± 2.9 (1.3 ± 0.3)	Max. 21.6 (2.2)		
	Swing control lever				12.8 ± 2.9 (1.3 ± 0.3)	Max. 21.6 (2.2)		
	Travel control lever				Lever	24.5 ± 5.9 (2.5 ± 0.6)	Max. 39.2 (4.0)	
		Pedal	74.5 ± 18.6 (7.6 ± 1.9)	Max. 107.9 (11)				
Hydraulic pressure	Unload pressure	· Engine at full throttle · Oil temperature: 45 – 55°C · All levers at neutral · Pump outlet port pressure		MPa (kg/cm ²)	3.9 ± 1.0 (40 ± 10)	3.9 ± 1.0 (40 ± 10)		
	Boom	RAISE			33.8 ± 1.0 (345 ± 10)	34.8 ± 1.0 (355 ± 10)	Max. 35.8 (365) Min. 32.3 (330)	Max. 36.3 (370) Min. 33.3 (340)
		LOWER	At high-pressure setting		31.4 ± 1.5 (320 ± 15)	Max. 33.3 (340) Min. 29.4 (300)		
			At low-pressure setting		18.1 ± 1.0 (185 ± 10)	Max. 19.6 (200) Min. 16.7 (170)		
	Arm	· Oil temperature: 45 – 55°C · Engine at full throttle · In heavy-duty mode · Pump outlet port pressure · Relieve only circuit being measured ★ The values in [] are the values when using the power max.			33.8 ± 1.0 (345 ± 10)	34.8 ± 1.0 (355 ± 10)	Max. 35.8 (365) Min. 32.3 (330)	Max. 36.3 (370) Min. 33.3 (340)
	Bucket				33.8 ± 1.0 (345 ± 10)	34.8 ± 1.0 (355 ± 10)	Max. 35.8 (365) Min. 32.3 (330)	Max. 36.3 (370) Min. 33.3 (340)
	Swing				30.9 ^{+1.0} _{-1.5} (315 ⁺¹⁰ ₋₁₅)	Max. 32.3 (330) Min. 28.4 (290)		
	Left travel				34.8 ^{+2.0} _{-1.0} (355 ⁺²⁰ ₋₁₀)	Max. 37.2 (380) Min. 33.3 (340)		
	Right travel				34.8 ^{+2.0} _{-1.0} (355 ⁺²⁰ ₋₁₀)	Max. 37.2 (380) Min. 33.3 (340)		
	Control pump				2.9 ^{+0.6} ₀ (30 ⁺⁶ ₀)	Max. 3.5 (36) Min. 2.9 (30)		
	LS differential pressure	· Oil temperature: 45 – 55°C · Engine at full throttle · In heavy-duty mode ★ LS differential pressure = Pump outlet port pressure – LS pressure	All levers at neutral		3.9 ± 1.0 (40 ± 10)	3.9 ± 1.0 (40 ± 10)		
			Travel Hi under no load, travel lever at half-way position		2.5 ± 0.1 (25 ± 1)	2.5 ± 0.1 (25 ± 1)		

020706





TESTING AND ADJUSTING

STANDARD VALUE TABLE FOR CHASSIS RELATED PARTS

Applicable model				PC300, 350-6			
Category	Item	Measurement conditions	Unit	Standard value for new machine		Service limit value	
Swing	Overrun when stopping swing	Work equipment posture Max. reach  Empty BKP00102 - Engine at full throttle - Hydraulic oil temperature: 45 – 55°C - In H/O mode - Stop after swinging one turn and measure distance that swing circle moves	Deg.	PC300	PC350	PC300	PC350
				Max. 110	Max. 120	Max. 140	Max. 150
	Time taken to start swing	Work equipment posture Max. reach  Empty BKP00326 - Engine at full throttle - Hydraulic oil temperature: 45 – 55°C - In H/O mode - Time taken to swing 90° and 180° from starting position	90°	3.6 ± 0.4		Max. 4.5	
			180°	5.1 ± 0.5		Max. 6.1	
	Time taken to swing	Work equipment posture Max. reach  Empty BKP00102 - Engine at full throttle - Hydraulic oil temperature: 45 – 55°C - In H/O mode - Swing one turn, then measure time taken to swing next 5 turns	Sec	30 ± 1.5		Max. 35	
	Hydraulic drift of swing	 BKP00103 - Engine stopped - Hydraulic oil temperature: 45 – 55°C - Set machine on 15° slope, and set upper structure at 90° to the side. - Make match marks on swing circle outer race and track frame. - Measure distance that match marks move apart after 5 minutes.	mm	0		0	
	Leakage from swing motor	- Engine at full throttle - Hydraulic oil temperature: 45 – 55°C - Swing lock switch ON - Relieve swing circuit.	ℓ/min	Max. 5.5		Max. 11	

TESTING AND ADJUSTING




STANDARD VALUE TABLE FOR CHASSIS RELATED PARTS

Applicable model					PC300, 350-6			
Category	Item	Measurement conditions		Unit	Standard value for new machine		Service limit value	
Travel	Travel speed (1)	 - Engine at full throttle - Hydraulic oil temperature: 45 – 55°C - In H/O mode - Raise track on one side at a time, rotate one turn, then measure time taken for next 5 turns with no load.	Travel speed	Sec	STD	LC	STD	LC
			Lo		47.5 ± 5.5	50.7 ± 5.9	42.0 – 58.5	44.8 – 62.5
			Mi		39.0 ± 4.0	41.6 ± 4.3	35.0 – 47.0	37.3 – 49.9
			Hi		32.0 ± 3.5	34.1 ± 3.7	28.5 – 39.0	30.4 – 41.5
	Travel speed (2)	 - Engine at full throttle - Hydraulic oil temperature: 45 – 55°C - In H/O mode - Run up for at least 10 m, and measure time taken to travel next 20 m on flat ground.	Lo		19.5 ± 3.0		16.5 – 25.5	
			Mi		16.0 ± 2.0		14.0 – 20.0	
			Hi		13.1 ± 1.0		12.1 – 15.1	
	Travel deviation	 - Engine at full throttle - Hydraulic oil temperature: 45 – 55°C - In H/O mode - Travel speed : Hi - Run up for at least 10 m, and measure deviation when traveling next 20 m on flat ground. ★ Use a hard horizontal surface.  ★ Measure dimension x.		mm	Max. 200		Max. 300	

020706






TESTING AND ADJUSTING

STANDARD VALUE TABLE FOR CHASSIS RELATED PARTS

Applicable model				PC300, 350-6			
Category	Item	Measurement conditions	Unit	Standard value for new machine		Service limit value	
Travel	Hydraulic drift of travel	 BKP00108 - Engine stopped - Hydraulic oil temperature: 45 – 55°C - Stop machine on 12° slope with sprocket facing straight up the slope. - Measure the distance the machine moves in 5 minutes.	mm	0		0	
	Leakage of travel motor	 Lock pin BKP00109 - Engine at full throttle - Hydraulic oil temperature: 45 – 55°C - Lock shoes and relieve travel circuit.	ℓ/mm	Max. 15		Max. 30	
Work equipment	Hydraulic drift of work equipment	Posture for measurement	mm	PC300	PC350	PC300	PC350
		 BKP00110		Max. 450	Max. 550	Max. 675	Max. 825
		- Place in above posture and measure extension or retraction of each cylinder and downward movement at tip of bucket teeth. - Bucket: Rated load 21.2 kN (2160 kg) - Horizontal, flat ground - Levers at neutral - Engine stopped - Hydraulic oil temperature: 45 – 55°C - Start measuring immediately after setting. - Measure hydraulic drift every 5 minutes, and judge from results for 15 minutes.		Max. 25	Max. 30	Max. 38	Max. 45
				Max. 135	Max. 165	Max. 203	Max. 248
	Bucket cylinder (amount of retraction of cylinder)			Max. 20	Max. 25	Max. 30	Max. 38

TESTING AND ADJUSTING



STANDARD VALUE TABLE FOR CHASSIS RELATED PARTS

Applicable model					PC300, 350-6			
Category	Item	Measurement conditions		Unit	Standard value for new machine		Service limit value	
Work equipment	Work equipment speed	Boom Bucket teeth in contact with ground ↕ Cylinder fully extended	 Empty BKP00111	RAISE	3.9 ± 0.4		Max. 4.7	
			· Engine at full throttle · Hydraulic oil temperature: 45 – 55°C · In H/O mode	LOWER	3.0 ± 0.3		Max. 3.5	
		Arm Cylinder fully retracted ↕ Fully extended	 Empty BKP00112	IN	PC300	PC350	PC300	PC350
			· Engine at full throttle · Hydraulic oil temperature: 45 – 55°C · In H/O mode	OUT	3.9 ± 0.4	4.4 ± 0.4	Max. 4.6	Max. 5.2
		Bucket Cylinder fully retracted ↕ Fully extended	 Empty BKP00113	CURL	3.2 ± 0.3		Max. 3.8	
			· Engine at full throttle · Hydraulic oil temperature: 45 – 55°C · In H/O mode	DUMP	2.3 ± 0.3		Max. 2.9	
	Time lag	Boom	 BKP00114	Sec	Max. 3.0		Max. 3.6	
		Arm	 BKP00115		Max. 3.0		Max. 3.6	
			· Lower boom and measure time taken from point where bucket contacts ground to point where chassis rises from ground · Engine at low idling · Hydraulic oil temperature: 45 – 55°C					
			· Stop arm suddenly and measure time taken for arm to stop · Engine at low idling · Hydraulic oil temperature: 45 – 55°C					

020706

TESTING AND ADJUSTING

STANDARD VALUE TABLE FOR CHASSIS RELATED PARTS

Applicable model				PC300, 350-6	
Category	Item	Measurement conditions	Unit	Standard value for new machine	Service limit value
Work equipment	Time lag	 · Stop bucket suddenly and measure time taken for bucket to stop at bottom and then start again · Engine at low idling · Hydraulic oil temperature: 45 – 55°C	Sec	Max. 3.0	Max. 5.0
	Internal leakage				
	Cylinders	· Hydraulic oil temperature: 45 – 55°C · Engine at full throttle · Relieve circuit to be measured	cc/min	Max. 4.5	Max. 20
	Center swivel joint			Max. 10	Max. 50
Performance in compound operation	Travel deviation when work equipment + travel are operated	· Hydraulic oil temperature: 45 – 55°C ★ Use a hard horizontal surface. ★ Measure dimension x.  · Oil temperature: 45 – 55°C	mm	Max. 400	Max. 440
Performance of hydraulic pump	Hydraulic pump delivery				
	Control pump	· Measure with engine at rated speed · At relief valve set pressure (3.1 MPa (32 kg/cm²)) See next page	ℓ/min	Max. 35.0	Max. 31.5
	Piston pump	See next page		See next page	

020706


TESTING AND ADJUSTING

STANDARD VALUE TABLE FOR CHASSIS RELATED PARTS

Category

PC300,350: Discharge amount of main piston pump (in H/O mode)

Performance of hydraulic pump



$$\text{Pump discharge amount} = \frac{P_1 + P_2}{0.2} \text{ (MPa)} \quad \left(\frac{P_1 + P_2}{2} \text{ (kg/cm}^2\text{)} \right)$$

(MPa (kg/cm²))

BKP00117

· Pump speed: At 2050 rpm, TVC current 180 mA

Check point	Test pump discharge pressure (MPa (kg/cm²))	Discharge pressure of other pump (MPa (kg/cm²))	Average pressure (MPa (kg/cm²))	Standard value for discharge amount Q (l/min)	Judgement standard lower limit Q (l/min)
As desired	P1	P2	$\frac{P_1 + P_2}{0.2}$ $\frac{P_1 + P_2}{2}$	See graph	See graph

- ★ As far as possible, bring pump discharge pressures P1 and P2 as close as possible to the average pressure when measuring.
The error is large near the point where the graph curves, so avoid measuring at this point.
- ★ When measuring with the pump mounted on the machine, if it is impossible to set the engine speed to the specified speed with the fuel control dial, take the pump discharge amount and the engine speed at the point of measurement, and use them as a base for calculating the pump discharge amount at the specified speed.

020706

STANDARD VALUE TABLE FOR ELECTRICAL PARTS

Sys-tem	Name of component	Connector No.	Inspection method	Judgment table	Measurement conditions										
Control system	Fuel control dial	E06 (male)	Measure resistance	If the condition is within the range shown in the table below, it is normal <table><tr><td>Between (1) – (2)</td><td>0.25 – 7 kΩ</td></tr><tr><td>Between (2) – (3)</td><td>0.25 – 7 kΩ</td></tr><tr><td>Between (1) – (3)</td><td>4 – 6 kΩ</td></tr></table>	Between (1) – (2)	0.25 – 7 kΩ	Between (2) – (3)	0.25 – 7 kΩ	Between (1) – (3)	4 – 6 kΩ	1) Turn starting switch OFF. 2) Disconnect connector.				
	Between (1) – (2)	0.25 – 7 kΩ													
	Between (2) – (3)	0.25 – 7 kΩ													
	Between (1) – (3)	4 – 6 kΩ													
	Governor motor	Potentiometer	E04 (male)	Measure resistance	If the condition is within the range shown in the table below, it is normal <table><tr><td>Between (1) – (2)</td><td>0.25 – 7 kΩ</td></tr><tr><td>Between (2) – (3)</td><td>0.25 – 7 kΩ</td></tr><tr><td>Between (1) – (3)</td><td>4 – 6 kΩ</td></tr></table>	Between (1) – (2)	0.25 – 7 kΩ	Between (2) – (3)	0.25 – 7 kΩ	Between (1) – (3)	4 – 6 kΩ	1) Turn starting switch OFF. 2) Disconnect connector.			
		Between (1) – (2)	0.25 – 7 kΩ												
		Between (2) – (3)	0.25 – 7 kΩ												
		Between (1) – (3)	4 – 6 kΩ												
	Motor	E05 (male)	Measure resistance	If the condition is as shown in the table below, it is normal <table><tr><td>Between (1) – (2)</td><td>2.5 – 7.5 Ω</td></tr><tr><td>Between (3) – (4)</td><td>2.5 – 7.5 Ω</td></tr><tr><td>Between (1) – (3)</td><td>No continuity</td></tr><tr><td>Between (1) – chassis</td><td>No continuity</td></tr><tr><td>Between (3) – chassis</td><td>No continuity</td></tr></table>	Between (1) – (2)	2.5 – 7.5 Ω	Between (3) – (4)	2.5 – 7.5 Ω	Between (1) – (3)	No continuity	Between (1) – chassis	No continuity	Between (3) – chassis	No continuity	1) Turn starting switch OFF. 2) Disconnect connector.
				Between (1) – (2)	2.5 – 7.5 Ω										
Between (3) – (4)				2.5 – 7.5 Ω											
Between (1) – (3)				No continuity											
Between (1) – chassis				No continuity											
Between (3) – chassis	No continuity														
Engine speed sensor	E07	Measure resistance	If the condition is within the range shown in the table below, it is normal <table><tr><td>Between(male) (1) – (2)</td><td>500 – 1,000 Ω</td></tr><tr><td>Between(male) (2) – chassis</td><td>Min. 1 MΩ</td></tr></table>	Between(male) (1) – (2)	500 – 1,000 Ω	Between(male) (2) – chassis	Min. 1 MΩ	1) Turn starting switch OFF. 2) Disconnect connector.							
		Between(male) (1) – (2)	500 – 1,000 Ω												
		Between(male) (2) – chassis	Min. 1 MΩ												
Measure voltage	Measure with AC range <table><tr><td>Between (1) – (2)</td><td>0.5 – 3.0 V</td></tr></table>	Between (1) – (2)	0.5 – 3.0 V	1) Start engine. 2) Insert T – adapter.											
Between (1) – (2)	0.5 – 3.0 V														
		Adjust	1) Screw in rotation sensor until it contacts ring gear, then turn back 1 ± 1/6 turns. 2) It must work normally when adjusted as above.												
PPC oil pressure switch	Travel S01 boom RAISE S02 arm OUT S03 boom LOWER S04 arm IN S05 bucket CURL S06 bucket DUMP S07 swing S08	Measure resistance	If the condition is as shown in the table below, it is normal When boom, arm, and bucket levers are operated <table><tr><td rowspan="2">Between (male) (1) – (2)</td><td>All levers at neutral</td><td>Min. 1 MΩ</td></tr><tr><td>Levers operated</td><td>Max. 1 Ω</td></tr></table> Between (male) (1),(2) - chassis Min. 1 MΩ	Between (male) (1) – (2)	All levers at neutral	Min. 1 MΩ	Levers operated	Max. 1 Ω	1) Start engine (or with engine stopped and accumulator charged) 2) Disconnect connectors S01 – S08.						
Between (male) (1) – (2)	All levers at neutral	Min. 1 MΩ													
	Levers operated	Max. 1 Ω													

TESTING AND ADJUSTING

STANDARD VALUE TABLE FOR ELECTRICAL PARTS

System	Name of component	Connector No.	Inspection method	Judgment table	Measurement conditions								
Control system	Pump pressure sensor	C07 (male) (rear) C08 (male) (front)	Measure voltage	If the condition is as shown in the table below, it is normal <table><tr><td colspan="2">Between (2) – (1)</td><td>18 – 28 V</td></tr><tr><td rowspan="2">Between (3) – (1)</td><td>All levers at neutral</td><td>0.5 – 1.5 V</td></tr><tr><td>At arm IN relief</td><td>3.1 – 4.5 V</td></tr></table>	Between (2) – (1)		18 – 28 V	Between (3) – (1)	All levers at neutral	0.5 – 1.5 V	At arm IN relief	3.1 – 4.5 V	1) Start engine. 2) Turn fuel control dial to MAX position. 3) Insert T – adapter.
	Between (2) – (1)		18 – 28 V										
	Between (3) – (1)	All levers at neutral	0.5 – 1.5 V										
		At arm IN relief	3.1 – 4.5 V										
	Swing lock switch	X05 (female)	Measure resistance	If the condition is as shown in the table below, it is normal <table><tr><td rowspan="2">Between (1) – (2) Between (3) – (4)</td><td>When switch is OFF</td><td>Min. 1 MΩ</td></tr><tr><td>When switch is ON</td><td>Max. 1 Ω</td></tr></table>	Between (1) – (2) Between (3) – (4)	When switch is OFF	Min. 1 MΩ	When switch is ON	Max. 1 Ω	1) Turn starting switch OFF. 2) Disconnect connector C02.			
	Between (1) – (2) Between (3) – (4)	When switch is OFF	Min. 1 MΩ										
		When switch is ON	Max. 1 Ω										
	TVC solenoid valve	C04 (male) C13 (male)	Measure resistance	If the condition is within the range shown in the table below, it is normal <table><tr><td>Between (1) – (2)</td><td>10 – 22 Ω</td></tr><tr><td>Between(1), (2) – chassis</td><td>Min. 1 MΩ</td></tr></table>	Between (1) – (2)	10 – 22 Ω	Between(1), (2) – chassis	Min. 1 MΩ	1) Turn TVC prolix switch OFF. 2) Turn starting switch OFF. 3) Disconnect connectors C04, C13.				
Between (1) – (2)	10 – 22 Ω												
Between(1), (2) – chassis	Min. 1 MΩ												
Swing holding brake solenoid valve	V04 (male)	Measure resistance	If the condition is within the range shown in the table below, it is normal <table><tr><td>Between (1) – (2)</td><td>20 – 60 Ω</td></tr><tr><td>Between(1), (2) – chassis</td><td>Min. 1 MΩ</td></tr></table>	Between (1) – (2)	20 – 60 Ω	Between(1), (2) – chassis	Min. 1 MΩ	1) Turn starting switch OFF. 2) Disconnect connector V04.					
Between (1) – (2)	20 – 60 Ω												
Between(1), (2) – chassis	Min. 1 MΩ												
Travel speed solenoid valve	V06 (male)	Measure resistance	If the condition is within the range shown in the table below, it is normal <table><tr><td>Between (1) – (2)</td><td>20 – 60 Ω</td></tr><tr><td>Between(1), (2) – chassis</td><td>Min. 1 MΩ</td></tr></table>	Between (1) – (2)	20 – 60 Ω	Between(1), (2) – chassis	Min. 1 MΩ	1) Turn starting switch OFF. 2) Disconnect connector V06.					
Between (1) – (2)	20 – 60 Ω												
Between(1), (2) – chassis	Min. 1 MΩ												
LS select solenoid valve	V02 (male)	Measure resistance	If the condition is within the range shown in the table below, it is normal <table><tr><td>Between (1) – (2)</td><td>20 – 60 Ω</td></tr><tr><td>Between(1), (2) – chassis</td><td>Min. 1 MΩ</td></tr></table>	Between (1) – (2)	20 – 60 Ω	Between(1), (2) – chassis	Min. 1 MΩ	1) Turn starting switch OFF. 2) Disconnect connector V02.					
Between (1) – (2)	20 – 60 Ω												
Between(1), (2) – chassis	Min. 1 MΩ												
Pump merge/divider solenoid valve	V03 (male)	Measure resistance	If the condition is within the range shown in the table below, it is normal <table><tr><td>Between (1) – (2)</td><td>20 – 60 Ω</td></tr><tr><td>Between(1), (2) – chassis</td><td>Min. 1 MΩ</td></tr></table>	Between (1) – (2)	20 – 60 Ω	Between(1), (2) – chassis	Min. 1 MΩ	1) Turn starting switch OFF. 2) Disconnect connector V03.					
Between (1) – (2)	20 – 60 Ω												
Between(1), (2) – chassis	Min. 1 MΩ												
Machine push-up solenoid valve (governor, pump controller does not carry out control)	V05 (male)	Measure resistance	If the condition is within the range shown in the table below, it is normal <table><tr><td>Between (1) – (2)</td><td>20 – 60 Ω</td></tr><tr><td>Between(1), (2) – chassis</td><td>Min. 1 MΩ</td></tr></table>	Between (1) – (2)	20 – 60 Ω	Between(1), (2) – chassis	Min. 1 MΩ	1) Turn starting switch OFF. 2) Disconnect connector V05.					
Between (1) – (2)	20 – 60 Ω												
Between(1), (2) – chassis	Min. 1 MΩ												

020706

TESTING AND ADJUSTING

STANDARD VALUE TABLE FOR ELECTRICAL PARTS

System	Name of component	Connector No.	Inspection method	Judgment table	Measurement conditions		
Control system	LS-EPC solenoid	C10 (male)	Measure resistance	If the condition is within the range shown in the table below, it is normal	1) Turn starting switch OFF. 2) Disconnect connector C10.		
				Between (1) - (2)		7 - 14 Ω	
				Between(1), (2) - chassis		Min. 1 MΩ	
	Governor, pump controller	Power source voltage	C01 C02	Measure voltage	If the condition is within the range shown in the table below, it is normal	1) Turn starting switch ON. 2) Insert T - adapter.	
					Between C01 (7),(13) - (6),(12)		20 - 30 V
					Between C02 (11),(21) - (6),(12)		20 - 30 V
		Fuel control dial	C03	Measure voltage	If the condition is as shown in the table below, it is normal	1) Turn starting switch ON. 2) Insert T - adapter.	
					Between (7) - (17) (power source)		4.75 - 5.25 V
Between (4) - (17) (low idling)					4.0 - 4.75 V		
Governor potentiometer		C03	Measure voltage	Between (4) - (17) (high idling)	0.25 - 1.0 V		
	If the condition is as shown in the table below, it is normal			1) Turn starting switch ON. 2) Insert T - adapter.			
	Between (14) - (17) (low idling)				2.9 - 3.3 V		
Coolant temperature sensor	P07 (male)	Measure resistance	Between (14) - (17) (high idling)		0.5 - 0.9 V		
			Between (7) - (17) (power source)	4.75 - 5.25 V			
			If the condition is as shown in the table below, it is normal	1) Turn starting switch OFF. 2) Disconnect connector P07. 3) Insert T - adapter. into connector at sensor end.			
Governor motor	C02	Measure voltage	Normal temperature (25°C)		Approx. 37 - 50 kΩ		
			100°C		Approx. 3.5 - 4.0 kΩ		
			If the condition is within the range shown in the table below, it is normal	1) Turn starting switch ON. 2) Insert T - adapter.			
Battery relay	C01	Measure voltage	Between (2) - (3)		1.8 - 4.6 V		
			Between (4) - (5)		1.8 - 4.6 V		
			If the condition is within the range shown in the table below, it is normal	1) Turn starting switch ON. 2) Insert T - adapter.			
Between (1) - (6)	20 - 30 V						
					★ This is only for 2.5 sec after the starting switch is operated ON → OFF; at other times it must be 0 V.		

TESTING AND ADJUSTING

STANDARD VALUE TABLE FOR ELECTRICAL PARTS

System	Name of component	Connector No.	Inspection method	Judgment table	Measurement conditions						
Control system	Governor, pump controller	Swing holding brake solenoid	C01	Measure voltage	If the condition is as shown in the table below, it is normal <table><tr><td>When either swing or work equipment control lever is operated (solenoid ON, swing holding brake canceled)</td><td rowspan="2">Between (3) – (6),(12)</td><td>20 – 30 V</td></tr><tr><td>Approx. 5 sec after swing lever and work equipment control levers are placed at neutral (solenoid OFF, swing holding brake applied)</td><td>0 – 3 V</td></tr></table>	When either swing or work equipment control lever is operated (solenoid ON, swing holding brake canceled)	Between (3) – (6),(12)	20 – 30 V	Approx. 5 sec after swing lever and work equipment control levers are placed at neutral (solenoid OFF, swing holding brake applied)	0 – 3 V	1) Start engine. 2) Turn swing lock switch OFF. 3) Turn swing lock solenoid switch OFF. 4) Insert T – adapter. ★ The lever can be operated slightly (without moving the equipment).
		When either swing or work equipment control lever is operated (solenoid ON, swing holding brake canceled)	Between (3) – (6),(12)	20 – 30 V							
		Approx. 5 sec after swing lever and work equipment control levers are placed at neutral (solenoid OFF, swing holding brake applied)		0 – 3 V							
		Travel speed solenoid	C01	Measure voltage	If the condition is as shown in the table below, it is normal <table><tr><td>With travel speed switch at Hi or Mi (solenoid ON, travel motor swash plate angle MIN)</td><td rowspan="2">Between (9) – (6),(12)</td><td>20 – 30 V</td></tr><tr><td>When travel speed switch is at Lo (solenoid OFF, travel motor swash plate angle MAX)</td><td>0 – 3 V</td></tr></table>	With travel speed switch at Hi or Mi (solenoid ON, travel motor swash plate angle MIN)	Between (9) – (6),(12)	20 – 30 V	When travel speed switch is at Lo (solenoid OFF, travel motor swash plate angle MAX)	0 – 3 V	1) Start engine. 2) Insert T – adapter. 3) Turn fuel control dial to MAX position. 4) Operate the lever slightly not enough to move the machine. To check that the solenoid is OFF, measure with the fuel control dial at LOW (1200 rpm or below)
With travel speed switch at Hi or Mi (solenoid ON, travel motor swash plate angle MIN)	Between (9) – (6),(12)	20 – 30 V									
When travel speed switch is at Lo (solenoid OFF, travel motor swash plate angle MAX)		0 – 3 V									
LS select solenoid	C01	Measure voltage	If the condition is as shown in the table below, it is normal <table><tr><td>When swing lock switch is OFF, and swing + travel levers are operated simultaneously (solenoid ON, LS divided)</td><td rowspan="2">Between (8) – (6),(12)</td><td>20 – 30 V</td></tr><tr><td>When swing lock switch is ON (solenoid OFF, LS not divided)</td><td>0 – 3 V</td></tr></table>	When swing lock switch is OFF, and swing + travel levers are operated simultaneously (solenoid ON, LS divided)	Between (8) – (6),(12)	20 – 30 V	When swing lock switch is ON (solenoid OFF, LS not divided)	0 – 3 V	1) Turn starting switch ON. 2) Insert T – adapter. ★ The lever can be operated slightly (without moving the equipment).		
When swing lock switch is OFF, and swing + travel levers are operated simultaneously (solenoid ON, LS divided)	Between (8) – (6),(12)	20 – 30 V									
When swing lock switch is ON (solenoid OFF, LS not divided)		0 – 3 V									
Pump merge/divider valve solenoid	C01	Measure voltage	If the condition is as shown in the table below, it is normal. <table><tr><td>When travel is operated independently (solenoid ON, divided)</td><td rowspan="2">Between (2) – (6),(12)</td><td>20 – 30 V</td></tr><tr><td>When levers and pedals are at neutral (solenoid OFF, merged)</td><td>0 – 3 V</td></tr></table>	When travel is operated independently (solenoid ON, divided)	Between (2) – (6),(12)	20 – 30 V	When levers and pedals are at neutral (solenoid OFF, merged)	0 – 3 V	1) Turn starting switch ON. 2) Insert T – adapter. ★ The lever can be operated slightly (without moving the equipment).		
When travel is operated independently (solenoid ON, divided)	Between (2) – (6),(12)	20 – 30 V									
When levers and pedals are at neutral (solenoid OFF, merged)		0 – 3 V									

020706







TESTING AND ADJUSTING

STANDARD VALUE TABLE FOR ELECTRICAL PARTS

System	Name of component	Connector No.	Inspection method	Judgment table	Measurement conditions	
Control system	Governor, pump controller	TVC solenoid valve (default value)	C02	Measure current	If the condition is as shown in the table below, it is normal · H/O mode	1) Turn starting switch ON. 2) Turn fuel control dial to MAX position 3) Turn prolix switch OFF.
				Between front (8) – (18)	520 ± 80 mA	
			Between rear (9) – (19)			
		LS-EPC solenoid valve (default value)	C02	Measure current	If the condition is as shown in the table below, it is normal · H/O mode	1) Turn starting switch ON. 2) Turn fuel control dial to MAX position 3) All levers at neutral.
				Between (7) – (17)	900 ± 80 mA	
		L.H. knob switch	C03	Measure voltage	If the condition is as shown in the table below, it is normal	1) Turn starting switch ON. 2) Insert T – adapter.
				When switch is ON	Between (9) – GND	20 – 28 V
		When switch is OFF	0 – 1 V			
	S-NET	C17	Measure voltage	If the condition is as shown in the table below, it is normal	1) Turn starting switch ON. 2) Insert T – adapter.	
		Between (4),(12) – GND	4 – 8 V			
	Kerosene mode	C17	Measure voltage	If the condition is as shown in the table below, it is normal	1) Turn starting switch ON. 2) Insert T – adapter.	
			Standard mode	Between (15) – GND	20 – 28 V	
		Kerosene mode	0 – 2 V			
	No. 2 throttle signal	Monitoring code 16	Engine speed	If the condition is as shown in the table below, it is normal	High idling (rpm)	1) Start engine. 2) Set monitoring code to 10 or 16 (command value). 3) Operate working mode switch and L.H. knob switch.
			H/O	Approx. 2250		
			G/O	Approx. 2050 (during operation) Approx. 1900 (idling)		
			F/O	Approx. 1900		
			L/O	Approx. 1700		
			Power max. (H/O) (G/O)	Approx. 2250		
			Swift slow-down (H/O) (G/O)	Approx. 1700		
	Model selection	C17 – C02	Continuity	If the condition is as shown in the table below, it is normal		1) Turn starting switch OFF. 2) Disconnect connector. 3) Connect T – adapter to wiring harness end.
			Between selection 1	C17(5) – C02(11)	No continuity	
			Between selection 2	C17(13) – C02(11)	Continuity	
			Between selection 3	C17(6) – C02(11)	Continuity	
			Between selection 4	C17(14) – C02(11)	No continuity	
			Between selection 5	C17(7) – C02(11)	No continuity	

TESTING AND ADJUSTING














STANDARD VALUE TABLE FOR ELECTRICAL PARTS

System	Name of component	Connector No.	Inspection method	Judgment table	Measurement conditions					
Monitor	Air cleaner clogging sensor	P11 (male) P12 (female)	Continuity	If the condition is as shown in the table below, it is normal <table><tr><td>Air cleaner normal</td><td rowspan="2">Between P11 – P12</td><td>Continuity</td></tr><tr><td>Air cleaner clogged</td><td>No continuity</td></tr></table>	Air cleaner normal	Between P11 – P12	Continuity	Air cleaner clogged	No continuity	1) Start engine. 2) Disconnect P11, P12.
	Air cleaner normal	Between P11 – P12	Continuity							
	Air cleaner clogged		No continuity							
	Engine speed sensor	E07	Measure resistance	If the condition is within the range shown in the table below, it is normal <table><tr><td>Between (1) – (2)</td><td>500 – 1000 Ω</td></tr><tr><td>Between(2) – chassis</td><td>Min. 1 MΩ</td></tr></table>	Between (1) – (2)	500 – 1000 Ω	Between(2) – chassis	Min. 1 MΩ	1) Turn starting switch OFF. 3) Disconnect connector.	
			Between (1) – (2)	500 – 1000 Ω						
			Between(2) – chassis	Min. 1 MΩ						
Measure voltage	Measure with AC range	1) Start engine. 2) Insert T – adapter.								
		Adjust	1) Screw in rotation sensor until it contacts ring gear, then turn back 1 ± 1/6 turns 2) It must work normally when adjusted as above.							
Coolant level sensor	P08 (male)	Measure resistance	If the condition is as shown in the table below, it is normal <table><tr><td>Above LOW level in sub-tank</td><td>Max. 1 Ω</td></tr><tr><td>Below LOW level in sub-tank</td><td>Min. 1 MΩ</td></tr></table>	Above LOW level in sub-tank	Max. 1 Ω	Below LOW level in sub-tank	Min. 1 MΩ	1) Turn starting switch OFF. 2) Disconnect connector P08. 3) Insert T – adapter into connector at sensor end.		
Above LOW level in sub-tank	Max. 1 Ω									
Below LOW level in sub-tank	Min. 1 MΩ									
Engine oil level sensor	P05 (male)	Measure resistance	If the condition is as shown in the table below, it is normal <table><tr><td> Raise float BLP00002 </td><td>Max. 1 Ω</td></tr><tr><td> Lower float BLP00003 </td><td>Min. 1 MΩ</td></tr></table>	 Raise float BLP00002	Max. 1 Ω	 Lower float BLP00003	Min. 1 MΩ	1) Turn starting switch OFF. 2) Disconnect connector P05. 3) Drain oil, then remove sensor.		
 Raise float BLP00002	Max. 1 Ω									
 Lower float BLP00003	Min. 1 MΩ									
Coolant temperature sensor	P07 (male)	Measure resistance	If the condition is as shown in the table below, it is normal <table><tr><td>Normal temperature (25°C)</td><td>Approx. 37 – 50 kΩ</td></tr><tr><td>100°C</td><td>Approx. 3.5 – 4.0 kΩ</td></tr></table>	Normal temperature (25°C)	Approx. 37 – 50 kΩ	100°C	Approx. 3.5 – 4.0 kΩ	1) Turn starting switch OFF. 2) Disconnect connector P07. 3) Insert T – adapter into connector at sensor end.		
Normal temperature (25°C)	Approx. 37 – 50 kΩ									
100°C	Approx. 3.5 – 4.0 kΩ									

020706

TESTING AND ADJUSTING

STANDARD VALUE TABLE FOR ELECTRICAL PARTS

System	Name of component	Connector No.	Inspection method	Judgment table	Measurement conditions								
Monitor	Engine oil pressure sensor	—	Measure resistance	If the condition is as shown in the table below, it is normal Low pressure end <table><tr><td>Engine oil pressure above 0.07 MPa (0.7 kg/cm²)</td><td>Min. 1M Ω</td></tr><tr><td>Engine oil pressure below 0.03 MPa (0.3 kg/cm²)</td><td>Max. 1 Ω</td></tr></table> High pressure end <table><tr><td>Engine oil pressure above 0.17 MPa (1.7 kg/cm²)</td><td>Min. 1M Ω</td></tr><tr><td>Engine oil pressure below 0.13 MPa (1.3 kg/cm²)</td><td>Max. 1 Ω</td></tr></table>	Engine oil pressure above 0.07 MPa (0.7 kg/cm ²)	Min. 1M Ω	Engine oil pressure below 0.03 MPa (0.3 kg/cm ²)	Max. 1 Ω	Engine oil pressure above 0.17 MPa (1.7 kg/cm ²)	Min. 1M Ω	Engine oil pressure below 0.13 MPa (1.3 kg/cm ²)	Max. 1 Ω	1) Install oil pressure measurement gauge. 2) Remove wiring harness terminal. 3) Start engine. 4) Put tester in contact between sensor terminal screw and chassis.
	Engine oil pressure above 0.07 MPa (0.7 kg/cm ²)	Min. 1M Ω											
	Engine oil pressure below 0.03 MPa (0.3 kg/cm ²)	Max. 1 Ω											
	Engine oil pressure above 0.17 MPa (1.7 kg/cm ²)	Min. 1M Ω											
Engine oil pressure below 0.13 MPa (1.3 kg/cm ²)	Max. 1 Ω												
Fuel level sensor	P06 (male)	Measure resistance	If the condition is as shown in the table below, it is normal <table><tr><td> Raise float to stopper BLP00004</td><td>Approx. 12 Ω or below</td></tr><tr><td> Lower float to stopper BLP00005</td><td>Approx. 85 – 110 Ω</td></tr></table>	 Raise float to stopper BLP00004	Approx. 12 Ω or below	 Lower float to stopper BLP00005	Approx. 85 – 110 Ω	1) Turn starting switch OFF. 2) Disconnect connector P06. 3) Drain fuel, then remove sensor. 4) Insert T – adapter into sensor. ★ Connect the T – adapter to the connector and sensor flange.					
 Raise float to stopper BLP00004	Approx. 12 Ω or below												
 Lower float to stopper BLP00005	Approx. 85 – 110 Ω												
Hydraulic oil level sensor	P09 (male)	Measure resistance	If the condition is as shown in the table below, it is normal <table><tr><td> Raise float BLP00002</td><td>Max. 1 Ω</td></tr><tr><td> Lower float BLP00003</td><td>Min. 1 MΩ</td></tr></table>	 Raise float BLP00002	Max. 1 Ω	 Lower float BLP00003	Min. 1 MΩ	1) Turn starting switch OFF. 2) Disconnect connector P09. 3) Drain oil, then remove sensor. 4) Insert T – adapter into sensor.					
 Raise float BLP00002	Max. 1 Ω												
 Lower float BLP00003	Min. 1 MΩ												
Air cleaner clogging sensor	P11 P12	Measure resistance	If the condition is as shown in the table below, it is normal <table><tr><td>Air cleaner normal</td><td>Continuity</td></tr><tr><td>Air cleaner clogged</td><td>No continuity</td></tr></table>  BLP00006	Air cleaner normal	Continuity	Air cleaner clogged	No continuity	1) Start engine. 2) Disconnect P11, P12. 3) Put tester in contact with connector at sensor end to measure.					
Air cleaner normal	Continuity												
Air cleaner clogged	No continuity												

TESTING AND ADJUSTING

STANDARD VALUE TABLE FOR ELECTRICAL PARTS

Name of component	Connector No.	Inspection method	Judgment table	Measurement conditions																																												
Alternator	Between alternator terminal R and chassis	Measure voltage	When engine is running (1/2 throttle or above) below, the sensor is defective. →27.5 – 29.5 V ★ If the battery is old, or after starting in cold areas, the voltage may not rise for some time.	1) Start engine.																																												
Gauges	<table><tr><td rowspan="2"></td><td colspan="2">Position of gauge display</td><td>Display level resistance kΩ (Monitor panel input resistance)</td></tr><tr><td colspan="2">Starting switch ON</td><td>Starting switch OFF</td></tr><tr><td rowspan="17">Measure resistance between coolant temperature gauge C03 (female) (1) – C03 (female) (16)</td><td rowspan="5">Right side</td><td>All OFF(15)</td><td>Min. – Max. – 0.646</td></tr><tr><td>14</td><td>0.575 – 3.420</td></tr><tr><td>13</td><td>3.156 – 3.708</td></tr><tr><td>12</td><td>3.422 – 3.804</td></tr><tr><td>11</td><td>3.512 – 3.900</td></tr><tr><td rowspan="5">↑</td><td>10</td><td>3.600 – 4.125</td></tr><tr><td>9</td><td>3.807 – 4.349</td></tr><tr><td>8</td><td>4.015 – 5.122</td></tr><tr><td>7</td><td>4.728 – 5.899</td></tr><tr><td>6</td><td>5.445 – 6.818</td></tr><tr><td rowspan="5">↓</td><td>5</td><td>6.294 – 7.910</td></tr><tr><td>4</td><td>7.302 – 9.210</td></tr><tr><td>3</td><td>8.502 – 10.774</td></tr><tr><td>2</td><td>9.946 – 36.535</td></tr><tr><td>1</td><td>33.725 –</td></tr><tr><td colspan="2">Left side</td><td></td></tr></table> ★ Levels 13 and 14 flash.				Position of gauge display		Display level resistance kΩ (Monitor panel input resistance)	Starting switch ON		Starting switch OFF	Measure resistance between coolant temperature gauge C03 (female) (1) – C03 (female) (16)	Right side	All OFF(15)	Min. – Max. – 0.646	14	0.575 – 3.420	13	3.156 – 3.708	12	3.422 – 3.804	11	3.512 – 3.900	↑	10	3.600 – 4.125	9	3.807 – 4.349	8	4.015 – 5.122	7	4.728 – 5.899	6	5.445 – 6.818	↓	5	6.294 – 7.910	4	7.302 – 9.210	3	8.502 – 10.774	2	9.946 – 36.535	1	33.725 –	Left side			1) Insert a dummy resistance with the starting switch OFF, or measure the resistance of the sensor. 2) Check the display with the starting switch ON.
		Position of gauge display			Display level resistance kΩ (Monitor panel input resistance)																																											
Starting switch ON		Starting switch OFF																																														
Measure resistance between coolant temperature gauge C03 (female) (1) – C03 (female) (16)	Right side	All OFF(15)	Min. – Max. – 0.646																																													
		14	0.575 – 3.420																																													
		13	3.156 – 3.708																																													
		12	3.422 – 3.804																																													
		11	3.512 – 3.900																																													
	↑	10	3.600 – 4.125																																													
		9	3.807 – 4.349																																													
		8	4.015 – 5.122																																													
		7	4.728 – 5.899																																													
		6	5.445 – 6.818																																													
	↓	5	6.294 – 7.910																																													
		4	7.302 – 9.210																																													
		3	8.502 – 10.774																																													
		2	9.946 – 36.535																																													
		1	33.725 –																																													
	Left side																																															
	<table><tr><td rowspan="2"></td><td colspan="2">Position of gauge display</td><td>Display level resistance kΩ (Monitor panel input resistance)</td></tr><tr><td colspan="2">Starting switch ON</td><td>Starting switch OFF</td></tr><tr><td rowspan="17">Measure resistance between fuel level gauge C03 (female) (2) – chassis</td><td rowspan="5">Right side</td><td>14</td><td>Min. – Max. – 13.82</td></tr><tr><td>13</td><td>11.71 – 17.43</td></tr><tr><td>12</td><td>15.18 – 21.25</td></tr><tr><td>11</td><td>18.90 – 25.05</td></tr><tr><td>10</td><td>22.59 – 28.45</td></tr><tr><td rowspan="5">↑</td><td>9</td><td>25.82 – 31.85</td></tr><tr><td>8</td><td>29.18 – 35.22</td></tr><tr><td>7</td><td>32.45 – 39.91</td></tr><tr><td>6</td><td>37.00 – 44.60</td></tr><tr><td>5</td><td>41.77 – 48.72</td></tr><tr><td rowspan="5">↓</td><td>4</td><td>45.52 – 55.14</td></tr><tr><td>3</td><td>50.42 – 64.35</td></tr><tr><td>2</td><td>60.61 – 77.07</td></tr><tr><td>1</td><td>72.98 – 691.5</td></tr><tr><td colspan="2">Left side</td><td>638.00 –</td></tr></table> ★ Level 1 flashes.				Position of gauge display		Display level resistance kΩ (Monitor panel input resistance)	Starting switch ON		Starting switch OFF	Measure resistance between fuel level gauge C03 (female) (2) – chassis	Right side	14	Min. – Max. – 13.82	13	11.71 – 17.43	12	15.18 – 21.25	11	18.90 – 25.05	10	22.59 – 28.45	↑	9	25.82 – 31.85	8	29.18 – 35.22	7	32.45 – 39.91	6	37.00 – 44.60	5	41.77 – 48.72	↓	4	45.52 – 55.14	3	50.42 – 64.35	2	60.61 – 77.07	1	72.98 – 691.5	Left side		638.00 –	1) Insert a dummy resistance with the starting switch OFF, or measure the resistance of the sensor. 2) Check the display with the starting switch ON.		
	Position of gauge display		Display level resistance kΩ (Monitor panel input resistance)																																													
	Starting switch ON		Starting switch OFF																																													
Measure resistance between fuel level gauge C03 (female) (2) – chassis	Right side	14	Min. – Max. – 13.82																																													
		13	11.71 – 17.43																																													
		12	15.18 – 21.25																																													
		11	18.90 – 25.05																																													
		10	22.59 – 28.45																																													
	↑	9	25.82 – 31.85																																													
		8	29.18 – 35.22																																													
		7	32.45 – 39.91																																													
		6	37.00 – 44.60																																													
		5	41.77 – 48.72																																													
	↓	4	45.52 – 55.14																																													
		3	50.42 – 64.35																																													
		2	60.61 – 77.07																																													
		1	72.98 – 691.5																																													
		Left side		638.00 –																																												

020706

TESTING AND ADJUSTING

TOOLS FOR TESTING, ADJUSTING, AND TROUBLESHOOTING

TOOLS FOR TESTING, ADJUSTING, AND TROUBLESHOOTING

Check or measurement item	Symbol	Part No.	Part Name	Remarks			
Engine speed	A	799-203-8001	Multi-tachometer	Kit Part No.:799-203-9000 Digital display L: 60 – 2,000 rpm H: 60 – 19,999 rpm			
		799-203-8901	Cranking set				
		6142-82-5112	Gear box	7/8 – 18NS			
		6210-81-4111		22 x 1.5			
Coolant and oil temperatures	B	799-101-1502	Digital temperature gauge	–50 – 1,200°C			
Oil pressure	C	1	799-101-5002	Hydraulic tester <i>b8-b</i>	Pressure gauge 2.5, 5.9, 39.2, 58.8 MPa (25, 60, 400, 600 kg/cm ²)		
			790-261-1203	Digital hydraulic tester	Pressure gauge 1.4 MPa (700 kg/cm ²)		
		2	799-401-2320	Hydraulic gauge	1.0 MPa (10 kg/cm ²)		
		3	•790-261-1311	Adapter	Both male and female 14 x 1.5 (female PT 1/8)		
			•790-261-1321		Both male and female 18 x 1.5 (female PT 1/8)		
			•790-261-1331		Both male and female 22 x 1.5 (female PT 1/8)		
		4	799-401-2700	Differential pressure gauge			
		5	790-261-1360	Adapter	Both male and female 14 x 1.5 (female PT 1/8)		
			790-261-1370	Nut	For 14 x 1.5 blind		
			07003-31419	Gasket	For blind		
			07040-11409	Plug	For 14 x 1.5 blind		
		Compression pressure	D	1	795-502-1590	Compression gauge	0 – 6.9 MPa (0 – 70 kg/cm ²)
				2	795-472-1370	Adapter	Kit Part No.: 795-502-1205
Blowby pressure	E	799-201-1504	Blow-by checker	0 – 500 mmH ₂ O			
Air supply pressure (boost pressure)	F	799-401-2310	Pressure gauge	1,500 mmHg			
Valve clearance	G	Commercially available	Feeler gauge				
Exhaust color	H	1	799-201-9000	Handy Smoke Checker	Discoloration 0 – 70% (with standard color) (Discoloration % x 1/10 = Bosch index)		
		2	Commercially available	Smoke meter			
Operating effort	J	79A-264-0020	Push-pull scale	0 – 294N (30 kg)			
		79A-264-0090		0 – 490N (50 kg)			
Stroke, hydraulic drift	K	Commercially available	Scale				
Work equipment speed	L	Commercially available	Stop watch				
Measuring voltage and resistance values	M	79A-264-0210	Tester				
Troubleshooting of wiring harnesses and sensors	N	1	799-601-7100	T-adapter box			
		2	799-601-7070	Adapter	For SWP14P		
			799-601-7360		For relay 5P		

020706


MEASURING ENGINE SPEED

⚠ When removing or installing the measuring equipment, be careful not to touch any high temperature parts.

★ Measure the engine speed under the following conditions.

- Coolant temperature: Within operating range
- Hydraulic oil temperature : 45 – 55°C

1. Install the sensor of multi-tachometer **A** to the speed pick-up port, then connect it to multi-tachometer **A**.



2. Start the engine, and measure the engine speed when it is set to the conditions for measuring.

1) Measuring low idling and high idling speeds
Measure the engine speed with the fuel control dial set to low idling and high idling.

★ Measure in the heavy-duty mode with the auto-deceleration OFF.

2) Measure the speed at near the rated speed.

i) Set the working mode the H/O mode.

ii) Set the power max./swift slow-down switch to the power max. position.

iii) Run the engine at full throttle, set the knob switch to the ON position, operate the arm lever, and measure the speed when the arm IN circuit is relieved.


★ Even if the L.H. knob switch is kept pressed, the power max. function is automatically turned off after approx. 8 seconds, so measure during the first 8 seconds.

★ Measuring speed when travel is operated: Knob switch ON

3) Measuring speed at 2-pump relief:

i) Set the working mode the H/O mode.

ii) Run the engine at full throttle, operate the arm lever, and measure the engine speed when the arm IN circuit is relieved.




MEASURING EXHAUST COLOR

- When measuring in the field when there is no air or power supply, use handy smoker checker **H1**; when recording official data, use smoke meter **H2**.
- ★ Raise the coolant temperature to the operating range before measuring.
- ⚠ When removing or installing the measuring equipment, be careful not to touch any high temperature part.



1. Measuring with handy smoke checker H1

- 1) Fit filter paper in tool **H1**.
- 2) Insert the exhaust gas intake port into the exhaust pipe, accelerate the engine suddenly, and at the same time operate the handle of tool **H1** to catch the exhaust gas on the filter paper.
- 3) Remove the filter paper and compare it with the scale provided to judge the condition.



2. Measuring with smoke meter H2

- 1) Insert the probe of tool **H2** into the outlet port of exhaust pipe(1), then tighten the clip to secure it to the exhaust pipe.
- 2) Connect the probe hose, accelerator switch plug, and air hose to tool **H2**.
 - ★ The pressure of the air supply should be less than 1.5 MPa (15 kg/cm²).
- 3) Connect the power cord to the AC power source socket.
 - ★ When connecting the port, check first that the power switch of tool **H2** is OFF.
- 4) Loosen the cap nut of the suction pump, then fit the filter paper.
- ★ Fit the filter paper securely so that the exhaust gas does not leak.
- 5) Turn the power switch of tool **H2** ON.
- 6) Accelerate the engine suddenly, and at the same time, depress the accelerator pedal of tool **H2** and catch the exhaust gas color on the filter paper.
- 7) Lay the filter paper used to catch the exhaust gas color on top of unused filter papers (10 sheets or more) inside the filter paper holder, and read the indicated value.




ADJUSTING VALVE CLEARANCE

1. Remove the cylinder head cover.
2. Rotate the crankshaft in the normal direction to align TOP 1.6 line (1) on the crankshaft pulley with pointer (2). When rotating, check the movement of the intake valve of No. 6 cylinder.
3. When No. 1 cylinder is at compression top dead center, adjust the valves marked ● in the valve arrangement chart. Next, rotate the crankshaft one turn (360°) in the normal direction and adjust the valve clearance of the remaining valves marked ○.
4. To adjust the valve clearance, loosen locknut (6), then insert feeler gauge **G** between rocker lever (3) and valve stem (4), and turn adjustment screw (5) until the clearance is a sliding fit. Then tighten locknut (6) to hold the adjustment screw in position.

 **kgm** Locknut : **44.1 ± 4.9 Nm (4.5 ± 0.5 kgm)**



- ★ The firing order is as follows: 1 – 5 – 3 – 6 – 2 – 4.
- ★ After adjusting No. 1 cylinder at compression top dead center, it is also possible to turn the crankshaft 120° each time and adjust the valve clearance of the intake and exhaust valves of each cylinder according to the firing order.
- ★ For details of the valve clearance, see the STANDARD VALUE TABLE for engine related parts.
- ★ After tightening the locknut, check the valve clearance again.



Valve arrangement chart

Cylinder No.	1	2	3	4	5	6
Intake valve	●	●	○	●	○	○
Exhaust valve	●	○	●	○	●	○




BKP00321



MEASURING COMPRESSION PRESSURE


⚠ When measuring the compression pressure, be careful not to touch the exhaust manifold or muffler, or to get your clothes caught in the fan, fan belt or other rotating parts.

1. Adjust the valve clearance.
For details, see ADJUSTING VALVE CLEARANCE.
 2. Warm up the engine to make the oil temperature 40 – 60°C.
 3. Remove nozzle holder assembly (1) from the cylinder to be measured.
 4. Install adapter **D2** in the mount of the nozzle holder, then connect pressure gauge **D1**.
 5. Set tachometer **A** in position.
 6. Disconnect the fuel control rod, place the governor lever of the injection pump in the NO INJECTION position, then crank the engine with the starting motor and measure the compression pressure.
- ★ Measure the compression pressure at the point where the pressure gauge indicator remains steady.
 - ★ When measuring the compression pressure, measure the engine speed to confirm that it is within the specified range.
 - ★ After measuring the compression pressure, install nozzle holder assembly (1).



MEASURING BLOW-BY PRESSURE

- ★ Measure the blow-by pressure under the following conditions.
 - Coolant temperature: Within operating range
 - Hydraulic oil temperature: 50 – 80°C
- 1. Install the nozzle of blow-by checker **E** to blow-by hose (1).
- 2. Connect the nozzle and gauge with the hose.
- 3. Run the engine at near the rated output and read the gauge measurement.
 - ★ Near rated output
 - Relieve the arm IN circuit in the H/O mode and power max. mode.
- ★ Measure the blow-by at the point where the gauge indicator remains steady.




020706

TESTING AND ADJUSTING FUEL INJECTION TIMING

Testing

- ★ If the fuel injection pump has been removed, check as follows.
- 1. Check that line **a** on the injection pump is aligned with line **b** on the mounting case.






Adjusting

- ★ If the lines are not aligned, adjust as follows.
- 1. Loosen nut (1) at the oblong portion and pump mounting nut (2), then move fuel injection pump (3) to align the lines.
- 2. Tighten nuts (1) and (2).
 Nut : $66.2 \pm 7.4 \text{ Nm}$ ($6.75 \pm 0.75 \text{ kgm}$)

MEASURING ENGINE OIL PRESSURE

- ★ Measure the engine oil pressure under the following conditions.
 - Coolant temperature: Within operating range
- 1. Remove engine oil low-pressure sensor (1) and high-pressure sensor (2), then install the adapter of oil pressure gauge kit **C1** and oil pressure gauge **C2** (1.0 MPa (10 kg/cm²)).
- 2. Start the engine, and measure the oil pressure with the engine at low idling and at high idling.
- ★ For low-pressure sensor (1), measure the engine oil pressure caution end with the engine at low idling, and for high-pressure sensor (2), measure the engine oil pressure caution end and the controller trouble data display end with the engine at high idling.



TESTING AND ADJUSTING ALTERNATOR BELT TENSION

- ★ If the deflection of the belt when it is pressed at a point **a** midway between the alternator pulley and the fan pulley is not within the standard value, or after carrying out maintenance or replacing the belt, adjust the belt tension as follows.



• Deflection of V-belt : 3 mm

1. Loosen mounting bolts (2) and mount bolt (3) of alternator (1).
2. Loosen locknut (4), turn belt tension adjustment bolt (5), and move alternator (1) to adjust the tension of the belt. When the tension is adjusted, tighten locknut (4).
3. Tighten mounting bolt (2) first, then tighten mount bolt (3).

 Mount bolt:

$110.3 \pm 12.3 \text{ Nm}$ ($11.25 \pm 1.25 \text{ kgm}$)

4. After adjusting the belt tension, check again to confirm that the belt tension is within the standard value.



TESTING AND ADJUSTING WATER PUMP BELT TENSION

- ★ If the deflection of the belt when it is pressed at a point **a** midway between the water pump pulley and the fan pulley is not within the standard value, or after carrying out maintenance or replacing the belt, adjust the belt tension as follows.

• Deflection of V-belt : 3 mm

1. Loosen mounting bolts (2) and locknut (3) of tension pulley (1).
2. Turn belt tension adjustment bolt (4) and move tension pulley (1) to adjust the tension of the belt. When the tension is adjusted, tighten mounting bolts (2).

 Mounting bolt :

$66.2 \pm 7.4 \text{ Nm}$ ($6.75 \pm 0.75 \text{ kgm}$)



3. Loosen adjustment bolt (4) 1/2 turns, then tighten locknut (3).

★ To prevent the adjustment bolt from falling out, loosen the tension applied to the bolt.

 Locknut:



$30.9 \pm 3.4 \text{ Nm}$ ($3.15 \pm 0.35 \text{ kgm}$)

4. After adjusting the belt tension, check again to confirm that the belt tension is within the standard value.





TESTING AND ADJUSTING BELT TENSION FOR AIR CONDITIONER COMPRESSOR

- ★ If the deflection of the belt when it is pressed at a point **a** midway between the drive pulley and the compressor pulley is not within the standard value, or when carrying out maintenance after replacing the belt, adjust the belt tension as follows.
 - Deflection of V-belt : 15 – 18 mm
- 1. Loosen 2 mount bolts (1) and adjustment plate bolt (2).
- 2. Move the position of compressor (3) to adjust the tension of the belt.
- 3. When the position of the compressor is fixed, tighten adjustment plate bolt (2) and mount bolts (1) to secure in position.
- 4. After adjusting the belt tension, repeat the above procedure to check that the belt tension is within the standard value.



ADJUSTING ENGINE SPEED SENSOR

1. Screw in until the tip of sensor (1) contacts gear (2).
 2. When gear (2) contacts sensor (1), turn back $1 \pm 1/6$ turns.
 3. Tighten locknut (3).
-  **kgm** Locknut : $58.8 \pm 9.8 \text{ Nm}$ ($6 \pm 1 \text{ kgm}$)
- ★ Be particularly careful when handling the sensor wiring to ensure that no excessive force is brought to bear on the wiring.
 - ★ Be careful not to let the tip of the sensor be scratched or to let any iron particles stick to the sensor tip.



MEASURING AIR SUPPLY PRESSURE (BOOST PRESSURE)

⚠ When removing or installing the measuring equipment or when carrying out the measurements, be careful not to touch any high temperature parts or rotating parts.



1. Remove air supply pressure measurement plug (1) (PT 1/8), then install the coupler of oil pressure gauge kit **C1**.
2. Connect the oil pressure measurement hose to the coupler and pressure gauge **F** (1500 mmHg).

Note: Run the engine at a mid-range speed or above, and use the self-seal portion of the gauge to bleed the oil from inside the hose.

- Insert the gauge about half way, and repeatedly open the self-seal portion to bleed the oil.
- ★ The gauge does not work if there is any oil inside the hose, so always be sure to bleed all the oil.

3. Run the engine at near the rated speed and measure the pressure indicated by the gauge.
 - ★ Near rated output
 - Run the engine at near the rated output. For details, see the measurement of the engine speed when the arm IN circuit is relieved in the H/O mode and power max. mode.

- ★ The air supply pressure (boost pressure) should be measured with the engine running at rated output. However, when measuring in the field, a similar value can be obtained with the above conditions.




TESTING AND ADJUSTING GOVERNOR MOTOR LEVER STROKE

Testing

★ Use the governor motor adjustment mode.

1. Preparatory work
 - 1) Keep the monitor panel time switch + travel speed (R.H.) switch + working mode (R.H.) switch pressed for 2.5 seconds.
 - 2) Set the fuel control dial to MAX, and the auto-deceleration switch to OFF.
 - ★ Any working mode can be used.
2. In this condition, check the governor lever and spring rod.
3. After checking, repeat the procedure in Step 1 to complete the governor motor adjustment mode.



Adjusting

1. Turn the starting switch OFF, then remove the nut and disconnect joint (1) from governor lever (2).
2. Repeat the procedure in Step 1 above to set to the governor motor adjustment mode.
3. Set governor lever (2) to a position where it contacts full speed stopper (3) of the fuel injection pump, then turn joints (1) and (4) to adjust the length of spring assembly (5) and adjust to the position of the hole of governor lever (2).
4. From the above position, shorten joints (1) and (4) a total of 2 turns (approx. 2.5 mm), and secure in position with the locknut.

Caution

- ★ When the spring assembly is removed and the starting switch is at the OFF position, if the governor motor lever is moved suddenly, the governor motor will generate electricity, and this may cause a failure in the governor controller.
- ★ When moving the governor motor lever, disconnect connector E05 first.

TESTING AND ADJUSTING HYDRAULIC PRESSURE IN WORK EQUIPMENT, SWING, TRAVEL CIRCUIT

Measuring

- ★ Oil temperature when measuring: 45 – 55°C

! Lower the work equipment to the ground and stop the engine. Loosen the oil filler cap slowly to release the pressure inside the hydraulic tank. Then put the safety lock lever in the LOCK position.

1. Remove pressure pick-up plug (1) or (2) (thread dia.=10mm, Pitch=1.25mm) from the circuit to be measured, then install oil pressure gauge C1 (58.8 MPa (600 kg/cm²)).
2. **Measuring unload pressure**
 - 1) Run the engine at full throttle and measure in the H/O mode.
 - 2) Measure the hydraulic pressure when all levers are at neutral.
3. **Measuring main relief pressure**
 - 1) Run the engine at full throttle and measure in the H/O mode.
 - 2) Measure the hydraulic pressure when each actuator is relieved.
 - ★ If the power max. switch is turned ON, the pressure will rise, so measure with both the switch OFF and ON. (When the switch is turned ON, it is automatically turned OFF after approx. 8 seconds, so measure during the first 8 seconds.)
 - ★ Note that the set pressure of the safety valve for the swing motor and head end of the boom is lower than the LS relief pressure, so the value measured will be the relief pressure of the safety valve.
 - ★ To check the operation of the safety valve at the boom LOWER end, measure the hydraulic pressure when the machine push-up switch is OFF (low pressure) and ON (high pressure).
 - ★ When measuring the hydraulic pressure in the boom LOWER circuit, block the hose (fit blind plug) at the boom cylinder head end.
 - ★ If the swing lock switch is turned ON, the pressure will rise, so always keep the lock switch OFF when measuring.
 - ★ To relieve the travel circuit, put block under the track shoe grouser, or put block between the sprocket and frame to lock the track.






Table 1 Combination of pumps and actuators controlled when flow from front and rear pumps is divided

Plug	Pump	Controlled actuator
1	Front pump	Boom cylinder (Lo, Hi) Arm cylinder (Hi) Bucket cylinder R.H. travel motor Service
2	Rear pum	Arm cylinder (Lo) Swing motor L.H. travel motor

Adjusting

★ The unload valve cannot be adjusted.

1. Main relief valve

- (1): For front pump
- (2): For rear pump

Loosen locknut (3), then turn adjustment screw (4) to adjust.

★ Turn the adjustment screw to adjust as follows.

- To INCREASE pressure, turn CLOCKWISE.
- To DECREASE pressure, turn COUNTER-CLOCKWISE.

★ Amount of adjustment for one turn of adjustment screw:

Approx. 12.5 MPa (128 kg/cm²)

 **kgm** Locknut : **68.6 ± 9.8 Nm (7 ± 1 kgm)**

2. Boom cylinder head safety valve

★ Adjust the safety valve at the high-pressure end first, then adjust the low-pressure end.

- (1): Boom cylinder head (LOWER) end

1) Disconnect pilot hose (2).

2) Adjusting high-pressure setting

Loosen locknut (3), then turn holder (4) to adjust.

 **kgm** Locknut :

107.8 ± 14.7 Nm (11 ± 1.5 kgm)

3) Adjusting low-pressure setting

Loosen locknut (5), then turn holder (6) to adjust.

 **kgm** Locknut :

85.8 ± 7.4 Nm (8.75 ± 0.75 kgm)

★ Turn the holder to adjust as follows.





- To INCREASE pressure, turn CLOCKWISE.
- To DECREASE pressure, turn COUNTER-CLOCKWISE.

★ Amount of adjustment for one turn of holder:
Approx. 21.8 MPa (222 kg/cm²)

[Reference] The oil pressure acting on port **CP** is as follows.

Machine push-up switch ON (high pressure): 0 MPa (0 kg/cm²)



Machine push-up switch OFF (low pressure): 2.7 MPa (28 kg/cm²)



3. Swing motor safety valve

- (1): For starting left swing (stopping right swing)
 - (2): For starting right swing (stopping left swing)
- 1) Remove the mounting bolts, then remove cover (3) and spring (4).
 - 2) Loosen locknut (5), then turn adjustment screw (6) to adjust.
 - ★ Carry out the adjustment with the valve assembly installed to the motor.
 - ★ Turn the adjustment screw to adjust as follows.
 - To INCREASE pressure, turn CLOCKWISE.
 - To DECREASE pressure, turn COUNTERCLOCKWISE.
 - ★ Amount of adjustment for one turn of adjustment screw: Approx. 3.9 MPa (39.5 kg/cm²)
-  **kgm** Locknut : **132.3 ± 14.7 Nm (13.5 ± 1.5 kgm)**
- 3) After completing the adjustment, install spring (4) and cover (5), then tighten the mounting bolts to the specified torque.

 **kgm** Cover mounting bolt : **110.3 ± 12.3 Nm (11.25 ± 1.25 kgm)**



TESTING AND ADJUSTING

TESTING AND ADJUSTING TVC VALVE OUTPUT PRESSURE (SERVO PISTON INPUT PRESSURE)

Measuring

- ★ Oil temperature when measuring: 45 – 55°C
- ⚠ Lower the work equipment to the ground and stop the engine. Loosen the oil filler cap slowly to release the pressure inside the hydraulic tank. Then put the safety lock lever in the LOCK position.

1. Remove pressure measurement plugs (1), (2), (3), and (4) (Thread dia.=10 mm, Pitch=1.25 mm), and install oil pressure gauge **C1**.

- ★ Plugs and measured pressure





1	Front pump discharge pressure	3	Front servo piston input pressure
2	Rear pump discharge pressure	4	Rear servo piston input pressure

- ★ Install a 39.2 MPa (400 kg/cm²) gauge to the servo valve end, and a 58.8 MPa (600 kg/cm²) gauge to the pump outlet port end.

2. Turn the swing lock switch ON.
3. Set the working mode to H/O mode and set the knob switch function to POWER MAX.
4. Run the engine at full throttle, turn the L.H. knob switch ON, and measure the oil pressure when the arm IN circuit is relieved.
 - ★ For the front pump, measure the oil pressure at plugs (1) and (3) at the same time; for the rear pump, measure the oil pressure at plugs (2) and (4) at the same time.
 - ★ The power max. function is automatically turned OFF 8 seconds after it is switched ON, so measure during the first 8 seconds.
 - ★ Check that the servo piston input pressure is 2/5 of the pump discharge pressure.

[Reference]

If there is any abnormality in the LS valve or servo piston, the servo piston input pressure will be almost the same or 0 of the pump discharge pressure.





020706

Adjusting

- ★ If the load becomes larger, the engine speed will drop. Or if the engine speed remains normal, the work equipment speed will drop. In such cases, if the pump discharge pressure and LS differential pressure are normal, adjust the TVC valve as follows.

1. Loosen locknut (1), and turn screw (2) to adjust.
 - ★ The direction to turn differs according to the position of the eccentric position punch mark on the screw, so check the mark before turning.
 - ★ Turn the screw as follows.
 - If work equipment is slow, turn in INCREASE direction
 - If engine speed drops, turn in DECREASE direction.

Punch mark	Increase	Decrease
Range ①	Within 90° in counterclockwise direction	Within 90° in clockwise direction
Range ②	Within 90° in clockwise direction	Within 90° in counterclockwise direction




2. After completing the adjustment, tighten locknut (1).

Locknut : $29.4 \pm 4.9 \text{ Nm}$ ($3.0 \pm 0.5 \text{ kgm}$)

Note: The screw is an eccentric cam, so if it is turned from the 0 position in the graph, the stroke of the servo piston (change in oil flow) will move as shown in the graph.

If it is turned one full turn, it will return to the original position, but the screw will become looser, so there will be play in the screw. Therefore, turn the screw a maximum of 90° to the left or right from the position set when the machine was shipped.



TESTING AND ADJUSTING LS VALVE OUTPUT PRESSURE (SERVO PISTON INPUT PRESSURE) AND LS DIFFERENTIAL PRESSURE

★ Oil temperature when measuring: 45 – 55°C

1. Measuring LS valve output pressure (servo piston input pressure)

- 1) Remove pressure measurement plugs (1), (2), (3), and (4) (Thread dia.= 10 mm, Pitch=1.25 mm), and install oil pressure gauge C1.

★ Plugs and measured pressure

1	Front pump discharge pressure	3	Front servo piston input pressure
2	Rear pump discharge pressure	4	Rear servo piston input pressure


★ Install a 39.2 MPa (400 kg/cm²) gauge to the servo valve end, and a 58.8 MPa (600 kg/cm²) gauge to the pump outlet port end.

- 2) Set the working mode to H/O mode, and turn the travel speed switch to Hi.
- 3) Use the work equipment to raise the track assembly on one side.


★ When measuring the front pump, push up the right track; when measuring the rear pump, push up the left track.

- 4) Run the engine at full throttle, set to the conditions shown in Table 1, and measure the pump discharge pressure and servo inlet pressure.


★ For the front pump, measure the oil pressure at plugs (1) and (3) at the same time; for the rear pump, measure the oil pressure at plugs (2) and (4) at the same time.



BLP00118




BLP00128



BLP00129

Table 1

Working mode	Travel lever	Pump pressure (MPa(kg/cm ²))	Servo inlet port pressure (MPa(kg/cm ²))	Remarks
H/O mode	Neutral	3.9 ± 1.0 (40 ± 10)	3.9 ± 1.0 (40 ± 10)	About same pressure
H/O mode	Half (travel circuit under no load)	Approx. 12.7 (130)	Approx. 4.9 (50)	About 2/5 of pressure



BLP00120

TESTING AND ADJUSTING**TESTING AND ADJUSTING LS VALVE OUTPUT PRESSURE (SERVO PISTON INPUT PRESSURE) AND LS DIFFERENTIAL PRESSURE****2. Measuring LS differential pressure**

- 1) Measuring with a differential pressure gauge
 - i) Remove pressure measurement plugs (1), (2), (3), and (4) (Thread dia.=10mm, Pitch=1.25mm), and install differential pressure gauge **C4**.

★ Plugs and measured pressure

1	Front pump discharge pressure	3	Front LS pressure
2	Rear pump discharge pressure	4	Rear LS pressure

- ★ Connect the pump discharge pressure to the high-pressure side of the differential gauge and the LS pressure to the low-pressure side.
- ii) Set the working mode to H/O mode, and turn the travel speed switch to Hi.
 - iii) Use the work equipment to raise the track assembly on one side.

★ When measuring the front pump, push up the right track; when measuring the rear pump, push up the left track.
 - iv) Run the engine at full throttle, set to the conditions shown in Table 2 and measure the LS differential pressure.






Table 2

Working mode	Travel lever	LS differential pressure (MPa (kg/cm ²))	Remarks
H/O mode	Neutral	3.9 ± 1.0 (40 ± 10)	(Note)
H/O mode	Half (travel circuit under no load)	2.5 ± 0.1 (25 ± 1)	

Note: When all control levers are at neutral, the LS differential pressure is the same as the unload pressure.

2) Measuring with oil pressure gauge




- ★ The maximum differential pressure is 2.9 ± 1.0 MPa (30 ± 10 kg/cm²), so measure with the same gauge.
- i) Remove pressure measurement plugs (1), (2), (3), and (4) (thread dia.=10mm, pitch=1.25mm), and install the plug of pressure gauge **C1**.
 - ii) Carry out the same operation as in Step 1)-ii), iii) above.



TESTING AND ADJUSTING

TESTING AND ADJUSTING LS VALVE OUTPUT PRESSURE (SERVO PISTON INPUT PRESSURE) AND LS DIFFERENTIAL PRESSURE

- iii) Install oil pressure gauge **C1** (58.8 MPa (600 kg/cm²)) to the measurement plug for the pump discharge pressure.
 - ★ Use a gauge with a scale in units of 1.0 MPa (10 kg/cm²).
 - (If no 58.8 MPa (600 kg/cm²) pressure gauge is available, a 39.2 MPa (400 kg/cm²) pressure gauge can be used.)
- iv) Set to the conditions in Table 2 and measure the pump discharge pressure.
 - ★ Stand directly in front of the indicator and be sure to read it correctly.
- v) Remove oil pressure gauge **C1**, then install it to the LS pressure measurement plug.
- vi) Set to the conditions in Table 2 and measure the LS pressure.
 - ★ Stand directly in front of the indicator and be sure to read it correctly.
 - (Pump discharge pressure) – (LS pressure) = LS Differential pressure



3. Adjusting LS valve


When the differential pressure is measured under the conditions above, and the results show that the differential pressure is not within the standard value, adjust as follows.

- 1) Loosen locknut (1) and turn screw (2) to adjust the differential pressure.
 - ★ Turn the screw to adjust the differential pressure as follows.
 - To INCREASE pressure, turn CLOCKWISE
 - To DECREASE pressure, turn COUNTER-CLOCKWISE
 - ★ Amount of adjustment for one turn of adjustment screw: Approx. 1.3 MPa (13.2 kg/cm²)

Note: Always measure the differential pressure while adjusting.

- 2) After adjusting, tighten locknut (1).

 Locknut: **68.6 ± 9.8 Nm (7 ± 1 kgm)**



020706




TESTING AND ADJUSTING CONTROL PUMP CIRCUIT OIL PRESSURE

Measuring

- ★ Oil temperature when measuring: 45 – 55°C
- 1. Remove pressure pick-up plug (1) (Thread dia.=10mm, Pitch=1.25mm), and install oil pressure gauge C1 (5.9 MPa (60 kg/cm²)).
- 2. Start the engine and measure with the engine at full throttle.
- ★ When testing for internal leakage of the equipment in the control circuit, use the parts given below to shut off the circuit for the following sections when measuring the relief pressure.

N0.	Section of hydraulic circuit shut off	Component that can be checked
1.	Control pump outlet port	Control pump
2.	LS-EPC valve inlet port	LS-EPC valve
3.	Solenoid valve inlet port	Solenoid valve
4.	Travel PPC valve inlet port	Travel PPC valve
5.	L.H. PPC valve inlet port	L.H. PPC valve
6.	R.H. PPC valve inlet port	R.H. PPC valve

- ★ Items No. 2 and below can be checked if the equipment in the previous number is normal.
- ★ Use the following parts to shut off the circuit.
 - For elbow
 - Sleeve nut: 07221-20210, 07221-20315
 - 07221-20422
 - Plug: 07222-00210, 07222-00315
 - 07222-00414
 - For hose
 - Plug: 07376-50210, 07376-50315
 - 07376-50422



BKP00142

TESTING AND ADJUSTING TESTING AND ADJUSTING CONTROL PUMP CIRCUIT OIL PRESSURE

Adjusting

1. Loosen locknut (1) and turn adjustment screw (2) to adjust.

★ Turn the adjustment screw as follows.


- To INCREASE pressure, turn CLOCKWISE
- To DECREASE pressure, turn COUNTER-CLOCKWISE

★ Amount of adjustment for one turn of adjustment screw:

Approx. 0.56 MPa (5.7 kg/cm²)

 **kgm** Locknut : **63.7 ± 9.8 Nm (6.5 ± 1 kgm)**

★ After completion of adjustment, repeat the procedure in Item 1 to check the set pressure again.



TESTING SOLENOID VALVE OUTPUT PRESSURE

★ Oil temperature when measuring: 45 – 55°C

1. Measuring output pressure of LS-EPC solenoid valve




- 1) Disconnect output hose (1) of the LS-EPC solenoid valve, then use adapter **C3** in the oil pressure gauge kit to install oil pressure gauge **C1** (5.9 MPa (60 kg/cm²)).
- 2) Measure the output pressure under the conditions in Table 1.

Table 1

Operation and working mode	Engine speed (rpm)	Output pressure (MPa(kg/cm ²))	[Reference] Current (A)
• All control levers at neutral	Min. 1500	2.9 ± 0.2 (30 ± 2)	900 ± 30
• H/O mode or G/O mode • Operate any control lever with travel at neutral	Min. 1900	0	0

★ The engine speed and LS-EPC current can be measured using the monitoring code on the monitor panel.

- Engine speed : [10] or [40]
- LS-EPC current : [15]



020706

TESTING AND ADJUSTING**TESTING SOLENOID VALVE OUTPUT PRESSURE****2. Measuring output pressure of ON/OFF solenoid valve**

- 1) Disconnect outlet hose (1) of the solenoid valve to be measured, then use adapter **C3** in the oil pressure gauge kit to install oil pressure gauge **C1** (5.9 MPa (60 kg/cm²)).
- 2) Measure the output pressure under the conditions in Table 2.





Table 2

Hose	Solenoid	Measurement conditions	operating conditions	Condition of solenoid	Oil pressure (MPa (kg/cm ²))	Remarks
1	LS select	Swing lock switch OFF, compound operation of swing + travel	LS circuit divided	ON	Min. 2.7 (28)	When the solenoid is ON, the oil pressure is the output pressure of the travel PPC valve
		Swing lock switch ON	LS circuit not divided	OFF	0	
2	Machine push-up	When machine push-up switch is at high-pressure setting	Safety valve at high-pressure setting	OFF	0	
		When machine push-up switch is at low-pressure setting	Safety valve at low-pressure setting	ON	Min. 2.7 (28)	
3	Pump merge/divider valve	Travel operated independently	Flow from front and rear pumps divided	ON	Min. 2.7 (28)	
		All levers at neutral	Flow from front and rear pumps merged	OFF	0	
4	Travel speed	When operate travel lever with travel speed switch at Hi or Mi	Motor swash plate angle at MIN	ON	Min. 2.7 (28)	
		Travel speed switch at Lo	Motor swash plate angle at MAX	OFF	0	
5	Swing holding brake	Swing or work equipment lever operated	Brake canceled	ON	Min. 2.7 (28)	
		All levers except travel at neutral (5 sec after returning to neutral)	Brake actuated	OFF	0	



- ★ With monitoring code (23), check at the same time that the solenoid is switched ON/OFF electrically.
(The machine push-up solenoid is not displayed.)
- ★ The measurement conditions in the table are typical conditions for measuring the output pressure. The solenoid valve may be actuated (ON/OFF) under conditions other than the measurement conditions given above.
- ★ Operate the lever slightly not enough to move the machine.

MEASURING PPC VALVE OUTPUT PRESSURE AND TESTING PPC SHUTTLE VALVE

★ Oil temperature when measuring: 45 – 55°C

1. Measuring PPC valve output pressure

- 1) Disconnect hose (1) of the circuit to be measured.
- 2) Install adapter **C3** between the hose and elbow.
- 3) Install oil pressure gauge **C1** (5.9 MPa (60 kg/cm²)) to adapter **C3**.
- 4) Run the engine at full throttle, operate the control lever of the circuit to be measured, and measure the oil pressure.





2. Checking PPC shuttle valve

★ If the output pressure at the control valve end is low, check for leakage of oil from the PPC shuttle valve as follows.

- 1) Disconnect hose (1) between the PPC valve and the shuttle valve of the circuit to be measured. Disconnect the hose from the shuttle valve together with the nipple.
- 2) Install adapter **C5** to the tip of the hose, then install oil pressure gauge **C1** (5.9 MPa (60 kg/cm²)).
- ★ Install a blind plug to the shuttle valve.
- 3) Run the engine at full throttle, operate the control lever, and measure the output pressure.

★ If the output pressure becomes normal, there is leakage from the PPC shuttle valve; if there is no change, the PPC valve is defective.



TESTING AND ADJUSTING


MEASURING PPC VALVE OUTPUT PRESSURE AND TESTING PPC SHUTTLE VALVE

3. Checking defective operation of PPC shuttle valve

- 1) Remove the applicable oil pressure switch, then install oil pressure gauge **C1** (5.9 MPa (60 kg/cm²)).
 - ★ Disconnect the outlet hose of the LS select shuttle valve before installing the oil pressure gauge.
- 2) Run the engine at full throttle, operate the applicable lever, and measure the output pressure.
 - ★ If output pressure is generated for all the applicable operations, the shuttle valve is normal.
 - ★ If no output pressure is generated all the applicable operations, the shuttle valve is defective.


- ①: Swing left, right shuttle valve
- ②: LS select shuttle valve (boom RAISE, arm OUT, all travel)
- ③: Boom RAISE, arm OUT shuttle valve
- ④: L.H. travel FORWARD, R.H. travel REVERSE shuttle valve
- ⑤: All travel shuttle valves (L.H., R.H. FORWARD, REVERSE)
- ⑥: L.H. travel REVERSE, R.H. travel FORWARD shuttle valve

Pressure switch piping diagram



BLP00152

020706



BKP00153

ADJUSTING WORK EQUIPMENT, SWING PPC VALVE

★ If there is excessive play in the work equipment or swing lever, adjust as follows.


⚠ Lower the work equipment to the ground and stop the engine. Loosen the oil filler cap slowly to release the pressure inside the hydraulic tank. Then set the safety lock lever to the LOCK position.

1. Remove the PPC valve.
2. Remove boot (1).
3. Loosen locknut (2), then screw in disc (3) until it contacts the 4 heads of piston (4).
 - ★ When doing this, do not move the piston.
4. Secure disc (3) in position, then tighten locknut (2) to the specified torque.

 Locknut : $112.7 \pm 14.7 \text{ Nm}$ ($11.5 \pm 1.5 \text{ kgm}$)

5. Install boot (1).



★ With the above adjustment, the clearance between disc (3) and piston (4) becomes 0.



BLP00154

TESTING TRAVEL DEVIATION

- ★ When traveling on level ground.
- 1. Set the machine in the travel posture.
 - ★ For the travel posture, extend the bucket and arm cylinder rods fully, and hold the boom angle at 45° .
- 2. Travel for 10 m, then measure the deviation when traveling for the next 20 m.
 - ★ Set to H/O mode and measure with the engine at full throttle.
 - ★ Install the hydraulic pressure gauge and measure the pump discharge pressure at the same time.



020706

TESTING LOCATIONS CAUSING HYDRAULIC DRIFT OF WORK EQUIPMENT



- ★ If there is any hydraulic drift in the work equipment (cylinders), check as follows to determine if the cause is in the cylinder packing or in the control valve.

1. Checking for defective cylinder packing

- 1) Checking boom and bucket cylinders
 - i) Set in the same posture as when measuring hydraulic drift, and stop the engine.
 - ii) Operate the boom control lever to RAISE or the bucket control lever to CURL.
 - If the lowering speed increases, the packing is defective.
 - If there is no change, the boom lock valve (boom) or the control valve (bucket) is defective.
 - 2) Checking arm cylinder
 - i) Operate the arm cylinder to move the arm in fully, then stop the engine.
 - ii) Operate the control lever to arm IN.
 - If the lowering speed increases, the packing is defective.
 - If there is no change, the control valve is defective.
- ★ If the pressure in the accumulator has dropped, run the engine for approx. 10 seconds to charge the accumulator again before operating.

[Reference] If the cause of the hydraulic drift is in the packing, and the above operation is carried out, the downward movement becomes faster for the following reasons.

- 1) If the work equipment is set to the above posture (holding pressure applied to the bottom end), the oil at the bottom end leaks to the head end. However, the volume at the head end is smaller than the volume at the bottom end by the volume of the rod, so the internal pressure at the head end increases because of the oil flowing in from the bottom end.
- 2) When the internal pressure at the head end increases, the pressure at the bottom end also rises in proportion to this. The balance is maintained at a certain pressure (this differs according to the amount of leakage) by repeating this procedure.
- 3) When the pressure is balanced, the downward movement becomes slower. If the lever is then operated according to the procedure given above, the circuit at the head end is opened to the drain circuit (the bottom end is closed by the check valve), so the oil at the head end flows to the drain circuit and the downward movement becomes faster.



TESTING AND ADJUSTING TESTING LOCATIONS CAUSING HYDRAULIC DRIFT OF WORK EQUIPMENT

2. Checking boom lock valve

⚠ Set the work equipment at the maximum reach, and the top of the boom horizontal, then stop the engine.
Lock the work equipment control levers and release the pressure inside the hydraulic tank.

1) Disconnect pilot hose (1) of the boom lock valve, and install a blind plug in the hose.


★ Blind plug: 07376-50315

★ Leave the boom lock valve end open.

2) Start the engine, charge the accumulator, then stop the engine.

3) Operate the boom control lever to the LOWER position.

★ If any oil leaks from the port that is left open, the boom lock valve is defective.



3. Checking PPC valve

If the hydraulic drift differs when the safety lock lever is in the LOCK or FREE position, (engine running), the PPC valve is defective.


MEASURING OIL LEAKAGE

★ Oil temperature when measuring: 45 – 55°C

1. Work equipment cylinder


- ★ If the hydraulic drift of the work equipment is outside the standard value, measure the leakage inside the cylinder as follows, and judge if the cause of the hydraulic drift is in the cylinder or in the control valve.
 - If the leakage is within the standard value, the problem is in the control valve.
 - If the leakage is greater than the standard value, the problem is in the cylinder.
- 1) Fully extend the rod of the cylinder to be measured, then stop the engine.
- 2) Disconnect piping (1) at the head end, then block the piping at the chassis end with a blind plug.
 - ⚠ Be careful not to disconnect the piping at the bottom end.
- 3) Start the engine and apply the relief pressure to the bottom end of the cylinder with the engine at full throttle.
 - ★ Boom cylinder : RAISE
 - Arm cylinder : IN
 - Bucket cylinder : CURL
- 4) Continue this condition for 30 seconds, then measure the oil leakage for the next one minute.

Posture for measuring boom cylinder




BLP00161

Posture for measuring arm, bucket cylinder




BLP00162

Boom cylinder





BLP00163

Arm cylinder





BLP00164






2. Swing motor

- 1) Disconnect drain hose (1) from the swing motor, then install a blind plug at the tank end.
- 2) Turn the swing lock switch ON.
- 3) Start the engine and operate the swing relief with the engine at full throttle.
- 4) Continue this condition for 30 seconds, then measure the oil leakage for the next one minute.
 - ★ After measuring, swing 180° and measure again.



3. Travel motor

- 1) Disconnect drain hose (1) from the travel motor, then fit a blind plug at the hose end.
- 2) Fit block ① under the track shoe grouser, or fit block ② between the sprocket and frame to lock the track.
- 3) Start the engine and operate the travel relief with the engine at full throttle.
⚠ When measuring the oil leakage from the travel motor, mistaken operation of the control lever may lead to a serious accident, so always use signals and check when carrying out this operation.
- 4) Continue this condition for 30 seconds, then measure the oil leakage for the next one minute.
★ When measuring, move the motor slightly (to change the position between the valve plate and cylinder, and piston and cylinder), and measure several times.




RELEASING REMAINING PRESSURE IN HYDRAULIC CIRCUIT

- ★ If the piping between the hydraulic cylinder and the control valve is to be disconnected, release the remaining pressure from the circuit as follows.
 The travel circuit is an open circuit, so there is no remaining pressure. It is enough to remove the oil filler cap.
1. Loosen the oil filler cap slowly to release the pressure inside the tank.
 2. Operate the control levers.
★ When the levers are operated 2 – 3 times, the pressure stored in the accumulator is removed.
 3. Start the engine, run at low idling for approx. 5 minutes, then stop the engine and operate the control levers.
★ Repeat the above operation 2 – 3 times to release all the remaining pressure.


TESTING CLEARANCE OF SWING CIRCLE BEARING

Method of testing clearance of swing circle bearing when mounted on machine

1. Fix a magnet-type dial gauge to the outer circle (or inner circle) of the swing circle, and put the tip of the probe in contact with the inner circle (or outer circle).
Set the dial gauge at the front or rear.




2. Extend the work equipment to the maximum reach, and set the tip of the bucket to the same height as the bottom of the revolving frame. When this is done, the upper structure will tilt forward, so the front will go down and the rear will rise.
3. Set the dial gauge to the zero point.



4. Set the arm more or less at right angles to the ground surface, then lower the boom until the front of the machine comes off the ground. When this is done, the upper structure will tilt back, so the front will rise and the rear will go down.
5. Read the value on the dial gauge at this point. The value on the dial gauge is the clearance of the swing circle bearing.

⚠ When carrying out the measurement, do not put your hand or feet under the undercarriage.


6. Return to the condition in Step 2, and check that the dial gauge has returned to the zero point. If it has not returned to the zero point, repeat Steps 3 to 5.



TESTING AND ADJUSTING TRACK SHOE TENSION


Testing

1. Raise the track frame on one side using the arm and boom.
2. Measure the clearance **a** (tension) between the bottom of the track frame and the top of the track shoe.
 - Measurement position
 STD : 4th track roller from the sprocket.
 LC : Midway between the 4th and 5th track roller from the sprocket.
 - Standard clearance **a** (tension) : 331 ± 20 mm



Adjusting

- ★ If the track shoe tension is not within the standard value, adjust as follows.
1. **If the track tension is too high:**
 Loosen plug (1) gradually, and release the grease.
 - ⚠ There is danger that the plug may fly out under the high internal pressure of the grease, so never loosen plug (1) more than 1 turn.
 - ★ If the grease does not come out easily, move the machine backwards or forwards slowly.
 2. **If the track tension is too low:**
 Pump in grease through grease fitting (2).
 - ★ If the grease cannot be pumped in easily, move the machine backwards and forwards slowly.



BLEEDING AIR

Order for operations and procedure for bleeding air

Air bleeding item	Air bleeding procedure					
	1	2	3	4	5	6
	Bleeding air from pump	Start engine	Bleeding air from cylinder	Bleeding air from swing motor	Bleeding air from travel motor	Start operations
• Change hydraulic oil • Clean strainer	○ →	○ →	○ →	○ (note) →	○ (note) →	○
• Replace return filter element		○				○
• Replace, repair pump • Remove suction piping	○ →	○ →	○ →			○
• Replace, repair control valve		○ →	○ →			○
• Replace cylinder • Remove cylinder piping		○ →	○ →			○
• Replace swing motor • Remove swing motor piping		○ →		○ →		○
• Replace travel motor, swivel • Remove travel motor, swivel piping		○ →			○ →	○

Note: Bleed the air from the swing and travel motors only when the oil inside the motor case has been drained.

1. Bleeding air from pump

- 1) Loosen air bleed plug (1), and check that oil oozes out from the plug.

- 2) When oil oozes out, tighten plug(1).

 **kgm** Air bleed plug:



$8.8 \pm 1.0 \text{ Nm}$ ($0.9 \pm 0.1 \text{ kgm}$)

- ★ If no oil oozes out from the air bleed plug:
- 3) Leave plug (1) loosened and remove drain hose (2) and elbow (3).
- 4) Pour in oil through the elbow mount hole until oil oozes out from plug (1).
- 5) Fit elbow (3) and install drain hose (2).
- 6) Tighten air bleed plug (1).

 **kgm** Air bleed plug:


$8.8 \pm 1.0 \text{ Nm}$ ($0.9 \pm 0.1 \text{ kgm}$)

- ★ Precautions when starting the engine
After completing the above procedure and starting the engine, run the engine at low idling for 10 minutes.
- ★ If the coolant temperature is low and automatic warming-up is carried out, cancel it by using the fuel control dial after starting the engine.




2. Bleeding air from hydraulic cylinders

- 1) Start the engine and run at idling for approx. 5 minutes.
 - 2) Run the engine at low idling, then raise and lower the boom 4 – 5 times in succession.
 - ★ Operate the piston rod to approx. 100 mm before the end of its stroke. Do not relieve the circuit under any circumstances.
 - 3) Run the engine at full throttle and repeat Step 2). After that, run the engine at low idling, and operate the piston rod to the end of its stroke to relieve the circuit.
 - 4) Repeat Steps 2) and 3) to bleed the air from the arm and bucket cylinders.
- ★ When the cylinder has been replaced, bleed the air before connecting the piston rod. Be particularly careful not to operate the cylinder to the end of its stroke when the piston rod has been connected to the LOWER end of the boom cylinder.

**3. Bleeding air from swing motor**


- 1) Inside motor case
 - Run the engine at low idling for 5 minutes.
 - ★ This operation will bleed the air inside the motor case automatically.
- 2) Inside brake case
 - ★ Normally, the air inside the brake case is bled automatically, but if it feels that the brake is dragging when operating the swing, bleed the air as follows.

Loosen the mouthpiece of brake hose (1), start the engine, and operate the swing prolix switch ON-OFF repeatedly. When oil oozes out, tighten the mouthpiece.

**4. Bleeding air from travel motor**

- 1) Run the engine at low idling, loosen air bleed plug (1), and check that oil oozes out from the plug.
- 2) When oil oozes out, tighten air bleed plug (1) again.

 **Air bleed plug:**
 $8.8 \pm 1.0 \text{ Nm } (0.9 \pm 0.1 \text{ kgm})$



TROUBLESHOOTING

Points to remember when troubleshooting	20-102
Sequence of events in troubleshooting	20-103
Points to remember when carrying out maintenance	20-104
Checks before troubleshooting	20-112
Connector types and mounting locations	20-114
Connection table for connector pin numbers	20-118
Explanation of control mechanism of electrical system	20-128
Display method and special functions of monitor panel	20-129
Method of using judgement table	20-137
Method of using troubleshooting charts	20-139
Details of troubleshooting and troubleshooting procedure	20-141
Service code table	20-146
Troubleshooting of communication abnormality system (N mode)	20-201
Troubleshooting of governor, pump controller [governor control system] (E mode)	20-251
Troubleshooting of engine (S mode)	20-301
Troubleshooting of governor, pump controller system [pump control system] (C mode)	20-351
Troubleshooting of governor, pump controller [input signal system] (F mode)	20-401
Troubleshooting of hydraulic, mechanical system (H mode)	20-451
Troubleshooting of monitor panel system (M mode)	20-501

020706

POINTS TO REMEMBER WHEN TROUBLESHOOTING

- ⚠ Stop the machine in a level place, and check that the safety pin, blocks, and parking brake are securely fitted.
- ⚠ When carrying out the operation with two or more workers, keep strictly to the agreed signals, and do not allow any unauthorized person to come near.
- ⚠ If the radiator cap is removed when the engine is hot, hot water may spurt out and cause burns, so wait for the engine to cool down before starting troubleshooting.
- ⚠ Be extremely careful not to touch any hot parts or to get caught in any rotating parts.
- ⚠ When disconnecting wiring, always disconnect the negative (–) terminal of the battery first.
- ⚠ When removing the plug or cap from a location which is under pressure from oil, water, or air, always release the internal pressure first. When installing measuring equipment, be sure to connect it properly.


The aim of troubleshooting is to pinpoint the basic cause of the failure, to carry out repairs swiftly, and to prevent reoccurrence of the failure.

When carrying out troubleshooting, an important point is of course to understand the structure and function. However, a short cut to effective troubleshooting is to ask the operator various questions to form some idea of possible causes of the failure that would produce the reported symptoms.

1. When carrying out troubleshooting, do not hurry to disassemble the components.
If components are disassembled immediately any failure occurs:
 - Parts that have no connection with the failure or other unnecessary parts will be disassembled.
 - It will become impossible to find the cause of the failure.

It will also cause a waste of manhours, parts, or oil or grease, and at the same time, will also lose the confidence of the user or operator.
For this reason, when carrying out troubleshooting, it is necessary to carry out thorough prior investigation and to carry out troubleshooting in accordance with the fixed procedure.
2. Points to ask user or operator
 - 1) Have any other problems occurred apart from the problem that has been reported?
 - 2) Was there anything strange about the machine before the failure occurred?
 - 3) Did the failure occur suddenly, or were there problems with the machine condition before this?
 - 4) Under what conditions did the failure occur?
 - 5) Had any repairs been carried out before the failure?
When were these repairs carried out?
 - 6) Has the same kind of failure occurred before?
3. Check before troubleshooting
 - 1) Check the oil level
 - 2) Check for any external leakage of oil from the piping or hydraulic equipment.
 - 3) Check the travel of the control levers.
 - 4) Check the stroke of the control valve spool.
 - 5) Other maintenance items can be checked externally, so check any item that is considered to be necessary.
4. Confirming failure
 - Confirm the extent of the failure yourself, and judge whether to handle it as a real failure or as a problem with the method of operation, etc.
 - ★ When operating the machine to reenact the troubleshooting symptoms, do not carry out any investigation or measurement that may make the problem worse.
5. Troubleshooting
 - Use the results of the investigation and inspection in Items 2 – 4 to narrow down the causes of failure, then use the troubleshooting flowchart to locate the position of the failure exactly.
 - ★ The basic procedure for troubleshooting is as follows.
 - 1) Start from the simple points.
 - 2) Start from the most likely points.
 - 3) Investigate other related parts or information.
6. Measures to remove root cause of failure
 - Even if the failure is repaired, if the root cause of the failure is not repaired, the same failure will occur again.
To prevent this, always investigate why the problem occurred. Then, remove the root cause.

SEQUENCE OF EVENTS IN TROUBLESHOOTING



020706

POINTS TO REMEMBER WHEN CARRYING OUT MAINTENANCE


To maintain the performance of the machine over a long period, and to prevent failures or other troubles before they occur, correct operation, maintenance and inspection, troubleshooting, and repairs must be carried out. This section deals particularly with correct repair procedures for mechatronics and is aimed at improving the quality of repairs. For this purpose, it gives sections on "Handling electric equipment" and "Handling hydraulic equipment" (particularly gear oil and hydraulic oil).

1. POINTS TO REMEMBER WHEN HANDLING ELECTRIC EQUIPMENT

1) Handling wiring harnesses and connectors

Wiring harnesses consist of wiring connecting one component to another component, connectors used for connecting and disconnecting one wire from another wire, and protectors or tubes used for protecting the wiring.


Compared with other electrical components fitted in boxes or cases, wiring harnesses are more likely to be affected by the direct effects of rain, water, heat, or vibration. Furthermore, during inspection and repair operations, they are frequently removed and installed again, so they are likely to suffer deformation or damage. For this reason, it is necessary to be extremely careful when handling wiring harnesses.



Main failures occurring in wiring harness


① Defective contact of connectors (defective contact between male and female)

Problems with defective contact are likely to occur because the male connector is not properly inserted into the female connector, or because one or both of the connectors is deformed or the position is not correctly aligned, or because there is corrosion or oxidization of the contact surfaces.



② Defective crimping or soldering of connectors

The pins of the male and female connectors are in contact at the crimped terminal or soldered portion, but if there is excessive force brought to bear on the wiring, the plating at the joint will peel and cause improper connection or breakage.




TROUBLESHOOTING

POINTS TO REMEMBER WHEN CARRYING OUT MAINTENANCE

③ Disconnections in wiring


If the wiring is held and the connectors are pulled apart, or components are lifted with a crane with the wiring still connected, or a heavy object hits the wiring, the crimping of the connector may separate, or the soldering may be damaged, or the wiring may be broken.



④ High-pressure water entering connector

The connector is designed to make it difficult for water to enter (drip-proof structure), but if high-pressure water is sprayed directly on the connector, water may enter the connector, depending on the direction of the water jet.

As already said, the connector is designed to prevent water from entering, but at the same time, if water does enter, it is difficult for it to be drained. Therefore, if water should get into the connector, the pins will be short-circuited by the water, so if any water gets in, immediately dry the connector or take other appropriate action before passing electricity through it.




⑤ Oil or dirt stuck to connector

If oil or grease are stuck to the connector and an oil film is formed on the mating surface between the male and female pins, the oil will not let the electricity pass, so there will be defective contact.

If there is oil or grease stuck to the connector, wipe it off with a dry cloth or blow it dry with compressed air and spray it with a contact restorer.

- ★ When wiping the mating portion of the connector, be careful not to use excessive force or deform the pins.
- ★ If there is oil or water in the compressed air, the contacts will become even dirtier, so remove the oil and water from the compressed air completely before cleaning with compressed air.



2) Removing, installing, and drying connectors and wiring harnesses




● Disconnecting connectors

- ① Hold the connectors when disconnecting.
When disconnecting the connectors, hold the connectors and not the wires. For connectors held by a screw, loosen the screw fully, then hold the male and female connectors in each hand and pull apart. For connectors which have a lock stopper, press down the stopper with your thumb and pull the connectors apart.


★ Never pull with one hand.

- ② When removing from clips
When removing a connector from a clip, pull the connector in a parallel direction to the clip.

★ If the connector is twisted up and down or to the left or right, the housing may break.






- ③ Action to take after removing connectors
After removing any connector, cover it with a vinyl bag to prevent any dust, dirt, oil, or water from getting in the connector portion.
- ★ If the machine is left disassembled for a long time, it is particularly easy for improper contact to occur, so always cover the connector.



● Connecting connectors

- ① Check the connector visually.
 - 1) Check that there is no oil, dirt, or water stuck to the connector pins (mating portion).
 - 2) Check that there is no deformation, defective contact, corrosion, or damage to the connector pins.
 - 3) Check that there is no damage or breakage to the outside of the connector.
 - ★ If there is any oil, water, or dirt stuck to the connector, wipe it off with a dry cloth. If any water has got inside the connector, warm the inside of the wiring with a dryer, but be careful not to make it too hot as this will cause short circuits.
 - ★ If there is any damage or breakage, replace the connector.
- ② Fix the connector securely.
Align the position of the connector correctly, then insert it securely.
For connectors with lock stopper, push in the connector until the stopper clicks into position.
- ③ Correct any protrusion of the boot and any misalignment of the wiring harness
For connectors fitted with boots, correct any protrusion of the boot. In addition, if the wiring harness is misaligned, or the clamp is out of position, adjust it to its correct position.
 - ★ If the connector cannot be corrected easily, remove the clamp and adjust the position.
- ④ If the connector clamp has been removed, be sure to return it to its original position. Check also that there are no loose clamps.




● **Drying wiring harness**


If there is any oil or dirt on the wiring harness, wipe it off with a dry cloth. Avoid washing it in water or using steam. If the connector must be washed in water, do not use high-pressure water or steam directly on the wiring harness.

If water gets directly on the connector, do as follows.


- ① Disconnect the connector and wipe off the water with a dry cloth.
 - ★ If the connector is blown dry with compressed air, there is the risk that oil in the air may cause defective contact, so remove all oil and water from the compressed air before blowing with air.



- ② Dry the inside of the connector with a dryer. If water gets inside the connector, use a dryer to dry the connector.
 - ★ Hot air from the dryer can be used, but regulate the time that the hot air is used in order not to make the connector or related parts too hot, as this will cause deformation or damage to the connector.




- ③ Carry out a continuity test on the connector. After drying, leave the wiring harness disconnected and carry out a continuity test to check for any short circuits between pins caused by water.
 - ★ After completely drying the connector, blow it with contact restorer and reassemble.




3) Handling control box


- ① The control box contains a microcomputer and electronic control circuits. These control all of the electronic circuits on the machine, so be extremely careful when handling the control box.
- ② Do not open the cover of the control box unless necessary.



- ③ Do not place objects on top of the control box.
- ④ Cover the control connectors with tape or a vinyl bag. Never touch the connector contacts with your hand.
- ⑤ During rainy weather, do not leave the control box in a place where it is exposed to rain.



- ⑥ Do not place the control box on oil, water, or soil, or in any hot place, even for a short time. (Place it on a suitable dry stand).
- ⑦ Precautions when carrying out arc welding
When carrying out arc welding on the body, disconnect all wiring harness connectors connected to the control box. Fit an arc welding ground close to the welding point.



2. Points to remember when troubleshooting electric circuits

- 1) Always turn the power OFF before disconnecting or connect connectors.
- 2) Before carrying out troubleshooting, check that all the related connectors are properly inserted.
★ Disconnect and connect the related connectors several times to check.
- 3) Always connect any disconnected connectors before going on to the next step.
★ If the power is turned ON with the connectors still disconnected, unnecessary abnormality displays will be generated.
- 4) When carrying out troubleshooting of circuits (measuring the voltage, resistance, continuity, or current), move the related wiring and connectors several times and check that there is no change in the reading of the tester.
★ If there is any change, there is probably defective contact in that circuit.

3. POINTS TO REMEMBER WHEN HANDLING HYDRAULIC EQUIPMENT


With the increase in pressure and precision of hydraulic equipment, the most common cause of failure is dirt (foreign material) in the hydraulic circuit. When adding hydraulic oil, or when disassembling or assembling hydraulic equipment, it is necessary to be particularly careful.

1) Be careful of the operating environment.

Avoid adding hydraulic oil, replacing filters, or repairing the machine in rain or high winds, or places where there is a lot of dust.

2) Disassembly and maintenance work in the field


If disassembly or maintenance work is carried out on hydraulic equipment in the field, there is danger of dust entering the equipment. It is also difficult to confirm the performance after repairs, so it is desirable to use unit exchange. Disassembly and maintenance of hydraulic equipment should be carried out in a specially prepared dustproof workshop, and the performance should be confirmed with special test equipment.



3) Sealing openings


After any piping or equipment is removed, the openings should be sealed with caps, tapes, or vinyl bags to prevent any dirt or dust from entering. If the opening is left open or is blocked with a rag, there is danger of dirt entering or of the surrounding area being made dirty by leaking oil so never do this.

Do not simply drain oil out on to the ground, collect it and ask the customer to dispose of it, or take it back with you for disposal.



4) Do not let any dirt or dust get in during refilling operations.

Be careful not to let any dirt or dust get in when refilling with hydraulic oil. Always keep the oil filler and the area around it clean, and also use clean pumps and oil containers. If an oil cleaning device is used, it is possible to filter out the dirt that has collected during storage, so this is an even more effective method.




5) Change hydraulic oil when the temperature is high.

When hydraulic oil or other oil is warm, it flows easily. In addition, the sludge can also be drained out easily from the circuit together with the oil, so it is best to change the oil when it is still warm. When changing the oil, as much as possible of the old hydraulic oil must be drained out. (Do not drain the oil from the hydraulic tank; also drain the oil from the filter and from the drain plug in the circuit.) If any old oil is left, the contaminants and sludge in it will mix with the new oil and will shorten the life of the hydraulic oil.

6) Flushing operations

After disassembling and assembling the equipment, or changing the oil, use flushing oil to remove the contaminants, sludge, and old oil from the hydraulic circuit.


Normally, flushing is carried out twice: primary flushing is carried out with flushing oil, and secondary flushing is carried out with the specified hydraulic oil.



7) Cleaning operations

After repairing the hydraulic equipment (pump, control valve, etc.) or when running the machine, carry out oil cleaning to remove the sludge or contaminants in the hydraulic oil circuit.

The oil cleaning equipment is used to remove the ultrafine (about 3μ) particles that the filter built into the hydraulic equipment cannot remove, so it is an extremely effective device.



TROUBLESHOOTING**CHECKS BEFORE TROUBLESHOOTING****CHECKS BEFORE TROUBLESHOOTING**

	Item	Judgement value	Action
Lubricating oil, coolant	1. Check fuel level, type of fuel	—	Add fuel
	2. Check for impurities in fuel	—	Clean, drain
	3. Check hydraulic oil level	—	Add oil
	4. Check hydraulic strainer	—	Clean, drain
	5. Check swing machinery oil level	—	Add oil
	6. Check engine oil level (oil pan oil level), type of oil	—	Add oil
	7. Check coolant level	—	Add water
	8. Check dust indicator for clogging	—	Clean or replace
	9. Check hydraulic filter	—	Replace
Electrical equipment	1. Check for looseness, corrosion of battery terminal, wiring	—	Tighten or replace
	2. Check for looseness, corrosion of alternator terminal, wiring	—	Tighten or replace
	3. Check for looseness, corrosion of starting motor terminal, wiring	—	Tighten or replace
Hydraulic, mechanical equipment	1. Check for abnormal noise, smell	—	Repair
	2. Check for oil leakage	—	Repair
	3. Carry out air bleeding	—	Bleed air
Electrics, electrical equipment	1. Check battery voltage (engine stopped)	20 – 30V	Replace
	2. Check battery electrolyte level	—	Add or replace
	3. Check for discolored, burnt, exposed wiring	—	Replace
	4. Check for missing wiring clamps, hanging wiring	—	Repair
	5. Check for water leaking on wiring (be particularly careful attention to water leaking on connectors or terminals)	—	Disconnect connector and dry
	6. Check for blown, corroded fuses	—	Replace
	7. Check alternator voltage (engine running at 1/2 throttle or above)	After running for several minutes: 27.5 - 29.5 V	Replace
	8. Check operating sound of battery (when switch is turned ON/OFF)	—	Replace

020706

CONNECTOR TYPES AND MOUNTING LOCATIONS

★ The Address column in the table above shows the address in the connector arrangement drawing (2-dimensional drawing).


Connector No.	Type	No. of pins	Mounting location	Address	Connector No.	Type	No. of pins	Mounting location	Address
C01	MIC	13	Governor, pump controller	E-3	H13	S	16	Intermediate connector	E-8
C02	MIC	21	Governor, pump controller	E-4	H14	M	6	Intermediate connector	E-9
C03	040	20	Governor, pump controller	F-3	H15	L	2	Intermediate connector	G-4
C04	X	2	Rear pump TVC solenoid valve	H-6	M02	X	2	Starting motor	I-2
C05	S	10	Pump prolix circuit switch	N-1	M06	M	3	Heater fan switch (option)	—
C06	M	2	TVC prolix resistor	O-2	M07	M	2	Light switch	N-4
C07	X	3	Rear pump pressure sensor	E-9	M08	M	1	Right front light	C-6
C08	X	3	Front pump pressure sensor	E-9	M09	M	1	Working lamp (boom)	D-9
C09	S	8	Model selection connector	H-5 P-2	M10	M	1	Intermediate connector	E-4
C10	X	2	LS-EPC solenoid valve	H-6	M11	L	2	Fusible link	—
C13	X	2	Front pump TVC solenoid valve	H-7	M12	KES1	3	Heater (option)	F-3
C16	MIC	17	Governor, pump controller	G-4	M13	KES0	2	Speaker	M-5 P-4
C17	040	16	Governor, pump controller	E-3	M14	L	2	Fusible link	—
D01	KES1	2	Window washer circuit	—	M16	—	1	Horn (high tone)	D-4
D03	KES1	2	LS select solenoid circuit	—	M17	—	1	Horn (low tone)	D-5
D04	KES1	2	Pump merge/divider solenoid circuit	—	M18	M	4	Wiper, washer switch	N-4
D05	KES1	2	Swing holding brake solenoid circuit	—	M20	—	—	Cigar lighter	M-4
D06	KES1	2	Machine push-up solenoid circuit	—	M21	PA	9	Radio	O-2
D07	KES1	2	Travel speed selector solenoid circuit	—	M22	M	2	Intermediate connector	F-4 P-7
D08	KES1	2	Heater circuit	—	M23	M	2	L.H. knob switch	G-4 O-6
D11	KES1	2	Alarm buzzer circuit	—	M23	M	2	Horn switch	O-5
D13	KES1	2	Battery relay drive circuit	—	M26	M	6	Air conditioner	F-3
D14	KES1	2	Diode	—	M28	KES0	2	Window washer motor	H-5
D17	KES1	2	Diode	—	M33	250	3	Power window switch	—
D26	KES1	2	Swing holding brake solenoid	—	M34	X	1	Electromagnetic clutch for air conditioner compressor	H-1
E04	X	3	Governor potentiometer	H-8	M35	X	2	Condenser for air conditioner	D-4
E05	X	4	Governor motor	G-8	M38	M	2	Machine push-up switch	N-5
E06	M	3	Fuel control dial	M-4	M40	M	1	Right front light (option)	L-8
E07	X	2	Engine speed sensor	I-3	M41	M	1	Left front light (option)	L-7
E08	SWP	14	Intermediate connector	H-7 I-1	M42	M	1	Rear working lamp	H-7
E11	X	2	Electrical intake air heater relay	G-4	M44	SWP	6	Intermediate connector for automatic lubrication (option)	D-4
F01	X	2	Travel alarm (option)	D-5	M45	M	3	Network bus	—
H12	S	16	Intermediate connector	G-4	M46	M	3	For troubleshooting	K-3

CONNECTOR TYPES AND MOUNTING LOCATIONS


[illegible]

CONNECTOR ARRANGEMENT DIAGRAM

★ For details of this page, see Section 90.



BBP00322









BBP00323

020706

CONNECTION TABLE FOR CONNECTOR PIN NUMBERS





















★ The terms male and female refer to the pins, while the terms male housing and female housing refer to the mating portion of the housing.

No. of pins	X type connector	
	Male (female housing)	Female (male housing)
2	 TEW00221	 TEW00222
3	 TEW00223	 TEW00224
4	 TEW00225	 TEW00226

020706

TROUBLESHOOTING











CONNECTION TABLE FOR CONNECTOR PIN NUMBERS

No. of pins	SWP type connector	
	Male (female housing)	Female (male housing)
6	  TEW00235	  BLP00033
8	  TEW00237	  TEW00238
12	  BLP00034	  BLP00035
14	  TEW00239	  TEW00240
16	  BLP00036	  BLP00037

020706

TROUBLESHOOTING

















CONNECTION TABLE FOR CONNECTOR PIN NUMBERS

No. of pins	M type connector	
	Male (female housing)	Female (male housing)
2	 BLP00038	 BLP00039
3	 TEW00243	 TEW00244
4	 TEW00245	 TEW00246
6	 TEW00247	 TEW00248
8	 BLP00040	 BLP00041

020706











TROUBLESHOOTING

CONNECTION TABLE FOR CONNECTOR PIN NUMBERS

No. of pins	S type connector	
	Male (female housing)	Female (male housing)
8	  TEW00249	  TEW00250
10	  TEW00251	  BLP00042
12	  BLP00043	  TEW00254
16	  BLP00044	  TEW00256

TROUBLESHOOTING

















CONNECTION TABLE FOR CONNECTOR PIN NUMBERS

No. of pins	MIC connector	
	Male (female housing)	Female (male housing)
5	 BLP00045	 BLP00046
9	 BLP00047	 BLP00048
13	 BLP00049	 BLP00050
17	 BLP00051	 BLP00052
21	 TEW00259	 TEW00260





020706

TROUBLESHOOTING

CONNECTION TABLE FOR CONNECTOR PIN NUMBERS

No. of pins	AMP040 type connector			
	Male (female housing)		Female (male housing)	
8		 BLP00053	 BLP00054	
12		 BLP00055	 BLP00056	
16		 BLP00057	 TEW00232	
20		 BLP00058	 TEW00234	



TROUBLESHOOTING
CONNECTION TABLE FOR CONNECTOR PIN NUMBERS

No. of pins	AMP070 type connector	
	Male (female housing)	Female (male housing)
8		
12		

020706

TROUBLESHOOTING





















CONNECTION TABLE FOR CONNECTOR PIN NUMBERS

No. of pins	L type type connector	
	Male (female housing)	Female (male housing)
2	 TEW00257	 TEW00258

020706

TROUBLESHOOTING





CONNECTION TABLE FOR CONNECTOR PIN NUMBERS

No. of pins	Automobile connector	
	Male (female housing)	Female (male housing)
2	  BLP00063	  BLP00064
3	  BLP00065	  BLP00066
4	  BLP00067	  BLP00068
6	  BLP00069	  BLP00070
8	  BLP00071	  BLP00072

020706

TROUBLESHOOTING


CONNECTION TABLE FOR CONNECTOR PIN NUMBERS

No. of pins	Relay connector	
	Male (female housing)	Female (male housing)
5	 BLP00073	 BLP00074
6	 BLP00075	 BLP00076

EXPLANATION OF CONTROL MECHANISM FOR ELECTRICAL SYSTEM

1. Explanation of machine control functions

The control mechanism for the electrical system consists of the monitor panel and governor and pump controller. The monitor panel and the governor and pump controller input the signals that are necessary, and together with the signals selected by the monitor panel, the governor and pump controller outputs or inputs the necessary signals and control the pump absorption torque and engine output.



020706

TAP00174

1. Display on machine monitor

2. Recording of service codes and user code display function

- ## 2) Types of user code and system

E03 (Swing holding brake system)

★ For details of the service codes included in the user code, see the action taken by the controller when an abnormality occurs, the symptoms on the machine or the judgement table.

- If it becomes necessary to display the user code, the time displayed panel is automatically switched to advise the operator to take the necessary action.

- [illegible]


TROUBLESHOOTING

DISPLAY METHOD AND SPECIAL FUNCTIONS OF MONITOR PANEL

4) Display of trouble data

The monitor panel records both service codes which are included in the user code, and service codes which are not included. This data can be displayed on the time display as follows.

- ★ For details of the service codes that are not included in the user code, see ACTION TAKEN BY CONTROLLER WHEN ABNORMALITY OCCURS AND PROBLEMS ON MACHINE or the JUDGMENT TABLE



TAP00175

i) Method of displaying trouble data

Operation	Display
1. To set to the trouble data display mode, Keep the TIME switch + L.H. travel speed switch pressed for 2.5 seconds. Note: It is possible to call it up at the following times. 1) In the normal mode 2) In the user code display mode 3) In the machine data monitoring mode 4) In the time adjustment mode 2. To go to the next service code display, press the time switch + R.H. working mode switch. 3. To go back to the previous service code display, press the time switch + L.H. working mode switch.	1. On the time display and service meter display, the service code and number of hours (service meter hours) that have elapsed since the occurrence of the abnormality are displayed. • Example of display : When E212 has occurred 12 hours before (service meter) 1) Display of service code 2) Display of elapsed time Diagram illustrating the display of service code and elapsed time. The display shows OFF, OFF, Service code (E212), OFF, OFF, Elapsed time data (12.00 h), and ON. 3) If any abnormality exists at this time, the E mark is displayed. Diagram illustrating the display of service code and elapsed time with an E mark. The display shows OFF, OFF, Service code (E212), OFF, OFF, Elapsed time data (12.00 h), and ON. If there is an abnormality, or the controller is carrying out self diagnosis, the output is shut off, and E is displayed.


BKP00079

BKP00080

020706


TROUBLESHOOTING

DISPLAY METHOD AND SPECIAL FUNCTIONS OF MONITOR PANEL

Operation	Display
4. To finish with the trouble data display mode, keep the TIME switch + L.H. travel speed switch pressed for 2.5 seconds. 5. To erase the memory, keep the time switch pressed, turn the starting switch from OFF to ON, and keep the time switch pressed for 5 seconds.	4) If there is no abnormality code in memory  BKP00081


3. Machine data monitoring function

The input signals from the sensors and the output signals to drive the solenoid are displayed on the time display and service meter display.



TAP00176

1) Method of displaying monitoring code

Operation	Display
1. To set to the machine data monitoring mode, do as follows. Keep the time switch + knob button function switch pressed for 2.5 seconds. Note: This is possible at the following times. 1) During the normal mode 2) During the user code display mode 3) During the time adjustment mode 4) During the trouble data display mode	1. On the time display and service meter display, the monitoring code and data are displayed. • Example of display 1) When engine speed is monitored (monitoring code 10)  BKP00083

TROUBLESHOOTING

DISPLAY METHOD AND SPECIAL FUNCTIONS OF MONITOR PANEL

Operation	Display
2. To go to the next monitoring code display, press the time switch + R.H. working mode switch. 3. To go back to the previous monitoring code display, press the time switch + L.H. working mode switch. 4. To finish with the machine data monitoring code mode, keep the time switch + knob button function switch pressed for 2.5 seconds.	2) When displaying bit pattern - For monitoring codes 08, 20 – 24, 36, 37, 47 – 49, 4A, display the bit pattern. - Example of monitoring code 20 The diagram illustrates the sequence of displays for monitoring code 20. It begins with a clock icon (OFF), followed by two blank displays (OFF), then a display showing '20' (Displays monitoring code), then an hourglass icon (OFF), then a display showing bit patterns 6, 4, 2, 5, 3, 1 (Displays bit pattern), and finally two blank displays (OFF). BKP00084 - The code No. is displayed in the monitoring code portion, and the display lights up to display bit patterns (1) – (6).

2) Table of machine data monitoring codes

★ For details of the B in the Unit column, see the bit pattern chart in the next section.

No.	Item	Unit	Name of component
01	Monitor model code	—	Monitor panel
02	Governor, pump controller model code	—	Governor, pump controller
03	Governor, pump controller model code	—	Governor, pump controller
08	S-NET component condition display	B	Governor, pump controller
10	Engine speed	10rpm	Governor, pump controller
11	Pump discharge pressure (F) input	MPa(kg/cm ²)	Governor, pump controller
12	Pump discharge pressure (R) input	MPa(kg/cm ²)	Governor, pump controller
13	TVC current (F) output	10mA	Governor, pump controller
14	TVC current (R) output	10mA	Governor, pump controller
15	LS-EPC current output	10mA	Governor, pump controller
16	No. 2 throttle command	10mA	Governor, pump controller
20	Governor, pump controller PPC oil pressure switch input signal (1)	B	Governor, pump controller
21	Governor, pump controller PPC oil pressure switch input signal (2)	B	Governor, pump controller
22	Governor, pump controller PPC oil pressure switch input signal (3)	B	Governor, pump controller
23	Governor, pump controller solenoid actuation	B	Governor, pump controller
24	Input condition of sensor for governor, pump controller monitor warning	B	Governor, pump controller
30	Fuel control dial input value	10mV	Governor, pump controller
31	Potentiometer voltage	10mV	Governor, pump controller
32	VBB voltage (battery voltage)	100mV	

TROUBLESHOOTING


DISPLAY METHOD AND SPECIAL FUNCTIONS OF MONITOR PANEL

★ For details of the B in the Unit column, see the bit pattern chart in the next section.

No.	Item	Unit	Name of component
33	Governor motor A phase current	10mV	Governor, pump controller
34	Governor motor B phase current	10mV	Governor, pump controller
35	Battery relay output voltage	100mV	Governor, pump controller
36	Governor governor input condition	B	Governor, pump controller
37	Governor governor output condition	B	Governor, pump controller
40	Engine speed	10rpm	Governor, pump controller
41	Coolant temperature sensor voltage	10mV	Governor, pump controller
42	Fuel sensor input voltage	10mV	Governor, pump controller
43	Battery charge input voltage	100mV	Governor, pump controller
47	Monitor panel output condition 1	B	Governor, pump controller
48	Monitor panel input condition 1	B	Governor, pump controller
49	Monitor panel input condition 2	B	Governor, pump controller
4A	Monitor panel input condition 3	B	Governor, pump controller

TROUBLESHOOTING**DISPLAY METHOD AND SPECIAL FUNCTIONS OF MONITOR PANEL****3) Bit pattern chart**

As shown in the diagram below, the time display has bit numbers which light up to show that the signal is being transmitted. (For details, see METHOD OF DISPLAYING MONITORING CODE.)



BKP00085

Code	Content	Bit	Details (condition when lighted up)
08	Connection of S-NET components	(1) (2) (3) (4) (5) (6)	Governor,pump controller connected (ID=2) Governor, pump controller connected (ID=3)
20	Input condition of governor, pump controller PPC switches	(1) (2) (3) (4) (5) (6)	Swing switch ON Travel switch ON Boom LOWER switch ON Boom RAISE switch ON Arm IN switch ON Arm OUT switch ON
21	Input condition of governor, pump controller PPC switches and other switches	(1) (2) (3) (4) (5) (6)	Bucket CURL switch ON Bucket DUMP switch ON Swing lock switch ON Service switch ON Model selection 5 Swing prolix switch ON
22	Input condition of governor, pump controller model selection and other switches Drive condition of governor,	(1) (2) (3) (4) (5) (6)	Model selection 1 GND connected Model selection 2 GND connected Model selection 3 GND connected Model selection 4 GND connected Kerosene mode input GND connected Knob switch ON

020706

TROUBLESHOOTING

DISPLAY METHOD AND SPECIAL FUNCTIONS OF MONITOR PANEL

Code	Content	Bit	Details (condition when lighted up)
23	pump controller ON/OFF solenoid valves	(1) (2) (3) (4) (5) (6)	LS select solenoid ON Swing holding brake ON Pump merge/divider solenoid ON Travel speed selector solenoid ON
24	Input condition 1 of sensor for governor, pump controller monitor warning	(1) (2) (3) (4) (5) (6)	Above engine oil pressure sensor Lo set pressure Above engine oil pressure sensor Hi set pressure Radiator water level sensor abnormal Engine oil level sensor abnormal Hydraulic oil level sensor abnormal Air cleaner clogging sensor abnormal
36	Input condition of governor, pump controller	(1) (2) (3) (4) (5) (6)	Starting switch ON
37	Output condition of governor, pump controller	(1) (2) (3) (4) (5) (6)	Battery relay: Actuated
47	Monitor panel output condition 1	(1) (2) (3) (4) (5) (6)	Alarm buzzer: when operated machine
49	Monitor panel input condition	(1) (2) (3) (4) (5) (6)	KEY ON SW OFF Terminal BR Voltage Hi LIGHT SW OFF Preheating switch OFF START C Sometimes turns ON


TROUBLESHOOTING

DISPLAY METHOD AND SPECIAL FUNCTIONS OF MONITOR PANEL

Code	Content	Bit	Details (condition when lighted up)
4A	Monitor panel output condition	(1)	Time switch OFF
		(2)	PPC oil pressure selector switch OFF
		(3)	Overload selector switch OFF
		(4)	STD/DLX selection STD
		(5)	Swing lock switch OFF
		(6)	Buzzer cancel switch OFF


4. Governor motor adjustment mode

This is used when adjusting the linkage between the governor motor and the injection pump. (For details of the procedure, see TESTING AND ADJUSTING.)

Operation	Display
1. To set to the governor motor adjustment mode, press the time switch + R.H. travel speed switch + R.H. working mode switch.	1. 
2. To return to the time display mode use the same procedure as in Step 1.	2. Buzzer sounds once a second

5. Time adjustment mode

To adjust the time, do as follows.

Operation	Display
1. To set to the time adjustment mode, keep the time switch depressed for 2.5 seconds.	1. The time mark portion flashes 
2. Use the L.H. working mode switch to advance the hour.	
3. Use the R.H. working mode switch to advance the minute.	
4. To return to the time display mode use the same procedure as in Step 1.	

★ The example shows the situation when setting to 12:34.

TROUBLESHOOTING

METHOD OF USING JUDGEMENT TABLE

2. When using judgement table for governor, pump controller (governor control system) and hydraulic related parts

- If a service code is displayed on the monitor panel, go to the troubleshooting code at the bottom of the judgement table (C-○○○).
(A ● mark is put at the places where the failure mode and service code match.)
- If a problem has appeared but no service code is displayed on the monitor panel, go to the point where the failure mode matches the input signal, and check the display for the input signal (the display at the place with a ○ mark).
- If it is displayed normally, go to the troubleshooting code on the right of the judgement table (H-○○○).
- If the input signal is not displayed on the monitor panel, go to the troubleshooting code at the bottom of the judgement table (F-○○○).

<Example> Failure mode "Upper structure does not swing".

Procedure: Check if the service code is being displayed on the monitor panel.

Failure mode		Governor, pump controller (E2XX system)	
		Service code	Self-diagnostic display
		21 22 23 24 25 26 27 28 29 30 31 32	E02 E03
All work equipment, travel, swing	Speeds of all work equipment, swing, travel are slow or lack power	●	●
	There is excessive drop in engine speed, or engine stalls	●	●
	No work equipment, travel, swing move	●	●
	Abnormal noise generated (around pump)	●	●
Work equipment	Auto-deceleration does not work	●	●
	Fine control ability is poor or response is poor	●	●
	Boom is slow or lacks power	●	●
	Arm is slow or lacks power	●	●
Compound operations	Bucket is slow or lacks power	●	●
	Boom does not move	●	●
	Arm does not move	●	●
	Bucket does not move	●	●
Travel system	Excessive hydraulic drift	●	●
	Excessive time lag (engine at low idling)	●	●
	Other equipment moves when single circuit is relieved	●	●
	In LJO, FJO modes, work equipment speed is faster than specified speed	●	●
Swing system	Machine push-up function does not work	●	●
	In compound operations, work equipment with larger load is slow	●	●
	In swing + boom (RAISE), boom is slow	●	●
	In swing + arm, arm is slow	●	●
Swing system	In swing + travel, travel speed drops excessively	●	●
	Deviation is excessive during normal travel	●	●
	Travel deviation	●	●
	Deviation is excessive when starting	●	●
Swing system	Travel speed is slow	●	●
	Steering does not turn or lacks power	●	●
	Travel speed does not switch or is faster than specified speed	●	●
	Does not move (one side only)	●	●
Swing system	Does not swing	●	●
	One direction only	●	●
	Swing acceleration is poor	●	●
	Both left and right	●	●
Swing system	Swing speed is slow	●	●
	One direction only	●	●
	Excessive overrun	●	●
	Both left and right	●	●
Swing system	when stopping swing	●	●
	One direction only	●	●
	Excessive shock when stopping swing (one direction only)	●	●
	Excessive abnormal noise when stopping swing	●	●
Swing system	Excessive hydraulic drift	●	●
	When holding brake is released	●	●
	When holding brake is applied	●	●
	Swing speed is faster than specified swing speed	●	●
Troubleshooting code when service code is displayed		C1 C2 C3 C4 C5 C6 C7 C8 C9 C10 C11 C12 C13 C14 C15 C16 C17 C18 C19 C20 C21 C22 C23 C24 C25 C26 C27 C28 C29 C30 C31 C32	
Troubleshooting code when there is abnormality in monitoring check			
A: This shows applicable item for service code (simultaneous abnormality at front or rear)			
●: This shows item that needs only checking with monitoring			
○: This shows item to check with monitoring or machine monitor			

* If service code E218 (abnormality in network system) is displayed, go to troubleshooting for N mode.

Check items in monitoring mode	
Pressure switch	Monitoring code
Pressure switch	H-1
Pressure switch	H-2
Pressure switch	H-3
Pressure switch	H-4
Pressure switch	H-5
Pressure switch	H-6
Pressure switch	H-7
Pressure switch	H-8
Pressure switch	H-9
Pressure switch	H-10
Pressure switch	H-11
Pressure switch	H-12
Pressure switch	H-13
Pressure switch	H-14
Pressure switch	H-15
Pressure switch	H-16
Pressure switch	H-17
Pressure switch	H-18
Pressure switch	H-19
Pressure switch	H-20
Pressure switch	H-21
Pressure switch	H-22
Pressure switch	H-23
Pressure switch	H-24
Pressure switch	H-25
Pressure switch	H-26
Pressure switch	H-27
Pressure switch	H-28
Pressure switch	H-29
Pressure switch	H-30
Pressure switch	H-31

[Judgement]

- 1) If a service code is being displayed on the monitor panelgo to troubleshooting [E2:○○○] for the governor, pump controller (pump control system).
- 2) If no service code is displayed on the monitor panel, and the upper structure does not swing :

- Check governor, pump controller input signal (Check in monitoring mode)
 - There is a signalGo to troubleshooting H-25 of mechanical system
 - There is no signal ..Go to troubleshooting F-○○○ of governor, pump controller input signal system (F mode for applicable system)

METHOD OF USING TROUBLESHOOTING CHARTS

1. Category of troubleshooting code number

Troubleshooting Code No.	Component	Service code
N-○○	Troubleshooting of communication abnormality system	E218 group
E-○○	Troubleshooting of electrical system for governor, pump controller (governor control system)	E3-○○ group
S-○○	Troubleshooting of engine related parts	—
C-○○	Troubleshooting of electrical system for governor, pump controller (pump control system)	E2-○○ group
F-○○	Troubleshooting of governor, pump controller (input signal system)	—
H-○○	Troubleshooting of hydraulic, mechanical system	—
M-○○	Troubleshooting of machine monitor	E1-○○ group

2. Method of using troubleshooting table for each troubleshooting mode

1) Troubleshooting code number and problem

The title of the troubleshooting chart gives the troubleshooting code, service code, and failure mode (problem with the machine). (See Example (1))

2) Distinguishing conditions

Even with the same failure mode (problem), the method of troubleshooting may differ according to the model, component, or problem. In such cases, the failure mode (problem) is further divided into sections marked with small letters (for example, a), so go to the appropriate section to carry out troubleshooting. (See Example (2)) If the troubleshooting table is not divided into sections, start troubleshooting from the first check item in the failure mode.

3) Method of following troubleshooting chart

- Check or measure the item inside

YES NO

, and according to the answer follow either the YES line or the NO line to go to the next

--

. (Note: The number written at the top right corner of the

--

 is an index number; it does not indicate the order to follow.)
- Following the YES or NO lines according to the results of the check or measurement will lead finally to the Cause column. Check the cause and take the action given in the Remedy column on the right. (See Example (3))
- Below the

--

 there are the methods for inspection or measurement, and the judgement values. If the judgement values below the

--

 are correct or the answer to the question inside the

--

 is YES, follow the YES line; if the judgement value is not correct, or the answer to the question is NO, follow the NO line.
- Below the

--

 is given the preparatory work needed for inspection and measurement, and the judgement values. If this preparatory work is neglected, or the method of operation or handling is mistaken, there is danger that it may cause mistaken judgement, or the equipment may be damaged. Therefore, before starting inspection or measurement, always read the instructions carefully, and start the work in order from Item 1).

4) General precautions

When carrying out troubleshooting for the failure mode (problem), precautions that apply to all items are given at the top of the page and marked with ★ (See Example (4)) .

The precautions marked ★ are not given in the

--

, but must always be followed when carrying out the check inside the

--

.

5) Troubleshooting tools

When carrying out the troubleshooting, prepare the necessary troubleshooting tools. For details, see TOOLS FOR TESTING, ADJUSTING, AND TROUBLESHOOTING.

TROUBLESHOOTING**METHOD OF USING TROUBLESHOOTING CHARTS****6) Installation position, pin number**

A diagram or chart is given for the connector type, installation position, and connector pin number connection. When carrying out troubleshooting, see this chart for details of the connector pin number and location for inspection and measurement of the wiring connector number appearing in the troubleshooting flow chart for each failure mode (problem).

<Example>

(1) **M-9 When starting switch is turned ON (engine stopped), check item for previous troubleshooting flashes**

(4) ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.

★ Always connect any disconnected connectors before going on the next step.

★ Check that the coolant is at the specified level before carrying out troubleshooting

(2) a)  (coolant level) flashes


SAP00519

Divided into sections a) and b)

b)  (engine oil level) flashes

SAP00523

(3)



Table

Short connector	Continuity
Connected	Yes
Disconnected	No


DETAILS OF TROUBLESHOOTING AND TROUBLESHOOTING PROCEDURE

If any abnormality should occur, it is necessary to go to the correct troubleshooting chart in accordance with the judgement table for that type of failure (governor, pump controller (governor control system) and governor, pump controller (pump control system). For details of the troubleshooting and troubleshooting procedure, refer to this flow chart.

When carrying out troubleshooting, ask the operator as much as possible about the condition of the machine, and check the following items before starting.

- (1) Condition of controller connection (check with monitoring codes 02 – 03)
- (2) Blown fuses
- (3) Battery voltage (monitoring mode 32)
- (4) Electricity generation (charge input) voltage (monitoring code 43)

The procedure for carrying out check items No. 3 and 4 in the flow chart below is given on the following pages.



★ For details, see governor, pump controller (governor control system) (pump control system) in the JUDGEMENT TABLE.

If there is no abnormality display in the communications system transmitted in S-NET, it can be taken that the output signal from the monitor panel has been transmitted. However, even if there is no abnormality display, if the operation is defective, use the following procedure when checking directly. If any abnormality occurs in the S-NET system, the system is automatically switched to the following default mode, so be careful when carrying out troubleshooting.

Default Mode when communications cannot be carried out for the monitor and governor, pump controller

Set mode		Pump control	Governor control
1	Working mode	G/O mode	H/O mode
2	Throttle signal	FULL	FULL
3	Auto-deceleration	ON (deceleration mode)	ON (deceleration mode)
4	Coolant temperature signal	OFF	—
5	Priority mode	OFF	—
6	Power max. mode	ON (power max. possible)	—
7	Travel speed	Lo	—
8	Automatic warming up	—	ON (automatic warming-up mode)

1. Procedure for checking monitor panel output signal

★ For details of operating the monitoring mode, see MONITOR PANEL DISPLAY AND SPECIAL FUNCTIONS.

1. Connection condition of components

- 1) Set to the monitoring mode and display monitoring code 08.
- 2) The time display (bits) will light up to display the components that are connected.
 - ★ Governor, pump controller (pump control system) (1) and governor, pump controller (governor control system) (2) will light up.

2. Checking working mode signal (check No. 2 throttle signal (monitoring code 16) at the same time)

- 1) Set to the monitoring mode and display monitoring code 10.
- 2) Switch the working mode as shown in Table 1 and check that the engine speed changes.

Table 1

Working mode	High idling speed (rpm) [The figures in () are the rated speed]
H/O	Approx. 2250 (2050)
G/O	Approx. 2050 <during operation> Approx. 1900 <idling> (1,850)
F/O	Approx. 1900 (1700)
L/O	Approx. 1700 (1500)

3. Checking travel speed selection signal
 - 1) Set to the monitoring mode and display monitoring code 23.
 - 2) Change the speed selector switch to Hi or Mi and run the engine at 1500 rpm or above. Check that bit (6) lights up when traveling at Hi or Mi (front or rear pump oil pressure: 21.6 – 32.3 MPa (220 – 330 kg/cm²)).
 4. Checking swing priority mode signal
 - ★ If the travel oil pressure switch signal is not input to the controller, the flow from the front and rear pumps will remain divided.
 - 1) Set to the monitoring mode and display monitoring code 23.
 - 2) Check that bit (4) lights up when the travel is operated (even when operated slightly).
 - ★ Check the operating condition of the pump merge/divider solenoid valve
- 2. Checking input signal of governor, pump controller**
- ★ Check the input signals for each controller as follows.
 - Pump control system
1. Checking input signal
 - 1) Check hydraulic switch
 - i) Set to the monitoring mode, and display monitoring codes 20 and 21.
 - ii) Operate each work equipment lever, and check how the bit pattern lights up.
 - ★ For details of the bit pattern chart, see MONITOR PANEL DISPLAY AND SPECIAL FUNCTIONS.
 - 2) Check speed sensor (check engine speed)
 - i) Set to the monitoring mode, and display monitoring code 10.
 - ii) Use the fuel control dial to change the speed, and measure the speed when this is done.
 - 3) Check pump discharge pressure sensor
 - i) Set to the monitoring mode, and display monitoring codes 11 and 12.
 - ★ Code 11 is for the front pump and code 12 is for the rear pump.
 - ii) Refer to Table 2 and measure the hydraulic pressure at the front or rear pump.

Table 2 Pump merge/flow logic and pumps actuated by control levers

	Independent operation (basic flow merged)		Travel operated independ- ently or compound opera- tion together with travel※	
	Front pump	Rear pump	Front pump	Rear pump
L.H. travel	○		○	
Swing	○	○	○	
Arm	○	○	○	
Boom	○	○		○
Bucket	○	○		○
R.H. travel		○		○

※ Conditions for compound operation with travel.

- (1) When measuring the oil pressure for any circuit other than travel, operate the travel lever slightly or connect a short connector (X-2P) to the travel oil pressure switch connector (CN-S01).
- (2) The circuits merge when the pressure of the front pump or rear pump is more than 19.6 MPa (200 kg/cm²).

TROUBLESHOOTING DETAILS OF TROUBLESHOOTING AND TROUBLESHOOTING PROCEDURE

- 4) Check kerosene mode input signal
 - i) Set to the monitoring mode, and display monitoring code 22.
 - ii) Connect the CN-M36 connector and check that bit (5) lights up.
- 5) Check knob switch input signal .
 - i) Set to the monitoring mode, and display monitoring code 22.
 - ii) Turn the knob switch ON and check that bit (6) lights up.
2. Check output signals
 - 1) Check LS-EPC solenoid output current
 - i) Set to the monitoring mode, and display monitoring code 15.
 - ii) Run the engine at high idling with all the levers at neutral and in the G/O or H/O mode, and measure the current.
 - ★ All levers at neutral: 900 ± 80 mA
 - Engine at high idling, any lever operated (other than travel): 0 A
 - 2) No. 2 throttle signal
 - i) Set to the monitoring mode, and display monitoring code 16.
 - ii) Use the procedure in Item 2 for checking the monitor panel output signal, and measure the engine speed.
 - 3) Checking ON $\leftrightarrow$ OFF solenoid condition
 - i) Set to the monitoring mode, and display monitoring code 23.
 - ii) Refer to Table 3 and check that the applicable bit lights up.

Table 3 Types of solenoid and conditions for actuation

Name of solenoid	Actuation condition	Bit that lights up
LS select	Swing lock switch OFF, swing + travel lever operated simultaneously	(2)
Swing holding brake	Swing or work equipment lever operated	(3)
Pump merge/divider	Travel operated independently	(4)
Travel speed selector	Travel speed selector switch Hi or Mi	(6)

★ Operate the lever slightly not enough to move the machine.

- 4) Check TVC solenoid output current
 - i) Set to the monitoring mode, and display monitoring codes 13 and 14.
 - Code 13 is for the front pump and code 14 is for the rear pump.
 - ii) With the starting switch kept at the ON position (G/O mode), measure the current when the fuel control dial is turned to the MAX position.
 - Current with starting switch ON (G/O mode) and fuel control dial at MAX : 520 ± 80 (mA)

020706

TROUBLESHOOTING DETAILS OF TROUBLESHOOTING AND TROUBLESHOOTING PROCEDURE

- **Governor control system**

1. Check input signal
 - 1) Check fuel control dial input voltage
 - i) Set to the monitoring mode, and display monitoring code 30.
 - ii) Measure the voltage when the fuel control dial is turned from low idling to high idling.
 - ★ Voltage: 0.25 – 4.75 V
 - 2) Check governor potentiometer voltage
 - i) Set to the monitoring mode, and display monitoring code 31.
 - ii) Measure the potentiometer voltage when the fuel control dial is turned from low idling to high idling.
 - ★ Voltage: 0.5 – 3.3 V
2. Check output signal
 - 1) Check governor motor drive current
 - i) Set to the monitoring mode, and display monitoring codes 33 and 34.
 - ★ Code 33 is the A phase (engine speed acceleration direction) and code 34 is the B phase (engine speed deceleration direction)
 - ii) Measure the governor motor drive current when the fuel control dial is turned in the acceleration direction and deceleration direction.
 - ★ Current: 700 ± 70 (mA)
 - 2) Measure battery relay drive output voltage
 - i) Set to the monitoring mode, and display monitoring code 35.
 - ii) Measure the battery relay drive output voltage when the starting switch is turned from ON to OFF.
 - or
 - iii) Set to the monitoring mode, and display monitoring code 37.
 - iv) Check that bit (1) lights up when the starting switch is turned from ON to OFF.

020706

SERVICE CODE TABLE

Service code	Abnormal system	User code	Service code	Abnormal system	User code
E101	Abnormality in error history data				
E102	Abnormality in time data				
E103	Short circuit in buzzer output, contact with 24V wiring harness for buzzer drive				
E104	Air cleaner clogging detected				
E106	Abnormality in engine oil pressure sensor (Hi) detected				
E108	Water temperature over 105°C				
E202	Short circuit in LS select solenoid system				
E203	Short circuit in swing holding brake solenoid system	E03			
E204	Short circuit in pump merge/divider solenoid system				
E206	Short circuit in travel speed solenoid system				
E212	Disconnection in LS select solenoid system				
E213	Disconnection in swing holding brake solenoid system				
E214	Disconnection in pump merge/divider solenoid system	E03			
E216	Disconnection in travel speed solenoid system				
E217	Error in model selection input				
E218	Network response overtime error				
E222	Short circuit in LS-EPC solenoid system				
E223	Disconnection in LS-EPC solenoid system				
E224	Abnormality in F pump pressure sensor system				
E225	Abnormality in R pump pressure sensor system				
E226	Abnormality in pressure sensor system power source				
E227	Abnormality in engine speed sensor				
E232	Short circuit in F pump TVC solenoid system	E02			
E233	Disconnection in F pump TVC solenoid system	E02			
E236	Short circuit in R pump TVC solenoid system	E02			
E237	Disconnection in R pump TVC solenoid system	E02			
E306	Abnormality in feedback potentiometer system				
E308	Abnormality in fuel control dial input value	E05			
E315	Short circuit in battery relay output system				
E316	Step-out in governor motor				
E317	Disconnection in governor motor system	E05			
E318	Short circuit in governor motor system	E05			

TROUBLESHOOTING OF COMMUNICATION ABNORMALITY SYSTEM (N MODE)

N-1	[E218] Communication abnormality	20-202
-----	--	--------

020706

TROUBLESHOOTING

N-1 [E218] Communication abnormality

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the service code E is not displayed, the problem has been removed.
- ★ If the starting switch was turned off after the abnormality occurred, turn the starting switch on and check that the service code displays E. (If it is not displayed, the problem has been removed.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.




Table 1

Monitoring code		Display
01	Monitor panel model code	300
02	Governor, pump controller model code	300
03	Governor, pump controller model code	300

- When each controller is connected to the network, "—" is displayed. If the correct alphanumeric are not displayed (another model is displayed), each controller shows model selection abnormal.


Table 2

Monitoring code		Display
08	Network connection condition	

BKP00093

- Light up when connected
(1) Governor, pump controller
(2) Governor, pump controller
- Note: Checks can be carried out with code 08 only when there is a disconnection. The display does not change when there is a short circuit. Therefore, checks when there is a short circuit should be carried out basically using Table 1.

N-1 Related electric circuit diagram



BKP00092

TROUBLESHOOTING OF GOVERNOR, PUMP CONTROLLER (GOVERNOR CONTROL SYSTEM) (E MODE)

Points to remember when carrying out troubleshooting of governor, pump controller system	20-252
Action taken by controller and condition of machine when abnormality occurs	20-254
Judgement table for governor, pump controller (governor control system) and engine related parts	20-258
Electrical circuit diagram of governor, pump controller (governor control system)	20-260
E- 1 Abnormality in governor, pump controller power source (controller LED is OFF)	20-262
E- 2 [E308] Abnormality in fuel control dial input value is displayed	20-263
E- 3 [E317] Abnormality (disconnection) in governor motor drive system is displayed	20-264
E- 4 [E318] Abnormality (short circuit) in governor motor drive system is displayed	20-265
E- 5 [E306] Abnormality in feedback potentiometer system is displayed	20-266
E- 6 [E315] Abnormality (short circuit) in battery relay output system is displayed	20-267
E- 7 [E316] Abnormality (step-out) in motor is displayed	20-268
E- 8 Engine does not start	20-270
E- 9 Engine speed is irregular	20-272
a) Idling speed is irregular	20-272
b) There is hunting	20-274
E-10 Lack of output (engine high idling speed is too low)	20-276
E-11 Engine does not stop	20-278
E-12 Defective operation of battery relay system (engine does not stop)	20-280

020706

POINTS TO REMEMBER WHEN CARRYING OUT TROUBLESHOOTING OF GOVERNOR, PUMP CONTROLLER SYSTEM


1. Points to remember when there is abnormality which is not displayed by user code

The engine is controlled by the governor and pump controller.

The problems that may occur with this system include the following.

1. Idling speed is too high (too low)
2. High idling speed is too low
3. Auto-deceleration speed is too high (too low)
4. Engine speed for automatic warming-up operation is too high (too low)
5. There is hunting
6. Engine does not stop

If any abnormality occurs, and the abnormality is displayed on the time display portion of the monitor panel, use the troubleshooting table to determine the appropriate troubleshooting flow chart from E-1 to E-12. However, if there is any abnormality in the machine and no abnormality display is given, it is necessary to determine whether the problem is in the mechanical system or in the electrical system. If the linkage between the governor motor and the injection pump is not properly adjusted, problems 1 to 6 listed above may occur. Therefore, if there is no abnormality display, but one of problems 1 to 6 above has occurred, carry out troubleshooting as follows.



Disconnect the linkage as explained above, or check the adjustment and go to the troubleshooting flow chart for the mechanical system or electrical system.

For details of the procedure for adjusting the linkage, see TESTING AND ADJUSTING.

2. Points to remember if abnormality returns to normal by itself

In the following two cases, there is a high probability that the same problem will occur again, so it is desirable to follow up this problem carefully.

- 1) If any abnormality returns to normal by itself, or
- 2) If the connector is disconnected and the T-adapter is inserted, or if the T-adapter is removed and the connector is returned to its original position when carrying out troubleshooting of the failure, and the service code is no longer displayed, or if the monitor display returns to normal.
- 3) After completing troubleshooting, always erase the service code from memory.

3. User code memory retention function

When displaying the abnormality code in memory and carrying out troubleshooting, note down the content of the display, then erase the display. After trying to re-enact the problem, carry out troubleshooting according to the failure code that is displayed.

(There are cases where mistaken operation or abnormalities that occur when the connector is disconnected are recorded by the memory retention function. Erasing the data in this way saves any wasted work.)

TROUBLESHOOTING**ACTION TAKEN BY CONTROLLER WHEN ABNORMALITY
OCCURS AND PROBLEMS ON MACHINE**

User code	Service code	Abnormal system	Nature of abnormality
E05	E308	Abnormality in fuel control dial input value	1. Short circuit in wiring harness between C03 (7) – (14), (7) – (17), (14) – (17) 2. Short circuit in wiring harness between E04 (1) – (2), (1) – (3), (2) – (3) 3. Short circuit in wiring harness between E06 (1) – (2), (1) – (3), (2) – (3) 4. Short circuit in wiring harness between C03 (7) – (4), (4) – (17) 5. Disconnection in wiring harness between C03 (7) – X07 (6) – E06 (1) 6. Disconnection in wiring harness between C03 (4) – X07 (5) – E06 (2) 7. Disconnection in wiring harness between C03 (17) – X07 (4) – E06 (3) 8. Defective fuel control dial 9. Defective contact of C03, X07, E06 connectors
	E317	Abnormality (disconnection) in motor drive system	1. Disconnection inside governor motor 2. Disconnection in wiring harness between C02 (2) – E05 (1) 3. Disconnection in wiring harness between C02 (4) – E05 (3) 4. Disconnection in wiring harness between C02 (3) – E05 (2) 5. Disconnection in wiring harness between C02 (5) – E05 (4) 6. Defective contact of E05 connector
	E318	Abnormality (short circuit) in motor drive system	1. Short circuit inside governor motor 2. Wiring harness between C02 (2) – E05 (1) and between C02 (4) – E05 (3) short circuiting with wiring harness between C02 (3) – E05 (2) 3. Wiring harness between C02 (4) – E05 (3) and between C02 (2) – E05 (1) short circuiting with wiring harness between C02 (5) – E05 (4) 4. Wiring harness in Items 2 and 3 short circuiting with ground

020706

TROUBLESHOOTING**ACTION TAKEN BY CONTROLLER WHEN ABNORMALITY OCCURS AND PROBLEMS ON MACHINE**

Condition when normal (voltage, current, resistance)			Action by controller when abnormality is detected	Problem that appears on machine when there is abnormality																	
<table><tr><td>C03 (female)</td><td>E06 (male)</td><td>Resistance value</td></tr><tr><td>(7) – (4)</td><td>(1) – (2)</td><td>0.25 – 7kΩ</td></tr><tr><td>(4) – (17)</td><td>(2) – (3)</td><td>0.25 – 7kΩ</td></tr><tr><td>(7) – (17)</td><td>—</td><td>2 – 3kΩ</td></tr><tr><td>—</td><td>(1) – (3)</td><td>4 – 6kΩ</td></tr><tr><td>Between each pin and chassis</td><td>—</td><td>Min. 1 MΩ</td></tr></table>	C03 (female)	E06 (male)	Resistance value	(7) – (4)	(1) – (2)	0.25 – 7kΩ	(4) – (17)	(2) – (3)	0.25 – 7kΩ	(7) – (17)	—	2 – 3kΩ	—	(1) – (3)	4 – 6kΩ	Between each pin and chassis	—	Min. 1 MΩ		Maintains engine speed at position of fuel control dial immediately before abnor- mality occurred	1. Does not become partial speed when set at MAX position 2. Does not reach high idling when set at partial speed 3. There are cases of hunting 4. Lacks output (max. speed of en- gine is too low)
C03 (female)	E06 (male)	Resistance value																			
(7) – (4)	(1) – (2)	0.25 – 7kΩ																			
(4) – (17)	(2) – (3)	0.25 – 7kΩ																			
(7) – (17)	—	2 – 3kΩ																			
—	(1) – (3)	4 – 6kΩ																			
Between each pin and chassis	—	Min. 1 MΩ																			
<table><tr><td>E05 (male)</td><td>C02 (female)</td><td>Resistance value</td></tr><tr><td>(1) – (2)</td><td>(2) – (3)</td><td>0.25 – 7kΩ</td></tr><tr><td>(3) – (4)</td><td>(4) – (5)</td><td>0.25 – 7kΩ</td></tr><tr><td>(1) – (3)</td><td>(2) – (4)</td><td>Min. 1 MΩ</td></tr><tr><td>(1) – (4)</td><td>(2) – (5)</td><td>Min. 1 MΩ</td></tr><tr><td>Between pins (1), (2), (3), (4) and chassis</td><td>Between pins (2), (3), (4), and (5) and chassis</td><td>Min. 1 MΩ</td></tr></table> Motor drive current: Hold: 0.7 A Start: 0.84 A	E05 (male)	C02 (female)	Resistance value	(1) – (2)	(2) – (3)	0.25 – 7kΩ	(3) – (4)	(4) – (5)	0.25 – 7kΩ	(1) – (3)	(2) – (4)	Min. 1 MΩ	(1) – (4)	(2) – (5)	Min. 1 MΩ	Between pins (1), (2), (3), (4) and chassis	Between pins (2), (3), (4), and (5) and chassis	Min. 1 MΩ		Takes no particular action	1. When there is a disconnection in both the A phase and B phase at the same time, the problem is the same as for a short circuit in the governor motor system 2. When there is a disconnection in only one of A phase or B phase 1) Engine does not stop 2) Stops moving at position im- mediately before failure, so en- gine speed cannot be control- led 3) There are cases of hunting
E05 (male)	C02 (female)	Resistance value																			
(1) – (2)	(2) – (3)	0.25 – 7kΩ																			
(3) – (4)	(4) – (5)	0.25 – 7kΩ																			
(1) – (3)	(2) – (4)	Min. 1 MΩ																			
(1) – (4)	(2) – (5)	Min. 1 MΩ																			
Between pins (1), (2), (3), (4) and chassis	Between pins (2), (3), (4), and (5) and chassis	Min. 1 MΩ																			
<table><tr><td>E05 (male)</td><td>C02 (female)</td><td>Resistance value</td></tr><tr><td>(1) – (2)</td><td>(2) – (3)</td><td>0.25 – 7kΩ</td></tr><tr><td>(3) – (4)</td><td>(4) – (5)</td><td>0.25 – 7kΩ</td></tr><tr><td>(1) – (3)</td><td>(2) – (4)</td><td>Min. 1 MΩ</td></tr><tr><td>(1) – (4)</td><td>(2) – (5)</td><td>Min. 1 MΩ</td></tr><tr><td>Between pins (1), (2), (3), (4) and chassis</td><td>Between pins (2), (3), (4), and (5) and chassis</td><td>Min. 1 MΩ</td></tr></table> Motor drive current: Hold: 0.7 A Start: 0.84 A	E05 (male)	C02 (female)	Resistance value	(1) – (2)	(2) – (3)	0.25 – 7kΩ	(3) – (4)	(4) – (5)	0.25 – 7kΩ	(1) – (3)	(2) – (4)	Min. 1 MΩ	(1) – (4)	(2) – (5)	Min. 1 MΩ	Between pins (1), (2), (3), (4) and chassis	Between pins (2), (3), (4), and (5) and chassis	Min. 1 MΩ		Sets motor drive current to 0	1. If during operation 1) Set to low idling 2) Engine does not stop 3) There are cases of hunting 2. When stopped 1) Engine starts, but stays at low idling 2) Engine does not stop after start- ing 3) There are cases of hunting
E05 (male)	C02 (female)	Resistance value																			
(1) – (2)	(2) – (3)	0.25 – 7kΩ																			
(3) – (4)	(4) – (5)	0.25 – 7kΩ																			
(1) – (3)	(2) – (4)	Min. 1 MΩ																			
(1) – (4)	(2) – (5)	Min. 1 MΩ																			
Between pins (1), (2), (3), (4) and chassis	Between pins (2), (3), (4), and (5) and chassis	Min. 1 MΩ																			

020706

ACTION TAKEN BY CONTROLLER WHEN ABNORMALITY OCCURS AND PROBLEMS ON MACHINE

TROUBLESHOOTING

User code	Service code	Abnormal system	Nature of abnormality
—	E306	Abnormality in feedback potentiometer system	1. Short circuit in wiring harness between C03 (7) – (14), (7) – (17), (14) – (17) 2. Short circuit in wiring harness between E04 (1) – (2), (1) – (3), (2) – (3) 3. Short circuit in wiring harness between E06 (1) – (2), (1) – (3), (2) – (3) 4. Short circuit in wiring harness between C03 (7) – (4), (4) – (17) 5. Disconnection in wiring harness between C03 (7) – E04 (1) 6. Disconnection in wiring harness between C03 (14) – E04 (2) 7. Disconnection in wiring harness between C03 (17) – E04 (3) 8. Defective governor motor potentiometer 9. Defective contact of C03, E04 connectors
—	E315	Abnormality (short circuit) in battery relay output system	If excess current flows between C03 (1) and battery relay ★ This occurs only when turning starting switch to OFF and stopping engine
—	E316	Abnormality (step-out) in motor	1. Defective adjustment of rod or scuffing of loose spring 2. Abnormality in governor motor 3. Abnormality in governor, pump controller

020706

TROUBLESHOOTING**ACTION TAKEN BY CONTROLLER WHEN ABNORMALITY OCCURS AND PROBLEMS ON MACHINE**

Condition when normal (voltage, current, resistance)	Action by controller when abnormality is detected	Problem that appears on machine when there is abnormality																		
<table border="1"> <thead> <tr> <th>C03 (female)</th><th>E04 (male)</th><th>Resistance value</th></tr> </thead> <tbody> <tr> <td>(7) – (14)</td><td>(1) – (2)</td><td>0.25 – 7kΩ</td></tr> <tr> <td>(7) – (17)</td><td>(2) – (3)</td><td>0.25 – 7kΩ</td></tr> <tr> <td>(14) – (17)</td><td>—</td><td>2 – 3kΩ</td></tr> <tr> <td>—</td><td>(1) – (3)</td><td>4 – 6kΩ</td></tr> <tr> <td>Between each pin and chassis</td><td>—</td><td>Min. 1 MΩ</td></tr> </tbody> </table>	C03 (female)	E04 (male)	Resistance value	(7) – (14)	(1) – (2)	0.25 – 7kΩ	(7) – (17)	(2) – (3)	0.25 – 7kΩ	(14) – (17)	—	2 – 3kΩ	—	(1) – (3)	4 – 6kΩ	Between each pin and chassis	—	Min. 1 MΩ	Calculates position of motor and carries out control from value of voltage immediately before abnormality occurred	1. Precision of engine speed control may be reduced. For example: 1) Engine does not rise to high idling speed (a little too low) 2) Engine does not go down to low idling speed (a little too high) 3) Defective engine speed for auto-deceleration or automatic warming-up 4) Engine may not stop ★ The governor motor moves in the direction to stop the engine, but the motor may not move completely to the position to stop the engine. 5) There are cases of hunting
C03 (female)	E04 (male)	Resistance value																		
(7) – (14)	(1) – (2)	0.25 – 7kΩ																		
(7) – (17)	(2) – (3)	0.25 – 7kΩ																		
(14) – (17)	—	2 – 3kΩ																		
—	(1) – (3)	4 – 6kΩ																		
Between each pin and chassis	—	Min. 1 MΩ																		
Between C03 (1) and chassis: 20 – 30 V ★ Holds with the motor in the stop position for 2 – 2.5 sec, returns to the low idling position, then turns the battery relay OFF.	Sets battery relay drive current to 0	Engine does not stop																		
1. Linkage adjustment correct 2. Must move lightly when connector is removed 3. Normal	1. Displays when returning from high idling to low idling ★ Starts again (repeats step-out) 2. In some cases it may not display when returning from partial speed to low idling	Engine speed cannot be controlled (particularly at high idling), so there is hunting																		

020706

JUDGEMENT TABLE FOR GOVERNOR, PUMP GOVERNOR (GOVERNOR CONTROL SYSTEM) AND ENGINE RELATED PARTS

TROUBLESHOOTING

JUDGEMENT TABLE FOR GOVERNOR, PUMP GOVERNOR (GOVERNOR CONTROL SYSTEM) AND ENGINE RELATED PARTS

Failure mode		Governor, pump controller, engine related parts (E3: system)						
		Self-diagnostic display						
		Abnormality in governor, pump controller power source system						
		Abnormality in fuel control dial input value	Abnormality (disconnection) in motor drive system	Abnormality (short circuit) in motor drive system	Abnormality in feedback potentiometer system	Abnormality (short circuit) in battery relay output	Abnormality (step-out) in motor	
User code		E05						
Service code		308	317	318	306	315	316	
1	Engine does not start easily							
2	Engine does not start							
3	Engine speed stays at low idling, and does not follow accelerator; or engine pickup is poor	●	●	●	●	●		
4	Engine stops during operation							
5	Engine rotation is irregular							
	When idling speed is irregular							
	When there is hunting		●	●	●	●		●
6	Lack of output (engine high idling speed is too low)		●			●		
7	Auto-deceleration does not work							
8	Engine does not stop	●		●	●	●	●	
9	Warming-up operation is defective							
10	Exhaust gas is black							
11	Oil consumption is excessive, or exhaust gas is blue							
12	Oil becomes dirty prematurely							
13	Fuel consumption is excessive, or exhaust gas is blue							
14	Oil is mixed in coolant							
15	Engine oil pressure caution lamp lights up							
16	Oil level rises							
17	Coolant temperature rises too high (overheating)							
18	Abnormal noise is generated							
19	There is excessive vibration							
20	Engine speed does not change even when working mode is switched							
Troubleshooting code when service code is displayed		E-1	E-2	E-3	E-4	E-5	E-6	E-7
Troubleshooting code when there is abnormality in monitoring or machine monitor check		—	—	—	—	—	—	—

● : This shows applicable item for service code

※ : This shows item that needs only checking with monitoring

020706


TROUBLESHOOTING

JUDGEMENT TABLE FOR GOVERNOR, PUMP GOVERNOR (GOVERNOR CONTROL SYSTEM) AND ENGINE RELATED PARTS

Checking monitoring, check items										Machine monitor check item	Does starting motor turn?	Troubleshooting code if no service code display is given
Battery relay drive signal	No. 2 throttle command value	Fuel control dial command value	Governor motor potentiometer	Governor motor A phase current	Governor motor B phase current	Coolant temperature voltage	102°C or above	105°C or above	Is red range displayed?			
Monitoring code												
35	16	30	31	33	34	41			108			
												S-1
											○	S-2
		*	*	*	*				○			S-3
												S-4
												E-9A), S-5
			*									E-9A), S-5
	*	*					○					E-10, S-6
												E-3 · E-4
○				*	*							E-11
							○		○			E-3 · E-4
												S-7
												S-8
												S-9
												S-10
												S-11
												S-12
												S-13
							○	○				S-14
												S-15
												S-16
	*											E-3 · E-4
—	—	—	—	—	—	—	—	—	—	—	—	
E-12	—	—	—	—	—	M-14	M-13	M-13	E-8			


○ : This shows item to check with monitoring or machine monitor

ELECTRICAL CIRCUIT DIAGRAM FOR E MODE SYSTEM



020706

BKP00219



BKP00095


E-1 Abnormality in governor, pump controller power source (controller LED is OFF)

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adaptor, or when removing the T-adaptor and returning the connector to its original position, if the service code E is not displayed, the problem has been removed.
- ★ Check that fuse 1 is not blown.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.
- ★ When the starting motor rotates correctly. (If the starting motor also does not rotate, go to E-8.)

		Cause	Remedy
1 Is voltage between C01 (7) (13) and C02 (11) (21) normal? • Turn starting switch ON. • 20 – 30 V	YES	Defective governor, pump controller	Replace
	NO	Defective contact, or disconnection in wiring harness between fuse 1 and C01 (female) (7) (13)	Repair or replace
	NO	Defective contact, or disconnection in wiring harness between fuse 1–H15 (2)–M14 (2) (1)–battery relay M	Repair or replace

020706


E-1 Related electric circuit diagram



BKP00096

E-2 [E308] Abnormality in fuel control dial input value is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the service code E is not displayed, the problem has been removed.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.




- ★ If E306 also occurs at the same time, check the wiring harness below.
 - Wiring harness between C03 (female) (7) – E04 (female) (1) short circuiting with ground, or contact with other wiring harness

Table 1

C03 (female)	E04 (male)	Resistance value
(7) – (4)	(1) – (2)	0.25 – 7kΩ
(4) – (17)	(2) – (3)	0.25 – 7kΩ
(7) – (17)	—	2 – 3kΩ
—	(1) – (3)	4 – 6kΩ
Between each pin and chassis	—	Min. 1 MΩ

E-2 Related electric circuit diagram



BKP00097

E-3 [E317] Abnormality (disconnection) in motor drive system is displayed


- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the service code E is not displayed, the problem has been removed.
- ★ During operation, if there is
 - 1) a simultaneous disconnection in A phase and B phase:
 - 1) the engine will run at low idling
 - 2) the engine will not stop
 - 2) a disconnection in either A phase or B phase, the engine speed will remain the same as before the abnormality occurred
- ★ If the problem occurs when the engine is stopped,
 - 1) the engine can be started, but it stays in low idling, or 2) it will not stop after it is started.
- ⚠ Check with the engine stopped (push the fuel control lever of the fuel injection pump to the NO INJECTION position).
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

		Cause	Remedy
Is resistance between each pin of E05 (male), or between each pin and chassis as shown in Table 1? • Turn starting switch OFF. • Disconnect E05.	YES	Defective governor, pump controller	Replace
	NO	Defective wiring harness in system with defective resistance	Replace
	NO	Defective governor motor	Replace

Table 1

E05 (male)	C02 (female)	Resistance value
(1) – (2)	(2) – (3)	2.5 – 7.5kΩ
(3) – (4)	(4) – (5)	2.5 – 7.5kΩ

E-3 Related electric circuit diagram



BKP00098

E-4 [E318] Abnormality (short circuit) in motor drive system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adaptor, or when removing the T-adaptor and returning the connector to its original position, if the service code E is not displayed, the problem has been removed.
- ★ If the abnormality occurs during operation, because of the force of the spring,
 - 1) the engine will run at low idling
 - 2) the engine will not stop
- ★ If the problem occurs when the engine is stopped,
 - 1) the engine can be started, but it stays in low idling, or 2) it will not stop after it is started.
- ⚠ Check with the engine stopped (push the fuel control lever of the fuel injection pump to the NO INJECTION position).
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.


		Cause	Remedy
1 Is resistance between each pin of E05 (male), or between each pin and chassis as shown in Table 1? • Turn starting switch OFF. • Disconnect E05. 2 YES Is resistance between each pin of C02 (female), or between each pin and chassis as shown in Table 1? • Turn starting switch OFF. • Disconnect C02. NO	Defective governor, pump controller	Replace	
		Defective wiring harness in system with defective resistance	Replace
		Defective governor motor	Replace

Table 1

Table 1

E05 (male)	C02 (female)	Resistance value
(1) – (2)	(2) – (3)	2.5 – 7.5kΩ
(3) – (4)	(4) – (5)	2.5 – 7.5kΩ
(1) – (3)	(2) – (4)	Min. 1 MΩ
(1) – (4)	(2) – (5)	Min. 1 MΩ
Between chassis and pins (1)(2)(3)(4)	Between chassis and pins (2)(3)(4)(5)	Min. 1 MΩ

E-4 Related electric circuit diagram



BKP00098

E-5 [E306] Abnormality in feedback potentiometer system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the service code E is not displayed, the problem has been removed.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.


		Cause	Remedy
Is resistance between E06 (male) (1)-(2), (2)-(3) as shown in Table 1? YES 1 Is resistance between each pin of C03 (female) (4) (7) (14), or between each pin and chassis as shown in Table 1? 2 YES NO • Turn starting switch OFF. • Disconnect C03. NO • Turn starting switch OFF. • Disconnect E04.		Defective governor, pump controller	Replace
		Defective wiring harness in system with defective resistance	Replace
		Defective governor motor	Replace

- ★ If E308 also occurs at the same time, check the wiring harness below.
 - Wiring harness between C03 (female) (7) – X07 (6) – E06 (female) (1) short circuiting with ground, or contact with other wiring harness

Table 1

C03 (female)	E04 (male)	Resistance value
(7) – (4)	(1) – (2)	0.25 – 7kΩ
(14) – (17)	(2) – (3)	0.25 – 7kΩ
(7) – (17)	—	2 – 3kΩ
—	(1) – (3)	4 – 6kΩ
Between each pin and chassis	—	Min. 1 MΩ

E-5 Related electric circuit diagram



BKP00097

E-6 [E315] Abnormality (short circuit) in battery relay output system is displayed

★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the service code E is not displayed, the problem has been removed.

⚠ Check with the engine stopped (push the fuel control lever of the fuel injection pump to the NO INJECTION position).


★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.

★ Always connect any disconnected connectors before going on the next step.

★ This only occurs when the engine is stopped and the starting switch is turned OFF.

		Cause	Remedy
1 Is resistance between C01 (female) (1) and chassis normal? • Between C01 (female) (1) and chassis: Approx. 100Ω • Turn starting switch OFF. • Disconnect C01.	YES	Defective governor, pump controller	Replace
	2 YES	Defective battery relay	Replace
	NO	1) Contact between other wiring harness and wiring harness between C01 (female) (1)-H02 (9)-battery relay BR. 2) When light is connected	Replace


E-6 Related electric circuit diagram



BKP00201

E-7 [E316] Abnormality (step-out) in motor is displayed


- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the service code E is not displayed, the problem has been removed.
- ★ If any other service code [E306] – [E318] has occurred at the same time, start troubleshooting from the code except code[E316].
- ★ Check that the fuse is normal.
- ★ Read the precautions given in TESTING AND ADJUSTING, “Adjusting travel of governor motor lever” before carrying out the troubleshooting.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.



020706


E-8 Engine does not start

- ★ When starting motor does not rotate.
- ★ Check that fuse No. 14 is not blown before starting troubleshooting.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.



020706

E-8 Related electric circuit diagram



BKP00202

020706

	Cause	Remedy
	Defective starting motor	Replace
	Defective contact of wiring harness between battery (+)-battery relay B-battery relay M-starting motor terminal B (including battery relay)	Replace
	Defective contact, or disconnection in wiring harness between starting switch terminal C-X07 (10)-E08 (1) -M2 (1)-starting motor terminal S	Replace
	Defective starting switch (between terminals B and C)	Replace
	Defective battery relay	Replace
	Defective contact of wiring harness between battery relay terminal E and revolving frame ground connection terminal	Replace
	Defective contact, or disconnection in wiring harness between starting switch terminal BR-D13-battery relay terminal BR	Replace
	Defective starting switch (between B and BR)	Replace
	Defective contact, or disconnection in wiring harness between battery terminal (+)-M11-H05 (6)-X07 (1)-starting switch terminal B (including fusible link)	Replace
	Lack of battery capacity	Charge or replace

E-9 Engine speed is irregular

- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

a) Idling speed is irregular




Table 1


Controller model code	
03	300
BKP00210	

- ★ The diagram shows monitoring code 03.

020706


	Cause	Remedy
	See N mode	
	Defective adjustment of linkage	Adjust
	Defective injection pump	See S mode
	Defective governor motor	Replace
	Defective contact of wiring harness between starting switch ACC-X07 (17)-C03 (femal) (8), or defective starting switch	Repair or replace
	See E-5	—
	See E-2	—
	See C-14	—

E-9 Related electric circuit diagram



BKP00203

b) There is hunting



020706


Table 1

Controller model code	
03	300
BKP00210	

★ The diagram shows monitoring code 03.

	Cause	Remedy
	See N mode	—
	Defective adjustment of linkage	Adjust
	Defective injection pump	See S mode
	Defective governor motor	Replace
	Defective contact of wiring harness between starting switch ACC – X07 (17) – C03 (female) (8), or defective starting switch	Repair or replace
	See E-5	—
	See E-2	—
	See C-14	—

E-9 Related electric circuit diagram



E-10 Lack of output (engine high idling speed is too low)

- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.





Table 1

Controller model code	
03	300
BKP00210	

- ★ The diagram shows monitoring code 03.

		Cause	Remedy
		See N mode	—
		Defective injection pump	See S mode
Starting motor signal Is voltage between C03 (8) and chassis normal and stable? 7 YES NO • During operation: 20 – 30V		Defective governor motor	Replace
		Defective contact of wiring harness between starting switch ACC – X07 (17) – C03 (female) (8), or defective starting switch	Repair or replace
		See E-5	—
		See E-2	—
		Defective adjustment of governor motor linkage	Adjust
		See S mode	—
		See C-14	—

E-10 Related electric circuit diagram



BKP00203

E-11 Engine does not stop

⚠ Check with the engine stopped (push the fuel control lever of the fuel injection pump to the NO INJECTION position).

- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.
- ★ Read the precautions given in TESTING AND ADJUSTING, "Adjusting travel of governor motor lever" before carrying out the troubleshooting.





Table 1

Controller model code	
03	300
BKP00210	

- ★ The diagram shows monitoring code 03.

Table 2




Note 1: When the starting switch is ON, the controller end is OFF, but a voltage of approx. 20 – 30V is always flowing from starting switch BR, so if the voltage is measured at C01 (1), there is a voltage of 20 – 30V.

020706


	Cause	Remedy
	Defective injection pump	See S mode
	Defective adjustment of linkage	Adjust
	Defective governor motor	Replace
	See E-5	—
	Defective governor, pump controller	Replace
	Contact with 24V wiring harness of wiring harness between starting switch ACC – X07 (17) – C03 (female) (8), or defective starting switch	Replace
	See C-14	—

E-11 Related electric circuit diagram




E-12 Defective operation of battery relay system (engine does not stop)

- ★ This only occurs when the engine is stopped and the starting switch is turned OFF.
- ⚠ Check with the engine stopped (push the fuel control lever of the fuel injection pump to the NO INJECTION position).
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.




020706

Table 1



Note 1: When the starting switch is ON, the controller end is OFF, but a voltage of approx. 20 – 30V is always flowing from starting switch BR, so if the voltage is measured at C01 (1), there is a voltage of 20 – 30V.

E-12 Related electric circuit diagram



BKP00208

020706

TROUBLESHOOTING OF ENGINE SYSTEM (S MODE)

Method of using troubleshooting charts	20-302
S- 1 Starting performance is poor (starting always takes time)	20-306
S- 2 Engine does not start	20-307
(1) Engine does not turn	20-307
(2) Engine turns but no exhaust smoke comes out (fuel is not being injected)	20-308
(3) Exhaust smoke comes out, but engine does not start (fuel is being injected)	20-309
S- 3 Engine does not pick up smoothly	20-310
S- 4 Engine stops during operations	20-311
S- 5 Engine does not rotate smoothly (hunting)	20-312
S- 6 Engine lacks output (no power)	20-313
S- 7 Exhaust gas is black	20-314
S- 8 Oil consumption is excessive, or exhaust gas is blue	20-315
S- 9 Oil becomes contaminated quickly	20-316
S-10 Fuel consumption is excessive	20-317
S-11 Oil is in cooling water	20-318
S-12 Oil pressure caution lamp lights up (drop in oil pressure)	20-319
S-13 Oil level rises (water, fuel in oil)	20-320
S-14 Water temperature becomes too high (overheating)	20-321
S-15 Abnormal noise is made	20-322
S-16 Vibration is excessive	20-323

020706

METHOD OF USING TROUBLESHOOTING CHARTS

This troubleshooting chart is divided into three sections: **questions, check items, and troubleshooting**. The questions and check items are used to pinpoint high probability causes that can be located from the failure symptoms or simple inspection without using troubleshooting tools.

Next, troubleshooting tools or direct inspection are used to check the high probability causes to make final confirmation.

[Questions]

Sections **A** + **B** in the chart on the right corresponds to the items where answers can be obtained from the user. The items in **B** are items that can be obtained from the user, depending on the user's level.

[Check items]

The serviceman carries out simple inspection to narrow down the causes. The items under **C** in the chart on the right correspond to this.

The serviceman narrows down the causes from information **A** that he has obtained from the user and the results of **C** that he has obtained from his own inspection.

[Troubleshooting]

Troubleshooting is carried out in the order of probability, starting with the causes that have been marked as having the highest probability from information gained from **[Questions]** and **[Check items]**.

		Causes		
		(1)	(2)	(3)
Questions	(a)	○		
	(b)			○
	(c)		○	
	(d)	○		
	(e)			○
Check items				
Troubleshooting	i	●		
	ii		●	
	iii			●

020706

TROUBLESHOOTING

METHOD OF USING TROUBLESHOOTING CHARTS

The basic method of using the troubleshooting chart is as follows.

Items listed for **[Questions]** and **[Check items]** that have a relationship with the Cause items are marked with ○, and of these, causes that have a high probability are marked with ◎.

Check each of the **[Questions]** and **[Check items]** in turn, and marked the ○ or ◎ in the chart for items where the problem appeared. The vertical column (Causes) that has the highest number of points is the most probable cause, so start troubleshooting for that item to make final confirmation of the cause.

※1. For **[Confirm recent repair history]** in the **[Questions]** Section, ask the user, and mark the Cause column with △ to use as reference for locating the cause of the failure. However, do not use this when making calculations to narrow down the causes.

※2. Use the △ in the Cause column as reference for **[Degree of use (Operated for long period)]** in the **[Questions]** section as reference. As a rule, do not use it when calculating the points for locating the cause, but it can be included if necessary to determine the order for troubleshooting.

		Causes						
		Seized turbocharger, interference	Clogged air cleaner element	Worn piston ring, cylinder	Clogged, seized injection nozzle	Improper injection timing	Defective injection pump (excessive injection)	
※1	Confirm recent repair history							
※2	Degree of use							
	Operated for long period	△	△	△				

020706

If we look from these three symptoms to find the causes, we find that there is a relationship with five causes. Let us explain here the method of using this causal relationship to pinpoint the most probable cause.

General causes why exhaust gas is black

- Insufficient intake of air
- Improper condition of fuel injection
- Excessive injection of fuel

te combustion)


as is black

njection

Legend

- : Possible causes (judging from Questions and check items)
- △ : Most probable causes (judging from Questions and Check items)
- ⊙ : Possible causes due to length of use (used for a long period)
- : Items to confirm the cause.

		Causes										
		Seized turbocharger interference Clogged air cleaner element Worn piston ring, cylinder Clogged, seized injection nozzle Improper injection timing Defective injection pump (excessive injection) Improper valve clearance Leakage of air between turbocharger and head Defective contact of valve, valve seat Defective injection pump (rack, plunger, seized)										
Questions	Confirm recent repair history											
	Degree of use											
	Operated for long period		△	△						△		
	Suddenly became black	○		○							○	
	Color of exhaust gas											
	Gradually became black	⊙		○					○			
	Blue under light load		○									
	Engine oil must be added more frequently											
	Power was lost											
	Suddenly	○						○			○	
Check items	Gradually		○	○					○	○		
	Non-specified fuel has been used			○							○	
	Noise of interference is heard from around turbocharger	○										
	Dust indicator is red	●										
	Blow-by gas is excessive		○									
	Engine pickup is poor and combustion is irregular	○		○			○	○	○			
	When exhaust manifold is touched immediately after starting engine, temperature of some cylinders is low			○							○	
	Match marks on fuel injection pump are out of alignment				○							
	Seal on injection pump has come off					○						
	Clanging sound is heard from around cylinder head						○					
Troubleshooting	Exhaust noise is abnormal	○		○					○			
	Muffler is crushed								○			
	Leakage of air between turbocharger and head, loose clamp									○		
	When turbocharger is rotated by hand, it is found to be heavy	●										
	When air cleaner is inspected directly, it is found to be clogged		●									
	When compression pressure is measured, it is found to be low			●							●	
	Speed of some cylinders does not change when operating on reduced cylinders				●							
	When check is made using delivery method, injection timing is found to be incorrect					●						
	Injection pump test shows that injection amount is incorrect						●					
	When valve clearance is checked directly it is found to be outside standard value							●				
Remedy	When muffler is removed, exhaust gas color returns to normal								●			
	When control rack is pushed, it is found to be heavy or does not return											●
	Replace											
	Clean											
	Replace											
	Replace											
	Adjust											
	Adjust											
	Replace											
	Repair											
	Replace											
	Replace											



S-1 Starting performance is poor (starting always takes time)

- ★ Check that the monitor panel does not display any abnormality in the governor control system.
General causes why exhaust smoke comes out but engine takes time to start
 - Defective electrical system
 - Insufficient supply of fuel
 - Insufficient intake of air
 - Improper selection of fuel
(At ambient temperature of 10°C or below, use ASTM D975 No. 1)

★ Battery charging rate

Ambient temperature	Charging rate	100%	90%	80%	75%	70%
20°C		1.28	1.26	1.24	1.23	1.22
0°C		1.29	1.27	1.25	1.24	1.23
-10°C		1.30	1.28	1.26	1.25	1.24

- The specific gravity should exceed the value for the charging rate of 70% in the above table.
- In cold areas the specific gravity must exceed the value for the charging rate of 75% in the above table.

Legend

- : Possible causes (judging from Questions and check items)
- : Most probable causes (judging from Questions and Check items)
- △ : Possible causes due to length of use (used for a long period)
- : Items to confirm the cause

		Causes										
		Worn piston ring, cylinder	Defective contact of valve, valve seat	Clogged air cleaner element	Clogged fuel filter, strainer	Starting aid	Defective feed pump strainer	Defective regulator	Defective or deteriorated alternator	Defective or deteriorated battery	Defective injection nozzle	Leakage, clogging, air in fuel piping
		Clogged air cleaner element	Defective air breather hole in fuel tank cap	Defective injection pump (rack, plunger stuck)	Leakage, clogging, air in fuel piping	Clogged air breather hole in fuel tank cap	Defective or deteriorated battery	Defective or deteriorated battery	Defective or deteriorated battery	Defective or deteriorated battery	Defective or deteriorated battery	Defective or deteriorated battery
Questions	Confirm recent repair history											
	Degree of use of machine	Operated for long period										
	Ease of starting	Gradually became worse	○	○	○	○	○	○	○	○	○	○
	Indicator lamp does not light up	Starts when warm										
	Engine oil must be added more frequently											
	Replacement of filters has not been carried out according to Operation Manual											
	Air cleaner clogging caution lamp flashes											
	Non-specified fuel is being used											
	Battery charge lamp is ON											
	Starting motor cranks engine slowly											
Check items	When exhaust manifold is touched immediately after starting engine, temperature of some cylinders is low											
	Engine does not pick up smoothly, and combustion is irregular											
	Blow-by gas is excessive											
	Match marks on fuel injection pump are out of alignment											
	Mud is stuck to fuel tank cap											
	When engine is cranked with starting motor, 1) Little fuel comes out even when injection pump sleeve nut is loosened											
	2) Little fuel comes out even when fuel filter air bleed plug is loosened											
	Leakage from fuel piping											
	There is hunting from engine (rotation is irregular)											
	When compression pressure is measured, it is found to be low											
Troubleshooting	When air cleaner element is inspected directly, it is found to be clogged											
	When fuel filter, strainer are inspected directly, they are found to be clogged											
	When feed pump strainer is inspected directly, it is found to be clogged											
	Heater mount does not become warm											
	Is voltage 26 – 30V between alternator terminal R and terminal E with engine at low idling?											
	Yes *											
	No											
	Either specific gravity of electrolyte or voltage of battery is low											
	Speed does not change when operation of certain cylinders is stopped											
	When check is made using delivery method, injection timing is found to be incorrect											
Remedy	When control rack is pushed, it is found to be heavy or does not return (when blind cover at rear of pump is removed, it can be seen that plunger control sleeve does not move)											
	When fuel cap is inspected directly, it is found to be clogged											

* It is not permitted to replace only the regulator.

S-2 Engine does not start

(1) Engine does not turn

General causes why engine does not turn

- Internal parts of engine seized
 - ★ If internal parts of the engine are seized, carry out troubleshooting for "Engine stops during operations".
- Defective electrical system

Legend

- : Possible causes (judging from Questions and check items)
- ⊙ : Most probable causes (judging from Questions and Check items)
- △ : Possible causes due to length of use (used for a long period)
- : Items to confirm the cause.

		Causes							
		Defective wiring of starting circuit	Defective or deteriorated battery	Defective starting motor	Broken ring gear	Defective safety relay or safety switch	Defective battery relay	Defective battery terminal connection	Defective starting switch
Questions	Confirm recent repair history								
	Degree of use of machine	Operated for long period	△	△					
	Condition of horn when starting switch is turned ON	Horn sounds	⊙				○	○	
		Horn does not sound or volume is low	⊙						
	When starting switch is turned to START, pinion moves out, but	Makes grating noise		⊙	⊙				
		Soon disengages again			⊙				
		Makes rattling noise and does not turn	⊙						
	When starting switch is turned to START, pinion does not move out								
	When starting switch is turned to ON, there is no clicking sound						⊙		
	Battery terminal is loose						⊙		
Check items	When battery is checked, battery electrolyte is found to be low	⊙							
	Specific gravity of electrolyte, voltage of battery is low	●							
	For the following conditions 1) - 5), turn the starting switch OFF, connect the cord, and carry out troubleshooting at ON								
	1) When terminal B and terminal C of starting switch are connected, engine starts								●
	2) When terminal B and terminal C of starting motor are connected, engine starts		●						
	3) When terminal B and terminal C of safety relay are connected, engine starts					●			
	4) When terminal of safety switch and terminal B of starting motor are connected, engine starts					●			
	5) There is no 24V between battery relay terminal M and terminal E						●		
	When ring gear is inspected directly, tooth surface is found to be chipped			●					
Remedy		—	Replace	Replace	Replace	Replace	Replace	Replace	Replace

(2) Engine turns but no exhaust smoke comes out (fuel is not being injected)

- ★ Check that the monitor panel does not display any abnormality in the governor control system.

General causes why engine turns but no exhaust smoke comes out

- Supply of fuel impossible
- Supply of fuel is extremely small
- Improper selection of fuel (particularly in winter)

★ Standards for use of fuel

Type of fluid	Ambient temperature							
	-22 -30	-4 -20	14 -10	32 0	50 10	68 20	86 30	104°F 40°C
Diesel fuel								

Legend

- : Possible causes (judging from Questions and check items)
 ⊙ : Most probable causes (judging from Questions and Check items)
 △ : Possible causes due to length of use (used for a long period)
 ● : Items to confirm the cause.

	Questions	Check items	Troubleshooting	Causes							
				Broken injection pump drive shaft, key	Defective injection pump (rack, plunger seized)	Seized, broken feed pump piston	Clogged fuel filter, strainer	Clogged feed pump strainer	Clogged, leaking fuel piping	Improper air breather hole in fuel tank cap	Improper fuel used
	Confirm recent repair history										
	Degree of use of machine Operated for long period				△	△			△		
	Exhaust smoke suddenly stops coming out (when starting again)	⊙	⊙	⊙							
	Replacement of filters has not been carried out according to Operation Manual				⊙	⊙					
	There is leakage from fuel piping							⊙			
	Mud is stuck to fuel tank cap								⊙		
	When fuel filter is drained, fuel does not come out									⊙	
	When engine is cranked with starting motor, 1) Injection pump coupling does not turn 2) No fuel comes out even when fuel filter air bleed plug is loosened 3) No fuel spurts out even when injection pipe sleeve nut is loosened	⊙ ⊙ ⊙				○ ○ ○				○	
	Rust and water are found when fuel tank is drained					○	○				
	Inspect injection pump directly		●								
	When control rack is pushed, it is found to be heavy, or does not return		●								
	Inspect feed pump directly			●							
	When fuel filter, strainer are inspected directly, they are found to be clogged				●					●	
	When feed pump strainer is inspected directly, it is found to be clogged					●					
	When fuel cap is inspected directly, it is found to be clogged								●		
	Remedy	Replace	Replace	Replace	Clean	Clean	Correct	Correct	Replace		

TROUBLESHOOTING

S-2

(3) Exhaust smoke comes out but engine does not start
(Fuel is being injected)

- ★ General causes why exhaust smoke comes out but engine does not start
- Lack of rotating force due to defective electrical system
 - Insufficient supply of fuel
 - Insufficient intake of air
 - Improper selection of fuel and oil

Legend

- : Possible causes (judging from Questions and check items)
 ⊙ : Most probable causes (judging from Questions and Check items)
 △ : Possible causes due to length of use (used for a long period)
 ● : Items to confirm the cause.

		Causes											
		Defective, broken valve system (valve, rocker lever, etc.) Defective injection pump (rack, plunger stuck) Worn piston ring, cylinder liner Clogged fuel filter, strainer Clogged feed pump strainer Electrical air cleaner element Defective intake air heater Leakage or deteriorated battery Clogged clogging, air in fuel system Clogged injection nozzle, defective spray Improper fuel used											
Questions	Confirm recent repair history												
	Degree of use of machine												
	Operated for long period			△	△	△					△		
	Suddenly failed to start	⊙	⊙										
	When engine is cranked, abnormal noise is heard from around head	⊙											
	Engine oil must be added more frequently		⊙										
	Non-specified fuel is being used		○								○		
	Replacement of filters has not been carried out according to Operation Manual				⊙	⊙	⊙						
	Rust and water are found when fuel tank is drained					⊙							
	Air cleaner clogging caution lamp flashes				⊙	⊙							
	Preheating indicator lamp does not light up						⊙						
	Starting motor cranks engine slowly							⊙					
	Mud is stuck to fuel tank cap										○		
	When fuel lever is placed at FULL position, it does not contact stopper	○											
Check items	When engine is cranked with starting motor, 1) Little fuel comes out even when injection pump sleeve nut is loosened 2) No fuel comes out even when fuel filter air bleed plug is loosened		⊙										
	There is leakage from fuel piping								⊙				
	When exhaust manifold is touched immediately after starting engine, temperature of some cylinders is low									⊙			
	When fuel filter is drained, no fuel comes out											⊙	
Troubleshooting	Remove head cover and check directly	●											
	When control rack is pushed, it is found to be heavy, or does not return		●										
	When compression pressure is measured, it is found to be low			●									
	When fuel filter, strainer are inspected directly, they are found to be clogged				●								●
	When feed pump strainer is inspected directly, it is found to be clogged					●							
	When air cleaner element is inspected directly, it is found to be clogged						●						
	Heater mount does not become warm							●					
	Either specific gravity of electrolyte or voltage of battery is low								●				
	When feed pump is operated, operation is too light or too heavy									●			
	When injection nozzle is tested as individual part, spray condition is found to be poor										●		
	When fuel cap is inspected directly, it is found to be clogged											●	
Remedy		Replace	Replace	Replace	Clean	Clean	Clean	Replace	Replace	Correct	Clean	Clean	Replace

020706

S-3 Engine does not pick up smoothly (follow-up is poor)

- ★ Check that the monitor panel does not display any abnormality in the governor control system.

General causes why engine does not pick up smoothly

- Insufficient intake of air
- Insufficient supply of fuel
- Improper condition of fuel injection
- Improper fuel used

Legend

- : Possible causes (judging from Questions and check items)
 ◎ : Most probable causes (judging from Questions and Check items)
 △ : Possible causes due to length of use (used for a long period)
 ● : Items to confirm the cause.

		Causes										
		Clogged air cleaner element	Clogged fuel filter, strainer	Clogged feed pump strainer	Clogged injection nozzle, defective spray	Seized injection pump plunger	Worn piston ring, cylinder liner	Seized turbocharger, interference	Improper valve clearance	Clogged air breather hole in fuel tank cap	Clogged, leaking fuel piping	Defective contact of valve and valve seat
Questions	Confirm recent repair history											
	Degree of use of machine	△	△	△		△						△
	Operated for long period											
	Replacement of filters has not been carried out according to Operation Manual	◎	◎	◎								
	Non-specified fuel is being used		◎	◎	◎	◎						
	Engine oil must be added more frequently					◎						
	Rust and water are found when fuel tank is drained	◎										
	Air cleaner clogging caution lamp flashes		◎	◎								
	Noise of interference is heard from around turbocharger						◎					
	Engine pick-up suddenly became poor				◎	◎			◎	◎		
Check items	Color of exhaust gas					◎						
	Blue under light load					◎						
	Black	◎		◎		◎						◎
	Clanging sound is heard from around cylinder head						◎					
	Mud is stuck to fuel tank cap							◎				
	There is leakage from fuel piping									◎		
	High idling speed under no load is normal, but speed suddenly drops when load is applied		◎	◎					◎			
	There is hunting from engine (rotation is irregular)		◎	◎	◎				◎			
	When exhaust manifold is touched immediately after starting engine, temperature of some cylinders is low			◎	◎							
	20. Blow-by gas is excessive					◎						
Troubleshooting	When air cleaner element is inspected directly, it is found to be clogged	●										
	When fuel filter, strainer are inspected directly, they are found to be clogged		●									
	When feed pump strainer is inspected directly, it is found to be clogged			●								
	Speed does not change when operation of certain cylinders is stopped				●							
	When control rack is pushed, it is found to be heavy, or does not return					●						
	When compression pressure is measured, it is found to be low						●					●
	When turbocharger is rotated by hand, it is found to be heavy							●				
	When valve clearance is checked directly, it is found to be outside standard value								●			
	When fuel cap is inspected directly, it is found to be clogged									●		
	When feed pump is operated, operation is too light or too heavy										●	
Remedy		Clean	Clean	Clean	Correct	Replace	Replace	Replace	Adjust	Clean	Correct	Replace

020706

S-4 Engine stops during operations

★ Check that the monitor panel fuel level display shows that there is still fuel remaining.
General causes why engine stops during operations

- Seized parts inside engine
- Insufficient supply of fuel
- overheating
- ★ If there is overheating and the engine stops, carry out troubleshooting for overheating.
- Failure in main piston pump
- ★ If the engine stops because of a failure in the main piston pump, carry out troubleshooting for the hydraulic system (H MODE).

Legend

- : Possible causes (judging from Questions and check items)
- ⊙ : Most probable causes (judging from Questions and Check items)
- △ : Possible causes due to length of use (used for a long period)
- : Items to confirm the cause.

		Causes										
		Broken, seized piston, connecting rod	Broken, seized crankshaft bearing	Broken valve system (valve, rocker lever, etc.)	Broken, seized gear train	Clogged fuel pump drive shaft, key	Clogged fuel filter, strainer	Broken, seized pump strainer	Clogged, leaking feed pump piston	Clogged air breather hole in fuel tank cap	Defective injection pump (rack, plunger stuck)	Failure in main pump
Questions	Confirm recent repair history											
	Degree of use of machine											
	Operated for long period					△	△					
	Condition when engine stopped	Abnormal noise was heard and engine stopped suddenly										
		⊙	⊙	⊙	⊙			○		○	⊙	
		Engine stopped slowly										
		⊙	○									
	There was hunting and engine stopped											
	Engine overheated and stopped											
	Replacement of filters has not been carried out according to Operation Manual											
	Non-specified fuel is being used											
Troubleshooting	When feed pump is operated, operation is too light or too heavy											
	Mud is stuck to fuel tank cap											
	Try to turn by hand using barring tool	Does not turn at all										
		⊙	⊙									
		Turns in opposite direction										
				⊙								
	Moves amount of backlash											
	Rust and water are found when fuel tank is drained											
	Metal particles are found when oil is drained											
Troubleshooting	When oil pan is removed and inspection is made directly, it is found to be abnormal											
	When head cover is removed and inspection is made directly, it is found to be abnormal											
	When gear train is inspected, it does not turn											
	When fuel filter, strainer are inspected directly, they are found to be clogged											
	When feed pump strainer is inspected directly, it is found to be clogged											
	Inspect feed pump directly											
	When control rack is pushed, it is found to be heavy, or does not return											
Remedy		Replace	Replace	Replace	Replace	Replace	Clean	Clean	Replace	Correct	Clean	Replace

See troubleshooting of hydraulic, mechanical system (H mode)

S-5 Engine does not rotate smoothly (hunting)

- ★ Check that the monitor panel does not display any abnormality in the governor control system.

General causes why engine does not rotate smoothly

- Air in fuel system
 - Defective governor mechanism
 - Defective electric governor mechanism
- ★ If hunting does not occur when the rod between the governor motor and the injection pump is disconnected, troubleshoot by using the electrical system troubleshooting (E mode).

Legend

- : Possible causes (judging from Questions and check items)
 ◎ : Most probable causes (judging from Questions and Check items)
 △ : Possible causes due to length of use (used for a long period)
 ● : Items to confirm the cause.

		Causes									
		Defective operation of governor	Defective adjustment of governor	Defective operation of governor	Low idling speed is too low	Clogged feed pump strainer	Clogged fuel filter, strainer	Clogged, air in circuit between fuel tank and feed pump	Clogged, air in circuit between feed pump and nozzle	Clogged air breather hole in fuel tank cap	
Questions	Confirm recent repair history										
	Degree of use of machine										
	Operated for long period				△	△					
	Condition of hunting	Occurs at a certain speed range		◎	◎	◎	○				
		Occurs at low idling		○		◎	○	○	○		
		Occurs even when speed is raised		○	○	○				○	
	Replacement of filters has not been carried out according to Operation Manual					◎	◎				
	Rust, water are found when fuel tank is drained					○	○				
	Leakage from fuel piping							◎	◎		
	When feed pump is operated,										
Check items	1) No response, light, return is quick							◎	◎		
	2) No response, light, return is normal							◎			
	Engine speed sometimes rises too far		◎	◎							
	Engine is sometimes difficult to stop		◎		◎						
	Seal on injection pump has come off			◎		◎					
Troubleshooting	When governor lever is moved it is found to be stiff		●		●						
	When injection pump is tested, governor is found to be improperly adjusted			●							
	When control rack is pushed, it is found to be heavy, or does not return				●						
	When fuel cap is inspected directly, it is found to be clogged					●				●	
	When feed pump strainer is inspected directly, it is found to be clogged						●				
	When fuel filter, strainer are inspected directly, they are found to be clogged							●			
Remedy		Adjust	Adjust	Adjust	Adjust	Clean	Clean	Correct	Correct	Clean	

020706

S-6 Engine lacks output (no power)

- ★ Check that the monitor panel does not display any abnormality in the governor control system. Measure the engine speed and judge if the cause is in the engine or in the chassis.

General causes why engine lacks output

- Insufficient intake of air
- Insufficient supply of fuel
- Improper condition of fuel injection
- Improper fuel used
(if non-specified fuel is used, output drops)
- Lack of output due to overheating
- ★ If there is overheating and insufficient output, carry out troubleshooting for overheating.

Legend

- : Possible causes (judging from Questions and check items)
 ⊙ : Most probable causes (judging from Questions and Check items)
 △ : Possible causes due to length of use (used for a long period)
 ● : Items to confirm the cause.

Engine or in the chassis.			Causes														
Several causes why engine lacks output																	
Insufficient intake of air																	
Insufficient supply of fuel																	
Improper condition of fuel injection																	
Improper fuel used																	
If non-specified fuel is used, output drops)																	
Lack of output due to overheating																	
If there is overheating and insufficient output,																	
Carry out troubleshooting for overheating.																	
Legend																	
○ : Possible causes (judging from Questions and check items)																	
◎ : Most probable causes (judging from Questions and Check items)																	
△ : Possible causes due to length of use (used for a long period)																	
● : Items to confirm the cause.																	
Questions	Confirm recent repair history																
	Degree of use of machine	Operated for long period	△		△	△	△				△						
	Power was lost	Suddenly		◎													◎
		Gradually	○		○	○	○	○			○						
	Engine oil must be added more frequently				◎												
	Replacement of filters has not been carried out according to Operation Manual		◎			◎	◎										
	Non-specified fuel is being used					◎	◎	◎	◎								
	Air cleaner clogging caution lamp flashes		◎														
	Color of exhaust gas	Black	◎	◎													
		Blue under light load			◎												
	Noise of interference is heard from around turbocharger			◎													
	Blow-by gas is excessive				◎												
	Engine pickup is poor and combustion is irregular			◎				◎					○	○			
	High idling speed under no load is normal, but speed suddenly drops when load is applied						◎	◎						○			
Check items	When exhaust manifold is touched immediately after starting engine, temperature of some cylinders is low							◎	○								
	There is hunting from engine (rotation is irregular)						○	○					○	○			
	Clanging sound is heard from around cylinder head									◎							
	High idling speed of engine is low									○			◎				
	Leakage from fuel piping												◎				
	Water temperature gauge is in red range																◎
	Troubleshooting	When air cleaner element is inspected directly, it is found to be clogged		●													
When turbocharger is rotated by hand, it is found to be heavy			●														
When compression pressure is measured, it is found to be low				●						●							
When fuel filter, strainer are inspected directly, they are found to be clogged					●												
When feed pump strainer is inspected directly, it is found to be clogged						●											
Speed does not change when operation of certain cylinders is stopped							●										
When control rack is pushed, it is found to be heavy, or does not return								●									
When valve clearance is checked directly, it is found to be outside standard value									●								
When lever is placed at FULL position, it does not contact stopper											●						
When feed pump is operated, operation is too light or too heavy													●				
When fuel cap is inspected directly, it is found to be clogged														●			
		Remedy		Clean	Replace	Replace	Clean	Clean	Correct	Replace	Adjust	Replace	Adjust	Correct	Clean		
																Carry out troubleshooting for overheating	

Carry out troubleshooting for overheating

S-7 Exhaust smoke is black (incomplete combustion)

General causes why exhaust smoke is black

- Insufficient intake of air
- Improper condition of fuel injection
- Excessive injection of fuel

Legend

- : Possible causes (judging from Questions and check items)
- ⊙ : Most probable causes (judging from Questions and Check items)
- △ : Possible causes due to length of use (used for a long period)
- : Items to confirm the cause.

(incomplete combustion)			Causes											
			Seized turbocharger, interference	Clogged air cleaner element	Worn piston ring, cylinder liner	Clogged injection nozzle, defective liner	Improper injection timing	Defective injection pump	Improper valve clearance (excessive injection)	Crushed, clogged muffler	Leakage of air between turbocharger and head	Defective contact of valve and valve seat	Defective injection pump (rack, plunger seized)	
Several causes why exhaust smoke is black														
Insufficient intake of air														
Improper condition of fuel injection														
Excessive injection of fuel														
Legend														
○ : Possible causes (judging from Questions and check items)														
⊙ : Most probable causes (judging from Questions and Check items)														
△ : Possible causes due to length of use (used for a long period)														
● : Items to confirm the cause.														
Questions	Confirm recent repair history													
	Degree of use of machine	Operated for long period		△	△	△					△			
	Color of exhaust gas	Suddenly became black	⊙										○	
		Gradually became black	⊙	⊙						○				
		Blue under light load			⊙									
	Engine oil must be added more frequently				⊙									
	Power was lost	Suddenly	⊙			○			○			○		
		Gradually		○	○					○	○			
	Non-specified fuel is being used					○							○	
	Noise of interference is heard from around turbocharger		⊙											
Check items	Air cleaner clogging caution lamp flashes			⊙										
	Blow-by gas is excessive				⊙									
	Engine pickup is poor and combustion is irregular		○			⊙		○	○	○		○		
	When exhaust manifold is touched immediately after starting engine, temperature of some cylinders is low					⊙						○		
	Match marks on fuel injection pump are out of alignment						⊙							
	Seal on injection pump has come off							⊙						
	Clanging sound is heard from around cylinder head								⊙					
	Exhaust noise is abnormal		○			○				⊙				
	Muffler is crushed									⊙				
	Leakage of air between turbocharger and head, loose clamp										⊙			
Troubleshooting	When turbocharger is rotated by hand, it is found to be heavy		●											
	When air cleaner is inspected directly, it is found to be clogged			●										
	When compression pressure is measured, it is found to be low				●							●		
	Speed does not change when operation of certain cylinders is stopped					●								
	When check is made using delivery method, injection timing is found to be incorrect						●							
	Injection pump test shows that injection amount is incorrect							●						
	When valve clearance is checked directly it is found to be outside standard value								●					
	When muffler is removed, exhaust color returns to normal									●				
	When control rack is pushed, it is found to be heavy, or does not return												●	
			Remedy	Replace	Clean	Replace	Replace	Adjust	Adjust	Adjust	Replace	Correct	Replace	Replace

S-8 Oil consumption is excessive (or exhaust smoke is blue)

- ★ Do not run the engine at idling for more than 20 minutes continuously. (Both low and high idling)

General causes why oil consumption is excessive

- Abnormal combustion of oil
- External leakage of oil
- Wear of lubrication system

			Causes												
			Broken piston ring	Worn piston ring, cylinder liner	Clogged breather or breather hose	Leakage from oil filter or oil cooler	Leakage from oil piping	Leakage from oil drain plug	Broken oil pan or cylinder head	Worn oil cooler	Worn seal at turbine end	Worn, broken rear seal	Turbocharger	Dust sucked in from intake system	Worn valve (stem, guide), broken seal
Questions	Confirm recent repair history														
	Degree of use of machine	Operated for long period		△						△	△			△	
	Oil consumption suddenly increased		◎						○						
	Engine oil must be added more frequently			◎					○						
	Engine oil becomes contaminated quickly		○	◎	○										
	Exhaust smoke is blue under light load		◎	◎											
	Amount of blow-by gas	Excessive	◎	◎							○				○
		None			◎										
	Area around engine is dirty with oil					◎	◎	◎	◎						
	There is oil in engine cooling water								◎						
	When exhaust pipe is removed, inside is found to be dirty with oil									◎					○
	When turbocharger air supply pipe is removed, inside is found to be dirty with oil										◎				
	Oil level in PTO chamber rises											◎			
	Clamps for intake system are loose												◎		
Check items	When compression pressure is measured, it is found to be low		●	●											
	When breather element is inspected, it is found to be clogged with dirty oil				●										
	There is external leakage of oil from engine					●	●	●	●						
	Pressure-tightness test of oil cooler shows there is leakage								●						
	Excessive play of turbocharger shaft									●	●				
	Inspect rear seal directly											●			
	When intake manifold is removed, dust is found inside												●		
	When intake manifold is removed, inside is found to be dirty with oil													●	
		Remedy	Replace	Replace	Clean	Correct	Correct	Correct	Correct	Replace	Replace	Replace	Correct	Correct	Correct

020706

S-9 Oil becomes contaminated quickly

General causes why oil becomes contaminated quickly

- Intake of exhaust gas due to internal wear
- Clogging of lubrication passage
- Improper fuel
- Improper oil used
- Operation under excessive load

		Causes									
		Worn piston ring, cylinder liner	Clogged breather, breather hose	Clogged oil filter	Worn valve, valve guide	Clogged oil cooler	Defective turbocharger drain pipe	Defective seal at turbocharger turbine end	Exhaust safety valve	Exhaust smoke is black	
Questions	Confirm recent repair history										
	Degree of use of machine										
	Engine oil must be added more frequently										
	Non-specified oil is being used										
	Color of exhaust gas										
	Blue under light load										
	Black										
	Amount of blow-by gas										
	Excessive										
	None										
Check items	When oil filter is inspected, metal particles are found										
	When exhaust pipe is removed, inside is found to be dirty with oil										
	Engine oil temperature rises quickly										
Troubleshooting	When compression pressure is measured, it is found to be low										
	When breather element is inspected directly, hose is broken or is found to be clogged with dirty oil										
	When oil filter is inspected directly, it is found to be clogged										
	When oil cooler is inspected directly, it is found to be clogged										
	Turbocharger drain tube is clogged										
	Excessive play of turbocharger shaft										
	When safety valve is directly inspected, spring is found to be catching or broken										
Remedy		Replace	Clean	Replace	Replace	Clean	Clean	Replace	Replace		

Carry out troubleshooting for "Exhaust smoke is black".

020706

S-10 Fuel consumption is excessive

General causes why fuel consumption is excessive

- Leakage of fuel
- Improper condition of fuel injection
- Excessive injection of fuel

Legend

- : Possible causes (judging from Questions and check items)
- ◎ : Most probable causes (judging from Questions and Check items)
- △ : Possible causes due to length of use (used for a long period)
- : Items to confirm the cause.

			Causes								
			Defective injection pump (excessive injection)	Defective nozzle holder spray	Defective injection pump plunger	Defective fuel injection timing	External leakage from fuel piping	Leakage of fuel inside head cover	Defective oil seal inside feed pump	Defective adjustment of fuel control linkage	
Questions	Confirm recent repair history										
	Degree of use of machine	Operated for long period		△	△				△		
	Condition of fuel consumption	More than for other machines of same model	◎			○					
		Gradually increased		○	○						
		Suddenly increased					○	○			
	Exhaust smoke color	Black	◎	○		○				○	
		White						○			
	Seal on injection pump has come off		◎								
	There is irregular combustion			◎							
	When exhaust manifold is touched immediately after starting engine, temperature of some cylinders is low			◎	○						
Check items	Match mark on injection pump is misaligned					◎					
	There is external leakage of fuel from engine						◎				
	Engine oil level rises and smells of diesel fuel		○					◎	◎		
	Engine low idling speed is high		○							◎	
Troubleshooting	Injection pump measurement shows that injection amount is excessive		●								
	Speed does not change when operation of certain cylinders is stopped			●							
	When control rack is pushed, it is found to be heavy, or does not return				●						
	When check is made using delivery method, injection timing is found to be incorrect					●					
	Remove head cover and inspect directly							●			
	Remove feed pump and inspect directly								●		
	When engine speed is measured, low idling speed is found to be high									●	
			Remedy	Adjust	Replace	Replace	Adjust	Correct	Correct	Correct	Adjust

S-11 Oil is in cooling water, or water spurts back, or water level goes down

General causes why oil is in cooling water

- Internal leakage in lubrication system
- Internal leakage in cooling system

Legend

- : Possible causes (judging from Questions and check items)
 ◎ : Most probable causes (judging from Questions and Check items)
 △ : Possible causes due to length of use (used for a long period)
 ● : Items to confirm the cause.

		Causes				
		Broken oil cooler core, O-ring	Broken cylinder head, head gasket	Insufficient protrusion of liner	Broken liner O-ring, holes caused by pitting	Internal cracks in cylinder block
Questions	Confirm recent repair history					
	Degree of use of machine	Operated for long period	△		△	
	Oil level	Suddenly increased	○	○		
		Gradually increased			○	○
Check items	Hard water is being used as cooling water	○			○	
	Engine oil level has risen, oil is cloudy white	◎			○	○
	Excessive air bubbles inside radiator, spurts back		◎	◎		
Troubleshooting	Pressure-tightness test of oil cooler shows there is leakage	●				
	Pressure-tightness test of cylinder head shows there is leakage		●			
	Remove cylinder head and inspect directly			●		
	Remove oil pan and inspect directly				●	●
Remedy		Replace	Replace	Replace	Replace	Replace

S-12 Oil pressure caution lamp lights up (drop in oil pressure)

- ★ Check that the monitor panel engine oil level lamp is not lighted up.

- ★ When the oil pressure sensor is normal (see M mode).

General causes why oil pressure lamp lights up

- Leakage, clogging, wear of lubricating system
- Defective oil pressure control
- Improper oil used (improper viscosity)
- Deterioration of oil due to overheating

- ★ Standards for engine oil selection

Type of fluid	Ambient temperature							
	-22 -30	-4 -20	14 -10	32 0	50 10	68 20	86 30	104°F 40°C
Engine oil								

Causes									
Clogged oil filter									
Worn bearing, journal									
Clogged strainer inside oil pan									
Clogged, broken oil pipe inside oil pan									
Broken suction pipe inside oil pan									
Defective oil pump									
Defective regulator valve									
Leaking main relief valve									
Defective oil pressure sensor									
Water, fuel in oil									

Legend

- : Possible causes (judging from Questions and check items)
- ⊙ : Most probable causes (judging from Questions and Check items)
- △ : Possible causes due to length of use (used for a long period)
- : Items to confirm the cause.

Questions	Confirm recent repair history																		
	Degree of use of machine	Operated for long period	△	△					△										
	Replacement of filters has not been carried out according to Operation Manual		◎																
	Non-specified oil is being used		○	○															
Check items	Condition when oil pressure lamp lights up	Lights up at low idling		◎							○								
		Lights up at low, high idling			◎	◎	◎	◎	○	○									
		Sometimes lights up								◎	◎						○		
	There is clogging, leakage from hydraulic piping (external)											◎							
	Metal particles are found when oil is drained			◎															
	Metal particles are stuck to oil filter element			◎					○										
	Oil is cloudy white or smells of diesel oil																		◎
	Troubleshooting	When oil filter is inspected directly, it is found to be clogged		●	●														
Remove oil pan and inspect directly				●	●	●													
Oil pump rotation is heavy, there is play								●											
There is catching of relief valve or regulator valve, spring or valve guide is broken									●	●									
When oil pressure is measured, it is found to be within standard value																	●		
		Remedy		Clean	Clean	Clean	Clean	Correct	Replace	Adjust	Adjust	Correct	Replace	—					
														Carry out troubleshooting for "Oil level rises".					

S-13 Oil level rises (water, fuel in oil)

- ★ If there is oil in the cooling water, carry out troubleshooting for "Oil is in cooling water".

General causes why oil level rises

- Water in oil
- Fuel in oil (diluted, and smells of diesel fuel)
- Entry of oil from other component

Legend

- : Possible causes (judging from Questions and check items)
 ⊙ : Most probable causes (judging from Questions and Check items)
 △ : Possible causes due to length of use (used for a long period)
 ● : Items to confirm the cause.

		Causes											
		Broken oil cooler core, O-ring Defective nozzle holder sleeve Broken cylinder head, head gasket (precombustion chamber) Clogged water pump breather hole, defective seal Worn, damaged rear seal surface Defective main pump seal Leakage of fuel inside head cover Defective part inside injection pump Defective thermostat seal (flange type) Damaged liner O-ring, holes made by pitting Cracks inside cylinder block											
Questions	Confirm recent repair history												
	Degree of use of machine		△		△	△	△					△	
	When engine is first started, drops of water come from muffler		⊙										
	Exhaust smoke is white		⊙					○		○	○		
	There is oil in radiator cooling water		⊙	○	○							○	○
	Leave radiator cap open. When engine is run at idling, an abnormal number of bubbles appear, or water spurts back			⊙								○	
	Water pump breather hole is clogged with mud				⊙								
	When water pump breather hole is cleaned, water comes out				⊙								
	Oil level goes down in damper chamber					⊙							
	Oil level goes down in hydraulic tank						⊙						
	Engine oil smells of diesel fuel							⊙	⊙	⊙			
	Fuel must be added more frequently							⊙	⊙	⊙			
Troubleshooting	Pressure-tightness test of oil cooler shows there is leakage	●											
	Pressure-tightness test of cylinder head shows there is leakage		●										
	When compression pressure is measured, it is found to be low			●									
	Remove water pump and inspect directly				●								
	Remove rear seal and inspect directly					●							
	When main pump is removed, seal is found to be damaged						●						
	Remove head cover and inspect directly							●					
	Remove injection pump and inspect directly								●				
	Defective contact of thermostat seal valve									●			
	Remove oil pan and check directly										●	●	
Remedy		Replace	Replace	Replace	Replace	Correct	Replace	Correct	Replace	Replace	Replace	Replace	Replace

S-14 Water temperature becomes too high (overheating)

- ★ Check that the monitor panel coolant level caution lamp is not lighted up.
- ★ When the monitor panel water temperature gauge is normal, go to troubleshooting of machine monitor system (M mode).

General causes why water temperature becomes too high

- Lack of cooling air (deformation, damage of fan)
- Drop in heat dissipation efficiency
- Defective cooling circulation system
- ★ Carry out troubleshooting for chassis.

Legend

- : Possible causes (judging from Questions and check items)
- ◎ : Most probable causes (judging from Questions and Check items)
- △ : Possible causes due to length of use (used for a long period)
- : Items to confirm the cause.

Pump is not lighted up.
 When the monitor panel water temperature gauge is normal, go to troubleshooting of machine monitor system (M mode).
 Several causes why water temperature becomes too high.

Lack of cooling air (deformation, damage of fan)
 Drop in heat dissipation efficiency
 Defective cooling circulation system
 Carry out troubleshooting for chassis.

Legend
 ○ : Possible causes (judging from Questions and check items)
 ◎ : Most probable causes (judging from Questions and Check items)
 △ : Possible causes due to length of use (used for a long period)
 ● : Items to confirm the cause.

		Causes											
		Broken water pump	Clogged, crushed radiator fins	Clogged radiator core	Defective thermostat (does not open)	Defective water temperature gauge	Fan belt slipping, worn fan pulley	Clogged, broken oil cooler	Defective radiator pressure valve	Broken head, head gasket	Damaged liner O-ring, holes made by pitting	External leakage from cooling water piping	
Questions	Confirm recent repair history												
	Degree of use of machine	Operated for long period		△	△						△	△	
	Condition of overheating	Suddenly overheated	◎				○						
		Always tends to overheat		◎	◎	○	○						
	Water temperature gauge	Rises quickly			◎								
		Does not go down				◎							
Check items	Fan belt whines under sudden load						◎						
	Cloudy white oil is floating on cooling water							◎					
	Cooling water flows out from overflow hose								◎				
	Excessive air bubbles inside radiator, water spurts back									◎			
	Engine oil level has risen, oil is cloudy white						○				◎		
	There is play when fan pulley is rotated		◎										
	Radiator shroud, inside of underguard are clogged with dirt or mud			◎									
	When light bulb is held behind radiator, no light passes through			◎									
	Water is leaking because of cracks in hose or loose clamps											◎	
	When belt tension is inspected, it is found to be loose						◎						
Troubleshooting	Temperature difference between top and bottom radiator tanks is excessive		●										
	Temperature difference between top and bottom radiator tanks is slight			●									
	When water filler port is inspected, core is found to be clogged				●								
	When function test is carried out on thermostat, it does not open even at cracking temperature					●							
	When water temperature is measured, it is found to be normal					●							
	When oil cooler is inspected directly, it is found to be clogged						●						
	When measurement is made with radiator cap tester, set pressure is found to be low							●					
	When compression pressure is measured, it is found to be low								●				
	Remove oil pan and inspect directly									●			
Remedy		Replace	Correct	Correct	Replace	Replace	Correct	Replace	Replace	Replace	Replace	Correct, replace	

S-15 Abnormal noise is made

★ Judge if the noise is an internal noise or an external noise.

General causes why abnormal noise is made

- Abnormality due to defective parts
- Abnormal combustion
- Air sucked in from intake system

Legend

- : Possible causes (judging from Questions and check items)
- ◎ : Most probable causes (judging from Questions and Check items)
- △ : Possible causes due to length of use (used for a long period)
- : Items to confirm the cause.

		Causes											
		Excessive wear of piston ring, cylinder liner	Seized turbocharger, interference	Missing, seized bushing	Clogged, seized injection nozzle	Defective injection pump	Deformed fan, fan belt interference	Defective injection pump (rack, plunger seized)	Defective adjustment of valve clearance	Broken dynamic valve system	Improper gear train backlash	Leakage of air between turbocharger and head	Defect inside muffler (dividing board out of position)
Questions	Confirm recent repair history												
	Degree of use of machine												
	Operated for long period	△											
	Condition of abnormal noise												
	Gradually occurred	○						○					
	Suddenly occurred		○	○					○				
	Non-specified fuel is being used				○	○							
	Engine oil must be added more frequently	◎											
	Color of exhaust gas												
	Blue under light load	◎											
	Black		◎					○			○		
	Metal particles are found in oil filter	◎		◎									
	Blow-by gas is excessive	◎											
	Noise of interference is heard from around turbocharger		◎										
Check items	Engine pickup is poor and combustion is abnormal				◎								
	When exhaust manifold is touched immediately after starting engine, temperature of some cylinders is low				◎	○							
	Seal on injection pump has come off					◎							
	Abnormal noise is loud when accelerating engine				○	○	○	○	○				
	Clanging sound is heard from around cylinder head							◎	◎				
	Leakage of air between turbocharger and head, loose clamp										◎		
	Vibrating noise is heard from around muffler											◎	
	When compression pressure is measured, it is found to be low	●											
	When turbocharger is rotated by hand, it is found to be heavy		●										
	Remove gear cover and inspect directly			●						●			
	Speed does not change when operation of certain cylinders is stopped				●								
	When control rack is pushed, it is found to be heavy, or does not return					●							
	Injection pump test shows that injection amount is incorrect						●						
	Fan is deformed, belt is loose							●					
Troubleshooting	When valve clearance is checked, it is found to be outside standard value								●				
	Remove cylinder head cover and inspect directly									●			
	When muffler is removed, abnormal noise disappears												●
Remedy		Replace	Replace	Replace	Replace	Correct	Replace	Correct	Replace	Correct	Replace	Replace	Replace

S-16 Vibration is excessive

- ★ If there is abnormal noise together with the vibration, carry out troubleshooting for "Abnormal noise is made".

General causes why vibration is excessive

- Defective parts (abnormal wear, breakage)
- Improper alignment
- Abnormal combustion

			Causes							
			Worn connecting rod, main bearing	Worn balancer, cam bushing	Loose engine mounting bolts	Broken part inside output shaft, broken cushion	Improper gear train backlash (damper)	Defective dynamic valve system	Defective injection pump (excessive injection)	
Questions	Confirm recent repair history									
	Degree of use of machine	Operated for long period	△	△	△					
	Condition of vibration	Suddenly increased				○		○		
		Gradually increased	○	○	○					
	Non-specified oil is being used		○	○						
	Metal particles are found in oil filter		◎	◎						
	Metal particles are found when oil is drained		◎	◎						
	Oil pressure is low at low idling		○	○						
	Vibration occurs at mid-range speed				○	○				
	Vibration follows engine speed				○	○	○			
Check items	Exhaust smoke is black							◎	○	
	Seal on injection pump has come off								◎	
Troubleshooting	Remove oil pan and inspect directly		●							
	Remove side cover and inspect directly			●						
	Inspect directly for loose engine mounting bolts, broken cushion				●					
	Inspect inside of output shaft (damper) directly					●				
	Remove front cover and inspect directly						●			
	Remove head cover and inspect directly							●		
	Injection pump test shows that injection amount is incorrect								●	
			Remedy	Replace	Replace	Replace	Replace	Correct	Replace	Adjust

Legend

- : Possible causes (judging from Questions and check items)
 ◎ : Most probable causes (judging from Questions and Check items)
 △ : Possible causes due to length of use (used for a long period)
 ● : Items to confirm the cause.

TROUBLESHOOTING OF GOVERNOR, PUMP CONTROLLER (PUMP CONTROL SYSTEM) (C MODE)

Points to remember when carrying out troubleshooting of pump controller system	20-352
Action taken by controller and condition of machine when abnormality occurs	20-354
Judgement table for governor, pump controller and hydraulic related parts	20-360
Electrical circuit diagram of C mode systems	20-362
C- 1 Abnormality in controller power source (controller LED is OFF)	20-364
C- 2 [E232] Short circuit in front pump TVC solenoid system is displayed	20-365
C- 3 [E233] Disconnection in front pump TVC solenoid system is displayed	20-367
C- 4 [E236] Short circuit in rear pump TVC solenoid system is displayed	20-369
C- 5 [E237] Disconnection in rear pump TVC solenoid system is displayed	20-371
C- 6 [E202] Short circuit in LS select solenoid system is displayed	20-373
C- 7 [E212] Disconnection in LS select solenoid system is displayed	20-374
C- 8 [E203] Short circuit in swing holding brake solenoid system is displayed	20-375
C- 9 [E213] Disconnection in swing holding brake solenoid system is displayed	20-377
C-10 [E204] Short circuit in pump merge/divider solenoid system is displayed	20-379
C-11 [E214] Disconnection in pump merge/divider solenoid system is displayed	20-380
C-12 [E206] Short circuit in travel speed solenoid system is displayed	20-381
C-13 [E216] Disconnection in travel speed solenoid system is displayed	20-382
C-14 [E217] Model selection input error is displayed	20-383
C-15 [E222] Short circuit in LS-EPC solenoid system is displayed	20-385
C-16 [E223] Disconnection in LS-EPC solenoid system is displayed	20-386
C-17 [E224] Abnormality in front pump pressure sensor system is displayed	20-387
C-18 [E225] Abnormality in rear pump pressure sensor system is displayed	20-388
C-19 [E226] Abnormality in pressure sensor power source is displayed	20-389
C-20 [E227] Abnormality in engine speed sensor system is displayed	20-390
C-21 Abnormality in machine push-up solenoid system (no service code displayed)	20-391

020706

POINTS TO REMEMBER WHEN TROUBLESHOOTING PUMP CONTROLLER SYSTEM

1. Points to remember if abnormality returns to normal by itself

In the following two cases, there is a high probability that the same problem will occur again, so it is desirable to follow up this problem carefully.

- 1) If any abnormality returns to normal by itself, or
- 2) If the connector is disconnected and the T-adapter is inserted, or if the T-adapter is removed and the connector is returned to its original position when carrying out troubleshooting of the failure, and the service code is no longer displayed, or if the monitor display returns to normal.
- 3) After completing troubleshooting, always erase the user code from memory.

2. User code memory retention function

When displaying the abnormality code in memory and carrying out troubleshooting, note down the content of the display, then erase the display. After trying to re-enact the problem, carry out troubleshooting according to the failure code that is displayed.

(There are cases where mistaken operation or abnormalities that occur when the connector is disconnected are recorded by the memory retention function. Erasing the data in this way saves any wasted work.)

ACTION TAKEN BY CONTROLLER WHEN ABNORMALITY
OCCURS AND PROBLEMS ON MACHINE

User code	Service code	Abnormal system	Nature of abnormality
E02	E232	Short circuit in front pump TVC solenoid system	1. Short circuit with ground, short circuit inside front pump TVC solenoid 2. Short circuit with power source, short circuit with ground in wiring harness between controller C02 (8) and TVC solenoid C13 (1) ((+) side) 3. Short circuit with power source in wiring harness between controller C02 (18) and TVC solenoid C13 (2) ((-) side) 4. Defective governor, pump controller
	E233	Disconnection in front pump TVC solenoid system	1. Disconnection, defective contact inside front pump TVC solenoid 2. Disconnection, defective contact in wiring harness between controller C02 (8) and TVC solenoid C13 (1) ((+) side) 3. Disconnection, defective contact, short circuit with ground in wiring harness between controller C02 (18) and TVC solenoid C13 (2) ((-) side) 4. Defective governor, pump controller
	E236	Short circuit in rear pump TVC solenoid system	1. Short circuit with ground, short circuit inside rear pump TVC solenoid 2. Short circuit with power source, short circuit with ground in wiring harness between controller C02 (9) and TVC solenoid C04 (1) ((+) side) 3. Short circuit with power source in wiring harness between controller C02 (19) and TVC solenoid C04 (2) ((-) side) 4. Defective governor, pump controller
	E237	Disconnection in rear pump TVC solenoid system	1. Disconnection, defective contact inside rear pump TVC solenoid 2. Disconnection, defective contact in wiring harness between controller C02 (9) and TVC solenoid C04 (1) ((+) side) 3. Disconnection, defective contact, short circuit with ground in wiring harness between controller C02 (19) and TVC solenoid C04 (2) ((-) side) 4. Defective governor, pump controller
E03	E203	Short circuit in swing holding brake solenoid system	1. Short circuit with ground, short circuit inside swing holding brake solenoid 2. Short circuit with ground in wiring harness between controller C01 (3) and solenoid V04 (2) ((+) side) 3. Defective governor, pump controller
	E213	Disconnection in swing holding brake solenoid system	1. Disconnection, defective contact inside swing holding brake solenoid 2. Disconnection, defective contact, short circuit with power source in wiring harness between controller C01 (3) and solenoid V04 (2) ((+) side) 3. Disconnection, defective contact in wiring harness between solenoid V04 (1) and chassis ground ((-) side) 4. Defective governor, pump controller

020706

TROUBLESHOOTING

ACTION TAKEN BY CONTROLLER WHEN ABNORMALITY OCCURS AND PROBLEMS ON MACHINE

Condition when normal (voltage, current, resistance)	Action by controller when abnormality is detected	Problem that appears on machine when there is abnormality
Resistance of solenoid: 10 – 22 Ω	1. Makes output to TVC solenoid 0. 2. Displays user code E02 on monitor panel. ★ If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)	1. No current flows to the front pump TVC solenoid. Therefore, when the load is large, there is a big drop in the engine speed which may result in the engine stalling. 2. The swing acceleration is poor
Resistance of solenoid: 10 – 22 Ω Current: 1000 mA (H/O mode, auto-deceleration ON, levers at neutral, fuel control dial at MAX.)	1. The current stops flowing to the TVC solenoid, so no particular action is taken. 2. If there is a short circuit with the ground at the (-) end, the current (min. 1A) continues to flow to the TVC solenoid. 3. It displays user code E02 on the monitor panel. ★ If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)	1. In the case of 1, it is the same as E232. 2. In the case of 2, the current (min. 1A) continues to flow to the front pump TVC solenoid, so the output of the front pump TVC valve increases and the overall speed becomes slower.
Resistance of solenoid: 10 – 22 Ω	1. Makes output to TVC solenoid 0. 2. Displays user code E02 on monitor panel. ★ If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)	Same as E232 (but for the rear pump)
Resistance of solenoid: 10 – 22 Ω Current: 1000 mA (H/O mode, auto-deceleration ON, levers at neutral, fuel control dial at MAX.)	1. The current stops flowing to the TVC solenoid, so no particular action is taken. 2. If there is a short circuit with the ground at the (-) end, the current (min. 1A) continues to flow to the TVC solenoid. 3. It displays user code E02 on the monitor panel. ★ If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)	Same as E233 (but for the rear pump)
Resistance of solenoid: 20 – 60 Ω	1. Makes output to TVC solenoid 0. 2. Displays user code E03 on monitor panel. ★ If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)	When the swing is operated, the motor brake is not released, so the upper structure does not swing.
Resistance of solenoid: 20 – 60 Ω	1. The current stops flowing to the solenoid, so no particular action is taken. 2. Displays user code E03 on monitor panel. ★ If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)	Same as display for E203

ACTION TAKEN BY CONTROLLER WHEN ABNORMALITY OCCURS AND PROBLEMS ON MACHINE

TROUBLESHOOTING

User code	Service code	Abnormal system	Nature of abnormality
—	E202	Short circuit in LS select solenoid system	1. Short circuit with ground, short circuit inside LS select solenoid 2. Short circuit with ground in wiring harness between controller C01 (8) and solenoid V02 (2) ((+) side) 3. Defective governor, pump controller
—	E204	Short circuit in pump merge/divider solenoid system	1. Short circuit with ground, short circuit inside pump merge/divider solenoid 2. Short circuit with ground in wiring harness between controller C01 (2) and solenoid V03 (2) ((+) side) 3. Defective governor, pump controller
—	E206	Short circuit in travel speed solenoid system	1. Short circuit with ground, short circuit inside travel speed solenoid 2. Short circuit with ground in wiring harness between controller C01 (9) and solenoid V06 (2) ((+) side) 3. Defective governor, pump controller
—	E212	Disconnection in LS select solenoid system	1. Disconnection, defective contact inside LS select solenoid 2. Disconnection, defective contact, short circuit with power source in wiring harness between controller C01 (9) and solenoid V02 (2) ((+) side) 3. Disconnection, defective contact in wiring harness between solenoid V02 (1) and chassis ground ((-) side) 4. Defective governor, pump controller
—	E214	Disconnection in pump merge/divider solenoid system	1. Disconnection, defective contact inside pump merge/divider solenoid 2. Disconnection, defective contact, short circuit with power source in wiring harness between controller C01 (2) and solenoid V03 (2) ((+) side) 3. Disconnection, defective contact in wiring harness between solenoid V03 (2) and chassis ground ((-) side) 4. Defective governor, pump controller
—	E216	Disconnection in travel speed solenoid system	1. Disconnection, defective contact inside travel speed solenoid 2. Disconnection, defective contact, short circuit with power source in wiring harness between controller C01 (9) and solenoid V06 (2) ((+) side) 3. Disconnection, defective contact in wiring harness between solenoid V06 (1) and chassis ground ((-) side) 4. Defective governor, pump controller
—	E217	Model selection input error	1. Disconnection, defective contact, short circuit with ground in model selection wiring harness C17(5) (6) (7) (13) (14) 2. Defective governor, pump controller

020706

TROUBLESHOOTING

ACTION TAKEN BY CONTROLLER WHEN ABNORMALITY OCCURS AND PROBLEMS ON MACHINE

Condition when normal (voltage, current, resistance)	Action by controller when abnormality is detected	Problem that appears on machine when there is abnormality
Resistance of solenoid: 20 – 60 Ω	1. Makes output to solenoid 0. ★ If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)	1. With swing + boom RAISE, the boom is slow. 2. With swing + arm IN, the arm IN movement is slow. 3. With swing + arm OUT, the arm OUT movement is slow. 4. With swing + travel, there is a big drop in the travel speed.
Resistance of solenoid: 20 – 60 Ω	1. Makes output to solenoid 0. ★ If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)	The pump merge/divider valve continues to merge the oil flow. 1. In the L/O and F/O modes, the work equipment and swing speeds become faster. 2. The steering is difficult to turn.
Resistance of solenoid: 20 – 60 Ω	1. Makes output to solenoid 0. ★ If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)	Even if the travel speed is switched, the travel speed does not change (remains at Lo)
Resistance of solenoid: 20 – 60 Ω	1. The current stops flowing to the solenoid, so no particular action is taken. ★ If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)	Same content as display for E202
Resistance of solenoid: 20 – 60 Ω	1. The current stops flowing to the solenoid, so no particular action is taken. ★ If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)	Same content as display for E204
Resistance of solenoid: 20 – 60 Ω	1. The current stops flowing to the solenoid, so no particular action is taken. ★ If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)	Same content as display for E206
Between C17 (6), (13) and chassis: Max. 1 Ω Between C17 (5),(7),(14) and chassis: Min. 1 MΩ	Detects abnormality in input 1) Retains data when starting switch is ON 2) Functions as PC100 when non-set conditions are input	1. Engine stalls, or 2. Work equipment, swing, travel speeds are all slow, and there is no power

020706

ACTION TAKEN BY CONTROLLER WHEN ABNORMALITY OCCURS AND PROBLEMS ON MACHINE

TROUBLESHOOTING

User code	Service code	Abnormal system	Nature of abnormality
—	E218	Network response overtime error	1. Disconnection, short circuit, short circuit with ground in network wiring harness 2. Abnormality in governor, pump controller 3. Abnormality in monitor
—	E222	Short circuit in LS-EPC solenoid system	1. Short circuit with ground, short circuit inside LS-EPC solenoid 2. Short circuit with power source, short circuit with ground in wiring harness between controller C02 (7) and solenoid C10 (1) ((+) side) 3. Short circuit with power source in wiring harness between controller C02 (17) and solenoid C10 (2) ((-) side) 4. Defective governor, pump controller
—	E223	Disconnection in LS-EPC solenoid system	1. Disconnection, defective contact inside LS-EPC solenoid 2. Disconnection, defective contact in wiring harness between controller C02 (7) and solenoid C10 (1) ((+) side) 3. Disconnection, defective contact, short circuit with ground in wiring harness between controller C02 (17) and solenoid C10 (2) ((-) side) 4. Defective governor, pump controller
—	E224	Abnormality in front pump pressure sensor system	1. Disconnection, defective contact, short circuit, short circuit with ground inside front pump pressure sensor 2. Disconnection, defective contact, short circuit in wiring harness between controller C03 (6) and pressure sensor C08 (2) ((+) side) and between C03 (16) and C08 (1) ((-) side) 3. Disconnection, defective contact, short circuit with power source, short circuit with ground in wiring harness between controller C03 (3) and pressure sensor C08 (3) (SIG side) 4. Defective governor, pump controller
—	E225	Abnormality in rear pump pressure sensor system	1. Disconnection, defective contact, short circuit, short circuit with ground inside rear pump pressure sensor 2. Disconnection, defective contact, short circuit in wiring harness between controller C03 (6) and pressure sensor C07 (2) ((+) side) and between C03 (16) and C07 (1) ((-) side) 3. Disconnection, defective contact, short circuit with power source, short circuit with ground in wiring harness between controller C03 (13) and pressure sensor C07 (3) (SIG side) 4. Defective governor, pump controller
—	E226	Abnormality in pressure sensor power source system	1. Short circuit, short circuit with ground inside front pump pressure sensor or rear pump pressure sensor 2. Short circuit, short circuit with ground in wiring harness between controller C03 (6) and front pressure sensor C08 (2) or rear pressure sensor C07 (2) ((+) side) 3. Defective governor, pump controller
—	E227	Abnormality in speed sensor system	1. Disconnection, defective contact, short circuit inside engine speed sensor 2. Disconnection, defective contact, short circuit with ground in wiring harness between controller C16 (1) and speed sensor E07 (2) ((-) side) and between C16 (2) and E07 (1) (SIG side) 3. Defective governor, pump controller

020706

TROUBLESHOOTING

ACTION TAKEN BY CONTROLLER WHEN ABNORMALITY OCCURS AND PROBLEMS ON MACHINE

Condition when normal (voltage, current, resistance)	Action by controller when abnormality is detected	Problem that appears on machine when there is abnormality
	1. When communications are impossible with the monitor, control is carried out with the following settings. ① Working mode: G/O ② Priority mode: OFF ③ Travel speed: Lo ④ Auto-deceleration: ON ⑤ Power max. : ON (others are as usual)	1. ① Even when travel is operated, the power max. function does not work ② The swift speed-down function does not work ③ The auto-deceleration cannot be canceled ④ The travel speed does not increase ⑤ The priority mode has no effect ⑥ The automatic mode has no effect
Resistance of solenoid: 7 – 14 Ω	1. Makes output to LS-EPC solenoid 0. ★ If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)	1. The Lo travel speed is too fast. 2. In L/O and F/O modes, the work equipment speed is too fast. 3. When the engine is running at low idling, the swing speed is too fast.
Current: Approx. 705 mA (Levers at neutral, low idling)	1. The current stops flowing to the LS-EPC solenoid, so no particular action is taken. 2. If there is a short circuit with the ground at the (-) end, the current (min. 1A) continues to flow to the LS-EPC solenoid. ★ If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)	1. In the case of 1, it is the same as E222 2. In the case of 2, electric current (min. 1A) continues to flow to the LS-EPC solenoid, so the work equipment, travel, and swing speeds are slow
- Between C03 (3) and (16): 0.5 – 4.5 V - Between C03 (6) and (16): 18 – 28 V - Between C03 (female) (3) and (16), (3) and chassis - Resistance: Min. 1 MΩ (Disconnect connectors C03 and C08.)	1. Takes front pump pressure as 0 MPa (0 kg/cm ²) when actuating. ★ If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)	1. The travel speed does not automatically shift (it does not change from Hi to Lo). ★ If the button is operated manually, the panel display is switched.
- Between C03 (13) and (16): 0.5 – 4.5 V - Between C03 (6) and (16): 18 – 28 V - Between C03 (female) (13) and (16), (13) and chassis - Resistance: Min. 1 MΩ (Disconnect connectors C03 and C07.)	1. Takes rear pump pressure as 0 MPa (0 kg/cm ²) when actuating. ★ If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)	1. The travel speed does not automatically shift (it does not change from Hi to Lo). ★ If the button is operated manually, the panel display is switched.
Voltage between C03 (6) and (16): 18 – 28 V	1. Takes front pump and rear pump pressure as 0 MPa (0 kg/cm ²) when actuating. 2. When abnormality is detected, it switches the output OFF, and when all levers are returned to neutral, it outputs again. ★ This automatic resetting is repeated up to 3 times.	1. The travel speed does not automatically shift (it does not change from Hi to Lo). ★ If the button is operated manually, the panel display is switched.
- Resistance: 500 – 1000 Ω - Voltage (AC range) : 0.5 – 3.0 V (engine started)	1. It functions in the equivalent of the G/O mode (the speed rises)	It operates about the same as G/O mode (prolix) (the power is slightly lower)

020706

TROUBLESHOOTING

JUDGEMENT TABLE FOR GOVERNOR, PUMP CONTROLLER
(PUMP CONTROL SYSTEM) AND HYDRAULIC RELATED PARTSJUDGEMENT TABLE FOR GOVERNOR, PUMP CONTROLLER
(PUMP CONTROL SYSTEM) AND HYDRAULIC RELATED PARTS

Failure mode		Abnormality in controller power source	Governor, pump controller (E2:XX system)															
			Self-diagnostic display															
			Short circuit in front pump TVC solenoid system				Disconnection in front pump TVC solenoid system				Short circuit in rear pump TVC solenoid system				Disconnection in rear pump TVC solenoid system			
			Short circuit in LS select solenoid system				Disconnection in LS select solenoid system				Short circuit in swing holding brake solenoid system				Disconnection in swing holding brake solenoid system			
User code		LED	E02				E03				—				—			
Service code		OFF	232	233	236	237	202	212	203	213	204	214	206	216	217	222	223	
All work equipment, travel, swing	Speeds of all work equipment, swing, travel are slow or lack power	▲	▲	▲	▲													
	There is excessive drop in engine speed, or engine stalls	●	●	●	●										●			
	No work equipment, travel, swing move																	
	Abnormal noise generated (around pump)																	
	Auto-deceleration does not work	●																
Work equipment	Fine control ability is poor or response is poor																	
	Boom is slow or lacks power											●						
	Arm is slow or lacks power											●						
	Bucket is slow or lacks power																	
	Boom does not move																	
	Arm does not move																	
	Bucket does not move																	
	Excessive hydraulic drift																	
	Excessive time lag (engine at low idling)																●	
	Other equipment moves when single circuit is relieved																	
Compound operations	In L/O, F/O modes, work equipment speed is faster than specified speed										●	●				●	●	
	Machine push-up function does not work																	
	In compound operations, work equipment with larger load is slow																	
	In swing + boom (RAISE), boom is slow							●	●									
	In swing + arm, arm is slow							●	●									
Travel system	In swing + travel, travel speed drops excessively							●	●									
	Travel deviation																	
	Deviation is excessive during normal travel																	
	Deviation is excessive when starting																	
	Travel speed is slow																	●
Swing system	Steering does not turn or lacks power										●	●						
	Travel speed does not switch or is faster than specified speed	●												●	●		●	●
	Does not move (one side only)																	
	Does not swing										●	●						
	Both left and right																	
	One direction only																	
	Swing acceleration is poor or swing speed is slow		●	●	●	●												
	Both left and right																	
	One direction only																	
	Excessive overrun when stopping swing																	
Swing system	Both left and right																	
	One direction only																	
	Excessive shock when stopping swing (one direction only)																	
	Excessive abnormal noise when stopping swing																	
	Excessive hydraulic drift of swing																	
Swing system	When holding brake is released																	
	When holding brake is applied																	
Swing speed is faster than specified swing speed											●	●					●	●
Troubleshooting code when service code is displayed		C-1	C-2	C-3	C-4	C-5	C-6	C-7	C-8	C-9	C-10	C-11	C-12	C-13	C-14	C-15	C-16	
Troubleshooting code when there is abnormality in monitoring check		—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—

▲: This shows applicable item for service code (simultaneous abnormality at front or rear)

●: This shows applicable item for service code

※: This shows item that needs only checking with monitoring


○: This shows item to check with monitoring or machine monitor

JUDGEMENT TABLE FOR GOVERNOR, PUMP CONTROLLER (PUMP CONTROL SYSTEM) AND HYDRAULIC RELATED PARTS

★ If service code E218 (abnormality in network system) is displayed, go to troubleshooting for N mode.

Governor, pump controller EZ-XX system Self-diagnostic display				Check items in monitoring mode																	Troubleshooting code if no service code is displayed								
Abnormality in front pump pressure sensor system	Abnormality in rear pump pressure sensor system	Abnormality in pressure sensor power source system	Abnormality in engine speed sensor system	Pressure switch								Swing lock switch	Kerosene mode	Knob switch	Actuation of solenoid			Model code	Engine speed input					Front pump discharge pressure input	Rear pump discharge pressure input	Front pump TVC current output	Rear pump TVC current output	LS-EPC current output	
				Swing	Travel	Boom LOWER	Boom RAISE	Arm IN	Arm OUT	Bucket CURL	Bucket DUMP				LS select	Swing holding brake	Pump merge/divider		Travel speed										
Bit pattern															Monitoring code														
224	225	226	227	20				21				22	23				02	10	11	12	13	14	15						
			●															※	※								H-1		
			●																		※	※					H-2		
																											H-3		
																											H-4		
			●	○																							H-5		
																											H-6		
																			※			※	※				H-7		
																			※			※	※				H-8		
																						※	※				H-9		
																											H-10		
																											H-11		
																									※		H-12		
																											H-13		
																			※						※		H-14		
																											H-15		
																											C-21		
																											H-16		
																											H-17		
																											H-18		
																											H-19		
																											H-20		
																									※		H-21		
																											H-22		
●	●	●	●		○																				※		H-23		
																											H-24		
					○																						H-25		
																											H-26		
																											H-27		
																											H-28		
																											H-29		
																											H-30		
																											H-31		
C-17	C-18	C-19	C-20	-	-	-	-	-	-	-	-	-	-	-	-	-	※	-	-	-	-	-	-	-	※				
-	-	-	-	F-1	F-2	F-3	F-4	F-5	F-6	F-7	F-8	F-9	F-10	F-11	-	-	-	-	-	-	-	-	-	-	-	-			

ELECTRICAL CIRCUIT DIAGRAM FOR C MODE




BKP00182

020706

TROUBLESHOOTING


ELECTRICAL CIRCUIT DIAGRAM FOR C MODE



BKP00183

C-1 Abnormality in controller power source system (controller LED is OFF)

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ Check that fuse 1 is not blown.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.
- ★ When the starting motor rotates normally. (If the starting motor also does not rotate, go to E-8.)




020706

C-1 Related electric circuit diagram

Governor, pump controller

C01(MIC13)



BKP00186


- ★ **This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.**
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Always turn the TVC prolix switch OFF.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.



Troubleshooting No. 2	Troubleshooting No. 3	Troubleshooting No. 4	Resistance value
Between C13 (male) (1) – (2)	Between C02 (female) (8) – (18)	Between C05 (female) (3) – (4)	10 – 22 Ω
Between C13 (male) (1) – chassis	Between C02 (female) (8) – chassis	Between C05 (female) (3) – chassis	Min. 1 MΩ

Troubleshooting No. 5	Resistance value
Between C05 (male) (1) – (3), (2) – (4)	Max. 1 Ω
Between C05 (male) (1)(2)(3)(4) – chassis	Min. 1 MΩ

C-2 Related electric circuit diagram



BKP00187

020706

C-3 [E233] Disconnection in front pump TVC solenoid system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ If there is a disconnection in the solenoid or wiring harness, no current flows to the solenoid. If the No. 2 pin of the solenoid is short circuiting with the ground, the current (approx. 1 A) continues to flow to the solenoid.
- ★ Always turn the TVC prolix switch OFF.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.





Table 1

Troubleshooting No. 2	Troubleshooting No. 3	Troubleshooting No. 4	Resistance value
Between C13 (male) (1) – (2)	Between C02 (female) (8) – (18)	Between C05 (female) (3) – (4)	10 – 22 Ω
Between C13 (male) (2) – chassis	Between C02 (female) (18) – chassis	Between C05 (female) (4) – chassis	Min. 1 MΩ

Table 2

Troubleshooting No. 5	Resistance value
Between C05 (male) (1) – (3), (2) – (4)	Max. 1 Ω
Between C05 (male) (1)(2)(3)(4) – chassis	Min. 1 MΩ

C-3 Related electric circuit diagram



BKP00187

C-4 [E236] Short circuit in rear pump TVC solenoid system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adaptor, or when removing the T-adaptor and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Always turn the TVC prolix switch OFF.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.





Table 1

Troubleshooting No. 2	Troubleshooting No. 3	Troubleshooting No. 4	Resistance value
Between C04 (male) (1) – (2)	Between C02 (female) (9) – (19)	Between C05 (female) (8) – (9)	10 – 22 Ω
Between C04 (male) (1) – chassis	Between C02 (female) (9) – chassis	Between C05 (female) (8) – chassis	Min. 1 MΩ

Table 2

Troubleshooting No. 5	Resistance value
Between C05 (male) (6) – (8), (7) – (9)	Max. 1 Ω
Between C05 (male) (6)(7)(8)(9) – chassis	Min. 1 MΩ

C-4 Related electric circuit diagram



BKP00188

C-5 [E237] Disconnection in rear pump TVC solenoid system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ If there is a disconnection in the solenoid or wiring harness, no current flows to the solenoid. If the No. 2 pin of the solenoid is short circuiting with the ground, the current (approx. 1 A) continues to flow to the solenoid.
- ★ Always turn the TVC prolix switch OFF.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.





Table 1

Troubleshooting No. 2	Troubleshooting No. 3	Troubleshooting No. 4	Resistance value
Between C04 (male) (1) - (2)	Between C02 (female) (9) - (19)	Between C05 (female) (8) - (9)	10 - 22 Ω
Between C04 (male) (2) - chassis	Between C02 (female) (19) - chassis	Between C05 (female) (9) - chassis	Min. 1 MΩ

Table 2

Troubleshooting No. 5	Resistance value
Between C05 (male) (6) - (8), (7) - (9)	Max. 1 Ω
Between C05 (male) (6)(7)(8)(9) - chassis	Min. 1 MΩ

C-5 Related electric circuit diagram



BKP00188

020706

C-6 [E202] Short circuit in LS select solenoid system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.





Table 1

Between V02 (male) (1) – (2)	20 – 60 Ω
Between V02 (male) (2) – chassis	Min. 1 MΩ

C-6 Related electric circuit diagram



BKP00189

C-7 [E212] Disconnection in LS select solenoid system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.





Table 1

Troubleshooting No. 3	Troubleshooting No. 4	Voltage	Measurement condition
Between C01 (male) (8) – chassis	Between V02 (female) (2) – chassis	0 – 3V	When swing lock switch is ON
		20 – 30V	When swing lock switch is OFF
			When swing and travel are operated at same time

C-7 Related electric circuit diagram



BKP00189

C-8 [E203] Short circuit in swing brake solenoid system is displayed

- ★ **This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.**
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.
- ★ Always turn the swing lock prolix switch OFF, then turn the swing lock switch OFF before checking.





Table 1

Between V04 (male) (1) – (2)	20 – 60 Ω
Between V04 (male) (2) – chassis	Min. 1 M Ω


C-8 Related electric circuit diagram



BKP00190


020706

- ★ **This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.**
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Always turn the swing lock prolix switch OFF, then turn the swing lock switch OFF before checking.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.



Troubleshooting No. 3	Troubleshooting No. 4	Troubleshooting No. 6	Voltage	Measurement condition
Between C01 (male)	Between X05 (male)	Between V04 (male)	0 – 3V	5 seconds after all levers are returned to neutral
(3) – chassis	(3) – chassis	(2) – chassis	20 – 30V	Swing lever operated

C-9 Related electric circuit diagram



BKP00190

020706

C-10 [E204] Short circuit in pump merge/divider solenoid system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.





Table 1

Between V03 (male) (1) – (2)	20 – 60 Ω
Between V03 (male) (2) – chassis	Min. 1 MΩ


C-10 Related electric circuit diagram



BKP00191

C-11 [E214] Disconnection in pump merge/divider solenoid system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.




020706

Table 1

Troubleshooting No. 3	Troubleshooting No. 4	Voltage	Measurement condition
Between C01 (male) (2) – chassis	Between V03 (female) (2) – chassis	0 – 3V	All levers at neutral
		20 – 30V	Travel operated independently

C-11 Related electric circuit diagram



BKP00191

C-12 [E206] Short circuit in travel speed solenoid system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.





Table 1

Between V06 (male) (1) – (2)	20 – 60 Ω
Between V06 (male) (2) – chassis	Min. 1 MΩ

C-12 Related electric circuit diagram



BKP00192

C-13 [E216] Disconnection in travel speed selector solenoid system is displayed


- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

		Cause	Remedy
1 Interchange connector with other solenoid. Is [E216] displayed? • Turn starting switch OFF. • Interchange V06 with other connector. • Turn starting switch ON.	2 Is resistance between V06 (male) (1) and (2) normal? • Turn starting switch OFF. • Disconnect V06. • 20 – 60 Ω	Defective contact or disconnection in wiring harness between V06 (female) (1) and chassis ground Short circuit with power source, defective contact, or disconnection in wiring harness between C01 (female) (9) – V06 (female) (2) Defective governor, pump controller Defective travel speed solenoid (internal disconnection or short circuit with power source)	Repair or replace Repair or replace Replace Replace
	3 Is voltage between C01 (male) (9) and chassis as shown in Table 1? • Turn starting switch ON. • Disconnect C01.		
	4 Is voltage between V06 (female) (2) and chassis as shown in Table 1? • Turn starting switch ON. • Disconnect V06.		

Table 1

Troubleshooting No. 3	Troubleshooting No. 4	Voltage	Measurement condition
Between C01 (male) (9) – chassis	Between V06 (female) (2) – chassis	0 – 3V	Travel speed switch at Lo
		20 – 30V	Travel speed switch at Mi or Hi Operate the lever slightly not enough to move the machine

C-13 Related electric circuit diagram



BKP00192

C-14 [E217] Model selection input error is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.





Table 1 Monitoring code display


Model code display	Model selection signal input display	
Monitoring codes 02, 03	Monitoring code 21	Monitoring code 22
		

- ★ The diagram shows monitoring code 02.
- ★ Check the bit pattern display marked with ←.

Table 2 Voltage of wiring harness

C17	Between (5) - chassis	Between (6) - chassis	Between (7) - chassis	Between (13) - chassis	Between (14) - chassis
Voltage	20 - 30 V	Max. 1 V	20 - 30 V	Max. 1 V	20 - 30 V

C-14 Related electric circuit diagram



BKP00199

020706

C-15 [E222] Short circuit in LS-EPC solenoid system is displayed


- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

		Cause	Remedy
Is resistance between C10 (male) (1) and (2), (1) and chassis as shown in Table 1? 1 YES • Turn starting switch OFF. • Disconnect C10.	Is resistance between C02 (female) (7) and (17), (7) and chassis as shown in Table 1? 2 YES	Defective governor, pump controller	Replace
	NO	Short circuit with ground or short circuit with power source in wiring harness between C02 (female) (7) – C10 (female) (1), or short circuit with power source in wiring harness between C02 (female) (17) – C10 (female) (2)	Repair or replace
	NO	Defective LS-EPC solenoid (internal short circuit with ground or short circuit with power source)	Replace

Table 1

Troubleshooting No. 1	Troubleshooting No. 2	Resistance value
Between C10 (male) (1) – (2)	Between C02 (female) (7) – (17)	7 – 14 Ω
Between C10 (male) (1) – chassis	Between C02 (female) (7) – chassis	Min. 1 MΩ


C-15 Related electric circuit diagram



BKP00251

C-16 [E223] Disconnection in LS-EPC solenoid system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.




020706

Table 1

Troubleshooting No. 1	Troubleshooting No. 2	Resistance value
Between C10 (male) (1) – (2)	Between C02 (female) (7) – (17)	7 – 14 Ω
Between C10 (male) (2) – chassis	Between C02 (female) (17) – chassis	Min. 1 MΩ

C-16 Related electric circuit diagram




BKP00251

C-17 [E224] Abnormality in front pump pressure sensor system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

					Cause	Remedy			
Interchange connector with rear pump pressure sensor. Is [E224] displayed? • Turn starting switch OFF. • Interchange C07 with C08. • Engine at high idling	1	YES	Is voltage between C08 (2) and (1) normal?	2	YES	Defective governor, pump controller	Replace		
				YES	3	Is voltage between C03 (3) and (16) normal?			
						NO	Short circuit with power source, defective contact, or disconnection in wiring harness between C03 (female) (3) – C08 (female) (3)	Repair or replace	
				NO	4	Is voltage between C08 (2) and chassis normal?	YES	Short circuit with ground, defective contact, or disconnection in wiring harness between C03 (female) (16) and C08 (female) (1)	Repair or replace
						NO	Short circuit with ground, defective contact, or disconnection in wiring harness between C03 (female) (6) and C08 (female) (2)	Repair or replace	
					Defective front pump pressure sensor (internal disconnection, defective contact, short circuit, or short circuit with ground)	Replace			

C-17 Related electric circuit diagram



BKP00252


C-18 [E225] Abnormality in rear pump pressure sensor system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

				Cause	Remedy
1 Interchange connector with front pump pressure sensor. Is [E225] displayed? • Turn starting switch OFF. • Interchange C08 with C07. • Engine at high idling	YES	2 Is voltage between C07 (2) and (1) normal? • Turn starting switch ON. • 18 – 28 V	YES	Defective governor, pump controller	Replace
	NO		NO	Short circuit with power source, defective contact, or disconnection in wiring harness between C03 (female) (13) – C07 (female) (3)	Repair or replace
	NO	3 Is voltage between C03 (3) and (16) normal? • Engine at high idling • Operate repeatedly arm IN relief ↔ lever NEUTRAL. • 0.5 – 4.5 V	YES	Short circuit with ground, defective contact, or disconnection in wiring harness between C03 (female) (16) and C07 (female) (1)	Repair or replace
			NO	Short circuit with ground, defective contact, or disconnection in wiring harness between C03 (female) (6) and C07 (female) (2)	Repair or replace
	NO	4 Is voltage between C07 (2) and chassis normal? • Disconnect C07. • Turn starting switch ON. • 18 – 28 V	YES	Defective rear pump pressure sensor (internal disconnection, defective contact, short circuit, or short circuit with ground)	Replace
			NO		

020706


C-18 Related electric circuit diagram




BKP00253

C-19 [E226] Abnormality in pressure sensor power source system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.



C-19 Related electric circuit diagram




C-20 [E227] Abnormality in engine speed sensor system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

			Cause	Remedy
Is resistance between E07 (male) (1) and (2) normal? • Turn starting switch OFF. • Disconnect E07. • 500 – 1000 Ω	1	YES		
		YES	Is resistance between C16 (female) (1) and (2) normal?	
		NO	• Turn starting switch OFF. • Disconnect C16. • 500 – 1000 Ω	
		NO		
		2 YES	Defective governor, pump controller	Replace
			Short circuit with ground, defective contact, or disconnection in wiring harness between C16 (female) (1) – E08 (10) – E07 (female) (2), or between C16 (female) (2) – E08 (9) – E07 (female) (1)	Repair or replace
			Defective engine speed sensor (internal disconnection, defective contact, or short circuit with ground)	Replace

020706

C-20 Related electric circuit diagram




BKP00255

b) If solenoid is not canceled (turned OFF) when machine push-up switch is set to high-pressure setting

- ★ Carry out troubleshooting with the machine push-up switch at the high-pressure setting position.

		Cause	Remedy		
1 Is voltage between V05 (2) and chassis normal? • Turn starting switch ON. • Max. 1 V	YES	Defective machine push-up solenoid (internal short circuit with power source)	Replace		
	NO	2 Is voltage between M38 (1) and chassis normal? • Turn starting switch ON. • Max. 1 V	YES	Defective machine push-up switch (internal short circuit with power source)	Replace
	NO	Short circuit with power source in wiring harness between M38 (male) (1) – X01 (16) – H13 (3) – V05 (female) (2)	Repair or replace		

C-21 Related electric circuit diagram



BKP00256


020706

TROUBLESHOOTING OF GOVERNOR, PUMP CONTROLLER (INPUT SIGNAL SYSTEM) (F MODE)

Electrical circuit diagram for F mode	20-401-1
F- 1 Bit pattern 20-(1) Swing oil pressure switch does not light up	20-402
F- 2 Bit pattern 20-(2) Travel oil pressure switch does not light up	20-403
F- 3 Bit pattern 20-(3) Boom LOWER oil pressure switch does not light up	20-404
F- 4 Bit pattern 20-(4) Boom RAISE oil pressure switch does not light up	20-405
F- 5 Bit pattern 20-(5) Arm IN oil pressure switch does not light up	20-406
F- 6 Bit pattern 20-(6) Arm OUT oil pressure switch does not light up	20-407
F- 7 Bit pattern 21-(1) Bucket CURL oil pressure switch does not light up	20-408
F- 8 Bit pattern 21-(2) Bucket DUMP oil pressure switch does not light up	20-409
F- 9 Bit pattern 21-(3) Swing lock switch does not light up	20-410
F-10 Bit pattern 22-(5) Kerosene mode connection does not light up	20-411
F-11 Bit pattern 22-(6) L.H. knob switch does not light up	20-412

020706

ELECTRICAL CIRCUIT DIAGRAM FOR F MODE



BKP00182



F-1 Bit pattern 20-(1) Swing oil pressure switch does not light up


- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the monitor code display returns to normal, the problem has been removed.

⚠ Turn the swing lock switch ON before operating the swing lever.

- ★ If there is no display when the lever is operated on one side, the PPC shuttle valve is defective. (See H-5)

(When measuring with the engine stopped, charge the accumulator first.)


- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
★ Always connect any disconnected connectors before going on the next step.



Note 1: It is also possible to fit a short connector and judge the condition. In this case, check the voltage between C16 (5) and the chassis.

- If it is 20 – 30 V: Go to YES
- If it is less than 1 V: Go to NO

F-1 Related electric circuit diagram



BKP00257

F-2 Bit pattern 20-(2) Travel oil pressure switch does not light up

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the monitor code display returns to normal, the problem has been removed.

⚠ Before operating the travel lever, check that the surrounding area is safe.

- ★ If there is no display when the travel lever is operated on one side, the PPC shuttle valve is defective. (See H-5)

(When measuring with the engine stopped, charge the accumulator first.)


- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
★ Always connect any disconnected connectors before going on the next step.

		Cause	Remedy
020706 1 Is voltage between C16 (13) and chassis normal? - Start engine. - Travel lever at neutral : 20 – 30V - Travel lever operated : Max. 1 V	YES	Defective governor, pump controller	Replace
	NO	Defective contact, or disconnection in wiring harness between S01 (female) (1) and chassis ground	Repair or replace
	2	Defective contact, short circuit with ground, or disconnection in wiring harness between C16 (female) (13) and S01 (female) (2)	Repair or replace
	3	Defective travel oil pressure switch (If the condition does not return to normal even when the switch is replaced, go to H-5.)	Replace

Note 1: It is also possible to fit a short connector and judge the condition. In this case, check the voltage between C16 (13) and the chassis.

- If it is 20 – 30 V: Go to YES
- If it is less than 1 V: Go to NO

F-2 Related electric circuit diagram



F-3 Bit pattern 20-(3) Boom LOWER oil pressure switch does not light up

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the monitor code display returns to normal, the problem has been removed.

⚠ When measuring with the engine running, operate the lever slightly and make sure that the work equipment does not move.

(When measuring with the engine stopped, charge the accumulator first.)


- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

		Cause	Remedy
1 Is voltage between C17 (10) and chassis normal? • Start engine. • Boom lever at neutral: 20 – 30V • Boom lever operated to LOWER: Max. 1V	YES	Defective governor, pump controller	Replace
	NO	Defective contact, or disconnection in wiring harness between S04 (female) (1) and chassis ground	Repair or replace
	NO	Defective contact, short circuit with ground, or disconnection in wiring harness between C17 (female) (10) – H13 (11) – S04 (female) (2)	Repair or replace
	NO	Defective boom LOWER oil pressure switch (If the condition does not return to normal even when the switch is replaced, go to H-5.)	Replace
2 Is resistance between S04 (male) (1) and (2) normal, and is circuit insulated from chassis? • Disconnect S04. • Start engine. • Boom lever at neutral: Min. 1 MΩ • Boom lever operated to LOWER: Max. 1 Ω • See Note 1.			
3 Is resistance between C17 (female) (10) and S04 (female) (2) normal, and is circuit insulated from chassis? • Turn starting switch OFF. • Disconnect C17 and S04. • Between C17 and S04: Max. 1 Ω • Between wiring harness and chassis: Min. 1 MΩ			

Note 1: It is also possible to fit a short connector and judge the condition. In this case, check the voltage between C17 (10) and the chassis.

- If it is 20 – 30 V: Go to YES
- If it is less than 1 V: Go to NO

F-3 Related electric circuit diagram



BKP00259


F-4 Bit pattern 20-(4) Boom RAISE oil pressure switch does not light up

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the monitor code display returns to normal, the problem has been removed.


⚠ When measuring with the engine running, operate the lever slightly and make sure that the work equipment does not move.

(When measuring with the engine stopped, charge the accumulator first.)

- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
★ Always connect any disconnected connectors before going on the next step.



F-4 Related electric circuit diagram




F-5 Bit pattern 20-(5) Arm IN oil pressure switch does not light up

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the monitor code display returns to normal, the problem has been removed.

⚠ When measuring with the engine running, operate the lever slightly and make sure that the work equipment does not move.


(When measuring with the engine stopped, charge the accumulator first.)

- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
★ Always connect any disconnected connectors before going on the next step.



Note 1: It is also possible to fit a short connector and judge the condition. In this case, check the voltage between C17 (3) and the chassis.
• If it is 20 – 30V: Go to YES
• If it is less than 1V: Go to NO

F-5 Related electric circuit diagram



BKP00261

F-6 Bit pattern 20-(6) Arm OUT oil pressure switch does not light up

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the monitor code display returns to normal, the problem has been removed.

⚠ When measuring with the engine running, operate the lever slightly and make sure that the work equipment does not move.


(When measuring with the engine stopped, charge the accumulator first.)

- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
★ Always connect any disconnected connectors before going on the next step.

		Cause	Remedy
020706 1 Is voltage between C17 (11) and chassis normal? • Start engine. • Arm lever at neutral: 20 – 30V • Arm lever operated to OUT: Max. 1 V	YES	Defective governor, pump controller	Replace
	NO	Defective contact, or disconnection in wiring harness between S03 (female) (1) and chassis ground	Repair or replace
	2	Defective contact, short circuit with ground, or disconnection in wiring harness between C17 (female) (11) – H13 (12) – S03 (female) (2)	Repair or replace
	3	Defective arm OUT oil pressure switch (If the condition does not return to normal even when the switch is replaced, go to H-5.)	Replace

Note 1: It is also possible to fit a short connector and judge the condition. In this case, check the voltage between C17 (11) and the chassis.
• If it is 20 – 30V: Go to YES
• If it is less than 1V: Go to NO

F-6 Related electric circuit diagram




F-7 Bit pattern 21-(1) Bucket CURL oil pressure switch does not light up

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the monitor code display returns to normal, the problem has been removed.

⚠ When measuring with the engine running, operate the lever slightly and make sure that the work equipment does not move.

(When measuring with the engine stopped, charge the accumulator first.)


- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
★ Always connect any disconnected connectors before going on the next step.



Note 1: It is also possible to fit a short connector and judge the condition. In this case, check the voltage between C16 (11) and the chassis.

- If it is 20 – 30V: Go to YES
- If it is less than 1V: Go to NO

F-7 Related electric circuit diagram



BKP00263

F-8 Bit pattern 21-(2) Bucket DUMP oil pressure switch does not light up

★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adaptor, or when removing the T-adaptor and returning the connector to its original position, if the monitor code display returns to normal, the problem has been removed.

⚠ When measuring with the engine running, operate the lever slightly and make sure that the work equipment does not move.

(When measuring with the engine stopped, charge the accumulator first.)


- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

		Cause	Remedy
020706 1 Is voltage between C16 (12) and chassis normal? • Start engine. • Bucket lever at neutral: 20 – 30V • Bucket lever operated to DUMP: Max. 1 V	YES	Defective governor, pump controller	Replace
	NO	Defective contact or disconnection in wiring harness between S07 (female) (2) and chassis ground	Repair or replace
	NO	Defective contact, short circuit with ground, or disconnection in wiring harness between C16 (female) (12) and S07 (female) (2)	Repair or replace
	NO	Defective bucket DUMP oil pressure switch (If the condition does not return to normal even when the switch is replaced, go to H-5.)	Replace

Note 1: It is also possible to fit a short connector and judge the condition. In this case, check the voltage between C16 (12) and the chassis.

- If it is 20 – 30V: Go to YES
- If it is less than 1V: Go to NO


F-8 Related electric circuit diagram



BKP00264


F-9 Bit pattern 21-(3) Swing lock switch does not light up

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adaptor, or when removing the T-adaptor and returning the connector to its original position, if the monitor code display returns to normal, the problem has been removed.
- ★ If the panel display is normal. (If the swing lock lamp does not light up, go to M-21.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.



020706


F-9 Related electric circuit diagram




BKP00265

F-10 Bit pattern 22-(5) Kerosene mode connection does not light up

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the monitor code display returns to normal, the problem has been removed.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.




F-10 Related electric circuit diagram



BKP00266


F-11 Bit pattern 22-(6) L.H. knob switch does not light up

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the monitor code display returns to normal, the problem has been removed.
- ★ When fuse No. 5 is not blown.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.



020706

F-11 Related electric circuit diagram




BKP00267

TROUBLESHOOTING OF HYDRAULIC, MECHANICAL SYSTEM (H MODE)

Pump merge/divider logic, LS select logic, solenoid actuation table	20-452
Table of failure modes and causes	20-454
All work equipment, travel, swing	
H-1 Speeds of all work equipment, swing, travel are slow or lack power	20-458
H-2 There is excessive drop in engine speed, or engine stalls	20-460
H-3 No work equipment, travel, swing move	20-461
H-4 Abnormal noise generated (around pump)	20-461
H-5 Auto-deceleration does not work	20-462
H-6 Fine control ability is poor or response is poor	20-462
Work equipment	
H-7 Boom is slow or lacks power	20-464
H-8 Arm is slow or lacks power	20-466
H-9 Bucket is slow or lacks power	20-468
H-10 Work equipment (boom, arm, bucket) does not move	20-469
H-11 Excessive hydraulic drift (boom, arm, bucket)	20-469
H-12 Excessive time lag (engine at low idling)	20-470
H-13 Other equipment moves when single circuit is relieved	20-470
H-14 In L/O, F/O modes, work equipment speed is faster than set speed	20-471
H-15 Defective actuation of machine push-up function	20-471
Compound operations	
H-16 In compound operations, work equipment with larger load is slow	20-471
H-17 In swing + boom RAISE, boom RAISE is slow	20-472
H-18 In swing + arm, arm is slow	20-472
H-19 In swing + travel, travel speed drops excessively	20-472
Travel system	
H-20 Travel deviation	20-473
H-21 Travel speed is slow	20-474
H-22 Steering does not turn easily or lacks power	20-476
H-23 Travel speed does not switch or is faster than set speed	20-478
H-24 Travel does not move (one side only)	20-478
Swing system	
H-25 Does not swing (both left and right, one direction only)	20-479
H-26 Swing acceleration is poor or swing speed is slow (both left and right, one direction only)	20-480
H-27 Excessive overrun when stopping swing (both left and right, one direction only)	20-482
H-28 Excessive shock when stopping swing (one direction only)	20-483
H-29 Excessive abnormal noise when stopping swing	20-483
H-30 Excessive hydraulic drift of swing (when brake is ON, when brake is OFF)	20-484
H-31 Swing speed is faster than specified speed	20-485

PUMP MERGE/DIVIDER LOGIC

Divide (pump merge/divider solenoid ON)	Merge (pump merge/divider solenoid OFF)
- Travel operated independently. - Travel + work equipment (any one of boom, arm, bucket, swing, or service) + front or rear pump oil pressure 19.6 MPa (200 kg/cm²) or above when raised or 14.7 MPa (150 kg/cm²) or above when lowered. (See diagram)  Pressure MPa(kg/cm²) BKP00221 - Breaker mode + service (breaker) valve pressure switch ON.	All operations except those on left.

LS SELECT LOGIC

LS separated (LS select solenoid ON)	LS not separated (LS select solenoid OFF)
- With swing priority mode ON and swing lock switch OFF: Travel + swing - With swing priority mode OFF and swing lock switch OFF: - Travel + swing - Boom RAISE ON - Arm OUT ON - Arm IN + front or rear pump oil pressure 14.7 MPa (150 kg/cm²) or above.	- Swing lock switch ON - With swing priority mode ON and swing lock switch OFF: Any operation except travel + swing - With swing priority mode OFF and swing lock switch OFF: Any operation except 2-1) – 2-4) on left

SOLENOID ACTUATION TABLE

Name of solenoid	ON (energized)	OFF
Swing holding brake	Brake released	Brake applied
Travel speed	Travel motor swash plate angle at MIN	Travel motor swash plate angle at MAX
LS select	LS separated	LS not separated
Pump merge/divider valve	Divided flow	Merged flow
Machine push-up	Low pressure	High pressure

TROUBLESHOOTING

TABLE OF FAILURE MODES AND CAUSES

TABLE OF FAILURE MODES AND CAUSES (1/2)

Parts causing failure Failure mode		Piston pump								Control valve					
		F				R									
		TVC valve	LS valve	Servo piston	Pump proper	TVC valve	LS valve	Servo piston	Pump proper						
All work equipment, travel, swing	Speeds of all work equipment, swing, travel are slow or lack power	▲	▲	▲	▲	▲	▲	▲	▲	○					
	There is excessive drop in engine speed, or engine stalls	○	○	○		○	○	○							
	No work equipment, travel, swing move				△				△	○		○			
	Abnormal noise generated (around pump)				○				○		○				
	Auto-deceleration does not work														
Work equipment	Fine control ability is poor or response is poor		○				○								
	Boom is slow or lacks power													○	
	Arm is slow or lacks power													○	
	Bucket is slow or lacks power													○	
	Boom does not move													○	
	Arm does not move													○	
	Bucket does not move													○	
	Excessive hydraulic drift													○	
	Excessive time lag (engine at low idling)														
	Other equipment moves when single circuit is relieved														
	In L/O, F/O modes, work equipment speed is faster than specified speed		○				○								
	Machine push-up function does not work														
	Compound operations	In compound operations, work equipment with larger load is slow													
In swing + boom (RAISE), boom is slow															
In swing + arm, arm is slow															
In swing + travel, travel speed drops excessively															
Travel system	Travel deviation	Deviation is excessive during normal travel													○
		Deviation is excessive when starting													
	Travel speed is slow													○	
	Steering does not turn or lacks power													○	
	Travel speed does not switch or is faster than specified speed														
	Does not move (one side only)		○				○								
Swing system	Does not swing	Both left and right													
		One direction only													○
	Swing acceleration is poor or swing speed is slow	Both left and right													○
		One direction only													○
	Excessive overrun when stopping swing	Both left and right													
		One direction only													○
	Excessive shock when stopping swing (one direction only)														
	Excessive abnormal noise when stopping swing														
	Excessive hydraulic drift of swing	When brake ON													
	When brake OFF													○	
	Swing speed is faster than specified swing speed		○				○								

★ In the failure modes, modes for compound operations are used when independent operations are normal

▲: When there is an abnormality for both front and rear

020706

TROUBLESHOOTING

TABLE OF FAILURE MODES AND CAUSES

Control valve																	Troubleshooting code
Front pump		Rear pump		Pressure compensation valve	Pump merge/divider valve		LS circuit check valve	LS shuttle valve	LS select valve	LS circuit throttle	Arm counterbalance valve	Re-generation valve		Safety-suction valve	Suction valve	Slow return valve for pump merge/divider	
Main relief valve	Unload valve	Main relief valve	Unload valve		Main pump merge/divider valve	LS pump merge/divider valve						Boom	Arm				
▲	▲	▲	▲														
																	H-1
																	H-2
																	H-3
																	H-4
																	H-5
																	H-6
																	H-7
																	H-8
																	H-9
																	H-10
																	H-11
																	H-12
																	H-13
																	H-14
																	H-15
																	H-16
																	H-17
																	H-18
																	H-19
																	H-20
																	H-21
																	H-22
																	H-23
																	H-24
																	H-25
																	H-26
																	H-27
																	H-28
																	H-29
																	H-30
																	H-31

020706

TABLE OF FAILURE MODES AND CAUSES (2/2)

Failure mode			Parts causing failure		Solenoid valve						Swing motor	
					LS-EPC	LS select	Pump merge/divider valve	Swing holding brake	Travel speed selector	Machine push-up	Holding brake	Safety-suction valve
All work equipment, travel, swing	Speeds of all work equipment, swing, travel are slow or lack power		○									
	There is excessive drop in engine speed, or engine stalls											
	No work equipment, travel, swing move											
	Abnormal noise generated (around pump)											
	Auto-deceleration does not work											
Work equipment	Fine control ability is poor or response is poor											
	Boom is slow or lacks power				○							
	Arm is slow or lacks power				○							
	Bucket is slow or lacks power											
	Boom does not move											
	Arm does not move											
	Bucket does not move											
	Excessive hydraulic drift											
	Excessive time lag (engine at low idling)		○									
	Other equipment moves when single circuit is relieved											
	In L/O, F/O modes, work equipment speed is faster than specified speed		○		○							
	Machine push-up function does not work							○				
	Compound operations	In compound operations, work equipment with larger load is slow		○								
In swing + boom (RAISE), boom is slow			○									
In swing + arm, arm is slow			○									
In swing + travel, travel speed drops excessively			○									
Travel system	Travel deviation	Deviation is excessive during normal travel										
		Deviation is excessive when starting										
	Travel speed is slow		○									
	Steering does not turn or lacks power				○							
	Travel speed does not switch or is faster than specified speed		○		○		○					
	Does not move (one side only)											
Swing system	Does not swing	Both left and right				○				○		○
		One direction only									○	
	Swing acceleration is poor or swing speed is slow	Both left and right										○
		One direction only									○	
	Excessive overrun when stopping swing	Both left and right										○
		One direction only									○	
	Excessive shock when stopping swing (one direction only)											
	Excessive abnormal noise when stopping swing											
	Excessive hydraulic drift of swing	When brake ON				○				○		
		When brake OFF									○	○
Swing speed is faster than specified swing speed		○										

★ In the failure modes, modes for compound operations are used when independent operations are normal

▲: When there is an abnormality for both front and rear

020706

TROUBLESHOOTING


TABLE OF FAILURE MODES AND CAUSES

Travel motor					Pressure switch										Pressure sensor		Troubleshooting code				
Safety valve	Counterbalance valve	Check valve	Travel speed selector servo piston	Leakage, breakage inside body	Swing machinery	Final drive	Hydraulic cylinder	Boom lock valve	Back pressure valve	Travel junction valve	Boom		Arm		Bucket			Swing	Travel	Front pump	Rear pump
											RAISE	LOWER	IN	OUT	CURL	DUMP					
																					H-1
																					H-2
																					H-3
																					H-4
																					H-5
																					H-6
																					H-7
																					H-8
																					H-9
																					H-10
																					H-11
																					H-12
																					H-13
																					H-14
																					H-15
																					H-16
																					H-17
																					H-18
																					H-19
																					H-20
																					H-21
																					H-22
																					H-23
																					H-24
																					H-25
																					H-26
																					H-27
																					H-28
																					H-29
																					H-30
																					H-31

020706

H-1 Speeds of all work equipment, swing, travel are slow or lack power

- ★ Carry out troubleshooting in the H/O mode.
- ★ Check that no abnormal noise is being generated from the main pump before carrying out troubleshooting. (If there is any abnormal noise, carry out troubleshooting for H-4.)



020706

- ★ Measuring servo piston inlet port pressure in Item No. 4
 - Measure the input pressure to the large diameter end of the servo piston when the arm is relieved in the power max. mode. (Approx. 12.7 MPa (130 kg/cm²))
Basically, the pressure at the large diameter end is approx. 2/5 of the small diameter end. (For details, see TESTING AND ADJUSTING.)]

TROUBLESHOOTING


H-1

020706

	Cause	Remedy
	Defective adjustment of TVC valve	Adjust
	Defective servo assembly (defective TVC valve)	Repair or replace
	Defective piston pump	Repair or replace
	Defective servo assembly (defective LS valve)	Repair or replace
	Defective piston pump (servo piston)	Repair or replace
	Defective operation of LS-EPC solenoid valve	Replace
	Defective operation of main relief assembly (valve which becomes normal when adjusted)	Adjust
	Defective operation of unload valve (valve which becomes normal when replaced)	Replace
	Defective operation of main relief valve	Replace
	Defective hydraulic equipment in control pump circuit (See TESTING AND ADJUSTING)	Repair or replace

H-2 There is excessive drop in engine speed, or engine stalls

- ★ Carry out troubleshooting in the H/O mode.
- ★ Check that the main relief pressure is normal.



Note 1: Replace the servo valve assembly on the defective side with a new part, and if the engine speed is lower than the reference value below, carry out troubleshooting for S mode (engine). If it is higher, it can be judged that the TVC valve (servo valve assembly) is defective, so replace it.


- ★ Engine speed (reference) at arm IN relief when engine and pump are normal

Engine speed at arm IN relief	Conditions
2,030 ± 100rpm	• Engine at high idling • Power max. mode • L.H. knob switch ON


TROUBLESHOOTING

H-3, H-4

H-3 No work equipment, travel, swing move



H-4 Abnormal noise generated (around pump)



H-5 Auto-deceleration does not work (when PPC shuttle valve is cause)

- ★ The control pressure for the travel and swing passes through the PPC shuttle valve and is supplied to the pressure switch.

		Cause	Remedy
Does condition become normal when pressure switch is replaced? 1 YES	YES	Defective pressure switch	Replace
	NO	Defective operation of PPC shuttle valve in applicable system (swing or travel)	Repair or replace


H-6 Fine control ability is poor or response is poor

020706

		Cause	Remedy	
Is output pressure of LS-EPC normal? 1 • Engine speed: Max. 1350 rpm • Output pressure: 2.2 ± 0.2 MPa (22 ± 2 kg/cm²)	YES	Is throttle in LS circuit clogged?		
	2 YES		Clogged throttle in LS circuit	Clean
	NO		Defective servo valve assembly (LS valve), or defective servo piston	Replace
	NO		Defective LS-EPC valve	Repair or replace

H-7 Boom is slow or lacks power

- ★ When travel and swing speeds are normal.
- ★ Carry out troubleshooting in the H/O mode.



020706

Note 1: If auto-deceleration is canceled when boom RAISE or boom LOWER is operated, system is normal.

Note 2: After inspection, do not forget to return the interchanged valves to the original position.

TROUBLESHOOTING


H-7

		Cause	Remedy
7 YES Is operating pressure normal when boom RAISE is being operated? • 15.7 ± 1.0 MPa (160 ± 10 kg/cm²) • Engine at high idling • At max. reach, no load	High	Defective operation of boom lock valve	Correct or replace
	Low	Defective boom cylinder piston packing	Correct or replace
8 YES Is pump merge/divider solenoid valve output pressure normal? • When boom is raised: 0 MPa (0 kg/cm²)	NO	Defective operation of LS shuttle valve (LS shuttle for R.H. travel or bucket)	Correct or replace
		Defective operation of pump merge/divider valve or LS pump merge/divider valve	Correct or replace
		Defective operation of pump merge/divider solenoid valve	Correct or replace
		Defective boom lock valve or suction valve for boom in control valve	Replace
		Defective operation of boom lock valve	Correct or replace
		Defective operation of boom regeneration valve	Correct or replace
		Defective operation of boom pressure compensation valve or pressure compensation piston (for boom RAISE end, check boom Hi also)	Correct or replace
		Defective operation of control valve spool (for boom RAISE end, check boom Hi spool also)	Correct or replace
		Defective PPC valve	Replace
		Defective boom RAISE or boom LOWER pressure switch	Replace

020706

H-8 Arm is slow or lacks power

- ★ When travel and swing speeds are normal.
- ★ Carry out troubleshooting in the H/O mode.



020706

Note 1: If the auto-deceleration is canceled when arm IN or arm OUT is operated, the system is normal.

Note 2: After inspection, do not forget to return the interchanged valves to the original position.

TROUBLESHOOTING


H-8

		Cause	Remedy
Is leakage from arm cylinder normal? 7 YES • Max. 20 cc/min • Engine at high idling NO		Defective operation of arm regeneration valve	Correct or replace
		Defective arm cylinder piston packing	Correct or replace
		Defective operation of LS shuttle valve (LS shuttle for L.H. travel, boom, R.H. travel or bucket)	Correct or replace
		Defective safety-suction valve for arm	Replace
		Defective operation of arm pressure compensation valve or pressure compensation piston (for arm Lo and arm Hi)	Correct or replace
		Defective operation of control valve spool (for arm Lo and arm Hi)	Correct or replace
		Defective PPC valve	Replace
		Defective arm IN or arm OUT pressure switch	Replace

020706

H-9 Bucket is slow or lacks power

★ When travel and swing speeds are normal.




Note 1: If the auto-deceleration is canceled when bucket CURL or bucket DUMP is operated, the system is normal.

Note 2: After inspection, do not forget to return the interchanged valves to the original position.

H-10 Work equipment (boom, arm, bucket) does not move (but travel and swing are normal)

- ★ When boom, arm, and bucket are each operated independently.




- Min. 2.7 MPa (28 kg/cm²)
- Engine at high idling

NO

Cause	Remedy
Defective control valve spool	Correct or replace
Defective PPC valve	Replace


H-11 Excessive hydraulic drift (boom, arm, bucket)

1) Excessive hydraulic drift of boom



- See TESTING AND ADJUSTING.
- It is also possible to measure leakage of cylinder.
- Max. 20 cc/min
- At relief
- Engine at high idling


NO



NO


Cause	Remedy
Defective hydraulic cylinder piston packing	Replace
Defective operation of safety-suction valve	Replace
Defective operation of boom lock valve	Correct or replace

2) Excessive hydraulic drift of arm or bucket




- See TESTING AND ADJUSTING.
- It is also possible to measure leakage of cylinder.
- Max. 20 cc/min
- At relief
- Engine at high idling

NO



NO




NO

- It is also possible to interchange with other compensation valve.
- See Note 1.

Cause	Remedy
Defective hydraulic cylinder piston packing	Replace
Defective operation of safety-suction valve	Replace
Defective control valve spool	Replace
Damaged slipper seal of pressure compensation valve, or defective operation of pressure compensation piston	Correct or replace

Note 1: After inspection, do not forget to return the interchanged valves to the original position.

H-12 Excessive time lag (engine at low idling)



Note 1: Output pressure of LS-EPC solenoid

- 2.2 ± 0.2 MPa (22 ± 2 kg/cm²) is output from the LS-EPC solenoid when the engine is at low idling (approx. 1350 rpm or below) regardless of the working mode.

Note 2: After inspection, do not forget to return the interchanged valves to the original position.

H-13 Other equipment moves when single circuit is relieved

Cause	Remedy
Defective operation of pressure compensation valve slipper seal (The slipper seal in the pressure compensation valve of the circuit that moved is defective.)	Replace

020706

H-14 In L/O, F/O modes, work equipment speed is faster than specified speed

		Cause	Remedy
1 YES Is output pressure of LS-EPC solenoid valve normal? • See Note 1.		Defective LS valve	Correct or replace
	NO	Defective operation of LS-EPC solenoid valve	Correct or replace

Note 1: Output pressure of LS control EPC solenoid (travel OFF)

- 2.2 ± 0.2 MPa (22 ± 2 kg/cm²) is output from the LS-EPC solenoid when the engine is at low idling (approx. 1350 rpm or below) regardless of the working mode.

H-15 Defective actuation of machine push-up function

★ When electrical system is normal.

		Cause	Remedy
1 YES Is output pressure of machine push-up solenoid valve as shown in Table 1? • Engine at high idling • For details of the measurement procedure, see TESTING AND ADJUSTING.		Defective safety valve	Replace
	NO	Defective operation of solenoid valve	Correct or replace

Table 1

Machine push-up switch	Oil pressure MPa (kg/cm ²)
① Low pressure setting	$2.9^{+0.5}_{-0.3}$ (30^{+5}_{-3})
② High pressure setting	0

H-16 In compound operations, work equipment with larger load is slow

Cause	Remedy
Defective operation of pressure compensation valve	Replace (replace pressure compensation valve on side where load is lower)

	Combination of compound operation	Side where load is larger
1	Boom RAISE + arm IN	Boom RAISE
2	Boom RAISE + arm OUT	Arm OUT
3	Boom RAISE + bucket CURL	Boom RAISE
4	Arm OUT + bucket CURL	Arm OUT
5	Boom LOWER + arm OUT	Arm OUT

H-17 In swing + boom RAISE, boom RAISE is slow

- ★ If swing and boom RAISE work normally when operated independently.
- ★ Carry out troubleshooting with the swing priority mode OFF.

		Cause	Remedy
1 Is output pressure of LS select solenoid valve normal? • Min. 2.7 MPa (28 kg/cm²) • Operate boom RAISE (operate lever slightly) YES NO	YES	Defective operation of LS select valve	Correct or replace
	NO	Defective operation of LS select solenoid valve	Correct or replace
	2 Does PPC shuttle valve for LS select circuit move smoothly? YES NO	Defective operation of PPC shuttle valve for LS select circuit (PPC shuttle for boom RAISE, LS select)	Correct or replace

H-18 In swing + arm, arm is slow

- ★ See H-17.
 (If the operation is normal when the swing and arm are operated independently, carry out troubleshooting with the swing priority mode OFF.
 If the Cause column shows that there is defective operation of the LS shuttle valve, the cause is in the shuttle valve for the arm OUT, IN and LS select.)


H-19 In swing + travel, travel speed drops excessively

- ★ See H-17.
 (If the operation is normal when the swing and travel are operated independently, carry out troubleshooting with the swing priority mode OFF.
 If the Cause column shows that there is defective operation of the PPC shuttle valve, the cause is in the shuttle valve for the LS select.)

H-20 Travel deviation

- ★ Carry out troubleshooting in the H/O mode.
- ★ When swing and work equipment speeds are normal.

a) When there is deviation in normal travel




Note 1: • Remove the PPC shuttle block inlet hose, fit an adapter, and block the tip.
 • If the adapter for blocking the circuit is not available, interchange the travel PPC hoses with the PPC hoses for the bucket (CURL, DUMP), boom (LOWER), or arm (IN) at both the inlet and outlet ports of the shuttle block, and check operation.

b) Excessive travel deviation when starting

Cause	Remedy
Defective operation of travel counterbalance valve	Correct or replace
Clogging of throttle inside servo of front or rear pump	Correct or replace

H-21 Travel speed is slow

- ★ Check that the spool of the travel PPC valve is moving the full stroke before carrying out troubleshooting.
- ★ Carry out troubleshooting in the H/O mode.
- ★ When swing and work equipment speeds are normal.



- Note 1: • Measure the travel speed under no load or measure the time taken to travel 20 m. (See MAINTENANCE STANDARD FOR CHASSIS RELATED PARTS.)
- When measuring the speed of the travel motor under no load → Remove connector of LS control EPC solenoid, and measure travel speed in Lo and Hi.

Note 2: Output pressure of LS-EPC solenoid

unit: MPa (kg/cm²)

Engine speed (rpm) \ Travel speed	Lo	Mi	Hi
Max. 1,350	2.2 ± 0.2 (22.0 ± 2.0)	2.2 ± 0.2 (22.0 ± 2.0)	2.2 ± 0.2 (22.0 ± 2.0)
Max. 1,800	0.6 ± 0.2 (6.7 ± 2.0)	2.9 ± 0.2 (30.0 ± 2.0)	0.6 ± 0.2 (6.7 ± 2.0)
Max. 1,900	0.3 ± 0.2 (3.3 ± 2.0)	2.9 ± 0.2 (30.0 ± 2.0)	0.3 ± 0.2 (3.3 ± 2.0)

TROUBLESHOOTING

H-21


		Cause	Remedy
		Defective operation of LS shuttle valve (for bucket)	Correct or replace
		Defective operation of LS-EPC solenoid valve	Correct or replace
		Defective travel pressure switch	Replace
8 YES Does condition become normal when travel suction valve for control valve is replaced? • See Note 1.		Defective operation of travel suction valve for control valve	Correct or replace
		Defective travel motor assembly	Correct or replace
		Defective pressure compensation valve, or defective operation of pressure compensation piston	Correct or replace
		Defective operation of travel spool for control valve	Correct or replace
		Defective operation of junction valve	Correct or replace
		Defective PPC shuttle	Correct or replace
		Defective PPC valve	Replace

Note 3: After inspection, do not forget to return the interchanged valves to the original position.

Note 4: • Remove the PPC shuttle block inlet hose, fit an adapter, and block the tip.
 • If the adapter for blocking the circuit is not available, interchange the travel PPC hoses with the PPC hoses for the bucket (CURL, DUMP), boom (LOWER), or arm (IN) at both the inlet and outlet ports of the shuttle block, and check operation.

H-22 Steering does not turn easily or lacks power

★ Carry out troubleshooting in the H/O mode.



020706

		Cause	Remedy
		Defective operation of pump merge/divider valve or LS pump merge/divider valve	Correct or replace
		Defective operation of main pump merge/divider solenoid valve	Correct or replace
		Defective operation of travel junction valve spool	Correct or replace
		Defective operation of LS circuit check valve	Correct or replace
		Defective control valve suction valve	Replace
		Defective travel motor check valve	Correct or replace
		Defective travel motor safety valve	Replace
		Defective operation of LS shuttle valve for bucket	Correct or replace
		Defective travel pressure switch	Replace

Does bucket LS shuttle valve move smoothly?

6 YES

NO

Does condition become normal when suction valve of control valve is interchanged?

7 YES

• Interchange left and right spools. NO

Does condition become normal when suction valve of motor is interchanged?

8 YES

NO

020706

H-23 Travel speed does not switch or is faster than specified speed

★ Carry out troubleshooting in the H/O mode.





Table 1. Output pressure of LS-EPC solenoid

Unit: MPa (kg/cm²)

Travel speed	Lo	Mi	Hi
LS-EPC output pressure	0.2 ± 0.2 (2.0 ± 2.0)	2.9 ± 0.2 (30.0 ± 2.0)	0.2 ± 0.2 (2.0 ± 2.0)
Remarks	• Engine at high idling • Operate travel lever slightly (auto-deceleration cancel position)		


020706

H-24 Travel does not move (one side only)




H-25 Does not swing

a) Does not swing to either left or right




b) Does not swing in one direction



H-26 Swing acceleration is poor or swing speed is slow

- ★ Carry out troubleshooting in the H/O mode.
- ★ If condition is normal when work equipment is operated independently.

a) Swing acceleration is poor



020706


- Note 1:
- Remove the PPC shuttle block inlet hose, fit an adapter, and block the tip.
 - If the adapter for blocking the circuit is not available, interchange the swing PPC hoses with the PPC hoses for the bucket (CURL, DUMP), at both the inlet and outlet ports of the shuttle block, and check operation.
- Note 2: After inspection, do not forget to return the interchanged valves to the original position.

	Cause	Remedy
	Defective swing motor assembly	Replace
	Defective operation of LS shuttle valve (all LS shuttles)	Correct or replace
	Defective operation of swing motor safety-suction valve	Correct or replace
	Defective operation of pressure compensation valve or compensation piston	Correct or replace
	Defective operation of control valve spool for swing	Correct or replace
	Defective operation of PPC shuttle valve	Correct or replace
	Defective PPC valve	Replace

020706

H-27 Excessive overrun when stopping swing

a) One direction only



b) Both directions

Cause	Remedy
Defective swing motor	Repair or replace

020706

H-28 Excessive shock when stopping swing (one direction only)


		Cause	Remedy
1 YES Does condition become normal when left and right swing PPC slow return valves are interchanged? NO	YES	Defective swing PPC slow return valve (check valve)	Correct or replace
	NO	Defective PPC valve	Replace

H-29 Excessive abnormal noise when stopping swing


		Cause	Remedy
1 YES Does condition become normal when swing motor safety-suction valve is cleaned? NO	YES	Defective operation of swing motor safety-suction valve	Clean
	2 YES Does condition become normal when swing motor safety-suction valve is replaced? NO	Defective swing motor safety-suction valve	Replace
		Defective swing machinery	Repair or replace
	3 YES Is foreign material found in swing machinery? NO	Defective back pressure valve	Correct or replace
	NO		

H-30 Excessive hydraulic drift of swing

a) When swing holding brake is released



b) When swing holding brake is applied



H-31 Swing speed is faster than specified swing speed

		Cause	Remedy
Is output pressure of LS-EPC solenoid valve normal? • See Table 1.	1 YES	Defective operation of LS valve	Replace servo assembly
	NO	Defective LS-EPC solenoid	Correct or replace

Table 1. Output pressure of LS-EPC solenoid valve
unit: MPa (kg/cm²)

H/O mode	G/O mode	F/O mode	L/O mode
0.2 ± 0.2 (2.0 ± 2.0)	0.2 ± 0.2 (2.0 ± 2.0)	1.5 ± 0.2 (15.4 ± 2.0)	2.2 ± 0.2 (22.0 ± 2.0)
• Engine at high idling • Travel OFF			

TROUBLESHOOTING OF MACHINE MONITOR SYSTEM (M MODE)

Action taken by monitor panel and condition of machine when abnormality occurs	20-504
Electrical circuit diagram for monitor system	20-506
M-1 [E101] Abnormality in error data is displayed	
[E102] Error in clock data is displayed	20-508
M-2 [E103] Short circuit in buzzer output or contact of 24V wiring harness	
with buzzer drive harness is displayed	20-509
M-3 [E104] Air cleaner clogging detected is displayed	20-510
M-4 [E106] Drop in engine oil pressure Hi detected is displayed	20-510
M-5 [E108] Engine water temperature 105°C detected is displayed	20-511
M-6 When starting switch is turned ON, none of lamps on monitor panel	
light up for 3 seconds	20-512
M-7 When starting switch is turned ON, monitor panel lamps all stay lighted up	
and do not go out	20-514
M-8 When starting switch is turned ON, items lighted up on monitor panel are different from	
actual machine (model)	20-514
M-9 When starting switch is turned ON (engine stopped), basic check items flash	20-515
M-10 Preheating is not being used but preheating monitor lights up	20-518
M-11 When starting switch is turned ON and engine is started, basic check items flash	20-519
M-12 When starting switch is turned ON (engine stopped), caution items,	
emergency stop items flash	20-521
M-13 When starting switch is turned ON and engine is started, caution items,	
emergency stop items flash	20-523
M-14 When starting switch is turned ON (engine stopped), buzzer does not sound for 1 second	
Caution item flashes but buzzer does not sound	20-526
M-15 No abnormality is displayed on monitor but buzzer sounds	20-526
M-16 Night lighting on monitor panel does not light up (liquid crystal display is normal)	20-527
M-17 Coolant temperature gauge does not rise	20-528
M-18 Coolant temperature gauge does not give any display	20-528
M-19 Fuel level gauge always displays FULL	20-529
M-20 Fuel level gauge does not give any display	20-529
M-21 Swing lock switch is turned ON (LOCK) but swing lock monitor does not light up	20-530
M-22 Swing prolix switch is turned ON (prolix), but swing lock monitor does not flash	20-530
M-23 Service meter does not advance while engine is running	20-531
M-24 When starting switch is at OFF and time switch is pressed,	
time and service meter are not displayed	20-531
M-25 Defective fuel level sensor system	20-532
M-26 Defective coolant temperature sensor system	20-533

M-27 Defective engine oil level sensor system	20-534
M-28 Defective coolant level sensor system	20-535
M-29 Defective hydraulic oil level sensor system	20-536
M-30 Wiper does not work or switch is not being used but wiper is actuated	20-537
M-31 Electric grease gun does not work	20-541

**ACTION TAKEN BY MONITOR PANEL WHEN ABNORMALITY
OCCURS AND PROBLEMS ON MACHINE**

User code	Service code	Abnormal system	Nature of abnormality
—	E101	Abnormality in error data	1. Abnormality in internal memory 2. Excess voltage (more than 36V) has occurred 3. Low voltage (less than 12V) has occurred 4. Connector has separated
—	E102	Abnormality in clock data	1. Abnormality in internal clock function 2. Excess voltage (more than 36V) has occurred 3. Low voltage (less than 12V) has occurred 4. Connector has separated
—	E103	Short circuit in buzzer output system	1. Short circuit inside buzzer 2. Power line in contact with wiring harness between monitor (P01 (7) pin) and buzzer 3. Abnormality in monitor panel
—	E104	Air cleaner clogging detected is displayed	1. Air cleaner clogging sensor has detected clogging
—	E106	Drop in engine oil Hi pressure detected is displayed	1. Engine oil pressure Hi sensor has detected drop in oil pressure
—	E108	Engine water temperature 105°C detected is displayed	1. Coolant temperature gauge has detected water temperature of 105°C

TROUBLESHOOTING**ACTION TAKEN BY MONITOR PANEL WHEN ABNORMALITY OCCURS AND PROBLEMS ON MACHINE**

Condition when normal (voltage, current, resistance)	Action by controller when abnormality is detected	Problem that appears on machine when there is abnormality
When starting switch is turned ON, keep time switch pressed for 5 seconds to actuate clear function	—	- Service code cannot be cleared - Time becomes 00:00.
	—	- Service code cannot be cleared - Time becomes 00:00. - Clock does not advance.
- Voltage between P01 (7) – chassis Buzzer ON: Max. 1V Buzzer OFF: 20 – 30V ★ When there is a disconnection, E103 is not displayed and the buzzer does not sound	—	Buzzer does not sound
Resistance between P11 (male) – P12 (male): Min. 1 Ω (engine started)	—	If abnormality detection continues, air cleaner clogging caution lamp flashes and buzzer sounds
Resistance between sensor terminal and chassis: Min. 1 MΩ (engine at mid-range speed or above)	—	If abnormality detection continues, engine oil pressure caution lamp flashes and buzzer sounds
Resistance between P07 (1) – (2): Min. 3.156 Ω (engine started)	—	- If abnormality detection continues, coolant temperature caution lamp flashes and buzzer sounds - If abnormality detection continues, engine speed is reduced to low idling

020706



020706

M-1 [E101] Abnormality in error data is displayed [E102] Error in clock data is displayed

- ★ This is not an abnormality. It occurs during troubleshooting when disconnecting and connecting connector P02 (for the monitor panel electrical system), fuse No. 13, connector M14, connector M11, battery relay terminal B, or the battery terminal.
(When the monitor panel power source circuit is shut off with the starting switch turned OFF.)
- ★ If the service code display appears again after the system has been reset, carry out troubleshooting as follows.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.


		Cause	Remedy
Does service code display appear again after system has been reset? 1 YES Is voltage between P02 (8)(14) and chassis normal? • Turn starting switch OFF. • 20 - 30 V 2 YES NO • After resetting system, carry out normal operations for a short time and watch the condition. (See Note 1.)		Defective monitor panel	Replace
		Disconnection, defective contact, short circuit with ground in wiring harness between battery - battery relay B - M11 (1)(2) - H14 (1) - fuse No. 13 - P02 (female) (8)(14)	Repair or replace
		Normal	—

Note 1: Resetting operation:

Turn the starting switch OFF. Then keep the time switch at the back of the monitor panel depressed, switch the starting switch ON again, and keep the time switch depressed for 5 seconds to return the system to normal.

(With this operation, all the service codes in the internal memory are erased.)

M-1 Related electric circuit diagram



BKP00272

M-2 [E103] Short circuit in buzzer output or contact of 24V wiring harness with buzzer drive harness is displayed


- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the system has been reset.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

		Cause	Remedy
Is resistance between P04 (male) (1) – (2), (2) – chassis as shown in the table? 1 YES • Turn starting switch OFF. • Disconnect P04.	Is voltage between P04 (2) and chassis normal? 2 YES	Defective monitor panel	Replace
	NO	Short circuit with power source in wiring harness between P01 (female)(7) and P04 (female)(2) or short circuit in wiring harness between P04 (1) and (2)	Repair or replace
	NO	Defective buzzer	Replace

Table

P04 (male)	Resistance value
Between (1) and (2)	200 – 300 Ω
Between (2) and chassis	Min. 1 MΩ

M-2 Related electric circuit diagram



BKP00273

M-3 [E104] Air cleaner clogging detected is displayed

		Cause	Remedy
1 Is air cleaner clogging caution lamp on monitor flashing? YES NO	YES	See M-13 f)	—
	2 Is "E" service code displayed? YES NO	Defective monitor panel	Replace
	• Turn starting switch ON.	Failure in engine system (See Note 1)	—

Note 1: The monitor panel display has returned to normal, but the air cleaner clogging sensor has detected symptoms of clogging in the past, so carry out troubleshooting of the engine to remove the problem.

M-4 [E106] Drop in engine oil Hi pressure detected is displayed

		Cause	Remedy
1 Is engine oil pressure caution lamp on monitor flashing? YES NO	YES	See M-13 a)	—
	2 Is "E" service code displayed? YES NO	Defective monitor panel	Replace
	• Turn starting switch ON.	Failure in engine system (See Note 1)	—

Note 1: The monitor panel display has returned to normal, but the engine oil pressure Hi sensor has detected symptoms of a drop in the oil pressure in the past, so carry out troubleshooting of the engine to remove the problem.

M-5 [E108] Engine water temperature 105°C detected is displayed

		Cause	Remedy
Does coolant temperature gauge on monitor panel display red range and is caution lamp flashing? 1 YES NO		See M-13 d)	—
	2 YES Is "E" service code displayed?	Defective monitor panel	Replace
	• Turn starting switch ON. NO	Failure in engine system (See Note 1)	


Note 1: The monitor panel display has returned to normal, but the coolant temperature sensor has detected symptoms of the coolant temperature reaching 105°C in the past, so carry out troubleshooting of the engine to remove the problem.

020706

M-6 When starting switch is turned ON, none of lamps on monitor panel light up for 3 seconds

- ★ Check that fuses No. 10 and 13 are not blown.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

a) None of lamps on monitor panel light up




020706

b) Some of lamps on monitor panel do not light up

Cause	Remedy
Defective monitor panel	Replace

M-6 a) Related electric circuit diagram



BKP00274

020706

M-7 When starting switch is turned ON, monitor panel lamps all stay lighted up and do not go out


	Cause	Remedy
	Defective monitor panel	Replace

M-8 When starting switch is turned ON, items lighted up on monitor panel are different from actual machine (model)

- ★ Immediately after replacing the monitor panel, turn the starting switch OFF, then turn it ON again and check.

1 YES Is display of monitoring code 01 as shown in table? • Turn starting switch ON. • Set to monitoring code 01.		Cause	Remedy
	NO	Defective monitor panel	Replace
		Go to troubleshooting for C mode (See C-14)	—

Table




M-9 When starting switch is turned ON (engine stopped), basic check items flashes

- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

a) (coolant level) flashes

SAP00519


- ★ Check that the coolant is at the specified level before carrying out troubleshooting.



Table

Short connector	Continuity
Connected	Yes
Disconnected	No

M-9 a) Related electric circuit diagram




BKP00277

TROUBLESHOOTING

b) (engine oil level) flashes

SAP00523

★ Check that the engine oil is at the specified level before carrying out troubleshooting.




020706

Table

Chassis ground	Continuity
Connected	Yes
Disconnected	No

M-9 b) Related electric circuit diagram




BKP00278

c) (hydraulic oil level) flashes

SAP00524


- ★ Check that the hydraulic oil is at the specified level before carrying out troubleshooting.



Table

Chassis ground	Continuity
Connected	Yes
Disconnected	No

M-9 c) Related electric circuit diagram



BKP00279


M-10 Preheating is not being used but lights up




SAP00526

(preheating monitor)

- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.



M-10 Related electric circuit diagram




BKP00280


M-11 When starting switch is turned ON and engine is started, basic check items flash

- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.
- ★ Check both the alternator system and the engine oil pressure system.

a) Alternator system



M-11 a) Related electric circuit diagram




BKP00282



b) Engine oil pressure system

★ When engine oil pressure is normal.

1) Low-pressure sensor



2) High-pressure sensor


**M-11 b) Related electric circuit diagram**

BKP00283


M-12 When starting switch is turned ON (engine stopped), caution items, emergency items flash (battery, engine oil pressure lamps do not light up)

- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.
- ★ Check both the alternator system and the engine oil pressure system.

a) Alternator system



M-12 a) Related electric circuit diagram




BKP00282


b) Engine oil pressure sensor system

★ When engine oil pressure is normal.


1) Low-pressure sensor



2) High-pressure sensor



M-12 b) Related electric circuit diagram



BKP00283

M-13 When starting switch is turned ON and engine is started, caution items, emergency items flash (when there is no abnormality in engine or items to check before troubleshooting)

- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

a) (engine oil pressure) flashes

SAP00520

- ★ Check that the engine oil pressure is normal before carrying out troubleshooting.

Cause	Remedy
See M-11 b)	—

b) (coolant level) flashes

SAP00519

- ★ Check that the coolant level is normal before carrying out troubleshooting.

Cause	Remedy
See M-9 a)	—

c) (battery charge) flashes

SAP00522

Cause	Remedy
See M-11 a)	—


TROUBLESHOOTING

M-13

d) (coolant temperature) flashes


SAP00527

- ★ Check that the coolant temperature is normal before carrying out troubleshooting.



Cause	Remedy
Defective coolant temperature sensor system (see M-26)	—
Defective governor, pump controller	Replace
Short circuit of wiring harness between C03 (female) (1) – E08 (6) – P07 (female) (1) and wiring harness between C03 (female) (16) – E08 (11) – P07 (female) (2)	Repair or replace
Defective monitor panel	Replace

M-13 d) Related electric circuit diagram




BKP00284

e) (fuel level) flashes


SAP00528

- ★ Check that there is fuel before carrying out troubleshooting.



Cause	Remedy
Defective fuel level sensor system (see M-25)	—
Defective governor, pump controller	Replace
Defective contact or disconnection in wiring harness between C03 (female) (2) and P06 (female) (1)	Repair or replace
Defective monitor panel	Replace

M-13 e) Related electric circuit diagram




BKP00285


f) (air cleaner clogging) flashes

SAP00521

- ★ Check that the air cleaner is not clogged before carrying out troubleshooting.




M-13 f) Related electric circuit diagram



BKP00286


M-14 When starting switch is turned ON (engine stopped), buzzer does not sound for 1 second Caution item flashes but buzzer does not sound

- ★ Of the caution items, the buzzer will not sound even if there is an abnormality in the battery charge or fuel level.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.




M-15 No abnormality is displayed on monitor but buzzer sounds

- ★ When the buzzer sounds continuously.
If the buzzer sounds intermittently, carry out troubleshooting M-14.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.




M-14, 15 Related electric circuit diagram



BKP00273


M-16 Night lighting on monitor panel does not light up (liquid crystal display is normal)

★ When the front lamp and working lamp light up normally.



020706


M-16 Related electric circuit diagram



BKP00287


M-17 Coolant temperature gauge does not rise

- ★ If the coolant temperature actually does not rise, check the engine system.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.




M-18 Coolant temperature gauge does not give any display (none of gauge lamps light up during operation)

- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.




M-17, 18 Related electric circuit diagram



BKP00284


M-19 Fuel level gauge always displays FULL

- ★ Check if the tank is actually full before carrying out troubleshooting.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.




M-20 Fuel level gauge does not give display

- ★ Check that there is actually no fuel before carrying out troubleshooting.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.



M-19, 20 Related electric circuit diagram



BKP00285

M-21 Swing lock switch is turned ON (LOCK) but (swing lock monitor) does not light up




- ★ Carry out this troubleshooting only if the swing lock is actually being actuated.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

1 YES		Cause	Remedy
Is voltage between P05 and chassis as shown in table?	YES	Defective monitor panel	Replace
	NO	Defective contact or disconnection in wiring harness between P01 (female) (5) – X01 (4) – X05 (male)	Repair or replace


• Turn starting switch ON.

M-21 Related electric circuit diagram


Monitor panel
P01(04020)



X01(MIC21)




X05(M4)



H14(M6)



Swing lock switch



Table

Swing lock switch ON	Max. 1 V
Swing lock switch OFF	20 – 30 V

BKP00288

M-22 Swing prolix switch is turned ON (prolix), but (swing lock monitor) does not flash



- ★ Carry out this troubleshooting only if the swing prolix is actually being actuated.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

2 YES		Cause	Remedy
Is voltage between C17 (8) and chassis as shown in table?	YES	Defective monitor panel	Replace
	NO	Defective governor, pump controller	Replace
	NO	Defective contact or disconnection in wiring harness between C17 (female) (8) and prolix switch (4)	Repair or replace



• Turn starting switch ON.

Table

Swing prolix switch ON	Max. 1 V
Swing prolix switch OFF	20 – 30 V

M-22 Related electric circuit diagram


Monitor panel Governor, pump controller
C17(04016)



H14(M6)




Swing prolix switch



BKP00289

M-23 Service meter does not advance while engine is running




020706

M-24 When starting switch is at OFF and time switch is pressed, time and service meter are not displayed




M-25 Defective fuel level sensor system

★ Remove the fuel level sensor when carrying out the troubleshooting.



Table

Top (FULL) stopper position	Approx. 12 Ω or below
Bottom (EMPTY) stopper position	Approx. 85 – 110 Ω




Note 1: Difference between fuel level and gauge display

For gauge display position 14 (FULL), the amount of fuel is 78-100%; and for display position 1 (EMPTY) it is below 14.5%. If the chassis is at an angle, the displayed amount of fuel will be different from the actual amount. Therefore, when checking, stop the machine at a horizontal place and wait for at least 2 minutes before checking the gauge. (The display is given a time delay so that the gauge can deal with sudden changes in the fuel level.)

Note 2: There is the possibility of defective installation or interference with the sensor inside the tank, so be careful when installing.


Note 3: Check for vibration at the connector mount. If there is excessive vibration, take the appropriate action.

M-26 Defective coolant temperature sensor system



Table

Normal temperature (25°C)	Approx. 37 – 50 kΩ
100°C	Approx. 3.5 – 4.0 kΩ




BKP00291

Note 1: If the problem occurs again, the connector (female) at the chassis end is probably defective, so check the connector and wiring harness at the chassis end.

Note 2: Check for vibration at the connector mount. If there is excessive vibration, take the appropriate action.


M-27 Defective engine oil level sensor system

★ Remove the engine oil level sensor when carrying out troubleshooting.



Table

Float UP	Max. 1 Ω
Float DOWN	Min. 1 MΩ



BLP00292

Note 1: Variations in oil level

The oil level may change according to the angle of the machine, the engine speed, or the temperature of the oil, so if there is any display, check the oil level again with the machine at a horizontal place.


Note 2: If the problem occurs again, the connector (female) at the chassis end is probably defective, so check the connector and wiring harness at the chassis end.

Note 3: Check for vibration at the connector mount. If there is excessive vibration, take the appropriate action.

Note 4: Defective installation is a possible cause, so be careful when installing. If the problem occurs again, check for any vibration of the mount, and if there is excessive vibration, take the appropriate action.


M-28 Defective coolant level sensor system

★ Remove the coolant level sensor when carrying out troubleshooting.



Table

Float UP	Max. 1 Ω
Float DOWN	Min. 1 MΩ



BLP00293

Note 1: Variations in coolant level

The coolant level may change according to the angle of the machine, or the swaying of the machine, so if there is any display, check the coolant level again with the machine at a horizontal place.


Note 2: If the problem occurs again, the connector (female) at the chassis end is probably defective, so check the connector and wiring harness at the chassis end.

Note 3: Check for vibration at the connector mount. If there is excessive vibration, take the appropriate action.

Note 4: Defective installation is a possible cause, so be careful when installing. If the problem occurs again, check for any vibration of the mount, and if there is excessive vibration, take the appropriate action.


M-29 Defective hydraulic oil level sensor system

★ Remove the hydraulic oil level sensor when carrying out troubleshooting.



Table

Float UP	Max. 1 Ω
Float DOWN	Min. 1 MΩ



BLP00292

Note 1: Variations in hydraulic oil level

The hydraulic oil level may change according to the angle of the machine, or the swaying of the machine, so if there is any display, check the hydraulic oil level again with the machine at a horizontal place.

Note 2: If the problem occurs again, the connector (female) at the chassis end is probably defective, so check the connector and wiring harness at the chassis end.

Note 3: Check for vibration at the connector mount. If there is excessive vibration, take the appropriate action.

Note 4: Defective installation is a possible cause, so be careful when installing. If the problem occurs again, check for any vibration of the mount, and if there is excessive vibration, take the appropriate action.

M-30 Wiper does not work or switch is not being used but wiper is actuated

a) Wiper does not work

- ★ Check that fuse No. 7 is normal.




Table 1


Actuation mode	M18 (female)	W08 (female)	Resistance (Ω)
INT mode	Between (1) - (4)	Between (12) - (15)	Max. 1 Ω
	Between (1) - (2)	Between (12) - (14)	Max. 1 MΩ
	Between (2) - (4)	Between (14) - (15)	
OFF mode	Between (1) - (2)	Between (12) - (14)	Max. 1 MΩ
	Between (1) - (4)	Between (12) - (15)	
	Between (2) - (4)	Between (14) - (15)	
ON mode	Between (1) - (2)	Between (12) - (14)	Max. 1 Ω
	Between (1) - (4)	Between (12) - (15)	Max. 1 MΩ
	Between (2) - (4)	Between (14) - (15)	

Table 2


Between W04 (female) (1) - W08 (female) (7)	Max. 1 Ω
Between W04 (female) (3) - W08 (female) (6)	
Between W04 (female) (4) - W08 (female) (11)	
Between W04 (female) (5) - W08 (female) (9)	
Between W04 (female) (6) - W08 (female) (10)	
Between W04 (female) (1)(3)(4)(5)(6) - GND	Min. 1 MΩ

Table 3


Timing chart (when wiper is ON)



Timing chart (for wiper INT)



M-30 Related electric circuit diagram



b) Wiper switch is not being used but wiper is actuated





Table 1


Actuation mode	M18 (female)	W08 (female)	Resistance (Ω)
INT mode	Between (1) – (4)	Between (12) – (15)	Max. 1 Ω
	Between (1) – (2)	Between (12) – (14)	Max. 1 M Ω
	Between (2) – (4)	Between (14) – (15)	
OFF mode	Between (1) – (2)	Between (12) – (14)	Max. 1 M Ω
	Between (1) – (4)	Between (12) – (15)	
	Between (2) – (4)	Between (14) – (15)	
ON mode	Between (1) – (2)	Between (12) – (14)	Max. 1 Ω
	Between (1) – (4)	Between (12) – (15)	Max. 1 M Ω
	Between (2) – (4)	Between (14) – (15)	

Table 3


Timing chart (when wiper is ON)



Timing chart (for wiper INT)



M-30 Related electric circuit diagram




M-31 Electric grease gun does not work

- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.
- ★ Check that there is grease before starting troubleshooting.
- ★ Check that fuse No. 1 for the electric grease gun is normal.

		Cause	Remedy
1 YES Is voltage between electric grease gun connector CN (1) and chassis normal? • Turn starting switch ON. • 20 – 28 V	2 YES	Defective electric grease gun	Repair or replace
	NO	Defective contact or disconnection in wiring harness between CN (female) (2) and chassis	Repair or replace
	NO	Defective contact or disconnection in wiring harness between CN (female) (1) and fuse No.1	Repair or replace

M-31 Related electric circuit diagram



30 DISASSEMBLY AND ASSEMBLY

020706

METHOD OF USING MANUAL	30- 3	CENTER SWIVEL JOINT ASSEMBLY	
PRECAUTIONS WHEN CARRYING OUT		Removal and Installation	30-40
OPERATION	30- 5	Disassembly and Assembly	30-41
SPECIAL TOOL LIST	30- 9	FINAL DRIVE ASSEMBLY	
SKETCHES OF SPECIAL TOOLS	30-12	Removal and Installation	30-42
STARTING MOTOR ASSEMBLY		Disassembly	30-43
Removal and Installation	30-14	Assembly	30-47
ALTERNATOR ASSEMBLY		TRAVEL MOTOR ASSEMBLY	
Removal and Installation	30-15	Disassembly	30-52-1
ENGINE OIL COOLER ASSEMBLY		Assembly	30-52-6
Removal and Installation	30-16	SPROCKET	
FUEL INJECTION PUMP ASSEMBLY		Removal and Installation	30-53
Removal	30-17	SWING MOTOR ASSEMBLY	
Installation	30-18	Removal and Installation	30-54
WATER PUMP ASSEMBLY		Disassembly	30-54-1
Removal and Installation	30-19	Assembly	30-54-4
NOZZLE HOLDER ASSEMBLY		SWING MACHINERY ASSEMBLY	
Removal and Installation	30-20	Removal and Installation	30-55
TURBOCHARGER ASSEMBLY		Disassembly	30-56
Removal and Installation	30-21	Assembly	30-60
THERMOSTAT ASSEMBLY		REVOLVING FRAME ASSEMBLY	
Removal and Installation	30-22	Removal	30-65
ENGINE FRONT SEAL		Installation	30-66
Removal	30-23	SWING CIRCLE ASSEMBLY	
Installation	30-24	Removal and Installation	30-67
GOVERNOR MOTOR ASSEMBLY		IDLER, RECOIL SPRING ASSEMBLY	
Removal and Installation	30-25	Removal and Installation	30-68
CYLINDER HEAD ASSEMBLY		IDLER ASSEMBLY	
Removal	30-26	Disassembly	30-69
Installation	30-28	Assembly	30-70
AFTERCOOLER ASSEMBLY		RECOIL SPRING ASSEMBLY	
Removal and Installation	30-31	Disassembly	30-72
HYDRAULIC COOLER ASSEMBLY		Assembly	30-73
Removal	30-32	TRACK ROLLER ASSEMBLY	
RADIATOR, HYDRAULIC COOLER		Removal and Installation	30-74
ASSEMBLY		Disassembly	30-75
Removal	30-33	Assembly	30-76
Installation	30-34	CARRIER ROLLER ASSEMBLY	
ENGINE, MAIN PUMP ASSEMBLY		Removal and Installation	30-78
Removal	30-35	Disassembly	30-79
Installation	30-37	Assembly	30-81
DAMPER ASSEMBLY		TRACK SHOE ASSEMBLY	
Removal and Installation	30-38	Removal and Installation	30-83
FUEL TANK ASSEMBLY			
Removal and Installation	30-39		

HYDRAULIC TANK ASSEMBLY			
Removal	30- 84		
Installation	30- 85		
CONTROL PUMP ASSEMBLY			
Removal and Installation	30- 86		
MAIN PUMP ASSEMBLY			
Removal	30- 87		
Installation	30- 88		
Disassembly	30-88-1		
Assembly	30-88-7		
MAIN PUMP INPUT SHAFT OIL SEAL			
Removal and Installation	30- 89		
CONTROL VALVE ASSEMBLY			
Removal	30- 90		
Installation	30- 92		
Disassembly	30- 93		
Assembly	30- 97		
PUMP MERGE/DIVIDER VALVE ASSEMBLY			
Disassembly and Assembly	30-102		
PRESSURE COMPENSATION VALVE ASSEMBLY			
Disassembly and Assembly	30-103		
SERVO VALVE ASSEMBLY FOR FRONT PUMP			
Removal and Installation	30-105		
SERVO VALVE ASSEMBLY FOR REAR PUMP			
Removal and Installation	30-106		
LS-EPC SOLENOID VALVE ASSEMBLY			
Removal and Installation	30-107		
SOLENOID VALVE ASSEMBLY			
Removal and Installation	30-108		
WORK EQUIPMENT PPC VALVE ASSEMBLY			
Removal and Installation	30-109		
Disassembly	30-110		
Assembly	30-111		
TRAVEL PPC VALVE ASSEMBLY			
Removal and Installation	30-112		
Disassembly	30-113		
Assembly	30-114		
PPC SHUTTLE VALVE ASSEMBLY			
Removal	30-115		
Installation	30-116		
Disassembly	30-117		
Assembly	30-118		
BOOM LOCK VALVE ASSEMBLY			
Removal and Installation	30-119		
Disassembly and Assembly	30-120		
BOOM CYLINDER ASSEMBLY			
Removal	30-121		
Installation	30-122		
ARM CYLINDER ASSEMBLY			
Removal	30-123		
Installation	30-124		
BUCKET CYLINDER ASSEMBLY			
Removal	30-125		
Installation	30-126		
HYDRAULIC CYLINDER ASSEMBLY			
Disassembly	30-127		
Assembly	30-129		
WORK EQUIPMENT ASSEMBLY			
Removal	30-131		
Installation	30-132		
BUCKET ASSEMBLY			
Removal	30-133		
Installation	30-134		
ARM ASSEMBLY			
Removal	30-135		
Installation	30-136		
BUCKET, ARM ASSEMBLY			
Removal	30-137		
Installation	30-138		
BOOM ASSEMBLY			
Removal	30-139		
Installation	30-140		
OPERATOR'S CAB ASSEMBLY			
Removal	30-141		
Installation	30-142		
COUNTERWEIGHT ASSEMBLY			
Removal and Installation	30-143		
AIR CONDITIONER COMPRESSOR ASSEMBLY			
Removal and Installation	30-144		
CONDENSER ASSEMBLY			
Removal and Installation	30-145		
AIR CONDITIONER UNIT ASSEMBLY			
Removal	30-146		
Installation	30-147		
GOVERNOR, PUMP CONTROLLER ASSEMBLY			
Removal and Installation	30-148		
MONITOR PANEL ASSEMBLY			
Removal and Installation	30-149		
CONTROL STAND CASE			
Removal	30-150		
Installation	30-151		

METHOD OF USING MANUAL

1. When removing or installing unit assemblies

- ① When removing or installing a unit assembly, the order of work and techniques used are given for the removal operation; the order of work for the installation operation is not given.
- ② Any special techniques applying only to the installation procedure are marked ※ 1, and the same mark is placed after the relevant step in the removal procedure to indicate which step in the installation procedure it applies to.

(Example)

REMOVAL OF ○○○○ ASSEMBLY	Title of operation
	Precautions related to safety when carrying out the operation
1. XXXX (1)	Step in operation
★	Technique or important point to remember when removing XXXX (1).
2. △ △ △ △ (2):	※ 1 Indicates that a technique is listed for use during installation
3. □ □ □ □ assembly (3)	
	Quantity of oil or water drained
INSTALLATION OF ○○○○ ASSEMBLY	Title of operation
• Carry out installation in the reverse order to removal.	
※ 1	Technique used during installation
★	Technique or important point to remember when installing △ △ △ △ (2).
• Adding water, oil	Step in operation
★	Point to remember when adding water or oil
	Quantity when filling with oil and water

2. General precautions when carrying out installation or removal (disassembly or assembly) of units are given together as PRECAUTIONS WHEN CARRYING OUT OPERATION, so be sure to follow these precautions when carrying out the operation.


3. Listing of special tools

- ① For details of the description, part number, and quantity of any tools (A1, etc.) that appear in the operation procedure, see the SPECIAL TOOLS LIST given in this manual.

DISASSEMBLY AND ASSEMBLY**METHOD OF USING MANUAL****4. General tightening torque table (when using torque wrench)**

- ★ In the case of metric nuts and bolts for which there is no special instruction, tighten to the torque given in the table below.

Thread diameter	Width across flats		
		SAD00481	SAD00482
mm	mm	kgm	Nm
6	10	1.35 ± 0.15	13.2 ± 1.4
8	13	3.2 ± 0.3	31.4 ± 2.9
10	17	6.7 ± 0.7	65.7 ± 6.8
12	19	11.5 ± 1.0	112 ± 9.8
14	22	18.0 ± 2.0	177 ± 19
16	24	28.5 ± 3	279 ± 29
18	27	39 ± 4	383 ± 39
20	30	56 ± 6	549 ± 58
22	32	76 ± 8	745 ± 78
24	36	94.5 ± 10	927 ± 98
27	41	135 ± 15	1320 ± 140
30	46	175 ± 20	1720 ± 190
33	50	225 ± 25	2210 ± 240
36	55	280 ± 30	2750 ± 290
39	60	335 ± 35	3280 ± 340



SAD00483

020706

5. Table of tightening torques for flared nuts

- ★ In the case of flared nuts for which there is no special instruction, tighten to the torque given in the table below.

Thread diameter	Width across flats	Tightening torque	
		kgm	Nm
14	19	2.5 ± 0.5	24.5 ± 4.9
18	24	5 ± 2	49 ± 19.6
22	27	8 ± 2	78.5 ± 19.6
24	32	14 ± 3	137.3 ± 29.4
30	36	18 ± 3	176.5 ± 29.4
33	41	20 ± 5	196.1 ± 49
36	46	25 ± 5	245.2 ± 49
42	55	30 ± 5	294.2 ± 49

6. Table of tightening torques for split flange bolts

- ★ In the case of split flange bolts for which there is no special instruction, tighten to the torque given in the table below.

Thread diameter	Width across flats	Tightening torque	
		kgm	Nm
10	14	6.7 ± 0.7	65.7 ± 6.8
12	17	11.5 ± 1	112 ± 9.8
16	22	28.5 ± 3	279 ± 29

PRECAUTIONS WHEN CARRYING OUT OPERATION

[When carrying out removal or installation (disassembly or assembly) of units, be sure to follow the general precautions given below when carrying out the operation.]

1. Precautions when carrying out removal work

- If the coolant contains antifreeze, dispose of it correctly.
- After disconnecting hoses or tubes, cover them or fit blind plugs to prevent dirt or dust from entering.
- When draining oil, prepare a container of adequate size to catch the oil.
- Confirm the match marks showing the installation position, and make match marks in the necessary places before removal to prevent any mistake when assembling.
- To prevent any excessive force from being applied to the wiring, always hold the connectors when disconnecting the connectors. Do not pull the wires.
- Fit wires and hoses with tags to show their installation position to prevent any mistake when installing.
- Check the number and thickness of the shims, and keep in a safe place.
- When raising components, be sure to use lifting equipment of ample strength.
- When using forcing screws to remove any components, tighten the forcing screws uniformly in turn.
- Before removing any unit, clean the surrounding area and fit a cover to prevent any dust or dirt from entering after removal.

★ Precautions when handling piping during disassembly

Fit the following blind plugs into the piping after disconnecting it during disassembly operations.

1) Hoses and tubes using sleeve nuts


Nominal number	Plug (nut end)	Sleeve nut (elbow end) Use the two items below as a set
02	07376-50210	07221-20210 (Nut), 07222-00210 (Plug)
03	07376-50315	07221-20315 (Nut), 07222-00312 (Plug)
04	07376-50422	07221-20422 (Nut), 07222-00414 (Plug)
05	07376-50522	07221-20522 (Nut), 07222-00515 (Plug)
06	07376-50628	07221-20628 (Nut), 07222-00616 (Plug)
10	07376-51034	07221-21034 (Nut), 07222-01018 (Plug)
12	07376-51234	07221-21234 (Nut), 07222-01219 (Plug)

2) Split flange type hoses and tubes

Nominal number	Flange (hose end)	Sleeve head (tube end)	Split flange
04	07379-00400	07378-10400	07371-30400
05	07379-00500	07378-10500	07371-30500

3) If the part is not under hydraulic pressure, the following corks can be used.

Nominal number	Part Number	Dimensions		
		D	d	L
06	07049-00608	6	5	8
08	07049-00811	8	6.5	11
10	07049-01012	10	8.5	12
12	07049-01215	12	10	15
14	07049-01418	14	11.5	18
16	07049-01620	16	13.5	20
18	07049-01822	18	15	22
20	07049-02025	20	17	25
22	07049-02228	22	18.5	28
24	07049-02430	24	20	30
27	07049-02734	27	22.5	34



DEW00401

2. Precautions when carrying out installation work

- Tighten all bolts and nuts (sleeve nuts) to the specified (KES) torque.
 - Install the hoses without twisting or interference.
 - Replace all gaskets, O-rings, cotter pins, and lock plates with new parts.
 - Bend the cotter pins and lock plates securely.
 - When coating with adhesive, clean the part and remove all oil and grease, then coat the threaded portion with 2 – 3 drops of adhesive.
 - When coating with gasket sealant, clean the surface and remove all oil and grease, check that there is no dirt or damage, then coat uniformly with gasket sealant.
 - Clean all parts, and correct any damage, dents, burrs, or rust.
 - Coat rotating parts and sliding parts with engine oil.
 - When press fitting parts, coat the surface with anti-friction compound (LM-P).
 - After fitting snap rings, check that the snap ring is fitted securely in the ring groove.
 - When connecting wiring connectors, clean the connector to remove all oil, dirt, or water, then connect securely.
 - When using eyebolts, check that there is no deformation or deterioration, screw them in fully, and align the direction of the hook.
 - When tightening split flanges, tighten uniformly in turn to prevent excessive tightening on one side.
- ★ When operating the hydraulic cylinders for the first time after reassembling cylinders, pumps and other hydraulic equipment removed for repair, always bleed the air as follows:
1. Start the engine and run at low idling.
 2. Operate the work equipment control lever to operate the hydraulic cylinder 4 – 5 times, stopping the cylinder 100 mm from the end of its stroke.
 3. Next, operate the hydraulic cylinder 3 – 4 times to the end of its stroke.
 4. After doing this, run the engine at normal speed.
- ★ When using the machine for the first time after repair or long storage, follow the same procedure.
- 3. Precautions when completing the operation**
- If the coolant has been drained, tighten the drain valve, and add water to the specified level. Run the engine to circulate the water through the system. Then check the water level again.
 - If the hydraulic equipment has been removed and installed again, add engine oil to the specified level. Run the engine to circulate the oil through the system. Then check the oil level again.
 - If the piping or hydraulic equipment have been removed, always bleed the air from the system after reassembling the parts.
 - ★ For details, see TESTING AND ADJUSTING, Bleeding air.
 - Add the specified amount of grease (molybdenum disulphide grease) to the work equipment parts.

SPECIAL TOOL LIST

- ★ Tools with part number 79○T-○○○-○○○○ cannot be supplied (they are items to be locally manufactured).
- ★ New/remodel: N: Tools with new part numbers, newly developed for this model.
- ★ R: Tools with upgraded part numbers, remodeled from items already available for other models.
- ★ Blank: Tools already available for other models, used without any modification.
- ★ Tools marked ○ in the Sketch column are tools introduced in special sketches (See SKETCHES OF SPECIAL TOOLS).

Component	Symbol		Part No.	Part Name	Q'ty	New/ remodel	Sketch	Nature of work, remarks			
Engine assembly	A		790-331-1110	Wrench	1			Removal, installa- tion	Tightening of cylinder head bolt		
Swing machinery assembly	F		796T-626-1110	Push tool	1	N		Dis- assembly, assembly	Press fitting of bearing		
Final drive assembly	J	2	1	796-627-1210	Wrench	1	N		Dis- assembly, assembly	Removal, installa- tion of round nut	
			1	796T-627-1230	Push tool	1	N			Pushing of bearing inner race	
			2	790-101-2510	Block	1					
			3	792-104-3940	Bolt	2					
			4	01580-11613	Nut	2					
			5	790-101-2570	Washer	2					
			6	01643-31645	Washer	1					
			7	790-105-2100	Jack	1					
			8	790-101-1102	Pump	1					
		3	790-331-1110	Wrench	1			Tightening of cover bolt			
		4	791-580-1510	Installer	1			Installation of floating seal			
Idler assembly	L		1	796-570-1020	Installer	1		Dis- assembly, assembly	Installation of floating seal		
2			791-601-1000	Oil pump	1				Charging with oil		
Track roller assembly			3	796-670-1010	Installer	1			Dis- assembly, assembly	Installation of floating seal	
4			791-601-1000	Oil pump	1			Charging with oil			
Carrier roller assembly			5	790-302-1500	Wrench kit	1			Dis- assembly, assembly	Removal, installation of nut	
				• 09003-05560	• Wrench	1					
				6	796-670-1020	Installer	1				Installation of floating seal
				7	796T-630-1130	Push tool	1	N			Press fitting of ring
	8	791-601-1000	Oil pump	1				Charging with oil			
Recoil spring assembly	M	1	791-685-8005	Compressor B	1			Dis- assembly, assembly	Removal, installation of recoil spring		
			791-635-3160	Extension	1						
			790-101-1600	Cylinder (686kN(70t))	1						
			790-101-1102	Oil pump	1						

DISASSEMBLY AND ASSEMBLY**SPECIAL TOOL LIST**

Component		Symbol		Part No.	Part Name	Q'ty	New/ remodel	Sketch	Nature of work, remarks		
Recoil spring assembly	M	2		790-201-1500	Push tool kit	1			Dis-assembly, assembly	Installation of piston dust seal	
				• 790-201-1650	• Plate	1					
				• 790-101-5021	• Grip	1					
				• 01010-50816	• Bolt	1					
Track shoe assembly	R			791-646-3000	Remover, installer	1			Removal, installation	Removal, press fitting of master pin	
				790-101-1300	Cylinder	1					
				790-101-1102	Pump	1					
Main pump	Hydraulic pump assembly	S	1	796-660-1200	Oil stopper assembly	1	N		Removal, installation	Shutting off hydraulic oil	
					• 796-460-1210	• Oil stopper	1				
					• 796-660-1210	• Rod	1	N			
					• 20Y-60-21330	• Rod assembly	1				
			2	790-201-2700	Push tool kit	1				Press fitting of shaft oil seal	
					• 790-201-2740	• Spacer	1				
	Disassembly, assembly of pump	S	3	1	790-501-5000	Unit repair stand	1			For Japan	
					790-501-5200	Unit repair stand	1			For overseas	
				2	790-901-2110	Bracket	1				
				3	793-617-1110	Plate	1			For front	
				4	796-660-1430	Plate	1	N		For rear	
	Removal, installation of cylinder block spring	S	4	1	790-201-3610	Bolt	1				
				2	796-465-1110	Washer	1				
				3	01643-33080	Washer	1				
				4	01643-32060	Washer	2				
				5	01582-02016	Nut	1				
Removal, installation of cover	S	5	1	796-720-2250	Screwdriver	1					
				2	796-720-2220	Socket	1				
Removal, installation of servo piston rod	S	6	1	791-463-1100	Holder	1					
				2	• 791-463-1150	• Plate	1				
				3	• 791-463-1160	• Bolt	1				
Press fitting of bearing	S	7		790-201-2700	Push tool kit	1					
				• 790-201-2740	• Spacer	1					
Positioning of servo piston swash plate angle	S	8		796-660-1400	Gauge assembly	1	N				
				• 796-660-1440	• Plate	1	N				
				• 796-660-1450	• Plate	1	N				
				• 01010-51030	• Bolt	1	N				
				• 01010-51835	• Bolt	1	N				

020706

DISASSEMBLY AND ASSEMBLY

SPECIAL TOOL LIST

Component		Symbol		Part No.	Part Name	Q'ty	New/ remodel	Sketch	Nature of work, remarks
Main pump	Press fitting of needle bearing	S	9	791-101-5201	Push tool kit	1			
				• 790-101-5251	• Plate	1			
				• 790-101-5221	• Grip	1			
				• 01010-51225	• Bolt	1			
	Measuring drive shaft rotating torque	S	10	01435-01016	Bolt	1			
	Leak test of servo valve	S	11	799-301-1600	Oil leak tester	1			
	Press fitting of oil seal	S	12	790-201-2700	Push tool kit	1			
				• 790-201-2740	• Spacer	1			
Swing motor	Disassembly, assembly of motor	S	13	1	790-501-5000	Unit repair stand	1		For Japan
					790-501-5200	Unit repair stand	1		For Overseas
				2	790-901-2110	Bracket	1		
				3	790-401-1470	Plate	1		
	Removal, installation of retainer mounting screw	S	14	1	796-730-2120	Screwdriver	1		
				2	796-720-2220	Socket	1		
	Releasing brake	S	15	1	796T-660-1510	Pump adapter	1	N	
					• 790-101-1430	• Coupler assembly	1		
					• 796-660-1490	• Nipple	1	N	
					• 799-101-5130	• Gauge	1		
					• 799-101-5160	• Nipple	1		
					• 790-301-1190	• Nipple	1		
					• 790-301-1660	• Tee	1		
					• 205-70-51390	• Nipple	1		
					• 790-301-1210	• Joint	1		
					• 07002-01423	• O-ring	1		
				2	790-101-1102	Pump	1		
	Press fitting of main bearing inner race	S	16	790-201-2850	Spacer	1			
	Installation of sub bearing outer race	S	17	790-201-2860	Spacer	1			
	Press fitting of sub bearing inner race	S	18	790-201-2840	Spacer	1			
	Pushing out drive shaft	S	19	1	790-101-2510	Block	1		
				2	791-600-1120	Bolt	2		
				3	01643-31845	Washer	6		
				4	01580-11613	Nut	6		
				5	790-105-2100	Jack	1		
				6	790-101-1102	Pump	1		

020706

DISASSEMBLY AND ASSEMBLY

SPECIAL TOOL LIST

Component		Symbol		Part No.	Part Name	Q'ty	New/ remodel	Sketch	Nature of work, remarks	
Swing motor	Measuring drive shaft rotating torque	S	20	01435-01220	Bolt	1				
	Press fitting of oil seal	S	21	790-201-1500	Push tool kit	1				
				• 790-201-1590	• Plate	1				
				• 790-101-5021	• Grip	1				
				• 01010-50816	• Bolt	1				
	Securing housing	S	22	1 796T-660-1520	Plate	1	N	○		
				2 01010-51020	Bolt	2				
				3 01010-51835	Bolt	4				
				4 01580-11815	Nut	4				
	Press fitting of dowel pin	S	23	796T-660-1540	Push tool	1	N	○		
	Removal of brake piston	S	24	799-301-1600	Oil leak tester	1				
Travel motor	Disassembly, assembly of motor	S	25	1 790-501-5000	Unit repair stand	1			For Japan	
				790-501-5200	Unit repair stand	1			For Overseas	
				2 790-901-2110	Bracket	1				
				3 790-901-1361	Plate	1				
	Pulling out piston	S	26	799-301-1600	Oil leak tester	1			✓	
	Disassembly, assembly of cylinder block	S	27	1 796-465-1110	Washer	1				
				2 790-201-3610	Bolt	1				
				3 01582-02016	Nut	1				
				4 01643-32460	Washer	1				
				5 01643-32060	Washer	1				
	Press fitting of main bearing	S	28	796-465-1120	Push tool	1				
	Installation of cylinder block, piston assembly	S	29	1 796-465-1131	Push tool	1				
				2 01010-51070	Bolt	1				
	Press fitting of sub bearing	S	30	796-460-1120	Push tool	1				
	Press fitting of oil seal	S	31	1 796-465-1131	Push tool	1				
				2 790-101-5221	Grip	1				
				3 01010-51225	Bolt	1				
Center swivel joint assembly	T		790-101-2501	Push tool kit	1			Dis-assembly, assembly	Disconnection of shaft and rotor	
			• 790-101-2510	• Block	1					
			• 790-101-2520	• Screw	1					
			• 791-112-1180	• Nut	1					
			• 790-101-2540	• Washer	1					
			• 790-101-2630	• Leg	2					

020706

DISASSEMBLY AND ASSEMBLY


SPECIAL TOOL LIST

Component	Symbol	Part No.	Part Name	Q'ty	New/ remodel	Sketch	Nature of work, remarks	
Center swivel joint assembly	T	• 790-101-2570	• Plate	4			Dis-assembly, assembly	Disconnection of shaft and rotor
		• 790-101-2560	• Nut	2				
		• 790-101-2650	• Adapter	2				
Hydraulic cylinder assembly	U	1	790-502-1003	Cylinder repair stand	1		Dis-assembly, assembly	Securing of cylinder
		2	790-720-1000	Expander	1			Installation of piston ring
		3	790-720-1680	Ring	1			
			07281-01589	Clamp	1			Press fitting of coil bushing Boom, bucket Arm
			790-201-1702	Push tool kit	1			
			• 790-201-1851	• Push tool	1			
		4	• 790-201-1861	• Push tool	1			
			• 790-101-5021	• Grip	1			
			• 01010-50816	• Bolt	1			
Hydraulic cylinder assembly	U		790-201-1500	Push tool kit	1		Dis-assembly, assembly	Installation of dust seal
			• 790-201-1660	• Plate	1			Boom, bucket
			• 790-201-1670	• Plate	1			Arm
			• 790-101-5021	• Grip	1			
			• 01010-50816	• Bolt	1			
Work equipment assembly, boom assembly	V		796-670-1100	Remover assembly	1	N	Removal, installation	Removal of boom foot pin
			• 796-670-1110	• Sleeve	1	N		
			• 796-670-1120	• Plate	1	N		
			• 796-670-1130	• Screw	1	N		
			• 791-775-1150	• Adapter	1			
			• 01643-33080	• Washer	1			
			• 01803-13034	• Nut	1			
			790-101-4000	Puller	1			
			790-101-1102	Pump	1			
Components related to air conditioner	X		799-703-1200	Service tool kit	1		Removal, installation	Charging with freon gas (R134a)
			799-703-1100	Vacuum pump (100V)	1			
			799-703-1110	Vacuum pump (220V)	1			
			799-703-1120	Vacuum pump (240V)	1			
			799-703-1400	Gas leak detector	1			

SKETCHES OF SPECIAL TOOLS


Note: Komatsu cannot accept any responsibility for special tools manufactured according to these sketches.

F Push tool




020706

J2-1 Push tool




L7 Push tool



020706


S15-1
Pump adapter




020706

S22-1
Plate

020706



S23
Push tool





020706

REMOVAL OF STARTING MOTOR ASSEMBLY

⚠ Disconnect the cable from the negative (-) terminal of the battery.

1. Open engine hood.
2. Remove engine undercover.
3. Remove starting motor wiring harness cover.
4. Disconnect starting motor harnesses (1) and (2), and connector (3) (CN-M2).
5. Remove 3 mounting bolts, then remove starting motor assembly (4).
 - ★ The two mounting bolts at the top are also used for tightening the cover mounting bracket in Step 3.





INSTALLATION OF STARTING MOTOR ASSEMBLY

- Carry out installation in the reverse order to removal.

REMOVAL OF ALTERNATOR ASSEMBLY

⚠ Disconnect the cable from the negative (-) terminal of the battery.

1. Open engine hood.
2. Disconnect alternator wiring (1), (2), and (3).
3. Loosen tension lock bolt (4) and mount bolt (5).
4. Loosen tension adjustment bolt (6), and remove belt (7) from alternator pulley.
5. Remove tension lock bolt (4) and mount bolt (5), then remove alternator assembly (8). ※ 1



INSTALLATION OF ALTERNATOR ASSEMBLY



- Carry out installation in the reverse order to removal.

※ 1

- ★ Adjust the belt tension
For details, see TESTING AND ADJUSTING,
Testing and adjusting of alternator belt tension.

REMOVAL OF ENGINE OIL COOLER ASSEMBLY

1. Drain coolant.
2. Remove fuel injection pump assembly.
For details, see REMOVAL OF FUEL INJECTION PUMP ASSEMBLY.
3. Disconnect engine oil pressure sensor wiring harnesses (1) and (2) from sensor.
4. Remove oil filter (3) together with bracket. ※ I
5. Disconnect bottom part of tube (4).
6. Remove oil cooler assembly (5).
7. Remove oil cooler core (7) from cover (6).





INSTALLATION OF ENGINE OIL COOLER ASSEMBLY

- Carry out installation in the reverse order to removal.

※ I



Mounting bolt of oil filter marked with
※: $18.6 \pm 4.9 \text{ Nm}$ ($1.9 \pm 0.5 \text{ kgm}$)







020706

REMOVAL OF FUEL INJECTION PUMP ASSEMBLY

⚠ Disconnect the cable from the negative (–) terminal of the battery.

1. Open engine hood.
2. Disconnect governor motor wiring connector (1) (CN-E05).
3. Disconnect governor motor spring rod (2). ※ 1
 - ★ Do not rotate the shaft of the governor motor suddenly.
 - ★ Always disconnect governor motor connector CN-E05 before disconnecting the rod.
 - ★ Check the position of the lever hole.
4. Remove fuel filter (3) together with bracket and hose.
 - ★ Disconnect the hose at the injection pump end. ※ 2
5. Disconnect fuel supply hose (4) and return hose (5). ※ 3
 - ★ There is no stop valve installed to the supply hose, so stop the fuel.
6. Remove boost compensation tube (6) and injection pump lubrication tube (7). ※ 4
7. Disconnect 6 delivery tubes (8). ※ 5
8. Remove bracket (9).
9. Remove mounting bolts, then remove fuel injection pump assembly (10). ※ 6



INSTALLATION OF FUEL INJECTION PUMP ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1

- ★ Adjust the spring rod.
For details, see TESTING AND ADJUSTING, Adjusting governor motor lever stroke.
- ★ Connect the spring rod before connecting the connector (CN-E05).

※ 2

- kgm Joint bolt (width across flats: 22 mm):
 $17.16 \pm 2.45 \text{ Nm}$ ($1.75 \pm 0.25 \text{ kgm}$)

※ 3

- kgm Joint bolt (width across flats: 22 mm):
 $17.16 \pm 2.45 \text{ Nm}$ ($1.75 \pm 0.25 \text{ kgm}$)

※ 4


- kgm Boost compensation tube nut
 - Intake manifold end: **$24.5 \pm 9.8 \text{ Nm}$ ($2.5 \pm 1.0 \text{ kgm}$)**
 - Injection pump end: **$10.30 \pm 2.45 \text{ Nm}$ ($1.05 \pm 0.25 \text{ kgm}$)**
- kgm Lubrication tube joint bolt:
 $12.26 \pm 1.47 \text{ Nm}$ ($1.15 \pm 0.15 \text{ kgm}$)

※ 5

- kgm Delivery tube sleeve nut:
 $22.06 \pm 2.45 \text{ Nm}$ ($2.25 \pm 0.25 \text{ kgm}$)

※ 6





- ★ Align the spline notch, then align the line on the fuel injection pump with the line on the gear case, and install the coupling.
- ★ Adjust the injection timing.
For details, see TESTING AND ADJUSTING, Adjusting fuel injection timing.
- ★ Bleed the air from the fuel circuit.



020706

REMOVAL OF WATER PUMP ASSEMBLY

1. Drain coolant.
2. Open engine hood.
3. Loosen adjustment bolt (2) and mount bolts (3) of tension pulley (1), and remove belt (4) from water pump pulley. ※ 1
4. Disconnect bypass hose (5), aeration tube (6), heater hose (7), and clamps (8) and (9).
★ Check the angle of the clamps.
5. Disconnect water pump inlet hose (10).
6. Remove mounting bolts, then remove water pump assembly (11). ※ 2
★ There is one mounting bolt at the cylinder block end.



INSTALLATION OF WATER PUMP ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1

- ★ Adjust the belt tension.
For details, see TESTING AND ADJUSTING, Testing and adjusting of water pump belt tension.

※ 2


- ★ Set one mounting bolt at the fan pulley end installed to the water pump (it will not go in later).
- **Refilling with water**
 - ★ Add water through the water filler to the specified level.
Run the engine to circulate the water through the system. Then check the water level again.

REMOVAL OF NOZZLE HOLDER ASSEMBLY

1. Open engine hood.
2. Disconnect delivery tube (1).
3. Disconnect spill hose (2).
4. Remove holder (3).
5. Remove nozzle assembly (4).

※ 1

※ 2



INSTALLATION OF NOZZLE HOLDER ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1

kgm

Delivery tube sleeve nut:


$22.06 \pm 2.45 \text{ Nm}$ ($2.25 \pm 0.25 \text{ kgm}$)

※ 2

kgm

Nozzle holder mounting bolt :



$44.1 \pm 4.9 \text{ Nm}$ ($4.5 \pm 0.5 \text{ kgm}$)



020706

REMOVAL OF TURBOCHARGER ASSEMBLY

1. Open engine hood.
2. Remove top adiabatic cover (1) together with stay.
3. Remove intake hose (2).
4. Remove turbocharger outlet hose (3).
5. Remove bottom adiabatic cover (4).
6. Remove clamp (7) and bolts and nuts of connecting clamp (6) of exhaust pipe (5). ※ 1
7. Remove turbocharger lubrication inlet tube (8).
8. Disconnect turbocharger lubrication return hose (9).
9. Remove turbocharger assembly (10) while pulling out exhaust pipe (5). ※ 2



INSTALLATION OF TURBOCHARGER ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1

- ★ Do not use the connection clamp again. Replace it with a new part.



Exhaust pipe connection:

Coat with thermosetting agent (Nihon Holt Fire Gum or equivalent)




Tightening nut of connecting clamp (6):

 $83.4 \pm 14.7 \text{ Nm}$ ($8.5 \pm 1.5 \text{ kgm}$)



※ 2

- ⌘ Turbocharger mounting nut:

 $36.77 \pm 7.35 \text{ Nm}$ ($3.75 \pm 0.75 \text{ kgm}$)

REMOVAL OF THERMOSTAT ASSEMBLY

1. Drain engine coolant.
2. Open engine hood.
3. Disconnect aeration tube (1).
4. Disconnect water pump inlet hose (2).
 - ★ The mounting bolts (inside bottom bolts) of the thermostat cover cannot be removed, so disconnect the hose.
5. Remove thermostat cover (3).
 - ★ There are two clamps, so check the mounting angle.
6. Remove thermostat (4).



INSTALLATION OF THERMOSTAT ASSEMBLY

- Carry out installation in the reverse order to removal.
- **Refilling with water**
 - ★ Add water through the water filler to the specified level.
 - Run the engine to circulate the water through the system. Then check the water level again.


REMOVAL OF ENGINE FRONT SEAL

1. Remove radiator and hydraulic cooler assembly.
For details, see REMOVAL OF RADIATOR, HYDRAULIC COOLER ASSEMBLY.

2. Remove fan (1).

※ 1


3. Remove fan guard (2).



4. Loosen tension of alternator (3), tension pulley (4), and air conditioner compressor (5), and remove belts (6), (7), and (8).

※ 2

★ For details, see REMOVAL OF ALTERNATOR, WATER PUMP, AIR CONDITIONER COMPRESSOR.




5. Remove damper (9).

※ 3

★ The compressor drive pulley will also come off at the same time.


6. Remove front pulley mounting bolt (10) and washer (11).

※ 4



7. Using puller ①, remove front pulley (12).


★ The collar will also come off at the same time.



020706

8. Remove front oil seal (12).

※ 5



INSTALLATION OF ENGINE FRONT SEAL

- Carry out installation in the reverse order to removal.

※ 1

 Fan mounting bolt: **66.19 ± 2.45 Nm**
(6.75 ± 0.25 kgm)

※ 2

- ★ Adjust the belt tension.
For details, see TESTING AND ADJUSTING, Testing and adjusting alternator belt, water pump belt, and air conditioner compressor belt tension.

※ 3

 Damper mounting bolt:
66.19 ± 2.45 Nm (6.75 ± 0.25 kgm)

※ 4

 Front pulley mounting bolt:
451 ± 29 Nm (46 ± 3 kgm)

※ 5


- ★ Press fit the front seal until it is level with the surface of the front cover.

 Lip of oil seal: **Grease (G2-LI)**
(approx. 2 cc.)

REMOVAL OF GOVERNOR MOTOR ASSEMBLY

⚠ Disconnect the cable from the negative (-) terminal of the battery.

1. Open engine hood.
2. Disconnect wiring connectors (1) (CN-E04) and (2) (CN-E05).
3. Remove cover (3).
4. Disconnect spring rod (4).
5. Remove governor motor assembly (5). ※ I




INSTALLATION OF GOVERNOR MOTOR ASSEMBLY

- Carry out installation in the reverse order to removal.

※ I



- ★ Adjust the spring rod.
- For details, see TESTING AND ADJUSTING, Testing and adjusting of governor motor lever stroke.




REMOVAL OF CYLINDER HEAD ASSEMBLY

⚠ Disconnect the cable from the negative (–) terminal of the battery.


1. Open engine hood.
2. Drain coolant.
3. Remove intake connector (2).
4. Remove clamp (3), and disconnect spill hose (4).
5. Disconnect fuel filter (5) at bracket end, then move it towards counterweight.
6. Disconnect heater relay (6) at bracket end.
★ One connector clamp and one wiring harness clamp are tightened together.
7. Disconnect wiring harness clamp (7), then return bolt to its original position.
8. Disconnect bypass hose (8) and aeration tube (9).
9. Disconnect block (10) from cylinder head.



10. Disconnect oil filter bracket (11) from intake manifold.
11. Remove boost compensation tube (12). ※ 1
12. Disconnect both ends of delivery tube (13). ※ 2
13. Remove intake manifold (14). ※ 3
★ There is a wiring clamp at the bolt at the bottom of the No. 6 cylinder.



14. Loosen tension of alternator belt, then remove plate mounting bolt (15). ※ 4
15. Disconnect turbocharger outlet hose (16) and remove inlet hose (17).
16. Remove top adiabatic cover (18) and bottom adiabatic cover (19).
★ Remove the top adiabatic cover together with the stay.



DISASSEMBLY AND ASSEMBLY**CYLINDER HEAD**


17. Disconnect turbocharger lubrication inlet tube (21) and outlet tube (22).

★ Loosen the nut at the bottom, then move the inlet tube towards the control valve.

18. Remove mounting bolts and nuts of connecting clamp (23) of exhaust pipe (20), then remove clamp (24).

※ 5

19. Disconnect level gauge clamp (25).




20. Lift off turbocharger and exhaust manifold assembly (26).

※ 6

21. Remove exhaust pipe (20).

※ 7



22. Remove wiring harness (28) and lead (29).

※ 8

23. Remove 6 glow plugs (30).


※ 9

24. Disconnect spill hose (31), remove holder (32), then remove 6 nozzle holders (33).

※ 10

25. Disconnect blow-by hose (34), and remove head cover (35).


※ 11



26. Remove rocker arm assembly (36).

※ 12

★ Loosen the locknut, then loosen the adjustment screw 2 – 3 turns.




020706

27. Remove push rods (37).

28. Remove cylinder head bolts (38).

※ 13




29. Lift off cylinder head assembly (39).

※ 13



Cylinder head assembly: 65 kg



020706

INSTALLATION OF CYLINDER HEAD ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1



Boost compensation tube nut.

- Intake manifold end: $24.5 \pm 9.8 \text{ Nm}$
($2.5 \pm 1.0 \text{ kgm}$)
- Injection pump end: $10.30 \pm 2.45 \text{ Nm}$
($1.05 \pm 0.25 \text{ kgm}$)

※ 2



Delivery tube sleeve nut:

$22.06 \pm 2.45 \text{ Nm}$ ($2.25 \pm 0.25 \text{ kgm}$)

※ 3



Intake manifold mounting bolt:

$24.5 \pm 9.8 \text{ Nm}$ ($2.5 \pm 1 \text{ kgm}$)

※ 4



Adjust the belt tension.

For details, see TESTING AND ADJUSTING,
Testing and adjusting alternator belt tension.

※ 5

- ★ Do not use the connection clamp again. Replace it with a new part.

 Connecting clamp (23) tightening nut:
 $83.4 \pm 14.7 \text{ Nm}$ ($8.5 \pm 1.5 \text{ kgm}$)

※ 6

 Exhaust manifold mounting bolt:
 $44.1 \pm 9.8 \text{ Nm}$ ($4.5 \pm 1.0 \text{ kgm}$)

※ 7

 Exhaust pipe connection:
 Coat with thermosetting agent

※ 8

 Wiring harness and lead mounting nut:
 $1.47 \pm 0.49 \text{ Nm}$ ($0.15 \pm 0.05 \text{ kgm}$)

※ 9

 Glow plug:
 $17.16 \pm 2.45 \text{ Nm}$ ($1.75 \pm 0.25 \text{ kgm}$)

※ 10

★ Clean the mounting portion.
 Nozzle holder mounting bolt:
 $44.1 \pm 4.9 \text{ Nm}$ ($4.5 \pm 0.5 \text{ kgm}$)

※ 11

 Head cover mounting nut:
 $8.8 \pm 1.0 \text{ Nm}$ ($0.9 \pm 0.1 \text{ kgm}$)

※ 12

- ★ When tightening the nuts and bolts, start from the center and work towards the outside.
 - ★ Check that the ball of the adjustment screw is fitted properly into the socket of the push rod.
 - Adjust the valve clearance.
 For details, see TESTING AND ADJUSTING, Adjusting valve clearance.
-  Mounting bolt, nut:
 $24.5 \pm 4.9 \text{ Nm}$ ($2.5 \pm 0.5 \text{ kgm}$)

DISASSEMBLY AND ASSEMBLY

CYLINDER HEAD

※ 13




- ★ If any rust of more than 5 mm square is found on the shaft or the thread of the bolt, replace the head bolt with a new bolt.
- ★ Be careful to check that there is no dirt or dust on the mounting surface of the cylinder head or inside the cylinder.
- ★ When installing the gasket, check that the grommets have not come out.
- ★ Coat the thread and seat of the bolt, and the seat of the cylinder head holes completely with molybdenum disulphide (LM-P).

 Mounting bolt: **Anti-friction compound (LM-P).**


- ★ Tighten the cylinder head mounting bolts 2 – 3 turns by hand, then tighten in the order given in the diagram.

 **kgm** Cylinder head mounting bolt:

- 1st pass: Tighten to 98.1 ± 9.8 Nm (10 ± 1 kgm)
- 2nd pass: Tighten to 147.1 ± 4.9 Nm (15 ± 0.5 kgm)
- 3rd pass: 1. When using tool A.
- Using an angle tightening wrench, tighten bolt $90^{\circ +30^{\circ}}_{-0^{\circ}}$.
2. When not using tool A.
- 1) Using the angle of the bolt head as the base, make start marks on the cylinder head and socket.
 - 2) Make an end mark at a point $90^{\circ +30^{\circ}}_{-0^{\circ}}$ from the start mark.
 - 3) Tighten so that the start mark on the socket is aligned with the end mark on the cylinder head at the $90^{\circ +30^{\circ}}_{-0^{\circ}}$ position.




- ★ After tightening, make one punch mark on the bolt head to indicate the number of times it has been tightened.
 - If any bolt already has five punch marks, do not reuse it. Replace it with a new bolt.
- **Refilling with water.**
 - ★ Refill to the specified level, and run the engine to circulate the water through the system. Then check the water level again.



020706


REMOVAL OF AFTERCOOLER ASSEMBLY

1. Open aftercooler front cover.
2. Loosen clamps of aftercooler inlet hose (1) and outlet hose (2).
3. Remove mounting bolts, pull out from hose, and remove aftercooler assembly (3).



INSTALLATION OF AFTERCOOLER ASSEMBLY

- Carry out installation in the reverse order to removal.



REMOVAL OF HYDRAULIC COOLER ASSEMBLY

! Loosen the oil filler cap slowly to release the pressure inside the hydraulic tank.

1. Drain oil from hydraulic tank.



Hydraulic tank: Approx. **200 ℓ**

2. Lift off engine hood (1).
 - ★ Loosen the hinge mounting bolts before lifting.






Engine hood assembly: **85 kg**

3. Remove aftercooler top cover, and open front cover.
4. Remove aftercooler assembly.
For details, see REMOVAL OF AFTERCOOLER ASSEMBLY.
5. Disconnect hose (2) and tube (3).
 - ★ Set a container under the cooler assembly to catch the oil.
6. Sling hydraulic cooler assembly (4), remove mounting bolts, then lift off hydraulic cooler assembly.



Hydraulic cooler assembly: **90 kg**



INSTALLATION OF HYDRAULIC COOLER ASSEMBLY

- Carry out installation in the reverse order to removal.
- **Refilling with oil (hydraulic tank).**
 - ★ Add oil through the oil filler to the specified level.
Run the engine to circulate the oil through the system. Then check the oil level again.

REMOVAL OF RADIATOR, HYDRAULIC COOLER ASSEMBLY

- ⚠** Loosen the oil filler cap slowly to release the pressure inside the hydraulic tank.

1. Drain oil from hydraulic tank.



Hydraulic tank: Approx. **200 ℓ**

2. Drain coolant

3. Lift off engine hood (1).

- ★ Loosen the hinge mounting bolts before lifting.



Engine hood assembly: **85 kg**

4. Remove aftercooler top cover, and open front cover.

5. Remove radiator undercover.

6. Remove aftercooler assembly.

For details, see REMOVAL OF AFTERCOOLER ASSEMBLY.

7. Disconnect hydraulic cooler hose (2) and tube (3).

- ★ Set a container under the cooler assembly to catch the oil.

8. Remove shroud left cover (4).





- ★ The shroud mounting bolts cannot be removed, so remove the cover.

9. Disconnect radiator outlet hose (5).


- ★ Disconnect the clamps at two places at the same time.

10. Disconnect sub-tank hose (6).

11. Remove 2 mounting bolts of shroud (7) from below.




12. Disconnect radiator inlet hose (8).
13. Remove top 2 mounting bolts of shroud (7), and move it towards engine.



14. Sling radiator and hydraulic cooler assembly (9), remove top and bottom mount bolts, then lift off radiator and hydraulic cooler assembly. ※ 1
- ★ Check the direction of the holder plate at the bottom of the top mount.



Radiator, hydraulic cooler assembly:
160 kg



INSTALLATION OF RADIATOR, HYDRAULIC COOLER ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1



Mount bolt: 110.32 ± 12.26 Nm
(11.25 ± 1.25 kgm)

- **Refilling with water**
 - ★ Add water through the water filler to the specified level.
 - Run the engine to circulate the water through the system. Then check the water level again.
- **Refilling with oil (hydraulic tank)**
 - ★ Add oil through the oil filler to the specified level.
 - Run the engine to circulate the oil through the system. Then check the oil level again.

REMOVAL OF ENGINE, MAIN PUMP ASSEMBLY

⚠ Disconnect the cable from the negative (–) terminal of the battery.

⚠ Lower the work equipment completely to the ground and stop the engine. Then loosen the oil filler cap slowly to release the pressure inside the hydraulic tank.




1. Remove hydraulic tank strainer, and using tool **S1**, stop oil.
 - When not using tool **S1**, remove the drain plug, and drain the oil from the hydraulic tank and inside the system.



Hydraulic tank: Approx. **200 ℓ**

★ Mark all the piping with tags to prevent mistakes in the mounting position when installing.


2. Drain coolant.
3. Remove main pump side cover, undercover, and engine undercover.
4. Open engine hood.
5. Remove main pump top cover (1), and partitions (2) and (3).
6. Disconnect control pump outlet hoses (4) and (5).
7. Disconnect chassis ground (6).
8. Disconnect main pump inlet tube (7) and control pump inlet tube (8).



9. Disconnect TVC solenoid connectors (9) and (10) (CN-C04 and CN-C13).

★ Disconnect clamps at two places (pump and frame).


10. Disconnect main pump outlet hoses (11) and (12).
11. Disconnect pump case drain hose (13).
12. Disconnect front pump servo valve hose (14).
13. Disconnect rear pump servo valve hose (15).




DISASSEMBLY AND ASSEMBLY

ENGINE, MAIN PUMP

14. Remove aftercooler return tube (16) together with bracket.
15. Disconnect governor motor connectors (17) and (18) (CN-E04 and CN-E05).




16. Disconnect fuel return hose (19) and supply hose (20). ※ 1
- ★ There is no stop valve installed to the supply hose, so stop the fuel.
17. Disconnect car heater hose (21).
18. Disconnect clamp (22) of spill hose.
19. Disconnect water pump inlet hose (23).




20. Remove clamps (24) (2 places), and disconnect spill hose (25).
21. Remove engine outlet hose (26).
22. Remove fan guard (27), then remove fan (28).

※ 2



23. Disconnect turbocharger outlet hose (29), and remove inlet hose (30).
24. Disconnect dust indicator hose (31).
25. Remove air cleaner assembly (32) together with bracket.





020706

- ⚠ Push the valve of the air conditioner compressor slowly and release the refrigerant (R134a) gradually.
26. Disconnect air conditioner compressor hose (33). ※ 3
27. Disconnect wiring harness (34) from starting motor.
28. Disconnect wiring connector (35) (CN-E08) and clamp (36).
29. Remove engine mount bolts at front (37) and rear (38). ※ 4
30. Lift off engine and main pump assembly (39).



Engine, main pump assembly: **1100 kg**



INSTALLATION OF ENGINE, MAIN PUMP ASSEMBLY

- ⚠ Carry out installation in the reverse order to removal.

※ 1

kgm Joint bolt: **17.16 ± 2.45 Nm**
(1.75 ± 0.25 kgm)

※ 2



kgm Fan mounting bolt: **66.19 ± 7.35 Nm**
(6.75 ± 0.75 kgm)

※ 3

- ★ Check that there is no damage or deterioration of the O-ring, then connect the hose.

※ 4

kgm Engine mount bolt
(front): **384.91 ± 41.68 Nm** (39.25 ± 4.25 kgm)
(rear): **926.7 ± 103.0 Nm** (94.5 ± 10.5 kgm)



• Refilling with water

- ★ Add water through the water filler to the specified level.
Run the engine to circulate the water through the system. Then check the water level again.

• Charging air conditioner with gas

- ★ Using tool X, charge the air conditioner circuit with refrigerant (R134a).

• Refilling with oil (hydraulic tank)

- ★ Add oil through the oil filler to the specified level.
Run the engine to circulate the oil through the system. Then check the oil level again.


• Bleeding air

- ★ Bleed the air from the main pump.
For details, see TESTING AND ADJUSTING

REMOVAL OF DAMPER ASSEMBLY

1. Remove main pump assembly.
For details, see REMOVAL OF MAIN PUMP ASSEMBLY.
2. Remove damper assembly (1).

※ 1



INSTALLATION OF DAMPER ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1



Damper mounting bolt:
 $110.32 \pm 12.26 \text{ Nm}$ ($11.25 \pm 1.25 \text{ kgm}$)

REMOVAL OF FUEL TANK ASSEMBLY

- ⚠** Disconnect the cable from the negative (-) terminal of the battery.

1. Open drain valve of fuel tank and drain fuel.





Fuel tank: Approx. **470 ℓ**
(when tank is full)

2. Remove air conditioner condenser top cover.
3. Remove handrail (1), front cover (2), and battery case cover (3).
4. Disconnect fuel level sensor connector (4) (CN-P06).
5. Disconnect fuel supply hose (5), return hose (6), spill hose (7), and clamp (8).
6. Remove mounting bolts, and lift off fuel tank assembly (9).



Fuel tank assembly: **210 kg**






INSTALLATION OF FUEL TANK ASSEMBLY

- Carry out installation in the reverse order to removal.



Fuel tank mounting bolt:
277.04 ± 31.87 Nm (28.25 ± 3.25 kgm)






REMOVAL OF CENTER SWIVEL JOINT ASSEMBLY

- ⚠ Release the remaining pressure in the hydraulic circuit.
For details, see TESTING AND ADJUSTING, Releasing remaining pressure from hydraulic circuit.
- ⚠ Loosen the hydraulic tank oil filler cap slowly to release the pressure inside the hydraulic tank.
- ★ Mark all the piping with tags to prevent mistakes in the mounting position when installing.
- 1. Disconnect travel motor hoses (1) and (2).
- 2. Disconnect speed selector hose (3).
- 3. Disconnect drain hose (4), and remove elbow (5).
★ Install a blind plug in the drain hose.
- 4. Disconnect drain hoses (7) and (8).
★ Install a blind plug in the drain hose.
- 5. Disconnect travel hoses (9) and (10), and speed selector hose (11).
- 6. Pull out pin (12), and disconnect plate (13).
- 7. Sling center swivel joint assembly (14), remove mounting bolts from below, then lift off.



Center swivel joint assembly: **40 kg**




INSTALLATION OF CENTER SWIVEL JOINT ASSEMBLY

- Carry out installation in the reverse order to removal.




- ★ Assemble the center swivel as shown in the diagram below.
- **Refilling with oil (hydraulic tank)**
★ Add oil through the oil filler to the specified level.
Run the engine to circulate the oil through the system. Then check the oil level again.
- **Bleeding air**
★ Bleed the air from the travel motor.
For details, see TESTING AND ADJUSTING, Bleeding air.



DISASSEMBLY OF CENTER SWIVEL JOINT ASSEMBLY

1. Remove cover (1).
2. Remove snap ring (2).
3. Using puller ①, pull out swivel rotor (4) and ring (3) from swivel shaft (5).
4. Remove O-ring (6) and slipper seal (7) from swivel rotor.



ASSEMBLY OF CENTER SWIVEL JOINT ASSEMBLY

1. Assemble slipper seal (7) and O-ring (6) to swivel rotor.
2. Set swivel shaft (5) to block, then using push tool, tap swivel rotor (4) with a plastic hammer to install.


 Contact surface of rotor, shaft:

Grease (G2-LI)

- ★ When installing the rotor, be extremely careful not to damage the slipper seal and the O-ring.

3. Install ring (3) and secure with snap ring (2).
4. Fit O-ring and install cover (1).

 **kgm** Mounting bolt: **31.4 ± 2.9 Nm**
(3.2 ± 0.3 kgm)





REMOVAL OF FINAL DRIVE ASSEMBLY

1. Remove the track shoe assembly.
For details, see REMOVAL OF TRACK SHOE ASSEMBLY.
2. Using work equipment, push up track frame and set block between track frame and link.
- ⚠ Loosen the oil filler cap slowly to release the pressure inside the hydraulic tank.
3. Remove sprocket.
For details, see REMOVAL OF SPROCKET.
4. Remove cover (1).
5. Disconnect drain hose (2).
★ Set a container to catch the oil, then disconnect the hose and install a blind plug.
6. Disconnect speed selector hose (3) and motor hoses (4) and (5).
7. Sling final drive assembly (6), and remove mounting bolts, then remove. ※ 1



Final drive assembly: 550 kg



INSTALLATION OF FINAL DRIVE ASSEMBLY


- Carry out installation in the reverse order to removal.

※ 1



Final drive mounting bolt: $549 \pm 59 \text{ Nm}$
($56 \pm 6 \text{ kgm}$)

- **Refilling with oil (hydraulic tank)**
★ Add oil through the oil filler to the specified level.
Run the engine to circulate the oil through the system. Then check the oil level again.
- **Bleeding air**
★ Bleed the air from the travel motor (hydraulic tank).
For details, see TESTING AND ADJUSTING, Bleeding air.



DISASSEMBLY OF FINAL DRIVE ASSEMBLY

1. Draining oil


Remove drain plug and drain oil from final drive case.




Final drive case: Approx. 10 ℓ

2. Cover

1) Remove mounting bolts, then use forcing screws ① to disconnect cover (1) from ring gear.




2) Use eyebolts ② to remove cover (1).




3. Spacer

Remove spacer (2).




4. No. 1 carrier assembly



1) Remove No. 1 carrier assembly (3).




- 2) Disassemble No. 1 carrier assembly as follows.
- Push in pin (4), and knock out shaft (5) from carrier (6).
 - ★ After removing shaft (5), remove pin (4).
 - Remove thrust washer (7), gear (8), bearing (9), and thrust washer (10).




5. **No. 1 sun gear shaft**
Remove No. 1 sun gear shaft (11).
6. **No. 2 sun gear**
Remove No. 2 sun gear (12).



7. **Thrust washer**
Remove thrust washer (13).




8. **Ring gear**
Using eyebolts ③, remove ring gear (14).



9. No. 2 carrier assembly.

- 1) Remove No. 2 carrier assembly (15).




- 2) Disassemble No. 2 carrier assembly as follows.

- i) Push in pin (16) and pull out shaft (17) from carrier (18).


★ After removing the shaft, remove pin (16).

- ii) Remove thrust washer (19), gear (20), bearing (21), and thrust washer (22).




10. Nut

- 1) Remove lock plate (23).




- 2) Using tool J1, remove nut (24).




11. Hub assembly


- 1) Using eyebolts ④, remove hub assembly (25) from travel motor.




- 2) Disassemble hub assembly as follows.
 - i) Remove floating seal (26).



- ii) Remove bearings (27) and (28) from hub (29).



- 3) Remove floating seal (30) from travel motor (31).





020706

ASSEMBLY OF FINAL DRIVE ASSEMBLY


- ★ Clean all parts, and check for dirt or damage. Coat the sliding surfaces of all parts with engine oil before installing.

1. Hub assembly


- 1) Assemble hub assembly as follows.
 - i) Using push tool, press fit bearings (28) and (29) to hub.
 - ii) Using tool **J4**, install floating seal (26).
 - ★ Remove all oil and grease from the O-ring and O-ring contact surface, and dry the parts before installing the floating seal.
 - ★ After installing the floating seal, check that the angle of the floating seal is within 1 mm.
 - ★ After installing the floating seal, coat the sliding surface thinly with engine oil.



- 2) Using tool **J4**, install floating seal (30) to travel motor (31).
 - ★ The procedure for installation is the same as in Step 1)-ii) above.




- 3) Using eyebolts ④, set hub assembly (25) to travel motor, then using push tool, tap to press fit bearing portion.




2. Nut


- 1) Using tool **J2**, push inner race portion of bearing (27).
- ★ Pushing force: 14.7 – 18.6 kN (1.5 – 1.9 ton)
- ★ Rotate the hub 2 – 3 times before applying the pushing force to the bearing inner race.




- 2) Measure dimension **a** in the condition in Step 1) above.



- 3) Measure thickness **b** of nut (24) as an individual part.
- 4) Calculate $a - b = c$
- 5) Using tool **J1**, tighten nut (24) until **c** portion dimension is as follows.
 c portion dimension = $c \begin{smallmatrix} 0 \\ -1 \end{smallmatrix} \text{ mm}$




- 6) Using push-pull scale ⑤, measure tangential force in direction of rotation of hub in relation to motor case.
- ★ Tangential force: Max. 490 N (50 kg)
- ★ The tangential force is the maximum force when starting rotation.



020706

- 7) Install lock plate (23).




- ★ Install the lock plate as shown in the diagram on the right.

 Thread of mounting bolt:

Thread tightener (LT-2)

- ★ Do not coat the threaded portion of the nut with thread tightener (LT-2).

 **Mounting bolt: 66.19 ± 7.35 Nm**
(6.75 ± 0.75 kgm)




3. No. 2 carrier assembly

- 1) Assemble No. 2 carrier assembly as follows.

- ★ There are the remains of the caulking when the pin is inserted at the end face of hole **h** at the side of the carrier, so remove the caulked metal from the inside diameter of the hole before starting to assemble.

- i) Assemble bearing (21) to gear (20), fit top and bottom thrust washers (19) and (22), and set gear assembly in carrier (18).




- ii) Align with position of pin holes of shaft and carrier, then tap with a plastic hammer to install shaft (17).

- ★ When installing the shaft, rotate the planetary gear, and be careful not to damage the thrust washer.


- iii) Insert pin (16).

- ★ After inserting the pin, caulk the pin portion of the carrier.

- ★ After assembling the carrier assembly, check that gear (20) rotates smoothly.




- 2) Install No. 2 carrier assembly (15).
- ★ Align the position so that the three tips of the gear shafts of carrier assembly (15) enter the three hollows in the end face of the motor case, then install.



4. Ring gear

Fit O-ring to hub end, then using eyebolts ③, install ring gear (14).

- ★ Install so that the side with two grooves machined in the outside circumference of the ring gear is at the top (cover end).
- ★ Remove all grease and oil from the mating surface of the ring gear and hub.
- ★ Do not put any gasket sealant on the mating surface of the ring gear and hub under any circumstances.





5. Thrust washer

Install thrust washer (13).

6. No. 2 sun gear


Install No. 2 sun gear (12).




7. No. 1 carrier assembly

- 1) Assemble No. 1 carrier assembly as follows.


- ★ There are the remains of the caulking when the pin is inserted at the end face of hole **h** at the side of the carrier, so remove the caulked metal from the inside diameter of the hole before starting to assemble.
- i) Assemble bearing (9) to gear (8), fit top and bottom thrust washers (7) and (10) and set gear assembly to carrier (6).



- ii) Align position of pin holes of shaft and carrier, then tap with a plastic hammer to install shaft (5).
 - ★ When installing the shaft, rotate the planetary gear, and be careful not to damage the thrust washer.
- iii) Insert pin (4).
 - ★ After inserting the pin, caulk the pin portion of the carrier.
 - ★ After assembling the carrier assembly, check that gear (8) rotates smoothly.




- 2) Install No. 1 carrier assembly (3).




8. No. 1 sun gear shaft

Install No. 1 sun gear shaft (11).



9. Spacer


Install spacer (2).



10. Cover


- 1) Using eyebolts ②, install cover (1).

 Mounting surface of cover:
Gasket sealant (LG-6)



- 2) Using tool J3, tighten mounting bolts.

 Mounting bolt:
Initial torque: **98 Nm (10 kgm)**
Additional tightening angle:
115 – 125°

**11. Refilling with oil**

Tighten drain plug and add engine oil through oil filler.



Final drive case: Approx. **10 ℓ**


- ★ Carry out a final check of the oil level at the determined position after installing the final drive assembly to the chassis.

020706

DISASSEMBLY OF TRAVEL MOTOR ASSEMBLY

1. Travel motor assembly


Set travel motor assembly (1) to tool **S25**.



2. Plug, piston

Loosen plug (2) slowly and remove, then remove spring (3) and piston (4).

⚠ There is a force of approx. 294 N (30 kg) applied to the plug, so push the removal tool at a right angle when loosening the plug.




3. End cover assembly, valve plate

1) Turn over tool **S25** and remove safety valve assembly (5).

2) Loosen plug (6) slowly.

3) Lift off end cover (7).


★ The valve plate may be stuck to the end cover, so be careful not to drop it.



4) Remove valve plate (8).

★ When using again, keep in a safe place and be careful not to scratch or damage the cylinder block contact surface.

5) Remove outer race (9), then remove spacer (10).




6) Disassembly of end cover assembly


- i) Loosen plug (6) slowly and remove, then remove spring (11), piston (12), and spool (13).

⚠ There is a force of approx. 441 N (45 kg) applied to the plug, so push the removal tool at a right angle when loosening the plug.

- ii) Remove plug (14), then remove spring (15) and valve (16).
- iii) Remove ring (17), then remove seat (18), spring (19), and spool (20).
- iv) Remove plug (21), then remove ball (22).
- v) Remove plug (23), then remove valve (24).

**4. Spring**

Remove parking brake spring (25).




020706

5. Brake piston


Blow in compressed air with tool **S26**, and remove brake piston (26).

- ★ Air pressure: 0.2 MPa (2 kg/cm²)
- ★ Be careful that the air pressure is not too high. The brake piston will fly out.

**6. Bearing**


Using bearing race puller ① and gear puller ②, remove bearing (27).

- ★ Be careful not to apply any force to the bearing holder.
- ★ When using the cylinder block again, put gasket paper on the valve plate contact surface to protect the surface.
- ★ Never allow the puller to scratch or damage the cylinder block sliding surface.

**7. Cylinder block, piston assembly**


Rotate tool **S25** 90°, and remove cylinder block and piston assembly (28) from motor case (29).

- ★ The cylinder block and piston assembly may come off separately, so be careful not to drop them.




• **Disassembly of cylinder block, piston assembly**

- 1) Remove plate (30) and disc (31).
 - 2) Pull out piston assembly (33) from cylinder block (32), and remove retainer guide (34) and preload pin (35).
- ★ When removing the piston assembly from the cylinder block, the preload pin may come out, so be careful not to lose it.




- **Disassembly of piston assembly**

Pull out piston (37) from retainer shoe (36).




- **Disassembly of cylinder block**

- 1) Set tool **S27** to cylinder block (32).
- 2) Hold bolt of tool **S27** with wrench, tighten nut to compress spring, then remove snap ring (38).
- 3) Loosen nut of tool **S27** slowly to relieve tension of spring (39), then remove tool **S27**.
- 4) Remove spacer (40), spring (39), and spacer (40) from cylinder block (32).




8. Rocker cam, shaft assembly

- 1) Remove rocker cam (41) together with shaft assembly (42) from motor case (29).




- 2) Using push tool ③, remove bearing (44) from shaft (43).



020706


9. Disassembly of motor case

- 1) Remove ball (45).
- 2) Rotate tool **S25** 90°, remove snap ring (46) from motor case (29), then remove spacer (47).
- 3) Remove oil seal (48).
- 4) Remove outer race (49).



10. If above disassembly operation is not needed, and only oil seal is to be replaced, replace oil seal as follows.

- 1) Remove snap ring (46) and spacer (47).
- 2) Using bar ⑦ (hit end face with hammer), hit through to core of oil seal (48), then twist to remove.
 - ★ Hit at a point midway between the inside and outside circumference of the oil seal, and twist at two places on opposite sides (A and B in diagram) to remove.
 - ★ Be careful not to damage the shaft case.





ASSEMBLY OF TRAVEL MOTOR ASSEMBLY

Clean all parts, remove all burrs, and check for dirt or damage. Coat the rotating and sliding surfaces of all parts with engine oil (EO10-CD) before installing. Always check the following parts before assembling.

- ★ This check is unnecessary if both the cylinder block and valve plate are replacement parts (new parts).
- **Check contact between cylinder block and valve plate (For details, see procedure for checking contact.)**


1. Motor case

- 1) Using push tool ④, press fit outer race (49).
- 2) Set motor case (29) to tool **S25**.
- 3) Install ball (45).




2. Rocker cam, shaft assembly

- 1) Using tool **S28**, press fit bearing (44) to shaft (43) to make shaft assembly (42).
 - ★ When press fitting the bearing, push the end face of the bearing inner race with tool **S28** and press fit until it is in tight contact with the end face of the shaft.
 - ★ Press-fitting load:
2,392 – 9,787 N (244 – 998 kg)
 - Press-fitting surface of bearing:
Lubricating oil (EO10-CD)




- 2) Install rocker cam (41) to motor case (29) together with shaft assembly (42).
 - ★ When installing the rocker cam, check the contact with the ball, and check that the rocker cam moves smoothly without interfering with the motor case or shaft.
 - ★ Coat the ball hole in the rocker cam with grease (G2-LI). (To prevent the ball from coming out when the cylinder block and piston assembly is assembled.)



3. Cylinder block, piston assembly


• Assembly of cylinder block

- 1) Assemble spacer (40), spring (39), and spacer (40) to cylinder block (32).
- 2) Set tool **S27** to cylinder block (32).
- 3) Hold bolt of tool **S27** with wrench, tighten nut to compress spring (39), then install snap ring (38).
 - ★ Check that the snap ring is fitted securely in the groove.
- 4) Remove tool **S27**.




• Assembly of piston assembly

- 5) Assemble piston (37) to retainer shoe (36).




• Assembly of cylinder block, piston assembly

- 6) Assemble 3 preload pins (35) to cylinder block (32).
 - ★ Coat the preload pins with grease (G2-LI) to prevent them from coming out.
- 7) Assemble retainer guide (34) to cylinder block (32), then assemble piston assembly (33) to make cylinder block and piston assembly (28).
 - ★ Align the cylinder block and the spline of the retainer guide.




• Assembly of cylinder block and piston assembly

- 8) Secure shaft assembly in position with tool **S29**.
- 9) Rotate tool **S25** 90° and set opening of motor case facing side.



- 10) Install cylinder block and piston assembly (28) to motor case (29).

★ Align the spline of the cylinder block and piston assembly with the spline of the shaft assembly, then install.



4. Plate, disc, piston


- 1) Assemble plates (30) and discs (31) in order.

★ Do not wash the discs in trichlene or drizol, or blow strongly with air.




Front face of disc:

Lubricating oil (EO10-CD)




- **Method of placing plates and discs on top of each other.**

- Align cutout arc teeth areas **G**, **H**, and **I** of the discs.
- Protrusions **A**, **B**, **C**, **D**, **E**, and **F** on the outside of the plates can be set at any position in relation to positions **G**, **H**, and **I** of discs.




- 2) Fit O-ring and backup ring, and install brake piston (26).

★ Assemble the backup ring in the direction shown in the diagram.




- ★ Assemble so that the groove in the brake piston is aligned with the dowel pin in the end cover.




5. Adjusting end play of shaft

- Using tool **S30** and puller ⑤, press fit bearing (27) to shaft (43).
 - ★ When press fitting the bearing, push the end face of the bearing inner race with tool **S30** and press fit until it is in tight contact with the end face of the shaft.
 - ★ Press-fitting load:
2,667 – 10,963 N (272 – 1,118 kg)

 Press-fitting surface of bearing:
Lubricating oil (EO10-CD)




- Assemble spacer (10) to end cover (7), and install outer race (9).
 - ★ Assemble the same spacer that was removed.
- Align with dowel pin and install valve plate (8) to end cover (7).
 - ★ Check that there is no interference with the bearing and pin.
 - ★ Do not hit the valve plate or apply any impact when assembling.
(There is danger that this will damage the sliding surface or cause distortion.)
- Install end cover (7) to motor case (29).
 - ★ Do not install the O-ring and spring of the parking brake.



 **kgm** Mounting bolt:
461 ± 29 Nm (47 ± 3 kgm)

- Fit dial gauge ⑥ to motor case (29), move shaft in axial direction, and measure end play between shaft and bearing.
 - ★ End play: 0.05 – 0.25 mm



- 6) If dimension is not within standard value, adjust again as follows.
- Remove end cover.
 - Remove valve plate and outer race.
 - Set outer race (9) to bearing, then measure dimension **a** between end face of outer race and case, and calculate spacer **b** from the following formula.


$$b = 12.95 - a$$

- ★ Be careful not to install the shaft at an angle.
- ★ Measure at several places and take the average value as "a".

- Select spacer from table below.

b (mm)	1.70 – 1.79	1.80 – 1.89	1.90 – 1.99	2.00 – 2.09	2.10 – 2.19	2.20 – 2.29	2.30 – 2.39
Spacer to select	708-8H -32220	708-8H -32230	708-8H -32240	708-8H -32250	708-8H - 32260	708-8H -32270	708-8H -32280

- Fit selected spacer, then assemble again according to assembly Steps 5-2) – 5-5), and measure end play.
- After completion of adjustment, remove end cover, then remove valve plate.



6. End cover assembly


- Assembly of end cover assembly

- ★ Precautions when installing plug
 - Remove all oil and grease from the plug and female thread (end cover), and dry completely.
 - When coating with adhesive, coat with two drops (approx. 0.04 g) at a point 2 – 3 mm from the tip of the thread of the plug.



Plug: **Thread tightener**
(Loctite 638/648)

- Do not apply any pressure to the plug for 30 minutes after tightening.



- i) Assemble valve (24), then fit O-ring and install plug (23).

 Plug (23):
 $23.5 \pm 3.9 \text{ Nm}$ ($2.4 \pm 0.4 \text{ kgm}$)

- ii) Assemble ball (22), then fit O-ring and install plug (21).


 Plug (21):
 $23.5 \pm 3.9 \text{ Nm}$ ($2.4 \pm 0.4 \text{ kgm}$)

- iii) Assemble spool (20), spring (19), and seat (18) in order, then fit O-ring and install ring (17).

- iv) Assemble valve (16) and spring (15) in order, then fit backup ring and O-ring and install plug (14).


 Plug (14):
 $137.3 \pm 14.7 \text{ Nm}$ ($14 \pm 1.5 \text{ kgm}$)

- v) Assemble spool (13), piston (12), and spring (11) in order, then fit O-ring and tighten plug (6) temporarily.




CLP00692

- 2) Align with dowel pin, and install valve plate (8) to end cover (7).
 - ★ Check that there is no interference with the bearing and pin.
 - ★ Do not hit the valve plate or apply any impact when assembling.
(There is danger that this will damage the sliding surface or cause distortion.)



- 3) Install parking brake spring (25).
- 4) Fit O-ring, align dowel pin with groove portion of brake piston, and install end cover (7).
 - ★ Be extremely careful that the O-ring does not come out or get caught.



 Mating surface of motor case:
Gasket sealant (LG-7 or LG-5)

 Mounting bolt:
461 ± 29 Nm (47 ± 3 kgm)

- 5) Tighten plug (6).

 Plug (6):
419.2 ± 46.6 Nm (42.75 ± 4.75 kgm)

- 6) Fit backup ring and O-ring, and install safety valve assembly (5).

 Safety valve assembly:
318.7 ± 24.5 Nm (32.5 ± 2.5 kgm)

7. Plug, piston

Assemble piston (4) and spring (3), then fit O-ring and install plug (2).



★ Precautions when installing plug

- 1) Remove all oil and grease from the plug and female thread (motor case), and dry completely.
- 2) When coating with adhesive, coat with two drops (approx. 0.04 g) at a point 2 – 3 mm from the tip of the thread of the plug.

 Plug (2):
Thread tightener (Loctite 638/648)

- 3) Do not apply any pressure to plug for 30 minutes after tightening.

 Plug (2):
362.8 ± 39.2 Nm (37 ± 4 kgm)





8. Installation of oil seal


- 1) Check that there are no burrs or flashes at the corners of the shaft.
- 2) Using tool **S31**, press fit oil seal (48).
 - ★ Press fit until the end face of the motor case contacts tool **S31**.
 - ★ Clean the oil seal lip.



Tip of oil seal lip (whole circumference): **Grease (G2-LI-S)**



- 3) Assemble spacer (47), and install snap ring (46).





CHECKING CONTACT BETWEEN CYLINDER BLOCK AND VALVE PLATE

- ★ This check is unnecessary if both the cylinder block and valve plate are replacement parts (new parts).
 - ★ This check applies if one of the parts is a replacement part or a restored part.
 - ★ If the contact is defective, use a surface plate and correct by lapping.
- 1) Make a centering tool for the cylinder block and valve plate.
 - ★ The tool can be made from plastic, bakelite or any other soft material.
 - 2) Remove all oil and grease from the parts to be checked.
 - ★ Do not wipe with a cloth.
 - 3) Set the tool in position, then paint the cylinder block with inspection paint.
 - ★ Coat thinly with paint.
 - 4) Push the valve plate with a force of 39 – 49 N (4 – 5 kg) against the cylinder block, turn the valve plate 90°, then turn it back to the original position. Repeat this process 2 or 3 times.
 - 5) Remove the valve plate, transfer the contact surface to a tape, and check the contact surface.
 - ★ The contact of the plane surface of the valve plate and cylinder block must fulfill the conditions below and must cover the whole circumference without any break.
 - i) The contact at the seal portion (range of $\phi 84.4 - \phi 116.5$ mm from the inside) must be at least 80%.
 - ii) The contact at the land portion (range of $\phi 128 - \phi 142$ mm) must be at least 60%.

	Seal portion	Land portion
Valve plate	Min. 80%	Min. 60%
Cylinder block	Min. 80%	Min. 60%

- ★ For details of the operation, see the Parts Judgement Guide.




REMOVAL OF SPROCKET

1. Remove track shoe assembly.
For details, see REMOVAL OF TRACK SHOE ASSEMBLY.
2. Swing work equipment 90°, then push up chassis with work equipment and set block ① between track frame and track shoe.
3. Remove mounting bolts, then lift off sprocket (1).



Sprocket : **70 kg**



INSTALLATION OF SPROCKET

- Carry out installation in the reverse order to removal.



Thread of sprocket mounting bolt:

Thread tightener (LT-2)



kgm

Sprocket mounting bolt:



637 ± 49 Nm (65 ± 5 kgm)

REMOVAL OF SWING MOTOR ASSEMBLY

- ⚠ Release the remaining pressure in the hydraulic circuit.
For details, see TESTING AND ADJUSTING, Releasing remaining pressure from hydraulic circuit.
- ⚠ Loosen the oil filler cap slowly to release the pressure inside the hydraulic tank.
- ★ Fit blind plugs in the disconnected hoses and tubes.
- 1. Disconnect suction hose (1).
- 2. Disconnect swing hoses (2).
- 3. Disconnect drain hoses (3) and (4).
- 4. Disconnect swing holding brake hose (5).
- 5. Remove mounting bolts, and lift off swing motor assembly (6).



Swing motor assembly: **110 kg**




INSTALLATION OF SWING MOTOR ASSEMBLY

- Carry out installation in the reverse order to removal.
- **Refilling with oil (hydraulic tank).**
 - ★ Add oil through the oil filler to the specified level.
Run the engine to circulate the oil through the system. Then check the oil level again.
- **Bleeding air**
 - ★ Bleed the air from the swing motor.
For details, see TESTING AND ADJUSTING, Bleeding air.

DISASSEMBLY OF SWING MOTOR ASSEMBLY



1. Motor assembly

Set swing motor assembly (1) to tool **S13**.




2. Housing

- 1) Remove covers (2), then remove springs (3) and sleeves (4).
- 2) Remove housing mounting bolts (5).
- 3) Using eyebolts ① (Thread: 12mm, Pitch = 1.75mm), lift off housing (6).



★ Springs (7) may fall out during the removal operation, so be careful not to lose them.

- 4) Remove 6 springs (7) from valve case.





3. Valve plate

Remove valve plate (8).

4. Cylinder block

Remove cylinder block (9).



5. Spring



Remove spring (10) and center ring (11).

6. Retainer

Using tool **S14**, remove 7 mounting screws, then remove retainer (12).



7. Shaft, piston

Remove center shaft (13) and 7 pistons (14).



**8. Brake piston**

- 1) Using tool **S24**, pump in air through port **B** and remove brake piston (15).
 - ★ Air pressure: 0.2 MPa (2 kg/cm²)
 - ★ Be careful that the air pressure is not too high. The brake piston will fly out.

- 2) Remove O-ring (16) from piston.

**9. Plates, discs**


- 1) Remove plates (17) and discs (18).
- 2) Remove plates (19).
 - ★ Plates (17)(19): 5
 - ★ Discs (18): 3

**10. Cover**



- 1) Remove case assembly from tool **S13**, and turn over.
- 2) Remove snap ring (20), then remove cover (21).
 - ★ Put a screwdriver in contact with portion **a** and remove cover (21).
- 3) Remove oil seal (22) from cover (21).

11. Shaft assembly

- 1) Remove snap ring (23), then remove 2 spacers (24).




- 2) Set case assembly to press, and remove shaft assembly (25) from case (26).
- 3) Remove bearing (27) from shaft (28).



12. Bearing, seat, belleville spring

- 1) Remove bearing inner race (29) from case.
- 2) Remove bearing outer race (30).
- 3) Remove seat (31) and belleville spring (32).
- 4) Remove main bearing outer race (33).





020706

ASSEMBLY OF SWING MOTOR ASSEMBLY

Clean all parts, remove all burrs, and check for dirt or damage. Coat the rotating and sliding surfaces of all parts with engine oil (EO10-CD) before installing. Using chromium oxide, remove all the lapping powder from the places that have been lapped.

1. Outer race

Using push tool ② (outside diameter: 159mm), press fit outer race (33) to case.



2. Shaft assembly



1) Using tool **S16**, press fit bearing (27) to shaft.

★ Press fit until the end face of the inner race is in tight contact with the shaft.

Press fitting load:

7.71 – 39.22 kN (787 – 4,000 kg)


2) Set shaft assembly (25) to block ③ (outside diameter: 130mm, height: 50mm), then set case (26) in position.




3. Belleville spring, seat, bearing

1) Install belleville spring (32) and seat (31).


★ Install the belleville spring in the direction shown in Fig. A.



2) Using tool **S17**, install outer race (30).



- 3) Using tool **S18**, press fit bearing (29).
- ★ During the press-fitting operation, rotate case (26) and check that the bearing rotates smoothly.
 - ★ Press fit until seat (31) is in tight contact with case (26).
 - ★ Bearing press-fitting load: 3.92 – 20.15 kN (400 – 2,055 kg)




4. Spacer

- 1) Measure clearance **a** between bottom face of snap ring (23) and top face of bearing inner race, then select 2 spacers (24) equivalent to clearance **a** from table below.

Unit: mm



	Part No. of spacer (24)	Thickness
①	706-77-42440	2.3
②	706-77-42450	2.5
③	706-77-42460	2.7

- ★ Standard assembled thickness of spacer: 5.1 mm



- 2) After assembling spacer (24), install snap ring (23).

- ★ Check that the snap ring is fitted securely in the snap ring groove.




- 3) Pushing out drive shaft

- i) Set tool **S19** to case (26), then push out drive shaft under load given below until end face of bearing inner race (29) is in tight contact with spacer (24) and snap ring (23).

- ★ Load when pushing out shaft:
3.92 – 16.18 kN (400 – 1,650 kg)

- ii) After bringing into tight contact, apply a load of 21.57 kN (2,200 kg), and check that spacer (24) cannot be rotated by hand and that spacer is in tight contact.




- 4) Check clearance between case (26) and seat (31) as follows.

- i) Using tool **S19**, apply a load of 4.90 – 21.57 kN (500 – 2,200 kg) to tip of drive shaft, measure movement of drive shaft, and check that it is within specified value.



★ Movement of drive shaft:

0.1 – 0.4 mm




- ii) If movement of drive shaft is not within specified value, adjust spacer as follows.

- If clearance is less than 0.1 mm:
Replace spacer with (706-77-42440) and install snap ring.
- If clearance is more than 0.4 mm:
Replace spacer with (706-77-42460) and install snap ring.
- Repeat Steps 4-3) – 4) to measure movement of drive shaft, and check that clearance is within range of 0.1 – 0.4 mm.




- iii) Set motor case to tool **S13**, then use tool **S20** to measure rotating torque of drive shaft.

- ★ Rotating torque of drive shaft:
1.5 – 4.9 Nm (0.15 – 0.50 kgm)
- ★ Before carrying out the measurement, supply the bearing well with oil, and rotate the drive shaft at a speed of 1 turn every 5 seconds when measuring the rotating torque.





- ★ If the rotating torque is not within the range of 1.5 – 4.9 Nm (0.15 – 0.50 kgm), replace bearings (27) and (33) with new parts and adjust again.



5. Cover

- 1) Using tool **S21**, press fit oil seal (22) until it is in tight contact with cover (21).
 - 2) Assemble cover (21), and install snap ring (20).
- ★ Be careful not to damage the lip of the oil seal when installing the cover.



 Lip: **Grease (G2-LI-S)**



6. Plates, discs



Assemble plates (19), discs (18), and plates (17) to case.

- ★ Plates (17)(19): 5
- ★ Discs (18): 3
- ★ Before assembling the discs, coat the surface with lubricating oil.
- ★ Do not wash the discs in trichlene or drizol, or blow strongly with air.



7. Brake piston

- 1) Install O-ring (16) to piston.
- 2) Install brake piston (15).



8. Piston, shaft

- 1) Set 7 pistons (14) and center shaft (13) in position.

- 2) Using tool **S14**, tighten 7 retainer mounting screws.

- ★ Replace the retainer mounting screws with new parts.

 Screw: Thread tightener (LT-2)

 Screw:



1st step (tighten temporarily):

Max. 0.98 Nm (0.1 kgm)

2nd step: 3.9 – 5.9 Nm (0.4 – 0.6 kgm)


3rd step: 13.2 ± 1.5 Nm (1.35 ± 0.15 kgm)

- ★ Remove all oil and grease from the thread (male and female), and dry completely.
- ★ Order for tightening: ①-④-⑦-③-⑥-②-⑤
Tighten either clockwise or counterclockwise.
- ★ After tightening, wipe off any adhesive that has been squeezed out.
- ★ Check that the large ball of piston (14) and center shaft (13) move smoothly.




- 3) Using dial gauge ⑤, measure play of piston (14) in axial direction.

- ★ Play of piston in axial direction:
Max. 0.25 mm



**9. Spring**

- 1) Set housing (6) to tool **S13** together with tool **S22**, then adjust angle so that valve plate mounting surface is horizontal.



- 2) Install valve plate (8).



- 3) Assemble cylinder block (9) to housing (6).
- 4) Assemble spring (10) and center ring (11) to cylinder block.
- 5) Install 6 springs (7) to housing.
- 6) Press fit dowel pin (34).



- ★ Using tool **S23**, knock in the dowel pin so that dimension **a** is the standard value.
- ★ Standard dimension **a**: 8.0 – 10.0 mm
- ★ Assemble the tapered end to the hole in the housing.
- ★ Be careful not to damage the dowel pin and the brake piston.



10. Raise motor case assembly, align with housing and lower slowly, align 7 center shaft pistons with holes in cylinder block, then install housing (6).



Mating surface of case:

Gasket sealant (LG5 or LG7)


- ★ Align the positions of the dowel pin and motor case exactly when installing.



Mounting bolt:

277.0 ± 31.9 Nm (28.25 ± 3.25 kgm)

11. Set swing motor assembly to tool **S13**.





12. Install sleeves (4), springs (3), and covers (2).





Cover mounting bolt:

110.3 ± 12.3 Nm (11.25 ± 1.25 kgm)



13. Checking drive shaft rotating torque

- 1) Using tool **S15**, apply pressure of at least 2.0 MPa (20 kg/cm²) through port **B** to release brake.



- 2) Set tool **S20** in position and check rotating torque.


- ★ When checking the rotating torque, check that the shaft rotates smoothly without any variation.

Variation: Max. 1.5 Nm (0.15 kgm)

Rotating torque:

5.9 – 15.2 Nm (0.60 – 1.55 kgm)

- ★ If it is not within the specified range, adjust again from Step 4.




REMOVAL OF SWING MACHINERY ASSEMBLY

1. Remove swing motor assembly.
For details, see REMOVAL OF SWING MOTOR ASSEMBLY.
2. Remove mounting bolts (1). ※ 1
3. Lift off swing machinery assembly (2).



Swing machinery assembly: **390 kg**




INSTALLATION OF SWING MACHINERY ASSEMBLY

- Carry out installation in the reverse order to removal.



Swing machinery case mounting bolt:
966.0 ± 142.0 Nm (98.5 ± 14.5 kgm)



DISASSEMBLY OF SWING MACHINERY ASSEMBLY

1. Draining oil


Loosen drain plug and drain oil from swing machinery.



Swing machinery case: Approx. **13.5 ℓ**


2. Cover

Remove mounting bolts, then lift off cover (1).




3. No. 1 carrier assembly.

- 1) Remove thrust washer (2).
- 2) Remove No. 1 sun gear (3).




- 3) Remove No. 1 carrier assembly (4).




4. Disassemble No. 1 carrier assembly as follows.

- 1) Push in pin (5), and knock out shaft (6) from carrier (7).
- ★ After removing the shaft, remove pin (5).
- 2) Remove thrust washer (8), gear (9), bearing (10), and thrust washer (11).




5. Ring gear

Lift off ring gear (12).




6. No. 1 sun gear

- 1) Remove thrust washer (13) and collar (14).
- 2) Remove No. 1 sun gear (15).




- 3) Remove thrust washer (16).




7. No. 2 carrier assembly

Lift off No. 2 carrier assembly (17).




8. Disassemble No. 2 carrier assembly as follows.

- 1) Push in pin (18), and knock out shaft (19) from carrier (17).
- ★ After removing the shaft, remove pin (18).
- 2) Remove thrust washer (20), gear (21), bearing (22), and thrust washer (23).




9. Pinion shaft assembly.



- 1) Remove bolt (24), then remove holder (25).
- 2) Remove gear (26).



- 3) Turn over case and pinion assembly, then remove mounting bolts (28) of cover assembly (27).





- 4) Turn over case and pinion assembly (29), and set on press stand, then using push tool ①, remove pinion shaft assembly (30) with press.
- ★ Set a wooden block under the press, and be careful not to damage the pinion shaft assembly when removing it.



020706


10. Disassemble pinion shaft assembly as follows.

- 1) Using push tool ②, remove cover assembly (27) and bearing (31) from shaft (32).
- 2) Remove oil seal (33) from cover (27).



11. Bearing

Using push tool, remove bearing (34) from case (35).




ASSEMBLY OF SWING MACHINERY ASSEMBLY

- ★ Clean all parts, and check for dirt or damage. Coat the sliding surfaces of all parts with engine oil before installing.

1. Bearing


Using push tool ③, press fit bearing (31) to case (35).



2. Cover assembly


1) Using push tool ④, press fit oil seal (33) to cover (27).

-  Outside circumference of oil seal:
Gasket sealant (LG-6)
- ★ Be careful not to let the gasket sealant (LG-6) get on the oil seal lip when press fitting.



2) Fit cover assembly (27) to case (35), and tighten mounting bolts (28).


-  Cover mounting surface:
Gasket sealant (LG-6)
-  Mounting bolt: **66.19 ± 7.35 Nm (6.75 ± 0.75 kgm)**
-  Lip of oil seal: **Grease (G2-LI)**



3. Case assembly

1) Set case assembly (35) to shaft (32), then using push tool ⑤, press fit bearing inner race portion.


- ★ When setting the case assembly to the shaft, be extremely careful not to damage the oil seal.



2) Bearing

Using tool F, press fit bearing (34).

- ★ Press the bearing inner race and outer race at the same time when press fitting. Do not press only the inner race when press fitting.
- ★ After press fitting the bearing, check that the case rotates smoothly.




3) Gear, holder

Assemble gear (26), then fit holder (25) and tighten bolt (24).

 Mounting bolt:


Thread tightener (LT-2)

 Mounting bolt: **380.00 ± 46.58 Nm**
(38.75 ± 4.75 kgm)



4. Assemble No. 2 carrier assembly as follows

- ★ There are the remains of the caulking when the pin is inserted at the end face of hole h at the side of the carrier, so remove the caulked metal from the inside diameter of the hole before starting to assemble.
- 1) Assemble bearing (22) to gear (21), fit top and bottom thrust washers (23) and (20) and set gear assembly to carrier (17).




- 2) Align with position of pin holes of shaft and carrier, then tap with a plastic hammer to install shaft (19).

- ★ When installing the shaft, rotate the planetary gear, and be careful not to damage the thrust washer.

- 3) Insert pin (18).

- ★ After inserting the pin, caulk the pin portion of the carrier.
- ★ After assembling the carrier assembly, check that gear (21) rotates smoothly.




DISASSEMBLY AND ASSEMBLY

SWING MACHINERY


5. No. 2 carrier assembly

Raise No. 2 carrier assembly (17) and install.




6. No. 2 sun gear

1) Assemble thrust washer (16).



2) Install No. 2 sun gear (15) to No. 2 carrier, then install collar (14) and thrust washer (13).




7. Ring gear

Raise ring gear (12) and install.

★ Align with the drain hole and assemble.

 Mating surface of ring gear and case:
Gasket sealant (LG-6)




020706

8. Assemble No. 1 carrier assembly as follows.

- ★ There are the remains of the caulking when the pin is inserted at the end face of hole **h** at the side of the carrier, so remove the caulked metal from the inside diameter of the hole before starting to assemble.

- 1) Assemble bearing (10) to gear (9), fit top and bottom thrust washers (8) and (11) and set gear assembly to carrier (7).




- 2) Align position of pin holes of shaft and carrier, then tap with a plastic hammer to install shaft (6).

- ★ When installing the shaft, rotate the planetary gear, and be careful not to damage the thrust washer.


- 3) Insert pin (5).

- ★ After inserting the pin, caulk the pin portion of the carrier.

- ★ After assembling the carrier assembly, check that gear (9) rotates smoothly.


**9. No. 1 carrier assembly**

Install No. 1 carrier assembly (4).

**10. No. 1 sun gear**

- 1) Assemble No. 1 sun gear (3) to carrier assembly.

- 2) Install thrust washer (2).




11. Cover

Install cover (1).

 Cover mounting surface:

Gasket sealant (LG-6)

 **kgm** Mounting bolt: 1st pass: **98 Nm (10 kgm)**
2nd pass: **70 – 80°**



12. Refilling with oil

Tighten drain plug and add engine oil through oil filler.



Swing machinery case: Approx. **13.5 ℓ**

REMOVAL OF REVOLVING FRAME ASSEMBLY

1. Remove work equipment assembly.
For details, see REMOVAL OF WORK EQUIPMENT ASSEMBLY.

⚠ When disconnecting the hydraulic hoses, release the remaining pressure in the hydraulic circuit. For details, see TESTING AND ADJUSTING, Releasing remaining pressure from hydraulic circuit.

2. Disconnect boom cylinder hoses (1).
★ Fit blind plugs in the hoses and make it possible to swing the upper structure.

3. Raise boom cylinder assembly (2), then pull out foot pin (3) and lift off.
★ Remove the right cylinder assembly in the same way.

 Boom cylinder assembly: **300 kg**

4. Remove counterweight assembly.
For details, see REMOVAL OF COUNTERWEIGHT ASSEMBLY.

5. Remove engine hood (4), cover (5), and frame (6).

★ For details of the method of removing the engine hood, see REMOVAL OF HYDRAULIC COOLER ASSEMBLY.

6. Leave 3 mounting bolts each at front and rear of revolving frame, and remove other mounting bolts.





★ Swing the upper structure and set to a position where it is easy to remove the mounting bolts.

7. Disconnect drain hoses (7) and (8).

★ Install blind plugs in the drain hoses.

8. Disconnect travel hoses (9) and (10), and speed selector hose (11).


9. Pull out pin (12), and disconnect plate (13) from swivel joint.



10. Sling revolving frame assembly (14), then remove mounting bolts, and lift off revolving frame assembly.

- ★ Use 2 lever blocks.
- ★ Loosen the mounting bolts remaining at the front and rear and adjust the center of gravity with the lever block while lifting off.

 Revolving frame assembly: **7000 kg**



INSTALLATION OF REVOLVING FRAME ASSEMBLY

- Carry out installation in the reverse order to removal.

※ I

 Mating surface of swing circle:
Gasket sealant (LG-4)

 Thread of revolving frame mounting bolt:
Thread tightener (LT-2)


 Revolving frame mounting bolt:
926.7 ± 103.0 Nm (94.5 ± 10.5 kgm)

REMOVAL OF SWING CIRCLE ASSEMBLY

1. Remove revolving frame assembly.
For details, see REMOVAL OF REVOLVING FRAME ASSEMBLY.
2. Sling swing circle assembly (1) at three points, then remove mounting bolts, and lift off swing circle assembly.



kg Swing circle assembly: **500 kg**



INSTALLATION OF SWING CIRCLE ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1



Thread of swing circle mounting bolt:

Thread tightener (LT-2)




kgm Swing circle mounting bolt:

$926.7 \pm 103.0 \text{ Nm}$ ($94.5 \pm 10.5 \text{ kgm}$)

- ★ Set the soft zone **S** mark on the inside ring of the inner race facing the right side of the machine as shown in the diagram, then install to the track frame.





Swing circle: **Grease (G2-LI) 33 ℓ**



REMOVAL OF IDLER, RECOIL SPRING ASSEMBLY


1. Remove track shoe assembly.
For details, see REMOVAL OF TRACK SHOE ASSEMBLY.
★ Remove lubricator (1).



2. Sling idler and recoil spring assembly (2), and pull out to the front to remove.
★ Fit wire to the idler and spring of the idler and recoil spring assembly, and adjust the balance when removing.



Idler, recoil spring assembly: **430 kg**




3. Disconnect recoil spring assembly (4) from idler assembly (3).



Idler assembly: **170 kg**



Recoil spring assembly: **260 kg**



INSTALLATION OF IDLER, RECOIL SPRING ASSEMBLY


- Carry out installation in the reverse order to removal.

※ 1


- ★ When installing the idler assembly and recoil spring assembly, assemble so that the position of the greasing plug on the idler is on the outside for the right side of the machine and on the inside for the left side of the machine.

DISASSEMBLY OF IDLER ASSEMBLY



1. Remove pin (2), then remove support (3).
2. Remove floating seal (4) from support (3) and idler (5).
3. Pull out shaft and support assembly (6) from idler (5).
 - ★ It is filled with approx. 230 cc. of oil, so drain the oil at this point or lay a cloth to prevent the area from becoming dirty.



4. Remove floating seal (7) on opposite side from idler (5) and shaft and support assembly (6).




5. Remove pin (9), then remove support (10) from shaft (11).
6. Remove bushing (12) from idler (5).





ASSEMBLY OF IDLER ASSEMBLY


1. Press fit bushing (12) to idler (5).
2. Fit O-ring and install support (10) to shaft (11), then install pin (9).
 - ★ After inserting the pin, caulk the pin portion of the support.



3. Using tool L1, install floating seal (7) to idler (5) and shaft and support assembly (6).
 - ★ Coat the sliding surface of the floating seal with oil, and be careful not to let any dirt or dust get stuck to it.
 - ★ Remove all grease and oil from the contact surface of the O-ring and the floating seal.




4. Assemble shaft and support assembly (6) to idler (5).



020706


IDLER

-
- Diagram showing the assembly of the front cover. Part 5 is the front cover, and part 4 is the front cover gasket. The diagram shows the gasket being placed into the cover.



-
- This diagram illustrates the exploded view of a mechanical assembly, likely a pump or motor component. The parts are numbered as follows:
- 1**: A bracket or housing component at the top right.
 - 2**: A small pin or screw used to secure the bracket.
 - 3**: A small circular component, possibly a seal or gasket, located near the bracket.
 - 4**: A set of four small O-rings or seals.
 - 5**: A large, circular, ribbed component, possibly a pulley or flywheel.
 - 6**: A long, cylindrical shaft or rod.
 - 7**: A set of four small O-rings or seals along the shaft.
 - 8**: A small pin or screw used to secure the shaft.
 - 9**: A small pin or screw used to secure the bracket.
 - 10**: A small circular component, possibly a seal or gasket, located near the bracket.
 - 11**: A small cylindrical component, possibly a bush or spacer.
 - 12**: A small pin or screw used to secure the shaft.
 - 13**: A small pin or screw used to secure the bracket.

DISASSEMBLY OF RECOIL SPRING ASSEMBLY



1. Remove piston assembly (2) from recoil spring assembly (1).

2. Disassembly of recoil spring assembly

- 1) Set tool **M1** to recoil spring assembly (1).
 The recoil spring is under large installed load, so be sure to set the tool properly. Failure to do this is dangerous.

★ Installed load of spring:


173.3 kN (17,680 kg)

- 2) Apply hydraulic pressure slowly to compress spring, then remove lock plate (3), and remove nut (4).

- ★ Compress the spring to a point where the nut becomes loose.

★ Free length of spring: 795 mm

- 3) Remove yoke (6), cylinder (7), and dust seal (8) from spring (5).



4. Disassembly of piston assembly

- 1) Remove lock plate (10) from piston (9), then remove valve (11).
- 2) Remove snap ring (12), then remove U-packing (13) and ring (14).

ASSEMBLY OF RECOIL SPRING ASSEMBLY

1. Assembly of piston assembly

- 1) Assemble ring (14) and U-packing (13) to piston (9), and secure with snap ring (12).
- 2) Tighten valve (11) temporarily, and secure with lock plate (10).

2. Assembly of recoil spring assembly

- 1) Using tool **M2**, assemble dust seal (8) to cylinder (7).
- 2) Assemble cylinder (7) and yoke (6) to spring (5), and set in tool **M1**.

 Sliding portion of cylinder:

Grease (G2-LI)



- 3) Apply hydraulic pressure slowly to compress spring, and tighten nut (4) so that installed length of spring is dimension "a", then secure with lock plate (3)
 - ★ Installed length "a" of spring: 648 mm
- 4) Remove recoil spring assembly (1) from tool **M1**.

3. Assemble piston assembly (2) to recoil spring assembly (1).

 Piston sliding portion and wear ring:

Grease (G2-LI)

- ★ Assemble the cylinder assembly so that the mounting position of the valve is 90° to the side.
- ★ Fill the inside of the cylinder with approx. 200 cc of grease (G2-LI), then bleed the air and check that grease comes out of the grease hole.



REMOVAL OF TRACK ROLLER ASSEMBLY

1. Lower work equipment to ground, then loosen lubricator (1), and relieve track tension. ※ 1

⚠ The adjustment cylinder is under extremely high pressure, so never loosen the lubricator more than one turn. If the grease does not come out easily, move the machine backwards and forwards.

2. Remove mounting bolts of track roller guard (2), then swing work equipment 90°, jack up machine with work equipment, and remove track roller guard (2) towards outside of machine. ※ 2







Track roller guard: **35 kg**

3. Lower chassis completely, remove mounting bolts of track roller assembly (3), then jack up machine with work equipment, and remove track roller assembly (3) to outside of machine. ※ 3



Track roller assembly: **55 kg**



INSTALLATION OF TRACK ROLLER ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1

- ★ Adjust the track tension.
For details, see TESTING AND ADJUSTING, Testing and adjusting track tension.

※ 2



Roller guard mounting bolt:
Thread tightener (LT-2)



Roller guard mounting bolt:
926.7 ± 103.0 Nm (94.5 ± 10.5 kgm)

※ 3




Track roller mounting bolt:
Thread tightener (LT-2)





Track roller mounting bolt:
1st pass: **196.1 ± 19.6 Nm (20 ± 2 kgm)**
2nd pass:

Tighten an additional 105 ± 5°



DISASSEMBLY OF TRACK ROLLER ASSEMBLY





1. Remove pin (1), then remove collar (2).
2. Remove floating seal (3) from collar (2) and roller (4).
3. Pull out roller (4) from shaft (5).
 - ★ It is filled with 250 – 280 cc. of oil, so drain the oil at this point or lay a cloth to prevent the area from becoming dirty.



4. Remove floating seal (6) on opposite side from roller (4) and collar (8).







5. Remove pin (7), then remove collar (8) from shaft (5).
6. Remove bushings (9) and (10) from roller (4).



ASSEMBLY OF TRACK ROLLER ASSEMBLY



1. Using push tool ①, press fit bushings (9) and (10) to roller (4).
2. Assemble collar (8) to shaft (5), and install pin (7).
3. Using tool L3, install floating seal (6) to shaft (5).

- ★ When assembling the floating seal, clean the contact surface of O-ring (6c) and floating seal (6a), remove all grease and oil, and dry it. Make sure that no dirt or dust sticks to the contact surface of the floating seal.
- ★ After inserting the floating seal, check that the angle of the seal is less than 1 mm and that the protrusion of the seal is within a range of 5 – 7 mm.



4. Using tool L3, install floating seals (6) and (3) to roller (4).
- ★ For details of the precautions when installing floating seals (6b) and (6d), and (3b) and (3d), see the precautions marked ★ for Step 3.



5. Assemble shaft (5) to roller (4).



6. Turn over roller (4) and shaft (5) assembly.

7. Using tool L3, install floating seal (3) to collar (2).


- ★ For details of the precautions when installing floating seals (3a) and (3c), see the precautions marked ★ for Step 3.



DISASSEMBLY AND ASSEMBLY


TRACK ROLLER

8. Assemble collar (2) to shaft (5), and install pin (1).



9. Using tool L4, apply standard pressure to roller oil filler port, and check for leakage of air from seal.

- ★ Standard pressure: 0.1 MPa (1 kg/cm²)
- ★ Method of checking
The standard pressure shall be maintained for 10 seconds and the indicator of the gauge shall not go down.





10. Using tool L4, fill track roller assembly with oil, then tighten plug (11).



Track roller oil: 250 – 280 cc (EO30-CD)




Plug: 14.7 ± 4.9 Nm (1.5 ± 0.5 kgm)



REMOVAL OF CARRIER ROLLER ASSEMBLY


1. Lower work equipment to ground, then loosen lubricator (1), and relieve track tension. ※ 1

⚠ The adjustment cylinder is under extremely high pressure, so never loosen the lubricator more than one turn. If the grease does not come out, move the machine backwards and forwards.



2. Using hydraulic jacks ①, push up track to a position where carrier roller assembly can be removed, then remove carrier roller assembly (2). ※ 2

 Carrier roller assembly: **35 kg**




INSTALLATION OF CARRIER ROLLER ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1

- ★ Adjust the track tension.
For details, see TESTING AND ADJUSTING,
Testing and adjusting track tension.

DISASSEMBLY OF CARRIER ROLLER ASSEMBLY




CEP00231


1. Remove plug (1) and drain oil.

Carrier roller assembly: **450 – 500 cc**

2. Set carrier roller assembly on stand ①.
3. Remove cover (2).
4. Remove ring (3).




CEP00232




CEP00233

5. Using tool L5, remove nut (4).
6. Using push tool ②, pull out shaft assembly (5) from roller (6) with press, then remove inner race (7).




CEP00234




CEP00235

7. Remove outer races (8) and (9) from roller (6).
8. **Disassembly of shaft assembly.**
 - 1) Using puller ③, remove inner race (10).



CEP00236





CEP00237

DISASSEMBLY AND ASSEMBLY

CARRIER ROLLER

- 2) Remove floating seals (11).
- 3) Using push tool ④, remove collar (12) from shaft (13)



020706

ASSEMBLY OF CARRIER ROLLER ASSEMBLY

- Using push tool ⑤, press fit outer races (8) and (9) to roller (6).

- Assembly of shaft assembly.**

- Using tool L7, press fit collar (12) to shaft (13).

★ When press fitting, be careful that there is no scuffing.

 Fitting portion of shaft:

Engine oil (EO30-CD)







- Using tool L6, assemble floating seals (11).

★ When assembling the floating seal, clean the contact surface of O-ring (11c) and floating seal (11a), remove all grease and oil, and dry it. Make sure that no dirt or dust sticks to the contact surface of the floating seal.

★ After inserting the floating seal, check that the angle of the seal is less than 1 mm and that the protrusion of the seal is within a range of 5 – 7 mm.

- Assemble floating seals (11), then using push tool ⑥, press fit inner race (10).

★ For details of the precautions when installing floating seals (11b) and (11d), see the precautions marked ★ for Step 2).





- Assemble roller (6) to shaft assembly (5).


- Using push tool ⑦, press fit inner race (7).

★ When press fitting the bearing, rotate the roller, and press fit to a point where the rotation becomes slightly heavier.


- Using tool L5, tighten nut (4) to a point where drill hole in shaft is aligned with drill hole in nut.



6. Install ring (3).
7. Using push-pull scale (8), check that roller rotates smoothly.




8. Fit O-ring and install cover (2).



9. Using tool L8, apply standard pressure to roller oil filler port, and check for leakage of air from seal.

- ★ Standard pressure: 0.1 MPa (1 kg/cm²)
- ★ Method of checking
The standard pressure shall be maintained for 10 seconds and the indicator of the gauge shall not go down.




10. Using tool L8, fill carrier roller assembly with oil, then tighten plug (1).



Carrier roller oil: 450 – 500 cc (EO30-CD)



Plug: 14.7 ± 4.9 Nm (1.5 ± 0.5 kgm)





REMOVAL OF TRACK SHOE ASSEMBLY

1. Positioning track shoe

- ★ Stop the machine at a point where it is easy to set master pin removal tool **R**, and where master pin is in the middle of the track frame, then loosen lubricator (1), and relieve the track tension. ※ 1


⚠ The adjustment cylinder is under extremely high pressure, so never loosen the lubricator more than one turn. If the grease does not come out, move the machine backwards and forwards.



2. Using tool **R**, pull out master pin (2). ※ 2

3. Lay out track as follows.

- 1) Move machine forward so that position of temporary pin is at front of idler, set block ① in position, then remove temporary pin ②, and remove dust seal. ※ 3
- 2) Drive machine in reverse to lay out track.



INSTALLATION OF TRACK SHOE ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1



Adjust the track tension.
For details, see TESTING AND ADJUSTING, Testing and adjusting track tension.

※ 2

- ★ Use tool **R** and press fit so that the protrusion of the master pin is dimension "a".
Protrusion "a" of master pin: 4.2 ± 2 mm

※ 3

When assembling the dust seal, coat the bushing contact surface with grease (G2-LI).



REMOVAL OF HYDRAULIC TANK ASSEMBLY

- Swing the upper structure to set the position of the hydraulic tank drain and mounting bolt outside the track.



⚠ Loosen the hydraulic tank oil filler cap slowly to release the pressure inside the hydraulic tank.

1. Drain oil from hydraulic tank.




Hydraulic tank: Approx. **200 ℓ**


2. Remove operator's cab assembly.
For details, see REMOVAL OF OPERATOR'S CAB ASSEMBLY.
3. Remove control valve top cover, hydraulic tank undercover, and main pump undercover.
4. Open main pump side cover, then remove partitions (1) and (2).
5. Remove covers (3) and (4).
6. Remove air conditioner air suction port (5).



7. Disconnect drain hoses (6), (7), and (8).




8. Disconnect hydraulic oil filter inlet hose (9) and outlet hose (10).




020706

9. Disconnect hydraulic oil cooler return hose (11).
10. Disconnect drain hoses (12), (13), and (14).
11. Disconnect hydraulic oil level sensor connector (15) (CN-P09).




12. Remove main pump suction tube (16).
 - ★ A box wrench cannot be fitted on the center rear mount bolt, so disconnect both sides of tube (16) and offset them.



13. Remove mounting bolts, and lift off hydraulic tank assembly (17). ※ 1

 Hydraulic tank assembly: 230 kg



INSTALLATION OF HYDRAULIC TANK ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1

 Hydraulic tank mounting bolt:
277.04 ± 31.87 Nm (28.25 ± 3.25 kgm)

- **Refilling with oil (hydraulic tank)**
 - ★ Add oil through the oil filler to the specified level.
 - Run the engine to circulate the oil through the system. Then check the oil level again.
- **Bleeding air**
 - Bleed the air.
 - For details, see TESTING AND ADJUSTING, Bleeding air.



REMOVAL OF CONTROL PUMP ASSEMBLY

- ⚠ Lower the work equipment completely to the ground and stop the engine. Then loosen the oil filler cap slowly to release the pressure inside the hydraulic tank.
- ⚠ Disconnect the cable from the negative (-) terminal of the battery.
 - ★ Mark all the piping with tags to prevent mistakes when installing.
- 1. Remove hydraulic tank strainer, and using tool **S1**, stop oil.
 - ★ When not using tool **S1**, remove the drain plug, and drain the oil from the hydraulic tank and inside the system.



Hydraulic tank: Approx. **200 ℓ**

- 2. Remove control pump inlet tube (1).
- 3. Disconnect control pump outlet hoses (2) and (3).
- 4. Remove control pump assembly (4). ※ 1
 - ★ Remove only the bolts with a width across flats of 17 mm.



INSTALLATION OF CONTROL PUMP ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1


- ★ Align with the groove of coupling (5), then install.



Control pump mounting bolt:

66.19 ± 7.35 Nm (6.75 ± 0.75 kgm)

- **Refilling with oil (hydraulic tank)**
 - ★ Add oil through the oil filler to the specified level.
 - Run the engine to circulate the oil through the system. Then check the oil level again.



REMOVAL OF MAIN PUMP ASSEMBLY

- ⚠ Lower the work equipment completely to the ground and stop the engine. Then loosen the oil filler cap slowly to release the pressure inside the hydraulic tank.
- ⚠ Disconnect the cable from the negative (-) terminal of the battery.
 - ★ Mark all the piping with tags to prevent mistakes when installing.
- 1. Remove hydraulic tank strainer, and using tool **S1**, stop oil.
 - ★ When not using tool **S1**, remove the drain plug, and drain the oil from the hydraulic tank and inside the system.



Hydraulic tank: **Approx. 200 ℓ**

- 2. Remove main pump side cover and undercover, and open engine hood.

- 3. Drain oil from damper case.



Damper case: **Approx. 1.3 ℓ**

- 4. Remove main pump top cover (1), and partitions (2) and (3).

- 5. Disconnect TVC solenoid connectors (9) and (10) (CN-C04 and CN-C13).

★ There is a clamp for the front servo valve.

- 6. Disconnect main pump outlet hoses (11) and (12).





- 7. Disconnect pump case drain hose (13).

- 8. Disconnect rear pump servo valve hose (14).

- 9. Disconnect front pump servo valve hose (15).

- 10. Disconnect control pump outlet hoses (16) and (17).


- 11. Disconnect main pump inlet tube (18) and control pump inlet tube (19).



12. Sling main pump assembly (20), remove mounting bolts, then lift off.



Main pump assembly: **250 kg**



INSTALLATION OF MAIN PUMP ASSEMBLY

- Carry out installation in the reverse order to removal.



- Involute spline of main pump:
Anti-friction compound (LM-G)
- Mating surface of main pump case:
Gasket sealant (LG-6)

- Refilling with oil (damper case)**
 - ★ Add engine oil through the oil filler to the specified level. Run the engine, then stop the engine, wait for 15 minutes, and check the oil level again.
- Refilling with oil (hydraulic tank)**
 - ★ Add oil through the oil filler to the specified level.
Run the engine to circulate the oil through the system. Then check the oil level again.
- Bleeding air**
 - ★ Bleed the air.
For details, see TESTING AND ADJUSTING, Bleeding air.

020706


DISASSEMBLY OF MAIN PUMP ASSEMBLY

1. Pump assembly

Set pump assembly (1) to tool S3.


2. Hose

Remove hose (2), elbow, and tee.



3. Rear pump assembly

- 1) Sling rear pump assembly (3).
- 2) Remove 8 bolts at rear pump end, then remove rear pump assembly (3).
 - ★ Leave the end cap at the front end.
 - ★ Be careful not to drop the rear pump valve plate, cylinder block, piston assembly, or other parts.




• Disassembly of front pump assembly

4. Servo valve assembly

- 1) Remove servo valve assembly (4).
- 2) Disassembly of servo valve assembly

• TVC valve


- i) Remove solenoid assembly (5), then remove sleeve (6) and spool (7).
- ii) Remove seat (8), then remove springs (9) and (10).
- iii) Remove plug (11), then remove piston (12).
- iv) Remove locknut (13), then remove plug (14) and lever assembly (15).
- v) Remove nut (16) from lever assembly (15), then remove washer (17), bearing (18), pin (19), and lever (20).
- vi) Remove snap ring (21), then remove plug (22).



- **LS valve**
 - i) Remove locknut (23), then remove plug (24), seat (25), spring (26), and seat (27).
 - ★ Measure the dimension between the end face of locknut (23) and the end face of plug (24).
 - ii) Remove plug (28), then remove sleeve (29), piston (30), and spool (31).
- Remove filter (32), then remove spacer (33) and orifice (34).


5. Valve plate, end cap

- 1) Remove valve plate (36) from end cap (35).
- 2) Remove 8 mounting bolts, then remove end cap (35).
 - ★ If the valve plate is stuck to the end cap, be careful not to drop it.
 - ★ Measure protrusion **L** of maximum swash plate angle adjustment screw (37).
- 3) Remove valve plate (38) from end cap (35).



• Disassembly of end cap


- 1) Remove bearings (39) and (40) from end cap (35).
- 2) Remove coupling (41).



6. Cylinder block, piston assembly

Remove cylinder block and piston assembly (42) from pump case (43).


- ★ The cylinder block and piston assembly may come off separately, so be careful not to drop them.




020706

- **Disassembly of cylinder block, piston assembly**
Pull out piston assembly (45) from cylinder block (44), and remove retainer guide (46) and 3 preload pins (47).

★ When removing the piston assembly from the cylinder block, the preload pins may come out, so be careful not to lose them.




- **Disassembly of piston assembly**
Pull out piston (49) from retainer shoe (48).




• Disassembly of cylinder block

- 1) Set tool **S4** to cylinder block (44).
- 2) Hold bolt of tool **S4** with wrench, tighten nut to compress spring, and remove snap ring (50).
- 3) Loosen nut of tool **S4** slowly to release tension of spring (51), then remove tool **S4**.
- 4) Remove seat (52), spring (51), and seat (53) from cylinder block (44).
★ Check the assembly direction of seat (53).




7. Servo piston assembly


- 1) Remove mounting screws with tool **S5**, then remove cover (54). (Front pump only)




- 2) Remove plug (55), then remove spring (56).



- 3) Using bolt (6 mm), remove stopper (57).




- 4) Set tool **S6** in position, and assemble spacers ① to both ends of rod (58).
- 5) Move to side and loosen piston (59) so that width across flats of rocker cam comes off from width across flats of cradle.
★ Be careful not to let the bolt portion of tool **S6** come off the rod.
- 6) Remove piston (59), then remove rod (58).
★ Check the assembly direction of rod (58).




8. Shaft, cradle assembly

- 1) Remove rocker cam (60) from shaft and cradle assembly (61).





- 2) Remove 6 bolts, then remove shaft and cradle assembly (61) from front pump case (43).




• **Disassembly of shaft, cradle assembly**

- 1) Push cradle (63) with push tool ② to remove it from shaft (62). When removing, be careful to keep cradle (63) straight.
- 2) Remove snap ring (64), then remove washer (65).




- 3) Using push tool ③, remove bearing (66) from shaft (62).
 - ★ Bearing (66) divides into the flange ring and the bearing, so be careful not to lose either part.
 - ★ Check the installation direction of the bearing.



9. Disassembly of pump case


- 1) Loosen locknut (68) of minimum swash plate angle adjustment screw (67), and remove screw (67).
 - ★ Before loosening the locknut, measure dimension L between the end face of the case and the end face of the screw.
- 2) Rotate tool S3 90°, remove snap ring (69) from front pump case (43), then remove spacer (70).
- 3) Remove oil seal (71).



DISASSEMBLY AND ASSEMBLY**MAIN PUMP ASSEMBLY**

10. If above disassembly operation is not needed, and only oil seal is to be replaced, replace oil seal as follows.


- 1) Remove snap ring (69) and spacer (70).
- 2) Using bar ④ (hit end face with hammer), hit through to core of oil seal (71), then twist to remove.
 - ★ Hit at a point midway between the inside and outside circumference of the oil seal, and twist at two places on opposite sides (A and B in diagram) to remove.
 - ★ Be careful not to damage the shaft.



• **Disassembly of rear pump assembly**

11. **Rear pump assembly**
Set rear pump assembly (3) to tool S3.

12. **Control valve assembly**
Same operation as in Item 4.




13. **Control pump assembly**
Remove control pump assembly (72), then remove collar (73) and coupling (74).

14. **Cylinder block, piston assembly**
Same operation as in Item 6.


15. **Servo piston assembly**
Same operation as in Item 7.

16. **Shaft, cradle assembly**
Same operation as in Item 8.



17. **Disassembly of pump case**
Loosen locknut (76) of minimum swash plate angle adjustment screw (75), then remove screw (75).

- ★ Before loosening the locknut, measure the dimension between the end face of the locknut and the end face of the screw.



020706

ASSEMBLY OF MAIN PUMP ASSEMBLY

- ★ Clean all parts, remove all burrs, and check for dirt or damage. Coat the rotating and sliding surfaces of all parts with engine oil (EO10-CD) before installing.
Always check the following parts before assembling.

- i) Check contact of cradle and rocker cam (for details, see procedure for checking contact).
- ii) Check contact between cylinder block and valve plate (for details, see procedure for checking contact).
- iii) Check contact between valve plate and end cap (for details, see procedure for checking contact).

• Assembly of front pump assembly

1. Shaft, cradle assembly

• Assembly of shaft and cradle assembly

- 1) Assemble flange ring to shaft (62), then use tool S7 to press fit bearing (66).

 Press-fitting surface of bearing:
Grease (G2-LI)

- ★ When press fitting the bearing, push the end face of the bearing inner race with tool S7.

- 2) Assemble washer (65), and install snap ring (64).



• Method of selecting lock washer (65)

- i) After press fitting bearing (66) to shaft (62), assemble washer (65) (removed during disassembly).
- ii) Measure clearance dimension **a** between end face of assembled washer (65) and snap ring groove.

★ Clearance dimension **a**:
1.45 – 1.60 mm

- iii) If clearance "**a**" is not within above standard value, select washer from table below and assemble.


Washer Part No.	708-17-12750	708-17-12760	708-17-12770
Washer thickness (mm)	3.0	3.1	3.2




- 3) Using push tool ⑤, press fit cradle (63) to shaft (62) to make shaft and cradle assembly (61).

 Press-fitting surface of bearing:
Grease (G2-LI)

- ★ When press fitting the bearing, push the end face of the bearing outer race with push tool ⑤.




- 4) Set pump case (43) to tool S3-3.



- 5) Fit dowel pin and O-ring to bottom surface of inside of pump case (43), then install shaft and cradle assembly (61).


 **Cradle mounting bolt:**
110.3 ± 12.3 Nm (11.25 ± 1.25 kgm)

- ★ Check that there is no rising and that the pin does not fall out.
★ Be extremely careful that the O-ring does not come out or get caught.



2. Rocker cam

Assemble rocker cam (60) to shaft and cradle assembly (61).





3. Servo piston assembly

- 1) Assemble spherical portion of rod (58) to rocker cam.
 - ★ When assembling the rod, assemble with the spring seat surface facing in the direction of assembly of the spring.
- 2) Fit piston (59), set tool **S6** on opposite side from when loosening, set spacer ① on front end of rod, and tighten piston (59).
 - ★ Before tightening piston (59), move to the side so that the width across flats of the rocker cam comes out from the width across flats of the cradle. (This is to prevent damage to the rocker cam and cradle when tightening the piston.)

 Near  area of piston thread in diagram on right: **Coat with three drops of adhesive (Loctite 648)**

 **Piston:**
 $475.6 \pm 34.3 \text{ Nm}$ ($48.5 \pm 3.5 \text{ kgm}$)



4. Positioning minimum swash plate angle

- 1) Remove 2 dowel pins from servo valve assembly mounting surface.
- 2) Set tool **S8** in position.
- 3) Assemble O-ring and tighten screw (76) until it contacts piston (59).



 **Screw:**
 $12.3 \pm 2.5 \text{ Nm}$ ($1.25 \pm 0.25 \text{ kgm}$)

- 4) Tighten locknut (77) to hold screw (76) in position.

 **Locknut:**
 $254.9 \pm 29.4 \text{ Nm}$ ($26 \pm 3 \text{ kgm}$)

- ★ After completion of assembly, carry out a bench test to check the minimum flow.
- ★ Assemble the spring after measuring the rotating torque of the pump assembly.


- 5) Assemble backup ring and O-ring to stopper (57), and install to case.



5. Cylinder block, piston assembly

• Assembly of cylinder block


- 1) Assemble seat (53), spring (51), and seat (52) to cylinder block (44).
 - ★ Assemble with the tapered portion on the inside of seat (53) facing down.
- 2) Set tool **S4** to cylinder block (44).
- 3) Hold bolt of tool **S4** with wrench, tighten nut to compress spring (51), then install snap ring (50).
 - ★ Check that the snap ring is fitted securely in the groove.



- 4) Remove tool **S4**.


• Assembly of piston assembly

- 5) Assemble piston (49) to retainer shoe (48).




• Assembly of cylinder block and piston assembly

- 6) Assemble 3 preload pins (47) to cylinder block (44).
 - ★ To prevent the preload pins from coming out, coat the pins with grease (G2-LI).
- 7) Assemble retainer guide (46) to cylinder block (44), then install piston assembly (45) to make cylinder block and piston assembly (42).
 - ★ Align the spline for the cylinder block and retainer guide.



• Installation of cylinder block and piston assembly

- 8) Install cylinder block and piston assembly (42) to pump case (43).
 - ★ Before assembling the cylinder block and piston assembly, assemble the width across flats of the rocker cam to the cradle securely.



6. End cap

- 1) Using tool **S9**, assemble bearing (39) to end cap (35), then turn over end cap (35).

★ Press fit the bearing until it comes into contact with the other end.



Press-fitting surface of bearing:

Grease (G2-LI)

- 2) Assemble snap ring (78) to coupling (41), then assemble to end cap (35).

- 3) Using tool **S9**, press fit bearing (40) to end cap (35).

★ Press fit the bearing until it comes into contact with the other end.



Press-fitting surface of bearing:

Grease (G2-LI)

- 4) Install dowel pin to end cap (35).

7. Positioning maximum swash plate angle

- 1) Fit washer and locknut (79) to screw (37), then install to end cap (35).

- 2) Adjust so that protrusion from mating surface of case with end cap is as shown below.

★ Protrusion: 9.0 mm

- 3) Tighten locknut (79) to hold in position.

Locknut:

254.9 ± 29.4 Nm (26 ± 3 kgm)

8. End cap assembly

- 1) Assemble valve plate (38) to end cap (35).




★ Align the dowel pin and pin hole to install.

★ Check that there is no interference with the bearing and pin.

★ Check that the end cap and valve plate port holes are aligned.

★ Do not hit the valve plate or apply any impact when assembling.

(There is danger that this will damage the sliding surface or cause distortion.)




- 2) Assemble end cap assembly (35) to front pump case (43).

- ★ Support the coupling with the handle of a screwdriver, and align with the shaft spline to install.
- ★ Check that there is no rising and that the pin does not fall out.
- ★ Be extremely careful that the O-ring does not come out or get caught.


 Mating surface of pump case:
Gasket sealant (LG-7 or LG-5)

 Mounting bolt:
 $384.9 \pm 41.7 \text{ Nm}$ ($39.25 \pm 4.25 \text{ kgm}$)



9. Measuring rotating torque of pump assembly


- 1) Set tool **S10** to pump shaft.
- 2) Set torque wrench to tool **S10**, rotate shaft at low speed (3 – 5 sec/1 turn) and measure rotating torque.
 - ★ When checking the rotating torque, check that the shaft rotates smoothly without any variation.
 - Variation range:
Max. 2.9 Nm (0.3 kgm)
 - Rotating torque:
Max. 24.5 Nm (2.5 kgm)
 - ★ If there is any abnormality in the rotating torque, disassemble again and check.



10. Servo piston spring


- 1) Assemble spring (56).
- 2) Fit O-ring and install plug (55).

 Plug:
 $151.9 \pm 24.5 \text{ Nm}$ ($15.5 \pm 2.5 \text{ kgm}$)



- 3) Using tool **S5**, tighten mounting screws and install cover (54).

 Mounting screw:
 $30.9 \pm 3.4 \text{ Nm}$ ($3.15 \pm 0.35 \text{ kgm}$)



11. Servo valve assembly**1) Assembly of servo valve assembly****• LS valve**

- i) Assemble spool (31), piston (30), and sleeve (29) to body, then fit O-ring and install plug (28).

 **kgm** Plug (28):
 $110.3 \pm 12.3 \text{ Nm}$ ($11.25 \pm 1.25 \text{ kgm}$)

- ★ Check that the relative movements of the body and spool (31), and sleeve (29) and piston (30) are smooth.

- ii) Assemble seat (27), spring (26), and seat (25), then fit backup ring and O-ring and install plug (24).

- iii) Tighten locknut (23).

 **kgm** Locknut (23):
 $68.6 \pm 9.8 \text{ Nm}$ ($7 \pm 1 \text{ kgm}$)

- ★ Install so that the dimension between the end face of locknut (23) and the end face of plug (24) is the dimension measured during disassembly.

- iv) After completion of assembly, carry out a bench test of the performance and make final adjustment of plug (24).

• TVC valve


- i) Fit O-ring and assemble plug (22), then install snap ring (21).

- ii) Install pin (19), washer (17), bearing (18), and nut (16) to lever (20) to make lever assembly (15).

 **kgm** Nut (16):
 $10.8 \pm 0.98 \text{ Nm}$ ($1.1 \pm 0.1 \text{ kgm}$)

 Nut (16):
Thread tightener (Loctite 648)

- ★ Check that the movement of lever (20) and bearing (18) is smooth.




CLP00600

- iii) Fit O-ring to plug (14), then install to lever assembly (15) and body.

★ Tighten to a point where the tip of plug (14) is in contact with plug (22), then turn back at least 180° in the direction of loosening and move the mark to the position $\theta = 0$ in the diagram on the right.

★ If the position of the mark is between the $\theta = 180^\circ$ and 360° positions in the diagram on the right at the point where the tip of plug (14) contacts plug (22), turn back at least 1 turn to the temporary assembly position ($\theta = 0$).



- iv) Tighten locknut (13).

 **kgm** Locknut (13):
 $29.4 \pm 4.9 \text{ Nm}$ ($3 \pm 0.5 \text{ kgm}$)

★ Check that the movement of lever (20) and plug (22) and plug (14) is smooth.

- v) Assemble piston (12), then fit O-ring and install plug (11).

 **kgm** Plug (11):
 $11.3 \pm 1.5 \text{ Nm}$ ($1.15 \pm 0.15 \text{ kgm}$)

- vi) Assemble spool (7) to sleeve (6), then install together with seat (8), and springs (9) and (10) to body.

★ Check that the relative movement of sleeve (7) and spool (6) is smooth.

- vii) Install O-ring, then install solenoid assembly (5).


 **kgm** Solenoid assembly mounting bolt:
 $13.2 \pm 1.5 \text{ Nm}$ ($1.35 \pm 0.15 \text{ kgm}$)

 Mating surface of solenoid assembly:
Gasket sealant (LG-7 or LG-5 (Loctite 572/575))

- viii) Using tool **S11**, check that there is no leakage of oil or air from mating surface with solenoid assembly.

★ Air pressure : 0.5 MPa (5 kg/cm²)

- ix) After completion of assembly, carry out a bench test to check performance, and make final adjustment of plug (14).



- Assemble orifice (34), and install spacer (33), filter (32), and O-ring.

 **kgm** Orifice (34):

$9.8 \pm 1.9 \text{ Nm}$ ($1.0 \pm 0.2 \text{ kgm}$)

- 2) After completion of assembly, carry out bench test of servo valve assembly (4) as an individual part to check performance and carry out adjustment.
- 3) Fit O-ring and filter to servo valve assembly (4) and install to pump case.
 - ★ Install the filter so that the mesh end is at the front face end of the valve body.
 - ★ Be extremely careful that the O-ring and filter do not fall out.
 - ★ Tighten the mounting bolts gradually in turn on opposite sides.


 **kgm** Mounting bolt:

$66.2 \pm 7.4 \text{ Nm}$ ($6.75 \pm 0.75 \text{ kgm}$)



Mating surface of servo valve:

Gasket sealant (LG-7 or LG-5 (Loctite 572/575))



• Assembly of rear pump assembly

12. Shaft, cradle assembly

Same operation as in Item 1. (Set pump case to tool S3-4.)

- ★ Be careful not to mistake the dowel pin and control pump oil hole in the operation in Step 1-5).

13. Rocker cam

Same operation as in Item 2.

14. Servo piston assembly

Same operation as in Item 3.

15. Positioning minimum swash plate angle

Same operation as in Item 4.

16. Cylinder block, piston assembly

Same operation as in Item 5.

17. Positioning maximum swash plate angle

Same operation as in Item 7.

18. Servo piston spring

Same operation as in Item 10.

19. Servo valve assembly


Same operation as in Item 11.

20. Control pump assembly

- 1) Install collar (73).
- 2) Fit coupling (74) to drive shaft, fit O-ring and install control pump assembly (72).

 **kgm** Mounting bolt:
 $66.2 \pm 7.4 \text{ Nm}$ ($6.75 \pm 0.75 \text{ kgm}$)

 Mating surface of control pump:
Gasket sealant (LG-7 or LG-5)


**21. Rear pump assembly**

Assemble valve plate, dowel pin, and O-ring to end cap, sling rear pump assembly (3), then align with shaft spline and install.


- ★ When slinging, be careful not to drop the cylinder block, piston assembly, or other parts.

 Mating surface of pump case:
Gasket sealant (LG-7 or LG-5 (Loctite 572/575))


 **kgm** Mounting bolt:
 $384.9 \pm 41.7 \text{ Nm}$ ($39.25 \pm 4.25 \text{ kgm}$)

**22. Measuring rotating torque of pump assembly**

- 1) Set tool **S10** to pump shaft.
- 2) Set torque wrench to tool **S10**, rotate shaft at low speed (3 – 5 sec/1 turn) and measure rotating torque.
 - ★ When checking the rotating torque, check that the shaft rotates smoothly without any variation.
 - Variation range: Max. 2.9 Nm (0.3 kgm)
 - Rotating torque: Max. 4.9 Nm (5.0 kgm)
 - ★ If there is any abnormality in the rotating torque, disassemble again and check.

**23. Oil seal**

- 1) Check that there are no burrs or flashes at corners of shaft.
- 2) Using tool **S12**, press fit oil seal (72).
- 3) Assemble spacer (71), and install snap ring (70).




24. Hose

Install elbow, tee, and hose (2).

 **Hose: 24.5 ± 4.9 Nm (2.5 ± 0.5 kgm)**

25. Pump assembly

Remove pump assembly (1) from tool **S3**.



CHECKING CONTACT BETWEEN CYLINDER BLOCK AND VALVE PLATE, ROCKER CAM AND CRADLE, VALVE PLATE AND END CAP

1. Checking contact between cylinder block and valve plate

- ★ This check is unnecessary if both the cylinder block and valve plate are replacement parts (new parts).
- ★ This check applies if one of the parts is a replacement part or a restored part.

1) Make a centering tool for the cylinder block and valve plate.

- ★ The tool can be made from plastic, bakelite or any other soft material.

2) Remove all oil and grease from the parts to be checked.

- ★ Do not wipe with a cloth.

3) Set the tool in position, then paint the cylinder block with inspection paint.

- ★ Coat thinly with paint.



4) Push the valve plate with a force of 39 – 49 N (4 – 5 kg) against the cylinder block, turn the valve plate 90°, then turn it back to the original position. Repeat this process 2 or 3 times.

5) Remove the valve plate, transfer the contact surface to a tape, and check the contact surface.

- ★ The contact of the spherical surface of the valve plate and cylinder block must fulfill the conditions below and cover the whole circumference without any break.

- i) The contact at the seal portion (range from bottom to ϕ 101.5 mm) must be at least 80%.
- ii) The contact at the land portion (range from ϕ 101.5 mm to ϕ 128 mm) must be 20 – 80%.

	Seal portion	Land portion
Valve plate	Min. 80%	20 – 80 %
Cylinder block	Min. 80%	20 – 80 %



2. Checking contact between rocker cam and cradle

- ★ This check is unnecessary if both the rocker cam and cradle are replacement parts (new parts).
- ★ This check applies if one of the parts is a replacement part or a restored part.

1) Remove all oil and grease from the parts to be checked.

- ★ Do not wipe with a cloth.

2) Paint the cradle with inspection paint.

- ★ Coat thinly with paint.

3) Put the rocker cam on top, push with a force of 39 – 49 N (4 – 5 kg), and move it between the maximum swash plate angle and the position where it contacts the stopper. Repeat this process 2 or 3 times.

4) Remove the rocker cam, transfer the contact surface to a tape, and check the contact surface.

- ★ The standard for the contact surface is as given below.

i) Contact within central portion (36 – 50 mm) must be at least 90%.


ii) Contact in range between central portion (36 – 50 mm) and 67 mm must be 50 – 90%.

iii) Contact of area outside 67 mm width (outside) must be less than 50%.
(It is not permitted to have contact only at the outside and no contact at the center.)

[Reference]

If the contact is not within the standard value, and lapping is carried out, it must always be carried out for both parts together.


- ★ Parts with any scratches or damage must not be used.



3. Checking contact between valve plate and end cap


- ★ This check is unnecessary if both the valve plate and end cap are replacement parts (new parts).
- ★ This check applies if one of the parts is a replacement part or a restored part.
- ★ If the contact is defective, use a surface plate and correct by lapping.

- 1) Remove all oil and grease from the parts to be checked.
 - ★ Do not wipe with a cloth.
- 2) Paint the end cap with inspection paint.
 - ★ Coat thinly with paint.
- 3) Push the valve plate with a force of 39 – 49 N (4 – 5 kg) against the end cap, turn the valve plate 90°, then turn it back to the original position. Repeat this process 2 or 3 times.
- 4) Remove the valve plate, transfer the contact surface to a tape, and check the contact surface.
 - ★ The contact of the plane surface between the valve plate and end cap must cover at least 80% without any variation.
 - ★ For details of the operation, see the Parts Judgement Guide.



REMOVAL OF MAIN PUMP INPUT SHAFT OIL SEAL

1. Remove main pump assembly.
For details, see REMOVAL OF MAIN PUMP ASSEMBLY.
2. Remove snap ring (1), then remove spacer (2).
3. Lever up oil seal (3) with a screwdriver to remove.
★ When removing the oil seal, be extremely careful not to damage the shaft.



INSTALLATION OF MAIN PUMP INPUT SHAFT OIL SEAL


- Carry out installation in the reverse order to removal.

※ I

 Lip of oil seal: **Grease (G2-LI)**

 Coat the outside circumference of the oil seal with grease (G2-LI) thinly, then press fit.



- ★ Using tool **S2**, press fit oil seal (3).




REMOVAL OF CONTROL VALVE ASSEMBLY

- ⚠ Lower the work equipment completely to the ground and stop the engine. Then loosen the oil filler cap slowly to release the pressure inside the hydraulic tank.
- ⚠ Release the remaining pressure in the hydraulic circuit.
For details, see TESTING AND ADJUSTING, Releasing pressure in hydraulic circuit.
- ★ Make match marks before disconnecting the PPC circuit hoses.
- ★ Fit blind plugs in the disconnected hoses and tubes.


1. Open engine hood.
2. Remove control valve top cover.
3. Disconnect turbocharger outlet port hose (1), and remove inlet port hose (2).
4. Disconnect air cleaner clogging sensor hose (3).
5. Disconnect air cleaner assembly (4) together with bracket.
6. Disconnect wiring harness (5), and remove partition (6).



7. Disconnect 9 bottom PPC hoses (7).
8. Disconnect pump merge/divider solenoid hose (8).



9. Disconnect pressure sensor connectors (9) and (10) (CN-C08 and CN-C07).
10. Disconnect main pump outlet hoses (11) and (12).




DISASSEMBLY AND ASSEMBLY

CONTROL VALVE

11. Disconnect hoses (13), (14), (15), (16), (17), and (18).

- ★ Hose (13): For arm boost PPC
- Hoses (14) and (15): For R.H. straight travel
- Hoses (16) and (17): For L.H. straight travel
- Hose (18): For drain circuit




12. Disconnect hoses (19) and (20).

- ★ Hose (19): For drain circuit
- Hose (20): For high-pressure circuit

13. Remove elbows (21), (22), and (23).

14. Set hose mounts of elbows (24) and (25) facing down.


15. Disconnect control valve return hose (26).




16. Disconnect drain hose (27).

17. Disconnect 10 top PPC hoses (28).

18. Disconnect safety valve hose (29).



19. Disconnect high-pressure circuit hose (30) and LS pressure hoses (31).




020706


DISASSEMBLY AND ASSEMBLY

CONTROL VALVE

20. Disconnect swing motor suction hose (32).
21. Disconnect bucket hoses (33).
22. Disconnect 2 R.H. travel hoses (34).
23. Disconnect arm hoses (35).
24. Disconnect L.H. travel hoses (36).




25. Remove swing motor hoses (37).
26. Remove boom tubes (38) and (39).
27. Disconnect LS select valve hose (40).



28. Sling control valve assembly (41), then remove mounting bolts, and lift off control valve assembly.
 - ★ Move slightly to the front and pass through the bracket to lift off.



Control valve assembly: **260 kg**





INSTALLATION OF CONTROL VALVE ASSEMBLY

- Carry out installation in the reverse order to removal.
- **Refilling with oil (hydraulic tank)**
Add oil through the oil filler to the specified level.
Run the engine to circulate the oil through the system. Then check the oil level again.

020706

DISASSEMBLY OF CONTROL VALVE ASSEMBLY



- ★ The set pressure of the safety valve and arm counterbalance valve cannot be adjusted when they are installed on the machine, so do not disassemble.
- 1. Main relief valve, unload LS relief valve.**
 - 1) Remove main relief valve (1).
 - 2) Remove unload LS relief valve (2) and sleeve (3).
- 2. Safety-suction valve, suction valve.**
 - 1) Remove safety-suction valve (4).
 - 2) Remove suction valve (5).
 - 3) Remove plug (5a).
- 3. Pressure compensation valves**
 - ★ Before removing any pressure compensation valve, check and mark its mounting position.
 - 1) Remove arm Hi IN pressure compensation valve (6), bucket DUMP pressure compensation valve (7), R.H. travel REVERSE pressure compensation valve (8), boom LOWER pressure compensation valve (9), right swing pressure compensation valve (10), L.H. travel REVERSE pressure compensation valve (11), and arm IN pressure compensation valve (12).
 - ★ After removing the pressure compensation valves, remove check valve (13) from each pressure compensation valve mount.
 - 2) Remove boom Hi RAISE pressure compensation valve (14), bucket CURL pressure compensation valve (15), R.H. travel FORWARD pressure compensation valve (16), boom RAISE pressure compensation valve (17), left swing pressure compensation valve (18), L.H. travel FORWARD pressure compensation valve (19), and arm OUT pressure compensation valve (20).
 - ★ After removing the pressure compensation valves, remove check valve (21) from each pressure compensation valve mount.
- 4. LS select valve.**
 - Remove LS select valve (22).

5. LS shuttle valves, pump merge/divider valve, regeneration valve, block.


- 1) Remove LS shuttle valves (23) and (24).
- 2) Remove pump merge/divider valve (25), then remove spring (26) and valve (27).
- 3) Remove regeneration valve (28), then remove spring (26) and valve (27).
- 4) Remove block (29).

6. Boom Hi, arm Hi control valves.

• **Arm Hi control valve**

★ Mark with tags to prevent mistakes in the mounting position when assembling the springs and spools.


- 1) Remove case (30), then pull out spool assembly (31) to position shown in diagram on right.
- 2) To prevent damage to spool assembly (31), hold position ① shown in diagram on right with a wrench (width across flats: 24mm), remove plug (32), then disassemble into retainer (33), springs (34a) and (34b), retainer (35), and spool (36).



• **Boom Hi control valve**

★ Mark with tags to prevent mistakes in the mounting position when assembling the springs and spools.

- 3) Remove case (37), then remove spring (38) and plate (39).
- 4) To prevent damage to spool assembly (40), hold position ② shown in diagram on right with a wrench (width across flats: 24mm), remove plug (41), then remove valve.
- 5) Remove seal (43) from valve (42), then remove seal (45) from spool (44).



7. Swing, boom, bucket control valves.

- ★ Mark with tags to prevent mistakes in the mounting position when assembling the springs and spool assembly.
- ★ Do not disassemble the spool assembly.
- 1) Remove case (46), then remove spring (47) and retainer (48).
- 2) Remove spool assembly (49).
- 3) Remove case (50), then remove spring (51) and retainer (52).

8. L.H. travel, R.H. travel control valves

- ★ Mark with tags to prevent mistakes in the mounting position when assembling the springs and spool assembly.
- ★ Do not disassemble the spool assembly.
- 1) Remove case (53), then remove spring (54) and retainer (55).
- 2) Remove spool assembly (56).
- 3) Remove case (57), spring (58), and retainer (59).



9. Arm control valve

- ★ Mark with tags to prevent mistakes in the mounting position when assembling the springs and spool assembly.
- ★ Do not disassemble the spool assembly.
- 1) Remove plug (60), then remove valve (61).
- 2) Remove case (62), then remove springs (63) and (64), and retainer (65).
- 3) Remove spool assembly (66).
- 4) Remove case (67), then remove spring (68) and retainer (69).

10. Covers

Remove covers (71) and (72), and valve (73) from valve body (70).

ASSEMBLY OF CONTROL VALVE ASSEMBLY



- ★ Check the spools and valves for dirt, damage, or burrs. Coat the sliding surfaces of all parts with engine oil before installing.


1. Covers

Install valve (73), and covers (72) and (71) to valve body (70).

- ★ Check that there is no damage to the O-ring, then install securely to the mating surface of the cover and valve.
- ★ Tighten the mounting bolts of covers (72) and (71) in the order shown in the diagram on the right.

 Cover mounting bolt:

166.7 ± 9.8 Nm (17 ± 1 kgm)



CDP00544

2. Arm control valve spool

- ★ Check the mounting position of the springs and spool assembly before installing.
- 1) Assemble spool assembly (66) to valve body (70), and fit retainer (69) and spring (68), then fit O-ring to case (61) and install.
- 2) Fit retainer (65), and springs (64) and (63) to spool assembly (66), then fit O-ring to case (62) and install.
- 3) Assemble valve (61), and install plug (60).
- 4) Tighten mounting bolts of cases (67) and (62) to specified torque.

 Case mounting bolt:

30.89 ± 3.43 Nm (3.15 ± 0.35 kgm)

- 5) Tighten plug (60) to specified torque.

 Plug:

107.9 ± 14.7 Nm (11 ± 1.5 kgm)

3. L.H. travel, R.H. travel control valves

- ★ Check the mounting position of the spring and spool assembly before installing.
- 1) Assemble spool assembly (56) to valve body (70), assemble retainer (59) and spring (58), then fit O-ring to case (57) and install.
- 2) Assemble retainer (55) and spring (54) to spool, then fit O-ring to case (53) and install.
- 3) Tighten cases (57) and (53) to specified torque.

 Case mounting bolt:

30.89 ± 3.43 Nm (3.15 ± 0.35 kgm)

4. Swing, boom, bucket control valve spools

- ★ Check the mounting position of the springs and spool assembly before installing.

- 1) Assemble spool assembly (49) to valve body (70).
- 2) Assemble retainer (52) and spring (51), then fit O-ring to case (50) and install.
- 3) Assemble retainer (48) and spring (47) to spool, then fit O-ring to case (46) and install.
- 4) Tighten mounting bolts of cases (50) and (46) to specified torque.

 **Case mounting bolt:**

$30.89 \pm 3.43 \text{ Nm}$ ($3.15 \pm 0.35 \text{ kgm}$)

5. Boom Hi, arm Hi control valve spools

- **Boom Hi control valve spool**

- ★ Check the mounting position of the spring and spool assembly before installing.

- 1) Fit seal (45) to spool (44), and install seal (43) to valve (42).
- 2) Assemble spool (44) to position shown in diagram on right, install plate (39) and valve (42) to spool (44), then hold position ⑥ shown in diagram on right with a wrench (width across flats: 24mm), and tighten plug (41).


 **Plug:**

$13.24 \pm 1.47 \text{ Nm}$ ($1.35 \pm 0.15 \text{ kgm}$)

- 3) Push spool assembly (40) into body, fit spring (38), then fit O-ring to case (37) and install.

 **Case mounting bolt:**

$30.89 \pm 3.43 \text{ Nm}$ ($3.15 \pm 0.35 \text{ kgm}$)




- **Arm Hi control valve spool**

- ★ Check the mounting position of the spring and spool assembly before installing.

- 1) Assemble spool (31) to position shown in diagram on right, install retainer (35), springs (34a) and (34b), and retainer (33), then install plug (32).
- 2) Hold spool (31) at position ① shown in diagram on right with a wrench (width across flats: 24mm), and tighten plug (32).

 **Plug:**

$17.16 \pm 2.45 \text{ Nm}$ ($1.75 \pm 0.25 \text{ kgm}$)



DISASSEMBLY AND ASSEMBLY**CONTROL VALVE**

- 3) Push spool assembly (31) into body, then fit O-ring to case (30) and install.

 Case mounting bolt:
 $30.89 \pm 3.43 \text{ Nm}$ ($3.15 \pm 0.35 \text{ kgm}$)

6. LS shuttle valve, pump merge/divider valve, regeneration valve, block.

- 1) Install block (29).

 Block mounting bolt:
 $30.89 \pm 3.43 \text{ Nm}$ ($3.15 \pm 0.35 \text{ kgm}$)

- 2) Assemble valve (27) and spring (26) to valve body (70), fit O-ring to regeneration valve (28), and install.

 Valve mounting bolt:
 $66.19 \pm 7.35 \text{ Nm}$ ($6.75 \pm 0.75 \text{ kgm}$)

- 3) Assemble valve (27) and spring (26) to valve body (70), and install pump merge/divider valve (25).

 Mounting bolt:
 $166.7 \pm 9.8 \text{ Nm}$ ($17 \pm 1 \text{ kgm}$)

- ★ Tighten the mounting bolts of the pump merge/divider valve in the order shown in the diagram on the right.

- 4) Install LS shuttle valves (24) and (23).

 Mounting bolt:
 $66.19 \pm 7.35 \text{ Nm}$ ($6.75 \pm 0.75 \text{ kgm}$)

7. LS select valve




Install LS select valve (22).

 LS select valve:
 $127.5 \pm 19.6 \text{ Nm}$ ($13 \pm 2 \text{ kgm}$)

8. Pressure compensation valves

- ★ Check the marks made on each pressure compensation valve during disassembly, and install in the correct position.

- 1) Before installing pressure compensation valves below, install check valves (21) and (13).
- 2) Install arm OUT pressure compensation valve (20), L.H. travel FORWARD pressure compensation valve (19), left swing pressure compensation valve (18), boom LOWER pressure compensation valve (17), R.H. travel FORWARD pressure compensation valve (16), bucket CURL pressure compensation valve (15), and boom Hi RAISE pressure compensation valve (14).



020706

- 3) Install arm IN pressure compensation valve (12), L.H. travel REVERSE pressure compensation valve (11), right swing pressure compensation valve (10), boom LOWER pressure compensation valve (9), R.H. travel REVERSE pressure compensation valve (8), bucket DUMP pressure compensation valve (7), and arm Hi IN pressure compensation valve (6).

 **kgm** Pressure compensation valve:
392.3 ± 19.6 Nm (40 ± 2 kgm)


9. Safety-suction valve, suction valve

- 1) Fit O-ring and install suction valve (5).
 **kgm** Suction valve:
147.1 ± 9.8 Nm (15 ± 1 kgm)
- 2) Fit O-ring and install safety-suction valve (4).
 **kgm** Safety-suction valve:
147.1 ± 9.8 Nm (15 ± 1 kgm)
- 3) Install plug (5a).
Plug: 147.1 ± 9.8 Nm (15 ± 1 kgm)

10. Main relief valve, unload LS relief valve

- 1) Fit O-ring and install sleeve (3).
 **kgm** Sleeve:
85.80 ± 7.35 Nm (8.75 ± 0.75 kgm)
- 2) Fit O-ring and install unload LS relief valve (2).
 **kgm** Unload LS relief valve:
166.7 ± 19.6 Nm (17 ± 2 kgm)
- 3) Fit O-ring and install main relief valve (1).
 **kgm** Main relief valve:
53.9 ± 4.9 Nm (5.5 ± 0.5 kgm)

DISASSEMBLY OF PUMP MERGE/DIVIDER VALVE ASSEMBLY




1. Remove plug (2) from valve body (1), then remove spring (3) and spool (4).
2. Remove plate (5).
3. Remove plug (6), then remove spring (7) and spool (8).
4. Remove plug (9).
- ★ After disassembling, if there is any abnormality in body (1) or spools (4) or (8), replace the whole pump merge/divider valve assembly.

ASSEMBLY OF PUMP MERGE/DIVIDER VALVE ASSEMBLY

- Before assembling, coat the sliding surface with engine oil.
1. Fit O-ring to plug (9) and install to valve body (1).
 Plug (9): **39.2 ± 5.9 Nm (4.0 ± 0.6 kgm)**
 2. Assemble spool (8) and spring (7), then fit O-ring to plug (6) and install.
 Plug (6): **39.2 ± 5.9 Nm (4.0 ± 0.6 kgm)**
 3. Fit O-ring to plate (5) and install valve body.
 4. Assemble spool (4) and spring (3), then fit O-ring to plug (2) and install.
 Plug (2):
152.0 ± 24.5 Nm (15.5 ± 2.5 kgm)

DISASSEMBLY OF PRESSURE COMPENSATION VALVE ASSEMBLY



CEP00548

- The structure of the parts for pressure compensation valves A – I is the same, but the part numbers for the component parts is different, so be careful when assembling.
- 1. Remove piston sub-assembly (2) and piston (3) from sleeve (1), then remove seal (4).
 - ★ Sub-piston assembly (2) is assembled to pressure compensation valves A-C, E-I, and piston (3) is assembled to pressure compensation valves D.
- 2. Remove spring (5), then remove ring (6) and O-rings (7) and (8) from sleeve (1).
 - ★ After disassembling, if there is any abnormality in sleeve (1), seal (4), piston sub-assembly (2), or piston (3), replace the whole pressure compensation valve assembly.

Pressure compensation valves

- A: Arm IN Hi
- B: Boom RAISE Hi
- C: Boom LOWER
- D: R.H. travel REVERSE, L.H. travel REVERSE
R.H. travel FORWARD, L.H. travel FORWARD
- E: Boom RAISE
- F: Arm OUT
- G: Bucket CURL
- H: Arm IN
- I: Right swing, left swing, bucket dump


ASSEMBLY OF PRESSURE COMPENSATION VALVE ASSEMBLY

- Before assembling, coat the sliding surface with engine oil.
- 1. Install O-rings (8) and (7) and ring (6) to sleeve (1).
- 2. Assemble spring (5), then assemble seal (4) to piston sub-assembly (2) and piston (3), and install to sleeve.

REMOVAL OF SERVO VALVE ASSEMBLY FOR FRONT PUMP

- ⚠ Disconnect the cable from the negative (–) terminal of the battery.
- ⚠ Loosen the oil filler cap slowly to release the pressure inside the hydraulic tank.
- 1. Disconnect TVC solenoid connector (1) (CN-C13).
- 2. Disconnect clamp (2).
- 3. Disconnect LS-EPC hose (3), LS pressure hose (4), and pump circuit pressure hose (5).
- ★ Fit blind plugs in the disconnected hoses.
- 4. Remove servo valve assembly (6) for front pump.

※ I



INSTALLATION OF SERVO VALVE ASSEMBLY FOR FRONT PUMP

- Carry out installation in the reverse order to removal.

※ I

- ★ Be careful not to let the O-ring or filter fall out when installing.
- ★ Tighten the mounting bolts gradually on opposite sides in turn.


 **Servo valve mounting bolt:**
66.19 ± 7.35 Nm (6.75 ± 0.75 kgm)

- ★ Check the performance of the work equipment, travel, and swing.
For details, see TESTING AND ADJUSTING.
- **Refilling with oil (hydraulic tank)**
 - ★ Add oil through the oil filler to the specified level.
Run the engine to circulate the oil through the system. Then check the oil level again.

REMOVAL OF SERVO VALVE ASSEMBLY FOR REAR PUMP

- ⚠ Disconnect the cable from the negative (-) terminal of the battery.
- ⚠ Loosen the oil filler cap slowly to release the pressure inside the hydraulic tank.
- 1. Disconnect TVC solenoid connector (1) (CN-C04).
- 2. Disconnect connector bracket (2) from servo valve.
- 3. Disconnect LS-EPC hoses (3) and (4), LS pressure hose (5), and pump circuit pressure hose (6).
- Fit blind plugs in the disconnected hoses.
- 4. Remove servo valve assembly (7) for rear pump.

※ I



INSTALLATION OF SERVO VALVE ASSEMBLY FOR REAR PUMP

- Carry out installation in the reverse order to removal.

※ I


- ★ Be careful not to let the O-ring or filter fall out when installing.
- ★ Tighten the mounting bolts gradually on opposite sides in turn.

 **Servo valve mounting bolt:**
66.19 ± 7.35 Nm (6.75 ± 0.75 kgm)

- ★ Check the performance of the work equipment, travel, and swing.
For details, see TESTING AND ADJUSTING.
- **Refilling with oil (hydraulic tank)**
 - ★ Add oil through the oil filler to the specified level.
Run the engine to circulate the oil through the system. Then check the oil level again.

REMOVAL OF LS-EPC SOLENOID VALVE ASSEMBLY

- ⚠ Disconnect the cable from the negative (-) terminal of the battery.
- ⚠ Loosen the hydraulic tank oil filler cap slowly to release the pressure inside the hydraulic tank.
- 1. Open main pump side cover.
- 2. Disconnect wiring connector (CN-C10).
- 3. Disconnect hoses (1), (2), (3), and (4).
 - ★ Fit blind plugs in the disconnected hoses.
- 4. Remove LS-EPC solenoid valve assembly (5).





INSTALLATION OF LS-EPC SOLENOID VALVE ASSEMBLY

- Carry out installation in the reverse order to removal.

REMOVAL OF SOLENOID VALVE ASSEMBLY

- ⚠ Disconnect the cable from the negative (–) terminal of the battery.
 - ⚠ Loosen the hydraulic tank oil filler cap slowly to release the pressure inside the hydraulic tank.
 - ★ Make match marks on the hoses and at the male and female ends of the connectors.
 - 1. Remove 5 solenoid wiring connectors (1) from clip and disconnect.
 - 2. Disconnect hoses (2) and (3) installed to bottom of valve.
 - 3. Disconnect valve hoses (4).
 - 4. Remove mounting bolts, then remove solenoid valve assembly (5).
- When removing solenoid valve as an individual part.
 - 1) If mounting nut (6) is removed, only coil assembly needs to be removed. ※ 1
 - 2) When washing valve, loosen mounting nut (7) and remove. ※ 2




INSTALLATION OF SOLENOID VALVE ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1  **kgm** Coil mounting nut (6):
 $7.85 \pm 0.98 \text{ Nm}$ ($0.8 \pm 0.1 \text{ kgm}$)



※ 2  **kgm** Valve mounting nut (7):
 $50.99 \pm 3.43 \text{ Nm}$ ($5.2 \pm 0.35 \text{ kgm}$)



REMOVAL OF WORK EQUIPMENT PPC VALVE ASSEMBLY

⚠ Lower the work equipment completely to the ground and stop the engine. Then loosen the oil filler cap slowly to release the pressure inside the hydraulic tank.

1. Remove case.
For details, see REMOVAL OF CONTROL STAND CASE.
2. Disconnect wiring connector (1).
3. Remove joint bolt (2), and disconnect hose (3).
★ Make match marks on the hoses. ※ 1
4. Remove mounting bolts, raise PPC valve assembly (4), then disconnect hoses (5) and (6), and remove. ※ 2



INSTALLATION OF WORK EQUIPMENT, PPC VALVE ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1

 **kgm** Hose mount joint bolt:
29.4 ± 4.9 Nm (3.0 ± 0.5 kgm)


※ 2

 **kgm** Hose mount joint bolt:
39.2 ± 4.9 Nm (4.0 ± 0.5 kgm)

- ★ If there is excessive play in the control levers, adjust the PPC valve.
For details, see TESTING AND ADJUSTING, Adjusting PPC valve.

DISASSEMBLY OF WORK EQUIPMENT PPC VALVE ASSEMBLY

1. Remove nut (1), then remove disc (2) and boot (3).
2. Remove bolts, then remove plate (5).
★ Do not remove joint (4) unless it is to be replaced.
3. Remove seal (6) and collar (7).
4. Pull out piston (8), and remove retainer (9), springs (10) and (11), and shim (12).
★ Spring (10) consists of two springs each of two types with different installed loads, so check the mounting position (hydraulic port) and mark with tags to prevent mistakes when installing.
5. Pull out valve (13) from body (14).



020706

ASSEMBLY OF WORK EQUIPMENT PPC VALVE ASSEMBLY

1. Assemble valve (13) to body (14).
2. Assemble shim (12) and spring (11) to valve (13).
 - ★ When assembling spring (11), set the end with the small coil diameter (inside diameter) at shim (12) end.
3. Assemble spring (10), retainer (9), and piston (8).
 - ★ The number of loops in the coil for spring (10) is different for each of the hydraulic ports below, so be careful when installing.

Position of port	Free length of spring (mm)
P1, P2	44.4
P3, P4	42.4

- ★ The position of each port is marked at the bottom of the valve body.

 Piston: **Grease (G2-LI)**

- ★ When assembling piston (8), coat the outside of the piston and the inside of the hole in the body with grease.

4. Fit O-ring to collar (7) and assemble in body (14), then install seal (6).

5. Install plate (5).

 Mounting bolt:

$13.24 \pm 1.47 \text{ Nm}$ ($1.35 \pm 0.15 \text{ kgm}$)

6. Install joint (4).

 Sliding portion of joint: **Grease (G2-LI)**

 Female thread of body:

Thread tightener (LT-2)

- ★ Coat two places on the female thread with one drop of Loctite each as shown in the diagram on the right.

 Joint: **$44.1 \pm 4.9 \text{ Nm}$ ($4.5 \pm 0.5 \text{ kgm}$)**


- ★ Keep strictly to the tightening torque.

7. Assemble boot (3) and disc (2), and tighten with nut (1).

 Nut: **$112.8 \pm 14.7 \text{ Nm}$ ($11.5 \pm 1.5 \text{ kgm}$)**

- ★ After assembling the disc, adjust the height of the disc.

For details, see TESTING AND ADJUSTING, Adjusting PPC valve.







CEP00425

REMOVAL OF TRAVEL PPC VALVE ASSEMBLY

⚠ Lower the work equipment completely to the ground and stop the engine. Then loosen the oil filler cap slowly to release the pressure inside the hydraulic tank.

1. Remove travel PPC valve undercover.
2. Remove floor mat.
3. Remove pedals (1) and levers (2).
4. Remove cover (3). ※ 1
5. Remove covers (4), then remove springs (5).
6. Disconnect 6 PPC hoses (7), and remove travel PPC valve assembly (8). ※ 2



INSTALLATION OF TRAVEL PPC VALVE ASSEMBLY

- Carry out installation in the reverse order to removal.


※ 1  **kgm** Cover mounting bolt:
 $19.6 \pm 1.9 \text{ Nm}$ ($2.0 \pm 0.2 \text{ kgm}$)

※ 2  **kgm** Hose mounting joint bolt
(width across flats: 30mm):
 $39.2 \pm 4.9 \text{ Nm}$ ($4.0 \pm 0.5 \text{ kgm}$)

 **kgm** Hose mounting joint bolt
(width across flats: 22mm):
 $29.4 \pm 4.9 \text{ Nm}$ ($3.0 \pm 0.5 \text{ kgm}$)

DISASSEMBLY OF TRAVEL PPC VALVE ASSEMBLY


1. Remove screw (1), then remove lever (2).
2. Remove mounting bolts (3), then remove case and shaft assembly (4).
3. Remove mounting bolts (5), then remove plate (6) together with damper assembly (7).
★ Check the thickness and mounting position of washer (18).
4. Remove mounting bolts (8), then remove damper assembly (7) from plate (6).
5. Remove seal (9) and collar (10).
6. Pull out piston (11), and remove retainer (12), springs (13) and (14), and shims (15).
★ Check the number and thickness of shims (15) for each mounting position, and keep in a safe place.
7. Pull out valve (16) from body (17).



CEP00533

ASSEMBLY OF TRAVEL PPC VALVE ASSEMBLY

1. Assemble valve (16) in body (17).
2. Assemble shim (15) and spring (14) to valve (16).
 - ★ Assemble the same number and thickness of shim (15) as was removed during disassembly.
Standard shim thickness: 0.3 mm
 - ★ Spring (14) is not symmetrical at the top and bottom, so assemble with the small coil diameter (inside diameter) at the shim end.
3. Assemble spring (13), retainer (12), and piston (11).
 -  Outside circumference of piston, body hole: **Grease (G2- LI)**
4. Fit O-ring (10) and collar (9) and assemble in body (17), then install seal (9).
5. Install damper assembly (7) to plate (6), then tighten mounting bolts (8).
 -  Mounting bolt: **Thread tightener (LT-2)**
 -  Mounting bolt: **4.41 ± 0.49 Nm (0.45 ± 0.05 kgm)**
6. Install plate (6) and damper assembly (7) as one unit, then tighten mounting bolts (5).
 - ★ Temporarily assemble standard washer (1.6 mm) for washer (18).
After completing the assembly, measure the difference in the angle when the left and right levers are operated fully. If the angle is greater than 0.7°, change the thickness of washer (18) to make the difference less than 0.7°.
 - ★ Washer thickness: 1.0, 1.3, 1.6 mm
 - ★ If the washer is thinner by 0.3 mm, the angle of the full stroke is 0.39° greater.
 -  Mounting bolt: **30.89 ± 3.43 Nm (3.15 ± 0.35 kgm)**
7. Install case and shaft assembly (4), then tighten mounting bolts (3).
 -  Rocking portion of shaft, contact portion of lever and piston: **Grease (G2-LI)**
 -  Mounting bolt: **27.95 ± 3.43 Nm (2.85 ± 0.35 kgm)**
8. Install lever (2), then tighten screw (1).
 -  Rocking portion of lever pin and plate: **Grease (G2-LI)**
 -  Screw: **8.8 ± 0.98 Nm (0.9 ± 0.1 kgm)**



CEP00533

020706



REMOVAL OF PPC SHUTTLE VALVE ASSEMBLY

- ⚠ Lower the work equipment completely to the ground and stop the engine. Then loosen the oil filler cap slowly to release the pressure inside the hydraulic tank.
- ⚠ Disconnect the cable from the negative (-) terminal of the battery.
- ★ Make match marks at the male and female ends of the oil pressure switch connectors.
- ★ Before disconnecting any hoses, check the distinguishing tape stuck to the hose, or make match marks.

1. Disconnect 8 oil pressure switch connectors (1).


2. Disconnect 12 PPC hoses (2).

※ 1




3. Disconnect 15 control valve hoses (3) (quick joint connection).

※ 1




4. Disconnect 4 straight-travel hoses (4).

- ★ The elbows on the front two hoses are long, so hold the elbow with a wrench when disconnecting the hoses.



5. Disconnect clamp (5).
6. Remove mounting bolts, then remove PPC shuttle valve assembly (6).



INSTALLATION OF PPC SHUTTLE VALVE ASSEMBLY


- Carry out installation in the reverse order to removal.

※ 1

- Check that the quick joint does not come out when the hose is pulled.
- **Refilling with oil (hydraulic tank)**
 - ★ Add oil through the oil filler to the specified level.
Run the engine to circulate the oil through the system. Then check the oil level again.

020706

DISASSEMBLY OF PPC SHUTTLE VALVE ASSEMBLY



SDP00610

1. Disconnection of valve

Remove mounting bolts (1), and disconnect shuttle valve assembly (2), travel junction valve assembly (3) and plate (4).


2. Disassembly of shuttle valve assembly

- 1) Remove 8 oil pressure switches (5).
 - 2) Remove 2 slow return valves (6).
 - 3) Remove shuttle valve (7).
 - 4) Remove plugs (8), then remove balls (9).
- ★ There are 6 plugs and 6 balls.

3. Disassembly of travel junction valve assembly

- 1) Remove 2 each of plug (10), spring (11), and retainer (12).
- 2) Remove spool (13).
- 3) Remove 2 plugs (14).

ASSEMBLY OF PPC SHUTTLE VALVE ASSEMBLY



SDP00610

1. Assembly of travel junction valve assembly.

- 1) Fit O-ring and install 2 plugs (14).

Plug:

$17.16 \pm 2.45 \text{ Nm}$ ($1.75 \pm 0.25 \text{ kgm}$)

- 2) Assemble spool (13), and install 2 retainers (12) and springs (11).
- 3) Fit O-ring and install 2 plugs (10).

Plug:

$107.9 \pm 14.7 \text{ Nm}$ ($11.0 \pm 1.5 \text{ kgm}$)

2. Assembly of shuttle valve assembly

- 1) Fit O-ring and assemble balls (9), then install plugs (8).

★ There are 6 plugs and 6 balls.

Plug:

$34.3 \pm 4.9 \text{ Nm}$ ($3.5 \pm 0.5 \text{ kgm}$)

- 2) Fit O-ring and install shuttle valve (7).
 - ★ If the shuttle valve has been disassembled, be careful of the direction of installation of the poppet when assembling.
- 3) Fit O-ring and install 2 slow return valves (6).
 - ★ If the slow return valve has been disassembled, be careful of the direction of installation of the poppet when assembling.

- 4) Install 8 oil pressure switches (5).

3. Connection of valve

Fit O-ring and assemble shuttle valve assembly (2), travel junction valve assembly (3) and plate (4), then tighten mounting bolts (1).

Mounting bolt:


$66.19 \pm 7.35 \text{ Nm}$ ($6.75 \pm 0.75 \text{ kgm}$)

020706

REMOVAL OF BOOM LOCK VALVE ASSEMBLY

⚠ Lower the work equipment completely to the ground and stop the engine. Then loosen the oil filler cap slowly to release the pressure inside the hydraulic tank.

1. Disconnect drain hose (1) and PPC hose (2).
★ Install blind plugs in the disconnected hoses.
2. Disconnect control valve tube (3) and cylinder hoses (4).
★ Install blind plugs in the disconnected hoses.
3. Remove mounting bolts (bottom of valve), then remove boom lock valve assembly (5).



INSTALLATION OF BOOM LOCK VALVE ASSEMBLY

- Carry out installation in the reverse order to removal.
- **Refilling with oil**
 - ★ Add oil through the oil filler to the specified level.
Run the engine to circulate the oil through the system. Then check the oil level again.
- **Bleeding air**
 - ★ Bleed the air.
For details, see TESTING AND ADJUSTING, Bleeding air.

DISASSEMBLY OF BOOM LOCK VALVE ASSEMBLY

1. Remove safety valve assembly (1).
★ The safety valve assembly cannot be adjusted when it is mounted on the machine, so do not disassemble it.
2. Remove body (2), then remove spring (3) and check valve (4).
3. Remove plug (5), then remove spacer (6), spring (7), seat (8), and spool (9).

ASSEMBLY OF BOOM LOCK VALVE ASSEMBLY

- ★ Coat the sliding parts with engine oil before assembling.

1. Assemble spool (9), seat (8), spring (7), and washer (6) to body (2), then fit O-ring and install plug (5).


 Plug: $39.2 \pm 4.9 \text{ Nm}$ ($4.0 \pm 0.5 \text{ kgm}$)

2. Assemble check valve (4) and spring (3) to body (10), then fit O-ring and install body (2).

3. Fit O-ring and install safety valve assembly (1).

 Safety valve:

$225.6 \pm 9.8 \text{ Nm}$ ($23 \pm 1 \text{ kgm}$)






020706

REMOVAL OF BOOM CYLINDER ASSEMBLY

⚠ Extend the arm and bucket fully, lower the work equipment completely to the ground, and put the safety lock lever in the LOCK position.

1. Disconnect grease hose (1).
2. Sling boom cylinder assembly (2), and remove lock bolt (3). ※ 1
3. Remove plate (4), then remove head pin (5). ※ 2
 - ★ There are shims installed, so check the number and thickness, and keep in a safe place.
4. Start engine, and retract piston rod, then tie piston rod with wire to prevent it from coming out.
 - ★ Set stand ① under the cylinder assembly, and adjust the position for slinging the cylinder assembly.
 - ⚠ Release the remaining pressure in the hydraulic circuit.
For details, see TESTING AND ADJUSTING, Releasing remaining pressure in hydraulic circuit.
5. Disconnect hoses (6).
6. Remove plate, then using forcing screws ②, remove bottom pin (7), and remove boom cylinder assembly (2). ※ 3
 - ★ There are shims installed, so check the number and thickness, and keep in a safe place.

 Boom cylinder assembly: **300 kg**



INSTALLATION OF BOOM CYLINDER ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1

- ★ When tightening the locknut, tighten so that the clearance between the plate and nut is 0.5 – 1.5 mm.

※ 2

- Inside surface of bushing when assembling pin: **Anti-friction compound (LM-P)**
Greasing after assembling pin:

Grease (LM-G)

- ⚠ When aligning the position of the pin hole, never insert your fingers in the pin hole.
- ★ Adjust the shim thickness so that the clearance between the end face of the rod of cylinder (2) and plate (4) is less than 1.0 mm.
 - Standard shim thickness:
1.0 mm, 1.5 mm




※ 3

- Inside surface of bushing when assembling pin: **Anti-friction compound (LM-P)**
Greasing after assembling pin:

Grease (LM-G)

- ⚠ When aligning the position of the pin hole, never insert your fingers in the pin hole.
- ★ Adjust the shim thickness so that the clearance between the end face of the bottom of cylinder (2) and bracket (8) is less than 1.0 mm.
 - Standard shim thickness:
1.0 mm, 1.5 mm

- **Bleeding air**
 - ★ Bleed the air.
For details, see TESTING AND ADJUSTING, Bleeding air.
- **Refilling with oil (hydraulic tank)**
 - ★ Add oil through the oil filler to the specified level.
Run the engine to circulate the oil through the system. Then check the oil level again.



020706

REMOVAL OF ARM CYLINDER ASSEMBLY

⚠ Extend the arm cylinder piston rod to a point approx. 200 mm before the end of the IN stroke, lower the work equipment completely to the ground, then set the remaining safety lock lever to the LOCK position.

1. Set block ① between arm cylinder and boom.
2. Remove plate (1), then remove head pin (2).

※ 1

3. Start engine, and retract piston rod, then tie piston rod with wire to prevent it from coming out.

⚠ Release the remaining pressure in the hydraulic circuit.

For details, see TESTING AND ADJUSTING, Releasing remaining pressure in hydraulic circuit.

4. Disconnect hoses (3).
5. Disconnect grease hose (4).



6. Raise arm cylinder assembly (5), remove plate (4), then remove bottom pin (7), and remove arm cylinder assembly (5).

※ 2

★ There are shims installed, so check the number and thickness, and keep in a safe place.



Arm cylinder assembly: **430 kg (PC300)**
440 kg (PC350)



INSTALLATION OF ARM CYLINDER ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1



Inside surface of bushing when assembling pin: **Anti-friction compound (LM-P)**



Greasing after assembling pin:

Grease (LM-G)



When aligning the position of the pin hole, never insert your fingers in the pin hole.

※ 2



Inside surface of bushing when assembling pin: **Anti-friction compound (LM-P)**



Greasing after assembling pin:


Grease (LM-G)



When aligning the position of the pin hole, never insert your fingers in the pin hole.

- ★ Adjust the shim thickness so that the clearance between the end face of the bottom of cylinder (5) and bracket (8) is less than 1.0 mm.

- Standard shim thickness: 1.0 mm



- **Bleeding air**
 - ★ Bleed the air.
For details, see TESTING AND ADJUSTING, Bleeding air.
- **Refilling with oil (hydraulic tank)**
 - ★ Add oil through the oil filler to the specified level.
Run the engine to circulate the oil through the system. Then check the oil level again.

020706

REMOVAL OF BUCKET CYLINDER ASSEMBLY

⚠ Extend the bucket cylinder piston rod to a point approx. 200 mm before the end of the DUMP stroke, lower the work equipment completely to the ground, then set the safety lock lever to the LOCK position.

1. Set block ① under arm top, block ② between link and arm, and block ③ between bucket cylinder and arm.

2. Remove lock bolt (1).

※ 1

3. Remove plate (2), then remove head pin (3).

※ 2

4. Start engine, and retract piston rod, then tie piston rod with wire to prevent it from coming out.

⚠ Release the remaining pressure in the hydraulic circuit.

For details, see TESTING AND ADJUSTING, Releasing remaining pressure in hydraulic circuit.

5. Disconnect hoses (4).




6. Raise bucket cylinder assembly (5), remove plate (6), then remove bottom pin (7), and remove bucket cylinder assembly (5).

※ 3

★ There are shims installed, so check the number and thickness, and keep in a safe place.



Bucket cylinder assembly: **270 kg**




020706

INSTALLATION OF BUCKET CYLINDER ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1

- ★ When tightening the locknut, tighten so that the clearance between the plate and nut is 0.5 – 1.5 mm.




※ 2

- Inside surface of bushing when assembling pin: **Anti-friction compound (LM-P)**
- Grease after assembling pin: **Grease (LM-G)**

- ⚠ When aligning the position of the pin hole, never insert your fingers in the pin hole.

- ★ Adjust the shim thickness so that the clearance between link (8) and link (9) is less than 1.0 mm.
 - Standard shim thickness: 0.8 mm




※ 3

- Inside surface of bushing when assembling pin: **Anti-friction compound (LM-P)**
- Grease after assembling pin: **Grease (LM-G)**

- ⚠ When aligning the position of the pin hole, never insert your fingers in the pin hole.

- ★ Adjust the shim thickness so that the clearance between the end face of the bottom of cylinder (5) and bracket (10) is less than 1.0 mm.
 - Standard shim thickness: 1.0 mm



- **Bleeding air**
 - ★ Bleed the air.
For details, see TESTING AND ADJUSTING, Bleeding air.
- **Refilling with oil (hydraulic tank)**
 - ★ Add oil through the oil filler to the specified level.
Run the engine to circulate the oil through the system. Then check the oil level again.

020706

DISASSEMBLY OF HYDRAULIC CYLINDER ASSEMBLY

1. Piston rod assembly.

- 1) Fix bottom end of cylinder assembly (1) in tool **U1** or press, then remove mounting bolts, and disconnect head assembly (2).



Unit: mm

Cylinder	Boom	Arm	Bucket
Bolt (width across flats)	27	30	27


- 2) Pull out piston rod assembly (3).
★ Place a container under the cylinder to catch the oil.

2. Piston assembly, head assembly.


- 1) Fix head end of piston rod assembly (3) in tool **U1** or press.



- 2) Remove screw (4), then remove 11 balls (5), and remove plunger (6).
★ Arm cylinder only
- 3) Remove 6 screws (7), then remove spacer (8).



- 4) Remove piston assembly (9), O-ring and backup ring (10).
- 5) Remove plunger (11).
★ Boom and arm cylinder only.
- 6) Disassembly of piston assembly.
 - i) Remove rings (12).
 - ii) Remove wear rings (13).
 - iii) Remove piston ring (14).




DISASSEMBLY AND ASSEMBLY

HYDRAULIC CYLINDER

- 7) Remove collar assembly (15) and head assembly (2) from piston rod (3).


★ The collar is on the boom and arm cylinder only.



- 8) Disassembly of collar


★ Disassemble collar (15) for the boom and arm cylinders only.

- i) Remove O-ring and backup ring (16).
- ii) Remove collar (18) and ring (19) from collar (17).



- 9) Disassembly of head assembly

- i) Remove O-ring and backup ring (20).
- ii) Remove snap ring (21), then remove dust seal (22).
- iii) Remove rod packing (23).
- iv) Remove buffer ring (24).
- v) Remove bushing (25).





020706

ASSEMBLY OF HYDRAULIC CYLINDER ASSEMBLY

- ★ Be careful not to damage the packings, dust seals, and O- rings.
- ★ Do not try to force the backup ring into position. Warm it in warm water (50 – 60°C) before fitting it.



1. Assembly of cylinder head assembly

- 1) Using tool **U4**, press fit bushing (25).
- 2) Assemble buffer ring (24).
- 3) Assemble rod packing (23).
- 4) Using tool **U5**, install dust seal (22), and secure with snap ring (21).
- 5) Install O-ring and backup ring (20).



2. Assembly of collar assembly




- ★ Assemble collar (15) for the boom and arm cylinders only.
- 1) Assemble ring (19) and collar (18) to collar (17).
 - 2) Assemble O-ring and backup ring (16).



3. Assembly of piston assembly

- 1) Using tool **U2**, expand piston ring (14).
 - ★ Set the piston ring on the tool **U2**, and turn the handle 8 – 10 times to expand the ring.
- 2) Assemble piston ring (14) to piston.
- 3) Set tool **U3** in position, and compress piston ring (14).
- 4) Assemble wear ring (13).
- 5) Assemble ring (12).
 - ★ Be careful not to open the end gap of the ring too wide.

 Ring groove: **Grease (G2-LI)**



DISASSEMBLY AND ASSEMBLY**HYDRAULIC CYLINDER****4. Piston rod assembly**

- 1) Fix head end of piston rod in tool **U1** or press.
- 2) Assemble head assembly (2) and collar assembly (15) to rod.
 - ★ Collar assembly (15) is for the boom and arm cylinder only.
- 3) Install plunger (11), O-ring and backup ring (10).
 - ★ Plunger (11) is for the boom and arm cylinder only.
- 4) Install piston assembly (9) and spacer (8), and tighten with screws (7).

 Screw: (7)

Thread tightener (Loctite No. 262)

 Screw: Arm cylinder:

176.5 ± 19.6 Nm (18 ± 2 kgm)

Boom cylinder: **110.32 ± 12.26 Nm**
(11.25 ± 1.25 kgm)

- 5) Set plunger (6) on piston rod, assemble 11 balls (5), then secure with screw (4).



 Screw: **Thread tightener (LT-2)**

 Screw: (4)

66.19 ± 7.35 Nm (6.75 ± 0.75 kgm)

- ★ Caulk the ~~rod end~~ after tightening the screw. (4)



(*) (Arm cylinder only)

**5. Cylinder assembly**

- 1) Fix bottom end of cylinder tube in tool **U1** or press.
- 2) Assemble piston rod assembly (2).
 -  Seal: **Grease (G2-LI)**
 - ★ Set the end gap of the ring at the horizontal (side) position, align the center of shaft and cylinder tube, then insert.
 - ★ After inserting, check that the ring is not broken and has not come out, then push in fully.
- 3) Tighten head assembly (1) with mounting bolts.

 Mounting bolt:

Cylinder	Width across flats (mm)	Tightening torque (Nm(kgm))
Boom, bucket	27	372.7 ± 53.9 (38 ± 5.5)
Arm	30	529.6 ± 78.5 (54 ± 8)



020706





REMOVAL OF WORK EQUIPMENT ASSEMBLY

⚠ Extend the arm and bucket fully, lower the work equipment to the ground, and set the safety lock lever to the LOCK position.

1. Disconnect grease hose (1).
2. Sling boom cylinder assembly (2), and remove lock bolt (3).
3. Remove plate (4), then remove head pin (5). ※ 1
※ 2
 - ★ There are shims installed, so check the number and thickness, and keep in a safe place.
4. Start engine, and retract piston rod, then tie piston rod with wire to prevent it from coming out, and lower cylinder onto stand.
 - ★ Disconnect the boom cylinder on the opposite side in the same way.
- ⚠ Release the remaining pressure in the hydraulic circuit.
 For details, see TESTING AND ADJUSTING, Releasing remaining pressure in hydraulic circuit.
5. Disconnect arm cylinder hoses (6) and bucket cylinder hoses (7), and secure to valve with rope.
6. Disconnect wiring connector (8) for working lamp.
7. Remove plate, and set tool **V** to boom foot pin (9).
8. Raise work equipment assembly (10), then remove boom foot pin (9) using tool **V**, and remove work equipment assembly (10). ※ 3
 - ★ There are shims installed, so check the number and thickness, and keep in a safe place.



Work equipment assembly: **5700 kg**



INSTALLATION OF WORK EQUIPMENT ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1

- ★ When tightening the locknut, tighten so that the clearance between the plate and nut is 0.5 – 1.5 mm.

※ 2

- Inside surface of bushing when assembling pin: **Anti-friction compound (LM-P)**
Grease after assembling pin:

Grease (LM-G)

- ⚠ When aligning the position of the pin hole, never insert your fingers in the pin hole.
- ★ Adjust the shim thickness so that the clearance between the end face of the rod of cylinder (2) and plate (4) is less than 1.0 mm.
 - Standard shim thickness:
1.0 mm, 1.5 mm

※ 3

- Inside surface of bushing when assembling pin: **Anti-friction compound (LM-P)**
Grease after assembling pin:

Grease (LM-G)




- ⚠ When aligning the position of the pin hole, never insert your fingers in the pin hole.
- ★ Adjust the shim thickness so that the clearance between the end face of the foot of boom (11) and bracket (12) is less than 1.0 mm.
 - Standard shim thickness:
0.8 mm, 1.5 mm

- Bleeding air**

- ★ Bleed the air.
For details, see TESTING AND ADJUSTING, Bleeding air.

- Refilling with oil (hydraulic tank)**

- ★ Add oil through the oil filler to the specified level.
Run the engine to circulate the oil through the system. Then check the oil level again.



020706

REMOVAL OF BUCKET ASSEMBLY

⚠ Set the back of the bucket facing down, lower the work equipment completely to the ground, and set the safety lock lever to the LOCK position.

1. Remove lock bolt (1). ※ 1

2. Remove connecting pin (2) between link and bucket. ※ 2

★ There are shims installed, so check the number and thickness, and keep in a safe place.

3. Start engine, and retract piston rod, then tie link to arm with wire to prevent piston rod from coming out.




4. Remove lock bolt (3). ※ 3

5. Remove plate (4), then remove connecting pin (5) between arm and bucket. ※ 4

★ There are shims installed, so check the number and thickness, and keep in a safe place.

6. Start engine, then raise work equipment and swing to remove bucket assembly (6).

 Bucket assembly: **1050 kg**



020706

INSTALLATION OF BUCKET ASSEMBLY

Carry out installation in the reverse order to removal.

※ 1, ※ 3

- ★ When tightening the locknut, tighten so that the clearance between the plate and nut is 0.5 – 1.5 mm.

※ 2

Inside surface of bushing when assembling pin: **Anti-friction compound (LM-P)**



Grease after assembling pin:

Grease (LM-G)



When aligning the position of the pin hole, never insert your fingers in the pin hole.

- ★ Adjust the shim thickness so that the clearance between the end face of the boss of bucket (6) and link (7) is less than 1.0 mm.
 - Standard shim thickness: 0.8 mm

※ 4



Inside surface of bushing when assembling pin: **Anti-friction compound (LM-P)**






Grease after assembling pin:

Grease (LM-G)



When aligning the position of the pin hole, never insert your fingers in the pin hole.



- ★ Insert the O-ring at the end face of the bucket boss securely.
- ★ Adjusting bucket clearance.
 - 1) Measure clearance **a** between arm (8) and bushing (9).
 - ★ It is easier to measure if the bucket is moved to one side so that all the play is in one place.
 - 2) Select shim thickness **b** so that clearance **a** is 0.5 – 1.0 mm.
 - ★ Standard shim thickness: 0.5 mm, 1.0 mm
 - 3) Install selected shim, then install plate (4).



020706

REMOVAL OF ARM ASSEMBLY

1. Remove bucket assembly.
For details, see REMOVAL OF BUCKET ASSEMBLY.
2. Secure link to arm with wire.
 ⚠ Extend the arm cylinder piston rod to a point approx. 200 mm before the end of the IN stroke, then lower the arm on to block ① and stand ②, and set the safety lock lever to the LOCK position.
3. Set block ③ between arm cylinder and boom.
4. Remove plate (1), then remove arm cylinder head pin (2). ※ 1
5. Start engine, and retract piston rod, then tie piston rod with wire to prevent it from coming out.
 ⚠ Release the remaining pressure in the hydraulic circuit.
 For details, see TESTING AND ADJUSTING, Releasing remaining pressure in hydraulic circuit.
6. Disconnect 2 bucket cylinder hoses (3).
7. Remove plate (4), then remove connecting pin (5) between arm and boom. ※ 2
 ★ There are shims installed, so check the number and thickness, and keep in a safe place.
8. Start engine, then raise boom and swing to remove arm assembly (6).



Arm assembly: **1500 kg**

INSTALLATION OF ARM ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1



Inside surface of bushing when assembling pin: **Anti-friction compound (LM-P)**



Grease after assembling pin:

Grease (LM-G)



When aligning the position of the pin hole, never insert your fingers in the pin hole.

※ 2



Inside surface of bushing when assembling pin: **Anti-friction compound (LM-P)**



Grease after assembling pin:

Grease (LM-G)



When aligning the position of the pin hole, never insert your fingers in the pin hole.


- ★ Adjust the shim thickness so that the clearance between the end face of the bottom of arm (6) and boom (7) is below 1.0 mm.
- ★ Standard shim thickness: 1.0 mm

- **Bleeding air**

- ★ Bleed the air.
For details, see TESTING AND ADJUSTING, Bleeding air.

- **Refilling with oil (hydraulic tank)**

- ★ Add oil through the oil filler to the specified level.
Run the engine to circulate the oil through the system. Then check the oil level again.



020706

REMOVAL OF BUCKET, ARM ASSEMBLY

⚠ Extend the bucket cylinder piston rod to the end of the CURL stroke, and the arm cylinder piston rod to a point approx. 200 mm before the end of the IN stroke. Then lower the work equipment completely to the ground, and set the safety lock lever to the LOCK position.

1. Set block ① to bucket cylinder bottom mounting boss portion of arm.

2. Remove plate (1), then remove arm cylinder head pin (2). ※ 1

3. Start engine, and retract piston rod, then tie piston rod with wire to prevent it from coming out.

⚠ Release the remaining pressure in the hydraulic circuit.
For details, see TESTING AND ADJUSTING, Releasing remaining pressure in hydraulic circuit.




4. Disconnect 2 bucket cylinder hoses (3).

5. Remove plate (4), then remove connecting pin (5) between arm and boom. ※ 2

★ There are shims installed, so check the number and thickness, and keep in a safe place.

6. Start engine, then raise boom and swing to remove bucket and arm assembly (6).

 Bucket, arm assembly: **2600 kg**



020706

INSTALLATION OF BUCKET, ARM ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1

 Inside surface of bushing when assembling pin: **Anti-friction compound (LM-P)**

 Grease after assembling pin:

Grease (LM-G)

 When aligning the position of the pin hole, never insert your fingers in the pin hole.

※ 2

 Inside surface of bushing when assembling pin: **Anti-friction compound (LM-P)**

 Grease after assembling pin:

Grease (LM-G)

 When aligning the position of the pin hole, never insert your fingers in the pin hole.

- ★ Adjust the shim thickness so that the clearance between the end face of the bottom of arm (6) and boom (7) is less than 1.0 mm.


- Standard shim thickness: 1.0 mm

- **Bleeding air**

- ★ Bleed the air.
For details, see TESTING AND ADJUSTING, Bleeding air.

- **Refilling with oil (hydraulic tank)**

- ★ Add oil through the oil filler to the specified level.
Run the engine to circulate the oil through the system. Then check the oil level again.



020706

REMOVAL OF BOOM ASSEMBLY

1. Remove bucket and arm assembly
For details, see REMOVAL OF BUCKET, ARM ASSEMBLY.

⚠ Lower the boom assembly completely to the ground, and set the safety lock lever to the LOCK position.

2. Disconnect grease hose (1).
3. Sling boom cylinder assembly (2), and remove lock bolt (3).
4. Remove plate (4), then remove head pin (5).

※ 1

※ 2

★ There are shims installed, so check the number and thickness, and keep in a safe place.

5. Start engine, and retract piston rod, then tie piston rod with wire to prevent it from coming out, and lower it onto stand.

★ Disconnect the boom cylinder on the opposite side in the same way.

⚠ Release the remaining pressure in the hydraulic circuit.

For details, see TESTING AND ADJUSTING, Releasing remaining pressure in hydraulic circuit.





6. Disconnect arm cylinder hoses (6) and bucket cylinder hoses (7), and secure to valve with rope.
7. Disconnect wiring connector (8) for working lamp
8. Remove plate, and set tool V to boom foot pin (9).
9. Raise boom assembly (10), remove boom foot pin (9) using tool V, then remove boom assembly (10).

※ 3

★ There are shims installed, so check the number and thickness, and keep in a safe place.



Boom assembly: **3000 kg**



INSTALLATION OF BOOM ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1

- ★ When tightening the locknut, tighten so that the clearance between the plate and nut is 0.5 – 1.5 mm.

※ 2

- Inside surface of bushing when assembling pin: **Anti-friction compound (LM-P)**
Grease after assembling pin:

Grease (LM-G)

- ⚠ When aligning the position of the pin hole, never insert your fingers in the pin hole.
- ★ Adjust the shim thickness so that the clearance between the end face of the rod of cylinder (2) and plate (4) is less than 1.0 mm.
 - Standard shim thickness:
1.0 mm, 1.5 mm

※ 3

- Inside surface of bushing when assembling pin: **Anti-friction compound (LM-P)**
Grease after assembling pin:

Grease (LM-G)




- ⚠ When aligning the position of the pin hole, never insert your fingers in the pin hole.
- ★ Adjust the shim thickness so that the clearance between the end face of the foot of boom (10) and bracket (11) is less than 1.0 mm.
 - Standard shim thickness:
0.8 mm, 1.5 mm

• Bleeding air

- ★ Bleed the air.
For details, see TESTING AND ADJUSTING, Bleeding air.

• Refilling with oil (hydraulic tank)

- ★ Add oil through the oil filler to the specified level.
Run the engine to circulate the oil through the system. Then check the oil level again.




020706


REMOVAL OF OPERATOR'S CAB ASSEMBLY

⚠ Disconnect the cable from the negative (–) terminal of the battery.



1. Remove floor mat.
2. Remove operator's seat (1).
★ Be careful not to damage the covers.




3. Remove knob (2).
4. Remove 4 bolts and 1 clip, then remove panels (3) and (4).





5. Disconnect window washer hose (5).
6. Remove plate (6), then remove left cover (7).



7. Disconnect hose (8) and speaker wiring connector, then remove right cover (9).
★ Lift up right cover (9) slightly before disconnecting the speaker wiring connector.



8. Remove cover (10) and duct (11).
9. Disconnect air conditioner cable (12).
10. Disconnect duct (13) at front.
11. Disconnect 11 connectors (14).
 - ★ Panel: CN-X07 (MIC21)
 - ★ Controller: CN-C01 (MIC13)
 - : CN-C02 (MIC21)
 - : CN-C03 (MIC20)
 - : CN-C16 (MIC17)
 - ★ Wiring harness intermediate
 - : CN-H12 (S16) White
 - : CN-H13 (S16) Blue
 - : CN-H14 (M6)
 - : CN-H15 (L2)
 - ★ Speaker: CM-M13 (KES-2)
 - ★ Air conditioner: No connector No.




12. Remove 4 mounting nuts and 6 mounting bolts, then lift off operator's cab assembly (15). ※ 1



Operator's cab assembly: **300 kg**

• ※: Nut ▲: Bolt

★ Check the length of the bolts.



INSTALLATION OF OPERATOR'S CAB ASSEMBLY


- Carry out installation in the reverse order to removal.

※ 1



Mounting nut:

277.04 ± 31.87 Nm (28.25 ± 3.25 kgm)




020706

REMOVAL OF COUNTERWEIGHT ASSEMBLY

1. Set lifting hook chains of counterweight assembly in position, and sling.
2. Remove mounting bolts (1).
★ Check the location of the shims.
3. Lift off counterweight assembly (2). ※ I



Counterweight assembly: **5500 kg**



INSTALLATION OF COUNTERWEIGHT ASSEMBLY


- Carry out installation in the reverse order to removal.

※ I

- ★ Adjust the stepped difference (top and bottom clearance) from the bodywork with shims.
- ★ Install so that the clearance between the door and counterweight and the clearance between the revolving frame and the counterweight are a uniform 10 ± 5 mm.

 Thread of counterweight mounting bolt:
Thread tightener (LT-2)



 Counterweight mounting bolt:
 1814.2 ± 98.1 Nm (185 ± 10 kgm)



REMOVAL OF AIR CONDITIONER COMPRESSOR ASSEMBLY

- ⚠ Disconnect the cable from the negative (–) terminal of the battery.
- ⚠ Open the engine hood, then push the valve of the air conditioner compressor hose slowly and release the refrigerant (R134a) gradually.

1. Disconnect wiring connector (1) (CN-M34).
2. Disconnect hoses (2). ※ 1
3. Loosen tension bolts (3) and compressor mounting bolts, and remove V-belt (4) from pulley. ※ 2
4. Remove 3 mounting bolts (5) of compressor bracket, then remove compressor assembly (6).
 - ★ It is difficult to remove the compressor mounting bolts, so remove together with the bracket.



INSTALLATION OF AIR CONDITIONER COMPRESSOR ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1

- ★ When installing the hoses, check that the O-ring is not damaged or deteriorated, then connect the hoses.

※ 2

- ★ Adjust the belt tension.
For details, see TESTING AND ADJUSTING, Testing and adjusting belt tension for air conditioner compressor.




- **Charging with refrigerant**

- ★ Using tool X, charge the air conditioner circuit with air conditioner gas (R134a).

REMOVAL OF CONDENSER ASSEMBLY

- ⚠ Disconnect the cable from the negative (-) terminal of the battery.
- ⚠ Open the engine hood, then push the valve of the air conditioner compressor hose slowly and release the refrigerant (R134a) gradually.

1. Open condenser side cover, and remove top cover.
2. Disconnect wiring connector (1) (CN-M35).
★ This is at the rear of the condenser.
3. Disconnect hoses (2) and (3), and clamp (4). ※ 1
★ Be careful not to lose the O-ring.
4. Remove condenser assembly (5) together with receiver.



INSTALLATION OF CONDENSER ASSEMBLY

- Carry out installation in the reverse order to removal.



※ 1

- ★ Check that the O-ring is not damaged or deteriorated, then connect the hoses.
- **Charging with refrigerant**
 - ★ Using tool X, charge the air conditioner circuit with air conditioner gas (R134a).


REMOVAL OF AIR CONDITIONER UNIT ASSEMBLY

- ⚠ Disconnect the cable from the negative (-) terminal of the battery.
- ⚠ Open the engine hood, then push the valve of the air conditioner compressor hose slowly and release the refrigerant (R134a) gradually.


1. Drain coolant.
2. Slide operator's seat fully forward.
3. Remove plate (1), then remove left cover (2).
4. Disconnect hose (3) and speaker wiring connector, and remove right cover (4).
 - ★ Lift up the cover slightly before disconnecting the speaker wiring connector.



5. Remove cover (5) and duct (6).




6. Disconnect wiring connector (7) (CN-M23).




020706

7. Disconnect wiring connector (8) (CN-M23).




8. Disconnect wiring connector (9) (CN-M26).



9. Disconnect air conditioner hose (10), heater hose (11), and air conditioner wire (12).

10. Remove mounting bolts, then remove air conditioner unit assembly (13).

※ 1



INSTALLATION OF AIR CONDITIONER UNIT ASSEMBLY

- Carry out installation in the reverse order to removal.



※ 1

- ★ Insert duct (13) while installing.
- **Refilling with water**
 - ★ Add water through water filler to the specified level.
 - Run the engine to circulate the water through the system. Then check the water level again.
- **Charging with refrigerant**
 - ★ Using tool X, charge the air conditioner circuit with air conditioner gas (R134a).

REMOVAL OF GOVERNOR, PUMP CONTROLLER ASSEMBLY

⚠ Disconnect the cable from the negative (-) terminal of the battery.

1. Slide operator's seat fully forward.
2. Remove plate (1), then remove left cover (2).
3. Disconnect hose (3) and speaker wiring connector, then remove right cover (4).
 - ★ Lift up the cover slightly before disconnecting the speaker wiring connector.
4. Remove 5 connectors (5).
5. Remove governor and pump controller assembly. ※ 1




INSTALLATION OF GOVERNOR, PUMP CONTROLLER ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1

- Check the performance of the work equipment, travel, and swing. For details, see TESTING AND ADJUSTING.




020706

REMOVAL OF MONITOR PANEL ASSEMBLY

⚠ Disconnect the cable from the negative (-) terminal of the battery.

1. Remove 4 screws (1), and disconnect monitor panel assembly (2) from bracket.
2. Disconnect connectors (3), then remove monitor panel assembly (2). ※ 1




INSTALLATION OF MONITOR PANEL ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1



- Check the mode setting and display function. For details, see TESTING, ADJUSTING, AND TROUBLESHOOTING.



REMOVAL OF CONTROL STAND CASE


1. Tray

- 1) Insert a thin flat-headed screwdriver into notch at rear of tray (1) and lever up lightly to release rear claw (2).
- ★ The claw can only be released from the rear.



- 2) Pull tray (1) to rear to remove.




※ 2



2. Boot

- 1) Insert a thin flat-headed screwdriver between boot (3) and upper case (4), remove claw (5) at front of boot from upper case, then raise front.
- 2) Pull boot (3) to front to remove claw at rear of boot.
- 3) Disconnect wiring connector (7) from hole for removed tray.
- 4) Push boot up, remove bolt (8), then remove lever (9) and boot (3).
- ★ Check the direction of the lever.



※ 1




020706

3. Upper case.

- 1) Remove 4 upper case mounting screws (10).





- 2) Push bottom center of upper case (11) from both sides, and lift up to release claws at both sides.



- 3) Use a screwdriver from front of upper case to release claws (12) at front of case.

- 4) Remove upper case (11).



INSTALLATION OF CONTROL STAND CASE


- Carry out installation in the reverse order to removal.

※ 1

- ★ When installing the boot, insert the claw at the rear first.

※ 2

- ★ When installing the tray and upper case, insert the claws at the front first.






40 MAINTENANCE STANDARD

Engine mount	40- 2
Swing machinery	40- 4
Swing circle	40- 6
Final drive	40- 8
Track frame and recoil spring	40-10
Idler	40-12
Carrier roller	40-14
Track roller	40-15
Track	40-16
Hydraulic pump	40-18
Control pump and relief valve	40-19
Control valve	40-20
Suction-safety valve	40-26
Swing motor	40-27
Travel motor	40-28
Work equipment, swing PPC valve	40-29
Travel PPC valve	40-30
Service PPC valve	40-31
PPC shuttle valve, travel junction valve ..	40-32
EPC solenoid valve	40-33
Center swivel joint	40-34
Boom holding valve	40-35
Hydraulic cylinder	40-36
Work equipment	40-38

020706

ENGINE MOUNT




SDP00401

Unit: mm

No.	Check item	Criteria		Remedy
		Standard size	Repair limit	
1	Free height of front mount rubber	84	—	Replace
2	Free height of rear mount rubber	126	—	

SWING MACHINERY



020706

SAP00403


MAINTENANCE STANDARD

SWING MACHINERY

Unit: mm

No.	Check item	Criteria		Remedy
		Standard clearance	Clearance limit	
1	Backlash between swing motor shaft and No. 1 sun gear	0.19 – 0.29	—	Replace
2	Backlash between No. 1 sun gear and No. 1 planet gear	0.17 – 0.52	0.90	
3	Backlash between No. 1 planet gear and ring gear	0.20 – 0.61	0.90	
4	Backlash between No. 2 planet carrier and coupling	0.047 – 0.122	—	
5	Backlash between No. 1 planet carrier and No. 2 sun gear	0.37 – 0.65	1.10	
6	Backlash between No. 2 sun gear and No. 2 planet gear	0.17 – 0.52	1.00	
7	Backlash between No. 2 planet gear and ring gear	0.20 – 0.61	1.10	
8	Backlash between coupling and swing pinion	0.07 – 0.24	—	
9	Backlash between swing pinion and swing circle	0 – 1.21	2.00	
10	Clearance between plate and coupling	0.06 – 0.82	—	
11	Wear of swing pinion oil seal contact surface	Standard size	Repair limit	Repair hard chrome plating or replace
		140 ⁰ _{-0.100}	—	

SWING CIRCLE




020706

Unit: mm

No.	Check item	Criteria		Remedy
		Standard clearance	Clearance limit	
1	Clearance of bearing in axial direction (when mounted on machine)	0.5 – 1.6	3.2	Replace

FINAL DRIVE



SAP00407

020706


020706

Unit: mm

No.	Check item	Criteria		Remedy
		Standard clearance	Clearance limit	
1	Backlash between No. 1 sun gear and No. 1 planet gear	0.17 – 0.50	1.00	Replace
2	Backlash between No. 1 planet gear and ring gear	0.24 – 0.70	1.10	
3	Backlash between No. 2 planet carrier and motor	0.06 – 0.24	—	
4	Backlash between No. 2 sun gear and No. 2 planet gear	0.19 – 0.54	1.00	
5	Backlash between No. 2 planet gear and ring gear	0.24 – 0.70	1.10	
6	Backlash between No. 1 planet gear and No. 2 sun gear	0.40 – 0.73	1.00	
7	End play of sprocket shaft	0.10 – 0.15	—	
8	Wear of sprocket teeth	Repair limit: 6		Rebuild or replace
9	Sprocket tooth width	Standard size	Repair limit	
		87	84	

TRACK FRAME AND RECOIL SPRING

★ The diagram shows the PC300-6



SAP00409

Unit: mm

No.	Check item	Criteria				Remedy
			Standard size	Tolerance	Repair limit	
1	Top-to-bottom width of idler guide	Track frame	123	$+2$ -1	127	Rebuild or replace
		Idler support	120	± 0.5	118	
2	Left-to-right width of idler guide	Track frame	266	$+3$ -1	271	
		Idler support	261	—	259	
3	Recoil spring	Standard size		Repair limit		Replace
		Free length x OD	Installed length	Installed load	Free length	
		795 x 241	648	173 kN (17,680 kg)	—	
					139 kN (14,140 kg)	

020706


MAINTENANCE STANDARD

IDLER

Unit: mm

No.	Check item	Criteria					Remedy
1	Outside diameter of protruding portion	Standard size		Repair limit			Rebuild or replace
		630		—			
2	Outside diameter of tread	590		578			
3	Width of protrusion	101		—			
4	Overall width	190		—			
5	Width of tread	44.5		50.5			Replace bushing
6	Clearance between shaft and bushing	Standard size	Tolerance		Standard clearance	Clearance limit	
			Shaft	Hole			
		80	−0.225 −0.325	+0.130 −0.010	0.215 – 0.455	1.5	
7	Clearance between shaft and support	80	−0.225 −0.290	−0.085 −0.195	0.03 – 0.205	—	Replace
8	Interference between idler and bushing	Standard size	Tolerance		Standard interference	Interference limit	Replace bushing
			Shaft	Hole			
		87.6	+0.087 +0.037	−0.027 −0.079	0.064 – 0.166	—	
9	Side clearance of idler (both sides)	Standard clearance		Clearance limit			
		0.68 – 1.22		2			

CARRIER ROLLER




SBP00415

Unit: mm

No.	Check item	Criteria				Remedy	
1	Outside diameter of flange (outside)	Standard size		Repair limit		Rebuild or replace	
		200		—			
2	Outside diameter of tread	168		158			
3	Width of tread	49.5		57.5			
4	Interference between shaft and bearing	Standard size	Tolerance		Standard interference	Interference limit	
			Shaft	Hole			
		55	+0.021 +0.002	0 -0.015	0.002 – 0.036	—	
5	Interference between roller and bearing	100	0 -0.015	-0.024 -0.059	0.009 – 0.059	—	Replace
6	Side clearance of roller	Standard size		Repair limit			
		0.01 – 0.24		—			

020706

TRACK ROLLER





SBP00413

Unit: mm

No.	Check item	Criteria					Remedy
1	Outside diameter of flange (outside)	Standard size		Repair limit			Rebuild or replace
		216		—			
2	Outside diameter of tread	180		168			
3	Width of tread	49		55			
4	Width of flange	27		—			Replace bushing
5	Clearance between shaft and bushing	Standard size	Tolerance		Standard clearance	Clearance limit	
			Shaft	Hole			
		65	-0.215 -0.315	+0.186 -0.064	0.151 – 0.501	1.5	
6	Interference between roller and bearing	Standard size	Tolerance		Standard interference	Interference limit	
			Shaft	Hole			
		72	+0.108 +0.008	-0.006 -0.036	0.014 – 0.144	—	
7	Side clearance of idler (both sides)	Standard clearance		Clearance limit			Replace
		0.41 – 0.95		1.5			

TRACK



SDP00416

020706

MAINTENANCE STANDARD





TRACK

Unit: mm

No.	Check item	Criteria					Remedy
1	Link pitch	Standard size		Repair limit			Replace
		216		—			
2	Outside diameter of bushing	66.5		61			
3	Height of grouser	36		—			Carry out lug welding or rebuild if it is possible within repairable limit
4	Height of link	116		107			
5	Interference between bushing and link	Standard size	Tolerance		Standard interference	Interference limit	If it is lower than interference limit, replace with oversize
			Shaft	Hole			
		66.5	+0.464 +0.424	+0.074 0	0.35 – 0.464	0.10	
6	Interference between regular pin and link	44.6 (Shaft) 44.35 (Hole)	+0.235 +0.085	+0.062 0	0.273 – 0.485	0.14	
7	Interference between master pin and link	44.6 (Shaft) 44.35 (Hole)	+0.03 0	+0.062 0	0.188 – 0.28	0.14	
8	Protrusion of bushing	5.25 ± 0.3					
9	Tightening torque for shoe bolt	After tightening to initial torque 196.1 ± 19.6 Nm (20 ± 2 kgm), tighten a further 120 ± 10°					Replace

HYDRAULIC PUMP

HPV125 + 125




SDP00418

020706

CONTROL PUMP AND RELIEF VALVE

BAR-020




SBP00420

Unit: mm

No.	Check item	Criteria					Remedy
1	Top clearance of gear	Standard clearance		Clearance limit			Replace
		0.085 – 0.125		0.145			
2	Side clearance of gear	0.050 – 0.060		0.105			
3	Clearance between gear shaft and bushing	0.045 – 0.098		0.13			
4	Control relief valve spring	Standard size			Repair limit		
		Free length x OD	Installed length	Installed load	Free length	Installed load	
		32.3 x ϕ 13	25.0	177.5 N (18.1 kg)	—	159.9 N (16.3 kg)	
—	Performance Oil: EO10-CD Oil temperature: 50 ± 5°C Oil pressure: 2.9 MPa (30 kg/cm ²)	Standard discharge amount		Discharge limit			Replace
		Speed (rpm)	Delivery (ℓ/min)	Speed (rpm)	Delivery (ℓ/min)		
		3,200	60.2	3,200	43		

CONTROL VALVE


- 10-spool valve (1/6)
- ★ For details of the 9-, 8-, and 7-spool valves, see 10-SPOOL VALVE.
- ★ For details of this page, see Section 90.



020706

SAP00421

(2/6)




SAP00422

Unit: mm

No.	Check item	Criteria					Remedy
1	Spool return spring	Standard size			Repair limit		Replace spring if there is damage or deformation
		Free length x OD	Installed length	Installed load	Free length	Installed load	
		54.5 x 34.8	51.2	393.3 N (40.1 kg)	—	314.8 N (32.1 kg)	
2	Spool return spring	54.2 x 34.8	51.2	416.8 N (42.5 kg)	—	338.3 N (34.5 kg)	
3	Spool return spring	54.6 x 34.8	51.2	420.7 N (42.9 kg)	—	342.3 N (34.9 kg)	
4	Spool return spring	54.4 x 34.8	51.2	411.9 N (42.0 kg)	—	333.4 N (34.0 kg)	
5	Spool return spring	54.9 x 24.2	51.2	251.0 N (25.6 kg)	—	201.0 N (20.5 kg)	

(3/6)




SAP00424

020706

Unit: mm

No.	Check item	Criteria					Remedy
1	Valve spring	Standard size			Repair limit		Replace spring if there is damage or deformation
		Free length x OD	Installed length	Installed load	Free length	Installed load	
		23.2 x 7.2	19	41.2 N (4.2 kg)	—	33.3 N (3.4 kg)	
2	Relief spring	30.7 x 9.6	26.3	369.7 N (37.7 kg)	—	296.2 N (30.2 kg)	
3	Unload spring	38.5 x 9.8	26	83.4 N (8.5 kg)	—	66.7 N (6.8 kg)	

(4/6)




SAP00425

MAINTENANCE STANDARD

CONTROL VALVE

(5/6)



SAP00427

Unit: mm


No.	Check item	Criteria					Remedy
1	Regeneration valve spring	Standard size			Repair limit		Replace spring if there is damage or deformation
		Free length x OD	Installed length	Installed load	Free length	Installed load	
		31.5 x 10.3	19.5	5.9 N (0.6 kg)	—	4.4 N (0.45 kg)	
2	Piston return spring	48.1 x 10.8	28	17.5 N (1.78 kg)	—	13.9 N (1.42 kg)	
3	Piston return spring	50.4 x 17	39	158.9 N (16.2 kg)	—	142.2 N (14.5 kg)	
4	Piston return spring	48 x 10.4	36	59 N (6 kg)	—	47.1 N (4.8 kg)	
5	Load spring	30.4 x 16.7	27	428.6 N (43.7 kg)	—	343.2 N (35.0 kg)	
6	Check valve spring	13.6 x 5.5	10	1.96 N (0.2 kg)	—	1.47 N (0.15 kg)	
7	Piston return spring	24.5 x 25.2	12	1.96 N (0.2 kg)	—	1.47 N (0.15 kg)	

020706

MAINTENANCE STANDARD

CONTROL VALVE

(6/6)




SAP00429

Unit: mm

No.	Check item	Criteria					Remedy
1	Check valve spring	Standard size			Repair limit		Replace spring if there is damage or deformation
		Free length x OD	Installed length	Installed load	Free length	Installed load	
		11.5 x 4.6	8.5	1.47 N (0.15 kg)	—	1.18 N (0.12 kg)	
2	Spool return spring	65.5 x 27.2	50	167.7 N (17.1 kg)	—	134.3 N (13.7 kg)	
3	Spool return spring	13.6 x 5.5	10	1.96 N (0.2 kg)	—	1.47 N (0.15 kg)	

SUCTION-SAFETY VALVE

FOR SERVICE VALVE




020706

Unit: mm

No.	Check item	Criteria						Remedy
1	Suction valve spring	Standard size				Repair limit		Replace
		Wire diameter	Free length x OD	Installed length	Installed load	Free length	Installed load	
		φ 0.9	16.3 x φ 21.3	1.5	2.06 N (0.21 kg)	—	1.57 N (0.16 kg)	
2	Piston spring	φ 0.5	20 x φ 7	14	2.06 N (0.21 kg)	—	1.57 N (0.16 kg)	

SWING MOTOR
KMF160AB-3




Unit: mm

No.	Check item	Criteria					Remedy
1	Check valve spring	Standard size			Repair limit		Replace spring if there is damage or deformation
		Free length x OD	Installed length	Installed load	Free length	Installed load	
		46.9 x 9.2	35	11.8 N (1.2 kg)	—	9.4 N (0.96 kg)	

TRAVEL MOTOR

HMV160ADT-2




SDP00432

020706

Unit: mm

No.	Check item	Criteria					Remedy
1	Spool return spring	Standard size			Repair limit		Replace spring if there is damage or deformation
		Free length x OD	Installed length	Installed load	Free length	Installed load	
		58.43 x 30.0	42.0	426.0 N (43.5 kg)	—	341.3 N (34.8 kg)	
2	Check valve spring	33.0 x 13.8	23.0	1.28 N (0.13 kg)	—	0.98 N (0.10 kg)	
3	Regulator piston spring	61.1 x 23.2	30.0	399.1 N (40.7 kg)	—	319.7 N (32.6 kg)	

WORK EQUIPMENT, SWING PPC VALVE




SBP00434

Unit: mm

No.	Check item	Criteria					Remedy
1	Centering spring (for P3, P4)	Standard size			Repair limit		Replace spring if there is damage or deformation
		Free length x OD	Installed length	Installed load	Free length	Installed load	
		42.4 x 15.5	34	17.7 N (1.8 kg)	—	13.7 N (1.4 kg)	
2	Centering spring (for P1, P2)	44.4 x 15.5	34	29.4 N (3.0 kg)	—	23.5 N (2.4 kg)	
3	Metering spring	26.5 x 8.2	24.9	16.7 N (1.7 kg)	—	13.7 N (1.4 kg)	

TRAVEL PPC VALVE




SBP00435

Unit: mm

No.	Check item	Criteria					Remedy
1	Metering spring	Standard size			Repair limit		Replace spring if there is damage or deformation
		Free length x OD	Installed length	Installed load	Free length	Installed load	
		26.5 x 8.15	24.7	16.7 N (1.7 kg)	—	13.7 N (1.4 kg)	
2	Centering spring	48.1 x 15.5	32.5	107.9 N (11 kg)	—	86.3 N (8.8 kg)	

SERVICE PPC VALVE




SBP00436

Unit: mm

No.	Check item	Criteria					Remedy
1	Centering spring	Standard size			Repair limit		Replace spring if there is damage or deformation
		Free length x OD	Installed length	Installed load	Free length	Installed load	
		64.8 x 16.6	40.5	46.1 N (4.7 kg)	(62.9)	44.1 N (4.5 kg)	
2	Metering spring	26.0 x 10.5	25.0	25.5 N (2.6 kg)	(25.2)	24.5 N (2.5 kg)	

PPC SHUTTLE VALVE, TRAVEL JUNCTION VALVE




020706

SDP00437

Unit: mm

No.	Check item	Criteria					Remedy
1	Spool return spring	Standard size			Repair limit		Replace spring if there is damage or deformation
		Free length x OD	Installed length	Installed load	Free length	Installed load	
		23.6 x 13.3	20	14.7 N (1.5 kg)	—	11.8 N (1.2 kg)	

EPC SOLENOID VALVE
FOR LS VALVE




SBP00438

020706

Unit: mm

No.	Check item	Criteria					Remedy
1	Return spring	Standard size			Repair limit		Replace EPC valve assembly if there is damage or deformation
		Free length x OD	Installed length	Installed load	Free length	Installed load	
		9.0 x 11.4	7.9	3.14 N (0.32 kg)	—	—	

CENTER SWIVEL JOINT




SBP00439

020706

Unit: mm

No.	Check item	Criteria			Remedy
		Standard size	Standard clearance	Clearance limit	
1	Clearance between rotor and shaft	90	0.056 – 0.105	0.111	Replace

BOOM HOLDING VALVE




SAP00440

Unit: mm

No.	Check item	Criteria					Remedy
1	Pilot valve spring	Standard size			Repair limit		Replace spring if there is damage or deformation
		Free length x OD	Installed length	Installed load	Free length	Installed load	
		26.5 x 11.2	25.0	4.70 N (0.48 kg)	—	3.63 N (0.38 kg)	
2	Check valve spring	37.2 x 16.2	30.0	35.3 N (3.6 kg)	—	28.4 N (2.9 kg)	

HYDRAULIC CYLINDER

★ The diagram shows the boom cylinder.




Unit: mm


No.	Check item		Criteria					Remedy
1	Clearance between piston rod and bushing	Name of cylinder	Standard size	Tolerance		Standard clearance	Clearance limit	Replace bushing
				Shaft	Hole			
		Boom	100	-0.036 -0.090	+0.257 +0.047	0.083 – 0.347	0.447	
		Arm	110	-0.036 -0.090	+0.261 +0.047	0.083 – 0.351	0.451	
		Bucket	100	-0.036 -0.090	+0.257 +0.047	0.083 – 0.347	0.447	
2	Clearance between piston rod support shaft and bushing	Arm (for PC350)	110	-0.036 -0.090	+0.261 +0.047	0.083 – 0.351	0.451	Replace pin, bushing
		Boom	100		+0.457 +0.370		1.0	
		Arm	100		+0.457 +0.370		1.0	
		Bucket	90		+0.457 +0.370		1.0	
3	Clearance between cylinder bottom support shaft and bushing	Arm (for PC350)	100		+0.457 +0.370		1.0	
		Boom	90		+0.457 +0.370		1.0	
		Arm	100		+0.457 +0.370		1.0	
		Bucket	90		+0.457 +0.370		1.0	
		Arm (for PC350)	100		+0.457 +0.370		1.0	
		Boom	90		+0.457 +0.370		1.0	
		Arm	100		+0.457 +0.370		1.0	
		Bucket	90		+0.457 +0.370		1.0	

020706


WORK EQUIPMENT




SBP00443




A-A




B-B




C-C




D-D




E-E



F-F



G-G



G-G

SAP00444

020706


020706

Unit: mm

No.	Check item	Criteria					Remedy
1	Clearance between bushing and mounting pin of boom and revolving frame	Standard size	Tolerance		Standard clearance	Clearance limit	Replace
			Shaft	Hole			
2	Clearance between bushing and mounting pin of boom and arm	110	-0.036 -0.071	+0.357 +0.270	0.306 – 0.428	1.0	
3	Clearance between bushing and mounting pin of boom and link	90	-0.036 -0.090	+0.338 +0.272	0.308 – 0.428	1.0	
4	Clearance between bushing and mounting pin of boom and bucket	90	-0.036 -0.090	+0.337 +0.271	0.307 – 0.427	1.0	
5	Clearance between bushing and mounting pin of link and bucket	90	-0.036 -0.090	+0.346 +0.275	0.311 – 0.436	1.0	
6	Clearance between bushing and mounting pin of link and link	90	-0.036 -0.090	+0.346 +0.275	0.311 – 0.436	1.0	
7	Bucket clearance (a)	0.5 – 1.0					
8	Bucket clearance (b)	2.0					

DIMENSIONS OF WORK EQUIPMENT

1. ARM



SAP00446

020706


MAINTENANCE STANDARD

WORK EQUIPMENT

Unit: mm

No. \ Model		PC300-6	PC350-6
1		$\phi 100^{+0.1}_{-0} / -0.036 / -0.090$	$\phi 100^{+0.1}_{-0} / -0.036 / -0.090$
2		$\phi 117.3^{+1.5}_{-0} / 116 \pm 1.2$	$\phi 117.3^{+1.5}_{-0} / 116 \pm 1.2$
3		$320^{+0.5}_{-0} / -0.3 / -0.8$	$320^{+0.5}_{-0} / -0.3 / -0.8$
4		$\phi 110^{+0.1}_{-0} / -0.036 / -0.090$	$\phi 110^{+0.1}_{-0} / -0.036 / -0.090$
5		428.4 ± 1.0	468 ± 1
6		219 ± 0.5	234.0 ± 0.5
7		935.7 ± 1.0	1022.8 ± 1.0
8		3179 ± 3	3179 ± 3
9		3095.7 ± 1.0	3095.7 ± 1.0
10		468 ± 1	472.5 ± 1.0
11		731.0 ± 0.2	731.0 ± 0.2
12		728.0 ± 0.5	728.0 ± 0.5
13		513.6	513.6
14		1670	1670
15		$\phi 90^{+0.2}_{-0} / -0.036 / -0.090$	$\phi 90^{+0.2}_{-0} / -0.036 / -0.090$
16		345.0 ± 0.5	345.0 ± 0.5
17		$\phi 90^{+0.2}_{-0} / -0.036 / -0.090$	$\phi 90^{+0.2}_{-0} / -0.036 / -0.090$
18	Arm as individual part	$330^{0}_{-0.5}$	$330^{0}_{-0.5}$
	When press fitting bushing	345	345
19	Min.	1990	1990
	Max.	3275	3275

2. BUCKET



SAP00447

020706

MAINTENANCE STANDARD

WORK EQUIPMENT

Unit: mm

No.	Model	PC300-6	PC350-6
1		512.2 ± 0.5	512.2 ± 0.5
2		37.9 ± 0.5	37.9 ± 0.5
3		94°19'	93°12'
4		513.6	513.6
5		1658	1663
6		193	173
7		—	—
8		50°	42°
9		$\phi 90^{+0.2}_0$	$\phi 90^{+0.2}_0$
10		346^{+1}_0	346^{+1}_0
11		68	68
12		138	138
13		525.5 ± 0.5	525.5 ± 0.5
14		$\phi 26$	$\phi 26$
15		$\phi 170$	$\phi 170$
16		$\phi 200$	$\phi 200$
17		146.1	135.5
18		137.6	142.0
19		R115	R115
20		R100	R100
21		370^{+2}_0	370^{+2}_0
22		60	60

020706


90 OTHERS

Hydraulic piping diagram (10-12)	90- 3
Hydraulic circuit diagram (10-13)	90- 5
Control valve	
10-spool valve (10-38)	90- 7
9-spool valve (10-44)	90- 9
8-spool valve (10-45)	90-11
7-spool valve (10-46)	90-13
Operation for each function	
of CLSS (10-52)	90-13-1
Operation of whole CLSS system	
1. When all work equipment is	
at neutral (10-72)	90-15
2. Pump flow merged, bucket CURL	
operated independently (10-74)	90-17
3. Pump flow merged, boom RAISE	
operated independently (10-76)	90-19
4. Pump flow merged, arm IN operated	
independently (10-78)	90-21
5. Pump flow merged, arm OUT	
operated independently (10-80)	90-23
6. Pump flow divided, travel operated	
independently (10-82)	90-25
7. Pump flow merged, arm IN + boom	
RAISE operated simultaneously	
(10-84)	90-27
8. Pump flow merged, swing + boom	
RAISE operated simultaneously	
(10-86)	90-29
9. Pump flow divided (pump pressure:	
19.6 MPa (200 kg/cm ²) or above),	
travel + boom RAISE operated	
simultaneously (10-88)	90-31
10. Pump flow divided (pump pressure:	
19.6 MPa (200 kg/cm ²) or above),	
travel + arm IN operated	
simultaneously (10-90)	90-33
Actual electric wiring diagram (10-138)	90-35
Actual electric wiring diagram	
(10-139)	90-35-1
Electric circuit diagram (10-140)	90-37
Electric circuit diagram (10-141)	90-39

Connector arrangement diagram	
(20-116)	90-39-1
Control valve (40-20)	90-41


★ This section has been enlarged to make it easier to read; the page number in () shows the original page.

HYDRAULIC PIPING DIAGRAM



020706


SBP00149



CONTROL VALVE

10-SPOOL VALVE (STD + SERVICE VALVE x 3)

020706




SAP00188

9-SPOOL VALVE (STD + SERVICE VALVE x 2)

★ For details of the names of the ports and the main structure, see 10-SPOOL VALVE.

020706




SAP00195

8-SPOOL VALVE (STD + SERVICE VALVE x 1)

★ For details of the names of the ports and the main structure, see 10-SPOOL VALVE.

020706




SAP00196

7-SPOOL VALVE (STD)

★ For details of the names of the ports and the main structure, see 10-SPOOL VALVE.


020706



SAP00197

OPERATION FOR EACH FUNCTION OF CLSS

Hydraulic circuit diagram for system




OPERATION OF WHOLE CLSS SYSTEM

1. When all work equipment is at neutral


- ★ The diagram shows the situation when all work equipment is at neutral.
- ★ The valves and circuits that are not connected with the explanation of the operation of the CLSS hydraulic system have been omitted.

020706



SAP00231


2. Pump flow merged, bucket CURL operated independently



020706

SAP00232

3. Pump flow merged, boom RAISE operated independently
(Boom Lo valve + boom Hi valve)




020706

SAP00233

4. Pump flow merged, arm IN operated independently
(Arm Lo valve + Arm Hi valve)


020706



SAP00234


5. Pump flow merged, arm OUT operated independently
(Return circuit arm Lo + arm Hi)

020706



SAP00235

6. Pump flow divided, travel operated independently




020706

SAP00236


7. Pump flow merged, arm IN + boom RAISE operated simultaneously

020706




SAP00237

8. Pump flow merged, swing + boom RAISE operated simultaneously



SAP00238


9. Pump flow divided (pump pressure: 19.6 MPa (200 kg/cm²) or above), travel + boom RAISE operated simultaneously



SAP00240

10. Pump flow divided (pump pressure: 19.6 MPa (200 kg/cm²) or above), travel + arm IN operated simultaneously


020706





SAP00241

ACTUAL ELECTRIC WIRING DIAGRAM


020706






1. Working lamp
2. Front pump pressure sensor
3. Rear pump pressure sensor
4. Radiator water level sensor
5. Engine speed sensor
6. Front pump TVC solenoid
7. Rear pump TVC solenoid
8. Window washer tank
9. Hydraulic oil level sensor
10. LS control EPC valve
11. Horn (high tone)
12. Horn (low tone)
13. Battery relay
14. Battery
15. Right head lamp
16. Fuel level sensor
17. Swing pressure switch
18. Bucket DUMP pressure switch
19. Bucket CURL pressure switch
20. Arm IN pressure switch
21. Boom LOWER pressure switch
22. Arm OUT pressure switch
23. Travel pressure switch
24. Boom RAISE pressure switch
25. Swing brake solenoid valve
26. Travel speed solenoid valve
27. Pump merge/divider solenoid valve
28. Boom Hi 2-stage safety solenoid valve
29. LS select solenoid valve
30. Engine water temperature sensor
31. Intake air heater
32. Engine oil pressure sensor
33. Starting motor
34. Air conditioner compressor
35. Engine oil level sensor
36. Alternator
37. Wiper motor
38. Horn switch
39. Additional right head lamp
40. Right front lock
41. Room lamp
42. Auto pull-up motor
43. Window limit switch (rear)
44. Left front lock
45. Window limit switch (front)
46. Additional left head lamp
47. Left knob switch
48. Fuse box
49. Alarm buzzer
50. Starting switch
51. Fuel control dial
52. Cigarette lighter
53. Swing lock switch
54. Wiper, washer switch
55. Lamp switch
56. Buzzer cancel switch
57. Car heater fan switch
58. Machine push-up switch
59. Front window auto pull-up switch
60. Speaker
61. Kerosene mode connector
62. Air conditioner control panel
63. Governor, pump controller
64. Radio
65. TVC prolix resistor
66. Wiper motor controller
67. Lamp relay
68. Lamp relay
69. Monitor panel
70. Swing prolix switch
71. Pump prolix switch


020706





CONNECTOR ARRANGEMENT DIAGRAM

020706




BBP00322

CONTROL VALVE

10-SPOOL VALVE

★ For details of the 9-, 8-, 7-spool valves, see 10-SPOOL VALVE.



★ When tightening the bolts at the places marked ★, always use 2 washers on top of each other.

