

SHOP MANUAL

KOMATSU

PC340, PC340LC-6k PC340NLC-6k

MACHINE MODEL

SERIAL NUMBER

PC340-6k

K30001 and up

PC340LC -6k

K30001 and up

PC340NLC-6k

K30001 and up

- This shop manual may contain attachments and optional equipment that are not available in your area. Please consult your local Komatsu distributor for those items you may require. Materials and specifications are subject to change without notice.
- PC340-6K mount the SA6D114E-1 engine.
For details of the engine, see the Engine Shop Manual.

The affected pages are indicated by the use of the following marks. It is requested that necessary actions be taken to these pages according to the table below.

Mark	Indication	Action required
○	Page to be newly added	Add
●	Page to be replaced	Replace
()	Page to be deleted	Discard

Pages having no marks are those previously revised or made additions.

LIST OF REVISED PAGES

Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision
●	00-1	④		10-2			10-38			10-74			10-108	
	00-2	④		10-3			10-39			10-75			10-109	
●	00-2-1	④		10-4			10-40			10-76			10-110	
●	00-2-2	④		10-5			10-41			10-77			10-111	
●	00-2-3	④		10-6			10-42			10-78			10-112	
●	00-2-4	④		10-7			10-43			10-79			10-113	
	00-3			10-8			10-44			10-80			10-114	
	00-4			10-9			10-45			10-81			10-115	
	00-5			10-10			10-47			10-82			10-116	
	00-6			10-12			10-49			10-83			10-117	
	00-7			10-13			10-50			10-84			10-118	
	00-8			10-14			10-51			10-85			10-120	
	00-9			10-15			10-52			10-86			10-121	
	00-10			10-16			10-53			10-87			10-122	
	00-11			10-17			10-54			10-88			10-123	
	00-12			10-18			10-55			10-89			10-124	
	00-13			10-19			10-56			10-90			10-125	
	00-14			10-20			10-57			10-91			10-126	
	00-15			10-22			10-58			10-92			10-127	
	00-16			10-23			10-59			10-93			10-128	
	00-17			10-24			10-60			10-94			10-129	
				10-25			10-61			10-95			10-130	
				10-26			10-62			10-96			10-131	
	01-1			10-27			10-63			10-98			10-132	
	01-2			10-28			10-64			10-99			10-133	
●	01-3	①		10-29			10-65			10-100			10-134	
	01-4			10-30			10-66			10-101			10-135	
	01-5			10-31			10-67			10-102			10-136	
	01-6			10-32			10-68			10-103			10-137	
	01-7			10-33			10-69			10-104		●	10-138	④
	01-8			10-34			10-70			10-105			10-139	
	01-9			10-35			10-72			10-106		●	10-139-1	④
●	10-1	①		10-36			10-73			10-107		○	10-140	④

Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision
	10-140			20-9		○	20-101	①	○	20-252	①		20-323	
	10-141			20-10		○	20-102	①	○	20-253	①		20-324	
●	10-142	①		20-11		○	20-103	①	○	20-254	①		20-325	
	10-143			20-12		○	20-104	①	○	20-255	①		20-326	
	10-144			20-13		○	20-105	①	○	20-256	①		20-327	
	10-145			20-14		○	20-106	①	○	20-257	①		20-328	
	10-146			20-15		○	20-107	①	○	20-258	①		20-329	
	10-147			20-16		○	20-108	①	○	20-259	①		20-330	
	10-148			20-17		○	20-109	①	○	20-260	①		20-331	
	10-149			20-18		○	20-110	①	○	20-261	①		20-332	
	10-150			20-20		○	20-111	①	○	20-262	①		20-333	
	10-151			20-21		○	20-112	①	○	20-263	①		20-334	
	10-152			20-22		○	20-113	①	○	20-264	①		20-335	
	10-153			20-23		○	20-114	①	○	20-265	①		20-336	
●	10-154	①		20-24		○	20-115	①	○	20-266	①		20-337	
	10-155			20-25		○	20-116	①	○	20-267	①		20-338	
	10-156			20-26		○	20-117	①	○	20-268	①		20-339	
	10-157			20-27		○	20-118	①	○	20-269	①		20-340	
	10-158			20-28		○	20-119	①	○	20-270	①		20-341	
	10-159			20-29		○	20-120	①	○	20-271	①		20-342	
	10-160			20-30		○	20-121	①	○	20-272	①		20-343	
	10-161			20-31		○	20-122	①	○	20-273	①		20-344	
	10-162			20-32		○	20-123	①	○	20-274	①		20-345	
	10-163			20-33		○	20-124	①	○	20-275	①			
	10-164			20-34		○	20-125	①	○	20-276	①			
	10-165			20-35		○	20-126	①	○	20-277	①	○	20-351	①
	10-166		●	20-36	③	○	20-127	①	○	20-278	①	○	20-352	①
	10-167			20-37		○	20-128	①	○	20-279	①	○	20-354	①
	10-168			20-38		○	20-129	①	○	20-280	①	○	20-355	①
	10-169			20-39		○	20-130	①	○	20-281	①	○	20-356	①
	10-170			20-40		○	20-131	①				○	20-357	①
●	10-171	③		20-41		○	20-132	①				○	20-358	①
	10-172			20-42		○	20-133	①		20-301		○	20-359	①
	10-173			20-43		○	20-134	①		20-302		○	20-360	①
	10-174			20-44		○	20-135	①		20-303		○	20-361	①
	10-175			20-45		○	20-136	①		20-304		○	20-362	①
	10-176			20-46		○	20-137	①		20-305		○	20-363	①
	10-177			20-47		○	20-138	①		20-306		○	20-364	①
	10-178			20-48		○	20-139	①		20-307		○	20-365	①
	10-179			20-49		○	20-140	①		20-308		○	20-366	①
	10-180			20-50		○	20-141	①		20-309		○	20-367	①
	10-181			20-51		○	20-142	①		20-310		○	20-368	①
	10-182			20-52		○	20-143	①		20-311		○	20-369	①
	10-183			20-53		○	20-144	①		20-312		○	20-370	①
				20-54		○	20-145	①		20-313		○	20-371	①
				20-55		○	20-146	①		20-314		○	20-372	①
	20-1			20-56						20-315		○	20-373	①
	20-2			20-57						20-316		○	20-374	①
	20-3			20-58		○	20-201	①		20-317		○	20-375	①
	20-4			20-59		○	20-202	①		20-318		○	20-376	①
	20-5			20-60		○	20-203	①		20-319		○	20-377	①
	20-6			20-61						20-320		○	20-378	①
	20-7									20-321		○	20-379	①
	20-8					○	20-251	①		20-322		○	20-380	①

Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision
o	20-381	①	o	20-478	①		30-5			30-61			30-115	
o	20-382	①	o	20-479	①		30-6			30-62			30-116	
o	20-383	①	o	20-480	①		30-9			30-63			30-117	
o	20-384	①	o	20-481	①		30-10			30-64			30-118	
o	20-385	①	o	20-482	①		30-11			30-65			30-119	
o	20-386	①	o	20-483	①		30-12			30-66			30-120	
o	20-387	①	o	20-484	①		30-13			30-67			30-121	
o	20-388	①	o	20-485	①		30-14			30-68			30-122	
o	20-389	①					30-15			30-69			30-123	
o	20-390	①					30-16			30-70			30-124	
o	20-391	①	o	20-501	①		30-17			30-71			30-125	
o	20-392	①	o	20-502	①		30-18			30-72			30-126	
			o	20-504	①		30-19			30-73			30-127	
			o	20-505	①		30-20			30-74			30-128	
o	20-401	①	o	20-506	①		30-21			30-75			30-129	
o	20-401-1	①	o	20-507	①		30-22			30-76			30-130	
o	20-402	①	o	20-508	①		30-23			30-77			30-131	
o	20-403	①	o	20-509	①		30-24			30-78			30-132	
o	20-404	①	o	20-510	①		30-25			30-79			30-133	
o	20-405	①	o	20-511	①		30-26			30-80			30-134	
o	20-406	①	o	20-512	①		30-27			30-81			30-135	
o	20-407	①	o	20-513	①		30-28			30-82			30-136	
o	20-408	①	o	20-514	①		30-29			30-83			30-137	
o	20-409	①	o	20-515	①		30-30			30-84			30-138	
o	20-410	①	o	20-516	①		30-31			30-85			30-139	
o	20-411	①	o	20-517	①		30-32			30-86			30-140	
o	20-412	①	o	20-518	①		30-33			30-87				
			o	20-519	①		30-34			30-88			40-1	
o	20-451	①	o	20-520	①		30-35			30-89			40-2	
o	20-452	①	o	20-521	①		30-36			30-90			40-3	
o	20-454	①	o	20-522	①		30-37			30-91			40-4	
o	20-455	①	o	20-523	①		30-38			30-92			40-6	
o	20-456	①	o	20-524	①		30-39			30-93			40-7	
o	20-457	①	o	20-525	①		30-40			30-94	•		40-8	④
o	20-458	①	o	20-526	①		30-41			30-95			40-10	
o	20-459	①	o	20-527	①		30-42			30-96			40-11	
o	20-460	①	o	20-528	①		30-43			30-97			40-12	
o	20-461	①	o	20-529	①		30-44			30-98			40-13	
o	20-462	①	o	20-530	①		30-45			30-99			40-14	
o	20-463	①	o	20-531	①		30-46			30-100	•		40-15	④
o	20-464	①	o	20-532	①		30-47			30-101			40-16	
o	20-465	①	o	20-533	①		30-48			30-102			40-17	
o	20-466	①	o	20-534	①		30-49			30-103			40-18	
o	20-467	①	o	20-535	①		30-50			30-104			40-19	
o	20-468	①	o	20-536	①		30-51			30-105			40-20	
o	20-469	①					30-52			30-106			40-21	
o	20-470	①					30-53			30-107			40-22	
o	20-471	①	o	20-541	①		30-54			30-108			40-23	
o	20-472	①	o	20-542	①		30-55			30-109			40-24	
o	20-473	①					30-56			30-110			40-25	
o	20-474	①		30-1			30-57			30-111			40-26	
o	20-475	①		30-2			30-58			30-112			40-27	
o	20-476	①		30-3			30-59			30-113			40-28	
o	20-477	①		30-4			30-60			30-114			40-29	

Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision
	40-30													
	40-31													
	40-32													
●	40-33	③												
	40-35													
●	40-36	③												
	40-37													
	40-38													
○	90-3	②												
○	90-5	②												
○	90-7	②												
○	90-9	②												
○	90-11	②												
○	90-13-1	②												
○	90-15	②												
○	90-17	②												
○	90-19	②												
○	90-21	②												
○	90-23	②												
○	90-25	②												
○	90-27	②												
○	90-29	②												
○	90-31	②												
○	90-33	②												
○	90-35	②												
○	90-35-1	②												
○	90-37	②												
○	90-39	②												
○	90-39-1	②												
○	90-41	②												

FOREWORD

GENERAL

This shop manual has been prepared as an aid to improve the quality of repairs by giving the serviceman an accurate understanding of the product and by showing him the correct way to perform repairs and make judgements. Make sure you understand the contents of this manual and use it to full effect at every opportunity.

This shop manual mainly contains the necessary technical information for operations performed in a service workshop. For ease of understanding, the manual is divided into the following chapters; these chapters are further divided into the each main group of components.

STRUCTURE AND FUNCTION

This section explains the structure and function of each component. It serves not only to give an understanding of the structure, but also serves as reference material for troubleshooting.

TESTING AND ADJUSTING

This section explains checks to be made before and after performing repairs, as well as adjustments to be made at completion of the checks and repairs.

Troubleshooting charts correlating "Problems" to "Causes" are also included in this section.

DISASSEMBLY AND ASSEMBLY

This section explains the order to be followed when removing, installing, disassembling or assembling each component, as well as precautions to be taken for these operations.

MAINTENANCE STANDARD

This section gives the judgement standards when inspecting disassembled parts.

NOTICE

The specifications contained in this shop manual are subject to change at any time and without any advance notice. Use the specifications given in the book with the latest date.

HOISTING INSTRUCTIONS

HOISTING

⚠ Heavy parts (25 kg or more) must be lifted with a hoist, etc. In the **DISASSEMBLY AND ASSEMBLY** section, every part weighing 25 kg or more is indicated clearly with the symbol .

- If a part cannot be smoothly removed from the machine by hoisting, the following checks should be made:
 - 1) Check for removal of all bolts fastening the part to the relative parts.
 - 2) Check for existence of another part causing interference with the part to be removed.


WIRE ROPES

- 1) Use adequate ropes depending on the weight of parts to be hoisted, referring to the table below:

Wire ropes (Standard "Z" or "S" twist ropes without galvanizing)	
Rope diameter (mm)	Allowable load (tons)
10	1.0
11.2	1.4
12.5	1.6
14	2.2
16	2.8
18	3.6
20	4.4
22.4	5.6
30	10.0
40	18.0
50	28.0
60	40.0

- ★ The allowable load value is estimated to be one-sixth or one-seventh of the breaking strength of the rope used.
- 2) Sling wire ropes from the middle portion of the hook.

Slinging near the edge of the hook may cause the rope to slip off the hook during hoisting, and a serious accident can result. Hooks have maximum strength at the middle portion.




SAD00479

- 3) Do not sling a heavy load with one rope alone, but sling with two or more ropes symmetrically wound onto the load.

⚠ Slinging with one rope may cause turning of the load during hoisting, untwisting of the rope, or slipping of the rope from its original winding position on the load, which can result in a dangerous accident.

- 4) Do not sling a heavy load with ropes forming a wide hanging angle from the hook. When hoisting a load with two or more ropes, the force subjected to each rope will increase with the hanging angles. The table below shows the variation of allowable load (kg) when hoisting is made with two ropes, each of which is allowed to sling up to 1000 kg vertically, at various hanging angles.

When two ropes sling a load vertically, up to 2000 kg of total weight can be suspended. This weight becomes 1000 kg when two ropes make a 120° hanging angle. On the other hand, two ropes are subjected to an excessive force as large as 4000 kg if they sling a 2000 kg load at a lifting angle of 150°.



FOREWORD

COATING MATERIALS

COATING MATERIALS

The recommended coating materials prescribed in Komatsu Shop Manuals are listed below.

Category	Komatsu code	Part No.	Q'ty	Container	Main applications, features
Adhesive	LT-1A	790-129-9030	150 g	Tube	Used to prevent rubber gaskets, rubber cushions, and cork plugs from coming out
	LT-1B	790-129-9050	20 g (x2)	Plastic container	Used in places requiring an immediately effective, strong adhesive. Used for plastics (except polyethylene, polypropylene, tetrafluoroethylene, and vinyl chloride), rubber, metal, and non-metal.
	LT-2	09940-00030	50 g	Plastic container	- Features: Resistance to heat, chemicals - Used for anti-loosening and sealant purposes for bolts and plugs.
	LT-3	790-129-9060 (Set of adhesive and hardening agent)	Adhesive :1 Kg Hardening agent: :500 g	Can	Used as adhesive or sealant for metal, glass, plastic
	LT-4	790-129-9040	250 g	Plastic container	Used as sealant for machined holes
	(Loctite 648-50)	79A-129-9110	50 cc	—	- Features: Resistance to heat, chemicals - Used at joint portions subject to high temperature
Gasket sealant	LG-1	790-129-9010	200 g	Tube	Used as adhesive or sealant for gaskets and packings of power train case, etc.
	LG-3	790-129-9070	1 Kg	Can	- Features: Resistance to heat - Used as sealant for flange surfaces and bolts at high temperature locations, used to prevent seizure - Used as sealant for heat resistant gasket for high temperature locations such as engine precombustion chamber, exhaust pipe
	LG-4	790-129-9020	200 g	Tube	- Features: Resistance to water, oil - Used as sealant for flange surface, thread - Also possible to use as sealant for flanges with large clearance - Used as sealant for mating surfaces of final drive case, transmission case
	LG-5	790-129-9080	1 Kg	Plastic container	- Used as sealant for various threads, pipe joints, flanges - Used as sealant for tapered plugs, elbows, nipples of hydraulic piping
	LG-6	09940-00011	250 g	Tube	- Features: Silicon based, resistance to heat, cold - Used as sealant for flange surface, thread - Used as sealant for oil pan, final drive case, etc.
	LG-7	09920-00150	150 g	Tube	- Features: Silicon based, quick hardening type - Used as sealant for flywheel housing, intake manifold, oil pan, thermostat housing, etc.
Rust prevention lubricant	—	09940-00051	60 g	Can	Used as lubricant for sliding parts (to prevent squeaking)
Molybdenum disulphide lubricant	—	09940-00040	200 g	Tube	- Used to prevent seizure or scuffing of the thread when press fitting or shrink fitting - Used as lubricant for linkage, bearings, etc.
Lithium grease	G2-LI	SYG-350LI SYG-400LI SYG-400LI-A SYG-160LI SYGA-160CNLI	Various	Various	General purpose type
Calcium grease	G2-CA	SSG2-400CA SYG2-350CA SYG2-400CA-A SYG2-160CA SYGA-160CNCA	Various	Various	Used for normal temperature, light load bearing at places in contact with water or steam
Molybdenum disulphide grease	—	SYG2-400M	400 g (10 per case)	Bellows type	Used for places with heavy load

STANDARD TIGHTENING TORQUE

STANDARD TIGHTENING TORQUES OF BOLTS AND NUTS

The following charts give the standard tightening torques of bolts and nuts. Exceptions are given in section of **DISASSEMBLY AND ASSEMBLY**.

1 Kgm = 9.806 Nm

Thread diameter of bolt	Width across flats		
		kgm	Nm
6	10	1.35 ± 0.15	13.2 ± 1.4
8	13	3.2 ± 0.3	31.4 ± 2.9
10	17	6.7 ± 0.7	65.7 ± 6.8
12	19	11.5 ± 1.0	112 ± 9.8
14	22	18.0 ± 2.0	177 ± 19
16	24	28.5 ± 3	279 ± 29
18	27	39 ± 4	383 ± 39
20	30	56 ± 6	549 ± 58
22	32	76 ± 8	745 ± 78
24	36	94.5 ± 10	927 ± 98
27	41	135 ± 15	1320 ± 140
30	46	175 ± 20	1720 ± 190
33	50	225 ± 25	2210 ± 240
36	55	280 ± 30	2750 ± 290
39	60	335 ± 35	3280 ± 340

- ★ This torque table does not apply to the bolts with which nylon packings or other nonferrous metal washers are to be used, or which require tightening to otherwise specified torque.

FOREWORD

STANDARD TIGHTENING TORQUE


TIGHTENING TORQUE OF SPLIT FLANGE BOLTS

Use these torques for split flange bolts.

Thread diameter of bolt	Width across flats	Tightening torque	
mm	mm	kgm	Nm
10	14	6.7 ± 0.7	65.7 ± 6.8
12	17	11.5 ± 1	112 ± 9.8
16	22	28.5 ± 3	279 ± 29

TIGHTENING TORQUE FOR FLARED NUTS

Use these torques for flared part of nut.



Thread diameter of nut part	Width across flats of nut part	Tightening torque	
mm	mm	kgm	Nm
14	19	2.5 ± 0.5	24.5 ± 4.9
18	24	5 ± 2	49 ± 19.6
22	27	8 ± 2	78.5 ± 19.6
24	32	14 ± 3	137.3 ± 29.4
30	36	18 ± 3	176.5 ± 29.4
33	41	20 ± 5	196.1 ± 49
36	46	25 ± 5	245.2 ± 49
42	55	30 ± 5	294.2 ± 49

ELECTRIC WIRE CODE

In the wiring diagrams, various colors and symbols are employed to indicate the thickness of wires. This wire code table will help you understand WIRING DIAGRAMS.

Example: 5WB indicates a cable having a nominal number 5 and white coating with black stripe.

CLASSIFICATION BY THICKNESS

Nominal number	Copper wire			Cable O.D. (mm)	Current rating (A)	Applicable circuit
	Number of strands	Dia. of strands (mm)	Cross section (mm ²)			
0.85	11	0.32	0.88	2.4	12	Starting, lighting, signal etc.
2	26	0.32	2.09	3.1	20	Lighting, signal etc.
5	65	0.32	5.23	4.6	37	Charging and signal
15	84	0.45	13.36	7.0	59	Starting (Glow plug)
40	85	0.80	42.73	11.4	135	Starting
60	127	0.80	63.84	13.6	178	Starting
100	217	0.80	109.1	17.6	230	Starting

CLASSIFICATION BY COLOR AND CODE

Priority	Circuits		Charging	Ground	Starting	Lighting	Instrument	Signal	Other
	Classification								
1	Primary	Code	W	B	B	R	Y	G	L
		Color	White	Black	Black	Red	Yellow	Green	Blue
2	Auxiliary	Code	WR	—	BW	RW	YR	GW	LW
		Color	White & Red	—	Black & White	Red & White	Yellow & Red	Green & White	Blue & White
Code		WB	—	BY	RB	YB	GR	LR	
Color		White & Black	—	Black & Yellow	Red & Black	Yellow & Black	Green & Red	Blue & Red	
Code		WL	—	BR	RY	YG	GY	LY	
Color		White & Blue	—	Black & Red	Red & Yellow	Yellow & Green	Green & Yellow	Blue & Yellow	
Code		WG	—	—	RG	YL	GB	LB	
Color		White & Green	—	—	Red & Green	Yellow & Blue	Green & Black	Blue & Black	
Code		—	—	—	RL	YW	GL	—	
Color		—	—	—	Red & Blue	Yellow & White	Green & Blue	—	

CONVERSION TABLE

METHOD OF USING THE CONVERSION TABLE

The Conversion Table in this section is provided to enable simple conversion of figures. For details of the method of using the Conversion Table, see the example given below.

EXAMPLE

- Method of using the Conversion Table to convert from millimeters to inches
1. Convert 55 mm into inches.
 - (1) Locate the number 50 in the vertical column at the left side, take this as (A), then draw a horizontal line from (A).
 - (2) Locate the number 5 in the row across the top, take this as (B), then draw a perpendicular line down from (B).
 - (3) Take the point where the two lines cross as (C). This point (C) gives the value when converting from millimeters to inches. Therefore, 55 mm = 2.165 inches.
 2. Convert 550 mm into inches.
 - (1) The number 550 does not appear in the table, so divide by 10 (move the decimal point one place to the left) to convert it to 55 mm.
 - (2) Carry out the same procedure as above to convert 55 mm to 2.165 inches.
 - (3) The original value (550 mm) was divided by 10, so multiply 2.165 inches by 10 (move the decimal point one place to the right) to return to the original value. This gives 550 mm = 21.65 inches.

Millimeters to inches

1 mm = 0.03937 in

	0	1	2	3	4	5	6	7	8	9
0	0	0.039	0.079	0.118	0.157	0.197	0.236	0.276	0.315	0.354
10	0.394	0.433	0.472	0.512	0.551	0.591	0.630	0.669	0.709	0.748
20	0.787	0.827	0.866	0.906	0.945	0.984	1.024	1.063	1.102	1.142
30	1.181	1.220	1.260	1.299	1.339	1.378	1.417	1.457	1.496	1.536
40	1.575	1.614	1.654	1.693	1.732	1.772	1.811	1.850	1.890	1.929
(A) 50	1.969	2.008	2.047	2.087	2.126	2.165	2.205	2.244	2.283	2.323
60	2.362	2.402	2.441	2.480	2.520	2.559	2.598	2.638	2.677	2.717
70	2.756	2.795	2.835	2.874	2.913	2.953	2.992	3.032	3.071	3.110
80	3.150	3.189	3.228	3.268	3.307	3.346	3.386	3.425	3.465	3.504
90	3.543	3.583	3.622	3.661	3.701	3.740	3.780	3.819	3.858	3.898

FOREWORD**CONVERSION TABLE****Millimeters to Inches**

1 mm = 0.03937 in

	0	1	2	3	4	5	6	7	8	9
0	0	0.039	0.079	0.118	0.157	0.197	0.236	0.276	0.315	0.354
10	0.394	0.433	0.472	0.512	0.551	0.591	0.630	0.669	0.709	0.748
20	0.787	0.827	0.866	0.906	0.945	0.984	1.024	1.063	1.102	1.142
30	1.181	1.220	1.260	1.299	1.339	1.378	1.417	1.457	1.496	1.536
40	1.575	1.614	1.654	1.693	1.732	1.772	1.811	1.850	1.890	1.929
50	1.969	2.008	2.047	2.087	2.126	2.165	2.205	2.244	2.283	2.323
60	2.362	2.402	2.441	2.480	2.520	2.559	2.598	2.638	2.677	2.717
70	2.756	2.795	2.835	2.874	2.913	2.953	2.992	3.032	3.071	3.110
80	3.150	3.189	3.228	3.268	3.307	3.346	3.386	3.425	3.465	3.504
90	3.543	3.583	3.622	3.661	3.701	3.740	3.780	3.819	3.858	3.898

Kilogram to Pound

1 kg = 2.2046 lb

	0	1	2	3	4	5	6	7	8	9
0	0	2.20	4.41	6.61	8.82	11.02	13.23	15.43	17.64	19.84
10	22.05	24.25	26.46	28.66	30.86	33.07	35.27	37.48	39.68	41.89
20	44.09	46.30	48.50	50.71	51.91	55.12	57.32	59.53	61.73	63.93
30	66.14	68.34	70.55	72.75	74.96	77.16	79.37	81.57	83.78	85.98
40	88.18	90.39	92.59	94.80	97.00	99.21	101.41	103.62	105.82	108.03
50	110.23	112.44	114.64	116.85	119.05	121.25	123.46	125.66	127.87	130.07
60	132.28	134.48	136.69	138.89	141.10	143.30	145.51	147.71	149.91	152.12
70	154.32	156.53	158.73	160.94	163.14	165.35	167.55	169.76	171.96	174.17
80	176.37	178.57	180.78	182.98	185.19	187.39	189.60	191.80	194.01	196.21
90	198.42	200.62	202.83	205.03	207.24	209.44	211.64	213.85	216.05	218.26

FOREWORD**CONVERSION TABLE****Liter to U.S. Gallon**

1ℓ = 0.2642 U.S. Gal

	0	1	2	3	4	5	6	7	8	9
0	0	0.264	0.528	0.793	1.057	1.321	1.585	1.849	2.113	2.378
10	2.642	2.906	3.170	3.434	3.698	3.963	4.227	4.491	4.755	5.019
20	5.283	5.548	5.812	6.076	6.340	6.604	6.869	7.133	7.397	7.661
30	7.925	8.189	8.454	8.718	8.982	9.246	9.510	9.774	10.039	10.303
40	10.567	10.831	11.095	11.359	11.624	11.888	12.152	12.416	12.680	12.944
50	13.209	13.473	13.737	14.001	14.265	14.529	14.795	15.058	15.322	15.586
60	15.850	16.115	16.379	16.643	16.907	17.171	17.435	17.700	17.964	18.228
70	18.492	18.756	19.020	19.285	19.549	19.813	20.077	20.341	20.605	20.870
80	21.134	21.398	21.662	21.926	22.190	22.455	22.719	22.983	23.247	23.511
90	23.775	24.040	24.304	24.568	24.832	25.096	25.361	25.625	25.889	26.153

Liter to U.K. Gallon

1ℓ = 0.21997 U.K. Gal

	0	1	2	3	4	5	6	7	8	9
0	0	0.220	0.440	0.660	0.880	1.100	1.320	1.540	1.760	1.980
10	2.200	2.420	2.640	2.860	3.080	3.300	3.520	3.740	3.950	4.179
20	4.399	4.619	4.839	5.059	5.279	5.499	5.719	5.939	6.159	6.379
30	6.599	6.819	7.039	7.259	7.479	7.699	7.919	8.139	8.359	8.579
40	8.799	9.019	9.239	9.459	9.679	9.899	10.119	10.339	10.559	10.778
50	10.998	11.281	11.438	11.658	11.878	12.098	12.318	12.528	12.758	12.978
60	13.198	13.418	13.638	13.858	14.078	14.298	14.518	14.738	14.958	15.178
70	15.398	15.618	15.838	16.058	16.278	16.498	16.718	16.938	17.158	17.378
80	17.598	17.818	18.037	18.257	18.477	18.697	18.917	19.137	19.357	19.577
90	19.797	20.017	20.237	20.457	20.677	20.897	21.117	21.337	21.557	21.777

FOREWORD**CONVERSION TABLE****kgm to ft. lb**

1 kgm = 7.233 ft. lb

	0	1	2	3	4	5	6	7	8	9
0	0	7.2	14.5	21.7	28.9	36.2	43.4	50.6	57.9	65.1
10	72.3	79.6	86.8	94.0	101.3	108.5	115.7	123.0	130.2	137.4
20	144.7	151.9	159.1	166.4	173.6	180.8	188.1	195.3	202.5	209.8
30	217.0	224.2	231.5	238.7	245.9	253.2	260.4	267.6	274.9	282.1
40	289.3	296.6	303.8	311.0	318.3	325.5	332.7	340.0	347.2	354.4
50	361.7	368.9	376.1	383.4	390.6	397.8	405.1	412.3	419.5	426.8
60	434.0	441.2	448.5	455.7	462.9	470.2	477.4	484.6	491.8	499.1
70	506.3	513.5	520.8	528.0	535.2	542.5	549.7	556.9	564.2	571.4
80	578.6	585.9	593.1	600.3	607.6	614.8	622.0	629.3	636.5	643.7
90	651.0	658.2	665.4	672.7	679.9	687.1	694.4	701.6	708.8	716.1
100	723.3	730.5	737.8	745.0	752.2	759.5	766.7	773.9	781.2	788.4
110	795.6	802.9	810.1	817.3	824.6	831.8	839.0	846.3	853.5	860.7
120	868.0	875.2	882.4	889.7	896.9	904.1	911.4	918.6	925.8	933.1
130	940.3	947.5	954.8	962.0	969.2	976.5	983.7	990.9	998.2	1005.4
140	1012.6	1019.9	1027.1	1034.3	1041.5	1048.8	1056.0	1063.2	1070.5	1077.7
150	1084.9	1092.2	1099.4	1106.6	1113.9	1121.1	1128.3	1135.6	1142.8	1150.0
160	1157.3	1164.5	1171.7	1179.0	1186.2	1193.4	1200.7	1207.9	1215.1	1222.4
170	1129.6	1236.8	1244.1	1251.3	1258.5	1265.8	1273.0	1280.1	1287.5	1294.7
180	1301.9	1309.2	1316.4	1323.6	1330.9	1338.1	1345.3	1352.6	1359.8	1367.0
190	1374.3	1381.5	1388.7	1396.0	1403.2	1410.4	1417.7	1424.9	1432.1	1439.4

FOREWORD**CONVERSION TABLE****kg/cm² to lb/in²**1kg/cm² = 14.2233 lb/in²

	0	1	2	3	4	5	6	7	8	9
0	0	14.2	28.4	42.7	56.9	71.1	85.3	99.6	113.8	128.0
10	142.2	156.5	170.7	184.9	199.1	213.4	227.6	241.8	256.0	270.2
20	284.5	298.7	312.9	327.1	341.4	355.6	369.8	384.0	398.3	412.5
30	426.7	440.9	455.1	469.4	483.6	497.8	512.0	526.3	540.5	554.7
40	568.9	583.2	597.4	611.6	625.8	640.1	654.3	668.5	682.7	696.9
50	711.2	725.4	739.6	753.8	768.1	782.3	796.5	810.7	825.0	839.2
60	853.4	867.6	881.8	896.1	910.3	924.5	938.7	953.0	967.2	981.4
70	995.6	1010	1024	1038	1053	1067	1081	1095	1109	1124
80	1138	1152	1166	1181	1195	1209	1223	1237	1252	1266
90	1280	1294	1309	1323	1337	1351	1365	1380	1394	1408
100	1422	1437	1451	1465	1479	1493	1508	1522	1536	1550
110	1565	1579	1593	1607	1621	1636	1650	1664	1678	1693
120	1707	1721	1735	1749	1764	1778	1792	1806	1821	1835
130	1849	1863	1877	1892	1906	1920	1934	1949	1963	1977
140	1991	2005	2020	2034	2048	2062	2077	2091	2105	2119
150	2134	2148	2162	2176	2190	2205	2219	2233	2247	2262
160	2276	2290	2304	2318	2333	2347	2361	2375	2389	2404
170	2418	2432	2446	2460	2475	2489	2503	2518	2532	2546
180	2560	2574	2589	2603	2617	2631	2646	2660	2674	2688
190	2702	2717	2731	2745	2759	2773	2788	2802	2816	2830
200	2845	2859	2873	2887	2901	2916	2930	2944	2958	2973
210	2987	3001	3015	3030	3044	3058	3072	3086	3101	3115
220	3129	3143	3158	3172	3186	3200	3214	3229	3243	3257
230	3271	3286	3300	3314	3328	3343	3357	3371	3385	3399
240	3414	3428	3442	3456	3470	3485	3499	3513	3527	3542

FOREWORD

CONVERSION TABLE

Temperature

Fahrenheit-Centigrade Conversion ; a simple way to convert a Fahrenheit temperature reading into a Centigrade temperature reading or vice versa is to enter the accompanying table in the center or boldface column of figures.

These figures refer to the temperature in either Fahrenheit or Centigrade degrees.

If it is desired to convert from Fahrenheit to Centigrade degrees, consider the center column as a table of Fahrenheit temperatures and read the corresponding Centigrade temperature in the column at the left.

If it is desired to convert from Centigrade to Fahrenheit degrees, consider the center column as a table of Centigrade values, and read the corresponding Fahrenheit temperature on the right.

$$1^{\circ}\text{C} = 33.8^{\circ}\text{F}$$


°C		°F	°C		°F	°C		°F	°C		°F
-40.4	-40	-40.0	-11.7	11	51.8	7.8	46	114.8	27.2	81	117.8
-37.2	-35	-31.0	-11.1	12	53.6	8.3	47	116.6	27.8	82	179.6
-34.4	-30	-22.0	-10.6	13	55.4	8.9	48	118.4	28.3	83	181.4
-31.7	-25	-13.0	-10.0	14	57.2	9.4	49	120.2	28.9	84	183.2
-28.9	-20	-4.0	-9.4	15	59.0	10.0	50	122.0	29.4	85	185.0
-28.3	-19	-2.2	-8.9	16	60.8	10.6	51	123.8	30.0	86	186.8
-27.8	-18	-0.4	-8.3	17	62.6	11.1	52	125.6	30.6	87	188.6
-27.2	-17	1.4	-7.8	18	64.4	11.7	53	127.4	31.1	88	190.4
-26.7	-16	3.2	-7.2	19	66.2	12.2	54	129.2	31.7	89	192.2
-26.1	-15	5.0	-6.7	20	68.0	12.8	55	131.0	32.2	90	194.0
-25.6	-14	6.8	-6.1	21	69.8	13.3	56	132.8	32.8	91	195.8
-25.0	-13	8.6	-5.6	22	71.6	13.9	57	134.6	33.3	92	197.6
-24.4	-12	10.4	-5.0	23	73.4	14.4	58	136.4	33.9	93	199.4
-23.9	-11	12.2	-4.4	24	75.2	15.0	59	138.2	34.4	94	201.2
-23.3	-10	14.0	-3.9	25	77.0	15.6	60	140.0	35.0	95	203.0
-22.8	-9	15.8	-3.3	26	78.8	16.1	61	141.8	35.6	96	204.8
-22.2	-8	17.6	-2.8	27	80.6	16.7	62	143.6	36.1	97	206.6
-21.7	-7	19.4	-2.2	28	82.4	17.2	63	145.4	36.7	98	208.4
-21.1	-6	21.2	-1.7	29	84.2	17.8	64	147.2	37.2	99	210.2
-20.6	-5	23.0	-1.1	30	86.0	18.3	65	149.0	37.8	100	212.0
-20.0	-4	24.8	-0.6	31	87.8	18.9	66	150.8	40.6	105	221.0
-19.4	-3	26.6	0	32	89.6	19.4	67	152.6	43.3	110	230.0
-18.9	-2	28.4	0.6	33	91.4	20.0	68	154.4	46.1	115	239.0
-18.3	-1	30.2	1.1	34	93.2	20.6	69	156.2	48.9	120	248.0
-17.8	0	32.0	1.7	35	95.0	21.1	70	158.0	51.7	125	257.0
-17.2	1	33.8	2.2	36	96.8	21.7	71	159.8	54.4	130	266.0
-16.7	2	35.6	2.8	37	98.6	22.2	72	161.6	57.2	135	275.0
-16.1	3	37.4	3.3	38	100.4	22.8	73	163.4	60.0	140	284.0
-15.6	4	39.2	3.9	39	102.2	23.3	74	165.2	62.7	145	293.0
-15.0	5	41.0	4.4	40	104.0	23.9	75	167.0	65.6	150	302.0
-14.4	6	42.8	5.0	41	105.8	24.4	76	168.8	68.3	155	311.0
-13.9	7	44.6	5.6	42	107.6	25.0	77	170.6	71.1	160	320.0
-13.3	8	46.4	6.1	43	109.4	25.6	78	172.4	73.9	165	329.0
-12.8	9	48.2	6.7	44	111.2	26.1	79	174.2	76.7	170	338.0
-12.2	10	50.0	7.2	45	113.0	26.7	80	176.0	79.4	175	347.0

01 GENERAL

Specification drawings	01- 2
Specifications	01- 4
Weight table	01- 8
Fuel, coolant and lubricants	01-12

SPECIFICATION DRAWINGS



PC340, 340LC-6K



- ★ The figures in () indicate the PC340LC.
- ★ The values marked ※ are for shovel operations.

PC340NLC-6K

Unit: mm



GENERAL
SPECIFICATIONS
SPECIFICATIONS

Machine model				PC340-6K	PC340LC-6K	PC340NLC-6K
Serial Number				30001 and up	30001 and up	30001 and up
Bucket capacity		SAE/CECE (m³)		1.32/1.2	1.32/1.2	1.32/1.2
Operating weight		(kg)		32430	33530	33130
Performance	Working ranges	Max. digging depth	(mm)	7,380	7,380	7,380
		Max. vertical wall depth	(mm)	6,480	6,480	6,480
		Max. digging reach	(mm)	11,100	11,100	11,100
		Max. reach at ground level	(mm)	10,920	10,920	10,920
		Max. digging height	(mm)	10,210	10,210	10,210
		Max. dumping height	(mm)	7,110	7,110	7,110
		Max. digging force (using power max. function)	(kN(kg))	187.2 (19,100)	187.2 (19,100)	187.2 (19,100)
		Swing speed	(rpm)	10.0	10.0	10.0
		Swing max. slope angle	(deg.)	21.0	21.0	21.0
		Travel speed	(km/h)	Lo: 3.7 Mi: 4.5 HI: 5.5	Lo: 3.7 Mi: 4.5 HI: 5.5	Lo: 4.7 Mi: 4.5 HI: 5.5
		Gradeability	(deg.)	35	35	35
		Ground pressure		0.063 (0.64)	0.051 (0.52)	0.062 (0.3)
		[standard triple grouser shoe width]	(kg/cm²)	[600 mm]	[700 mm]	[700 mm]
Dimensions		Overall length (for transport)	(mm)	11015	11015	11015
		Overall width	(mm)	3,190	3,290	2,995
		Overall width of track	(mm)	3,190	3,290	2,990
		Overall height (for transport)	(mm)	3,255	3,255	3,265
		Overall height to top of cab	(mm)	3,130	3,130	3,130
		Ground clearance of counterweight	(mm)	1,186	1,186	1,186
		Min. ground clearance	(mm)	498	495	495
		Tail swing radius	(mm)	3375	3375	3375
		Min. swing radius of work equipment	(mm)	4,310	4,310	4,310
		Height of work equipment at min. swing radius	(mm)	8,440	8,440	8,440
		Length of track on ground	(mm)	3,700	4,030	4,030
		Track gauge	(mm)	2,590	2,590	2,390
		Height of machine cab	(mm)	2,580	2,580	2,580

GENERAL
SPECIFICATIONS

Unit: kg

Machine model		PC340-6K	PC340LC,NLC-6K
Serial Number		30001 and up	30001 and up
Engine	Model	SA6D114E-1	
	Type	4-cycle, water-cooled, in-line, vertical, direct injection with turbocharger and aftercooler (water cooled)	
	No. of cylinders - bore x stroke (mm)	6 - 114 x 135	
	Piston displacement (cc)	8,270	
	Performance	Flywheel horsepower (kW(HP)/rpm)	173 (232)/1,750
		Max. torque (Nm(kgm)/rpm)	980 (100)/1,400
		Max. speed at no load (rpm)	2,050
		Min. speed at no load (rpm)	900
		Min. fuel consumption (g/kW.h(g/HP.h))	205 (151)
	Starting motor		24,4 7.5 kW
	Alternator		24V, 45 kW
	Battery		12V, 160 Ah x 2
	Radiator core type		CWX-4
Under-Carriage	Carrier roller		2 on each side
	Track roller		7 on each side
	Track shoe		Assembly-type triple grouser
Hydraulic system	Hydraulic pump	Type x No.	Variable displacement piston type x 2; gear type x 1
		Delivery (✓ /min.)	Piston type: 250 x 2, gear type: 35
		Set pressure (MPa(kg/cm ²))	Piston type: 34.8 (355), gear type: 2.9 (30)
	Control valve	Type x No.	6-spool + 2-spool type x 1
		Control method	Hydraulic
	Hydraulic motor	Travel motor	Piston type (with brake valve, shaft brake): x 2
		Swing motor	Piston type (with safety valve, shaft brake): x 2
	Hydraulic cylinder		Double-acting piston
	Hydraulic tank		Box-shaped, sealed
	Hydraulic filter		Tank return side
	Hydraulic cooler		Air cooled

GENERAL
WEIGHT TABLE
WEIGHT TABLE

Unit: kg

Machine model	PC340-6K	PC340LC-6K	PC340NLC-6K
Serial Number	30001 and up	30001 and up	30001 and up
Engine assembly	1,000	1,000	1,000
• Engine	675	675	675
• Damper	14,7	14,7	14,7
• Hydraulic pump	200	200	200
Radiator, oil cooler assembly	165	165	165
Hydraulic tank, filter assembly (excl. hydraulic oil)	228	228	228
Fuel tank (excl. fuel)	218	218	218
Revolving frame	2,630	2,630	2,630
Operator's cab	287	287	287
Operator's seat	29	29	29
Counterweight	6,320	6,320	6,320
Swing machinery	380	380	380
Control valve (standard)	267	267	267
Swing motor	81	81	81
Travel motor	173 x 2	173 x 2	173 x 2
Center swivel joint	38	38	38
Track frame assembly	7,970	8,560	8,326
• Track frame	4,695	5,182	5,013
• Swing circle	487	487	487
• Idler	166	166	166
• Idler cushion	257 x 2	257 x 2	257 x 2
• Carrier roller	31 x 4	31 x 4	31 x 4
• Track roller	52 x 14	52 x 16	52 x 16
• Final drive (incl. travel motor)	595 x 2	595 x 2	595 x 2


GENERAL
WEIGHT TABLE


Unit: kg			
Machine model	PC340-6K	PC340LC-6K	PC340NLC-6K
Serial Number	30001 and up	30001 and up	30001 and up
Track shoe assembly			
Standard triple grouser shoe (600 mm)	3,600	3,840	3,340
Standard triple grouser shoe (700 mm)	3,940	4,220	-
Wide triple grouser shoe (800 mm)	4,300	4,560	-
Boom assembly	2,478	2,478	2,478
Arm assembly	1,615	1,615	1,615
Bucket assembly	1,014	1,014	1,014
Boom cylinder assembly	296 x 2	296 x 2	296 x 2
Arm cylinder assembly	425	425	425
Bucket cylinder assembly	263	263	263
Link assembly	320	320	320
Boom pin	76 + 15 x 2 + 56 + 17 + 42	76 + 15 x 2 + 56 + 17 + 42	76 + 15 x 2 + 56 + 17 + 42
Arm pin	13 + 17	13 + 17	13 + 17
Bucket pin	30 x 2	30 x 2	30 x 2
Link pin	27 x 2	27 x 2	27 x 2

10 STRUCTURE AND FUNCTION

Parts related to engine	10-	2
Radiator, oil cooler	10-	4
Power train	10-	5
Final drive	10-	6
Swing circle	10-	7
Swing machinery	10-	8
Track frame, recoil spring	10-	9
Track shoe	10-	10
Hydraulic piping drawing	10-	12
Hydraulic circuit drawing	10-	13
Hydraulic tank, hydraulic filter	10-	14
Hydraulic pump	10-	15
Control valve	10-	38
Suction safety valve	10-	47
CLSS	10-	49
Swing motor	10-	92
Center swivel joint	10-	96
Travel motor	10-	98
Valve motor	10-	107
Work equipment, swing PPC valve	10-	108
Travel PpC valve	10-	112
PPc valve for service valve	10-	116
PPC safety lock valve	10-	120
PPC accumulator	10-	120
PPC shuttle valve, travel junction valve	10-	121
EPC solenoid valve	10-	128
For LS select, boom Hi 2-stage safety valve, merge/flow divider, travel speed, swing brake	10-	128
For LS vlave control	10-	130
Boom safety valve	10-	133
Hydraulic cylinder	10-	136
Overload warning device	10-	137
Work equipment	10-	140
Actual electric wiring diagram	10-	141
Electric circuit diagram	10-	143
Engine control	10-	145
Electronic control system	10-	151
Machine monitor system	10-	175
Breaker Mode-hydraulic performance	10-	183

PARTS RELATED TO ENGINE





1. Drive plate
2. Torsion spring
3. Stopper pin
4. Friction plate
5. Damper assembly







6. Air cleaner
7. Intake connector
8. Muffler
9. Rear engine mount
10. Front engine mount

Outline

- The damper assembly is a wet type

Oil capacity: 0.75 ℓ


RADIATOR, OIL COOLER



- | | |
|-------------------------|-----------------|
| 1. Reservoir tank | 7. Radiator cap |
| 2. Oil cooler | 8. Net |
| 3. Radiator | 9. Shroud |
| 4. Fan | 10. Cushion |
| 5. Radiator inlet hose | 11. O-ring |
| 6. Radiator outlet hose | 12. Collar |

Specifications
 Radiator: CWX-4
 Oil cooler: SF-4


POWER TRAIN



1. Idler
2. Center swivel joint
3. Control valve
4. Final drive
5. Travel motor
6. Engine

7. Hydraulic pump
8. Travel speed solenoid valve
9. Swing brake solenoid valve
10. Swing machinery
11. Swing motor
12. Swing circle


FINAL DRIVE



1. Level plug
2. Drain plug
3. No. 1 planetary gear (No. of teeth: 41)
4. No. 1 sun gear (No. of teeth: 10)
5. No. 2 sun gear (No. of teeth: 19)
6. No. 1 planetary carrier
7. No. 2 planetary carrier
8. Cover
9. Ring gear (No. of teeth: 92)
10. Hub
11. Sprocket
12. Floating seal
13. Travel motor
14. No. 2 planetary gear (No. of teeth: 35)


Specifications

Reduction ratio: $-\left(\frac{10+92}{10}\right) \times \left(\frac{19+92}{19}\right) + 1$
 $= - 58.589$



A-A

SWING CIRCLE



1. Swing circle inner race (No. of teeth: 90)
2. Ball
3. Swing circle outer race


- a. Inner race soft zone S position
- b. Outer race soft zone S position

Specifications


Reduction ratio: $-\frac{90}{13} = -6.923$

Amount of grease: 33 ℓ (G2-LI)

SWING MACHINERY



1. Swing pinion (No. of teeth: 13)
2. Cover
3. Case
4. Coupling
5. No. 2 planetary gear (No. of teeth: 31)
6. Ring gear (No. of teeth: 84)
7. No. 1 planetary gear (No. of teeth: 31)
8. Cover
9. Swing motor
10. Oil level gauge
11. No. 1 sun gear (No. of teeth: 21)
12. No. 1 planetary carrier
13. No. 2 sun gear (No. of teeth: 21)
14. No. 2 planetary carrier
15. Drain plug




Specifications

Reduction ratio: $\frac{21+84}{21} \times \frac{21+84}{21}$
 = 35.000

TRACK FRAME, RECOIL SPRING

★ The diagram shows the PC340-6K



1. Idler
2. Track frame
3. Carrier roller
4. Final drive
5. Track roller
6. Track shoe
7. Center guard
8. Recoil spring
9. Front guard

- The dimensions and number of track rollers may differ according to the model, but the basic structure is the same.
- No. of track rollers.

Model	No. of track rollers (each side)
PC340-6K	7
PC340LC-6K, PC340 NLC-6K	8

TRACK SHOE

Standard shoe

Model	PC340-6K	PC340LC-6K	PC340NLC-6K
Item			
Shoe width (mm) (triple shoe)	600	700	600
Link pitch (mm)	216	216	216
No. of shoes (each side)	45	48	48

Selection of track shoe

- Select the most suitable track shoe from the following table

	PC340-6K		PC340LC-6K		PC340NLC-6K	
	Specifications	Category	Specifications	Category	Specifications	Category
Standard	600 mm triple	A	700 mm triple	B	600 mm triple	A
Option	700 mm triple	B	600 mm triple	A		
Option	800 mm triple	C	800 mm triple	B		

Category	Use	Precautions when using
A	Rocky ground, normal river soil	Travel in Lo speed when traveling on rough ground with obstacles such as large boulders and fallen trees.
B	Normal soil, soft land	- Cannot be used on rough ground where there are large obstacles such as boulders and fallen trees. - Travel in Hi speed only on flat ground; when it is impossible to avoid traveling over obstacles, lower the travel speed to approx. half of Lo speed.
C	Extremely soft ground (swampy ground)	- Use only for ground where "A" and "B" sink and are impossible to use. - Cannot be used on rough ground where there are large obstacles such as boulders and fallen trees - Travel in Hi speed only on flat ground; when it is impossible to avoid traveling over obstacles, lower the travel speed to approx. half of Lo speed.
D	Paved surface	The shoes are flat, so they have low gradeability
E	Paved surface	The shoes are made of rubber, so be careful when traveling on rough ground

★ Categories "B" and "C" are wide shoes, so there are restrictions on their use. Therefore, before using, check the restrictions and consider carefully the conditions of use before recommending a suitable shoe width. If necessary, give the customer guidance in their use.


★ When selecting the shoe width, select the narrowest shoe possible within the range that will give no problem with flotation and ground pressure.

If a wider shoe than necessary is used, there will be a large load on the shoe, and this may lead to bending of the shoe, cracking of the links, breakage of the pins, loosening of the shoe bolts, or other problems.


HYDRAULIC PIPING DRAWING

★ For details of this page, see Section 90.


1. Bucket cylinder
2. Arm cylinder
3. Boom cylinder
4. Center swivel joint
5. Swing motor
6. Oil cooler
7. Control valve
8. PPC shuttle valve
9. Hydraulic filter
10. Hydraulic pump
11. L.H. travel motor
12. Hydraulic tank
13. PPC safety lock valve
14. L.H. PPC valve
15. R.H. PPC valve
16. Travel PPC valve
17. Boom holding valve
18. Accumulator
19. Solenoid valve assembly
- 19A. LS select solenoid valve
- 19B. Boom Hi 2-stage safety solenoid valve
- 19C. Merge/flow divider solenoid valve
- 19D. Travel speed solenoid valve
- 19E. Swing brake solenoid valve



★ For details of this page, see Section 90.



HYDRAULIC TANK, HYDRAULIC FILTER



1. Hydraulic filter
 - 1a. Bypass valve
 - 1b. Strainer
 - 1c. Element
 - 1d. Cooler check valve
2. Hydraulic tank
3. Oil filler cap
4. Sight gauge
5. Hydraulic oil level sensor
6. Suction strainer

Specifications


Tank capacity: 315 ℓ

Amount of oil inside tank: 207 ℓ (at H level)

Safety valve

- Relief cracking pressure: 0.017 ± 0.007 MPa
(0.17 ± 0.07 kg/cm²)
- Suction cracking pressure: $0 - 0.0005$ MPa
($0 - 0.005$ kg/cm²)
- Bypass valve set pressure: 0.103 ± 0.02 MPa
(1.05 ± 0.2 kg/cm²)

HYDRAULIC PUMP




1. Front main pump
2. Rear main pump
3. Relief valve
4. Rear TVC, LS valve
5. Front TVC, LS valve
6. Control pump

- a. Port Pd1F (pump drain)
- b. Port PAF (front delivery)
- c. Port PAR (rear delivery)
- d. Port PGS (control pump suction)
- e. Port PGA (control pump delivery)
- f. Port PLS1F (front LS pressure)
- g. Port PLS1R (rear LS pressure)
- h. Port P_{sig} (LS control pressure EPC pressure)
- i. Port P_s (pump suction)
- j. Port PP2F (front No. 2 pump delivery pressure)
- k. Port PP2R (rear No. 2 pump delivery pressure)

Outline

This pump consists of two variable displacement swash plate type piston pumps, TVC, LS valves, control pump, and relief valve.

1. MAIN PUMP (HPV 140+140)





- a. Port PD1F (pump drain)
- b. Port PAF (front pump delivery)
- c. Port PAR (rear pump delivery)
- d. Port Pen1F (front control pressure)
- e. Port PARF (rear delivery pressure)

- f. Port PARR (rear delivery pressure)
- g. Port Pen1R (rear control pressure)
- h. Port Ps (suction)
- i. Port PAFF (front delivery pressure)
- j. Port Psd (control pump drain)


STRUCTURE AND FUNCTION

HYDRAULIC PUMP



- 1. Shaft (front)
- 2. Cradle
- 3. Case (front)
- 4. Rocker cam
- 5. Shoe
- 6. Piston

- 7. Cylinder block
- 8. Valve plate
- 9. End cap
- 10. Shaft (rear)
- 11. Case (rear)
- 12. Servo piston



Function

- The engine rotation and torque transmitted to the pump shaft is converted into hydraulic energy, and pressurized oil is discharged according to the load.
- It is possible to change the delivery amount by changing the swash plate angle.


Structure

- Cylinder block (7) is supported to shaft (1) by spline **S**, and shaft (1) is supported by the front and rear bearings.
- The tip of piston (6) is a concave ball, and shoe (5) is caulked to it to form one unit. Piston (6) and shoe (5) form a spherical bearing.
- Rocker cam (4) has flat surface **A**, and shoe (5) is always pressed against this surface while sliding in a circular movement. Rocker cam (4) brings high pressure oil at cylindrical surface **B** with cradle (2), which is secured to the case, and forms a static pressure bearing when it slides.
- Piston (6) carries out relative movement in the axial direction inside each cylinder chamber of cylinder block (7).
- The cylinder block seals the pressure oil to valve plate (8) and carries out relative rotation. This surface is designed so that the oil pressure balance is maintained at a suitable level. The oil inside each cylinder chamber of cylinder block (7) is sucked in and discharged through valve plate (8).


Operation

1. Operation of pump


- Cylinder block (7) rotates together with shaft (1), and shoe (5) slides on flat surface A. When this happens, rocker cam (4) moves along cylindrical surface B, so angle α between center line X of rocker cam (4) and the axial direction of cylinder block (7) changes. (Angle α is called the swash plate angle.)




- Center line X of rocker cam (4) maintains swash plate angle α in relation to the axial direction of cylinder block (7), and flat surface A moves as a cam in relation to shoe (5). In this way, piston (6) slides on the inside of cylinder block (7), so a difference between volume E and F is created inside cylinder block (7). The suction and discharge is equal to this difference $F - E$.



- In other words, when cylinder block (7) rotates and the volume of chamber E becomes smaller, the oil is discharged during that stroke. On the other hand, the volume of chamber F becomes larger, and as the volume becomes bigger, the oil is sucked in.
- If center line X of rocker cam (4) is in line with the axial direction of cylinder block (7) (swash plate angle = 0), the difference between volumes E' and F' inside cylinder block (7) becomes 0, so the pump does not carry out any suction or discharge of oil.




2. Control of discharge amount



- If swash plate angle α becomes larger, the difference in volumes **E** and **F** becomes larger and discharge volume **Q** increases.
- Swash plate angle α is changed by servo piston (12).
- Servo piston (12) moves in a reciprocal movement ($\leftrightarrow$) according to the command from the control valve.
- This straight line movement is transmitted through rod (13) to rocker cam (4), and rocker cam (4), which is supported by the cylindrical surface to cradle (2), moves in a rocking movement on the cylindrical surface in ($\updownarrow$ direction).
- With servo piston (12), the area receiving the pressure is different on the left and right, so main pump discharge pressure (self pressure) **PP** is always connected to the chamber receiving the pressure on the small diameter piston side (the self-pressure is brought in). Output pressure **Pen** of the LS valve is brought to the chamber receiving the pressure at the large diameter piston end. The relationship in the size of self-pressure **PP** and the pressure at the small diameter piston end, and the ratio between the area receiving the pressure at the small diameter piston end and the large diameter piston end controls the movement of servo piston (12).

2. TVC, LS VALVE






- a. Port Pen1 (signal pressure output)
- b. Port Pa2 (rear pump delivery pressure inlet port)
- c. Port Pa1 (front pump delivery pressure inlet port)

- d. Port PLS1 (control valve LS pressure inlet port)
- e. Port Psig1 (LS control EPC pressure inlet port)
- f. Port PP2 (pump pressure No. 2 port)

STRUCTURE AND FUNCTION

HYDRAULIC PUMP



LS valve

1. Locknut
2. Plug
3. Spring
4. Spool

5. Sleeve
6. Piston
7. Plug

TVC valve

8. Solenoid
9. Piston
10. Sleeve
11. Spring

12. Spring
13. Piston
14. Lever
15. Valve body


STRUCTURE AND FUNCTION

HYDRAULIC PUMP

Function


1. LS valve

- The LS valve detects the load and controls the discharge amount.
- This valve controls main pump discharge amount Q according to differential pressure $\Delta PLS (=P_{2P}-P_{LS})$ (the difference between main pump pressure P_{2P} and control valve outlet port pressure P_{LS}) (called the LS differential pressure).
- Main pump pressure P_{2P} coming from the control valve inlet port, pressure P_{LS} (called the LS pressure) coming from the control valve output, and pressure P_{sig} (called the LS selector pressure) from the proportional solenoid valve enter this valve. The relationship between discharge amount Q and differential pressure ΔPLS , (the difference between main pump pressure P_{2P} and LS pressure P_{LS}) ($=P_{2P}-P_{LS}$) changes as shown in the diagram on the right according to LS selector pressure P_{sig} .
- When P_{sig} changes between 0 – 2.9 MPa (0 – 30 kg/cm²), the spring load changes according to this, and the point for switching the pump discharge amount changes at the rated central value between 1.0 – 2.5 MPa (10.0 – 25.0 kg/cm²).



2. TVC valve

- When pump discharge pressure $PP1$ (self-pressure) and $PP2$ (other pump pressure) are high, the TVC valve controls the pump so that no more oil than the constant flow (in accordance with the discharge pressure) flows even if the stroke of the control valve becomes larger. In this way it carries out equal horsepower control so that the horsepower absorbed by the pump does not exceed the engine horsepower.
- In other words, if the load during the operation becomes larger and the pump discharge pressure rises, it reduces the discharge amount from the pump; and if the pump discharge pressure drops, it increases the discharge amount from the pump. The relationship between the average of the front and rear pump discharge pressures ($PP1 + PP2$)/2 and pump discharge amount Q is shown on the right, with the current given to the TVC valve solenoid shown as a parameter. However, in the heavy-duty operation mode, there are cases where it is given the function of sensing the actual speed of the en-



gine, and if the speed drops because of an increase in the load, it reduces the pump discharge amount to allow the speed to recover. In other words, when the load increases and the engine speed drops below the set value, the command to the TVC valve solenoid from the controller increases according to the drop in the engine speed to reduce the pump swash plate angle.


STRUCTURE AND FUNCTION

HYDRAULIC PUMP


Operation

1. LS valve

1) When control valve is at NEUTRAL position




- The LS valve is a three-way selector valve, with pressure **PLS** (LS pressure) from the outlet port of the control valve brought to spring chamber **i**, and main pump discharge pressure **P2P** brought to chamber **j** of plug (6).
- The size of the force of this LS pressure **PLS** + force **F** of spring (3) and the main pump pressure (self pressure) **P2P** determines the position of spool (4). However, the size of the output pressure **Psig** (the LS selection pressure) of the EPC valve for the LS valve entering port **e** also changes the position of spool (4). (The set pressure of the spring changes.)
- Before the engine is started, servo piston (1) is pushed to the right by spring (7) installed to rod (2). (See the diagram on the right)
- When the engine is started and the control lever is at the NEUTRAL position, LS pressure **PLS** is 0 MPa (0 kg/cm²). (It is intercon-




ected with the drain circuit through the control valve spool.) At this point, spool (4) is pushed to the left, and port **d** and port **c** are connected. Pump pressure **PP** enters the large diameter end of the piston from port **h**, and the same pump pressure **PP** also enters the small diameter end of the piston, so the swash plate is moved to the minimum angle by the difference in area of piston (1).

3) Operation in minimum direction for pump discharge amount



- The following explains the situation if servo piston (1) moves to the left (the discharge amount becomes smaller). When LS differential pressure ΔP_{LS} becomes larger (for example, when the area of opening of the control valve becomes smaller and pump pressure **PP** rises), main pump discharge pressure **P_{2P}** pushes spool (4) to the left.
- When spool (4) moves, main pump pressure **PP** flows from port **d** to port **c**, and from port **h**, it enters the large piston diameter end.
- Main pump pressure **PP** also enters the small piston diameter end, but because of the difference in area between the large piston diameter end and small piston diameter end of servo piston (1), servo piston (1) is pushed to the left. As a result, rod (2) moves in the direction to make the swash plate angle smaller.
- If LS selection pressure **P_{sig}** enters port **e**, it acts to make the set pressure of spring (3) weaker.


4) When servo piston is balanced



- Let us take the area receiving the pressure at the large piston diameter end as A_1 , the area receiving the pressure at the small diameter end as A_0 , and the pressure flowing into the large piston diameter end as P_{en} . If main pump discharge pressure P_{2P} of the LS valve and the combined force of force F of spring (3) and LS pressure P_{LS} are balanced, and the relationship is $A_0 \times P_{2P} = A_1 \times P_{en}$, servo piston (1) will stop in that position, and the swash plate will be kept at an intermediate position. (It will stop at a position where the opening of the throttle between port b and port c and between port d and port e of spool (4) is approximately the same. At this point, the pressure of port c is approx. $1/2$ pump pressure P_P .)
- At this point, the relationship between the area receiving the pressure at both ends of piston (1) is $A_0 : A_1 = 1 : 2$, so the pressure applied to both ends of the piston when it is balanced becomes $P_P : P_{en} = 2 : 1$.
- The position where spool (4) is balanced and stopped is the standard center, and the force of spring (3) is adjusted so that it is determined when $P_{2P} - P_{LS} = 2.5 \text{ MPa}$ (25 kg/cm^2). However, if P_{sig} (the output pressure of $0 - 2.9 \text{ MPa}$ ($0 - 30 \text{ kg/cm}^2$) of the EPC valve of the LS valve) is applied to port e , the balance stop position will change in proportion to pressure P_{sig} between $P_{2P} - P_{LS} = 2.5 - 1.0 \text{ MPa}$ ($25 - 10 \text{ kg/cm}^2$).

2. TVC valve

1) When governor, pump controller are normal



a. When the load on the actuator is small and pump pressures PP1 and PP2 are low

① Action of solenoid (1)

- Command current x from the governor, pump controller flows to solenoid (1). This command current changes the internal force pushing solenoid push pin (11).
- On the opposite side to the force pushing this solenoid push pin (11) is the spring set pressure of springs (3) and (4) and pump pressure **PP1** and other pump pressure **PP2** (see ★). Piston (2) stops at a position where the combined force pushing piston (2) is bal-


anced, and the pressure (pressure of port **c**) output from the TVC valve changes according to this position.

- The size of command current x is determined by the nature of the operation (lever operation), the selection of the working mode, and the set value and actual value for the engine speed.

STRUCTURE AND FUNCTION**HYDRAULIC PUMP****② Action of spring**

- The spring load of springs (3) and (4) in the TVC valve is determined by the position of the swash plate.
- When servo piston (9) moves, cam (7), which is connected to rod (8), also moves. When this happens, lever (6) is rotated by the angle of cam (7), and piston (5) moves to the right or left.
- If piston (5) moves to the right, spring (3) is compressed; and if it moves further to the right, spring (4) contacts seat (10), so both spring (3) and spring (4) function. In other words, the spring load is changed by piston (5) extending or contracting springs (3) and (4).
- If command current **x** input to solenoid (1) changes further, the pushing force of solenoid push pin (11) changes, and the spring load of springs (3) and (4) also changes according to the value of the solenoid command current.
- Port **c** of the TVC valve is connected to port **e** of the LS valve (see 1. LS valve). Self pressure **PP1** enters port **b** and the small piston diameter end of servo piston (9), and the other main pump pressure **PP2** enters port **a**.
- When pump pressures **PP1** and **PP2** are small, piston (2) is on the right. At this point, port **c** and port **d** are connected, and the pressure entering the LS valve becomes drain pressure **PT**.
If port **h** and port **e** of the LS valve are connected (see 1. LS valve), the pressure entering the large piston diameter end from port **f** becomes drain pressure **PT**, and servo piston (9) moves to the right. In this way, the pump discharge amount moves in the direction of increase.
- As servo piston (9) moves further, piston (5) is moved to the left by rod (8), cam (7), and lever (6). Springs (3) and (4) expand and the spring force becomes weaker. When the spring force becomes weaker, piston (2) moves to the left, so the connection between port **c** and port **d** is cut, and the pump discharge pressure port **b** is connected to port **c**. As a result, the pressure at port **c** rises, and the pressure at the large piston diameter end also rises, so the movement of piston (9) to the right is stopped. In other words,

the stop position for piston (9) (= pump discharge amount) is decided at the point where the force of springs (3) and (4) and the pushing force from the solenoid and the pushing force created by pressures **PP1** and **PP2** acting on piston (2) are in balance.




b. When load on actuator is small and pump discharge pressure is high

- When the load is large and pump discharge pressures **PP1** and **PP2** are high, the force pushing piston (2) to the left becomes larger and piston (2) moves to the position shown in the diagram above. When this happens, as shown in the diagram above, with the pressurized oil flowing from port **c** to the LS valve, part of the pressurized oil from port **b** flows out to port **d** and becomes approximately half of main pump pressure **PP1**.
- When port **h** and port **e** of the LS valve are connected (see 1. LS valve), the pressure from port **f** enters the large piston diameter end of servo piston (9), and servo piston (9) stops.
- If main pump pressures **PP1** and **PP2** increase further and piston (2) moves to the left, main pump pressure **PP1** flows to port **c** and acts to make the discharge amount the minimum. When piston (9) moves to the left, piston (5) is moved to the right by cam (7) and lever (6). For this reason, springs (3) and (4) are compressed and push back piston (2). Because of this force, piston (2) cuts off the connection from port **b** to port **c**, and port **c** and port **d** are connected. As a result, the pressure at port **c** (= **f**) drops, and piston (9) stops moving to the left. The position in which piston (9) stops when this happens is further to the left than the position when main pump pressures **PP1** and **PP2** are low.


STRUCTURE AND FUNCTION

HYDRAULIC PUMP


- The relation of pump pressures $PP1 + PP2$ and the position of servo piston (9) forms a bent line because of the double-spring effect of springs (3) and (4). The relationship between pump pressures $PP1 + PP2$ and pump discharge amount Q is shown in the figure on the right.



- If command current x sent to solenoid (1) increases further, the relationship between pump pressures $PP1$ and $PP2$, and pump discharge amount Q is proportional to the pushing force of the solenoid and moves in parallel. In other words, if the pushing force of solenoid (1) is added to the force pushing to the left because of the pump pressure applied to the piston (2), the relationship between P and Q moves from **A** to **B** in accordance with the increase in x .




2) When governor, pump controller is abnormal and TVC prolix switch is ON




a. When load on main pump is light

- If there is a failure in the governor, pump controller, turn TVC prolix switch ON to switch to the resistor side. In this case, the power source is taken directly from the battery. But if the current is used as it is, it is too large, so use the resistor to control the current flowing to solenoid (1).
- When this is done, the current becomes constant, so the force pushing solenoid push pin (11) is also constant.
- If main pump pressures **PP1** and **PP2** are low, the combined force of the pump pressure and the force of solenoid (1) is weaker than the spring set force, so piston (2) is balanced at a position to the right.
- At this point, port **c** is connected to the drain pressure of port **d**, and the large piston diameter end of servo piston (9) also becomes the drain pressure **PT** through the LS valve. When this happens, the pressure at the small piston diameter end is large, so servo piston (9) moves in the direction to make the discharge amount larger.



b. When load on main pump is heavy


- In the same way as in the previous item, when the TVC prolix switch is ON, the command current x sent to solenoid (1) becomes constant. For this reason, the force of solenoid push pin (11) pushing piston (2) is constant.
- If main pump pressures **PP1** and **PP2** increase, piston (2) moves further to the left than when the main pump load is light, and is balanced at a position towards the left.
- In this case, the pressure from port **b** flows to port **c**, so servo piston (9) moves to the left (to make the discharge amount smaller) by the same mechanism as explained in Item 2.1)-b, and stops at a position further to the left than when the load on the pump is light. In other words, even when the TVC prolix switch is ON, the curve for the pump pres-



sure **P** and discharge amount **Q** is determined as shown in the diagram for the value of the current sent to the solenoid through the resistor.

- The curve when the TVC prolix switch is ON is curve **B**, which is to the left of curve **A** for when the governor, pump controller is normal.

3. CONTROL PUMP (BAR-020)



1. Body
2. Driven gear
3. Housing
4. Drive gear
5. Relief valve
6. Filter

- a. Suction port
- b. Delivery port


Specifications

Type: BAR-020

Theoretical delivery: 20.9 cc/rev

Max. delivery pressure: 3.2 MPa (33kg/cm²)

RELIEF VALVE



SBP00185

Function

The relief valve is assembled in the body of the control pump, and when the PPC valve is at neutral, the oil sent from the pump is relieved through this valve.

(It sets the maximum pressure in the circuit during operations.)

Operation


- Chamber **A** is the pump circuit and chamber **C** is the drain circuit. The oil passes through the orifice in the main valve and fills chamber **B**.

1. Adjustment screw
2. Locknut
3. Sleeve
4. Main valve spring
5. Pilot piston
6. Main valve


Set pressure:

$3.2 \begin{smallmatrix} 0 \\ -0.1 \end{smallmatrix}$ MPa (at 33 l/min)

$(33 \begin{smallmatrix} 0 \\ -1 \end{smallmatrix}$ kg/cm² (at 33 l/min))




- If any abnormal pressure is generated, and the differential pressure $[\pi/4(D^2 - d^2) \times \text{pressure of chamber A}]$ created by the difference in the area of **d** and diameter **D** reaches the pressure set by the main valve spring, the main valve opens, and the oil in chamber **A** is released to chamber **C**. This suppresses the rise in the pressure in chamber **A**.



CONTROL VALVE

10-spool valve (STD + service valve x 3)

★ For details of this page, see Section 90.



STRUCTURE AND FUNCTION

CONTROL VALVE

1. 6-spool valve
2. Boom, arm Hi valve
3. Cover 1
4. Cover 2
5. Merge/flow divider valve
6. Service valve
7. Service valve
8. Service valve


- a. Port PP1 (from front main pump)
- b. Port PP2 (from rear main pump)
- c. Port A6 (to arm cylinder head)
- d. Port B6 (to arm cylinder bottom)
- e. Port A5 (to L.H. travel motor)
- f. Port B5 (to L.H. travel motor)
- g. Port A4 (to swing motor)
- h. Port B4 (to swing motor)
- i. Port A3 (to boom cylinder bottom)
- j. Port B3 (to boom cylinder head)
- k. Port A2 (to R.H. travel motor)
- l. Port B2 (to R.H. travel motor)
- m. Port A1 (to bucket cylinder bottom)
- n. Port B1 (to bucket cylinder head)
- o. Port A-1 (to boom cylinder bottom)
- p. Port B-1 (to arm cylinder bottom)
- q. Port A-2 (to attachment)
- r. Port B-2 (to attachment)
- s. Port A-3 (to attachment)
- t. Port B-3 (to attachment)
- u. Port A-4 (to attachment)
- v. Port B-4 (to attachment)
- w. Port T1 (to travel junction valve)
- x. Port T2 (to travel junction valve)
- y. Port T3 (to travel junction valve)
- z. Port T4 (to travel junction valve)

Outline

- This control valve consists of a 7-spool valve (the 6-spool valve = Hi valve) and 3 sets of service valves. The merge/flow divider valve is installed to this. (1 service valve is provided as standard)
- All the valves are connected by a bolt to form one unit, and the passages are internally connected, so the structure is compact and is very easy to service.
- This control valve is designed to assist only the boom and arm valves with their large flow using the Hi valve, so it has a simple structure.



- aa. Port PLS1 (to front pump control)
- ab. Port PLS2 (to rear pump control)
- ac. Port PPS1 (to front pump control)
- ad. Port PPS2 (to rear pump control)
- ba. Port T (to tank)
- bb. Port Ts (to tank)
- cc. Port Ps (from merge/flow divider solenoid valve)
- dd. Port BP (from LS select solenoid valve)
- ee. Port PTR1 (to travel junction valve)
- ef. Port PTR2 (to travel junction valve)
- ff. Port Cp (from 2-stage safety valve selector solenoid valve)
- pa. Port P12 (from arm PPC valve)
- pb. Port P11 (from arm PPC valve)
- pc. Port P10 (from L.H. travel PPC valve)
- pd. Port P9 (from L.H. travel PPC valve)
- pe. Port P8 (from swing PPC valve)
- pf. Port P7 (from swing PPC valve)
- pg. Port P6 (from boom PPC valve)
- ph. Port P5 (from boom PPC valve)
- pi. Port P4 (from R.H. travel PPC valve)
- pj. Port P3 (from R.H. travel PPC valve)
- pk. Port P2 (from bucket PPC valve)
- pl. Port P1 (from bucket PPC valve)
- pm. Port P-2 (from boom PPC valve)
- pn. Port P-1B (from arm PPC valve)
- po. Port P-1A (from arm PPC valve)
- pp. Port P-4 (from service PPC valve)
- pq. Port P-3 (from service PPC valve)
- pr. Port P-6 (from service PPC valve)
- ps. Port P-5 (from service PPC valve)
- pt. Port P-8 (from service PPC valve)
- pu. Port P-7 (from service PPC valve)
- gf. Port SA (pressure sensor mount port)
- gg. Port SB (pressure sensor mount port)

Main structure of 10-spool valve (1/3)









- | | |
|------------------------|------------------------------------|
| 1. Spool (arm Lo) | 10. Spool (service) |
| 2. Spool (L.H. travel) | 11. Spool (service) |
| 3. Spool (swing) | 12. Spool return spring |
| 4. Spool (boom Lo) | 13. Main relief valve (bucket) |
| 5. Spool (R.H. travel) | 14. Main relief valve (arm Lo) |
| 6. Spool (bucket) | 15. Unload valve (bucket) |
| 7. Spool (boom Hi) | 16. Unload valve (arm Lo) |
| 8. Spool (arm Hi) | 17. Piston (arm Lo stroke control) |
| 9. Spool (service) | |




(2/3)



1. LS shuttle valve
2. LS select valve
3. Merge/flow divider valve (main)
4. Return spring
5. Merge/flow divider valve (for LS)
6. Return spring
7. LS bypass valve

(3/3)






1. Pressure compensation valve
2. Safety-suction valve
3. Safety-suction valve (for large flow)
4. Safety-suction valve (2-stage)
5. Check valve for regeneration circuit (arm)
6. Check valve for regeneration circuit (boom)

8-spool valve (STD + service valve x 1)


★ For details of the names of the ports and the main structure, see 10-SPOOL VALVE

★ For details of this page, see Section 90.



SUCTION SAFETY VALVE

FOR SERVICE VALVE




- 1. Suction valve
- 2. Main valve
- 3. Piston
- 4. Piston spring
- 5. Poppet
- 6. Poppet spring
- 7. Suction valve spring
- 8. Sleeve
- 9. Adjustment screw
- 10. Locknut

SBP00198

Part No.	Set pressure	Use
709-70-74800	20.6 MPa (210 kg/cm ²) at 190ℓ/min	For breaker
709-70-75100	20.1 MPa (205 kg/cm ²) at 5ℓ/min	For breaker
709-70-75300	16.7 MPa (170 kg/cm ²) at 190ℓ/min	For breaker
709-70-74600	24.5 MPa (250 kg/cm ²) at 5ℓ/min	For crusher

CLSS

Outline of CLSS



Outline

- CLSS stands for Closed center Load Sensing System, and has the following features.

Features


- Fine control not influenced by load
- Control enabling digging even with fine control.
- Ease of compound operation ensured by flow divider function using area of opening of spool during compound operations.
- Energy saving using variable pump control

Structure


- The CLSS consists of a main pump (2 pumps), control valve, and actuators for the work equipment.
- The main pump consists of the pump itself, the TVC valve and LS valve.

Basic principle**1) Control of pump swash plate angle**

- The pump swash plate angle (pump discharge amount) is controlled so that LS differential pressure ΔP_{LS} (the difference between pump pressure P_P and control valve outlet port LS pressure P_{LS}) (load pressure of actuator) is constant.
(LS pressure ΔP_{LS} = Pump discharge pressure P_P - LS pressure P_{LS})



SBP00200




- If LS differential pressure ΔP_{LS} becomes lower than the set pressure of the LS valve (when the actuator load pressure is high), the pump swash plate moves towards the maximum position; if it becomes higher than the set pressure of the LS valve (when the actuator load pressure is low), the pump swash plate moves towards the minimum position.

2) Pressure compensation

- A pressure compensation valve is installed to the outlet port side of the control valve to balance the load.

When two actuators are operated together, this valve acts to make pressure difference ΔP between the upstream (inlet port) and downstream (outlet port) of the spool of each valve the same regardless of the size of the load (pressure).


In this way, the flow of oil from the pump is divided (compensated) in proportion to the area of openings **S1** and **S2** of each valve.



Operation for each function of CLSS

Hydraulic circuit diagram for system


★ For details of this page, see Section 90.



- 1A. Main relief valve (bucket group)
- 1B. Main relief valve (arm group)
- 2A. Unload valve (bucket group)
- 2B. Unload valve (arm group)
- 3. Pressure compensation valve
- 4. Safety-suction valve
- 5. Safety-suction valve (for large flow)
- 6. Safety-suction valve (2-stage)
- 7. Bucket spool
- 8. LS shuttle valve
- 9. R.H. travel spool
- 10. Suction valve
- 11. Boom Lo spool
- 12. Check valve (for boom regeneration circuit)
- 13. Swing spool
- 14. L.H. travel spool
- 15. Arm Lo spool
- 16. Check valve (for arm regeneration circuit)
- 17. Boom Hi spool
- 18. Arm Hi spool
- 19. LS select valve
- 20. Merge/flow divider valve
- 21. LS bypass valve
 - A. To bucket cylinder
 - B. To R.H. travel motor
 - C. To boom cylinder
 - D. To swing motor
 - E. To L.H. travel motor
 - F. To arm cylinder
 - G. To travel junction valve
 - H. To travel junction valve


SYSTEM DIAGRAM

- ★ This shows actuator (6A) at stroke end relief in the merge mode.



- | | | |
|-----------------------------|-------------------|---------------------|
| 1A. Main pump | 5A. Control valve | 9A. Tank passage |
| 1B. Main pump | 5B. Control valve | 9B. Tank passage |
| 2A. Main relief valve | 6A. Actuator | 10A. Valve |
| 2B. Main relief valve | 6B. Actuator | 10B. Valve |
| 3A. Unload valve | 7A. Pump passage | 11A. Spring |
| 3B. Unload valve | 7B. Pump passage | 11B. Spring |
| 4. Merge/flow divider valve | 8A. LS circuit | 12. LS bypass valve |
| | 8B. LS circuit | |

1. When unload valve is actuated




Function

- When all the control valves are at neutral, the oil discharged when the pump is at the minimum swash plate angle is drained. When this happens, the pump pressure becomes a pressure that matches the set load of springs (11A, 11B) inside the valve (P1 pressure). The LS pressure is drained from LS bypass valve (12), so LS pressure $\approx$ tank pressure $\approx$ 0 MPa (0 kg/cm²).
- When operated (for operations in the discharge range for the minimum swash plate angle), the discharge pressure of the oil discharged with the pump at the minimum swash plate angle is LS pressure + P1 pressure. In other words, the LS control differential pressure (ΔP_{LS}) of the oil discharged at the minimum swash plate angle is the P1 pressure.
- When the unload operation is carried out, the differential pressure (pump discharge pressure – LS circuit pressure) is greater than the pump LS control pressure, so a signal is sent to move the pump swash plate to the minimum angle.

Operation

- The pressure in pump passages (7A, 7B) is received by the end face of valves (10A, 10B). The control valve is at neutral, so the pressure in LS circuits (8A, 8B) is 0 MPa (0 kg/cm²).
- The pressurized oil in pump passages (7A, 7B) is stopped by valves (10A, 10B). There is no way for the pressurized oil discharged by the pump to escape, so the pressure rises. When this pressure becomes larger than the



2. At LS relief


(1) Cut-off control actuated

Function

- When cut-off control is being carried out on the pump by the TVC valve, the pump swash plate angle is at the minimum.
- The relief valve acts to relieve the oil flow when the pump is at the minimum swash plate angle in order to maintain the overall balance.

Operation


- When the cylinder reaches the end of its stroke, main relief valves (2A, 2B) open and pump discharge amount Q is relieved to tank passages (9A, 9B).
- When pump delivery pressure P_P comes close to the relief pressure, the governor, pump controller sends a signal to the solenoid of the TVC valve and carries out the cut-off function to make pump discharge amount Q the minimum.
- The spool is at the end of its stroke, so there is no flow of oil upstream or downstream from the spool. As a result, pump delivery pressure P_P and LS pressure P_{LS} are almost the same pressure, and LS differential pressure ΔP_{LS} becomes 0.
- LS differential pressure ΔP_{LS} is lower than the LS set pressure of the LS valve, so the LS valve acts to try to move the pump swash plate angle to the maximum. However, because of the structure, the action of the TVC valve is given priority over the action of the LS valve, so the pump is held at the minimum swash plate angle by the cut-off function of the TVC valve.



(2) Cut-off canceled (power max. mode, fine control mode, travel)


Function, operation

- In the power max. mode, fine control mode, or travel mode, the torque cut-off signal is not given, so the torque moves on the pump output curve.
- When this happens, the pump discharge amount is relieved from the relief valve, so the overall balance is maintained.



3. Introduction of LS pressure

- ★ The diagram shows the condition for arm IN.



1. Main pump
2. Main spool
3. Pressure compensation valve
4. Valve
5. Ball valve
6. LS circuit
7. LS shuttle valve


Function

- The upstream pressure (= spool meter-in downstream pressure) of pressure compensation valve (3) is introduced and goes to shuttle valve (7) as the **LS** pressure. When this happens, it is connected to port **B** of the actuator through valve (4), and **LS** pressure $\approx$ actuator load pressure. Introduction hole **a** inside the spool has a small diameter, so it also acts as a throttle.

Operation

- When spool (2) is operated, the pump pressure passes through introduction hole **a**, enters port **C**, and is taken to the LS circuit. When the pump pressure rises and reaches the load pressure of port **B**, ball valve (5) opens.

4. LS bypass valve




1. Main pump
2. Main spool
3. Pressure compensation valve
4. LS shuttle valve
5. LS bypass valve
6. LS circuit

Function

- The residual pressure in LS circuit (6) is released from orifices **a** and **b**.
- This reduces the speed of the rise in the LS pressure, and prevents any sudden change in the oil pressure. Furthermore, a pressure loss is generated by the circuit resistance between throttle **c** of main spool (2) and LS shuttle valve (4) according to the bypass flow from LS bypass valve (5). As a result, the effective LS differential pressure drops, and the dynamic stability of the actuator is increased.

5. Pressure compensation valve



1. Main pump
2. Valve
3. Shuttle valve

4. Piston
5. Spring
6. LS shuttle valve

Function

- 1) **During independent operation and at maximum load pressure (during compound operations, when load pressure is higher than other work equipment)**
 - The pressure compensation valve acts as a load check valve.

Operation

- If the pump pressure (LS pressure) is lower than the load pressure at port C, shuttle valve (3) inside pressure compensation valve piston (4) moves to interconnect spring chamber E and port C. From this condition, the force of spring (5) acts to move piston (4) and valve (2) in the direction of closing.


Reference: Integrated pressure compensation valve


- When high peak pressure is generated in the actuator circuit or when peak pressure is generated repeatedly over a continuous period (such as when using a breaker), valve (2) may hit valve chamber seat s and generate a high stress. To prevent this, an integrated pressure compensation valve combining valve (2) and piston (4) is used. On

this machine, this is employed for the bucket valve (at the cylinder bottom) and service valve.

With the integrated compensation valve, as a basic rule, port C and spring chamber E are not interconnected, so even if a high peak pressure is generated at port C, valve (7) does not hit the valve chamber.

(However, the system is designed so that port C and spring chamber E are interconnected just before the bucket valve is seated.)






2) When receiving compensation (during compound operations, when load pressure is lower than other work equipment)

- The pressure compensation valve is closed by the LS pressure of port D, and the spool meter-in downstream pressure of port B becomes the same as the maximum pressure of the other work equipment. The spool meter-in upstream pressure of port A is the pump pressure, so spool meter-in differential pressure (upstream pressure (pressure of port A) – downstream pressure (pressure of port B)) becomes the same for all spools that are being operated. In this way, the pump flow is divided in proportion to the area of the meter-in opening.

Operation

- Spring chamber E is interconnected with port D. Piston (4) and valve (2) are actuated by the LS circuit pressure from the other work equipment at port F in the direction of closing (to the right). In other words, the valve upstream pressure of port B (= spool meter-in downstream pressure) is controlled by the LS pressure.

6. Shuttle valve inside pressure compensation valve




1. Main pump
2. Valve
3. Shuttle valve inside pressure compensation valve
4. Piston

Function


When holding pressure at port A > LS pressure in spring chamber B.

- Shuttle valve (3) is pushed to the right by the pressure of port A, and the circuit between ports A and C is shut off. In this condition, the holding pressure at port A is taken to spring chamber B, and pushes piston (4) to the left to prevent piston (4) and valve (2) from separating.




< For travel >


- No holding pressure is generated at port A in the travel circuit, so a pressure compensation valve without a shuttle valve is used.



Reference: When there is no shuttle valve

- If there is no shuttle valve, piston (4) and valve (2) will separate. In this condition, if another actuator is operated, the piston acts as an accumulator, so there is a time lag.





< Area ratio of pressure compensation valve >

The condition of the flow division changes according to the ratio of the areas of portion **A1** and portion **A2** of the pressure compensation valve.


Area ratio = $A2/A1$

- When area ratio = 1: Spool meter-in downstream pressure = Max. load pressure, and oil flow is divided in proportion to area of opening of spool.
- When ratio is more than 1: Spool meter-in downstream pressure > Max. load pressure, and a smaller oil flow is divided than the proportion between the areas of opening of the spool.
- When ratio is less than 1: Spool meter-in downstream pressure < Max. load pressure, and a larger oil flow is divided than the proportion between the areas of opening of the spool.

Area ratio for each part of work equipment

	Port A		Port B	
	Area ratio	Throttle diameter (mm)	Area ratio	Throttle diameter (mm)
Bucket	★0.93 (CURL)	φ2.0	0.88 (DUMP)	φ2.0
L.H./ R.H. travel	0.98	φ1.0	0.98	φ1.0
Boom	0.98 (RAISE) (both Lo and Hi valves)	φ1.0	0.98 (LOWER)	φ2.0
Swing	0.88	φ2.0	0.88	φ2.0
Arm	0.90 (OUT)	φ2.0	0.93 (IN) (both Lo and Hi valves)	φ2.0
Service (for 2-spool valve)	★0.94	φ2.0	★0.94	φ2.0
Service (for 1-spool valve)	★0.98	φ2.0	★0.98	φ2.0


★ Integrated pressure compensation valve



2) Cylinder head pressure > Cylinder bottom pressure (digging operations, etc.)

- Check valve (5) in regeneration circuit (8) acts to shut off the flow from the cylinder head to the cylinder bottom.

8. Arm regeneration circuit



1. Main pump
2. Main spool
- 3A. Pressure compensation valve
- 3B. Pressure compensation valve
- 4A. Safety valve
- 4B. Safety valve
5. Check valve
6. LS shuttle valve
7. Drain circuit
8. Regeneration circuit


Function**Cylinder head pressure > cylinder bottom pressure**

- A return flow circuit is provided from the cylinder head to the cylinder bottom so that when the arm is moved IN, the flow of oil to the cylinder becomes the pump discharge amount + the return flow. This covers for any negative pressure at the cylinder bottom, and, as a result, increases the cylinder speed.

Operation

- When the cylinder head pressure > cylinder bottom pressure, the pressurized oil from the cylinder head passes through the notch in spool (2), enters port C and opens check valve (8), then passes through ports D and E to flow back to the cylinder bottom.

9. Merge/flow divider valve



1. Main spool
2. Spring
3. LS spool
4. Spring
5. LS circuit (bucket)
6. LS circuit (arm)
7. LS circuit (arm)
8. LS circuit (bucket)


Function

- This acts to merge or divide (send each to its own control valve group) oil flows **P1** and **P2** of pressurized oil discharged from the two pumps.
- At the same time, it also carries out merging and dividing of the LS circuit pressure.

Operation

1) When merging pump flow (when pilot pressure **PS** is OFF)

- Pilot pressure **PS** is OFF, so main spool (1) is pushed fully to the left by spring (2), and ports **E** and **F** are interconnected. Therefore, pressurized oil flows **P1** and **P2** discharged from the two pumps are merged at ports **E** and **F**, and are sent to the control valve that demands the oil.
- In the same way, LS spool (3) is also pushed fully to the left by spring (4), so the ports are connected as follows.
Connected ports: **A** ↔ **D**, **B** ↔ **C**
- Therefore, the **LS** pressure supplied from the spools of each control valve to **LS** circuits (5), (6), (7), and (8) is all sent to the pressure compensation valve and other valves.



2) When dividing pump flow (when pilot pressure PS is ON)

- When pilot pressure **PS** is ON, main spool (1) is moved to the right by the **PS** pressure, and ports **E** and **F** are disconnected. Therefore, the pressurized oil discharged from each pump is sent to its own control valve group.

Pressure **P1**: To bucket, R.H. travel, boom group

Pressure **P2**: To swing, L.H. travel, arm group


- In the same way, LS spool (3) is also moved to the right by the **PS** pressure, and the ports are connected as follows.

Connected ports: **B** ↔ **D**, others are not connected.

Therefore, LS circuits (5), (6), (7), and (8) are all connected to their own control valve group.

10. LS select valve

- ★ The diagram shows the situation when the swing and left travel are operated at the same time. (BP pressure ON)



1. Valve
2. Spring
3. Piston
4. Piston
5. Swing spool
6. L.H. travel spool
7. Arm spool
8. LS shuttle valve
9. LS circuit

Function

- This valve is used to increase the ease of operating the work equipment. It prevents high pressure from being generated when the swing is operated. It also prevents the high LS pressure from the swing circuit from flowing into any other LS circuit when the swing is operated together with the work equipment.



Operation

1) When pilot pressure BP is OFF


- Pilot pressure BP is OFF, so piston (3) is pushed to the left by spring (2). If the swing is then operated, swing LS pressure P1 passes through swing spool (5) and enters port A. It pushes valve (1) to the left and connects ports A and B. Therefore, swing LS pressure P1 flows to LS shuttle valve (8).

2) When pilot pressure BP is ON

- When pilot pressure BP is ON, piston (3) is moved to the right against spring (2) by the BP pressure. It pushes valve (1) to the right and closes the circuit between ports A and B. As a result, swing LS pressure P1 stops flowing to LS shuttle valve (8), and even if swing LS pressure P1 rises to a high pressure, it does not influence any other LS circuit.



11. 2-stage safety valve (installed to boom cylinder head)





1. Spring
2. Piston
3. Spring
4. Holder

Function

- The set pressure of the safety valve can be set to two stages and the low pressure setting can be made smaller. Because of this, when digging with boom, even if high pressure is brought to bear on the boom cylinder, it is possible to let the boom escape without operating the control lever. This makes it possible to carry out operations with high efficiency and with little vibration of the chassis.


Operation

- The set pressure of the safety valve is determined by the load pressure of spring (1).
- 1) **When pilot pressure P is OFF: high pressure setting**
 - Pilot pressure P is OFF, so piston (2) is pushed to the left by spring (3). (Installed load of spring (1) < installed load of spring (3)). When this happens, the installed load of spring (1) becomes the maximum, and the set pressure is set to high pressure. In addition, passage B is connected to the drain circuit through passage C and chamber D.
 - 2) **When pilot pressure P is ON: low pressure setting**
 - When pilot pressure P is ON, the pilot pressure goes to portion A through passage B, and piston (2) acts on the diameter of portion A receiving the pressure ($d_2 - d_1$). Piston (2) is moved to the right against spring (3) by this pilot pressure. It moves the full stroke until it contacts holder (4). As a result, spring (1) extends, the installed load becomes the minimum, and the set pressure is set to low pressure. In addition, an amount of oil equivalent to the piston stroke passes through passage C and chamber D, and is drained.



- ★ The diagram shows the situation when all work equipment is at neutral.
- ★ The valves and circuits that are not connected with the explanation of the operation of the CLSS hydraulic system have been omitted.
- ★ For details of this page, see Section 90.

OPERATION OF CLSS SYSTEM AS A WHOLE 1. When all work equipment is at neutral



1. Hydraulic tank
- 2A. Main pump (front)
- 2B. Main pump (rear)
- 3A. TVC valve (front)
- 3B. TVC valve (rear)
- 4A. LS valve (front)
- 4B. LS valve (rear)
- 5A. Merge/flow divider valve (main)
- 5B. Merge/flow divider valve (for LS)
6. Bucket spool
7. R.H. travel spool
8. Boom Lo spool
9. Swing spool
10. L.H. travel spool
11. Arm Lo spool
12. Boom Hi spool
13. Arm Hi spool
14. Pressure compensation valve (with shuttle valve)
15. Pressure compensation valve (with shuttle valve, integrated type) (bucket CURL)
16. Pressure compensation valve (without shuttle valve) (travel)
17. Safety-suction valve
18. Safety-suction valve (bucket CURL)
19. 2-stage safety-suction valve (boom LOWER)
20. Plug
21. LS shuttle valve (bucket)
22. LS shuttle valve (R.H. travel)
23. LS shuttle valve (boom)
24. LS shuttle valve (L.H. travel)
25. LS shuttle valve (arm)
26. Check valve (for boom regeneration circuit)
27. Check valve (for arm regeneration circuit)
- 28A. Main relief valve (bucket group)
- 28B. Main relief valve (arm group)
- 29A. Unload valve (bucket group)
- 29B. Unload valve (arm group)
30. LS select valve
31. LS check valve
32. LS bypass valve

Note: Groups of control valves by main pump circuit


Bucket group: Bucket, R.H. travel, boom Lo, boom Hi, Arm Hi

Arm group: Swing, L.H. travel, arm Lo

Operation

- When the levers are at neutral, the pump is at the minimum swash plate angle, and the oil flow is drained from unload valves (29A, 29B).
- The LS pressure is connected to hydraulic tank (1) by LS bypass valve (32). The LS differential pressure ΔP_{LS} (unload pressure – tank pressure) at this point is $\Delta P_{LS} > \text{pump LS control pressure}$, so the pump swash plate angle is the minimum.

2. Pump flow merged, bucket CURL operated independently
★ For details of this page, see Section 90.




Operation

- When the bucket CURL is operated, unload valves (29A, 29B) are closed.
- The swash plate of the main pump is controlled (LS control) to match the area of the meter-in opening of bucket spool (6), so the pump swash plate is balanced at a position which matches the oil flow demanded by the spool meter-in.

(ΔP_{LS} = pump LS control pressure)

3. Pump flow merged, boom RAISE operated independently
(Boom Lo valve + boom Hi valve)

★ For details of this page, see Section 90.



Operation


- When the boom RAISE is operated, unload valves (29A, 29B) are closed.
- The swash plate of the main pump is controlled (LS control) to match the total area of the meter-in opening of boom Lo spool (8) and boom Hi spool (12).

(ΔP_{LS} = pump LS control pressure)

- When the spool meter-in opening comes near the maximum, both pumps are at the maximum swash plate angle.
(When the pump discharge is the maximum, the maximum area of opening of the spool is also large, so the LS differential pressure is smaller than the LS control pressure and the swash plate angle is always at the maximum.)

($\Delta P_{LS} <$ pump LS control pressure)

4. Pump flow merged, arm IN operated independently
(Arm Lo valve + arm Hi valve)
★ For details of this page, see Section 90.



Operation


- When the arm IN is operated, unload valves (29A, 29B) are closed.
- The swash plate of the main pump is controlled (LS control) to match the total area of the meter-in opening of arm Lo spool (11) and arm Hi spool (13).

(ΔP_{LS} = pump LS control pressure)

- When the spool meter-in opening comes near the maximum, both pumps are at the maximum swash plate angle.
(When the pump discharge is the maximum, the maximum area of opening of the spool is also large, so the LS differential pressure is smaller than the LS control pressure and the swash plate angle is always at the maximum.)

($\Delta P_{LS} <$ pump LS control pressure)


5. Pump flow merged, arm OUT operated independently
(Return circuit arm Lo + arm Hi)
★ For details of this page, see Section 90.



Operation

- When the arm OUT is operated, unload valves (29A, 29B) are closed.
- The swash plate of the main pump is controlled (LS control) to match the area of the meter-in opening of arm Lo spool (11), so the pump swash plate is balanced at a position which matches the oil flow demanded by the spool meter-in.
(ΔPLS = pump LS control pressure)
- When this happens, the oil from the cylinder bottom is divided, sent to the Lo and Hi spools, and then returned, so it is possible to keep the pressure loss in the circuit small.

6. Pump flow divided, travel operated independently
★ For details of this page, see Section 90.



Operation

- Pilot pressure **PA** of merge/flow divider valve (5A) ON

1)

- When the STRAIGHT TRAVEL is operated, a flow of oil is supplied from the main pump to match the stroke of the left and right travel spools (10) and (7).

Flow of oil from main pump (2A):

To L.H. spool (10) (arm group)

Flow of oil from main pump (2B):


To R.H. spool (7) (bucket group)

- The straight travel is compensated by the travel junction valve.

2)

- From the condition in 1) above, if the lever on the side being steered is returned (the oil flow becomes small) or the lever on the other side is operated in the opposite direction (the direction of travel is reversed), the oil flow from the pump is being divided, so the left and right travel circuits are controlled independently and the machine is steered.

7. Pump flow merged, arm IN + boom RAISE operated simultaneously
 ★ For details of this page, see Section 90.



Operation


1)

- When the arm and boom are operated simultaneously, the swash plate angle for both pumps becomes the maximum.
- When this happens, the load pressure at the boom RAISE side is higher than at the arm side, so the LS pressure passes through ports **E** and **F** of boom Lo spool (8), enters boom LS shuttle valve (23) and is sent to the LS circuit. This LS pressure is transmitted to port **G** of pressure compensation valve (14), and acts to increase the set pressure of the pressure compensation valve. Because of this, the pressure between port **H** of arm Lo spool (11) and port **I** of pressure compensation valve (14) rises, and the spool meter-in LS differential pressure (pump pressure – LS pressure = ΔPLS) becomes the same as that at the boom end.

2)

- Because of the above operation, the oil flow is divided in proportion to the total area of opening of boom Lo spool (8) and boom Hi spool (12), and the total area of opening of arm Lo spool (11) and arm Hi spool (13).
- Meter-in LS differential pressure ΔPLS during boom RAISE + arm IN is $\Delta PLS < \text{pump LS control pressure}$, so the main pump swash plate angle is set to maximum.

8. Pump flow merged, swing + boom RAISE operated simultaneously
★ For details of this page, see Section 90.




Operation

- When the boom RAISE is being operated in the heavy-duty digging mode the swing is operated simultaneously, the pilot pressure of LS select valve (3) is turned ON.


- When this happens, the LS select valve is shut off, and the high pressure generated when the swing is operated does not flow to the LS circuit, so the LS circuit pressure becomes the boom pressure.

The swash plate of the main pump is controlled (LS control) by the difference in pressure between the boom and LS pressure.

- In addition, the pump pressure is determined by the boom pressure, so even if the swing drive pressure is high, the pump can deliver an ample flow of oil regardless of the pump output curve.




9. Pump flow divided (pump pressure: 19.6 MPa (200 kg/cm²) or above), travel + boom RAISE operated simultaneously
★ For details of this page, see Section 90.



Operation

- When the travel and boom RAISE are operated simultaneously (such as when raising the boom before traveling up a steep slope), if the pump pressure rises to 19.6 MPa (200 kg/cm²), the merge/flow divider valve pilot is turned ON and the pump flow is divided.
- In addition, the boom Hi spool does not move because of the travel **PPC** pressure. The flow of oil to the boom at this point is restricted, so the travel pressure is maintained and it is possible to carry out compound operations easily.

★ For details of this page, see Section 90.




Operation

- When the travel and arm IN are operated simultaneously (such as when using the digging action of the arm to help the machine travel up a steep slope), if the pump pressure rises to 19.6 MPa (200 kg/cm²), the merge/flow divider valve pilot is turned ON and the pump flow is divided.
- In addition, the stroke of the arm Lo spool is restricted by the travel **PPC** pressure. The flow of oil to the arm at this point is restricted, so the travel pressure is maintained and it is possible to carry out compound operations easily.

SWING MOTOR

KMF160AB-3




- a. Port T1 (to tank)
- b. Port B (from swing brake solenoid valve)
- c. Port MA (from control valve)
- d. Port MB (from control valve)
- e. Port S (from lift check valve)
- f. Port T2 (to port S)

Specifications


Model:	KMF160AB-3
Theoretical delivery:	160.7 cc/rev
Safety valve set pressure:	28.4 ^{+0.5} MPa at 244 /min (290 ⁺⁵ Kg/cm ² at 244 /min)
Rated speed:	1,525 rpm (1,680 rpm max.)
Brake releasing pressure:	1.8 ± 0.4 MPa (18.4 ± 4 kg/cm ²)

STRUCTURE AND FUNCTION


SWING MOTOR



C - C



A - A



B - B


1. Output shaft
2. Oil seal
3. Case
4. Plate
5. Disc
6. Brake piston
7. Spring
8. Housing

9. Piston assembly
10. Cylinder block
11. Spring
12. Center shaft
13. Valve plate
14. Suction valve spring
15. Suction-safety valve

SUCTION-SAFETY VALVE

Function

- When the swing is stopped, the outlet port circuit of the motor is closed by the control valve, but the motor continues to be turned by the inertia of the swing. As a result, the pressure at the outlet port of the motor becomes abnormally high and there is danger that the motor will be damaged.
- The safety valve is installed to prevent this problem. It acts to release the abnormally high pressure oil from the outlet port of the motor to port **S**, and also functions as a swing brake.
- The suction valve supplies an amount of oil equivalent to the amount of oil released by the safety valve. It sends this oil from port **S** to the inlet port of the motor to prevent any cavitation.



Operation


1. When starting swing

- If the swing control lever is operated to swing to the right, the pressurized oil from the pump passes through the control valve and is supplied to port **MA**.
- When this happens, the pressure at port **MA** rises and the starting force is generated in the motor, so the motor starts to turn. The oil from the outlet port of the motor flows from port **MB** through the control valve and returns to the tank.

2. When stopping swing

- When the swing control lever is returned to the neutral position, no more pressurized oil is supplied from the pump to port **MA**. At the same time, the oil from the outlet port of the motor returns from the control valve to the tank, and the circuit is closed.
- The pressure at port **MB** rises, and rotating resistance to the motor is generated, so the brake starts to take effect. If the pressure at port **MB** rises to the set pressure of safety valve (1), safety valve (1) opens and releases the pressurized oil at port **MB** to port **S**.
- No pressurized oil is supplied at port **MA**, but the swing continues, so negative force is generated.

When this negative pressure drops to the set pressure of suction valve (2), suction valve (2) opens and oil is supplied from port **S** to prevent cavitation.




Operation of swing brake

1) Swing brake solenoid valve de-energized

If the swing brake solenoid valve is de-energized, the flow of pressurized oil from the control pump is shut off, and port **B** is connected to the tank circuit.


As a result, brake piston (6) is pushed down by brake spring (7), pushes disc (5) and plate (4) together, and the brake is applied.




2) Swing brake solenoid valve energized

When the swing brake solenoid valve is energized, the valve is switched, and pressurized oil from the control valve enters port **B** and flows to brake chamber **a**.

The pressurized oil entering chamber **a** overcomes brake spring (7) and pushes brake piston (6) up. As a result, disc (5) and plate (4) are separated and the brake is released.



CENTER SWIVEL JOINT




1. Cover
2. Body
3. Slipper seal
4. O-ring
5. Shaft

- A1. From control valve port B2
 A2. To R.H. travel motor port PB
 B1. From control valve port B5
 B2. To L.H. travel motor port PA
 C1. From control valve port A2
 C2. To R.H. travel motor port PA

- D1. From control valve port A5
 D2. To L.H. travel motor port PB
 E1. From travel speed EPC valve
 E2. To L.H. and R.H. travel motors
 port P
 T1. To tank
 T2. From L.H. and R.H. travel motors
 port T

TRAVEL MOTOR

HMV160ADT-2







- a. Port PB (from control valve)
- b. Port PA (from control valve)
- c. Port T (to tank)
- d. Port P (from travel speed solenoid valve)

Specifications

Model:	HMV160ADT-2
Theoretical delivery:	Min 110.1 cc/rpm Max 160.8 cc/rpm
Set pressure:	34.8 MPa (355 kg/cm ²)
Rated speed:	Min. capacity 2,225 rpm Max. capacity 1,524 rpm
Brake releasing pressure:	1.2 ± 0.4 MPa (12 ± 4 kg/cm ²)
Travel speed switching pressure:	0.8 $\pm_{-0.1}^{+0.4}$ MPa (Differential pressure) (8 $\pm_{-1}^{+4}$ kg/cm ²) (Differential pressure))

STRUCTURE AND FUNCTION

TRAVEL MOTOR




- | | |
|-----------------|----------------------|
| 1. Output shaft | 9. Regulator valve |
| 2. Motor case | 10. Spring |
| 3. Ball | 11. Brake spring |
| 4. Rocker cam | 12. Brake piston |
| 5. Piston | 13. Plate |
| 6. Cylinder | 14. Disc |
| 7. Valve plate | 15. Regulator piston |
| 8. End cover | 16. Spring |

- | |
|--------------------------|
| 17. Check valve spring |
| 18. Check valve |
| 19. Counterbalance valve |
| 20. Spool return spring |
| 21. Safety valve |
| 22. Slow return valve |


Operation of motor

- 1) At low speed (motor swash plate angle at maximum)



- The solenoid valve is de-energized, so the pilot pressure oil from the control pump does not flow to port **P**.
For this reason, regulator valve (9) is pushed fully to the right by spring (10).
- Because of this, it pushes slow return valve (22), and the main pressure oil from the control valve going to end cover (8) is shut off by regulator valve (9).
- Fulcrum **a** of rocker cam (4) is eccentric to point of application **b** of the combined force of the propulsion force of the piston of cylinder (6), so the combined force of the piston propulsion force acts as a moment to angle rocker cam (4) in the direction of the maximum swash plate angle.
- At the same time, the pressurized oil at regulator piston (15) passes through orifice **c** in regulator valve (9) and is drained to the motor case.
- As a result, rocker cam (4) moves in the maximum swash plate angle direction, the motor capacity becomes maximum, and the system is set to low speed.

- 2) At high speed (motor swash plate angle at minimum)




- When the solenoid valve is energized, the pilot pressure oil from the control pump flows to port P, and pushes regulator valve (9) to the left.
- Because of this, the main pressure oil from the control valve passes through passage d in regulator valve (9), enters regulator piston (15), and pushes regulator piston (15) to the right.
- As a result, rocker cam (4) moves in the minimum swash plate angle direction, the motor capacity becomes minimum, and the system is set to high travel speed.

Operation of parking brake

1) When starting to travel

- When the travel lever is operated, the pressurized oil from the pump actuates counterbalance valve spool (19), opens the circuit to the parking brake, and flows into chamber a of brake piston (12). It overcomes the force of spring (11), and pushes piston (12) to the right.


When this happens, the force pushing plate (13) and disc (14) together is lost, so plate (13) and disc (14) separate and the brake is released.



2) When stopping travel


- When the travel lever is placed in neutral, counterbalance valve spool (19) returns to the neutral position and the circuit to the parking brake is closed.

The pressurized oil in chamber a of brake piston (12) is drained to the case from the orifice in the brake piston, and brake piston (12) is pushed fully to the left by spring (11). As a result, plate (13) and disc (14) are pushed together, and the brake is applied. A time delay is provided by having the pressurized oil pass through a throttle in slow return valve (22) when the brake piston returns, and this ensures that the brake is applied after the machine stops.



Operation of brake valve

- The brake valve consists of a check valve, counterbalance valve, and safety valve in a circuit as shown in the diagram on the right. (Fig. 1)
- The function and operation of each component is as given below.



(Fig. 1)


1) Counterbalance valve, check valve

Function


- When traveling downhill, the weight of the machine makes it try to travel faster than the speed of the motor. As a result, if the machine travels with the engine at low speed, the motor will rotate without load and the machine will run away, which is extremely dangerous. To prevent this, these valves act to make the machine travel according to the engine speed (pump discharge amount).

Operation when pressurized oil is supplied

- When the travel lever is operated, the pressurized oil from the control valve is supplied to port PA. It pushes open check valve (18a) and flows from motor inlet port MA to motor outlet port MB. However, the motor outlet port is closed by check valve (18b) and spool (19), so the pressure at the supply side rises. (Fig. 2).
- The pressurized oil at the supply side flows from orifice E1 in spool (19) and orifice E2 in the piston to chamber S1. When the pressure in chamber S1 goes above the spool switching pressure, spool (19) is pushed to the right. As a result, port MB and port PB are connected, the outlet port side of the motor is opened, and the motor starts to rotate. (Fig. 3).




(Fig. 2)



(Fig. 3)

Operation of brake when traveling downhill

- If the machine tries to run away when traveling downhill, the motor will turn under no load, so the pressure at the motor inlet port will drop, and the pressure in chamber **S1** through orifices **E1** and **E2** will also drop. When the pressure in chamber **S1** drops below the spool switching pressure, spool (19) is returned to the left by spring (20), and outlet port **MB** is throttled. As a result, the pressure at the outlet port side rises, resistance is generated to the rotation of the motor, and this prevents the machine from running away. In other words, the spool moves to a position where the pressure at outlet port **MB** balances the pressure at the inlet port and the force generated by the weight of the machine. It throttles the outlet port circuit and controls the travel speed according to the amount of oil discharged from the pump. (Fig. 4)




(Fig. 4)

2) Safety valve (2-direction operation, 2-stage set safety valve)

Function

- When travel is stopped (or when traveling downhill), the circuits at the inlet and outlet ports of the motor are closed by the counterbalance valve. However, the motor is rotated by inertia, so the pressure at the outlet port of the motor will become abnormally high and will damage the motor or piping. The safety valve acts to release this abnormal pressure and send it to the inlet port side of the motor to prevent damage to the equipment.




(Fig. 5)

Operation in both directions

1) When pressure in chamber MB has become high (when rotating clockwise)


- When the travel is stopped (or when traveling downhill), chamber **MB** in the outlet port circuit is closed by the check valve of the counterbalance valve, but the pressure at the outlet port rises because of inertia. (Fig. 5)
- If the pressure goes above the set pressure, the force produced by the difference in area between **D1** and **D2** [$\pi 4(D1^2 - D2^2) \times \text{pressure}$] overcomes the force of the spring and moves the poppet to the left, so the oil flows to chamber **MA** in the circuit on the opposite side. (Fig. 6).



(Fig. 6)


2) When pressure in chamber **MA** has become high (when rotating counterclockwise)

- When the travel is stopped (or when traveling downhill), chamber **MA** in the outlet port circuit is closed by the check valve of the counterbalance valve, but the pressure at the outlet port rises because of inertia. (Fig. 7)



(Fig. 7)

- If the pressure goes above the set pressure, the force produced by the difference in area between **D1** and **D3** [$\pi/4(D3^2 - D1^2) \times \text{pressure}$] overcomes the force of the spring and moves the poppet to the left, so the oil flows to chamber **MB** in the circuit on the opposite side. (Fig. 8)




(Fig. 8)

Operation of mechanism for varying set pressure

1) When starting travel (high-pressure setting)

- When the travel lever is operated, the pressurized oil from the pump actuates counterbalance valve spool (19), and opens the pilot circuit to the safety valve. The oil passes from chamber **G** to passage **H** and flows into chamber **J**, pushes the piston to the right, and compresses the spring to make the set load larger. Because of this, the set pressure of the safety valve is switched to the high pressure setting, and a large draw-bar pull is made available.




(Fig. 9)

STRUCTURE AND FUNCTION**TRAVEL MOTOR****2) When stopping travel (low-pressure setting)**

- When the travel lever is placed at neutral, the pressure in chamber **PA** drops and counterbalance valve spool (19) returns to the neutral position. While the counterbalance valve spool is returning to the neutral position, the pressurized oil in chamber **J** passes through passage **H**, and escapes to chamber **PA** from chamber **G**. The piston moves to the left, and the set load becomes smaller. Because of this, the set pressure of the safety valve is switched to the low-pressure setting and relieves the shock when reducing speed.


[Set pressure of safety valve]

When starting, } : High-pressure when traveling } setting	When stopping: Low-pressure setting
37.7 MPa (385 kg/cm ²)	27.4 MPa (280 kg/cm ²)



(Fig. 10)

VALVE CONTROL




1. Travel PPC valve
2. L.H. travel lever
3. R.H. travel lever
4. Right PPC valve
5. Right work equipment lever
6. Accumulator
7. Solenoid block
8. Control valve

9. Hydraulic pump
10. LS control EPC valve
11. PPC shuttle valve
12. Left work equipment lever
13. PPC safety lock valve
14. Left PPC valve
15. Safety lock lever

Lever positions

- | | |
|---------------|------------------|
| ① NEUTRAL | ⑩ Swing left |
| ② Boom RAISE | ⑪ NEUTRAL |
| ③ Boom LOWER | ⑫ Travel REVERSE |
| ④ Bucket DUMP | ⑬ Travel FORWARD |
| ⑤ Bucket CURL | ⑭ LOCK |
| ⑥ NEUTRAL | ⑮ FREE |
| ⑦ Arm IN | |
| ⑧ Arm OUT | |
| ⑨ Swing right | |

WORK EQUIPMENT, SWING PPC VALVE








- a. Port P (from control pump)
- b. Port T (to tank)
- c. Port P2 (L.H.: Arm IN/R.H.: Boom RAISE)

- d. Port P4 (L.H.: Left swing/R.H.: Bucket DUMP)
- e. Port P1 (L.H.: Arm OUT/R.H.: Boom LOWER)
- f. Port P3 (L.H.: Right swing/R.H.: Bucket CURL)

STRUCTURE AND FUNCTION

WORK EQUIPMENT, SWING PPC VALVE



1. Spool
2. Metering spring
3. Centering spring
4. Piston
5. Disc
6. Nut (for connecting lever)

7. Joint
8. Plate
9. Retainer
10. Body
11. Filter

STRUCTURE AND FUNCTION

WORK EQUIPMENT, SWING PPC VALVE

Operation

1) At neutral

Ports **A** and **B** of the control valve and ports **P1** and **P2** of the PPC valve are connected to drain chamber **D** through fine control hole **f** in spool (1). (Fig. 1)

2) Fine control (neutral → fine control)


When piston (4) starts to be pushed by disc (5), retainer (9) is pushed. Spool (1) is also pushed by metering spring (2) and moves down.

When this happens, fine control hole **f** is shut off from drain chamber **D**. At almost the same time, it is connected to pump pressure chamber **PP**, and the pilot pressure of the control pump is sent from port **A** through fine control hole **f** to port **P1**.


When the pressure at port **P1** rises, spool (1) is pushed back. Fine control hole **f** is shut off from pump pressure chamber **PP**. At almost the same time, it is connected to drain chamber **D**, so the pressure at port **P1** escapes. As a result, spool (1) moves up and down until the force of metering spool (2) is balanced with the pressure of port **P1**.

The relationship of the positions of spool (1) and body (10) (fine control hole **f** is in the middle between drain hole **D** and pump pressure chamber **PP**) does not change until retainer (9) contacts spool (1).

Therefore, metering spring (2) is compressed in proportion to the travel of the control lever, so the pressure at port **P1** also rises in proportion to the travel of the control lever. In this way, the spool of the control valve moves to a position where the pressure of chamber **A** (same as pressure at port **P1**) and the force of the return spring of the control valve spool are balanced. (Fig. 2)



(Fig. 1)



(Fig. 2)


3) Fine control (control lever returned)

When disc (5) starts to be returned, spool (1) is pushed up by the force of centering spring (3) and the pressure at port **P1**.

Because of this, fine control hole **f** is connected to drain chamber **D**, and the pressurized oil at port **P1** is released.

If the pressure at port **P1** drops too much, spool (1) is pushed down by metering spring (2), so fine control hole **f** is shut off from drain chamber **D**. At almost the same time, it is connected to pump pressure chamber **PP**, so the pressure at port **P1** supplies the pump pressure until the pressure recovers to a pressure equivalent to the position of the lever.

When the control valve returns, oil in drain chamber **D** flows in from fine control hole **f'** of the valve on the side that is not moving. It passes through port **P2** and goes to chamber **B** to charge the oil. (Fig. 3)




(Fig. 3)

4) At full stroke


Disc (5) pushes down piston (4), and retainer (9) pushes down spool (1). Fine control hole **f** is shut off from drain chamber **D**, and is connected to pump pressure chamber **PP**. Therefore, the pilot pressure oil from the control pump passes through fine control hole **f** and flows to chamber **A** from port **P1** to push the control valve spool.

The return oil from chamber **B** passes from port **P2** through fine control hole **f'** and flows to drain chamber **D**. (Fig. 4)



(Fig. 4)


TRAVEL PPC VALVE




- a. Port P (from control pump)
- b. Port T (to tank)
- c. Port P1 (L.H. travel FORWARD)
- d. Port P3 (R.H. travel FORWARD)
- e. Port P2 (L.H. travel REVERSE)
- f. Port P4 (R.H. travel REVERSE)

STRUCTURE AND FUNCTION


TRAVEL PPC VALVE




A - A



B - B



C - C




D - D

- 1. Piston
- 2. Plate
- 3. Collar
- 4. Body

- 5. Valve
- 6. Metering spring
- 7. Centering spring
- 8. Bolt

OPERATION**1) At neutral**

Ports **A** and **B** of the control valve and ports **P1** and **P2** of the PPC valve are connected to drain chamber **D** through fine control hole **f** in spool (1). (Fig. 1)



(Fig. 1)

2) Fine control (neutral → fine control)


When piston (4) starts to be pushed by disc (5), retainer (9) is pushed. Spool (1) is also pushed by metering spring (2) and moves down.

When this happens, fine control hole **f** is shut off from drain chamber **D**. At almost the same time, it is connected to pump pressure chamber **PP**, and the pilot pressure of the control pump is sent from port **A** through fine control hole **f** to port **P1**.

When the pressure at port **P1** rises, spool (1) is pushed back. Fine control hole **f** is shut off from pump pressure chamber **PP**. At almost the same time, it is connected to drain chamber **D**, so the pressure at port **P1** escapes. As a result, spool (1) moves up and down until the force of metering spool (2) is balanced with the pressure of port **P1**.

The relationship of the positions of spool (1) and body (10) (fine control hole **f** is in the middle between drain hole **D** and pump pressure chamber **PP**) does not change until retainer (9) contacts spool (1).

Therefore, metering spring (2) is compressed in proportion to the travel of the control lever, so the pressure at port **P1** also rises in proportion to the travel of the control lever. In this way, the spool of the control valve moves to a position where the pressure of chamber **A** (same as pressure at port **P1**) and the force of the return spring of the control valve spool are balanced. (Fig. 2)



(Fig. 2)


3) Fine control (control lever returned)

When disc (5) starts to be returned, spool (1) is pushed up by the force of centering spring (3) and the pressure at port **P1**.

Because of this, fine control hole **f** is connected to drain chamber **D**, and the pressurized oil at port **P1** is released.

If the pressure at port **P1** drops too much, spool (1) is pushed down by metering spring (2), so fine control hole **f** is shut off from drain chamber **D**. At almost the same time, it is connected to pump pressure chamber **PP**, so the pressure at port **P1** supplies the pump pressure until the pressure recovers to a pressure equivalent to the position of the lever.

When the control valve returns, oil in drain chamber **D** flows in from fine control hole **f'** of the valve on the side that is not moving. It passes through port **P2** and goes to chamber **B** to charge the oil. (Fig. 3)




(Fig. 3)

4) At full stroke


Disc (5) pushes down piston (4), and retainer (9) pushes down spool (1). Fine control hole **f** is shut off from drain chamber **D**, and is connected to pump pressure chamber **PP**. Therefore, the pilot pressure oil from the control pump passes through fine control hole **f** and flows to chamber **A** from port **P1** to push the control valve spool.

The return oil from chamber **B** passes from port **P2** through fine control hole **f'** and flows to drain chamber **D**. (Fig. 4)




(Fig. 4)

SERVICE PPC VALVE



1. Pin
 2. Cam
 3. Ball
 4. Piston
 5. Cover
 6. Sleeve
 7. Centering spring
 8. Metering spring
 9. Spool
 10. Body
-
- a. Port **T** (to tank)
 - b. Port **P** (from control pump)
 - c. Port **A** (to service valve P-1)
 - d. Port **B** (to service valve P-2)




STRUCTURE AND FUNCTION

SERVICE PPC VALVE

OPERATION


At neutral

- The pressurized oil from the control pump enters from port **P** and is blocked by spool (9).
- Ports **A** and **B** of the control valve and ports **a** and **b** of the PPC valve are connected to drain port **T** through fine control hole **X** of spool (9).



When operated


- When cam (2) is moved, metering spring (8) is pushed by ball (3), piston (4), and sleeve (6), and spool (9) is pushed down by this.
- As a result, fine control hole **X** is shut off from the drain circuit. At almost the same time, fine control portion **Y** is connected with port **a**, and the pressurized oil from port **P** flows from port **a** to port **A** of the control valve.




STRUCTURE AND FUNCTION

SERVICE PPC VALVE

- When the pressure at port **a** becomes higher, spool (9) is pushed back by the force acting on the end of the spool. When fine control portion **Y** closes, fine control hole **X** is connected to the drain circuit at almost the same time.
- As a result, spool (9) moves up and down to balance the force at port **a** and the force at metering spring (8).
- Therefore, metering spring (8) is compressed in proportion to the amount the control lever is moved. The spring force becomes larger, so the pressure at port **a** also increases in proportion to the amount the control lever is operated.
- In this way, the control valve spool moves to a position where the pressure of port **A** (the same as the pressure at port **a**) is balanced with the force of the return spring of the control valve spool.




PPC SAFETY LOCK VALVE



1. Lever
2. Body
3. Seat
4. Ball
5. End cap

PPC ACCUMULATOR




1. Gas plug
2. Shell
3. Poppet
4. Holder
5. Bladder
6. Oil port

Specifications

Actual gas volume: 400 cm³

PPC SHUTTLE VALVE, TRAVEL JUNCTION VALVE



1. PPC shuttle valve
2. Travel junction valve


Outline

- The PPC shuttle valve and travel junction valve form a combined structure.

STRUCTURE AND FUNCTION

PPC SHUTTLE VALVE, TRAVEL JUNCTION VALVE

PPC SHUTTLE VALVE



Function

- The PPC shuttle valve sends the PPC valve output pressure to the control valve and travel junction valve. It is provided with a mount port for the pressure switch for detecting the pilot pressure.


STRUCTURE AND FUNCTION

PPC SHUTTLE VALVE, TRAVEL JUNCTION VALVE

- a. Port P11 [to control valve (swing)]
- b. Port P21 [to control valve (swing)]
- c. Port P31 [to control valve (bucket)]
- d. Port P41 [to control valve (bucket)]
- e. Port P51 [to control valve (boom)]
- f. Port P61 [to control valve (arm)]
- g. Port PLS (from LS select valve)
- h. Port P71 [to control valve (arm)]
- i. Port P81 [to control valve (boom)]
- j. Port PA1 [to control valve (R.H. travel)]
- k. Port PB1 [to control valve (L.H. travel)]
- l. Port PC1 [to control valve (L.H. travel)]
- m. Port P91 [to control valve (R.H. travel)]
- n. Port P12 (from swing PPC valve)
- o. Port P22 (from swing PPC valve)
- p. Port P32 (from bucket PPC valve)
- q. Port P42 (from bucket PPC valve)
- r. Port P52 (from boom PPC valve)
- s. Port P62 (from arm PPC valve)
- t. Port P72 (from arm PPC valve)
- u. Port P82 (from boom PPC valve)
- v. Port PA2 (from R.H. travel PPC valve)
- w. Port PB2 (from L.H. travel PPC valve)
- x. Port PC2 (from L.H. travel PPC valve)
- y. Port P32 (from R.H. travel PPC valve)
- z1. Port PR (to travel junction valve)
- z2. Port PF (to travel junction valve)
- aa. Port A1 (mount port for swing pressure switch)
- ba. Port A8 (mount port for bucket DUMP pressure switch)
- bb. Port A2 (mount port for bucket CURL pressure switch)
- ca. Port A4 (mount port for arm OUT pressure switch)
- cb. Port A3 (mount port for arm IN pressure switch)
- da. Port A5 (mount port for boom RAISE pressure switch)
- db. Port A7 (mount port for boom LOWER pressure switch)
- ee. Port A6 (mount port for travel pressure switch)

STRUCTURE AND FUNCTION

PPC SHUTTLE VALVE, TRAVEL JUNCTION VALVE




- 1. Body
- 2. Plug
- 3. Ball

STRUCTURE AND FUNCTION

PPC SHUTTLE VALVE, TRAVEL JUNCTION VALVE

TRAVEL JUNCTION VALVE




1. Body
2. Plug
3. Spring
4. Spool

- a. Port T1 (from L.H. travel control valve)
- b. Port T2 (from R.H. travel control valve)
- c. Port T3 (from L.H. travel control valve)
- d. Port T4 (from R.H. travel control valve)
- e. Port Pf (from PPC shuttle valve)
- f. Port PR (from PPC shuttle valve)

STRUCTURE AND FUNCTION

PPC SHUTTLE VALVE, TRAVEL JUNCTION VALVE

STRAIGHT-TRAVEL SYSTEM



Function

- A travel junction valve is installed between the travel valve and travel motor to compensate for any difference in the oil flow to the left and right travel circuits when traveling in a straight line.
- Because of this, the flow of oil to the left and right travel motors when traveling in a straight line is almost the same, so there is no travel deviation.
- The travel junction valve interconnects the travel circuits when the straight-travel is operated independently or when the straight travel + another actuator are operated simultaneously.
- When steering, if the difference in the movement of the travel levers is more than approx. 10 mm, the travel junction valve is switched, and the left and right travel circuits are shut off.

STRUCTURE AND FUNCTION


PPC SHUTTLE VALVE, TRAVEL JUNCTION VALVE

Operation

- A: PPC output pressure (R.H. travel REVERSE or L.H. travel FORWARD)
 B: PPC output pressure (R.H. travel FORWARD or L.H. travel REVERSE)


When traveling in a straight line in forward or reverse

- When traveling forward (or in reverse), there is no difference in the pilot pressure from the PPC shuttle valve (the output pressure of each PPC valve), so the spool is balanced in the middle. In this condition, the R.H. FORWARD and L.H. FORWARD, and R.H. REVERSE and L.H. REVERSE are interconnected through the spool.




When steering in forward or reverse

- When the steering is operated in forward (or reverse), if the difference in the pilot pressure from the PPC shuttle valve becomes greater than the switching pressure (spring force), the spool moves to the right or left and the left and right forward and left and right reverse passages are separated. Because of this, a difference in pressure is created in the left and right circuits, and the steering can be operated.



EPC SOLENOID VALVE

For LS select, boom Hi 2-stage safety valve, merge/flow divider, travel speed, swing brake




1. LS select solenoid valve
2. Boom Hi 2-stage safety valve solenoid valve
3. Merge/flow divider solenoid valve
4. Travel speed solenoid valve
5. Swing brake solenoid valve

- a. To tank
- b. From control pump
- c. To PPC valve
- d. From shuttle valve
- e. To LS select valve
- f. To boom control valve
- g. To merge/flow divider valve
- h. To L.H. and R.H. travel motors
- i. To swing motor
- j. To accumulator

STRUCTURE AND FUNCTION

EPC SOLENOID VALVE




1. Connector
2. Variable core
3. Coil
4. Cage
5. Spool
6. Block
7. Spring

Operation


When solenoid is de-energized

- The signal current does not flow from the controller, so solenoid (3) is de-energized. For this reason, spool (5) is pushed to the right by spring (6). As a result, the circuit between ports **P** and **A** closes and the pressurized oil from the control pump does not flow to the actuator. At the same time, the pressurized oil from the actuator flows from port **A** to port **T**, and is then drained to the tank.



When solenoid is energized


- When the signal current flows from the controller to solenoid (3), solenoid (3) is energized. For this reason, spool (5) is pushed to the left. As a result, the pressurized oil from the control pump flows from port **P** through the inside of spool (5) to port **A**, and then flows to the actuator. At the same time, port **T** is closed, and this stops the oil from flowing to the tank.



STRUCTURE AND FUNCTION

EPC SOLENOID VALVE

FOR LS VALVE CONTROL



- 1. Body
- 2. Spool
- 3. Spring
- 4. Push pin

- 5. Coil
- 6. Plunger
- 7. Connector


- a. Port C (to LS valve)
- b. Port T (to tank)
- c. Port P (from control pump)

STRUCTURE AND FUNCTION

EPC SOLENOID VALVE

Function

- The EPC valve consists of the proportional solenoid portion and the hydraulic valve portion.
- When it receives signal current i from the governor and pump controller, it generates the EPC output pressure in proportion to the size of the signal, and outputs it to the LS valve.




Operation

1. When signal current is 0 (coil de-energized)

- There is no signal current flowing from the controller to coil (5), coil (5) is de-energized.
- For this reason, spool (2) is pushed to the right by spring (3).

As a result, port **P** closes and the pressurized oil from the control pump does not flow to the LS valve.

At the same time, the pressurized oil from the LS valve passes from port **C** through port **T** and is drained to the tank.




STRUCTURE AND FUNCTION

EPC SOLENOID VALVE


2. When signal current is very small (coil energized, fine control)

- When a very small signal current flows to coil (5), coil (5) is energized, a propulsion force is generated, and this pushes plunger (6) to the left.
- Push pin (4) pushes spool (2) to the left, and pressurized oil flows from port **P** to port **C**.
- When the pressure at port **C** rises and the load of spring (3) + the force acting on surface **a** of spool (2) becomes greater than the propulsion force of plunger (6), spool (2) is pushed to the right. The circuit between port **P** and port **C** is shut off, and at the same time, port **C** and port **T** are connected.
- As a result, spool (2) moves up and down so that the propulsion force of plunger (6) is balanced with the load of spring (3) + pressure of port **C**.
- Therefore, the circuit pressure between the EPC valve and the LS valve is controlled in proportion to the size of the signal current.




3. When signal current is maximum (coil energized, operated fully)

- When the signal current flows to coil (5), coil (5) is energized.
- When this happens, the signal current is at its maximum, so the propulsion force of plunger (6) is also at its maximum. For this reason, spool (1) is pushed fully to the left by push pin (4).
- As a result, the flow of pressurized oil from port **P** flows at its maximum to port **C**, and the circuit pressure between the EPC valve and LS valve becomes the maximum. At the same time, port **T** closes and stops the oil from flowing to the tank.



BOOM SAFETY VALVE




STRUCTURE AND FUNCTION

BOOM HOLDING VALVE


OPERATION BOOM RAISE

- During boom raising the pilot signal from wrist control operates control valve spool to direct high pressure oil to port V of hose burst valve.
- This pressure lifts check valve (4) from seat & high pressure oil flows in the bottom of the cylinder raising the boom.



BOOM LOWER

- During boom lowering the pilot signal reverses the flow through the control valve spool. High pressure oil flow to the head side of the cylinder. Oil in the bottom side of the cylinder flows through the port Cy of the valve but cannot flow past the check valve. The pilot signal also opens the spool (2) of the hose burst valve and allows oil to flow back to tank.




STRUCTURE AND FUNCTION

BOOM HOLDING VALVE

When hose burst occurs (Operation to lower safety)

- The sudden loss of pressure at port V will cause check valve (4) to re-seat and so the valve is locked.
- The boom can be lowered in a controlled way by operating the wrist control in the normal way.



STRUCTURE AND FUNCTION**HYDRAULIC CYLINDER****HYDRAULIC CYLINDER****Specifications**

Unit: mm

Item	Boom	Arm	Bucket
	PC340-6K,LC-6K,NLC-6K	PC340-6K,LC-6K,NLC-6K	PC340-6K,LC-6K,NLC-6K
Outside diameter of piston rod	100	110	100
Inside diameter of cylinder	140	160	140
Stroke	1,480	1,685	1,285
Max. stroke	3,610	4,080	3,275
Min. stroke	2,130	2,395	1,990

OVERLOAD WARNING DEVICE


1.OUTLINE

Function


- This device is installed to prevent the machine from tipping over when it lifts an excessive weight while being used as a crane.

Structure

- When an excessive weight is lifted, the oil pressure goes up at the bottom side of the boom cylinders. When this happens, the pressure switch senses the rising pressure, turns the pressure switch on, and lights the monitor lamp to warn the operator. When the monitor lamp lights, immediately lower the weight to the ground or bring the arm closer in the operator to prevent the machine from tipping over.



Overload warning
pilot lamp



Effective from machine s/n K30601 till K30512
(see also page 10-139-1)

2. OPERATION

- Hose (2) directs the oil pressure from the bottom side of the boom cylinders to pressure switch (3).
- a. When the boom is in the lowest position.**
- When boom (5) is in the lowest position, lever (4) takes position B in Fig. 2 and the operating pressure becomes 360 kg/cm².
- b. When the boom is in the highest position.**
- When the boom is in the highest position, lever (4) takes position B in Fig. 2 and the operating pressure becomes 360 kg/cm².
- c. When the boom is in an arbitrary position.**
- When the boom is in a position anywhere between the lowest and the highest points, the operating pressure of switch (3) will be somewhere between 60 kg/cm² and 360 kg/cm², based on the boom position.
For instance, when the boom is in a certain position between the lowest and the highest points, lever (4) takes a position which corresponds to that boom position.
If lever (4) is in the position to make the operating pressure of the pressure switch 150 kg/cm² (which is the same pressure as the bottom side of the boom cylinder), the pressure switch will turn on when excessive weight is lifted by the boom and the oil pressure of the bottom of the boom cylinders exceeds 150 kg/cm².



When the machine is performing any kind of operation other than lifting loads, fasten the pressure switch lever (4) with the bolt (6) to prolong the life at the pressure switch.




Fig. 1




Fig. 2

STRUCTURE AND FUNCTION

OVERLOAD WARNING DEVICE

3. ADJUSTING PRESSURE OF THE OIL PRESSURE SWITCH

- **Screw D: Pressure range adjustment screw**


To make an adjustment so that the oil pressure switch acts normally when checking the operation of the overload warning device. Turning to the left makes the pressure range wider.

- **Screw E: Zero point adjustment screw**



Turning to the right one complete turn raises the pressure by 57 kg/cm².

Each complete turn to the left lowers the pressure by 57 kg/cm².

When an adjustment is required, contact your Komatsu distributor and have him make the adjustment.



1. Body
2. Bourdon tube
3. Eccentric disc
4. Microswitch
5. Lever and roller
6. Adjustment screw (E)
7. Adjustment screw (D)




STRUCTURE AND FUNCTION


OVERLOAD WARNING DEVICE

Effective from machine s/n K30513. The overload warning system will operate as follow:

Mose (1) disects oil pressure from the bottom side of the boom cylinders to pressure switch (2). Pressure switch (2) signals the warning device, but the alarm is only raised when the machine is in LO mode with active mode switched off.



WORK EQUIPMENT




SBP00311

1. Arm
2. Bucket cylinder
3. Arm cylinder
4. Boom
5. Boom cylinder
6. Bucket

ACTUAL ELECTRIC WIRING DIAGRAM


★ For details of this page, see Section 90.



STRUCTURE AND FUNCTION

ACTUAL ELECTRIC WIRING DIAGRAM

1. Fuel level sensor
2. Working light
3. Hydraulic oil level sensor
4. LS control EPC valve
5. Rear pump pressure sensor
6. Front pump pressure sensor
7. Rear pump TVC valve
8. Front pump TVC valve
9. Rear working light
10. Governor motor
11. Engine speed sensor
12. Engine oil pressure sensor
13. Safety relay
14. Air cleaner clogging sensor
15. Coolant level sensor
16. Window washer motor
17. Horn (high tone)
18. Horn (low tone)
19. Battery relay
20. R.H. head light
21. Battery
22. Wiper motor
23. Horn switch
24. R.H. additional light
25. Room lamp
26. LH additional light
27. LH knob switch
28. Alternator
29. Coolant temperature sensor
30. Grid heater
31. Heater relay
32. Starting motor
33. Air conditioner compressor
34. Engine oil level sensor
35. Fuse box
36. Caution buzzer
37. Starting switch
38. Fuel control dial
39. Cigarette lighter
40. Swing lock switch
41. Wiper switch
42. Light switch
43. Buzzer cancel switch.
44. Service meter (integral to monitor panel)
45. Speaker
46. Kerosene mode connector
47. Heater control panel (air conditioner option)
48. 2-stage pressure relief switch
49. Pump/engine throttle controller
50. Radio
51. TVC prolix resistor
52. Wiper motor controller
53. Additional light relay (Cab)
54. Light relay (Boom, RH Deck, engine room)
55. Monitor panel
56. Swing lock prolix switch
57. TVC prolix switch
58. Swing oil pressure switch
59. Bucket curl oil pressure switch
60. Bucket dump oil pressure switch
61. Arm in oil pressure switch
62. Boom lower oil pressure switch
63. Arm out oil pressure switch
64. Travel oil pressure switch
65. Boom raise oil pressure switch
66. Swing brake solenoid valve
67. Travel speed solenoid valve
68. Pump merge-divider solenoid valve
69. 2-stage relief solenoid valve
70. LS select solenoid valve
71. Rear additional lamp
72. Beacon connector
73. RH Boom working light
74. Engine room lamp
76. Overload caution switch
77. LH Deck additional lamp
78. Lower wiper motor
79. Lower wiper switch
80. Beacon switch
81. Heated seat switch
82. Lower wiper relay
83. Additional light relay (CWT, LH deck)
84. Voltage dropper (rear Radio)
85. Refuelling pump
86. Heater (Air conditioner option)
87. Air conditioner condensor Fan
88. Air conditioner pressure switch





★ For details of this page, see Section 90.

STRUCTURE AND FUNCTION


ELECTRIC CIRCUIT DIAGRAM

★ For details of this page, see Section 90.
(1/3)






★ For details of this page, see Section 90.
(2/3)



ENGINE CONTROL



1. Battery relay
2. Battery
3. Starting switch
4. Fuel control dial
5. Governor motor
6. Starting motor
7. Governor, pump controller
8. Fuel injection pump


Function

- The engine can be started and stopped simply by using the starting switch.
- A dial-type engine control is used to control the engine speed. The governor, pump controller receives the control signal from the fuel control dial, sends a drive signal to the governor motor, and controls the angle of the governor lever in the fuel injection pump.

1. Operation of system


Starting engine

- When the starting switch is turned to the START position, the starting signal flows to the starting motor, and the starting motor turns to start the engine. When this happens, the governor and pump controller checks the signal from the fuel control dial and sets the engine speed to the speed set by the fuel control dial.




Engine speed control

- The fuel control dial sends a signal to the governor and pump controller according to the position of the dial. The governor and pump controller calculates the angle of the governor motor according to this signal, and sends a signal to drive the governor motor so that it is at that angle. When this happens, the operating angle of the governor motor is detected by the potentiometer, and feedback is sent to the governor and pump controller, so that it can observe the operation of the governor motor.




Stopping engine

- When governor and pump controller detects that the starting switch is turned to the STOP position, it drives the governor motor so that the governor lever is set to the NO INJECTION position.
- When this happens, to maintain the electric power in the system until the engine stops completely, the governor and pump controller itself drives the battery relay.




2. Components of system

Fuel control dial




Function

- The fuel control dial is installed at the bottom of the monitor panel. A potentiometer is installed under the knob, and when the knob is turned, it rotates the potentiometer shaft. When the shaft rotates, the resistance of the variable resistor inside the potentiometer changes, and the desired throttle signal is sent to the governor and pump controller. The shaded area in the graph on the right is the abnormality detection area and the engine speed is set at low idling.



Governor motor



Function

- The motor is rotated and the governor lever of the fuel injection pump is controlled by the drive signal from the governor and pump controller.
- A stepping motor is used for the motor which provides the power.
- In addition, a potentiometer for giving feedback is installed to allow observation of the operation of the motor.
- The rotation of the motor is transmitted to the potentiometer through a gear.

Operation


Motor stationary

- Both A phase and B phase of the motor are continuous, and a holding torque is generated in the motor.

Motor rotating

- A pulse current is applied to the A phase and B phase from the governor and pump controller to give synchronous rotation with the pulse.

Governor, pump controller



STRUCTURE AND FUNCTION

ENGINE CONTROL

Input and output signals

CN-1

Pin No.	Name of signal	Input/output
1	Battery realy drive output	Output
2	Pump merge/divider solenoid/NC	Output
3	Swing holding brake solenoid	Output
4	NC	
5	NC	
6	GND	Input
7	Power source (+24)	Input
8	LSdivider solenoid/LS cut-of solenoid	Output
9	Travel selector solenoid	Output
10	NC	
11	NC	
12	GND	Input
13	Power source (+24V)	Input

CN-2

Pin No.	Name of signal	Input/output
1	Solenoid power source (+24V)	Input
2	Governor motor phase A (+)	Output
3	Governor motor phase A (-)	Output
4	Governor motor phase B (+)	Output
5	Governor motor phase B (-)	Output
6	NC	
7	LS-EPC solenoid (+)	Output
8	TVC solenoid 1 (+)	Output
9	TVC solenoid 2 (+)	Output
10	NC	
11	PGND	Input
12	Solenoid power source (+24V)	Input
13	NC	
14	NC	
15	NC	
16	NC	
17	LS-EPC solenoid (-)	Output
18	TVC solenoid 1 (-)	Output
19	TVC solenoid 2 (-)	Output
20	NC	
21	PGND	Input

CN-2


Pin No.	Name of signal	Input/output
1	Engine water temperature sensor	Input
2	Fuel level sensor	Input
3	Pump F pressure input	Input
4	Throttle potentiometer input	Input
5	NC	
6	Pressure sensor power source (+24V)	Output
7	Potentiometer power source (+5V)	Output
8	Starting switch (ACC)	Input
9	Knob switch	Input
10	Battery charge (alternator terminal R)	Input
11	Pump R pressure input	Input
12	Feedback potentiometer input	Input
13	NC	Input
14	Pressure sensor GND	Input
15	Potentiometer GND	Input
16	Starting switch (terminal C)	Input
17	Automatic greasing controller abnormality	Input
18	NC	
19	NC	
20	Boom RAISE pressure switch	Input
21	Arm IN pressure switch	Input
22	S-NET (+)	Input/Output
23	Model selection 1	Input
24	Model selection 3	Input
25	Model selection 5	Input
26	Swing prolix switch	Input
27	Overload sensor	Input
28	Boom LOWER pressure switch	Input
29	Arm OUT pressure switch	Input
30	S-NET (+)	Input/Output
31	Model selection 2	Input
32	Model selection 4	Input
33	Swing lock switch	Input

CN-2

Pin No.	Name of signal	Input/output
1	Engine speed sensor GND	Input
2	Engine speed sensor	Input
3	GND	Input
4	GND	Input
5	Swing pressure switch	Input
6	Service valve pressure switch	Input
7	Engine oil pressure sensor H	Input
8	Radiator water level sensor	Input
9	Hydraulic oil lever sensor	Input
10	NC	
11	Bucket CURL pressure switch	Input
12	Bucket DUMP pressure switch	Input
13	Travel pressure switch	Input
14	NC	
15	Engine oil pressure sensor L	Input
16	Engine oil lever sensor	Input
17	Air cleaner clogging sensor	Input


ELECTRONIC CONTROL SYSTEM

CONTROL FUNCTION



★ For details of the self-diagnostic function, see TROUBLESHOOTING.




TOTAL SYSTEM DIAGRAM



STRUCTURE AND FUNCTION

ELECTRONIC CONTROL SYSTEM

1) Control method in each mode Heavy-duty operation mode



- Matching point in heavy-duty operation mode:
Rated output point




Mode	Model	PC340-6K, PC340LC-6K, PC340NLC-6K
Heavy-duty		173kW (235 PS)/1,750 rpm

- When the load on the pump rises and the pressure rises, the engine speed goes down. When this happens, the pump discharge amount is reduced, and the engine speed is controlled so that it becomes near the rated output point.

If the reverse happens and the pressure goes down, the system is controlled so that the pump discharge amount is increased until the engine speed becomes near the rated output point.

By repeating this control, the engine can always be used at near the rated output point.

General, breaker, finishing operation mode




- Matching point

Mode	G/O	B/O	F/O
Partial output point	95%	95%	86%

Mode	Model	PC340-6K, PC340LC-6K, PC340NLC-6K
G/O		151kW (206 PS)/1,650 rpm
B/O		151kW (206 PS)/1,650 rpm
F/O		125kW (170 PS)/1,450 rpm

- When the load on the pump rises and the pressure rises, the engine speed goes down. When this happens, mutual control of the engine and pump is used to control the system so that the pump absorption torque follows the equal horsepower curve of the engine, and the engine speed is lowered while keeping the torque constant. In this way, the engine is used in a range which provides good fuel efficiency

Lifting operation mode




- Matching point lifting operation mode:
77% partial output point

Mode	Model	PC340-6K, PC340LC-6K, PC340NLC-6K
L/O		106kW (144 PS)/1,300 rpm

- When the lifting operation mode is selected, the engine speed is automatically lowered to the partial position. In this condition, control is carried out in the same way as for the general operation, finishing, and breaker operation modes to match the load on the pump. In this way, the fuel consumption is reduced and the fine control ability is improved.

Power max. mode, travel




- Matchin point lifting operation mode:
77% partial output point


Mode	Model	PC340-6K, PC340LC-6K, PC340NLC-6K
Power max.		173kW (235 PS)/1,750 rpm

- When the pump load increases, the engine speed drops. When this happens, the pump discharge is reduced to prevent the engine speed from going down and to ensure that the engine is used at near the rated output point. The cut-off at relief is canceled and the oil flow at relief is increased.


2) Control function when TVC prolix switch is ON



- Even if any abnormality should occur in the controller or sensor, the TVC prolix switch can be turned ON to provide an absorption torque more or less equivalent to the general operation mode, thereby allowing the machine to maintain its functions.




In this case, it is designed to allow a constant current to flow from the battery to the TVC valve, so oil pressure sensing is carried out only by the TVC valve.



- Optimum matching under various working conditions with the fine control mode function which reduces the hydraulic loss and improves the ease of fine control.


1) LS control function

- The switching point (LS set differential pressure) for the pump discharge amount inside the LS valve is changed by changing the output pressure from the LS EPC valve to the LS valve according to the engine speed and operating condition of the actuator.
- Because of this, the timing for starting the discharge amount from the pump can be optimized, to give excellent ease of compound operation and fine control.




2) Cut-off function

- If the load becomes large during the operation and the pump discharge pressure rises to a point close to the relief pressure, the pump pressure sensor detects this, and the controller sends a signal to the TVC valve to reduce the discharge amount in order to reduce the relief loss.



3) Cut-off cancel function

- The cut-off cancel function stops the actuation of the cut-off function in order to ensure the flow of oil from the pump near the relief pressure, thereby preventing any drop in speed.
- The relief pressure when the cut-off function is actuated is 33.8 MPa (345 kg/cm²), but when the cut-off is canceled, the relief pressure rises to approx. 34.8 MPa (355 kg/cm²). Because of this, the hydraulic pressure is increased by one stage.



Switches and cut-off functions

	Working mode switch		Swing lock switch		Knob switch	
	Heavy digging	Digging	ON	OFF	ON	OFF
Cut-off function	Actuated	Actuated	Canceled	Actuated	Canceled	Actuated

- ※ When the swing lock switch is set to ON, hydraulic oil is quickly warmed, also when the swing lock switch is set to ON, the function is canceled. Under these conditions, when work equipment is relieved, hydraulic oil temperature goes up more quickly, and warming time is shortened.

STRUCTURE AND FUNCTION

ELECTRONIC CONTROL SYSTEM


4) Fine control mode function

- When the finishing mode is selected as the working mode, the pump LS valve is controlled, and the pump discharge amount is reduced to improve the ease of fine control and the precision when finishing.
- Relationship between working mode and pump discharge amount (for independent operation)

Actuator	Boom		Arm	Bucket		Swing	Breaker
	RAISE	LOWER		CURL	DUMP		
Working mode							
Heavy-duty operation (H/O)	100	30	100	75	60	55	—
General operation (G/O)							
Finishing operation (F/O)	83	30	83	60	50	45	—
Lifting mode (L/O)	75		75	55	45	40	—
Breaker (B/O)	100	30	100	75	60	55	45

- ★ In each working mode, the full flow of the pump at the set engine speed is taken as 100%.

3. Power max. function, swift slow-down function



Function

- This function provides an increase in the digging power for a certain time or switches the working mode to the fine operation to reduce the speed. It is operated using the L.H. knob switch to momentarily match the operating conditions.
- ★ The power max. function and swift slow-down function are operated with the same switch. Only one of these functions can be selected at any time; they cannot both be operated together.

1) Power max. function

- During digging operations, when that extra bit of digging power is needed (for example, when digging up boulders), the L.H. knob switch can be pressed to raise the hydraulic pressure by approx. 10% and increase the digging force.
- If the L.H. knob switch is pressed ON when the working mode is at H/O or G/O, each function is automatically set as follows.



Working mode	Engine, pump control	Cut-off function	Actuating time
Heavy-duty operations	Matching at rated output point	Canceled	Automatically canceled after 8.5 sec


2) Swift slow-down function

- During normal operations, if it is desired to carry out lifting operations or finishing operations for a moment, the working mode can be switched to L/O by operating the L.H. knob switch.
- If the L.H. knob switch is pressed ON when the working mode is at H/O or G/O, each function is automatically set as follows.



Working mode	Actuating time
Lifting operation	While switch is kept pressed

4. Auto deceleration system



Function

- If all the control levers are at neutral when waiting for work or waiting for a dump truck, the engine speed is automatically reduced to a midrange speed to reduce fuel consumption and noise.
- If any lever is operated, the engine speed returns immediately to the set speed.

STRUCTURE AND FUNCTION

ELECTRONIC CONTROL SYSTEM


Operation

Control levers at neutral


- If the engine is running at above the deceleration actuation speed (approx. 1400 rpm), and all the control levers are returned to neutral, the engine speed drops immediately to approx. 100 rpm below the set speed to the No. 1 deceleration position.
- If another 4 seconds passes, the engine speed is reduced to the No. 2 deceleration position (approx. 1400 rpm), and is kept at that speed until a lever is operated.

When control lever is operated

- If any control lever is operated when the engine speed is at No. 2 deceleration, the engine speed will immediately rise to the speed set by the fuel control dial.



5. Automatic warming-up and engine overheating prevention function




Function


- If the water temperature is low, this automatically raises the engine speed to warm up the engine after it is started. (Automatic warming-up function).
In addition, if the water temperature rises too high during operations, it reduces the load of the pump to prevent overheating. (Engine overheating prevention function)

STRUCTURE AND FUNCTION**ELECTRONIC CONTROL SYSTEM****1) Engine automatic warming-up function**

- After the engine is started, if the engine coolant temperature is low, the engine speed is automatically raised to warm up the engine.



**2) Engine overheat prevention function**

- This function protects the engine by lowering the pump load and engine speed to prevent overheating when the engine coolant temperature has risen too far.
- This system is actuated when the water temperature is 105°C and above.




6. Swing priority function


- There is a SWING PRIORITY mode switch on the monitor panel. This switch can be turned ON or OFF to change the matching of the boom RAISE and SWING operations. The oil flow is divided and sent to the swing to match the swing angle to allow compound operations to be carried out easily.
Swing priority mode OFF: 90° swing and loading of dump truck
Swing priority mode ON: 180° swing and loading of dump truck



- The change in the matching between the boom RAISE and SWING is carried out by changing the signal to the LS select valve.
When swing priority mode is OFF
Solenoid: ON
LS select valve: merged
When swing priority mode is ON
Solenoid: OFF
LS select valve: divided



7. Swing control system



Function

- The system is provided with a swing lock and swing holding brake function.

STRUCTURE AND FUNCTION**ELECTRONIC CONTROL SYSTEM****1) Swing lock, swing holding brake function**

- The swing lock (manual) can be locked at any desired position, and the swing holding brake (automatic) is interconnected with the swing, so it prevents any hydraulic drift after the swing is stopped.

- Swing lock switch and swing lock, swing holding brake

Lock switch	Lock lamp	Function	Operation
OFF	OFF	Swing holding brake	When swing lever is placed at neutral, swing brake is applied after approx. 5 sec; when swing lever is operated, brake is canceled and swing can be operated freely
ON	ON	Swing lock	Swing lock is actuated and swing is held in position. Even when swing lever is operated, swing lock is not canceled and swing does not move.


※ Operation of swing lock prolix switch

- If any abnormality should occur in the controller, and the swing holding brake is not actuated normally and the swing cannot be operated, the swing lock prolix switch can be operated to cancel the swing lock and allow the swing to be operated.
- ★ Even when the swing lock prolix switch is turned ON, the swing lock switch stays ON and the swing brake is not canceled.
- ★ When the swing brake is canceled, the swing has only a hydraulic brake operated by the safety valve, so if the swing is stopped on a slope, there may be hydraulic drift.


Swing lock prolix switch	ON (when controller is abnormal)		OFF (when controller is normal)	
Swing lock switch	ON	OFF	ON	OFF
Swing brake	Swing lock applied	Swing lock canceled	Swing lock applied	Swing holding brake applied

2) Hydraulic oil quick warm-up function when swing lock switch is ON

- When the swing lock switch is turned ON, the pump cut-off is canceled. If the work equipment is relieved in this condition, the hydraulic oil temperature will rise more quickly and the warming-up time can be reduced.



8. Travel control system



Function

- When traveling, the pump control is carried out, and the travel speed can be selected manually or automatically to give a travel performance that suits the nature of the work or the jobsite.


1) Pump control function when traveling

- If the travel is operated in any working mode other than the heavy-duty operation mode, this increases the pump absorption torque while keeping the working mode and engine speed as the are.
- ★ For details, see PUMP & ENGINE MUTUAL CONTROL.

2) Travel speed selection function



- Manual selection using travel speed switch**
If the travel speed switch is set to Lo, Mi, or Hi, the governor and pump controller controls the pump flow and motor volume at each speed range as shown on the right to switch the travel speed.
- Automatic selection according to engine speed**
If the engine speed is reduced to below 1,350 rpm by the fuel control dial:
 - If the machine is traveling in Lo, it will not shift even if Mi or Hi are selected.
 - If the machine is traveling in Mi, it will not shift eve if Hi is selected.
 - If the machine is traveling in Hi, it will automatically shift to Lo.
- Automatic selection according to pump discharge pressure**
If the machine is traveling with the travel speed switch at Hi, and the load increases, such as when traveling up a steep hill, if the travel pressure continues at 32.3 MPa (330 kg/cm²) for more than 1.0 sec, the pump volume is automatically switched and the travel speed changes to Lo.
(The travel speed switch stays at Hi.)
The machine continues to travel in Lo, and when the load is reduced, such as when the machine travels again on flat ground or goes downhill, and the travel pressure stays at 21.6 MPa (220 kg/cm²) or less for more than 1.0 sec, the pump volume is automatically switched and the travel speed returns to Hi.

Travel speed switch	Lo (Low speed)	Mi (Mid-range speed)	Hi (High speed)
Pump flow (%)	100	60	100
Motor volume	Max.	Min.	Min.
Travel speed (km/h)	3.7	4.5	5.5



9. Components of system

1) Engine speed sensor




1. Wire
2. Magnet
3. Terminal
4. Housing
5. Connector

Function

- The engine speed sensor is installed to the ring gear portion of the engine flywheel. It counts electrically the number of gear teeth that pass in front of the sensor, and sends the results to the governor and pump controller.
- This detection is carried out by a magnet, and an electric current is generated every time the gear tooth passes in front of the magnet.

2) PPC hydraulic switch



1. Plug
2. Switch
3. Connector

Specifications

Composition of points:

N.O. points

Actuation (ON) pressure:



0.5 ± 0.1 MPa

$(5.0 \pm 1.0 \text{ kg/cm}^2)$

Reset (OFF) pressure:

0.3 ± 0.05 MPa


$(3.0 \pm 0.5 \text{ kg/cm}^2)$



Function

- There are 8 switches installed to the PPC shuttle valve. The operating condition detected from the PPC pressure, and this is sent to the governor and pump controller.

3) Pump pressure sensor





Function

- This sensor is installed to the inlet port circuit of the control valve. It converts the pump discharge pressure to a voltage and sends this to the governor and pump controller.


Operation

- When the pressurized oil entering from the pressure introduction portion pressurizes the diaphragm of the pressure detection portion, the diaphragm deflects and changes shape.
- A gauge layer is installed to the face opposite the diaphragm, and the resistance of the gauge layer converts the deflection of the diaphragm into an output voltage and sends it to the amp (voltage amplifier).
- The voltage is further amplified by the amplifier and is sent to the governor and pump controller.
- Relationship between P pressure (MPa (kg/cm²)) and output voltage (V).

$$V = 0.008 \times P + 1.0$$



4) TVC prolix resistor



- 1. Resistor
- 2. Connector

Specification

Resistance: 8.5 Ω

Function

- This resistor acts to allow a suitable current to flow to the TVC solenoid when the TVC prolix switch is ON.
- No current flows when the TVC prolix switch is OFF.

5) Fuel control dial, governor motor, governor and pump controller

★ See ENGINE CONTROL

6) Monitor panel

★ See MONITORING SYSTEM

7) TVC valve

★ See HYDRAULIC PUMP

8) LS control EPC valve

LS select solenoid valve

Boom Hi 2-stage safety valve solenoid valve


Merge/flow divider valve solenoid valve

Travel speed solenoid valve

Swing brake solenoid valve


★ See EPC SOLENOID VALVE

MACHINE MONITOR SYSTEM



Function

- The machine monitor system uses the sensors installed to all parts of the machine to observe the condition of the machine. It processes this information swiftly, and displays it on a panel to inform the operator of the condition of the machine. The content of the information displayed on the machine can broadly be divided as follows.
 1. **Monitor portion**
This gives an alarm if any abnormality occurs in the machine.
 2. **Gauge portion**
This always displays the condition of the machine (coolant temperature, fuel level).
- The monitor panel also has various built-in mode selector switches, and functions as the control panel for the machine control system.

STRUCTURE AND FUNCTION**MACHINE MONITOR SYSTEM****1. Monitor panel****Outline**

- The monitor panel consists of the switches for the monitor display functions, mode selector, and electrical components. It has a built-in CPU (Central Processing Unit), and processes, displays, and outputs the information. The monitor display panel uses a liquid crystal display (LCD). The mode switches are flat sheet switches.

Input and output signals**CN-P01**

Pin No.	Name of signal
1	N/W signal
2	N/W GND
3	ND
4	NC
5	Swing lock
6	Buzzer stop
7	Buzzer output
8	Lamp
9	Key ON signal
10	Terminal BR
11	N/W signal
12	N/W GND
13	NC
14	NC
15	NC
16	NC
17	NC
18	Preheating
19	Start signal
20	NC


CN-P02

Pin No.	Name of signal
1	GND
2	NC
3	NC
4	NC
5	NC
6	NC
7	NC
8	+VB
9	GND
10	NC
11	NC
12	NC
13	NC
14	NC
15	NC
16	+VB

STRUCTURE AND FUNCTION



MACHINE MONITOR SYSTEM


DISPLAY MONITOR



1. Clock (displays error code when error occurs)
2. Service meter (displays telephone number when error occurs)
3. Coolant temperature gauge
4. Fuel gauge
5. Engine oil level caution lamp
6. Hydraulic oil level caution lamp
7. Preheating pilot lamp
8. Swing holding brake pilot lamp
9. Charge level caution lamp
10. Air cleaner clogging caution lamp
11. PPC oil pressure caution lamp
12. Overload caution lamp
13. Coolant level caution lamp
14. Engine oil pressure caution lamp
15. Fuel level caution lamp
16. Coolant temperature caution lamp

Content of display

Symbol	Display item	Display range	When engine is stopped	When engine is running
 SAP00519	Coolant level	Below low level	Flashes when abnormal	Flashes and buzzer sounds when abnormal
 SAP00520	Engine oil pressure	below 0.11 ± 0.01 MPa (1.1 ± 0.1 kg/cm ²)	Lights up when normal (goes out when engine starts)	Flashes and buzzer sounds when abnormal
 SAP00521	Air cleaner clogging	When clogged	OFF	Flashes when abnormal
 SAP00522	Charge level	When charging is defective	Lights up when normal (goes out when engine starts)	Flashes when abnormal
 SAP00523	Engine oil level	Below low level	Flashes when abnormal	OFF
 SAP00524	Hydraulic oil level	Below low level	OFF	Flashes when abnormal
 SDP00688	Over load	Above high level	OFF	Flashes when abnormal
 SDP00689	PPC oil pressure	Below low level	OFF	Flashes when abnormal
 SDP00582	Parking	When swing is locked	Lights up when swing lock switch is ON, flashes when swing lock prolix switch is ON	
 SAP00526	Preheating	During preheating	Lights up for 30 seconds when starting switch is at HEAT, then flashes for 10 seconds to indicate that preheating is completed	
 SAP00703	Coolant temperature	Flashes when above 102°C, flashes and buzzer sounds when above 105°C		
 SAP00704	Fuel level	Flashes when below low level		

STRUCTURE AND FUNCTION**MACHINE MONITOR SYSTEM****MODE SELECTION SWITCHES**

1. Working mode switch
2. Auto deceleration switch
3. Swing priority mode switch
4. Travel speed switch
5. Power max./Swift slow-down switch

- The switch portion consists of five mode selection switches, and the condition of the machine changes each time that any switch is pressed. The LED above the switch lights up to display the present condition of the machine.

Switch actuation table

Switch	Item	Action
 SDP00692	WORKING MODE	H/O ↔ G/O ↔ F/O ↔ L/O ↔ B/O
 SDP00693	KNOB BUTTON	 (POWER UP) ↔ (SPEED DOWN) SDP00694
 SDP00695	AUTO DECEL	ON ↔ OFF
 SDP00696	TRAVEL SPEED	Hi ↔ Mi ↔ Lo
 SAP00706	SWING PRIORITY MODE	OFF ↔ ON

★ The bold letters indicate the default position of the switch when the starting switch is turned ON.


2. Sensors

- The signals from the sensors are input directly to the monitor panel.

The contact type sensors are always connected at one end to the chassis GND.

Name of sensor	Type of sensor	When normal	When abnormal
Coolant level	Contact type	ON (closed)	OFF (open)
Engine oil level	Resistance type	-	-
Hydraulic oil level	Contact type	ON (closed)	OFF (open)
Engine oil pressure	Contact type	OFF (open)	ON (closed)
Coolant temperature	Resistance type	—	—
Fuel level	Resistance type	—	—
Air cleaner clogging	Contact type	OFF (closed)	ON (open)

Coolant level sensor




1. Sub-tank
2. Float
3. Sensor
4. Connector

STRUCTURE AND FUNCTION



MACHINE MONITOR SYSTEM

Hydraulic oil level sensor




1. Connector
2. Bracket
3. Float
4. Switch

Engine oil pressure sensor




Composition of circuit

Coolant temperature sensor



1. Connector
2. Plug
3. Thermistor



Composition of circuit

STRUCTURE AND FUNCTION


MACHINE MONITOR SYSTEM

Engine oil level sensor




1. Sensor
2. Conector

Signal

Composition of circuit




Air cleaner clogging sensor



STRUCTURE AND FUNCTION

FRONT WINDOW AUTO PULL-UP SYSTEM

Fuel level sensor





BREAKER MODE HYDRAULIC PERFORMANCE

The performance of the hydraulic system when used in the B.O. mode for attachment operation, is shown below.

The pressure **Pa** is that which is observed at the inlet to the Attachment.

The pressure **Pb** is the pressure observed on the return line or tank line (back pressure).

The figure below shows the pressures at points A and B for varying flow through the attachment.



20 TESTING AND ADJUSTING

Standard value table for engine related parts	20-2	Testing and adjusting TVC valve output pressure (servo piston input pressure)	20-40
Standard value table for chassis related parts	20-3	Testing and adjusting LS valve output pressure (servo piston input pressure- and LS differential pressure)	20-42
Standard value table for electrical parts	20-11	Testing and adjusting control pump circuit oil pressure	20-45
Tools for testing, adjusting, and troubleshooting .	20-20	Testing solenoid valve output pressure	20-47
Measuring exhaust colour	20-21	Measuring PPC valve output pressure and testing PPC shuttle valve	20-49
Adjusting valve clearance	20-22	Adjusting work equipment, swing PPC valve	20-51
Measuring compression pressure	20-25	Testing travel deviation	20-52
Measuring blow-by pressure	20-25	Testing locations causing hydraulic drift of work equipment	20-53
Testing and adjusting fuel injection timing	20-26	Measuring oil leakage	20-55
Measuring engine oil pressure	20-29	Releasing remaining pressure in hydraulic circuit .	20-57
Test fan belt tension	20-30	Testing clearance of swing circle bearing	20-58
Check alternator and water pump belt tension, adjust checking tension	20-31	Testing and adjusting track shoe tension	20-59
Check and adjust tension of air conditioner compressor belt	20-32	Bleeding air	20-60
Adjusting engine speed sensor	20-32		
Measuring air supply pressure (boost pressure) .	20-33		
Turbocharger wastegate Actuator-calibration . . .	20-35		
Testing and adjusting governor motor lever stroke	20-36		
Testing and adjusting hydraulic pressure in work equipment, swing, travel circuit	20-37		

★ Note the following when making judgements using the standard value tables for testing, adjusting, or troubleshooting.

1. The standard value for a new machine given in the table is the value used when shipping the machine from the factory and is given for reference. It is used as a guideline for judging the progress of wear after the machine has been operated, and as a reference value when carrying out repairs.
2. The service limit value given in the tables is the estimated value for the shipped machine based on the results of various tests. It is used for reference together with the state of repair and the history of operation to judge if there is a failure.
3. These standard values are not the standards used in dealing with claims.

 **When carrying out testing, adjusting, or troubleshooting, park the machine on level ground, inset the safety pins, and use blocks to prevent the machine from moving.**

 **When carrying out work together with other workers, always use signals and do not let unauthorized people near the machine.**

 **When checking the water level, always wait for the water to cool down. If the radiator cap is removed when the water is still hot, the water will spurt out and cause burns.**


 **Be careful not to get caught in the fan, fan belt or other rotating parts.**

STANDARD VALUE TABLE FOR ENGINE RELATED PARTS

Applicable model			PC340-6K	
Engine			SA6D114E-1	
Item	Measurement conditions	Unit	Standard value for new machine	Service limit value
Engine speed	High idling	rpm	2,050 ± 50	2,050 ± 50
	Low idling		900 $^{+50}_0$	900 ± 50
	Rated speed		1,750	—
Rated speed	Air supply pressure (boost pressure)	kPa	140	
Exhaust gas color	At sudden acceleration	Bosch index	Max. 2.0	7.5
	At high idling		Max. 1.5	2.5
Valve clearance (normal temperature)	Intake valve	mm	0.30	—
	Exhaust valve		0.61	—
Compression pressure (SAE oil)	(Oil temperature: 40 - 60°C) Engine speed: 250 rpm	MPa (kg/cm ²)	Min. 2.41 (25)	2.01 (21)
Blowby pressure (SAE oil)	(Water temperature: Operating range) At rated output	l/min	Max. 113	226
Oil pressure	(Water temperature: Operating range) At high idling	kPa (kg/cm ²)	207-276 (2.11-2.81)	207 (2.11)
			—	—
	At low idling			69 (0.7)
Oil temperature	At rated speed (inside oil pan)	°C	98.9 - 126.6 (max.)	—
Fuel injection timing	Before top dead center	° (degree)	16	16
Belt tension	Deflection when pressed with finger force of approx. 58.8N (6 kg)	Crankshaft pulley - alternator	9.5 - 12.7	9.5 - 12.7
		Fan pulley - water pump	9.5 - 12.7	9.5 - 12.7
		Crankshaft pulley - air conditioner compressor	14 - 16	14 - 16
Turbocharger Wastegate pressure setting	Rated speed	kPa	194 - 208	—

STANDARD VALUE TABLE FOR CHASSIS RELATED PARTS

★ The Standard value for new machine and Service limit value in the table below are all values when measured in the heavy-duty mode.

Applicable model				PC340-6k					
Category	Item	Measurement conditions	Unit	Standard value for new machine			Service limit value		
Engine speed	At 2-pump relief	- Engine water temperature: Within operating range - Hydraulic oil temperature: 45 – 55°C - Engine at full throttle - In H/O mode - Arm IN relief	rpm	When swing lock switch is OFF: 1,930 ± 100			When swing lock switch is OFF: 1,930 ± 100		
				When swing lock switch is ON: 1,750 ± 50			1,750 ± 100		
	At 2-pump relief + power max.	- Engine at full throttle - In H/O mode - Arm IN relief + power max. ON		1,740 ± 50			1,740 ± 100		
	Engine speed when auto-deceleration is actuated	- Auto-deceleration switch ON - Fuel control dial at MAX. - Control levers at neutral.		1,400 ± 100			1,400 ± 100		
Spool stroke	Boom Lo control valve	 BLP00101	mm	ℓ	a	b	ℓ	a	b
	Boom Hi control valve								
	Arm Lo control valve								
	Arm Hi control valve								
	Bucket control valve			—	9.5 ± 0.5	9.5 ± 0.5	—	9.5 ± 0.5	9.5 ± 0.5
	Swing control valve								
	Left travel control valve								
	Right travel control valve								
Travel of control levers	Boom control lever	- Center of lever knob - Read max. value to end of travel - Engine stopped - Exclude play at neutral.	mm	85 ± 10			Max. 95 Min. 75		
	Arm control lever			85 ± 10			Max. 95 Min. 75		
	Bucket control lever			85 ± 10			Max. 95 Min. 75		
	Swing control lever			85 ± 10			Max. 95 Min. 75		
	Travel control lever			115 ± 12			Max. 127 Min. 103		
	Play of control lever	Work equipment, swing		Max. 10			Max. 15		
		Travel		Max. 20			Max. 30		





TESTING AND ADJUSTING

STANDARD VALUE TABLE FOR CHASSIS RELATED PARTS

Applicable model					PC340-6K		
Category	Item	Measurement conditions		Unit	Standard value for new machine	Service limit value	
Operating effort of control levers	Boom control lever	· Engine at full throttle · Oil temperature: 45 – 55°C · Fit push-pull scale to center of control lever knob or tip of pedal to measure · Measure max. value to end of travel		N (kg)	15.7 ± 3.9 (1.6 ± 0.4)	Max. 24.5 (2.5)	
	Arm control lever				12.8 ± 3.9 (1.6 ± 0.4)	Max. 24.5 (2.5)	
	Bucket control lever				12.8 ± 2.9 (1.3 ± 0.3)	Max. 21.6 (2.2)	
	Swing control lever				15.7 ± 2.9 (1.6 ± 0.4)	Max. 21.6 (2.2)	
	Travel control lever				Lever	24.5 ± 5.9 (2.5 ± 0.6)	Max. 39.2 (4.0)
		Pedal	74.5 ± 18.6 (7.6 ± 1.9)	Max. 107.9 (11)			
Hydraulic pressure	Unload pressure	· Engine at full throttle · Oil temperature: 45 – 55°C · All levers at neutral · Pump outlet port pressure		MPa (kg/cm ²)	3.9 ± 1.0 (40 ± 10)	3.9 ± 1.0 (40 ± 10)	
	Boom	RAISE			33.8 ± 1.0 (345 ± 10)	$\left[\begin{array}{c} 34.8 \pm 1.0 \\ (355 \pm 10) \end{array} \right]$	Max. 35.8 (365) [Max. 36.3 (370)] Min. 32.3 (330) [Min. 33.3 (340)]
		LOWER	At high-pressure setting		31.4 ± 1.5 (320 ± 15)	Max. 33.3 (340) Min. 29.4 (300)	
			At low-pressure setting		18.1 ± 1.0 (185 ± 10)	Max. 19.6 (200) Min. 16.7 (170)	
	Arm	· Oil temperature: 45 – 55°C · Engine at full throttle · In heavy-duty mode · Pump outlet port pressure · Relieve only circuit being measured ★ The values in [] are the values when using the power max.			33.8 ± 1.0 (345 ± 10)	$\left[\begin{array}{c} 34.8 \pm 1.0 \\ (355 \pm 10) \end{array} \right]$	Max. 35.8 (365) [Max. 36.3 (370)] Min. 32.3 (330) [Min. 33.3 (340)]
	Bucket				33.8 ± 1.0 (345 ± 10)	$\left[\begin{array}{c} 34.8 \pm 1.0 \\ (355 \pm 10) \end{array} \right]$	Max. 35.8 (365) [Max. 36.3 (370)] Min. 32.3 (330) [Min. 33.3 (340)]
	Swing				30.9 ^{+1.0} _{-1.5} (315 ⁺¹⁰ ₋₁₅)	Max. 32.3 (330) Min. 28.4 (290)	
	Left travel				34.8 ^{+2.0} _{-1.0} (355 ⁺²⁰ ₋₁₀)	Max. 37.2 (380) Min. 33.3 (340)	
	Right travel				34.8 ^{+2.0} _{-1.0} (355 ⁺²⁰ ₋₁₀)	Max. 37.2 (380) Min. 33.3 (340)	
	Control pump				2.9 ^{+0.6} ₀ (30 ⁺⁶ ₀)	Max. 3.5 (36) Min. 2.9 (30)	
	LS differential pressure				· Oil temperature: 45 – 55°C · Engine at full throttle · In heavy-duty mode ★ LS differential pressure = Pump outlet port pressure – LS pressure	All levers at neutral	3.9 ± 1.0 (40 ± 10)
		Travel Hi under no load, travel lever at half-way position	2.5 ± 0.1 (25 ± 1)			2.5 ± 0.1 (25 ± 1)	





TESTING AND ADJUSTING

STANDARD VALUE TABLE FOR CHASSIS RELATED PARTS

Applicable model				PC340-6k	
Category	Item	Measurement conditions	Unit	Standard value for new machine	Service limit value
Swing	Overrun when stopping swing	Work equipment posture Max. reach  · Engine at full throttle · Hydraulic oil temperature: 45 – 55°C · In H/O mode · Stop after swinging one turn and measure distance that swing circle moves	Deg.	Max. 110	Max. 140
	Time taken to start swing	Work equipment posture Max. reach  · Engine at full throttle · Hydraulic oil temperature: 45 – 55°C · In H/O mode · Time taken to swing 90° and 180° from starting position	90°	3.8 ± 0.4	Max. 4.5
			180°	5.2 ± 0.5	Max. 6.1
	Time taken to swing	Work equipment posture Max. reach  · Engine at full throttle · Hydraulic oil temperature: 45 – 55°C · In H/O mode · Swing one turn, then measure time taken to swing next 5 turns	Sec	30 ± 1.5	Max. 35
	Hydraulic drift of swing	 · Engine stopped · Hydraulic oil temperature: 45 – 55°C · Set machine on 15° slope, and set upper structure at 90° to the side. · Make match marks on swing circle outer race and track frame. · Measure distance that match marks move apart after 5 minutes.	mm	0	0
	Leakage from swing motor	· Engine at full throttle · Hydraulic oil temperature: 45 – 55°C · Swing lock switch ON · Relieve swing circuit.	ℓ/min	Max. 5.5	Max. 11




TESTING AND ADJUSTING

STANDARD VALUE TABLE FOR CHASSIS RELATED PARTS






Applicable model				PC340-6k				
Category	Item	Measurement conditions		Unit	Standard value for new machine		Service limit value	
Travel	Travel speed (1)	 BKP00104	Travel speed	Sec	STD	LC/NLC	STD	LC/NLC
			Lo		47.5 ± 5.5	50.7 ± 5.9	42.0 – 58.5	44.8 – 62.5
			Mi		39.0 ± 4.0	41.6 ± 4.3	35.0 – 47.0	37.3 – 49.9
	Hi	32.0 ± 3.5	34.1 ± 3.7		28.5 – 39.0	30.4 – 41.5		
	Travel speed (2)	 BKP00105	Lo		19.5 ± 3.0		16.5 – 25.5	
			Mi		16.0 ± 2.0		14.0 – 20.0	
			Hi		13.1 ± 1.0		12.1 – 15.1	
	Travel deviation	 BKP00106	- Engine at full throttle - Hydraulic oil temperature: 45 – 55°C - In H/O mode - Travel speed : Hi - Run up for at least 10 m, and measure deviation when traveling next 20 m on flat ground. ★ Use a hard horizontal surface.  BKP00107		mm	Max. 200		Max. 300
★ Measure dimension x.								

TESTING AND ADJUSTING

STANDARD VALUE TABLE FOR CHASSIS RELATED PARTS



Applicable model				PC340-6k	
Cate-gory	Item	Measurement conditions	Unit	Standard value for new machine	Service limit value
Travel	Hydraulic drift of travel	 BKP00108 · Engine stopped · Hydraulic oil temperature: 45 – 55°C · Stop machine on 12° slope with sprocket facing straight up the slope. · Measure the distance the machine moves in 5 minutes.	mm	0	0
	Leakage of travel motor	 Lock pin BKP00109 · Engine at full throttle · Hydraulic oil temperature: 45 – 55°C · Lock shoes and relieve travel circuit.	ℓ/mm	Max. 15	Max. 30
Work equipment	Posture for measurement		mm		
	Total work equipment (hydraulic drift at tip of bucket teeth)	 BKP00110		Max. 450	Max. 675
	Boom cylinder (amount of retraction of cylinder)	· Place in above posture and measure extension or retraction of each cylinder and downward movement at tip of bucket teeth. · Bucket: Rated load 21.2 kN (2160 kg) · Horizontal, flat ground · Levers at neutral · Engine stopped · Hydraulic oil temperature: 45 – 55°C · Start measuring immediately after setting. · Measure hydraulic drift every 5 minutes, and judge from results for 15 minutes.		Max. 25	Max. 38
	Arm cylinder (amount of extension of cylinder)			Max. 135	Max. 203
	Bucket cylinder (amount of retraction of cylinder)			Max. 20	Max. 30

TESTING AND ADJUSTING
STANDARD VALUE TABLE FOR CHASSIS RELATED PARTS

Applicable model				PC340-6k	
Category	Item	Measurement conditions	Unit	Standard value for new machine	Service limit value
Work equipment	Work equipment speed	Boom Bucket teeth in contact with ground  Empty BKP00111 RAISE	Sec	3.9 ± 0.4	Max. 4.7
		Cylinder fully extended · Engine at full throttle · Hydraulic oil temperature: 45 – 55°C · In H/O mode LOWER		3.0 ± 0.3	Max. 3.5
		Arm Cylinder fully retracted  Empty BKP00112 IN		3.9 ± 0.4	Max. 4.6
		Fully extended · Engine at full throttle · Hydraulic oil temperature: 45 – 55°C · In H/O mode OUT		3.4 ± 0.3	Max. 4.0
		Bucket Cylinder fully retracted  Empty BKP00113 CURL		3.2 ± 0.3	Max. 3.8
		Fully extended · Engine at full throttle · Hydraulic oil temperature: 45 – 55°C · In H/O mode DUMP		2.3 ± 0.3	Max. 2.9
	Time lag	Boom  BKP00114 · Lower boom and measure time taken from point where bucket contacts ground to point where chassis rises from ground · Engine at low idling · Hydraulic oil temperature: 45 – 55°C		Max. 3.0	Max. 3.6
		Arm  BKP00115 · Stop arm suddenly and measure time taken for arm to stop · Engine at low idling · Hydraulic oil temperature: 45 – 55°C		Max. 3.0	Max. 3.6

TESTING AND ADJUSTING

STANDARD VALUE TABLE FOR CHASSIS RELATED PARTS

Applicable model				PC340-6k	
Category	Item	Measurement conditions	Unit	Standard value for new machine	Service limit value
Work equipment	Time lag	 - Stop bucket suddenly and measure time taken for bucket to stop at bottom and then start again - Engine at low idling - Hydraulic oil temperature: 45 – 55°C	Sec	Max. 3.0	Max. 5.0
	Internal leakage				
	Cylinders	- Hydraulic oil temperature: 45 – 55°C - Engine at full throttle - Relieve circuit to be measured	cc/min	Max. 4.5	Max. 20
	Center swivel joint			Max. 10	Max. 50
Performance in compound operation	Travel deviation when work equipment + travel are operated	- Hydraulic oil temperature: 45 – 55°C ★ Use a hard horizontal surface. ★ Measure dimension x.  - Oil temperature: 45 – 55°C	mm	Max. 400	Max. 440
Performance of hydraulic pump	Hydraulic pump delivery				
	Control pump	- Measure with engine at rated speed - At relief valve set pressure (3.1 MPa (32 kg/cm²)) - See next page	ℓ/min	Max. 35.0	Max. 31.5
	Piston pump	See next page		See next page	


TESTING AND ADJUSTING

STANDARD VALUE TABLE FOR CHASSIS RELATED PARTS

Category

PC340-6k: Discharge amount of main piston pump (in H/O mode)

Performance of hydraulic pump



BKP00117

· Pump speed: At 2050 rpm, TVC current 180 mA

Check point	Test pump discharge pressure (MPa (kg/cm ²))	Discharge pressure of other pump (MPa (kg/cm ²))	Average pressure (MPa (kg/cm ²))	Standard value for discharge amount Q (l/min)	Judgement standard lower limit Q (l/min)
As desired	P1	P2	$\frac{P1 + P2}{0.2} \left(\frac{P1 + P2}{2} \right)$	See graph	See graph

- ★ As far as possible, bring pump discharge pressures P1 and P2 as close as possible to the average pressure when measuring.
The error is large near the point where the graph curves, so avoid measuring at this point.
- ★ When measuring with the pump mounted on the machine, if it is impossible to set the engine speed to the specified speed with the fuel control dial, take the pump discharge amount and the engine speed at the point of measurement, and use them as a base for calculating the pump discharge amount at the specified speed.

STANDARD VALUE TABLE FOR ELECTRICAL PARTS

System	Name of component		Connector No.	Inspection method	Judgment table	Measurement conditions									
Control system	Fuel control dial		E06 (male)	Measure resistance	If the condition is within the range shown in the table below, it is normal <table><tr><td>Between (1) – (2)</td><td>0.25 – 7 kΩ</td></tr><tr><td>Between (2) – (3)</td><td>0.25 – 7 kΩ</td></tr><tr><td>Between (1) – (3)</td><td>4 – 6 kΩ</td></tr></table>	Between (1) – (2)	0.25 – 7 kΩ	Between (2) – (3)	0.25 – 7 kΩ	Between (1) – (3)	4 – 6 kΩ	1) Turn starting switch OFF. 2) Disconnect connector.			
	Between (1) – (2)	0.25 – 7 kΩ													
	Between (2) – (3)	0.25 – 7 kΩ													
	Between (1) – (3)	4 – 6 kΩ													
	Governor motor	Potentiometer	E04 (male)	Measure resistance	If the condition is within the range shown in the table below, it is normal <table><tr><td>Between (1) – (2)</td><td>0.25 – 7 kΩ</td></tr><tr><td>Between (2) – (3)</td><td>0.25 – 7 kΩ</td></tr><tr><td>Between (1) – (3)</td><td>4 – 6 kΩ</td></tr></table>	Between (1) – (2)	0.25 – 7 kΩ	Between (2) – (3)	0.25 – 7 kΩ	Between (1) – (3)	4 – 6 kΩ	1) Turn starting switch OFF. 2) Disconnect connector.			
		Between (1) – (2)	0.25 – 7 kΩ												
	Between (2) – (3)	0.25 – 7 kΩ													
	Between (1) – (3)	4 – 6 kΩ													
	Motor	E05 (male)	Measure resistance	If the condition is as shown in the table below, it is normal <table><tr><td>Between (1) – (2)</td><td>2.5 – 7.5 Ω</td></tr><tr><td>Between (3) – (4)</td><td>2.5 – 7.5 Ω</td></tr><tr><td>Between (1) – (3)</td><td>No continuity</td></tr><tr><td>Between (1) – chassis</td><td>No continuity</td></tr><tr><td>Between (3) – chassis</td><td>No continuity</td></tr></table>	Between (1) – (2)	2.5 – 7.5 Ω	Between (3) – (4)	2.5 – 7.5 Ω	Between (1) – (3)	No continuity	Between (1) – chassis	No continuity	Between (3) – chassis	No continuity	1) Turn starting switch OFF. 2) Disconnect connector.
	Between (1) – (2)	2.5 – 7.5 Ω													
Between (3) – (4)	2.5 – 7.5 Ω														
Between (1) – (3)	No continuity														
Between (1) – chassis	No continuity														
Between (3) – chassis	No continuity														
Engine speed sensor		E07	Measure resistance	If the condition is within the range shown in the table below, it is normal <table><tr><td>Between(male) (1) – (2)</td><td>500 – 1,000 Ω</td></tr><tr><td>Between(male) (2) – chassis</td><td>Min. 1 MΩ</td></tr></table>	Between(male) (1) – (2)	500 – 1,000 Ω	Between(male) (2) – chassis	Min. 1 MΩ	1) Turn starting switch OFF. 2) Disconnect connector.						
			Between(male) (1) – (2)	500 – 1,000 Ω											
			Between(male) (2) – chassis	Min. 1 MΩ											
Measure voltage	Measure with AC range	1) Start engine. 2) Insert T – adapter.													
		Adjust	1) Screw in rotation sensor until it contacts ring gear, then turn back 1 ± 1/6 turns. 2) It must work normally when adjusted as above.												
PPC oil pressure switch	Travel S01 boom RAISE S02 arm OUT S03 boom LOWER S04 arm IN S05 bucket CURL S06 bucket DUMP S07 swing S08		Measure resistance	If the condition is as shown in the table below, it is normal When boom, arm, and bucket levers are operated <table><tr><td rowspan="2">Between (male) (1) – (2)</td><td>All levers at neutral</td><td>Min. 1 MΩ</td></tr><tr><td>Levers operated</td><td>Max. 1 Ω</td></tr><tr><td colspan="2">Between (male) (1),(2) - chassis</td><td>Min. 1 MΩ</td></tr></table>	Between (male) (1) – (2)	All levers at neutral	Min. 1 MΩ	Levers operated	Max. 1 Ω	Between (male) (1),(2) - chassis		Min. 1 MΩ	1) Start engine (or with engine stopped and accumulator charged) 2) Disconnect connectors S01 – S08.		
Between (male) (1) – (2)	All levers at neutral	Min. 1 MΩ													
	Levers operated	Max. 1 Ω													
Between (male) (1),(2) - chassis		Min. 1 MΩ													

TESTING AND ADJUSTING

STANDARD VALUE TABLE FOR ELECTRICAL PARTS

System	Name of component	Connector No.	Inspection method	Judgment table	Measurement conditions								
Control system	Pump pressure sensor	C07 (male) (rear) C08 (male) (front)	Measure voltage	If the condition is as shown in the table below, it is normal <table><tr><td colspan="2">Between (2) – (1)</td><td>18 – 28 V</td></tr><tr><td rowspan="2">Between (3) – (1)</td><td>All levers at neutral</td><td>0.5 – 1.5 V</td></tr><tr><td>At arm IN relief</td><td>3.1 – 4.5 V</td></tr></table>	Between (2) – (1)		18 – 28 V	Between (3) – (1)	All levers at neutral	0.5 – 1.5 V	At arm IN relief	3.1 – 4.5 V	1) Start engine. 2) Turn fuel control dial to MAX position. 3) Insert T – adapter.
	Between (2) – (1)		18 – 28 V										
	Between (3) – (1)	All levers at neutral	0.5 – 1.5 V										
		At arm IN relief	3.1 – 4.5 V										
	Swing lock switch	X05 (female)	Measure resistance	If the condition is as shown in the table below, it is normal <table><tr><td>Between (1) – (2)</td><td>When switch is OFF</td><td>Min. 1 MΩ</td></tr><tr><td>Between (3) – (4)</td><td>When switch is ON</td><td>Max. 1 Ω</td></tr></table>	Between (1) – (2)	When switch is OFF	Min. 1 MΩ	Between (3) – (4)	When switch is ON	Max. 1 Ω	1) Turn starting switch OFF. 2) Disconnect connector C02.		
	Between (1) – (2)	When switch is OFF	Min. 1 MΩ										
	Between (3) – (4)	When switch is ON	Max. 1 Ω										
	TVC solenoid valve	C04 (male) C13 (male)	Measure resistance	If the condition is within the range shown in the table below, it is normal <table><tr><td>Between (1) – (2)</td><td>10 – 22 Ω</td></tr><tr><td>Between(1), (2) – chassis</td><td>Min. 1 MΩ</td></tr></table>	Between (1) – (2)	10 – 22 Ω	Between(1), (2) – chassis	Min. 1 MΩ	1) Turn TVC prolix switch OFF. 2) Turn starting switch OFF. 3) Disconnect connectors C04, C13.				
Between (1) – (2)	10 – 22 Ω												
Between(1), (2) – chassis	Min. 1 MΩ												
Swing holding brake solenoid valve	V04 (male)	Measure resistance	If the condition is within the range shown in the table below, it is normal <table><tr><td>Between (1) – (2)</td><td>20 – 60 Ω</td></tr><tr><td>Between(1), (2) – chassis</td><td>Min. 1 MΩ</td></tr></table>	Between (1) – (2)	20 – 60 Ω	Between(1), (2) – chassis	Min. 1 MΩ	1) Turn starting switch OFF. 2) Disconnect connector V04.					
Between (1) – (2)	20 – 60 Ω												
Between(1), (2) – chassis	Min. 1 MΩ												
Travel speed solenoid valve	V06 (male)	Measure resistance	If the condition is within the range shown in the table below, it is normal <table><tr><td>Between (1) – (2)</td><td>20 – 60 Ω</td></tr><tr><td>Between(1), (2) – chassis</td><td>Min. 1 MΩ</td></tr></table>	Between (1) – (2)	20 – 60 Ω	Between(1), (2) – chassis	Min. 1 MΩ	1) Turn starting switch OFF. 2) Disconnect connector V06.					
Between (1) – (2)	20 – 60 Ω												
Between(1), (2) – chassis	Min. 1 MΩ												
LS select solenoid valve	V02 (male)	Measure resistance	If the condition is within the range shown in the table below, it is normal <table><tr><td>Between (1) – (2)</td><td>20 – 60 Ω</td></tr><tr><td>Between(1), (2) – chassis</td><td>Min. 1 MΩ</td></tr></table>	Between (1) – (2)	20 – 60 Ω	Between(1), (2) – chassis	Min. 1 MΩ	1) Turn starting switch OFF. 2) Disconnect connector V02.					
Between (1) – (2)	20 – 60 Ω												
Between(1), (2) – chassis	Min. 1 MΩ												
Pump merge/divider solenoid valve	V03 (male)	Measure resistance	If the condition is within the range shown in the table below, it is normal <table><tr><td>Between (1) – (2)</td><td>20 – 60 Ω</td></tr><tr><td>Between(1), (2) – chassis</td><td>Min. 1 MΩ</td></tr></table>	Between (1) – (2)	20 – 60 Ω	Between(1), (2) – chassis	Min. 1 MΩ	1) Turn starting switch OFF. 2) Disconnect connector V03.					
Between (1) – (2)	20 – 60 Ω												
Between(1), (2) – chassis	Min. 1 MΩ												
Machine 2-stage relief solenoid valve (governor, pump controller does not carry out control	V05 (male)	Measure resistance	If the condition is within the range shown in the table below, it is normal <table><tr><td>Between (1) – (2)</td><td>20 – 60 Ω</td></tr><tr><td>Between(1), (2) – chassis</td><td>Min. 1 MΩ</td></tr></table>	Between (1) – (2)	20 – 60 Ω	Between(1), (2) – chassis	Min. 1 MΩ	1) Turn starting switch OFF. 2) Disconnect connector V05.					
Between (1) – (2)	20 – 60 Ω												
Between(1), (2) – chassis	Min. 1 MΩ												

TESTING AND ADJUSTING

STANDARD VALUE TABLE FOR ELECTRICAL PARTS

System	Name of component	Connector No.	Inspection method	Judgment table	Measurement conditions							
Control system	LS-EPC solenoid	C10 (male)	Measure resistance	If the condition is within the range shown in the table below, it is normal <table><tr><td>Between (1) – (2)</td><td>7 – 14 Ω</td></tr><tr><td>Between(1), (2) – chassis</td><td>Min. 1 MΩ</td></tr></table>	Between (1) – (2)	7 – 14 Ω	Between(1), (2) – chassis	Min. 1 MΩ	1) Turn starting switch OFF. 2) Disconnect connector C10.			
	Between (1) – (2)	7 – 14 Ω										
	Between(1), (2) – chassis	Min. 1 MΩ										
	Governor, pump controller	Power source voltage	C01 C02	Measure voltage	If the condition is within the range shown in the table below, it is normal <table><tr><td>Between C01 (7),(13) – (6),(12)</td><td>20 – 30 V</td></tr><tr><td>Between C02 (11),(21) – (6),(12)</td><td>20 – 30 V</td></tr></table>	Between C01 (7),(13) – (6),(12)	20 – 30 V	Between C02 (11),(21) – (6),(12)	20 – 30 V	1) Turn starting switch ON. 2) Insert T – adapter.		
		Between C01 (7),(13) – (6),(12)	20 – 30 V									
		Between C02 (11),(21) – (6),(12)	20 – 30 V									
		Fuel control dial	C03	Measure voltage	If the condition is as shown in the table below, it is normal <table><tr><td>Between (7) – (17) (power source)</td><td>4.75 – 5.25 V</td></tr><tr><td>Between (4) – (17) (low idling)</td><td>4.0 – 4.75 V</td></tr><tr><td>Between (4) – (17) (high idling)</td><td>0.25 – 1.0 V</td></tr></table>	Between (7) – (17) (power source)	4.75 – 5.25 V	Between (4) – (17) (low idling)	4.0 – 4.75 V	Between (4) – (17) (high idling)	0.25 – 1.0 V	1) Turn starting switch ON. 2) Insert T – adapter.
		Between (7) – (17) (power source)	4.75 – 5.25 V									
Between (4) – (17) (low idling)		4.0 – 4.75 V										
Between (4) – (17) (high idling)	0.25 – 1.0 V											
Governor potentiometer	C03	Measure voltage	If the condition is as shown in the table below, it is normal <table><tr><td>Between (14) – (17) (low idling)</td><td>2.9 – 3.3 V</td></tr><tr><td>Between (14) – (17) (high idling)</td><td>0.5 – 0.9 V</td></tr><tr><td>Between (7) – (17) (power source)</td><td>4.75 – 5.25 V</td></tr></table>	Between (14) – (17) (low idling)	2.9 – 3.3 V	Between (14) – (17) (high idling)	0.5 – 0.9 V	Between (7) – (17) (power source)	4.75 – 5.25 V	1) Turn starting switch ON. 2) Insert T – adapter.		
Between (14) – (17) (low idling)	2.9 – 3.3 V											
Between (14) – (17) (high idling)	0.5 – 0.9 V											
Between (7) – (17) (power source)	4.75 – 5.25 V											
Coolant temperature sensor	P07 (male)	Measure resistance	If the condition is as shown in the table below, it is normal <table><tr><td>Normal temperature (25°C)</td><td>Approx. 37 – 50 kΩ</td></tr><tr><td>100°C</td><td>Approx. 3.5 – 4.0 kΩ</td></tr></table>	Normal temperature (25°C)	Approx. 37 – 50 kΩ	100°C	Approx. 3.5 – 4.0 kΩ	1) Turn starting switch OFF. 2) Disconnect connector P07. 3) Insert T – adapter. into connector at sensor end.				
Normal temperature (25°C)	Approx. 37 – 50 kΩ											
100°C	Approx. 3.5 – 4.0 kΩ											
Governor motor	C02	Measure voltage	If the condition is within the range shown in the table below, it is normal <table><tr><td>Between (2) – (3)</td><td>1.8 – 4.6 V</td></tr><tr><td>Between (4) – (5)</td><td>1.8 – 4.6 V</td></tr></table>	Between (2) – (3)	1.8 – 4.6 V	Between (4) – (5)	1.8 – 4.6 V	1) Turn starting switch ON. 2) Insert T – adapter.				
Between (2) – (3)	1.8 – 4.6 V											
Between (4) – (5)	1.8 – 4.6 V											
Battery relay	C01	Measure voltage	If the condition is within the range shown in the table below, it is normal <table><tr><td>Between (1) – (6)</td><td>20 – 30 V</td></tr></table> ★ This is only for 2.5 sec after the starting switch is operated ON → OFF; at other times it must be 0 V.	Between (1) – (6)	20 – 30 V	1) Turn starting switch ON. 2) Insert T – adapter.						
Between (1) – (6)	20 – 30 V											

TESTING AND ADJUSTING

STANDARD VALUE TABLE FOR ELECTRICAL PARTS

System	Name of component	Connector No.	Inspection method	Judgment table	Measurement conditions						
Control system	Governor, pump controller	Swing holding brake solenoid	C01	Measure voltage	If the condition is as shown in the table below, it is normal <table><tr><td>When either swing or work equipment control lever is operated (solenoid ON, swing holding brake canceled)</td><td rowspan="2">Between (3) – (6),(12)</td><td>20 – 30 V</td></tr><tr><td>Approx. 5 sec after swing lever and work equipment control levers are placed at neutral (solenoid OFF, swing holding brake applied)</td><td>0 – 3 V</td></tr></table>	When either swing or work equipment control lever is operated (solenoid ON, swing holding brake canceled)	Between (3) – (6),(12)	20 – 30 V	Approx. 5 sec after swing lever and work equipment control levers are placed at neutral (solenoid OFF, swing holding brake applied)	0 – 3 V	1) Start engine. 2) Turn swing lock switch OFF. 3) Turn swing lock prolix switch OFF. 4) Insert T – adapter. ★ The lever can be operated slightly (without moving the equipment).
		When either swing or work equipment control lever is operated (solenoid ON, swing holding brake canceled)	Between (3) – (6),(12)	20 – 30 V							
		Approx. 5 sec after swing lever and work equipment control levers are placed at neutral (solenoid OFF, swing holding brake applied)		0 – 3 V							
		Travel speed solenoid	C01	Measure voltage	If the condition is as shown in the table below, it is normal <table><tr><td>With travel speed switch at Hi or Mi (solenoid ON, travel motor swash plate angle MIN)</td><td rowspan="2">Between (9) – (6),(12)</td><td>20 – 30 V</td></tr><tr><td>When travel speed switch is at Lo (solenoid OFF, travel motor swash plate angle MAX)</td><td>0 – 3 V</td></tr></table>	With travel speed switch at Hi or Mi (solenoid ON, travel motor swash plate angle MIN)	Between (9) – (6),(12)	20 – 30 V	When travel speed switch is at Lo (solenoid OFF, travel motor swash plate angle MAX)	0 – 3 V	1) Start engine. 2) Insert T – adapter. 3) Turn fuel control dial to MAX position. 4) Operate the lever slightly not enough to move the machine. To check that the solenoid is OFF, measure with the fuel control dial at LOW (1200 rpm or below)
With travel speed switch at Hi or Mi (solenoid ON, travel motor swash plate angle MIN)	Between (9) – (6),(12)	20 – 30 V									
When travel speed switch is at Lo (solenoid OFF, travel motor swash plate angle MAX)		0 – 3 V									
LS select solenoid	C01	Measure voltage	If the condition is as shown in the table below, it is normal <table><tr><td>When swing lock switch is OFF, and swing + travel levers are operated simultaneously (solenoid ON, LS divided)</td><td rowspan="2">Between (8) – (6),(12)</td><td>20 – 30 V</td></tr><tr><td>When swing lock switch is ON (solenoid OFF, LS not divided)</td><td>0 – 3 V</td></tr></table>	When swing lock switch is OFF, and swing + travel levers are operated simultaneously (solenoid ON, LS divided)	Between (8) – (6),(12)	20 – 30 V	When swing lock switch is ON (solenoid OFF, LS not divided)	0 – 3 V	1) Turn starting switch ON. 2) Insert T – adapter. ★ The lever can be operated slightly (without moving the equipment).		
When swing lock switch is OFF, and swing + travel levers are operated simultaneously (solenoid ON, LS divided)	Between (8) – (6),(12)	20 – 30 V									
When swing lock switch is ON (solenoid OFF, LS not divided)		0 – 3 V									
Pump merge/divider valve solenoid	C01	Measure voltage	If the condition is as shown in the table below, it is normal. <table><tr><td>When travel is operated independently (solenoid ON, divided)</td><td rowspan="2">Between (2) – (6),(12)</td><td>20 – 30 V</td></tr><tr><td>When levers and pedals are at neutral (solenoid OFF, merged)</td><td>0 – 3 V</td></tr></table>	When travel is operated independently (solenoid ON, divided)	Between (2) – (6),(12)	20 – 30 V	When levers and pedals are at neutral (solenoid OFF, merged)	0 – 3 V	1) Turn starting switch ON. 2) Insert T – adapter. ★ The lever can be operated slightly (without moving the equipment).		
When travel is operated independently (solenoid ON, divided)	Between (2) – (6),(12)	20 – 30 V									
When levers and pedals are at neutral (solenoid OFF, merged)		0 – 3 V									

TESTING AND ADJUSTING

STANDARD VALUE TABLE FOR ELECTRICAL PARTS

System	Name of component	Connector No.	Inspection method	Judgment table	Measurement conditions			
Control system	Governor, pump controller	TVC solenoid valve (default value)	C02	Measure current	If the condition is as shown in the table below, it is normal · H/O mode	1) Turn starting switch ON. 2) Turn fuel control dial to MAX position 3) Turn prolux switch OFF.		
					Between front (8) – (18)	520 ± 80 mA		
					Between rear (9) – (19)			
		LS-EPC solenoid valve (default value)	C02	Measure current	If the condition is as shown in the table below, it is normal · H/O mode	1) Turn starting switch ON. 2) Turn fuel control dial to MAX position 3) All levers at neutral.		
					Between (7) – (17)	900 ± 80 mA		
		L.H. knob switch	C03	Measure voltage	If the condition is as shown in the table below, it is normal	1) Turn starting switch ON. 2) Insertl T – adapter.		
			When switch is ON	Between (9) – GND	20 – 28 V			
			When switch is OFF		0 – 1 V			
			S-NET	C17	Measure voltage	If the condition is as shown in the table below, it is normal	1) Turn starting switch ON. 2) Insertl T – adapter.	
			No. 2 throttle signal	Monitoring code 16	Engine speed	If the condition is as shown in the table below, it is normal	High idling (rpm)	1) Start engine. 2) Set monitoring code to 10 or 16 (command value). 3) Operate working mode switch and L.H. knob switch.
						H/O	Approx. 2250	
						G/O	Approx. 2050 (during operation) Approx. 1900 (idling)	
						F/O	Approx. 1900	
						L/O	Approx. 1700	
						Power max. (H/O) (G/O)	Approx. 2250	
						Swift slow-down (H/O) (G/O)	Approx. 1700	
						</		







TESTING AND ADJUSTING

STANDARD VALUE TABLE FOR ELECTRICAL PARTS

Sys-tem	Name of component	Connector No.	Inspection method	Judgment table	Measurement conditions					
Monitor	Air cleaner clogging sensor	P11 (male) P12 (female)	Continuity	If the condition is as shown in the table below, it is normal <table><tr><td>Air cleaner normal</td><td rowspan="2">Between P11 – P12</td><td>Continuity</td></tr><tr><td>Air cleaner clogged</td><td>No continuity</td></tr></table>	Air cleaner normal	Between P11 – P12	Continuity	Air cleaner clogged	No continuity	1) Start engine 2) Disconnect P11, 12. 3) Put tester in contact with connector at sensor end to measure.
	Air cleaner normal	Between P11 – P12	Continuity							
	Air cleaner clogged		No continuity							
	Engine speed sensor	E07	Measure resistance	If the condition is within the range shown in the table below, it is normal <table><tr><td>Between (1) – (2)</td><td>500 – 1000 Ω</td></tr><tr><td>Between(2) – chassis</td><td>Min. 1 MΩ</td></tr></table>	Between (1) – (2)	500 – 1000 Ω	Between(2) – chassis	Min. 1 MΩ	1) Turn starting switch OFF. 3) Disconnect connector.	
			Between (1) – (2)	500 – 1000 Ω						
			Between(2) – chassis	Min. 1 MΩ						
	Measure voltage	Measure with AC range	<table><tr><td>Between (1) – (2)</td><td>0.5 – 3.0 V</td></tr></table>	Between (1) – (2)	0.5 – 3.0 V	1) Start engine. 2) Insert T – adapter.				
Between (1) – (2)	0.5 – 3.0 V									
Adjust	1) Screw in rotation sensor until it contacts ring gear, then turn back 1 ± 1/6 turns 2) It must work normally when adjusted as above.									
Coolant level sensor	P08 (male)	Measure resistance	If the condition is as shown in the table below, it is normal <table><tr><td>Above LOW level in sub-tank</td><td>Max. 1 Ω</td></tr><tr><td>Below LOW level in sub-tank</td><td>Min. 1 MΩ</td></tr></table>	Above LOW level in sub-tank	Max. 1 Ω	Below LOW level in sub-tank	Min. 1 MΩ	1) Turn starting switch OFF. 2) Disconnect connector P08. 3) Insert T – adapter into connector at sensor end.		
Above LOW level in sub-tank	Max. 1 Ω									
Below LOW level in sub-tank	Min. 1 MΩ									
Engine oil level sensor	P05 (male)	Measure resistance	If the condition is as shown in the table below, it is normal <table><tr><td>Submerged in oil</td><td>Max. 1 Ω</td></tr><tr><td>Not sub-merged in oil</td><td>Min. 1 MΩ</td></tr></table>	Submerged in oil	Max. 1 Ω	Not sub-merged in oil	Min. 1 MΩ	1) Turn starting switch OFF. 2) Disconnect connector P05. 3) Drain oil, then remove sensor.		
Submerged in oil	Max. 1 Ω									
Not sub-merged in oil	Min. 1 MΩ									
Coolant temperature sensor	P07 (male)	Measure resistance	If the condition is as shown in the table below, it is normal <table><tr><td>Normal temperature (20°C)</td><td>Approx. 70 - 78 kΩ</td></tr><tr><td>100°C</td><td>Approx. 3.4 - 3.8 kΩ</td></tr></table>	Normal temperature (20°C)	Approx. 70 - 78 kΩ	100°C	Approx. 3.4 - 3.8 kΩ	1) Turn starting switch OFF. 2) Disconnect connector P07. 3) Insert T – adapter. into connector at sensor end.		
Normal temperature (20°C)	Approx. 70 - 78 kΩ									
100°C	Approx. 3.4 - 3.8 kΩ									

TESTING AND ADJUSTING

STANDARD VALUE TABLE FOR ELECTRICAL PARTS

System	Component	Connector N°	Inspect. method	Judgment table	Measurement conditions				
Monitor	Engine oil pressure sensor	—	Measure resistance	If the condition is as shown in the table below, it is normal. Low pressure sensor <table><tr><td>Pressure rising</td><td>Opens at 0.110 ± 0.014 MPa (Non continuity) (1.12 ± 0.14 kg/cm²)</td></tr><tr><td>Pressure dropping</td><td>Close at 0.110 ± 0.014 MPa (Continuity) (0.85 ± 0.14 kg/cm²)</td></tr></table> Sensor connector 	Pressure rising	Opens at 0.110 ± 0.014 MPa (Non continuity) (1.12 ± 0.14 kg/cm ²)	Pressure dropping	Close at 0.110 ± 0.014 MPa (Continuity) (0.85 ± 0.14 kg/cm ²)	1) Install oil pressure measuring gauge. 2) Remove wiring harness terminal. 3) Start engine. 4) Put tester in contact between sensor terminals A&c.
	Pressure rising	Opens at 0.110 ± 0.014 MPa (Non continuity) (1.12 ± 0.14 kg/cm ²)							
	Pressure dropping	Close at 0.110 ± 0.014 MPa (Continuity) (0.85 ± 0.14 kg/cm ²)							
Fuel level sensor	P06 (male)	Measure resistance	If the condition is as shown in the table below, it is normal <table><tr><td> BLP00004 Raise float to stopper </td><td>Approx. 12 Ω or below</td></tr><tr><td> BLP00005 Lower float to stopper </td><td>Approx. 85 – 110 Ω</td></tr></table>	 BLP00004 Raise float to stopper	Approx. 12 Ω or below	 BLP00005 Lower float to stopper	Approx. 85 – 110 Ω	1) Turn starting switch OFF. 2) Disconnect connector P06. 3) Drain fuel, then remove sensor. 4) Insert T – adapter into sensor. ★ Connect the T – adapter to the connector and sensor flange.	
 BLP00004 Raise float to stopper	Approx. 12 Ω or below								
 BLP00005 Lower float to stopper	Approx. 85 – 110 Ω								
Hydraulic oil level sensor	P09 (male)	Measure resistance	If the condition is as shown in the table below, it is normal <table><tr><td> BLP00002 Raise float </td><td>Max. 1 Ω</td></tr><tr><td> BLP00003 Lower float </td><td>Min. 1 MΩ</td></tr></table>	 BLP00002 Raise float	Max. 1 Ω	 BLP00003 Lower float	Min. 1 MΩ	1) Turn starting switch OFF. 2) Disconnect connector P09. 3) Drain oil, then remove sensor. 4) Insert T – adapter into sensor.	
 BLP00002 Raise float	Max. 1 Ω								
 BLP00003 Lower float	Min. 1 MΩ								

TESTING AND ADJUSTING

STANDARD VALUE TABLE FOR ELECTRICAL PARTS

Name of component	Connector No.	Inspection method	Judgment table	Measurement conditions																																												
Alternator	Between alternator terminal R and chassis	Measure voltage	When engine is running (1/2 throttle or above) below, the sensor is defective. →27.5 – 29.5 V ★ If the battery is old, or after starting in cold areas, the voltage may not rise for some time.	1) Start engine.																																												
Gauges	<table><tr><td rowspan="2"></td><td colspan="2">Position of gauge display</td><td>Display level resistance kΩ (Monitor panel input resistance)</td></tr><tr><td colspan="2">Starting switch ON</td><td>Starting switch OFF</td></tr><tr><td rowspan="17">Measure resistance between coolant temperature gauge C03 (female) (1) – C03 (female) (16)</td><td rowspan="5">Right side</td><td>All OFF(15)</td><td>Min. – Max. – 0.646</td></tr><tr><td>14</td><td>0.575 – 3.420</td></tr><tr><td>13</td><td>3.156 – 3.708</td></tr><tr><td>12</td><td>3.422 – 3.804</td></tr><tr><td>11</td><td>3.512 – 3.900</td></tr><tr><td rowspan="5">↑</td><td>10</td><td>3.600 – 4.125</td></tr><tr><td>9</td><td>3.807 – 4.349</td></tr><tr><td>8</td><td>4.015 – 5.122</td></tr><tr><td>7</td><td>4.728 – 5.899</td></tr><tr><td>6</td><td>5.445 – 6.818</td></tr><tr><td rowspan="5">↓</td><td>5</td><td>6.294 – 7.910</td></tr><tr><td>4</td><td>7.302 – 9.210</td></tr><tr><td>3</td><td>8.502 – 10.774</td></tr><tr><td>2</td><td>9.946 – 36.535</td></tr><tr><td>1</td><td>33.725 –</td></tr><tr><td colspan="2">Left side</td><td></td></tr></table> ★ Levels 13 and 14 flash.				Position of gauge display		Display level resistance kΩ (Monitor panel input resistance)	Starting switch ON		Starting switch OFF	Measure resistance between coolant temperature gauge C03 (female) (1) – C03 (female) (16)	Right side	All OFF(15)	Min. – Max. – 0.646	14	0.575 – 3.420	13	3.156 – 3.708	12	3.422 – 3.804	11	3.512 – 3.900	↑	10	3.600 – 4.125	9	3.807 – 4.349	8	4.015 – 5.122	7	4.728 – 5.899	6	5.445 – 6.818	↓	5	6.294 – 7.910	4	7.302 – 9.210	3	8.502 – 10.774	2	9.946 – 36.535	1	33.725 –	Left side			1) Insert a dummy resistance with the starting switch OFF, or measure the resistance of the sensor. 2) Check the display with the starting switch ON.
		Position of gauge display			Display level resistance kΩ (Monitor panel input resistance)																																											
		Starting switch ON		Starting switch OFF																																												
Measure resistance between coolant temperature gauge C03 (female) (1) – C03 (female) (16)	Right side	All OFF(15)	Min. – Max. – 0.646																																													
		14	0.575 – 3.420																																													
		13	3.156 – 3.708																																													
		12	3.422 – 3.804																																													
		11	3.512 – 3.900																																													
	↑	10	3.600 – 4.125																																													
		9	3.807 – 4.349																																													
		8	4.015 – 5.122																																													
		7	4.728 – 5.899																																													
		6	5.445 – 6.818																																													
	↓	5	6.294 – 7.910																																													
		4	7.302 – 9.210																																													
		3	8.502 – 10.774																																													
		2	9.946 – 36.535																																													
		1	33.725 –																																													
	Left side																																															
	<table><tr><td rowspan="2"></td><td colspan="2">Position of gauge display</td><td>Display level resistance kΩ (Monitor panel input resistance)</td></tr><tr><td colspan="2">Starting switch ON</td><td>Starting switch OFF</td></tr><tr><td rowspan="17">Measure resistance between fuel level gauge C03 (female) (2) – chassis</td><td rowspan="5">Right side</td><td>14</td><td>Min. – Max. – 13.82</td></tr><tr><td>13</td><td>11.71 – 17.43</td></tr><tr><td>12</td><td>15.18 – 21.25</td></tr><tr><td>11</td><td>18.90 – 25.05</td></tr><tr><td>10</td><td>22.59 – 28.45</td></tr><tr><td rowspan="5">↑</td><td>9</td><td>25.82 – 31.85</td></tr><tr><td>8</td><td>29.18 – 35.22</td></tr><tr><td>7</td><td>32.45 – 39.91</td></tr><tr><td>6</td><td>37.00 – 44.60</td></tr><tr><td>5</td><td>41.77 – 48.72</td></tr><tr><td rowspan="5">↓</td><td>4</td><td>45.52 – 55.14</td></tr><tr><td>3</td><td>50.42 – 64.35</td></tr><tr><td>2</td><td>60.61 – 77.07</td></tr><tr><td>1</td><td>72.98 – 691.5</td></tr><tr><td>All OFF(0)</td><td>638.00 –</td></tr><tr><td colspan="2">Left side</td><td></td></tr></table> ★ Level 1 flashes.				Position of gauge display		Display level resistance kΩ (Monitor panel input resistance)	Starting switch ON		Starting switch OFF	Measure resistance between fuel level gauge C03 (female) (2) – chassis	Right side	14	Min. – Max. – 13.82	13	11.71 – 17.43	12	15.18 – 21.25	11	18.90 – 25.05	10	22.59 – 28.45	↑	9	25.82 – 31.85	8	29.18 – 35.22	7	32.45 – 39.91	6	37.00 – 44.60	5	41.77 – 48.72	↓	4	45.52 – 55.14	3	50.42 – 64.35	2	60.61 – 77.07	1	72.98 – 691.5	All OFF(0)	638.00 –	Left side			1) Insert a dummy resistance with the starting switch OFF, or measure the resistance of the sensor. 2) Check the display with the starting switch ON.
	Position of gauge display		Display level resistance kΩ (Monitor panel input resistance)																																													
	Starting switch ON		Starting switch OFF																																													
Measure resistance between fuel level gauge C03 (female) (2) – chassis	Right side	14	Min. – Max. – 13.82																																													
		13	11.71 – 17.43																																													
		12	15.18 – 21.25																																													
		11	18.90 – 25.05																																													
		10	22.59 – 28.45																																													
	↑	9	25.82 – 31.85																																													
		8	29.18 – 35.22																																													
		7	32.45 – 39.91																																													
		6	37.00 – 44.60																																													
		5	41.77 – 48.72																																													
	↓	4	45.52 – 55.14																																													
		3	50.42 – 64.35																																													
		2	60.61 – 77.07																																													
		1	72.98 – 691.5																																													
		All OFF(0)	638.00 –																																													
	Left side																																															

TOOLS FOR TESTING, ADJUSTING, AND TROUBLESHOOTING


Check or measurement item	Symbol		Part No.	Part Name	Remarks
Coolant and oil temperatures	B		799-101-1502	Digital temperature gauge	−50 – 1,200°C
Oil pressure	C	1	799-101-5002	Hydraulic tester	Pressure gauge 2.5, 5.9, 39.2, 58.8 MPa (25, 60, 400, 600 kg/cm ²)
			790-261-1203	Digital hydraulic tester	Pressure gauge 71.4 MPa (700 kg/cm ²)
		2	795-790-1100	Hydraulic gauge	
		3	•790-261-1311	Adapter	Both male and female 14 x 1.5 (female PT 1/8)
			•790-261-1321		Both male and female 18 x 1.5 (female PT 1/8)
			•790-261-1331		Both male and female 22 x 1.5 (female PT 1/8)
		4	799-401-2700	Differential pressure gauge	
		5	790-261-1370	Nut	For 14 x 1.5 blind
			07003-31419	Gasket	For blind
			07040-11409	Plug	For 14 x 1.5 blind
Compression pressure	D	1	795-502-1590	Compression gauge	0 – 6.9 MPa (0 – 70 kg/cm ²)
2		795-472-1370	Adapter	Kit Part No.: 795-502-1205	
Blowby pressure	E	1	795-790-1900	Blow-by adapter	
2		795-790-1610	Manometer		
Air supply pressure (boost pressure)	F		795-790-1470	Pressure gauge	
Valve clearance	G		Commercially available	Feeler gauge	
Exhaust color	H	1	799-201-9000	Handy Smoke Checker	Discoloration 0 – 70% (with standard color)
		2	Commercially available	Smoke meter	(Discoloration % x 1/10 = Bosch index)
Operating effort	J		79A-264-0020	Push-pull scale	0 – 294N (30 kg)
			79A-264-0090		0 – 490N (50 kg)
Stroke, hydraulic drift	K		Commercially available	Scale	
Work equipment speed	L		Commercially available	Stop watch	
Measuring voltage and resistance values	M		79A-264-0210	Tester	
Troubleshooting of wiring harnesses and sensors	N	1	799-601-7100	T-adapter box	
		2	799-601-7070	Adapter	For SWP14P
			799-601-7360		For relay 5P
Wastegate pressure	P	1	795-790-1700	Pressure gauge	-

MEASURING EXHAUST COLOUR

- When measuring in the field when there is no air or power supply, use handy smoker checker **H1**; when recording official data, use smoke meter **H2**.
- ★ Raise the coolant temperature to the operating range before measuring.
- ⚠ When removing or installing the measuring equipment, be careful not to touch any high temperature part.



1. Measuring with handy smoke checker H1

- 1) Fit filter paper in tool **H1**.
- 2) Insert the exhaust gas intake port into the exhaust pipe, accelerate the engine suddenly, and at the same time operate the handle of tool **H1** to catch the exhaust gas on the filter paper.
- 3) Remove the filter paper and compare it with the scale provided to judge the condition.



2. Measuring with smoke meter H2

- 1) Insert the probe of tool **H2** into the outlet port of exhaust pipe(1), then tighten the clip to secure it to the exhaust pipe.
- 2) Connect the probe hose, accelerator switch plug, and air hose to tool **H2**.
 - ★ The pressure of the air supply should be less than 1.5 MPa (15 kg/cm²).
- 3) Connect the power cord to the AC100V outlet.
 - ★ When connecting the port, check first that the power switch of tool **H2** is OFF.
- 4) Loosen the cap nut of the suction pump, then fit the filter paper.
- ★ Fit the filter paper securely so that the exhaust gas does not leak.
- 5) Turn the power switch of tool **H2** ON.
- 6) Accelerate the engine suddenly, and at the same time, depress the accelerator pedal of tool **H2** and catch the exhaust gas color on the filter paper.
- 7) Lay the filter paper used to catch the exhaust gas color on top of unused filter papers (10 sheets or more) inside the filter paper holder, and read the indicated value.









ADJUSTING VALVE CLEARANCE

1. Remove the air crossover tube if the engine is so equipped.
2. Disconnect the support clamps, hose clamp and wastegate sensing line. Remove the crankcase vent tube and any other parts that would prevent removal of the valve cover.
3. Remove the valve cover
4. Locate Top Dead Center (TDC) for Cylinder Number 1 by rotating the crankshaft slowly while pressing on the engine timing pin.

When the engine timing pin engages the hole in the camshaft gear, Cylinder Number 1 is at TDC on the compression stroke.

Caution

Be sure to disengage the engine timing pin after locating TDC to prevent damage to the engine timing pin.



TESTING AND ADJUSTING

ADJUSTING VALVE CLEARANCE

Intake Clearance: 0.30 mm [0.012 inch]

Exhaust Clearance: 0.61 mm [0.024 inch]

Check/set valves with engine cold - below 60°C [140°F].

NOTE:

The clearance is correct when some resistance is "felt" when the feeler gauge is slipped between the valve stem and the rocker lever.

5. Locate Top Dead Center (TDC) for Cylinder Number 1. Check/adjust the valves indicated for STEP A (I = Intake; E = Exhaust).

After tightening the rocker lever lock nut, check the valve clearance to make sure the valve clearance has not changed.

Torque Value: 24 N•m [18 ft-lb]

6. Mark the vibration damper and rotate the crankshaft 360 degrees.






Caution:

Be sure the engine timing pin is disengaged to prevent damage to the engine timing pin.

7. Set the valves indicated for STEP B.

After tightening the rocker lever lock nut, check the valve clearance to make sure the valve clearance has not changed.

8. Install the rubber seal into the groove in the valve cover. Start the installation at the overlap area shown in the illustration. Do not stretch the rubber seal.




TESTING AND ADJUSTING

ADJUSTING VALVE CLEARANCE

9. Install new sealing o-rings on the capscrews.

Install the valve cover and wastegate sensing tube.


Torque Value: 24 N•m [18 ft-lb]




10. Install the crankcase vent tube and secure with the support clamps and hose clamp.

A = 24 N•m [18 ft-lb]

B = 43 N•m [32 ft-lb]



11. Install the air crossover tube and any other parts previously removed to gain access to the valve cover.



MEASURING COMPRESSION PRESSURE

- ⚠ When measuring the compression pressure, be careful not to touch the exhaust manifold or muffler, or to get your clothes caught in the fan, fan belt or other rotating part.
1. Adjust the valve clearance.
For details, see ADJUSTING VALVE CLEARANCE.
 2. Warm up the engine to make the oil temperature 40 - 60°C
 3. Remove nozzle holder assembly from the cylinder to be measured.
 4. Connect pressure gauge.
 5. Disconnect the fuel control rod, place the governor lever of the injection pump in the NO INJECTION position, then crank the engine with the starting motor and measure the compression pressure.
- ★ Measure the compression pressure at the point where the pressure gauge indicator remains steady.
 - ★ When measuring the compression pressure, measure the engine speed to confirm that it is within the specified range.
 - ★ After measuring the compression pressure, install nozzle holder assembly (1).

NOTE: Due to variables such as; starter and battery conditions that affect engine cranking speed, it is difficult to establish an absolute value for compression pressure; however, the following values can be used as guidelines:

- New engine (cranking speed @ 250 RPM)
2413 kPa [350 psi]
- Used engine (cranking speed @ 250 RPM)
2068 kPa [300 psi]

It is recommended that the compression pressure be checked on all cylinders and then compared. All cylinders should be within 690 kPa [100 psi] of each other

MEASURING BLOW-BY PRESSURE

Blowby is generally recorded in liters/minute.




Install the Engine Blowby Tool **E1** to the crankcase breather tube in the valve cover.

Install the water manometer **E2** to the engine blowby tool.

Use the Blowby Conversion Chart to convert the manometer reading to liters/minute.

NOTE: A pressure gauge can be used to record the engine blowby.

Minimum Gauge Capacity: 1270 mm H₂O [50 inches H₂O].



Blowby Conversion Chart (7.67 mm [0.302 in] Orifice)

Inches of Water	Liters/Minute
1	50
2	84
3	103
4	119
5	133
6	145
7	155
8	164
9	172
10	180
11	187
12	193
13	200
14	206
15	211
16	217
17	222
18	226
19	229
20	235
21	239
22	242
23	246
24	248

TESTING AND ADJUSTING FUEL INJECTION TIMING

Fuel injection pump to-engine timing is extremely critical. Fuel injection pump timing that is off by only a few crank-shaft degrees will cause:

1. Poor performance -- starting and power
2. Excessive smoke and emissions
3. Poor fuel economy
4. Excessive cylinder pressure



The governors have a provision for locking the fuel injection pump shaft at a position corresponding to top dead center (TDC) for No.1 cylinder. New and reconditioned fuel injection pumps should be received with the shafts locked in this position.

The engine is equipped with an engine timing pin to locate TDC for No. 1 cylinder.


If the timing pin is incorrectly located on the gear housing, the timing procedure will not make sure that the fuel injection pump is timed correctly.

The timing pin assembly is aligned to the gear housing to correspond to a hole in the back side of the camshaft gear when No.1 cylinder is at TDC. If the gear housing or timing pin assembly is removed, it will be necessary to relocate it.

The fuel injection pump also has a timing pin (1), located in the governor housing, to position the pump shaft to correspond with TDC for cylinder No. 1. After the pump is installed, the timing pin **must** be reversed and stored into the governor housing (2).



1. Insert engine timing pin to locate top dead center
2. Check fuel pump timing by removing access plug and timing pin from the governor




TESTING AND ADJUSTING

TESTING AND ADJUSTING FUEL INJECTION TIMING


If the timing tooth is not aligned with the timing pin hole, rotate the pump shaft until the timing tooth aligns.

Before the pump shaft can be rotated it is necessary to remove the fuel pump drive gear, nut and washer.



Reverse the position of the pin so the slot of the pin will fit over the timing tooth in the fuel injection pump.


Install and secure the timing pin with the access plug.




Install the fuel pump drive gear retaining nut and washer.

Initial Torque Value: 12 N·m [106 in-lb]

⚠ Caution: To prevent damage to the timing pins, do not exceed the torque value given. This is not the final torque value for the retaining nut.



Disengage the engine timing pin.




TESTING AND ADJUSTING

TESTING AND ADJUSTING FUEL INJECTION TIMING


Remove the fuel pump timing pin plug. Reverse the position of the pin and install the pin, plug and sealing washer.

Torque Value: 15 N•m [11 ft-lb]




Tighten the fuel injection pump drive gear nut.

Torque Value: 104 N•m [77 ft-lb]



MEASURING ENGINE OIL PRESSURE

- ★ Measure the engine oil pressure under the following conditions.
 - Coolant temperature: Within operating range
- 1. Remove engine oil pressure sensor (1) then install the oil pressure gauge **C2** (1.0 MPa (10 kg/cm²))
- 2. Start the engine, and measure the oil pressure with the engine at low idling and at high idling.
- ★ For low-pressure sensor (1), measure the engine oil pressure caution end with the engine at low idling, and for high-pressure sensor (2), measure the engine oil pressure caution end and the controller trouble data display end with the engine at high idling.



TEST AND ADJUST FAN BELT TENSION




The engine is equipped with an automatic belt tensioner that maintains correct tension on the drive belt. To check belt tension a Gates type gauge must be used because of the wide drive belt. Proper tension should be 355 to 455 N·m (80 to 110 lbs.) gauge value. If a Gates type gauge is not available, tension may be checked by belt deflection. Press the belt with your finger at the longest span (Figure 5) and measure the deflection. Maximum deflection 9.5 to 12.7 mm (0.37 to 0.50 in).

ADJUSTING

With the automatic belt tensioner, no adjustment is required.

REPLACEMENT

To replace the drive belt, place a 3/8 in. drive ratchet ② in the 3/8 in. square drive hole in the belt tensioner. Push the ratchet "UP" to loosen the tensioner. Remove the old belt ①. Inspect belt tensioner. The tensioner pulley should spin freely with no rough spots detected under hand pressure. Install the new belt.



CHECK AND ADJUST ALTERNATOR AND WATER PUMP BELT TENSION.

The engine is equipped with an automatic belt tensioner that maintains correct tension on the drive belt. To check belt tension a Gates type gauge must be used because of the wide drive belt. Proper tension should be 355 to 455 N·m (80 to 110 lbs.) gauge value.

If a Gates type gauge is not available, tension may be checked by belt deflection. Press the belt with your finger at the longest span (Figure 5) and measure the deflection. Maximum deflection 9.5 to 12.7 mm (0.37 to 0.50 in).



ADJUSTMENT

With the automatic belt tensioner, no adjustment is required.

REPLACEMENT

To replace the drive belt, place a 3/8 in. drive ratchet in the 3/8 in. square drive hole in the belt tensioner. Push the ratchet "UP" to loosen the tensioner. Remove the old belt. Inspect belt tensioner. The tensioner pulley should spin freely with no rough spots detected under hand pressure. Install the new belt.

NOTE: The belt tensioner is spring loaded and must be pivoted away from the belt. Pivoting in the wrong direction can result in damage to the belt tensioner.






CHECK AND ADJUST TENSION OF AIR CONDITIONER COMPRESSOR BELT

Testing

The belt should deflect 14-16 mm (0.55-0.63in) when pressed with a finger force of approx. 6 kg (13 lb) at a point midway between the crankshaft pulley and the compressor pulley.



Adjusting

1. Loosen 2 bolts ① and 2 bolts ②, and move compressor ③ to adjust.
2. When the deflection is correct, tighten bolts ① and ② to hold the compressor in position.
3. Check each pulley for damage, and check the V-groove and V-belt for wear. In particular, check that the V-belt is not contacting the bottom of the V-groove.
4. If the V-belt is stretched and cannot be adjusted any further, or if there are any cuts or cracks, replace the V-belt.
5. After replacing the V-belt, adjust again after one hour of operation.



ADJUSTING ENGINE SPEED SENSOR

1. Screw in until the tip of sensor (1) contacts gear (2).
 2. When gear (2) contacts sensor (1), turn back $1 \pm 1/6$ turns.
 3. Tighten locknut (3).
-  Locknut : $58.8 \pm 9.8 \text{ Nm}$ ($6 \pm 1 \text{ kgm}$)
- ★ Be particularly careful when handling the sensor wiring to ensure that no excessive force is brought to bear on the wiring.
 - ★ Be careful not to let the tip of the sensor be scratched or to let any iron particles stick to the sensor tip.



MEASURING AIR SUPPLY PRESSURE (BOOST PRESSURE)


Pressure gauge, Part N°

⚠ When removing or installing the measuring equipment or when carrying out the measurements, be careful not to touch any high temperature parts or rotating parts.

1. Remove the air intake access plug then install the pressure gauge **P1**.

Note: Run the engine at a mid-range speed or above, and use the self-seal portion of the gauge to bleed the oil from inside the hose.

- Insert the gauge about half way, and repeatedly open the self-seal portion to bleed the oil.
 - ★ The gauge does not work if there is any oil inside the hose, so always be sure to bleed all the oil.
2. Run the engine at near the rated speed and measure the pressure indicated by the gauge.
 - ★ Near rated output
 - Run the engine at near the rated output. For details, see the measurement of the engine speed when the arm IN circuit is relieved in the H/O mode and power max. mode.
- ★ The air supply pressure (boost pressure) should be measured with the engine running at rated output. However, when measuring in the field, a similar value can be obtained with the above conditions.



MEASURING WASTEGATE SETTING PRESSURE



Visually inspect the wastegate actuator hose for corks or holes. Replace the hose if damaged.

Connect regulated air pressure and an accurate pressure gauge to the capsule. Apply 2,0 kg/cm², 209 kPa (30.3 psi) to make sure the wastegate is functioning properly. The actuating rod should move approximately 5 mm [0.200 in] without sticking or air leakage.

NOTE: A small amount of travel when air pressure is first applied is normal, the tolerance is being removed from the system.

Replace the actuator if no movement of the actuator rod and lever is detected. Refer to Procedure 3-04.

If repair is not correct, refer to Turbo-changer Wastegate Actuator - Calibration



Turbocharger Wastegate Actuator-Calibration

Note: The wastegate is set accurately from the factory. Adjustment is not necessary unless the capsule is removed.

Attach a dial indicator as show, so that its shaft is in line with the wastegate actuator rod. Set the indicator to zero with no air pressure applied to the wastegate capsule.

Connect clean, regulated air pressure supply and an accurate pressure gauge to the capsule.

Apply 1,8 kg/cm² (26.4 psi) and measure the rod travel and compare to the table below.

Wastegate Actuator Rod Movement		
mm		in
0.33	MIN	0.013
1.3	MAX	0.050

Replace the actuator if no movement of the actuator rod and lever is detected. Refer to Procedure 3-04.

Caution: Do not pull, push or force alignment of the clevis pin.

While pressure is being applied, adjust linkage as follow:




- Pull the wastegate lever to the foremost closed position (lever toward actuator).
- Adjust the length of the clevis end of the control rod to where the clevis pin hole aligns to the wastegate lever.
- Install the adjusting link an retaining clip.
- After adjustment is completed, tighten actuator rod locknut.

Disconnect regulated air pressure line from the actuator.

Connect the turbo boost line to the actuator and secure hose clamp.

⚠ Caution: The turbocharger is a performance part and must not be tampered with. The wastegate bracket is an intergral part of the turbocharger. Tampering with the Wastegate Components can reduce durability by increasing cylinder pressure and thermal loading due to incorrect inlet and exhaust manifold pressure.


Poor fuel economy and failure to meet regulatory emissions laws may result. Increasing the turbocharger boost will not increase engine power.



TESTING AND ADJUSTING GOVERNOR MOTOR LEVER STROKE

Testing

- ★ Use the governor motor adjustment mode.
- 1. Preparatory work
 - 1) Keep the monitor panel time switch + travel speed (R.H.) switch + working mode (R.H.) switch pressed for 2.5 seconds.
 - 2) Set the fuel control dial to MAX, and the auto-deceleration switch to OFF.
 - ★ Any working mode can be used.
- 2. In this condition, check the governor lever and spring rod.
- 3. After checking, repeat the procedure in Step 1 to complete the governor motor adjustment mode.



Adjusting

1. Turn the starting switch OFF, then remove the nut and disconnect joint (1) from governor lever (2).
2. Repeat the procedure in Step 1 above to set to the governor motor adjustment mode.
3. Set governor lever (2) to a position where it contacts full speed stopper of the fuel injection pump, then turn joints (1) and (4) to adjust the length of spring assembly (5) and adjust to the position of the hole governor lever (2).
4. From the above position, lengthen joints (1) and (4) a total of 2 turns (approx. 2.5 mm), and secure in position with the locknut.

Caution


- ★ When the spring assembly is removed and the starting switch is at the OFF position, if the governor motor lever is moved suddenly, the governor motor will generate electricity, and this may cause a failure in the governor controller.
- ★ When moving the governor motor lever, disconnect connector E05 first.

TESTING AND ADJUSTING HYDRAULIC PRESSURE IN WORK EQUIPMENT, SWING, TRAVEL CIRCUIT


Measuring

- ★ Oil temperature when measuring: 45 – 55°C
- ⚠ Lower the work equipment to the ground and stop the engine. Loosen the oil filler cap slowly to release the pressure inside the hydraulic tank. Then put the safety lock lever in the LOCK position.


1. Remove pressure pick-up plug (1) or (2) (thread dia.=10mm, Pitch=1.25mm) from the circuit to be measured, then install oil pressure gauge **C1** (58.8 MPa (600 kg/cm²)).
2. **Measuring unload pressure**
 - 1) Run the engine at full throttle and measure in the H/O mode.
 - 2) Measure the hydraulic pressure when all levers are at neutral.
3. **Measuring main relief pressure**
 - 1) Run the engine at full throttle and measure in the H/O mode.
 - 2) Measure the hydraulic pressure when each actuator is relieved.
 - ★ If the power max. switch is turned ON, the pressure will rise, so measure with both the switch OFF and ON. (When the switch is turned ON, it is automatically turned OFF after approx. 8 seconds, so measure during the first 8 seconds.)
 - ★ Note that the set pressure of the safety valve for the swing motor and head end of the boom is lower than the LS relief pressure, so the value measured will be the relief pressure of the safety valve.
 - ★ To check the operation of the safety valve at the boom LOWER end, measure the hydraulic pressure when the machine push-up switch is OFF (low pressure) and ON (high pressure).
 - ★ When measuring the hydraulic pressure in the boom LOWER circuit, block the hose (fit blind plug) at the boom cylinder head end.
 - ★ If the swing lock switch is turned ON, the pressure will rise, so always keep the lock switch OFF when measuring.
 - ★ To relieve the travel circuit, put block under the track shoe grouser, or put block between the sprocket and frame to lock the track.



BLP00118



BLP00119



BLP00120

Table 1 Combination of pumps and actuators controlled when flow from front and rear pumps is divided

Plug	Pump	Controlled actuator
1	Front pump	Boom cylinder (Lo, Hi) Arm cylinder (Hi) Bucket cylinder R.H. travel motor Service
2	Rear pum	Arm cylinder (Lo) Swing motor L.H. travel motor

TESTING AND ADJUSTING

Adjusting

- ★ The unload valve cannot be adjusted.

1. Main relief valve


- (1): For front pump
- (2): For rear pump

Loosen locknut (3), then turn adjustment screw (4) to adjust.

- ★ Turn the adjustment screw to adjust as follows.
 - To INCREASE pressure, turn CLOCKWISE.
 - To DECREASE pressure, turn COUNTER-CLOCKWISE.
- ★ Amount of adjustment for one turn of adjustment screw:

Approx. 12.5 MPa (128 kg/cm²)

 Locknut : **68.6 ± 9.8 Nm (7 ± 1 kgm)**



2. Boom cylinder head safety valve

- ★ Adjust the safety valve at the high-pressure end first, then adjust the low-pressure end.
 - (1): Boom cylinder head (LOWER) end
 - 1) Disconnect pilot hose (2).
 - 2) Adjusting high-pressure setting
- Loosen locknut (3), then turn holder (4) to adjust.

 Locknut :



107.8 ± 14.7 Nm (11 ± 1.5 kgm)

- 3) Adjusting low-pressure setting
- Loosen locknut (5), then turn holder (6) to adjust.

 Locknut :

85.8 ± 7.4 Nm (8.75 ± 0.75 kgm)


- ★ Turn the holder to adjust as follows.
 - To INCREASE pressure, turn CLOCKWISE.
 - To DECREASE pressure, turn COUNTER-CLOCKWISE.
 - ★ Amount of adjustment for one turn of holder:
- Approx. 21.8 MPa (222 kg/cm²)



[Reference] The oil pressure acting on port **CP** is as follows.



Machine push-up switch ON (high pressure): 0 MPa (0 kg/cm²)

Machine push-up switch OFF (low pressure): 2.7 MPa (28 kg/cm²)



3. Swing motor safety valve

- (1): For starting left swing (stopping right swing)
 - (2): For starting right swing (stopping left swing)
- 1) Remove the mounting bolts, then remove cover (3) and spring (4).
 - 2) Loosen locknut (5), then turn adjustment screw (6) to adjust.
 - ★ Carry out the adjustment with the valve assembly installed to the motor.
 - ★ Turn the adjustment screw to adjust as follows.
 - To INCREASE pressure, turn CLOCKWISE.
 - To DECREASE pressure, turn COUNTERCLOCKWISE.
 - ★ Amount of adjustment for one turn of adjustment screw: Approx. 3.9 MPa (39.5 kg/cm²)
-  **kgm** Locknut : **132.3 ± 14.7 Nm (13.5 ± 1.5 kgm)**
- 3) After completing the adjustment, install spring (4) and cover (5), then tighten the mounting bolts to the specified torque.
-  **kgm** Cover mounting bolt : **110.3 ± 12.3 Nm (11.25 ± 1.25 kgm)**



TESTING AND ADJUSTING TVC VALVE OUTPUT PRESSURE (SERVO PISTON INPUT PRESSURE)

Measuring

- ★ Oil temperature when measuring: 45 – 55°C

! Lower the work equipment to the ground and stop the engine. Loosen the oil filler cap slowly to release the pressure inside the hydraulic tank. Then put the safety lock lever in the LOCK position.

1. Remove pressure measurement plugs (1), (2), (3), and (4) (Thread dia.=10 mm, Pitch=1.25 mm), and install oil pressure gauge **C1**.

- ★ Plugs and measured pressure





1	Front pump discharge pressure	3	Front servo piston input pressure
2	Rear pump discharge pressure	4	Rear servo piston input pressure

- ★ Install a 39.2 MPa (400 kg/cm²) gauge to the servo valve end, and a 58.8 MPa (600 kg/cm²) gauge to the pump outlet port end.

2. Turn the swing lock switch ON.
3. Set the working mode to H/O mode and set the knob switch function to POWER MAX.
4. Run the engine at full throttle, turn the L.H. knob switch ON, and measure the oil pressure when the arm IN circuit is relieved.
 - ★ For the front pump, measure the oil pressure at plugs (1) and (3) at the same time; for the rear pump, measure the oil pressure at plugs (2) and (4) at the same time.
 - ★ The power max. function is automatically turned OFF 8 seconds after it is switched ON, so measure during the first 8 seconds.
 - ★ Check that the servo piston input pressure is 2/5 of the pump discharge pressure.

[Reference]

If there is any abnormality in the LS valve or servo piston, the servo piston input pressure will be almost the same or 0 of the pump discharge pressure.





TESTING AND ADJUSTING**TESTING AND ADJUSTING TVC VALVE OUTPUT PRESSURE
(SERVO PISTON INPUT PRESSURE)****Adjusting**

- ★ If the load becomes larger, the engine speed will drop. Or if the engine speed remains normal, the work equipment speed will drop. In such cases, if the pump discharge pressure and LS differential pressure are normal, adjust the TVC valve as follows.

- Loosen locknut (1), and turn screw (2) to adjust.
 - ★ The direction to turn differs according to the position of the eccentric position punch mark on the screw, so check the mark before turning.
 - ★ Turn the screw as follows.
 - If work equipment is slow, turn in INCREASE direction
 - If engine speed drops, turn in DECREASE direction.

Punch mark	Increase	Decrease
Range ①	Within 90° in counterclockwise direction	Within 90° in clockwise direction
Range ②	Within 90° in clockwise direction	Within 90° in counterclockwise direction




- After completing the adjustment, tighten locknut (1).

Locknut : **29.4 ± 4.9 Nm (3.0 ± 0.5 kgm)**

Note: The screw is an eccentric cam, so if it is turned from the 0 position in the graph, the stroke of the servo piston (change in oil flow) will move as shown in the graph.

If it is turned one full turn, it will return to the original position, but the screw will become looser, so there will be play in the screw.

Therefore, turn the screw a maximum of 90° to the left or right from the position set when the machine was shipped.



TESTING AND ADJUSTING LS VALVE OUTPUT PRESSURE (SERVO PISTON INPUT PRESSURE) AND LS DIFFERENTIAL PRESSURE

TESTING AND ADJUSTING LS VALVE OUTPUT PRESSURE (SERVO PISTON INPUT PRESSURE) AND LS DIFFERENTIAL PRESSURE

★ Oil temperature when measuring: 45 – 55°C

1. Measuring LS valve output pressure (servo piston input pressure)

- 1) Remove pressure measurement plugs (1), (2), (3), and (4) (Thread dia.= 10 mm, Pitch=1.25 mm), and install oil pressure gauge C1.

★ Plugs and measured pressure

1	Front pump discharge pressure	3	Front servo piston input pressure
2	Rear pump discharge pressure	4	Rear servo piston input pressure


★ Install a 39.2 MPa (400 kg/cm²) gauge to the servo valve end, and a 58.8 MPa (600 kg/cm²) gauge to the pump outlet port end.

- 2) Set the working mode to H/O mode, and turn the travel speed switch to Hi.
- 3) Use the work equipment to raise the track assembly on one side.


★ When measuring the front pump, push up the right track; when measuring the rear pump, push up the left track.

- 4) Run the engine at full throttle, set to the conditions shown in Table 1, and measure the pump discharge pressure and servo inlet pressure.


★ For the front pump, measure the oil pressure at plugs (1) and (3) at the same time; for the rear pump, measure the oil pressure at plugs (2) and (4) at the same time.



BLP00118




BLP00128



BLP00129

Table 1

Working mode	Travel lever	Pump pressure (MPa(kg/cm ²))	Servo inlet port pressure (MPa(kg/cm ²))	Remarks
H/O mode	Neutral	3.9 ± 1.0 (40 ± 10)	3.9 ± 1.0 (40 ± 10)	About same pressure
H/O mode	Half (travel circuit under no load)	Approx. 12.7 (130)	Approx. 4.9 (50)	About 2/5 of pressure



BLP00120

2. Measuring LS differential pressure**1) Measuring with a differential pressure gauge**

- i) Remove pressure measurement plugs (1), (2), (3), and (4) (Thread dia.=10mm, Pitch=1.25mm), and install differential pressure gauge **C4**.

★ Plugs and measured pressure

1	Front pump discharge pressure	3	Front LS pressure
2	Rear pump discharge pressure	4	Rear LS pressure

★ Connect the pump discharge pressure to the high-pressure side of the differential gauge and the LS pressure to the low-pressure side.

- ii) Set the working mode to H/O mode, and turn the travel speed switch to Hi.

- iii) Use the work equipment to raise the track assembly on one side.

★ When measuring the front pump, push up the right track; when measuring the rear pump, push up the left track.

- iv) Run the engine at full throttle, set to the conditions shown in Table 2 and measure the LS differential pressure.

Table 2

Working mode	Travel lever	LS differential pressure (MPa (kg/cm ²))	Remarks
H/O mode	Neutral	3.9 ± 1.0 (40 ± 10)	(Note)
H/O mode	Half (travel circuit under no load)	2.5 ± 0.1 (25 ± 1)	






Note: When all control levers are at neutral, the LS differential pressure is the same as the unload pressure.

2) Measuring with oil pressure gauge

★ The maximum differential pressure is 2.9 ± 1.0 MPa (30 ± 10 kg/cm²), so measure with the same gauge.

- i) Remove pressure measurement plugs (1), (2), (3), and (4) (thread dia.=10mm, pitch=1.25mm), and install the plug of pressure gauge **C1**.




- ii) Carry out the same operation as in Step 1)-ii), iii) above.



TESTING AND ADJUSTING LS VALVE OUTPUT PRESSURE (SERVO PISTON INPUT PRESSURE) AND LS DIFFERENTIAL PRESSURE

TESTING AND ADJUSTING

- iii) Install oil pressure gauge **C1** (58.8 MPa (600 kg/cm²) to the measurement plug for the pump discharge pressure.
 - ★ Use a gauge with a scale in units of 1.0 MPa (10 kg/cm²).
(If no 58.8 MPa (600 kg/cm²) pressure gauge is available, a 39.2 MPa (400 kg/cm²) pressure gauge can be used.)
- iv) Set to the conditions in Table 2 and measure the pump discharge pressure.
 - ★ Stand directly in front of the indicator and be sure to read it correctly.
- v) Remove oil pressure gauge **C1**, then install it to the LS pressure measurement plug.
- vi) Set to the conditions in Table 2 and measure the LS pressure.
 - ★ Stand directly in front of the indicator and be sure to read it correctly.
(Pump discharge pressure) – (LS pressure) = LS Differential pressure



3. Adjusting LS valve


When the differential pressure is measured under the conditions above, and the results show that the differential pressure is not within the standard value, adjust as follows.

- 1) Loosen locknut (1) and turn screw (2) to adjust the differential pressure.
 - ★ Turn the screw to adjust the differential pressure as follows.
 - To INCREASE pressure, turn CLOCKWISE
 - To DECREASE pressure, turn COUNTER-CLOCKWISE
 - ★ Amount of adjustment for one turn of adjustment screw: Approx. 1.3 MPa (13.2 kg/cm²)

Note: Always measure the differential pressure while adjusting.

- 2) After adjusting, tighten locknut (1).

 Locknut: **68.6 ± 9.8 Nm (7 ± 1 kgm)**






TESTING AND ADJUSTING CONTROL PUMP CIRCUIT OIL PRESSURE

Measuring

- ★ Oil temperature when measuring: 45 – 55°C
- 1. Remove pressure pick-up plug (1) (Thread dia.=10mm, Pitch=1.25mm), and install oil pressure gauge **C1** (5.9 MPa (60 kg/cm²)).
- 2. Start the engine and measure with the engine at full throttle.
- ★ When testing for internal leakage of the equipment in the control circuit, use the parts given below to shut off the circuit for the following sections when measuring the relief pressure.

N0.	Section of hydraulic circuit shut off	Component that can be checked
1.	Control pump outlet port	Control pump
2.	LS-EPC valve inlet port	LS-EPC valve
3.	Solenoid valve inlet port	Solenoid valve
4.	Travel PPC valve inlet port	Travel PPC valve
5.	L.H. PPC valve inlet port	L.H. PPC valve
6.	R.H. PPC valve inlet port	R.H. PPC valve

- ★ Items No. 2 and below can be checked if the equipment in the previous number is normal.
- ★ Use the following parts to shut off the circuit.
 - For elbow
 - Sleeve nut: 07221-20210, 07221-20315
 - 07221-20422
 - Plug: 07222-00210, 07222-00315
 - 07222-00414
 - For hose
 - Plug: 07376-50210, 07376-50315
 - 07376-50422



TESTING AND ADJUSTING TESTING AND ADJUSTING CONTROL PUMP CIRCUIT OIL PRESSURE

Adjusting


1. Loosen locknut (1) and turn adjustment screw (2) to adjust.

- ★ Turn the adjustment screw as follows.
 - To INCREASE pressure, turn CLOCKWISE
 - To DECREASE pressure, turn COUNTER-CLOCKWISE
- ★ Amount of adjustment for one turn of adjustment screw:

Approx. 0.56 MPa (5.7 kg/cm²)

 **kgm** Locknut : **63.7 ± 9.8 Nm (6.5 ± 1 kgm)**

- ★ After completion of adjustment, repeat the procedure in Item 1 to check the set pressure again.



TESTING SOLENOID VALVE OUTPUT PRESSURE

★ Oil temperature when measuring: 45 – 55°C

1. Measuring output pressure of LS-EPC solenoid valve




- 1) Disconnect output hose (1) of the LS-EPC solenoid valve, then use adapter **C3** in the oil pressure gauge kit to install oil pressure gauge **C1** (5.9 MPa (60 kg/cm²)).
- 2) Measure the output pressure under the conditions in Table 1.

Table 1

Operation and working mode	Engine speed (rpm)	Output pressure (MPa(kg/cm ²))	[Reference] Current (A)
• All control levers at neutral	Min. 1500	2.9 ± 0.2 (30 ± 2)	900 ± 30
• H/O mode or G/O mode • Operate any control lever with travel at neutral	Min. 1900	0	0

★ The engine speed and LS-EPC current can be measured using the monitoring code on the monitor panel.

- Engine speed : [10] or [40]
- LS-EPC current : [15]



TESTING AND ADJUSTING**TESTING SOLENOID VALVE OUTPUT PRESSURE****2. Measuring output pressure of ON/OFF solenoid valve**

- 1) Disconnect outlet hose (1) of the solenoid valve to be measured, then use adapter **C3** in the oil pressure gauge kit to install oil pressure gauge **C1** (5.9 MPa (60 kg/cm²)).
- 2) Measure the output pressure under the conditions in Table 2.





Table 2

Hose	Solenoid	Measurement conditions	operating conditions	Condition of solenoid	Oil pressure (MPa (kg/cm ²))	Remarks
1	LS select	Swing lock switch OFF, compound operation of swing + travel	LS circuit divided	ON	Min. 2.7 (28)	When the solenoid is ON, the oil pressure is the output pressure of the travel PPC valve
		Swing lock switch ON	LS circuit not divided	OFF	0	
2	Machine push-up	When machine push-up switch is at high-pressure setting	Safety valve at high-pressure setting	OFF	0	
		When machine push-up switch is at low-pressure setting	Safety valve at low-pressure setting	ON	Min. 2.7 (28)	
3	Pump merge/divider valve	Travel operated independently	Flow from front and rear pumps divided	ON	Min. 2.7 (28)	
		All levers at neutral	Flow from front and rear pumps merged	OFF	0	
4	Travel speed	When operate travel lever with travel speed switch at Hi or Mi	Motor swash plate angle at MIN	ON	Min. 2.7 (28)	
		Travel speed switch at Lo	Motor swash plate angle at MAX	OFF	0	
5	Swing holding brake	Swing or work equipment lever operated	Brake canceled	ON	Min. 2.7 (28)	
		All levers except travel at neutral (5 sec after returning to neutral)	Brake actuated	OFF	0	



- ★ With monitoring code (23), check at the same time that the solenoid is switched ON/OFF electrically.
(The machine push-up solenoid is not displayed.)
- ★ The measurement conditions in the table are typical conditions for measuring the output pressure. The solenoid valve may be actuated (ON/OFF) under conditions other than the measurement conditions given above.
- ★ Operate the lever slightly not enough to move the machine.

MEASURING PPC VALVE OUTPUT PRESSURE AND TESTING PPC SHUTTLE VALVE

★ Oil temperature when measuring: 45 – 55°C

1. Measuring PPC valve output pressure



- 1) Disconnect hose (1) of the circuit to be measured.
- 2) Install adapter **C3** between the hose and elbow.
- 3) Install oil pressure gauge **C1** (5.9 MPa (60 kg/cm²)) to adapter **C3**.
- 4) Run the engine at full throttle, operate the control lever of the circuit to be measured, and measure the oil pressure.



2. Checking PPC shuttle valve

★ If the output pressure at the control valve end is low, check for leakage of oil from the PPC shuttle valve as follows.

- 1) Disconnect hose (1) between the PPC valve and the shuttle valve of the circuit to be measured. Disconnect the hose from the shuttle valve together with the nipple.
- 2) Install adapter **C5** to the tip of the hose, then install oil pressure gauge **C1** (5.9 MPa (60 kg/cm²)).
 - ★ Install a blind plug to the shuttle valve.
- 3) Run the engine at full throttle, operate the control lever, and measure the output pressure.
 - ★ If the output pressure becomes normal, there is leakage from the PPC shuttle valve; if there is no change, the PPC valve is defective.





MEASURING PPC VALVE OUTPUT PRESSURE AND TESTING PPC SHUTTLE VALVE

TESTING AND ADJUSTING

3. Checking defective operation of PPC shuttle valve

- 1) Remove the applicable oil pressure switch, then install oil pressure gauge **C1** (5.9 MPa (60 kg/cm²)).
 - ★ Disconnect the outlet hose of the LS select shuttle valve before installing the oil pressure gauge.
- 2) Run the engine at full throttle, operate the applicable lever, and measure the output pressure.
 - ★ If output pressure is generated for all the applicable operations, the shuttle valve is normal.
 - ★ If no output pressure is generated all the applicable operations, the shuttle valve is defective.

- ①: Swing left, right shuttle valve
- ②: LS select shuttle valve (boom RAISE, arm OUT, all travel)
- ③: Boom RAISE, arm OUT shuttle valve
- ④: L.H. travel FORWARD, R.H. travel REVERSE shuttle valve
- ⑤: All travel shuttle valves (L.H., R.H. FORWARD, REVERSE)
- ⑥: L.H. travel REVERSE, R.H. travel FORWARD shuttle valve




ADJUSTING WORK EQUIPMENT, SWING PPC VALVE

★ If there is excessive play in the work equipment or swing lever, adjust as follows.

⚠ Lower the work equipment to the ground and stop the engine. Loosen the oil filler cap slowly to release the pressure inside the hydraulic tank. Then set the safety lock lever to the LOCK position.

1. Remove the PPC valve.
2. Remove boot (1).
3. Loosen locknut (2), then screw in disc (3) until it contacts the 4 heads of piston (4).
★ When doing this, do not move the piston.
4. Secure disc (3) in position, then tighten locknut (2) to the specified torque.
 Locknut : $112.7 \pm 14.7 \text{ Nm}$ ($11.5 \pm 1.5 \text{ kgm}$)
5. Install boot (1).



★ With the above adjustment, the clearance between disc (3) and piston (4) becomes 0.



BLP00154

TESTING TRAVEL DEVIATION

- ★ When traveling on level ground.
- 1. Set the machine in the travel posture.
 - ★ For the travel posture, extend the bucket and arm cylinder rods fully, and hold the boom angle at 45° .
- 2. Travel for 10 m, then measure the deviation when traveling for the next 20 m.
 - ★ Set to H/O mode and measure with the engine at full throttle.
 - ★ Install the hydraulic pressure gauge and measure the pump discharge pressure at the same time.



TESTING LOCATIONS CAUSING HYDRAULIC DRIFT OF WORK EQUIPMENT



- ★ If there is any hydraulic drift in the work equipment (cylinders), check as follows to determine if the cause is in the cylinder packing or in the control valve.

1. Checking for defective cylinder packing

- 1) Checking boom and bucket cylinders
 - i) Set in the same posture as when measuring hydraulic drift, and stop the engine.
 - ii) Operate the boom control lever to RAISE or the bucket control lever to CURL.
 - If the lowering speed increases, the packing is defective.
 - If there is no change, the boom safety valve (boom) or the control valve (bucket) is defective.
 - 2) Checking arm cylinder
 - i) Operate the arm cylinder to move the arm in fully, then stop the engine.
 - ii) Operate the control lever to arm IN.
 - If the lowering speed increases, the packing is defective.
 - If there is no change, the control valve is defective.
- ★ If the pressure in the accumulator has dropped, run the engine for approx. 10 seconds to charge the accumulator again before operating.

[Reference] If the cause of the hydraulic drift is in the packing, and the above operation is carried out, the downward movement becomes faster for the following reasons.

- 1) If the work equipment is set to the above posture (holding pressure applied to the bottom end), the oil at the bottom end leaks to the head end. However, the volume at the head end is smaller than the volume at the bottom end by the volume of the rod, so the internal pressure at the head end increases because of the oil flowing in from the bottom end.
- 2) When the internal pressure at the head end increases, the pressure at the bottom end also rises in proportion to this. The balance is maintained at a certain pressure (this differs according to the amount of leakage) by repeating this procedure.
- 3) When the pressure is balanced, the downward movement becomes slower. If the lever is then operated according to the procedure given above, the circuit at the head end is opened to the drain circuit (the bottom end is closed by the check valve), so the oil at the head end flows to the drain circuit and the downward movement becomes faster.



TESTING AND ADJUSTING TESTING LOCATIONS CAUSING HYDRAULIC DRIFT OF WORK EQUIPMENT

2. Checking PPC valve

If the hydraulic drift differs when the safety lock lever is in the LOCK or FREE position, (engine running), the PPC valve is defective.


MEASURING OIL LEAKAGE

★ Oil temperature when measuring: 45 – 55°C

1. Work equipment cylinder


- ★ If the hydraulic drift of the work equipment is outside the standard value, measure the leakage inside the cylinder as follows, and judge if the cause of the hydraulic drift is in the cylinder or in the control valve.
 - If the leakage is within the standard value, the problem is in the control valve.
 - If the leakage is greater than the standard value, the problem is in the cylinder.
- 1) Fully extend the rod of the cylinder to be measured, then stop the engine.
- 2) Disconnect piping (1) at the head end, then block the piping at the chassis end with a blind plug.
 - ⚠ Be careful not to disconnect the piping at the bottom end.
- 3) Start the engine and apply the relief pressure to the bottom end of the cylinder with the engine at full throttle.
 - ★ Boom cylinder : RAISE
 - Arm cylinder : IN
 - Bucket cylinder : CURL
- 4) Continue this condition for 30 seconds, then measure the oil leakage for the next one minute.

Posture for measuring boom cylinder




BLP00161

Posture for measuring arm, bucket cylinder




BLP00162

Boom cylinder





BLP00163

Arm cylinder




BLP00164



2. Swing motor

- 1) Disconnect drain hose (1) from the swing motor, then install a blind plug at the tank end.
- 2) Turn the swing lock switch ON.
- 3) Start the engine and operate the swing relief with the engine at full throttle.
- 4) Continue this condition for 30 seconds, then measure the oil leakage for the next one minute.
 - ★ After measuring, swing 180° and measure again.



TESTING AND ADJUSTING

RELEASING REMAINING PRESSURE IN HYDRAULIC CIRCUIT




3. Travel motor

- 1) Disconnect drain hose (1) from the travel motor, then fit a blind plug at the hose end.
- 2) Fit block ① under the track shoe grouser, or fit block ② between the sprocket and frame to lock the track.
- 3) Start the engine and operate the travel relief with the engine at full throttle.

⚠ When measuring the oil leakage from the travel motor, mistaken operation of the control lever may lead to a serious accident, so always use signals and check when carrying out this operation.

- 4) Continue this condition for 30 seconds, then measure the oil leakage for the next one minute.

★ When measuring, move the motor slightly (to change the position between the valve plate and cylinder, and piston and cylinder), and measure several times.



RELEASING REMAINING PRESSURE IN HYDRAULIC CIRCUIT

- ★ If the piping between the hydraulic cylinder and the control valve is to be disconnected, release the remaining pressure from the circuit as follows.

The travel circuit is an open circuit, so there is no remaining pressure. It is enough to remove the oil filler cap.


1. Loosen the oil filler cap slowly to release the pressure inside the tank.
2. Operate the control levers.
 - ★ When the levers are operated 2 – 3 times, the pressure stored in the accumulator is removed.
3. Start the engine, run at low idling for approx. 5 minutes, then stop the engine and operate the control levers.
 - ★ Repeat the above operation 2 – 3 times to release all the remaining pressure.

TESTING CLEARANCE OF SWING CIRCLE BEARING


Method of testing clearance of swing circle bearing when mounted on machine

1. Fix a magnet-type dial gauge to the outer circle (or inner circle) of the swing circle, and put the tip of the probe in contact with the inner circle (or outer circle).

Set the dial gauge at the front or rear.



2. Extend the work equipment to the maximum reach, and set the tip of the bucket to the same height as the bottom of the revolving frame. When this is done, the upper structure will tilt forward, so the front will go down and the rear will rise.
3. Set the dial gauge to the zero point.




4. Set the arm more or less at right angles to the ground surface, then lower the boom until the front of the machine comes off the ground. When this is done, the upper structure will tilt back, so the front will rise and the rear will go down.

5. Read the value on the dial gauge at this point. The value on the dial gauge is the clearance of the swing circle bearing.

⚠ When carrying out the measurement, do not put your hand or feet under the undercarriage.


6. Return to the condition in Step 2, and check that the dial gauge has returned to the zero point. If it has not returned to the zero point, repeat Steps 3 to 5.



TESTING AND ADJUSTING TRACK SHOE TENSION


Testing

1. Raise the track frame on one side using the arm and boom.
2. Measure the clearance **a** (tension) between the bottom of the track frame and the top of the track shoe.
 - Measurement position
 STD : 4th track roller from the sprocket.
 LC : Midway between the 4th and 5th track roller from the sprocket.
 - Standard clearance **a** (tension) : 331 ± 20 mm



Adjusting

- ★ If the track shoe tension is not within the standard value, adjust as follows.
1. **If the track tension is too high:**
 Loosen plug (1) gradually, and release the grease.
 - ⚠ There is danger that the plug may fly out under the high internal pressure of the grease, so never loosen plug (1) more than 1 turn.
 - ★ If the grease does not come out easily, move the machine backwards or forwards slowly.
 2. **If the track tension is too low:**
 Pump in grease through grease fitting (2).
 - ★ If the grease cannot be pumped in easily, move the machine backwards and forwards slowly.



BLEEDING AIR

Order for operations and procedure for bleeding air

Air bleeding item	Air bleeding procedure					
	1	2	3	4	5	6
	Bleeding air from pump	Start engine	Bleeding air from cylinder	Bleeding air from swing motor	Bleeding air from travel motor	Start operations
• Change hydraulic oil • Clean strainer	○ →	○ →	○ →	○ (note) →	○ (note) →	○
• Replace return filter element		○				○
• Replace, repair pump • Remove suction piping	○ →	○ →	○ →			○
• Replace, repair control valve		○ →	○ →			○
• Replace cylinder • Remove cylinder piping		○ →	○ →			○
• Replace swing motor • Remove swing motor piping		○ →		○ →		○
• Replace travel motor, swivel • Remove travel motor, swivel piping		○ →			○ →	○

Note: Bleed the air from the swing and travel motors only when the oil inside the motor case has been drained.

1. Bleeding air from pump

- Loosen air bleed plug (1), and check that oil oozes out from the plug.

- When oil oozes out, tighten plug(1).

 **Air bleed plug:**



$8.8 \pm 1.0 \text{ Nm}$ ($0.9 \pm 0.1 \text{ kgm}$)

- ★ If no oil oozes out from the air bleed plug:
- Leave plug (1) loosened and remove drain hose (2) and elbow (3).
 - Pour in oil through the elbow mount hole until oil oozes out from plug (1).
 - Fit elbow (3) and install drain hose (2).
 - Tighten air bleed plug (1).

 **Air bleed plug:**


$8.8 \pm 1.0 \text{ Nm}$ ($0.9 \pm 0.1 \text{ kgm}$)

- ★ **Precautions when starting the engine**
After completing the above procedure and starting the engine, run the engine at low idling for 10 minutes.
- ★ If the coolant temperature is low and automatic warming-up is carried out, cancel it by using the fuel control dial after starting the engine.



2. Bleeding air from hydraulic cylinders


- 1) Start the engine and run at idling for approx. 5 minutes.
- 2) Run the engine at low idling, then raise and lower the boom 4 – 5 times in succession.
 - ★ Operate the piston rod to approx. 100 mm before the end of its stroke. Do not relieve the circuit under any circumstances.
- 3) Run the engine at full throttle and repeat Step 2). After that, run the engine at low idling, and operate the piston rod to the end of its stroke to relieve the circuit.
- 4) Repeat Steps 2) and 3) to bleed the air from the arm and bucket cylinders.
- ★ When the cylinder has been replaced, bleed the air before connecting the piston rod. Be particularly careful not to operate the cylinder to the end of its stroke when the piston rod has been connected to the LOWER end of the boom cylinder.



3. Bleeding air from swing motor

- 1) Inside motor case
 - Run the engine at low idling for 5 minutes.
 - ★ This operation will bleed the air inside the motor case automatically.
- 2) Inside brake case
 - ★ Normally, the air inside the brake case is bled automatically, but if it feels that the brake is dragging when operating the swing, bleed the air as follows.


Loosen the mouthpiece of brake hose (1), start the engine, and operate the swing prox switch ON-OFF repeatedly. When oil oozes out, tighten the mouthpiece.



4. Bleeding air from travel motor

- 1) Run the engine at low idling, loosen air bleed plug (1), and check that oil oozes out from the plug.
- 2) When oil oozes out, tighten air bleed plug (1) again.

 **kgm** Air bleed plug:
 $8.8 \pm 1.0 \text{ Nm}$ ($0.9 \pm 0.1 \text{ kgm}$)



TROUBLESHOOTING

Points to remember when troubleshooting	20-102
Sequence of events in troubleshooting	20-103
Points to remember when carrying out maintenance	20-104
Checks before troubleshooting	20-112
Connector types and mounting locations	20-114
Connection table for connector pin numbers	20-118
Explanation of control mechanism of electrical system	20-128
Display method and special functions of monitor panel	20-129
Method of using judgement table	20-137
Method of using troubleshooting charts	20-139
Details of troubleshooting and troubleshooting procedure	20-141
Service code table	20-146
Troubleshooting of communication abnormality system (N mode)	20-201
Troubleshooting of governor, pump controller [governor control system] (E mode)	20-251
Troubleshooting of engine (S mode)	20-301
Troubleshooting of governor, pump controller system [pump control system] (C mode)	20-351
Troubleshooting of governor, pump controller [input signal system] (F mode)	20-401
Troubleshooting of hydraulic, mechanical system (H mode)	20-451
Troubleshooting of monitor panel system (M mode)	20-501

POINTS TO REMEMBER WHEN TROUBLESHOOTING


- ⚠ Stop the machine in a level place, and check that the safety pin, blocks, and parking brake are securely fitted.
- ⚠ When carrying out the operation with two or more workers, keep strictly to the agreed signals, and do not allow any unauthorized person to come near.
- ⚠ If the radiator cap is removed when the engine is hot, hot water may spurt out and cause burns, so wait for the engine to cool down before starting troubleshooting.
- ⚠ Be extremely careful not to touch any hot parts or to get caught in any rotating parts.
- ⚠ When disconnecting wiring, always disconnect the negative (–) terminal of the battery first.
- ⚠ When removing the plug or cap from a location which is under pressure from oil, water, or air, always release the internal pressure first. When installing measuring equipment, be sure to connect it properly.

The aim of troubleshooting is to pinpoint the basic cause of the failure, to carry out repairs swiftly, and to prevent reoccurrence of the failure.

When carrying out troubleshooting, and important point is of course to understand the structure and function. However, a short cut to effective troubleshooting is to ask the operator various questions to form some idea of possible causes of the failure that would produce the reported symptoms.

1. When carrying out troubleshooting, do not hurry to disassemble the components.
If components are disassembled immediately any failure occurs:
 - Parts that have no connection with the failure or other unnecessary parts will be disassembled.
 - It will become impossible to find the cause of the failure.It will also cause a waste of manhours, parts, or oil or grease, and at the same time, will also lose the confidence of the user or operator.
For this reason, when carrying out troubleshooting, it is necessary to carry out thorough prior investigation and to carry out troubleshooting in accordance with the fixed procedure.
2. Points to ask user or operator
 - 1) Have any other problems occurred apart from the problem that has been reported?
 - 2) Was there anything strange about the machine before the failure occurred?
 - 3) Did the failure occur suddenly, or were there problems with the machine condition before this?
 - 4) Under what conditions did the failure occur?
 - 5) Had any repairs been carried out before the failure?
When were these repairs carried out?
 - 6) Has the same kind of failure occurred before?
3. Check before troubleshooting
 - 1) Check the oil level
 - 2) Check for any external leakage of oil from the piping or hydraulic equipment.
 - 3) Check the travel of the control levers.
 - 4) Check the stroke of the control valve spool.
 - 5) Other maintenance items can be checked externally, so check any item that is considered to be necessary.
4. Confirming failure
 - Confirm the extent of the failure yourself, and judge whether to handle it as a real failure or as a problem with the method of operation, etc.
 - ★ When operating the machine to reenact the troubleshooting symptoms, do not carry out any investigation or measurement that may make the problem worse.
5. Troubleshooting
 - Use the results of the investigation and inspection in Items 2 – 4 to narrow down the causes of failure, then use the troubleshooting flowchart to locate the position of the failure exactly.
 - ★ The basic procedure for troubleshooting is as follows.
 - 1) Start from the simple points.
 - 2) Start from the most likely points.
 - 3) Investigate other related parts or information.
6. Measures to remove root cause of failure
 - Even if the failure is repaired, if the root cause of the failure is not repaired, the same failure will occur again.
To prevent this, always investigate why the problem occurred. Then, remove the root cause.

SEQUENCE OF EVENTS IN TROUBLESHOOTING



POINTS TO REMEMBER WHEN CARRYING OUT MAINTENANCE


To maintain the performance of the machine over a long period, and to prevent failures or other troubles before they occur, correct operation, maintenance and inspection, troubleshooting, and repairs must be carried out. This section deals particularly with correct repair procedures for mechatronics and is aimed at improving the quality of repairs. For this purpose, it gives sections on "Handling electric equipment" and "Handling hydraulic equipment" (particularly gear oil and hydraulic oil).

1. POINTS TO REMEMBER WHEN HANDLING ELECTRIC EQUIPMENT

1) Handling wiring harnesses and connectors

Wiring harnesses consist of wiring connecting one component to another component, connectors used for connecting and disconnecting one wire from another wire, and protectors or tubes used for protecting the wiring.


Compared with other electrical components fitted in boxes or cases, wiring harnesses are more likely to be affected by the direct effects of rain, water, heat, or vibration. Furthermore, during inspection and repair operations, they are frequently removed and installed again, so they are likely to suffer deformation or damage. For this reason, it is necessary to be extremely careful when handling wiring harnesses.



Main failures occurring in wiring harness


① Defective contact of connectors (defective contact between male and female)

Problems with defective contact are likely to occur because the male connector is not properly inserted into the female connector, or because one or both of the connectors is deformed or the position is not correctly aligned, or because there is corrosion or oxidization of the contact surfaces.




② Defective crimping or soldering of connectors

The pins of the male and female connectors are in contact at the crimped terminal or soldered portion, but if there is excessive force brought to bear on the wiring, the plating at the joint will peel and cause improper connection or breakage.



③ Disconnections in wiring

If the wiring is held and the connectors are pulled apart, or components are lifted with a crane with the wiring still connected, or a heavy object hits the wiring, the crimping of the connector may separate, or the soldering may be damaged, or the wiring may be broken.




TEW00194

④ High-pressure water entering connector

The connector is designed to make it difficult for water to enter (drip-proof structure), but if high-pressure water is sprayed directly on the connector, depending on the direction of the water jet.

As already said, the connector is designed to prevent water from entering, but at the same time, if water does enter, it is difficult for it to be drained. Therefore, if water should get into the connector, the pins will be short-circuited by the water, so if any water gets in, immediately dry the connector or take other appropriate action before passing electricity through it.




TEW00195

⑤ Oil or dirt stuck to connector

If oil or grease are stuck to the connector and an oil film is formed on the mating surface between the male and female pins, the oil will not let the electricity pass, so there will be defective contact.

If there is oil or grease stuck to the connector, wipe it off with a dry cloth or blow it dry with compressed air and spray it with a contact restorer.

- ★ When wiping the mating portion of the connector, be careful not to use excessive force or deform the pins.
- ★ If there is oil or water in the compressed air, the contacts will become even dirtier, so remove the oil and water from the compressed air completely before cleaning with compressed air.




TEW00196



2) Removing, installing, and drying connectors and wiring harnesses

● **Disconnecting connectors**


- ① Hold the connectors when disconnecting.
When disconnecting the connectors, hold the connectors and not the wires. For connectors held by a screw, loosen the screw fully, then hold the male and female connectors in each hand and pull apart. For connectors which have a lock stopper, press down the stopper with your thumb and pull the connectors apart.
★ Never pull with one hand.



- ② When removing from clips
When removing a connector from a clip, pull the connector in a parallel direction to the clip.
★ If the connector is twisted up and down or to the left or right, the housing may break.






- ③ Action to take after removing connectors
After removing any connector, cover it with a vinyl bag to prevent any dust, dirt, oil, or water from getting in the connector portion.
★ If the machine is left disassembled for a long time, it is particularly easy for improper contact to occur, so always cover the connector.



● **Connecting connectors**

- ① Check the connector visually.
 - 1) Check that there is no oil, dirt, or water stuck to the connector pins (mating portion).
 - 2) Check that there is no deformation, defective contact, corrosion, or damage to the connector pins.
 - 3) Check that there is no damage or breakage to the outside of the connector.
 - ★ If there is any oil, water, or dirt stuck to the connector, wipe it off with a dry cloth. If any water has got inside the connector, warm the inside of the wiring with a dryer, but be careful not to make it too hot as this will cause short circuits.
 - ★ If there is any damage or breakage, replace the connector.
- ② Fix the connector securely.

Align the position of the connector correctly, then insert it securely.
For connectors with lock stopper, push in the connector until the stopper clicks into position.
- ③ Correct any protrusion of the boot and any misalignment of the wiring harness
For connectors fitted with boots, correct any protrusion of the boot. In addition, if the wiring harness is misaligned, or the clamp is out of position, adjust it to its correct position.
 - ★ If the connector cannot be corrected easily, remove the clamp and adjust the position.
- ④ If the connector clamp has been removed, be sure to return it to its original position. Check also that there are no loose clamps.



TROUBLESHOOTING


POINTS TO REMEMBER WHEN CARRYING OUT MAINTENANCE

● Drying wiring harness

If there is any oil or dirt on the wiring harness, wipe it off with a dry cloth. Avoid washing it in water or using steam. If the connector must be washed in water, do not use high-pressure water or steam directly on the wiring harness.

If water gets directly on the connector, do as follows.


- ① Disconnect the connector and wipe off the water with a dry cloth.
 - ★ If the connector is blown dry with compressed air, there is the risk that oil in the air may cause defective contact, so remove all oil and water from the compressed air before blowing with air.



- ② Dry the inside of the connector with a dryer.

If water gets inside the connector, use a dryer to dry the connector.


 - ★ Hot air from the dryer can be used, but regulate the time that the hot air is used in order not to make the connector or related parts too hot, as this will cause deformation or damage to the connector.



- ③ Carry out a continuity test on the connector.

After drying, leave the wiring harness disconnected and carry out a continuity test to check for any short circuits between pins caused by water.

 - ★ After completely drying the connector, blow it with contact restorer and reassemble.




TROUBLESHOOTING


POINTS TO REMEMBER WHEN CARRYING OUT MAINTENANCE

3) Handling control box


- ① The control box contains a microcomputer and electronic control circuits. These control all of the electronic circuits on the machine, so be extremely careful when handling the control box.
- ② Do not open the cover of the control box unless necessary.



- ③ Do not place objects on top of the control box.
- ④ Cover the control connectors with tape or a vinyl bag. Never touch the connector contacts with your hand.
- ⑤ During rainy weather, do not leave the control box in a place where it is exposed to rain.



- ⑥ Do not place the control box on oil, water, or soil, or in any hot place, even for a short time.
(Place it on a suitable dry stand).
- ⑦ Precautions when carrying out arc welding
When carrying out arc welding on the body, disconnect all wiring harness connectors connected to the control box. Fit an arc welding ground close to the welding point.



2. Points to remember when troubleshooting electric circuits

- 1) Always turn the power OFF before disconnecting or connect connectors.
- 2) Before carrying out troubleshooting, check that all the related connectors are properly inserted.
★ Disconnect and connect the related connectors several times to check.
- 3) Always connect any disconnected connectors before going on to the next step.
★ If the power is turned ON with the connectors still disconnected, unnecessary abnormality displays will be generated.
- 4) When carrying out troubleshooting of circuits (measuring the voltage, resistance, continuity, or current), move the related wiring and connectors several times and check that there is no change in the reading of the tester.
★ If there is any change, there is probably defective contact in that circuit.

TROUBLESHOOTING

POINTS TO REMEMBER WHEN CARRYING OUT MAINTENANCE

3. POINTS TO REMEMBER WHEN HANDLING HYDRAULIC EQUIPMENT


With the increase in pressure and precision of hydraulic equipment, the most common cause of failure is dirt (foreign material) in the hydraulic circuit. When adding hydraulic oil, or when disassembling or assembling hydraulic equipment, it is necessary to be particularly careful.

1) Be careful of the operating environment.

Avoid adding hydraulic oil, replacing filters, or repairing the machine in rain or high winds, or places where there is a lot of dust.

2) Disassembly and maintenance work in the field


If disassembly or maintenance work is carried out on hydraulic equipment in the field, there is danger of dust entering the equipment. It is also difficult to confirm the performance after repairs, so it is desirable to use unit exchange. Disassembly and maintenance of hydraulic equipment should be carried out in a specially prepared dustproof workshop, and the performance should be confirmed with special test equipment.



3) Sealing openings


After any piping or equipment is removed, the openings should be sealed with caps, tapes, or vinyl bags to prevent any dirt or dust from entering. If the opening is left open or is blocked with a rag, there is danger of dirt entering or of the surrounding area being made dirty by leaking oil so never do this.

Do not simply drain oil out on to the ground, collect it and ask the customer to dispose of it, or take it back with you for disposal.



4) Do not let any dirt or dust get in during refilling operations.

Be careful not to let any dirt or dust get in when refilling with hydraulic oil. Always keep the oil filler and the area around it clean, and also use clean pumps and oil containers. If an oil cleaning device is used, it is possible to filter out the dirt that has collected during storage, so this is an even more effective method.




5) Change hydraulic oil when the temperature is high.

When hydraulic oil or other oil is warm, it flows easily. In addition, the sludge can also be drained out easily from the circuit together with the oil, so it is best to change the oil when it is still warm. When changing the oil, as much as possible of the old hydraulic oil must be drained out. (Do not drain the oil from the hydraulic tank; also drain the oil from the filter and from the drain plug in the circuit.) If any old oil is left, the contaminants and sludge in it will mix with the new oil and will shorten the life of the hydraulic oil.

6) Flushing operations

After disassembling and assembling the equipment, or changing the oil, use flushing oil to remove the contaminants, sludge, and old oil from the hydraulic circuit.


Normally, flushing is carried out twice: primary flushing is carried out with flushing oil, and secondary flushing is carried out with the specified hydraulic oil.



7) Cleaning operations

After repairing the hydraulic equipment (pump, control valve, etc.) or when running the machine, carry out oil cleaning to remove the sludge or contaminants in the hydraulic oil circuit.

The oil cleaning equipment is used to remove the ultrafine (about 3μ) particles that the filter built into the hydraulic equipment cannot remove, so it is an extremely effective device.



CHECKS BEFORE TROUBLESHOOTING

	Item	Judgement value	Action
Lubricating oil, coolant	1. Check fuel level, type of fuel	—	Add fuel
	2. Check for impurities in fuel	—	Clean, drain
	3. Check hydraulic oil level	—	Add oil
	4. Check hydraulic oil strainer	—	Clean, drain
	5. Check swing machinery oil level	—	Add oil
	6. Check engine oil level (oil pan oil level), type of oil	—	Add oil
	7. Check coolant level	—	Add water
	8. Check dust indicator for clogging	—	Clean or replace
	9. Check hydraulic oil filter	—	Replace
Electrical equipment	1. Check for looseness, corrosion of battery terminal, wiring	—	Tighten or replace
	2. Check for looseness, corrosion of alternator terminal, wiring	—	Tighten or replace
	3. Check for looseness, corrosion of starting motor terminal, wiring	—	Tighten or replace
Hydraulic, mechanical equipment	1. Check for abnormal noise, smell	—	Repair
	2. Check for oil leakage	—	Repair
	3. Carry out air bleeding	—	Bleed air
Electrics, electrical equipment	1. Check battery voltage (engine stopped)	20 – 30V	Replace
	2. Check battery electrolyte level	—	Add or replace
	3. Check for discolored, burnt, exposed wiring	—	Replace
	4. Check for missing wiring clamps, hanging wiring	—	Repair
	5. Check for water leaking on wiring (be particularly careful attention to water leaking on connectors or terminals)	—	Disconnect connector and dry
	6. Check for blown, corroded fuses	—	Replace
	7. Check alternator voltage (engine running at 1/2 throttle or above)	After running for several minutes: 27.5 - 29.5 V	Replace
	8. Check operating sound of battery (when switch is turned ON/OFF)	—	Replace

CONNECTOR TYPES AND MOUNTING LOCATIONS


★ The Address column in the table below shows the address in the connector arrangement drawing (2-dimensional drawing).


Con- nector No.	Type	No. of pins	Mounting location	Add- ress
A16	—	2	Diode	H3
C01	MIC	13	Governor pump controller	G7
C02	MIC	21	Governor pump controller	G7
C03	040	20	Governor pump controller	G7
C04	X	2	Rear pump TVC solenoid valve	H7
C05	S	10	Pump redundancy circuit switch	M2
C06	M	2	Resister	N3
C07	X	3	Rear pump pressure sensor	G8
C08	X	3	Front pump pressure sensor	G8
C09	S	8	Model selection connector	O3
C10	X	2	EPC valve for LS	H7
C13	X	2	Front pump	H7
C16	MIC	17	Governor pump controller	G7
E04	X	3	Potential meter	H2
E05	X	4	Governor motor	H2
E06	M	3	Fuel dial	G2
E07	X	2	Engine speed sensor	G2
E08	SWP	14	Engine harness	H7
E10	—	3	Shut off valve	H2
H07	S	12	Panel harness	G7
H08	M	6	Base harness	G7
H12	S	16	Base harness	G7
H13	S	16	Base harness	G7
H14	M	6	Base harness	G7
H15	L	2	Base harness	G7
K02	X	4	Pressure switch for A/C (option)	H7
M02	X	2	Starting motor	H2
M08	M	2	Right deck	M8
M10	M	1	Working lamp boom (left)	G7
M11	L	2	Fusible link	F7
M12	M	4	Heater	F7
M13	—	8	Speaker	O5
M14	L	2	Fusible link	F7
M16	—	1	Horn (high tone)	F7
M17	—	1	Horn (low tone)	F7
M18	M	4	Wiper, washer switch	N4
M20	—	1	Cigar lighter	N4
M22	M	2	Left knob switch	G7
M23	M	2	Horn switch	G6
M26	—	11	To A/C (option)	G6
M34	—	1	A/C compressor	H3

Con- nector No.	Type	No. of pins	Mounting location	Add- ress
M35	X	4	To A/C condensor (option)	G7
M38	M	3	Lamp switch	N4
M49	—	1	Refuelling pump (option)	G7
M51	KESI	2	Left front lamp	M5
M52	X	2	Overload alarm (option)	F7
M53	—	2	Heated seat (option)	N6
P01	040	20	Monitor	L2
P02	040	18	Monitor	L2
P03	M	2	Buzzer cancel switch	N4
P04	M	2	Alarm buzzer	L2
P05	—	4	Engine oil level sensor	H2
P06	X	1	Fuel level sensor	F7
P08	X	2	Radiator water level sensor	G8
P09	X	1	Hydraulic oil level sensor	H7
P11	—	1	Air cleaner clogging sensor	G8
P12	—	1	Air cleaner clogging sensor	G8
R04	SINGAWA	6	Relay for std. lamp	M2
R05	SINGAWA	6	Relay for optional lamp	M2
R10	SINGAWA	6	Relay for opt. lamp	M2
R11	SINGAWA	6	Relay for opt. lower wiper	M2
S01	X	2	Travel	F2
S02	X	2	Boom up	F2
S03	X	2	Arm dump	F2
S04	X	2	Boom down	F3
S05	X	2	Arm dig	F3
S06	X	2	Bucket dig	F3
S07	X	2	Bucket dump	F3
S08	X	2	Swing	F3
S09	X	2	Service pressure switch	M6
V02	X	2	LS Divide valve	D3
V03	X	2	Confluence valve	D3
V04	X	2	Swing parking brake	D2
V05	X	2	Machine push up	D3
V06	X	2	Travel speed	D3
W04	M	6	Wiper motor	M6
W08	070	18	Wiper motor controller	N8
W10	M	4	Connector	N2
W15	KES	4	To wiper	L1
X01	MIC	21	Intermediate connector	O5
X05	M	4	Swing lock switch	N4
X07	MIC	17	Panel harness	O4

CONNECTOR ARRANGEMENT DIAGRAM

★ For details of this page, see Section 90.











BBP00323











CONNECTION TABLE FOR CONNECTOR PIN NUMBERS

★ The terms male and female refer to the pins, while the terms male housing and female housing refer to the mating portion of the housing.

No. of pins	X type connector	
	Male (female housing)	Female (male housing)
2	 TEW00221	 TEW00222
3	 TEW00223	 TEW00224
4	 TEW00225	 TEW00226











TROUBLESHOOTING

CONNECTION TABLE FOR CONNECTOR PIN NUMBERS

No. of pins	SWP type connector	
	Male (female housing)	Female (male housing)
6	 TEW00235	 BLP00033
8	 TEW00237	 TEW00238
12	 BLP00034	 BLP00035
14	 TEW00239	 TEW00240
16	 BLP00036	 BLP00037









TROUBLESHOOTING

CONNECTION TABLE FOR CONNECTOR PIN NUMBERS

No. of pins	M type connector	
	Male (female housing)	Female (male housing)
2	 BLP00038	 BLP00039
3	 TEW00243	 TEW00244
4	 TEW00245	 TEW00246
6	 TEW00247	 TEW00248
8	 BLP00040	 BLP00041











TROUBLESHOOTING

CONNECTION TABLE FOR CONNECTOR PIN NUMBERS

No. of pins	S type connector	
	Male (female housing)	Female (male housing)
8	 TEW00249	 TEW00250
10	 TEW00251	 BLP00042
12	 BLP00043	 TEW00254
16	 BLP00044	 TEW00256

















TROUBLESHOOTING

CONNECTION TABLE FOR CONNECTOR PIN NUMBERS

No. of pins	MIC connector	
	Male (female housing)	Female (male housing)
5	 BLP00045	 BLP00046
9	 BLP00047	 BLP00048
13	 BLP00049	 BLP00050
17	 BLP00051	 BLP00052
21	 TEW00259	 TEW00260





TROUBLESHOOTING

CONNECTION TABLE FOR CONNECTOR PIN NUMBERS

No. of pins	AMP040 type connector			
	Male (female housing)		Female (male housing)	
8		 BLP00053	 BLP00054	
12		 BLP00055	 BLP00056	
16		 BLP00057	 TEW00232	
20		 BLP00058	 TEW00234	



TROUBLESHOOTING

CONNECTION TABLE FOR CONNECTOR PIN NUMBERS

No. of pins	AMP070 type connector	
	Male (female housing)	Female (male housing)
8		
12		





















TROUBLESHOOTING

CONNECTION TABLE FOR CONNECTOR PIN NUMBERS

No. of pins	L type type connector	
	Male (female housing)	Female (male housing)
2	 TEW00257	 TEW00258





TROUBLESHOOTING

CONNECTION TABLE FOR CONNECTOR PIN NUMBERS

No. of pins	Automobile connector	
	Male (female housing)	Female (male housing)
2	  BLP00063	  BLP00064
3	  BLP00065	  BLP00066
4	  BLP00067	  BLP00068
6	  BLP00069	  BLP00070
8	  BLP00071	  BLP00072

TROUBLESHOOTING


CONNECTION TABLE FOR CONNECTOR PIN NUMBERS

No. of pins	Relay connector	
	Male (female housing)	Female (male housing)
5	 BLP00073	 BLP00074
6	 BLP00075	 BLP00076

EXPLANATION OF CONTROL MECHANISM FOR ELECTRICAL SYSTEM

1. Explanation of machine control functions

The control mechanism for the electrical system consists of the monitor panel and governor and pump controller. The monitor panel and the governor and pump controller input the signals that are necessary, and together with the signals selected by the monitor panel, the governor and pump controller outputs or inputs the necessary signals and control the pump absorption torque and engine output.



TAP00174

DISPLAY METHOD AND SPECIAL FUNCTIONS OF MONITOR PANEL

1. Display on machine monitor

When the starting switch is turned on, all the monitor and gauge lamps light up for approx. 3 seconds, and the buzzer sounds for approx. 1 second. During this time, the monitor itself carries out self diagnosis, and after it has finished, it returns to the normal display.

2. Recording of service codes and user code display function

1) All the abnormality data for the governor and pump controller is sent to the monitor panel. When the monitor panel receives this data, it records the abnormality data, and at the same time, depending on the nature of the abnormality, it displays the user code on the time display panel to advise the operator of the action to take. However, in cases of abnormalities which are not urgent and do not require the user code to be displayed, only the content of the abnormality is recorded, and no display is given.

2) Types of user code and system

E02 (TVC system)

E03 (Swing holding brake system)


E05 (Governor motor system)

★ For details of the service codes included in the user code, see the action taken by the controller when an abnormality occurs, the symptoms on the machine or the judgement table.

3) Displaying user code

If it becomes necessary to display the user code, the time displayed panel is automatically switched to advise the operator to take the necessary action.

- Actual display (Example: Disconnection in the cancel solenoid system for the swing holding brake)




TROUBLESHOOTING

DISPLAY METHOD AND SPECIAL FUNCTIONS OF MONITOR PANEL

4) Display of trouble data

The monitor panel records both service codes which are included in the user code, and service codes which are not included. This data can be displayed on the time display as follows.

- ★ For details of the service codes that are not included in the user code, see ACTION TAKEN BY CONTROLLER WHEN ABNORMALITY OCCURS AND PROBLEMS ON MACHINE or the JUDGMENT TABLE




TAP00175

i) Method of displaying trouble data


Operation	Display
1. To set to the trouble data display mode, Keep the TIME switch + L.H. travel speed switch pressed for 2.5 seconds. Note: It is possible to call it up at the following times. 1) In the normal mode 2) In the user code display mode 3) In the machine data monitoring mode 4) In the time adjustment mode	1. On the time display and service meter display, the service code and number of hours (service meter hours) that have elapsed since the occurrence of the abnormality are displayed. • Example of display : When E212 has occurred 12 hours before (service meter) 1) Display of service code 2) Display of elapsed time BKP00079 3) If any abnormality exists at this time, the E mark is displayed. BKP00080

TROUBLESHOOTING**DISPLAY METHOD AND SPECIAL FUNCTIONS OF MONITOR PANEL**

Operation	Display
4. To finish with the trouble data display mode, keep the TIME switch + L.H. travel speed switch pressed for 2.5 seconds. 5. To erase the memory, keep the time switch pressed, turn the starting switch from OFF to ON, and keep the time switch pressed for 5 seconds.	4) If there is no abnormality code in memory  BKP00081


3. Machine data monitoring function

The input signals from the sensors and the output signals to drive the solenoid are displayed on the time display and service meter display.




TAP00176

1) Method of displaying monitoring code

Operation	Display
1. To set to the machine data monitoring mode, do as follows. Keep the time switch + knob button function switch pressed for 2.5 seconds. Note: This is possible at the following times. - During the normal mode - During the user code display mode - During the time adjustment mode - During the trouble data display mode	1. On the time display and service meter display, the monitoring code and data are displayed. - Example of display 1) When engine speed is monitored (monitoring code 10)  (example of 1950 rpm) BKP00083

TROUBLESHOOTING

DISPLAY METHOD AND SPECIAL FUNCTIONS OF MONITOR PANEL

Operation	Display
2. To go to the next monitoring code display, press the time switch + R.H. working mode switch. 3. To go back to the previous monitoring code display, press the time switch + L.H. working mode switch. 4. To finish with the machine data monitoring code mode, keep the time switch + knob button function switch pressed for 2.5 seconds.	2) When displaying bit pattern - For monitoring codes 08, 20 – 24, 36, 37, 47 – 49, 4A, display the bit pattern. - Example of monitoring code 20  • The code No. is displayed in the monitoring code portion, and the display lights up to display bit patterns (1) – (6).

2) Table of machine data monitoring codes

★ For details of the B in the Unit column, see the bit pattern chart in the next section.

No.	Item	Unit	Name of component
01	Monitor model code	—	Monitor panel
02	Governor, pump controller model code	—	Governor, pump controller
03	Governor, pump controller model code	—	Governor, pump controller
08	S-NET component condition display	B	Governor, pump controller
10	Engine speed	10rpm	Governor, pump controller
11	Pump discharge pressure (F) input	MPa(kg/cm ²)	Governor, pump controller
12	Pump discharge pressure (R) input	MPa(kg/cm ²)	Governor, pump controller
13	TVC current (F) output	10mA	Governor, pump controller
14	TVC current (R) output	10mA	Governor, pump controller
15	LS-EPC current output	10mA	Governor, pump controller
16	No. 2 throttle command	10mA	Governor, pump controller
20	Governor, pump controller PPC oil pressure switch input signal (1)	B	Governor, pump controller
21	Governor, pump controller PPC oil pressure switch input signal (2)	B	Governor, pump controller
22	Governor, pump controller PPC oil pressure switch input signal (3)	B	Governor, pump controller
23	Governor, pump controller solenoid actuation	B	Governor, pump controller
24	Input condition of sensor for governor, pump controller monitor warning	B	Governor, pump controller
30	Fuel control dial input value	10mV	Governor, pump controller
31	Potentiometer voltage	10mV	Governor, pump controller
32	VBB voltage (battery voltage)	100mV	

TROUBLESHOOTING**DISPLAY METHOD AND SPECIAL FUNCTIONS OF MONITOR PANEL**

★ For details of the B in the Unit column, see the bit pattern chart in the next section.


No.	Item	Unit	Name of component
33	Governor motor A phase current	10mV	Governor, pump controller
34	Governor motor B phase current	10mV	Governor, pump controller
35	Battery relay output voltage	100mV	Governor, pump controller
36	Governor governor input condition	B	Governor, pump controller
37	Governor governor output condition	B	Governor, pump controller
40	Engine speed	10rpm	Governor, pump controller
41	Coolant temperature sensor voltage	10mV	Governor, pump controller
42	Fuel sensor input voltage	10mV	Governor, pump controller
43	Battery charge input voltage	100mV	Governor, pump controller
47	Monitor panel output condition 1	B	Governor, pump controller
48	Monitor panel input condition 1	B	Governor, pump controller
49	Monitor panel input condition 2	B	Governor, pump controller
4A	Monitor panel input condition 3	B	Governor, pump controller

TROUBLESHOOTING

DISPLAY METHOD AND SPECIAL FUNCTIONS OF MONITOR PANEL

3) Bit pattern chart

As shown in the diagram below, the time display has bit numbers which light up to show that the signal is being transmitted. (For details, see METHOD OF DISPLAYING MONITORING CODE.)



BKP00085

Code	Content	Bit	Details (condition when lighted up)
08	Connection of S-NET components	(1) (2) (3) (4) (5) (6)	(1) Governor, pump controller connected (ID=2) (2) Governor, pump controller connected (ID=3)
20	Input condition of governor, pump controller PPC switches	(1) (2) (3) (4) (5) (6)	(1) Swing switch ON (2) Travel switch ON (3) Boom LOWER switch ON (4) Boom RAISE switch ON (5) Arm IN switch ON (6) Arm OUT switch ON
21	Input condition of governor, pump controller PPC switches and other switches	(1) (2) (3) (4) (5) (6)	(1) Bucket CURL switch ON (2) Bucket DUMP switch ON (3) Swing lock switch ON (4) Service switch ON (5) Model selection 5 (6) Swing prolix switch ON
22	Input condition of governor, pump controller model selection and other switches Drive condition of governor,	(1) (2) (3) (4) (5) (6)	(1) Model selection 1 GND connected (2) Model selection 2 GND connected (3) Model selection 3 GND connected (4) Model selection 4 GND connected (5) Kerosene mode input GND connected (6) Knob switch ON

TROUBLESHOOTING

DISPLAY METHOD AND SPECIAL FUNCTIONS OF MONITOR PANEL

Code	Content	Bit	Details (condition when lighted up)
23	pump controller ON/OFF solenoid valves	(1) (2) (3) (4) (5) (6)	LS select solenoid ON Swing holding brake ON Pump merge/divider solenoid ON Travel speed selector solenoid ON
24	Input condition 1 of sensor for governor, pump controller monitor warning	(1) (2) (3) (4) (5) (6)	Above engine oil pressure sensor Lo set pressure Above engine oil pressure sensor Hi set pressure Radiator water level sensor abnormal Engine oil level sensor abnormal Hydraulic oil level sensor abnormal Air cleaner clogging sensor abnormal
36	Input condition of governor, pump controller	(1) (2) (3) (4) (5) (6)	Starting switch ON
37	Output condition of governor, pump controller	(1) (2) (3) (4) (5) (6)	Battery relay: Actuated
47	Monitor panel output condition 1	(1) (2) (3) (4) (5) (6)	Alarm buzzer: when operated machine
49	Monitor panel input condition	(1) (2) (3) (4) (5) (6)	KEY ON SW OFF Terminal BR Voltage Hi LIGHT SW OFF Preheating switch OFF START C Sometimes turns ON

TROUBLESHOOTING**DISPLAY METHOD AND SPECIAL FUNCTIONS OF MONITOR PANEL**

Code	Content	Bit	Details (condition when lighted up)
4A	Monitor panel output condition	(1)	Time switch OFF
		(2)	PPC oil pressure selector switch OFF
		(3)	Overload selector switch OFF
		(4)	STD/DLX selection STD
		(5)	Swing lock switch OFF
		(6)	Buzzer cancel switch OFF

4. Governor motor adjustment mode

This is used when adjusting the linkage between the governor motor and the injection pump. (For details of the procedure, see TESTING AND ADJUSTING.)

Operation	Display
1. To set to the governor motor adjustment mode, press the time switch + R.H. travel speed switch + R.H. working mode switch.	1.
2. To return to the time display mode use the same procedure as in Step 1.	2. Buzzer sounds once a second

5. Time adjustment mode

To adjust the time, do as follows.

Operation	Display
1. To set to the time adjustment mode, keep the time switch depressed for 2.5 seconds. 2. Use the L.H. working mode switch to advance the hour. 3. Use the R.H. working mode switch to advance the minute. 4. To return to the time display mode use the same procedure as in Step 1.	1. The time mark portion flashes ★ The example shows the situation when setting to 12:34.

METHOD OF USING JUDGEMENT TABLE

This judgement table is a tool to determine if the problem with the machine is caused by an abnormality in the electrical system or by an abnormality in the hydraulic or mechanical system. The symptoms are then used to decide which troubleshooting table (E-○○, S-○○, C-○○, F-○○, H-○○, M-○○) matches the symptoms.

The judgement table is designed so that it is easy to determine from the user code and service code which troubleshooting table to go to.

★ The abnormality display (warning) given by the monitor panel leads directly to troubleshooting of the machine monitor (M-○○). (See troubleshooting of the machine monitor system)

1. When using judgement table for governor, pump controller (governor control system) and engine related parts

- If a service code is displayed on the monitor panel, go to the troubleshooting code at the bottom of the judgement table (E-○○). (A ● mark is put at the places where the failure mode and service code match.)
- If a problem has appeared but no service code is displayed on the monitor panel, go to the point where the failure mode matches the troubleshooting code on the right of the judgement table (E-○○ or S-○○).

<Example> Failure mode "Engine does not start".

Procedure: Check if the service code is being displayed on the monitor panel.

Failure mode	Governor, pump controller, power source system						User code	Service code	Checking monitoring, check items										Main monitor check item	Troubleshooting code if no service code display is given
	Abnormality in governor, pump controller, power source system	Abnormality in fuel control dial input value	Abnormality (disconnection) in motor drive system	Abnormality (short circuit) in motor drive system	Abnormality in feedback potentiometer system	Abnormality (short circuit) in battery relay output			Battery relay drive signal	No. 2 throttle command value	Fuel control dial command value	Governor motor potentiometer	Governor motor A phase current	Governor motor B phase current	Coolant temperature voltage	102°C or above	105°C or above	Is red range displayed?		
1 Engine does not start easily							E05	308 317 318 306 315 316												S-1
2 Engine does not start																				S-2
3 Engine speed stays at low idling, and does not follow accelerator; or engine pickup is poor	●	●	●	●	●	●			+	+	+	+								S-3
4 Engine stops during operation																				S-4
5 Engine rotation is irregular																				E-9A, S-5
6 Lack of output (engine high idling speed is too low)																				E-9A, S-5
7 Auto-deceleration does not work																				E-10, S-6
8 Engine does not stop	●	●	●	●	●	●														E-3 - E-4
9 Warming-up operation is defective																				E-11
10 Exhaust gas is black																				E-3 - E-4
11 Oil consumption is excessive, or exhaust gas is blue																				S-7
12 Oil becomes dirty prematurely																				S-8
13 Fuel consumption is excessive, or exhaust gas is blue																				S-9
14 Oil is mixed in coolant																				S-10
15 Engine oil pressure caution lamp lights up																				S-11
16 Oil level rises																				S-12
17 Coolant temperature rises too high (overheating)																				S-13
18 Abnormal noise is generated																				S-14
19 There is excessive vibration																				S-15
20 Engine speed does not change even when working mode is switched																				S-16
Troubleshooting code when service code is displayed	E-1	E-2	E-3	E-4	E-5	E-6	E-7													E-3 - E-4
Troubleshooting code when there is abnormality in monitoring or machine monitor check																				

● : This shows applicable item for service code
 * : This shows item that needs only checking with monitoring

[Judgement]

- If a service code is being displayed on the monitor panelgo to troubleshooting [E3:○○] for the governor, pump controller (governor control system).
- If no service code is displayed on the monitor panel, and the engine does not start:

- Check that starting motor rotates
 - Starting motor rotatesGo to troubleshooting S-2 of mechanical system
 - Starting motor does not rotateGo to troubleshooting E-8 of electrical system

METHOD OF USING TROUBLESHOOTING CHARTS

1. Category of troubleshooting code number

Troubleshooting Code No.	Component	Service code
N-○○	Troubleshooting of communication abnormality system	E218 group
E-○○	Troubleshooting of electrical system for governor, pump controller (governor control system)	E3-○○ group
S-○○	Troubleshooting of engine related parts	—
C-○○	Troubleshooting of electrical system for governor, pump controller (pump control system)	E2-○○ group
F-○○	Troubleshooting of governor, pump controller (input signal system)	—
H-○○	Troubleshooting of hydraulic, mechanical system	—
M-○○	Troubleshooting of machine monitor	E1-○○ group

2. Method of using troubleshooting table for each troubleshooting mode

- 1) Troubleshooting code number and problem
The title of the troubleshooting chart gives the troubleshooting code, service code, and failure mode (problem with the machine). (See Example (1))
- 2) Distinguishing conditions
Even with the same failure mode (problem), the method of troubleshooting may differ according to the model, component, or problem. In such cases, the failure mode (problem) is further divided into sections marked with small letters (for example, a), so go to the appropriate section to carry out troubleshooting. (See Example (2)) If the troubleshooting table is not divided into sections, start troubleshooting from the first check item in the failure mode.
- 3) Method of following troubleshooting chart
 - Check or measure the item inside

YES NO

, and according to the answer follow either the YES line or the NO line to go to the next

--

. (Note: The number written at the top right corner of the

--

 is an index number; it does not indicate the order to follow.)
 - Following the YES or NO lines according to the results of the check or measurement will lead finally to the Cause column. Check the cause and take the action given in the Remedy column on the right. (See Example (3))
 - Below the

--

 there are the methods for inspection or measurement, and the judgement values. If the judgement values below the

--

 are correct or the answer to the question inside the

--

 is YES, follow the YES line; if the judgement value is not correct, or the answer to the question is NO, follow the NO line.
 - Below the

--

 is given the preparatory work needed for inspection and measurement, and the judgement values. If this preparatory work is neglected, or the method of operation or handling is mistaken, there is danger that it may cause mistaken judgement, or the equipment may be damaged. Therefore, before starting inspection or measurement, always read the instructions carefully, and start the work in order from Item 1).
- 4) General precautions
When carrying out troubleshooting for the failure mode (problem), precautions that apply to all items are given at the top of the page and marked with ★ (See Example (4)).
The precautions marked ★ are not given in the

--

, but must always be followed when carrying out the check inside the

--

.
- 5) Troubleshooting tools
When carrying out the troubleshooting, prepare the necessary troubleshooting tools. For details, see TOOLS FOR TESTING, ADJUSTING, AND TROUBLESHOOTING.

TROUBLESHOOTING**METHOD OF USING TROUBLESHOOTING CHARTS**

6) Installation position, pin number

A diagram or chart is given for the connector type, installation position, and connector pin number connection. When carrying out troubleshooting, see this chart for details of the connector pin number and location for inspection and measurement of the wiring connector number appearing in the troubleshooting flow chart for each failure mode (problem).

<Example>

(1) **M-9 When starting switch is turned ON (engine stopped), check item for previous troubleshooting flashes**

(4) ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.

★ Always connect any disconnected connectors before going on the next step.

★ Check that the coolant is at the specified level before carrying out troubleshooting

(2) a)  (coolant level) flashes


SAP00519

Divided into sections a) and b)

b)  (engine oil level) flashes

SAP00523

(3)



Table

Short connector	Continuity
Connected	Yes
Disconnected	No

①

TROUBLESHOOTING DETAILS OF TROUBLESHOOTING AND TROUBLESHOOTING PROCEDURE

If there is no abnormality display in the communications system transmitted in S-NET, it can be taken that the output signal from the monitor panel has been transmitted. However, even if there is no abnormality display, if the operation is defective, use the following procedure when checking directly. If any abnormality occurs in the S-NET system, the system is automatically switched to the following default mode, so be careful when carrying out troubleshooting.

Default Mode when communications cannot be carried out for the monitor and governor, pump controller

Set mode		Pump control	Governor control
1	Working mode	G/O mode	H/O mode
2	Throttle signal	FULL	FULL
3	Auto-deceleration	ON (deceleration mode)	ON (deceleration mode)
4	Coolant temperature signal	OFF	—
5	Priority mode	OFF	—
6	Power max. mode	ON (power max. possible)	—
7	Travel speed	Lo	—
8	Automatic warming up	—	ON (automatic warming-up mode)

1. Procedure for checking monitor panel output signal

★ For details of operating the monitoring mode, see MONITOR PANEL DISPLAY AND SPECIAL FUNCTIONS.

1. Connection condition of components

- 1) Set to the monitoring mode and display monitoring code 08.
- 2) The time display (bits) will light up to display the components that are connected.
 - ★ Governor, pump controller (pump control system) (1) and governor, pump controller (governor control system) (2) will light up.

2. Checking working mode signal (check No. 2 throttle signal (monitoring code 16) at the same time)

- 1) Set to the monitoring mode and display monitoring code 10.
- 2) Switch the working mode as shown in Table 1 and check that the engine speed changes.

Table 1

Working mode	High idling speed (rpm) [The figures in () are the rated speed]
H/O	Approx. 2050 (1750)
G/O	Approx. 1950 <during operation> Approx. 1800 <idling> (1,650)
F/O	Approx. 1800 (1450)
L/O	Approx. 1600 (1300)

TROUBLESHOOTING DETAILS OF TROUBLESHOOTING AND TROUBLESHOOTING PROCEDURE

3. Checking travel speed selection signal
 - 1) Set to the monitoring mode and display monitoring code 23.
 - 2) Change the speed selector switch to Hi or Mi and run the engine at 1500 rpm or above. Check that bit (6) lights up when traveling at Hi or Mi (front or rear pump oil pressure: 21.6 – 32.3 MPa (220 – 330 kg/cm²))
4. Checking swing priority mode signal
 - ★ If the travel oil pressure switch signal is not input to the controller, the flow from the front and rear pumps will remain divided.
 - 1) Set to the monitoring mode and display monitoring code 23.
 - 2) Check that bit (4) lights up when the travel is operated (even when operated slightly).
 - ★ Check the operating condition of the pump merge/divider solenoid valve

2. Checking input signal of governor, pump controller

- ★ Check the input signals for each controller as follows.
- Pump control system
- 1. Checking input signal
 - 1) Check hydraulic switch
 - i) Set to the monitoring mode, and display monitoring codes 20 and 21.
 - ii) Operate each work equipment lever, and check how the bit pattern lights up.
 - ★ For details of the bit pattern chart, see MONITOR PANEL DISPLAY AND SPECIAL FUNCTIONS.
 - 2) Check speed sensor (check engine speed)
 - i) Set to the monitoring mode, and display monitoring code 10.
 - ii) Use the fuel control dial to change the speed, and measure the speed when this is done.
 - 3) Check pump discharge pressure sensor
 - i) Set to the monitoring mode, and display monitoring codes 11 and 12.
 - ★ Code 11 is for the front pump and code 12 is for the rear pump.
 - ii) Refer to Table 2 and measure the hydraulic pressure at the front or rear pump.

Table 2 Pump merge/flow logic and pumps actuated by control levers

	Independent operation (basic flow merged)		Travel operated independ- ently or compound opera- tion together with travel※	
	Front pump	Rear pump	Front pump	Rear pump
L.H. travel				
Swing				
Arm				
Boom				
Bucket				
R.H. travel				

※ Conditions for compound operation with travel.

- (1) When measuring the oil pressure for any circuit other than travel, operate the travel lever slightly or connect a short connector (X-2P) to the travel oil pressure switch connector (CN-S01).
- (2) The circuits merge when the pressure of the front pump or rear pump is more than 19.6 MPa (200 kg/cm²).

TROUBLESHOOTING DETAILS OF TROUBLESHOOTING AND TROUBLESHOOTING PROCEDURE

- 4) Check kerosene mode input signal
 - i) Set to the monitoring mode, and display monitoring code 22.
 - ii) Connect the CN-M36 connector and check that bit (5) lights up.
- 5) Check knob switch input signal .
 - i) Set to the monitoring mode, and display monitoring code 22.
 - ii) Turn the knob switch ON and check that bit (6) lights up.
2. Check output signals
 - 1) Check LS-EPC solenoid output current
 - i) Set to the monitoring mode, and display monitoring code 15.
 - ii) Run the engine at high idling with all the levers at neutral and in the G/O or H/O mode, and measure the current.
 - ★ All levers at neutral: 900 ± 80 mA
 - Engine at high idling, any lever operated (other than travel): 0 A
 - 2) No. 2 throttle signal
 - i) Set to the monitoring mode, and display monitoring code 16.
 - ii) Use the procedure in Item 2 for checking the monitor panel output signal, and measure the engine speed.
 - 3) Checking ON ↔ OFF solenoid condition
 - i) Set to the monitoring mode, and display monitoring code 23.
 - ii) Refer to Table 3 and check that the applicable bit lights up.

Table 3 Types of solenoid and conditions for actuation

Name of solenoid	Actuation condition	Bit that lights up
LS select	Swing lock switch OFF, swing + travel lever operated simultaneously	(2)
Swing holding brake	Swing or work equipment lever operated	(3)
Pump merge/divider	Travel operated independently	(4)
Travel speed selector	Travel speed selector switch Hi or Mi	(6)

★ Operate the lever slightly not enough to move the machine.

- 4) Check TVC solenoid output current
 - i) Set to the monitoring mode, and display monitoring codes 13 and 14.
 - Code 13 is for the front pump and code 14 is for the rear pump.
 - ii) With the starting switch kept at the ON position (G/O mode), measure the current when the fuel control dial is turned to the MAX position.
 - Current with starting switch ON (G/O mode) and fuel control dial at MAX : 520 ± 80 (mA)

TROUBLESHOOTING DETAILS OF TROUBLESHOOTING AND TROUBLESHOOTING PROCEDURE

- **Governor control system**

1. Check input signal
 - 1) Check fuel control dial input voltage
 - i) Set to the monitoring mode, and display monitoring code 30.
 - ii) Measure the voltage when the fuel control dial is turned from low idling to high idling.
 - ★ Voltage: 0.25 – 4.75 V
 - 2) Check governor potentiometer voltage
 - i) Set to the monitoring mode, and display monitoring code 31.
 - ii) Measure the potentiometer voltage when the fuel control dial is turned from low idling to high idling.
 - ★ Voltage: 0.5 – 3.3 V
2. Check output signal
 - 1) Check governor motor drive current
 - i) Set to the monitoring mode, and display monitoring codes 33 and 34.
 - ★ Code 33 is the A phase (engine speed acceleration direction) and code 34 is the B phase (engine speed deceleration direction)
 - ii) Measure the governor motor drive current when the fuel control dial is turned in the acceleration direction and deceleration direction.
 - ★ Current: 700 ± 70 (mA)
 - 2) Measure battery relay drive output voltage
 - i) Set to the monitoring mode, and display monitoring code 35.
 - ii) Measure the battery relay drive output voltage when the starting switch is turned from ON to OFF.
 - or
 - iii) Set to the monitoring mode, and display monitoring code 37.
 - iv) Check that bit (1) lights up when the starting switch is turned from ON to OFF.

SERVICE CODE TABLE

Service code	Abnormal system	User code	Service code	Abnormal system	User code
E101	Abnormality in error history data				
E102	Abnormality in time data				
E103	Short circuit in buzzer output, contact with 24V wiring harness for buzzer drive				
E104	Air cleaner clogging detected				
E106	Abnormality in engine oil pressure sensor detected				
E108	Water temperature over 105°C				
E202	Short circuit in LS select solenoid system				
E203	Short circuit in swing holding brake solenoid system	E03			
E204	Short circuit in pump merge/divider solenoid system				
E206	Short circuit in travel speed solenoid system				
E212	Disconnection in LS select solenoid system				
E213	Disconnection in swing holding brake solenoid system				
E214	Disconnection in pump merge/divider solenoid system	E03			
E216	Disconnection in travel speed solenoid system				
E217	Error in model selection input				
E218	Network response overtime error				
E222	Short circuit in LS-EPC solenoid system				
E223	Disconnection in LS-EPC solenoid system				
E224	Abnormality in F pump pressure sensor system				
E225	Abnormality in R pump pressure sensor system				
E226	Abnormality in pressure sensor system power source				
E227	Abnormality in engine speed sensor				
E232	Short circuit in F pump TVC solenoid system	E02			
E233	Disconnection in F pump TVC solenoid system	E02			
E236	Short circuit in R pump TVC solenoid system	E02			
E237	Disconnection in R pump TVC solenoid system	E02			
E306	Abnormality in feedback potentiometer system				
E308	Abnormality in fuel control dial input value	E05			
E315	Short circuit in battery relay output system				
E316	Step-out in governor motor				
E317	Disconnection in governor motor system	E05			
E318	Short circuit in governor motor system	E05			

TROUBLESHOOTING OF COMMUNICATION ABNORMALITY SYSTEM (N MODE)

N-1	[E218] Communication abnormality	20-202
-----	--	--------

N-1[E218] Communication abnormality

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the service code E is not displayed, the problem has been removed.
- ★ If the starting switch was turned off after the abnormality occurred, turn the starting switch on and check that the service code displays E. (If it is not displayed, the problem has been removed.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.




Table 1

Monitoring code		Display
01	Monitor panel model code	300
02	Governor, pump controller model code	300
03	Governor, pump controller model code	300

- When each controller is connected to the network, "—" is displayed. If the correct alphanumeric are not displayed (another model is displayed), each controller shows model selection abnormal.


Table 2

Monitoring code	Display
08	Network connection condition

BKP00093

- Light up when connected
 - (1) Governor, pump controller
 - (2) Governor, pump controller
- Note: Checks can be carried out with code 08 only when there is a disconnection. The display does not change when there is a short circuit. Therefore, checks when there is a short circuit should be carried out basically using Table 1.

N-1 Related electric circuit diagram



BKP00092

TROUBLESHOOTING OF GOVERNOR, PUMP CONTROLLER (GOVERNOR CONTROL SYSTEM) (E MODE)

Points to remember when carrying out troubleshooting of governor, pump controller system	20-252
Action taken by controller and condition of machine when abnormality occurs	20-254
Judgement table for governor, pump controller (governor control system) and engine related parts	20-258
Electrical circuit diagram of governor, pump controller (governor control system)	20-260
E- 1 Abnormality in governor, pump controller power source (controller LED is OFF)	20-262
E- 2 [E308] Abnormality in fuel control dial input value is displayed	20-263
E- 3 [E317] Abnormality (disconnection) in governor motor drive system is displayed	20-264
E- 4 [E318] Abnormality (short circuit) in governor motor drive system is displayed	20-265
E- 5 [E306] Abnormality in feedback potentiometer system is displayed	20-266
E- 6 [E315] Abnormality (short circuit) in battery relay output system is displayed	20-267
E- 7 [E316] Abnormality (step-out) in motor is displayed	20-268
E- 8 Engine does not start	20-270
E- 9 Engine speed is irregular	20-272
a) Idling speed is irregular	20-272
b) There is hunting	20-274
E-10 Lack of output (engine high idling speed is too low)	20-276
E-11 Engine does not stop	20-278
E-12 Defective operation of battery relay system (engine does not stop)	20-280

POINTS TO REMEMBER WHEN CARRYING OUT TROUBLESHOOTING OF GOVERNOR, PUMP CONTROLLER SYSTEM


1. Points to remember when there is abnormality which is not displayed by user code

The engine is controlled by the governor and pump controller.

The problems that may occur with this system include the following.

1. Idling speed is too high (too low)
2. High idling speed is too low
3. Auto-deceleration speed is too high (too low)
4. Engine speed for automatic warming-up operation is too high (too low)
5. There is hunting
6. Engine does not stop

If any abnormality occurs, and the abnormality is displayed on the time display portion of the monitor panel, use the troubleshooting table to determine the appropriate troubleshooting flow chart from E-1 to E-12. However, if there is any abnormality in the machine and no abnormality display is given, it is necessary to determine whether the problem is in the mechanical system or in the electrical system. If the linkage between the governor motor and the injection pump is not properly adjusted, problems 1 to 6 listed above may occur. Therefore, if there is no abnormality display, but one of problems 1 to 6 above has occurred, carry out troubleshooting as follows.



Disconnect the linkage as explained above, or check the adjustment and go to the troubleshooting flow chart for the mechanical system or electrical system.

For details of the procedure for adjusting the linkage, see TESTING AND ADJUSTING.

2. Points to remember if abnormality returns to normal by itself

In the following two cases, there is a high probability that the same problem will occur again, so it is desirable to follow up this problem carefully.

- 1) If any abnormality returns to normal by itself, or
- 2) If the connector is disconnected and the T-adapter is inserted, or if the T-adapter is removed and the connector is returned to its original position when carrying out troubleshooting of the failure, and the service code is no longer displayed, or if the monitor display returns to normal.
- 3) After completing troubleshooting, always erase the service code from memory.

3. User code memory retention function

When displaying the abnormality code in memory and carrying out troubleshooting, note down the content of the display, then erase the display. After trying to re-enact the problem, carry out troubleshooting according to the failure code that is displayed.

(There are cases where mistaken operation or abnormalities that occur when the connector is disconnected are recorded by the memory retention function. Erasing the data in this way saves any wasted work.)

ACTION TAKEN BY CONTROLLER WHEN ABNORMALITY
OCCURS AND PROBLEMS ON MACHINE

User code	Service code	Abnormal system	Nature of abnormality
E05	E308	Abnormality in fuel control dial input value	1. Short circuit in wiring harness between C03 (7) – (14), (7) – (17), (14) – (17) 2. Short circuit in wiring harness between E04 (1) – (2), (1) – (3), (2) – (3) 3. Short circuit in wiring harness between E06 (1) – (2), (1) – (3), (2) – (3) 4. Short circuit in wiring harness between C03 (7) – (4), (4) – (17) 5. Disconnection in wiring harness between C03 (7) – X07 (6) – E06 (1) 6. Disconnection in wiring harness between C03 (4) – X07 (5) – E06 (2) 7. Disconnection in wiring harness between C03 (17) – X07 (4) – E06 (3) 8. Defective fuel control dial 9. Defective contact of C03, X07, E06 connectors
	E317	Abnormality (disconnection) in motor drive system	1. Disconnection inside governor motor 2. Disconnection in wiring harness between C02 (2) – E05 (1) 3. Disconnection in wiring harness between C02 (4) – E05 (3) 4. Disconnection in wiring harness between C02 (3) – E05 (2) 5. Disconnection in wiring harness between C02 (5) – E05 (4) 6. Defective contact of E05 connector
	E318	Abnormality (short circuit) in motor drive system	1. Short circuit inside governor motor 2. Wiring harness between C02 (2) – E05 (1) and between C02 (4) – E05 (3) short circuiting with wiring harness between C02 (3) – E05 (2) 3. Wiring harness between C02 (4) – E05 (3) and between C02 (2) – E05 (1) short circuiting with wiring harness between C02 (5) – E05 (4) 4. Wiring harness in Items 2 and 3 short circuiting with ground

TROUBLESHOOTING

ACTION TAKEN BY CONTROLLER WHEN ABNORMALITY OCCURS AND PROBLEMS ON MACHINE

Condition when normal (voltage, current, resistance)	Action by controller when abnormality is detected	Problem that appears on machine when there is abnormality																		
<table border="1"> <thead> <tr> <th>C03 (female)</th><th>E06 (male)</th><th>Resistance value</th></tr> </thead> <tbody> <tr> <td>(7) – (4)</td><td>(1) – (2)</td><td>0.25 – 7kΩ</td></tr> <tr> <td>(4) – (17)</td><td>(2) – (3)</td><td>0.25 – 7kΩ</td></tr> <tr> <td>(7) – (17)</td><td>—</td><td>2 – 3kΩ</td></tr> <tr> <td>—</td><td>(1) – (3)</td><td>4 – 6kΩ</td></tr> <tr> <td>Between each pin and chassis</td><td>—</td><td>Min. 1 MΩ</td></tr> </tbody> </table>	C03 (female)	E06 (male)	Resistance value	(7) – (4)	(1) – (2)	0.25 – 7kΩ	(4) – (17)	(2) – (3)	0.25 – 7kΩ	(7) – (17)	—	2 – 3kΩ	—	(1) – (3)	4 – 6kΩ	Between each pin and chassis	—	Min. 1 MΩ	Maintains engine speed at position of fuel control dial immediately before abnormality occurred	- Does not become partial speed when set at MAX position - Does not reach high idling when set at partial speed - There are cases of hunting - Lacks output (max. speed of engine is too low)
C03 (female)	E06 (male)	Resistance value																		
(7) – (4)	(1) – (2)	0.25 – 7kΩ																		
(4) – (17)	(2) – (3)	0.25 – 7kΩ																		
(7) – (17)	—	2 – 3kΩ																		
—	(1) – (3)	4 – 6kΩ																		
Between each pin and chassis	—	Min. 1 MΩ																		
<table border="1"> <thead> <tr> <th>E05 (male)</th><th>C02 (female)</th><th>Resistance value</th></tr> </thead> <tbody> <tr> <td>(1) – (2)</td><td>(2) – (3)</td><td>0.25 – 7kΩ</td></tr> <tr> <td>(3) – (4)</td><td>(4) – (5)</td><td>0.25 – 7kΩ</td></tr> <tr> <td>(1) – (3)</td><td>(2) – (4)</td><td>Min. 1 MΩ</td></tr> <tr> <td>(1) – (4)</td><td>(2) – (5)</td><td>Min. 1 MΩ</td></tr> <tr> <td>Between pins (1), (2), (3), (4) and chassis</td><td>Between pins (2), (3), (4), and (5) and chassis</td><td>Min. 1 MΩ</td></tr> </tbody> </table> Motor drive current: Hold: 0.7 A Start: 0.84 A	E05 (male)	C02 (female)	Resistance value	(1) – (2)	(2) – (3)	0.25 – 7kΩ	(3) – (4)	(4) – (5)	0.25 – 7kΩ	(1) – (3)	(2) – (4)	Min. 1 MΩ	(1) – (4)	(2) – (5)	Min. 1 MΩ	Between pins (1), (2), (3), (4) and chassis	Between pins (2), (3), (4), and (5) and chassis	Min. 1 MΩ	Takes no particular action	- When there is a disconnection in both the A phase and B phase at the same time, the problem is the same as for a short circuit in the governor motor system - When there is a disconnection in only one of A phase or B phase - Engine does not stop - Stops moving at position immediately before failure, so engine speed cannot be controlled - There are cases of hunting
E05 (male)	C02 (female)	Resistance value																		
(1) – (2)	(2) – (3)	0.25 – 7kΩ																		
(3) – (4)	(4) – (5)	0.25 – 7kΩ																		
(1) – (3)	(2) – (4)	Min. 1 MΩ																		
(1) – (4)	(2) – (5)	Min. 1 MΩ																		
Between pins (1), (2), (3), (4) and chassis	Between pins (2), (3), (4), and (5) and chassis	Min. 1 MΩ																		
<table border="1"> <thead> <tr> <th>E05 (male)</th><th>C02 (female)</th><th>Resistance value</th></tr> </thead> <tbody> <tr> <td>(1) – (2)</td><td>(2) – (3)</td><td>0.25 – 7kΩ</td></tr> <tr> <td>(3) – (4)</td><td>(4) – (5)</td><td>0.25 – 7kΩ</td></tr> <tr> <td>(1) – (3)</td><td>(2) – (4)</td><td>Min. 1 MΩ</td></tr> <tr> <td>(1) – (4)</td><td>(2) – (5)</td><td>Min. 1 MΩ</td></tr> <tr> <td>Between pins (1), (2), (3), (4) and chassis</td><td>Between pins (2), (3), (4), and (5) and chassis</td><td>Min. 1 MΩ</td></tr> </tbody> </table> Motor drive current: Hold: 0.7 A Start: 0.84 A	E05 (male)	C02 (female)	Resistance value	(1) – (2)	(2) – (3)	0.25 – 7kΩ	(3) – (4)	(4) – (5)	0.25 – 7kΩ	(1) – (3)	(2) – (4)	Min. 1 MΩ	(1) – (4)	(2) – (5)	Min. 1 MΩ	Between pins (1), (2), (3), (4) and chassis	Between pins (2), (3), (4), and (5) and chassis	Min. 1 MΩ	Sets motor drive current to 0	- If during operation - Set to low idling - Engine does not stop - There are cases of hunting - When stopped - Engine starts, but stays at low idling - Engine does not stop after starting - There are cases of hunting
E05 (male)	C02 (female)	Resistance value																		
(1) – (2)	(2) – (3)	0.25 – 7kΩ																		
(3) – (4)	(4) – (5)	0.25 – 7kΩ																		
(1) – (3)	(2) – (4)	Min. 1 MΩ																		
(1) – (4)	(2) – (5)	Min. 1 MΩ																		
Between pins (1), (2), (3), (4) and chassis	Between pins (2), (3), (4), and (5) and chassis	Min. 1 MΩ																		

ACTION TAKEN BY CONTROLLER WHEN ABNORMALITY OCCURS AND PROBLEMS ON MACHINE

TROUBLESHOOTING

User code	Service code	Abnormal system	Nature of abnormality
—	E306	Abnormality in feedback potentiometer system	1. Short circuit in wiring harness between C03 (7) – (14), (7) – (17), (14) – (17) 2. Short circuit in wiring harness between E04 (1) – (2), (1) – (3), (2) – (3) 3. Short circuit in wiring harness between E06 (1) – (2), (1) – (3), (2) – (3) 4. Short circuit in wiring harness between C03 (7) – (4), (4) – (17) 5. Disconnection in wiring harness between C03 (7) – E04 (1) 6. Disconnection in wiring harness between C03 (14) – E04 (2) 7. Disconnection in wiring harness between C03 (17) – E04 (3) 8. Defective governor motor potentiometer 9. Defective contact of C03, E04 connectors
—	E315	Abnormality (short circuit) in battery relay output system	If excess current flows between C03 (1) and battery relay ★ This occurs only when turning starting switch to OFF and stopping engine
—	E316	Abnormality (step-out) in motor	1. Defective adjustment of rod or scuffing of loose spring
			2. Abnormality in governor motor
			3. Abnormality in governor, pump controller

ACTION TAKEN BY CONTROLLER WHEN ABNORMALITY OCCURS AND PROBLEMS ON MACHINE

TROUBLESHOOTING

Condition when normal (voltage, current, resistance)	Action by controller when abnormality is detected	Problem that appears on machine when there is abnormality																		
<table border="1"> <thead> <tr> <th>C03 (female)</th><th>E04 (male)</th><th>Resistance value</th></tr> </thead> <tbody> <tr> <td>(7) – (14)</td><td>(1) – (2)</td><td>0.25 – 7kΩ</td></tr> <tr> <td>(7) – (17)</td><td>(2) – (3)</td><td>0.25 – 7kΩ</td></tr> <tr> <td>(14) – (17)</td><td>—</td><td>2 – 3kΩ</td></tr> <tr> <td>—</td><td>(1) – (3)</td><td>4 – 6kΩ</td></tr> <tr> <td>Between each pin and chassis</td><td>—</td><td>Min. 1 MΩ</td></tr> </tbody> </table>	C03 (female)	E04 (male)	Resistance value	(7) – (14)	(1) – (2)	0.25 – 7kΩ	(7) – (17)	(2) – (3)	0.25 – 7kΩ	(14) – (17)	—	2 – 3kΩ	—	(1) – (3)	4 – 6kΩ	Between each pin and chassis	—	Min. 1 MΩ	Calculates position of motor and carries out control from value of voltage immediately before abnormality occurred	1. Precision of engine speed control may be reduced. For example: 1) Engine does not rise to high idling speed (a little too low) 2) Engine does not go down to low idling speed (a little too high) 3) Defective engine speed for auto-deceleration or automatic warming-up 4) Engine may not stop ★ The governor motor moves in the direction to stop the engine, but the motor may not move completely to the position to stop the engine. 5) There are cases of hunting
C03 (female)	E04 (male)	Resistance value																		
(7) – (14)	(1) – (2)	0.25 – 7kΩ																		
(7) – (17)	(2) – (3)	0.25 – 7kΩ																		
(14) – (17)	—	2 – 3kΩ																		
—	(1) – (3)	4 – 6kΩ																		
Between each pin and chassis	—	Min. 1 MΩ																		
Between C03 (1) and chassis: 20 – 30 V ★ Holds with the motor in the stop position for 2 – 2.5 sec, returns to the low idling position, then turns the battery relay OFF.	Sets battery relay drive current to 0	Engine does not stop																		
1. Linkage adjustment correct 2. Must move lightly when connector is removed 3. Normal	1. Displays when returning from high idling to low idling ★ Starts again (repeats step-out) 2. In some cases it may not display when returning from partial speed to low idling	Engine speed cannot be controlled (particularly at high idling), so there is hunting																		

JUDGEMENT TABLE FOR GOVERNOR, PUMP GOVERNOR (GOVERNOR CONTROL SYSTEM) AND ENGINE RELATED PARTS

TROUBLESHOOTING

JUDGEMENT TABLE FOR GOVERNOR, PUMP GOVERNOR (GOVERNOR CONTROL SYSTEM) AND ENGINE RELATED PARTS

Failure mode		Governor, pump controller, engine related parts (E3: system)						
		Self-diagnostic display						
		Abnormality in governor, pump controller power source system						
		Abnormality in fuel control dial input value	Abnormality (disconnection) in motor drive system	Abnormality (short circuit) in motor drive system	Abnormality in feedback potentiometer system	Abnormality (short circuit) in battery relay output	Abnormality (step-out) in motor	
User code		E05						
Service code		308	317	318	306	315	316	
1	Engine does not start easily							
2	Engine does not start							
3	Engine speed stays at low idling, and does not follow accelerator; or engine pickup is poor	●	●	●	●	●		
4	Engine stops during operation							
5	Engine rotation is irregular							
	When idling speed is irregular							
	When there is hunting		●	●	●	●		●
6	Lack of output (engine high idling speed is too low)		●			●		
7	Auto-deceleration does not work							
8	Engine does not stop	●		●	●	●	●	
9	Warming-up operation is defective							
10	Exhaust gas is black							
11	Oil consumption is excessive, or exhaust gas is blue							
12	Oil becomes dirty prematurely							
13	Fuel consumption is excessive, or exhaust gas is blue							
14	Oil is mixed in coolant							
15	Engine oil pressure caution lamp lights up							
16	Oil level rises							
17	Coolant temperature rises too high (overheating)							
18	Abnormal noise is generated							
19	There is excessive vibration							
20	Engine speed does not change even when working mode is switched							
Troubleshooting code when service code is displayed		E-1	E-2	E-3	E-4	E-5	E-6	E-7
Troubleshooting code when there is abnormality in monitoring or machine monitor check		—	—	—	—	—	—	—

● : This shows applicable item for service code

※ : This shows item that needs only checking with monitoring


TROUBLESHOOTING

JUDGEMENT TABLE FOR GOVERNOR, PUMP GOVERNOR (GOVERNOR CONTROL SYSTEM) AND ENGINE RELATED PARTS


Checking monitoring, check items								Machine monitor check item	Does starting motor turn?	Troubleshooting code if no service code display is given
Battery relay drive signal	No. 2 throttle command value	Fuel control dial command value	Governor motor potentiometer	Governor motor A phase current	Governor motor B phase current	Coolant temperature voltage	102℃ or above	Is red range displayed?		
Monitoring code							105℃ or above			
35	16	30	31	33	34	41	108			
										S-1
										S-2
		※	※	※	※					S-3
										S-4
										E-9A), S-5
			※							E-9A), S-5
	※	※								E-10, S-6
										E-3・E-4
				※	※					E-11
										E-3・E-4
										S-7
										S-8
										S-9
										S-10
										S-11
										S-12
										S-13
										S-14
										S-15
										S-16
	※									E-3・E-4
E-12	—	—	—	—	—	—	M-14	M-13	M-13	E-8

: This shows item to check with monitoring or machine monitor

ELECTRICAL CIRCUIT DIAGRAM FOR E MODE SYSTEM



BKP00219




BKP00095

- ★ **This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the service code E is not displayed, the problem has been removed.**
- ★ Check that fuse 1 is not blown.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.
- ★ When the starting motor rotates correctly. (If the starting motor also does not rotate, go to E-8.)



E-2 [E308] Abnormality in fuel control dial input value is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the service code E is not displayed, the problem has been removed.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.




- ★ If E306 also occurs at the same time, check the wiring harness below.
 - Wiring harness between C03 (female) (7) – E04 (female) (1) short circuiting with ground, or contact with other wiring harness

Table 1

C03 (female)	E04 (male)	Resistance value
(7) – (4)	(1) – (2)	0.25 – 7kΩ
(4) – (17)	(2) – (3)	0.25 – 7kΩ
(7) – (17)	—	2 – 3kΩ
—	(1) – (3)	4 – 6kΩ
Between each pin and chassis	—	Min. 1 MΩ

E-2 Related electric circuit diagram



BKP00097

E-3 [E317] Abnormality (disconnection) in motor drive system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adaptor, or when removing the T-adaptor and returning the connector to its original position, if the service code E is not displayed, the problem has been removed.
- ★ During operation, if there is
 - 1) a simultaneous disconnection in A phase and B phase:
 - 1) the engine will run at low idling
 - 2) the engine will not stop
 - 2) a disconnection in either A phase or B phase, the engine speed will remain the same as before the abnormality occurred
- ★ If the problem occurs when the engine is stopped,
 - 1) the engine can be started, but it stays in low idling, or 2) it will not stop after it is started.
- ⚠ Check with the engine stopped (push the fuel control lever of the fuel injection pump to the NO INJECTION position).
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.





Table 1

E05 (male)	C02 (female)	Resistance value
(1) – (2)	(2) – (3)	2.5 – 7.5kΩ
(3) – (4)	(4) – (5)	2.5 – 7.5kΩ

E-3 Related electric circuit diagram



BKP00098

E-4 [E318] Abnormality (short circuit) in motor drive system is displayed


- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the service code E is not displayed, the problem has been removed.
- ★ If the abnormality occurs during operation, because of the force of the spring,
 - 1) the engine will run at low idling
 - 2) the engine will not stop
- ★ If the problem occurs when the engine is stopped,
 - 1) the engine can be started, but it stays in low idling, or 2) it will not stop after it is started.
- ⚠ Check with the engine stopped (push the fuel control lever of the fuel injection pump to the NO INJECTION position).
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

		Cause	Remedy
Is resistance between each pin of E05 (male), or between each pin and chassis as shown in Table 1? 1 YES • Turn starting switch OFF. • Disconnect E05.	Is resistance between each pin of C02 (female), or between each pin and chassis as shown in Table 1? 2 YES	Defective governor, pump controller	Replace
	NO	Defective wiring harness in system with defective resistance	Replace
	NO	Defective governor motor	Replace

Table 1

E05 (male)	C02 (female)	Resistance value
(1) – (2)	(2) – (3)	2.5 – 7.5kΩ
(3) – (4)	(4) – (5)	2.5 – 7.5kΩ
(1) – (3)	(2) – (4)	Min. 1 MΩ
(1) – (4)	(2) – (5)	Min. 1 MΩ
Between chassis and pins (1)(2)(3)(4)	Between chassis and pins (2)(3)(4)(5)	Min. 1 MΩ

E-4 Related electric circuit diagram



BKP00098

E-5 [E306] Abnormality in feedback potentiometer system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the service code E is not displayed, the problem has been removed.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.


		Cause	Remedy
Is resistance between E06 (male) (1)-(2), (2)-(3) as shown in Table 1? YES 1 Is resistance between each pin of C03 (female) (4) (7) (14), or between each pin and chassis as shown in Table 1? 2 YES NO • Turn starting switch OFF. • Disconnect C03. NO • Turn starting switch OFF. • Disconnect E04.		Defective governor, pump controller	Replace
		Defective wiring harness in system with defective resistance	Replace
		Defective governor motor	Replace

- ★ If E308 also occurs at the same time, check the wiring harness below.
 - Wiring harness between C03 (female) (7) – X07 (6) – E06 (female) (1) short circuiting with ground, or contact with other wiring harness

Table 1

C03 (female)	E04 (male)	Resistance value
(7) – (4)	(1) – (2)	0.25 – 7kΩ
(14) – (17)	(2) – (3)	0.25 – 7kΩ
(7) – (17)	—	2 – 3kΩ
—	(1) – (3)	4 – 6kΩ
Between each pin and chassis	—	Min. 1 MΩ

E-5 Related electric circuit diagram



BKP00097

E-6 [E315] Abnormality (short circuit) in battery relay output system is displayed


★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the service code E is not displayed, the problem has been removed.

⚠ Check with the engine stopped (push the fuel control lever of the fuel injection pump to the NO INJECTION position).

- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.
- ★ This only occurs when the engine is stopped and the starting switch is turned OFF.


		Cause	Remedy
1 Is resistance between C01 (female) (1) and chassis normal? • Between C01 (female) (1) and chassis: Approx. 100Ω • Turn starting switch OFF. • Disconnect C01.	YES	Defective governor, pump controller	Replace
	NO	Defective battery relay	Replace
2 Is resistance between C01 (female) (1) and battery relay terminal BR, and between wiring harness and chassis normal? • Between C01 (female) (1) and battery relay BR: Max 1 Ω • Between wiring harness and chassis: Min. 1 MΩ. • Turn starting switch OFF. • Disconnect C01 and battery relay BR.	YES	1) Contact between other wiring harness and wiring harness between C01 (female) (1)-H02 (9)-battery relay BR.	Replace
	NO	2) When light is connected	Replace

E-6 Related electric circuit diagram




E-7 [E316] Abnormality (step-out) in motor is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the service code E is not displayed, the problem has been removed.
- ★ If any other service code [E306] – [E318] has occurred at the same time, start troubleshooting from the code except code[E316].
- ★ Check that the fuse is normal.
- ★ Read the precautions given in TESTING AND ADJUSTING, "Adjusting travel of governor motor lever" before carrying out the troubleshooting.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.




E-8 Engine does not start

- ★ When starting motor does not rotate.
- ★ Check that fuse No. 14 is not blown before starting troubleshooting.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.



E-8 Related electric circuit diagram



	Cause	Remedy
	Defective starting motor	Replace
	Defective contact of wiring harness between battery (+)-battery relay B-battery relay M-starting motor terminal B (including battery relay)	Replace
	Defective contact, or disconnection in wiring harness between starting switch terminal C-X07 (10)-E08 (1) -M2 (1)-starting motor terminal S	Replace
	Defective starting switch (between terminals B and C)	Replace
	Defective battery relay	Replace
	Defective contact of wiring harness between battery relay terminal E and revolving frame ground connection terminal	Replace
	Defective contact, or disconnection in wiring harness between starting switch terminal BR-D13-battery relay terminal BR	Replace
	Defective starting switch (between B and BR)	Replace
	Defective contact, or disconnection in wiring harness between battery terminal (+)-M11-H05 (6)-X07 (1)-starting switch terminal B (including fusible link)	Replace
	Lack of battery capacity	Charge or replace

E-9 Engine speed is irregular

- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

a) Idling speed is irregular





Table 1

Controller model code	
03	300
BKP00210	

- ★ The diagram shows monitoring code 03.

	Cause	Remedy
	See N mode	
	Defective adjustment of linkage	Adjust
	Defective injection pump	See S mode
	Defective governor motor	Replace
	Defective contact of wiring harness between starting switch ACC-X07 (17)-C03 (femal) (8), or defective starting switch	Repair or replace
	See E-5	—
	See E-2	—
	See C-14	—

E-9 Related electric circuit diagram



BKP00203

b) There is hunting





Table 1

Controller model code	
03	300
BKP00210	

★ The diagram shows monitoring code 03.

	Cause	Remedy
	See N mode	—
	Defective adjustment of linkage	Adjust
	Defective injection pump	See S mode
	Defective governor motor	Replace
	Defective contact of wiring harness between starting switch ACC – X07 (17) – C03 (female) (8), or defective starting switch	Repair or replace
	See E-5	—
	See E-2	—
	See C-14	—

E-9 Related electric circuit diagram



E-10 Lack of output (engine high idling speed is too low)

- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.





Table 1

Controller model code	
03	300
BKP00210	

- ★ The diagram shows monitoring code 03.

		Cause	Remedy
Starting motor signal 7 YES Is voltage between C03 (8) and chassis normal and stable? • During operation: 20 – 30V NO		See N mode	—
		Defective injection pump	See S mode
		Defective governor motor	Replace
		Defective contact of wiring harness between starting switch ACC – X07 (17) – C03 (female) (8), or defective starting switch	Repair or replace
		See E-5	—
		See E-2	—
		Defective adjustment of governor motor linkage	Adjust
		See S mode	—
		See C-14	—

E-9 Related electric circuit diagram



E-11 Engine does not stop

⚠ Check with the engine stopped (push the fuel control lever of the fuel injection pump to the NO INJECTION position).

- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.
- ★ Read the precautions given in TESTING AND ADJUSTING, "Adjusting travel of governor motor lever" before carrying out the troubleshooting.





Table 1

Controller model code	
03	300
BKP00210	

- ★ The diagram shows monitoring code 03.


Table 2



Note 1: When the starting switch is ON, the controller end is OFF, but a voltage of approx. 20 – 30V is always flowing from starting switch BR, so if the voltage is measured at C01 (1), there is a voltage of 20 – 30V.

	Cause	Remedy
	Defective injection pump	See S mode
	Defective adjustment of linkage	Adjust
	Defective governor motor	Replace
	See E-5	—
	Defective governor, pump controller	Replace
	Contact with 24V wiring harness of wiring harness between starting switch ACC – X07 (17) – C03 (female) (8), or defective starting switch	Replace
	See C-14	—

E-11 Related electric circuit diagram



E-12 Defective operation of battery relay system (engine does not stop)

- ★ This only occurs when the engine is stopped and the starting switch is turned OFF.
- ⚠ Check with the engine stopped (push the fuel control lever of the fuel injection pump to the NO INJECTION position).
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.





Table 1



Note 1: When the starting switch is ON, the controller end is OFF, but a voltage of approx. 20 – 30V is always flowing from starting switch BR, so if the voltage is measured at C01 (1), there is a voltage of 20 – 30V.

①

Troubleshooting Logic Section Contents

Section S - Troubleshooting	20-302
Procedures and Techniques	20-302
Troubleshooting Symptoms Charts	20-303
Alternator Not Charging or Insufficient Charging	20-303
Compression Knock	20-304
Connecting Rod Bearing Noise (Refer to Engine Noise Excessive - Connecting Rod Symptom Chart)	
Coolant Contaminated	20-305
Coolant Loss	20-306
Coolant Temperature Above Normal - Gradual Overheat	20-308
Coolant Temperature Above Normal - Sudden Overheat	20-311
Coolant temperature Below Normal	20-313
Driveability - General Information	
Driveability/Low Power - Customer Complaint Form	
Driveability/Low Power/Excessive Fuel Consumption - Checklist	
Engine Crankcase Gases (Blowby) - Excessive	20-314
Engine Cranks, But Will Not Start - No Smoke from Exhaust	20-315
Engine Difficult to Start or Will Not Start - Exhaust Smoke Present	20-317
Engine Idle Rough, Warm Engine	20-319
Engine Misfiring	20-321
Engine Noise Diagnostic Procedures - General Information	
Engine Noise Excessive	20-323
Engine Power Output Low	20-326
Engine Starts But Will Not Keep Running	20-327
Engine Surges at Idle	20-328
Engine Vibration - Excessive	20-329
Engine Will Not Crank or Cranks Slowly	20-330
Engine Will Not Reach Rated Speed When Loaded	20-331
Engine Will Not Shut Off	20-333
Exhaust Black Smoke Excessive Under Loaded	20-334
Exhaust White Smoke Excessive (Warm Engine)	20-336
Fuel Consumption Excessive	20-337
Fuel or Oil Leaking from Exhaust Manifold	20-338
Lubricating Oil Contaminated	20-339
Lubricating Oil Consumption Excessive	20-340
Lubricating Oil Pressure Low	20-342
Lubricating Oil Pressure High	20-344

Section S - Troubleshooting

Procedures and Techniques

A thorough analysis of the customer's complaint is the key to successful troubleshooting. The more information known about a complaint, the faster and easier the problem can be solved.

The "Troubleshooting Symptoms Charts" beginning on Page 20-303 are organized so that a problem can be located and corrected by doing the easiest and most logical things first. Completed all steps in the sequence shown from top to bottom.

It is not possible to include all the solutions to problems that can occur; however, these charts should stimulate a thought process that will lead to the cause and correction of the problem.

Follow these basic troubleshooting steps:

- Get all the facts concerning the complaint.
- Analyze the problem thoroughly.
- Relate the symptoms to the basic engine systems and components.
- Consider any recent maintenance or repair action that may relate to the problem.
- Double-check before beginning any disassembly.
- Solve the problem by using the logic charts and doing the easiest things first.
- Determine the cause of the problem and make a thorough repair.
- After repairs have been made, operate the engine to make sure the cause of the problem has been corrected.


Troubleshooting Symptoms Charts

Use the charts on the following pages of this section to aid in diagnosing specific engine problems. Read each row of blocks from top to bottom. Follow the arrows through the chart to identify the corrective action.

TROUBLESHOOTING

METHOD OF USING TROUBLESHOOTING CHARTS


Alternator Not Charging or insufficient Charging



TROUBLESHOOTING

METHOD OF USING TROUBLESHOOTING CHARTS


Compression Knock



TROUBLESHOOTING

METHOD OF USING TROUBLESHOOTING CHARTS


Coolant Contaminated



TROUBLESHOOTING

METHOD OF USING TROUBLESHOOTING CHARTS

Coolant Loos



(Continued)


Coolant Loss (Continued)

Cause	Corrections
Aftercooler Leaking	Check/replace the aftercooler. Check for coolant in the intake manifold and in the oil.
OK ↓	
Lubricating Oil Cooler Leaking	Check/replace the oil cooler. Check for coolant in the oil.
OK ↓	
Cylinder Head Gasket Leaking	Check/replace the head gasket. Check liner protrusion.
OK ↓	
Cylinder Head Cracked, Porous, or Expansion Plugs Leaking	Check/replace the head.
OK ↓	
Liner O-Ring Leaking	Remove the oil pan and check liner o-rings for leakage.
OK ↓	
Cylinder Block Coolant Passages Leaking	Check/replace the cylinder block.


TROUBLESHOOTING

METHOD OF USING TROUBLESHOOTING CHARTS

Coolant Temperature Above Normal - Gradual Overheat




Coolant Temperature Above Normal - Gradual Overheat (Continued)



TROUBLESHOOTING

METHOD OF USING TROUBLESHOOTING CHARTS


Coolant Temperature Above Normal - Gradual Overheat (Continued)



TROUBLESHOOTING

METHOD OF USING TROUBLESHOOTING CHARTS


Coolant Temperature Above Normal - Sudden Overheat




TROUBLESHOOTING

METHOD OF USING TROUBLESHOOTING CHARTS


Coolant Temperature Above Normal - Sudden Overheat (Continued)



Coolant Temperature Below Normal




Engine Crankcase Gases (Blowby) - Excessive



TROUBLESHOOTING

METHOD OF USING TROUBLESHOOTING CHARTS


Engine Cranks, But Will Not Start - No Smoke from Exhaust




TROUBLESHOOTING

METHOD OF USING TROUBLESHOOTING CHARTS

Engine Cranks, But Will Not Start - No Smoke From Exhaust (Continued)



Engine Difficult to Start or Will Not Start - Exhaust Smoke Present



TROUBLESHOOTING

METHOD OF USING TROUBLESHOOTING CHARTS


Engine Difficult to Start or Will Not Start - Exhaust Smoke Present (Continued)

Cause	Corrections
Fuel Supply Restricted	Clean or replace pre-filters and screens and check fuel lines for restrictions.
OK ↓	
Intake Air System Restricted	Check intake air system for restrictions.
OK ↓	
Fuel Contaminated	Verify by operating engine from a temporary supply tank.
OK ↓	
Injection Pump Timing Incorrect	Check to dead center (TDC). Check injection pump timing. Check/time the fuel injection pump using the spill port timing if equipment is available.
OK ↓	
Injectors Worn or Malfunctioning	Check/replace injectors.
OK ↓	
Valves Incorrectly Adjusted	Adjust valves.
OK ↓	
Engine Compression Low	Perform compression check to identify problem
OK ↓	
Injection Pump Worn or Malfunctioning	Remove the fuel injection pump. Have calibration checked.

TROUBLESHOOTING


METHOD OF USING TROUBLESHOOTING CHARTS

Engine Idle Rough, Warm Engine



(Continued)


Engine Idle Rough, Warm Engine (Continued)



TROUBLESHOOTING


METHOD OF USING TROUBLESHOOTING CHARTS

Engine Misfiring



(Continued)


Engine Misfiring (Continued)



TROUBLESHOOTING

METHOD OF USING TROUBLESHOOTING CHARTS

Engine Power Output Low




(Continued)

TROUBLESHOOTING

METHOD OF USING TROUBLESHOOTING CHARTS

Engine Power Output Low (Continued)



TROUBLESHOOTING

METHOD OF USING TROUBLESHOOTING CHARTS


Engine Power Output Low (Continued)

Cause	Corrections
Air Leak Between Turbocharger and Intake Manifold	Check and correct leaks in the air crossover tube, charge air cooler connections, hoses, or through holes in the manifold cover.
OK	
Exhaust Leak Between Turbocharger and Exhaust Manifold	Check and correct leaks. Check for a cracked exhaust manifold.
OK	
Injector Nozzles Worn or Malfunctioning	Check/replace injectors.
OK	
Turbocharger Worn or Malfunctioning	Check for correct boost pressure. Replace turbocharger if low.
OK	
Valves Incorrectly Adjust	Adjust valves. Inspect push rods, springs, etc.
OK	
Injection Pump Timing Incorrect	Check injection pump timing.
OK	
Injection Pump Worn or Malfunctioning	Remove the fuel injection pump. Have calibration checked.
OK	
Engine Compression Low	Bleed the fuel system and check for suction leaks.

TROUBLESHOOTING

METHOD OF USING TROUBLESHOOTING CHARTS


Engine Noise Excessive



TROUBLESHOOTING

METHOD OF USING TROUBLESHOOTING CHARTS


Engine Starts But Will Not Keep Running



TROUBLESHOOTING

METHOD OF USING TROUBLESHOOTING CHARTS


Engine Surges at Idle



TROUBLESHOOTING

METHOD OF USING TROUBLESHOOTING CHARTS

Engine Vibration Excessive



TROUBLESHOOTING

METHOD OF USING TROUBLESHOOTING CHARTS


Engine Will Not Crank or Cranks Slowly

Cause	Corrections
Starting Circuit Connections Loose or Corroded	Clean and tighten connections.
OK ↓	
Battery Charge Low	Check electrolyte level and specific gravity, charge as required.
OK ↓	
No Voltage to Starter Solenoid	Check voltage to solenoid.
OK ↓	
Solenoid or Starting Motor Malfunction	Replace starting motor.
OK ↓	
Crankshaft Rotation Restricted	Rotate the crankshaft to check for rotational resistance.
OK ↓	
Starting Motor Operating But Not Cranking the Engine	Remove the starting motor and check for broken teeth on the flywheel or broken starting motor spring.

TROUBLESHOOTING

METHOD OF USING TROUBLESHOOTING CHARTS


Engine Will Not Reach Rated Speed When Loaded



TROUBLESHOOTING

METHOD OF USING TROUBLESHOOTING CHARTS


Engine Will Not Reach Rated Speed When Loaded (Continued)



TROUBLESHOOTING

METHOD OF USING TROUBLESHOOTING CHARTS


Engine Will Not Shut Off



TROUBLESHOOTING

METHOD OF USING TROUBLESHOOTING CHARTS

Exhaust Black Smoke Excessive Under Load



(Continued)

TROUBLESHOOTING

METHOD OF USING TROUBLESHOOTING CHARTS

Exhaust Black Smoke Excessive Under Load (Continued)

Cause	Corrections
Injector Nozzle Malfunctioning	Remove and have nozzles tested. Replace injectors if necessary.
OK ↓	
Engine Running Too Cold (Below 60°C {140°F})	Check thermostat and cooling system.
OK ↓	
Injection Pump Timing Incorrect	Check and adjust injection pump timing.
OK ↓	
AFC Malfunction or Injection Pump Overfueled	Remove and test injection pump
OK ↓	
Piston Rings Not Sealing	Perform a compression check. Repair as required.


TROUBLESHOOTING

METHOD OF USING TROUBLESHOOTING CHARTS

Exhaust White Smoke Excessive (Warm Engine)

Cause	Corrections
Improper Starting Procedure	Verify proper starting procedure. Refer to Starting Instructions in the Operation and Maintenance Manual.
OK ↓	
Coolant Temperature Too Low	Refer to Troubleshooting Logic Chart for "Coolant Temperature Below Normal".
OK ↓	
Intake Air Temperature Too Low	Refer to vehicle operation manual for shutter operation. Check intake air heater operation. (if required).
OK ↓	
Fuel Quality Poor	Verify by operating engine from a temporary tank with good quality fuel. Clean and flush the fuel supply tanks.
OK ↓	
Injection Pump Timing Incorrectly Asjusted	Check top dead center (TDC). Check/adjust injection pump timing. Check/time the fuelinjection pump using the spill port timing if equipmnet is available.
OK ↓	
Injectors Malfunctioning	Replace injectors.
OK ↓	
Coolant Leaking Into Combustion Chamber	Refer to Troubleshooting Logic Chart for "Coolant Loss".
OK ↓	
Injection Pump Malfunctioning	Remove fuel injectiion pump. Have calibration checked. Check for debris in delivery valves.


Fuel Consumption Excessive



TROUBLESHOOTING

METHOD OF USING TROUBLESHOOTING CHARTS


Fuel or Oil Leaking from Exhaust Manifold



TROUBLESHOOTING

METHOD OF USING TROUBLESHOOTING CHARTS


Lubricating Oil Contaminated




TROUBLESHOOTING

METHOD OF USING TROUBLESHOOTING CHARTS

Lubricating Oil Consumption Excessive




Lubricating Oil Consumption Excessive (Cotinued)



TROUBLESHOOTING

METHOD OF USING TROUBLESHOOTING CHARTS

Lubricating Oil Pressure Low



TROUBLESHOOTING

METHOD OF USING TROUBLESHOOTING CHARTS


Lubricating Oil Pressure Low (Continued)

Cause	Corrections
Pipe Plug Loose or Missing	Check for external leak at rear of cylinder head, along fuel pump side of block, oil cooler cover and gear housing.
OK ↓	
Oil Filter Plugged	Change oil and replace filter.
OK ↓	
Oil Cooler Plugged	Check and replace oil cooler.
OK ↓	
Cup Plug Internal Leak	Check oil rifle cup plugs, cup plug in front and rear face of block.
OK ↓	
Suction Tube Loose or Gasket Leaking	Replace gasket and tighten tube.
OK ↓	
Lubricating Oil Pump Worn	Check/replace oil pump.
OK ↓	
Main Bearing Cap Loose	Check/install new bearing(s) Tighten cap.
OK ↓	
Connecting Rod or Main Bearings Worn	Check/replace bearings. Also check/replace piston cooling nozzles.

TROUBLESHOOTING

METHOD OF USING TROUBLESHOOTING CHARTS

Lubricating Oil Pressure High



Engine Noise Diagnostic Procedures General Information

NOTE: When diagnosing engine noise problems, make sure that noises caused by accessories, such as the air compressor and power takeoff, are **not** mistaken for engine noises. Remove the accessory drive belts to eliminate noise caused by these units. Noise will also travel to other metal parts not related to the problem. The use of a stethoscope can help locate an engine noise.

Engine noises heard at the crankshaft speed, engine RPM, are noises related to the crankshaft, rods, pistons, and piston pins. Noises heard at the camshaft speed, one-half of the engine RPM, are related to the valve train. A hand-held digital tachometer can help to determine if the noise is related to components operating at the crankshaft or camshaft speed.

There is **not** a definite rule or test that will positively determine the source of a noise complaint.

Engine driven components and accessories, such as gear-driven fan clutches, hydraulic pumps, belt-driven alternators, air-conditioning compressors, and turbochargers can contribute to engine noise. Use the following information as a guide to diagnosing engine noise.

Main Bearing Noise (Refer to Engine Noise Excessive - Main Bearing Symptom Chart)

The noise caused by a loose main bearing is a loud dull knock heard when the engine is pulling a load. If all main bearings are loose, a loud clatter will be heard. The knock is heard regularly every other revolution. The noise is the loudest when the engine is lugging or under heavy load. The knock is duller than a connecting rod noise. Low oil pressure can also accompany this condition.

If the bearing is **not** loose enough to produce a knock by itself, the bearing can knock if the oil is too thin, or if there is no oil at the bearing.

An irregular noise can indicate worn crankshaft thrust bearings.

An intermittent sharp knock indicates excessive crankshaft end clearance. Repeated clutch disengagements can cause a change in the noise.

Connecting Rod Bearing Noise (Refer to Engine Noise Excessive - Connecting Rod Symptom Chart)

Connecting rods with excessive clearance knock at all engine speeds, and under both idle and load conditions. When the bearings begin to become loose, the noise can be confused with piston slap or loose piston pins. The noise increases in volume with engine speed. Low oil pressure can also accompany this condition.

Piston Noise (Refer to Engine Noise Excessive - Piston Symptom Chart)

It is difficult to tell the difference between piston pin, connecting rod, and piston noise. A loose piston pin causes a loud double knock which is usually heard when the engine is idling. When the injector to this cylinder is held down, a noticeable change will be heard in the sound of the knocking noise. However, on some engines the knock becomes more noticeable when the vehicle is operated on the road at a steady speed condition.

TROUBLESHOOTING OF GOVERNOR, PUMP CONTROLLER (PUMP CONTROL SYSTEM) (C MODE)

Points to remember when carrying out troubleshooting of pump controller system	20-352
Action taken by controller and condition of machine when abnormality occurs	20-354
Judgement table for governor, pump controller and hydraulic related parts	20-360
Electrical circuit diagram of C mode systems	20-362
C- 1 Abnormality in controller power source (controller LED is OFF)	20-364
C- 2 [E232] Short circuit in front pump TVC solenoid system is displayed	20-365
C- 3 [E233] Disconnection in front pump TVC solenoid system is displayed	20-367
C- 4 [E236] Short circuit in rear pump TVC solenoid system is displayed	20-369
C- 5 [E237] Disconnection in rear pump TVC solenoid system is displayed	20-371
C- 6 [E202] Short circuit in LS select solenoid system is displayed	20-373
C- 7 [E212] Disconnection in LS select solenoid system is displayed	20-374
C- 8 [E203] Short circuit in swing holding brake solenoid system is displayed	20-375
C- 9 [E213] Disconnection in swing holding brake solenoid system is displayed	20-377
C-10 [E204] Short circuit in pump merge/divider solenoid system is displayed	20-379
C-11 [E214] Disconnection in pump merge/divider solenoid system is displayed	20-380
C-12 [E206] Short circuit in travel speed solenoid system is displayed	20-381
C-13 [E216] Disconnection in travel speed solenoid system is displayed	20-382
C-14 [E217] Model selection input error is displayed	20-383
C-15 [E222] Short circuit in LS-EPC solenoid system is displayed	20-385
C-16 [E223] Disconnection in LS-EPC solenoid system is displayed	20-386
C-17 [E224] Abnormality in front pump pressure sensor system is displayed	20-387
C-18 [E225] Abnormality in rear pump pressure sensor system is displayed	20-388
C-19 [E226] Abnormality in pressure sensor power source is displayed	20-389
C-20 [E227] Abnormality in engine speed sensor system is displayed	20-390
C-21 Abnormality in machine 2-stage relief solenoid system (no service code displayed)	20-391

POINTS TO REMEMBER WHEN TROUBLESHOOTING PUMP CONTROLLER SYSTEM

1. Points to remember if abnormality returns to normal by itself

In the following two cases, there is a high probability that the same problem will occur again, so it is desirable to follow up this problem carefully.

- 1) If any abnormality returns to normal by itself, or
- 2) If the connector is disconnected and the T-adapter is inserted, or if the T-adapter is removed and the connector is returned to its original position when carrying out troubleshooting of the failure, and the service code is no longer displayed, or if the monitor display returns to normal.
- 3) After completing troubleshooting, always erase the user code from memory.

2. User code memory retention function

When displaying the abnormality code in memory and carrying out troubleshooting, note down the content of the display, then erase the display. After trying to re-enact the problem, carry out troubleshooting according to the failure code that is displayed.

(There are cases where mistaken operation or abnormalities that occur when the connector is disconnected are recorded by the memory retention function. Erasing the data in this way saves any wasted work.)

ACTION TAKEN BY CONTROLLER WHEN ABNORMALITY
OCCURS AND PROBLEMS ON MACHINE

User code	Service code	Abnormal system	Nature of abnormality
E02	E232	Short circuit in front pump TVC solenoid system	1. Short circuit with ground, short circuit inside front pump TVC solenoid 2. Short circuit with power source, short circuit with ground in wiring harness between controller C02 (8) and TVC solenoid C13 (1) ((+) side) 3. Short circuit with power source in wiring harness between controller C02 (18) and TVC solenoid C13 (2) ((-) side) 4. Defective governor, pump controller
	E233	Disconnection in front pump TVC solenoid system	1. Disconnection, defective contact inside front pump TVC solenoid 2. Disconnection, defective contact in wiring harness between controller C02 (8) and TVC solenoid C13 (1) ((+) side) 3. Disconnection, defective contact, short circuit with ground in wiring harness between controller C02 (18) and TVC solenoid C13 (2) ((-) side) 4. Defective governor, pump controller
	E236	Short circuit in rear pump TVC solenoid system	1. Short circuit with ground, short circuit inside rear pump TVC solenoid 2. Short circuit with power source, short circuit with ground in wiring harness between controller C02 (9) and TVC solenoid C04 (1) ((+) side) 3. Short circuit with power source in wiring harness between controller C02 (19) and TVC solenoid C04 (2) ((-) side) 4. Defective governor, pump controller
	E237	Disconnection in rear pump TVC solenoid system	1. Disconnection, defective contact inside rear pump TVC solenoid 2. Disconnection, defective contact in wiring harness between controller C02 (9) and TVC solenoid C04 (1) ((+) side) 3. Disconnection, defective contact, short circuit with ground in wiring harness between controller C02 (19) and TVC solenoid C04 (2) ((-) side) 4. Defective governor, pump controller
E03	E203	Short circuit in swing holding brake solenoid system	1. Short circuit with ground, short circuit inside swing holding brake solenoid 2. Short circuit with ground in wiring harness between controller C01 (3) and solenoid V04 (2) ((+) side) 3. Defective governor, pump controller
	E213	Disconnection in swing holding brake solenoid system	1. Disconnection, defective contact inside swing holding brake solenoid 2. Disconnection, defective contact, short circuit with power source in wiring harness between controller C01 (3) and solenoid V04 (2) ((+) side) 3. Disconnection, defective contact in wiring harness between solenoid V04 (1) and chassis ground ((-) side) 4. Defective governor, pump controller

ACTION TAKEN BY CONTROLLER WHEN ABNORMALITY OCCURS AND PROBLEMS ON MACHINE

TROUBLESHOOTING

Condition when normal (voltage, current, resistance)	Action by controller when abnormality is detected	Problem that appears on machine when there is abnormality
Resistance of solenoid: 10 – 22 Ω	- Makes output to TVC solenoid 0. - Displays user code E02 on monitor panel. ★ If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)	- No current flows to the front pump TVC solenoid. Therefore, when the load is large, there is a big drop in the engine speed which may result in the engine stalling. - The swing acceleration is poor
- Resistance of solenoid: 10 – 22 Ω - Current: 1000 mA (H/O mode, auto-deceleration ON, levers at neutral, fuel control dial at MAX.)	- The current stops flowing to the TVC solenoid, so no particular action is taken. - If there is a short circuit with the ground at the (-) end, the current (min. 1A) continues to flow to the TVC solenoid. - It displays user code E02 on the monitor panel. ★ If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)	- In the case of 1, it is the same as E232. - In the case of 2, the current (min. 1A) continues to flow to the front pump TVC solenoid, so the output of the front pump TVC valve increases and the overall speed becomes slower.
Resistance of solenoid: 10 – 22 Ω	- Makes output to TVC solenoid 0. - Displays user code E02 on monitor panel. ★ If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)	Same as E232 (but for the rear pump)
- Resistance of solenoid: 10 – 22 Ω - Current: 1000 mA (H/O mode, auto-deceleration ON, levers at neutral, fuel control dial at MAX.)	- The current stops flowing to the TVC solenoid, so no particular action is taken. - If there is a short circuit with the ground at the (-) end, the current (min. 1A) continues to flow to the TVC solenoid. - It displays user code E02 on the monitor panel. ★ If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)	Same as E233 (but for the rear pump)
Resistance of solenoid: 20 – 60 Ω	- Makes output to TVC solenoid 0. - Displays user code E03 on monitor panel. ★ If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)	When the swing is operated, the motor brake is not released, so the upper structure does not swing.
Resistance of solenoid: 20 – 60 Ω	- The current stops flowing to the solenoid, so no particular action is taken. - Displays user code E03 on monitor panel. ★ If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)	Same as display for E203

ACTION TAKEN BY CONTROLLER WHEN ABNORMALITY OCCURS AND PROBLEMS ON MACHINE

TROUBLESHOOTING

User code	Service code	Abnormal system	Nature of abnormality
—	E202	Short circuit in LS select solenoid system	1. Short circuit with ground, short circuit inside LS select solenoid 2. Short circuit with ground in wiring harness between controller C01 (8) and solenoid V02 (2) ((+) side) 3. Defective governor, pump controller
—	E204	Short circuit in pump merge/divider solenoid system	1. Short circuit with ground, short circuit inside pump merge/divider solenoid 2. Short circuit with ground in wiring harness between controller C01 (2) and solenoid V03 (2) ((+) side) 3. Defective governor, pump controller
—	E206	Short circuit in travel speed solenoid system	1. Short circuit with ground, short circuit inside travel speed solenoid 2. Short circuit with ground in wiring harness between controller C01 (9) and solenoid V06 (2) ((+) side) 3. Defective governor, pump controller
—	E212	Disconnection in LS select solenoid system	1. Disconnection, defective contact inside LS select solenoid 2. Disconnection, defective contact, short circuit with power source in wiring harness between controller C01 (9) and solenoid V02 (2) ((+) side) 3. Disconnection, defective contact in wiring harness between solenoid V02 (1) and chassis ground ((-) side) 4. Defective governor, pump controller
—	E214	Disconnection in pump merge/divider solenoid system	1. Disconnection, defective contact inside pump merge/divider solenoid 2. Disconnection, defective contact, short circuit with power source in wiring harness between controller C01 (2) and solenoid V03 (2) ((+) side) 3. Disconnection, defective contact in wiring harness between solenoid V03 (2) and chassis ground ((-) side) 4. Defective governor, pump controller
—	E216	Disconnection in travel speed solenoid system	1. Disconnection, defective contact inside travel speed solenoid 2. Disconnection, defective contact, short circuit with power source in wiring harness between controller C01 (9) and solenoid V06 (2) ((+) side) 3. Disconnection, defective contact in wiring harness between solenoid V06 (1) and chassis ground ((-) side) 4. Defective governor, pump controller
—	E217	Model selection input error	1. Disconnection, defective contact, short circuit with ground in model selection wiring harness C17(5) (6) (7) (13) (14) 2. Defective governor, pump controller

TROUBLESHOOTING**ACTION TAKEN BY CONTROLLER WHEN ABNORMALITY OCCURS AND PROBLEMS ON MACHINE**

Condition when normal (voltage, current, resistance)	Action by controller when abnormality is detected	Problem that appears on machine when there is abnormality
Resistance of solenoid: 20 – 60 Ω	1. Makes output to solenoid 0. ★ If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)	1. With swing + boom RAISE, the boom is slow. 2. With swing + arm IN, the arm IN movement is slow. 3. With swing + arm OUT, the arm OUT movement is slow. 4. With swing + travel, there is a big drop in the travel speed.
Resistance of solenoid: 20 – 60 Ω	1. Makes output to solenoid 0. ★ If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)	The pump merge/divider valve continues to merge the oil flow. 1. In the L/O and F/O modes, the work equipment and swing speeds become faster. 2. The steering is difficult to turn.
Resistance of solenoid: 20 – 60 Ω	1. Makes output to solenoid 0. ★ If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)	Even if the travel speed is switched, the travel speed does not change (remains at Lo)
Resistance of solenoid: 20 – 60 Ω	1. The current stops flowing to the solenoid, so no particular action is taken. ★ If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)	Same content as display for E202
Resistance of solenoid: 20 – 60 Ω	1. The current stops flowing to the solenoid, so no particular action is taken. ★ If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)	Same content as display for E204
Resistance of solenoid: 20 – 60 Ω	1. The current stops flowing to the solenoid, so no particular action is taken. ★ If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)	Same content as display for E206
Between C17 (6), (13) and chassis: Max. 1 Ω Between C17 (5),(7),(14) and chassis: Min. 1 M Ω	Detects abnormality in input 1) Retains data when starting switch is ON 2) Functions as PC100 when non-set conditions are input	1. Engine stalls, or 2. Work equipment, swing, travel speeds are all slow, and there is no power

ACTION TAKEN BY CONTROLLER WHEN ABNORMALITY OCCURS AND PROBLEMS ON MACHINE

TROUBLESHOOTING

User code	Service code	Abnormal system	Nature of abnormality
—	E218	Network response overtime error	1. Disconnection, short circuit, short circuit with ground in network wiring harness 2. Abnormality in governor, pump controller 3. Abnormality in monitor
—	E222	Short circuit in LS-EPC solenoid system	1. Short circuit with ground, short circuit inside LS-EPC solenoid 2. Short circuit with power source, short circuit with ground in wiring harness between controller C02 (7) and solenoid C10 (1) ((+) side) 3. Short circuit with power source in wiring harness between controller C02 (17) and solenoid C10 (2) ((-) side) 4. Defective governor, pump controller
—	E223	Disconnection in LS-EPC solenoid system	1. Disconnection, defective contact inside LS-EPC solenoid 2. Disconnection, defective contact in wiring harness between controller C02 (7) and solenoid C10 (1) ((+) side) 3. Disconnection, defective contact, short circuit with ground in wiring harness between controller C02 (17) and solenoid C10 (2) ((-) side) 4. Defective governor, pump controller
—	E224	Abnormality in front pump pressure sensor system	1. Disconnection, defective contact, short circuit, short circuit with ground inside front pump pressure sensor 2. Disconnection, defective contact, short circuit in wiring harness between controller C03 (6) and pressure sensor C08 (2) ((+) side) and between C03 (16) and C08 (1) ((-) side) 3. Disconnection, defective contact, short circuit with power source, short circuit with ground in wiring harness between controller C03 (3) and pressure sensor C08 (3) (SIG side) 4. Defective governor, pump controller
—	E225	Abnormality in rear pump pressure sensor system	1. Disconnection, defective contact, short circuit, short circuit with ground inside rear pump pressure sensor 2. Disconnection, defective contact, short circuit in wiring harness between controller C03 (6) and pressure sensor C07 (2) ((+) side) and between C03 (16) and C07 (1) ((-) side) 3. Disconnection, defective contact, short circuit with power source, short circuit with ground in wiring harness between controller C03 (13) and pressure sensor C07 (3) (SIG side) 4. Defective governor, pump controller
—	E226	Abnormality in pressure sensor power source system	1. Short circuit, short circuit with ground inside front pump pressure sensor or rear pump pressure sensor 2. Short circuit, short circuit with ground in wiring harness between controller C03 (6) and front pressure sensor C08 (2) or rear pressure sensor C07 (2) ((+) side) 3. Defective governor, pump controller
—	E227	Abnormality in speed sensor system	1. Disconnection, defective contact, short circuit inside engine speed sensor 2. Disconnection, defective contact, short circuit with ground in wiring harness between controller C16 (1) and speed sensor E07 (2) ((-) side) and between C16 (2) and E07 (1) (SIG side) 3. Defective governor, pump controller

ACTION TAKEN BY CONTROLLER WHEN ABNORMALITY OCCURS AND PROBLEMS ON MACHINE

TROUBLESHOOTING

Condition when normal (voltage, current, resistance)	Action by controller when abnormality is detected	Problem that appears on machine when there is abnormality
	1. When communications are impossible with the monitor, control is carried out with the following settings. ① Working mode: G/O ② Priority mode: OFF ③ Travel speed: Lo ④ Auto-deceleration: ON ⑤ Power max. : ON (others are as usual)	1. ① Even when travel is operated, the power max. function does not work ② The swift speed-down function does not work ③ The auto-deceleration cannot be canceled ④ The travel speed does not increase ⑤ The priority mode has no effect ⑥ The automatic mode has no effect
Resistance of solenoid: 7 – 14 Ω	1. Makes output to LS-EPC solenoid 0. ★ If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)	1. The Lo travel speed is too fast. 2. In L/O and F/O modes, the work equipment speed is too fast. 3. When the engine is running at low idling, the swing speed is too fast.
Current: Approx. 705 mA (Levers at neutral, low idling)	1. The current stops flowing to the LS-EPC solenoid, so no particular action is taken. 2. If there is a short circuit with the ground at the (-) end, the current (min. 1A) continues to flow to the LS-EPC solenoid. ★ If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)	1. In the case of 1, it is the same as E222 2. In the case of 2, electric current (min. 1A) continues to flow to the LS-EPC solenoid, so the work equipment, travel, and swing speeds are slow
Between C03 (3) and (16): 0.5 – 4.5 V Between C03 (6) and (16): 18 – 28 V Between C03 (female) (3) and (16), (3) and chassis Resistance: Min. 1 MΩ (Disconnect connectors C03 and C08.)	1. Takes front pump pressure as 0 MPa (0 kg/cm ²) when actuating. ★ If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)	1. The travel speed does not automatically shift (it does not change from Hi to Lo). ★ If the button is operated manually, the panel display is switched.
Between C03 (13) and (16): 0.5 – 4.5 V Between C03 (6) and (16): 18 – 28 V Between C03 (female) (13) and (16), (13) and chassis Resistance: Min. 1 MΩ (Disconnect connectors C03 and C07.)	1. Takes rear pump pressure as 0 MPa (0 kg/cm ²) when actuating. ★ If the abnormality is restored by the vibration of the machine, it resets the power source to restore to the proper condition. (However, the service code display does not go out.)	1. The travel speed does not automatically shift (it does not change from Hi to Lo). ★ If the button is operated manually, the panel display is switched.
Voltage between C03 (6) and (16): 18 – 28 V	1. Takes front pump and rear pump pressure as 0 MPa (0 kg/cm ²) when actuating. 2. When abnormality is detected, it switches the output OFF, and when all levers are returned to neutral, it outputs again. ★ This automatic resetting is repeated up to 3 times.	1. The travel speed does not automatically shift (it does not change from Hi to Lo). ★ If the button is operated manually, the panel display is switched.
Resistance: 500 – 1000 Ω Voltage (AC range) : 0.5 – 3.0 V (engine started)	1. It functions in the equivalent of the G/O mode (the speed rises)	It operates about the same as G/O mode (prolix) (the power is slightly lower)

JUDGEMENT TABLE FOR GOVERNOR, PUMP CONTROLLER
(PUMP CONTROL SYSTEM) AND HYDRAULIC RELATED PARTS

Failure mode			Abnormality in controller power source	Governor, pump controller (E2:XX system)																
				Self-diagnostic display																
				Short circuit in front pump TVC solenoid system				Disconnection in front pump TVC solenoid system				Short circuit in rear pump TVC solenoid system				Disconnection in rear pump TVC solenoid system				
				Short circuit in LS select solenoid system				Disconnection in LS select solenoid system				Short circuit in swing holding brake solenoid system				Disconnection in swing holding brake solenoid system				
			User code	LED	E02				—				E03				—			
			Service code	OFF	232	233	236	237	202	212	203	213	204	214	206	216	217	222	223	
All work equipment, travel, swing	Speeds of all work equipment, swing, travel are slow or lack power			▲	▲	▲	▲										●		●	
	There is excessive drop in engine speed, or engine stalls			●	●	●	●										●			
	No work equipment, travel, swing move																			
	Abnormal noise generated (around pump)																			
	Auto-deceleration does not work			●																
	Fine control ability is poor or response is poor																			
Work equipment	Boom is slow or lacks power													●						
	Arm is slow or lacks power													●						
	Bucket is slow or lacks power																			
	Boom does not move																			
	Arm does not move																			
	Bucket does not move																			
	Excessive hydraulic drift																			
	Excessive time lag (engine at low idling)																		●	
	Other equipment moves when single circuit is relieved																			
	In L/O, F/O modes, work equipment speed is faster than specified speed													●	●			●	●	
	Machine 2-stage relief function does not work																			
Compound operations	In compound operations, work equipment with larger load is slow									●	●									
	In swing + boom (RAISE), boom is slow								●	●										
	In swing + arm, arm is slow								●	●										
	In swing + travel, travel speed drops excessively								●	●										
Travel system	Travel deviation	Deviation is excessive during normal travel																		
		Deviation is excessive when starting																		
	Travel speed is slow													●	●				●	
	Steering does not turn or lacks power													●	●					
	Travel speed does not switch or is faster than specified speed			●												●	●		●	●
	Does not move (one side only)																			
Swing system	Does not swing	Both left and right										●	●							
		One direction only																		
	Swing acceleration is poor or swing speed is slow	Both left and right		●	●	●	●													
		One direction only																		
	Excessive overrun when stopping swing	Both left and right																		
		One direction only																		
	Excessive shock when stopping swing (one direction only)																			
	Excessive abnormal noise when stopping swing																			
	Excessive hydraulic drift of swing	When holding brake is released																		
When holding brake is applied																				
	Swing speed is faster than specified swing speed												●	●				●	●	
Troubleshooting code when service code is displayed				C-1	C-2	C-3	C-4	C-5	C-6	C-7	C-8	C-9	C-10	C-11	C-12	C-13	C-14	C-15	C-16	
Troubleshooting code when there is abnormality in monitoring check				—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	

▲: This shows applicable item for service code (simultaneous abnormality at front or rear)

●: This shows applicable item for service code

※: This shows item that needs only checking with monitoring

○: This shows item to check with monitoring or machine monitor


TROUBLESHOOTING

**JUDGEMENT TABLE FOR GOVERNOR, PUMP CONTROLLER
(PUMP CONTROL SYSTEM) AND HYDRAULIC RELATED PARTS**

★ If service code E218 (abnormality in network system) is displayed, go to troubleshooting for N mode.

[illegible]

ELECTRICAL CIRCUIT DIAGRAM FOR C MODE




BKP00182



C-1 Abnormality in controller power source system (controller LED is OFF)


- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ Check that fuse 1 is not blown.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.
- ★ When the starting motor rotates normally. (If the starting motor also does not rotate, go to E-8.)



C-1 Related electric circuit diagram

Governor, pump controller

C01(MIC13)



BKP00186

C-2 [E232] Short circuit in front pump TVC solenoid system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Always turn the TVC prolix switch OFF.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.





Table 1

Troubleshooting No. 2	Troubleshooting No. 3	Troubleshooting No. 4	Resistance value
Between C13 (male) (1) - (2)	Between C02 (female) (8) - (18)	Between C05 (female) (3) - (4)	10 - 22 Ω
Between C13 (male) (1) - chassis	Between C02 (female) (8) - chassis	Between C05 (female) (3) - chassis	Min. 1 MΩ

Table 2

Troubleshooting No. 5	Resistance value
Between C05 (male) (1) - (3), (2) - (4)	Max. 1 Ω
Between C05 (male) (1)(2)(3)(4) - chassis	Min. 1 MΩ

C-2 Related electric circuit diagram



BKP00187

C-3 [E233] Disconnection in front pump TVC solenoid system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ If there is a disconnection in the solenoid or wiring harness, no current flows to the solenoid. If the No. 2 pin of the solenoid is short circuiting with the ground, the current (approx. 1 A) continues to flow to the solenoid.
- ★ Always turn the TVC prolix switch OFF.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.





Table 1

Troubleshooting No. 2	Troubleshooting No. 3	Troubleshooting No. 4	Resistance value
Between C13 (male) (1) – (2)	Between C02 (female) (8) – (18)	Between C05 (female) (3) – (4)	10 – 22 Ω
Between C13 (male) (2) – chassis	Between C02 (female) (18) – chassis	Between C05 (female) (4) – chassis	Min. 1 MΩ

Table 2

Troubleshooting No. 5	Resistance value
Between C05 (male) (1) – (3), (2) – (4)	Max. 1 Ω
Between C05 (male) (1)(2)(3)(4) – chassis	Min. 1 MΩ

C-3 Related electric circuit diagram



BKP00187

C-4 [E236] Short circuit in rear pump TVC solenoid system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Always turn the TVC prolix switch OFF.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.





Table 1

Troubleshooting No. 2	Troubleshooting No. 3	Troubleshooting No. 4	Resistance value
Between C04 (male) (1) – (2)	Between C02 (female) (9) – (19)	Between C05 (female) (8) – (9)	10 – 22 Ω
Between C04 (male) (1) – chassis	Between C02 (female) (9) – chassis	Between C05 (female) (8) – chassis	Min. 1 MΩ

Table 2

Troubleshooting No. 5	Resistance value
Between C05 (male) (6) – (8), (7) – (9)	Max. 1 Ω
Between C05 (male) (6)(7)(8)(9) – chassis	Min. 1 MΩ

C-4 Related electric circuit diagram



BKP00188

C-5 [E237] Disconnection in rear pump TVC solenoid system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ If there is a disconnection in the solenoid or wiring harness, no current flows to the solenoid. If the No. 2 pin of the solenoid is short circuiting with the ground, the current (approx. 1 A) continues to flow to the solenoid.
- ★ Always turn the TVC prolix switch OFF.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.





Table 1

Troubleshooting No. 2	Troubleshooting No. 3	Troubleshooting No. 4	Resistance value
Between C04 (male) (1) – (2)	Between C02 (female) (9) – (19)	Between C05 (female) (8) – (9)	10 – 22 Ω
Between C04 (male) (2) – chassis	Between C02 (female) (19) – chassis	Between C05 (female) (9) – chassis	Min. 1 MΩ

Table 2

Troubleshooting No. 5	Resistance value
Between C05 (male) (6) – (8), (7) – (9)	Max. 1 Ω
Between C05 (male) (6)(7)(8)(9) – chassis	Min. 1 MΩ

C-5 Related electric circuit diagram



BKP00188

C-6 [E202] Short circuit in LS select solenoid system is displayed


- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

		Cause	Remedy
1 Interchange connector with other solenoid. Is [E202] displayed? • Turn starting switch OFF. • Interchange V02 with other connector. • Start engine. • Turn swing lock switch OFF. • Operate swing + travel at same time.	YES		
	NO		
	YES		
2 Is resistance between V02 (male) (1) and (2), (2) and chassis as shown in Table 1? • Turn starting switch OFF. • Disconnect V02.	YES		
	NO		
3 Is resistance between C01 (female) (8) and chassis normal? • Turn starting switch OFF. • Disconnect C01. • 20 – 60 Ω	YES	Defective governor, pump controller	Replace
	NO	Short circuit with chassis ground in wiring harness between C01 (female) (8) and V02 (female) (2)	Repair or replace
		Defective LS select solenoid (internal short circuit or short circuit with ground)	Replace

Table 1

Between V02 (male) (1) – (2)	20 – 60 Ω
Between V02 (male) (2) – chassis	Min. 1 MΩ

C-6 Related electric circuit diagram



BKP00189

C-8 [E203] Short circuit in swing brake solenoid system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.
- ★ Always turn the swing lock prolix switch OFF, then turn the swing lock switch OFF before checking.





Table 1

Between V04 (male) (1) – (2)	20 – 60 Ω
Between V04 (male) (2) – chassis	Min. 1 MΩ

C-8 Related electric circuit diagram



BKP00190

C-9 [E213] Disconnection in swing brake solenoid system is displayed

- ★ **This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.**
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Always turn the swing lock prolix switch OFF, then turn the swing lock switch OFF before checking.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.





Table 1

Troubleshooting No. 3	Troubleshooting No. 4	Troubleshooting No. 6	Voltage	Measurement condition
Between C01 (male)	Between X05 (male)	Between V04 (male)	0 – 3V	5 seconds after all levers are returned to neutral
(3) – chassis	(3) – chassis	(2) – chassis	20 – 30V	Swing lever operated

C-9 Related electric circuit diagram



BKP00190

C-10 [E204] Short circuit in pump merge/divider solenoid system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.





Table 1

Between V03 (male) (1) – (2)	20 – 60 Ω
Between V03 (male) (2) – chassis	Min. 1 MΩ

C-10 Related electric circuit diagram



BKP00191

C-11 [E214] Disconnection in pump merge/divider solenoid system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.





Table 1

Troubleshooting No. 3	Troubleshooting No. 4	Voltage	Measurement condition
Between C01 (male) (2) – chassis	Between V03 (female) (2) – chassis	0 – 3V	All levers at neutral
		20 – 30V	Travel operated independently

C-11 Related electric circuit diagram



BKP00191

C-12 [E206] Short circuit in travel speed solenoid system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adaptor, or when removing the T-adaptor and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.





Table 1

Between V06 (male) (1) – (2)	20 – 60 Ω
Between V06 (male) (2) – chassis	Min. 1 MΩ

C-12 Related electric circuit diagram



BKP00192

C-13 [E216] Disconnection in travel speed selector solenoid system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.





Table 1

Troubleshooting No. 3	Troubleshooting No. 4	Voltage	Measurement condition
Between C01 (male) (9) – chassis	Between V06 (female) (2) – chassis	0 – 3V	Travel speed switch at Lo
		20 – 30V	Travel speed switch at Mi or Hi Operate the lever slightly not enough to move the machine

C-13 Related electric circuit diagram



BKP00192

C-14 [E217] Model selection input error is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.




Table 1 Monitoring code display


Model code display	Model selection signal input display	
Monitoring codes 02, 03	Monitoring code 21	Monitoring code 22
 BKP00193	 BKP00194	 BKP00195

- ★ The diagram shows monitoring code 02.
- ★ Check the bit pattern display marked with ←.

Table 2 Voltage of wiring harness

C17	Between (5) - chassis	Between (6) - chassis	Between (7) - chassis	Between (13) - chassis	Between (14) - chassis
Voltage	20 - 30 V	Max. 1 V	20 - 30 V	Max. 1 V	20 - 30 V

C-14 Related electric circuit diagram



BKP00199

C-15 [E222] Short circuit in LS-EPC solenoid system is displayed


- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

		Cause	Remedy
Is resistance between C10 (male) (1) and (2), (1) and chassis as shown in Table 1? 1 YES • Turn starting switch OFF. • Disconnect C10.	Is resistance between C02 (female) (7) and (17), (7) and chassis as shown in Table 1? 2 YES	Defective governor, pump controller	Replace
	NO	Short circuit with ground or short circuit with power source in wiring harness between C02 (female) (7) – C10 (female) (1), or short circuit with power source in wiring harness between C02 (female) (17) – C10 (female) (2)	Repair or replace
	NO	Defective LS-EPC solenoid (internal short circuit with ground or short circuit with power source)	Replace

Table 1

Troubleshooting No. 1	Troubleshooting No. 2	Resistance value
Between C10 (male) (1) – (2)	Between C02 (female) (7) – (17)	7 – 14 Ω
Between C10 (male) (1) – chassis	Between C02 (female) (7) – chassis	Min. 1 MΩ

C-15 Related electric circuit diagram



BKP00251

C-16 [E223] Disconnection in LS-EPC solenoid system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.





Table 1

Troubleshooting No. 1	Troubleshooting No. 2	Resistance value
Between C10 (male) (1) – (2)	Between C02 (female) (7) – (17)	7 – 14 Ω
Between C10 (male) (2) – chassis	Between C02 (female) (17) – chassis	Min. 1 MΩ

C-16 Related electric circuit diagram




BKP00251

C-17 [E224] Abnormality in front pump pressure sensor system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adaptor, or when removing the T-adaptor and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

				Cause	Remedy	
1 Interchange connector with rear pump pressure sensor. Is [E224] displayed? • Turn starting switch OFF. • Interchange C07 with C08. • Engine at high idling	YES	2 Is voltage between C08 (2) and (1) normal? • Turn starting switch ON. • 18 – 28 V	YES	3 Is voltage between C03 (3) and (16) normal? • Engine at high idling • Operate repeatedly arm IN relief→ lever NEUTRAL. • 0.5 – 4.5 V	Defective governor, pump controller	Replace
			NO		Short circuit with power source, defective contact, or disconnection in wiring harness between C03 (female) (3) – C08 (female) (3)	Repair or replace
		NO	4 Is voltage between C08 (2) and chassis normal? • Disconnect C08. • Turn starting switch ON. • 18 – 28 V	YES	Short circuit with ground, defective contact, or disconnection in wiring harness between C03 (female) (16) and C08 (female) (1)	Repair or replace
				NO	Short circuit with ground, defective contact, or disconnection in wiring harness between C03 (female) (6) and C08 (female) (2)	Repair or replace
		NO			Defective front pump pressure sensor (internal disconnection, defective contact, short circuit, or short circuit with ground)	Replace


C-17 Related electric circuit diagram




BKP00252

C-18 [E225] Abnormality in rear pump pressure sensor system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.



C-18 Related electric circuit diagram




BKP00253

C-19 [E226] Abnormality in pressure sensor power source system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.


		Cause	Remedy
1 Is resistance between C03 (female) (6) and (16), (6) (16) and chassis normal? • Turn starting switch OFF. • Disconnect C03, C07, and C08. • Min. 1 MΩ	YES		
	NO		
	YES	Defective front pump pressure sensor (internal short circuit or short circuit with ground)	Replace
	NO	Defective rear pump pressure sensor (internal short circuit or short circuit with ground)	Replace
2 Is voltage between C03 (6) and (16) normal? • Turn starting switch ON. • Disconnect C08. • 18 – 28 V	YES		
	NO	Defective governor, pump controller	Replace
3 Is voltage between C03 (6) and (16) normal? • Turn starting switch ON. • Disconnect C07. • 18 – 28 V	YES		
	NO	Short circuit or short circuit with ground in wiring harness of system where resistance value is defective	Repair or replace

C-19 Related electric circuit diagram




C-20 [E227] Abnormality in engine speed sensor system is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if an E service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the problem has been removed.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.




C-20 Related electric circuit diagram




BKP00255

C-21 Abnormality in machine 2-stage pressure relief solenoid system (no service code displayed)

- ★ Even if any abnormality occurs in the machine 2-stage pressure relief solenoid system, the service code is not displayed on the monitor panel.
 - ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
 - ★ Always connect any disconnected connectors before going on the next step.
- a) If solenoid is not actuated (turned ON) when machine 2-stage relief switch is set to low-pressure setting
- ★ Check that fuse No. 2 is not blown.
 - ★ Carry out troubleshooting with the machine 2-stage relief switch at the low-pressure setting position.




C-21 Related electric circuit diagram




BKP00256

b) **If solenoid is not canceled (turned OFF) when machine 2-stage pressure relief switch is det to high-pressure setting**

- ★ Carry out troubleshooting with the machine 2-stage pressure relief switch at the high-pressure setting position.




C-21 Related electric circuit diagram




BKP00256

TROUBLESHOOTING OF GOVERNOR, PUMP CONTROLLER (INPUT SIGNAL SYSTEM) (F MODE)

Electrical circuit diagram for F mode	20-401-1
F- 1 Bit pattern 20-(1) Swing oil pressure switch does not light up	20-402
F- 2 Bit pattern 20-(2) Travel oil pressure switch does not light up	20-403
F- 3 Bit pattern 20-(3) Boom LOWER oil pressure switch does not light up	20-404
F- 4 Bit pattern 20-(4) Boom RAISE oil pressure switch does not light up	20-405
F- 5 Bit pattern 20-(5) Arm IN oil pressure switch does not light up	20-406
F- 6 Bit pattern 20-(6) Arm OUT oil pressure switch does not light up	20-407
F- 7 Bit pattern 21-(1) Bucket CURL oil pressure switch does not light up	20-408
F- 8 Bit pattern 21-(2) Bucket DUMP oil pressure switch does not light up	20-409
F- 9 Bit pattern 21-(3) Swing lock switch does not light up	20-410
F-10 Bit pattern 22-(5) Kerosene mode connection does not light up	20-411
F-11 Bit pattern 22-(6) L.H. knob switch does not light up	20-412





F-1 Bit pattern 20-(1) Swing oil pressure switch does not light up


- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the monitor code display returns to normal, the problem has been removed.

⚠ Turn the swing lock switch ON before operating the swing lever.

- ★ If there is no display when the lever is operated on one side, the PPC shuttle valve is defective. (See H-5)

(When measuring with the engine stopped, charge the accumulator first.)


- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.



Note 1: It is also possible to fit a short connector and judge the condition. In this case, check the voltage between C16 (5) and the chassis.

- If it is 20 – 30 V: Go to YES
- If it is less than 1 V: Go to NO

F-1 Related electric circuit diagram



BKP00257

F-2 Bit pattern 20-(2) Travel oil pressure switch does not light up

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the monitor code display returns to normal, the problem has been removed.

⚠ Before operating the travel lever, check that the surrounding area is safe.

- ★ If there is no display when the travel lever is operated on one side, the PPC shuttle valve is defective. (See H-5)

(When measuring with the engine stopped, charge the accumulator first.)


- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
★ Always connect any disconnected connectors before going on the next step.

		Cause	Remedy
1 Is voltage between C16 (13) and chassis normal? • Start engine. • Travel lever at neutral : 20 – 30V • Travel lever operated : Max. 1 V	YES	Defective governor, pump controller	Replace
	NO	Defective contact, or disconnection in wiring harness between S01 (female) (1) and chassis ground	Repair or replace
	NO	Defective contact, short circuit with ground, or disconnection in wiring harness between C16 (female) (13) and S01 (female) (2)	Repair or replace
	NO	Defective travel oil pressure switch (If the condition does not return to normal even when the switch is replaced, go to H-5.)	Replace
2 Is resistance between S01 (male) (1) and (2) normal, and is circuit insulated from chassis? • Disconnect S01 • Start engine. • Travel lever at neutral : Min. 1MΩ • Travel lever operated : Max: 1 Ω • See Note 1.			
3 Is resistance between C16 (female) (13) and S01 (female) (2) normal, and is circuit insulated from chassis? • Turn starting switch OFF. • Disconnect C16 and S01. • Between C16 and S01: Max. 1 Ω • Between wiring harness and chassis: Min. 1 MΩ			

Note 1: It is also possible to fit a short connector and judge the condition. In this case, check the voltage between C16 (13) and the chassis.

- If it is 20 – 30 V: Go to YES
- If it is less than 1 V: Go to NO

F-2 Related electric circuit diagram



BKP00258


F-3 Bit pattern 20-(3) Boom LOWER oil pressure switch does not light up

★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the monitor code display returns to normal, the problem has been removed.


⚠ When measuring with the engine running, operate the lever slightly and make sure that the work equipment does not move.

(When measuring with the engine stopped, charge the accumulator first.)

- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.



F-3 Related electric circuit diagram




F-4 Bit pattern 20-(4) Boom RAISE oil pressure switch does not light up

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the monitor code display returns to normal, the problem has been removed.

⚠ When measuring with the engine running, operate the lever slightly and make sure that the work equipment does not move.

(When measuring with the engine stopped, charge the accumulator first.)


- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
★ Always connect any disconnected connectors before going on the next step.



Note 1: It is also possible to fit a short connector and judge the condition. In this case, check the voltage between C17 (2) and the chassis.

- If it is 20 - 30V: Go to YES
- If it is less than 1V: Go to NO

F-4 Related electric circuit diagram



BKP00260

F-5 Bit pattern 20-(5) Arm IN oil pressure switch does not light up

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the monitor code display returns to normal, the problem has been removed.

⚠ When measuring with the engine running, operate the lever slightly and make sure that the work equipment does not move.


(When measuring with the engine stopped, charge the accumulator first.)

- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
★ Always connect any disconnected connectors before going on the next step.

		Cause	Remedy
1 Is voltage between C17 (3) and chassis normal? • Start engine. • Arm lever at neutral: 20 – 30V • Arm lever operated to IN : Max. 1 V YES NO	YES 3 Is resistance between C17 (female) (3) and S05 (female) (2) normal, and is circuit insulated from chassis? YES NO	Defective governor, pump controller	Replace
	YES 2 Is resistance between S05 (male) (1) and (2) normal, and is circuit insulated from chassis? YES NO	Defective contact, or disconnection in wiring harness between S05 (female) (1) and chassis ground	Repair or replace
	YES • Turn starting switch OFF. • Disconnect C17 and S05. • Between C17 and S05: Max. 1 Ω • Between wiring harness and chassis : Min. 1 MΩ	Defective contact, short circuit with ground, or disconnection in wiring harness between C17 (female) (3) – H13 (10) – S05 (female) (2)	Repair or replace
	NO • Disconnect S05. • Start engine. • Arm lever at neutral : Min. 1 MΩ • Arm lever operated to IN: Max. 1 Ω • See Note 1.	Defective arm IN oil pressure switch (If the condition does not return to normal even when the switch is replaced, go to H-5.)	Replace

Note 1: It is also possible to fit a short connector and judge the condition. In this case, check the voltage between C17 (3) and the chassis.
• If it is 20 – 30V: Go to YES
• If it is less than 1V: Go to NO

F-5 Related electric circuit diagram



BKP00261


F-6 Bit pattern 20-(6) Arm OUT oil pressure switch does not light up

★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the monitor code display returns to normal, the problem has been removed.

⚠ When measuring with the engine running, operate the lever slightly and make sure that the work equipment does not move.

(When measuring with the engine stopped, charge the accumulator first.)


- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.



Note 1: It is also possible to fit a short connector and judge the condition. In this case, check the voltage between C17 (11) and the chassis.

- If it is 20 – 30V: Go to YES
- If it is less than 1V: Go to NO

F-6 Related electric circuit diagram



F-7 Bit pattern 21-(1) Bucket CURL oil pressure switch does not light up


★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the monitor code display returns to normal, the problem has been removed.

⚠ When measuring with the engine running, operate the lever slightly and make sure that the work equipment does not move.

(When measuring with the engine stopped, charge the accumulator first.)

★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.


★ Always connect any disconnected connectors before going on the next step.



Note 1: It is also possible to fit a short connector and judge the condition. In this case, check the voltage between C16 (11) and the chassis.

- If it is 20 – 30V: Go to YES
- If it is less than 1V: Go to NO

F-7 Related electric circuit diagram



BKP00263


F-8 Bit pattern 21-(2) Bucket DUMP oil pressure switch does not light up

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the monitor code display returns to normal, the problem has been removed.

⚠ When measuring with the engine running, operate the lever slightly and make sure that the work equipment does not move.

(When measuring with the engine stopped, charge the accumulator first.)


- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
★ Always connect any disconnected connectors before going on the next step.



Note 1: It is also possible to fit a short connector and judge the condition. In this case, check the voltage between C16 (12) and the chassis.

- If it is 20 – 30V: Go to YES
- If it is less than 1V: Go to NO


F-8 Related electric circuit diagram




BKP00264

F-9 Bit pattern 21-(3) Swing lock switch does not light up

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the monitor code display returns to normal, the problem has been removed.
- ★ If the panel display is normal. (If the swing lock lamp does not light up, go to M-21.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.



F-9 Related electric circuit diagram




BKP00265

F-11 Bit pattern 22-(6) L.H. knob switch does not light up

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the monitor code display returns to normal, the problem has been removed.
- ★ When fuse No. 5 is not blown.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

			Cause	Remedy
1 Is voltage between C03 (9) and chassis normal? • Turn starting switch ON. • Knob switch ON: 20 – 30V OFF: Max. 1 V YES NO			Defective governor, pump controller	Replace
2 Is voltage between knob switch inlet terminal and chassis normal? • Turn starting switch ON. • 20 – 30V YES NO			Defective contact, or disconnection in wiring harness between knob switch outlet – M23 (2) – M22 (2) – C03 (female) (9)	Repair wiring harness
3 Is resistance between terminals of knob switch normal? • Turn starting switch OFF. • Disconnect switch terminal. • Knob switch ON: Max. 1 Ω OFF: Min. 1 MΩ YES NO			Defective L.H. knob switch	Replace
			Defective contact, or disconnection in wiring harness between fuse No. 5 – H12 (16) – M22 (1) – H23 (1) – knob switch inlet	Repair wiring harness

F-11 Related electric circuit diagram




BKP00267

TROUBLESHOOTING OF HYDRAULIC, MECHANICAL SYSTEM (H MODE)

Pump merge/divider logic, LS select logic, solenoid actuation table	20-452
Table of failure modes and causes	20-454
All work equipment, travel, swing	
H-1 Speeds of all work equipment, swing, travel are slow or lack power	20-458
H-2 There is excessive drop in engine speed, or engine stalls	20-460
H-3 No work equipment, travel, swing move	20-461
H-4 Abnormal noise generated (around pump)	20-461
H-5 Auto-deceleration does not work	20-462
H-6 Fine control ability is poor or response is poor	20-462
Work equipment	
H-7 Boom is slow or lacks power	20-464
H-8 Arm is slow or lacks power	20-466
H-9 Bucket is slow or lacks power	20-468
H-10 Work equipment (boom, arm, bucket) does not move	20-469
H-11 Excessive hydraulic drift (boom, arm, bucket)	20-469
H-12 Excessive time lag (engine at low idling)	20-470
H-13 Other equipment moves when single circuit is relieved	20-470
H-14 In L/O, F/O modes, work equipment speed is faster than set speed	20-471
H-15 Defective actuation of machine 2-stage pressure relief	20-471
Compound operations	
H-16 In compound operations, work equipment with larger load is slow	20-471
H-17 In swing + boom RAISE, boom RAISE is slow	20-472
H-18 In swing + arm, arm is slow	20-472
H-19 In swing + travel, travel speed drops excessively	20-472
Travel system	
H-20 Travel deviation	20-473
H-21 Travel speed is slow	20-474
H-22 Steering does not turn easily or lacks power	20-476
H-23 Travel speed does not switch or is faster than set speed	20-478
H-24 Travel does not move (one side only)	20-478
Swing system	
H-25 Does not swing (both left and right, one direction only)	20-479
H-26 Swing acceleration is poor or swing speed is slow (both left and right, one direction only)	20-480
H-27 Excessive overrun when stopping swing (both left and right, one direction only)	20-482
H-28 Excessive shock when stopping swing (one direction only)	20-483
H-29 Excessive abnormal noise when stopping swing	20-483
H-30 Excessive hydraulic drift of swing (when brake is ON, when brake is OFF)	20-484
H-31 Swing speed is faster than specified speed	20-485

TROUBLESHOOTING PUMP MERGE/DIVIDER LOGIC, LS SELECT LOGIC, SOLENOID ACTUATION TABLE

PUMP MERGE/DIVIDER LOGIC

Divide (pump merge/divider solenoid ON)	Merge (pump merge/divider solenoid OFF)
- Travel operated independently. - Travel + work equipment (any one of boom, arm, bucket, swing, or service) + front or rear pump oil pressure 19.6 MPa (200 kg/cm²) or above when raised or 14.7 MPa (150 kg/cm²) or above when lowered. (See diagram)  Pressure MPa(kg/cm²) BKP00221 - Breaker mode + service (breaker) valve pressure switch ON.	All operations except those on left.

LS SELECT LOGIC

LS separated (LS select solenoid ON)	LS not separated (LS select solenoid OFF)
- With swing priority mode ON and swing lock switch OFF: Travel + swing - With swing priority mode OFF and swing lock switch OFF: - Travel + swing - Boom RAISE ON - Arm OUT ON - Arm IN + front or rear pump oil pressure 14.7 MPa (150 kg/cm²) or above.	- Swing lock switch ON - With swing priority mode ON and swing lock switch OFF: Any operation except travel + swing - With swing priority mode OFF and swing lock switch OFF: Any operation except 2-1) – 2-4) on left

SOLENOID ACTUATION TABLE

Name of solenoid	ON (energized)	OFF
Swing holding brake	Brake released	Brake applied
Travel speed	Travel motor swash plate angle at MIN	Travel motor swash plate angle at MAX
LS select	LS separated	LS not separated
Pump merge/divider valve	Divided flow	Merged flow
Machine 2 stage relief	Low pressure	High pressure

TROUBLESHOOTING

TABLE OF FAILURE MODES AND CAUSES

TABLE OF FAILURE MODES AND CAUSES (1/2)

Failure mode		Parts causing failure	Piston pump								Control valve			
			F				R							
			TVC valve	LS valve	Servo piston	Pump proper	TVC valve	LS valve	Servo piston	Pump proper				
All work equipment, travel, swing	Speeds of all work equipment, swing, travel are slow or lack power		▲	▲	▲	▲	▲	▲	▲	○				
	There is excessive drop in engine speed, or engine stalls		○	○	○		○	○	○					
	No work equipment, travel, swing move					△				△	○		○	
	Abnormal noise generated (around pump)					○				○		○		
	Auto-deceleration does not work													
Work equipment	Fine control ability is poor or response is poor			○										
	Boom is slow or lacks power												○	
	Arm is slow or lacks power												○	
	Bucket is slow or lacks power												○	
	Boom does not move												○	
	Arm does not move												○	
	Bucket does not move												○	
	Excessive hydraulic drift												○	
	Excessive time lag (engine at low idling)													
	Other equipment moves when single circuit is relieved													
	In L/O, F/O modes, work equipment speed is faster than specified speed			○				○						
	Machine 2-stage relief function does not work													
Compound operations	In compound operations, work equipment with larger load is slow													
	In swing + boom (RAISE), boom is slow													
	In swing + arm, arm is slow													
	In swing + travel, travel speed drops excessively													
Travel system	Travel deviation	Deviation is excessive during normal travel											○	
		Deviation is excessive when starting												
	Travel speed is slow												○	
	Steering does not turn or lacks power												○	
	Travel speed does not switch or is faster than specified speed													
	Does not move (one side only)			○				○						
Swing system	Does not swing	Both left and right												
		One direction only											○	
	Swing acceleration is poor or swing speed is slow	Both left and right	○	○										
		One direction only											○	
	Excessive overrun when stopping swing	Both left and right												
		One direction only											○	
	Excessive shock when stopping swing (one direction only)													
	Excessive abnormal noise when stopping swing													
	Excessive hydraulic drift of swing	When brake ON												
When brake OFF												○		
Swing speed is faster than specified swing speed			○				○							

★ In the failure modes, modes for compound operations are used when independent operations are normal

▲: When there is an abnormality for both front and rear

TROUBLESHOOTING

TABLE OF FAILURE MODES AND CAUSES

Control valve																	Troubleshooting code
Front pump		Rear pump		Pressure compensation valve	Pump merge/divider valve		LS circuit check valve	LS shuttle valve	LS select valve	LS circuit throttle	Arm counterbalance valve	Re-generation valve		Safety-suction valve	Suction valve	Slow return valve for pump merge/divider	
Main relief valve	Unload valve	Main relief valve	Unload valve		Main pump merge/divider valve	LS pump merge/divider valve						Boom	Arm				
▲	▲	▲	▲														
																	H-1
																	H-2
																	H-3
																	H-4
																	H-5
																	H-6
																	H-7
																	H-8
																	H-9
																	H-10
																	H-11
																	H-12
																	H-13
																	H-14
																	H-15
																	H-16
																	H-17
																	H-18
																	H-19
																	H-20
																	H-21
																	H-22
																	H-23
																	H-24
																	H-25
																	H-26
																	H-27
																	H-28
																	H-29
																	H-30
																	H-31

TABLE OF FAILURE MODES AND CAUSES (2/2)

Failure mode			Parts causing failure		Solenoid valve						Swing motor	
					LS-EPC	LS select	Pump merge/divider valve	Swing holding brake	Travel speed selector	Machine 2-stage relief	Holding brake	Safety-suction valve
All work equipment, travel, swing	Speeds of all work equipment, swing, travel are slow or lack power		○									
	There is excessive drop in engine speed, or engine stalls											
	No work equipment, travel, swing move											
	Abnormal noise generated (around pump)											
	Auto-deceleration does not work											
	Fine control ability is poor or response is poor											
Work equipment	Boom is slow or lacks power				○							
	Arm is slow or lacks power				○							
	Bucket is slow or lacks power											
	Boom does not move											
	Arm does not move											
	Bucket does not move											
	Excessive hydraulic drift											
	Excessive time lag (engine at low idling)		○									
	Other equipment moves when single circuit is relieved											
	In L/O, F/O modes, work equipment speed is faster than specified speed		○		○							
Machine 2-stage relief function does not work						○						
Compound operations	In compound operations, work equipment with larger load is slow											
	In swing + boom (RAISE), boom is slow			○								
	In swing + arm, arm is slow			○								
	In swing + travel, travel speed drops excessively			○								
Travel system	Travel deviation	Deviation is excessive during normal travel										
		Deviation is excessive when starting										
	Travel speed is slow		○									
	Steering does not turn or lacks power				○							
	Travel speed does not switch or is faster than specified speed		○		○		○					
	Does not move (one side only)											
Swing system	Does not swing	Both left and right				○				○		○
		One direction only									○	
	Swing acceleration is poor or swing speed is slow	Both left and right										○
		One direction only									○	
	Excessive overrun when stopping swing	Both left and right										○
		One direction only									○	
	Excessive shock when stopping swing (one direction only)											
	Excessive abnormal noise when stopping swing										○	
	Excessive hydraulic drift of swing	When brake ON				○				○		
	When brake OFF									○	○	
Swing speed is faster than specified swing speed		○										

★ In the failure modes, modes for compound operations are used when independent operations are normal

▲: When there is an abnormality for both front and rear


TROUBLESHOOTING

TABLE OF FAILURE MODES AND CAUSES

Travel motor					Pressure switch														Pressure sensor		Troubleshooting code
Safety valve	Counterbalance valve	Check valve	Travel speed selector servo piston	Leakage, breakage inside body	Swing machinery	Final drive	Hydraulic cylinder	Boom lock valve	Back pressure valve	Travel junction valve	RAISE	LOWER	IN	OUT	CURL	DUMP	Swing	Travel	Front pump	Rear pump	
																					H-1
																					H-2
																					H-3
																					H-4
																					H-5
																					H-6
																					H-7
																					H-8
																					H-9
																					H-10
																					H-11
																					H-12
																					H-13
																					H-14
																					H-15
																					H-16
																					H-17
																					H-18
																					H-19
																					H-20
																					H-21
																					H-22
																					H-23
																					H-24
																					H-25
																					H-26
																					H-27
																					H-28
																					H-29
																					H-30
																					H-31

H-1 Speeds of all work equipment, swing, travel are slow or lack power

- ★ Carry out troubleshooting in the H/O mode.
- ★ Check that no abnormal noise is being generated from the main pump before carrying out troubleshooting. (If there is any abnormal noise, carry out troubleshooting for H-4.)




- ★ Measuring servo piston inlet port pressure in Item No. 4
 - Measure the input pressure to the large diameter end of the servo piston when the arm is relieved in the power max. mode. (Approx. 12.7 MPa (130 kg/cm²))
Basically, the pressure at the large diameter end is approx. 2/5 of the small diameter end. (For details, see TESTING AND ADJUSTING.)

TROUBLESHOOTING**H-1**

	Cause	Remedy
	Defective adjustment of TVC valve	Adjust
	Defective servo assembly (defective TVC valve)	Repair or replace
	Defective piston pump	Repair or replace
	Defective servo assembly (defective LS valve)	Repair or replace
	Defective piston pump (servo piston)	Repair or replace
	Defective operation of LS-EPC solenoid valve	Replace
	Defective operation of main relief assembly (valve which becomes normal when adjusted)	Adjust
	Defective operation of unload valve (valve which becomes normal when replaced)	Replace
	Defective operation of main relief valve	Replace
	Defective hydraulic equipment in control pump circuit (See TESTING AND ADJUSTING)	Repair or replace

H-2 There is excessive drop in engine speed, or engine stalls

- ★ Carry out troubleshooting in the H/O mode.
- ★ Check that the main relief pressure is normal.




Note 1: Replace the servo valve assembly on the defective side with a new part, and if the engine speed is lower than the reference value below, carry out troubleshooting for S mode (engine). If it is higher, it can be judged that the TVC valve (servo valve assembly) is defective, so replace it.


- ★ Engine speed (reference) at arm IN relief when engine and pump are normal

Engine speed at arm IN relief	Conditions
1,740 ± 100rpm	• Engine at high idling • Power max. mode • L.H. knob switch ON

H-3 No work equipment, travel, swing move



H-4 Abnormal noise generated (around pump)



H-5 Auto-deceleration does not work (when PPC shuttle valve is cause)

- ★ The control pressure for the travel and swing passes through the PPC shuttle valve and is supplied to the pressure switch.


		Cause	Remedy
Does condition become normal when pressure switch is replaced? 1 YES NO	YES	Defective pressure switch	Replace
	NO	Defective operation of PPC shuttle valve in applicable system (swing or travel)	Repair or replace

H-6 Fine control ability is poor or response is poor

		Cause	Remedy	
Is output pressure of LS-EPC normal? • Engine speed: Max. 1350 rpm • Output pressure: 2.2 ± 0.2 MPa (22 ± 2 kg/cm²)	1 YES	Is throttle in LS circuit clogged?		
	2 YES		Clogged throttle in LS circuit	Clean
	NO		Defective servo valve assembly (LS valve), or defective servo piston	Replace
	NO		Defective LS-EPC valve	Repair or replace

H-7 Boom is slow or lacks power

- ★ When travel and swing speeds are normal.
- ★ Carry out troubleshooting in the H/O mode.




Note 1: If auto-deceleration is canceled when boom RAISE or boom LOWER is operated, system is normal.

Note 2: After inspection, do not forget to return the interchanged valves to the original position.

			Cause	Remedy
7 YES Is operating pressure normal when boom RAISE is being operated? • 15.7 ± 1.0 MPa (160 ± 10 kg/cm ²) • Engine at high idling • At max. reach, no load	High		Defective operation of boom lock valve	Correct or replace
	Low		Defective boom cylinder piston packing	Correct or replace
	NO		Defective operation of LS shuttle valve (LS shuttle for R.H. travel or bucket)	Correct or replace
8 YES Is pump merge/divider solenoid valve output pressure normal? • When boom is raised: 0 MPa (0 kg/cm ²)			Defective operation of pump merge/divider valve or LS pump merge/divider valve	Correct or replace
			Defective operation of pump merge/divider solenoid valve	Correct or replace
	NO		Defective boom lock valve or suction valve for boom in control valve	Replace
			Defective operation of boom lock valve	Correct or replace
			Defective operation of boom regeneration valve	Correct or replace
			Defective operation of boom pressure compensation valve or pressure compensation piston (for boom RAISE end, check boom Hi also)	Correct or replace
			Defective operation of control valve spool (for boom RAISE end, check boom Hi spool also)	Correct or replace
			Defective PPC valve	Replace
			Defective boom RAISE or boom LOWER pressure switch	Replace

H-8 Arm is slow or lacks power

- ★ When travel and swing speeds are normal.
- ★ Carry out troubleshooting in the H/O mode.




Note 1: If the auto-deceleration is canceled when arm IN or arm OUT is operated, the system is normal.

Note 2: After inspection, do not forget to return the interchanged valves to the original position.

		Cause	Remedy
7 YES Is leakage from arm cylinder normal? • Max. 20 cc/min • Engine at high idling	YES	Defective operation of arm regeneration valve	Correct or replace
	NO	Defective arm cylinder piston packing	Correct or replace
		Defective operation of LS shuttle valve (LS shuttle for L.H. travel, boom, R.H. travel or bucket)	Correct or replace
		Defective safety-suction valve for arm	Replace
		Defective operation of arm pressure compensation valve or pressure compensation piston (for arm Lo and arm Hi)	Correct or replace
		Defective operation of control valve spool (for arm Lo and arm Hi)	Correct or replace
		Defective PPC valve	Replace
		Defective arm IN or arm OUT pressure switch	Replace

H-9 Bucket is slow or lacks power

★ When travel and swing speeds are normal.



Note 1: If the auto-deceleration is canceled when bucket CURL or bucket DUMP is operated, the system is normal.

Note 2: After inspection, do not forget to return the interchanged valves to the original position.

H-10 Work equipment (boom, arm, bucket) does not move (but travel and swing are normal)

- ★ When boom, arm, and bucket are each operated independently.

1 YES Is output pressure of PPC valve normal?		Defective control valve spool	Correct or replace
• Min. 2.7 MPa (28 kg/cm²) • Engine at high idling	NO	Defective PPC valve	Replace

H-11 Excessive hydraulic drift (boom, arm, bucket)

1) Excessive hydraulic drift of boom


1 Does speed of downward movement become faster when lever is operated?	YES	Defective hydraulic cylinder piston packing	Replace
• See TESTING AND ADJUSTING. • It is also possible to measure leakage of cylinder. • Max. 20 cc/min • At relief • Engine at high idling	NO 2 YES Does condition become normal when safety-suction valve is interchanged?	Defective operation of safety-suction valve	Replace
	NO	Defective operation of boom lock valve	Correct or replace

2) Excessive hydraulic drift of arm or bucket

1 Does speed of downward movement become faster when lever is operated?	YES	Defective hydraulic cylinder piston packing	Replace
• See TESTING AND ADJUSTING. • It is also possible to measure leakage of cylinder. • Max. 20 cc/min • At relief • Engine at high idling	NO 2 YES Does condition become normal when safety-suction valve is interchanged?	Defective operation of safety-suction valve	Replace
	NO 3 YES Is slipper seal of pressure compensation valve damaged? Or does pressure compensation piston move smoothly?	Defective control valve spool	Replace
	NO • It is also possible to interchange with other compensation valve. • See Note 1.	Damaged slipper seal of pressure compensation valve, or defective operation of pressure compensation piston	Correct or replace

Note 1: After inspection, do not forget to return the interchanged valves to the original position.

H-12 Excessive time lag (engine at low idling)



Note 1: Output pressure of LS-EPC solenoid

- 2.2 ± 0.2 MPa (22 ± 2 kg/cm²) is output from the LS-EPC solenoid when the engine is at low idling (approx. 1350 rpm or below) regardless of the working mode.

Note 2: After inspection, do not forget to return the interchanged valves to the original position.

H-13 Other equipment moves when single circuit is relieved

Cause	Remedy
Defective operation of pressure compensation valve slipper seal (The slipper seal in the pressure compensation valve of the circuit that moved is defective.)	Replace

H-14 In L/O, F/O modes, work equipment speed is faster than specified speed

		Cause	Remedy
Is output pressure of LS-EPC solenoid valve normal? • See Note 1.	1 YES	Defective LS valve	Correct or replace
	NO	Defective operation of LS-EPC solenoid valve	Correct or replace

Note 1: Output pressure of LS control EPC solenoid (travel OFF)

- 2.2 ± 0.2 MPa (22 ± 2 kg/cm²) is output from the LS-EPC solenoid when the engine is at low idling (approx. 1350 rpm or below) regardless of the working mode.

H-15 Defective actuation of machine 2-stage pressure relief

★ When electrical system is normal.

		Cause	Remedy
Is output pressure of machine 2-stage pressure relief solenoid valve as shown in Table 1? • Engine at high idling • For details of the measurement procedure, see TESTING AND ADJUSTING.	1 YES	Defective safety valve	Replace
	NO	Defective operation of solenoid valve	Correct or replace

Table 1

Machine 2-stage pressure relief switch	Oil pressure MPa (kg/cm ²)
① Low pressure setting	$2.9^{+0.5}_{-0.3}$ (30^{+5}_{-3})
② High pressure setting	0


H-16 In compound operations, work equipment with larger load is slow

Cause	Remedy
Defective operation of pressure compensation valve	Replace (replace pressure compensation valve on side where load is lower)

	Combination of compound operation	Side where load is larger
1	Boom RAISE + arm IN	Boom RAISE
2	Boom RAISE + arm OUT	Arm OUT
3	Boom RAISE + bucket CURL	Boom RAISE
4	Arm OUT + bucket CURL	Arm OUT
5	Boom LOWER + arm OUT	Arm OUT

H-17 In swing + boom RAISE, boom RAISE is slow

- ★ If swing and boom RAISE work normally when operated independently.
- ★ Carry out troubleshooting with the swing priority mode OFF.

**H-18 In swing + arm, arm is slow**

- ★ See H-17.

(If the operation is normal when the swing and arm are operated independently, carry out troubleshooting with the swing priority mode OFF.

If the Cause column shows that there is defective operation of the LS shuttle valve, the cause is in the shuttle valve for the arm OUT, IN and LS select.)

H-19 In swing + travel, travel speed drops excessively

- ★ See H-17.


(If the operation is normal when the swing and travel are operated independently, carry out troubleshooting with the swing priority mode OFF.

If the Cause column shows that there is defective operation of the PPC shuttle valve, the cause is in the shuttle valve for the LS select.)

H-20 Travel deviation

- ★ Carry out troubleshooting in the H/O mode.
- ★ When swing and work equipment speeds are normal.

a) When there is deviation in normal travel




- Note 1:
- Remove the PPC shuttle block inlet hose, fit an adapter, and block the tip.
 - If the adapter for blocking the circuit is not available, interchange the travel PPC hoses with the PPC hoses for the bucket (CURL, DUMP), boom (LOWER), or arm (IN) at both the inlet and outlet ports of the shuttle block, and check operation.

b) Excessive travel deviation when starting

Cause	Remedy
Defective operation of travel counterbalance valve	Correct or replace
Clogging of throttle inside servo of front or rear pump	Correct or replace

H-21 Travel speed is slow

- ★ Check that the spool of the travel PPC valve is moving the full stroke before carrying out troubleshooting.
- ★ Carry out troubleshooting in the H/O mode.
- ★ When swing and work equipment speeds are normal.



- Note 1: • Measure the travel speed under no load or measure the time taken to travel 20 m. (See MAINTENANCE STANDARD FOR CHASSIS RELATED PARTS.)
- When measuring the speed of the travel motor under no load → Remove connector of LS control EPC solenoid, and measure travel speed in Lo and Hi.

Note 2: Output pressure of LS-EPC solenoid

unit: MPa (kg/cm²)

Engine speed (rpm) \ Travel speed	Lo	Mi	Hi
Max. 1,200	2.2 ± 0.2 (22.0 ± 2.0)	2.2 ± 0.2 (22.0 ± 2.0)	2.2 ± 0.2 (22.0 ± 2.0)
Max. 1,550	0.6 ± 0.2 (6.7 ± 2.0)	2.9 ± 0.2 (30.0 ± 2.0)	0.6 ± 0.2 (6.7 ± 2.0)
Max. 1,650	0.3 ± 0.2 (3.3 ± 2.0)	2.9 ± 0.2 (30.0 ± 2.0)	0.3 ± 0.2 (3.3 ± 2.0)

		Cause	Remedy
		Defective operation of LS shuttle valve (for bucket)	Correct or replace
		Defective operation of LS-EPC solenoid valve	Correct or replace
		Defective travel pressure switch	Replace
		Defective operation of travel suction valve for control valve	Correct or replace
		Defective travel motor assembly	Correct or replace
		Defective pressure compensation valve, or defective operation of pressure compensation piston	Correct or replace
		Defective operation of travel spool for control valve	Correct or replace
		Defective operation of junction valve	Correct or replace
		Defective PPC shuttle	Correct or replace
		Defective PPC valve	Replace

8 YES

Does condition become normal when travel suction valve for control valve is replaced?

• See Note 1.

NO


Note 3: After inspection, do not forget to return the interchanged valves to the original position.

Note 4: • Remove the PPC shuttle block inlet hose, fit an adapter, and block the tip.

- If the adapter for blocking the circuit is not available, interchange the travel PPC hoses with the PPC hoses for the bucket (CURL, DUMP), boom (LOWER), or arm (IN) at both the inlet and outlet ports of the shuttle block, and check operation.

H-22 Steering does not turn easily or lacks power

★ Carry out troubleshooting in the H/O mode.





H-23 Travel speed does not switch or is faster than specified speed

★ Carry out troubleshooting in the H/O mode.





Table 1. Output pressure of LS-EPC solenoid

Unit: MPa (kg/cm²)


Travel speed	Lo	Mi	Hi
LS-EPC output pressure	0.2 ± 0.2 (2.0 ± 2.0)	2.9 ± 0.2 (30.0 ± 2.0)	0.2 ± 0.2 (2.0 ± 2.0)
Remarks	- Engine at high idling - Operate travel lever slightly (auto-deceleration cancel position)		

H-24 Travel does not move (one side only)




H-25 Does not swing

a) Does not swing to either left or right




b) Does not swing in one direction



H-26 Swing acceleration is poor or swing speed is slow

- ★ Carry out troubleshooting in the H/O mode.
- ★ If condition is normal when work equipment is operated independently.

a) Swing acceleration is poor




Note 1: • Remove the PPC shuttle block inlet hose, fit an adapter, and block the tip.
• If the adapter for blocking the circuit is not available, interchange the swing PPC hoses with the PPC hoses for the bucket (CURL, DUMP), at both the inlet and outlet ports of the shuttle block, and check operation.

Note 2: After inspection, do not forget to return the interchanged valves to the original position.

	Cause	Remedy
	Defective swing motor assembly	Replace
	Defective operation of LS shuttle valve (all LS shuttles)	Correct or replace
	Defective operation of swing motor safety-suction valve	Correct or replace
	Defective operation of pressure compensation valve or compensation piston	Correct or replace
	Defective operation of control valve spool for swing	Correct or replace
	Defective operation of PPC shuttle valve	Correct or replace
	Defective PPC valve	Replace

H-27 Excessive overrun when stopping swing

a) One direction only



b) Both directions

Cause	Remedy
Defective swing motor	Repair or replace

H-28 Excessive shock when stopping swing (one direction only)


		Cause	Remedy
1 YES Does condition become normal when left and right swing PPC slow return valves are interchanged?	YES	Defective swing PPC slow return valve (check valve)	Correct or replace
	NO	Defective PPC valve	Replace

H-29 Excessive abnormal noise when stopping swing


		Cause	Remedy
1 YES Does condition become normal when swing motor safety-suction valve is cleaned?	YES	Defective operation of swing motor safety-suction valve	Clean
	2 YES Does condition become normal when swing motor safety-suction valve is replaced?	Defective swing motor safety-suction valve	Replace
		Defective swing machinery	Repair or replace
	NO	Defective back pressure valve	Correct or replace

H-30 Excessive hydraulic drift of swing

a) When swing holding brake is released



b) When swing holding brake is applied



H-31 Swing speed is faster than specified swing speed

		Cause	Remedy
Is output pressure of LS-EPC solenoid valve normal? • See Table 1.	1 YES	Defective operation of LS valve	Replace servo assembly
	NO	Defective LS-EPC solenoid	Correct or replace

Table 1. Output pressure of LS-EPC solenoid valve

unit: MPa (kg/cm²)

H/O mode	G/O mode	F/O mode	L/O mode
0.2 ± 0.2 (2.0 ± 2.0)	0.2 ± 0.2 (2.0 ± 2.0)	1.5 ± 0.2 (15.4 ± 2.0)	2.2 ± 0.2 (22.0 ± 2.0)
• Engine at high idling • Travel OFF			

TROUBLESHOOTING OF MACHINE MONITOR SYSTEM (M MODE)

Action taken by monitor panel and condition of machine when abnormality occurs	20-504
Electrical circuit diagram for monitor system	20-506
M-1 [E101] Abnormality in error data is displayed	
[E102] Error in clock data is displayed	20-508
M-2 [E103] Short circuit in buzzer output or contact of 24V wiring harness with buzzer drive harness is displayed	20-509
M-3 [E104] Air cleaner clogging detected is displayed	20-510
M-4 [E106] Drop in engine oil pressure detected is displayed	20-510
M-5 [E108] Engine water temperature 105°C detected is displayed	20-511
M-6 When starting switch is turned ON, none of lamps on monitor panel light up for 3 seconds	20-512
M-7 When starting switch is turned ON, monitor panel lamps all stay lighted up and do not go out	20-514
M-8 When starting switch is turned ON, items lighted up on monitor panel are different from actual machine (model)	20-514
M-9 When starting switch is turned ON (engine stopped), basic check items flash	20-515
M-10 Preheating is not being used but preheating monitor lights up	20-518
M-11 When starting switch is turned ON and engine is started, basic check items flash	20-519
M-12 When starting switch is turned ON (engine stopped), caution items, emergency stop items flash	20-521
M-13 When starting switch is turned ON and engine is started, caution items, emergency stop items flash	20-523
M-14 When starting switch is turned ON (engine stopped), buzzer does not sound for 1 second Caution item flashes but buzzer does not sound	20-526
M-15 No abnormality is displayed on monitor but buzzer sounds	20-526
M-16 Night lighting on monitor panel does not light up (liquid crystal display is normal)	20-527
M-17 Coolant temperature gauge does not rise	20-528
M-18 Coolant temperature gauge does not give any display	20-528
M-19 Fuel level gauge always displays FULL	20-529
M-20 Fuel level gauge does not give any display	20-529
M-21 Swing lock switch is turned ON (LOCK) but swing lock monitor does not light up	20-530
M-22 Swing prolix switch is turned ON (prolix), but swing lock monitor does not flash	20-530
M-23 Service meter does not advance while engine is running	20-531
M-24 When starting switch is at OFF and time switch is pressed, time and service meter are not displayed	20-531
M-25 Defective fuel level sensor system	20-532
M-26 Defective coolant temperature sensor system	20-533

M-27 Defective engine oil level sensor system	20-534
M-28 Defective coolant level sensor system	20-535
M-29 Defective hydraulic oil level sensor system	20-536
M-30 Wiper does not work or switch is not being used but wiper is actuated	20-537
Working light, panel lighting do not light up, or switch is not being used but lights light up.	20.541


ACTION TAKEN BY MONITOR PANEL WHEN ABNORMALITY OCCURS AND PROBLEMS ON MACHINE


User code	Service code	Abnormal system	Nature of abnormality
—	E101	Abnormality in error data	1. Abnormality in internal memory 2. Excess voltage (more than 36V) has occurred 3. Low voltage (less than 12V) has occurred 4. Connector has separated
—	E102	Abnormality in clock data	1. Abnormality in internal clock function 2. Excess voltage (more than 36V) has occurred 3. Low voltage (less than 12V) has occurred 4. Connector has separated
—	E103	Short circuit in buzzer output system	1. Short circuit inside buzzer 2. Power line in contact with wiring harness between monitor (P01 (7) pin) and buzzer 3. Abnormality in monitor panel
—	E104	Air cleaner clogging detected is displayed	1. Air cleaner clogging sensor has detected clogging
—	E106	Drop in engine oil Hi pressure detected is displayed	1. Engine oil pressure sensor has detected drop in oil pressure
—	E108	Engine water temperature 105°C detected is displayed	1. Coolant temperature gauge has detected water temperature of 105°C

ACTION TAKEN BY MONITOR PANEL WHEN ABNORMALITY OCCURS AND PROBLEMS ON MACHINE

TROUBLESHOOTING

Condition when normal (voltage, current, resistance)	Action by controller when abnormality is detected	Problem that appears on machine when there is abnormality
When starting switch is turned ON, keep time switch pressed for 5 seconds to actuate clear function	—	- Service code cannot be cleared - Time becomes 00:00.
	—	- Service code cannot be cleared - Time becomes 00:00. - Clock does not advance.
- Voltage between P01 (7) – chassis Buzzer ON: Max. 1V Buzzer OFF: 20 – 30V ★ When there is a disconnection, E103 is not displayed and the buzzer does not sound	—	Buzzer does not sound
Resistance between P11 (male) – P12 (male): Min. 1 Ω (engine started)	—	If abnormality detection continues, air cleaner clogging caution lamp flashes and buzzer sounds
Resistance between sensor terminal and chassis: Min. 1 MΩ (engine at mid-range speed or above)	—	If abnormality detection continues, engine oil pressure caution lamp flashes and buzzer sounds
Resistance between P07 (1) – (2): Min. 3.156 Ω (engine started)	—	- If abnormality detection continues, coolant temperature caution lamp flashes and buzzer sounds - If abnormality detection continues, engine speed is reduced to low idling





M-1 [E101] Abnormality in error data is displayed [E102] Error in clock data is displayed

- ★ This is not an abnormality. It occurs during troubleshooting when disconnecting and connecting connector P02 (for the monitor panel electrical system), fuse No. 13, connector M14, connector M11, battery relay terminal B, or the battery terminal.
(When the monitor panel power source circuit is shut off with the starting switch turned OFF.)
- ★ If the service code display appears again after the system has been reset, carry out troubleshooting as follows.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.


		Cause	Remedy
Does service code display appear again after system has been reset? 1 YES Is voltage between P02 (8)(14) and chassis normal? 2 YES • Turn starting switch OFF. • 20 - 30 V NO • After resetting system, carry out normal operations for a short time and watch the condition. (See Note 1.)		Defective monitor panel	Replace
		Disconnection, defective contact, short circuit with ground in wiring harness between battery - battery relay B - M11 (1)(2) - H14 (1) - fuse No. 13 - P02 (female) (8)(14)	Repair or replace
		Normal	—

Note 1: Resetting operation:

Turn the starting switch OFF. Then keep the time switch at the back of the monitor panel depressed, switch the starting switch ON again, and keep the time switch depressed for 5 seconds to return the system to normal.

(With this operation, all the service codes in the internal memory are erased.)

M-1 Related electric circuit diagram



BKP00272

M-2 [E103] Short circuit in buzzer output or contact of 24V wiring harness with buzzer drive harness is displayed


- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if an E service code is displayed. (If it is not displayed, the system has been reset.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

		Cause	Remedy
1 Is resistance between P04 (male) (1) – (2), (2) – chassis as shown in the table? • Turn starting switch OFF. • Disconnect P04.	YES		
	2 YES	Defective monitor panel	Replace
	2 NO	Short circuit with power source in wiring harness between P01 (female)(7) and P04 (female)(2) or short circuit in wiring harness between P04 (1) and (2)	Repair or replace
	NO	Defective buzzer	Replace

Table

P04 (male)	Resistance value
Between (1) and (2)	200 – 300 Ω
Between (2) and chassis	Min. 1 MΩ

M-2 Related electric circuit diagram



BKP00273

M-3 [E104] Air cleaner clogging detected is displayed

		Cause	Remedy
1 Is air cleaner clogging caution lamp on monitor flashing?	YES	See M-13 f)	—
	NO	Defective monitor panel	Replace
	NO	Failure in engine system (See Note 1)	—

2

Is "E" service code displayed?

YES
 • Turn starting switch ON.

Note 1: The monitor panel display has returned to normal, but the air cleaner clogging sensor has detected symptoms of clogging in the past, so carry out troubleshooting of the engine to remove the problem.

M-4 [E106] Drop in engine oil Hi pressure detected is displayed

		Cause	Remedy
1 Is engine oil pressure caution lamp on monitor flashing?	YES	See M-13 a)	—
	NO	Defective monitor panel	Replace
	NO	Failure in engine system (See Note 1)	—

2

Is "E" service code displayed?

YES
 • Turn starting switch ON.

Note 1: The monitor panel display has returned to normal, but the engine oil pressure Hi sensor has detected symptoms of a drop in the oil pressure in the past, so carry out troubleshooting of the engine to remove the problem.

M-5 [E108] Engine water temperature 105°C detected is displayed


		Cause	Remedy
1 Does coolant temperature gauge on monitor panel display red range and is caution lamp flashing? YES NO	YES	See M-13 d)	—
	2 Is "E" service code displayed? YES NO	Defective monitor panel	Replace
	• Turn starting switch ON.	Failure in engine system (See Note 1)	

Note 1: The monitor panel display has returned to normal, but the coolant temperature sensor has detected symptoms of the coolant temperature reaching 105°C in the past, so carry out troubleshooting of the engine to remove the problem.

M-6 When starting switch is turned ON, none of the lamps on the monitor panel light up for 3 seconds

- ★ Check that fuses No. 10 and 13 are not blown.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.


a) None of lamps on monitor panel light up



b) Some of lamps on monitor panel do not light up

Cause	Remedy
Defective monitor panel	Replace

M-6 a) Related electric circuit diagram



BKP00274

M-7 When starting switch is turned ON, monitor panel lamps all stay lit up and do not go out


		Cause	Remedy
		Defective monitor panel	Replace

M-8 When starting switch is turned ON, items lit up on monitor panel are different from actual machine (model)

- ★ Immediately after replacing the monitor panel, turn the starting switch OFF, then turn it ON again and check.

		Cause	Remedy
Is display of monitoring code 01 as shown in table? • Turn starting switch ON. • Set to monitoring code 01.	1 YES	Defective monitor panel	Replace
	NO	Go to troubleshooting for C mode (See C-14)	—

Table




M-9 When starting switch is turned ON (engine stopped), basic check items flashes

- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

a) (coolant level) flashes

SAP00519


- ★ Check that the coolant is at the specified level before carrying out troubleshooting.



Table

Short connector	Continuity
Connected	Yes
Disconnected	No

M-9 a) Related electric circuit diagram




BKP00277

b) (engine oil level) flashes


SAP00523

- ★ Check that the engine oil is at the specified level before carrying out troubleshooting.



Table


Chassis ground	Continuity
Connected	Yes
Disconnected	No

M-9 b) Related electric circuit diagram


c) (hydraulic oil level) flashes

SAP00524


★ Check that the hydraulic oil is at the specified level before carrying out troubleshooting.



Table

Chassis ground	Continuity
Connected	Yes
Disconnected	No

M-9 c) Related electric circuit diagram



BKP00279

M-10 Preheating is not being used but lights up (preheating monitor)




SAP00526

- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the the next step.

		Cause	Remedy
Is voltage between starting switch terminal R1 and chassis normal? • Disconnect terminal R1. • Turn starting switch ON. • Max. 1 V	1 YES	Is voltage between P01 (18) and chassis normal?	
	2 YES	Defective monitor panel	Replace
	NO	Short circuit with power source in wiring harness between starting switch R1 - X07 (3) - H13 (6) - P01 (female)(18) or E11 (female)(1) - E08 (3) - H13 (female)(6)	Repair or replace
	NO	Defective starting switch	Replace

M-10 Related electric circuit diagram




BKP00280


M-11 When starting switch is turned ON and engine is started, basic check items flash

- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.
- ★ Check both the alternator system and the engine oil pressure system.

a) Alternator system



M-11 a) Related electric circuit diagram





BKP00282

b) Engine oil pressure system

★ When engine oil pressure is normal.

1) Low-pressure sensor


**M-11 b) Related electric circuit diagram**

BKP00283


M-12 When starting switch is turned ON (engine stopped), caution items, emergency items flash (battery, engine oil pressure lamps do not light up)

- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.
- ★ Check both the alternator system and the engine oil pressure system.

a) Alternator system





M-12 a) Related electric circuit diagram



BKP00282

b) Engine oil pressure sensor system

★ When engine oil pressure is normal.

1) Low-pressure sensor**M-12 b) Related electric circuit diagram**

BKP00283

M-13 When starting switch is turned ON and engine is started, caution items, emergency items flash (when there is no abnormality in engine or items to check before troubleshooting)

- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

a) (engine oil pressure) flashes

SAP00520

- ★ Check that the engine oil pressure is normal before carrying out troubleshooting.

Cause	Remedy
See M-11 b)	—

b) (coolant level) flashes

SAP00519

- ★ Check that the coolant level is normal before carrying out troubleshooting.

Cause	Remedy
See M-9 a)	—

c) (battery charge) flashes


SAP00522

Cause	Remedy
See M-11 a)	—


d) (coolant temperature) flashes

SAP00527

- ★ Check that the coolant temperature is normal before carrying out troubleshooting.




M-13 d) Related electric circuit diagram




e) (fuel level) flashes

SAP00528

- ★ Check that there is fuel before carrying out troubleshooting.




M-13 e) Related electric circuit diagram




BKP00285

f) (air cleaner clogging) flashes
SAP00521

★ Check that the air cleaner is not clogged before carrying out troubleshooting.




M-13 f) Related electric circuit diagram



BKP00286


M-14 When starting switch is turned ON (engine stopped), buzzer does not sound for 1 second Caution item flashes but buzzer does not sound

- ★ Of the caution items, the buzzer will not sound even if there is an abnormality in the battery charge or fuel level.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.




M-15 No abnormality is displayed on monitor but buzzer sounds

- ★ When the buzzer sounds continuously.
If the buzzer sounds intermittently, carry out troubleshooting M-14.)
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.




M-14, 15 Related electric circuit diagram




BKP00273

M-16 Night lighting on monitor panel does not light up (liquid crystal display is normal)

★ When the front lamp and working lamp light up normally.




M-16 Related electric circuit diagram



BKP00287


M-17 Coolant temperature gauge does not rise

- ★ If the coolant temperature actually does not rise, check the engine system.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.




M-18 Coolant temperature gauge does not give any display (none of gauge lamps light up during operation)

- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.




M-17, 18 Related electric circuit diagram



BKP00284


M-19 Fuel level gauge always displays FULL

- ★ Check if the tank is actually full before carrying out troubleshooting.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.




M-20 Fuel level gauge does not give display

- ★ Check that there is actually no fuel before carrying out troubleshooting.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.



M-19, 20 Related electric circuit diagram



BKP00285

M-21 Swing lock switch is turned ON (LOCK) but (swing lock monitor) does not light up


SAT00098

- ★ Carry out this troubleshooting only if the swing lock is actually being actuated.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

1 YES		Defective monitor panel	Replace
Is voltage between P05 and chassis as shown in table?		Defective contact or disconnection in wiring harness between P01 (female) (5) – X01 (4) – X05 (male)	Repair or replace
• Turn starting switch ON.	NO		

M-21 Related electric circuit diagram

Swing lock switch



M-22 Swing prolix switch is turned ON (prolix), but (swing lock monitor) does not flash

SAT00098

BKP00288

- ★ Carry out this troubleshooting only if the swing prolix is actually being actuated.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.


ing on the next step.			
	2 YES		
YES	Is bit (6) of monitoring code 21 lighted up?		Defective monitor panel
1			Replace
Is voltage between C17 (8) and chassis as shown in table?	• Turn starting switch ON.	NO	Defective governor, pump controller
	• Set to monitoring code 21.		Replace
• Turn starting switch ON.	NO	Defective contact or disconnection in wiring harness between C17 (female) (8) and prolix switch (4)	Repair or replace



Table

Swing prolix switch ON	Max. 1 V
Swing prolix switch OFF	20 – 30 V

M-22 Related electric circuit diagram


Swing prolix switch



M-23 Service meter does not advance while engine is running**M-24 When starting switch is at OFF and time switch is pressed, time and service meter are not displayed**


M-25 Defective fuel level sensor system

★ Remove the fuel level sensor when carrying out the troubleshooting.



Table

Top (FULL) stopper position	Approx. 12 Ω or below
Bottom (EMPTY) stopper position	Approx. 85 – 110 Ω



Note 1: Difference between fuel level and gauge display

For gauge display position 14 (FULL), the amount of fuel is 78-100%; and for display position 1 (EMPTY) it is below 14.5%. If the chassis is at an angle, the displayed amount of fuel will be different from the actual amount. Therefore, when checking, stop the machine at a horizontal place and wait for at least 2 minutes before checking the gauge. (The display is given a time delay so that the gauge can deal with sudden changes in the fuel level.)

Note 2: There is the possibility of defective installation or interference with the sensor inside the tank, so be careful when installing.

Note 3: Check for vibration at the connector mount. If there is excessive vibration, take the appropriate action.

M-26 Defective coolant temperature sensor system





Table 1

Normal temperature (20°C)	Approx. 70 ~ 78 kΩ
100°C	Approx. 3 Ω



Note 1: If the problem occurs again, the connector (female) at the chassis end is probably defective, so check the connector and wiring harness at the chassis end.





Note 2: Check for vibration at the connector mount. If there is excessive vibration, take the appropriate action.

M-27 Defective engine oil level sensor system

- ★ Remove the engine oil level sensor when carrying out troubleshooting.
- ★ Connect a 24V power to the oil level sensor '+' (pin C) and '-' (pin B)
- ★ Connect a multi-meter between the 'Sig (pin D) and '-' (pin B).
- ★ Clean any dirt or foreign matter from sensor elements.

Table 1

Submerged	Max. 1 Ω
Not submerged	Min. 1 M Ω



Note1: Variations in oil level.


The oil may change according to the angle of the machine, the engine speed, or the temperature of the oil, so if there is any display check the oil level again with the machine on horizontal ground.

Note 2: If the problem persists, check the connector and wiring harness at the chassis end.

Note 3: Check for vibration at the connector mount. Take the appropriate action for any excessive vibration.


M-28 Defective coolant level sensor system

★ Remove the coolant level sensor when carrying out troubleshooting.



Table

Float UP	Max. 1 Ω
Float DOWN	Min. 1 MΩ



BLP00293

Note 1: Variations in coolant level

The coolant level may change according to the angle of the machine, or the swaying of the machine, so if there is any display, check the coolant level again with the machine at a horizontal place.


Note 2: If the problem occurs again, the connector (female) at the chassis end is probably defective, so check the connector and wiring harness at the chassis end.

Note 3: Check for vibration at the connector mount. If there is excessive vibration, take the appropriate action.

Note 4: Defective installation is a possible cause, so be careful when installing. If the problem occurs again, check for any vibration of the mount, and if there is excessive vibration, take the appropriate action.


M-29 Defective hydraulic oil level sensor system

★ Remove the hydraulic oil level sensor when carrying out troubleshooting.



Table

Float UP	Max. 1 Ω
Float DOWN	Min. 1 MΩ



BLP00292

Note 1: Variations in hydraulic oil level

The hydraulic oil level may change according to the angle of the machine, or the swaying of the machine, so if there is any display, check the hydraulic oil level again with the machine at a horizontal place.

Note 2: If the problem occurs again, the connector (female) at the chassis end is probably defective, so check the connector and wiring harness at the chassis end.


Note 3: Check for vibration at the connector mount. If there is excessive vibration, take the appropriate action.

Note 4: Defective installation is a possible cause, so be careful when installing. If the problem occurs again, check for any vibration of the mount, and if there is excessive vibration, take the appropriate action.

M-25 Working light, panel lighting do not light up, or switch is not being used but lights light up


a) Working light does not light up

- ★ Check that fuse 4 is normal.




b) Panel lighting does not light up


- ★ When the lamp lights up normally.



c) Light switch is not being used but working light lights up



m-25 Related electric circuit diagram



30 DISASSEMBLY AND ASSEMBLY

METHOD OF USING MANUAL	30- 3	SPROCKET	
PRECAUTIONS WHEN CARRYING OUT		Removal and Installation	30- 48
OPERATION	30- 5	SWING MOTOR ASSEMBLY	
SPECIAL TOOL LIST	30- 9	Removal and Installation	30- 49
SKETCHES OF SPECIAL TOOLS	30- 12	SWING MACHINERY ASSEMBLY	
STARTING MOTOR ASSEMBLY		Removal and Installation	30- 50
Removal and Installation	30- 14	Disassembly	30- 51
ALTERNATOR ASSEMBLY		Assembly	30- 55
Removal and Installation	30- 15	REVOLVING FRAME ASSEMBLY	
NOZZLE HOLDER ASSEMBLY		Removal	30- 60
Removal and Installation	30- 16	Instllation	30- 61
THERMOSTAT ASSEMBLY		SWING CIRCLE ASSEMBLY	
Removal and Installation	30- 19	Removal and Installation	30- 62
CYLINDER HEAD ASSEMBLY		IDLER, RECOIL SPRING ASSEMBLY	
Removal	30- 22	Removal and Installation	30- 63
Installation	30- 23	IDLER ASSEMBLY	
HYDRAULIC COOLER ASSEMBLY		Disassembly	30- 64
Removal	30- 27	Assembly	30- 65
RADIATOR, HYDRAULIC COOLER ASSEMBLY		RECOIL SPRING ASSEMBLY	
Removal	30- 28	Disassembly	30- 67
Installation	30- 29	Assembly	30- 68
ENGINE, MAIN PUMP ASSEMBLY		TRACK ROLLER ASSEMBLY	
Removal	30- 30	Removal and Installation	30- 69
Installation	30- 32	Disassembly	30- 70
DAMPER ASSEMBLY		Assembly	30- 71
Removal and Installation	30- 33	CARRIER ROLLER ASSEMBLY	
FUEL TANK ASSEMBLY		Removal and Insallation	30- 73
Removal and Installation	30- 34	Disassembly	30- 74
CENTER SWIVEL JOINT ASSEMBLY		Assembly	30- 76
Removal and Installation	30- 35	TRACK SHOE ASSEMBLY	
Disassembly and Assembly	30- 36	Removal and Installation	30- 78
FINAL DRIVE ASSEMBLY			
Removal and Installation	30- 37		
Disassembly	30- 38		
Assembly	30- 42		

HYDRAULIC TANK ASSEMBLY		
Removal	30- 79	
Installation	30- 80	
CONTROL PUMP ASSEMBLY		
Removal and Installation	30- 81	
MAIN PUMP ASSEMBLY		
Removal	30- 82	
Installation	30- 83	
MAIN PUMP INPUT SHAFT OIL SEAL		
Removal and Installation	30- 84	
CONTROL VALVE ASSEMBLY		
Removal	30- 85	
Installation	30- 87	
Disassembly	30- 88	
Assembly	30- 92	
PUMP MERGE/DIVIDER VALVE ASSEMBLY		
Disassembly and Assembly	30- 97	
PRESSURE COMPENSATION VALVE ASSEMBLY		
Disassembly and Assembly	30- 98	
SERVO VALVE ASSEMBLY FOR FRONT PUMP		
Removal and Installation	30- 99	
SERVO VALVE ASSEMBLY FOR REAR PUMP		
Removal and Installation	30-100	
LS-EPC SOLENOID VALVE ASSEMBLY		
Removal and Installation	30-101	
SOLENOID VALVE ASSEMBLY		
Removal and Installation	30-102	
WORK EQUIPMENT PPC VALVE ASSEMBLY		
Removal and Installation	30-103	
Disassembly	30-104	
Assembly	30-105	
TRAVEL PPC VALVE ASSEMBLY		
Removal and Installation	30-106	
Disassembly	30-107	
Assembly	30-108	
PPC SHUTTLE VALVE ASSEMBLY		
Removal	30-109	
Installation	30-110	
Disassembly	30-111	
Assembly	30-112	
BOOM CYLINDER ASSEMBLY		
Removal	30-113	
Installation	30-114	
ARM CYLINDER ASSEMBLY		
Removal	30-115	
Installation	30-116	
BUCKET CYLINDER ASSEMBLY		
Removal	30-117	
Installation	30-118	
HYDRAULIC CYLINDER ASSEMBLY		
Disassembly	30-119	
Assembly	30-121	
WORK EQUIPMENT ASSEMBLY		
Removal	30-123	
Installation	30-124	
BUCKET ASSEMBLY		
Removal	30-125	
Installation	30-126	
ARM ASSEMBLY		
Removal	30-127	
Installation	30-128	
BUCKET, ARM ASSEMBLY		
Removal	30-129	
Installation	30-130	
BOOM ASSEMBLY		
Removal	30-131	
Installation	30-132	
OPERATOR'S CAB ASSEMBLY		
Removal	30-133	
Installation	30-134	
COUNTERWEIGHT ASSEMBLY		
Removal and Installation	30-135	
GOVERNOR, PUMP CONTROLLER ASSEMBLY		
Removal and Installation	30-137	
MONITOR PANAL ASSEMBLY		
Removal and Installation	30-138	
CONTROL STAND CASE		
Removal	30-139	
Installation	30-140	

METHOD OF USING MANUAL

1. When removing or installing unit assemblies

- ① When removing or installing a unit assembly, the order of work and techniques used are given for the removal operation; the order of work for the installation operation is not given.
- ② Any special techniques applying only to the installation procedure are marked ※ 1, and the same mark is placed after the relevant step in the removal procedure to indicate which step in the installation procedure it applies to.

(Example)

REMOVAL OF ○○○○ ASSEMBLY Title of operation



..... Precautions related to safety when carrying out the operation

1. XXXX (1) Step in operation

★ Technique or important point to remember when removing XXXX (1).

2. △△△△ (2): ※ 1 Indicates that a technique is listed for use during installation

3. □□□□ assembly (3)



..... Quantity of oil or water drained

INSTALLATION OF ○○○○ ASSEMBLYTitle of operation

- Carry out installation in the reverse order to removal.

※ 1 Technique used during installation

★ Technique or important point to remember when installing △△△△ (2).

- Adding water, oil Step in operation

★ Point to remember when adding water or oil



..... Quantity when filling with oil and water

2. General precautions when carrying out installation or removal (disassembly or assembly) of units are given together as PRECAUTIONS WHEN CARRYING OUT OPERATION, so be sure to follow these precautions when carrying out the operation.


3. Listing of special tools

- ① For details of the description, part number, and quantity of any tools (A1, etc.) that appear in the operation procedure, see the SPECIAL TOOLS LIST given in this manual.

4. General tightening torque table (when using torque wrench)

★ In the case of metric nuts and bolts for which there is no special instruction, tighten to the torque given in the table below.

Thread diameter	Width across flats		
		SAD00481	SAD00482
mm	mm	kgm	Nm
6	10	1.35 ± 0.15	13.2 ± 1.4
8	13	3.2 ± 0.3	31.4 ± 2.9
10	17	6.7 ± 0.7	65.7 ± 6.8
12	19	11.5 ± 1.0	112 ± 9.8
14	22	18.0 ± 2.0	177 ± 19
16	24	28.5 ± 3	279 ± 29
18	27	39 ± 4	383 ± 39
20	30	56 ± 6	549 ± 58
22	32	76 ± 8	745 ± 78
24	36	94.5 ± 10	927 ± 98
27	41	135 ± 15	1320 ± 140
30	46	175 ± 20	1720 ± 190
33	50	225 ± 25	2210 ± 240
36	55	280 ± 30	2750 ± 290
39	60	335 ± 35	3280 ± 340



SAD00483

5. Table of tightening torques for flared nuts

★ In the case of flared nuts for which there is no special instruction, tighten to the torque given in the table below.

Thread diameter	Width across flats	Tightening torque	
		kgm	Nm
mm	mm		
14	19	2.5 ± 0.5	24.5 ± 4.9
18	24	5 ± 2	49 ± 19.6
22	27	8 ± 2	78.5 ± 19.6
24	32	14 ± 3	137.3 ± 29.4
30	36	18 ± 3	176.5 ± 29.4
33	41	20 ± 5	196.1 ± 49
36	46	25 ± 5	245.2 ± 49
42	55	30 ± 5	294.2 ± 49

6. Table of tightening torques for split flange bolts

★ In the case of split flange bolts for which there is no special instruction, tighten to the torque given in the table below.

Thread diameter	Width across flats	Tightening torque	
		kgm	Nm
mm	mm		
10	14	6.7 ± 0.7	65.7 ± 6.8
12	17	11.5 ± 1	112 ± 9.8
16	22	28.5 ± 3	279 ± 29

PRECAUTIONS WHEN CARRYING OUT OPERATION

[When carrying out removal or installation (disassembly or assembly) of units, be sure to follow the general precautions given below when carrying out the operation.]

1. Precautions when carrying out removal work

- If the coolant contains antifreeze, dispose of it correctly.
- After disconnecting hoses or tubes, cover them or fit blind plugs to prevent dirt or dust from entering.
- When draining oil, prepare a container of adequate size to catch the oil.
- Confirm the match marks showing the installation position, and make match marks in the necessary places before removal to prevent any mistake when assembling.
- To prevent any excessive force from being applied to the wiring, always hold the connectors when disconnecting the connectors. Do not pull the wires.
- Fit wires and hoses with tags to show their installation position to prevent any mistake when installing.
- Check the number and thickness of the shims, and keep in a safe place.
- When raising components, be sure to use lifting equipment of ample strength.
- When using forcing screws to remove any components, tighten the forcing screws uniformly in turn.
- Before removing any unit, clean the surrounding area and fit a cover to prevent any dust or dirt from entering after removal.

★ Precautions when handling piping during disassembly

Fit the following blind plugs into the piping after disconnecting it during disassembly operations.

1) Hoses and tubes using sleeve nuts


Nominal number	Plug (nut end)	Sleeve nut (elbow end) Use the two items below as a set
02	07376-50210	07221-20210 (Nut), 07222-00210 (Plug)
03	07376-50315	07221-20315 (Nut), 07222-00312 (Plug)
04	07376-50422	07221-20422 (Nut), 07222-00414 (Plug)
05	07376-50522	07221-20522 (Nut), 07222-00515 (Plug)
06	07376-50628	07221-20628 (Nut), 07222-00616 (Plug)
10	07376-51034	07221-21034 (Nut), 07222-01018 (Plug)
12	07376-51234	07221-21234 (Nut), 07222-01219 (Plug)

2) Split flange type hoses and tubes

Nominal number	Flange (hose end)	Sleeve head (tube end)	Split flange
04	07379-00400	07378-10400	07371-30400
05	07379-00500	07378-10500	07371-30500

3) If the part is not under hydraulic pressure, the following corks can be used.

Nominal number	Part Number	Dimensions		
		D	d	L
06	07049-00608	6	5	8
08	07049-00811	8	6.5	11
10	07049-01012	10	8.5	12
12	07049-01215	12	10	15
14	07049-01418	14	11.5	18
16	07049-01620	16	13.5	20
18	07049-01822	18	15	22
20	07049-02025	20	17	25
22	07049-02228	22	18.5	28
24	07049-02430	24	20	30
27	07049-02734	27	22.5	34



DEW00401

2. Precautions when carrying out installation work

- Tighten all bolts and nuts (sleeve nuts) to the specified (KES) torque.
 - Install the hoses without twisting or interference.
 - Replace all gaskets, O-rings, cotter pins, and lock plates with new parts.
 - Bend the cotter pins and lock plates securely.
 - When coating with adhesive, clean the part and remove all oil and grease, then coat the threaded portion with 2 – 3 drops of adhesive.
 - When coating with gasket sealant, clean the surface and remove all oil and grease, check that there is no dirt or damage, then coat uniformly with gasket sealant.
 - Clean all parts, and correct any damage, dents, burrs, or rust.
 - Coat rotating parts and sliding parts with engine oil.
 - When press fitting parts, coat the surface with anti-friction compound (LM-P).
 - After fitting snap rings, check that the snap ring is fitted securely in the ring groove.
 - When connecting wiring connectors, clean the connector to remove all oil, dirt, or water, then connect securely.
 - When using eyebolts, check that there is no deformation or deterioration, screw them in fully, and align the direction of the hook.
 - When tightening split flanges, tighten uniformly in turn to prevent excessive tightening on one side.
- ★ When operating the hydraulic cylinders for the first time after reassembling cylinders, pumps and other hydraulic equipment removed for repair, always bleed the air as follows:
1. Start the engine and run at low idling.
 2. Operate the work equipment control lever to operate the hydraulic cylinder 4 – 5 times, stopping the cylinder 100 mm from the end of its stroke.
 3. Next, operate the hydraulic cylinder 3 – 4 times to the end of its stroke.
 4. After doing this, run the engine at normal speed.
- ★ When using the machine for the first time after repair or long storage, follow the same procedure.
- 3. Precautions when completing the operation**
- If the coolant has been drained, tighten the drain valve, and add water to the specified level. Run the engine to circulate the water through the system. Then check the water level again.
 - If the hydraulic equipment has been removed and installed again, add engine oil to the specified level. Run the engine to circulate the oil through the system. Then check the oil level again.
 - If the piping or hydraulic equipment have been removed, always bleed the air from the system after reassembling the parts.
 - ★ For details, see TESTING AND ADJUSTING, Bleeding air.
 - Add the specified amount of grease (molybdenum disulphide grease) to the work equipment parts.

SPECIAL TOOL LIST

- ★ Tools with part number 79○T-○○○-○○○○ cannot be supplied (they are items to be locally manufactured).
- ★ New/remodel: N: Tools with new part numbers, newly developed for this model.
- ★ R: Tools with upgraded part numbers, remodeled from items already available for other models.
- ★ Blank: Tools already available for other models, used without any modification.
- ★ Tools marked ○ in the Sketch column are tools introduced in special sketches (See SKETCHES OF SPECIAL TOOLS).

Component	Symbol		Part No.	Part Name	Q'ty	New/ remodel	Sketch	Nature of work, remarks		
Engine assembly	A		790-331-1110	Wrench	1			Removal, installa- tion	Tightening of cylinder head bolt	
Swing machinery assembly	F		796T-626-1110	Push tool	1	N	○	Dis- assembly, assembly	Press fitting of bearing	
Final drive assembly	J	1	796-627-1210	Wrench	1	N		Dis- assembly, assembly	Removal, installa- tion of round nut	
		2	1	796T-627-1230	Push tool	1	N		○	Pushing of bearing inner race
			2	790-101-2510	Block	1				
			3	792-104-3940	Bolt	2				
			4	10580-11613	Nut	2				
			5	790-101-2570	Washer	2				
			6	01643-31645	Washer	1				
			7	790-105-2100	Jack	1				
			8	790-101-1102	Pump	1				
		3	790-331-1110	Wrench	1				Tightening of cover bolt	
		4	791-580-1510	Installer	1				Installation of floating seal	
Idler assembly	L	1	796-570-1020	Installer	1		Dis- assembly, assembly	Installation of floating seal		
2		791-601-1000	Oil pump	1				Charging with oil		
Track roller assembly		3	796-670-1010	Installer	1			Dis- assembly, assembly	Installation of floating seal	
		4	791-601-1000	Oil pump	1				Charging with oil	
Carrier roller assembly			5	790-302-1500	Wrench kit	1		Dis- assembly, assembly	Removal, installation of nut	
				• 09003-05560	• Wrench	1				Installation of floating seal
			6	796-670-1020	Installer	1				Press fitting of ring
			7	796T-630-1130	Push tool	1	N		○	Charging with oil
	8		791-601-1000	Oil pump	1					
Recoil spring assembly	M	1	791-685-8005	Compressor B	1		Dis- assembly, assembly	Removal, installation of recoil spring		
			791-635-3160	Extension	1					
			790-101-1600	Cylinder (686kN(70t))	1					
			790-101-1102	Oil pump	1					

DISASSEMBLY AND ASSEMBLY
SPECIAL TOOL LIST

Component	Symbol		Part No.	Part Name	Q'ty	New/ remodel	Sketch	Nature of work, remarks	
Recoil spring assembly	M	2	790-201-1500	Push tool kit	1			Dis-assembly, assembly	Installation of piston dust seal
			• 790-201-1650	• Plate	1				
			• 790-101-5021	• Grip	1				
			• 01010-50816	• Bolt	1				
Track shoe assembly	R		791-646-3000	Remover, installer	1			Removal, installation	Removal, press fitting of master pin
			790-101-1300	Cylinder	1				
			790-101-1102	Pump	1				
Hydraulic pump assembly	S	1	796-660-1200	Oil stopper assembly	1	N	Removal, installation	Shutting off hydraulic oil	
			• 796-460-1210	• Oil stopper	1				
			• 796-660-1210	• Rod	1	N			
			• 20Y-60-21330	• Rod assembly	1				
		2	790-201-2700	Push tool kit	1				Press fitting of shaft oil seal
			• 790-201-2740	• Spacer	1				
Center swivel joint assembly	T		790-101-2501	Push tool kit	1			Dis-assembly, assembly	Disconnection of shaft and rotor
			• 790-101-2510	• Block	1				
			• 790-101-2520	• Screw	1				
			• 791-112-1180	• Nut	1				
			• 790-101-2540	• Washer	1				
			• 790-101-2630	• Leg	2				
			• 790-101-2570	• Plate	4				
			• 790-101-2560	• Nut	2				
			• 790-101-2650	• Adapter	2				
Hydraulic cylinder assembly	U	1	790-502-1003	Cylinder repair stand	1			Dis-assembly, assembly	Securing of cylinder
		2	790-720-1000	Expander	1				Installation of piston ring
		3	790-720-1680	Ring	1				
			07281-01589	Clamp	1				Press fitting of coil bushing
		4	790-201-1702	Push tool kit	1				Boom, bucket
			• 790-201-1851	• Push tool	1				
			• 790-201-1861	• Push tool	1				
			• 790-101-5021	• Grip	1				
			• 01010-50816	• Bolt	1				


DISASSEMBLY AND ASSEMBLY
SPECIAL TOOL LIST

Component	Symbol		Part No.	Part Name	Q'ty	New/ remodel	Sketch	Nature of work, remarks	
Hydraulic cylinder assembly	U	5	790-201-1500	Push tool kit	1			Dis-assembly, assembly	Installation of dust seal
			• 790-201-1660	• Plate	1				Boom, bucket
			• 790-201-1670	• Plate	1				Arm
			• 790-101-5021	• Grip	1				
			• 01010-50816	• Bolt	1				
Work equipment assembly, boom assembly	V		796-670-1100	Remover assembly	1	N		Removal, installation	Removal of boom foot pin
			• 796-670-1110	• Sleeve	1	N			
			• 796-670-1120	• Plate	1	N			
			• 796-670-1130	• Screw	1	N			
			• 791-775-1150	• Adapter	1				
			• 01643-33080	• Washer	1				
			• 01803-13034	• Nut	1				
			790-101-4000	Puller	1				
			790-101-1102	Pump	1				

SKETCHES OF SPECIAL TOOLS


Note: Komatsu cannot accept any responsibility for special tools manufactured according to these sketches.

F Push tool




020706

J2-1 Push tool





L7 Push tool



REMOVAL OF STARTING MOTOR ASSEMBLY

⚠ Disconnect the cable from the negative (-) terminal of the battery.

1. Open engine hood.
2. Remove engine undercover.
3. Remove starting motor wiring harness cover.
4. Disconnect starting motor harnesses
5. Remove 3 mounting bolts, then remove starting motor assembly (4).



INSTALLATION OF STARTING MOTOR ASSEMBLY

1. Apply a coat of Three Bond Sealant to the starter mounting surface and both sides of the spacer and starting motor gasket, if equipped.
2. Coat the starting motor capscrews with Loctite™ pipe sealant PST.

Install the starting motor. Tighten the starting motor capscrews.

Torque Value: 77 N•m [57 ft-lb]

NOTE: Starting motor capscrews that are precoated with Vibra-Seal require a lower torque.

Torque Value: 68 N•m [50 ft-lb]

REMOVAL OF ALTERNATOR ASSEMBLY

⚠ Disconnect the cable from the negative (-) terminal of the battery.




1. Open the engine hood.
2. Disconnect alternator wiring.
3. Remove drive belt (1) by,
 - a) Place a 3/8 in. drive ratchet in the 3/8 in. drive hole in the belt tensioner.
 - b) Push the ratchet (2) in the direction shown to release the belt tension.
 - c) Remove the belt.

NOTE: The belt tensioner is spring loaded and must be pivoted away from the belt. Pivoting the wrong way can result in damage to the tensioner.

4. Remove the alternator brace capscrew (A).
5. Remove the tail support bracket capscrew (B).
6. Remove the alternator mounting capscrews and nuts.
7. Remove the alternator.



INSTALLATION OF ALTERNATOR ASSEMBLY

- Carry out installation in the reverse order to removal.




1. Remove the high pressure fuel lines.


Caution: Cover the injectors and fuel pump high pressure outlet connections to avoid damage from contamination.




2. Remove the fuel drain manifold. Discard the sealing washers.



3. Remove the injectors.



4. Remove and discard the sealing washers.




Injector - Installation


1. Lubricate the sealing lips of the sleeve with anti-seize compound. Assemble the injector, sealing sleeve, a new copper sealing washer and the hold-down clamp.

Use only one washer.


Service Tip: A light coat of clean 15W-40 engine oil between the washer and injector will aid in holding the washer in place during installation.



2. Install the injector assembly into the injector bore. The injector leak-off connection must be toward the valve cover.




3. Install the holddown capscrew.
Torque Value: 24 N•m [18 ft-lb]



4. Install the fuel drain manifold and new copper sealing washer as illustrated.
Torque Value: 9 N•m [80 in-lb]


NOTE: The banjo connector seal (siamese washer) must be installed as illustrated.



5. Install new sealing washers and connect the drain manifold to the fuel filter head.

Torque Value:

Filter Head Banjo	15 N•m [11 ft-lb]
Injector Banjo	9 N•m [80 in-lb]



6. Loosen the vibration isolator capscrews so the fuel lines can be easily moved.

NOTE: To prevent breakage to the fuel lines, they must be connected to the injector and fuel injection pump in a “free state” without forcing the connecting nuts. Since the fuel lines are properly sized for specific application, bending should not be necessary.

⚠ Caution: If removed, install the support clamp in the original position and make sure the lines do not contact each other or another component.




7. Install the high pressure fuel lines in the reverse order of removal.

NOTE: Thoroughly clean the high pressure fuel lines to make sure no debris is present before installing the fuel lines onto the injectors of fuel injection pump.

8. Tighten all high pressure fuel line fittings and mounting hardware.

Torque Value:






1. Line Fittings 24 N•m [18 ft-lb]
2. Support Bracket Capscrews 24 N•m [18 ft-lb]
3. Vibration Isolator Capscrews 6 N•m [53 in-lb]



REMOVAL**Preparatory Steps:**






- a. Disconnect the battery
 - b. Drain coolant
 - c. Remove the radiator hose from the outlet connection.
 - d. Remove the drive belt.
1. Loosen the alternator link capscrew. (See fig. 1)
 2. Loosen the tail support capscrew if the alternator is so equipped. (See fig. 1)
 3. Remove the alternator mounting bolts and nuts. Lower the alternator. (See fig. 2)
 4. Remove the capscrews from the thermostat housing and water outlet connection. Remove the water outlet connection. (See fig. 3)
 5. Remove the thermostat housing and belt tensioner assembly. (See fig. 4)
 6. Remove the thermostats and clean the gasket surfaces. (See fig. 5)

⚠ **Caution:** Do not let any debris fall into the thermostat cavity when cleaning gasket surfaces.



Installation

- 1 Install the new thermostats. (See fig. 1)
- 2 Position a new gasket over the thermostats. (See fig. 2)
- 3 Position the thermostat housing and belt tensioner over the thermostats and gasket. (See fig. 4)
- 4 Make sure the gasket is aligned with the capscrew holes. Install the capscrews and use your fingers to tighten. (See fig. 4)
- 5 Install the water outlet connection. (See fig. 5)
- 6 Tighten all capscrews. (See fig. 5)
Torque Value: 24 N•m [18 ft-lb]



DISASSEMBLY AND ASSEMBLY

THERMOSTAT

8. Position the alternator and install the mounting bolts and nuts.





Torque Value:

(Alternator Mounting)	77 N•m	[57 ft-lb]
(Alternator Link)	43 N•m	[32 ft-lb]

9. Install the drive belt.
10. Install and tighten the battery electrical connections.
11. Fill the cooling system.

⚠ Caution: During filling, air must be vented from the engine coolant passages. Open the engine vent petcock if equipped. Also, be sure to open the petcock on the aftercooler for aftercooled engines. The system must be filled slowly to prevent air locks. Wait 2 to 3 minutes to allow air to be vented, then add coolant to bring the level to the bottom of the radiator filler neck.

12. Operate the engine normal operating temperature and check for leaks, and coolant level.



REMOVAL

- ⚠ **Disconnect the cable from the negative (-) terminal of the battery.**

1. Drain the cooling system.
 - Remove the turbocharger and piping.
 - Remove the aftercooler.
 - Remove the exhaust manifold.
 - Remove the fuel lines and injector nozzles
 - Remove the valve cover, rocker lever assemblies and push rods.
 - Remove the fuel filters.
 - Remove the fan hub.
 - Remove the alternator.
 - Remove the belt tensioner.

NOTE:

It may be easier to remove the thermostat housing to gain access to the exhaust manifold capscrew for No. 1 cylinder.

2. Remove the thermostat housing/coolant outlet assembly.
3. Disconnect the coolant vent tube.
4. Remove the cylinder head capscrews in the sequence shown in fig. 4.






The component weighs 23 kg [50 lb] or more. To avoid personal injury, use a hoist or get assistance to lift the component.

Use a hoist or hydraulic arm to remove the cylinder head.

Make sure the head is removed in a direct upward motion.

5. Remove the cylinder head gasket.

NOTE: Place the cylinder head on wood blocks to prevent damage to the combustion face.



Installation

Place clean lint-free rags over the pistons to prevent dirt from falling into the engine.

Plug or cover the coolant and oil passages in the cylinder block deck.

1. Use a gasket scraper to clean the cylinder block deck surface.

Caution: When using compressed air to clean capscrew holes, always wear safety glasses or a face shield to protect the eyes. Personal injury can result.

NOTE: Make sure the cylinder head capscrew holes are clean.

2. Use compressed air to clean from the capscrew holes.

Remove all rags, plugs or covers from pistons, coolant and oil passages.

NOTE: Make sure the new head gasket is correctly aligned with the holes in the cylinder block.

The cylinder block and head must be clean and dry.

3. Position the gasket onto the dowels.

Caution: Do not drop the cylinder head on the cylinder head gasket. The gasket material can be damaged.

4. Carefully install the cylinder head onto the gasket and cylinder block.

NOTE: Use clean 15W-40 oil to coat the cylinder head capscrew threads and underneath the head flange.

Allow the excess oil to drain from the capscrew threads.

5. Install the capscrews in the cylinder head.

NOTE: Be sure to install the six capscrews into the holes underneath the injectors.

NOTE: The top of the cylinder head capscrew is identified with an angle marking. The cylinder head capscrews must be tightened by using the tree-step "torque plus angle" method, described as follows:

- 5.1. Follow the numbered sequence and tighten all capscrews.

Torque Value: (Step One) 70 N•m [52-ft-lb]

Follow the numbered sequence and check the torque on all capscrews again.

FIG. 1




FIG. 2




FIG. 3




FIG. 4





FIG. 5



DISASSEMBLY AND ASSEMBLY**CYLINDER HEAD**

- 5.2. Follow the numbered sequence and tighten only the 12 long capscrews:

Torque Value: (Step Two) 145 N•m [105 ft-lb]

Follow the numbered sequence and check the torque on all long capscrews again.

- 5.3. Torque Value: (Step Three)

Follow the numbered sequence and turn all the capscrews 90 degrees as indicated on the capscrew head.

To accurately turn the capscrew to the desired angle, a small "dot" and a "window" are marked on the capscrew head.

FIG. 6






FIG. 7




6. Mark the cylinder head adjacent to the dot on the capscrew head. This mark will serve as an indexing aid.

FIG. 8



7. Rotate the capscrew until the mark, that has been made on the cylinder head, falls into the "window" on the capscrew head.


FIG. 9



Service Tip:

Use a permanent marker to mark the socket corresponding to one of the flats of the socket hex.

FIG. 10




DISASSEMBLY AND ASSEMBLY

CYLINDER HEAD


8. After the torque has been completed, mark the cylinder head at the location of the dot.

FIG. 11




9. Position the socket on the capscrew such that the mark on the socket is at the same point as the window on the capscrew.

FIG. 12



10. Turn the socket until the mark of the socket aligns with the mark on the cylinder head.

FIG. 13




11. Install the thermostat housing.
Install the belt tensioner and bracket.

Install the exhaust manifold.
Install the rocker lever oil manifold.


Install the rocker assemblies.

FIG. 14




12. Adjust the valve clearance.
Install the valve cover.
Install the injectors.
Install the fuel lines.
Install the turbocharger.
Install the crankcase vent tube.


FIG. 15




13. Fill and vent the cooling system.



14. Vent the high pressure fuel lines.



15. Operate the engine at idle 5 to 10 minutes to check for leaks and proper operation, check coolant level and top-up if required.



REMOVAL OF HYDRAULIC COOLER ASSEMBLY

- ⚠ Loosen the oil filler cap slowly to release the pressure inside the hydraulic tank.

1. Drain oil from hydraulic tank.



Hydraulic tank: Approx. **200 ℓ**

2. Lift off engine hood (1).

- ★ Loosen the hinge mounting bolts before lifting.





Engine hood assembly: **85 kg**

3. Remove top cover, and open front cover

4. Disconnect hose (2) and tube (3)

- ★ Set a container under the cooler assembly to catch the oil.


5. Sling hydraulic cooler assembly (4), remove mounting bolts, then lift off hydraulic cooler assembly.



Hydraulic cooler assembly: **90 kg**

INSTALLATION OF HYDRAULIC COOLER ASSEMBLY

- Carry out installation in the reverse order to removal.
- **Refilling with oil (hydraulic tank).**
 - ★ Add oil through the oil filler to the specified level.
 - Run the engine to circulate the oil through the system. Then check the oil level again.



REMOVAL OF RADIATOR, HYDRAULIC COOLER ASSEMBLY

⚠ Loosen the oil filler cap slowly to release the pressure inside the hydraulic tank.

1. Drain oil from hydraulic tank.



Hydraulic tank: Approx. 200 ℓ

2. Drain coolant

3. Lift off engine hood (1).

★ Loosen the hinge mounting bolts before lifting.



Engine hood assembly: 85 kg

4. Remove top cover, and open front cover

5. Remove radiator undercover.

6. Disconnect hydraulic cooler hose (2) and tube (3).

★ Set a container under the cooler assembly to catch the oil.

7. Remove shroud left cover (4).





★ The shroud mounting bolts cannot be removed, so remove the cover.

8. Disconnect radiator outlet hose (5).


★ Disconnect the clamps at two places at the same time.

9. Disconnect sub-tank hose (6).

10. Remove 2 mounting bolts of shroud (7) from below.




12. Disconnect radiator inlet hose (8).
13. Remove top 2 mounting bolts of shroud (7), and move it towards engine.



14. Sling radiator and hydraulic cooler assembly (9), remove top and bottom mount bolts, then lift off radiator and hydraulic cooler assembly. ※ 1
- ★ Check the direction of the holder plate at the bottom of the top mount.



Radiator, hydraulic cooler assembly:
160 kg



INSTALLATION OF RADIATOR, HYDRAULIC COOLER ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1

Mount bolt: **110.32 ± 12.26 Nm**
(11.25 ± 1.25 kgm)

- **Refilling with water**
 - ★ Add water through the water filler to the specified level.
Run the engine to circulate the water through the system. Then check the water level again.
- **Refilling with oil (hydraulic tank)**
 - ★ Add oil through the oil filler to the specified level.
Run the engine to circulate the oil through the system. Then check the oil level again.

REMOVAL OF ENGINE, MAIN PUMP ASSEMBLY

⚠ Disconnect the cable from the negative (-) terminal of the battery.

⚠ Lower the work equipment completely to the ground and stop the engine. Then loosen the oil filler cap slowly to release the pressure inside the hydraulic tank.

1. Remove hydraulic tank strainer, and using tool **S1**, stop oil.

- When not using tool **S1**, remove the drain plug, and drain the oil from the hydraulic tank and inside the system.






Hydraulic tank: Approx. **200 ℓ**

- ★ Mark all the piping with tags to prevent mistakes in the mounting position when installing.

2. Drain coolant.
3. Remove main pump side cover, undercover, and engine undercover.
4. Open engine hood.
5. Remove main pump top cover (1), and partitions (2) and (3).
6. Disconnect control pump outlet hoses (4) and (5).

7. Disconnect chassis ground (6).
8. Disconnect main pump inlet tube (7) and control pump inlet tube (8).



9. Disconnect TVC solenoid connectors (9) and (10) (CN-C04 and CN-C13).


- ★ Disconnect clamps at two places (pump and frame).

10. Disconnect main pump outlet hoses (11) and (12).

11. Disconnect pump case drain hose (13).

12. Disconnect front pump servo valve hose (14).

13. Disconnect rear pump servo valve hose (15).




14. Disconnect governor motor connectors (CN-E04 and CN-E05)


15. Disconnect fuel return hose (19) and supply hose (20). ※ 1

★ There is no stop valve installed to the supply hose, so stop the fuel.


16. Disconnect car heater hose (21).
17. Disconnect clamp (22) of spill hose.
18. Disconnect water pump inlet hose (23)



19. Remove clamps (24) (2 places), and disconnect spill hose (25).
20. Remove engine outlet hose (26).
21. Remove fan guard (27), then remove fan (28). ※ 2



22. Disconnect turbocharger outlet hose (29), and remove inlet hose (30).
23. Disconnect dust indicator hose (31).
24. Remove air cleaner assembly (32) together with bracket.



⚠ Push the valve of the air conditioner compressor slowly and release the refrigerant (R134a) gradually.

26. Disconnect air conditioner compressor hose (33).

※ 3

27. Disconnect wiring harness (34) from starting motor.

28. Disconnect wiring connector (35) (CN-E08) and clamp (36).


29. Remove engine mount bolts at front (37) and rear (38).

※ 4


30. Lift off engine and main pump assembly (39).



Engine, main pump assembly: **1100 kg**



CEP00373



CEP00374

INSTALLATION OF ENGINE, MAIN PUMP ASSEMBLY

⚠ Carry out installation in the reverse order to removal.

※ 1



Joint bolt: **17.16 ± 2.45 Nm**
(1.75 ± 0.25 kgm)

※ 2



Fan mounting bolt: **66.19 ± 7.35 Nm**
(6.75 ± 0.75 kgm)



※ 3

★ Check that there is no damage or deterioration of the O-ring, then connect the hose.

※ 4



Engine mount bolt
(front): **384.91 ± 41.68 Nm** (39.25 ± 4.25 kgm)
(rear): **926.7 ± 103.0 Nm** (94.5 ± 10.5 kgm)



- * Refilling with coolant
 - Add coolant through the water filler to the specified level.
 - Run the engine to circulate the coolant through the system. Then check the coolant level again.

- **Charging air conditioner with gas**

- ★ Using tool X, charge the air conditioner circuit with refrigerant (R134a).

- **Refilling with oil (hydraulic tank)**

- ★ Add oil through the oil filler to the specified level.

Run the engine to circulate the oil through the system. Then check the oil level again.


- **Bleeding air**

- ★ Bleed the air from the main pump.
- For details, see TESTING AND ADJUSTING

REMOVAL OF DAMPER ASSEMBLY

1. Remove main pump assembly.
For details, see REMOVAL OF MAIN PUMP ASSEMBLY.
2. Remove damper assembly (1).

※ 1



INSTALLATION OF DAMPER ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1



Damper mounting bolt:
110.32 ± 12.26 Nm (11.25 ± 1.25 kgm)

REMOVAL OF FUEL TANK ASSEMBLY

⚠ Disconnect the cable from the negative (-) terminal of the battery.

1. Open drain valve of fuel tank and drain fuel.





Fuel tank: Approx. 540 ℓ
(when tank is full)

2. Remove air conditioner condenser top cover.
3. Remove handrail (1), front cover (2), and battery case cover (3).
4. Disconnect fuel level sensor connector (4) (CN-P06).
5. Disconnect fuel supply hose (5), return hose (6), spill hose (7), and clamp (8).
6. Remove mounting bolts, and lift off fuel tank assembly (9).



Fuel tank assembly: **210 kg**






INSTALLATION OF FUEL TANK ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1



Fuel tank mounting bolt:
277.04 ± 31.87 Nm (28.25 ± 3.25 kgm)





REMOVAL OF CENTER SWIVEL JOINT ASSEMBLY

- ⚠ Release the remaining pressure in the hydraulic circuit.
For details, see TESTING AND ADJUSTING, Releasing remaining pressure from hydraulic circuit.
- ⚠ Loosen the hydraulic tank oil filler cap slowly to release the pressure inside the hydraulic tank.
- ★ Mark all the piping with tags to prevent mistakes in the mounting position when installing.
- 1. Disconnect travel motor hoses (1) and (2).
- 2. Disconnect speed selector hose (3).
- 3. Disconnect drain hose (4), and remove elbow (5).
★ Install a blind plug in the drain hose.
- 4. Disconnect drain hoses (7) and (8).
★ Install a blind plug in the drain hose.
- 5. Disconnect travel hoses (9) and (10), and speed selector hose (11).
- 6. Pull out pin (12), and disconnect plate (13).
- 7. Sling center swivel joint assembly (14), remove mounting bolts from below, then lift off.



Center swivel joint assembly: 40 kg





INSTALLATION OF CENTER SWIVEL JOINT ASSEMBLY

- Carry out installation in the reverse order to removal.


※ 1

- ★ Assemble the center swivel as shown in the diagram below.
- **Refilling with oil (hydraulic tank)**
 - ★ Add oil through the oil filler to the specified level.
Run the engine to circulate the oil through the system. Then check the oil level again.
- **Bleeding air**
 - ★ Bleed the air from the travel motor.
For details, see TESTING AND ADJUSTING, Bleeding air.



DISASSEMBLY OF CENTER SWIVEL JOINT ASSEMBLY

1. Remove cover (1).
2. Remove lock plate (2).
3. Using puller ①, pull out swivel casing (4) from swivel shaft (5).
4. Remove O-ring (6) and slipper seal (7) from swivel rotor.



ASSEMBLY OF CENTER SWIVEL JOINT ASSEMBLY

1. Assemble slipper seal (7) and O-ring (6) to swivel rotor.
2. Set swivel shaft (5) to block, then using push tool, tap swivel casing (4) with a plastic hammer to install.



Contact surface of rotor, shaft:


Grease (G2-LI)

- ★ When installing the rotor, be extremely careful not to damage the slipper seal and the O-ring.

3. Install lock plate and bolts.
4. Fit O-ring and install cover (1).



Mounting bolt: **31.4 ± 2.9 Nm**
(3.2 ± 0.3 kgm)





CEP00382

REMOVAL OF FINAL DRIVE ASSEMBLY

1. Remove the track shoe assembly.
For details, see REMOVAL OF TRACK SHOE ASSEMBLY.
2. Using work equipment, push up track frame and set block between track frame and link.
- ⚠ Loosen the oil filler cap slowly to release the pressure inside the hydraulic tank.
3. Remove sprocket.
For details, see REMOVAL OF SPROCKET.
4. Remove cover (1).
5. Disconnect drain hose (2).
★ Set a container to catch the oil, then disconnect the hose and install a blind plug.
6. Disconnect speed selector hose (3) and motor hoses (4) and (5).
7. Sling final drive assembly (6), and remove mounting bolts, then remove. ※ 1



Final drive assembly: **550 kg**



INSTALLATION OF FINAL DRIVE ASSEMBLY


- Carry out installation in the reverse order to removal.

※ 1



Final drive mounting bolt: **549 ± 59 Nm**
(**56 ± 6 kgm**)

- **Refilling with oil (hydraulic tank)**
 - ★ Add oil through the oil filler to the specified level.
Run the engine to circulate the oil through the system. Then check the oil level again.
- **Bleeding air**
 - ★ Bleed the air from the travel motor (hydraulic tank).
For details, see TESTING AND ADJUSTING, Bleeding air.



DISASSEMBLY OF FINAL DRIVE ASSEMBLY

1. Draining oil


Remove drain plug and drain oil from final drive case.




Final drive case: Approx. 10 ℓ

2. Cover

1) Remove mounting bolts, then use forcing screws ① to disconnect cover (1) from ring gear.




2) Use eyebolts ② to remove cover (1).




3. Spacer

Remove spacer (2).




4. No. 1 carrier assembly

1) Remove No. 1 carrier assembly (3).



- 2) Disassemble No. 1 carrier assembly as follows.
- i) Push in pin (4), and knock out shaft (5) from carrier (6).
 - ★ After removing shaft (5), remove pin (4).
 - ii) Remove thrust washer (7), gear (8), bearing (9), and thrust washer (10).





5. No. 1 sun gear shaft

Remove No. 1 sun gear shaft (11).


6. No. 2 sun gear

Remove No. 2 sun gear (12).




7. Thrust washer

Remove thrust washer (13).




8. Ring gear

Using eyebolts ③, remove ring gear (14).




9. No. 2 carrier assembly.

- 1) Remove No. 2 carrier assembly (15).




- 2) Disassemble No. 2 carrier assembly as follows.

- i) Push in pin (16) and pull out shaft (17) from carrier (18).
★ After removing the shaft, remove pin (16).
- ii) Remove thrust washer (19), gear (20), bearing (21), and thrust washer (22).




10. Nut

- 1) Remove lock plate (23).




- 2) Using tool J1, remove nut (24).




11. Hub assembly


- 1) Using eyebolts ④, remove hub assembly (25) from travel motor.




- 2) Disassemble hub assembly as follows.
 - i) Remove floating seal (26).



- ii) Remove bearings (27) and (28) from hub (29).



- 3) Remove floating seal (30) from travel motor (31).






ASSEMBLY OF FINAL DRIVE ASSEMBLY


- ★ Clean all parts, and check for dirt or damage. Coat the sliding surfaces of all parts with engine oil before installing.

1. Hub assembly

- 1) Assemble hub assembly as follows.
 - i) Using push tool, press fit bearings (28) and (29) to hub.
 - ii) Using tool **J4**, install floating seal (26).
 - ★ Remove all oil and grease from the O-ring and O-ring contact surface, and dry the parts before installing the floating seal.
 - ★ After installing the floating seal, check that the angle of the floating seal is within 1 mm.
 - ★ After installing the floating seal, coat the sliding surface thinly with engine oil.
- 2) Using tool **J4**, install floating seal (30) to travel motor (31).
 - ★ The procedure for installation is the same as in Step 1)-ii) above.




- 3) Using eyebolts ④, set hub assembly (25) to travel motor, then using push tool, tap to press fit bearing portion.




2. Nut


- 1) Using tool **J2**, push inner race portion of bearing (27).
 - ★ Pushing force: 14.7 – 18.6 kN (1.5 – 1.9 ton)
 - ★ Rotate the hub 2 – 3 times before applying the pushing force to the bearing inner race.




- 2) Measure dimension **a** in the condition in Step 1) above.




- 3) Measure thickness **b** of nut (24) as an individual part.
- 4) Calculate $a - b = c$
- 5) Using tool **J1**, tighten nut (24) until **c** portion dimension is as follows.
 c portion dimension = $c \begin{smallmatrix} 0 \\ -1 \end{smallmatrix}$ mm



- 6) Using push-pull scale ⑤, measure tangential force in direction of rotation of hub in relation to motor case.
 - ★ Tangential force: Max. 490 N (50 kg)
 - ★ The tangential force is the maximum force when starting rotation.



7) Install lock plate (23).




- ★ Install the lock plate as shown in the diagram on the right.

 Thread of mounting bolt:

Thread tightener (LT-2)

- ★ Do not coat the threaded portion of the nut with thread tightener (LT-2).

 **Mounting bolt: $66.19 \pm 7.35 \text{ Nm}$
($6.75 \pm 0.75 \text{ kgm}$)**




3. No. 2 carrier assembly

1) Assemble No. 2 carrier assembly as follows.

- ★ There are the remains of the caulking when the pin is inserted at the end face of hole **h** at the side of the carrier, so remove the caulked metal from the inside diameter of the hole before starting to assemble.

i) Assemble bearing (21) to gear (20), fit top and bottom thrust washers (19) and (22), and set gear assembly in carrier (18).




ii) Align with position of pin holes of shaft and carrier, then tap with a plastic hammer to install shaft (17).

- ★ When installing the shaft, rotate the planetary gear, and be careful not to damage the thrust washer.


iii) Insert pin (16).

- ★ After inserting the pin, caulk the pin portion of the carrier.

- ★ After assembling the carrier assembly, check that gear (20) rotates smoothly.




- 2) Install No. 2 carrier assembly (15).
 - ★ Align the position so that the three tips of the gear shafts of carrier assembly (15) enter the three hollows in the end face of the motor case, then install.



4. Ring gear

Fit O-ring to hub end, then using eyebolts ③, install ring gear (14).

- ★ Install so that the side with two grooves machined in the outside circumference of the ring gear is at the top (cover end).
- ★ Remove all grease and oil from the mating surface of the ring gear and hub.
- ★ Do not put any gasket sealant on the mating surface of the ring gear and hub under any circumstances.





5. Thrust washer

Install thrust washer (13).

6. No. 2 sun gear


Install No. 2 sun gear (12).




7. No. 1 carrier assembly

- 1) Assemble No. 1 carrier assembly as follows.


- ★ There are the remains of the caulking when the pin is inserted at the end face of hole h at the side of the carrier, so remove the caulked metal from the inside diameter of the hole before starting to assemble.
- i) Assemble bearing (9) to gear (8), fit top and bottom thrust washers (7) and (10) and set gear assembly to carrier (6).



- ii) Align position of pin holes of shaft and carrier, then tap with a plastic hammer to install shaft (5).
 - ★ When installing the shaft, rotate the planetary gear, and be careful not to damage the thrust washer.
- iii) Insert pin (4).
 - ★ After inserting the pin, caulk the pin portion of the carrier.
 - ★ After assembling the carrier assembly, check that gear (8) rotates smoothly.




- 2) Install No. 1 carrier assembly (3).




8. No. 1 sun gear shaft

Install No. 1 sun gear shaft (11).



9. Spacer


Install spacer (2).



10. Cover


- 1) Using eyebolts ②, install cover (1).

 Mounting surface of cover:
Gasket sealant (LG-6)



- 2) Using tool **J3**, tighten mounting bolts.

 Mounting bolt:
Initial torque: **98 Nm (10 kgm)**
Additional tightening angle:
115 – 125°



11. Refilling with oil

Tighten drain plug and add engine oil through oil filler.



Final drive case: Approx. **10 ℓ**

- ★ Carry out a final check of the oil level at the determined position after installing the final drive assembly to the chassis.


REMOVAL OF SPROCKET

1. Remove track shoe assembly.
For details, see REMOVAL OF TRACK SHOE ASSEMBLY.
2. Swing work equipment 90°, then push up chassis with work equipment and set block ① between track frame and track shoe.
3. Remove mounting bolts, then lift off sprocket (1).

※ 1



Sprocket : 70 kg



INSTALLATION OF SPROCKET

- Carry out installation in the reverse order to removal.

※ 1



Thread of sprocket mounting bolt:

Thread tightener (LT-2)



Sprocket mounting bolt:



637 ± 49 Nm (65 ± 5 kgm)

REMOVAL OF SWING MOTOR ASSEMBLY

- ⚠ Release the remaining pressure in the hydraulic circuit.
For details, see TESTING AND ADJUSTING, Releasing remaining pressure from hydraulic circuit.
- ⚠ Loosen the oil filler cap slowly to release the pressure inside the hydraulic tank.
- ★ Fit blind plugs in the disconnected hoses and tubes.
- 1. Disconnect suction hose (1).
- 2. Disconnect swing hoses (2).
- 3. Disconnect drain hoses (3) and (4).
- 4. Disconnect swing holding brake hose (5).
- 5. Remove mounting bolts, and lift off swing motor assembly (6).



Swing motor assembly: **110 kg**



INSTALLATION OF SWING MOTOR ASSEMBLY


- Carry out installation in the reverse order to removal.
- **Refilling with oil (hydraulic tank).**
 - ★ Add oil through the oil filler to the specified level.
Run the engine to circulate the oil through the system. Then check the oil level again.
- **Bleeding air**
 - ★ Bleed the air from the swing motor.
For details, see TESTING AND ADJUSTING, Bleeding air.

REMOVAL OF SWING MACHINERY ASSEMBLY

1. Remove swing motor assembly.
For details, see REMOVAL OF SWING MOTOR ASSEMBLY.
2. Remove mounting bolts (1). ※ 1
3. Lift off swing machinery assembly (2).



Swing machinery assembly: **390 kg**




INSTALLATION OF SWING MACHINERY ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1



Swing machinery case mounting bolt:
966.0 ± 142.0 Nm (98.5 ± 14.5 kgm)



DISASSEMBLY OF SWING MACHINERY ASSEMBLY

1. Draining oil


Loosen drain plug and drain oil from swing machinery.



Swing machinery case: Approx. 13.5 ℓ


2. Cover

Remove mounting bolts, then lift off cover (1).




3. No. 1 carrier assembly.

- 1) Remove thrust washer (2).
- 2) Remove No. 1 sun gear (3).




- 3) Remove No. 1 carrier assembly (4).




4. Disassemble No. 1 carrier assembly as follows.

- 1) Push in pin (5), and knock out shaft (6) from carrier (7).
★ After removing the shaft, remove pin (5).
- 2) Remove thrust washer (8), gear (9), bearing (10), and thrust washer (11).




5. Ring gear

Lift off ring gear (12).




6. No. 1 sun gear

- 1) Remove thrust washer (13) and collar (14).
- 2) Remove No. 1 sun gear (15).




- 3) Remove thrust washer (16).



7. No. 2 carrier assembly

Lift off No. 2 carrier assembly (17).




DISASSEMBLY AND ASSEMBLY

SWING MACHINERY


8. Disassemble No. 2 carrier assembly as follows.

- 1) Push in pin (18), and knock out shaft (19) from carrier (17).
- ★ After removing the shaft, remove pin (18).
- 2) Remove thrust washer (20), gear (21), bearing (22), and thrust washer (23).




9. Pinion shaft assembly.



- 1) Remove bolt (24), then remove holder (25).
- 2) Remove gear (26).





- 3) Turn over case and pinion assembly, then remove mounting bolts (28) of cover assembly (27).




- 4) Turn over case and pinion assembly (29), and set on press stand, then using push tool ①, remove pinion shaft assembly (30) with press.
- ★ Set a wooden block under the press, and be careful not to damage the pinion shaft assembly when removing it.



- 10. Disassemble pinion shaft assembly as follows.**
- 1) Using push tool ②, remove cover assembly (27) and bearing (31) from shaft (32).
 - 2) Remove oil seal (33) from cover (27).



- 11. Bearing**
- Using push tool, remove bearing (34) from case (35).




ASSEMBLY OF SWING MACHINERY ASSEMBLY

- ★ Clean all parts, and check for dirt or damage. Coat the sliding surfaces of all parts with engine oil before installing.

1. Bearing

Using push tool ③, press fit bearing (31) to case (35).




2. Cover assembly

- 1) Using push tool ④, press fit oil seal (33) to cover (27).

 Outside circumference of oil seal:

Gasket sealant (LG-6)

- ★ Be careful not to let the gasket sealant (LG-6) get on the oil seal lip when press fitting.




- 2) Fit cover assembly (27) to case (35), and tighten mounting bolts (28).

 Cover mounting surface:

Gasket sealant (LG-6)

 Mounting bolt: $66.19 \pm 7.35 \text{ Nm}$
($6.75 \pm 0.75 \text{ kgm}$)


 Lip of oil seal: **Grease (G2-LI)**



3. Case assembly

- 1) Set case assembly (35) to shaft (32), then using push tool ⑤, press fit bearing inner race portion.


- ★ When setting the case assembly to the shaft, be extremely careful not to damage the oil seal.



2) Bearing

Using tool F, press fit bearing (34).

- ★ Press the bearing inner race and outer race at the same time when press fitting. Do not press only the inner race when press fitting.
- ★ After press fitting the bearing, check that the case rotates smoothly.




3) Gear, holder

Assemble gear (26), then fit holder (25) and tighten bolt (24).

 Mounting bolt:

Thread tightener (LT-2)


 Mounting bolt: **380.00 ± 46.58 Nm**
(38.75 ± 4.75 kgm)



4. Assemble No. 2 carrier assembly as follows

- ★ There are the remains of the caulking when the pin is inserted at the end face of hole h at the side of the carrier, so remove the caulked metal from the inside diameter of the hole before starting to assemble.

- 1) Assemble bearing (22) to gear (21), fit top and bottom thrust washers (23) and (20) and set gear assembly to carrier (17).




- 2) Align with position of pin holes of shaft and carrier, then tap with a plastic hammer to install shaft (19).

- ★ When installing the shaft, rotate the planetary gear, and be careful not to damage the thrust washer.


- 3) Insert pin (18).

- ★ After inserting the pin, caulk the pin portion of the carrier.
- ★ After assembling the carrier assembly, check that gear (21) rotates smoothly.




5. No. 2 carrier assembly

Raise No. 2 carrier assembly (17) and install.




6. No. 2 sun gear

1) Assemble thrust washer (16).



2) Install No. 2 sun gear (15) to No. 2 carrier, then install collar (14) and thrust washer (13).




7. Ring gear

Raise ring gear (12) and install.


★ Align with the drain hole and assemble.

 Mating surface of ring gear and case:
Gasket sealant (LG-6)



8. Assemble No. 1 carrier assembly as follows.

- ★ There are the remains of the caulking when the pin is inserted at the end face of hole **h** at the side of the carrier, so remove the caulked metal from the inside diameter of the hole before starting to assemble.
- 1) Assemble bearing (10) to gear (9), fit top and bottom thrust washers (8) and (11) and set gear assembly to carrier (7).




- 2) Align position of pin holes of shaft and carrier, then tap with a plastic hammer to install shaft (6).

★ When installing the shaft, rotate the planetary gear, and be careful not to damage the thrust washer.

- 3) Insert pin (5).


★ After inserting the pin, caulk the pin portion of the carrier.

★ After assembling the carrier assembly, check that gear (9) rotates smoothly.




9. No. 1 carrier assembly

Install No. 1 carrier assembly (4).



10. No. 1 sun gear

- 1) Assemble No. 1 sun gear (3) to carrier assembly.
- 2) Install thrust washer (2).



11. Cover

Install cover (1).




Cover mounting surface:

Gasket sealant (LG-6)



Mounting bolt: 1st pass: **98 Nm (10 kgm)**
2nd pass: **70 – 80°**



12. Refilling with oil

Tighten drain plug and add engine oil through oil filler.



Swing machinery case: Approx. **13.5 ℓ**

REMOVAL OF REVOLVING FRAME ASSEMBLY

1. Remove work equipment assembly.
For details, see REMOVAL OF WORK EQUIPMENT ASSEMBLY.

⚠ When disconnecting the hydraulic hoses, release the remaining pressure in the hydraulic circuit.
For details, see TESTING AND ADJUSTING, Releasing remaining pressure from hydraulic circuit.



2. Disconnect boom cylinder hoses (1).
★ Fit blind plugs in the hoses and make it possible to swing the upper structure.

3. Raise boom cylinder assembly (2), then pull out foot pin (3) and lift off.

★ Remove the right cylinder assembly in the same way.

 Boom cylinder assembly: **300 kg**

4. Remove counterweight assembly.
For details, see REMOVAL OF COUNTERWEIGHT ASSEMBLY.




5. Remove engine hood (4), cover (5), and frame (6).

★ For details of the method of removing the engine hood, see REMOVAL OF HYDRAULIC COOLER ASSEMBLY.

6. Leave 3 mounting bolts each at front and rear of revolving frame, and remove other mounting bolts.


★ Swing the upper structure and set to a position where it is easy to remove the mounting bolts.



7. Disconnect drain hoses (7) and (8).
★ Install blind plugs in the drain hoses.

8. Disconnect travel hoses (9) and (10), and speed selector hose (11).

9. Pull out pin (12), and disconnect plate (13) from swivel joint.




10. Sling revolving frame assembly (14), then remove mounting bolts, and lift off revolving frame assembly.

- ★ Use 2 lever blocks.
- ★ Loosen the mounting bolts remaining at the front and rear and adjust the center of gravity with the lever block while lifting off.



Revolving frame assembly: 7000 kg



INSTALLATION OF REVOLVING FRAME ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1



Mating surface of swing circle:

Gasket sealant (LG-4)



Thread of revolving frame mounting bolt:

Thread tightener (LT-2)



Revolving frame mounting bolt:


926.7 ± 103.0 Nm (94.5 ± 10.5 kgm)

REMOVAL OF SWING CIRCLE ASSEMBLY

1. Remove revolving frame assembly.
For details, see REMOVAL OF REVOLVING FRAME ASSEMBLY.
2. Sling swing circle assembly (1) at three points, then remove mounting bolts, and lift off swing circle assembly.



Swing circle assembly: **500 kg**



INSTALLATION OF SWING CIRCLE ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1



Thread of swing circle mounting bolt:
Thread tightener (LT-2)




Swing circle mounting bolt:
926.7 ± 103.0 Nm (94.5 ± 10.5 kgm)

- ★ Set the soft zone **S** mark on the inside ring of the inner race facing the right side of the machine as shown in the diagram, then install to the track frame.





Swing circle: **Grease (G2-LI) 33 ℓ**



REMOVAL OF IDLER, RECOIL SPRING ASSEMBLY


1. Remove track shoe assembly.
For details, see REMOVAL OF TRACK SHOE ASSEMBLY.
★ Remove lubricator (1).



2. Sling idler and recoil spring assembly (2), and pull out to the front to remove.
★ Fit wire to the idler and spring of the idler and recoil spring assembly, and adjust the balance when removing.



Idler, recoil spring assembly: **430 kg**




3. Disconnect recoil spring assembly (4) from idler assembly (3).



Idler assembly: **170 kg**



Recoil spring assembly: **260 kg**



INSTALLATION OF IDLER, RECOIL SPRING ASSEMBLY


- Carry out installation in the reverse order to removal.

※ 1


- ★ When installing the idler assembly and recoil spring assembly, assemble so that the position of the greasing plug on the idler is on the outside for the right side of the machine and on the inside for the left side of the machine.

DISASSEMBLY OF IDLER ASSEMBLY


1. Remove pin (2), then remove support (3).
2. Remove floating seal (4) from support (3) and idler (5).
3. Pull out shaft and support assembly (6) from idler (5).
 - ★ It is filled with approx. 230 cc. of oil, so drain the oil at this point or lay a cloth to prevent the area from becoming dirty.



4. Remove floating seal (7) on opposite side from idler (5) and shaft and support assembly (6).





5. Remove pin (9), then remove support (10) from shaft (11).
6. Remove bushing (12) from idler (5).





ASSEMBLY OF IDLER ASSEMBLY


1. Press fit bushing (12) to idler (5).
2. Fit O-ring and install support (10) to shaft (11), then install pin (9).
 - ★ After inserting the pin, caulk the pin portion of the support.



3. Using tool L1, install floating seal (7) to idler (5) and shaft and support assembly (6).
 - ★ Coat the sliding surface of the floating seal with oil, and be careful not to let any dirt or dust get stuck to it.
 - ★ Remove all grease and oil from the contact surface of the O-ring and the floating seal.



4. Assemble shaft and support assembly (6) to idler (5).





DISASSEMBLY AND ASSEMBLY

IDLER

5. Using tool **L1**, install floating seal (4) to idler (5) and support (3).

- ★ Coat the sliding surface of the floating seal with oil, and be careful not to let any dirt or dust get stuck to it.
- ★ Remove all grease and oil from the contact surface of the O-ring and the floating seal.



6. Install O-ring, then assemble support (3) and install pin (2).

- ★ After inserting the pin, caulk the pin portion of the support.


7. Add oil and tighten plug.




Oil: Approx. **230 cc** (EO30-CD)



Plug: **152.0 ± 24.5 Nm (15.5 ± 2.5 kgm)**



DISASSEMBLY OF RECOIL SPRING ASSEMBLY



CEP00054

1. Remove piston assembly (2) from recoil spring assembly (1).

2. Disassembly of recoil spring assembly

- 1) Set tool **M1** to recoil spring assembly (1).

⚠ The recoil spring is under large installed load, so be sure to set the tool properly. Failure to do this is dangerous.

★ Installed load of spring:

173.3 kN (17,680 kg)

- 2) Apply hydraulic pressure slowly to compress spring, then remove lock plate (3), and remove nut (4).


★ Compress the spring to a point where the nut becomes loose.

★ Free length of spring: 795 mm

- 3) Remove yoke (6), cylinder (7), and dust seal (8) from spring (5).

4. Disassembly of piston assembly

- 1) Remove lock plate (10) from piston (9), then remove valve (11).
- 2) Remove snap ring (12), then remove U-packing (13) and ring (14).



CEP00055

ASSEMBLY OF RECOIL SPRING ASSEMBLY

1. Assembly of piston assembly

- 1) Assemble ring (14) and U-packing (13) to piston (9), and secure with snap ring (12).
- 2) Tighten valve (11) temporarily, and secure with lock plate (10).

2. Assembly of recoil spring assembly

- 1) Using tool **M2**, assemble dust seal (8) to cylinder (7).
- 2) Assemble cylinder (7) and yoke (6) to spring (5), and set in tool **M1**.

 Sliding portion of cylinder:

Grease (G2-LI)



- 3) Apply hydraulic pressure slowly to compress spring, and tighten nut (4) so that installed length of spring is dimension "a", then secure with lock plate (3)
 - ★ Installed length "a" of spring: 648 mm
- 4) Remove recoil spring assembly (1) from tool **M1**.

3. Assemble piston assembly (2) to recoil spring assembly (1).

 Piston sliding portion and wear ring:

Grease (G2-LI)

- ★ Assemble the cylinder assembly so that the mounting position of the valve is 90° to the side.
- ★ Fill the inside of the cylinder with approx. 200 cc of grease (G2-LI), then bleed the air and check that grease comes out of the grease hole.



REMOVAL OF TRACK ROLLER ASSEMBLY

1. Lower work equipment to ground, then loosen lubricator (1), and relieve track tension. ※ 1

⚠ The adjustment cylinder is under extremely high pressure, so never loosen the lubricator more than one turn. If the grease does not come out easily, move the machine backwards and forwards.

2. Remove mounting bolts of track roller guard (2), then swing work equipment 90°, jack up machine with work equipment, and remove track roller guard (2) towards outside of machine. ※ 2






Track roller guard: **35 kg**

3. Lower chassis completely, remove mounting bolts of track roller assembly (3), then jack up machine with work equipment, and remove track roller assembly (3) to outside of machine. ※ 3



Track roller assembly: **55 kg**



INSTALLATION OF TRACK ROLLER ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1

- ★ Adjust the track tension.
For details, see TESTING AND ADJUSTING, Testing and adjusting track tension.

※ 2

 Roller guard mounting bolt:
Thread tightener (LT-2)


 Roller guard mounting bolt:
926.7 ± 103.0 Nm (94.5 ± 10.5 kgm)

※ 3


 Track roller mounting bolt:
Thread tightener (LT-2)

 Track roller mounting bolt:
1st pass: **196.1 ± 19.6 Nm (20 ± 2 kgm)**
2nd pass:



Tighten an additional 105 ± 5°





DISASSEMBLY OF TRACK ROLLER ASSEMBLY



1. Remove pin (1), then remove collar (2).
2. Remove floating seal (3) from collar (2) and roller (4).
3. Pull out roller (4) from shaft (5).
★ It is filled with 250 – 280 cc. of oil, so drain the oil at this point or lay a cloth to prevent the area from becoming dirty.





4. Remove floating seal (6) on opposite side from roller (4) and collar (8).



5. Remove pin (7), then remove collar (8) from shaft (5).





6. Remove bushings (9) and (10) from roller (4).



ASSEMBLY OF TRACK ROLLER ASSEMBLY



1. Using push tool ①, press fit bushings (9) and (10) to roller (4).
2. Assemble collar (8) to shaft (5), and install pin (7).
3. Using tool L3, install floating seal (6) to shaft (5).

- ★ When assembling the floating seal, clean the contact surface of O-ring (6c) and floating seal (6a), remove all grease and oil, and dry it. Make sure that no dirt or dust sticks to the contact surface of the floating seal.
- ★ After inserting the floating seal, check that the angle of the seal is less than 1 mm and that the protrusion of the seal is within a range of 5 – 7 mm.





4. Using tool L3, install floating seals (6) and (3) to roller (4).
- ★ For details of the precautions when installing floating seals (6b) and (6d), and (3b) and (3d), see the precautions marked ★ for Step 3.


5. Assemble shaft (5) to roller (4).



6. Turn over roller (4) and shaft (5) assembly.
 7. Using tool L3, install floating seal (3) to collar (2).
- ★ For details of the precautions when installing floating seals (3a) and (3c), see the precautions marked ★ for Step 3.




8. Assemble collar (2) to shaft (5), and install pin (1).



9. Using tool L4, apply standard pressure to roller oil filler port, and check for leakage of air from seal.

- ★ Standard pressure: 0.1 MPa (1 kg/cm²)
- ★ Method of checking
The standard pressure shall be maintained for 10 seconds and the indicator of the gauge shall not go down.





10. Using tool L4, fill track roller assembly with oil, then tighten plug (11).



Track roller oil: 250 – 280 cc (EO30-CD)





Plug: 14.7 ± 4.9 Nm (1.5 ± 0.5 kgm)



REMOVAL OF CARRIER ROLLER ASSEMBLY

1. Lower work equipment to ground, then loosen lubricator (1), and relieve track tension. ※ 1


⚠ The adjustment cylinder is under extremely high pressure, so never loosen the lubricator more than one turn. If the grease does not come out, move the machine backwards and forwards.



2. Using hydraulic jacks ①, push up track to a position where carrier roller assembly can be removed, then remove carrier roller assembly (2). ※ 2



Carrier roller assembly: 35 kg




INSTALLATION OF CARRIER ROLLER ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1

- ★ Adjust the track tension.
For details, see TESTING AND ADJUSTING,
Testing and adjusting track tension.

DISASSEMBLY OF CARRIER ROLLER ASSEMBLY



1. Remove plug (1) and drain oil.





Carrier roller assembly: 450 – 500 cc

2. Set carrier roller assembly on stand ①.



3. Remove cover (2).

4. Remove ring (3).



5. Using tool L5, remove nut (4).



6. Using push tool ②, pull out shaft assembly (5) from roller (6) with press, then remove inner race (7).



7. Remove outer races (8) and (9) from roller (6).

8. **Disassembly of shaft assembly.**



- 1) Using puller ③, remove inner race (10).



DISASSEMBLY AND ASSEMBLY

CARRIER ROLLER

- 2) Remove floating seals (11).
- 3) Using push tool ④, remove collar (12) from shaft (13)



ASSEMBLY OF CARRIER ROLLER ASSEMBLY

1. Using push tool ⑤, press fit outer races (8) and (9) to roller (6).

2. **Assembly of shaft assembly.**

- 1) Using tool L7, press fit collar (12) to shaft (13).

★ When press fitting, be careful that there is no scuffing.

 Fitting portion of shaft:

Engine oil (EO30-CD)







- 2) Using tool L6, assemble floating seals (11).

★ When assembling the floating seal, clean the contact surface of O-ring (11c) and floating seal (11a), remove all grease and oil, and dry it. Make sure that no dirt or dust sticks to the contact surface of the floating seal.

★ After inserting the floating seal, check that the angle of the seal is less than 1 mm and that the protrusion of the seal is within a range of 5 – 7 mm.

- 3) Assemble floating seals (11), then using push tool ⑥, press fit inner race (10).

★ For details of the precautions when installing floating seals (11b) and (11d), see the precautions marked ★ for Step 2).





3. Assemble roller (6) to shaft assembly (5).

4. Using push tool ⑦, press fit inner race (7).

★ When press fitting the bearing, rotate the roller, and press fit to a point where the rotation becomes slightly heavier.



5. Using tool L5, tighten nut (4) to a point where drill hole in shaft is aligned with drill hole in nut.




DISASSEMBLY AND ASSEMBLY

CARRIER ROLLER


6. Install ring (3).
7. Using push-pull scale (8), check that roller rotates smoothly.



8. Fit O-ring and install cover (2).



9. Using tool L8, apply standard pressure to roller oil filler port, and check for leakage of air from seal.
 - ★ Standard pressure: 0.1 MPa (1 kg/cm²)
 - ★ Method of checking
The standard pressure shall be maintained for 10 seconds and the indicator of the gauge shall not go down.




10. Using tool L8, fill carrier roller assembly with oil, then tighten plug (1).



Carrier roller oil: 450 – 500 cc (EO30-CD)



Plug: 14.7 ± 4.9 Nm (1.5 ± 0.5 kgm)



REMOVAL OF TRACK SHOE ASSEMBLY

1. Positioning track shoe



- ★ Stop the machine at a point where it is easy to set master pin removal tool **R**, and where master pin is in the middle of the track frame, then loosen lubricator (1), and relieve the track tension. ※ 1

⚠ The adjustment cylinder is under extremely high pressure, so never loosen the lubricator more than one turn. If the grease does not come out, move the machine backwards and forwards.

2. Using tool **R**, pull out master pin (2). ※ 2

3. Lay out track as follows.

- 1) Move machine forward so that position of temporary pin is at front of idler, set block ① in position, then remove temporary pin ②, and remove dust seal. ※ 3
- 2) Drive machine in reverse to lay out track.



INSTALLATION OF TRACK SHOE ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1

Adjust the track tension.
For details, see TESTING AND ADJUSTING, Testing and adjusting track tension.



※ 2

- ★ Use tool **R** and press fit so that the protrusion of the master pin is dimension "a".
Protrusion "a" of master pin: 4.2 ± 2 mm

※ 3



When assembling the dust seal, coat the bushing contact surface with grease (G2-LI).



REMOVAL OF HYDRAULIC TANK ASSEMBLY

- Swing the upper structure to set the position of the hydraulic tank drain and mounting bolt outside the track.



⚠ Loosen the hydraulic tank oil filler cap slowly to release the pressure inside the hydraulic tank.

1. Drain oil from hydraulic tank.




Hydraulic tank: Approx. 200 ℓ


2. Remove operator's cab assembly.
For details, see REMOVAL OF OPERATOR'S CAB ASSEMBLY.
3. Remove control valve top cover, hydraulic tank undercover, and main pump undercover.
4. Open main pump side cover, then remove partitions (1) and (2).
5. Remove covers (3) and (4).
6. Remove air conditioner air suction port (5).




7. Disconnect drain hoses (6), (7), and (8).




8. Disconnect hydraulic oil filter inlet hose (9) and outlet hose (10).



9. Disconnect hydraulic oil cooler return hose (11).
10. Disconnect drain hoses (12), (13), and (14).
11. Disconnect hydraulic oil level sensor connector (15) (CN-P09).




12. Remove main pump suction tube (16).
 - ★ A box wrench cannot be fitted on the center rear mount bolt, so disconnect both sides of tube (16) and offset them.



13. Remove mounting bolts, and lift off hydraulic tank assembly (17).

 Hydraulic tank assembly: **230 kg**



INSTALLATION OF HYDRAULIC TANK ASSEMBLY

- Carry out installation in the reverse order to removal.



 Hydraulic tank mounting bolt:
 $277.04 \pm 31.87 \text{ Nm}$ ($28.25 \pm 3.25 \text{ kgm}$)

- **Refilling with oil (hydraulic tank)**
 - ★ Add oil through the oil filler to the specified level.
Run the engine to circulate the oil through the system. Then check the oil level again.
- **Bleeding air**
Bleed the air.
For details, see TESTING AND ADJUSTING, Bleeding air.



REMOVAL OF CONTROL PUMP ASSEMBLY

- ⚠ Lower the work equipment completely to the ground and stop the engine. Then loosen the oil filler cap slowly to release the pressure inside the hydraulic tank.
- ⚠ Disconnect the cable from the negative (-) terminal of the battery.
 - ★ Mark all the piping with tags to prevent mistakes when installing.
- 1. Remove hydraulic tank strainer, and using tool **S1**, stop oil.
 - ★ When not using tool **S1**, remove the drain plug, and drain the oil from the hydraulic tank and inside the system.



Hydraulic tank: Approx. 200 ℓ

- 2. Remove control pump inlet tube (1).
- 3. Disconnect control pump outlet hoses (2) and (3).
- 4. Remove control pump assembly (4). ※ 1
 - ★ Remove only the bolts with a width across flats of 17 mm.



INSTALLATION OF CONTROL PUMP ASSEMBLY


- Carry out installation in the reverse order to removal.

※ 1

- ★ Align with the groove of coupling (5), then install.

kgm Control pump mounting bolt:
 $66.19 \pm 7.35 \text{ Nm}$ ($6.75 \pm 0.75 \text{ kgm}$)

- **Refilling with oil (hydraulic tank)**
 - ★ Add oil through the oil filler to the specified level.
 - Run the engine to circulate the oil through the system. Then check the oil level again.



REMOVAL OF MAIN PUMP ASSEMBLY

⚠ Lower the work equipment completely to the ground and stop the engine. Then loosen the oil filler cap slowly to release the pressure inside the hydraulic tank.

⚠ Disconnect the cable from the negative (-) terminal of the battery.

★ Mark all the piping with tags to prevent mistakes when installing.

1. Remove hydraulic tank strainer, and using tool **S1**, stop oil.

★ When not using tool **S1**, remove the drain plug, and drain the oil from the hydraulic tank and inside the system.



Hydraulic tank: **Approx. 200 ℓ**

2. Remove main pump side cover and undercover, and open engine hood.

3. Drain oil from damper case.



Damper case: **Approx. 1.3 ℓ**

4. Remove main pump top cover (1), and partitions (2) and (3).

5. Disconnect TVC solenoid connectors (9) and (10) (CN-C04 and CN-C13).

★ There is a clamp for the front servo valve.

6. Disconnect main pump outlet hoses (11) and (12).





7. Disconnect pump case drain hose (13).

8. Disconnect rear pump servo valve hose (14).

9. Disconnect front pump servo valve hose (15).

10. Disconnect control pump outlet hoses (16) and (17).


11. Disconnect main pump inlet tube (18) and control pump inlet tube (19).



12. Sling main pump assembly (20), remove mounting bolts, then lift off.



Main pump assembly: **250 kg**



INSTALLATION OF MAIN PUMP ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1



Involute spline of main pump:
Anti-friction compound (LM-G)




Mating surface of main pump case:
Gasket sealant (LG-6)

- **Refilling with oil (damper case)**
 - ★ Add engine oil through the oil filler to the specified level. Run the engine, then stop the engine, wait for 15 minutes, and check the oil level again.
- **Refilling with oil (hydraulic tank)**
 - ★ Add oil through the oil filler to the specified level.
Run the engine to circulate the oil through the system. Then check the oil level again.
- **Bleeding air**
 - ★ Bleed the air.
For details, see TESTING AND ADJUSTING, Bleeding air.

REMOVAL OF MAIN PUMP INPUT SHAFT OIL SEAL

1. Remove main pump assembly.
For details, see REMOVAL OF MAIN PUMP ASSEMBLY.
2. Remove snap ring (1), then remove spacer (2).
3. Lever up oil seal (3) with a screwdriver to remove.
※ 1
★ When removing the oil seal, be extremely careful not to damage the shaft.



INSTALLATION OF MAIN PUMP INPUT SHAFT OIL SEAL

- Carry out installation in the reverse order to removal.

※ 1




Lip of oil seal: **Grease (G2-LI)**



Coat the outside circumference of the oil seal with grease (G2-LI) thinly, then press fit.

- ★ Using tool **S2**, press fit oil seal (3).



REMOVAL OF CONTROL VALVE ASSEMBLY

⚠ Lower the work equipment completely to the ground and stop the engine. Then loosen the oil filler cap slowly to release the pressure inside the hydraulic tank.



⚠ Release the remaining pressure in the hydraulic circuit.

For details, see TESTING AND ADJUSTING, Releasing pressure in hydraulic circuit.


★ Make match marks before disconnecting the PPC circuit hoses.

★ Fit blind plugs in the disconnected hoses and tubes.


1. Open engine hood.
2. Remove control valve top cover.
3. Disconnect turbocharger inlet port hose (2) and remove.
4. Disconnect air cleaner clogging sensor hose (3).
5. Disconnect air cleaner assembly (4) together with bracket.
6. Disconnect wiring harness (5), and remove partition (6).



7. Disconnect 9 bottom PPC hoses (7).
8. Disconnect pump merge/divider solenoid hose (8).



9. Disconnect pressure sensor connectors (9) and (10) (CN-C08 and CN-C07).
10. Disconnect main pump outlet hoses (11) and (12).




DISASSEMBLY AND ASSEMBLY

CONTROL VALVE

11. Disconnect hoses (13), (14), (15), (16), (17), and (18).

- ★ Hose (13): For arm boost PPC
- Hoses (14) and (15): For R.H. straight travel
- Hoses (16) and (17): For L.H. straight travel
- Hose (18): For drain circuit




12. Disconnect hoses (19) and (20).

- ★ Hose (19): For drain circuit
- Hose (20): For high-pressure circuit

13. Remove elbows (21), (22), and (23).

14. Set hose mounts of elbows (24) and (25) facing down.


15. Disconnect control valve return hose (26).




16. Disconnect drain hose (27).

17. Disconnect 10 top PPC hoses (28).

18. Disconnect safety valve hose (29).




19. Disconnect high-pressure circuit hose (30) and LS pressure hoses (31).




DISASSEMBLY AND ASSEMBLY

CONTROL VALVE

20. Disconnect swing motor suction hose (32).
21. Disconnect bucket hoses (33).
22. Disconnect 2 R.H. travel hoses (34).
23. Disconnect arm hoses (35).
24. Disconnect L.H. travel hoses (36).




25. Remove swing motor hoses (37).
26. Remove boom tubes (38) and (39).
27. Disconnect LS select valve hose (40).



28. Sling control valve assembly (41), then remove mounting bolts, and lift off control valve assembly.
 - ★ Move slightly to the front and pass through the bracket to lift off.



Control valve assembly: **260 kg**





INSTALLATION OF CONTROL VALVE ASSEMBLY

- Carry out installation in the reverse order to removal.
- **Refilling with oil (hydraulic tank)**
Add oil through the oil filler to the specified level.
Run the engine to circulate the oil through the system. Then check the oil level again.

DISASSEMBLY OF CONTROL VALVE ASSEMBLY

NOTE: Control valve assembly had additional circuit (HCU) spool fitted as standard.



- ★ The set pressure of the safety valve and arm counterbalance valve cannot be adjusted when they are installed on the machine, so do not disassemble.

1. Main relief valve, unload LS relief valve.

- 1) Remove main relief valve (1).
- 2) Remove unload LS relief valve (2) and sleeve (3).

2. Safety-suction valve, suction valve.

- 1) Remove safety-suction valve (4).
- 2) Remove suction valve (5).
- 3) Remove plug (5a).

3. Pressure compensation valves

- ★ Before removing any pressure compensation valve, check and mark its mounting position.
- 1) Remove arm Hi IN pressure compensation valve (6), bucket DUMP pressure compensation valve (7), R.H. travel REVERSE pressure compensation valve (8), boom LOWER pressure compensation valve (9), right swing pressure compensation valve (10), L.H. travel REVERSE pressure compensation valve (11), and arm IN pressure compensation valve (12).
 - ★ After removing the pressure compensation valves, remove check valve (13) from each pressure compensation valve mount.
- 2) Remove boom Hi RAISE pressure compensation valve (14), bucket CURL pressure compensation valve (15), R.H. travel FORWARD pressure compensation valve (16), boom RAISE pressure compensation valve (17), left swing pressure compensation valve (18), L.H. travel FORWARD pressure compensation valve (19), and arm OUT pressure compensation valve (20).
 - ★ After removing the pressure compensation valves, remove check valve (21) from each pressure compensation valve mount.

4. LS select valve.

- Remove LS select valve (22).

DISASSEMBLY AND ASSEMBLY

CONTROL VALVE

5. LS shuttle valves, pump merge/divider valve, regeneration valve, block.


- 1) Remove LS shuttle valves (23) and (24).
- 2) Remove pump merge/divider valve (25), then remove spring (26) and valve (27).
- 3) Remove regeneration valve (28), then remove spring (26) and valve (27).
- 4) Remove block (29).

6. Boom Hi, arm Hi control valves.

• Arm Hi control valve

- ★ Mark with tags to prevent mistakes in the mounting position when assembling the springs and spools.


- 1) Remove case (30), then pull out spool assembly (31) to position shown in diagram on right.
- 2) To prevent damage to spool assembly (31), hold position ① shown in diagram on right with a wrench (width across flats: 24mm), remove plug (32), then disassemble into retainer (33), springs (34a) and (34b), retainer (35), and spool (36).



• Boom Hi control valve

- ★ Mark with tags to prevent mistakes in the mounting position when assembling the springs and spools.

- 3) Remove case (37), then remove spring (38) and plate (39).
- 4) To prevent damage to spool assembly (40), hold position ② shown in diagram on right with a wrench (width across flats: 24mm), remove plug (41), then remove valve.
- 5) Remove seal (43) from valve (42), then remove seal (45) from spool (44).



7. Swing, boom, bucket control valves.

- ★ Mark with tags to prevent mistakes in the mounting position when assembling the springs and spool assembly.
- ★ Do not disassemble the spool assembly.
- 1) Remove case (46), then remove spring (47) and retainer (48).
- 2) Remove spool assembly (49).
- 3) Remove case (50), then remove spring (51) and retainer (52).

8. L.H. travel, R.H. travel control valves

- ★ Mark with tags to prevent mistakes in the mounting position when assembling the springs and spool assembly.
- ★ Do not disassemble the spool assembly.
- 1) Remove case (53), then remove spring (54) and retainer (55).
- 2) Remove spool assembly (56).
- 3) Remove case (57), spring (58), and retainer (59).



9. Arm control valve

- ★ Mark with tags to prevent mistakes in the mounting position when assembling the springs and spool assembly.
- ★ Do not disassemble the spool assembly.
- 1) Remove plug (60), then remove valve (61).
- 2) Remove case (62), then remove springs (63) and (64), and retainer (65).
- 3) Remove spool assembly (66).
- 4) Remove case (67), then remove spring (68) and retainer (69).

10. Covers

Remove covers (71) and (72), and valve (73) from valve body (70).

ASSEMBLY OF CONTROL VALVE ASSEMBLY



- ★ Check the spools and valves for dirt, damage, or burrs. Coat the sliding surfaces of all parts with engine oil before installing.


1. Covers

Install valve (73), and covers (72) and (71) to valve body (70).

- ★ Check that there is no damage to the O-ring, then install securely to the mating surface of the cover and valve.
- ★ Tighten the mounting bolts of covers (72) and (71) in the order shown in the diagram on the right.

 **kgm** Cover mounting bolt:

$166.7 \pm 9.8 \text{ Nm}$ ($17 \pm 1 \text{ kgm}$)



2. Arm control valve spool

- ★ Check the mounting position of the springs and spool assembly before installing.
- 1) Assemble spool assembly (66) to valve body (70), and fit retainer (69) and spring (68), then fit O-ring to case (61) and install.
- 2) Fit retainer (65), and springs (64) and (63) to spool assembly (66), then fit O-ring to case (62) and install.
- 3) Assemble valve (61), and install plug (60).
- 4) Tighten mounting bolts of cases (67) and (62) to specified torque.

 **kgm** Case mounting bolt:

$30.89 \pm 3.43 \text{ Nm}$ ($3.15 \pm 0.35 \text{ kgm}$)

- 5) Tighten plug (60) to specified torque.

 **kgm** Plug:

$107.9 \pm 14.7 \text{ Nm}$ ($11 \pm 1.5 \text{ kgm}$)

3. L.H. travel, R.H. travel control valves

- ★ Check the mounting position of the spring and spool assembly before installing.
- 1) Assemble spool assembly (56) to valve body (70), assemble retainer (59) and spring (58), then fit O-ring to case (57) and install.
- 2) Assemble retainer (55) and spring (54) to spool, then fit O-ring to case (53) and install.
- 3) Tighten cases (57) and (53) to specified torque.

 **kgm** Case mounting bolt:

$30.89 \pm 3.43 \text{ Nm}$ ($3.15 \pm 0.35 \text{ kgm}$)

4. Swing, boom, bucket control valve spools

- ★ Check the mounting position of the springs and spool assembly before installing.
- 1) Assemble spool assembly (49) to valve body (70).
- 2) Assemble retainer (52) and spring (51), then fit O-ring to case (50) and install.
- 3) Assemble retainer (48) and spring (47) to spool, then fit O-ring to case (46) and install.
- 4) Tighten mounting bolts of cases (50) and (46) to specified torque.

 Case mounting bolt:

30.89 ± 3.43 Nm (3.15 ± 0.35 kgm)

5. Boom Hi, arm Hi control valve spools

• Boom Hi control valve spool

- ★ Check the mounting position of the spring and spool assembly before installing.
- 1) Fit seal (45) to spool (44), and install seal (43) to valve (42).
- 2) Assemble spool (44) to position shown in diagram on right, install plate (39) and valve (42) to spool (44), then hold position ⑥ shown in diagram on right with a wrench (width across flats: 24mm), and tighten plug (41).


 Plug:

13.24 ± 1.47 Nm (1.35 ± 0.15 kgm)

- 3) Push spool assembly (40) into body, fit spring (38), then fit O-ring to case (37) and install.

 Case mounting bolt:

30.89 ± 3.43 Nm (3.15 ± 0.35 kgm)




• Arm Hi control valve spool

- ★ Check the mounting position of the spring and spool assembly before installing.
- 1) Assemble spool (31) to position shown in diagram on right, install retainer (35), springs (34a) and (34b), and retainer (33), then install plug (32).
- 2) Hold spool (31) at position ① shown in diagram on right with a wrench (width across flats: 24mm), and tighten plug (32).

 Plug:

17.16 ± 2.45 Nm (1.75 ± 0.25 kgm)



DISASSEMBLY AND ASSEMBLY

CONTROL VALVE

- 3) Push spool assembly (31) into body, then fit O-ring to case (30) and install.

 Case mounting bolt:

$30.89 \pm 3.43 \text{ Nm}$ ($3.15 \pm 0.35 \text{ kgm}$)

6. LS shuttle valve, pump merge/divider valve, regeneration valve, block.

- 1) Install block (29).

 Block mounting bolt:

$30.89 \pm 3.43 \text{ Nm}$ ($3.15 \pm 0.35 \text{ kgm}$)

- 2) Assemble valve (27) and spring (26) to valve body (70), fit O-ring to regeneration valve (28), and install.

 Valve mounting bolt:

$66.19 \pm 7.35 \text{ Nm}$ ($6.75 \pm 0.75 \text{ kgm}$)

- 3) Assemble valve (27) and spring (26) to valve body (70), and install pump merge/divider valve (25).

 Mounting bolt:

$166.7 \pm 9.8 \text{ Nm}$ ($17 \pm 1 \text{ kgm}$)

- ★ Tighten the mounting bolts of the pump merge/divider valve in the order shown in the diagram on the right.

- 4) Install LS shuttle valves (24) and (23).

 Mounting bolt:

$66.19 \pm 7.35 \text{ Nm}$ ($6.75 \pm 0.75 \text{ kgm}$)

7. LS select valve

Install LS select valve (22).


 LS select valve:

$127.5 \pm 19.6 \text{ Nm}$ ($13 \pm 2 \text{ kgm}$)


8. Pressure compensation valves

- ★ Check the marks made on each pressure compensation valve during disassembly, and install in the correct position.


- 1) Before installing pressure compensation valves below, install check valves (21) and (13).
- 2) Install arm OUT pressure compensation valve (20), L.H. travel FORWARD pressure compensation valve (19), left swing pressure compensation valve (18), boom LOWER pressure compensation valve (17), R.H. travel FORWARD pressure compensation valve (16), bucket CURL pressure compensation valve (15), and boom Hi RAISE pressure compensation valve (14).



CDP00545



CDP00546



CDP00544

- 3) Install arm IN pressure compensation valve (12), L.H. travel REVERSE pressure compensation valve (11), right swing pressure compensation valve (10), boom LOWER pressure compensation valve (9), R.H. travel REVERSE pressure compensation valve (8), bucket DUMP pressure compensation valve (7), and arm Hi IN pressure compensation valve (6).

 Pressure compensation valve:
392.3 ± 19.6 Nm (40 ± 2 kgm)

9. Safety-suction valve, suction valve

- 1) Fit O-ring and install suction valve (5).

 Suction valve:
147.1 ± 9.8 Nm (15 ± 1 kgm)

- 2) Fit O-ring and install safety-suction valve (4).

 Safety-suction valve:
147.1 ± 9.8 Nm (15 ± 1 kgm)

- 3) Install plug (5a).

Plug: 147.1 ± 9.8 Nm (15 ± 1 kgm)

10. Main relief valve, unload LS relief valve

- 1) Fit O-ring and install sleeve (3).

 Sleeve:
85.80 ± 7.35 Nm (8.75 ± 0.75 kgm)


- 2) Fit O-ring and install unload LS relief valve (2).

 Unload LS relief valve:
98.1 ± 9.8 Nm (10 ± 1 kgm)

- 3) Fit O-ring and install main relief valve (1).

 Main relief valve:
53.9 ± 4.9 Nm (5.5 ± 0.5 kgm)

DISASSEMBLY OF PUMP MERGE/DIVIDER VALVE ASSEMBLY




CEP00547

1. Remove plug (2) from valve body (1), then remove spring (3) and spool (4).
2. Remove plate (5).
3. Remove plug (6), then remove spring (7) and spool (8).
4. Remove plug (9).
- ★ After disassembling, if there is any abnormality in body (1) or spools (4) or (8), replace the whole pump merge/divider valve assembly.

ASSEMBLY OF PUMP MERGE/DIVIDER VALVE ASSEMBLY

- Before assembling, coat the sliding surface with engine oil.
1. Fit O-ring to plug (9) and install to valve body (1).
 Plug (9): **39.2 ± 5.9 Nm (4.0 ± 0.6 kgm)**
 2. Assemble spool (8) and spring (7), then fit O-ring to plug (6) and install.
 Plug (6): **39.2 ± 5.9 Nm (4.0 ± 0.6 kgm)**
 3. Fit O-ring to plate (5) and install valve body.
 4. Assemble spool (4) and spring (3), then fit O-ring to plug (2) and install.
 Plug (2):
152.0 ± 24.5 Nm (15.5 ± 2.5 kgm)

DISASSEMBLY OF PRESSURE COMPENSATION VALVE ASSEMBLY



- The structure of the parts for pressure compensation valves A – I is the same, but the part numbers for the component parts is different, so be careful when assembling.
- 1. Remove piston sub-assembly (2) and piston (3) from sleeve (1), then remove seal (4).
 - ★ Sub-piston assembly (2) is assembled to pressure compensation valves A-C, E-I, and piston (3) is assembled to pressure compensation valves D.
- 2. Remove spring (5), then remove ring (6) and O-rings (7) and (8) from sleeve (1).
 - ★ After disassembling, if there is any abnormality in sleeve (1), seal (4), piston sub-assembly (2), or piston (3), replace the whole pressure compensation valve assembly.

Pressure compensation valves

- A: Arm IN Hi
- B: Boom RAISE Hi
- C: Boom LOWER
- D: R.H. travel REVERSE, L.H. travel REVERSE
R.H. travel FORWARD, L.H. travel FORWARD
- E: Boom RAISE
- F: Arm OUT
- G: Bucket CURL
- H: Arm IN
- I: Right swing, left swing, bucket dump


ASSEMBLY OF PRESSURE COMPENSATION VALVE ASSEMBLY

- Before assembling, coat the sliding surface with engine oil.
- 1. Install O-rings (8) and (7) and ring (6) to sleeve (1).
- 2. Assemble spring (5), then assemble seal (4) to piston sub-assembly (2) and piston (3), and install to sleeve.

REMOVAL OF SERVO VALVE ASSEMBLY FOR FRONT PUMP

- ⚠ Disconnect the cable from the negative (-) terminal of the battery.
- ⚠ Loosen the oil filler cap slowly to release the pressure inside the hydraulic tank.
- 1. Disconnect TVC solenoid connector (1) (CN-C13).
- 2. Disconnect clamp (2).
- 3. Disconnect LS-EPC hose (3), LS pressure hose (4), and pump circuit pressure hose (5).
 - ★ Fit blind plugs in the disconnected hoses.
- 4. Remove servo valve assembly (6) for front pump.

※ 1



INSTALLATION OF SERVO VALVE ASSEMBLY FOR FRONT PUMP

- Carry out installation in the reverse order to removal.

※ 1

- ★ Be careful not to let the O-ring or filter fall out when installing.
- ★ Tighten the mounting bolts gradually on opposite sides in turn.

⚙️ **Servo valve mounting bolt:**

66.19 ± 7.35 Nm (6.75 ± 0.75 kgm)

- ★ Check the performance of the work equipment, travel, and swing.
- For details, see TESTING AND ADJUSTING.


- **Refilling with oil (hydraulic tank)**

- ★ Add oil through the oil filler to the specified level.
- Run the engine to circulate the oil through the system. Then check the oil level again.

REMOVAL OF SERVO VALVE ASSEMBLY FOR REAR PUMP

- ⚠ Disconnect the cable from the negative (-) terminal of the battery.
- ⚠ Loosen the oil filler cap slowly to release the pressure inside the hydraulic tank.
- 1. Disconnect TVC solenoid connector (1) (CN-C04).
- 2. Disconnect connector bracket (2) from servo valve.
- 3. Disconnect LS-EPC hoses (3) and (4), LS pressure hose (5), and pump circuit pressure hose (6).
- Fit blind plugs in the disconnected hoses.
- 4. Remove servo valve assembly (7) for rear pump.

※ 1



CEP00413

INSTALLATION OF SERVO VALVE ASSEMBLY FOR REAR PUMP

- Carry out installation in the reverse order to removal.

※ 1

- ★ Be careful not to let the O-ring or filter fall out when installing.
- ★ Tighten the mounting bolts gradually on opposite sides in turn.

 **Servo valve mounting bolt:**
66.19 ± 7.35 Nm (6.75 ± 0.75 kgm)

- ★ Check the performance of the work equipment, travel, and swing.
For details, see TESTING AND ADJUSTING.


• Refilling with oil (hydraulic tank)

- ★ Add oil through the oil filler to the specified level.
Run the engine to circulate the oil through the system. Then check the oil level again.

REMOVAL OF LS-EPC SOLENOID VALVE ASSEMBLY

- ⚠ Disconnect the cable from the negative (-) terminal of the battery.
- ⚠ Loosen the hydraulic tank oil filler cap slowly to release the pressure inside the hydraulic tank.

1. Open main pump side cover.
2. Disconnect wiring connector (CN-C10).
3. Disconnect hoses (1), (2), (3), and (4).
 - ★ Fit blind plugs in the disconnected hoses.
4. Remove LS-EPC solenoid valve assembly (5).





INSTALLATION OF LS-EPC SOLENOID VALVE ASSEMBLY

- Carry out installation in the reverse order to removal.

REMOVAL OF SOLENOID VALVE ASSEMBLY

- ⚠ Disconnect the cable from the negative (–) terminal of the battery.
- ⚠ Loosen the hydraulic tank oil filler cap slowly to release the pressure inside the hydraulic tank.
- ★ Make match marks on the hoses and at the male and female ends of the connectors.
- 1. Remove 5 solenoid wiring connectors (1) from clip and disconnect.
- 2. Disconnect hoses (2) and (3) installed to bottom of valve.
- 3. Disconnect valve hoses (4).
- 4. Remove mounting bolts, then remove solenoid valve assembly (5).
- When removing solenoid valve as an individual part.
 - 1) If mounting nut (6) is removed, only coil assembly needs to be removed. ※ 1
 - 2) When washing valve, loosen mounting nut (7) and remove. ※ 2




INSTALLATION OF SOLENOID VALVE ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1  **kgm** Coil mounting nut (6):
 $7.85 \pm 0.98 \text{ Nm}$ ($0.8 \pm 0.1 \text{ kgm}$)



※ 2  **kgm** Valve mounting nut (7):
 $50.99 \pm 3.43 \text{ Nm}$ ($5.2 \pm 0.35 \text{ kgm}$)



REMOVAL OF WORK EQUIPMENT PPC VALVE ASSEMBLY

⚠ Lower the work equipment completely to the ground and stop the engine. Then loosen the oil filler cap slowly to release the pressure inside the hydraulic tank.

1. Remove case.
For details, see REMOVAL OF CONTROL STAND CASE.
2. Disconnect wiring connector (1).
3. Remove joint bolt (2), and disconnect hose (3).
★ Make match marks on the hoses. ※ 1
4. Remove mounting bolts, raise PPC valve assembly (4), then disconnect hoses (5) and (6), and remove. ※ 2



INSTALLATION OF WORK EQUIPMENT, SWING PPC VALVE ASSEMBLY

- Carry out installation in the reverse order to removal.


※ 1
 **kgm** Hose mount joint bolt:
 $29.4 \pm 4.9 \text{ Nm}$ ($3.0 \pm 0.5 \text{ kgm}$)

※ 2
 **kgm** Hose mount joint bolt:
 $39.2 \pm 4.9 \text{ Nm}$ ($4.0 \pm 0.5 \text{ kgm}$)

- ★ If there is excessive play in the control levers, adjust the PPC valve.
For details, see TESTING AND ADJUSTING, Adjusting PPC valve.

DISASSEMBLY OF WORK EQUIPMENT PPC VALVE ASSEMBLY

1. Remove nut (1), then remove disc (2) and boot (3).
2. Remove bolts, then remove plate (5).
 - ★ Do not remove joint (4) unless it is to be replaced.
3. Remove seal (6) and collar (7).
4. Pull out pusher (8), and remove retainers (9), springs (10) and (11), and shim (12).
 - ★ Spring (10) consists of two springs each of two types with different installed loads, so check the mounting position (hydraulic port) and mark with tags to prevent mistakes when installing.
5. Pull out valve (13) from body (14).



ASSEMBLY OF WORK EQUIPMENT PPC VALVE ASSEMBLY

1. Assemble valve (13) to body (14).
2. Assemble shim (12) and spring (11) to valve (13).
 - ★ When assembling spring (11), set the end with the small coil diameter (inside diameter) at shim (12) end.
3. Assemble spring (10), retainer (9), and piston (8).
 - ★ The number of loops in the coil for spring (10) is different for each of the hydraulic ports below, so be careful when installing.

Position of port	Free length of spring (mm)
P1, P2	44.4
P3, P4	42.4

- ★ The position of each port is marked at the bottom of the valve body.

 Piston: **Grease (G2-LI)**

- ★ When assembling piston (8), coat the outside of the piston and the inside of the hole in the body with grease.

4. Fit O-ring to collar (7) and assemble in body (14), then install seal (6).
5. Install plate (5).

 Mounting bolt:
13.24 ± 1.47 Nm (1.35 ± 0.15 kgm)

6. Install joint (4).

 Sliding portion of joint: **Grease (G2-LI)**

 Female thread of body:

Thread tightener (LT-2)

- ★ Coat two places on the female thread with one drop of Loctite each as shown in the diagram on the right.


 Joint: **44.1 ± 4.9 Nm (4.5 ± 0.5 kgm)**

- ★ Keep strictly to the tightening torque.

7. Assemble boot (3) and disc (2), and tighten with nut (1).

 Nut: **112.8 ± 14.7 Nm (11.5 ± 1.5 kgm)**





- ★ After assembling the disc, adjust the height of the disc.
For details, see TESTING AND ADJUSTING, Adjusting PPC valve.



REMOVAL OF TRAVEL PPC VALVE ASSEMBLY

! Lower the work equipment completely to the ground and stop the engine. Then loosen the oil filler cap slowly to release the pressure inside the hydraulic tank.

1. Remove travel PPC valve undercover.
2. Remove floor mat.
3. Remove pedals (1) and levers (2).
4. Remove cover (3). ※ 1
5. Remove covers (4), then remove springs (5).
6. Disconnect 6 PPC hoses (7), and remove travel PPC valve assembly (8). ※ 2



INSTALLATION OF TRAVEL PPC VALVE ASSEMBLY

- Carry out installation in the reverse order to removal.


※ 1 **kgm** Cover mounting bolt:
19.6 ± 1.9 Nm (2.0 ± 0.2 kgm)

※ 2 **kgm** Hose mounting joint bolt
(width across flats: 30mm):
39.2 ± 4.9 Nm (4.0 ± 0.5 kgm)

kgm Hose mounting joint bolt
(width across flats: 22mm):
29.4 ± 4.9 Nm (3.0 ± 0.5 kgm)

DISASSEMBLY OF TRAVEL PPC VALVE ASSEMBLY

1. Remove screw (1), then remove lever (2).
2. Remove mounting bolts (3), then remove case and shaft assembly (4).
3. Remove mounting bolts (5), then remove plate (6) together with damper assembly (7).
 - ★ Check the thickness and mounting position of washer (18).
4. Remove mounting bolts (8), then remove damper assembly (7) from plate (6).
5. Remove seal (9) and collar (10).
6. Pull out piston (11), and remove retainer (12), springs (13) and (14), and shims (15).
 - ★ Check the number and thickness of shims (15) for each mounting position, and keep in a safe place.
7. Pull out valve (16) from body (17).



ASSEMBLY OF TRAVEL PPC VALVE ASSEMBLY

1. Assemble valve (16) in body (17).
2. Assemble shim (15) and spring (14) to valve (16).

★ Assemble the same number and thickness of shim (15) as was removed during disassembly.

Standard shim thickness: 0.3 mm

★ Spring (14) is not symmetrical at the top and bottom, so assemble with the small coil diameter (inside diameter) at the shim end.

3. Assemble spring (13), retainer (12), and piston (11).

 Outside circumference of piston, body hole: **Grease (G2- LI)**

4. Fit O-ring to collar (10) and assemble in body (17), then install seal (9).

5. Install damper assembly (7) to plate (6), then tighten mounting bolts (8).

 Mounting bolt: **Thread tightener (LT-2)**

 Mounting bolt:

$4.41 \pm 0.49 \text{ Nm}$ ($0.45 \pm 0.05 \text{ kgm}$)

6. Install plate (6) and damper assembly (7) as one unit, then tighten mounting bolts (5).

★ Temporarily assemble standard washer (1.6 mm) for washer (18).

After completing the assembly, measure the difference in the angle when the left and right levers are operated fully. If the angle is greater than 0.7° , change the thickness of washer (18) to make the difference less than 0.7° .

★ Washer thickness: 1.0, 1.3, 1.6 mm

★ If the washer is thinner by 0.3 mm, the angle of the full stroke is 0.39° greater.

 Mounting bolt:

$30.89 \pm 3.43 \text{ Nm}$ ($3.15 \pm 0.35 \text{ kgm}$)

7. Install case and shaft assembly (4), then tighten mounting bolts (3).

 Rocking portion of shaft, contact portion of lever and piston: **Grease (G2-LI)**


 Mounting bolt:

$27.95 \pm 3.43 \text{ Nm}$ ($2.85 \pm 0.35 \text{ kgm}$)

8. Install lever (2), then tighten screw (1).

 Rocking portion of lever pin and plate: **Grease (G2-LI)**

 Screw: **$8.8 \pm 0.98 \text{ Nm}$ ($0.9 \pm 0.1 \text{ kgm}$)**



CEP00533


REMOVAL OF PPC SHUTTLE VALVE ASSEMBLY

- ⚠ Lower the work equipment completely to the ground and stop the engine. Then loosen the oil filler cap slowly to release the pressure inside the hydraulic tank.
- ⚠ Disconnect the cable from the negative (-) terminal of the battery.
- ★ Make match marks at the male and female ends of the oil pressure switch connectors.
- ★ Before disconnecting any hoses, check the distinguishing tape stuck to the hose, or make match marks.

1. Disconnect 8 oil pressure switch connectors (1).


2. Disconnect 12 PPC hoses (2).

※ 1





3. Disconnect 15 control valve hoses (3) (quick joint connection).

※ 1




4. Disconnect 4 straight-travel hoses (4).

- ★ The elbows on the front two hoses are long, so hold the elbow with a wrench when disconnecting the hoses.



5. Disconnect clamp (5).
6. Remove mounting bolts, then remove PPC shuttle valve assembly (6).




INSTALLATION OF PPC SHUTTLE VALVE ASSEMBLY

- Carry out installation in the reverse order to removal.



- Check that the quick joint does not come out when the hose is pulled.
- **Refilling with oil (hydraulic tank)**
 - ★ Add oil through the oil filler to the specified level.
Run the engine to circulate the oil through the system. Then check the oil level again.

DISASSEMBLY OF PPC SHUTTLE VALVE ASSEMBLY



1. Disconnection of valve

Remove mounting bolts (1), and disconnect shuttle valve assembly (2), travel junction valve assembly (3) and plate (4).


2. Disassembly of shuttle valve assembly

- 1) Remove 8 oil pressure switches (5).
- 2) Remove 2 slow return valves (6).
- 3) Remove shuttle valve (7).
- 4) Remove plugs (8), then remove balls (9).
★ There are 6 plugs and 6 balls.

3. Disassembly of travel junction valve assembly

- 1) Remove 2 each of plug (10), spring (11), and retainer (12).
- 2) Remove spool (13).
- 3) Remove 2 plugs (14).

ASSEMBLY OF PPC SHUTTLE VALVE ASSEMBLY



SDP00610

1. Assembly of travel junction valve assembly.

- 1) Fit O-ring and install 2 plugs (14).
 Plug:
 $17.16 \pm 2.45 \text{ Nm}$ ($1.75 \pm 0.25 \text{ kgm}$)
- 2) Assemble spool (13), and install 2 retainers (12) and springs (11).
- 3) Fit O-ring and install 2 plugs (10).
 Plug:
 $107.9 \pm 14.7 \text{ Nm}$ ($11.0 \pm 1.5 \text{ kgm}$)

- 4) Install 8 oil pressure switches (5).

3. Connection of valve

Fit O-ring and assemble shuttle valve assembly (2), travel junction valve assembly (3) and plate (4), then tighten mounting bolts (1).

- Mounting bolt:
 $66.19 \pm 7.35 \text{ Nm}$ ($6.75 \pm 0.75 \text{ kgm}$)

2. Assembly of shuttle valve assembly

- 1) Fit O-ring and assemble balls (9), then install plugs (8).
 ★ There are 6 plugs and 6 balls.
 Plug:
 $34.3 \pm 4.9 \text{ Nm}$ ($3.5 \pm 0.5 \text{ kgm}$)
- 2) Fit O-ring and install shuttle valve (7).
 ★ If the shuttle valve has been disassembled, be careful of the direction of installation of the poppet when assembling.
- 3) Fit O-ring and install 2 slow return valves (6).
 ★ If the slow return valve has been disassembled, be careful of the direction of installation of the poppet when assembling.

REMOVAL OF BOOM CYLINDER ASSEMBLY




⚠ Extend the arm and bucket fully, lower the work equipment completely to the ground, and put the safety lock lever in the LOCK position.

1. Disconnect grease hose (1).
2. Sling boom cylinder assembly (2), and remove lock bolt (3). ※ 1
3. Remove plate (4), then remove head pin (5). ※ 2
 - ★ There are shims installed, so check the number and thickness, and keep in a safe place.
4. Start engine, and retract piston rod, then tie piston rod with wire to prevent it from coming out.
 - ★ Set stand ① under the cylinder assembly, and adjust the position for slinging the cylinder assembly.

⚠ Release the remaining pressure in the hydraulic circuit.
For details, see TESTING AND ADJUSTING, Releasing remaining pressure in hydraulic circuit.
5. Disconnect hoses (6).
6. Remove plate, then using forcing screws ②, remove bottom pin (7), and remove boom cylinder assembly (2). ※ 3
 - ★ There are shims installed, so check the number and thickness, and keep in a safe place.



Boom cylinder assembly: **300 kg**



INSTALLATION OF BOOM CYLINDER ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1

- ★ When tightening the locknut, tighten so that the clearance between the plate and nut is 0.5 – 1.5 mm.

※ 2

- Inside surface of bushing when assembling pin: **Anti-friction compound (LM-P)**
- Greasing after assembling pin: **Grease (LM-G)**




- ⚠ When aligning the position of the pin hole, never insert your fingers in the pin hole.
- ★ Adjust the shim thickness so that the clearance between the end face of the rod of cylinder (2) and plate (4) is less than 1.0 mm.
 - Standard shim thickness: 1.0 mm, 1.5 mm

※ 3

- Inside surface of bushing when assembling pin: **Anti-friction compound (LM-P)**
- Greasing after assembling pin: **Grease (LM-G)**

- ⚠ When aligning the position of the pin hole, never insert your fingers in the pin hole.
- ★ Adjust the shim thickness so that the clearance between the end face of the bottom of cylinder (2) and bracket (8) is less than 1.0 mm.
 - Standard shim thickness: 1.0 mm, 1.5 mm

- Bleeding air**
 - ★ Bleed the air. For details, see TESTING AND ADJUSTING, Bleeding air.
- Refilling with oil (hydraulic tank)**
 - ★ Add oil through the oil filler to the specified level. Run the engine to circulate the oil through the system. Then check the oil level again.



REMOVAL OF ARM CYLINDER ASSEMBLY

⚠ Extend the arm cylinder piston rod to a point approx. 200 mm before the end of the IN stroke, lower the work equipment completely to the ground, then set the remaining safety lock lever to the LOCK position.

1. Set block ① between arm cylinder and boom.
2. Remove plate (1), then remove head pin (2).

※ 1

3. Start engine, and retract piston rod, then tie piston rod with wire to prevent it from coming out.



⚠ Release the remaining pressure in the hydraulic circuit.
For details, see TESTING AND ADJUSTING, Releasing remaining pressure in hydraulic circuit.

4. Disconnect hoses (3).
5. Disconnect grease hose (4).
6. Raise arm cylinder assembly (5), remove plate (4), then remove bottom pin (7), and remove arm cylinder assembly (5).

※ 2



Arm cylinder assembly: **430 kg (PC300)**
440 kg (PC350)



INSTALLATION OF ARM CYLINDER ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1

 Inside surface of bushing when assembling pin: **Anti-friction compound (LM-P)**

 Greasing after assembling pin: **Grease (LM-G)**

 When aligning the position of the pin hole, never insert your fingers in the pin hole.

※ 2

 Inside surface of bushing when assembling pin: **Anti-friction compound (LM-P)**

 Greasing after assembling pin: **Grease (LM-G)**

 When aligning the position of the pin hole, never insert your fingers in the pin hole.

- ★ Adjust the shim thickness so that the clearance between the end face of the bottom of cylinder (5) and bracket (8) is less than 1.0 mm.


- Standard shim thickness: 1.0 mm

- **Bleeding air**

- ★ Bleed the air.
For details, see TESTING AND ADJUSTING, Bleeding air.

- **Refilling with oil (hydraulic tank)**

- ★ Add oil through the oil filler to the specified level.
Run the engine to circulate the oil through the system. Then check the oil level again.



REMOVAL OF BUCKET CYLINDER ASSEMBLY

⚠ Extend the bucket cylinder piston rod to a point approx. 200 mm before the end of the DUMP stroke, lower the work equipment completely to the ground, then set the safety lock lever to the LOCK position.

1. Set block ① under arm top, block ② between link and arm, and block ③ between bucket cylinder and arm.

2. Remove lock bolt (1).

※ 1

3. Remove plate (2), then remove head pin (3).

※ 2

4. Start engine, and retract piston rod, then tie piston rod with wire to prevent it from coming out.

⚠ Release the remaining pressure in the hydraulic circuit.

For details, see TESTING AND ADJUSTING, Releasing remaining pressure in hydraulic circuit.

5. Disconnect hoses (4).




6. Raise bucket cylinder assembly (5), remove plate (6), then remove bottom pin (7), and remove bucket cylinder assembly (5).

※ 3

★ There are shims installed, so check the number and thickness, and keep in a safe place.



Bucket cylinder assembly: 270 kg




INSTALLATION OF BUCKET CYLINDER ASSEMBLY

- Carry out installation in the reverse order to removal.


※ 1

- ★ When tightening the locknut, tighten so that the clearance between the plate and nut is 0.5 – 1.5 mm.




※ 2

- Inside surface of bushing when assembling pin: **Anti-friction compound (LM-P)**
- Grease after assembling pin: **Grease (LM-G)**
- ⚠ When aligning the position of the pin hole, never insert your fingers in the pin hole.
- ★ Adjust the shim thickness so that the clearance between link (8) and link (9) is less than 1.0 mm.
 - Standard shim thickness: 0.8 mm



※ 3

- Inside surface of bushing when assembling pin: **Anti-friction compound (LM-P)**
- Grease after assembling pin: **Grease (LM-G)**
- ⚠ When aligning the position of the pin hole, never insert your fingers in the pin hole.
- ★ Adjust the shim thickness so that the clearance between the end face of the bottom of cylinder (5) and bracket (10) is less than 1.0 mm.
 - Standard shim thickness: 1.0 mm



- **Bleeding air**
 - ★ Bleed the air.
For details, see TESTING AND ADJUSTING, Bleeding air.
- **Refilling with oil (hydraulic tank)**
 - ★ Add oil through the oil filler to the specified level.
Run the engine to circulate the oil through the system. Then check the oil level again.

DISASSEMBLY OF HYDRAULIC CYLINDER ASSEMBLY

1. Piston rod assembly.

- 1) Fix bottom end of cylinder assembly (1) in tool **U1** or press, then remove mounting bolts, and disconnect head assembly (2).



Unit: mm

Cylinder	Boom	Arm	Bucket
Bolt (width across flats)	27	30	27


- 2) Pull out piston rod assembly (3).
- ★ Place a container under the cylinder to catch the oil.

2. Piston assembly, head assembly.


- 1) Fix head end of piston rod assembly (3) in tool **U1** or press.



- 2) Remove screw (4), then remove 11 balls (5), and remove plunger (6).
- ★ Arm cylinder only
- 3) Remove 6 screws (7), then remove spacer (8).



- 4) Remove piston assembly (9), O-ring and backup ring (10).
- 5) Remove plunger (11).
- ★ Boom and arm cylinder only.
- 6) Disassembly of piston assembly.
 - i) Remove rings (12).
 - ii) Remove wear rings (13).
 - iii) Remove piston ring (14).




DISASSEMBLY AND ASSEMBLY

HYDRAULIC CYLINDER

- 7) Remove collar assembly (15) and head assembly (2) from piston rod (3).


★ The collar is on the boom and arm cylinder only.



- 8) Disassembly of collar


★ Disassemble collar (15) for the boom and arm cylinders only.

- i) Remove O-ring and backup ring (16).
- ii) Remove collar (18) and ring (19) from collar (17).



- 9) Disassembly of head assembly

- i) Remove O-ring and backup ring (20).
- ii) Remove snap ring (21), then remove dust seal (22).
- iii) Remove rod packing (23).
- iv) Remove buffer ring (24).
- v) Remove bushing (25).





ASSEMBLY OF HYDRAULIC CYLINDER ASSEMBLY

- ★ Be careful not to damage the packings, dust seals, and O- rings.
- ★ Do not try to force the backup ring into position. Warm it in warm water (50 – 60°C) before fitting it.



1. Assembly of cylinder head assembly

- 1) Using tool **U4**, press fit bushing (25).
- 2) Assemble buffer ring (24).
- 3) Assemble rod packing (23).
- 4) Using tool **U5**, install dust seal (22), and secure with snap ring (21).
- 5) Install O-ring and backup ring (20).



2. Assembly of collar assembly




- ★ Assemble collar (15) for the boom and arm cylinders only.
- 1) Assemble ring (19) and collar (18) to collar (17).
 - 2) Assemble O-ring and backup ring (16).



3. Assembly of piston assembly

- 1) Using tool **U2**, expand piston ring (14).
 - ★ Set the piston ring on the tool **U2**, and turn the handle 8 – 10 times to expand the ring.
- 2) Assemble piston ring (14) to piston.
- 3) Set tool **U3** in position, and compress piston ring (14).
- 4) Assemble wear ring (13).
- 5) Assemble ring (12).
 - ★ Be careful not to open the end gap of the ring too wide.

 Ring groove: **Grease (G2-LI)**



4. Piston rod assembly

- 1) Fix head end of piston rod in tool **U1** or press.
- 2) Assemble head assembly (2) and collar assembly (15) to rod.
 - ★ Collar assembly (15) is for the boom and arm cylinder only.
- 3) Install plunger (11), O-ring and backup ring (10).
 - ★ Plunger (11) is for the boom and arm cylinder only.
- 4) Install piston assembly (9) and spacer (8), and tighten with screws (7).

 Screw:

Thread tightener (Loctite No. 262)

 Screw: Arm cylinder:

176.5 ± 19.6 Nm (18 ± 2 kgm)

Boom cylinder: **110.32 ± 12.26 Nm**

(11.25 ± 1.25 kgm)



- 5) Set plunger (6) on piston rod, assemble 11 balls (5), then secure with screw (4).

 Screw: **Thread tightener (LT-2)**

 Screw:

66.19 ± 7.35 Nm (6.75 ± 0.75 kgm)



- ★ Caulk the rod end after tightening the screw.
- ★ Arm cylinder only.

**5. Cylinder assembly**

- 1) Fix bottom end of cylinder tube in tool **U1** or press.
- 2) Assemble piston rod assembly (2).
 -  Seal: **Grease (G2-LI)**
 - ★ Set the end gap of the ring at the horizontal (side) position, align the center of shaft and cylinder tube, then insert.
 - ★ After inserting, check that the ring is not broken and has not come out, then push in fully.
- 3) Tighten head assembly (1) with mounting bolts.

 Mounting bolt:

Cylinder	Width across flats (mm)	Tightening torque (Nm(kgm))
Boom, bucket	27	372.7 ± 53.9 (38 ± 5.5)
Arm	30	529.6 ± 78.5 (54 ± 8)







REMOVAL OF WORK EQUIPMENT ASSEMBLY

⚠ Extend the arm and bucket fully, lower the work equipment to the ground, and set the safety lock lever to the LOCK position.

1. Disconnect grease hose (1).
2. Sling boom cylinder assembly (2), and remove lock bolt (3).
3. Remove plate (4), then remove head pin (5). ※ 1
※ 2
 ★ There are shims installed, so check the number and thickness, and keep in a safe place.
4. Start engine, and retract piston rod, then tie piston rod with wire to prevent it from coming out, and lower cylinder onto stand.
 ★ Disconnect the boom cylinder on the opposite side in the same way.
⚠ Release the remaining pressure in the hydraulic circuit.
 For details, see TESTING AND ADJUSTING, Releasing remaining pressure in hydraulic circuit.
5. Disconnect arm cylinder hoses (6) and bucket cylinder hoses (7), and secure to valve with rope.
6. Disconnect wiring connector (8) for working lamp.
7. Remove plate, and set tool **V** to boom foot pin (9).
8. Raise work equipment assembly (10), then remove boom foot pin (9) using tool **V**, and remove work equipment assembly (10). ※ 3
 ★ There are shims installed, so check the number and thickness, and keep in a safe place.



Work equipment assembly: **5700 kg**



INSTALLATION OF WORK EQUIPMENT ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1

- ★ When tightening the locknut, tighten so that the clearance between the plate and nut is 0.5 – 1.5 mm.

※ 2

- Inside surface of bushing when assembling pin: **Anti-friction compound (LM-P)**
- Grease after assembling pin:

Grease (LM-G)

- ⚠ When aligning the position of the pin hole, never insert your fingers in the pin hole.
- ★ Adjust the shim thickness so that the clearance between the end face of the rod of cylinder (2) and plate (4) is less than 1.0 mm.
 - Standard shim thickness: 1.0 mm, 1.5 mm

※ 3

- Inside surface of bushing when assembling pin: **Anti-friction compound (LM-P)**
- Grease after assembling pin:

Grease (LM-G)




- ⚠ When aligning the position of the pin hole, never insert your fingers in the pin hole.
- ★ Adjust the shim thickness so that the clearance between the end face of the foot of boom (11) and bracket (12) is less than 1.0 mm.
 - Standard shim thickness: 0.8 mm, 1.5 mm

- **Bleeding air**

- ★ Bleed the air.
For details, see TESTING AND ADJUSTING, Bleeding air.

- **Refilling with oil (hydraulic tank)**

- ★ Add oil through the oil filler to the specified level.
Run the engine to circulate the oil through the system. Then check the oil level again.






REMOVAL OF BUCKET ASSEMBLY

- ⚠ Set the back of the bucket facing down, lower the work equipment completely to the ground, and set the safety lock lever to the LOCK position.

1. Remove lock bolt (1). ※ 1
2. Remove connecting pin (2) between link and bucket. ※ 2
 - ★ There are shims installed, so check the number and thickness, and keep in a safe place.
3. Start engine, and retract piston rod, then tie link to arm with wire to prevent piston rod from coming out.
4. Remove lock bolt (3). ※ 3
5. Remove plate (4), then remove connecting pin (5) between arm and bucket. ※ 4
 - ★ There are shims installed, so check the number and thickness, and keep in a safe place.
6. Start engine, then raise work equipment and swing to remove bucket assembly (6).



Bucket assembly: **1050 kg**



INSTALLATION OF BUCKET ASSEMBLY

Carry out installation in the reverse order to removal.

※ 1, ※ 3

- ★ When tightening the locknut, tighten so that the clearance between the plate and nut is 0.5 – 1.5 mm.

※ 2

Inside surface of bushing when assembling pin: **Anti-friction compound (LM-P)**



Grease after assembling pin:

Grease (LM-G)



When aligning the position of the pin hole, never insert your fingers in the pin hole.

- ★ Adjust the shim thickness so that the clearance between the end face of the boss of bucket (6) and link (7) is less than 1.0 mm.
 - Standard shim thickness: 0.8 mm

※ 4



Inside surface of bushing when assembling pin: **Anti-friction compound (LM-P)**






Grease after assembling pin:

Grease (LM-G)





When aligning the position of the pin hole, never insert your fingers in the pin hole.

- ★ Insert the O-ring at the end face of the bucket boss securely.
- ★ Adjusting bucket clearance.
 - 1) Measure clearance **a** between arm (8) and bushing (9).
 - ★ It is easier to measure if the bucket is moved to one side so that all the play is in one place.
 - 2) Select shim thickness **b** so that clearance **a** is 0.5 – 1.0 mm.
 - ★ Standard shim thickness: 0.5 mm, 1.0 mm
 - 3) Install selected shim, then install plate (4).



REMOVAL OF ARM ASSEMBLY

1. Remove bucket assembly.
For details, see REMOVAL OF BUCKET ASSEMBLY.
2. Secure link to arm with wire.
 ⚠ Extend the arm cylinder piston rod to a point approx. 200 mm before the end of the IN stroke, then lower the arm on to block ① and stand ②, and set the safety lock lever to the LOCK position.
3. Set block ③ between arm cylinder and boom.
4. Remove plate (1), then remove arm cylinder head pin (2). ※ 1
5. Start engine, and retract piston rod, then tie piston rod with wire to prevent it from coming out.
 ⚠ Release the remaining pressure in the hydraulic circuit.
 For details, see TESTING AND ADJUSTING, Releasing remaining pressure in hydraulic circuit.
6. Disconnect 2 bucket cylinder hoses (3).
7. Remove plate (4), then remove connecting pin (5) between arm and boom. ※ 2
 ★ There are shims installed, so check the number and thickness, and keep in a safe place.
8. Start engine, then raise boom and swing to remove arm assembly (6).



Arm assembly: **1500 kg**

INSTALLATION OF ARM ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1

 Inside surface of bushing when assembling pin: **Anti-friction compound (LM-P)**

 Grease after assembling pin: **Grease (LM-G)**

 When aligning the position of the pin hole, never insert your fingers in the pin hole.

※ 2

 Inside surface of bushing when assembling pin: **Anti-friction compound (LM-P)**

 Grease after assembling pin: **Grease (LM-G)**

 When aligning the position of the pin hole, never insert your fingers in the pin hole.

★ Adjust the shim thickness so that the clearance between the end face of the bottom of arm (6) and boom (7) is below 1.0 mm.


★ Standard shim thickness: 1.0 mm

- **Bleeding air**

★ Bleed the air.
For details, see TESTING AND ADJUSTING, Bleeding air.

- **Refilling with oil (hydraulic tank)**

★ Add oil through the oil filler to the specified level.
Run the engine to circulate the oil through the system. Then check the oil level again.






REMOVAL OF BUCKET, ARM ASSEMBLY

⚠ Extend the bucket cylinder piston rod to the end of the CURL stroke, and the arm cylinder piston rod to a point approx. 200 mm before the end of the IN stroke. Then lower the work equipment completely to the ground, and set the safety lock lever to the LOCK position.

1. Set block ① to bucket cylinder bottom mounting boss portion of arm.
2. Remove plate (1), then remove arm cylinder head pin (2). ※ 1
3. Start engine, and retract piston rod, then tie piston rod with wire to prevent it from coming out.
⚠ Release the remaining pressure in the hydraulic circuit.
 For details, see TESTING AND ADJUSTING, Releasing remaining pressure in hydraulic circuit.
4. Disconnect 2 bucket cylinder hoses (3).
5. Remove plate (4), then remove connecting pin (5) between arm and boom. ※ 2
 ★ There are shims installed, so check the number and thickness, and keep in a safe place.
6. Start engine, then raise boom and swing to remove bucket and arm assembly (6).



Bucket, arm assembly: **2600 kg**



INSTALLATION OF BUCKET, ARM ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1

 Inside surface of bushing when assembling pin: **Anti-friction compound (LM-P)**
 Grease after assembling pin:

Grease (LM-G)

- ⚠ When aligning the position of the pin hole, never insert your fingers in the pin hole.

※ 2

 Inside surface of bushing when assembling pin: **Anti-friction compound (LM-P)**
 Grease after assembling pin:

Grease (LM-G)


- ⚠ When aligning the position of the pin hole, never insert your fingers in the pin hole.
- ★ Adjust the shim thickness so that the clearance between the end face of the bottom of arm (6) and boom (7) is less than 1.0 mm.
 - Standard shim thickness: 1.0 mm

- **Bleeding air**

- ★ Bleed the air.
For details, see TESTING AND ADJUSTING, Bleeding air.

- **Refilling with oil (hydraulic tank)**

- ★ Add oil through the oil filler to the specified level.
Run the engine to circulate the oil through the system. Then check the oil level again.







REMOVAL OF BOOM ASSEMBLY

1. Remove bucket and arm assembly
For details, see REMOVAL OF BUCKET, ARM ASSEMBLY.
- ⚠ Lower the boom assembly completely to the ground, and set the safety lock lever to the LOCK position.
2. Disconnect grease hose (1).
3. Sling boom cylinder assembly (2), and remove lock bolt (3). ※ 1
4. Remove plate (4), then remove head pin (5). ※ 2
- ★ There are shims installed, so check the number and thickness, and keep in a safe place.
5. Start engine, and retract piston rod, then tie piston rod with wire to prevent it from coming out, and lower it onto stand.
- ★ Disconnect the boom cylinder on the opposite side in the same way.
- ⚠ Release the remaining pressure in the hydraulic circuit.
For details, see TESTING AND ADJUSTING, Releasing remaining pressure in hydraulic circuit.
6. Disconnect arm cylinder hoses (6) and bucket cylinder hoses (7), and secure to valve with rope.
7. Disconnect wiring connector (8) for working lamp
8. Remove plate, and set tool V to boom foot pin (9).
9. Raise boom assembly (10), remove boom foot pin (9) using tool V, then remove boom assembly (10). ※ 3
- ★ There are shims installed, so check the number and thickness, and keep in a safe place.



Boom assembly: **3000 kg**



INSTALLATION OF BOOM ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1

- ★ When tightening the locknut, tighten so that the clearance between the plate and nut is 0.5 – 1.5 mm.

※ 2

- Inside surface of bushing when assembling pin: **Anti-friction compound (LM-P)**
- Grease after assembling pin: **Grease (LM-G)**

- ⚠ When aligning the position of the pin hole, never insert your fingers in the pin hole.
- ★ Adjust the shim thickness so that the clearance between the end face of the rod of cylinder (2) and plate (4) is less than 1.0 mm.
 - Standard shim thickness: 1.0 mm, 1.5 mm

※ 3

- Inside surface of bushing when assembling pin: **Anti-friction compound (LM-P)**
- Grease after assembling pin: **Grease (LM-G)**




- ⚠ When aligning the position of the pin hole, never insert your fingers in the pin hole.
- ★ Adjust the shim thickness so that the clearance between the end face of the foot of boom (10) and bracket (11) is less than 1.0 mm.
 - Standard shim thickness: 0.8 mm, 1.5 mm

Bleeding air

- ★ Bleed the air.
For details, see TESTING AND ADJUSTING, Bleeding air.

Refilling with oil (hydraulic tank)


- ★ Add oil through the oil filler to the specified level.
Run the engine to circulate the oil through the system. Then check the oil level again.




REMOVAL OF OPERATOR'S CAB ASSEMBLY

⚠ Disconnect the cable from the negative (-) terminal of the battery.



1. Remove floor mat.
2. Remove operator's seat (1).
★ Be careful not to damage the covers.




3. Remove knob (2).
4. Remove 4 bolts and 1 clip, then remove panels (3) and (4).





5. Disconnect window washer hose (5).
6. Remove plate (6), then remove left cover (7).



7. Disconnect hose (8) and speaker wiring connector, then remove right cover (9).
★ Lift up right cover (9) slightly before disconnecting the speaker wiring connector.



8. Remove cover (10) and duct (11).
9. Disconnect air conditioner cable (12).
10. Disconnect duct (13) at front.
11. Disconnect 11 connectors (14).
 - ★ Panel: CN-X07 (MIC21)
 - ★ Controller: CN-C01 (MIC13)
 - : CN-C02 (MIC21)
 - : CN-C03 (MIC20)
 - : CN-C16 (MIC17)
 - ★ Wiring harness intermediate
 - : CN-H12 (S16) White
 - : CN-H13 (S16) Blue
 - : CN-H14 (M6)
 - : CN-H15 (L2)
 - ★ Speaker: CM-M13 (KES-2)
 - ★ Air conditioner: No connector No.




12. Remove 4 mounting nuts and 6 mounting bolts, then lift off operator's cab assembly (15). ※ 1



Operator's cab assembly: **300 kg**

• ※: Nut ▲: Bolt

★ Check the length of the bolts.



INSTALLATION OF OPERATOR'S CAB ASSEMBLY


- Carry out installation in the reverse order to removal.

※ 1



Mounting nut:


277.04 ± 31.87 Nm (28.25 ± 3.25 kgm)



REMOVAL OF COUNTERWEIGHT ASSEMBLY

1. Set lifting hook chains of counterweight assembly in position, and sling.
2. Remove mounting bolts (1).
- ★ Check the location of the shims.
3. Lift off counterweight assembly (2).

※ 1


Counterweight assembly: **5500 kg**

INSTALLATION OF COUNTERWEIGHT ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1

- ★ Adjust the stepped difference (top and bottom clearance) from the bodywork with shims.
- ★ Install so that the clearance between the door and counterweight and the clearance between the revolving frame and the counterweight are a uniform 10 ± 5 mm.

Thread of counterweight mounting bolt:
Thread tightener (LT-2)Counterweight mounting bolt:
 1814.2 ± 98.1 Nm (185 ± 10 kgm)



CEP00536

CEP00537

REMOVAL OF AIR CONDITIONER COMPRESSOR ASSEMBLY

- ⚠ Disconnect the cable from the negative (-) terminal of the battery.
- ⚠ Open the engine hood, then push the valve of the air conditioner compressor hose slowly and release the refrigerant (R134a) gradually.

1. Disconnect wiring connector (1) (CN-M34).
2. Disconnect hoses (2). ※ 1
3. Loosen tension bolts (3) and compressor mounting bolts, and remove V-belt (4) from pulley. ※ 2
4. Remove 3 mounting bolts (5) of compressor bracket, then remove compressor assembly (6).
 - ★ It is difficult to remove the compressor mounting bolts, so remove together with the bracket.



INSTALLATION OF AIR CONDITIONER COMPRESSOR ASSEMBLY

- Carry out installation in the reverse order to removal.

- ※ 1
- ★ When installing the hoses, check that the O-ring is not damaged or deteriorated, then connect the hoses.


- ※ 2
- ★ Adjust the belt tension.
For details, see TESTING AND ADJUSTING, Testing and adjusting belt tension for air conditioner compressor.

- **Charging with refrigerant**
 - ★ Using tool X, charge the air conditioner circuit with air conditioner gas (R134a).

REMOVAL OF GOVERNOR, PUMP CONTROLLER ASSEMBLY

⚠ Disconnect the cable from the negative (-) terminal of the battery.

1. Remove Radio (2) if fitted.
2. Remove plate (1), then remove cover (2), (3).
3. Lift cover (3) away carefully to locate speaker harness connector. Disconnect and remove panel completely.
4. Remove divider board (5).
5. Disconnect wiring connector (6), and remove engine throttle controller assembly (7).




INSTALLATION OF GOVERNOR, PUMP CONTROLLER ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1


- Check the performance of the work equipment, travel, and swing. For details, see TESTING AND ADJUSTING.



REMOVAL OF MONITOR PANEL ASSEMBLY

⚠ Disconnect the cable from the negative (-) terminal of the battery.

1. Remove 4 screws (1), and disconnect monitor panel assembly (2) from bracket.
2. Disconnect connectors (3), then remove monitor panel assembly (2). ※ 1




INSTALLATION OF MONITOR PANEL ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1

- Check the mode setting and display function. For details, see TESTING, ADJUSTING, AND TROUBLESHOOTING.





REMOVAL OF CONTROL STAND CASE

1. Tray


- 1) Insert a thin flat-headed screwdriver into notch at rear of tray (1) and lever up lightly to release rear claw (2).

★ The claw can only be released from the rear.



- 2) Pull tray (1) to rear to remove.

※ 2



2. Boot

- 1) Insert a thin flat-headed screwdriver between boot (3) and upper case (4), remove claw (5) at front of boot from upper case, then raise front.




- 2) Pull boot (3) to front to remove claw at rear of boot.

※ 1

- 3) Disconnect wiring connector (7) from hole for removed tray.



- 4) Push boot up, remove bolt (8), then remove lever (9) and boot (3).

★ Check the direction of the lever.




3. Upper case.

- 1) Remove 4 upper case mounting screws (10).





- 2) Push bottom center of upper case (11) from both sides, and lift up to release claws at both sides.



- 3) Use a screwdriver from front of upper case to release claws (12) at front of case.

- 4) Remove upper case (11).



INSTALLATION OF CONTROL STAND CASE


- Carry out installation in the reverse order to removal.

※ 1

- ★ When installing the boot, insert the claw at the rear first.

※ 2


- ★ When installing the tray and upper case, insert the claws at the front first.



40 MAINTENANCE STANDARD

Swing machinery	40- 2
Swing circle	40- 4
Final drive	40- 6
Track frame and recoil spring	40- 8
Idler	40- 10
Carrier roller	40- 12
Track roller	40- 13
Track	40- 14
Hydraulic pump	40- 16
Control pump and relief valve	40- 17
Control valve	40- 18
Suction-safety valve	40- 24
Swing motor	40- 25
Travel motor	40- 26
Work equipment, swing PPC valve	40- 27
Travel PPC valve	40- 28
Service PPC valve	40- 29
PPC shuttle valve, travel junction valve	40- 30
EPC solenoid valve	40- 31
Center swivel joint	40- 32
Hydraulic cylinder	40- 33
Work equipment	40- 35

SWING MACHINERY



SAP00403


MAINTENANCE STANDARD

SWING MACHINERY

Unit: mm

No.	Check item	Criteria		Remedy
		Standard clearance	Clearance limit	
1	Backlash between swing motor shaft and No. 1 sun gear	0.19 – 0.29	—	Replace
2	Backlash between No. 1 sun gear and No. 1 planet gear	0.17 – 0.52	0.90	
3	Backlash between No. 1 planet gear and ring gear	0.20 – 0.61	0.90	
4	Backlash between No. 2 planet carrier and coupling	0.047 – 0.122	—	
5	Backlash between No. 1 planet carrier and No. 2 sun gear	0.37 – 0.65	1.10	
6	Backlash between No. 2 sun gear and No. 2 planet gear	0.17 – 0.52	1.00	
7	Backlash between No. 2 planet gear and ring gear	0.20 – 0.61	1.10	
8	Backlash between coupling and swing pinion	0.07 – 0.24	—	
9	Backlash between swing pinion and swing circle	0 – 1.21	2.00	
10	Clearance between plate and coupling	0.06 – 0.82	—	
11	Wear of swing pinion oil seal contact surface	Standard size	Repair limit	Repair hard chrome plating or replace
		140 ⁰ _{-0.100}	—	


SWING CIRCLE



Unit: mm

No.	Check item	Criteria		Remedy
		Standard clearance	Clearance limit	
1	Clearance of bearing in axial direction (when mounted on machine)	0.5 – 1.6	3.2	Replace

FINAL DRIVE



SAP00407

MAINTENANCE STANDARD


FINAL DRIVE

Unit: mm

No.	Check item	Criteria		Remedy
1	Backlash between No. 1 sun gear and No 1. planet gear	Standard clearance	Clearance limit	Replace
		0.17 - 0.50	1.00	
2	Backlash between No. 1 planet gear and ring gear	0.24 - 0.70	1.10	
3	Backlash between No. 2 planet carrier and motor	0.06 - 0.24	-	
4	Backlash between No. 2 sun gear and No. 2 planet gear	0.19 - 0.54	1.00	
5	Backlash between No. 2 planet gear and ring gear	0.24 - 0.70	1.10	
6	Backlash between No. 1 planet gear and No. 2 sun gear	0.40 - 0.73	1.00	
7	End play of sprocket shaft	0.10 - 0.15	-	
8	Wear of sprocket teeth	Repair limit: 6		Rebuid or replace
		Standard size	Repair limit:	
9	Sprocket tooth width	87	84	

TRACK FRAME AND RECOIL SPRING

★ The diagram shows the PC340-6




SAP00409

Unit: mm

No	Check item	Criteria				Remedy
			Standard size	Tolerance	Repair limit	
1	Top-to-bottom width of idler guide	Track frame	123	+3 -1	127	Rebuild or replace
		Idler support	120	± 0.5	118	
2	Left-to-right width of idler guide	Track frame	266	+4 -1	271	
		Idler support	261	-	259	
3	Recoil spring	Standard size		Tolerance	Repair limit	Replace
		Free length x OD	Installed length	Installed load	Installed load	
		795 x 241	648	173 KN (17680 kgf)	- 139 KN (14140 kgf)	

MEMO

IDLER




SBP00411

MAINTENANCE STANDARD
IDLER

Unit: mm

No.	Check item	Criteria					Remedy
1	Outside diameter of protruding portion	Standard size		Repair limit			Rebuild or replace
		630		—			
2	Outside diameter of tread	590		578			
3	Width of protrusion	101		—			
4	Overall width	190		—			
5	Width of tread	44.5		50.5			Replace bushing
6	Clearance between shaft and bushing	Standard size	Tolerance		Standard clearance	Clearance limit	
			Shaft	Hole			
		80	-0.225 -0.325	+0.130 -0.010	0.215 – 0.455	1.5	
7	Clearance between shaft and support	80	-0.225 -0.290	-0.085 -0.195	0.03 – 0.205	—	Replace
8	Interference between idler and bushing	Standard size	Tolerance		Standard interference	Interference limit	Replace bushing
			Shaft	Hole			
		87.6	+0.087 +0.037	-0.042 -0.079	0.064 – 0.166	—	
9	Side clearance of idler (both sides)	Standard clearance		Clearance limit			
		0.68 – 1.22		2			

CARRIER ROLLER




SBP00415

Unit: mm

No.	Check item	Criteria					Remedy
1	Outside diameter of flange (outside)	Standard size		Repair limit			Rebuild or replace
		200		—			
2	Outside diameter of tread	168		158			
3	Width of tread	57		66			
4	Interference between shaft and bearing	Standard size	Tolerance		Standard interference	Interference limit	Replace
			Shaft	Hole			
		55	+0.021 +0.002	0 −0.015	0.002 – 0.036	—	
5	Interference between roller and bearing	100	0 −0.015	−0.024 −0.059	0.009 – 0.059	—	
6	Side clearance of roller	Standard size		Repair limit			
		0.01 – 0.22		—			

TRACK ROLLER





SBP00413

Unit: mm

No.	Check item	Criteria				Remedy	
1	Outside diameter of flange (outside)	Standard size		Repair limit		Rebuild or replace	
		216		—			
2	Outside diameter of tread	180		168			
3	Width of tread	49		55			
4	Width of flange	27		—		Replace bushing	
5	Clearance between shaft and bushing	Standard size	Tolerance		Standard clearance		Clearance limit
			Shaft	Hole			
		65	-0.250 -0.315	+0.186 -0.064	0.151 – 0.501		1.5
6	Interference between roller and bearing	Standard size	Tolerance		Standard interference	Interference limit	
			Shaft	Hole			
		72	+0.108 +0.008	-0.006 -0.036	0.014 – 0.144	—	
7	Side clearance of idler (both sides)	Standard clearance		Clearance limit		Replace	
		0.44 - 0.97		1.5			

TRACK



SDP00416


MAINTENANCE STANDARD
TRACK

Unit: mm


No.	Check item	Criteria					Remedy
1	Link pitch	Standard size		Repair limit			Replace
		216.3		219.3			
2	Outside diameter of bushing	66.9		61.9			
3	Height of grouser	36		24			Carry out lug welding or rebuild if it is possible withing repairable limit
4	Height of link	116		107			
5	Interference between bushing and link	Standard size	Tolerance		Standard interference	Interference limit	If it is lower than interference limit, replace with oversize
			Shaft	Hole			
		66.5	+0.464 +0.424	+0.074 0	0.35 - 0.464	0.10	
6	Interference between regular pin and link	44.6 (Shaft) 44.35 (Hole)	+0.235 +0.085	+0.062 0	0.273 - 0.485	0.14	
7	Interference between master pin and link	44.6 (Shaft) 44.35 (Hole)	+0.03 0	+0.062 0	0.188 - 0.28	0.14	
8	Protrusion of bushing	5.25 ± 0.3					
9	Tightening torque for shoe bolt	After tightening to initial torque 392.3 ± 39.2 Nm (40 ± 4 kgm), tighten a further 120 ± 10°					Replace

HYDRAULIC PUMP

HPV140+140





 **kgm** $66.15 \pm 7.35 \text{ Nm}$
($6.75 \pm 0.75 \text{ kgm}$)



 **kgm** $66.15 \pm 7.35 \text{ Nm}$
($6.75 \pm 0.75 \text{ kgm}$)

 **kgm** $66.15 \pm 7.35 \text{ Nm}$
($6.75 \pm 0.75 \text{ kgm}$)




 **kgm** $68.6 \pm 9.8 \text{ Nm}$
($7 \pm 1 \text{ kgm}$)

 **kgm** $68.6 \pm 9.8 \text{ Nm}$
($7 \pm 1 \text{ kgm}$)

SDP00419

CONTROL PUMP AND RELIEF VALVE

BAR-020



SBP00420


Unit: mm

No.	Check item	Criteria					Remedy
1	Top clearance of gear	Standard clearance		Clearance limit			Replace
		0.085 – 0.125		0.145			
2	Side clearance of gear	0.050 – 0.060		0.105			
3	Clearance between gear shaft and bushing	0.045 – 0.098		0.13			
4	Control relief valve spring	Standard size			Repair limit		
		Free length x OD	Installed length	Installed load	Free length	Installed load	
		32.3 x φ13	25.0	177.5 N (18.1 kg)	—	159.9 N (16.3 kg)	
—	Performance Oil: EO10-CD Oil temperature: 50 ± 5°C Oil pressure: 2.9 MPa (30 kg/cm ²)	Standard discharge amount		Discharge limit		Replace	
		Speed (rpm)	Delivery (ℓ/min)	Speed (rpm)	Delivery (ℓ/min)		
		3,200	60.2	3,200	43		




CONTROL VALVE

10-spool valve (1/6)

- ★ For details of the 9-, 8-, and 7-spool valves, see 10-SPOOL VALVE.
- ★ For details of this page, see Section 90.



- ★ When tightening the bolts at the places marked ★, always use 2 washers on top of each other.




SAP00421

MAINTENANCE STANDARD

CONTROL VALVE

(2/6)



SAP00422


Unit: mm

No.	Check item	Criteria					Remedy
1	Spool return spring	Standard size			Repair limit		Replace spring if there is damage or deformation
		Free length x OD	Installed length	Installed load	Free length	Installed load	
		54.5 x 34.8	51.2	393.3 N (40.1 kg)	—	314.8 N (32.1 kg)	
2	Spool return spring	54.2 x 34.8	51.2	416.8 N (42.5 kg)	—	338.3 N (34.5 kg)	
3	Spool return spring	54.6 x 34.8	51.2	420.7 N (42.9 kg)	—	342.3 N (34.9 kg)	
4	Spool return spring	54.4 x 34.8	51.2	411.9 N (42.0 kg)	—	333.4 N (34.0 kg)	
5	Spool return spring	54.9 x 24.2	51.2	251.0 N (25.6 kg)	—	201.0 N (20.5 kg)	

MAINTENANCE STANDARD

CONTROL VALVE

(3/6)




SAP00424

Unit: mm

No.	Check item	Criteria					Remedy
1	Valve spring	Standard size			Repair limit		Replace spring if there is damage or deformation
		Free length x OD	Installed length	Installed load	Free length	Installed load	
		23.2 x 7.2	19	41.2 N (4.2 kg)	—	33.3 N (3.4 kg)	
2	Relief spring	30.7 x 9.6	26.3	369.7 N (37.7 kg)	—	296.2 N (30.2 kg)	
3	Unload spring	38.5 x 9.8	26	83.4 N (8.5 kg)	—	66.7 N (6.8 kg)	


(4/6)



MAINTENANCE STANDARD

CONTROL VALVE

(5/6)




SAP00427

Unit: mm

No.	Check item	Criteria					Remedy
1	Regeneration valve spring	Standard size			Repair limit		Replace spring if there is damage or deformation
		Free length x OD	Installed length	Installed load	Free length	Installed load	
		31.5 x 10.3	19.5	5.9 N (0.6 kg)	—	4.4 N (0.45 kg)	
2	Piston return spring	48.1 x 10.8	28	17.5 N (1.78 kg)	—	13.9 N (1.42 kg)	
3	Piston return spring	50.4 x 17	39	158.9 N (16.2 kg)	—	142.2 N (14.5 kg)	
4	Piston return spring	48 x 10.4	36	59 N (6 kg)	—	47.1 N (4.8 kg)	
5	Load spring	30.4 x 16.7	27	428.6 N (43.7 kg)	—	343.2 N (35.0 kg)	
6	Check valve spring	13.6 x 5.5	10	1.96 N (0.2 kg)	—	1.47 N (0.15 kg)	
7	Piston return spring	24.5 x 25.2	12	1.96 N (0.2 kg)	—	1.47 N (0.15 kg)	

(6/6)




SAP00429

Unit: mm

No.	Check item	Criteria					Remedy
1	Check valve spring	Standard size			Repair limit		Replace spring if there is damage or deformation
		Free length x OD	Installed length	Installed load	Free length	Installed load	
		11.5 x 4.6	8.5	1.47 N (0.15 kg)	—	1.18 N (0.12 kg)	
2	Spool return spring	65.5 x 27.2	50	167.7 N (17.1 kg)	—	134.3 N (13.7 kg)	
3	Spool return spring	13.6 x 5.5	10	1.96 N (0.2 kg)	—	1.47 N (0.15 kg)	

SUCTION-SAFETY VALVE

FOR SERVICE VALVE




SBP00430

Unit: mm

No.	Check item	Criteria						Remedy
1	Suction valve spring	Standard size				Repair limit		Replace
		Wire diameter	Free length x OD	Installed length	Installed load	Free length	Installed load	
		φ 0.9	16.3 x φ 21.3	1.5	2.06 N (0.21 kg)	—	1.57 N (0.16 kg)	
2	Piston spring	φ 0.5	20 x φ 7	14	2.06 N (0.21 kg)	—	1.57 N (0.16 kg)	

SWING MOTOR

KMF160AB-3




Unit: mm

No.	Check item	Criteria					Remedy
1	Check valve spring	Standard size			Repair limit		Replace spring if there is damage or deformation
		Free length x OD	Installed length	Installed load	Free length	Installed load	
		46.9 x 9.2	35	11.8 N (1.2 kg)	—	9.4 N (0.96 kg)	

TRAVEL MOTOR

HMV160ADT-2




SDP00432

Unit: mm

No.	Check item	Criteria					Remedy
1	Spool return spring	Standard size			Repair limit		Replace spring if there is damage or deformation
		Free length x OD	Installed length	Installed load	Free length	Installed load	
		58.43 x 30.0	42.0	426.0 N (43.5 kg)	—	341.3 N (34.8 kg)	
2	Check valve spring	33.0 x 13.8	23.0	1.28 N (0.13 kg)	—	0.98 N (0.10 kg)	
3	Regulator piston spring	61.1 x 23.2	30.0	399.1 N (40.7 kg)	—	319.7 N (32.6 kg)	


WORK EQUIPMENT, SWING PPC VALVE



Unit: mm

No.	Check item	Criteria					Remedy
1	Centring spring (for P3, P4)	Standard size			Repair limit		Replace spring if ther is damage or deformation
		Free length x OD	Installed length	Installed load	Free length	Installed load	
		43.3 x 19.5	33.5	17.7 N (1.8 kg)	—	13.7 N (1.4 kg)	
2	Centring spring (for P3, P4)	45.5 x 19.6	33.5	29.0 N (3.0 kg)	—	23.2 N (2.4 kg)	
3	Metering spring	27.6 x 9.5	26	16.7 N (1.7 kg)	—	13.7 N (1.4 kg)	

TRAVEL PPC VALVE




SBP00435

Unit: mm

No.	Check item	Criteria					Remedy
1	Metering spring	Standard size			Repair limit		Replace spring if there is damage or deformation
		Free length x OD	Installed length	Installed load	Free length	Installed load	
		26.5 x 8.15	24.7	16.7 N (1.7 kg)	—	13.7 N (1.4 kg)	
2	Centering spring	48.1 x 15.5	32.5	107.9 N (11 kg)	—	86.3 N (8.8 kg)	


SERVICE PPC VALVE



Unit: mm

No.	Check item	Criteria					Remedy
1	Centring spring	Standard size			Repair limit		Replace spring if there is damage or deformation
		Free length x OD	Installed length	Installed load	Free length	Installed load	
		41.5 x 13.2	31.5	60 N (6.1 kg)	(40.3)	57.5 N (5.8 kg)	
2	Metering spring	28.5 x 7.6	26.5	17 N (1.7 kg)	(27.6)	16.3 N (1.7 kg)	

PPC SHUTTLE VALVE, TRAVEL JUNCTION VALVE




SDP00437

Unit: mm

No.	Check item	Criteria					Remedy
1	Spool return spring	Standard size			Repair limit		Replace spring if there is damage or deformation
		Free length x OD	Installed length	Installed load	Free length	Installed load	
		23.6 x 13.3	20	14.7 N (1.5 kg)	—	11.8 N (1.2 kg)	

Replace
spring if there
is damage or
deformation

EPC SOLENOID VALVE FOR LS VALVE




SBP00438

Unit: mm

No.	Check item	Criteria					Remedy
1	Return spring	Standard size			Repair limit		Replace EPC valve assembly if there is damage or deformation
		Free length x OD	Installed length	Installed load	Free length	Installed load	
		9.0 x 11.4	7.9	3.14 N (0.32 kg)	—	—	

CENTER SWIVEL JOINT




Unit: mm

No.	Check item	Criteria			Remedy
		Standard size	Standard clearance	Clearance limit	
1	Clearance between rotor and shaft	90	0.06 - 0.125	0.131	Replace

HYDRAULIC CYLINDER

★ The diagram shows the boom cylinder.

kgm	Boom: 327±54 Nm (38.0±5.5 kgm)	kgm	Boom: 112.7±9.8 Nm (11.5±1.0 kgm)
	Arm: 529±78 Nm (54.0±5.5 kgm)		Arm: 176±19.6 Nm (18.0±1.0 kgm)
	Bucket: 372±54 Nm (38.0± kgm)		Bucket: 112.7±9.8 Nm (11.5±1.0 kgm)




SBP00441


Unit: mm

No	Check item		Criteria					Remedy
1	Clearance between piston rod and bushing	Cylinder	Standard size	Tolerance		Standard clearance	Clearance limit	Replace bushing
		Shaft		Hole				
		Boom	100	-0.036 -0.090	+0.257 +0.047	0.083 - 0.347	0.447	
		Arm	110	-0.036 -0.090	+0.261 +0.047	0.083 - 0.351	0.451	
		Bucket	100	-0.030 -0.090	+0.257 +0.047	0.083 - 0.347	0.447	
2	Clearance between piston rod support shaft and bushing	Boom	100		+0.181 +0.125		1.0	Replace pin, bushing
		Arm	100		+0.457 +0.370		1.0	
		Bucket	90		+0.457 +0.371		1.0	
3	Clearance between bushing and mounting pin	Boom	90		+0.107 +0.045		1.0	
		Arm	100		+0.457 +0.370		1.0	
		Bucket	90		+0.457 +0.370		1.0	

WORK EQUIPMENT



SBP00443




SAP00444

Unit: mm

No	Check item	Criteria					Remedy
1	Clearance between bushing and mounting pin of boom and revolving frame	Standard size	Tolerance		Standard clearance	Clearance limit	Replace
			Shaft	Hole			
		110	-0.036 -0.071	+0.135 +0.055	0.091 - 0.225	1.0	
2	Clearance between bushing and mounting pin of boom and arm	110	-0.036 -0.090	+0.354 +0.275	0.311 - 0.444	1.0	
3	Clearance between bushing and mounting pin of boom and arm	90	-0.036 -0.090	+0.338 +0.272	0.308 - 0.428	1.0	
4	Clearance between bushing and mounting pin of boom and bucket	90	-0.036 -0.090	+0.337 +0.271	0.307 - 0.427	1.0	
5	Clearance between bushing and mounting pin of link and bucket	90	-0.036 -0.090	+0.346 +0.275	0.311 - 0.436	1.0	
6	Clearance between bushing and mounting pin of link and link	90	-0.036 -0.090	+0.346 +0.275	0.311 - 0.436	1.0	
7	Bucket clearance (a)	0.5 - 1.0					Adjust shims
8	Bucket clearance (b)	2.0					

DIMENSIONS OF WORK EQUIPMENT

1. ARM



SAP00446

MAINTENANCE STANDARD
WORK EQUIPMENT

Unit: mm

No. \ Model		Pc340-6k
1		$\varnothing 100 \begin{smallmatrix} +0.1 \\ 0 \end{smallmatrix} / \begin{smallmatrix} -0.036 \\ -0.090 \end{smallmatrix}$
2		$\varnothing 117.3 \begin{smallmatrix} +1.5 \\ 0 \end{smallmatrix} 116 \pm 1.2$
3		$320 \begin{smallmatrix} +0.5 \\ 0 \end{smallmatrix} / \begin{smallmatrix} -0.3 \\ -0.8 \end{smallmatrix}$
4		$\varnothing 110 \begin{smallmatrix} +0.354 \\ +0.275 \end{smallmatrix} / \begin{smallmatrix} -0.036 \\ -0.090 \end{smallmatrix}$
5		428.4 ± 1.0
6		219 ± 0.5
7		935.7 ± 1.0
8		3179 ± 3
9		3095.6 ± 1.0
10		468 ± 1
11		731.0 ± 0.2
12		728.0 ± 0.5
13		513.6
14		1443.6
15		$\varnothing 90 \begin{smallmatrix} +0.346 \\ +0.275 \end{smallmatrix} / \begin{smallmatrix} -0.036 \\ -0.090 \end{smallmatrix}$
16		345.0 ± 0.5
17		$\varnothing 90 \begin{smallmatrix} +0.337 \\ +0.271 \end{smallmatrix} / \begin{smallmatrix} -0.036 \\ -0.090 \end{smallmatrix}$
18	Arm as individual part	$330 \begin{smallmatrix} 0 \\ -0.5 \end{smallmatrix}$
	When press fitting bushing	$345 \begin{smallmatrix} +0.4 \\ 0 \end{smallmatrix}$
19	Min.	1990
	Max.	3275

SHOP MANUAL

KOMATSU

PC340, PC340LC-6k PC340NLC-6k

MACHINE MODEL

SERIAL NUMBER

PC340-6k

K30001 and up

PC340LC -6k

K30001 and up

PC340NLC-6k

K30001 and up

- This shop manual may contain attachments and optional equipment that are not available in your area. Please consult your local Komatsu distributor for those items you may require. Materials and specifications are subject to change without notice.
- PC340-6K mount the SA6D114E-1 engine.
For details of the engine, see the Engine Shop Manual.

The affected pages are indicated by the use of the following marks. It is requested that necessary actions be taken to these pages according to the table below.

Mark	Indication	Action required
○	Page to be newly added	Add
●	Page to be replaced	Replace
()	Page to be deleted	Discard

Pages having no marks are those previously revised or made additions.

LIST OF REVISED PAGES

Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision
●	00-1	①		10-2			10-38			10-74			10-108	
	00-2			10-3			10-39			10-75			10-109	
○	00-2-1	①		10-4			10-40			10-76			10-110	
○	00-2-2	①		10-5			10-41			10-77			10-111	
○	00-2-3	①		10-6			10-42			10-78			10-112	
○	00-2-4	①		10-7			10-43			10-79			10-113	
	00-3			10-8			10-44			10-80			10-114	
	00-4			10-9			10-45			10-81			10-115	
	00-5			10-10			10-47			10-82			10-116	
	00-6			10-12			10-49			10-83			10-117	
	00-7			10-13			10-50			10-84			10-118	
	00-8			10-14			10-51			10-85			10-120	
	00-9			10-15			10-52			10-86			10-121	
	00-10			10-16			10-53			10-87			10-122	
	00-11			10-17			10-54			10-88			10-123	
	00-12			10-18			10-55			10-89			10-124	
	00-13			10-19			10-56			10-90			10-125	
	00-14			10-20			10-57			10-91			10-126	
	00-15			10-22			10-58			10-92			10-127	
	00-16			10-23			10-59			10-93			10-128	
	00-17			10-24			10-60			10-94			10-129	
				10-25			10-61			10-95			10-130	
				10-26			10-62			10-96			10-131	
	01-1			10-27			10-63			10-98			10-132	
	01-2			10-28			10-64			10-99			10-133	
	01-3	①		10-29			10-65			10-100			10-134	
	01-4			10-30			10-66			10-101			10-135	
	01-5			10-31			10-67			10-102			10-136	
	01-6			10-32			10-68			10-103			10-137	
	01-7			10-33			10-69			10-104			10-138	
	01-8			10-34			10-70			10-105			10-139	
	01-9			10-35			10-72			10-106			10-140	
	10-1	①		10-36			10-73			10-107			10-140	


Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision
	10-141			20-10			20-102	①		20-253	①		20-324	
	10-142	①		20-11			20-103	①		20-254	①		20-325	
	10-143			20-12			20-104	①		20-255	①		20-326	
	10-144			20-13			20-105	①		20-256	①		20-327	
	10-145			20-14			20-106	①		20-257	①		20-328	
	10-146			20-15			20-107	①		20-258	①		20-329	
	10-147			20-16			20-108	①		20-259	①		20-330	
	10-148			20-17			20-109	①		20-260	①		20-331	
	10-149			20-18			20-110	①		20-261	①		20-332	
	10-150			20-20			20-111	①		20-262	①		20-333	
	10-151			20-21			20-112	①		20-263	①		20-334	
	10-152			20-22			20-113	①		20-264	①		20-335	
	10-153			20-23			20-114	①		20-265	①		20-336	
	10-154	①		20-24			20-115	①		20-266	①		20-337	
	10-155			20-25			20-116	①		20-267	①		20-338	
	10-156			20-26			20-117	①		20-268	①		20-339	
	10-157			20-27			20-118	①		20-269	①		20-340	
	10-158			20-28			20-119	①		20-270	①		20-341	
	10-159			20-29			20-120	①		20-271	①		20-342	
	10-160			20-30			20-121	①		20-272	①		20-343	
	10-161			20-31			20-122	①		20-273	①		20-344	
	10-162			20-32			20-123	①		20-274	①		20-345	
	10-163			20-33			20-124	①		20-275	①			
	10-164			20-34			20-125	①		20-276	①			
	10-165			20-35			20-126	①		20-277	①		20-351	①
	10-166			20-36			20-127	①		20-278	①		20-352	①
	10-167			20-37			20-128	①		20-279	①		20-354	①
	10-168			20-38			20-129	①		20-280	①		20-355	①
	10-169			20-39			20-130	①		20-281	①		20-356	①
	10-170			20-40			20-131	①					20-357	①
	10-171			20-41			20-132	①					20-358	①
	10-172			20-42			20-133	①		20-301			20-359	①
	10-173			20-43			20-134	①		20-302			20-360	①
	10-174			20-44			20-135	①		20-303			20-361	①
	10-175			20-45			20-136	①		20-304			20-362	①
	10-176			20-46			20-137	①		20-305			20-363	①
	10-177			20-47			20-138	①		20-306			20-364	①
	10-178			20-48			20-139	①		20-307			20-365	①
	10-179			20-49			20-140	①		20-308			20-366	①
	10-180			20-50			20-141	①		20-309			20-367	①
	10-181			20-51			20-142	①		20-310			20-368	①
	10-182			20-52			20-143	①		20-311			20-369	①
	10-183			20-53			20-144	①		20-312			20-370	①
				20-54			20-145	①		20-313			20-371	①
				20-55			20-146	①		20-314			20-372	①
	20-1			20-56						20-315			20-373	①
	20-2			20-57						20-316			20-374	①
	20-3			20-58			20-201	①		20-317			20-375	①
	20-4			20-59			20-202	①		20-318			20-376	①
	20-5			20-60			20-203	①		20-319			20-377	①
	20-6			20-61						20-320			20-378	①
	20-7									20-321			20-379	①
	20-8						20-251	①		20-322			20-380	①
	20-9			20-101	①		20-252	①		20-323			20-381	①


Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision
	20-382	①		20-479	①		30-6			30-62			30-116	
	20-383	①		20-480	①		30-9			30-63			30-117	
	20-384	①		20-481	①		30-10			30-64			30-118	
	20-385	①		20-482	①		30-11			30-65			30-119	
	20-386	①		20-483	①		30-12			30-66			30-120	
	20-387	①		20-484	①		30-13			30-67			30-121	
	20-388	①		20-485	①		30-14			30-68			30-122	
	20-389	①					30-15			30-69			30-123	
	20-390	①					30-16			30-70			30-124	
	20-391	①		20-501	①		30-17			30-71			30-125	
	20-392	①		20-502	①		30-18			30-72			30-126	
				20-504	①		30-19			30-73			30-127	
				20-505	①		30-20			30-74			30-128	
	20-401	①		20-506	①		30-21			30-75			30-129	
	20-401-1	①		20-507	①		30-22			30-76			30-130	
	20-402	①		20-508	①		30-23			30-77			30-131	
	20-403	①		20-509	①		30-24			30-78			30-132	
	20-404	①		20-510	①		30-25			30-79			30-133	
	20-405	①		20-511	①		30-26			30-80			30-134	
	20-406	①		20-512	①		30-27			30-81			30-135	
	20-407	①		20-513	①		30-28			30-82			30-136	
	20-408	①		20-514	①		30-29			30-83			30-137	
	20-409	①		20-515	①		30-30			30-84			30-138	
	20-410	①		20-516	①		30-31			30-85			30-139	
	20-411	①		20-517	①		30-32			30-86			30-140	
	20-412	①		20-518	①		30-33			30-87				
				20-519	①		30-34			30-88			40-1	
	20-451	①		20-520	①		30-35			30-89			40-2	
	20-452	①		20-521	①		30-36			30-90			40-3	
	20-454	①		20-522	①		30-37			30-91			40-4	
	20-455	①		20-523	①		30-38			30-92			40-6	
	20-456	①		20-524	①		30-39			30-93			40-7	
	20-457	①		20-525	①		30-40			30-94			40-8	
	20-458	①		20-526	①		30-41			30-95			40-10	
	20-459	①		20-527	①		30-42			30-96			40-11	
	20-460	①		20-528	①		30-43			30-97			40-12	
	20-461	①		20-529	①		30-44			30-98			40-13	
	20-462	①		20-530	①		30-45			30-99			40-14	
	20-463	①		20-531	①		30-46			30-100			40-15	
	20-464	①		20-532	①		30-47			30-101			40-16	
	20-465	①		20-533	①		30-48			30-102			40-17	
	20-466	①		20-534	①		30-49			30-103			40-18	
	20-467	①		20-535	①		30-50			30-104			40-19	
	20-468	①		20-536	①		30-51			30-105			40-20	
	20-469	①					30-52			30-106			40-21	
	20-470	①					30-53			30-107			40-22	
	20-471	①		20-541	①		30-54			30-108			40-23	
	20-472	①		20-542	①		30-55			30-109			40-24	
	20-473	①					30-56			30-110			40-25	
	20-474	①		30-1			30-57			30-111			40-26	
	20-475	①		30-2			30-58			30-112			40-27	
	20-476	①		30-3			30-59			30-113			40-28	
	20-477	①		30-4			30-60			30-114			40-29	
	20-478	①		30-5			30-61			30-115			40-30	

Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision
	40-31													
	40-32													
	40-33													
	40-35													
	40-36													
	40-37													
	40-38													
o	90-3	②												
o	90-5	②												
o	90-7	②												
o	90-9	②												
o	90-11	②												
o	90-13-1	②												
o	90-15	②												
o	90-17	②												
o	90-19	②												
o	90-21	②												
o	90-23	②												
o	90-25	②												
o	90-27	②												
o	90-29	②												
o	90-31	②												
o	90-33	②												
o	90-35	②												
o	90-35-1	②												
o	90-37	②												
o	90-39	②												
o	90-39-1	②												
o	90-41	②												

90 OTHERS


Hydraulic piping drawing	90-3
Hydraulic circuit diagram	90-5
Control valve 10-spool valve (STD + service valve x 3)	90-7
9-spool valve (STD + service valve x 2)	90-9
8-spool valve (STD + service valve x 1)	90-11
Operation for each function of CLSS	90-13-1
Operation of CLSS system as a whole	90-15
2. Pump flow merged, bucket CURL operated independently	90-17
3. Pump flow merged, boom RAISE operated independently	90-19
4. Pump flow merged, arm IN operated independently	90-21
5. Pump flow merged, arm OUT operated independently	90-23
6. Pump flow divided, travel operated independently	90-25
7. Pump flow merged, arm IN + boom RAISE operated simultaneously	90-27
8. Pump flow merged, swing + boom RAISE operated simultaneously	90-29
9. Pump flow divided (pump pressure: 19.6 MPa (200 kg/cm ²) or above) travel + boom RAISE operated simultaneously	90-31
10. Pump flow divided (pump pressure: 19.6 Mpa (200 kg/cm ²) or above) travel + arm IN operated simultaneously	90-33
Actual electric wiring diagram	90-35
Actual electric wiring diagram	90-35-1
Electric circuit diagram (1/3)	90-37
Electric circuit diagram (1/2)	90-39
Connector arrangement diagram	90-39-1
Control valve 10 spool valve (1/6)	90-41





- | | |
|---|--------------------------------------|
| 1. Working lamp | 37. Wiper motor |
| 2. Front pump pressure sensor | 38. Horn switch |
| 3. Rear pump pressure sensor | 39. Additional right head lamp |
| 4. Radiator water level sensor | 40. Right front lock |
| 5. Engine speed sensor | 41. Room lamp |
| 6. Front pump TVC solenoid | 42. Auto pull-up motor |
| 7. Rear pump TVC solenoid | 43. Window limit switch (rear) |
| 8. Window washer tank | 44. Left front lock |
| 9. Hydraulic oil level sensor | 45. Window limit switch (front) |
| 10. LS control EPC valve | 46. Additional left head lamp |
| 11. Horn (high tone) | 47. Left knob switch |
| 12. Horn (low tone) | 48. Fuse box |
| 13. Battery relay | 49. Alarm buzzer |
| 14. Battery | 50. Starting switch |
| 15. Right head lamp | 51. Fuel control dial |
| 16. Fuel level sensor | 52. Cigarette lighter |
| 17. Swing pressure switch | 53. Swing lock switch |
| 18. Bucket DUMP pressure switch | 54. Wiper, washer switch |
| 19. Bucket CURL pressure switch | 55. Lamp switch |
| 20. Arm IN pressure switch | 56. Buzzer cancel switch |
| 21. Boom LOWER pressure switch | 57. Car heater fan switch |
| 22. Arm OUT pressure switch | 58. Machine push-up switch |
| 23. Travel pressure switch | 59. Front window auto pull-up switch |
| 24. Boom RAISE pressure switch | 60. Speaker |
| 25. Swing brake solenoid valve | 61. Kerosene mode connector |
| 26. Travel speed solenoid valve | 62. Air conditioner control panel |
| 27. Pump merge/divider solenoid valve | 63. Governor, pump controller |
| 28. Boom Hi 2-stage safety solenoid valve | 64. Radio |
| 29. LS select solenoid valve | 65. TVC prolix resistor |
| 30. Engine water temperature sensor | 66. Wiper motor controller |
| 31. Intake air heater | 67. Lamp relay |
| 32. Engine oil pressure sensor | 68. Lamp relay |
| 33. Starting motor | 69. Monitor panel |
| 34. Air conditioner compressor | 70. Swing prolix switch |
| 35. Engine oil level sensor | 71. Pump prolix switch |
| 36. Alternator | |


ACTUAL ELECTRIC WIRING DIAGRAM



CONTROL VALVE


10-spool valve (1/6)

★ For details of the 9-, 8-, and 7-spool valves, see 10-SPOOL VALVE.



SAP00421


CONNECTOR ARRANGEMENT DIAGRAM




88P00322

9-spool valve (STD + service valve x 2)


★ For details of the names of the ports and the main structure, see 10-SPOOL VALVE






8-spool valve (STD + service valve x 1)

★ For details of the names of the ports and the main structure, see 10-SPOOL VALVE



HYDRAULIC PIPING DRAWING



1. Bucket cylinder
2. Arm cylinder
3. Boom cylinder
4. Center swivel joint
5. Swing motor
6. Oil cooler
7. Control valve
8. PPC shuttle valve
9. Hydraulic filter
10. Hydraulic pump
11. L.H. travel motor
12. Hydraulic tank
13. PPC safety lock valve
14. L.H. PPC valve
15. R.H. PPC valve
16. Travel PPC valve
17. Boom holding valve
18. Accumulator
19. Solenoid valve assembly
 - 19A. LS select solenoid valve
 - 19B. Boom Hi 2-stage safety solenoid valve
 - 19C. Merge/flow divider solenoid valve
 - 19D. Travel speed solenoid valve
 - 19E. Swing brake solenoid valve