

# **WORKSHOP MANUAL**

## **N-SERIES**

# **ENGINE**

## **SECTION 6E**

# **ISUZU**

**ISUZU**



International Service & Parts  
*Tokyo, Japan*

---

## **NOTICE**

**Before using this Workshop Manual to assist you in performing vehicle service and maintenance operations, it is recommended that you carefully read and thoroughly understand the information contained in Section-0A under the headings “GENERAL REPAIR INSTRUCTIONS” and “HOW TO USE THIS MANUAL”.**

**All material contained in this Manual is based on latest product information available at the time of publication.**

**All rights are reserved to make changes at any time without prior notice.**

**Applicable Model:**

---

**N-Series**

---

**This manual is applicable to 2005 year model.**

---

**THIS MANUAL INCLUDES THE FOLLOWING SECTIONS:**

| <b>SECTION No.</b> | <b>CONTENTS</b>              |
|--------------------|------------------------------|
| <b>6E</b>          | <b>ENGINE CONTROL SYSTEM</b> |