

INTELLA LIFTPARTS INC

Kalmar parts | Kalmar reach stacker parts | Kalmar lift truck parts

10071.001	Plate,Wear / Per Meter	2642	Bearing (Mast Wheel)
1094	Wheel Stud	2695	Screw *Qp
113	Grease Fitting Extension	2856	Nut,Wheel (Support W
121124.0100	Steering Spindle	2882	Washer
123	Screw **Qp**	2884	Hex Nut **See Te
1328	Wiper (Spindle Pin)	2908	Screw *Qp
150197.0100	Steering Spindle [Right]	3022	Screw *Qp
1550454421	Shock Absorber [Tt]	3049	Nut,Hex *Qp
158686.0032	See 158686.0050 Or .0080	3052	Nut *Qp
1592	Wheel Nut	306324.001	Shaft,Support Roller
1593	Wheel Bolt	306408.002	Bracket,Hyd.Cylinder
163	Extension,Valve (Tir	306487.001	Shaft,Mounting (Mast
166	Grease Fitting	3076	Bolt
167	Grease Fitting *Qp	3090	Bolt M10 X 35 *Qp
1710304111	Pedal Valve [Tt]	309354.0100	Top Support Roller Assy.
1762	Bearing [Steer Axle]	309354.0200	Top Support Roller Assy.
1862030061	Lever, Lifting Lowering	309743.0100	Shaft [Support Roller]
1873010817	Bulb	3104	Bolt *Qp
198	Extension,Valve (Tir	3119	Bolt,Hex Head *Qp
238504.0100	Shaft (Steer.Suspens	3127100000	Lock
2458	Bushing	3197010021	Cab Filter
2459	Key [Twistlock]	3223	Pin [Chain Anchor]
2565	Bearing	3252	Clamp,Hose
258066.0100	Ring,Spacer (Drive A	3283	Pin,Cotter
2581	Retaining Ring	3289	Pin,Cotter
2585	Retaining Ring	3290	Pin,Cotter
2587	Ring,Retaining	3293400011	Air Filter
2588	Retaining Ring	333985.0100	Support Roller
2590	Retaining Ring	333986.0100	Shaft [Support Roller]
2628	Washer,Lock *Qp	334194.0100	Roller W/O Stub Shaft
		335095.0100	Cover [Mast Wheel]

INTELLA LIFTPARTS INC

Kalmar parts | Kalmar reach stacker parts | Kalmar lift truck parts

336365.0100	Shaft,Mast Wheel	405809.001	Shaft,Mast Wheel
338503.0500	Washer (Updated)	405809.002	Shaft,Mast Wheel
338505.0100	Spacer (Steer.Suspen	405809.003	Pivot Shaft [Mast Wheel]
338505.0300	Spacer	405809.004	Shaft,Mast Wheel
338506.0100	Washer (Steer.Suspen	405810.001	Mast Wheel W/O Bearing [405810
338582.0100	Support Roller	405810.007	Mast Wheel
338835.0100	Support Roller Complete	405970.001	Shaft
339482.0100	Shaft,Mast Wheel	405970.008	Shaft
339483.0100	Support Roller Assy.	405974.001	Plate,Locking
339486.0100	Mast Wheel Cover	406101.001	Roller,Support (Only)
340444.0100	Symbol (Lift)	406102.002	Shaft,Support Roller
340444.0200	Symbol (Fork Tilt)	406210.001	Pin (Chain Attachmen
340444.0300	Symbol (Fork Spreadi	406210.002	Shaft
340444.0400	Symbol (Side Shift)	406317.001	Shaft
3474	Adapter	406317.003	Shaft
350190.0100	Holder,Bearing	406322.001	Bracket,Fork
3503	O-Ring (Hyd Pump)	406532.001	Mast Wheel [W/Bearings]
3505	O-Ring Hyd. Pump	406774.001	Roller,Support
3506	O-Ring (Hyd Pump) *Qp	406775.001	See A60898.0100
3507	O-Ring *Qp	406776.001	Support Roller Compl
3552	Coupling	407063.0100	Clamp (Hyd.Cylinder)
356341.0100	Shaft	407269.0500	Support Roller Assy. Kpl
358595.0100	Shaft,Mounting (Mast)	407269.0700	Support Roller Assy. Kpl
360154.0100	Mast Wheel	408470.0199	Support Roller Assembly
361146.0100	Pin [Twist Lock]	408470.0299	Support Roller Assembly
3720	Valve,Regulator	408985.3300	Nipple
3948	Cap,Radiator	409242.0200	Support Roller
405796.0200	Support Roller [Only]	409423.0100	Shim,Top Sup Roller
405796.0300	Support Roller [Only]	409423.0300	Shim,Top Sup Roller
405797.001	Ear [Support Roller]	420094.0100	Holder
405800.003	Shaft,Support Roller	420316.0100	Shaft

INTELLA LIFTPARTS INC

Kalmar parts | Kalmar reach stacker parts | Kalmar lift truck parts

420331.0200	See A49173.0100	438660.0200	Shaft
420426.0100	Shaft	439484.0100	Support Roller
420675.0100	Shaft	439485.0100	Shaft
420675.0500	Shaft	4428	Hose/Per Meter
421026.0100	Holder	4441	Sleeve
421027.0100	Shaft	450191.0100	Shim
421028.0100	Shaft	450191.0200	Shim
421112.0100	Axle	450192.0100	Protection Ring
421115.0100	Wheel	450193.0300	Link Lever [450193.0200]
421173.0200	Washer	450194.0100	Shaft
422478.0100	Washer	450195.0100	Shaft
422479.0100	Washer	454452.3200	Seal Kit (Hyd.Cylinder)
425808.0300	Seal Kit (Servo Control)	454452.4700	Seal Kit (Hyd.Cylind
425817.6500	Seal Kit	454452.5800	Seal Kit
425817.8169	Brake Pedal Spring Kit [A08460	454452.6700	Seal Kit
425817.8279	Service Kit, Te13, Te17	454452.9500	Seal Kit (Hyd.Cylinder)
425817.8286	Spindle Thrust Bearing Kit	454626.0100	Brake Pedal Assembly [5465]
425819.0300	Wear Pad	455450.0100	Washer
425954.0100	Washer	4565	Washer *Qp
432865.0100	Shim (Support Roller	4578	Screw *Qp
433846.0100	Spacer Ring	459121.1200	Seal Kit (Hyd.Cylind
433848.0100	Nut	459121.1600	Seal Kit (Hyd.Cylind
433853.0200	Arm,Steering	460703.0100	Pin (Twist Lock Box)
433972.0100	Spacer (Support Roll	460735.0100	Spacer
434008.0100	Bushing	460844.0200	Pivot Shaft
434195.0100	Shaft,Pivot	4698	Ring,Lock [59552346]
434196.0100	Ring,Spacer	4738	Nut
434197.0100	Roller,Support	4884	Breather [Lift Cylinder]
435618.0100	Washer [Tab]	50012120	Washer [924015.0122]
436019.0100	Clamp (Drive Axle Mo	50012200	Washer *Qp
438660.0100	Shaft [Cyl Mount]	50012240	Washer [923864.1346]

INTELLA LIFTPARTS INC

Kalmar parts | Kalmar reach stacker parts | Kalmar lift truck parts

50192120	Washer[923828.0766]	5475	Clamp,Hose
50410200	Hex Nut [923863.7176]	548	Wheel Nut
50411241	Nut	5482	Motor,Wiper (Front)
50611360	Nut.....	5517	Ret. Ring
50711390	Nut	5606	Diode *Qp
50751361	Nut	5623	Hose,Tank /Meter
51010160	Lock Nut *Qp	5659	Latch
51010240	Lock Nut[923864.1319,920076.00	5660	Hook
51010390	Lock Nut923828.	5725	Seal Kit (Hyd.Cylinder)
51011301	Nut	581804620	Screw *Qp
5182	Hose [Radiator]	586	Nut,Wheel
5191	Plate,End	590	Stud,Wheel
5192	Pin	5935	Seal Ring *Qp
5199	Coupling	5937	Seal Ring *Qp
5252	O-Ring (Hyd Pump) *Qp	5938	Seal Ring
529801960	Screw	5939	Seal Ring (Hyd.Fitti
53060138	Hex Screw *Qp	5957	Nut *Qp
53060140	Bolt *Qp	60240705	Rope Clips
53060220	Screw	602407191	Rope Clips
53060221	Hex Screw *Qp[923863.7377]	606014024	Chain [923976.2406]
5309	Ret. Ring *Qp	61121551	Sleeve.....
5311	Ret. Ring *Qp	611314001	Joint Bearing.....
5314	Ret. Ring *Qp	61131503	Bearing [923857.0070, 2566]
5397	Lock Nut [Mast Wheel]	611326031	Bearing [61132603].....
5398	Lock Washer [Mast Wheel]	61132992	Bearing [923857.0103]
5412	Sensor,Air Pressure	614200131	Gasket, Wet Disc
5423	Warning Light [Green]	61420015	Lip Seal.....
5430	Cover (Pilot Light)	61440222	O-Ring *Qp
5433	Pump [Windshield Washer]	61440695	O-Ring *Qp
546	Wheel Nut [Steer Axle]	61461601	Scraper.....
5473	Clamp,Hose	61588140	Seal Ring *Qp

INTELLA LIFTPARTS INC

Kalmar parts | Kalmar reach stacker parts | Kalmar lift truck parts

616571051	Shim	9033.224	Nut
616571505	Shim	920002.005	Tredoring
61730020	Retainer Ring *Qp	920002.011	Tredoring
61730050	Stop Ring *Qp [0929535030]	920028.006	Pulley, Alternator [800029573]
61733090	C-Clip.....[923863.78	920037.042	Retaining Ring
61803030	Bearing [Tt]	920037.046	Retaining Ring [Mast Wheel]
63865252	Control Glass.....	920042.005	Screw
643445101	Joint [L32771102].....	920042.008	Screw
64411110	Fitting *Qp	920042.012	Screw
64411203	Grease Fitting [160]	920042.019	Screw
65090961	Bulb	920042.028	Screw
65210507	Cable Shoe (+)	920042.030	Screw
65210508	Cable Shoe (-)	920042.070	Bolt*Qp
65210860	Led Plug [652119782,N0809069,	920042.074	Screw
65214319	Plug.....	920042.078	Screw
65214320	Contact *Qp	920042.080	Bolt (Motor Mount)
65232562	Signal Light.....	920043.046	Screw
65237156	Inductive Switch [See Text]	920043.053	Screw*Qp
652381060	Relay [65766016,806109710]	920043.054	Screw
652381065	Relay [J019120]	920043.056	Screw *Qp*
65238757	Press.Switch [65238754]..	920043.085	Screw *Qp*
65238768	Switch	920046.038	Retaining Ring
65238896	Speed Sensor [Trans]	920046.085	Retaining Ring
65245444	Inner Part.(24 Pin Male)	920049.003	Pin *Qp*
65270110	Fuse 10A *Qp[806818525]	920049.007	Split Pin *Qp
65270115	Fuse 15A *Qp[806818526]	920049.011	Pin,Cotter*Qp
65270130	Fuse *Qp	920052.0043	O-Ring
9013.101	O-Ring	920052.009	O-Ring (Servo)*Qp
9014.107	Screw, Mc6S 10* 55 12.9Obh	920052.016	O-Ring
9014.911	Ring	920052.047	O-Ring
9027.018	Bearing [2564]	920052.049	O-Ring

INTELLA LIFTPARTS INC

Kalmar parts | Kalmar reach stacker parts | Kalmar lift truck parts

920055.001	Screw,Set*Qp	920074.104	Screw
920058.003	Washer, Copper 20*16*1,5	920076.003	Nut, Lås M 8 8Fzb
920058.009	Washer, Copper 14,5*20*1,5	920076.007	Lock Nut
920065.010	Bearing	920076.008	Lock Nut
920068.0040	Nut	920081.010	Valve,Check
920068.007	Nut [920068.031]	920085.0005	Washer,Seal (Steer W
920068.019	Wheel Nut	920085.0006	Washer,Seal (Steer W
920068.020	Wheel Nut [Steer Axle]	920085.003	Sealing Washer
920068.021	Nut	920085.004	Washer, Sealing
920068.024	Nut	920085.007	Sealing Washer
920068.025	Nut	920085.009	Seal Ring
920068.027	Nut	920085.010	Dust Shield
920068.029	Nut	920085.015	Washer,Seal (Mast Wh
920068.030	Nut [Chain Adjuster]	920085.016	Dust Shield
920069.020	Screw,Set*Qp	920085.017	Seal Waher [Mast Wheel]
920069.030	Screw,Set*Qp	920085.028	Gasket
920070.018	Bushing	920085.030	Sealing,Axial, 100,8* 60
920070.019	Bushing	920085.031	Seal
920070.023	Bushing (Mast Mounting)	920085.032	Seal
920070.030	Slide Bearing	920087.001	Guide Bearing
920070.031	Bushing	920090.001	Filter Insert [Hyd]
920070.049	Bearing	920091.007	O-Ring (Valve)*Qp
920070.057	Slide Bearing	920098.003	Washer
920071.0035	Shim *Qp	920098.009	Washer
920071.007	Shims * Qp*	920098.011	Washer
920071.009	Shim (Mast Wheel)*Qp	920098.025	Washer, Brb 8.4*16 Fzb
920071.012	Shim	920099.021	Screw
920071.013	Shim	920099.024	Screw
920071.014	Shim	920099.025	Screw,M6S 8* 16 8.8Fzb
920071.016	Shim	920099.026	Screw
920074.100	Bolt (Cylinder Mount	920099.027	Screw

INTELLA LIFTPARTS INC

Kalmar parts | Kalmar reach stacker parts | Kalmar lift truck parts

920099.061	Screw	920448.002	Flasher Relay[806818539]
920099.065	Screw	920451.005	Ignition Switch W/Keys [806818
920099.073	Screw	920456.003	Sensor [Trans Oil Pressure][65
920125.016	Clamp	920457.016	Temp Gauge
920130.002	Filter,Breather (Hyd Tank)	920463.002	Pin,Roll
920130.005	Filter (920090.001 Element)	920463.006	Pin,Roll*Qp[59539343]
920130.009	Breather Filter	920463.013	Pin
920133.057	Bolt *Qp	920463.014	Pin,Roll*Qp[59539465,923855.09
920147.002	Sensor,Oil Pressure	920463.017	Pin [Mast Wheel]
920148.006	Indicator Light [Front + Rear]	920463.019	Pin, Roll
920150.003	Horn	920466.001	Washer
920155.003	Ring,Lock	920466.006	Washer (Drive Axle M
920165.007	Washer	920467.032	Bolt,Drive Axle Mount
920169.011	Sensor [Hyd Tank]	920467.034	Bolt
920176.002	Washer Motor	920467.037	Screw
920183.009	Wiperblade	920471.014	Cable Eye
920183.019	Blade,Wiper (Front)	920483.001	Bulb [Turn Signal/Brake/Twistl
920183.020	Blade,Wiper (Rear & Roof)	920584.0004	O-Ring
920350.017	Bushing	920584.0005	O Ring
920370.001	Washer	920596.0022	Sensor [Brake Light - Red Dot]
920370.002	Shim	920596.0023	Neutral Switch [Green Dot]
920371.010	Screw	920596.0024	Sensor [Low Pressure - White D
920373.096	Bolt	920596.0025	Sensor [Red Dot]
920373.100	Bolt	920596.0026	Sensor [Light Green Dot]
920373.104	Screw	920596.0027	Sensor [Declutch - Black Dot]
920373.106	Bolt (Cylinder Mount	920596.0028	Sensor [Yellow Dot]
920373.113	Bolt	920596.0029	Sensor [Inching - Brown Dot]
920379.003	Seal,Oil (Output Sha	920596.0031	Sensor,Hyd.Pressure
920379.005	Piston Ring	920596.0032	Sensor {Blue/White}
920431.004	End,Terminal*Qp	920596.0044	Pressure Switch
920437.004	Switch (Heater/A.C.)Fan	920596.0054	Indicator

INTELLA LIFTPARTS INC

Kalmar parts | Kalmar reach stacker parts | Kalmar lift truck parts

920596.0055	Pressure Sensor	920749.0005	Screw *Qp
920596.0059	Sensor [Green Dot]	920777.0015	O-Ring
920598.0002	Seal,Wheel (Steer Ax	920777.0019	O-Ring 215.49 X 3.53
920598.0004	Wheel Seal	920777.0025	O-Ring [Orfs] **Qp
920598.0005	Seal,Wheel (Steering	920777.0026	Use 804702893
920670.0003	Seal Kit Hyd.Cylinder	920794.0002	Test Nipple
920714.0003	Bolt,Hollow	920798.0002	O-Ring
920723.0003	Filter (Air Safety)	920798.0014	O-Ring *Qp
920728.106	Bolt *Qp [923636.0189]	920798.0032	O-Ring
920728.136	Bolt *Qp	920799.0002	Plate,Cover
920728.232	Screw	920811.0014	V-Belt
920729.0011	Bearing	920811.0015	V-Belt [A/C Comp]
920730.0001	Fuse (5Amp)	920811.0016	Belt [A/C A41218.0700]
920730.0005	Fuse [10A]	920811.0018	Belt
920730.0006	Fuse [15A]	920857.0002	Main Switch
920730.0007	Fuse [25A]	920872.0003	Screw,Set *Qp
920730.0010	Fuse [5A]	920888.0007	Wiper Arm
920730.0011	Fuseable Link [25A]	920897.0001	Hose,Radiator
920730.0012	Fuseable Link [30A]	920920.0001	Wheel Nut
920734.0001	Rubber Mount [Motor/Trans]	920920.0004	Wheel Nut
920734.0002	Rubber Mount [Cab/Trans]	920924.0002	Bearing
920741.0023	Shock [Driver'S Seat]	920925.0001	Seal Ring
920744.0002	Seal Kit (Hyd.Cylind	920928.0002	Handle,Door (W/Lock)
920744.0004	Seal Kit	920932.0001	V-Strip/Meter
920744.0005	Seal Kit (Hyd.Cylinder)	920934.0001	Strip,Rubber Per M.
920744.0006	Seal Kit (Hyd.Cylinder)	920952.0030	Hose Clamp
920744.0019	Seal Kit	920952.0035	Hose Clamp
920744.0026	Seal Kit (Hyd.Cylinder)	920959.0001	Grommet,Rubber
920744.0033	Seal Kit	920965.0001	Tank,Expansion
920747.0025	Warning Light	920965.0004	Expansion Tank
920749.0002	Screw *Qp	920966.0001	Expansion Tank Cap

INTELLA LIFTPARTS INC

Kalmar parts | Kalmar reach stacker parts | Kalmar lift truck parts

920966.0002	Expansion Tank Cap Green [T130	921159.0011	O-Ring (Wet Disc Bra
920966.0003	Lock, Expansion Tank	921161.0020	Bolt (Univ.Drive Sha
920969.0005	Filter (Air)	921162.0002	Bearing
920969.0045	Filter Element	921162.0003	Bearing
920971.0005	Switch [L41309024]	921162.0016	Bearing [Mast Wheel]
920971.0009	Switch,Toggle [806108106]	921163.0001	Bearing
920971.0013	Switch [Pk Brake]	921307.0001	Seal Kit [454452.9200]
920971.0016	Switch,Toggle	921317.0001	Seal Ring
920971.0027	Toggle Switch	921317.0002	Seal Ring (Steer Spindle)
920976.0001	Screw	921317.0003	Wiper
920976.0002	Screw	921350.0004	Oil Filter [Perkins]
920981.0023	O-Ring	921352.0005	Seal Kit
920983.0004	Gasket [Valve Cover]	921377.0005	Cap *Qp
920989.0003	Filter (Cab)	921401.0003	Washer
920994.0004	Hose	921418.0015	Symbol[Working Lights]
920995.0013	Pipe,Flex	921462.0003	Protective Cover
920995.0021	Hose	921462.0008	Cover,Protective
921028.0004	Filter (Transmission	921462.0010	Plug
921028.0007	Trans Filter	921463.0001	Bearing [9026.678]
921030.0001	Bulb	921463.0003	Bearing
921030.0003	Bulb	921463.0012	Guide, Bearing
921055.0019	Air Vent, Defroster [922789.00	921464.0034	Spacer Ring
921056.0019	Receiver Dryer [923726.0211 ,	921466.0004	Seal
921060.0004	Lever, Adj. [921060.0001]	921477.0032	Spring
921083.0003	Expansion Valve [923726.0611]	921496.0003	V Belt
921096.0010	V Belt Kit	921496.0028	V-Belt
921102.0001	Ring,Retaining	921510.0001	Boot,Rubber (Servo C
921104.0001	Filter (Oil)	921560.0001	Hose (Oil Cooler)
921106.0003	Thermostat	921577.0010	Fuse Box [Engine] [1866010051,
921159.0005	O-Ring	921577.0014	Fuse Box
921159.0008	O-Ring	921577.0015	Fuse Jumper

INTELLA LIFTPARTS INC

Kalmar parts | Kalmar reach stacker parts | Kalmar lift truck parts

921577.0016	Fuse Box	921928.0007	Filler Cap
921581.0004	Seal Cylinder Head	922010.0001	Cover (Switch)
921582.0001	Wheel Bolt	922010.0004	Plate,Cover
921584.0003	Lock Assy [Door Lh]	922026.0003	Wheel Bolt
921584.0016	Lock (Latch)	922029.0002	Cylinder [Engine Cover]
921609.0018	Handle [Hood]	922029.0010	Cylinder (Engine Cover)
921660.0007	Repair Kit (Servo Co	922029.0017	Gas Spring
921685.0001	Inductive Switch [Twistlocks]	922036.0010	Fuel Gauge
921689.0007	Filter Insert [923764.0603]	922037.0006	Use 923944.2226
921689.0009	Filter Element	922037.0008	Sensor, Fuel Guage
921702.0008	Mirror [Rear View]	922037.0015	Sensor, Fuel
921721.0005	Peg	922050.0003	Cone *Qp
921732.0006	Glass Lens	922050.0004	Cone *Qp
921733.0004	Work Light	922053.0003	Gasket (Fuel Line)
921733.0006	Work Light	922054.0001	Filter (Fuel)
921742.0005	Headlight	922055.0001	Seal Ring (Fuel Filt
921777.0001	Seal Ring (Hyd.Fitti *Qp	922062.0001	Seal Timing Gear
921786.0005	Tube Valve Extension	922136.0004	Clamp,Exhaust Pipe
921830.0002	Relay W/Diode	922139.0002	Washer,Lock
921830.0007	Relay	922200.0003	Relay [Key Start]
921831.0001	Relay Holder	922201.0001	Cable Terminal, Rsh D3,5 A0,5-
921899.104	Screw *Qp	922202.0001	Cable Terminal, Rs D3,5
921899.125	Bolt *Qp	922204.0001	Block,Terminal
921899.135	Bolt *Qp	922204.0044	Bushing Block [A+B 1+2 Ports]
921899.147	Screw	922204.0045	Bushing Block [C+D 3+4 Ports]
921899.167	Bolt	922204.0046	Bushing Block [E+F 5+6 Ports]
921899.208	Bolt	922204.0102	Terminal Block
921899.226	Bolt *Qp	922204.0104	Terminal Block
921922.0010	Screw	922204.0105	Terminal Block
921928.0005	Cap,Fuel Tank	922204.0108	Wire Seal
921928.0006	Cap,Fuel Tank (W/Loc	922218.0001	Lens Cover [Amber]

INTELLA LIFTPARTS INC

Kalmar parts | Kalmar reach stacker parts | Kalmar lift truck parts

922264.0003	Valve	923107.0735	Screw
922267.0001	Repair Kit (Qck.Coup	923107.0847	O-Ring (Thermostat H
922315.0004	Filter [Hydraulic Tank]	923108.0008	Spring Driver'S Seat
922316.0007	Filter, By Pass	923108.0324	O-Ring (Main Valve)
922369.0001	Disc,Clutch (Inner)	923109.0054	Screw [923636.0713,801903680]
922369.0002	Disc,Clutch (Outer)	923109.0277	O-Ring (Thermostat)
922373.0004	Wiring Harness	923109.0322	Seal Ring
922381.0001	Nut [Se4323] *Qp	923109.0333	Gasket [800820077]
922429.0001	Boot,Rubber (Cont.Ca	923109.0433	Bearing
922442.0012	Control Cable [Throttle]	923109.0449	Seal Kit [804705516]
922442.0045	Control Cable [Engine Stop]	923109.0520	Piston [Brake Caliper]
922463.0003	Cable Attachment Kit [80681779	923109.0714	Valve Spool [800820303]
922484.0001	Radiator Hose	923109.0715	O-Ring (Valve Spool)
922581.0002	Spring	923109.0724	Wheel Clamp
922599.0002	Bracket 1 Only	923110.0078	Filter Insert
922690.0029	Seal (Valve Cover)	923110.0104	O-Ring (Main Valve)
922776.0001	Gasket Kit,Cylinder	923110.0105	O-Ring (Main Valve) *Qp
922831.0007	Clamp	923110.0128	Seal (Hydraulic Pump
922908.0004	Shuttle Valve,3X04	923110.0209	Seal Kit (Hyd.Filt.Hous.)
922908.0008	Shuttle Valve	923110.0360	Grease [1Kg Can] Gleitmo 805-6
922974.0001	Nut	923110.0436	Lock Nut
922974.0004	Nut, Nyloc M12, Class 10.9 Fzb	923110.0437	Key
922974.0005	Lock Nut	923110.0577	Air Filter [923110.0838]
922978.0003	O-Ring *Qp	923110.0578	Air Filter Safety [923110.0839
922993.0002	Nut [Wheelnut Protection]	923110.0598	Gasket Kit
923050.0001	Pin	923110.0850	Stud
923071.0001	Filter Insert	923110.0854	Coil
923071.0002	Filter Insert	923119.0001	Hose Wheel
923091.0003	Back-Up Alarm	923120.0002	O-Ring
923107.0648	Gasket (Exhaust Mani	923120.0059	O-Ring (Servo Contro
923107.0699	Plug	923120.0060	O-Ring (Servo Contro

INTELLA LIFTPARTS INC

Kalmar parts | Kalmar reach stacker parts | Kalmar lift truck parts

923120.0061	Seal (Servo Control)	923349.0533	Seal,Oil (Brake Assy
923120.0120	O-Ring (Servo Contro	923349.0595	Plug (Planetary Gear
923120.0222	Filter (Air)	923349.0596	Indicator,Fluid Leve
923120.0223	O-Ring (Hydraulic Fi	923349.0597	Breather Filter
923120.0291	Filter (Air Safety)	923349.0602	Breather
923120.0404	O-Ring	923349.0603	Sight Glass [Planetary Gear]
923120.0555	Ignition Key	923349.0729	Seal
923120.0560	Lens Cover [Red]	923349.0840	O-Ring (Plntry Ge [804106594]
923120.0571	Fuel Filter	923349.0842	Ring,Backing [923705.0825]
923120.0942	Seal	923349.0847	Ring,Retaining
923140.0003	Valve	923349.0848	Seal [923941.0406]
923152.0001	Nut (Turbo Mount) *Qp	923349.0849	Gear Coupling
923162.0003	Level Indicator	923349.0850	Flange (Planetary Ge
923170.0003	Seal	923349.0851	Plug
923171.0003	Rubber Pad [Cab Mount]	923349.0852	O-Ring [923705.0823]
923174.0001	Indicator,Fluid Level	923349.0855	Pin,Roll (Planetary
923176.0001	Sensor [Coolant Level]	923349.0869	Bolt
923186.0003	Oil Filler Cap	923349.0872	Tube (Trailer Chain)
923187.0001	Hose,Radiator	923349.0874	Bolt *Qp
923190.0002	Pad	923349.0875	Solenoid,Magnetic Va
923196.0002	Cap,Radiator	923349.0967	Hose,Oil Cooler (Eng
923301.0001	Insulation, Per Meter	923349.0987	O-Ring
923301.0002	Wrap,Electrical Cable/M	923379.0001	Rubber Cushion
923341.0003	Starter Solenoid [5.9/8.3]	923405.0002	Speed Sensor [923405.0001]
923341.0004	Relay	923418.0004	Latch
923349.0056	Knob, Servo Control	923419.0001	Lock Nut
923349.0287	Seal (Gear Wheel)[804106716]	923420.0018	Wear Pad
923349.0303	Bearing (Planetary G	923436.0027	Bearing
923349.0401	Gasket	923436.0802	Plate
923349.0516	Spring (Brake Assy.)	923436.0809	Seal
923349.0532	Clutch Disc [Inner]	923436.0811	O-Ring

INTELLA LIFTPARTS INC

Kalmar parts | Kalmar reach stacker parts | Kalmar lift truck parts

923436.0823	O-Ring	923584.0001	Position Lamp
923455.0001	Door Handle [Rh+Lh Outside]	923611.0008	Pin
923455.0002	Pin,Locking (Door)	923611.0009	Lock Plate
923455.0003	Handle,Door (Right)	923611.0010	Washer *Qp
923455.0005	Handle,Door (Left)	923611.0011	Pin
923455.0014	Door Handle [Rh Inside]	923636.0056	Washer [923726.0350]
923455.0015	Door Handle [Lh Inside]	923636.0163	Bolt,Wheel (Drive Ax)[80190463
923455.0017	Retainer	923636.0195	Seal Kit [802311201,800311201]
923455.0020	Lock	923636.0257	Solenoid [800021326]
923455.0021	Door Holder(Push Button)	923636.0311	Washer
923455.0022	Pin(Push Button)	923636.0435	Nut [801904108]
923458.0184	Seal (Fuel Injector)	923636.0948	Seal Ring
923458.0269	Nut	923657.0001	Lock Washer
923458.0818	Plate (Differential)	923657.0004	Lock Washer
923468.0145	Sleeve [Fuel Injector]	923657.0005	Washer,Lock
923468.0147	Seal (Water Port)	923657.0007	Washer Las 6.5 Nordlock
923468.0162	Wheel Bolt	923657.0010	Lock Washer[50192390]
923468.0189	Bolt (Differential)	923657.0014	Lock Washer
923468.0191	Axle Nut [802309441]	923702.0009	Contact, Female
923468.0213	O-Ring	923705.0009	Gasket
923468.0214	O-Ring *Qp	923705.0107	Bolt
923468.0222	Ring [802309488]	923705.0114	Roll Pin [Dowel]
923468.0226	Screw *Qp [923726.0394]	923705.0116	Outer Disc,Clutch
923468.0232	Plug (Drive Axle) [923468.0344	923705.0117	Inner Disc,Clutch
923468.0462	O-Ring	923705.0126	Spring
923476.0002	Seal	923705.0132	Clutch Disc [Outer]
923497.0001	Fitting	923705.0341	Nozzle,Fuel Injector
923507.0009	Bolt	923705.0366	V Belt Kit (Kit = 2 Belts)
923507.0014	Screw, M6S 24*340 10.90Bh	923705.0430	Seal
923510.0001	Cap,Radiator	923705.0470	Damp Filter
923550.0003	Washer *Qp	923705.0524	Alt. Belt

INTELLA LIFTPARTS INC

Kalmar parts | Kalmar reach stacker parts | Kalmar lift truck parts

923705.0569	Screw	923828.0007	Seal Kit
923705.0583	Bolt	923828.0012	Seal Kit
923705.0820	Lock Ring	923828.0139	Seal
923705.0822	Ring, Back-Up	923828.0326	Filter, Fuel Pump
923705.0824	Ring	923828.0593	Water Filter [J021445]
923705.0826	O-Ring	923828.0734	Shaft [K5681460]
923705.0938	Key [804301070]	923829.0551	Belt, Serpentine Alternator
923705.0979	Coil	923829.0615	Oil Filter [800044638,923726.0
923726.0159	Seal	923829.0616	Trans Oil Filter [921028.0005]
923726.0187	Filter	923829.0618	Fuel Filter [800044640]
923726.0352	Sleeve	923829.0620	Oil Filter
923726.0354	Seal	923829.0652	Gasket
923726.0359	Inner Disc	923829.0662	Exhaust Cushion
923726.0360	Outer Disc	923829.0668	Filter Insert [Cab]
923726.0362	Gasket	923829.0680	V-Belt Set
923726.0363	Gasket	923829.0736	Seal Kit
923726.0366	O-Ring	923855.0244	Seal, Brown
923726.0367	O-Ring	923855.0255	Ring *Qp
923726.0388	Washer	923855.0265	Spring
923726.0396	O-Ring **Qp**	923855.0789	O-Ring
923726.0424	Brake Pad Set	923855.1183	Filter, Breather
923726.0428	Stud	923855.1184	Filter Element Servo
923726.0437	O-Ring	923855.1185	Filter Element
923726.0558	Gasket Set [804106418]	923855.1186	Coil
923727.0556	Seal Ring (923468.0204)	923855.1242	Button
923727.0590	Bolt [923726.0382]	923855.1243	Button
923736.0860	Wheel Bolt	923855.1244	Button
923764.0072	Filter Insert [923978.0418]	923855.1391	Temp Sensor [Trans] [923941.05
923764.0274	Seal	923855.1406	Plug
923764.0288	Screw *Qp	923855.1431	Seal
923774.0004	Screw	923855.1433	Outter Disc Clutch

INTELLA LIFTPARTS INC

Kalmar parts | Kalmar reach stacker parts | Kalmar lift truck parts

923855.1442	Seal Ring	923881.0001	Fitting
923855.1448	Seal	923881.0029	Nipple
923855.1459	Piston Ring	923881.0061	Nipple
923855.1469	Outter Disc Clutch	923895.0002	Washers
923855.1496	Oil Seal	923899.0635	Pipe
923855.1517	Gasket	923899.0647	O-Ring
923855.1519	Washer	923899.0685	Washer
923855.1522	Gasket	923934.0098	Wiper Arm
923855.1527	Gasket	923934.0189	Valve
923855.1533	O-Ring	923935.0047	Fluid Body Tank
923855.1554	Filter [A/C]	923935.0048	Screw
923855.1565	Sensor	923935.0127	Wiper Blade
923855.1574	Temp. Sensor	923936.0061	Switch
923855.1628	Guide Bearing	923941.0091	Coil
923855.1677	Seal Kit	923941.0092	O-Ring
923855.1689	O-Ring	923941.0121	Thermoswitch [Oil Cooler]
923855.1691	O-Ring	923941.0137	Holder
923855.1692	Spring	923944.0052	Filter Insert
923855.1695	Seal	923944.0247	Seal Kit
923855.1701	Seal Ring	923944.0491	Solenoid [923120.0886]
923855.1702	O-Ring	923944.0784	Belt
923855.1706	Dust Boot	923944.0786	Belt
923855.1709	Sleeve	923944.1474	Filter, Water Seperator
923855.1712	Cotter Pin	923944.1492	Clutch Disc [923855.1432]
923855.1724	Temp. Sensor	923944.1493	Inner Disc,Clutch Plate
923855.1754	Pump	923944.1494	Clutch Disc [923976.2816]
923855.1760	Link	923976.0118	Fuel Filter
923855.1808	Mounting Kit	923976.0126	Fuel Filter
923861.0042	Seal	923976.0129	Gasket
923861.0045	Seal	923976.0179	Coolant Filter [923976.3569]
923861.0066	Fuel Filter, Insert	923976.0204	V-Belt

INTELLA LIFTPARTS INC

Kalmar parts | Kalmar reach stacker parts | Kalmar lift truck parts

923976.0308	Level Sensor [Exp Tank]	923976.3193	O-Ring
923976.0330	Fan Belt	923976.3194	Seal Ring
923976.0599	Seal Ring	923976.3209	O-Ring
923976.0647	O-Ring	923976.3216	Tensioner
923976.0653	Bearing	923976.3222	Belt
923976.0671	V-Belt [800044988]	923976.3258	Fuel Filter, Water Sep
923976.0682	Oil Press. Sensor	923976.3291	Belt
923976.0691	V-Belt	923976.4019	Belt Serpentine
923976.0715	Thermostat	923976.4402	Oil Filter
923976.0746	Alternator Belt	923976.4410	Oil Filter
923976.0978	Thermostat	923976.4503	Pre-Filter Use 923944.1474
923976.0986	V-Belt	923976.4754	Trans Filter [800821362]
923976.1155	Oil Filter (90031083)	923976.5284	Fuel Filter Insert
923976.1313	O-Ring, -	923978.0078	Safety Filter
923976.1364	Seal Ring	923978.0398	Fuel Filter
923976.1373	Ring	923978.0417	Filter Insert
923976.1375	Ring	923978.0419	Relay
923976.1376	Seal	923978.0421	Socket
923976.1382	Clutch	923978.0459	Solenoid
923976.1383	Clutch Outer Disc	923978.0513	Seal Kit, Cylinder
923976.1384	Clutch Inner Disc	924015.0565	Bolt
923976.1399	Clutch Outer Disc	924015.0572	Bearing
923976.1400	Clutch Inner Disc	924015.0573	Bearing
923976.1401	Ring	924015.0597	Work Light
923976.1429	Gasket	924151.0001	Work Light
923976.1431	Gasket		
923976.1455	Solenoid 12V		
923976.2553	Sensor Charge Air Prepressure		
923976.2639	Slide Plate		
923976.3127	Fuel Filter [Tad650 & 750]		
923976.3154	O-Ring		