

Parts Book

DUMP TRUCK

GALEO

HD785-7

SERIAL NUMBERS J20001-- and up

NOTICE

Komatsu has Operation & Maintenance Manuals written in some other languages. if a foreign language manual is necessary, contact your local distributor for availability.



WARNING

Unsafe Use of this machine may cause serious injury or Death. Operators and maintenance personnel must read this manual before operating or maintaining this machine. This manual should be kept near the machine for reference and periodically reviewed by all personnel who will come into contact with it.

KOMATSU

LEPBH78700

PARTS BOOK

HD785-7

Serial No. J20001 and up

FOREWORD

When ordering a spare part, specially the part number, part name, and quantity required, and also specify your machine model code, machine serial number, engine serial number and the service meter reading.

This Parts Book describes not only standard items but also optional equipment and attachments. To order a part, please contact your nearest Komatsu distributor.

This Parts Book contains the information and special symbols as follows:

Figure And List	When you open this Parts Book, you will find an illustration on the left page (even-numbered page) for the spare parts group. Each individual part in the group is given an index number. On the right page, the component parts of the group are listed in the order of the index numbers shown on the illustration page. The part number, part name, and applicable machine serial number are given for each part.
Ref.	The Ref. is the number of the illustration shown on the page. It is not the spare part number. The numbers are not always continuous.
Item	This is the same as the item number in the illustration. The parts are listed in item number order.
Part No.	The number given in the Part No. Column is the part number for the part shown. It is the code used when ordering that part. It is important that there be no mistake in this code number when ordering.
Description	This gives the name of part that has the part number listed. The mark “.” is put in front of the part name of an assembly part and the item is entered following the assembly. If a part marked with “.” is a sub assembly, its components are marked with “.”. Example : ELEMENT ASSEMBLY, AIR CLEANER .ELEMENT ASSEMBLY, OUTER ..ELEMENT, OUTER ..NUT, WING ..WASHER
Qty (Quantity)	This specifies the number of pieces used for one machine. However, if a part is included in the assembly and/or component is specified.
Options	Applicable engine serial number is indicated for the engine volume, in the chassis volume, this indicates the machine serial number in which the part is used.

Symbols and codes

Symbols and codes used in the PART No. and DESCRIPTION columns, and represent the following:

- The part specified in the line above can be used instead of this part.
- ▣ This part can be used instead of the part specified in the line immediately above.
- ◆ This part and the part specified in the line immediately above are interchangeable.
- ▲ The part specified in the DESCRIPTION column can be used instead of this part if it is used as a set.
- ☒ This shows discontinued part. The part specified in the above line is supplied instead.
- ▼ This shows discontinued part. The part specified in the DESCRIPTION column is supplied instead as a set.
- ☆ This part cannot be supplied as an individual part. It is supplied as an assembly.
- ★ This part cannot be supplied as individual part. It is supplied as an assembly. However, it is supplied as an individual part by authorized distributor only.
- ⊙ This indicates a part group. The part marked with this symbol is not considered a supply part.
- ===== The parts surrounded by this line are components of the part group specified in the above line.
- G-1, G2 These indicate categories of part groups.
- KIT This indicates kit parts. For kit parts, refer to the service kit tables provided in this Parts Book.
- △ This indicates a part supplied semi-finished. It requires additional work before installation.
- PAINT (1) This indicates parts shipped painted with under coat.
- PAINT (2) This indicates parts supplied with different colors from the original color of your machine.
- (A) This code indicates special parts for cold weather “A” specification (-30°C) machines.
- (B) This code indicates special parts for cold weather “B” specification (-50°C) machines.

HD785-7
SAA12V140E-3B

Serial No. J20001 and up
Engine No. 00500319 and up

CONTENTS

OF-2Foreword

CO-1Contents

Page	Reference	Title
[ENGINE]		
030010	A1010-A7B4	CTLINDER HEAD
030020	A1110-A7A6	HEAT COVER
030030	A1310-A7E9	AIR INTAKE MANIFOLD
030040	A1310-B7E9	AIR INTAKE CONNECTION AND SENSOR
030050	A1370-A7D1	PRE-HEATER SWITCH
030060	A1510-A7V6	EXHAUST MANIFOLD (WITH EXHAUST TEMPERATURE
030070	A1530-A7D6	TURBOCHARGER AND LUBRICATING OIL PIPING
030080	A1530-B7D6	TURBOCHARGER WATER PIPING
030090	A1530-C7D6	TURBOCHARGER(KTR110L-F85PW) (INNER PARTS)
030100	A1570-A7A8	HEAT SHIELD
030110	A1650-A7A3	EXHAUST BRAKE AND MOUNTING
030120	A1650-A7A4	EXHAUST BRAKE (WITHOUT EXHAUST BRAKE SPEC)
030130	A1650-B7A3	EXHAUST BRAKE (INNER PARTS)
030140	A1730-A7C5	THERMOSTAT AND THERMOSTAT HOUSING
030150	A1730-A7C7	THERMOSTAT AND THERMOSTAT HOUSING (EXTREMELY BAD FUEL AND POOR FUEL ARRANGEMENTS SPEC) (WATER DUSTY)
030160	A2010-A7C6	CYLINDER BLOCK
030170	A2011-A7C1	CYLINDER BLOCK ACCESSORY (BLIND COVER AND-SENSOR)
030180	A2011-A7C2	CYLINDER BLOCK ACCESSORY(BLIND COVER AND-SENSOR) (ADDITIONAL FUEL FILTER SPEC)

Page	Reference	Title
030185	A2011-A7C6	CYLINDER BLOCK ACCESSORY (OIL SENSOR SWITCH-AND WATER HEATER)
030190	A2040-A7B4	FRONT COVER
030200	A2041-A7E5	GEAR CASE AND FRONT COVER ACCESSORY
030210	A2041-A7E7	GEAR CASE AND FRONT COVER ACCESSORY (EXTREMELY BAD FUEL AND POOR FUEL ARRANGEMENT SPEC) (WATER)
030220	A2041-B7E5	BREATHER AND BLOWBY SENSOR WIRING
030230	A2041-B7E7	BREATHER AND BLOWBY SENSOR WIRING(EXTREMELY BAD FUEL AND POOR FUEL ARRANGEMENT SPEC) (WATER DUST)
030240	A2050-A7A3	IDLER GEAR
030250	A2060-A7A1	CAMFOLLOWER COVER
030260	A2070-A7B6	OIL FILLER
030270	A2110-A7G1	OIL PAN SUCTION TUBE
030275	A2110-A7G7	OIL PAN AND SUCTION TUBE (COLD TERRAN SPEC) (PM-CLINIC SPEC)
030280	A2110-B7G1	OIL LEVEL SENSOR
030290	A2110-C7G1	OIL LEVEL GAUGE
030300	A2210-A7C9	FLYWHEEL HOUSING (WITH BARING AND REVOLUTION-SENSOR)
030310	A2230-A7B6	FLYWHEEL
030320	A2250-A7A6	FRONT SUPPORT AND REAR BRACKET (SERVICE ONLY)
030335	A2250-A7C7	FRONT SUPPORT AND BRACKET
030337	A2250-A7C8	FRONT SUPPORT AND BRACKET
030340	A2310-A7A4	CRANKSHAFT
030350	A2330-A7A1	DAMPER
030360	A2350-A7B5	PISTON
030370	A2370-A7A3	CRANK PULLEY (PULLEY DIAMETER 182MM)
030380	A2410-A7A7	CAMSHAFT
030390	A2411-A7A5	CAMFOLLOWER
030400	A2411-B7A5	ROCKER ARM

Page	Reference	Title
030410	A3010-A7A6	OIL PUMP
030420	A3110-A7D7	OIL FILTER
030430	A3110-B7D7	OIL ADAPTER
030440	A3310-A7C4	OIL COOLER
030445	A3310-A7C6	OIL COOLER (COLD TERRAIN SPEC) (PM CLINIC SPEC) ..
030450	A4010-A7F7	FUEL INJECTION PUMP MOUNTING
030460	A4010-B7F7	COMMON RAIL (L.H) (INNER PARTS)
030470	A4010-C7F7	COMMON RAIL (R.H) (INNER PARTS)
030480	A4040-A7A7	FUEL SUPPLY PUMP BRACKET AND RAIL RETURN PIPING
030490	A4040-A7A8	SUPPLY PUMP BRACKET AND RAIL PIPING (EXTREMELY- BAD FUEL AND POOR FUEL ARRANGEMENT SPEC) (WA- TER DUST)
030500	A4050-A7A5	FUEL INJECTION PIPING (1/4) (COMMON RAIL INJECTOR)
030510	A4050-B7A5	FUEL INJECTION PIPING (2/4) (INJECTION PIPING SUP PORT)
030520	A4050-C7A5	FUEL INJECTION PIPING (3/4) (INJECTION PIPING COVER)
030530	A4050-D7A5	FUEL INJECTION PIPING (4/4) (SUPPLY PUMP-COMMON RAIL)
030540	A4060-A7A7	FUEL SUPPLY PUMP LUBRICATOR
030550	A4060-A7A8	FUEL SUPPLY PUMP LUBRICATOR (EXTREMELY BAD FUEL AND POOR FUEL ARRANGEMENT SPEC) (WATER DUSTY)
030560	A4080-A7B2	FUEL INJECTION PUMP DRIVE
030570	A4110-A7E5	FUEL PIPING (R.H. BANK)
030580	A4110-A7E6	FUEL PIPING (EXTREMELY BAD FUEL AND POOR FUEL- ARRANGEMENT SPEC)(WATER DUSTY)
030590	A4110-B7E5	FUEL PIPING (L.H BANK)
030600	A4110-B7E6	FUEL CONNECTION (EXTREMELY BAD FUEL AND POOR- FUEL ARRANGEMENT SPEC) (WATER DUST DUSTY)
030610	A4110-C7E6	FUEL FILTER (EXTREMELY BAD FUEL AND POOR FUEL- ZARRANGEMENT SPEC) (WATER DUSTY)
030620	A4110-D7E6	FUEL AIR VENT (R.H BANK) (EXTREMELY BAD FUEL AND- POOR FUEL ARRANGEMENT SPEC) (WATER DUSTY)

Page	Reference	Title
030630	A4110-E7E6	FUEL AIR VENT (L.H BANK) (EXTREMELY BAD FUEL AND- POOR FUEL ARRANGEMENT SPEC) (WATER DUSTY)
030640	A4110-F7E6	FUEL PRIMING PUMP (EXTREMELY BAD FUEL AND POOR- FUEL ARRANGEMENT SPEC) (WATER DUSTY)
030650	A4110-G7E6	FUEL PRIMING PUMP COVER (EXTREMELY BAD FUEL AND POOR FUEL ARRANGEMENT SPEC)
030655	A4119-A7A1	FUEL FILTER (1-5/8) (SERVICE ONLY)
030660	A4210-A7C5	FUEL INJECTION NOZZLE AND SPILL PIPE
030670	A4230-A7C6	FUEL RETURN
030680	A4710-A7D8	FUEL CONTROLLER
030690	A4710-A7D9	FUEL CONTROLLER (EXTREMELY BAD FUEL AND POOR- FUEL ARRANGEMENT SPEC)
030700	A5010-A7E7	WATER PUMP
030705	A5010-A7E8	WATER PUMP
030710	A5010-A7E9	WATER PUMP (EXTREMELY BAD FUEL AND POOR FUEL- ARRANGEMENT SPEC) (WATER DUSTY)
030720	A5010-B7E7	WATER PUMP BYPASS PIPING
030725	A5010-B7E8	WATER PUMP BYPASS PIPING
030730	A5010-B7E9	WATER PUMP BYPASS PIPING(EXTREMELY BAD FUEL AND POOR FUEL ARRANGEMENT SPEC) (WATER DUSTY)
030740	A5010-C7E7	AIR WATER PIPING AND WATER OUTLET
030745	A5010-C7E8	AIR VENT PIPING AND WATER OUTLET
030750	A5010-C7E9	AIR PIPING AND WATER OUTLET (ADDITIONAL FUEL FIL- TER SPEC)
030760	A5030-A7B5	COOLING FAN (SUCTION TYPE)
030770	A5050-A7B5	FAN PULLEY AND DRIVE BELT
030780	A5060-A7B3	FAN DRIVE
030790	A5080-A7B1	TENSION PULLEY
030800	A5210-A7A1	CORROSION RESISTOR
030810	A5210-A7A6	CORROSION RESISTOR (EXTREMELY BAD FUEL AND- POOR FUEL ARRANGEMENT SPEC) (WATER DUST)
030820	A6010-A7C1	ALTERNATOR MOUNTING (90A)
030830	A6010-A7C2	ALTERNATOR MOUNTING (90A) (EXTREMELY BAD FUEL ...

Page	Reference	Title
		AND POOR FUELARRANGEMENT SPEC) (WATER DUST) .
030840	A6010-B7C1	ALTERNATOR (90A) (INNER PARTS)
030860	A6030-A7B3	ALTERNATOR DRIVE
030870	A6210-A7B1	STARTING MOTOR MOUNTING (7.5KW)
030875	A6210-A7B3	STARTING MOTOR MOUNTING (11KW)
030880	A6210-B7B1	STARTING MOTOR (7.5KW)(INNER PARTS)
030890	A6810-A7C7	ELECTRICAL WIRING (1/3) (INJECTOR HARNESS GROUP)
030900	A6810-B7C7	ELECTRICAL WIRING (2/3) (PRESSURE AND TEMPERATU- RE SENSOR GROUP)
030910	A6810-C7C7	ELECTRICAL WIRING (3/3) (MAIN HARNESS GROUP)
030912	A8110-A7A3	CYLINDER HEAD GASKET KIT (FOR HD785-7)
030914	A8120-A7A3	CYLINDER BLOCK GASKET KIT (FOR HD785-7)
030916	A8160-A7A2	WATER PUMP GASKET KIT (FOR HD785-7)
030920	A9810-A7H5	NAME PLATE AND CAUTION (REGULATION OF EPA2ND) ...
030930	A9810-A7H6	NAME PLATE AND CAUTION (ENGLISH)
030940	A9980-A7A7	PM-CLINIC ACCESSORY
030950	A9980-A7A8	PM-CLINIC ACCESSORY
[ENGINE RELATED PARTS]		
030010	B0100-01A0	ENGINE MOUNTING
030020	B0100-02A0	EXHAUST BRACKET
030030	B0100-03A0	ENGINE COOLING TUBE
030040	B0600-01A0	DAMPER
[COOLING SYSTEM]		
060010	C0110-01A0	RADIATOR (1/2)
060020	C0110-02A0	RADIATOR (2/2)
060030	C0110-02A1	RADIATOR (2/2) (WITH AIR CONDITIONER)
060040	C0110-03A0	RADIATOR (FAN NET)
060050	C0110-04A0	RADIATOR (MOUNTING BRACKET)
060060	C0110-05A0	RADIATOR (BUFFLE)
060070	C0120-01A0	COOLANT LINE (1/3)
060080	C0120-02A0	COOLANT LINE (2/3)

Page	Reference	Title
060090	C0120-03A0	COOLANT LINE (3/3)
060100	C0120-04A0	COOLANT LINE (BYPASS TUBE)
060110	C0120-05A0	COOLANT LINE (AIR INTAKE PIPING)
060120	C0130-01A0	COOLANT LEVEL SENSOR
[FUEL TANK AND RELATED PARTS]		
090010	D0100-01A0	FUEL TANK (TANK) (1/2)
090050	D0100-02A3	FUEL TANK (TANK) (2/2) (WITH FUEL QUICK COUPLER- AND VANDALISM PROTECTION)
090060	D0100-03A0	FUEL TANK (SUCTION VALVE)
090090	D0100-04A4	FUEL TANK (WITH FUEL QUICK CHARGER VALVE)(FOR- ADDITIONAL FUEL FILTER)
090100	D0100-05A0	FUEL TANK (BOLT HOLE PLUG)
090110	D0100-06A0	FUEL TANK (MOUNTING BRACKET AND COVER)
090120	D0200-01A0	FUEL LINE (1/7)
090130	D0200-02A0	FUEL LINE (2/7)
090140	D0200-03A0	FUEL LINE (3/7)
090150	D0200-04A0	FUEL LINE (4/7)
090160	D0200-05A0	FUEL LINE (5/7)
090170	D0200-06A0	FUEL LINE (6/7)
090180	D0200-07A0	FUEL LINE (7/7)
090190	D0200-11A1	FUEL LINE (TANK TO BLOCK)(FOR ADDITIONAL FUEL - FILTER)
090200	D0200-12A1	FUEL LINE (BLOCK)(FOR ADDITIONAL FUEL FILTER)
090210	D0200-13A1	FUEL LINE (BLOCK TO COOLING PLATE)(FLOOR ADDI- TIONAL FUEL FILTER)
090220	D0200-14A1	FUEL LINE (COOLING PLATE TO WATER SEPARATOR)- (R.H)(FOR ADDITIONAL FUEL FILTER)
090230	D0200-15A1	FUEL LINE (COOLING PLATE TO WATER SEPARATOR)- (L.H)(FOR ADDITIONAL FUEL FILTER)
090240	D0200-16A1	FUEL LINE (WATER SEPARATOR)(R.H) (FOR ADDITIONAL- FUEL FILTER)
090250	D0200-17A1	FUEL LINE (WATER SEPARATOR) (L.H) (FOR ADDITIONAL-

Page	Reference	Title
		FUEL FILTER)
090260	D0200-18A1	FUEL LINE (WATER SEPARATOR TO FILTER) (L.H)(FOR- ADDITIONAL FUEL FILTER)
090270	D0200-19A1	FUEL LINE (WATER SEPARATOR TO FILTER) (R.H)(FOR- ADDITIONAL FUEL FILTER)
090280	D0200-20A1	FUEL LINE (FILTER TO ENGINE) (R.H) (FOR ADDITIONAL- FUEL FILTER)
090290	D0200-21A1	FUEL LINE (FILTER TO ENGINE) (L.H) (FOR ADDITIONAL- FUEL FILTER)
090300	D0200-22A1	FUEL LINE (FILTER TO ENGINE) (R.H) (FOR ADDITIONAL- FUEL FILTER)
090310	D0200-23A1	FUEL LINE (BLOCK TO ENGINE) (L.H) (FOR ADDITIONAL- FUEL FILTER)
[ELECTRICAL SYSTEM]		
120010	E0100-01A0	BATTERY BOX (BATTERY)
120020	E0100-01A1	BATTERY BOX (BATTERY) (LARGE CAPACITY)
120030	E0100-02A0	BATTERY BOX (STAY)
120040	E0100-03A0	BATTERY BOX (BOX)
120050	E0100-04A0	BATTERY BOX (RELAY)
120060	E0100-05A0	BATTERY BOX (CIRCUIT BREAKER)
120070	E0100-05A3	BATTERY BOX (CIRCUIT BREAKER) (ADDITIONAL FILTER)
120080	E0100-06A0	REAR HOOD
120090	E0100-06A2	REAR HOOD (FOR EXHAUST BRAKE)
120100	E0100-07A0	BRAKE LINE (VALVE BOX)
120110	E0100-08A0	BRAKE LINE (UNDER HOOD)
120120	E0100-09A0	BRAKE LINE (CAB HOOD)
120130	E0100-10A0	BREATHER
120140	E0100-11A2	EXHAUST BRAKE VALVE
120150	E0100-12A0	REAR HOOD RELATED PARTS
120160	E0100-12A3	REAR HOOD RELATED PARTS (ADDITIONAL FILTER)
120170	E0200-01A0	ELECTRICAL SYSTEM (MAIN HARNESS)
120180	E0200-01A1	ELECTRICAL SYSTEM (MAIN HARNESS) (ADDITIONAL-

Page	Reference	Title
		FILTER)
120190	E0200-02A0	ELECTRICAL SYSTEM (BRACKET CLAMP)
120200	E0200-03A0	ELECTRICAL SYSTEM (STARTER CABLE)
120210	E0200-04A0	ELECTRICAL SYSTEM (HORN AND BRACKET)
120230	E0200-05A0	ELECTRICAL SYSTEM (CLIP, R.H)
120240	E0302-01A0	REAR LAMP (BRACKET)
120250	E0302-01A1	REAR LAMP (BRACKET) (FOR OPTION LAMP)
120260	E0302-02A0	REAR LAMP (LAMP AND BUZZER)
120270	E0302-A2A2	REAR LAMP (LAMP AND BUZZER) (WITH ADDITIONAL- LAMP)
120280	E0302-02A3	REAR LAMP (LAMP AND BUZZER) (WITH LED LAMP)
120290	E0302-02A4	REAR LAMP (LAMP AND BUZZER) (WITH ADDITIONAL LAMP -AND LED LAMP)
120300	E0302-03A0	REAR LAMP (MOUNTING PARTS)
120310	E0350-01A0	SIDE LAMP
120320	E0350-01A1	SIDE LAMP (FOR PAYLOAD MATAR)
120330	E0360-01A0	FOG LAMP
120340	E0820-01A0	PAYLOAD METER LAMP
[TORQUE CONVERTER AND TRANSMISSION]		
150010	F3210-01A0	FRONT PROPELLER SHAFT
150020	F3240-01A0	REAL PROPELLER SHAFT UNIT
150030	F3310-51A0	TORQUE CONVERTER (1/7) (BARE UNIT)
150040	F3310-52A0	TORQUE CONVERTER (2/7) (INPUT SHAFT)
150050	F3310-53A0	TORQUE CONVERTER (3/7) (DRIVE CASE)
150060	F3310-54A0	TORQUE CONVERTER (4/7) (REAR HOUSING)
150070	F3310-55A0	TORQUE CONVERTER (5/7) (POWER TAKE OFF)
150080	F3310-56A0	TORQUE CONVERTER (6/7) (VALVE MOUNT)
150090	F3310-57A0	TORQUE CONVERTER (7/7) (CHARGE PUMP)
150100	F3310-58A0	TORQUE CONVERTER VALVE
150110	F3320-51A0	TRANSMISSION (1/10) (1ST, 2ND, 3RD AND REVERSE- CLUTCH)
150120	F3320-52A0	TRANSMISSION (2/10) (HIGH CLUTCH)

Page	Reference	Title
150130	F3320-53A0	TRANSMISSION (3/10) (LOW AND 4TH CLUTCH)
150140	F3320-54A0	TRANSMISSION (4/10) (CARRIER) C (1/4)
150150	F3320-55A0	TRANSMISSION (5/10) (CARRIER) C (2/4)
150160	F3320-56A0	TRANSMISSION (6/10) (CARRIER) C (3/4)
150170	F3320-57A0	TRANSMISSION (7/10) (CARRIER) C (4/4)
150180	F3320-58A0	TRANSMISSION (8/10) (CASE)
150190	F3320-59A0	TRANSMISSION (9/10) (DOCKING UNIT)
150200	F3320-60A0	TRANSMISSION (10/10) (INPUT AND OUTPUT)
150210	F3320-61A0	TRANSMISSION CONTROLL VALVE (1/4)
150220	F3320-62A0	TRANSMISSION CONTROLL VALVE (2/4)
150230	F3320-63A0	TRANSMISSION CONTROLL VALVE (3/4)
150240	F3320-64A0	TRANSMISSION CONTROLL VALVE (4/4)
150250	F3320-65A0	TRANSMISSION LUBRICATION VALVE
150260	F3320-66A0	TRANSMISSION OIL PAN
150270	F3320-67A0	TRANSMISSION SENSOR
150280	F3500-01A0	REAR AXLE (DIFFERENTIAL) (1/3)
150290	F3500-02A0	REAR AXLE (DIFFERENTIAL) (2/3)
150300	F3500-03A0	REAR AXLE (DIFFERENTIAL) (3/3)
150310	F3500-04A0	REAR AXLE (FINAL DRIVE) (L.H) (1/2)
150320	F3500-05A0	REAR AXLE (FINAL DRIVE) (L.H) (2/2)
150340	F3500-06A1	REAR AXLE (FINAL BRAKE) (L.H) (ABS/ASR) (1/4)
150360	F3500-07A1	REAR AXLE (FINAL BRAKE) (L.H) (ABS/ASR) (2/4)
150380	F3500-08A1	REAR AXLE (FINAL BRAKE) (L.H) (ABS/ASR) (3/4)
150390	F3500-09A1	REAR AXLE (FINAL BRAKE) (L.H) (ABS/ASR) (4/4)
150400	F3500-10A0	REAR AXLE (FINAL DRIVE) (R.H) (ABS/ASR) (1/2)
150410	F3500-11A0	REAR AXLE (FINAL DRIVE) (R.H) (ABS/ASR) (2/2)
150430	F3500-12A1	REAR AXLE (FINAL BRAKE) (R.H) (ABS/ASR) (1/4)
150450	F3500-13A1	REAR AXLE (FINAL BRAKE) (R.H) (ABS/ASR) (2/4)
150470	F3500-14A1	REAR AXLE (FINAL BRAKE) (R.H) (ABS/ASR) (3/4)
150480	F3500-15A1	REAR AXLE (FINAL BRAKE) (R.H) (ABS/ASR) (4/4)
150490	F3500-16A0	REAR AXLE (HOUSING)
150510	F3500-17A1	REAR AXLE (BRAKE PIPING) (ABS/ASR)
150520	F3500-18A1	REAR AXLE (AXLE SENSOR)

Page	Reference	Title
150540	F3350-19A1	REAR AXLE (BLIND PARTS) (FOR WITH ABS)
150550	F3500-20A0	REAR AXLE SUPPORT
150560	F3810-01A0	TRANSMISSION MOUNTING PARTS
150570	F4400-01A0	FRONT AXLE (R.H) (HUB)
150580	F4400-02A0	FRONT AXLE (R.H) (BRAKE) (1/3)
150590	F4400-03A0	FRONT AXLE (R.H) (BRAKE) (2/3)
150600	F4400-04A0	FRONT AXLE (R.H) (BRAKE) (3/3)
150610	F4400-05A0	FRONT AXLE (R.H) (FRONT SUSPENSION ASS'Y) (CYLIN DER)
150620	F4400-05A2	FRONT AXLE (R.H) (FRONT SUSPENSION ASS'Y) (CYLIN DER) (FOR PAYLOAD METER)
150630	F4400-06A0	FRONT AXLE (R.H) (FRONT SUSPENSION ASS'Y) (VALVE) .
150660	F4400-08A0	FRONT AXLE (R.H) (FRONT SUSPENSION ASS'Y) (COVER)
150680	F4400-08A2	FRONT AXLE (R.H) (FRONT SUSPENSION ASS'Y) (COVER) (FOR PAYLOAD METER)
150700	F4400-09A2	FRONT AXLE (R.H) (SENSOR) (FOR PAYLOAD METER)
150710	F4400-10A0	FRONT EXLE (R.H) (LUBLICATION)
150720	F4400-11A0	FRONT AXLE (R.H) (LEVER)
150730	F4400-12A0	FRONT AXLE (R.H) (FINAL BRAKE LINE)
150740	F4400-13A0	FRONT EXLE (R.H) (BRAKE COOLING LINE)
150760	F4400-15A0	FRONT AXLE (R.H) (TRANSPORT)
150770	F4400-15A1	FRONT AXLE (R.H) (TRANSPORT) (AUTO SUSPENSION) ...
150780	F4400-21A0	FRONT AXLE (L.H) (HUB)
150790	F4400-22A0	FRONT AXLE (L.H) (BRAKE) (1/3)
150800	F4400-23A0	FRONT AXLE (L.H.) (2/3)
150810	F4400-24A0	FRONT AXLE (L.H.) (3/3)
150820	F4400-25A0	FRONT AXLE (R.H) (FRONT SUSPENSION ASS'Y) (CYLIN DER)
150830	F4400-25A2	FRONT AXLE (L.H) (FRONT SUSPENSION ASS'Y) (CYLIN DER) (FOR PAYLOAD METER)
150840	F4400-26A0	FRONT AXLE (L.H) (FRONT SUSPENSION ASS'Y) (VALVE) ..
150870	F4400-28A0	FRONT AXLE (L.H) (FRONT SUSPENSION ASS'Y) (COVER)
150890	F4400-28A2	FRONT AXLE (L.H) (FRONT SUSPENSION ASS'Y) (COVER)

Page	Reference	Title
		(FOR PAYLOAD METER)
150910	F4400-29A2	FRONT AXLE (L.H) (SENSOR) (FOR PAYLOAD METER)
150920	F4400-30A0	FRONT AXLE (L.H.) (LUBICATION)
150930	F4400-31A0	FRONT AXLE (L.H.) (LEVER)
150940	F4400-32A0	FRONT AXLE (L.H) (BRAKE LINE)
150950	F4400-33A0	FRONT AXLE (L.H) (BRAKE COOLING LINE)
150970	F4400-35A0	FRONT AXLE (L.H.) (TRANSPORT)
150980	F4400-35A1	FRONT AXLE (L.H) (TRANSPORT) (AUTO SUSPENSION) ...
150990	F4400-36A1	FRONT AXLE (L.H) (HOSE CLIP) (FOR SUSPENSION CY- LINDER LINE) (AUTO SUSPENSION)
151000	F4400-36A3	FRONT AXLE (L.H) (HOSE CLIP) (FOR SUSPENSION CY- LINDER LINE) (AUTO SUSPENSION AND PAYLOAD METER)
[HYDRAULIC SYSTEM]		
210010	H0100-01A0	HYDRAULIC TANK ASS'Y (1/2)
210020	H0100-02A0	HYDRAULIC TANK ASS'Y (2/2)
210030	H0100-02A1	HYDRAULIC TANK ASS'Y (2/2) (WITH VANDALISM PROTEC TION)
210040	H0100-03A0	HYDRAULIC TANK ASS'Y (VALVE)
210050	H0100-04A0	HYDRAULIC TANK ASS'Y (TRANSMISSION FILTER.)
210070	H0100-05A0A	HYDRAULIC TANK ASS'Y (BRAKE COOLING LINE)
210080	H0100-06A0	HYDRAULIC TANK ASS'Y (SUCTION LINE)
210090	H0100-07A0	HYDRAULIC TANK ASS'Y (PETROL PIPING)
210100	H0100-07A1	HYDRAULIC TANK ASS'Y (WITH VANDALISM PROTECTION)
210110	H0100-08A0	HYDRAULIC TANK ASS'Y (D/V-FILTER LINE)
210120	H0100-09A0	HYDRAULIC TANK ASS'Y (STEERING VALVE LINE)
210130	H0100-10A0	HYDRAULIC TANK ASS'Y (HOIST VALVE TO DUMP CON TROL VALVE LINE)
210140	H0100-11A0	HYDRAULIC TANK ASS'Y (HOIST LINE)
210150	H0100-12A0	HYDRAULIC TANK ASS'Y (RETURN LINE)
210160	H0100-13A0	HYDRAULIC TANK ASS'Y (TRANSMISSION TO FILTER LINE)
210170	H0100-14A0	HYDRAULIC TANK ASS'Y (EMERGENCY STEERING LINE) .

Page	Reference	Title
210180	H0100-15A0	HYDRAULIC TANK ASS'Y (SENSOR)
210190	H0100-16A0	HYDRAULIC TANK ASS'Y (MOUNTING PARTS)
210200	H0125-01A0	BRAKE CONTROL VALVE
210210	H0125-51A0	BRAKE CONTROL VALVE (INNER PARTS)
210220	H0210-01A0	HYDRAULIC MAIN PUMP
210230	H3310-01A0	TRANSMISSION PIPING (1/4)
210240	H3310-02A0	TRANSMISSION PIPING (2/4)
210250	H3310-03A0	TRANSMISSION PIPING (3/4)
210260	H3310-04A0	TRANSMISSION PIPING (4/4)
210270	H3310-05A0	TRANSMISSION PIPING (BREATHHER TUBE) (1/2)
210280	H3310-06A0	TRANSMISSION PIPING (BREATHHER TUBE) (2/2)
210290	H3410-01A0	STEERING AND HOIST PIPING (STEERING CYLINDER)
210300	H3410-02A0	STEERING AND HOIST PIPING (CROSS OVER VALVE)
210310	H3410-02A1	STEERING AND HOIST PIPING (CROSS OVER VALVE)
		(FOR- ASR)
210320	H3410-03A0	STEERING AND HOIST PIPING (PIPING) (1/7)
210330	H3410-04A0	STEERING AND HOIST PIPING (PIPING) (2/7)
210350	H3410-05A0A	STEERING AND HOIST PIPING (PIPING) (3/7)
210370	H3410-06A0A	STEERING AND HOIST PIPING (PIPING) (4/7)
210380	H3410-07A0	STEERING AND HOIST PIPING (PIPING) (5/7)
210390	H3410-08A0	STEERING AND HOIST PIPING (PIPING) (6/7)
210400	H3410-09A0	STEERING AND HOIST PIPING (PIPING) (7/7)
210410	H3410-10A0	STEERING AND HOIST PIPING (DUMP CONTROL)
210420	H3410-11A0	STEERING AND HOIST PIPING (DUMP CONTROL LINE)- (1/3)
210430	H3410-12A0	STEERING AND HOIST PIPING (DUMP CONTROL LINE)- (2/3)
210440	H3410-13A0	STEERING AND HOIST PIPING (DUMP CONTROL LINE)- (3/3)
210450	H3410-51A0	CROSSOVER RELIEF VALVE
210460	H3510-01A0	BRAKE COOLING OIL LINE (PUMP TO REAR BRAKE) (1/2)
210470	H3510-02A0	BRAKE COOLING OIL LINE (PUMP TO REAR BRAKE) (2/2)
210480	H3510-03A0	BRAKE COOLING OIL LINE (T/M TO FRONT BRAKE) (1/2) ..

Page	Reference	Title
210480	H3410-05A0	HYDRAULIC PIPING (HOIST CYLINDER LINE) (1/2)
210490	H3410-06A0	HYDRAULIC PIPING (HOIST CYLINDER LINE) (2/2)
210490	H3510-04A0	BRAKE COOLING OIL LINE (T/M TO FRONT BRAKE) (2/2) ..
210500	H3510-05A0	BRAKE COOLING OIL LINE (BRAKE TO OIL COOLER)
210510	H3510-06A0	BRAKE COOLING OIL LINE (OIL COOLER TO FILTER)
210520	H3510-07A0	BRAKE COOLING OIL LINE (BRAKE CONTROL VALVE TO- FILTER)
210530	H3510-08A0	BRAKE COOLING OIL LINE (SUCTION PIPING)
210540	H3510-09A0	BRAKE COOLING OIL LINE (SENSOR)
210550	H3530-01A0	ACCUMULATOR BOX (R.H) (1/3)
210560	H3530-02A0	ACCUMULATOR BOX (R.H) (2/3)
210570	H3530-03A0	ACCUMULATOR BOX (R.H) (3/3)
210580	H3530-04A0	ACCUMULATOR BOX (L.H)
210590	H3530-05A0	ACCUMULATOR MOUNTING PARTS
210600	H3530-06A0	ACCUMULATOR CHARGER VALVE (INNER PARTS)
210610	H3530-51A0	ACCUMULATOR CHARGER VALVE (INNER PARTS)
210620	H3540-01A0	BRAKE PIPING (FILTER LINE)
210630	H3540-02A0	BRAKE PIPING (FRAME L.H. SIDE)
210640	H3540-03A0	BRAKE PIPING (FRAME R.H. SIDE) (1/3)
210650	H3540-04A0	BRAKE PIPING (FRAME R.H. SIDE) (2/3)
210660	H3540-05A0	BRAKE PIPING (FRAME R.H. SIDE) (3/3)
210670	H3540-06A1	BRAKE PIPING (FRAME R.H. SIDE) (FOR ASR)
210680	H3540-07A0	BRAKE PIPING (PARKING BRAKE VALVE LINE)
210690	H3540-07A1	BRAKE PIPING (PARKING BRAKE VALVE LINE) (FOR ASR) .
210700	H3540-08A0	BRAKE PIPING (PROPORTIONAL VALVE LNE)
210710	H3540-08A1	BRAKE PIPING (PROPORTIONAL VALVE LNE) (FOR ASR) ..
210720	H3540-09A0	BRAKE PIPING (BRAKE SUB TANK) (TANK)
210730	H3540-09A2	BRAKE PIPING (BRAKE SUB TANK)(TANK) (WITH VANDA- LISM PROTECTION)
210740	H3540-10A0	BRAKE PIPING (BRAKE SUB TANK) (TANK MOUNTING- PARTS)
210750	H3540-11A0	BRAKE PIPING (BRAKE SUB TANK) (TANK RELATED- PARTS) (1/2)

Page	Reference	Title
210760	H3540-12A0	BRAKE PIPING (BRAKE SUB TANK) (TANK RELATED- PARTS) (2/2)
210770	H3540-13A0	REAR BRAKE PIPING
210780	H3540-13A1	REAR BRAKE PIPING (FOR ASR)
210790	H3540-14A0	FRONT BRAKE PIPING (R.H)
210800	H3540-15A0	FRONT BRAKE PIPING (L.H)
210810	H3540-51A0	BRAKE PIPING (FILTER INNER PARTS)
210820	H3540-52A0	BRAKE PIPING (PARKING BRAKE VALVE) (INNER PARTS) ..
210830	H3540-52A1	BRAKE PIPING (PARKING BRAKE VALVE) (INNER PARTS)- (FOR ASR)
210840	H3540-53A0	BRAKE PIPING (PROPORTIONAL VALVE) (INNER PARTS) ..
210850	H3540-53A1	BRAKE PIPING (PROPORTIONAL VALVE) (INNER PARTS)- (FOR ASR)
210860	H3921-01A0	EMERGENCY STEERING FLOW SWITCH

[MAIN FRAME AND RELATED PARTS]

240010	J3100-01A0	MAIN FRAMEM(FRAME)
240100	J3100-01A9	MAIN FRAMEM(FRAME) (ASR) (ADDITIONAL FILTER)
240120	J3100-02A0	MAIN FRAME (BRACKET)
240130	J3100-02A8	MAIN FRAME (BRACKET) (ADDITIONAL FILTER)
240140	J3100-03A0	MAIN FRAME (AXLE SUPPORT)
240150	J3210-01A0	REAR SUPPORT
240160	J3210-01A1	REAR SUPPORT (MUFFLER)
240170	J3220-01A0	FRONT SUPPORT (SUPPORT) (L.H)
240180	J3220-01A1	FRONT SUPPORT (SUPPORT) (L.H) (FOG LAMP)
240190	J3220-02A0	FRONT SUPPORT (L.H.) (BRACKET)
240200	J3220-03A0	FRONT SUPPORT (L.H.) (SUPPORT RELATED PARTS)
240210	J3220-04A0	FRONT SUPPORT (L.H.) (STEP)
240220	J3220-05A0	FRONT SUPPORT (L.H.) (STEERING VALVE)
240230	J3220-06A0	FRONT SUPPORT (L.H.) (STEERING PIPING)
240250	J3220-07A1	FRONT SUPPORT (R.H) (SUPPORT) (FOG LAMP)
240250	J3220-07A1	FRONT SUPPORT (R.H) (SUPPORT) (FOG LAMP)

Page	Reference	Title
240260	J3220-08A0	FRONT SUPPORT (R.H) (BOLT LINE)
240270	J3220-09A0	FRONT SUPPORT (R.H) (BRACKET)
240280	J3220-09A2	FRONT SUPPORT (R.H) (BRACKET) (VHMS LESS)
240290	J3220-10A0	FRONT SUPPORT (R.H) (STEP)
240300	J3220-11A0	FRONT SUPPORT (CAB MOUNTING PARTS)
240310	J3310-01A0	ENGINE FUEL FILTER AND RELATED PARTS (L.H) (1/2)
240320	J3310-01A1	ENGINE FUEL FILTER AND RELATED PARTS (L.H.) (ADDI- TIONAL FILTER)
240330	J3310-02A0	ENGINE FUEL FILTER AND RELATED PARTS (L.H.) (2/2)
240340	J3310-03A0	ENGINE FUEL FILTER AND RELATED PARTS (R.H) (1/2)
240350	J3310-03A1	ENGINE FUEL FILTER AND RELATED PARTS (R.H.) (ADDI- TIONAL FILTER)
240360	J3310-04A0	ENGINE FUEL FILTER AND RELATED PARTS (L.H) (ADDI- TIONAL FILTER)
240370	J3330-01A0	POSITIONER
240380	J3410-01A0	AIR INTAKE
240390	J3510-01A0	EXHAUST PIPING
240400	J3510-01A1	EXHAUST PIPING (FOR EXHAUST BOX)
240410	J3510-01A2	EXHAUST PIPING (FOR MUFFLER)
240420	J3510-02A1	EXHAUST BOX
240500	J3610-01A0	ENGINE CONTROL (ENGINE HARNESS)
240510	J3610-02A0	ENGINE CONTROL (HEATER RELAY HARNESS)
240520	J3610-02A1	ENGINE CONTROL (HEATER RELAY HARNESS) (ADDITI- ONAL FILTER)
240530	J3610-03A0	ENGINE EARTH
240540	J3610-04A1	ENGINE EARTH (ADDITIONAL FILTER)
240550	J3620-01A0	TRANSMISSION CONTROL
240560	J3630-01A0	STEERING LINK (LEVER AND ROD)
240570	J3630-02A0	STEERING LINK (RELATED PARTS)
240580	J3630-03A0	STEERING LINK (LUBRICATION PIPING)
240590	J3630-03A1	STEERING LINK (LUBRICATION PIPING) (ASR)
240600	J3641-01A0	EMERGENCY STEERING CONTROL (MOTOR)
240610	J3641-02A0	EMERGENCY STEERING CONTROL (RELATED PARTS)

Page	Reference	Title
240620	J3710-01A0	LUBRICATION PIPING
[OPERATOR'S COMPARTMENT AND CONTROL SYSTEM]		
270010	K0200-01A0	OPERATOR'S CAB (CAB)
270020	K0200-02A0	OPERATOR'S CAB (L.H. DOOR) (1/3)
270030	K0200-03A0	OPERATOR'S CAB (L.H. DOOR) (2/3)
270040	K0200-04A0	OPERATOR'S CAB (L.H. DOOR) (3/3)
270050	K0200-05A1	OPERATOR'S CAB (R.H. DOOR) (1/3) (SASH WINDOW)
270060	K0200-06A0	OPERATOR'S CAB (R.H. DOOR) (2/3)
270070	K0200-07A0	OPERATOR'S CAB (R.H. DOOR) (3/3)
270080	K0200-08A0	OPERATOR'S CAB (DOOR RELATED PARTS)
270090	K0200-09A0	OPERATOR'S CAB (GLASS)
270100	K0200-10A0	OPERATOR'S CAB (ANTENA CABLE)
270110	K0200-10A1	OPERATOR'S CAB (WITHOUT RADIO ANTENA)
270120	K0200-11A0	OPERATOR'S CAB (WIPER)
270130	K0200-12A0	OPERATOR'S CAB (SHEET CAB INSIDE)
270140	K0200-13A0	OPERATOR'S CAB (CAB ACCESSORY)
270150	K0200-13A1	OPERATOR'S CAB (CAB ACCESSORY) (WITHOUT SPEAKER)
270160	K0200-13A2	OPERATOR'S CAB (CAB ACCESSORY) (SUN VISOR SINLE - TYPE)
270170	K0200-14A0	OPERATOR'S CAB (ROOF PAD AND COVER)
270180	K0200-15A0	OPERATOR'S CAB (MARK AND PLATE)
270190	K0200-16A0	OPERATOR'S CAB (WINDOW WASHER TANK)
270200	K0200-17A0	OPERATOR'S CAB (AIR CONDITIONER FILTER)
270210	K0200-21A0	FLOOR (FLOOR RELATED PARTS)
270230	K0200-22A0A	FLOOR (ACCELERATOR PEDAL)
270240	K0200-23A0	FLOOR (BRAKE CONTROLE) (1/3)
270250	K0200-24A0	FLOOR (BRAKE CONTROLE) (2/3)
270260	K0200-25A0	FLOOR (BRAKE CONTROLE) (3/3)
270270	K0200-26A0	FLOOR (AIR CONDITIONER PIPING)
270280	K0200-31A0	FLOOR (DASHBOARD) (1/2)
270290	K0200-32A0	FLOOR (DASHBOARD) (2/2)
270300	K0200-32A1	FLOOR (DASHBOARD) (2/2) (FOR REAR VIEW TV MONI TOR)

Page	Reference	Title
270310	K0200-33A0	FLOOR (AIR DUCT)
270320	K0200-34A1	FLOOR (RADIO LESS)
270340	K0200-34A3	FLOOR (RADIO AND CASSETTE AM/FM)
270350	K0200-35A0	FLOOR (MONITOR DECAL)
270360	K0200-35A2	FLOOR (MONITOR DECAL) (LED DASHBOARD) (SIDE- LAMP SWITCH LESS)
270370	K0200-35A3	FLOOR (MONITORING DECAL) (WITH ARS SWITCH)
270380	K0200-35A4	FLOOR (MONITOR DECAL) (LED DASHBORD) (SIDE LAMP- SWITCH LESS)
270390	K0200-35A5	FLOOR (MONITOR DECAL) (LED DASHBORD)
270410	K0200-37A0	FLOOR (MONITOR PANEL) (KM/H)
270430	K0200-38A0	FLOOR (STEERING COLUMN)
270440	K0200-39A0	FLOOR (COLUMN SWITCH AND STEERING WHEEL)- (WITH SENSOR)
270450	K0200-39A1	FLOOR (COLUMN SWITCH AND STEERING WHEEL)
270460	K0200-40A0	FLOOR (MONITOR DECAL)
270470	K0200-41A0	FLOOR (OPERATOR'S SEAT)
270490	K0200-42A0	FLOOR (OPERATOR'S SEAT) (INNER PARTS)
270510	K0200-43A0	FLOOR (DUMP CONTROL)
270520	K0200-51A1	FLOOR (CONSOLE BOX) (R.H. POWER WINDOW SWITCH- LESS)
270530	K0200-52A0	FLOOR (CONSOLE BOX) (12V DC LESS)
270540	K0200-52A1	FLOOR (CONSOLE BOX) (12V DC)
270550	K0200-61A0	FLOOR (REAR COVER)
270560	K0200-62A0	FLOOR (AUXILIARY SEAT)
270570	K0200-62A1	FLOOR (AUXILIARY SEAT) (SEAT BELT 75MM)
270580	K0200-63A0	FLOOR (FUSE BOX AND RELAY)
270590	K0200-64A0	FLOOR (SIDE LAMP RELAY)
270600	K0200-65A0	FLOOR (ROLL OVER ANGLE SENSOR)
270610	K0200-65A1	FLOOR (ROLL OVER ANGLE SENSOR LES PARTS)
270620	K0200-66A0	FLOOR (FLOOR WIRING)
270630	K0200-67A0	FLOOR (EMERGENCY STARTING TIMER)
270640	K0200-68A0	FLOOR (REAR COVER)

Page	Reference	Title
270650	K0200-69A0	FLOOR (PAYLOAD METER ANGLE SENSOR)
270660	K0200-69A1	FLOOR (PAYLOAD METER ANGLE SENSOR LESS PARTS) .
270670	K0200-70A0	FLOOR (VHMS)
270680	K0200-70A1	FLOOR (VHMS LESS PARTS)
270690	K0200-71A1	FLOOR (PAYLOAD METER LESS PARTS)
270700	K0200-72A0	FLOOR (CONNECTOR PLUG)
270710	K0200-80A0	FLOOR (CAB UNDER PARTS)
270720	K0310-01A0	FLOOR MAT
270730	K3110-01A0	CAB GUARD (FRONT STEP)
270740	K3110-02A0	CAB GUARD (SIDE STEP)
270750	K3110-03A0	CAB GUARD (TOE DUARD)
270760	K3110-04A0	CAB GUARD (SIDE MIRROR (L.H.)
270770	K3110-05A0	CAB GUARD (BOLT LINE)
270780	K3110-06A0	CAB GUARD (RADIO ANTENA)
270790	K3110-07A0	CAB GUARD (CAP)
270800	K3110-08A0	CAB GUARD (MAD GUARD)
270810	K3110-09A0	CAB GUARD (CAB UNDER COVER)

[PLATFORM AND RELATED PARTS]

300010	L3100-01A0	PLATFORM SUB ASS'Y (L.H.)
300020	L3100-02A0	PLATFORM SUB ASS'Y (R.H.)
300050	L3100-03A0	PLATFORM SUB ASS'Y (R.H.) (MUD GUARD)
300060	L3100-04A0	PLATFORM SUB ASS'Y (R.H.) (HANDRAIL)
300070	L3100-05A0	PLATFORM SUB ASS'Y (R.H.) (TOE GUARD)
300090	L3100-06A0	PLATFORM SUB ASS'Y (PLATFORM RELATED PARTS)
300110	L3200-01A0	COOLANT RESERVE TANK
300120	L3200-01A1	COOLANT RESERVE TANK (VANDALISM PROTECTION)
300130	L3310-01A0	UNDER MIRROR
300140	L3320-01A0	SIDE MIRROR
300150	L3320-01A1	SIDE MIRROR (WITH ADDITIONAL SIDE MIRROR)

[GUARD]

330010	M3110-01A0	RADIATOR GUARD
--------	------------	----------------------

Page	Reference	Title
330020	M3141-01A0	HOOD
330030	M3142-01A0	ENGINE SIDE COVER (R.H.)
330040	M3142-02A0	ENGINE SIDE COVER (L.H)
330050	M3150-01A0	FIRE PROTECTION (ENGINE REAR COVER)
330060	M3150-02A0	FIRE PROTECTION (EXHAUST COVER)
330070	M3150-03A0	FIRE PROTECTION (STEERING PIPING PRPTECTION) (WI- THOUT SIDE COVER)
330090	M3210-01A0	FENDER (L.H.)
330100	M3210-02A0	FENDER (R.H.)
330120	M3810-01A0	ENGINE UNDER GUARD
330130	M3820-01A0	TRANSMISSION UNDER GUARD
[RIM AND TIRE]		
360010	S0110-01A0	RIM (FRONT WHEEL)
360030	S0110-02A0	RIM (REAR WHEEL)
360050	S0120-01A0	TIRE (27.00,R49,E4, BELSHINA)
360060	S0120-01A1	TIRE (27.00R49,E4,GP)
360100	S3300-01A0	REAR SUSPENSION
360110	S3310-01A0	REAR SUSPENSION PRESSURE SENSOR
[BODY]		
390010	T3110-01A0	BODY
390020	T3110-01A1	BODY (WITH PLATFORM GUARD)
390030	T3110-01A2	BODY (WITH BODY LINIER)
390040	T3110-01A3	BODY (WITH 300MM SPILL GUARD)
390050	T3120-01A0	BODY ACCESSORY
390070	T3130-01A0	HOIST CYLINDER
390080	T3140-01A0	EXHAUST BOX
[MARKS AND PLATES]		
420010	U0100-01A0	NAME PLATE UNIT (1/2)
420020	U0100-02A1	NAME PLATE UNIT (2/2)(ENGLISH)


Page	Reference	Title
420030	U0100-02A2	NAME PLATE UNIT (2/2)(INDONESIAN)
[TOOL]		
450010	V0100-01A0	SPARE PARTS
450030	V0100-01A2	SPARE PARTS (FUEL FILTER)
450050	V0300-01A0	GENERAL TOOL UNIT (HOSE)
450060	V0300-01A1	GENERAL TOOL UNIT
450070	V0300-02A0	TOOL BOX UNIT
[MISCELLANEOUS]		
480010	W3111-01A0	AIR CONDITIONER RELATED PARTS (1/3)
480020	W3111-02A0	AIR CONDITIONER RELATED PARTS (2/3)
480030	W3111-03A0	AIR CONDITIONER RELATED PARTS (3/3)
480040	W3116-01A1	FIRE EXTINGUISHER (ENGLIS)
480050	W3116-01A2	FIRE EXTINGUISHER (INDONESIAN)
480060	W3117-01A0	FRONT PROPELLER SHAFT GUARD
480070	W3118-01A0	REAR PROPELLER SHAFT GUARD
480080	W3124-01A0	ABS/ASR CHASSIS (STEERING SENSOR)
480090	W3124-02A0	ABS/ASR CHASSIS (VALVE)
480100	W3124-03A0	ABS/ASR CHASSIS (WIRING HARNESS)
480110	W3124-04A0	ABS/ASR CHASSIS (AXLE SENSOR)
480120	W3124-51A0	ABS/ASR CHASSIS (ASR VALVE) (INNER PARTS) (1/2)
480130	W3124-52A0	ABS/ASR CHASSIS (ASR VALVE) (INNER PARTS) (2/2)
480150	W3157-01A0	VEHICLE HEALTH MONITORING SYSTEM
480160	W3157-01A2	VEHICLE HEALTH MONITORING SYSTEM LESS
[SERVICE KIT AND COMPONENT PARTS]		
510010	Y0100-01A0	SERVICE KIT
510020	Y1600-01A1	HYDRAULIC PUMP (STEERING AND HOIST) (1/2)
510030	Y1600-02A1	HYDRAULIC PUMP (STEERING AND HOIST) (2/2)
510040	Y1600-11A1	HYDRAULIC PUMP (1/3)
510050	Y1600-12A1	HYDRAULIC PUMP (2/3)
510060	Y1600-13A1	HYDRAULIC PUMP (3/3)

Page	Reference	Title
510070	Y1600-21A1	HYDRAULIC PUMP (1/3)
510080	Y1600-22A1	HYDRAULIC PUMP (2/3)
510090	Y1600-23A1	HYDRAULIC PUMP (3/3)
510100	Y1620-01A0	HOIST CYLINDER (INNER PARTS)
510110	Y1620-11A0	STEERING CYLINDER (L.H) (INNER PARTS)
510120	Y1620-12A0	STEERING CYLINDER (R.H) (INNER PARTS)
510130	Y1629-01A0	ACCUMULATOR (BRAKE CONTROL) (INNER PARTS)
510140	Y1660-01A0	HOIST VALVE (1/3)
510150	Y1660-02A0	HOIST VALVE (2/3)
510160	Y1660-03A0	HOIST VALVE (3/3)
510170	Y1660-11A0	DEMAND VALVE (1/2)
510180	Y1660-12A0	DEMAND VALVE (2/2)
510190	Y1676-01A0	CHECK VALVE
510200	Y1679-01A0	ELECTRIC LEVER

Page	Reference	Title
------	-----------	-------

ENGINE

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

CYLINDER HEAD

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6219-11-1100	CYLINDER HEAD ASS'Y	12	00500319-
	☆	*HEAD, CYLINDER	1	00500319-
2	6216-11-1330	*INSERT,INTAKE VALVE (STD)	2	00500319-
	6216-19-1330	*INSERT, 0.25MM,INTAKE VALVE (OS)	2	00500319-
	6216-18-1330	*INSERT, 0.50MM,INTAKE VALVE (OS)	2	00500319-
	6216-17-1330	*INSERT, 0.75MM,INTAKE VALVE (OS)	2	00500319-
	6216-16-1330	*INSERT, 1.00MM,INTAKE VALVE (OS)	2	00500319-
3	6217-11-1321	*INSERT,EXHAUST VALVE (STD)	2	00500319-
	6217-19-1321	*INSERT, 0.25MM,EXHAUST VALVE (OS)	2	00500319-
	6217-18-1321	*INSERT, 0.50MM,EXHAUST VALVE (OS)	2	00500319-
	6217-17-1321	*INSERT, 0.75MM,EXHAUST VALVE (OS)	2	00500319-
	6217-16-1321	*INSERT, 1.00MM,EXHAUST VALVE (OS)	2	00500319-
4	6217-16-1440	*GUIDE,VALVE	4	00500319-
5	6210-11-1150	*PIPE	1	00500319-
6	07000-73025	*O-RING (K1)	1	00500319-
7	6162-13-1150	*PLUG,EXPANSION	13	00500319-
8	07043-50108	*PLUG	1	00500319-
9	708-21-12541	*PLUG	2	00500319-
10	6210-11-1140	GUIDE,CROSSHEAD	24	00500319-
11	6210-41-4430	SPRING,OUTER	48	00500319-
12	6210-41-4440	SPRING,INNER	48	00500319-
13	6210-41-4510	SEAT,SPRING ^a UPPER	48	00500319-
14	6215-41-4220	VALVE,EXHAUST	24	00500319-
15	6217-41-4110	VALVE,INTAKE	24	00500319-
16	6217-41-4531	SEAT,SPRING ^a LOWER	48	00500319-
17	6217-41-4540	SEAL,VALVE STEM (K1)	48	00500319-
18	6136-41-4520	COTTER,VALVE	96	00500319-
19	6210-17-1814	GASKET,HEAD (K1)	12	00500319-
20	6210-11-1820	*GROMMET,OIL	1	00500319-
21	6210-11-1831	*GROMMET,OIL	1	00500319-
22	6210-11-1840	*GROMMET,OIL	1	00500319-
23	6210-11-1962	*GROMMET,WATER	1	00500319-
24	6210-11-1952	*GROMMET,WATER	4	00500319-
25	6210-11-1940	*GROMMET,WATER	4	00500319-
		OVERSIZE 0.40MM		
19	6210-19-1814	GASKET,HEAD	12	00500319-
20	6210-19-1820	*GROMMET,OIL	1	00500319-
21	6210-19-1831	*GROMMET,OIL	1	00500319-
22	6210-19-1840	*GROMMET,OIL	1	00500319-
23	6210-19-1962	*GROMMET,WATER	1	00500319-
24	6210-19-1952	*GROMMET,WATER	4	00500319-
25	6210-19-1940	*GROMMET,WATER	4	00500319-
26	6217-11-1610	BOLT	36	00500319-
27	6217-11-1620	BOLT	36	00500319-


SAA12V140E-3B S/N 00500319-



SAA12V140E-3B S/N 00500319-

CYLINDER HEAD


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
28	01643-51645	WASHER	72	00500319-
29	01438-01020	BOLT	12	00500319-
30	6210-41-5620	CROSSHEAD	24	00500319-
31	6210-41-5641	SCREW	24	00500319-
32	6162-43-5630	NUT	24	00500319-



HEAD COVER

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6217-11-8110	COVER,HEAD	12	00500319-
2	6217-11-8830	GASKET (K1)	12	00500319-
3	01435-00855	BOLT	32	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

AIR INTAKE MANIFOLD

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6219-11-4111	MANIFOLD,AIR INTAKE	2	00500319-
2	6210-11-4811	GASKET (K1)	12	00500319-
3	01011-81085	BOLT	24	00500319-
4	01011-81000	BOLT	16	00500319-
5	01011-81020	BOLT	8	00500319-
6	01643-31032	WASHER	48	00500319-
7	6216-11-8210	PLATE	1	00500319-
8	6216-11-8220	GASKET (K1)	1	00500319-
9	01010-81025	BOLT	4	00500319-
10	6215-81-9510	PLUG	2	00500319-
11	6215-81-9710	O-RING (K1)	2	00500319-
12	6215-81-9520	PLUG	11	00500319-
13	6215-81-9720	O-RING (K1)	11	00500319-
14	6219-11-6310	CONNECTOR,AIR	2	00500319-
15	600-815-4280	HEATER,RIBBON	2	00500319-
16	6211-11-4821	GASKET (K1)	4	00500319-
17	6162-13-6530	BOLT	4	00500319-
18	01011-81045	BOLT	3	00500319-
19	01643-31032	WASHER	9	00500319-
20	07042-70108	PLUG	4	00500319-
21	417-963-1620	BRACKET	1	00500319-
22	01011-81055	BOLT	1	00500319-

SAA12V140E-3B S/N 00500319-



SAA12V140E-3B S/N 00500319-

AIR INTAKE CONNECTION AND SENSOR


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6215-11-9350	TUBE,L.H.	1	00500319-
2	6215-11-9360	TUBE,R.H.	1	00500319-
3	07042-70108	PLUG	2	00500319-
4	6211-11-4410	CONNECTOR	2	00500319-
5	02895-77075	O-RING (K1)	8	00500319-
6	6219-11-8140	BRACKET	1	00500319-
7	6631-11-5630	SPACER	4	00500319-
8	01010-81030	BOLT	4	00500319-
9	01010-81045	BOLT	3	00500319-
10	01643-31032	WASHER	7	00500319-
11	6219-11-8170	BRACKET	1	00500319-
12	6219-11-8110	PLATE	1	00500319-
13	01010-81035	BOLT	3	00500319-
14	01643-31032	WASHER	6	00500319-
15	01010-81030	BOLT	3	00500319-
16	6219-11-8190	SPACER	1	00500319-
17	01010-81020	BOLT	2	00500319-
18	01643-31032	WASHER	2	00500319-
19	07283-31087	CLIP	4	00500319-
20	01643-31232	WASHER	8	00500319-
21	01597-01211	NUT	8	00500319-
22	01435-01025	BOLT	6	00500319-
23	01435-01030	BOLT	8	00500319-
24	6219-11-8130	BRACKET	4	00500319-
25	6150-81-6920	SPACER	8	00500319-
26	6219-11-8120	BRACKET	2	00500319-
27	01010-81030	BOLT	4	00500319-
28	01643-31032	WASHER	12	00500319-
29	01010-81065	BOLT	8	00500319-
30	6219-81-7590	BRACKET	1	00500319-
31	01010-81045	BOLT	2	00500319-
32	01643-30823	WASHER	2	00500319-
33	6261-81-2700	SENSOR ASS'Y,BOOST PRESSURE	1	00500319-
	6261-81-2710	*SENSOR	1	00500319-
	6261-81-2720	*O-RING	1	00500319-
34	01435-00616	BOLT	2	00500319-
35	6219-81-8940	BLOCK	1	00500319-
36	6216-11-8220	GASKET (K1)	1	00500319-
37	01010-81025	BOLT	3	00500319-
38	6560-61-7300	SENSOR ASS'Y,TEMPERATURE AIR INTAKE	1	00500319-
	6560-61-7310	.SENSOR	1	00500319-
	6735-21-1930	.O-RING	1	00500319-

SAA12V140E-3B S/N 00500319-


SAA12V140E-3B S/N 00500319-

PRE-HEATER SWITCH

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	600-815-2690	SWITCH,HEATER	2	00500319-
2	6212-81-4132	COVER,L.H.	1	00500319-
3	6219-81-6670	COVER,R.H.	1	00500319-
4	6219-81-8610	PLATE	2	00500319-
5	01435-01025	BOLT	8	00500319-
6	01435-00812	BOLT	4	00500319-
7	01643-30823	WASHER	4	00500319-
8	6219-81-8180	WIRE	2	00500319-
9	01435-01016	BOLT	2	00500319-
10	6219-81-8140	WIRE, 260MM	2	00500319-



SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

EXHAUST MANIFOLD (WITH EXHAUST TEMPERATURE SENSOR)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6215-11-5171	MANIFOLD,CENTER (L.H.).....	1	00500319-
2	6215-11-5181	MANIFOLD,CENTER (R.H.)	1	00500319-
3	6215-11-5110	MANIFOLD	2	00500319-
4	6215-11-5130	MANIFOLD	2	00500319-
5	6218-11-5880	GASKET (K1)	12	00500319-
6	01010-E1095	BOLT	48	00500319-
7	6215-11-5720	SPACER	48	00500319-
8	6215-11-5920	PLUG	2	00500319-
9	6151-11-8550	STUD	4	00500319-
10	600-871-4431	SENSOR,EXHAUST TEMPERATURE	4	00500319-
11	6219-81-8250	BRACKET	1	00500319-
12	01435-00860	BOLT	1	00500319-
13	6166-11-5391	SPACER	1	00500319-
14	01584-01008	NUT	1	00500319-
15	01643-31032	WASHER	1	00500319-
16	01010-81060	BOLT	1	00500319-
17	6240-81-4431	CLIP	8	00500319-
18	01010-81025	BOLT	1	00500319-
19	6215-11-6330	CLAMP	1	00500319-
20	419-15-17540	SPACER	1	00500319-
21	01010-E1030	BOLT	1	00500319-
22	01643-31032	WASHER	2	00500319-
23	6219-11-5170	BRACKET	1	00500319-
24	01010-E1025	BOLT	2	00500319-
25	01643-31032	WASHER	2	00500319-
26	560-43-12470	SPACER	1	00500319-
27	6142-22-4640	SPACER	1	00500319-
28	6240-81-4431	CLIP	4	00500319-
29	01010-81035	BOLT	1	00500319-
30	01010-81060	BOLT	1	00500319-
31	01643-31032	WASHER	2	00500319-
32	6219-81-6330	BRACKET	1	00500319-
33	01010-81025	BOLT	2	00500319-
34	01643-31032	WASHER	2	00500319-
35	6219-81-6340	BRACKET	1	00500319-
36	01435-00820	BOLT	4	00500319-
37	01010-81040	BOLT	2	00500319-
38	01643-31032	WASHER	2	00500319-
39	426-01-11310	BRACKET	1	00500319-
40	01010-80825	BOLT	1	00500319-
41	01643-30823	WASHER	1	00500319-
42	6151-51-8540	CLIP	1	00500319-
43	6219-81-8350	TUBE	1	00500319-
44	01010-81020	BOLT	1	00500319-
45	01643-31032	WASHER	1	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

TURBOCHARGER AND LUBRICATING OIL PIPING

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	(6505-57-5030)	TURBOCHARGER ASS'Y R.H (SEE FIG.A1530-C7D6)	1	00500319-
2	(6505-67-5040)	TURBOCHARGER ASS'Y L.H (SEE FIG.A1530-C7D6)	1	00500319-
3	6218-11-5830	GASKET (K1)	2	00500319-
4	6138-13-4510	BOLT	4	00500319-
5	6114-11-5590	NUT	8	00500319-
6	6164-62-8230	PLATE	4	00500319-
7	6164-62-8241	GASKET (K1)	4	00500319-
8	01010-E1020	BOLT	8	00500319-
9	6219-51-8150	TUBE,SUPPLY	2	00500319-
10	6162-73-4670	NIPPLE	2	00500319-
11	07002-21423	O-RING (K1)	2	00500319-
12	07206-31014	BOLT,JOINT	2	00500319-
13	07005-01412	GASKET (K1)	4	00500319-
14	6219-51-8160	BRACKET	2	00500319-
15	6934-52-6810	CLAMP	4	00500319-
16	01435-01040	BOLT	2	00500319-
17	01584-01008	NUT	2	00500319-
18	6164-51-8611	FLANGE,R.H.	1	00500319-
19	6164-51-8621	FLANGE,L.H.	1	00500319-
20	6151-51-8161	GASKET (K1)	2	00500319-
21	01010-81035	BOLT	4	00500319-
22	6151-53-8280	CLIP	2	00500319-
23	6212-65-6390	PLATE	1	00500319-
24	01435-01020	BOLT	1	00500319-
25	01435-01016	BOLT	1	00500319-
26	6128-21-6730	SPACER	1	00500319-
27	01435-01040	BOLT	1	00500319-
28	6219-51-8110	TUBE,RETURN ^a R.H.	1	00500319-
29	6219-51-8120	TUBE,RETURN ^a L.H.	1	00500319-
30	01010-81025	BOLT	4	00500319-
31	07000-72021	O-RING (K1)	2	00500319-
32	01435-01016	BOLT	2	00500319-
33	6151-51-8151	GASKET (K1)	2	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

TURBOCHARGER WATER PIPING

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6215-61-8610	JOINT	2	00500319-
2	07003-02026	GASKET (K1)	2	00500319-
3	07211-51016	NIPPLE	2	00500319-
4	07003-01621	GASKET (K1)	2	00500319-
5	6219-61-8320	TUBE,R.H.	1	00500319-
6	6219-61-8330	TUBE,L.H.	1	00500319-
7	07206-31014	BOLT,JOINT	2	00500319-
8	07003-01419	GASKET (K1)	4	00500319-
9	6219-61-8520	JOINT	2	00500319-
10	01252-61035	BOLT	4	00500319-
11	6164-62-8241	GASKET (K1)	2	00500319-
12	6219-61-8520	JOINT	2	00500319-
13	01252-61035	BOLT	4	00500319-
14	6164-62-8241	GASKET (K1)	2	00500319-
15	07212-50814	NIPPLE	2	00500319-
16	07003-01419	GASKET (K1)	2	00500319-
17	6219-61-8340	HOSE	1	00500319-
18	6215-61-8470	TUBE	1	00500319-
19	07206-31014	BOLT,JOINT	2	00500319-
20	07003-01419	GASKET (K1)	4	00500319-
21	6151-81-5960	BRACKET	3	00500319-
22	01435-01020	BOLT	2	00500319-
23	01010-81050	BOLT	1	00500319-
24	01643-31032	WASHER	1	00500319-
25	6151-51-8540	CLIP	3	00500319-
26	01435-01016	BOLT	2	00500319-
27	01584-01008	NUT	3	00500319-
28	6219-61-8360	BRACKET	1	00500319-
29	01011-81045	BOLT	2	00500319-
30	01643-31032	WASHER	2	00500319-
31	6215-61-8450	JOINT,WATER	1	00500319-
32	01435-00850	BOLT	2	00500319-
33	6219-61-8370	TUBE,L.H.	1	00500319-
34	6219-61-8380	TUBE,R.H.	1	00500319-
35	6141-71-1710	JOINT	2	00500319-
36	6127-71-5710	BOLT,JOINT	2	00500319-
37	07003-01419	GASKET (K1)	6	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

TURBOCHARGER (KTR110L-F85PW) (INNER PARTS)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	6505-67-5030	TURBOCHARGER ASS'Y,(KTR110L-F85PW)	1	00500319-
	6505-67-5040	TURBOCHARGER ASS'Y,(KTR110L-F85PW)	1	00500319-
	6505-67-5910	*CORE ASS'Y	1	00500319-
1	(★6505-67-3170)	**ROTOR, TURBIN	1	00500319-
2	(★6505-71-0210)	**PLATE, THURST	1	00500319-
3	(★6505-71-0230)	**SPACER, COLLAR	1	00500319-
4	(★6505-51-0252)	**FLINGER	1	00500319-
5	(★6505-67-1060)	**IMPELLER, BLOWER	1	00500319-
6	(★6505-11-0410)	**NUT, LOCK	1	00500319-
7	(★6505-71-0110)	**BEARING, JOURNAL	1	00500319-
8	(★6505-51-0151)	**BEARING, THRUST	1	00500319-
9	(★6505-71-0710)	**SHIELD, HEAT	1	00500319-
10	(★6505-51-0310)	**RING, TURBINE	2	00500319-
11	(★6505-51-0351)	**RING, SEAL BLOWER	2	00500319-
12	(★6505-71-0850)	**INSERT	1	00500319-
13	(★07000-E2050)	**O-RING	1	00500319-
14	(★6505-71-0010)	**HOUSING, CENTER	1	00500319-
15	(★04022-04008)	**PIN, DOWEL	1	00500319-
16	(★6505-71-0480)	**RING, SNAP	1	00500319-
17	6505-61-4370	*HOUSING,TURBINE	1	00500319-
18	6505-11-0520	*PLATE	2	00500319-
19	01020-01016	*BOLT	8	00500319-
20	6505-61-2160	*HOUSING,BLOWER	1	00500319-
21	6505-11-0450	*V-BAND	1	00500319-
22	6505-99-9011	*PLATE, NAME	1	00500319-
23	04418-02550	*SCREW	2	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

HEAT SHIELD

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6219-11-5780	COVER	2	00500319-
2	01010-E1040	BOLT	8	00500319-
3	01643-31032	WASHER	8	00500319-
4	6261-11-8280	COVER,TURBINE, R.H.	1	00500319-
5	6219-11-8240	COVER,TURBINE, L.H.	1	00500319-
6	6219-11-5790	PLATE	2	00500319-
7	6137-71-3750	SPACER	4	00500319-
8	01435-00895	BOLT	4	00500319-
9	6219-21-6410	PLATE	8	00500319-
10	6219-21-6420	PLATE	2	00500319-
11	6219-21-6450	BOLT	1	00500319-
12	01435-01025	BOLT	19	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

EXHAUST BRAKE AND MOUNTING

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	(6218-11-8102)	BRAKE ASS'Y (SEE FIG A1650-B7A3)	2	00500319-
2	6219-11-5130	BRACKET	1	00500319-
3	6219-11-5160	BRACKET	1	00500319-
4	6219-11-5140	BRACKET	1	00500319-
5	6219-11-5150	BRACKET	1	00500319-
6	01010-E1050	BOLT	4	00500319-
7	01020-11025	BOLT	12	00500319-
8	01010-E1035	BOLT	8	00500319-
9	6631-11-5630	SPACER	8	00500319-
10	01643-31032	WASHER	22	00500319-
11	6219-11-5110	CONNECTOR	1	00500319-
12	6219-11-5120	CONNECTOR	1	00500319-
13	6151-11-5751	GASKET (K1)	4	00500319-
14	6215-11-5920	PLUG	2	00500319-
15	6218-11-5140	CONNECTOR	2	00500319-
16	01011-E1245	BOLT	8	00500319-
17	01643-31232	WASHER	8	00500319-
18	6212-11-5940	GASKET (K1)	2	00500319-
19	01010-E1025	BOLT	2	00500319-
20	6219-11-9120	BRACKET	1	00500319-
21	6219-11-9130	BRACKET	1	00500319-
22	6219-11-9140	BRACKET	1	00500319-
23	6162-13-6530	BOLT	4	00500319-
24	01435-00825	BOLT	4	00500319-
25	01643-31032	WASHER	4	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

EXHAUST BRAKE (WITHOUT EXHAUST BRAKE SPEC)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6219-11-5130	BRACKET	1	00500319-
2	6219-11-5160	BRACKET	1	00500319-
3	6219-11-5140	BRACKET	1	00500319-
4	6219-11-5150	BRACKET	1	00500319-
5	01010-E1045	BOLT	4	00500319-
6	01010-E1050	BOLT	4	00500319-
7	01020-11025	BOLT	12	00500319-
8	01010-E1035	BOLT	8	00500319-
9	6631-11-5630	SPACER	8	00500319-
10	01643-31032	WASHER	22	00500319-
11	6219-11-5110	CONNECTOR	1	00500319-
12	6219-11-5120	CONNECTOR	1	00500319-
13	6151-11-5751	GASKET (K1)	2	00500319-
14	6215-11-5920	PLUG	2	00500319-
15	01010-E1265	BOLT	8	00500319-
16	6144-85-6550	SPACER	8	00500319-
17	6212-11-5940	GASKET (K1)	2	00500319-
18	6219-11-5240	TUBE	2	00500319-
19	01010-E1025	BOLT	2	00500319-
20	6165-71-6180	BOLT	4	00500319-
21	01643-31032	WASHER	4	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

EXHAUST BRAKE (INNER PARTS)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	6218-11-8102	EXHAUST BRAKE ASS'Y	2	00500319-
	MY281-05031	*BRAKE VALVE ASS'Y	1	00500319-
1	☆	**BODY	1	00500319-
2	☆	**BUSHING	1	00500319-
3	☆	**SHAFT	1	00500319-
4	MY281-24151	**VALVE	1	00500319-
5	☆	**BUSHING	1	00500319-
6	MY1100-0725	**BOLT	2	00500319-
7	☆	**SEAL,RING	6	00500319-
8	☆	**SEAL,RING	6	00500319-
9	MY281-20540	**COVER	1	00500319-
10	MY281-24372	**PLATE	1	00500319-
11	MY1100-0760	**BOLT	2	00500319-
12	MY1113-0285	**NUT,FLANGE	2	00500319-
13	MY1105-0047	**BOLT,FLANGE	2	00500319-
14	MY1105-0047	**BOLT,FLANGE	3	00500319-
15	MY1113-0285	**NUT,FLANGE	2	00500319-
16	MY0141-0806	**NUT,FLANGE	2	00500319-
17	MY281-22173	**LEVER	1	00500319-
18	MY281-23007	**LEVER	1	00500319-
	MY284-02005	*CONTROL ASS'Y	1	00500319-
	MY284-10707	**CYLINDER ASS'Y	1	00500319-
19	☆	***CYLINDER	1	00500319-
20	MY1306-0081	***SEAL,DUST	1	00500319-
21	MY1411-0591	***SPRING	1	00500319-
	MY284-10227	***SHAFT ASS'Y	1	00500319-
22	☆	***SHAFT	1	00500319-
23	☆	***PROTECTOR,CYLINDER	1	00500319-
24	☆	***PIN,SPRING	1	00500319-
25	☆	**BUSHING	1	00500319-
26	MY284-20729	**PLATE	1	00500319-
27	MY284-22001	**RING,WEAR	1	00500319-
28	MY1132-0255	**WASHER	1	00500319-
29	MY1113-0285	**NUT,FLANGE	1	00500319-
30	MY1173-0016	**O-RING	1	00500319-
31	MY284-20507	**COVER	1	00500319-
32	MY1105-0194	**BOLT,FLANGE	2	00500319-
33	MY652-21900	**FILTER	1	00500319-
34	MY0410-1210	**RING,RETAINING	1	00500319-
35	MY284-22203	**GUIDE	1	00500319-
36	MY0554-1008	**PLUG,TAPER	1	00500319-
37	☆	**LABEL	1	00500319-
38	MY1105-0166	*BOLT	2	00500319-
39	MY1113-0281	*NUT	2	00500319-
40	MY1291-0200	*CLEVIS	1	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

EXHAUST BRAKE (INNER PARTS)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
41	MY1155-0074	*PIN	2	00500319-
42	MY286-20111	*PIN	2	00500319-
43	MY286-20649	*INSULATOR	1	00500319-
44	☆	*LABEL	1	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

THERMOSTAT AND THERMOSTAT HOUSING

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	01011-81010	BOLT	2	00500319-
2	6215-11-6820	GASKET (K1)	1	00500319-
3	6215-11-6150	PLATE	1	00500319-
4	6215-11-6831	GASKET (K1)	1	00500319-
5	01010-81020	BOLT	3	00500319-
6	01010-81025	BOLT	1	00500319-
7	02720-40204	PLUG	1	00500319-
8	6219-11-6110	HOUSING,THERMOSTAT	1	00500319-
9	6215-11-6120	CASE,THERMOSTAT	1	00500319-
10	01011-81220	BOLT	12	00500319-
11	01643-31232	WASHER	12	00500319-
12	6215-11-6810	GASKET (K1)	1	00500319-
13	07043-70415	PLUG	2	00500319-
14	07040-11409	PLUG	2	00500319-
15	07005-01412	GASKET (K1)	2	00500319-
16	287-35-11470	PLUG	1	00500319-
17	6219-61-8510	NIPPLE	1	00500319-
18	07005-01612	GASKET (K1)	1	00500319-
19	6261-81-6900	SENSOR,WATER TEMPERATURE	1	00500319-
	6261-81-6910	*SENSOR	1	00500319-
	6261-84-9740	*O-RING	1	00500319-
20	600-421-6630	THERMOSTAT	3	00500319-
21	6162-13-6440	SEAL,THERMOSTAT (K1)	3	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

THERMOSTAT AND THERMOSTAT HOUSING (EXTREMELY BAD FUEL AND POOL ARRANGEMENT SPEC) (WATER DUSTY)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	01011-81010	BOLT	2	00500319-
2	6215-11-6820	GASKET (K1)	1	00500319-
3	6215-11-6150	PLATE	1	00500319-
4	6215-11-6831	GASKET (K1)	1	00500319-
5	01010-81025	BOLT	3	00500319-
6	02720-40204	PLUG	1	00500319-
7	6219-11-6110	HOUSING,THERMOSTAT	1	00500319-
8	6215-11-6120	CASE,THERMOSTAT	1	00500319-
9	01011-81220	BOLT	12	00500319-
10	01643-31232	WASHER	12	00500319-
11	6215-11-6810	GASKET (K1)	1	00500319-
12	07043-70415	PLUG	2	00500319-
13	07040-11409	PLUG	1	00500319-
14	07005-01412	GASKET (K1)	1	00500319-
15	287-35-11470	PLUG	1	00500319-
16	6219-61-8510	NIPPLE	1	00500319-
17	07005-01612	GASKET (K1)	1	00500319-
18	6261-81-6900	SENSOR,WATER TEMPERATURE	1	00500319-
	6261-81-6910	.SENSOR	1	00500319-
	6261-84-9740	.O-RING	1	00500319-
19	600-421-6630	THERMOSTAT	3	00500319-
20	6162-13-6440	SEAL,THERMOSTAT (K1)	3	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

CYLINDER BLOCK

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	6219-21-1200	CYLINDER BLOCK ASS'Y	1	00500319-
		*BLOCK	1	00500319-
1	☆	**BLOCK,CYLINDER	1	00500319-
2	☆	**CAP,MAIN METAL NO:1,2,3,4,5,6	5	00500319-
3	☆	**CAP,MAIN METAL NO:4	1	00500319-
4	☆	**CAP,MAIN METAL NO:7	1	00500319-
5	04020-00820	**PIN,DOWEL	2	00500319-
6	6215-21-1710	**BOLT,MAIN CAP	14	00500319-
7	01643-32460	**WASHER	14	00500319-
8	6210-21-1491	**BUSHING,CAMSHAFT	14	00500319-
9	6210-81-9210	**PLUG,EXPANSION	2	00500319-
10	07046-44016	**PLUG	2	00500319-
11	04020-00820	*PIN,DOWEL	24	00500319-
12	04020-01434	*PIN,DOWEL	2	00500319-
13	6127-21-1160	*PIN,DOWEL	2	00500319-
14	6210-81-9210	*PLUG,EXPANSION	10	00500319-
15	6215-81-9510	*PLUG	21	00500319-
16	6215-81-9710	*O-RING	21	00500319-
17	07046-42010	*PLUG	3	00500319-
18	07046-42516	*PLUG	2	00500319-
19	6210-21-1390	*PIN,METAL THRUST	6	00500319-
20	6215-81-9520	*PLUG	5	00500319-
21	6215-81-9720	*O-RING	5	00500319-
22	6215-81-9540	*PLUG	1	00500319-
23	6215-81-9740	*O-RING	1	00500319-
24	6219-21-1950	NOZZLE ASS'Y,PISTON COOLING	12	00500319-
25	01437-01025	BOLT	12	00500319-
26	01643-51032	WASHER	12	00500319-
27	6211-22-2220	LINER,CYLINDER	12	00500319-
28	6210-21-2270	SEAL,CREVICE (K2)	12	00500319-
29	6210-21-2240	O-RING,CENTER (K2)	12	00500319-
30	6210-21-2230	O-RING,LOWER (K2)	12	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

CYLINDER BLOCK ACCESSORY (BLIND COVER SENSOR)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6215-21-1610	COVER	2	00500319-
2	6215-21-1682	GASKET (K2)	3	00500319-
3	6219-61-8310	COVER	1	00500319-
4	01010-81225	BOLT	18	00500319-
5	6215-21-6460	COVER	2	00500319-
6	6215-21-6480	GASKET (K2)	2	00500319-
7	01010-81225	BOLT	8	00500319-
8	6217-21-1940	COVER	1	00500319-
9	6215-61-6630	O-RING (K2)	1	00500319-
10	01010-81020	BOLT	1	00500319-
11	6219-21-1920	COVER	1	00500319-
12	6215-21-1970	GASKET (K2)	1	00500319-
13	01010-81235	BOLT	2	00500319-
14	01643-31232	WASHER	2	00500319-
15	6215-21-5490	BUSHING	1	00500319-
16	6215-21-9210	PLUG	1	00500319-
17	6219-81-1961	SENSOR ASS'Y,OIL PRESSURE	1	00500319-
18	6261-81-6900	SENSOR,OIL TEMPERATURE	1	00500319-
	6261-81-6910	.SENSOR	1	00500319-
	6261-84-9740	.O-RING	1	00500319-
19	6162-73-4690	NIPPLE	2	00500319-
20	6215-81-9720	O-RING (K2)	3	00500319-
21	6215-81-9520	PLUG	1	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

CYLINDER BLOCK ACCESSORY (BLIND COVER SENSOR)
(ADDITIONAL FUEL FILTER SPEC)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6215-21-1610	COVER	2	00500319-
2	6215-21-1682	GASKET (K2)	3	00500319-
3	6219-61-8310	COVER	1	00500319-
4	01010-81225	BOLT	18	00500319-
5	6215-21-6460	COVER	2	00500319-
6	6215-21-6480	GASKET (K2)	2	00500319-
7	01010-81225	BOLT	8	00500319-
8	6218-21-1940	COVER	1	00500319-
9	6215-61-6630	O-RING (K2)	1	00500319-
10	01010-81020	BOLT	1	00500319-
11	6219-21-1920	COVER	1	00500319-
12	6215-21-1970	GASKET (K2)	1	00500319-
13	01010-81235	BOLT	2	00500319-
14	01643-31232	WASHER	2	00500319-
15	6215-21-5490	BUSHING	1	00500319-
16	6215-21-9210	PLUG	1	00500319-
17	6219-81-1961	SENSOR ASS'Y,OIL PRESSURE	1	00500319-
	6219-81-1991	*O-RING	1	00500319-
18	6261-81-6900	SENSOR,OIL TEMPERATURE	1	00500319-
	6261-81-6910	*SENSOR	1	00500319-
	6261-84-9740	*O-RING	1	00500319-
19	6162-73-4690	NIPPLE	2	00500319-
20	6215-81-9720	O-RING (K2)	3	00500319-
21	6215-81-9520	PLUG	1	00500319-


SAA12V140E-3B S/N 00500319-



SAA12V140E-3B S/N 00500319-

CYLINDER BLOCK ACCESSORY (OIL SENSOR SWITCH AND WATER HEATER)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6215-21-1610	COVER	2	00500319-
2	6215-21-1682	GASKET (K2)	3	00500319-
3	6219-61-8310	COVER	1	00500319-
4	01010-81225	BOLT	18	00500319-
5	6215-21-6460	COVER	2	00500319-
6	6215-21-6480	GASKET (K2)	2	00500319-
7	01010-81225	BOLT	8	00500319-
8	6217-21-1940	COVER	1	00500319-
9	6215-61-6630	O-RING (K2)	1	00500319-
10	01010-81020	BOLT	1	00500319-
11	6219-21-1930	COVER	1	00500319-
12	6215-21-1970	GASKET (K2)	1	00500319-
13	01010-81235	BOLT	2	00500319-
14	01643-31232	WASHER	2	00500319-
15	6215-61-7280	BRACKET	1	00500319-
16	6151-51-8490	SPACER	1	00500319-
17	01010-81040	BOLT	1	00500319-
18	01643-31032	WASHER	1	00500319-
19	01010-81016	BOLT	1	00500319-
20	01643-31032	WASHER	1	00500319-
21	6215-21-5490	BUSHING	1	00500319-
22	6215-21-9210	PLUG	1	00500319-
23	6219-81-1961	SENSOR ASS'Y,OIL PRESSURE	1	00500319-
24	6219-81-1991	*O-RING,OIL TEMPERATURE	1	00500319-
	6261-81-6900	SENSOR	1	00500319-
	6261-81-6910	*SENSOR	1	00500319-
	6261-84-9740	*O-RING	1	00500319-
25	6162-73-4690	NIPPLE	2	00500319-
26	6215-81-9720	O-RING (K2)	3	00500319-
27	6215-81-9520	PLUG	1	00500319-
28	600-815-9650	HEATER	1	00500319-
29	6150-21-1190	O-RING	1	00500319-
30	08193-20010	CLIP	1	00500319-



FRONT COVER

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6215-21-3133	COVER,GEAR CASE	1	00500319-
2	07046-11816	PLUG	10	00500319-
3	6215-21-3811	GASKET (K2)	1	00500319-
4	01011-81245	BOLT	1	00500319-
5	01011-81230	BOLT	9	00500319-
6	01010-81290	BOLT	3	00500319-
7	01010-81275	BOLT	7	00500319-
8	04020-01434	PIN,DOWEL	2	00500319-
9	07040-11007	PLUG	2	00500319-
10	07005-01012	GASKET (K2)	2	00500319-
11	07046-42816	PLUG	2	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

GEAR CASE AND FRONT COVER ACCESSORY

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6215-71-3711	COVER	1	00500319-
2	6215-81-6190	GASKET (K2)	1	00500319-
3	01010-81025	BOLT	3	00500319-
4	01643-31032	WASHER	3	00500319-
5	6215-21-3350	POINTER	1	00500319-
6	01435-00610	BOLT	2	00500319-
7	6245-21-3121	SEAL, FRONT (K2)	1	00500319-
8	6219-21-3510	COVER	1	00500319-
9	01010-81220	BOLT	6	00500319-
10	01643-31232	WASHER	6	00500319-
11	6215-21-1850	COVER	1	00500319-
12	6219-21-1810	COVER	1	00500319-
13	01010-81280	BOLT	4	00500319-
14	01010-81220	BOLT	1	00500319-
15	07000-72100	O-RING (K2)	1	00500319-
16	6215-51-5870	BRACKET	1	00500319-
17	01010-81235	BOLT	1	00500319-
18	01010-81230	BOLT	1	00500319-
19	01643-31232	WASHER	2	00500319-
20	6219-21-3110	CASE,GEAR	1	00500319-
21	07046-11816	PLUG	10	00500319-
22	6215-21-3820	GASKET (K2)	1	00500319-
23	01010-81230	BOLT	13	00500319-
24	6215-81-9510	PLUG	4	00500319-
25	6215-81-9710	O-RING (K2)	4	00500319-
26	09920-00150	LIQUID GASKET,LG-7, 150G	AR	00500319-


SAA12V140E-3B S/N 00500319-



SAA12V140E-3B S/N 00500319-
GEAR CASE AND FRONT COVER ACCESSORY (EXTREMELY
BAD FUEL AND POOR FUEL ARRANGEMENT SPEC) (WATER
DUST)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6219-61-8550	BRACKET	1	00500319-
2	6215-81-6190	GASKET (K2)	1	00500319-
3	426-06-11570	BRACKET	1	00500319-
4	01010-81025	BOLT	1	00500319-
5	01010-81030	BOLT	1	00500319-
6	01643-31032	WASHER	2	00500319-
7	6215-21-3350	POINTER	1	00500319-
8	01435-00610	BOLT	2	00500319-
9	6245-21-3121	SEAL, FRONT (K2)	1	00500319-
10	6219-21-3510	COVER	1	00500319-
11	01010-81225	BOLT	6	00500319-
12	01643-31232	WASHER	6	00500319-
13	6215-21-1850	COVER	1	00500319-
14	6219-21-1810	COVER	1	00500319-
15	01010-81085	BOLT	4	00500319-
16	01010-81025	BOLT	1	00500319-
17	07000-72100	O-RING (K2)	1	00500319-
18	6215-51-5870	BRACKET	1	00500319-
19	01010-81230	BOLT	1	00500319-
20	01010-81235	BOLT	1	00500319-
21	01643-31232	WASHER	2	00500319-
22	6219-21-3110	CASE,GEAR	1	00500319-
23	07046-11816	PLUG	10	00500319-
24	6215-21-3820	GASKET (K2)	1	00500319-
25	01010-81230	BOLT	13	00500319-
26	6215-81-9510	PLUG	4	00500319-
27	6215-81-9710	O-RING (K2)	4	00500319-
28	09920-00150	LIQUID GASKET,LG-7, 150G	AR	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

BREATHER AND BLOWBY SENSOR WIRING

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6210-21-8711	BREATHER	1	00500319-
2	6631-11-5630	SPACER	2	00500319-
3	01010-81040	BOLT	2	00500319-
4	07000-72060	O-RING (K2)	1	00500319-
5	6130-61-6611	HOSE	1	00500319-
6	07285-00260	CLIP	2	00500319-
7	6219-21-8790	TUBE,R.H.	1	00500319-
8	07285-00220	CLIP	1	00500319-
9	07287-01910	HOSE	1	00500319-
10	01010-81220	BOLT	2	00500319-
11	01010-81255	BOLT	1	00500319-
12	01643-31232	WASHER	1	00500319-
13	6127-11-5180	SPACER	1	00500319-
14	04434-52310	CLIP	1	00500319-
15	01010-81016	BOLT	1	00500319-
16	01643-31032	WASHER	1	00500319-
17	6210-21-8711	BREATHER	1	00500319-
18	6631-11-5630	SPACER	2	00500319-
19	01010-81040	BOLT	2	00500319-
20	07000-72060	O-RING (K2)	1	00500319-
21	6130-61-6611	HOSE	1	00500319-
22	07285-00260	CLIP	2	00500319-
23	01010-81220	BOLT	1	00500319-
24	01643-31232	WASHER	1	00500319-
25	07287-01910	HOSE	1	00500319-
26	07285-00220	CLIP	1	00500319-
27	6219-21-8780	TUBE,L.H.	1	00500319-
28	01010-81030	BOLT	1	00500319-
29	01643-31032	WASHER	1	00500319-
30	6218-81-4111	SENSOR ASS'Y,BLOWBY	1	00500319-
31	6215-11-6320	CONNECTOR	1	00500319-
32	07000-03050	O-RING (K2)	1	00500319-
33	01435-00620	BOLT	2	00500319-
34	6164-71-6491	BRACKET	1	00500319-
35	01010-81255	BOLT	1	00500319-
36	01643-31232	WASHER	1	00500319-
37	600-051-2100	CLIP	1	00500319-
38	01010-81025	BOLT	1	00500319-
39	01643-31032	WASHER	1	00500319-
40	01584-01008	NUT	1	00500319-
41	600-051-2100	CLIP	1	00500319-
42	01010-81030	BOLT	1	00500319-
43	01643-31032	WASHER	1	00500319-
44	600-051-2100	CLIP	1	00500319-
45	6218-81-8480	BAND	1	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

BREATHER AND BLOWBY SENSOR WIRING

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
46	01010-81020	BOLT	1	00500319-
47	01643-31032	WASHER	3	00500319-
48	6204-23-5910	STAY	2	00500319-
49	01010-81035	BOLT	2	00500319-
50	08193-20010	CLIP	1	00500319-
51	600-051-2100	CLIP	1	00500319-
52	6212-85-2440	PLATE	1	00500319-
53	01643-31032	WASHER	2	00500319-
54	01010-81025	BOLT	2	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

BREATHER AND BLOWBY SENSOR WIRING(EXTREMELY BAD FUEL AND POOR FUEL ARRANGEMENT SPEC) (WATER DUST)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6210-21-8711	BREATHER	1	00500319-
2	6631-11-5630	SPACER	2	00500319-
3	01010-81040	BOLT	2	00500319-
4	07000-72060	O-RING (K2)	1	00500319-
5	6130-61-6611	HOSE	1	00500319-
6	07285-00260	CLIP	2	00500319-
7	6219-21-8790	TUBE,R.H.	1	00500319-
8	07285-00220	CLIP	1	00500319-
9	07287-01910	HOSE	1	00500319-
10	01010-81225	BOLT	2	00500319-
11	01010-81230	BOLT	1	00500319-
12	01643-31232	WASHER	2	00500319-
13	6127-11-5180	SPACER	1	00500319-
14	04434-52310	CLIP	1	00500319-
15	01010-81016	BOLT	1	00500319-
16	01643-31032	WASHER	1	00500319-
17	6210-21-8711	BREATHER	1	00500319-
18	6631-11-5630	SPACER	2	00500319-
19	01010-81040	BOLT	2	00500319-
20	07000-72060	O-RING (K2)	1	00500319-
21	6130-61-6611	HOSE	1	00500319-
22	07285-00260	CLIP	2	00500319-
23	01010-81225	BOLT	1	00500319-
24	01643-31232	WASHER	1	00500319-
25	07287-01910	HOSE	1	00500319-
26	07285-00220	CLIP	1	00500319-
27	6219-21-8780	TUBE,L.H.	1	00500319-
28	01010-81030	BOLT	1	00500319-
29	01643-31032	WASHER	1	00500319-
30	6218-81-4111	SENSOR ASS'Y,BLOWBY	1	00500319-
31	6215-11-6320	CONNECTOR	1	00500319-
32	07000-03050	O-RING (K2)	1	00500319-
33	01435-00620	BOLT	2	00500319-
34	6164-71-6491	BRACKET	1	00500319-
35	01010-81255	BOLT	1	00500319-
36	01643-31232	WASHER	1	00500319-
37	600-051-2100	CLIP	1	00500319-
38	01010-81025	BOLT	1	00500319-
39	01643-31032	WASHER	1	00500319-
40	01584-01008	NUT	1	00500319-
41	600-051-2100	CLIP	1	00500319-
42	01010-81030	BOLT	1	00500319-
43	01643-31032	WASHER	1	00500319-
44	600-051-2100	CLIP	1	00500319-
45	6218-81-8480	BAND	1	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

BREATHER AND BLOWBY SENSOR WIRING(EXTREMELY BAD FUEL AND POOR FUEL ARRANGEMENT SPEC)(WATER DUST)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
46	01010-81020	BOLT	1	00500319-
47	01643-31032	WASHER	3	00500319-
48	6204-23-5910	STAY	2	00500319-
49	01010-81035	BOLT	2	00500319-
50	08193-20010	CLIP	1	00500319-
51	600-051-2100	CLIP	1	00500319-
52	6212-85-2440	PLATE	1	00500319-
53	01643-31032	WASHER	2	00500319-
54	01010-81025	BOLT	2	00500319-


SAA12V140E-3B S/N 00500319-



SAA12V140E-3B S/N 00500319-

IDLER GEAR


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6215-31-6160	GEAR,IDLER, R.H.	1	00500319-
2	6215-31-6120	GEAR,IDLER, L.H.	1	00500319-
	6215-31-6100	IDLER GEAR ASS'Y	2	00500319-
3	☆	.GEAR	1	00500319-
4	6212-31-6130	.BUSHING	1	00500319-
	6215-31-6500	IDLER GEAR ASS'Y	1	00500319-
5	☆	.GEAR	1	00500319-
6	6215-31-6150	.BUSHING	1	00500319-
7	6215-31-6420	SHAFT	1	00500319-
8	6215-31-6460	PLATE	1	00500319-
9	01010-81280	BOLT	2	00500319-
10	01010-81040	BOLT	12	00500319-
11	6127-21-1260	PIN,DOWEL	2	00500319-
12	6215-31-6431	SHAFT	2	00500319-
13	6215-31-6470	PLATE	2	00500319-
14	6215-31-6131	BEARING,THRUST	4	00500319-
15	01011-81210	BOLT	4	00500319-



CAMFOLLOWER COVER

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6215-21-6420	COVER,CAMFOLLOWER	12	00500319-
2	6215-21-6431	GASKET (K2)	12	00500319-
3	6215-21-6450	BOLT	51	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

OIL FILLER

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	07025-00100	CAP,OIL FILLER	1	00500319-
2	6215-21-7520	FILLER,OIL	1	00500319-
3	07000-E3038	O-RING (K2)	1	00500319-
4	01435-01025	BOLT	1	00500319-
5	417-823-1460	SPACER	1	00500319-
6	6219-71-4520	BRACKET	1	00500319-
7	07283-24346	CLIP	1	00500319-
8	01597-01009	NUT	2	00500319-
9	01643-31032	WASHER	2	00500319-
10	6217-11-9690	SPACER	2	00500319-
11	01436-01045	BOLT	2	00500319-
12	6215-21-7260	PLATE	1	00500319-
13	01435-01016	BOLT	1	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

OIL PAN AND SUCTION TUBE

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6215-21-5210	PAN,OIL	1	00500319-
2	6215-21-5121	PLATE,UNDER	1	00500319-
3	6215-21-5130	PLATE	1	00500319-
4	6215-21-5140	PLATE	2	00500319-
5	6215-21-5811	GASKET (K2)	1	00500319-
6	6215-21-5820	GASKET (K2)	1	00500319-
7	01010-81040	BOLT	35	00500319-
8	01010-81025	BOLT	26	00500319-
9	01010-81035	BOLT	5	00500319-
10	01643-31032	WASHER	26	00500319-
11	01435-01020	BOLT	2	00500319-
12	02720-41616	PLUG	4	00500319-
13	6215-21-5160	COVER	1	00500319-
14	01010-81020	BOLT	2	00500319-
15	01643-31032	WASHER	2	00500319-
16	6693-22-5600	VALVE ASS'Y	1	00500319-
17	☆	.BODY	1	00500319-
18	☆	.VALVE	1	00500319-
19	07040-02412	.PLUG	1	00500319-
20	04020-00514	.PIN	1	00500319-
21	07000-73028	O-RING (K2)	1	00500319-
22	01010-81030	BOLT	2	00500319-
23	01643-31032	WASHER	2	00500319-
24	6215-51-6362	TUBE,SUCTION	1	00500319-
25	07000-E2080	O-RING (K2)	1	00500319-
26	01010-81235	BOLT	2	00500319-
27	6215-51-6241	BRACKET	1	00500319-
28	01010-81030	BOLT	1	00500319-
29	01010-81030	BOLT	1	00500319-
30	01580-01008	NUT	1	00500319-
31	01643-31032	WASHER	1	00500319-
32	6110-23-6490	SPACER	2	00500319-
33	6141-25-3770	WASHER	1	00500319-
	(09920-00150)	LIQUID GASKET, LG 150 G	AR	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

OIL PAN AND SUCTION TUBE (COLD TERRAN SPEC) (PM CLINIC SPEC)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6215-21-5210	PAN,OIL	1	00500319-
2	6215-21-5121	PLATE,UNDER	1	00500319-
3	6215-21-5130	PLATE	1	00500319-
4	6215-21-5140	PLATE	2	00500319-
5	6215-21-5811	GASKET (K2)	1	00500319-
6	6215-21-5820	GASKET (K2)	1	00500319-
7	01010-81040	BOLT	35	00500319-
8	01010-81025	BOLT	26	00500319-
9	01010-81035	BOLT	5	00500319-
10	01643-31032	WASHER	26	00500319-
11	01435-01020	BOLT	2	00500319-
12	6215-21-5160	COVER	1	00500319-
13	01010-81020	BOLT	2	00500319-
14	01643-31032	WASHER	2	00500319-
15	6693-22-5600	VALVE ASS'Y	1	00500319-
16	☆	.BODY	1	00500319-
17	☆	.VALVE	1	00500319-
18	07040-02412	.PLUG	1	00500319-
19	04020-00514	.PIN	1	00500319-
20	07000-73028	O-RING (K2)	1	00500319-
21	01010-81030	BOLT	2	00500319-
22	01643-31032	WASHER	2	00500319-
23	6215-51-6362	TUBE,SUCTION	1	00500319-
24	07000-E2080	O-RING (K2)	1	00500319-
25	01010-81235	BOLT	2	00500319-
26	6215-51-6241	BRACKET	1	00500319-
27	01010-81030	BOLT	1	00500319-
28	01580-01008	NUT	1	00500319-
29	01643-31032	WASHER	1	00500319-
30	6110-23-6490	SPACER	2	00500319-
31	6141-25-3770	WASHER	1	00500319-
32	600-815-9640	HEATER	4	00500319-
33	(09920-00150)	LIQIUD GASKET LG7-150G	AR	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

OIL LEVEL SENSOR

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	7861-93-4550	SENSOR,LEVEL	1	00500319-
2	6162-83-8612	CASE	1	00500319-
3	07002-23634	O-RING (K2)	1	00500319-
4	6219-81-5920	BRACKET	1	00500319-
5	01435-01020	BOLT	1	00500319-
6	01435-01080	BOLT	2	00500319-
7	08193-20010	CLIP	1	00500319-
8	6934-71-5910	HOSE	1	00500319-
9	6162-73-4670	NIPPLE	1	00500319-
10	6934-71-5950	JOINT	1	00500319-
11	07206-31014	BOLT,JOINT	3	00500319-
12	07005-01412	GASKET (K2)	7	00500319-
13	07217-60813	ELBOW	1	00500319-
14	6215-81-5940	TUBE	1	00500319-
15	07043-70211	PLUG	1	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

OIL LEVEL GAUGE

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	04434-51308	CLIP	1	00500319-
2	01010-80816	BOLT	1	00500319-
3	01643-30823	WASHER	1	00500319-
4	07000-72012	O-RING (K2)	1	00500319-
5	07201-61527	NUT	1	00500319-
6	6215-21-5220	GAUGE,OIL	1	00500319-
7	6215-21-5420	GUIDE,OIL GAUGE	1	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

FLYWHEEL HOUSING (WITH BARING AND REVOLUTION SEN-
SOR)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6219-21-4110	HOUSING,FLYWHEEL	1	00500319-
2	6215-21-4810	GASKET (K2)	1	00500319-
3	01010-61865	BOLT	14	00500319-
4	01643-31845	WASHER	14	00500319-
5	07040-13316	PLUG	1	00500319-
6	07002-23334	O-RING (K2)	1	00500319-
7	6219-21-4260	SEAL, REAR,DRY TYPE (K2)	1	00500319-
8	6136-51-4140	PLUG	2	00500319-
9	07005-02216	GASKET	2	00500319-
10	6261-81-2901	SENSOR,REVOLUTION	1	00500319-
	6261-81-2911	.SENSOR	1	00500319-
	6271-81-9220	.O-RING	1	00500319-
11	01435-00816	BOLT	1	00500319-
	6162-23-4500	BARING DIVICE ASS'Y	1	00500319-
12	☆	.CASE	1	00500319-
13	☆	.SHAFT	1	00500319-
14	☆	.GEAR	1	00500319-
15	☆	.SPRING	1	00500319-
16	6162-23-4531	.PIN,SNAP	1	00500319-
17	☆	.SEAL,DUST	1	00500319-
18	6162-23-4941	GASKET (K2)	1	00500319-
19	01010-81030	BOLT	3	00500319-
20	01643-31032	WASHER	3	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

FLYWHEEL


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	6219-31-4100	FLYWHEEL	1	00500319-
1	★	.FLYWHEEL	1	00500319-
2	6645-31-1321	.GEAR,RING	1	00500319-
3	01050-32060	BOLT	10	00500319-
4	6127-11-1620	WASHER	10	00500319-
5	04020-01228	PIN,DOWEL	1	00500319-

SAA12V140E-3B S/N 00500319-

Front Side



Rear Side





SAA12V140E-3B S/N 00500319-

FRONT SUPPORT AND REAR BRACKET (SERVICE ONLY)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6215-21-3710	SUPPORT,FRONT	1	00500319-
2	6215-21-3310	BRACKET,REAR	2	00500319-
3	04020-01434	PIN,DOWEL	4	00500319-
4	01010-62050	BOLT	8	00500319-
5	01643-32060	WASHER	8	00500319-

SAA12V140E-3B S/N 00500319-





SAA12V140E-3B S/N 00500319-

FRONT SUPPORT AND BRACKET

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6215-21-3710	SUPPORT,FRONT	1	00500319-
2	561-01-81211	BRACKET	1	00500319-
3	01010-82085	BOLT	2	00500319-
4	01643-32060	WASHER	2	00500319-
5	6215-2L-3310	BRACKET,LINK PARTS	2	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

FRONT SUPPORT AND BRACKET

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6215-21-3710	SUPPORT,FRONT	1	00500319-
2	561-01-81211	BRACKET	1	00500319-
3	01010-82085	BOLT	2	00500319-
4	01643-32060	WASHER	2	00500319-
5	6215-21-3310	BRACKET,REAR	2	00500319-
6	04020-01434	PIN,DOWEL	4	00500319-
7	01010-62050	BOLT	8	00500319-
8	01643-32060	WASHER	8	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

CRANKSHAFT

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	6219-31-1100	CRANKSHAFT ASS'Y	1	00500319-
1	☆	*CRANKSHAFT	1	00500319-
2	6215-31-1140	*GEAR,CRANKSHAFT	1	00500319-
3	04010-00728	*KEY	1	00500319-
		STANDARD		
	6215-21-8001	MAIN METAL ASS'Y	1	00500319-
	6215-21-8011	*MAIN METAL ASS'Y,NO.1,2,3,5,6,7	6	00500319-
4	☆	**METAL, UPPER	1	00500319-
5	☆	**METAL, LOWER	1	00500319-
	6215-21-8021	*MAIN METAL ASS'Y,NO.4	1	00500319-
6	☆	**METAL, UPPER	1	00500319-
7	☆	**METAL, LOWER	1	00500319-
8	6215-21-8050	*THRUST METAL ASS'Y	1	00500319-
	☆	**METAL, THRUST	3	00500319-
		UNDERSIZE 0.25MM		
	6215-29-8011	*MAIN METAL ASS'Y,NO.1,2,3,5,6,7	6	00500319-
4	☆	**METAL, UPPER	1	00500319-
5	☆	**METAL, LOWER	1	00500319-
	6215-29-8021	*MAIN METAL ASS'Y,NO.4	1	00500319-
6	☆	**METAL, UPPER	1	00500319-
7	☆	**METAL, LOWER	1	00500319-
		UNDERSIZE 0.50MM		
	6215-28-8011	*MAIN METAL ASS'Y,NO.1,2,3,5,6,7	6	00500319-
4	☆	**METAL, UPPER	1	00500319-
5	☆	**METAL, LOWER	1	00500319-
	6215-28-8021	*MAIN METAL ASS'Y,NO.4	1	00500319-
6	☆	**METAL, UPPER	1	00500319-
7	☆	**METAL, LOWER	1	00500319-
		UNDERSIZE 0.75MM		
	6215-27-8011	*MAIN METAL ASS'Y,NO.1,2,3,5,6,7	6	00500319-
4	☆	**METAL, UPPER	1	00500319-
5	☆	**METAL, LOWER	1	00500319-
	6215-27-8021	*MAIN METAL ASS'Y,NO.4	1	00500319-
6	☆	**METAL, UPPER	1	00500319-
7	☆	**METAL, LOWER	1	00500319-
		UNDERSIZE 1.00MM		
	6215-26-8011	*MAIN METAL ASS'Y,NO.1,2,3,5,6,7	6	00500319-
4	☆	**METAL, UPPER	1	00500319-
5	☆	**METAL, LOWER	1	00500319-
	6215-26-8021	*MAIN METAL ASS'Y,NO.4	1	00500319-
6	☆	**METAL, UPPER	1	00500319-
7	☆	**METAL, LOWER	1	00500319-
		OVERSIZE 0.25MM		
8	6215-29-8050	*THRUST METAL ASS'Y	1	00500319-
	☆	**METAL, THRUST	3	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

CRANKSHAFT


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
8	6215-28-8050 ☆	OVERSIZE 0.50MM	1	00500319-
		*THRUST METAL ASS'Y	3	00500319-
		**METAL, THRUST		
8	6215-27-8050 ☆	OVERSIZE 0.75MM	1	00500319-
		*THRUST METAL ASS'Y	3	00500319-
		**METAL, THRUST		
8	6215-26-8050 ☆	OVERSIZE 1.00MM	1	00500319-
		*THRUST METAL ASS'Y	3	00500319-
		**METAL, THRUST		

DAMPER

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6215-31-8200	DAMPER ASS'Y	1	00500319-
2	01010-81235	BOLT	12	00500319-
3	01643-31232	WASHER	12	00500319-
4	04020-01024	PIN,DOWEL	1	00500319-



SAA12V140E-3B S/N 00500319-



SAA12V140E-3B S/N 00500319-

PISTON AND CONNECTING ROD


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6219-31-2110	PISTON.....	12	00500319-
2	6211-31-2410	PIN,PISTON	12	00500319-
3	04065-05220	RING,SNAP	24	00500319-
	6261-31-2030	PISTON RING ASS'Y,PER CYLINDER	12	00500319-
4	☆	*RING,TOP	1	00500319-
5	☆	*RING,SECOND	1	00500319-
6	☆	*RING,OIL	1	00500319-
	6219-31-3200	*CONNECTING ROD A.,L.H.	6	00500319-
	6219-31-3100	*CONNECTING ROD A.,R.H.	6	00500319-
7	☆	*ROD,L.H	1	00500319-
	☆	*ROD,R.H	1	00500319-
8	☆	*CAP,L.H	1	00500319-
	☆	*CAP,R.H	1	00500319-
9	6261-31-3140	*BUSHING	1	00500319-
10	02400-10413	*PIN,DOWEL	2	00500319-
11	6215-31-3310	*BOLT	4	00500319-
12	6215-31-3330	*WASHER	4	00500319-
		STANDARD		
13	6215-31-3060	METAL ASS'Y	12	00500319-
	☆	*METAL	2	00500319-
		UNDERSIZE 0.25MM		
13	6215-39-3060	METAL ASS'Y	12	00500319-
	☆	*METAL	2	00500319-
		UNDERSIZE 0.50MM		
13	6215-38-3060	METAL ASS'Y	12	00500319-
	☆	*METAL	2	00500319-
		UNDERSIZE 0.75MM		
13	6215-37-3060	METAL ASS'Y	12	00500319-
	☆	*METAL	2	00500319-
		UNDERSIZE 1.00MM		
13	6215-36-3060	METAL ASS'Y	12	00500319-
	☆	*METAL	2	00500319-


SAA12V140E-3B S/N 00500319-

SAA12V140E-3B S/N 00500319-

CRANK PULLEY (PULLEY DIAMETER 182MM)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6215-31-1530	PULLEY, HARDENING	1	00500319-
2	6162-33-5321	BOLT	6	00500319-
3	04020-01024	PIN,DOWEL	1	00500319-






CAMSHAFT

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	6215-41-1100	CAMSHAFT ASS'Y,R.H.	1	00500319-
1	☆	*CAMSHAFT, R.H.	1	00500319-
2	6215-41-1130	*GEAR,R.H.	1	00500319-
3	04010-00725	*KEY	1	00500319-
4	6210-41-1131	*PLATE,THRUST	1	00500319-
	6215-41-1200	CAMSHAFT ASS'Y,L.H.	1	00500319-
5	☆	*CAMSHAFT, L.H.	1	00500319-
6	6210-41-1120	*GEAR,L.H.	1	00500319-
7	04010-00725	*KEY	1	00500319-
8	6210-41-1131	*PLATE,THRUST	1	00500319-
9	01437-01220	BOLT	4	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

CAMFOLLOWER

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	6210-41-2320	LEVER ASS'Y	24	00500319-
1	☆	*LEVER	1	00500319-
2	☆	*SOCKET	1	00500319-
3	☆	*ROLLER,CAM	1	00500319-
4	☆	*PIN, ROLLER	1	00500319-
	6210-41-2400	SHAFT ASS'Y	12	00500319-
5	☆	*SHAFT	1	00500319-
6	6150-81-8420	*BALL	1	00500319-
7	04064-02212	RING,SNAP	48	00500319-
8	6210-41-2450	BOLT	24	00500319-
9	6210-41-2431	PIN,DOWEL	24	00500319-
10	6210-41-3120	ROD,PUSH	24	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

ROCKER ARM

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	6261-41-5040	ROCKER ARM ASS'Y,INTAKE	12	00500319-
	6261-41-5400	*ARM ASS'Y	1	00500319-
1	☆	**ARM,INTAKE	1	00500319-
2	6261-41-5420	**BUSHING	1	00500319-
3	6162-43-5340	**RIVET	1	00500319-
4	04260-00317	**BALL	1	00500319-
5	6217-41-5550	*SCREW	1	00500319-
6	01582-01008	*NUT	1	00500319-
	6261-41-5050	ROCKER ARM ASS'Y,EXHAUST	12	00500319-
	6261-41-5500	*ARM ASS'Y	1	00500319-
7	☆	**ARM,EXHAUST	1	00500319-
8	6261-41-5520	**BUSHING	1	00500319-
9	04260-00317	**BALL	1	00500319-
10	6217-41-5550	*SCREW	1	00500319-
11	01582-01008	*NUT	1	00500319-
	6934-42-5300	ROCKER ARM SHAFT A.	12	00500319-
12	☆	*SHAF	1	00500319-
13	04260-00635	*BALL	1	00500319-
14	6261-41-5530	BRACKET	12	00500319-
15	6210-41-5440	COLLAR	12	00500319-
16	04020-00514	PIN,DOWEL	12	00500319-
17	04020-00514	PIN,DOWEL	24	00500319-
18	6217-41-5540	SPACER	12	00500319-
19	6217-41-5570	BOLT	12	00500319-
20	6217-41-5560	BOLT	12	00500319-
21	6217-81-8311	BOLT	12	00500319-
22	01643-51232	WASHER	12	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

OIL PUMP

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6219-51-1000	OIL PUMP ASS'Y	1	00500319-
2	01437-01245	BOLT	2	00500319-
3	01437-01280	BOLT	1	00500319-
4	07000-E3050	O-RING (K2)	1	00500319-
	6219-51-2700	VALVE ASS'Y	1	00500319-
5	☆	*BODY	1	00500319-
6	6219-51-2740	*PLUG	1	00500319-
7	6219-51-2730	*VALVE	1	00500319-
8	6219-51-2750	*SPRING	1	00500319-
9	6215-51-1780	GASKET (K2)	1	00500319-
10	01437-01030	BOLT	2	00500319-
11	01437-01060	BOLT	1	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

OIL FILTER

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6216-54-6430	HEAD ASS'Y	1	00500319-
2	600-211-1340	CARTRIDGE,OIL	4	00500319-
3	01435-01075	BOLT	5	00500319-
4	01436-01020	BOLT	4	00500319-
5	6219-51-5100	CONNECTOR ASS'Y	1	00500319-
	6219-51-5120	*CONNECTOR	1	00500319-
	07043-70108	*PLUG	4	00500319-
6	6219-51-5150	SPACER	1	00500319-
7	07000-73045	O-RING (K2)	1	00500319-
8	07000-73040	O-RING (K2)	3	00500319-
9	01436-01050	BOLT	5	00500319-
10	01435-01035	BOLT	1	00500319-
11	01435-01095	BOLT	1	00500319-
12	6219-51-5810	TUBE,INLET	1	00500319-
13	6219-51-5820	TUBE,RETURN	1	00500319-
14	01010-81030	BOLT	4	00500319-
15	07000-73045	O-RING (K2)	2	00500319-
16	6219-51-5610	O-RING (K2)	2	00500319-
17	6215-51-5650	PLATE	1	00500319-
18	6219-51-5620	GROMMET (K2)	2	00500319-
19	01435-01025	BOLT	1	00500319-
20	6219-51-5830	PLATE	2	00500319-
21	01435-01055	BOLT	2	00500319-
22	01643-01032	WASHER	2	00500319-
23	6165-61-6791	CLAMP	4	00500319-
24	01435-00820	BOLT	2	00500319-
25	07040-12012	PLUG	1	00500319-
26	07002-22034	O-RING (K2)	1	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

OIL ADAPTER

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	6215-51-5601	VALVE ASS'Y	1	00500319-
1	6215-51-5511	*BODY	1	00500319-
2	6215-51-5540	*COVER	1	00500319-
3	6215-51-5550	*VALVE	1	00500319-
4	6215-51-5560	*SPRING, VALVE	1	00500319-
5	6215-51-1730	*VALVE	1	00500319-
6	6215-51-1791	*SPRING, VALVE	1	00500319-
7	6215-51-5571	*PLUG	1	00500319-
8	6215-51-5591	*PLUG	1	00500319-
9	01010-80812	*BOLT	3	00500319-
10	07000-72018	*O-RING	1	00500319-
11	07000-73022	*O-RING	1	00500319-
12	11T-27-11190	*SHIM, 1.0MM	1	00500319-
13	01010-81090	BOLT	4	00500319-
14	07000-73038	O-RING (K2)	3	00500319-
15	07000-72018	O-RING (K2)	1	00500319-
16	6219-51-5110	CONNECTOR	1	00500319-
17	07000-72018	O-RING (K2)	1	00500319-
18	07000-73042	O-RING (K2)	3	00500319-
19	01436-01025	BOLT	1	00500319-
20	6215-51-5481	COVER	1	00500319-
21	6215-51-5490	GASKET (K2)	1	00500319-
22	01010-81080	BOLT	6	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

OIL COOLER

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6215-61-2113	COVER	2	00500319-
2	600-651-1610	ELEMENT	2	00500319-
3	6210-61-2520	O-RING (K2)	4	00500319-
4	07000-A2016	O-RING (K2)	8	00500319-
5	6215-61-2580	NUT	8	00500319-
6	6215-61-2810	GASKET (K2)	2	00500319-
7	01010-81030	BOLT	24	00500319-
8	01010-81065	BOLT	2	00500319-
9	01010-81075	BOLT	4	00500319-
10	6215-61-2171	COVER	1	00500319-
11	07000-73040	O-RING (K2)	1	00500319-
12	01010-81085	BOLT	2	00500319-
13	01010-81030	BOLT	1	00500319-
14	07040-11409	PLUG	1	00500319-
15	07002-21423	O-RING (K2)	1	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

OIL COOLER (COLD TERRAIN SPEC) (PM CLINIC SPEC)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6215-61-2113	COVER	1	00500319-
2	600-651-1610	ELEMENT	1	00500319-
3	6210-61-2520	O-RING (K2)	2	00500319-
4	07000-A2016	O-RING (K2)	4	00500319-
5	6215-61-2580	NUT	4	00500319-
6	6215-61-2712	COVER	1	00500319-
7	600-651-1610	ELEMENT	1	00500319-
8	6210-61-2520	O-RING (K2)	2	00500319-
9	07000-A2016	O-RING (K2)	4	00500319-
10	6215-61-2580	NUT	4	00500319-
11	6215-61-2810	GASKET (K2)	2	00500319-
12	01010-81030	BOLT	24	00500319-
13	01010-81065	BOLT	2	00500319-
14	01010-81075	BOLT	4	00500319-
15	6215-61-2171	COVER	1	00500319-
16	07000-73040	O-RING (K2)	1	00500319-
17	01010-81085	BOLT	2	00500319-
18	01010-81030	BOLT	1	00500319-
19	07040-11409	PLUG	1	00500319-
20	07002-21423	O-RING (K2)	1	00500319-
21	6164-91-6290	SPACER	1	00500319-
22	01010-81075	BOLT	1	00500319-
23	01643-31032	WASHER	1	00500319-
24	600-815-9650	HEATER,WATER	1	00500319-
25	6150-21-1190	O-RING (K2)	1	00500319-
26	08193-20010	CLIP	1	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

FUEL INJECTION PUMP MOUNTING

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6219-71-1100	FUEL PUMP ASS'Y,SUPPLY (L.H.)	1	00500319-
2	★	*PUMP	1	00500319-
3	04010-00519	*KEY	1	00500319-
4	6219-71-3140	*COUPLING	1	00500319-
5	6219-71-3150	*NUT	1	00500319-
6	6219-71-1200	FUEL PUMP ASS'Y,SUPPLY (R.H.)	1	00500319-
7	★	*PUMP	1	00500319-
8	04010-00519	*KEY	1	00500319-
9	6219-71-3140	*COUPLING	1	00500319-
10	6219-71-3150	*NUT	1	00500319-
11	6217-71-5910	TUBE	2	00500319-
12	01010-81035	BOLT	6	00500319-
13	01643-31032	WASHER	6	00500319-
14	6934-72-3980	BOLT	2	00500319-
15	6151-71-2980	SPACER	2	00500319-
16	6219-71-8120	TUBE	2	00500319-
17	6217-71-5251	BOLT	4	00500319-
18	(6219-71-1210)	RAIL ASS'Y (L.H) (SEE FIG.A4010-B7F7)	1	00500319-
19	(6219-71-1220)	RAIL ASS'Y (R.H) (SEE FIG.A4010-C7F7)	1	00500319-
20	6219-71-4410	BRACKET	1	00500319-
21	01435-01070	BOLT	4	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

COMMON RAIL (L.H.) (INNER PARTS)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6219-71-1210	RAIL ASS'Y,COMMON	1	00500319-
2	ND095400-0310	LIMITER ASS'Y,FUEL FLOW	6	00500319-
3	ND095420-0150	LIMITER ASS'Y,FUEL PRESSURE	1	00500319-
4	ND499000-6160	SENSOR ASS'Y,PRESSURE	1	00500319-
5	ND095444-0020	PICCO RING	1	00500319-
6	ND095438-0090	BOLT,JOINT	1	00500319-
7	ND949010-2530	GASKET	2	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

COMMON RAIL (L.H.) (INNER PARTS)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6219-71-1220	RAIL ASS'Y,COMMON	1	00500319-
2	ND095400-0310	LIMITER ASS'Y,FUEL FLOW	6	00500319-
3	ND095420-0150	LIMITER ASS'Y,FUEL PRESSURE	1	00500319-
4	ND499000-6160	SENSOR ASS'Y,PRESSURE	1	00500319-
5	ND095444-0020	PICCO RING	1	00500319-
6	ND095438-0090	BOLT,JOINT	1	00500319-
7	ND949010-2530	GASKET	2	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

FUEL SUPPLY PUMP BRACKET AND RAIL RETURN PIPING

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6219-71-5570	TUBE,FUEL RETURN, L.H.	1	00500319-
2	6934-72-5660	CLAMP	2	00500319-
3	01010-81045	BOLT	1	00500319-
4	01643-31032	WASHER	1	00500319-
5	01584-01008	NUT	2	00500319-
6	6219-71-5680	BRACKET	2	00500319-
7	01010-81025	BOLT	1	00500319-
8	01643-31032	WASHER	1	00500319-
9	07206-31014	BOLT,JOINT	1	00500319-
10	07005-01412	GASKET (K2)	2	00500319-
11	6219-71-5640	TUBE,FUEL RETURN R.H.	1	00500319-
12	6219-71-5660	BRACKET	1	00500319-
13	6934-72-5660	CLAMP	2	00500319-
14	01010-81045	BOLT	1	00500319-
15	01643-31032	WASHER	1	00500319-
16	01584-01008	NUT	1	00500319-
17	07206-31014	BOLT,JOINT	1	00500319-
18	07005-01412	GASKET (K2)	2	00500319-
19	6219-71-4380	BRACKET	1	00500319-
20	6219-71-4390	BRACKET	1	00500319-
21	01435-01030	BOLT	2	00500319-
22	01435-01025	BOLT	2	00500319-
23	01584-01008	NUT	2	00500319-
24	01435-01220	BOLT	2	00500319-
25	6219-71-4480	BRACKET	1	00500319-
26	6219-71-4491	BRACKET	1	00500319-
27	01435-01025	BOLT	2	00500319-
28	01435-01030	BOLT	2	00500319-
29	01584-01008	NUT	2	00500319-
30	01435-01220	BOLT	2	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

SUPPLY PUMP BRACKET AND RAIL PIPING (EXTREMELY BAD FUEL AND POOR FUEL ARRANGEMENT SPEC) (WATER DUST)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6219-71-7790	TUBE,FUEL RETURN, L.H.	1	00500319-
2	6934-72-5660	CLAMP	4	00500319-
3	01010-81045	BOLT	2	00500319-
4	01643-31032	WASHER	2	00500319-
5	01584-01008	NUT	1	00500319-
6	6219-71-7970	BRACKET	1	00500319-
7	6219-71-7950	BRACKET	1	00500319-
8	01010-81025	BOLT	2	00500319-
9	01643-31032	WASHER	2	00500319-
10	07206-31014	BOLT,JOINT	1	00500319-
11	07005-01412	GASKET (K2)	2	00500319-
12	6219-71-7830	TUBE,FUEL RETURN, R.H.	1	00500319-
13	6934-71-5860	BRACKET	1	00500319-
14	6934-72-5660	CLAMP	2	00500319-
15	01010-81040	BOLT	1	00500319-
16	01643-31032	WASHER	1	00500319-
17	07206-31014	BOLT,JOINT	1	00500319-
18	07005-01412	GASKET (K2)	2	00500319-
19	6219-71-4380	BRACKET	1	00500319-
20	6219-71-7990	SPACER	1	00500319-
21	01010-81055	BOLT	2	00500319-
22	01643-31032	WASHER	2	00500319-
23	01435-01220	BOLT	2	00500319-
24	6219-71-4480	BRACKET	1	00500319-
25	6219-71-7980	SPACER	1	00500319-
26	01010-81075	BOLT	2	00500319-
27	01643-31032	WASHER	2	00500319-
28	01435-01220	BOLT	2	00500319-

SAA12V140E-3B S/N 00500319-

L. H. Bank



R. H. Bank




SAA12V140E-3B S/N 00500319-

FUEL INJECTION PIPING (1/4) (COMMON RAIL INJECTOR)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6219-71-4110	TUBE,INJECTION. NO.1, R.H.	1	00500319-
2	6219-71-4120	TUBE,INJECTION. NO.2, R.H.	1	00500319-
3	6219-71-4130	TUBE,INJECTION. NO.3, R.H.	1	00500319-
4	6219-71-4140	TUBE,INJECTION. NO.4, R.H.	1	00500319-
5	6219-71-4150	TUBE,INJECTION. NO.5, R.H.	1	00500319-
6	6219-71-4160	TUBE,INJECTION. NO.6, R.H.	1	00500319-
7	6219-71-4210	TUBE,INJECTION. NO.1, L.H.	1	00500319-
8	6219-71-4220	TUBE,INJECTION. NO.2, L.H.	1	00500319-
9	6219-71-4230	TUBE,INJECTION. NO.3, L.H.	1	00500319-
10	6219-71-4240	TUBE,INJECTION. NO.4, L.H.	1	00500319-
11	6219-71-4250	TUBE,INJECTION. NO.5, L.H.	1	00500319-
12	6219-71-4260	TUBE,INJECTION. NO.6, L.H.	1	00500319-
13	07000-E2015	O-RING (K1)	12	00500319-


SAA12V140E-3B S/N 00500319-



SAA12V140E-3B S/N 00500319-

FUEL INJECTION PIPING (2/4) (INJECTION PIPING SUPPORT)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6219-71-5410	BRACKET	5	00500319-
2	6219-71-5480	BRACKET	1	00500319-
3	01435-00820	BOLT	13	00500319-
4	6219-71-4680	BRACKET	1	00500319-
5	01010-81025	BOLT	1	00500319-
6	01643-31032	WASHER	1	00500319-
7	6261-71-6670	CLAMP	24	00500319-
8	01435-00630	BOLT	12	00500319-
9	6219-71-5420	BRACKET	10	00500319-
10	01435-00820	BOLT	20	00500319-
11	6219-71-5450	BRACKET	1	00500319-
12	6219-71-5330	BRACKET	2	00500319-
13	6219-71-8130	BRACKET	1	00500319-
14	6219-71-5430	BRACKET	2	00500319-
15	01435-01025	BOLT	8	00500319-
16	6217-71-6640	CLAMP,WITH THREAD	4	00500319-
17	6217-71-6650	CLAMP	6	00500319-
18	01435-00630	BOLT	4	00500319-
19	6217-71-6670	CLAMP	12	00500319-
20	6217-71-6660	CLAMP,WITH THREAD	11	00500319-
21	6217-71-6670	CLAMP	1	00500319-
22	01435-00630	BOLT	11	00500319-
23	6219-71-4590	BRACKET	1	00500319-
24	6219-71-4360	BRACKET	1	00500319-
25	01010-80825	BOLT	4	00500319-
26	6130-12-1961	SPACER	4	00500319-
27	6217-71-5260	CLAMP	2	00500319-
28	6217-71-5760	CLAMP	2	00500319-
29	01435-00635	BOLT	14	00500319-



FUEL INJECTION PIPING (3/4) (INJECTION PIPING COVER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6217-71-9780	CAP	4	00500319-
2	6217-71-9770	CAP	12	00500319-
3	6217-71-9791	COVER	16	00500319-
4	6156-71-9730	CLIP	4	00500319-
5	6217-71-5770	CLAMP	20	00500319-


SAA12V140E-3B S/N 00500319-



SAA12V140E-3B S/N 00500319-

FUEL INJECTION PIPING (4/4) (SUPPLY PUMP COMMON RAIL)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6219-71-5140	TUBE,SUPPLY, L.H.	2	00500319-
2	6219-71-5120	TUBE,SUPPLY, R.H.	2	00500319-
3	6219-71-4550	BRACKET.....	1	00500319-
4	01435-01025	BOLT	2	00500319-
5	6219-71-4470	BRACKET.....	1	00500319-
6	01435-01030	BOLT	2	00500319-
7	01643-31032	WASHER	2	00500319-
8	6219-71-4350	BRACKET.....	1	00500319-
9	01435-01025	BOLT	2	00500319-
10	01643-31032	WASHER	2	00500319-
11	6219-71-4340	BRACKET.....	1	00500319-
12	01435-01020	BOLT	2	00500319-
13	6215-71-4921	BOLT	2	00500319-
14	01584-01008	NUT	2	00500319-
15	6219-71-5490	BRACKET.....	1	00500319-
16	01435-01025	BOLT	1	00500319-
17	6219-71-5350	BRACKET.....	1	00500319-
18	01435-01025	BOLT	1	00500319-
19	6217-71-5281	BRACKET.....	1	00500319-
20	01435-01025	BOLT	1	00500319-
21	01584-01008	NUT	1	00500319-
22	6217-71-5170	CLAMP	2	00500319-
23	6217-71-5210	CLAMP	2	00500319-
24	01435-00640	BOLT	4	00500319-
25	01643-30823	WASHER	4	00500319-
26	6217-71-6640	CLAMP	1	00500319-
27	6217-71-6650	CLAMP	1	00500319-
28	01435-00630	BOLT	1	00500319-
29	6166-85-6720	CLAMP	2	00500319-
30	01435-00840	BOLT	1	00500319-
31	6217-71-5210	CLAMP	4	00500319-
32	01435-00630	BOLT	4	00500319-



FUEL INJECTION PUMP LUBRICATOR

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6219-71-5820	TUBE	1	00500319-
2	6219-71-5830	TUBE	1	00500319-
3	6219-71-5810	TUBE	1	00500319-
4	6934-72-7190	BOLT,JOINT	4	00500319-
5	07005-01012	GASKET (K2)	8	00500319-
6	6212-65-8860	ADAPTER	2	00500319-
7	6215-81-9720	O-RING (K2)	2	00500319-
8	6219-71-4530	BRACKET.....	1	00500319-
9	01435-01030	BOLT	1	00500319-
10	01584-01008	NUT	1	00500319-
11	6219-71-5360	BRACKET.....	1	00500319-
12	01435-01020	BOLT	1	00500319-
13	6934-72-5660	CLAMP	2	00500319-
14	01435-01040	BOLT	1	00500319-
15	6217-71-6670	CLAMP	2	00500319-
16	01435-00635	BOLT	1	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

FUEL INJECTION PUMP LUBRICATOR EXTREMELY BAD FUEL AND POOR FUEL ARRANGEMENT SPEC) (WATER DUST)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6219-71-5820	TUBE,SUPPLY (L.H.)	1	00500319-
2	6219-71-5830	TUBE,DRIVE CASE	1	00500319-
3	6219-71-7840	TUBE,SUPPLY (R.H.)	1	00500319-
4	6934-72-7190	BOLT,JOINT	4	00500319-
5	07005-01012	GASKET (K2)	8	00500319-
6	6212-65-8860	ADAPTER	2	00500319-
7	6215-81-9720	O-RING (K2)	2	00500319-
8	6219-71-4530	BRACKET	1	00500319-
9	01010-81075	BOLT	1	00500319-
10	01643-31032	WASHER	1	00500319-
11	6219-71-7870	BRACKET	1	00500319-
12	6219-71-7880	BRACKET	1	00500319-
13	01010-81025	BOLT	2	00500319-
14	01643-31032	WASHER	2	00500319-
15	6934-72-5660	CLAMP	6	00500319-
16	01010-81045	BOLT	3	00500319-
17	01643-31032	WASHER	3	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

FUEL INJECTION PUMP DRIVE

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	6219-71-3100	HOUSING ASS'Y	1	00500319-
1	★	*HOUSINH	1	00500319-
2	6210-21-1790	*BUSHING	2	00500319-
3	6553-71-3720	*SHAFT	1	00500319-
4	6215-81-9510	*PLUG	2	00500319-
5	6215-81-9710	*O-RING (K2)	2	00500319-
6	6219-71-3310	GEAR,INJECTION DRIVE	1	00500319-
7	6219-71-3120	SHAFT,(R.H.)	1	00500319-
8	6219-71-3130	COUPLING	1	00500319-
9	6219-71-3140	COUPLING	1	00500319-
10	6219-71-3150	NUT	2	00500319-
11	6219-71-3160	PLATE,THRUST	1	00500319-
12	01252-30820	BOLT	3	00500319-
13	6215-71-3170	WASHER	3	00500319-
14	07000-72100	O-RING (K2)	1	00500319-
15	07000-72020	O-RING (K2)	2	00500319-
16	01010-81235	BOLT	4	00500319-
17	04065-05520	RING	2	00500319-
18	04010-00519	KEY	2	00500319-
19	01643-31232	WASHER	4	00500319-
20	6219-71-3170	BOLT	1	00500319-
21	07005-00612	GASKET (K2)	1	00500319-
	6219-71-3200	HOUSING ASS'Y	1	00500319-
22	★	*HOUSINH	1	00500319-
23	6210-21-1790	*BUSHING	2	00500319-
24	6553-71-3720	*SHAFT	1	00500319-
25	6215-81-9510	*PLUG	1	00500319-
26	6215-81-9710	*O-RING (K2)	1	00500319-
27	6219-71-3320	GEAR,INJECTION DRIVE	1	00500319-
28	6219-71-3220	SHAFT,(L.H.)	1	00500319-
29	6219-71-3150	NUT	1	00500319-
30	6219-71-3160	PLATE,THRUST	1	00500319-
31	01252-30820	BOLT	1	00500319-
32	6215-71-3170	WASHER	1	00500319-
33	04010-00519	KEY	1	00500319-
34	04065-05520	RING	1	00500319-
35	01010-81035	BOLT	4	00500319-
36	01643-31032	WASHER	4	00500319-
37	6219-71-3170	BOLT	1	00500319-
38	07005-00612	GASKET (K2)	1	00500319-
39	6219-71-3280	O-RING (K2)	1	00500319-
40	6219-71-3230	COUPLING	1	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

FUEL PIPING (R.H. BANK)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6219-71-5580	JOINT,FUEL	1	00500319-
2	02781-00516	UNION	1	00500319-
3	07002-12034	O-RING (K2)	1	00500319-
4	02781-00420	UNION	2	00500319-
5	07002-11823	O-RING (K2)	2	00500319-
6	178-03-11610	COLLAR	3	00500319-
7	01011-81070	BOLT	1	00500319-
8	01011-81065	BOLT	2	00500319-
9	01643-31032	WASHER	4	00500319-
10	6219-71-5620	TUBE,RETURN	1	00500319-
11	6934-52-6810	CLAMP	2	00500319-
12	01010-81040	BOLT	1	00500319-
13	6219-71-5590	TUBE,SUPPLY	1	00500319-
14	6219-71-5610	TUBE,RETURN	1	00500319-
15	6166-75-6820	CLAMP	2	00500319-
16	01010-80845	BOLT	1	00500319-
17	01643-30823	WASHER	1	00500319-
18	01584-00806	NUT	1	00500319-
19	6219-71-5670	BRACKET	1	00500319-
20	01010-81020	BOLT	1	00500319-
21	01643-31032	WASHER	1	00500319-
22	07206-31014	BOLT,JOINT	4	00500319-
23	07005-01412	GASKET (K2)	15	00500319-
24	6151-51-8490	SPACER	1	00500319-
25	02781-0031D	UNION	1	00500319-
26	07002-11423	O-RING (K2)	1	00500319-
27	02781-00422	UNION	1	00500319-
28	07002-12034	O-RING (K2)	1	00500319-
29	6219-71-5560	HOSE	1	00500319-
30	02896-11012	O-RING (K2)	1	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

FUEL PIPING (EXTREMELY BAD FUEL AND POOR FUEL AR-
RANGEMENT SPEC) (WATER DUST)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6219-71-7520	TUBE	1	00500319-
2	6219-71-7531	TUBE	1	00500319-
3	6219-71-7941	BRACKET	1	00500319-
4	6219-71-7960	BRACKET	1	00500319-
5	01010-81025	BOLT	2	00500319-
6	01643-31032	WASHER	2	00500319-
7	6240-71-6510	CLAMP	2	00500319-
8	6240-71-6520	CLAMP	2	00500319-
9	01010-81045	BOLT	2	00500319-
10	01010-81035	BOLT	1	00500319-
11	01643-31032	WASHER	3	00500319-
12	01584-01008	NUT	1	00500319-
13	6219-71-7820	TUBE	1	00500319-
14	07206-31014	BOLT,JOINT	1	00500319-
15	07005-01412	GASKET (K2)	2	00500319-
16	6219-71-7540	BRACKET	1	00500319-
17	01010-80620	BOLT	1	00500319-
18	01643-30623	WASHER	1	00500319-
19	6934-52-6810	CLAMP	2	00500319-
20	01010-81045	BOLT	1	00500319-
21	01643-31032	WASHER	1	00500319-
22	6219-71-8170	TUBE	1	00500319-
23	6219-71-7780	TUBE	1	00500319-
24	6219-71-7770	TUBE	1	00500319-
25	07206-31014	BOLT,JOINT	1	00500319-
26	07005-01412	GASKET (K2)	2	00500319-
27	6219-71-7850	BRACKET	1	00500319-
28	01010-81025	BOLT	1	00500319-
29	01643-31032	WASHER	1	00500319-
30	6934-52-6810	CLAMP	2	00500319-
31	01010-81045	BOLT	1	00500319-
32	01643-31032	WASHER	1	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

FUEL PIPING (L.H. BANK)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6219-71-5510	JOINT,FUEL	1	00500319-
2	6219-71-8160	JOINT	1	00500319-
3	02781-00420	UNION	2	00500319-
4	07002-11823	O-RING (K2)	2	00500319-
5	6219-71-5520	BRACKET	1	00500319-
6	6151-51-8490	SPACER	3	00500319-
7	01010-81040	BOLT	3	00500319-
8	01010-81025	BOLT	3	00500319-
9	01643-31032	WASHER	6	00500319-
10	6219-71-5550	TUBE	1	00500319-
11	01011-81010	BOLT	1	00500319-
12	01643-31032	WASHER	1	00500319-
13	6221-81-6940	SPACER	1	00500319-
14	6219-71-5530	TUBE,SUPPLY	1	00500319-
15	6219-71-5540	TUBE,RETURN	1	00500319-
16	01584-00806	NUT	1	00500319-
17	01010-80845	BOLT	1	00500319-
18	01643-30823	WASHER	1	00500319-
19	6219-71-5690	BRACKET	1	00500319-
20	6166-75-6820	CLAMP	2	00500319-
21	07206-31014	BOLT,JOINT	4	00500319-
22	07005-01412	GASKET (K2)	15	00500319-
23	6151-51-8490	SPACER	1	00500319-
24	02781-0031D	UNION	1	00500319-
25	07002-11423	O-RING (K2)	1	00500319-
26	01010-81035	BOLT	1	00500319-
27	01643-31032	WASHER	1	00500319-
28	6934-52-6810	CLAMP	2	00500319-
29	6219-71-5851	BRACKET	1	00500319-
30	01010-81020	BOLT	1	00500319-
31	01643-31032	WASHER	1	00500319-

SAA12V140E-3B S/N 00500319-



Ref. A4110-B7E6

Page 030600

SAA12V140E-3B S/N 00500319-


**FUEL CONNECTION (EXTREMELY BAD FUEL AND POOR FUEL
ARRANGEMENT SPEC) (WATER DUST)**

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6219-71-7510	BLOCK	1	00500319-
2	01011-81040	BOLT	4	00500319-
3	01643-31032	WASHER	4	00500319-
4	02781-0031D	UNION	1	00500319-
5	02781-0042A	JOINT	3	00500319-
6	02781-00522	UNION	1	00500319-
7	02782-10522	ELBOW	1	00500319-
8	07002-11423	O-RING (K2)	2	00500319-
9	07002-12434	O-RING (K2)	5	00500319-
10	02896-11009	O-RING (K2)	1	00500319-
11	02896-11012	O-RING (K2)	3	00500319-
12	02896-11015	O-RING (K2)	2	00500319-
13	07040-11209	PLUG	1	00500319-
14	07040-11409	PLUG	1	00500319-
15	07040-12412	PLUG	3	00500319-
16	07005-01212	GASKET (K2)	1	00500319-
17	07002-12434	O-RING (K2)	3	00500319-
18	6219-71-7510	BLOCK	1	00500319-
19	01011-81040	BOLT	4	00500319-
20	01643-31032	WASHER	4	00500319-
21	02781-0031D	UNION	1	00500319-
22	02781-0042A	JOINT	1	00500319-
23	02781-00522	UNION	1	00500319-
24	02782-10425	ELBOW	1	00500319-
25	02783-10522	ELBOW	1	00500319-
26	22B-62-18940	ELBOW	1	00500319-
27	07002-11423	O-RING (K2)	2	00500319-
28	07002-12434	O-RING (K2)	5	00500319-
29	02896-11009	O-RING (K2)	1	00500319-
30	02896-11012	O-RING (K2)	3	00500319-
31	02896-11015	O-RING (K2)	2	00500319-
32	07040-11209	PLUG	1	00500319-
33	07040-11409	PLUG	1	00500319-
34	07040-12412	PLUG	3	00500319-
35	07005-01212	GASKET (K2)	1	00500319-
36	07002-12434	O-RING (K2)	3	00500319-

Ref. A4110-B7E6

Page 030600

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

FUEL FILTER (EXTREMELY BAD FUEL AND POOR FUEL AR-
RANGEMENT SPEC) (WATER DUSTY)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	6219-71-6700	HEAD ASS'Y	1	00500319-
1	6219-71-6710	.HEAD	1	00500319-
2	6110-73-6231	.PLUG	1	00500319-
3	07005-00812	.GASKET	1	00500319-
4	600-319-3520	CARTRIDGE (1-5/8),(SERVICE ONLY)	1	00500319-
	☆	CARTRIDGE (1-5/8)	1	00500319-
5	01010-81035	BOLT	2	00500319-
6	01011-81015	BOLT	2	00500319-
7	01643-31032	WASHER	4	00500319-
8	6219-71-6750	HOSE	1	00500319-
9	6219-71-6740	HOSE	1	00500319-
10	07206-31014	BOLT,JOINT	3	00500319-
11	07005-01412	GASKET (K2)	6	00500319-
12	04434-52511	CLIP	2	00500319-
13	07095-20318	CUSHION	2	00500319-
14	01010-81025	BOLT	1	00500319-
15	01010-81075	BOLT	1	00500319-
16	01643-31032	WASHER	2	00500319-
17	6152-51-5520	SPACER	1	00500319-
	6219-71-6700	HEAD ASS'Y	1	00500319-
18	6219-71-6710	.HEAD	1	00500319-
19	6110-73-6231	.PLUG	1	00500319-
20	07005-00812	.GASKET	1	00500319-
21	600-319-3520	CARTRIDGE (1-5/8),(SERVICE ONLY)	1	00500319-
	☆	CARTRIDGE (1-5/8)	1	00500319-
22	01010-81035	BOLT	2	00500319-
23	01011-81015	BOLT	2	00500319-
24	01643-31032	WASHER	4	00500319-
25	6219-71-5260	HOSE	1	00500319-
26	6219-71-6340	HOSE	1	00500319-
27	07206-31014	BOLT,JOINT	3	00500319-
28	07005-01412	GASKET (K2)	6	00500319-
29	6219-71-5270	BRACKET	1	00500319-
30	6219-71-4810	BRACKET	1	00500319-
31	01010-81230	BOLT	1	00500319-
32	01643-31232	WASHER	1	00500319-
33	01011-81030	BOLT	1	00500319-
34	01643-31032	WASHER	1	00500319-
35	6166-75-6820	CLAMP,HALF	2	00500319-
36	01435-00840	BOLT	1	00500319-
37	01584-00806	NUT	1	00500319-
38	04434-52511	CLIP	2	00500319-
39	07095-20318	CUSHION	2	00500319-
40	144-874-7470	BOSS	1	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

FUEL FILTER (EXTREMELY BAD FUEL AND POOR FUEL AR-
RANGEMENT SPEC) (WATER DUSTY)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
41	01010-81050	BOLT	1	00500319-
42	01010-81020	BOLT	1	00500319-
43	01643-31032	WASHER	2	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

FUEL AIR VENT (R.H BANK) (EXTREMELY BAD FUEL AND POOR FUEL ARRANGEMENT SPEC) (WATER DUSTY)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6219-71-7860	BRACKET	1	00500319-
2	01010-81035	BOLT	2	00500319-
3	01643-31032	WASHER	2	00500319-
4	6261-71-7190	BLOCK	1	00500319-
5	6240-71-6530	CLAMP	1	00500319-
6	6240-71-6540	CLAMP	1	00500319-
7	01435-01050	BOLT	3	00500319-
8	205-62-74690	NIPPLE	1	00500319-
9	07002-11423	O-RING (K2)	1	00500319-
10	6128-81-4810	VALVE	1	00500319-
11	6245-71-6180	BOLT	1	00500319-
12	6219-71-7910	HOSE	1	00500319-
13	6219-71-7920	HOSE	1	00500319-
14	07206-30508	BOLT,JOINT	1	00500319-
15	6245-71-5960	BOLT	1	00500319-
16	07005-00812	GASKET (K2)	4	00500319-
17	07206-30812	BOLT,JOINT	2	00500319-
18	07005-01212	GASKET (K2)	4	00500319-
19	6219-71-8210	JOINT	2	00500319-
20	6219-71-8220	JOINT	2	00500319-
21	6219-71-6770	BRACKET	1	00500319-
22	6215-71-4921	BOLT	1	00500319-
23	01643-31032	WASHER	1	00500319-
24	01584-01008	NUT	1	00500319-
25	01010-81035	BOLT	1	00500319-
26	01643-31032	WASHER	1	00500319-
27	6219-71-7890	BRACKET	1	00500319-
28	6219-71-7930	BRACKET	1	00500319-
29	01010-81030	BOLT	3	00500319-
30	01010-81040	BOLT	1	00500319-
31	01643-31032	WASHER	4	00500319-
33	6166-13-3580	CLIP	4	00500319-
32	419-15-17540	SPACER	1	00500319-
34	6210-11-5820	SPACER	1	00500319-
35	01010-81045	BOLT	1	00500319-
36	01010-81055	BOLT	1	00500319-
37	01643-31032	WASHER	2	00500319-
38	6245-81-9420	PLATE	1	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

FUEL AIR VENT (L.H BANK) (EXTREMELY BAD FUEL AND POOR FUEL ARRANGEMENT SPEC) (WATER DUSTY)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6219-71-7570	PLATE	1	00500319-
2	01010-81030	BOLT	2	00500319-
3	01643-31032	WASHER	2	00500319-
4	6261-71-7190	BLOCK	1	00500319-
5	6240-71-6530	CLAMP, HALF	1	00500319-
6	6240-71-6540	CLAMP, HALF	1	00500319-
7	01435-01045	BOLT	3	00500319-
8	205-62-74690	NIPPLE	1	00500319-
9	07002-11423	O-RING (K2)	1	00500319-
10	6128-81-4810	VALVE	1	00500319-
11	6245-71-6180	BOLT	1	00500319-
12	6219-71-7590	TUBE	1	00500319-
13	6219-71-7580	TUBE	1	00500319-
14	07206-30508	BOLT, JOINT	1	00500319-
15	6245-71-5960	BOLT	1	00500319-
16	07005-00812	GASKET (K2)	4	00500319-
17	07206-30812	BOLT, JOINT	2	00500319-
18	07005-01212	GASKET (K2)	4	00500319-
19	6210-81-5540	BRACKET	1	00500319-
20	01010-81025	BOLT	3	00500319-
21	6206-11-4490	SPACER	1	00500319-
22	6245-71-5950	CLIP	3	00500319-
23	6934-71-5860	BRACKET	1	00500319-
24	01010-81020	BOLT	1	00500319-
25	01010-81060	BOLT	1	00500319-
26	01584-01008	NUT	1	00500319-
27	6245-81-9420	PLATE	1	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

FUEL PRIMING PUMP (EXTREMELY BAD FUEL AND POOR FUEL ARRANGEMENT SPEC) (WATER DUSTY)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6245-71-8110	PUMP ASS'Y, PRIMING	1	00500319-
2	6245-71-5680	BRACKET	2	00500319-
3	01010-80616	BOLT	4	00500319-
4	01643-30623	WASHER	4	00500319-
5	6245-71-5640	BLOCK	2	00500319-
6	6934-71-5850	PLATE	1	00500319-
7	6166-11-5391	SPACER	1	00500319-
8	6219-71-3980	BOLT	2	00500319-
9	01010-81065	BOLT	1	00500319-
10	01010-81020	BOLT	1	00500319-
11	01643-31032	WASHER	3	00500319-
12	08193-20010	CLIP	1	00500319-
13	6219-71-6980	HOSE	1	00500319-
14	6219-71-6990	HOSE	1	00500319-
15	07206-30812	BOLT, JOINT	2	00500319-
16	07005-01212	GASKET (K2)	4	00500319-
17	07206-31014	BOLT, JOINT	1	00500319-
18	07005-01412	GASKET (K2)	2	00500319-
19	6245-71-8110	PUMP ASS'Y, PRIMING	1	00500319-
20	6245-71-5680	BRACKET	2	00500319-
21	01010-80616	BOLT	4	00500319-
22	01643-30623	WASHER	4	00500319-
23	6245-71-5640	BLOCK	2	00500319-
24	6934-71-5850	PLATE	1	00500319-
25	6166-11-5391	SPACER	1	00500319-
26	6219-71-3980	BOLT	2	00500319-
27	01010-81065	BOLT	1	00500319-
28	01010-81020	BOLT	1	00500319-
29	01643-31032	WASHER	3	00500319-
30	08193-20010	CLIP	1	00500319-
31	6219-71-5980	HOSE	1	00500319-
32	6219-71-5990	HOSE	1	00500319-
33	07206-30812	BOLT, JOINT	2	00500319-
34	07005-01212	GASKET (K2)	4	00500319-
35	07206-31014	BOLT, JOINT	1	00500319-
36	07005-01412	GASKET (K2)	2	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

FUEL PRIMING PUMP COVER (EXTREMELY BAD FUEL AND POOR FUEL ARRANGEMENT SPEC)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6219-71-8310	COVER,L.H.	1	00500319-
2	01010-81025	BOLT	3	00500319-
3	01643-31032	WASHER	3	00500319-
4	6219-71-8330	BRACKET	1	00500319-
5	01011-81010	BOLT	2	00500319-
6	01643-31032	WASHER	2	00500319-
7	6150-71-7130	COLLAR	2	00500319-
8	6219-71-8360	BRACKET	1	00500319-
9	01010-81075	BOLT	1	00500319-
10	01643-31032	WASHER	1	00500319-
11	6152-51-5520	SPACER	1	00500319-
12	6219-71-8320	COVER,R.H.	1	00500319-
13	01010-81025	BOLT	2	00500319-
14	01011-81005	BOLT	1	00500319-
15	01643-31032	WASHER	3	00500319-
16	6150-71-7130	COLLAR	1	00500319-
17	6219-71-8340	BRACKET	1	00500319-
18	01010-81025	BOLT	1	00500319-
19	01011-81005	BOLT	1	00500319-
20	01643-31032	WASHER	2	00500319-
21	6240-21-7470	SPACER	1	00500319-
22	6219-71-8350	BRACKET	1	00500319-
23	01010-81070	BOLT	1	00500319-
24	01643-31032	WASHER	1	00500319-


SAA12V140E-3B S/N 00500319-



SAA12V140E-3B S/N 00500319-
FUEL FILTER (1-5/8) (SERVICE ONLY)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	600-319-3520	CARTRIDGE (1-5/8),FUEL	2	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

FUEL INJECTION NOZZLE AND SPILL PIPE

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6219-71-7110	TUBE	2	00500319-
2	6934-72-7190	BOLT,JOINT	10	00500319-
3	07005-01012	GASKET (K1)	26	00500319-
4	6215-11-6560	BOLT,JOINT	2	00500319-
5	6217-81-9252	WIRING HARNESS	12	00500319-
6	07000-E2018	O-RING (K1)	12	00500319-
7	6219-71-5320	PLATE	12	00500319-
8	01435-00610	BOLT	12	00500319-
9	6217-71-5340	CLAMP	12	00500319-
10	6217-71-1150	CLAMP	12	00500319-
11	6217-71-1170	SPACER	12	00500319-
12	01435-00635	BOLT	12	00500319-
13	6217-71-1161	HOLDER	12	00500319-
14	6261-71-6150	GASKET (K1)	12	00500319-
15	6219-11-3100	INJECTOR	12	00500319-
16	01437-01070	BOLT	12	00500319-
17	6219-71-1150	GASKET (K1)	24	00500319-
18	6219-71-1160	GASKET (K1)	12	00500319-
19	6217-71-1140	WASHER	12	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

FUEL RETURN

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6219-71-6510	TUBE	1	00500319-
2	6219-71-6520	TUBE	1	00500319-
3	07005-01012	GASKET (K1)	4	00500319-
4	07206-30812	BOLT,JOINT	2	00500319-
5	07005-01212	GASKET (K1)	4	00500319-
6	6216-11-8220	GASKET (K1)	2	00500319-
7	6219-71-6680	BLOCK,FUEL	1	00500319-
8	01010-81065	BOLT	4	00500319-
9	01643-31032	WASHER	4	00500319-
10	6219-71-6540	BLOCK	1	00500319-
11	01010-81030	BOLT	4	00500319-
12	01643-31032	WASHER	4	00500319-
13	6219-71-8810	BLOCK	1	00500319-
14	01010-81030	BOLT	2	00500319-
15	6219-71-5210	TUBE	1	00500319-
16	6156-71-5370	JOINT	2	00500319-
17	07206-31014	BOLT,JOINT	4	00500319-
18	07005-01412	GASKET (K1)	8	00500319-
19	6261-81-6900	SENSOR	2	00500319-
	6261-81-6910	.SENSOR	1	00500319-
	6261-84-9740	.O-RING	1	00500319-
20	07040-12412	PLUG	1	00500319-
21	07005-02416	GASKET (K1)	1	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

FUEL CONTROLLER

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	600-464-1200	CONTROLLER ASS'Y,L.H.	1	00500319-
2	600-464-1270	CONTROLLER ASS'Y,R.H.	1	00500319-
3	01435-00845	BOLT	2	00500319-
4	6219-81-7100	COOLER,FUEL	2	00500319-
	☆	.COVER	1	00500319-
	☆	.CASE	1	00500319-
	☆	.O-RING	1	00500319-
	☆	.BOLT	21	00500319-
5	6251-81-7210	CUSHION	16	00500319-
6	01010-81050	BOLT	8	00500319-
7	01643-31032	WASHER	8	00500319-
8	6219-71-6280	UNION	1	00500319-
9	6219-71-6290	ELBOW	3	00500319-
10	07002-11823	O-RING (K2)	4	00500319-
11	02896-11018	O-RING (K2)	4	00500319-
12	02762-006A4	HOSE	1	00500319-
13	6219-81-6910	BRACKET,L.H.	1	00500319-
14	6219-81-6920	BRACKET,R.H.	1	00500319-
15	01010-81260	BOLT	10	00500319-
16	01643-31232	WASHER	10	00500319-
17	6219-81-6930	BRACKET,L.H.	1	00500319-
18	6219-81-6940	BRACKET,R.H.	1	00500319-
19	01010-81230	BOLT	12	00500319-
20	01643-31232	WASHER	12	00500319-
21	6219-81-6850	BAR	1	00500319-
22	01010-81050	BOLT	2	00500319-
23	01643-31032	WASHER	2	00500319-
24	6219-81-8560	COVER,L.H.	1	00500319-
25	6219-81-8570	COVER,R.H.	1	00500319-
26	01435-00845	BOLT	8	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

FUEL CONTROLLER (EXTREMELY BAD FUEL AND POOR FUEL
ARRANGEMENT SPEC)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	600-464-1200	CONTROLLER ASS'Y,L.H.	1	00500391-
2	600-464-1270	CONTROLLER ASS'Y,R.H.	1	00500391-
3	01435-00845	BOLT	2	00500391-
4	6219-81-7100	COOLER,FUEL	2	00500391-
	☆	.COVER	1	00500391-
	☆	.CASE	1	00500391-
	☆	.O-RING	1	00500391-
	☆	.BOLT	21	00500391-
5	6251-81-7210	CUSHION	16	00500391-
6	01010-81050	BOLT	8	00500391-
7	01643-31032	WASHER	8	00500391-
8	6219-71-5890	ELBOW	3	00500391-
9	6219-71-6290	ELBOW	1	00500391-
10	07002-11823	O-RING (K2)	4	00500391-
11	6219-81-6910	BRACKET,L.H.	1	00500391-
12	6219-81-6920	BRACKET,R.H.	1	00500391-
13	01010-81260	BOLT	10	00500391-
14	01643-31232	WASHER	10	00500391-
15	6219-81-6930	BRACKET,L.H.	1	00500391-
16	6219-81-6940	BRACKET,R.H.	1	00500391-
17	01010-81230	BOLT	12	00500391-
18	01643-31232	WASHER	12	00500391-
19	6219-81-6850	BAR	1	00500391-
20	01010-81050	BOLT	2	00500391-
21	01643-31032	WASHER	2	00500391-
22	6219-81-8560	COVER,L.H.	1	00500391-
23	6219-81-8570	COVER,R.H.	1	00500391-
24	01435-00845	BOLT	8	00500391-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

WATER PUMP

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	6215-61-1506	WATER PUMP ASS'Y	1	00500319-
1	★	*BODY, WATER PUMP	1	00500319-
2	6215-61-1451	*IMPELLER	1	00500319-
3	6215-61-1221	*SHAFT	1	00500319-
4	6215-61-1160	*GEAR	1	00500319-
5	6162-63-1515	*SEAL, WATER (K6)	1	00500319-
6	6150-61-1510	*SEAL, OIL (K6)	1	00500319-
7	06330-06206	*BEARING, BALL	1	00500319-
8	06330-06306	*BEARING, BALL	1	00500319-
9	6162-63-1440	*RING, SNAP	1	00500319-
10	6215-81-9520	*PLUG	1	00500319-
11	6215-81-9720	*O-RING (K6)	1	00500319-
12	6216-61-1120	*HOUSING	1	00500319-
13	07000-02140	*O-RING (K6)	1	00500319-
14	07000-02060	*O-RING (K6)	1	00500319-
15	07000-72016	*O-RING (K6)	1	00500319-
16	6215-81-9520	*PLUG	2	00500319-
17	6215-81-9720	*O-RING (K6)	2	00500319-
18	01010-81230	*BOLT	2	00500319-
19	07000-72100	O-RING (K6)	1	00500319-
20	01011-81265	BOLT	2	00500319-
21	01011-81210	BOLT	2	00500319-
22	6215-61-7510	CONNECTOR	1	00500319-
23	01011-81010	BOLT	3	00500319-
24	6215-61-6530	GASKET (K6)	1	00500319-
25	6215-61-7521	TUBE	1	00500319-
26	6215-61-6520	PLATE	1	00500319-
27	01010-81020	BOLT	1	00500319-
28	07000-G3045	O-RING (K6)	2	00500319-
29	6219-61-7110	CONNECTOR	1	00500319-
30	07000-G2080	O-RING (K6)	1	00500319-
31	07000-G2090	O-RING (K6)	1	00500319-
32	07043-70617	PLUG	1	00500319-
33	07043-70108	PLUG	1	00500319-
34	07730-50004	VALVE, DRAIN	1	00500319-
35	01010-81040	BOLT	3	00500319-
36	01010-81030	BOLT	2	00500319-
37	6934-71-5860	BRACKET	1	00500319-
38	6143-11-4290	SPACER	1	00500319-
39	01010-81080	BOLT	1	00500319-
40	01643-31032	WASHER	1	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

WATER PUMP

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	6215-61-1506	WATER PUMP ASS'Y	1	00500319-
1	6215-61-1151	.BODY, WATER PUMP	1	00500319-
2	6215-61-1451	.IMPELLER	1	00500319-
3	6215-61-1221	.SHAFT	1	00500319-
4	6215-61-1160	.GEAR	1	00500319-
5	6162-63-1515	.SEAL, WATER (K6)	1	00500319-
6	6150-61-1510	.SEAL, OIL (K6)	1	00500319-
7	06330-06206	.BEARING, BALL	1	00500319-
8	06330-06306	.BEARING, BALL	1	00500319-
9	6162-63-1440	.RING	1	00500319-
10	6215-81-9520	.PLUG	1	00500319-
11	6215-81-9720	.O-RING (K6)	1	00500319-
12	6216-61-1120	.HOUSING	1	00500319-
13	07000-02140	.O-RING (K6)	1	00500319-
14	07000-02060	.O-RING (K6)	1	00500319-
15	07000-72016	.O-RING (K6)	1	00500319-
16	6215-81-9520	.PLUG	1	00500319-
17	6215-81-9720	.O-RING (K6)	1	00500319-
18	01010-81230	.BOLT	2	00500319-
19	07000-72100	O-RING (K6)	1	00500319-
20	01011-81265	BOLT	2	00500319-
21	01011-81210	BOLT	2	00500319-
22	6219-61-7110	CONNECTOR	1	00500319-
23	07000-G2080	O-RING (K6)	1	00500319-
24	07000-G2090	O-RING (K6)	1	00500319-
25	01010-81030	BOLT	3	00500319-
26	01010-81040	BOLT	3	00500319-
27	07043-70617	PLUG	1	00500319-
28	07043-70108	PLUG	1	00500319-
29	07730-50004	VALVE, DRAIN	1	00500319-
30	6215-61-6510	TUBE	1	00500319-
31	6215-61-6520	PLATE	1	00500319-
32	6215-61-6530	GASKET	1	00500319-
33	07000-G3045	O-RING (K6)	1	00500319-
34	01010-81020	BOLT	1	00500319-
35	01010-81025	BOLT	3	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

WATER PUMP (EXTREMELY BAD FUEL AND POOR ARRANGE-
MENT SPEC) (WATER DUSTY)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	6215-61-1506	WATER PUMP ASS'Y	1	00500319-
1	★	.BODY, WATER PUMP	1	00500319-
2	6215-61-1451	.IMPELLER	1	00500319-
3	6215-61-1221	.SHAFT	1	00500319-
4	6215-61-1160	.GEAR	1	00500319-
5	6162-63-1515	.SEAL, WATER (K6)	1	00500319-
6	6150-61-1510	.SEAL,OIL (K6)	1	00500319-
7	06330-06206	.BEARING,BALL	1	00500319-
8	06330-06306	.BEARING,BALL	1	00500319-
9	6162-63-1440	.RING,SNAP	1	00500319-
10	6215-81-9520	.PLUG	1	00500319-
11	6215-81-9720	.O-RING (K6)	1	00500319-
12	6216-61-1120	.HOUSING	1	00500319-
13	07000-02140	.O-RING (K6)	1	00500319-
14	07000-02060	.O-RING (K6)	1	00500319-
15	07000-72016	.O-RING (K6)	1	00500319-
16	6215-81-9520	.PLUG	1	00500319-
17	6215-81-9720	.O-RING (K6)	1	00500319-
18	01010-81230	.BOLT	2	00500319-
19	07000-72100	O-RING (K6)	1	00500319-
20	01011-81265	BOLT	2	00500319-
21	01011-81210	BOLT	2	00500319-
22	6215-61-6530	GASKET (K6)	1	00500319-
23	6215-61-6510	TUBE	1	00500319-
24	6215-61-6520	PLATE	1	00500319-
25	01010-81020	BOLT	1	00500319-
26	07000-G3045	O-RING (K6)	1	00500319-
27	6219-61-7110	CONNECTOR	1	00500319-
28	07000-G2080	O-RING (K6)	1	00500319-
29	07000-G2090	O-RING (K6)	1	00500319-
30	07043-70617	PLUG	1	00500319-
31	07043-70108	PLUG	1	00500319-
32	07730-50004	VALVE	1	00500319-
33	01010-81040	BOLT	3	00500319-
34	01010-81030	BOLT	2	00500319-
35	6934-71-5860	BRACKET	1	00500319-
36	6143-11-4290	SPACER	1	00500319-
37	01010-81080	BOLT	1	00500319-
38	01643-31032	WASHER	1	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

WATER PUMP BYPASS PIPING

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6219-61-7130	TUBE,WATER INLET	1	00500319-
2	07042-A0415	PLUG	1	00500319-
3	6215-61-7361	GASKET (K6)	1	00500319-
4	01010-81230	BOLT	4	00500319-
5	6219-61-7120	TUBE,BYPASS	1	00500319-
6	6162-63-7390	GASKET (K6)	1	00500319-
7	01010-81030	BOLT	3	00500319-
8	6934-71-5860	BRACKET	1	00500319-
9	01010-81040	BOLT	1	00500319-
10	01643-31032	WASHER	1	00500319-
11	6219-61-7140	BRACKET	1	00500319-
12	01010-81025	BOLT	2	00500319-
13	6219-61-7420	TUBE,BYPASS	1	00500319-
14	6215-61-7490	GASKET (K6)	1	00500319-
15	01010-81245	BOLT	4	00500319-
16	01643-31232	WASHER	4	00500319-
17	6219-61-7410	TUBE,BYPASS	1	00500319-
18	07332-02000	COUPLING	2	00500319-
19	6219-61-7150	BRACKET	1	00500319-
20	01010-81025	BOLT	2	00500319-
21	07283-26163	CLIP	2	00500319-
22	07283-56170	SEAT	2	00500319-
23	01597-01009	NUT	4	00500319-
24	01643-31032	WASHER	4	00500319-
25	6219-61-7471	BRACKET	1	00500319-
26	07283-36163	CLIP	1	00500319-
27	07283-56170	SEAT	1	00500319-
28	01597-01009	NUT	2	00500319-
29	01643-31032	WASHER	2	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

WATER PUMP BYPASS PIPING

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6219-61-7130	TUBE,WATER INLET	1	00500319-
2	07042-A0415	PLUG	1	00500319-
3	6215-61-7361	GASKET (K6)	1	00500319-
4	01010-81230	BOLT	4	00500319-
5	6219-61-7120	TUBE,BYPASS	1	00500319-
6	6162-63-7390	GASKET (K6)	1	00500319-
7	01010-81030	BOLT	3	00500319-
8	6934-71-5860	BRACKET	1	00500319-
9	01010-81040	BOLT	1	00500319-
10	01643-31032	WASHER	1	00500319-
11	6219-61-7140	BRACKET	1	00500319-
12	01010-81025	BOLT	2	00500319-
13	6219-61-7420	TUBE,BYPASS	1	00500319-
14	6215-61-7490	GASKET (K6)	1	00500319-
15	01010-81250	BOLT	4	00500319-
16	01643-31232	WASHER	4	00500319-
17	6219-61-7410	TUBE,BYPASS	1	00500319-
18	07332-02000	COUPLING	2	00500319-
19	6219-61-7150	BRACKET	1	00500319-
20	01010-81025	BOLT	2	00500319-
21	07283-36163	CLIP	2	00500319-
22	07283-56170	SEAT	2	00500319-
23	01597-01009	NUT	4	00500319-
24	01643-31032	WASHER	4	00500319-
25	6219-61-7471	BRACKET	1	00500319-
26	07283-36163	CLIP	1	00500319-
27	07283-56170	SEAT	1	00500319-
28	01597-01009	NUT	2	00500319-
29	01643-31032	WASHER	2	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

WATER PUMP BYPASS PIPING (EXTREMELY BAD FUEL AND POOR FUEL ARRANGEMENT SPEC) (WATER DUSTY)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6219-61-7130	TUBE,WATER INLET	1	00500319-
2	07042-A0415	PLUG	1	00500319-
3	6215-61-7361	GASKET (K6)	1	00500319-
4	01010-81230	BOLT	4	00500319-
5	6219-61-7120	TUBE,BYPASS	1	00500319-
6	6162-63-7390	GASKET (K6)	1	00500319-
7	01010-81030	BOLT	3	00500319-
8	6934-71-5860	BRACKET	1	00500319-
9	01010-81040	BOLT	1	00500319-
10	01643-31032	WASHER	1	00500319-
11	6219-61-7140	BRACKET	1	00500319-
12	01010-81025	BOLT	2	00500319-
13	01643-31032	WASHER	2	00500319-
14	6219-61-7420	TUBE,BYPASS	1	00500319-
15	6215-61-7490	GASKET (K6)	1	00500319-
16	01010-81250	BOLT	4	00500319-
17	01643-31232	WASHER	4	00500319-
18	6219-61-7410	TUBE,BYPASS	1	00500319-
19	07332-02000	COUPLING	2	00500319-
20	6219-61-7151	BRACKET	1	00500319-
21	01010-81025	BOLT	2	00500319-
22	01643-31032	WASHER	2	00500319-
23	07283-36163	CLIP	2	00500319-
24	07283-56170	SEAT	2	00500319-
25	01597-01009	NUT	4	00500319-
26	01643-31032	WASHER	4	00500319-
27	6219-61-7471	BRACKET	1	00500319-
28	07283-36163	CLIP	1	00500319-
29	07283-56170	SEAT	1	00500319-
30	01597-01009	NUT	2	00500319-
31	01643-31032	WASHER	2	00500319-


SAA12V140E-3B S/N 00500319-



SAA12V140E-3B S/N 00500319-


AIR VENT PIPING AND WATER OUTLET

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6215-11-6180	TUBE,OUTLET, L.H.	1	00500319-
2	6215-11-6190	TUBE,OUTLET, R.H.	1	00500319-
3	6215-11-6831	GASKET (K1)	2	00500319-
4	01011-81030	BOLT	8	00500319-
5	07206-30710	BOLT,JOINT	10	00500319-
6	6215-11-6560	BOLT,JOINT	2	00500319-
7	01011-81010	BOLT	1	00500319-
8	01010-81030	BOLT	1	00500319-
9	6219-11-6510	TUBE,AIR VENT	2	00500319-
10	6219-11-6530	TUBE,L.H.	1	00500319-
11	6219-61-6580	TUBE,R.H.	1	00500319-
12	6219-61-6710	HOSE,R.H.	1	00500319-
13	6219-61-6730	HOSE,L.H.	1	00500319-
14	07003-01015	GASKET (K1)	26	00500319-
15	07281-00197	CLAMP	4	00500319-
16	417-823-1460	SPACER	1	00500319-



AIR VENT PIPING AND WATER OUTLET

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6215-11-6180	TUBE,OUTLET, L.H.	1	00500319-
2	6215-11-6190	TUBE,OUTLET, R.H.	1	00500319-
3	6215-11-6831	GASKET	2	00500319-
4	01011-81030	BOLT	8	00500319-
5	07206-30710	BOLT,JOINT	10	00500319-
6	6215-11-6560	BOLT,JOINT	2	00500319-
7	01011-81010	BOLT	1	00500319-
8	01010-81030	BOLT	1	00500319-
9	6219-11-6510	TUBE,AIR VENT	2	00500319-
10	6219-11-6530	TUBE,L.H.	1	00500319-
11	6219-61-6580	TUBE,R.H.	1	00500319-
12	6219-61-6710	HOSE,R.H.	1	00500319-
13	6219-61-6730	HOSE,L.H.	1	00500319-
14	07003-01015	GASKET	26	00500319-
15	07281-00197	CLAMP	4	00500319-
16	417-823-1460	SPACER	1	00500319-



AIR PIPING AND WATER OUTLET (ADDITIONAL FUEL FILTER SPEC)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6215-11-6180	TUBE,OUTLET, L.H.	1	00500319-
2	6215-11-6190	TUBE,OUTLET, R.H.	1	00500319-
3	6215-11-6831	GASKET (K1)	2	00500319-
4	01011-81030	BOLT	8	00500319-
5	07206-30710	BOLT,JOINT	10	00500319-
6	6215-11-6560	BOLT,JOINT	2	00500319-
7	01011-81015	BOLT	1	00500319-
8	01010-81035	BOLT	1	00500319-
9	6219-11-6510	TUBE,AIR VENT	2	00500319-
10	6219-11-6530	TUBE,L.H.	1	00500319-
11	6219-61-6580	TUBE,R.H.	1	00500319-
12	6219-61-6710	HOSE,R.H.	1	00500319-
13	6219-61-6730	HOSE,L.H.	1	00500319-
14	07003-01015	GASKET (K1)	26	00500319-
15	07281-00197	CLAMP	4	00500319-
16	417-823-1460	SPACER	1	00500319-


SAA12V140E-3B S/N 00500319-

SAA12V140E-3B S/N 00500319-

COOLING FAN (SUCTION TYPE)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	600-645-7450	FAN,COOLING	1	00500319-
2	01011-81215	BOLT	6	00500319-
3	01643-31232	WASHER	6	00500319-






FAN PULLEY AND DRIVE BELT

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6219-61-3710	PULLEY HARDENING	1	00500319-
2	01010-81235	BOLT	6	00500319-
3	6215-61-3690	V-BELT SET	1	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

FAN DRIVE

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	6219-61-3100	FAN HUB ASS'Y	1	00500319-
1	6215-61-3610	.SHAFT	1	00500319-
2	6215-61-3320	.CASE	1	00500319-
3	06340-06313	.BEARING,BALL	2	00500319-
4	6215-61-3330	.SPACER	1	00500319-
5	04080-06515	.HOLDER	1	00500319-
6	01010-61435	.BOLT	2	00500319-
7	07012-00110	.SEAL,OIL	1	00500319-
8	07043-00211	.PLUG	1	00500319-
9	07020-00000	.FITTING,GREASE	1	00500319-
10	6219-61-3110	.SPACER	1	00500319-
11	07029-00000	.VALVE,RELIEF	1	00500319-
12	6165-61-3271	.GASKET	1	00500319-
13	01010-81290	.BOLT	6	00500319-
14	01010-81240	BOLT	8	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

TENSION PULLEY

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	6215-61-6700	TENSION PULLEY ASS'Y	1	00500319-
1	6215-61-4740	.LEVER,TENSION	1	00500319-
2	07043-00108	.PLUG	1	00500319-
3	6215-61-4750	.PULLEY HARDENING	1	00500319-
4	06330-06308	.BEARING,BALL	2	00500319-
5	6215-61-4760	.SPACER	1	00500319-
6	04065-09030	.RING,SNAP	1	00500319-
7	6162-62-3830	.COVER	1	00500319-
8	01010-80816	.BOLT	2	00500319-
9	07012-00065	.SEAL,OIL	1	00500319-
10	6215-61-4720	.COVER	1	00500319-
11	07000-02090	.O-RING	1	00500319-
12	04065-09030	.RING,SNAP	1	00500319-
13	07029-00000	.VALVE	1	00500319-
14	07020-00000	.FITTING,GREASE	2	00500319-
15	6215-61-3480	.SPRING,TENSION	1	00500319-
	6127-61-3900	.BEARING ASS'Y	1	00500319-
16	6127-61-3910	.BEARING,NEEDLE	2	00500319-
17	6127-61-3920	.RACE,INNER	1	00500319-
18	06122-04504	.SEAL,DUST	2	00500319-
19	01435-01020	.BOLT	2	00500319-
20	6215-61-3840	.PLATE	1	00500319-
21	6219-61-3820	.SHAFT,TENSION	1	00500319-
22	01011-81260	BOLT	2	00500319-
23	01010-81245	BOLT	2	00500319-
24	01643-31232	WASHER	4	00500319-
25	6215-61-4770	YOKE	1	00500319-
26	6164-61-3770	BOLT	1	00500319-
27	6164-61-3780	WASHER	1	00500319-
28	01643-21845	WASHER	1	00500319-
29	01582-01815	NUT	1	00500319-
30	6215-61-4710	BRACKET	1	00500319-
31	01010-80816	BOLT	1	00500319-
32	6215-61-4730	WASHER	1	00500319-
33	01010-81240	BOLT	1	00500319-
34	01011-81255	BOLT	1	00500319-
35	01011-81200	BOLT	1	00500319-
36	6162-43-5350	WASHER	3	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

CORROSION RESISTOR

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	600-411-1602	RESISTOR ASS'Y,CORROSION	1	00500319-
	600-411-1610	*HEAD ASS'Y	1	00500319-
1	☆	**HEAD	1	00500319-
2	07000-01006	**O-RING	1	00500319-
3	07000-02014	**O-RING	1	00500319-
4	600-411-1250	**COVER	1	00500319-
5	600-411-1240	**HANDLE	1	00500319-
6	600-411-1260	**PLATE	1	00500319-
7	600-411-1280	**NUT	1	00500319-
8	600-411-1290	**WASHER,SPRING	1	00500319-
9	600-411-1231	**VALVE	1	00500319-
10	600-411-1670	**O-RING	2	00500319-
11	07043-00108	**PLUG	3	00500319-
12	600-411-1171	*CARTRIDGE	2	00500319-
13	01010-81035	BOLT	2	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

CORROSION RESISTOR (EXTREMELY BAD FUEL AND POOR FUEL ARRANGEMENT SPEC)(WATER DUST)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	600-411-1602	RESISTOR ASS'Y,CORROSION	1	00500319-
	600-411-1610	HEAD ASS'Y	1	00500319-
1	600-411-1620	.HEAD	1	00500319-
2	07000-01006	..O-RING	1	00500319-
3	07000-02014	..O-RING	1	00500319-
4	600-411-1250	..COVER	1	00500319-
5	600-411-1240	..HANDLE	1	00500319-
6	600-411-1260	..PLATE	1	00500319-
7	600-411-1280	..NUT	1	00500319-
8	600-411-1290	..WASHER,SPRING	1	00500319-
9	600-411-1231	..VALVE	1	00500319-
10	600-411-1670	..O-RING	1	00500319-
11	07043-00108	..PLUG	1	00500319-
12	600-411-1171	CARTRIDGE	2	00500319-
13	01010-81035	BOLT	1	00500319-
14	01010-81080	BOLT	1	00500319-
15	6219-61-8570	HOSE	1	00500319-
16	07212-50814	NIPPLE	1	00500319-
17	07206-31014	BOLT,JOINT	1	00500319-
18	07005-01412	GASKET (K2)	3	00500319-
19	6219-61-8560	TUBE	1	00500319-
20	07206-31014	BOLT,JOINT	2	00500319-
21	07005-01412	GASKET (K2)	4	00500319-
22	04434-51012	CLIP	2	00500319-
23	01010-81020	BOLT	1	00500319-
24	01643-31032	WASHER	1	00500319-
25	01011-81250	BOLT	1	00500319-
26	01643-31232	WASHER	1	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

ALTERNATOR MOUNTING (90A)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	(600-825-9330)	ALTERNATOR A.(90A)(SEE FIG.A6010-B7C1) ..	1	00500319-
2	6217-81-6840	BOLT	1	00500319-
3	01640-21323	WASHER	2	00500319-
4	6215-81-6180	BOLT	1	00500319-
5	01580-01008	NUT	1	00500319-
6	01643-01032	WASHER	1	00500319-
7	01010-81255	BOLT	1	00500319-
8	6215-81-6131	ROD,ADJUSTING	1	00500319-
9	01580-11411	NUT	2	00500319-
10	6215-81-6141	PLATE	1	00500319-
11	01580-11210	NUT	1	00500319-
12	01643-31232	WASHER	1	00500319-
13	6215-81-6150	PIN	1	00500319-
14	6130-22-3940	SPACER	1	00500319-
15	6164-11-5590	SPACER	1	00500319-
16	6261-81-6890	BRACKET	1	00500319-
17	6219-81-8170	WIRE	1	00500319-
18	01010-81020	BOLT	2	00500319-
19	01643-31032	WASHER	2	00500319-
20	6219-81-6810	BRACKET	1	00500319-
21	01010-81030	BOLT	4	00500319-
22	6219-81-6440	BRACKET	1	00500319-
23	6215-81-6190	GASKET (K2)	1	00500319-
24	6219-81-6190	BRACKET	1	00500319-
25	01010-81035	BOLT	6	00500319-
26	01643-31032	WASHER	16	00500319-
27	01010-81030	BOLT	2	00500319-
28	04020-00820	PIN	4	00500319-
29	6219-81-6840	BRACKET	1	00500319-
30	01010-81040	BOLT	2	00500319-
31	01643-31032	WASHER	2	00500319-
32	01010-81230	BOLT	2	00500319-
33	01643-31232	WASHER	3	00500319-
34	01011-81270	BOLT	1	00500319-
35	6219-81-6830	COVER	1	00500319-
36	6219-81-6870	SPACER	1	00500319-
37	6219-81-6860	BRACKET	1	00500319-
38	01010-81055	BOLT	2	00500319-
39	01643-31032	WASHER	2	00500319-
40	04120-21951	V-BELT	1	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

ALTERNATOR MOUNTING (90A) (EXTREMELY BAD FUEL AND POOR FUEL ARRANGEMENT SPEC)(WATER DUST)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	(600-825-9330)	ALTERNATOR A.(90A)(SEE FIG.A6010-B7C1) ..	1	00500319-
2	6217-81-6840	BOLT	1	00500319-
3	01640-21323	WASHER	2	00500319-
4	6215-81-6180	BOLT	1	00500319-
5	01580-01008	NUT	1	00500319-
6	01643-01032	WASHER	1	00500319-
7	01010-81255	BOLT	1	00500319-
8	6215-81-6131	ROD,ADJUSTING	1	00500319-
9	01580-11411	NUT	2	00500319-
10	6215-81-6141	PLATE	1	00500319-
11	01580-11210	NUT	1	00500319-
12	01643-31232	WASHER	1	00500319-
13	6215-81-6150	PIN	1	00500319-
14	6130-22-3940	SPACER	1	00500319-
15	6164-11-5590	SPACER	1	00500319-
16	6261-81-6890	BRACKET	1	00500319-
17	6219-81-8170	WIRE	1	00500319-
18	01010-81020	BOLT	2	00500319-
19	01643-31032	WASHER	2	00500319-
20	6219-81-6810	BRACKET	1	00500319-
21	01010-81030	BOLT	4	00500319-
22	6219-81-6660	BRACKET	1	00500319-
23	6215-81-6190	GASKET (K2)	1	00500319-
24	6219-81-6190	BRACKET	1	00500319-
25	01010-81035	BOLT	6	00500319-
26	01643-31032	WASHER	16	00500319-
27	01010-81030	BOLT	2	00500319-
28	04020-00820	PIN	4	00500319-
29	6219-81-6840	BRACKET	1	00500319-
30	01010-81040	BOLT	2	00500319-
31	01643-31032	WASHER	2	00500319-
32	01010-81230	BOLT	2	00500319-
33	01643-31232	WASHER	3	00500319-
34	01011-81270	BOLT	1	00500319-
35	6219-81-6830	COVER	1	00500319-
36	6219-81-6870	SPACER	1	00500319-
37	6219-81-6860	BRACKET	1	00500319-
38	01010-81055	BOLT	2	00500319-
39	01643-31032	WASHER	2	00500319-
40	04120-21951	V-BELT	1	00500319-


SAA12V140E-3B S/N 00500319-



SAA12V140E-3B S/N 00500319-


ALTERNATOR (90A) (INNER PARTS)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	600-825-9330	ALTERNATOR A. (90A)	1	00500319-
1	KD0-35100-0310	.ROTOR ASS'Y	1	00500319-
2	KD1-33923-0890	.COLLAR	1	00500319-
3	KD1-35923-0030	.COLLAR	1	00500319-
4	KD0-09201-0770	.BEARING,BALL	1	00500319-
5	KD0-35926-0080	.RETAINER	1	00500319-
6	KD0-35951-0080	.PACKING	2	00500319-
7	KD1-33926-0660	.RETAINER	1	00500319-
8	KD0-09201-0760	.BEARING,BALL+E2260	1	00500319-
9	KD1-33926-0790	.RETAINER	1	00500319-
10	KD0-35200-0320	.STATOR ASS'Y.....	1	00500319-
11	KD0-35300-0200	.BRACKET ASS'Y,FRONT	1	00500319-
12	KD0-0083-08802	.BOLT	4	00500319-
13	KD0-35411-0950	.PULLEY	1	00500319-
14	KD0-35421-0190	.FAN	1	00500319-
15	KD1-0335-22002	.WASHER,SPRING	1	00500319-
16	KD0-0280-22022	.NUT	1	00500319-
17	KD1-35921-0010	.WASHER	1	00500319-
18	KD0-35120-0250	.FIELD COIL ASS'Y	1	00500319-
	KD0-35700-0760	.BRACKET ASS'Y,REAR	1	00500319-
19	KD0-35710-0890	.BRACKET,REAR	1	00500319-
20	KD0-35730-0162	.RECTIFIER ASS'Y	1	00500319-
21	KD0-35943-0210	.BUSHING,INSULATE	1	00500319-
22	KD0-33902-0090	.NUT	1	00500319-
23	KD0-33902-0080	.NUT	6	00500319-
24	KD1-0020-06452	.SCREW	4	00500319-
25	KD1-0330-06012	.WASHER	5	00500319-
26	KD1-0335-06002	.WASHER,SPRING	5	00500319-
27	KD0-0080-06142	.BOLT	1	00500319-
28	KD0-35719-0180	.REGULATOR ASS'Y	1	00500319-
29	KD1-0416-04160	.KEY	1	00500319-




ALTERNATOR DRIVE

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	6215-21-3401	ACCESSORY DRIVE A.	1	00500319-
1	6215-21-3411	.HOUSING	1	00500319-
2	6215-21-3421	.SHAFT	1	00500319-
3	6215-21-3430	.HUB	1	00500319-
4	6215-21-3441	.GEAR	1	00500319-
5	6127-31-6221	.BUSHING	2	00500319-
6	6127-31-6261	.METAL,THRUST	2	00500319-
7	6215-21-3480	.SEAL,OIL	1	00500319-
8	6732-21-1960	.PLUG ASS'Y	1	00500319-
	6215-81-9510	..PLUG	1	00500319-
	6215-81-9710	..O-RING	1	00500319-
9	07000-72100	O-RING (K2)	1	00500319-
10	07000-72016	O-RING (K2)	1	00500319-
11	01010-81230	BOLT	2	00500319-
12	01010-81290	BOLT	1	00500319-
13	01011-81200	BOLT	1	00500319-
14	6219-81-6280	PULLEY▯ HARDENING	1	00500319-
15	01010-80820	BOLT	6	00500319-
16	6215-81-6950	COVER	1	00500319-



STARTING MOTOR MOUNTING (7.5KW)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	(600-813-7542)	STARTING MOTOR ASS'Y,(7.5KW) (SEE FIG. A6210-B7B1)	1	00500319-
2	6221-81-6810	GASKET (K2)	2	00500319-
3	01010-61640	BOLT	6	00500319-
4	6215-81-6310	BRACKET.....	1	00500319-
5	01010-81025	BOLT	2	00500319-
6	154-06-13130	CAP	2	00500319-
7	6215-81-6250	SPACER	2	00500319-
8	01582-01008	NUT	2	00500319-
9	01640-21016	WASHER	2	00500319-
10	01050-31020	BOLT	2	00500319-
11	08028-73020	CABLE	1	00500319-
12	07286-01903	HOSE	2	00500319-
13	08193-20010	CLIP	2	00500319-
14	01435-01016	BOLT	2	00500319-



STARTING MOTOR MOUNTING (11KW)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	600-813-9910	STARTING MOTOR ASS'Y	2	00500319-
2	6221-81-6810	GASKET (K2)	2	00500319-
3	01010-61640	BOLT	6	00500319-
4	6215-81-6310	BRACKET	1	00500319-
5	01010-81025	BOLT	2	00500319-
6	154-06-13130	CAP	2	00500319-
7	6215-81-6250	SPACER	2	00500319-
8	01582-01008	NUT	2	00500319-
9	01640-21016	WASHER	2	00500319-
10	01050-31020	BOLT	2	00500319-
11	08028-73025	CABLE	1	00500319-
12	07286-01903	HOSE	2	00500319-
13	08193-20010	CLIP	2	00500319-
14	01435-01016	BOLT	2	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

STARTING MOTOR (7.5KW) (INNER PARTS)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	600-813-7542	STARTING MOTOR ASS'Y,(7.5KW)	2	00500319-
1	KD1-09279-0090	*NUT	1	00500319-
2	KD1-0335-08002	*WASHER	4	00500319-
3	KD1-0330-08022	*WASHER	5	00500319-
4	KD1-0345-08001	*WASHER	2	00500319-
5	KD0-23303-0020	*PIN,LEVER	1	00500319-
6	KD1-23914-0020	*RING,CLIP	1	00500319-
7	KD1-23181-0020	*STOPPER,PINION	1	00500319-
8	KD1-23111-0160	*SHAFT	1	00500319-
9	KD0-23300-0260	*FRONT BRACKET A.	1	00500319-
10	KD1-23500-0160	*CLUTCH ASS'Y,OVER RUNNING	1	00500319-
11	KD1-23320-0190	*SHIFT LEVER ASS'Y	1	00500319-
12	KD1-0456-60067	*BEARING,BALL	1	00500319-
13	KD0-23600-0270	*CENTER BRACKET A.	1	00500319-
14	KD1-23611-0080	*BRACKET,CENTER	1	00500319-
15	KD1-09211-0981	*O-RING	2	00500319-
16	KD1-0456-62047	*BEARING,BALL	1	00500319-
17	KD0-0274-06202	*BOLT	3	00500319-
18	KD1-23951-0051	*PACKING	1	00500319-
19	KD1-0400-30100	*PIN,STRAIGHT	1	00500319-
20	KD0-23100-0231	*ARMATURE ASS'Y	1	00500319-
21	KD0-23200-0155	*YOKE ASS'Y	1	00500319-
22	KD0-47100-4830	*MAGNETIC SWITCH A.	1	00500319-
23	KD0-09271-3620	*NAME PLATE	1	00500319-
24	KD1-09211-1120	*O-RING	1	00500319-
25	KD0-23750-0390	*BRUSH HOLDER A.	1	00500319-
26	KD1-0505-00501	*O-RING	2	00500319-
27	KD1-47921-1000	*WASHER	2	00500319-
28	KD0-09001-4181	*BOLT	2	00500319-
29	KD1-0335-05002	*WASHER	2	00500319-
30	KD0-47761-2690	*COVER	1	00500319-
31	KD0-47761-2680	*COVER	1	00500319-
32	KD1-0456-62007	*BEARING,BALL	1	00500319-
33	KD0-23921-0230	*WASHER	1	00500319-
34	KD0-23711-0221	*BRACKET,REAR	1	00500319-
35	KD1-47921-0790	*WASHER	2	00500319-
36	KD1-0505-00601	*O-RING	2	00500319-
37	KD0-09001-4380	*.BOLT	2	00500319-
38	KD0-0020-05062	*SCREW	1	00500319-
39	KD1-0345-05001	*WASHER	1	00500319-
40	KD1-0240-08405	*BOLT	3	00500319-
41	KD1-23941-0040	*WASHER,INSULATE	1	00500319-
42	KD1-23921-0140	*WASHER	1	00500319-
43	KD1-23921-0130	*WASHER	1	00500319-
44	KD0-25000-8332	*SWITCH ASS'Y	1	00500319-

SAA12V140E-3B S/N 00500319-



SAA12V140E-3B S/N 00500319-


STARTING MOTOR (7.5KW) (INNER PARTS)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
45	KD0-47761-2670	*COVER	1	00500319-
46	KD1-0240-06305	*BOLT	6	00500319-
47	KD0-0270-06602	*BOLT	1	00500319-
48	KD1-47927-0940	*HOLDER	1	00500319-
49	KD0-09006-0660	*NUT	1	00500319-
50	KD0-09006-0670	*NUT	1	00500319-
51	KD1-09257-0050	*BAND	1	00500319-
52	KD0-09275-1430	*PLATE,CAUTION	1	00500319-

SAA12V140E-3B S/N 00500319-


SAA12V140E-3B S/N 00500319-

ELECTRICAL WIRING (1/3) (INJECTOR HARNESS GROUP)



INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6219-81-8810	WIRING HARNESS,L.H.	1	00500319-
2	6219-81-6360	BRACKET	1	00500319-
3	01010-80820	BOLT	2	00500319-
4	01643-30823	WASHER	2	00500319-
5	6219-81-8590	PLATE	1	00500319-
6	6219-11-5770	COVER	1	00500319-
7	01010-80850	BOLT	4	00500319-
8	01643-30823	WASHER	4	00500319-
9	600-051-2120	CLIP	1	00500319-
10	600-051-2100	CLIP	7	00500319-
11	600-051-2080	CLIP	1	00500319-
12	6150-81-6940	SPACER	2	00500319-
13	01010-80875	BOLT	6	00500319-
14	01643-30823	WASHER	6	00500319-
15	6219-81-8820	WIRING HARNESS,R.H.	1	00500319-
16	6219-81-8540	BRACKET	1	00500319-
17	01010-81025	BOLT	2	00500319-
18	01643-31032	WASHER	2	00500319-
19	6219-81-8580	BRACKET	1	00500319-
20	6219-11-5770	COVER	1	00500319-
21	01010-80850	BOLT	4	00500319-
22	01643-30823	WASHER	4	00500319-
23	600-051-2120	CLIP	4	00500319-
24	600-051-2100	CLIP	3	00500319-
25	600-051-2080	CLIP	3	00500319-
26	6150-81-6940	SPACER	2	00500319-
27	01010-80875	BOLT	6	00500319-
28	01643-30823	WASHER	7	00500319-
29	01010-80820	BOLT	1	00500319-
30	6218-81-8480	BAND	1	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

ELECTRICAL WIRING (2/3)(PRESSURE AND TEMPARATURE
SENSOR GROUP)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6219-81-8410	WIRING HARNESS	1	00500319-
2	6219-81-8470	BRACKET	1	00500319-
3	01010-81030	BOLT	1	00500319-
4	01643-31032	WASHER	1	00500319-
5	6218-81-8480	BAND	4	00500319-
6	6219-81-8480	BRACKET	1	00500319-
7	01010-81025	BOLT	1	00500319-
8	01643-31032	WASHER	1	00500319-
9	600-051-2060	CLIP	4	00500319-
10	600-051-2080	CLIP	2	00500319-
11	600-051-2100	CLIP	6	00500319-
12	600-051-2120	CLIP	1	00500319-
13	600-051-2140	CLIP	5	00500319-
14	600-051-2180	CLIP	3	00500319-
15	600-051-2200	CLIP	1	00500319-
16	600-051-3100	CLIP	1	00500319-
17	01010-81025	BOLT	9	00500319-
18	01643-31032	WASHER	9	00500319-
19	6212-85-2440	PLATE	6	00500319-
20	01010-81020	BOLT	13	00500319-
21	01643-31032	WASHER	13	00500319-
22	01010-81016	BOLT	1	00500319-
23	01643-31032	WASHER	1	00500319-
24	6142-22-4640	SPACER	1	00500319-
25	01010-81055	BOLT	1	00500319-
26	01643-31032	WASHER	1	00500319-
27	6130-12-1961	SPACER	1	00500319-
28	01010-80825	BOLT	1	00500319-
29	01643-30823	WASHER	1	00500319-
30	6219-81-8550	BRACKET	1	00500319-
31	6261-81-2600	SENSOR, AMBIENT AIR PRESSURE	1	00500319-
32	01252-60516	BOLT	1	00500319-
33	01010-81055	BOLT	1	00500319-
34	01643-31032	WASHER	1	00500319-
35	6219-81-8450	PLATE	1	00500319-
36	01010-81025	BOLT	1	00500319-
37	01643-01032	WASHER	1	00500319-
38	6215-71-4921	BOLT	1	00500319-
39	01580-11008	NUT	1	00500319-
40	01643-31032	WASHER	2	00500319-
41	6219-81-8440	BRACKET	1	00500319-
42	6218-81-8480	BAND	5	00500319-
43	6210-11-5820	SPACER	1	00500319-
44	01010-81050	BOLT	1	00500319-
45	01643-31032	WASHER	2	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

ELECTRICAL WIRING (2/3)(PRESSURE AND TEMPERATURE
SENSOR GROUP)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
46	6150-81-6960	SPACER	1	00500319-
47	01010-81235	BOLT	1	00500319-
48	01643-31232	WASHER	1	00500319-
49	6219-61-8470	BRACKET	1	00500319-
50	6219-61-8460	PLATE	1	00500319-
51	01010-81030	BOLT	1	00500319-
52	01643-31032	WASHER	1	00500319-
53	01436-00805	BOLT	1	00500319-
54	23S-44-14540	PLATE	1	00500319-
55	01010-81020	BOLT	1	00500319-
56	01643-01032	WASHER	1	00500319-

SAA12V140E-3B S/N 00500319-

SAA12V140E-3B S/N 00500319-



ELECTRICAL WIRING (3/3) (MAIN HARNESS GROUP)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6219-81-8421	WIRING HARNESS	1	00500319-
2	6219-81-8490	BRACKET	1	00500319-
3	01010-80820	BOLT	2	00500319-
4	01643-30823	WASHER	2	00500319-
5	6219-81-8470	BRACKET	1	00500319-
6	01010-81030	BOLT	1	00500319-
7	01643-31032	WASHER	1	00500319-
8	6218-81-8480	BAND	10	00500319-
9	6934-71-5860	BRACKET	1	00500319-
10	01010-81035	BOLT	1	00500319-
11	01643-31032	WASHER	1	00500319-
12	600-051-2060	CLIP	4	00500319-
13	600-051-2080	CLIP	2	00500319-
14	600-051-2100	CLIP	9	00500319-
15	600-051-2160	CLIP	1	00500319-
16	600-051-2120	CLIP	8	00500319-
17	600-051-2180	CLIP	2	00500319-
18	01010-81025	BOLT	6	00500319-
19	01643-31032	WASHER	6	00500319-
20	01010-81020	BOLT	13	00500319-
21	01010-81016	BOLT	7	00500319-
22	01643-31032	WASHER	19	00500319-
23	6142-22-4640	SPACER	1	00500319-
24	01010-81055	BOLT	1	00500319-
25	01643-31032	WASHER	1	00500319-
26	6218-81-8480	BAND	6	00500319-
27	6219-81-7860	BRACKET	1	00500319-
28	6152-11-4970	SPACER	2	00500319-
29	01010-81045	BOLT	2	00500319-
30	01643-31032	WASHER	2	00500319-
31	6210-11-5820	SPACER	1	00500319-
32	01010-81045	BOLT	1	00500319-
33	01643-31032	WASHER	1	00500319-
34	6219-81-7920	BRACKET	1	00500319-
35	01010-81035	BOLT	1	00500319-
36	6131-12-5920	SPACER	1	00500319-
37	01643-31032	WASHER	1	00500319-
38	6218-81-8480	BAND	5	00500319-
39	6212-85-2440	PLATE	4	00500319-
40	6219-81-7850	BRACKET	2	00500319-
41	01643-31032	WASHER	2	00500319-
42	01010-81030	BOLT	2	00500319-
43	01643-31032	WASHER	1	00500319-
44	08193-30010	CLIP	1	00500319-

SAA12V140E-3B S/N 00500319-

SAA12V140E-3B S/N 00500319-

CYLINDER HEAD GASKET KIT (FOR HD785-7)

KIT See subsequent pages for details.

K - 1 6219-K1-1300 CYLINDER HEAD GASKET KIT

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6219-K1-1300	GASKET KIT,CYLINDER HEAD	1	00500319-
	02895-77075	*O-RING,(SEE FIG.A1310)	8	00500319-
	07000-72021	*O-RING,(SEE FIG.A1530)	2	00500319-
	07000-73025	*O-RING,(SEE FIG.A1010)	12	00500319-
	07000-E2015	*O-RING,(SEE FIG.A4050)	12	00500319-
	07000-E2018	*O-RING,(SEE FIG.A4210)	12	00500319-
	07002-21423	*O-RING,(SEE FIG.A1530)	2	00500319-
	07003-01015	*GASKET,(SEE FIG.A5010)	26	00500319-
	07003-01419	*GASKET,(SEE FIG.A1530)	16	00500319-
	07003-01621	*GASKET,(SEE FIG.A1530)	2	00500319-
	07003-02026	*GASKET,(SEE FIG.A1530)	2	00500319-
	07005-01012	*GASKET,(SEE FIG.A4210, A4230)	30	00500319-
	07005-01212	*GASKET,(SEE FIG.A4230)	4	00500319-
	07005-01412	*GASKET,(SEE FIG.A1530, A1730)	14	00500319-
	07005-01612	*GASKET,(SEE FIG.A1730)	1	00500319-
	07005-02416	*GASKET,(SEE FIG.A4230)	1	00500319-
	6151-11-5751	*GASKET,(SEE FIG.A1650)	4	00500319-
	6151-51-8151	*GASKET,(SEE FIG.A1530)	2	00500319-
	6151-51-8161	*GASKET,(SEE FIG.A1530)	2	00500319-
	6162-13-6440	*SEAL,(SEE FIG.A1730)	3	00500319-
	6164-62-8241	*GASKET,(SEE FIG.A1530)	8	00500319-
	6210-11-4811	*GASKET,(SEE FIG.A1310)	12	00500319-
	6210-17-1814	*GASKET,(SEE FIG.A1010)	12	00500319-
	6211-11-4821	*GASKET,(SEE FIG.A1310)	4	00500319-
	6212-11-5940	*GASKET,(SEE FIG.A1610, A1650)	2	00500319-
	6215-11-6810	*GASKET,(SEE FIG.A1730)	1	00500319-
	6215-11-6820	*GASKET,(SEE FIG.A1730)	1	00500319-
	6215-11-6831	*GASKET,(SEE FIG.A1730)	3	00500319-
	6215-81-9710	*O-RING,(SEE FIG.A1310)	2	00500319-
	6215-81-9720	*O-RING,(SEE FIG.A1310)	11	00500319-
	6216-11-8220	*GASKET,(SEE FIG.A1310)	4	00500319-
	6217-11-8830	*GASKET,(SEE FIG.A1110)	12	00500319-
	6217-41-4540	*SEAL,(SEE FIG.A1010)	48	00500319-
	6218-11-5830	*GASKET,(SEE FIG.A1530)	2	00500319-
	6218-11-5880	*GASKET,(SEE FIG.A1510)	12	00500319-
	6219-71-1150	*GASKET,(SEE FIG.A4210)	24	00500319-
	6219-71-1160	*GASKET,(SEE FIG.A4210)	12	00500319-
	6261-71-6150	*GASKET,(SEE FIG.A4210)	12	00500319-
	6261-81-2720	*O-RING,(SEE FIG.A1310)	1	00500319-
	6261-84-9740	*O-RING,(SEE FIG.A1730)	3	00500319-
	6735-21-1930	*O-RING,(SEE FIG.A1310, A1410)	2	00500319-

Ref. A8110-A7A3

Page 030912

Ref. A8110-A7A3

Page 030912

SAA12V140E-3B S/N 00500319-

SAA12V140E-3B S/N 00500319-

CYLINDER BLOCK GASKET KIT (FOR HD785-7)

KIT See subsequent pages for details.

K - 2 6219-K2-1300 CYLINDER BLOCK GASKET KIT

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
2	6219-K2-1300	GASKET KIT,CYLINDER BLOCK	1	00500319-
	02896-11012	*O-RING,(SEE FIG.A4110, A4130)	12	00500319-
	02896-21018	*O-RING,(SEE FIG.A4710)	4	00500319-
	07000-03050	*O-RING,(SEE FIG.A2041)	1	00500319-
	07000-72012	*O-RING,(SEE FIG.A2110)	1	00500319-
	07000-72016	*O-RING,(SEE FIG.A6030)	2	00500319-
	07000-72018	*O-RING,(SEE FIG.A3110)	3	00500319-
	07000-72020	*O-RING,(SEE FIG.A4080)	2	00500319-
	07000-72060	*O-RING,(SEE FIG.A2041)	2	00500319-
	07000-72100	*O-RING,(SEE FIG.A2041, A4080, A6030)	3	00500319-
	6215-61-6630	*O-RING,(SEE FIG.A2011, A2110)	2	00500319-
	07000-73028	*O-RING,(SEE FIG.A2110, A9320)	4	00500319-
	07000-73038	*O-RING,(SEE FIG.A3110)	3	00500319-
	07000-73040	*O-RING,(SEE FIG.A3110, A3310)	4	00500319-
	07000-73042	*O-RING,(SEE FIG.A3110)	3	00500319-
	07000-73045	*O-RING,(SEE FIG.A3110)	3	00500319-
	07000-A2016	*O-RING,(SEE FIG.A3310)	8	00500319-
	07000-E2080	*O-RING,(SEE FIG.A2110)	1	00500319-
	07000-E3038	*O-RING,(SEE FIG.A2070)	1	00500319-
	07000-E3050	*O-RING,(SEE FIG.A3010)	1	00500319-
	07002-21423	*O-RING,(SEE FIG.A3310, A4110)	3	00500319-
	07002-21823	*O-RING,(SEE FIG.A4110, A4710)	8	00500319-
	07002-22034	*O-RING,(SEE FIG.A3110, A4110)	3	00500319-
	07002-23334	*O-RING,(SEE FIG.A2210)	1	00500319-
	07002-23634	*O-RING,(SEE FIG.A2110)	1	00500319-
	07005-00612	*GASKET,(SEE FIG.A4080)	2	00500319-
	07005-01012	*GASKET,(SEE FIG.A2040, A4060)	11	00500319-
	07005-01412	*GASKET,(SEE FIG.A2011 TO A5210)	43	00500319-
	07005-02216	*GASKET,(SEE FIG.A2210)	2	00500319-
	6162-23-4941	*GASKET,(SEE FIG.A2210)	1	00500319-
	6210-21-2230	*O-RING,(SEE FIG.A2010)	12	00500319-
	6210-21-2240	*O-RING,(SEE FIG.A2010)	12	00500319-
	6210-21-2270	*SEAL,(SEE FIG.A2010)	12	00500319-
	6210-61-2520	*O-RING,(SEE FIG.A3310)	4	00500319-
	6215-21-1682	*GASKET,(SEE FIG.A2011)	3	00500319-
	6215-21-1970	*GASKET,(SEE FIG.A2011)	1	00500319-
	6215-21-3811	*GASKET,(SEE FIG.A2040)	1	00500319-
	6215-21-3820	*GASKET,(SEE FIG.A2041)	1	00500319-
	6215-21-4810	*GASKET,(SEE FIG.A2210)	1	00500319-
	6215-21-5811	*GASKET,(SEE FIG.A2110)	1	00500319-
	6215-21-5820	*GASKET,(SEE FIG.A2110)	1	00500319-
	6215-21-6431	*GASKET,(SEE FIG.A2060)	12	00500319-
	6215-21-6480	*GASKET,(SEE FIG.A2011)	2	00500319-
	6215-51-1780	*GASKET,(SEE FIG.A3010)	1	00500319-

SAA12V140E-3B S/N 00500319-

KIT See subsequent pages for details.

K - 2 6219-K2-1300 CYLINDER BLOCK GASKET KIT

SAA12V140E-3B S/N 00500319-

CYLINDER BLOCK GASKET KIT (FOR HD785-7)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	6215-51-5490	*GASKET,(SEE FIG.A3110)	1	00500319-
	6215-61-2810	*GASKET,(SEE FIG.A3310)	2	00500319-
	6215-81-6190	*GASKET,(SEE FIG.A2041, A6010)	2	00500319-
	6215-81-9710	*O-RING,(SEE FIG.A2010 TO A6030)	7	00500319-
	6215-81-9720	*O-RING,(SEE FIG.A2010 TO A4060)	5	00500319-
	6219-21-4260	*SEAL, REAR,(SEE FIG.A2210)	1	00500319-
	6219-51-5610	*O-RING,(SEE FIG.A3110)	2	00500319-
	6219-51-5620	*GROMMET,(SEE FIG.A3110)	2	00500319-
	6219-71-3280	*O-RING,(SEE FIG.A4080)	1	00500319-
	6219-81-1991	*O-RING,(SEE FIG.A2011)	1	00500319-
	6221-81-6810	*GASKET,(SEE FIG.A6210)	2	00500319-
	6245-21-3121	*SEAL, FRONT,(SEE FIG.A2041)	1	00500319-
	6261-84-9740	*O-RING,(SEE FIG.A2011, A4230)	1	00500319-
	6271-81-9220	*O-RING,(SEE FIG.A2210)	1	00500319-
	ND094086-0210	*O-RING,(FOR FUEL PUMP)	2	00500319-

SAA12V140E-3B S/N 00500319-


KIT See subsequent pages for details.

K - 6 6219-K6-1200 WATER PUMP GASKET KIT

SAA12V140E-3B S/N 00500319-


WATER PUMP GASKET KIT (FOR HD785-7)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
6	6219-K6-1200	GASKET KIT,WATER PUMP	1	00500319-
	07000-02060	*O-RING,(SEE FIG.A5010)	1	00500319-
	07000-02140	*O-RING,(SEE FIG.A5010)	1	00500319-
	07000-72016	*O-RING,(SEE FIG.A5010)	1	00500319-
	07000-72100	*O-RING,(SEE FIG.A5010)	1	00500319-
	07000-G2080	*O-RING,(SEE FIG.A5010)	1	00500319-
	07000-G2090	*O-RING,(SEE FIG.A5010)	1	00500319-
	07000-G3045	*O-RING,(SEE FIG.A5010)	2	00500319-
	6162-63-1515	*SEAL, WATER,(SEE FIG.A5010)	1	00500319-
	6150-61-1510	*SEAL,(SEE FIG.A5010)	1	00500319-
	6215-61-6530	*GASKET,(SEE FIG.A5010)	1	00500319-
	6215-81-9720	*O-RING,(SEE FIG.A5010)	3	00500319-
	6162-63-7390	*GASKET,(SEE FIG.A5010)	1	00500319-
	6215-61-7361	*GASKET,(SEE FIG.A5010)	1	00500319-
	6215-61-7490	*GASKET,(SEE FIG.A5010)	1	00500319-



NAME PLATE AND CAUTION (REGULATION OF EPA2ND)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	04418-03060	SCREW	4	00500319-
2	6217-71-9331	PLATE,WARNING	2	00500319-



NAME PLATE AND CAUTION (ENGLISH)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	600-023-2140	PLATE▯ NAME,(LIMITED SUPPLY)	1	00500319-
2	04418-03060	SCREW	4	00500319-
3	6217-71-9331	PLATE,WARNING	2	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

PM-CLINIC ACCESSORY

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6219-51-8910	NIPPLE	1	00500319-
2	799-101-5160	NIPPLE,QUICK COUPLER	3	00500319-
3	6215-81-9730	O-RING	1	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

PM-CLINIC ACCESSORY

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	799-101-5230	NIPPLE	1	00500319-
2	6215-81-9720	O-RING	1	00500319-
3	799-101-5160	NIPPLE,QUICK COUPLER	2	00500319-


SAA12V140E-3B S/N 00500319-



SAA12V140E-3B S/N 00500319-

FUEL FILTER (1-5/8) (POOR FUEL ARRANGEMENT SPEC)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	6217-71-7300	HEAD ASS'Y (1-5/8)	2	00500319-
1	6217-71-7310	*HEAD (1-5/5), FUEL FILTER	1	00500319-
2	6110-73-6231	*PLUG	1	00500319-
3	07005-00812	*GASKET	1	00500319-
4	07043-70108	*PLUG	1	00500319-
5	600-319-3550	CARTRIDGE (1-5/8) , (SERVICE ONLY)	2	00500319-




FUEL PRE-FILTER (1-1/4) (POOR FUEL ARRANGEMENT SPEC)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6261-71-6430	HEAD, FILTER	2	00500319-
	600-319-4500	CARTRIDGE ASS'Y, (SERVICE ONLY)	2	00500319-
2	600-319-4540	*CARTRIDGE (1-1/4), (SERVICE ONLY)	1	00500319-
3	600-311-3220	*CAP	1	00500319-
4	600-311-3230	*SEAL	1	00500319-

JOINT (POOR ARRANGMENT SPEC)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	6156-71-5380	JOINT	1	00500319-



SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

SWITCH PLATE (POOR FUEL ARRANGEMENT SPEC)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	600-815-9490	SWITCH	1	00500319-
2	6245-81-9410	PLATE	1	00500319-

SAA12V140E-3B S/N 00500319-




SAA12V140E-3B S/N 00500319-

WATER SEPARATOR AND SENSOR (POOR FUEL ARRANGEMENT SPEC)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	600-311-9330	WATER SEPARATOR	2	00500319-
2	6560-61-7300	SENSOR ASS'Y	1	00500319-
	6560-61-7310	*SENSOR	1	00500319-
	6735-21-1930	*O-RING	1	00500319-

ENGINE RELATED PARTS


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up

ENGINE MOUNTING


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-01-81110	BRACKET	1	J20001-
2	01010-82085	BOLT	2	J20001-
3	01643-32060	WASHER	2	J20001-
4	569-01-81130	CUSHION	4	J20001-
5	561-01-81140	PLATE	2	J20001-
6	01011-81810	BOLT	4	J20001-
7	01643-31845	WASHER	4	J20001-
8	04434-53211	CLIP	2	J20001-
9	01010-81020	BOLT	2	J20001-
10	01643-31032	WASHER	2	J20001-
11	561-01-61121	BRACKET	2	J20001-
12	04020-01434	PIN	4	J20001-
13	01010-62050	BOLT	8	J20001-
14	01643-32060	WASHER	8	J20001-
15	287-01-18340	CUSHION	4	J20001-
16	561-01-61141	PLATE	2	J20001-
17	01011-81810	BOLT	4	J20001-
18	01643-31845	WASHER	4	J20001-



EXHAUST BRACKET

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-02-81140	BRACKET	1	J20001-
2	01010-81240	BOLT	4	J20001-
3	01643-31232	WASHER	4	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

ENGINE COOLING TUBE

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-03-62211	TUBE	1	J20001-
2	07000-12075	O-RING	1	J20001-
3	01010-81035	BOLT	4	J20001-
4	01643-31032	WASHER	4	J20001-
5	561-03-62230	HOSE	1	J20001-
6	07299-00080	CLAMP	4	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

DAMPER


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-01-74002	DAMPER ASS'Y	1	J20001-
	561-01-71140	.SHAFT	1	J20001-
	561-01-72661	.BODY ASS'Y	1	J20001-
2	561-01-72651	.BODY	1	J20001-
3	427-12-11223	.SPACER	1	J20001-
4	561-01-71370	.CAP	1	J20001-
5	04065-01030	.RING	1	J20001-
6	561-01-62141	.BODY	1	J20001-
7	561-01-62410	.RUBBER	4	J20001-
8	561-01-62420	.RUBBER	4	J20001-
9	01010-61240	.BOLT	12	J20001-
10	01643-31232	.WASHER	12	J20001-
11	06040-06219	.BEARING	2	J20001-
12	427-12-11262	.SPACER	1	J20001-
13	427-12-11343	.SEAL,OIL	1	J20001-
14	427-12-11353	.SEAL,OIL	1	J20001-
15	04071-00170	.RING	1	J20001-
16	01010-61250	.BOLT	16	J20001-
17	01643-31232	.WASHER	16	J20001-
18	07030-01030	.BREATHER	1	J20001-
19	561-01-62161	.FLANGE	2	J20001-
20	04020-00820	.PIN	4	J20001-
21	01010-61435	.BOLT	24	J20001-
22	01643-31445	.WASHER	24	J20001-
23	04064-09530	.RING	1	J20001-
24	561-01-71151	.COVER	1	J20001-
25	07040-11209	.PLUG	1	J20001-
26	07002-11223	.O-RING	1	J20001-
27	07040-10807	.PLUG	2	J20001-
28	07002-10823	.O-RING	2	J20001-
29	195-12-11241	.COVER	18	J20001-
30	01010-60812	.BOLT	54	J20001-
31	01641-20812	.WASHER	54	J20001-

COOLING SYSTEM




RADIATOR (1/2)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-03-84105	RADIATOR ASS'Y,AIR CONDITIONER	1	J20001-
1	561-03-81120	*SUPPORT	1	J20001-
2	561-03-81130	*SUPPORT	1	J20001-
3	561-03-81610	*BRACKET	4	J20001-
4	561-03-81660	*AFTER COOLER	2	J20001-
5	21N-03-37960	*SPACER	4	J20001-
6	198-03-22290	*ISOLATOR	4	J20001-
7	175-54-34170	*WASHER	4	J20001-
8	01010-81280	*BOLT	4	J20001-
9	01643-31232	*WASHER	4	J20001-
10	561-03-81921	*BRACKET	2	J20001-
11	01010-81230	*BOLT	6	J20001-
12	01643-31232	*WASHER	6	J20001-
13	561-03-81411	*SHROUD	1	J20001-
14	01010-81225	*BOLT	18	J20001-
15	01643-31232	*WASHER	18	J20001-
16	561-03-81110	*TANK,UPPER	1	J20001-
17	561-03-81450	*STAY,CROSS	1	J20001-
18	01010-81230	*BOLT	52	J20001-
19	01643-31232	*WASHER	52	J20001-
20	561-03-81310	*TANK	1	J20001-
21	07040-11007	*PLUG	3	J20001-
22	07002-21023	*O-RING	3	J20001-
23	569-03-81510	*CAP	2	J20001-
24	561-03-85190	*BRACKET	1	J20001-
25	01010-81230	*BOLT	4	J20001-
26	01643-31232	*WASHER	4	J20001-
27	561-03-81621	*BRACKET	1	J20001-
28	01010-81225	*BOLT	18	J20001-
29	01643-31232	*WASHER	18	J20001-
30	01010-81025	*BOLT	10	J20001-
31	01643-31032	*WASHER	10	J20001-




RADIATOR (2/2)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-03-84202	RADIATOR ASS'Y	1	J20001-
1	561-03-81631	.CORE	2	J20001-
2	561-03-81651	.CORE	1	J20001-
3	561-03-81641	.CORE	1	J20001-
4	561-03-81670	.PACKING	2	J20001-
5	561-03-81170	.PACKING	8	J20001-
6	426-03-31220	.O-RING	8	J20001-
7	01010-81025	.BOLT	16	J20001-
8	01643-31032	.WASHER	16	J20001-
9	426-03-37380	.GASKET	4	J20001-
10	561-03-81540	.TUBE	4	J20001-
11	01010-81025	.BOLT	8	J20001-
12	01643-31032	.WASHER	8	J20001-
13	561-03-81530	.HOSE	4	J20001-
14	07299-00070	.CLAMP	16	J20001-
15	561-03-85510	.BRACKET	1	J20001-
16	01010-81230	.BOLT	6	J20001-
17	01643-31232	.WASHER	6	J20001-
18	561-03-81280	.COOLER, HYDRAULIC OIL	1	J20001-
19	01010-81030	.BOLT	4	J20001-
20	01643-51032	.WASHER	4	J20001-
21	02782-10628	.ELBOW	2	J20001-
22	07002-22434	.O-RING	2	J20001-
23	02896-21018	.O-RING	2	J20001-




RADIATOR (2/2) (WITH AIR CONDITIONER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-03-84105	RADIATOR ASS'Y	1	J20001-
1	561-03-81631	.CORE	2	J20001-
2	561-03-81651	.CORE	1	J20001-
3	561-03-81641	.CORE	1	J20001-
4	561-03-81670	.PACKING	2	J20001-
5	561-03-81170	.PACKING	8	J20001-
6	426-03-31220	.O-RING	8	J20001-
7	01010-81025	.BOLT	16	J20001-
8	01643-31032	.WASHER	16	J20001-
9	426-03-37380	.GASKET	4	J20001-
10	561-03-81540	.TUBE	4	J20001-
11	01010-81025	.BOLT	8	J20001-
12	01643-31032	.WASHER	8	J20001-
13	561-03-81530	.HOSE	4	J20001-
14	07299-00070	.CLAMP	16	J20001-
15	561-03-85510	.BRACKET	1	J20001-
16	01010-81230	.BOLT	6	J20001-
17	01643-31232	.WASHER	6	J20001-
18	561-03-81280	.COOLER, HYDRAULIC OIL	1	J20001-
19	01010-81030	.BOLT	4	J20001-
20	01643-51032	.WASHER	4	J20001-
21	561-03-81242	.BRACKET	2	J20001-
22	01010-81040	.BOLT	4	J20001-
23	01643-31032	.WASHER	4	J20001-
24	56E-07-21133	.CONDENSER ASS'Y	1	J20001-
25	01010-80820	.BOLT	4	J20001-
26	01643-30823	.WASHER	4	J20001-
27	02782-10628	.ELBOW	2	J20001-
28	07002-22434	.O-RING	2	J20001-
29	02896-21018	.O-RING	2	J20001-



RADIATOR (FAN NET)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-03-84111	COVER	2	J20001-
2	561-03-84121	COVER	1	J20001-
3	561-03-84131	COVER	1	J20001-
4	01010-81230	BOLT	23	J20001-
5	01643-31232	WASHER	23	J20001-
6	561-03-84140	COVER,L.H.	1	J20001-
7	561-03-84152	COVER,R.H.	1	J20001-
8	01010-81230	BOLT	16	J20001-
9	01643-31232	WASHER	16	J20001-
10	561-03-84170	COVER	1	J20001-
11	01010-81225	BOLT	2	J20001-
12	01643-31232	WASHER	2	J20001-



RADIATOR (MOUNTING BRACKET)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-03-81712	BRACKET	2	J20001-
2	01010-81645	BOLT	8	J20001-
3	01643-31645	WASHER	8	J20001-
4	581-61-21520	CUSHION	2	J20001-
5	01010-81480	BOLT	4	J20001-
6	01596-01413	NUT	4	J20001-
7	01643-31445	WASHER	8	J20001-
8	561-03-81230	WASHER	4	J20001-
9	582-03-13180	ROD	2	J20001-
10	566-54-12212	CUSHION	8	J20001-
11	566-54-21910	BUSHING	4	J20001-
12	566-54-21920	PLATE	8	J20001-
13	01582-12016	NUT	12	J20001-
14	01643-32060	WASHER	8	J20001-
15	561-03-81721	BRACKET	2	J20001-
16	01010-81235	BOLT	4	J20001-
17	01643-31232	WASHER	4	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up


RADIATOR (BUFFLE)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-03-81812	BAFFLE	1	J20001-
2	01010-81225	BOLT	5	J20001-
3	01643-31232	WASHER	5	J20001-
4	561-03-81740	BAFFLE	1	J20001-
5	01010-81225	BOLT	5	J20001-
6	01643-31232	WASHER	5	J20001-
7	561-03-81832	BAFFLE	1	J20001-
8	01010-81220	BOLT	6	J20001-
9	01643-31232	WASHER	6	J20001-
10	561-03-81843	BAFFLE	1	J20001-
11	01010-81225	BOLT	2	J20001-
12	01643-31232	WASHER	2	J20001-
13	561-03-81853	BAFFLE	1	J20001-
14	01010-81225	BOLT	2	J20001-
15	01643-31232	WASHER	2	J20001-
16	561-03-81861	BAFFLE	1	J20001-
17	01010-81220	BOLT	3	J20001-
18	01643-31232	WASHER	3	J20001-
19	561-03-81761	BAFFLE	1	J20001-
20	01010-81016	BOLT	2	J20001-
21	01643-31032	WASHER	2	J20001-
22	561-03-81871	BAFFLE	1	J20001-
23	01010-81220	BOLT	3	J20001-
24	01643-31232	WASHER	3	J20001-
25	561-03-81751	BAFFLE	1	J20001-
26	01010-81016	BOLT	2	J20001-
27	01643-31032	WASHER	2	J20001-
28	561-03-81884	BAFFLE	1	J20001-
29	01010-81220	BOLT	3	J20001-
30	01643-31232	WASHER	3	J20001-
31	561-03-81771	BAFFLE	1	J20001-
32	01010-81016	BOLT	2	J20001-
33	01643-31032	WASHER	2	J20001-
34	561-03-81894	BAFFLE	1	J20001-
35	01010-81220	BOLT	4	J20001-
36	01643-31232	WASHER	4	J20001-
37	561-03-81761	BAFFLE	1	J20001-
38	01010-81016	BOLT	2	J20001-
39	01643-31032	WASHER	2	J20001-



COOLANT LINE (1/3)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-03-82160	TUBE	1	J20001-
2	07000-12120	O-RING	1	J20001-
3	01010-81240	BOLT	4	J20001-
4	01643-31232	WASHER	4	J20001-
5	561-03-62170	HOSE	2	J20001-
6	07299-00080	CLAMP	8	J20001-
7	195-03-13540	VALVE	1	J20001-
8	561-03-62660	TUBE	1	J20001-
9	07280-03223	CLAMP	1	J20001-
10	561-03-62230	HOSE	2	J20001-
11	07299-00080	CLAMP	8	J20001-
12	561-03-82111	TUBE	1	J20001-
13	561-03-82121	TUBE	1	J20001-
14	561-03-82620	BRACKET	2	J20001-
15	01010-81225	BOLT	4	J20001-
16	01643-31232	WASHER	4	J20001-
17	07283-36155	CLIP	4	J20001-
18	01597-01009	NUT	8	J20001-
19	01643-31032	WASHER	8	J20001-
20	04434-52511	CLIP	2	J20001-
21	07095-20318	CUSHION	2	J20001-
22	561-03-82421	HOSE	1	J20001-
23	07281-10709	CLAMP	4	J20001-
24	561-03-82340	HOSE	1	J20001-
25	07281-10709	CLAMP	4	J20001-
26	561-03-82350	TUBE	1	J20001-
27	561-03-82360	BRACKET	1	J20001-
28	01010-81225	BOLT	2	J20001-
29	01643-31232	WASHER	2	J20001-
30	07283-34949	CLIP	2	J20001-
31	01643-31032	WASHER	4	J20001-
32	01597-01009	NUT	4	J20001-
33	23S-61-12230	CLIP	3	J20001-
34	561-61-85540	GROMMET	3	J20001-
35	01010-81220	BOLT	3	J20001-
36	01643-31232	WASHER	3	J20001-



COOLANT LINE (2/3)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	09483-40316	HOSE	2	J20001-
2	07281-10197	CLAMP	8	J20001-
3	569-54-41380	PLATE	3	J20001-
4	561-61-84490	BRACKET	1	J20001-
5	07283-36155	CLIP	4	J20001-
6	01597-01009	NUT	8	J20001-
7	01643-31032	WASHER	8	J20001-
8	07095-20318	CUSHION	4	J20001-
9	04434-52511	CLIP	3	J20001-
10	04434-52512	CLIP	1	J20001-
11	01010-81220	BOLT	1	J20001-
12	01643-31232	WASHER	1	J20001-
13	561-03-62230	HOSE	1	J20001-
14	07299-00080	CLAMP	4	J20001-
15	562-03-12490	HOSE	1	J20001-
16	07299-00130	CLAMP	4	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up


COOLANT LINE (3/3)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	09483-40332	HOSE	1	J20001-
2	07281-10197	CLAMP	1	J20001-
3	07270-41511	TUBE	1	J20001-
4	07281-10197	CLAMP	1	J20001-
5	04434-51410	CLIP	10	J20001-
6	04434-51810	CLIP	2	J20001-
7	04434-52110	CLIP	3	J20001-
8	01010-81020	BOLT	12	J20001-
9	01643-31032	WASHER	12	J20001-
10	283-35-11120	ADAPTER	1	J20001-
11	07042-00415	PLUG	1	J20001-
12	561-03-81360	NIPPLE	1	J20001-
13	195-03-13241	VALVE	1	J20001-
14	561-03-82461	HOSE	1	J20001-
15	07281-10167	CLAMP	4	J20001-
16	561-03-82471	HOSE	1	J20001-
17	07281-10167	CLAMP	4	J20001-
18	561-03-81350	TUBE	1	J20001-
19	01010-81020	BOLT	2	J20001-
20	01643-31032	WASHER	2	J20001-
21	09483-40407	HOSE	1	J20001-
22	07281-00229	CLAMP	4	J20001-
23	561-03-81340	TUBE	1	J20001-
24	01010-81020	BOLT	2	J20001-
25	01643-31032	WASHER	2	J20001-
26	561-03-82480	HOSE	1	J20001-
27	07281-10167	CLAMP	4	J20001-
28	09483-40408	HOSE	1	J20001-
29	07281-00229	CLAMP	4	J20001-
30	431-03-11150	BRACKET	1	J20001-
31	01010-81020	BOLT	2	J20001-
32	01643-31032	WASHER	2	J20001-




COOLANT LINE (BYPASS TUBE)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-03-82222	TUBE	1	J20001-
2	561-03-85611	BRACKET	1	J20001-
3	01010-81025	BOLT	2	J20001-
4	01643-31032	WASHER	2	J20001-
5	07283-36155	CLIP	2	J20001-
6	01597-01009	NUT	4	J20001-
7	01643-31032	WASHER	4	J20001-



COOLANT LINE (AIR INTAKE PIPING)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-02-84711	TUBE	1	J20001-
2	566-02-6E141	HOSE	1	J20001-
3	566-02-6E151	ELBOW	1	J20001-
4	569-02-82190	CLAMP	8	J20001-
5	561-02-84760	BRACKET	1	J20001-
6	01010-81225	BOLT	4	J20001-
7	01643-31232	WASHER	4	J20001-
8	07283-31079	CLIP	2	J20001-
9	01597-01211	NUT	4	J20001-
10	01643-31232	WASHER	4	J20001-
11	561-02-84732	TUBE	1	J20001-
12	566-02-6E141	HOSE	1	J20001-
13	566-02-6E151	ELBOW	1	J20001-
14	569-02-82190	CLAMP	8	J20001-
15	561-02-84780	BRACKET	1	J20001-
16	01010-81225	BOLT	4	J20001-
17	01643-31232	WASHER	4	J20001-
18	07283-31079	CLIP	2	J20001-
19	01597-01211	NUT	4	J20001-
20	01643-31232	WASHER	4	J20001-
21	561-02-84721	TUBE	1	J20001-
22	566-02-6E141	HOSE	1	J20001-
23	566-02-6E151	ELBOW	1	J20001-
24	569-02-82190	CLAMP	8	J20001-
25	561-02-84770	BRACKET	1	J20001-
26	01010-81225	BOLT	4	J20001-
27	01643-31232	WASHER	4	J20001-
28	07283-31079	CLIP	2	J20001-
29	01597-01211	NUT	4	J20001-
30	01643-31232	WASHER	4	J20001-
31	561-02-84742	TUBE	1	J20001-
32	566-02-6E141	HOSE	1	J20001-
33	566-02-6E151	ELBOW	1	J20001-
34	569-02-82190	CLAMP	8	J20001-
35	561-02-84790	BRACKET	1	J20001-
36	01010-81225	BOLT	4	J20001-
37	01643-31232	WASHER	4	J20001-
38	07283-31079	CLIP	2	J20001-
39	01597-01211	NUT	4	J20001-
40	01643-31232	WASHER	4	J20001-



COOLANT LEVEL SENSOR

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	7861-93-4520	SENSOR	1	J20001-
2	07002-13634	O-RING	1	J20001-
3	08034-20519	BAND	1	J20001-


FUEL TANK AND RELATED PARTS



FUEL TANK (TANK) (1/2)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-84-81500	FUEL TANK ASS'Y	1	J20001-
1	561-04-81116	*FUEL TANK	1	J20001-
2	561-04-82130	*ELBOW	1	J20001-
3	561-04-82121	*VALVE	1	J20001-
4	14X-04-21650	*NIPPLE	1	J20001-
5	07002-12034	*O-RING	3	J20001-
6	22T-01-21160	*HOSE	1	J20001-
7	07281-00197	*CLAMP	1	J20001-
8	561-06-8A960	*SENSOR,LEVEL	1	J20001-
9	561-06-8A950	*TRANSMITTER	1	J20001-
10	561-04-81410	*GASKET	1	J20001-
11	01602-20619	*WASHER	4	J20001-
12	01252-70620	*BOLT	4	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up

FUEL TANK (TANK) (2/2)(WITH FUEL QUICK COUPLER AND VANDALISM PROTECTION)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-84-81500	FUEL TANK ASS'Y	1	J20001-
1	561-89-81410	*COVER	1	J20001-
2	01010-81225	*BOLT	4	J20001-
3	01643-31232	*WASHER	4	J20001-
4	19M-04-11220	*CAP	1	J20001-
5	07056-18422	*STRAINER	1	J20001-
6	428-04-11120	*COVER	2	J20001-
7	07000-15200	*O-RING	2	J20001-
8	01010-81025	*BOLT	12	J20001-
9	01643-31032	*WASHER	12	J20001-



FUEL TANK (SUCTION VALVE)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-84-81500	FUEL TANK ASS'Y	1	J20001-
1	561-04-82130	*ELBOW	1	J20001-
2	561-04-82121	*VALVE	1	J20001-
3	56B-43-17370	*NIPPLE	1	J20001-
4	07002-12034	*O-RING	3	J20001-
5	561-04-81271	*COVER	1	J20001-
6	01010-81220	*BOLT	4	J20001-
7	01643-31232	*WASHER	4	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up
FUEL TANK (WITH FUEL QUICK CHARGE VALVE)
(FOR ADDITIONAL FUEL FILTER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-84-81500	FUEL TANK ASS'Y	1	J20001-
1	21T-04-31130	*VENT ASS'Y	1	J20001-
2	07042-70312	*PLUG	1	J20001-
3	566-98-15200	*NIPPLE ASS'Y	1	J20001-
4	566-98-15300	*CAP ASS'Y	1	J20001-
5	01010-80816	*BOLT	1	J20001-
6	01643-30823	*WASHER	1	J20001-
7	561-04-83110	*COVER	1	J20001-
8	01010-81020	*BOLT	2	J20001-
9	01643-31032	*WASHER	2	J20001-



FUEL TANK (BOLT HOLE PLUG)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-84-81500 07049-01215	FUEL TANK ASS'Y *PLUG	1 8	J20001- J20001-



FUEL TANK (MOUNTING BRACKET AND COVER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-04-81120	BRACKET	1	J20001-
2	561-04-81131	BRACKET	1	J20001-
3	561-04-81160	PLATE	2	J20001-
4	01643-32060	WASHER	4	J20001-
5	01010-62090	BOLT	4	J20001-
6	561-04-81221	PLATE	1	J20001-
7	561-04-81230	BRACKET	1	J20001-
8	01643-32060	WASHER	6	J20001-
9	01580-12016	NUT	5	J20001-
10	561-46-62570	BOLT	5	J20001-
11	01010-62065	BOLT	1	J20001-
12	561-04-81241	BRACKET	1	J20001-
13	287-01-18340	CUSHION	2	J20001-
14	561-04-81251	PLATE	1	J20001-
15	01643-31845	WASHER	2	J20001-
16	01011-81800	BOLT	2	J20001-
17	01643-31645	WASHER	4	J20001-
18	01010-61645	BOLT	4	J20001-
19	561-04-81322	COVER	1	J20001-
20	01010-81020	BOLT	4	J20001-
21	01643-31032	WASHER	4	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

FUEL LINE (1/7)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	02764-00616	HOSE	1	J20001-
2	02896-11018	O-RING	2	J20001-
3	561-04-82291	BLOCK	1	J20001-
4	01010-81025	BOLT	2	J20001-
5	01643-31032	WASHER	2	J20001-
6	02764-00607	HOSE	1	J20001-
7	02896-11018	O-RING	2	J20001-
8	02762-00629	HOSE	1	J20001-
9	02896-11018	O-RING	2	J20001-
10	02762-005A7	HOSE	1	J20001-
11	02896-11015	O-RING	2	J20001-
12	561-04-82330	HOSE	1	J20001-
13	02896-11012	O-RING	2	J20001-
14	561-04-82340	HOSE	1	J20001-
15	02896-11012	O-RING	2	J20001-
16	02763-00315	HOSE	1	J20001-
17	02896-11009	O-RING	2	J20001-
18	02763-00421	HOSE	1	J20001-
19	02896-11012	O-RING	2	J20001-
20	02781-00422	UNION	1	J20001-
21	07002-12034	O-RING	1	J20001-
22	02763-00326	HOSE	1	J20001-
23	02896-11009	O-RING	2	J20001-
24	02763-00319	HOSE	1	J20001-
25	02896-11009	O-RING	2	J20001-
26	02781-00315	UNION	1	J20001-
27	07002-12034	O-RING	1	J20001-
28	02764-00522	HOSE	1	J20001-
29	02896-11015	O-RING	2	J20001-
30	02764-00509	HOSE	1	J20001-
31	02896-11015	O-RING	2	J20001-
32	561-04-82350	HOSE	1	J20001-
33	02896-11012	O-RING	2	J20001-
34	561-04-82360	HOSE	1	J20001-
35	02896-11012	O-RING	2	J20001-
36	02763-00311	HOSE	1	J20001-
37	02896-11009	O-RING	2	J20001-
38	02764-00319	HOSE	1	J20001-
39	02896-11009	O-RING	2	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

FUEL LINE (2/7)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	04434-53412	CLIP	1	J20001-
2	07095-20627	CUSHION	1	J20001-
3	01010-81220	BOLT	1	J20001-
4	01643-31232	WASHER	1	J20001-
5	04434-53412	CLIP	1	J20001-
6	07095-20627	CUSHION	1	J20001-
7	04434-52112	CLIP	1	J20001-
8	07095-20314	CUSHION	1	J20001-
9	01010-81230	BOLT	1	J20001-
10	01643-31232	WASHER	1	J20001-
11	561-04-82161	BRACKET	1	J20001-
12	07283-38973	CLIP	1	J20001-
13	01643-31232	WASHER	2	J20001-
14	01597-01211	NUT	2	J20001-
15	04434-53412	CLIP	1	J20001-
16	07095-20627	CUSHION	1	J20001-
17	04434-52112	CLIP	1	J20001-
18	07095-20314	CUSHION	1	J20001-
19	01010-81230	BOLT	1	J20001-
20	01643-31232	WASHER	1	J20001-
21	04434-52712	CLIP	1	J20001-
22	07095-20419	CUSHION	1	J20001-
23	01010-81230	BOLT	1	J20001-
24	01643-31232	WASHER	1	J20001-
25	561-04-82270	PLATE	1	J20001-
26	07283-38973	CLIP	1	J20001-
27	01643-31232	WASHER	2	J20001-
28	01597-01211	NUT	2	J20001-
29	04434-53412	CLIP	1	J20001-
30	07095-20627	CUSHION	1	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up

FUEL LINE (3/7)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	04434-53412	CLIP	2	J20001-
2	07095-20627	CUSHION	2	J20001-
3	01010-81225	BOLT	2	J20001-
4	01643-31232	WASHER	2	J20001-
5	561-04-82221	BRACKET	1	J20001-
6	01010-82040	BOLT	1	J20001-
7	01643-32060	WASHER	1	J20001-
8	04434-53412	CLIP	1	J20001-
9	07095-20627	CUSHION	1	J20001-
10	04434-52112	CLIP	1	J20001-
11	07095-20314	CUSHION	1	J20001-
12	01010-81225	BOLT	1	J20001-
13	01643-31232	WASHER	1	J20001-
14	04434-52112	CLIP	1	J20001-
15	07095-20314	CUSHION	1	J20001-
16	01010-81225	BOLT	1	J20001-
17	01643-31232	WASHER	1	J20001-
18	561-04-82211	BRACKET	1	J20001-
19	01010-81030	BOLT	1	J20001-
20	01643-31032	WASHER	1	J20001-
21	04434-53412	CLIP	1	J20001-
22	07095-20627	CUSHION	1	J20001-
23	04434-52112	CLIP	1	J20001-
24	07095-20314	CUSHION	1	J20001-
25	01010-81225	BOLT	1	J20001-
26	01643-31232	WASHER	1	J20001-
27	04434-52112	CLIP	1	J20001-
28	07095-20314	CUSHION	1	J20001-



FUEL LINE (4/7)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-04-82211	BRACKET	1	J20001-
2	01010-81030	BOLT	1	J20001-
3	01643-31032	WASHER	1	J20001-
4	04434-53412	CLIP	1	J20001-
5	07095-20627	CUSHION	1	J20001-
6	01010-81225	BOLT	1	J20001-
7	01643-31232	WASHER	1	J20001-
8	04434-52112	CLIP	1	J20001-
9	07095-20314	CUSHION	1	J20001-
10	205-30-62650	COLLAR	1	J20001-
11	04434-53412	CLIP	1	J20001-
12	07095-20627	CUSHION	1	J20001-
13	04434-53212	CLIP	1	J20001-
14	07095-20523	CUSHION	1	J20001-
15	01010-81255	BOLT	1	J20001-
16	01643-31232	WASHER	1	J20001-
17	04434-52712	CLIP	1	J20001-
18	07095-20419	CUSHION	1	J20001-
19	04434-52712	CLIP	1	J20001-
20	07095-20419	CUSHION	1	J20001-
21	01010-81225	BOLT	1	J20001-
22	01643-31232	WASHER	1	J20001-
23	415-03-11210	SPACER	1	J20001-
24	04434-52712	CLIP	1	J20001-
25	07095-20419	CUSHION	1	J20001-
26	04434-52112	CLIP	1	J20001-
27	07095-20314	CUSHION	1	J20001-
28	01010-81060	BOLT	1	J20001-
29	01643-31032	WASHER	1	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

FUEL LINE (5/7)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	421-62-11940	PLATE	1	J20001-
2	01010-81230	BOLT	1	J20001-
3	01643-31232	WASHER	1	J20001-
4	04434-52112	CLIP	1	J20001-
5	07095-20314	CUSHION	1	J20001-
6	04434-52112	CLIP	1	J20001-
7	07095-20314	CUSHION	1	J20001-
8	01010-81025	BOLT	1	J20001-
9	01643-31032	WASHER	1	J20001-
10	04434-52712	CLIP	1	J20001-
11	07095-20419	CUSHION	1	J20001-
11A	04434-52112	CLIP	1	J20001-
11B	07095-20314	CUSHION	1	J20001-
12	01010-81225	BOLT	1	J20001-
13	01643-31232	WASHER	1	J20001-
14	04434-52712	CLIP	1	J20001-
15	07095-20419	CUSHION	1	J20001-
16	01010-81230	BOLT	1	J20001-
17	01643-31232	WASHER	1	J20001-
18	04434-52712	CLIP	1	J20001-
19	07095-20419	CUSHION	1	J20001-
20	04434-52112	CLIP	1	J20001-
21	07095-20314	CUSHION	1	J20001-
22	01010-81230	BOLT	1	J20001-
23	01643-31232	WASHER	1	J20001-
24	04434-53212	CLIP	1	J20001-
25	07095-20523	CUSHION	1	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up


FUEL LINE (6/7)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-04-82280	BRACKET	1	J20001-
2	07283-36155	CLIP	1	J20001-
3	01643-31032	WASHER	2	J20001-
4	01597-01009	NUT	2	J20001-
5	04434-53212	CLIP	1	J20001-
6	07095-20523	CUSHION	1	J20001-
7	01010-81230	BOLT	1	J20001-
8	01643-31232	WASHER	1	J20001-
9	561-04-82280	BRACKET	1	J20001-
10	07283-36155	CLIP	1	J20001-
11	01643-31032	WASHER	2	J20001-
12	01597-01009	NUT	2	J20001-
13	04434-53212	CLIP	1	J20001-
14	07095-20523	CUSHION	1	J20001-
15	01010-81230	BOLT	1	J20001-
16	01643-31232	WASHER	1	J20001-
17	04434-53212	CLIP	1	J20001-
18	07095-20523	CUSHION	1	J20001-
19	01010-81225	BOLT	1	J20001-
20	01643-31232	WASHER	1	J20001-
21	144-947-3490	SPACER	1	J20001-
22	04434-53212	CLIP	1	J20001-
23	07095-20523	CUSHION	1	J20001-
24	04434-53212	CLIP	1	J20001-
25	07095-20523	CUSHION	1	J20001-
26	01010-81245	BOLT	1	J20001-
27	01643-31232	WASHER	1	J20001-
28	428-64-15110	COLLAR	1	J20001-
29	04434-53211	CLIP	1	J20001-
30	07095-20523	CUSHION	1	J20001-
31	04434-52110	CLIP	1	J20001-
32	07095-20314	CUSHION	1	J20001-
33	01010-81045	BOLT	1	J20001-
34	01643-31032	WASHER	1	J20001-
35	144-947-3490	SPACER	1	J20001-
36	04434-52712	CLIP	2	J20001-
37	07095-20419	CUSHION	2	J20001-
38	01010-81245	BOLT	1	J20001-
39	01643-31232	WASHER	1	J20001-



FUEL LINE (7/7)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-04-82251	PLATE	1	J20001-
2	07283-36155	CLIP	1	J20001-
3	01643-31032	WASHER	2	J20001-
4	01597-01009	NUT	2	J20001-
5	07094-30315	CLAMP	2	J20001-
6	07095-00314	CUSHION	2	J20001-
7	01011-81205	BOLT	1	J20001-
8	01643-31232	WASHER	1	J20001-
9	04434-52110	CLIP	1	J20001-
10	07095-20314	CUSHION	1	J20001-
11	01010-81020	BOLT	1	J20001-
12	01643-31032	WASHER	1	J20001-



FUEL LINE (TANK TO BLOCK) (FOR ADDITIONAL FUEL FILTER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	02764-00616	HOSE	1	J20001-
2	02896-11018	O-RING	2	J20001-
3	561-04-82161	BRACKET	1	J20001-
4	07283-38973	CLIP	1	J20001-
5	01643-31232	WASHER	2	J20001-
6	01597-01211	NUT	2	J20001-
7	561-04-82270	PLATE	1	J20001-
8	07283-38973	CLIP	1	J20001-
9	01643-31232	WASHER	2	J20001-
10	01597-01211	NUT	2	J20001-
11	04434-53412	CLIP	4	J20001-
12	07095-20627	CUSHION	4	J20001-
13	01010-81220	BOLT	1	J20001-
14	01643-31232	WASHER	1	J20001-
15	01010-81230	BOLT	2	J20001-
16	01643-31232	WASHER	2	J20001-
17	02781-00315	UNION	1	J20001-
18	07002-12034	O-RING	1	J20001-
19	02763-00319	HOSE	1	J20001-
20	02896-11009	O-RING	2	J20001-
21	04434-52112	CLIP	4	J20001-
22	07095-20314	CUSHION	4	J20001-
23	01010-81230	BOLT	1	J20001-
24	01643-31232	WASHER	1	J20001-
25	01010-81225	BOLT	1	J20001-
26	01643-31232	WASHER	1	J20001-
27	02781-00422	UNION	1	J20001-
28	07002-12034	O-RING	1	J20001-
29	02763-00421	HOSE	1	J20001-
30	02896-11012	O-RING	2	J20001-
31	04434-52712	CLIP	4	J20001-
32	07095-20419	CUSHION	4	J20001-
33	01010-81230	BOLT	2	J20001-
34	01643-31232	WASHER	2	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up

FUEL LINE (BLOCK) (FOR ADDITIONAL FUEL FILTER)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-84-81480	BLOCK ASS'Y	1	J20001-
1	561-04-82264	.BLOCK	1	J20001-
2	02782-10628	.ELBOW	1	J20001-
3	★	.O-RING	1	J20001-
4	02783-10628	.ELBOW	1	J20001-
5	★	.O-RING	1	J20001-
6	02781-00628	.UNION	1	J20001-
7	★	.O-RING	1	J20001-
8	02781-00422	.UNION	1	J20001-
9	07002-12034	.O-RING	1	J20001-
10	02781-00313	.UNION	5	J20001-
11	07002-11823	.O-RING	5	J20001-
12	(02782-10313)	ELBOW	1	J20001-
13	01010-81025	BOLT	2	J20001-
14	01643-31032	WASHER	2	J20001-



HD785-7 S/N J20001 and up
FUEL LINE (BLOCK TO COOLING PLATE) (FOR ADDITIONAL
FUEL FILTER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	02762-00607	HOSE	1	J20001-
2	02896-11018	O-RING	2	J20001-
3	04434-53412	CLIP	1	J20001-
4	07095-20627	CUSHION	1	J20001-
5	01010-81225	BOLT	1	J20001-
6	01643-31232	WASHER	1	J20001-
7	561-84-81450	HOSE	1	J20001-
8	02896-11018	O-RING	2	J20001-
9	04434-53412	CLIP	1	J20001-
10	04434-53411	CLIP	1	J20001-
11	07095-20627	CUSHION	2	J20001-
12	01010-81025	BOLT	1	J20001-
13	01643-31032	WASHER	1	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up
FUEL LINE (COOLING PLATE TO WATER SEPARATOR)
(R.H.) (FOR ADDITIONAL FUEL FILTER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	02762-00619	HOSE	1	J20001-
2	02896-11018	O-RING	2	J20001-
3	04434-53412	CLIP	1	J20001-
4	07095-20627	CUSHION	1	J20001-
5	01010-81225	BOLT	1	J20001-
6	01643-31232	WASHER	1	J20001-
7	561-04-82280	BRACKET	1	J20001-
8	07283-36155	CLIP	1	J20001-
9	01643-31032	WASHER	2	J20001-
10	01597-01009	NUT	2	J20001-
11	04434-53412	CLIP	1	J20001-
12	07095-20627	CUSHION	1	J20001-
13	01010-81230	BOLT	1	J20001-
14	01643-31232	WASHER	1	J20001-
15	561-04-82251	PLATE	1	J20001-
16	07283-36155	CLIP	1	J20001-
17	01643-31032	WASHER	2	J20001-
18	01597-01009	NUT	2	J20001-
19	0443-53412	CLIP	1	J20001-
20	07095-20627	CUSHION	1	J20001-
21	01010-81220	BOLT	1	J20001-
22	01643-31232	WASHER	1	J20001-
23	04434-53412	CLIP	1	J20001-
24	07095-20627	CUSHION	1	J20001-
25	01010-81225	BOLT	1	J20001-
26	01643-31232	WASHER	1	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up
FUEL LINE (COOLING PLATE TO WATER SEPARATOR)
(L.H.) (FOR ADDITIONAL FUEL FILTER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	02762-00623	HOSE	1	J20001-
2	02896-11018	O-RING	2	J20001-
3	04434-53412	CLIP	1	J20001-
4	07095-20627	CUSHION	1	J20001-
5	01010-81225	BOLT	1	J20001-
6	01643-31232	WASHER	1	J20001-
7	561-04-82221	BRACKET	1	J20001-
8	01010-82040	BOLT	1	J20001-
9	01643-32060	WASHER	1	J20001-
10	04434-53412	CLIP	1	J20001-
11	07095-20627	CUSHION	1	J20001-
12	01010-81225	BOLT	1	J20001-
13	01643-31232	WASHER	1	J20001-
14	561-04-82211	BRACKET	1	J20001-
15	01010-81025	BOLT	1	J20001-
16	01643-31032	WASHER	1	J20001-
17	04434-53412	CLIP	1	J20001-
18	07095-20627	CUSHION	1	J20001-
19	01010-81225	BOLT	1	J20001-
20	01643-31232	WASHER	1	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up
FUEL LINE (WATER SEPARATOR) (R.H.) (FOR ADDITIONAL
FUEL FILTER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-84-81410	BRACKET	1	J20001-
2	01010-81225	BOLT	4	J20001-
3	01643-31232	WASHER	4	J20001-
4	600-311-933A	WATER SEPARATOR	1	J20001-
5	01010-81030	BOLT	4	J20001-
6	01643-31032	WASHER	4	J20001-
7	02782-10628	ELBOW	2	J20001-
8	07002-12434	O-RING	2	J20001-
9	561-84-81580	TUBE	1	J20001-
10	02896-11018	O-RING	1	J20001-
11	561-84-81430	BRACKET	1	J20001-
12	01010-81230	BOLT	2	J20001-
13	01643-31232	WASHER	2	J20001-
14	07283-32738	CLIP	1	J20001-
15	01643-31032	WASHER	2	J20001-
16	01597-01009	NUT	2	J20001-
17	07270-41008	TUBE	2	J20001-
18	07285-00130	CLIP	2	J20001-
19	154-916-3550	BRACKET	2	J20001-
20	04434-52112	CLIP	4	J20001-
21	01010-81230	BOLT	2	J20001-
22	01643-31232	WASHER	2	J20001-
23	01010-81225	BOLT	1	J20001-
24	01643-31232	WASHER	1	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up
FUEL LINE (WATER SEPARATOR) (L.H.)
(FOR ADDITIONAL FUEL FILTER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-84-81420	BRACKET	1	J20001-
2	01010-81225	BOLT	4	J20001-
3	01643-31232	WASHER	4	J20001-
4	600-311-933A	WATER SEPARATOR	1	J20001-
5	01010-81030	BOLT	4	J20001-
6	01643-31032	WASHER	4	J20001-
7	02782-10628	ELBOW	2	J20001-
8	07002-12434	O-RING	2	J20001-
9	561-84-81490	TUBE	1	J20001-
10	02896-11018	O-RING	1	J20001-
11	561-84-81440	BRACKET	1	J20001-
12	01010-81230	BOLT	2	J20001-
13	01643-31232	WASHER	2	J20001-
14	07283-32738	CLIP	1	J20001-
15	01643-31032	WASHER	2	J20001-
16	01597-01009	NUT	2	J20001-
17	07270-41009	TUBE	2	J20001-
18	07285-00130	CLIP	2	J20001-
19	56D-61-11710	PLATE	1	J20001-
20	07283-33442	CLIP	1	J20001-
21	04434-52110	CLIP	2	J20001-
22	01643-31032	WASHER	2	J20001-
23	01597-01009	NUT	2	J20001-
24	421-62-11940	PLATE	1	J20001-
25	01010-81025	BOLT	1	J20001-
26	01643-31032	WASHER	1	J20001-
27	04434-52110	CLIP	2	J20001-
28	01010-81025	BOLT	1	J20001-
29	01643-31032	WASHER	1	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up
FUEL LINE (WATER SEPARATOR TO FILTER)
(L.H.) (FOR ADDITIONAL FUEL FILTER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	02762-00612	HOSE	1	J20001-
2	02896-11018	O-RING	2	J20001-
3	07094-30620	CLAMP	2	J20001-
4	07095-00628	CUSHION	2	J20001-
5	01010-81270	BOLT	1	J20001-
6	01643-31232	WASHER	1	J20001-
7	01643-31232	WASHER	1	J20001-
8	01580-11210	NUT	1	J20001-
9	04434-53412	CLIP	1	J20001-
10	07095-20627	CUSHION	1	J20001-
11	01010-81225	BOLT	1	J20001-
12	01643-31232	WASHER	1	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up
FUEL LINE (WATER SEPARATOR TO FILTER) (R.H.)
(FOR ADDITIONAL FUEL FILTER)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	02762-00610	HOSE	1	J20001-
2	02896-11018	O-RING	2	J20001-
3	281-01-17790	SEAT	1	J20001-
4	04434-53412	CLIP	1	J20001-
5	07095-20627	CUSHION	1	J20001-
6	01010-81290	BOLT	1	J20001-
7	01643-31232	WASHER	1	J20001-

HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up
FUEL LINE (FILTER TO ENGINE) (R.H.) (FOR ADDITIONAL FUEL FILTER)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	02764-005A9	HOSE	1	J20001-
2	02896-11015	O-RING	2	J20001-
3	04434-53212	CLIP	1	J20001-
4	07095-20523	CUSHION	1	J20001-
5	01010-81225	BOLT	1	J20001-
6	01643-31232	WASHER	1	J20001-
7	02764-00408	HOSE	1	J20001-
8	02896-11012	O-RING	2	J20001-
9	04434-52712	CLIP	1	J20001-
10	07095-20419	CUSHION	1	J20001-
11	01010-81225	BOLT	1	J20001-
12	01643-31232	WASHER	1	J20001-
13	02764-004A8	HOSE	1	J20001-
14	02896-11012	O-RING	2	J20001-
15	04434-52712	CLIP	2	J20001-
16	07095-20419	CUSHION	2	J20001-



HD785-7 S/N J20001 and up
FUEL LINE (FILTER TO ENGINE) (L.H.) (FOR ADDITIONAL FUEL
FILTER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	02764-00509	HOSE	1	J20001-
2	02896-11015	O-RING	2	J20001-
3	04434-53212	CLIP	1	J20001-
4	07095-20523	CUSHION	1	J20001-
5	02764-00410	HOSE	1	J20001-
6	02896-11012	O-RING	2	J20001-
7	04434-52712	CLIP	1	J20001-
8	07095-20419	CUSHION	1	J20001-
9	01010-81225	BOLT	1	J20001-
10	01643-31232	WASHER	1	J20001-
11	02764-004A9	HOSE	1	J20001-
12	02896-11012	O-RING	2	J20001-
13	04434-52712	CLIP	1	J20001-
14	07095-20419	CUSHION	1	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up
FUEL LINE (BLOCK TO ENGINE) (R.H.) (FOR ADDITIONAL FUEL
FILTER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	02764-00319	HOSE	1	J20001-
2	02896-11009	O-RING	2	J20001-
3	07094-30315	CLAMP	2	J20001-
4	07095-00314	CUSHION	1	J20001-
5	01011-81205	BOLT	1	J20001-
6	01643-31232	WASHER	1	J20001-
7	04434-52110	CLIP	3	J20001-
8	07095-20314	CUSHION	3	J20001-
9	01010-81020	BOLT	2	J20001-
10	01643-31032	WASHER	2	J20001-
11	02764-00308	HOSE	1	J20001-
12	02896-11009	O-RING	2	J20001-
13	07095-00314	CUSHION	1	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up
FUEL LINE (BLOCK TO ENGINE) (L.H.) (FOR ADDITIONAL FUEL FILTER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	02764-00326	HOSE	1	J20001-
2	02896-11009	O-RING	2	J20001-
3	421-62-11940	PLATE	1	J20001-
4	01010-81230	BOLT	1	J20001-
5	01643-31232	WASHER	1	J20001-
6	561-04-82211	BRACKET	1	J20001-
7	01010-81030	BOLT	1	J20001-
8	01643-31032	WASHER	1	J20001-
9	04434-52112	CLIP	5	J20001-
10	07095-20314	CUSHION	5	J20001-
11	01010-81025	BOLT	1	J20001-
12	01643-31032	WASHER	1	J20001-
13	01010-81225	BOLT	2	J20001-
14	01643-31232	WASHER	2	J20001-
15	561-84-81470	HOSE	1	J20001-
16	02896-11009	O-RING	2	J20001-
17	04434-52112	CLIP	2	J20001-
18	04434-52110	CLIP	1	J20001-
19	07095-20314	CUSHION	3	J20001-


ELECTRICAL SYSTEM



BATTERY BOX (BATTERY)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	08000-32220	BATTERY, WET	4	J20001-
	08000-00000	.TERMINAL, (+)	4	J20001-
	08000-00001	.TERMINAL, (-)	4	J20001-
2	08028-65020	CABLE	2	J20001-
3	08028-65080	CABLE	1	J20001-
4	08028-45080	CABLE	1	J20001-
5	08028-65060	CABLE	1	J20001-
6	08028-45085	CABLE	1	J20001-
7	56B-06-11210	CAP	2	J20001-
8	56B-06-11220	CAP	4	J20001-
9	424-09-12530	BOOT	2	J20001-
10	04434-52511	CLIP	6	J20001-
11	566-06-41290	INSULATOR	6	J20001-
12	01010-81016	BOLT	6	J20001-
13	01643-31032	WASHER	6	J20001-
14	561-06-83264	WIRING HARNESS	1	J20001-
15	04434-50810	CLIP	4	J20001-
16	08193-21012	CLIP	1	J20001-
17	01010-81016	BOLT	7	J20001-
18	01643-31032	WASHER	7	J20001-
19	08034-20834	BAND	1	J20001-
20	04434-51010	CLIP	1	J20001-
21	04434-51210	CLIP	2	J20001-
22	431-03-11150	BRACKET	1	J20001-
23	01010-81025	BOLT	1	J20001-
24	01643-31032	WASHER	1	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

BATTERY BOX (BATTERY) (LARGE CAPACITY)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	08000-02221	BATTERY, WET	4	J20001-
	08000-00000	.TERMINAL, (+)	4	J20001-
	08000-00001	.TERMINAL, (-)	4	J20001-
2	08028-65020	CABLE	2	J20001-
3	08028-65080	CABLE	1	J20001-
4	08028-45080	CABLE	1	J20001-
5	08028-65060	CABLE	1	J20001-
6	08028-45085	CABLE	1	J20001-
7	56B-06-11210	CAP	2	J20001-
8	56B-06-11220	CAP	4	J20001-
9	424-09-12530	BOOT	2	J20001-
10	04434-52511	CLIP	6	J20001-
11	566-06-41290	INSULATOR	6	J20001-
12	01010-81016	BOLT	6	J20001-
13	01643-31032	WASHER	6	J20001-
14	561-06-83264	WIRING HARNESS	1	J20001-
15	04434-50810	CLIP	4	J20001-
16	08193-21012	CLIP	1	J20001-
17	01010-81016	BOLT	7	J20001-
18	01643-31032	WASHER	7	J20001-
19	08034-20834	BAND	1	J20001-
20	04434-51010	CLIP	1	J20001-
21	04434-51210	CLIP	2	J20001-
22	431-03-11150	BRACKET	1	J20001-
23	01010-81025	BOLT	1	J20001-
24	01643-31032	WASHER	1	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up

BATTERY BOX (STAY)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	281-06-14170	CLAMP	2	J20001-
2	281-06-14161	ROD	4	J20001-
3	01643-31032	WASHER	4	J20001-
4	01580-11008	NUT	8	J20001-
5	421-06-11221	HOLDER	4	J20001-
6	565-56-12440	ROD	8	J20001-
7	01643-31032	WASHER	8	J20001-
8	01580-11008	NUT	16	J20001-



BATTERY BOX (BOX)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-54-81913	BOX	1	J20001-
2	01010-81225	BOLT	6	J20001-
3	01643-31232	WASHER	6	J20001-
4	561-54-81660	COVER	1	J20001-
5	01010-81225	BOLT	4	J20001-
6	01643-31232	WASHER	4	J20001-
7	09450-00000	CATCH	2	J20001-
8	09450-00002	PIN	2	J20001-
9	04050-11610	PIN	2	J20001-
10	561-54-81481	ANGLE	2	J20001-
11	01010-81225	BOLT	4	J20001-
12	01643-31232	WASHER	4	J20001-
13	569-54-61480	ROD	1	J20001-
14	04050-13020	PIN	2	J20001-
15	01643-31032	WASHER	2	J20001-
16	08007-23549	CUSHION	8	J20001-
17	08037-02512	GROMMET	2	J20001-
18	08037-03614	GROMMET	4	J20001-
19	566-54-8A940	SHEET	2	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up


BATTERY BOX (RELAY)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	08088-30000	SWITCH	2	J20001-
2	01010-80825	BOLT	4	J20001-
3	01643-30823	WASHER	4	J20001-
4	08028-65011	WIRE, 110MM	2	J20001-
5	08038-00035	CAP	4	J20001-
6	08038-00519	CAP	4	J20001-
7	561-06-61510	RELAY	2	J20001-
8	01010-80825	BOLT	4	J20001-
9	01643-30823	WASHER	4	J20001-
10	08028-65011	WIRE, 110MM	2	J20001-
11	08038-00035	CAP	4	J20001-
12	08038-00519	CAP	4	J20001-
13	08028-65175	CABLE	1	J20001-
14	04434-52511	CLIP	5	J20001-
15	566-06-41290	INSULATOR	5	J20001-
16	01010-81016	BOLT	3	J20001-
17	01643-31032	WASHER	3	J20001-



BATTERY BOX (CIRCUIT BREAKER)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-06-82680	BRACKET	1	J20001-
2	01010-81020	BOLT	2	J20001-
3	01643-31032	WASHER	2	J20001-
4	561-06-81520	HOLDER	2	J20001-
5	561-06-81610	FUSE	2	J20001-
6	01023-70614	SCREW	4	J20001-
7	561-06-81570	CABLE	1	J20001-
8	569-86-6J690	CABLE	1	J20001-
9	561-06-82691	BRACKET	1	J20001-
10	01010-81020	BOLT	2	J20001-
11	01643-31032	WASHER	2	J20001-
12	198-06-62830	CIRCUIT BREAKER	1	J20001-
13	421-06-11440	BREAKER	2	J20001-
14	21T-06-33190	BREAKER	1	J20001-
15	01010-80616	BOLT	8	J20001-
16	01643-30623	WASHER	8	J20001-
17	561-06-81550	CABLE	1	J20001-
18	561-06-81560	CABLE	1	J20001-
19	08028-67015	CABLE	1	J20001-
20	515-06-11810	CABLE	1	J20001-
21	08038-02027	CAP	8	J20001-
22	425-06-11310	FUSE ASS'Y	1	J20001-
23	01023-20616	SCREW	1	J20001-



BATTERY BOX (CIRCUIT BREAKER) (ADDITIONAL FILTER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-06-85680	BRACKET	1	J20001-
2	01010-81020	BOLT	2	J20001-
3	01643-31032	WASHER	2	J20001-
4	561-06-81520	HOLDER	2	J20001-
5	561-06-81610	FUSE	2	J20001-
6	01023-70614	SCREW	4	J20001-
7	561-06-81570	CABLE	1	J20001-
8	569-86-6J690	CABLE	1	J20001-
9	561-06-82691	BRACKET	1	J20001-
10	01010-81020	BOLT	2	J20001-
11	01643-31032	WASHER	2	J20001-
12	198-06-62830	CIRCUIT BREAKER	1	J20001-
13	421-06-11440	BREAKER	2	J20001-
14	21T-06-33190	BREAKER	1	J20001-
15	01010-80616	BOLT	8	J20001-
16	01643-30623	WASHER	8	J20001-
17	561-06-81550	CABLE	1	J20001-
18	561-06-81560	CABLE	1	J20001-
19	08028-67015	CABLE	1	J20001-
20	515-06-11810	CABLE	1	J20001-
21	08038-02027	CAP	8	J20001-
22	425-06-11310	FUSE ASS'Y	1	J20001-
23	561-06-85710	FUSE ASS'Y	1	J20001-
24	01023-20616	SCREW	2	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up

REAR HOOD


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-54-86552	HOOD	1	J20001-
2	01010-81225	BOLT	4	J20001-
3	01643-31232	WASHER	4	J20001-
4	09415-03614	CAP	4	J20001-
5	09450-00000	CATCH	2	J20001-
6	09450-00002	PIN	2	J20001-
7	04050-11610	PIN	2	J20001-
8	561-54-86561	BRACKET	2	J20001-
9	561-54-86770	PLATE	2	J20001-
10	01010-81020	BOLT	4	J20001-
11	01643-31032	WASHER	4	J20001-
12	561-89-86162	BRACKET	1	J20001-
13	561-89-82220	BRACKET	1	J20001-
14	561-89-82230	PLATE	1	J20001-
15	01010-81230	BOLT	8	J20001-
16	01643-31232	WASHER	8	J20001-



REAR HOOD (FOR EXHAUST BRAKE)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-54-87160	HOOD	1	J20001-
2	01010-81225	BOLT	4	J20001-
3	01643-31232	WASHER	4	J20001-
4	09415-03614	CAP	4	J20001-
5	09450-00000	CATCH	2	J20001-
6	09450-00002	PIN	2	J20001-
7	04050-11610	PIN	2	J20001-
8	561-54-87140	BRACKET	2	J20001-
9	561-54-86770	PLATE	2	J20001-
10	01010-81020	BOLT	4	J20001-
11	01643-31032	WASHER	4	J20001-
12	561-89-86162	BRACKET	1	J20001-
13	561-89-82220	BRACKET	1	J20001-
14	561-89-82230	PLATE	1	J20001-
15	01010-81230	BOLT	8	J20001-
16	01643-31232	WASHER	8	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

BRAKE LINE (VALVE BOX)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-43-83821	COVER	1	J20001-
2	01010-81020	BOLT	4	J20001-
3	01643-31032	WASHER	4	J20001-
4	561-43-83841	BRACKET	1	J20001-
5	01010-81020	BOLT	4	J20001-
6	01643-31032	WASHER	4	J20001-
7	56B-43-17430	VALVE ASS'Y	1	J20001-
8	01010-80870	BOLT	2	J20001-
9	01643-30823	WASHER	2	J20001-
10	569-43-83651	CONNECTOR	1	J20001-
11	07002-22034	O-RING	2	J20001-
12	02782-10516	ELBOW	2	J20001-
13	07002-22034	O-RING	2	J20001-
14	02896-21015	O-RING	2	J20001-
15	569-43-83720	BLOCK	1	J20001-
16	01010-81070	BOLT	2	J20001-
17	01643-31032	WASHER	2	J20001-
18	07043-00312	PLUG	1	J20001-
19	02781-00422	UNION	2	J20001-
20	07002-22034	O-RING	2	J20001-
21	02896-21012	O-RING	2	J20001-
22	561-43-83880	BRACKET	1	J20001-
23	01010-81025	BOLT	2	J20001-
24	01643-31032	WASHER	2	J20001-
25	569-43-83811	BLOCK	1	J20001-
26	01010-81070	BOLT	2	J20001-
27	01643-31032	WASHER	2	J20001-
28	566-32-11430	BLEEDER	1	J20001-
29	232-32-11350	CAP	1	J20001-
30	02781-00422	UNION	2	J20001-
31	07002-22034	O-RING	2	J20001-
32	02896-21012	O-RING	2	J20001-
33	02782-10516	ELBOW	1	J20001-
34	07002-22034	O-RING	1	J20001-
35	02896-21015	O-RING	1	J20001-
36	561-43-83831	COVER	1	J20001-
37	01010-81020	BOLT	4	J20001-
38	01643-31032	WASHER	4	J20001-
39	561-43-83890	BRACKET	1	J20001-
40	01010-81230	BOLT	4	J20001-
41	01643-31232	WASHER	4	J20001-
42	07040-12012	PLUG	1	J20001-
43	07002-22034	O-RING	1	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up

BRAKE LINE (UNDER HOOD)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-43-83411	TUBE	1	J20001-
2	02896-21018	O-RING	2	J20001-
3	561-43-83422	TUBE	1	J20001-
4	02896-21012	O-RING	2	J20001-
5	561-43-83430	TUBE	1	J20001-
6	02896-21012	O-RING	1	J20001-
7	561-43-86440	TUBE	1	J20001-
8	02896-21015	O-RING	1	J20001-
9	561-43-83452	TUBE	1	J20001-
10	207-62-64740	O-RING	2	J20001-
11	561-43-83460	TUBE	1	J20001-
12	02896-21015	O-RING	1	J20001-
13	561-43-83470	TUBE	1	J20001-
14	02896-21015	O-RING	2	J20001-
15	561-43-83480	TUBE	1	J20001-
16	02896-21012	O-RING	1	J20001-
17	561-43-86430	TUBE	1	J20001-
18	02896-21015	O-RING	1	J20001-
19	561-43-86411	TUBE	1	J20001-
20	02896-21012	O-RING	1	J20001-
21	561-43-86420	TUBE	1	J20001-
22	02896-21012	O-RING	1	J20001-
23	561-43-83561	PLATE	2	J20001-
24	561-43-83571	BRACKET	2	J20001-
25	561-43-86510	CLAMP	2	J20001-
26	561-43-86520	CLAMP	2	J20001-
27	01011-81235	BOLT	4	J20001-
28	01643-31232	WASHER	4	J20001-
29	561-43-84950	PLATE	1	J20001-
30	561-43-84960	PLATE	1	J20001-
31	561-43-84970	PLATE	1	J20001-
32	01010-81030	BOLT	6	J20001-
33	01643-31032	WASHER	6	J20001-
34	07283-32236	CLIP	7	J20001-
35	01643-31032	WASHER	14	J20001-
36	01597-01009	NUT	14	J20001-



BRAKE LINE (CAB HOOD)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-43-83551	BRACKET	1	J20001-
2	01010-81230	BOLT	2	J20001-
3	01643-31232	WASHER	2	J20001-
4	561-43-83950	HOSE	1	J20001-
5	07094-11024	CLAMP	2	J20001-
6	07095-01034	CUSHION	1	J20001-
7	01010-81285	BOLT	2	J20001-
8	01643-31232	WASHER	2	J20001-
9	02766-00608	HOSE	1	J20001-
10	07094-10620	CLAMP	2	J20001-
11	07095-00628	CUSHION	1	J20001-
12	02766-005A8	HOSE	1	J20001-
13	02766-00508	HOSE	1	J20001-
14	07094-10518	CLAMP	4	J20001-
15	07095-00524	CUSHION	2	J20001-
16	01643-31232	WASHER	1	J20001-
17	01011-81210	BOLT	2	J20001-
18	02765-00412	HOSE	1	J20001-
19	02767-00416	HOSE	2	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up


BREATHER

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	566-88-6B570	JOINT	1	J20001-
2	01010-81025	BOLT	2	J20001-
3	01643-31032	WASHER	2	J20001-
4	07030-00252	BREATHER	1	J20001-
5	07326-10302	ADAPTER	1	J20001-
6	07042-70312	PLUG	1	J20001-




EXHAUST BRAKE VALVE

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-88-81210	BLOCK	1	J20001-
2	01010-80616	BOLT	4	J20001-
3	01643-30623	WASHER	4	J20001-
4	561-88-81430	VALVE,REDUCING	1	J20001-
5	561-88-81440	SOLENOID VALVE	1	J20001-
6	561-88-81450	PLATE	1	J20001-
7	01010-81020	BOLT	4	J20001-
8	01643-31032	WASHER	4	J20001-
9	02781-0021D	UNION	2	J20001-
10	21W-62-43930	NIPPLE	1	J20001-
11	02782-1021A	ELBOW	1	J20001-
12	561-88-81240	SWITCH,PRESSURE	1	J20001-
13	02896-11008	O-RING	4	J20001-
14	07002-11423	O-RING	5	J20001-
15	08034-20519	BAND	1	J20001-
16	561-88-81251	TUBE	1	J20001-
17	561-88-81261	TUBE	1	J20001-
18	561-88-81271	TUBE	1	J20001-
19	561-88-81371	TUBE	1	J20001-
20	07283-31026	CLIP	4	J20001-
21	01596-00606	NUT	8	J20001-
22	01643-30623	WASHER	8	J20001-
23	07283-32236	CLIP	1	J20001-
24	01597-01009	NUT	2	J20001-
25	01643-31032	WASHER	2	J20001-
26	561-88-81280	PLATE	1	J20001-
27	07283-31026	CLIP	6	J20001-
28	01596-00606	NUT	12	J20001-
29	01643-30623	WASHER	12	J20001-
30	561-88-81410	PLATE	2	J20001-
31	01010-81025	BOLT	4	J20001-
32	01643-31032	WASHER	4	J20001-




REAR HOOD RELATED PARTS

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-54-86570	SEAL	1	J20001-
2	01124-51230	STUD	4	J20001-
3	01643-31232	WASHER	4	J20001-
4	01580-11210	NUT	4	J20001-
5	04434-51810	CLIP	2	J20001-
6	04434-51910	CLIP	2	J20001-
7	01010-81016	BOLT	4	J20001-
8	01643-31032	WASHER	4	J20001-
9	01010-81020	BOLT	1	J20001-
10	01643-31032	WASHER	1	J20001-
11	419-64-13110	SPACER	1	J20001-
12	195-979-5190	COLLAR	1	J20001-
13	07094-10417	CLAMP	4	J20001-
14	07095-00421	CUSHION	2	J20001-
15	01011-81215	BOLT	1	J20001-
16	01011-81230	BOLT	1	J20001-
17	01643-31232	WASHER	2	J20001-
18	07094-30417	CLAMP	6	J20001-
19	07095-00421	CUSHION	6	J20001-
20	01010-81265	BOLT	3	J20001-
21	01643-31232	WASHER	3	J20001-




REAR HOOD RELATED PARTS (ADDITIONAL FILTER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-54-86570	SEAL	1	J20001-
2	01124-51230	STUD	4	J20001-
3	01643-31232	WASHER	4	J20001-
4	01580-11210	NUT	4	J20001-
5	04434-51810	CLIP	2	J20001-
6	04434-51910	CLIP	2	J20001-
7	01010-81016	BOLT	4	J20001-
8	01643-31032	WASHER	4	J20001-
9	01010-81020	BOLT	1	J20001-
10	01643-31032	WASHER	1	J20001-
11	04434-50610	CLIP	1	J20001-
12	01010-81016	BOLT	1	J20001-
13	01643-31032	WASHER	1	J20001-
14	419-64-13110	SPACER	1	J20001-
15	195-979-5190	COLLAR	1	J20001-
16	07094-10417	CLAMP	4	J20001-
17	07095-00421	CUSHION	2	J20001-
18	01011-81215	BOLT	1	J20001-
19	01011-81230	BOLT	1	J20001-
20	01643-31232	WASHER	2	J20001-
21	07094-30417	CLAMP	6	J20001-
22	07095-00421	CUSHION	6	J20001-
23	01010-81265	BOLT	3	J20001-
24	01643-31232	WASHER	3	J20001-




ELECTRICAL SYSTEM (MAIN HARNESS)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-06-83214	WIRING HARNESS	1	J20001-
2	23S-62-25850	CLIP	2	J20001-
3	04434-52711	CLIP	3	J20001-
4	01010-81020	BOLT	33	J20001-
5	01643-31032	WASHER	33	J20001-
6	01010-81016	BOLT	48	J20001-
7	01643-31032	WASHER	48	J20001-
8	08034-20834	BAND	12	J20001-
9	04434-53211	CLIP	7	J20001-
10	04434-52110	CLIP	7	J20001-
11	04434-51710	CLIP	3	J20001-
12	04434-50810	CLIP	4	J20001-
13	04434-51010	CLIP	26	J20001-
14	04434-51610	CLIP	4	J20001-
15	08193-21012	CLIP	5	J20001-
16	08193-31012	CLIP	1	J20001-
17	04434-50610	CLIP	16	J20001-
18	04434-51012	CLIP	2	J20001-
19	01643-31032	WASHER	7	J20001-
20	01580-11008	NUT	3	J20001-
21	04434-51410	CLIP	9	J20001-
22	01010-81025	BOLT	7	J20001-
23	01643-31032	WASHER	7	J20001-
24	04434-51310	CLIP	4	J20001-
25	20Y-04-11230	BRACKET	1	J20001-
26	04434-52310	CLIP	4	J20001-
27	01010-81220	BOLT	1	J20001-
28	01643-31232	WASHER	1	J20001-
29	01597-01009	NUT	4	J20001-
30	569-54-41380	PLATE	1	J20001-
31	256-40-11620	PLATE	1	J20001-
32	07283-34949	CLIP	1	J20001-
33	07283-36155	CLIP	1	J20001-
34	431-07-12310	STAY	1	J20001-
35	07095-20419	CUSHION	1	J20001-
36	141-890-2630	PLATE	2	J20001-
37	04434-51210	CLIP	3	J20001-
38	6131-22-3750	BOSS	1	J20001-
39	01010-81040	BOLT	1	J20001-
40	01643-31032	WASHER	1	J20001-
41	561-61-65530	CLIP	3	J20001-
42	561-61-65540	INSULATOR	3	J20001-
43	07095-20211	CUSHION	1	J20001-
44	423-54-11340	SPACER	1	J20001-




ELECTRICAL SYSTEM (MAIN HARNESS)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
45	01010-81250	BOLT	1	J20001-
46	01643-31232	WASHER	1	J20001-
47	04434-50612	CLIP	1	J20001-
48	22D-62-12120	SPACER	1	J20001-
49	01010-81030	BOLT	1	J20001-
50	01643-31032	WASHER	1	J20001-




ELECTRICAL SYSTEM (MAIN HARNESS) (ADDITIONAL FILTER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-06-83214	WIRING HARNESS	1	J20001-
2	23S-62-25850	CLIP	2	J20001-
3	04434-52711	CLIP	3	J20001-
4	01010-81020	BOLT	36	J20001-
5	01643-31032	WASHER	36	J20001-
6	01010-81016	BOLT	44	J20001-
7	01643-31032	WASHER	44	J20001-
8	08034-20834	BAND	12	J20001-
9	04434-53211	CLIP	7	J20001-
10	04434-52110	CLIP	7	J20001-
11	04434-51710	CLIP	3	J20001-
12	04434-50810	CLIP	4	J20001-
13	04434-51010	CLIP	24	J20001-
14	04434-51610	CLIP	4	J20001-
15	08193-21012	CLIP	5	J20001-
16	08193-31012	CLIP	1	J20001-
17	04434-50610	CLIP	16	J20001-
18	04434-51012	CLIP	1	J20001-
19	01643-31032	WASHER	9	J20001-
20	01580-11008	NUT	3	J20001-
21	04434-51410	CLIP	9	J20001-
22	01010-81025	BOLT	7	J20001-
23	01643-31032	WASHER	7	J20001-
24	04434-51310	CLIP	4	J20001-
25	20Y-04-11230	BRACKET	1	J20001-
26	04434-52310	CLIP	4	J20001-
27	01010-81225	BOLT	1	J20001-
28	01643-31232	WASHER	1	J20001-
29	01597-01009	NUT	6	J20001-
30	569-54-41380	PLATE	1	J20001-
31	256-40-11620	PLATE	1	J20001-
32	07283-34949	CLIP	1	J20001-
33	07283-36155	CLIP	2	J20001-
34	431-07-12310	STAY	1	J20001-
35	07095-20419	CUSHION	1	J20001-
36	141-890-2630	PLATE	2	J20001-
37	04434-51210	CLIP	3	J20001-
38	561-04-82280	BRACKET	1	J20001-
39	01010-81220	BOLT	1	J20001-
40	01643-31232	WASHER	1	J20001-
41	561-61-65530	CLIP	3	J20001-
42	561-61-65540	INSULATOR	3	J20001-
43	07095-20211	CUSHION	1	J20001-
44	423-54-11340	SPACER	1	J20001-




ELECTRICAL SYSTEM (MAIN HARNESS) (ADDITIONAL FILTER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
45	01010-81250	BOLT	1	J20001-
46	01643-31232	WASHER	1	J20001-
47	04434-50612	CLIP	1	J20001-
48	22D-62-12120	SPACER	1	J20001-
49	01010-81030	BOLT	1	J20001-
50	01643-31032	WASHER	1	J20001-




ELECTRICAL SYSTEM (BRACKET CLAMP)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-06-82811	BRACKET	1	J20001-
2	01010-81220	BOLT	4	J20001-
3	01643-31232	WASHER	4	J20001-
4	561-06-82890	COVER	1	J20001-
5	01010-81020	BOLT	4	J20001-
6	01643-31032	WASHER	4	J20001-
7	561-06-82672	BRACKET	1	J20001-
8	01010-81270	BOLT	2	J20001-
9	01643-31232	WASHER	2	J20001-
10	01010-81225	BOLT	1	J20001-
11	01643-31232	WASHER	1	J20001-
12	561-06-82631	BRACKET	1	J20001-
13	01010-81225	BOLT	2	J20001-
14	01643-31232	WASHER	2	J20001-
15	561-06-82642	BRACKET	1	J20001-
16	01010-81225	BOLT	2	J20001-
17	01643-31232	WASHER	2	J20001-
18	561-06-82651	BRACKET	1	J20001-
19	01010-81225	BOLT	3	J20001-
20	01643-31232	WASHER	3	J20001-
21	561-06-82660	BRACKET	1	J20001-
22	01010-81225	BOLT	1	J20001-
23	01643-31232	WASHER	1	J20001-
24	01010-81425	BOLT	1	J20001-
25	01643-31445	WASHER	1	J20001-



ELECTRICAL SYSTEM (STARTER CABLE)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-06-81530	CABLE	2	J20001-
2	08038-00035	CAP	2	J20001-
3	04434-52711	CLIP	12	J20001-
4	04434-53411	CLIP	2	J20001-
5	07095-20627	CUSHION	2	J20001-
6	01010-81016	BOLT	5	J20001-
7	01643-31032	WASHER	5	J20001-
8	01010-81020	BOLT	2	J20001-
9	01643-31032	WASHER	2	J20001-
10	08034-20834	BAND	3	J20001-



ELECTRICAL SYSTEM (HORN AND BRACKET)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-06-80101	HORN ASS'Y	1	J20001-
2	01010-81025	BOLT	2	J20001-
3	01643-31032	WASHER	2	J20001-
4	561-06-82830	BRACKET	1	J20001-
5	01010-81020	BOLT	2	J20001-
6	01643-31032	WASHER	2	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

ELECTRICAL SYSTEM (CLIP, R.H.)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	08193-21012	CLIP	1	J20001-
2	01010-81016	BOLT	1	J20001-
3	01643-31032	WASHER	1	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

REAR LAMP (BRACKET)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-06-82710	BRACKET	1	J20001-
2	565-03-11270	CUSHION	2	J20001-
3	01643-31032	WASHER	2	J20001-
4	01580-11008	NUT	2	J20001-
5	561-06-82720	BRACKET	2	J20001-
6	01010-80825	BOLT	4	J20001-
7	01643-30823	WASHER	4	J20001-
8	01643-30823	WASHER	4	J20001-
9	01580-10806	NUT	4	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up


REAR LAMP (BRACKET) (FOR OPTION LAMP)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-86-82712	BRACKET	1	J20001-
2	565-03-11270	CUSHION	2	J20001-
3	01643-31032	WASHER	2	J20001-
4	01580-11008	NUT	2	J20001-
5	561-06-82720	BRACKET	2	J20001-
6	01010-80825	BOLT	4	J20001-
7	01643-30823	WASHER	4	J20001-
8	01643-30823	WASHER	4	J20001-
9	01580-10806	NUT	4	J20001-




REAR LAMP (LAMP AND BUZZER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	421-06-23350	LAMP ASS'Y	1	J20001-
	421-06-23320	.LENS	1	J20001-
	421-06-23330	.BULB, 70W	1	J20001-
2	08164-B0000	BACK UP ALARM	1	J20001-
3	01010-81095	BOLT	2	J20001-
4	01643-31032	WASHER	2	J20001-
5	56B-06-15620	LAMP ASS'Y	1	J20001-
	566-06-14340	.LENS	1	J20001-
	566-06-14350	.LENS	1	J20001-
	7821-92-1340	.CONNECTOR	1	J20001-
	7821-92-1440	.HOLDER	1	J20001-
	7821-92-1010	.TERMINAL	5	J20001-
	7821-92-1110	.GROMMET	5	J20001-
	7821-92-1130	.PLUG	1	J20001-
	01220-30416	.SCREW	16	J20001-
	08102-02403	.BULB, 3W	1	J20001-
	08104-12420	.BULB, 25/10W	1	J20001-
	08105-12420	.BULB, 25W	1	J20001-
6	56B-06-15630	LAMP ASS'Y	1	J20001-
	566-06-14340	.LENS	1	J20001-
	566-06-14350	.LENS	1	J20001-
	7821-92-1340	.CONNECTOR	1	J20001-
	7821-92-1440	.HOLDER	1	J20001-
	7821-92-1010	.TERMINAL	5	J20001-
	7821-92-1130	.PLUG	1	J20001-
	01220-30416	.SCREW	16	J20001-
	08105-12420	.BULB, 25W	1	J20001-
	7821-92-1130	.PLUG	1	J20001-
	08102-02403	.BULB, 3W	1	J20001-
	08104-12420	.BULB, 25/10W	1	J20001-
7	566-06-6D330	LAMP	1	J20001-
	566-06-14360	.LENS	1	J20001-
	01220-30416	.SCREW	7	J20001-
	08104-12420	.BULB, 25/10W	1	J20001-
	08192-26810	.CONNECTOR	1	J20001-
	08192-26910	.CONNECTOR	1	J20001-
8	01010-80825	BOLT	8	J20001-
9	01643-30823	WASHER	8	J20001-
10	01643-30823	WASHER	8	J20001-
11	01580-10806	NUT	8	J20001-
12	561-06-83272	WIRING HARNESS	1	J20001-
13	04434-51410	CLIP	1	J20001-
14	04434-51010	CLIP	2	J20001-
15	04434-50810	CLIP	2	J20001-




REAR LAMP (LAMP AND BUZZER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
16	04434-50510	CLIP	1	J20001-
17	08053-01510	CLIP	1	J20001-
18	08193-21012	CLIP	5	J20001-
19	01010-81016	BOLT	7	J20001-
20	01643-31032	WASHER	7	J20001-
21	08034-20414	BAND	1	J20001-




REAR LAMP (LAMP AND BUZZER) (WITH ADDITIONAL LAMP)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	421-06-23350	LAMP ASS'Y	2	J20001-
	421-06-23320	.LENS	2	J20001-
	421-06-23330	.BULB, 70W	2	J20001-
2	08164-B0000	BACK UP ALARM	1	J20001-
3	01010-81095	BOLT	2	J20001-
4	01643-31032	WASHER	2	J20001-
5	56B-06-15620	LAMP ASS'Y	1	J20001-
	566-06-14340	.LENS	1	J20001-
	566-06-14350	.LENS	1	J20001-
	7821-92-1340	.CONNECTOR	1	J20001-
	7821-92-1440	.HOLDER	1	J20001-
	7821-92-1010	.TERMINAL	5	J20001-
	7821-92-1110	.GROMMET	5	J20001-
	7821-92-1130	.PLUG	1	J20001-
	01220-30416	.SCREW	16	J20001-
	08102-02403	.BULB, 3W	1	J20001-
	08104-12420	.BULB, 25/10W	1	J20001-
	08105-12420	.BULB, 25W	1	J20001-
6	56B-06-15630	LAMP ASS'Y	1	J20001-
	566-06-14340	.LENS	1	J20001-
	566-06-14350	.LENS	1	J20001-
	7821-92-1340	.CONNECTOR	1	J20001-
	7821-92-1440	.HOLDER	1	J20001-
	7821-92-1010	.TERMINAL	5	J20001-
	7821-92-1130	.PLUG	1	J20001-
	01220-30416	.SCREW	16	J20001-
	08105-12420	.BULB, 25W	1	J20001-
	7821-92-1130	.PLUG	1	J20001-
	08102-02403	.BULB, 3W	1	J20001-
	08104-12420	.BULB, 25/10W	1	J20001-
7	566-06-6D330	LAMP	1	J20001-
	566-06-14360	.LENS	1	J20001-
	01220-30416	.SCREW	7	J20001-
	08104-12420	.BULB, 25/10W	1	J20001-
	08192-26910	.CONNECTOR	1	J20001-
	08192-26810	.CONNECTOR	1	J20001-
8	01010-80825	BOLT	8	J20001-
9	01643-30823	WASHER	8	J20001-
10	01643-30823	WASHER	8	J20001-
11	01580-10806	NUT	8	J20001-
12	561-06-83272	WIRING HARNESS	1	J20001-
13	04434-51410	CLIP	1	J20001-
14	04434-51010	CLIP	2	J20001-
15	04434-50810	CLIP	2	J20001-



REAR LAMP (LAMP AND BUZZER) (WITH ADDITIONAL LAMP)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
16	04434-50510	CLIP	1	J20001-
17	08053-01510	CLIP	2	J20001-
18	08193-21012	CLIP	5	J20001-
19	01010-81016	BOLT	8	J20001-
20	01643-31032	WASHER	8	J20001-
21	08034-20414	BAND	1	J20001-



REAR LAMP (LAMP AND BUZZER) (WITH LED LAMP)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	421-06-23350	LAMP ASS'Y	1	J20001-
	421-06-23320	LENS	1	J20001-
	421-06-23330	BULB $\square$ 70W	1	J20001-
2	08164-B0000	BACK UP ALARM	1	J20001-
3	01010-81095	BOLT	2	J20001-
4	01643-31032	WASHER	2	J20001-
5	561-06-85620	LAMP,LED $\square$ RED	3	J20001-
6	561-06-85630	LAMP,LED $\square$ AMBER	2	J20001-
7	561-06-85660	BRACKET	1	J20001-
8	01010-80820	BOLT	13	J20001-
9	01643-30823	WASHER	13	J20001-
10	561-06-85611	WIRING HARNESS	1	J20001-
11	561-06-83272	WIRING HARNESS	1	J20001-
12	04434-51410	CLIP	1	J20001-
13	04434-51210	CLIP	2	J20001-
14	04434-51010	CLIP	2	J20001-
15	04434-50810	CLIP	4	J20001-
16	04434-50510	CLIP	1	J20001-
17	08053-01510	CLIP	2	J20001-
18	08193-21012	CLIP	4	J20001-
19	01010-81016	BOLT	7	J20001-
20	01643-31032	WASHER	7	J20001-
21	08034-20414	BAND	6	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up
REAR LAMP (LAMP AND BUZZER) (WITH ADDITIONAL LAMP AND LED LAMP)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	421-06-23350	LAMP ASS'Y	2	J20001-
	421-06-23320	.LENS	2	J20001-
	421-06-23330	.BULB, 70W	2	J20001-
2	08164-B0000	BACK UP ALARM	1	J20001-
3	01010-81095	BOLT	2	J20001-
4	01643-31032	WASHER	2	J20001-
5	561-06-85620	LAMP,LED, RED	3	J20001-
6	561-06-85630	LAMP,LED, AMBER	2	J20001-
7	561-06-85660	BRACKET	1	J20001-
8	01010-80820	BOLT	13	J20001-
9	01643-30823	WASHER	13	J20001-
10	561-06-85611	WIRING HARNESS	1	J20001-
11	561-06-83272	WIRING HARNESS	1	J20001-
12	04434-51410	CLIP	1	J20001-
13	04434-51210	CLIP	2	J20001-
14	04434-51010	CLIP	2	J20001-
15	04434-50810	CLIP	4	J20001-
16	04434-50510	CLIP	1	J20001-
17	08053-01510	CLIP	2	J20001-
18	08193-21012	CLIP	4	J20001-
19	01010-81016	BOLT	12	J20001-
20	01643-31032	WASHER	12	J20001-
21	08034-20414	BAND	6	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up

REAR LAMP (MOUNTING PARTS)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	01010-81425	BOLT	4	J20001-
2	01643-31445	WASHER	4	J20001-
3	01010-81016	BOLT	1	J20001-
4	01643-31032	WASHER	1	J20001-



SIDE LAMP

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-85-81110	COVER	2	J20001-
2	01010-81220	BOLT	8	J20001-
3	01643-31232	WASHER	8	J20001-
4	421-06-23310	LAMP ASS'Y	2	J20001-
	421-06-23340	.LENS	2	J20001-
	421-06-23330	.BULB, 70W	2	J20001-
	01582-11411	.NUT	2	J20001-
	01602-21442	.WASHER	2	J20001-
	01643-31445	.WASHER	4	J20001-
	08056-00271	.CONNECTOR	2	J20001-
5	561-85-81150	COVER	1	J20001-
6	561-85-81160	COVER	1	J20001-
7	561-85-81170	COVER	1	J20001-
8	561-85-81180	COVER	1	J20001-
9	01010-81035	BOLT	2	J20001-
10	01643-31032	WASHER	2	J20001-
11	01010-81020	BOLT	8	J20001-
12	01643-31032	WASHER	8	J20001-
13	561-85-81211	WIRING HARNESS	1	J20001-
14	561-85-81220	WIRING HARNESS	1	J20001-
15	04434-50810	CLIP	17	J20001-
16	01010-81016	BOLT	12	J20001-
17	01643-31032	WASHER	12	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up

SIDE LAMP (FOR PAYLOAD METER)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-85-81110	COVER	2	J20001-
2	01010-81220	BOLT	8	J20001-
3	01643-31232	WASHER	8	J20001-
4	421-06-23310	LAMP ASS'Y	2	J20001-
	421-06-23340	.LENS	2	J20001-
	421-06-23330	.BULB, 70W	2	J20001-
	01582-11411	.NUT	2	J20001-
	01602-21442	.WASHER	2	J20001-
	01643-31445	.WASHER	4	J20001-
	08056-00271	.CONNECTOR	2	J20001-
5	561-85-81150	COVER	1	J20001-
6	561-85-81160	COVER	1	J20001-
7	561-85-81170	COVER	1	J20001-
8	561-85-81180	COVER	1	J20001-
9	01010-81035	BOLT	2	J20001-
10	01643-31032	WASHER	2	J20001-
11	01010-81020	BOLT	8	J20001-
12	01643-31032	WASHER	8	J20001-



FOG LAMP

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-85-81310	BRACKET	2	J20001-
2	01010-81220	BOLT	8	J20001-
3	01643-31232	WASHER	8	J20001-
4	22T-06-24110	LAMP	2	J20001-
	421-06-23330	BULB 70W	2	J20001-
	08056-00271	CONNECTOR	2	J20001-
5	09415-03614	CAP	2	J20001-
6	08037-03614	GROMMET	2	J20001-
7	08053-01510	CLIP	2	J20001-
8	01010-81016	BOLT	2	J20001-
9	01643-31032	WASHER	2	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

PAYLOAD METER LAMP


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-86-80201	LAMP ASS'Y,PAYLOADER, R.H.	1	J20001-
1	561-86-87311	.BRACKET	1	J20001-
2	561-86-87410	.LAMP, GREEN	1	J20001-
	08110-12410	.BULB, 12W	1	J20001-
3	561-86-87420	.LAMP, AMBER	1	J20001-
	08110-12410	.BULB, 12W	1	J20001-
4	561-86-87430	.LAMP, RED	1	J20001-
	08110-12410	.BULB, 12W	1	J20001-
5	08037-02512	.GROMMET	1	J20001-
6	421-62-18550	CUSHION	4	J20001-
7	421-62-23710	CUSHION	4	J20001-
8	175-54-34170	WASHER	4	J20001-
9	01010-81235	BOLT	4	J20001-
10	561-86-87531	WIRING HARNESS	1	J20001-
11	04434-50810	CLIP	12	J20001-
12	01010-81016	BOLT	6	J20001-
13	01643-31032	WASHER	6	J20001-
14	08034-20834	BAND	1	J20001-
15	569-86-87321	BRACKET	1	J20001-
16	01010-81020	BOLT	3	J20001-
17	01643-31032	WASHER	3	J20001-
18	421-62-23710	CUSHION	4	J20001-
	561-86-80100	LAMP ASS'Y,PAYLOADER, L.H.	1	J20001-
19	561-86-87330	.BRACKET	1	J20001-
20	561-86-87410	.LAMP, GREEN	1	J20001-
	08110-12410	.BULB, 12W	1	J20001-
21	561-86-87420	.LAMP, AMBER	1	J20001-
	08110-12410	.BULB, 12W	1	J20001-
22	561-86-87430	.LAMP, RED	1	J20001-
	08110-12410	.BULB, 12W	1	J20001-
23	421-62-18550	CUSHION	4	J20001-
24	175-54-34170	WASHER	4	J20001-
25	01010-81235	BOLT	4	J20001-
26	561-86-87522	WIRING HARNESS	1	J20001-
27	04434-50810	CLIP	5	J20001-
28	04434-51010	CLIP	4	J20001-
29	08034-20834	BAND	1	J20001-
30	01010-81016	BOLT	7	J20001-
31	01643-31032	WASHER	7	J20001-

TORQUE CONVERTER AND TRANSMISSION



FRONT PROPELLER SHAFT


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-20-71000	PROPELLER SHAFT	1	J20001-
1	561-20-71200	*YOKE	1	J20001-
2	561-20-71100	*SPIDER	2	J20001-
3	562-20-31801	*BOLT	8	J20001-
4	01010-62085	BOLT	8	J20001-



REAR PROPELLER SHAFT

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-20-72002	PROPELLER SHAFT	1	J20001-
1	42C-20-12621	*SPIDER ASS'Y	2	J20001-
2	561-20-72200	*YOKE ASS'Y	1	J20001-
3	42C-20-12690	*SCREW	8	J20001-
4	01050-61895	BOLT	4	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up


TORQUE CONVERTER (1/7) (BARE UNIT)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-13-71000	TORQUE CONVERTER A.	1	J20001-
		THIS ASSEMBLY CONSISTS OF ALL PARTS SHOWN IN FIGS F3310-51A0 TO F3310-58A0.		
1	561-13-71121	*PUMP	1	J20001-
2	07040-11007	*PLUG	2	J20001-
3	561-13-71141	*RETAINER	1	J20001-
4	711-28-41190	*GUIDE	1	J20001-
5	01010-81050	*BOLT	18	J20001-
6	01643-31032	*WASHER	18	J20001-
7	01010-81040	*BOLT	36	J20001-
8	01643-31032	*WASHER	36	J20001-
9	561-13-52110	*STATOR	1	J20001-
10	561-13-72120	*RACE	1	J20001-
11	01010-81025	*BOLT	24	J20001-
12	01643-31032	*WASHER	24	J20001-
13	561-13-72141	*BUSHING	1	J20001-
14	561-13-72151	*BUSHING	1	J20001-
15	711-28-32160	*WHEEL	1	J20001-
16	04260-00635	*BALL	2	J20001-
17	561-13-72170	*RING,SNAP	1	J20001-
	561-13-71020	*SHAFT ASS'Y	1	J20001-
18	☆	**SHAFT	1	J20001-
19	07043-70211	**PLUG	2	J20001-
20	711-31-13140	**PLUG	2	J20001-
21	07018-31907	*RING,SEAL (K1)	1	J20001-
22	561-13-71180	*BEARING	1	J20001-
23	711-28-42681	*NUT	2	J20001-
24	01010-81230	*BOLT	12	J20001-
25	01643-31232	*WASHER	12	J20001-
26	561-13-51520	*TURBINE	1	J20001-
27	561-13-71531	*BOSS	1	J20001-
28	01010-81230	*BOLT	30	J20001-
29	01643-31232	*WASHER	30	J20001-




TORQUE CONVERTER (2/7) (INPUT SHAFT)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(561-13-71000)	TORQUE CONVERTER A. THIS ASSEMBLY CONSISTS OF ALL PARTS SHOWN IN FIGS F3310-51A0 TO F3310-58A0.	1	J20001-
1	561-13-71351	*SHAFT	1	J20001-
2	711-23-11240	*BEARING	1	J20001-
3	19M-13-21370	*RING,SEAL	2	J20001-
4	01010-61655	*BOLT	18	J20001-
5	01643-31645	*WASHER	18	J20001-
6	561-13-79371	*RETAINER	1	J20001-
7	07012-50125	*OIL SEAL,OIL (K1)	1	J20001-
8	772-19-14280	*SEAL,DUST (K1)	1	J20001-
9	07000-75170	*O-RING (K1)	1	J20001-
10	01010-81030	*BOLT	2	J20001-
11	01643-31032	*WASHER	2	J20001-
12	561-13-79861	*COUPLING	1	J20001-
13	04064-09530	*RING,SNAP	1	J20001-
14	561-13-75380	*BUSHING	1	J20001-




TORQUE CONVERTER (3/7) (DRIVE CASE)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(561-13-71000)	TORQUE CONVERTER A. THIS ASSEMBLY CONSISTS OF ALL PARTS SHOWN IN FIGS F3310-51A0 TO F3310-58A0.	1	J20001-
1	568-13-11770	*PLATE	1	J20001-
2	04064-08530	*RING,SNAP	1	J20001-
3	561-13-77210	*PISTON	1	J20001-
4	195-15-32710	*DISC	3	J20001-
5	281-15-12720	*PLATE	2	J20001-
6	561-13-71211	*CASE	1	J20001-
7	113-15-12861	*RING,SEAL (K1)	2	J20001-
8	426-15-19220	*RING,SEAL (K1)	2	J20001-
	561-13-77110	*HOUSING COMPLETE	1	J20001-
9	561-13-77121	**HOUSING	1	J20001-
10	711-31-27130	**PIN	3	J20001-
11	711-20-11550	*BEARING	1	J20001-
12	01010-81245	*BOLT	30	J20001-
13	01643-31232	*WASHER	30	J20001-




TORQUE CONVERTER (4/70 (REAR HOISING))

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(561-13-71000)	TORQUE CONVERTER A.	1	J20001-
		THIS ASSEMBLY CONSISTS OF ALL PARTS SHOWN IN FIGS F3310-51A0 TO F3310-58A0.		
1	561-13-73111	*HOUSING	1	J20001-
2	07000-73035	*O-RING (K1)	3	J20001-
3	07000-73048	*O-RING (K1)	2	J20001-
4	708-8E-16150	*PLUG	1	J20001-
5	07002-61023	*O-RING (K1)	1	J20001-
6	561-13-53150	*O-RING (K1)	1	J20001-
7	01010-61640	*BOLT	16	J20001-
8	01643-31645	*WASHER	16	J20001-
9	01010-61655	*BOLT	16	J20001-
10	01643-31645	*.WASHER	16	J20001-
11	7861-93-3320	*SENSOR	1	J20001-
12	561-13-79630	*PLUG	1	J20001-




TORQUE CONVERTER (5/7) (POWER TAKE OFF)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(561-13-71000)	TORQUE CONVERTER A.	1	J20001-
		THIS ASSEMBLY CONSISTS OF ALL PARTS SHOWN IN FIGS F3310-51A0 TO F3310-58A0.		
	561-13-71010	*HOUSING A.	1	J20001-
1	561-13-73131	**HOUSING	1	J20001-
2	07043-70312	**PLUG	4	J20001-
3	561-13-43170	**PLUG,(D=1.0MM)	2	J20001-
4	561-13-73340	**SLEEVE	1	J20001-
5	198-15-26510	**PLUG	4	J20001-
6	09607-05080	*PLATE, NAME,(LIMITED SUPPLY)	1	J20001-
7	04418-13060	*SCREW	4	J20001-
8	04530-13045	*BOLT	2	J20001-
9	711-28-44351	*COVER	2	J20001-
10	561-13-74311	*GEAR	2	J20001-
11	711-28-44330	*BEARING	2	J20001-
12	711-28-44340	*PLATE	2	J20001-
13	04065-01254	*RING,SNAP	2	J20001-
14	01530-06214	*NUT	2	J20001-
15	07000-73022	*O-RING (K1)	2	J20001-
16	07000-75345	*O-RING (K1)	2	J20001-
17	01010-81030	*BOLT	16	J20001-
18	01643-31032	*WASHER	16	J20001-
19	04020-01024	*PIN	1	J20001-



TORQUE CONVERTER (6/7) (VALVE MOUNT)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(561-13-71000)	TORQUE CONVERTER A.	1	J20001-
		THIS ASSEMBLY CONSISTS OF ALL PARTS SHOWN IN FIGS F3310-51A0 TO F3310-58A0.		
1	561-13-76921	*TUBE	1	J20001-
2	561-13-76940	*FLANGE	1	J20001-
3	01010-81030	*BOLT	1	J20001-
4	01643-31032	*WASHER	1	J20001-
5	01010-81065	*BOLT	2	J20001-
6	01643-31032	*WASHER	2	J20001-
7	07000-73045	*O-RING (K2)	1	J20001-
8	711-28-46930	*TUBE	1	J20001-
9	07206-30812	*BOLT	4	J20001-
10	07005-01212	*GASKET (K2)	8	J20001-
11	232-43-14170	*CLIP	3	J20001-
12	01010-81016	*BOLT	1	J20001-
13	01643-31032	*WASHER	2	J20001-
14	(561-13-76602)	*VALVE ASS'Y (SEE FIG.3310-58A0)	1	J20001-
15	01010-81090	*BOLT	8	J20001-
16	01643-31032	*WASHER	8	J20001-
17	561-13-76661	*GASKET (K2)	1	J20001-



TORQUE CONVERTER (7/7) (CHARGE PUMP)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(561-13-71000)	TORQUE CONVERTER A. THIS ASSEMBLY CONSISTS OF ALL PARTS SHOWN IN FIGS F3310-51A0 TO F3310-58A0.	1	J20001-
1	711-28-44450	*COVER	1	J20001-
2	561-13-74410	*GEAR	1	J20001-
3	711-28-44330	*BEARING	1	J20001-
4	711-28-44340	*PLATE	1	J20001-
5	04065-01254	*RING,SNAP	1	J20001-
6	01530-06214	*NUT	1	J20001-
7	07000-75295	*O-RING (K1)	1	J20001-
8	01010-81030	*BOLT	8	J20001-
9	01643-31032	*WASHER	8	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

TORQUE CONVERTER VALVE

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(561-13-71000)	TORQUE CONVERTER A.	1	J20001-
		THIS ASSEMBLY CONSISTS OF ALL PARTS SHOWN IN FIGS F3310-51A0 TO F3310-58A0.		
	(561-13-76602)	*VALVE ASS'Y	1	J20001-
1	☆	**BODY	1	J20001-
2	561-13-56630	**SPOOL	1	J20001-
3	561-13-76720	**SPOOL	1	J20001-
4	711-35-46651	**VALVE	2	J20001-
5	711-35-46660	**VALVE	2	J20001-
6	711-35-26690	**SPRING	2	J20001-
7	569-13-56760	**SPRING	1	J20001-
8	125-15-36480	**SHIM ,0.5MM	3	J20001-
9	561-13-76670	**SPRING	1	J20001-
10	125-15-36480	**SHIM, 0.5MM	3	J20001-
11	711-20-16720	**COVER	1	J20001-
12	561-13-76680	**COVER	1	J20001-
13	711-20-16740	**PLATE	1	J20001-
14	561-13-76631	**COVER	1	J20001-
15	561-13-76620	**PISTON	1	J20001-
16	561-13-76651	**COVER	1	J20001-
17	04020-00616	**PIN,DOWEL	2	J20001-
18	561-13-76691	**SPOOL	1	J20001-
19	561-15-74650	**SPRING	1	J20001-
20	569-13-76710	**PISTON	1	J20001-
21	07750-02537	**VALVE	1	J20001-
22	07750-02545	**SPRING	1	J20001-
23	561-13-76770	**PLUG	1	J20001-
24	561-13-76780	**PLUG	1	J20001-
25	714-23-15560	**O-RING (K2)	4	J20001-
26	714-23-15551	**VALVE	2	J20001-
27	714-23-15530	**BALL	2	J20001-
28	07002-22034	**O-RING (K2)	2	J20001-
29	07000-72012	**O-RING (K2)	3	J20001-
30	07000-73030	**O-RING (K2)	1	J20001-
31	07000-73038	**O-RING (K2)	6	J20001-
32	01010-81025	**BOLT	8	J20001-
33	01010-81055	**BOLT	5	J20001-
34	01643-31032	**WASHER	5	J20001-
35	01643-51032	**WASHER	8	J20001-
36	20U-62-31250	**PLUG	1	J20001-
37	07002-61023	**O-RING (K2)	1	J20001-
38	708-8E-16150	**PLUG	3	J20001-
39	07002-61023	**O-RING (K2)	3	J20001-
40	07040-10807	**PLUG	1	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up


TORQUE CONVERTER VALVE

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
41	07002-60823	**O-RING (K2)	1	J20001-
42	125-15-22780	**PLUG	1	J20001-
43	425-15-35220	**SOLENOID	2	J20001-
44	561-13-76810	**BRACKET	1	J20001-
45	01252-60510	**BOLT	4	J20001-
46	561-15-74660	**SENSOR	2	J20001-
47	07002-61023	**O-RING (K2)	2	J20001-
48	08034-20414	**BAND	4	J20001-




TRANSMISSION (1/10) (1ST, 2ND, 3RD AND REVERSE CLUTCH)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(561-15-71001)	TORQUE CONVERTER A.	1	J20001-
		THIS ASSEMBLY CONSISTS OF ALL PARTS SHOWN IN FIGS F3320-51A0 TO F3320-67A0.		
1	561-15-71132	*HOUSING	1	J20001-
2	561-15-72571	*PISTON	1	J20001-
3	561-15-72581	*PISTON	1	J20001-
4	195-15-39220	*RING,SEAL (K3)	1	J20001-
5	175-15-59240	*RING,SEAL (K3)	1	J20001-
6	562-15-19560	*RING,SEAL (K3)	1	J20001-
7	195-15-29210	*RING,SEAL (K3)	1	J20001-
8	561-15-79690	*BEARING	1	J20001-
9	04071-00260	*RING	1	J20001-
10	04020-01842	*PIN,DOWEL	6	J20001-
11	566-15-11260	*PIN,DOWEL	2	J20001-
12	561-15-79710	*PIN	12	J20001-
13	561-15-41270	*PIN	6	J20001-
14	562-15-31290	*PIN	6	J20001-
15	195-15-12880	*SPRING	114	J20001-
16	561-15-71141	*HOUSING	1	J20001-
17	561-15-51310	*SLEEVE	20	J20001-
18	561-15-72581	*PISTON	1	J20001-
19	195-15-39220	*RING,SEAL (K3)	1	J20001-
20	175-15-59240	*RING,SEAL (K3)	1	J20001-
21	561-15-71151	*HOUSING	1	J20001-
22	561-15-72591	*PISTON	1	J20001-
23	175-15-59240	*RING,SEAL (K3)	1	J20001-
24	155-15-12811	*RING,SEAL (K3)	1	J20001-
25	561-15-72970	*PLATE	1	J20001-
26	561-15-72980	*PLATE	2	J20001-
27	561-15-71160	*PLATE	1	J20001-
28	562-15-22740	*PLATE	1	J20001-
29	6128-51-1632	*SPRING	24	J20001-
30	561-15-79840	*SPRING	12	J20001-
31	195-40-11431	*SPRING	12	J20001-
32	561-15-71290	*BOLT	20	J20001-
33	01643-31645	*WASHER	42	J20001-
34	01011-81635	*BOLT	22	J20001-




TRANSMISSION (2/10) (HIGH CLUTCH)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(561-15-71001)	TORQUE CONVERTER A.	1	J20001-
		THIS ASSEMBLY CONSISTS OF ALL PARTS SHOWN IN FIGS F3320-51A0 TO F3320-67A0.		
1	561-15-71170	*HOUSING	1	J20001-
2	04020-01434	*PIN,DOWEL	2	J20001-
3	561-15-72710	*PISTON	1	J20001-
4	175-15-59250	*RING,SEAL (K3)	1	J20001-
5	155-15-12811	*RING,SEAL (K3)	1	J20001-
6	582-15-11470	*PIN	6	J20001-
7	569-15-52930	*DISC	5	J20001-
8	103-15-12890	*PIN	12	J20001-
9	561-15-52941	*PLATE	4	J20001-
10	175-15-42880	*SPRING	30	J20001-
11	417-15-15770	*SPRING,INNER	12	J20001-
12	561-15-79730	*WASHER	12	J20001-
13	561-15-71181	*HOUSING	1	J20001-
14	569-15-59110	*O-RING (K3)	1	J20001-
15	07000-72055	*O-RING (K3)	1	J20001-
16	01010-61440	*BOLT	17	J20001-
17	01643-31445	*WASHER	17	J20001-
18	04020-01024	*PIN	1	J20001-
19	562-15-22890	*DISC	10	J20001-
20	561-15-52811	*DISC	4	J20001-
21	562-15-22870	*DISC	5	J20001-
22	561-15-52951	*PLATE	10	J20001-
23	561-15-52931	*PLATE	3	J20001-
24	562-15-22820	*PLATE	5	J20001-




TRANSMISSION (3/10) (LOW AND 4TH CLUTCH)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(561-15-71001)	TORQUE CONVERTER A.	1	J20001-
		THIS ASSEMBLY CONSISTS OF ALL PARTS SHOWN IN FIGS F3320-51A0 TO F3320-67A0.		
1	561-15-52671	*DRUM	1	J20001-
2	561-15-71211	*HOUSING	1	J20001-
3	561-15-71211	*HOUSING	1	J20001-
4	04020-01228	*PIN	2	J20001-
5	04020-01228	*PIN	2	J20001-
6	01010-81230	*BOLT	24	J20001-
7	01643-31232	*WASHER	24	J20001-
8	01010-81230	*BOLT	24	J20001-
9	01643-31232	*WASHER	24	J20001-
10	561-15-72880	*PISTON	1	J20001-
11	561-15-72880	*PISTON	1	J20001-
12	561-15-72320	*COVER	1	J20001-
13	561-15-72320	*COVER	1	J20001-
14	232-15-19270	*RING,SEAL (K3)	1	J20001-
15	232-15-19270	*RING,SEAL (K3)	1	J20001-
16	569-15-12860	*RING,SEAL (K3)	1	J20001-
17	569-15-12860	*RING,SEAL (K3)	1	J20001-
18	561-15-79220	*RING,SEAL (K3)	1	J20001-
19	561-15-79220	*RING,SEAL (K3)	1	J20001-
20	01010-81025	*BOLT	8	J20001-
21	01643-31032	*WASHER	8	J20001-
22	01010-81025	*BOLT	8	J20001-
23	01643-31032	*WASHER	8	J20001-
24	569-15-52930	*DISC	5	J20001-
25	569-15-52930	*DISC	4	J20001-
26	561-15-52961	*PLATE	4	J20001-
27	561-15-52961	*PLATE	3	J20001-
28	561-15-79811	*WAVE SPRING	5	J20001-
29	561-15-79811	*WAVE SPRING	4	J20001-
30	561-15-72650	*GEAR,RING	1	J20001-
31	561-15-71261	*COLLAR	1	J20001-
32	144-15-62890	*RING,SEAL	4	J20001-
33	561-15-61230	*BUSHING	1	J20001-
34	561-15-61230	*BUSHING	1	J20001-
35	561-15-69540	*RING	1	J20001-
36	561-15-69540	*RING	1	J20001-
37	561-15-59610	*BEARING	1	J20001-
38	561-15-59610	*BEARING	1	J20001-
39	561-15-59310	*BEARING	1	J20001-
40	04260-00635	*BALL	1	J20001-
41	04260-00635	*BALL	1	J20001-




TRANSMISSION (3/10) (LOW AND 4TH CLUTCH)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
42	561-15-71270	*CAGE	1	J20001-
43	01010-81030	*BOLT	6	J20001-
44	01643-31032	*WASHER	6	J20001-




TRANSMISSION (4/10) (CARRIER) (1/4)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(561-15-71001)	TORQUE CONVERTER A.	1	J20001-
		THIS ASSEMBLY CONSISTS OF ALL PARTS SHOWN IN FIGS F3320-51A0 TO F3320-67A0.		
	561-15-71050	CARRIER ASS'Y	1	J20001-
1	★	**CARRIER ASS'Y	1	J20001-
2	7720-30-2660	**SCREW, 3MM	4	J20001-
3	561-15-71321	*RETAINER	1	J20001-
4	01010-81030	*BOLT	3	J20001-
5	01643-31032	*WASHER	3	J20001-
6	561-15-72561	*SHAFT	6	J20001-
7	561-15-32570	*WASHER, THRUST	12	J20001-
8	561-15-72481	*GEAR	6	J20001-
9	561-15-79410	*BEARING	12	J20001-
10	04260-00635	*BALL	6	J20001-
11	561-15-72860	*BUSHING	1	J20001-
12	561-15-79550	*RING, SNAP	1	J20001-
13	195-09-18361	*RING, SEAL (K3)	1	J20001-




TRANSMISSION (5/10) (CARRIER) (2/4)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(561-15-71001)	TORQUE CONVERTER A.	1	J20001-
		THIS ASSEMBLY CONSISTS OF ALL PARTS SHOWN IN FIGS F3320-51A0 TO F3320-67A0.		
	561-15-71040	*CARRIER ASS'Y	1	J20001-
1	★	**CARRIER	1	J20001-
2	07043-70108	**PLUG	6	J20001-
3	561-15-72541	*SHAFT	4	J20001-
4	561-15-72550	*SHAFT	4	J20001-
5	561-15-42560	*WASHER, THRUST	16	J20001-
6	04260-00635	*BALL	8	J20001-
7	427-15-19520	*RING, SNAP	1	J20001-
8	561-15-79440	*BEARING	8	J20001-
9	561-15-79420	*BEARING	8	J20001-
10	561-15-72451	*GEAR	4	J20001-
11	561-15-62441	*GEAR	4	J20001-
12	561-15-79680	*BEARING	1	J20001-
13	561-15-72261	*HUB	1	J20001-
14	561-15-79540	*RING, SNAP	1	J20001-
15	561-15-79530	*RING, SNAP	1	J20001-
16	04077-00165	*RING	1	J20001-
17	561-15-72242	*GEAR	1	J20001-
18	561-15-72612	*GEAR, RING	1	J20001-
19	01010-81030	*BOLT	4	J20001-
20	01643-31032	*WASHER	4	J20001-




TRANSMISSION (6/10) (CARRIER) (3/4)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(561-15-71001)	TORQUE CONVERTER A.	1	J20001-
		THIS ASSEMBLY CONSISTS OF ALL PARTS SHOWN IN FIGS F3320-51A0 TO F3320-67A0.		
1	561-15-72331	*CARRIER	1	J20001-
2	561-15-72521	*SHAFT	4	J20001-
3	561-15-72421	*GEAR	4	J20001-
4	569-15-32580	*WASHER, THRUST	8	J20001-
5	561-15-79452	*BEARING	8	J20001-
6	561-15-79281	*RING, SEAL (K3)	1	J20001-
7	561-15-72160	*SPACER	1	J20001-
8	569-15-39520	*RING, SNAP	1	J20001-
9	569-15-39620	*BEARING	2	J20001-
10	04260-00635	*BALL	4	J20001-
11	561-15-72391	*COVER	1	J20001-
12	561-15-59110	*RING, SEAL	1	J20001-
13	561-15-72621	*GEAR, RING	1	J20001-
14	561-15-59520	*RING, SNAP	1	J20001-
15	561-15-72631	*GEAR, RING	1	J20001-
16	561-15-72641	*GEAR, RING	1	J20001-
17	561-15-71360	*SPACER	1	J20001-
18	04020-00616	*PIN, DOWEL	2	J20001-
19	561-15-72121	*SHAFT	1	J20001-
20	04064-08025	*RING	1	J20001-
21	04064-08025	*RING	1	J20001-
22	561-15-62250	*GEAR	1	J20001-
23	561-15-72231	*GEAR	1	J20001-
24	07018-21004	*RING, SEAL	1	J20001-
25	561-15-72872	*HUB	1	J20001-
26	04020-01228	*PIN	2	J20001-
27	01010-61440	*BOLT	8	J20001-
28	01643-31445	*WASHER	8	J20001-
29	14Y-22-13270	*RING, SEAL (K3)	1	J20001-




TRANSMISSION (7/10) (CARRIER) (4/4)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(561-15-71001)	TORQUE CONVERTER A.	1	J20001-
		THIS ASSEMBLY CONSISTS OF ALL PARTS SHOWN IN FIGS F3320-51A0 TO F3320-67A0.		
1	561-15-72311	*CARRIER	1	J20001-
2	561-15-69220	*SEAL RING, SEAL (K3)	1	J20001-
	561-15-71010	*SHAFT ASS'Y	4	J20001-
3	☆	**SHAFT	1	J20001-
4	569-15-31260	**PLUG	1	J20001-
5	561-15-72411	*GEAR	4	J20001-
6	561-15-79430	*BEARING	4	J20001-
7	569-15-32580	*WASHER, THRUST	8	J20001-
8	569-15-39620	*BEARING	1	J20001-
9	04260-00635	*BALL	4	J20001-
10	561-15-59310	*BEARING	1	J20001-
11	561-15-52281	*GEAR, RING	1	J20001-
12	561-15-59510	*RING, SNAP	1	J20001-
13	561-15-71351	*PLATE	1	J20001-
14	01010-81235	*BOLT	8	J20001-
15	01643-31232	*WASHER	8	J20001-
16	561-15-72210	*GEAR	1	J20001-
17	561-15-72291	*HUB	1	J20001-
18	198-15-29520	*RING	1	J20001-
19	561-15-72171	*SPACER	1	J20001-
20	561-15-52360	*COVER	1	J20001-
21	561-15-79510	*BEARING	1	J20001-
22	561-15-79910	*BEARING	1	J20001-
23	04071-00230	*RING, SNAP	1	J20001-
24	04064-07525	*RING, SNAP	1	J20001-
25	01010-81030	*BOLT	8	J20001-
26	01643-31032	*WASHER	8	J20001-




TRANSMISSION (8/10) (CASE)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(561-15-71001)	TORQUE CONVERTER A.	1	J20001-
		THIS ASSEMBLY CONSISTS OF ALL PARTS SHOWN IN FIGS F3320-51A0 TO F3320-67A0.		
	561-15-71030	*CASE ASS'Y	1	J20001-
1	★	**CASE	1	J20001-
2	567-15-41270	**PLUG	3	J20001-
3	567-15-41280	**PLUG	3	J20001-
4	01010-80835	**BOLT	3	J20001-
5	01643-30823	**WASHER	3	J20001-
6	07040-13618	*PLUG	2	J20001-
7	07002-63634	*O-RING (K3)	2	J20001-
8	04020-01024	*PIN	1	J20001-
9	04020-01434	*PIN,DOWEL	1	J20001-
10	566-15-11260	*PIN,DOWEL	1	J20001-
11	07048-02820	*PLUG	2	J20001-
12	04530-13045	*BOLT	2	J20001-
13	07000-73032	*O-RING (K3)	10	J20001-
14	07000-72055	*O-RING (K3)	1	J20001-
15	07000-72020	*O-RING (K3)	3	J20001-
16	07000-73032	*O-RING (K3)	1	J20001-
17	07000-73032	*O-RING (K3)	1	J20001-
18	07000-73032	*O-RING (K3)	1	J20001-
19	07000-73045	*O-RING (K3)	7	J20001-
20	07000-73045	*O-RING (K3)	1	J20001-
21	07000-73038	*O-RING (K3)	2	J20001-
22	01010-81020	*BOLT	2	J20001-
23	07000-73025	*O-RING (K3)	5	J20001-
24	07000-73022	*O-RING (K3)	5	J20001-
25	561-15-71330	*SLEEVE	2	J20001-
26	569-15-31310	*SLEEVE	2	J20001-
27	561-15-41330	*SLEEVE	1	J20001-
28	569-15-59110	*O-RING (K3)	1	J20001-
29	198-22-69640	*O-RING (K3)	1	J20001-




TRANSMISSION (9/10) (DOCKING UNIT)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(561-15-71001)	TORQUE CONVERTER A.	1	J20001-
		THIS ASSEMBLY CONSISTS OF ALL PARTS SHOWN IN FIGS F3320-51A0 TO F3320-67A0.		
1	561-15-76511	*COVER	1	J20001-
2	561-15-55910	*SPACER	8	J20001-
3	561-15-55940	*STUD	8	J20001-
4	01580-11008	*NUT	8	J20001-
5	01643-31032	*WASHER	8	J20001-
6	561-15-76721	*TUBE	1	J20001-
7	02782-10516	*ELBOW	2	J20001-
8	02896-61015	*O-RING (K3)	2	J20001-
9	07002-62034	*O-RING (K3)	2	J20001-
10	561-15-76711	*TUBE	1	J20001-
11	07000-73025	*O-RING (K3)	2	J20001-
12	01010-81040	*BOLT	3	J20001-
13	01643-51032	*WASHER	4	J20001-
14	01010-81085	*BOLT	1	J20001-
15	561-15-76731	*TUBE	1	J20001-
16	07005-01212	*GASKET (K3)	4	J20001-
17	07206-30812	*BOLT	2	J20001-
18	232-43-14170	*CLIP	2	J20001-
19	01010-81016	*BOLT	2	J20001-
20	01643-31032	*WASHER	2	J20001-
21	07049-01012	*PLUG	10	J20001-
22	07049-01620	*PLUG	6	J20001-
23	07049-02025	*PLUG	2	J20001-




TRANSMISSION (10/10) (INPUT AND OUTPUT)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(561-15-71001)	TORQUE CONVERTER A.	1	J20001-
		THIS ASSEMBLY CONSISTS OF ALL PARTS SHOWN IN FIGS F3320-51A0 TO F3320-67A0.		
	561-15-71060	*SHAFT ASS'Y	1	J20001-
1	★	**SHAFT	1	J20001-
2	★	**ORIFICE	1	J20001-
3	07018-20904	*RING,SEAL	1	J20001-
	561-15-71020	**CASE ASS'Y	1	J20001-
4	★	**CASE	1	J20001-
5	07043-70617	**PLUG	1	J20001-
6	07000-75220	*O-RING (K3)	1	J20001-
7	09608-05080	*PLATE, NAME	1	J20001-
8	04418-13060	*SCREW	4	J20001-
9	01010-61650	*BOLT	12	J20001-
10	01643-31645	*WASHER	16	J20001-
11	01011-81675	*BOLT	4	J20001-
12	561-15-73120	*CAGE	1	J20001-
13	01010-61665	*BOLT	8	J20001-
14	01643-31645	*WASHER	8	J20001-
15	07012-50130	*SEAL,OIL (K3)	1	J20001-
16	561-15-79650	*BEARING	1	J20001-
17	561-15-72180	*SPACER	1	J20001-
18	561-15-73412	*GEAR	1	J20001-
19	561-15-73430	*SPACER	1	J20001-
20	04070-00140	*RING	1	J20001-
21	04020-00616	*PIN,DOWEL	1	J20001-
22	561-15-72131	*COUPLING	1	J20001-
23	561-15-79661	*BEARING	1	J20001-
24	561-15-72381	*COVER	1	J20001-
25	561-15-79670	*BEARING	1	J20001-
26	569-15-39250	*RING,SEAL	1	J20001-
27	01252-71030	*BOLT	12	J20001-
28	01643-51032	*WASHER	12	J20001-




TRANSMISSION CONTROL VALVE (1/4)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(561-15-71001)	TORQUE CONVERTER A.	1	J20001-
		THIS ASSEMBLY CONSISTS OF ALL PARTS SHOWN IN FIGS F3320-51A0 TO F3320-67A0.		
	561-15-75001	*VALVE ASS'Y	1	J20001-
		THIS ASSEMBLY CONSISTS OF ALL PARTS SHOWN IN FIGS F3320-61A0 TO F3320-64A0.		
	425-15-35200	**ECMV ASS'Y	5	J20001-
1	☆	***BODY, VALVE	1	J20001-
2	☆	***SOLENOID	1	J20001-
3	☆	***VALVE	1	J20001-
4	☆	***BALL	1	J20001-
5	☆	***O-RING	1	J20001-
6	☆	***O-RING	1	J20001-
7	☆	***SPOOL	1	J20001-
8	☆	***SPRING, (L=24.5)	1	J20001-
9	☆	***SHIM, 0.5MM	3	J20001-
10	☆	***SHIM, 0.2MM	3	J20001-
11	☆	***PLUG	1	J20001-
12	☆	***SWITCH ASS'Y	1	J20001-
13	☆	***SPRING, (L=23.4)	1	J20001-
14	☆	***SHIM, 0.5MM	2	J20001-
15	☆	***SHIM, 0.2MM	1	J20001-
16	☆	***SHEET	1	J20001-
17	☆	***PIN	1	J20001-
18	☆	***SPRING, (L=18)	1	J20001-
19	☆	***SPOOL	1	J20001-
20	☆	***PLUG	1	J20001-
21	01252-60510	***BOLT	4	J20001-
22	714-23-15690	***BRACKET	1	J20001-
23	☆	***O-RING	1	J20001-
24	708-8E-16150	***PLUG	1	J20001-
25	☆	***PLUG	1	J20001-
26	07002-61023	***O-RING (K4)	1	J20001-
27	☆	***PLATE	1	J20001-
28	08034-20414	***BAND	1	J20001-
29	☆	***O-RING		J20001-




TRANSMISSION CONTROL VALVE (2/4)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(561-15-71001)	TORQUE CONVERTER A.	1	J20001-
		THIS ASSEMBLY CONSISTS OF ALL PARTS SHOWN IN FIGS F3320-51A0 TO F3320-67A0.		
	561-15-75001	*VALVE ASS'Y	1	J20001-
		THIS ASSEMBLY CONSISTS OF ALL PARTS SHOWN IN FIGS F3320-61A0 TO F3320-64A0.		
	566-15-85300	**ECMV ASS'Y	2	J20001-
1	☆	***BODY,VALVE	1	J20001-
2	☆	***SOLENOID	1	J20001-
3	☆	***VALVE	1	J20001-
4	☆	***BALL	1	J20001-
5	☆	***O-RING	1	J20001-
6	☆	***O-RING	1	J20001-
7	☆	***SPOOL	1	J20001-
8	☆	***SPRING,(L=24.5)	1	J20001-
9	☆	***SHIM, 0.5MM	3	J20001-
10	☆	***SHIM, 0.2MM	3	J20001-
11	☆	***PLUG	1	J20001-
12	☆	***SWITCH ASS'Y	1	J20001-
13	☆	***SPRING,(L=23.4)	1	J20001-
14	☆	***SHIM, 0.5MM	2	J20001-
15	☆	***SHIM, 0.2MM	1	J20001-
16	☆	***SHEET	1	J20001-
17	☆	***PIN	1	J20001-
18	☆	***SPRING,(L=18)	1	J20001-
19	☆	***SPOOL	1	J20001-
20	☆	***PLUG	1	J20001-
21	01252-60510	***BOLT	4	J20001-
22	714-23-15690	***BRACKET	1	J20001-
23	☆	***O-RING	1	J20001-
24	708-8E-16150	***PLUG	1	J20001-
25	☆	***PLUG	1	J20001-
26	07002-61023	***O-RING (K4)	1	J20001-
27	☆	***PLATE	1	J20001-
28	08034-00414	***BAND	1	J20001-
29	☆	***O-RING	1	J20001-




TRANSMISSION CONTROL VALVE (3/4)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(561-15-71001)	TORQUE CONVERTER A.	1	J20001-
		THIS ASSEMBLY CONSISTS OF ALL PARTS SHOWN IN FIGS F3320-51A0 TO F3320-67A0.		
	561-15-75001	*VALVE ASS'Y THIS ASSEMBLY CONSISTS OF ALL PARTS SHOWN IN FIGS F3320-61A0 TO F3320-64A0.	1	J20001-
	425-15-35300	*ECMV ASS'Y ***BODY	1	J20001-
1	☆	***SOLENOID	1	J20001-
2	☆	***VALVE	1	J20001-
3	☆	***BALL	1	J20001-
4	☆	***O-RING	1	J20001-
5	☆	***O-RING	1	J20001-
6	☆	***SPOOL	1	J20001-
7	☆	***SPRING,(L=24.5)	1	J20001-
8	☆	***SHIM, 0.5MM	3	J20001-
9	☆	***SHIM, 0.2MM	3	J20001-
10	☆	***PLUG	1	J20001-
11	☆	***PLATE	1	J20001-
12	☆	***SPRING, SEAT	1	J20001-
13	☆	***SLEEVE	1	J20001-
14	☆	***BOLT	4	J20001-
15	01252-60510	***BRACKET	1	J20001-
16	425-15-35330	***O-RING	1	J20001-
17	☆	***PLUG	1	J20001-
18	☆	***PLATE	1	J20001-
19	☆	***PLUG	1	J20001-
20	708-8E-16150	***O-RING (K4)	1	J20001-
21	07002-61023			




TRANSMISSION CONTROL VALVE (4/4)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(561-15-71001)	TORQUE CONVERTER A.	1	J20001-
		THIS ASSEMBLY CONSISTS OF ALL PARTS SHOWN IN FIGS F3320-51A0 TO F3320-67A0.		
	561-15-75001	*VALVE ASS'Y	1	J20001-
		THIS ASSEMBLY CONSISTS OF ALL PARTS SHOWN IN FIGS F3320-61A0 TO F3320-64A0.		
1	561-15-75131	**SEAT,VALVE	1	J20001-
2	01252-70650	**BOLT	32	J20001-
3	07000-72015	**O-RING (K4)	32	J20001-
4	07000-71007	**O-RING (K4)	8	J20001-
5	700-11-31980	**PLATE NAME	1	J20001-
6	723-11-15110	**PLUG	9	J20001-
7	07002-61623	**O-RING (K4)	9	J20001-
8	561-15-71720	**FILTER	1	J20001-
9	561-15-71730	***ELEMENT ASS'Y	1	J20001-
10	07000-02060	***O-RING (K4)	1	J20001-
11	01010-81030	**BOLT	1	J20001-
12	01643-31032	**WASHER	1	J20001-
13	01010-81080	**BOLT	1	J20001-
14	01643-31032	**WASHER	1	J20001-
15	07040-11812	**PLUG	1	J20001-
16	07002-61823	**O-RING (K4)	1	J20001-
17	07000-73022	**O-RING (K4)	2	J20001-
18	01252-71065	*BOLT	12	J20001-
19	01643-51032	*WASHER	12	J20001-
20	569-15-75140	*BOLT	1	J20001-
21	01643-31032	*WASHER	1	J20001-




TRANSMISSION LUBRICATION VALVE

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(561-15-71001)	TORQUE CONVERTER A.	1	J20001-
		THIS ASSEMBLY CONSISTS OF ALL PARTS SHOWN IN FIGS F3320-51A0 TO F3320-67A0.		
	561-15-74003	*VALVE ASS'Y	1	J20001-
1	☆	**VALVE BODY		J20001-
2	561-15-74611	**SPOOL	1	J20001-
3	561-13-76620	**PISTON	1	J20001-
4	561-15-74690	**SPRING	1	J20001-
5	561-15-74631	**COVER	1	J20001-
6	561-15-74641	**COVER	1	J20001-
7	07000-72012	**O-RING (K3)	1	J20001-
8	07000-72045	**O-RING (K3)	1	J20001-
9	07000-73030	**O-RING (K3)	1	J20001-
10	01010-81025	**BOLT	4	J20001-
11	01643-31032	**WASHER	4	J20001-
12	07040-10807	**PLUG	3	J20001-
13	07002-60823	**O-RING (K3)	3	J20001-
14	708-8E-16150	**PLUG	1	J20001-
15	07002-61023	**O-RING (K3)	1	J20001-
16	714-23-15551	**VALVE	1	J20001-
17	714-23-15530	**BALL	1	J20001-
18	561-13-76770	**PLUG	1	J20001-
19	714-23-15560	**O-RING (K3)	2	J20001-
20	07002-22034	**O-RING (K3)	1	J20001-
21	425-15-35220	**SOLENOID	1	J20001-
22	561-15-74660	**SENSOR	1	J20001-
23	07002-61023	*O-RING (K3)	1	J20001-
24	7861-93-3320	*SENSOR	1	J20001-
25	01010-81085	*BOLT	3	J20001-
26	01643-31032	*WASHER	3	J20001-
27	07000-72020	*O-RING (K3)	2	J20001-
28	07000-73045	*O-RING (K3)	2	J20001-
29	561-15-76741	*TUBE	1	J20001-
30	02781-00313	*UNION	1	J20001-
31	02781-0031D	*UNION	1	J20001-
32	02896-11009	*O-RING (K3)	2	J20001-
33	07002-61823	*O-RING (K3)	1	J20001-
34	07002-61423	*O-RING (K3)	1	J20001-




TRANSMISSION OIL PAN

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(561-15-71001)	TORQUE CONVERTER A.	1	J20001-
		THIS ASSEMBLY CONSISTS OF ALL PARTS SHOWN IN FIGS F3320-51A0 TO F3320-67A0.		
	561-15-71501	*OIL PAN ASS'Y	1	J20001-
1	561-15-71551	**TANK	1	J20001-
2	561-15-71581	**PLATE	1	J20001-
3	01010-81020	**BOLT	6	J20001-
4	01643-31032	**WASHER	6	J20001-
5	14X-49-12340	**COVER	4	J20001-
6	07000-72105	**O-RING (K3)	4	J20001-
7	01010-81025	**BOLT	16	J20001-
8	01643-31032	**WASHER	16	J20001-
9	569-15-51510	**MAGNET ASS'Y	4	J20001-
10	14X-49-12320	**SPRING	4	J20001-
	6693-22-5600	**VALVE ASS'Y	1	J20001-
11	6693-22-5610	***BODY	1	J20001-
12	6693-22-5620	***VALVE	1	J20001-
13	07040-02412	***PLUG	1	J20001-
14	04020-00514	***PIN	1	J20001-
15	07000-73028	**O-RING (K3)	1	J20001-
16	01010-81025	**BOLT	2	J20001-
17	01643-31032	**WASHER	2	J20001-
18	566-60-41300	**VALVE ASS'Y	2	J20001-
19	561-15-71560	**BLOCK	2	J20001-
20	07000-72085	**O-RING (K3)	2	J20001-
21	07042-70108	**PLUG	2	J20001-
22	01010-81250	**BOLT	8	J20001-
23	01643-31232	**WASHER	8	J20001-
24	561-15-71430	*GASKET (K3)	1	J20001-
25	01010-81030	*BOLT	40	J20001-
26	01643-31032	*WASHER	40	J20001-



TRANSMISSION SENSOR


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(561-15-71001)	TORQUE CONVERTER A.	1	J20001-
		THIS ASSEMBLY CONSISTS OF ALL PARTS SHOWN IN FIGS F3320-51A0 TO F3320-67A0.		
1	561-15-75822	*WIRING HARNESS	1	J20001-
2	04434-52510	*CLIP	1	J20001-
3	04434-52310	*CLIP	2	J20001-
4	04434-51610	*CLIP	1	J20001-
5	04434-51210	*CLIP	7	J20001-
6	04434-51010	*CLIP	1	J20001-
7	04434-50810	*CLIP	4	J20001-
8	04434-50610	*CLIP	1	J20001-
9	01010-81020	*BOLT	17	J20001-
10	01643-31032	*WASHER	17	J20001-
11	01010-81080	*BOLT	1	J20001-
12	01643-31032	*WASHER	1	J20001-
13	175-61-17240	*COLLAR	1	J20001-
14	561-15-78121	*COVER	1	J20001-
15	561-15-78131	*COVER	1	J20001-
16	561-15-78141	*COVER	1	J20001-
17	01010-81020	*BOLT	6	J20001-
18	01643-31032	*WASHER	6	J20001-
19	7861-93-2330	*SENSOR	3	J20001-
20	421-06-35121	*SENSOR	1	J20001-
21	561-15-76751	*ELBOW	1	J20001-
22	07002-62034	*O-RING (K3)	1	J20001-
23	08034-20414	*BAND	7	J20001-
24	08193-21012	*CLIP	8	J20001-
25	01010-81020	*BOLT	7	J20001-
26	01643-31032	*WASHER	7	J20001-



REAR AXLE (DIFFERENTIAL) (1/3)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-88-70002	AXLE ASS'Y,ABS/ASR	1	J20001-
	561-22-71002	*DIFFERENTIAL ASS'Y	1	J20001-
	561-22-71102	**CASE ASS'Y	1	J20001-
1	☆	***CASE	1	J20001-
2	01011-63080	***BOLT	8	J20001-
4	01643-33080	***WASHER	8	J20001-
4	04020-01842	***PIN,DOWEL	4	J20001-
5	☆	***CAP	1	J20001-
6	☆	***CAP	1	J20001-
7	01643-31645	**WASHER	4	J20001-
8	561-22-61150	**LOCK	2	J20001-
9	01010-61640	**BOLT	4	J20001-
10	585-22-21140	**NUT	2	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up


REAR AXLE (DIFFERENTIAL) (2/3)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-88-70002	AXLE ASS'Y,ABS/ASR	1	J20001-
	561-22-71002	*DIFFERENTIAL ASS'Y	1	J20001-
1	561-22-71350	**CAGE	1	J20001-
2	561-22-71810	**BEARING	1	J20001-
3	561-22-71820	**BEARING	1	J20001-
4	07000-15340	**O-RING	1	J20001-
5	561-81-00050	**SHIM ASS'Y	1	J20001-
	☆	***SHIM, 0.2MM	4	J20001-
	☆	***SHIM, 0.3MM	3	J20001-
	☆	***SHIM, 1.0MM	3	J20001-
	☆	***SHIM, 0.05MM	3	J20001-
6	561-22-71311	**CAGE	1	J20001-
7	07000-15315	*O-RING	1	J20001-
8	07012-50150	**SEAL	1	J20001-
9	561-22-71230	**COUPLING	1	J20001-
10	427-22-11240	**HOLDER	1	J20001-
11	562-15-19970	**O-RING	1	J20001-
12	01643-33690	**WASHER	1	J20001-
13	562-22-11950	**BOLT	1	J20001-
14	561-22-71300	**SHIM ASS'Y	1	J20001-
	☆	***SHIM, 1.0MM	3	J20001-
	☆	***SHIM, 0.3MM	2	J20001-
	☆	***SHIM, 0.2MM	4	J20001-
15	01010-62080	**BOLT	16	J20001-
16	01643-32060	**WASHER	16	J20001-
	561-22-71202	**PINION GEAR ASS'Y	1	J20001-
17	☆	***PINION	1	J20001-
18	☆	***GEAR	1	J20001-




REAR AXLE (DIFFERENTIAL) (3/3)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-88-70002	AXLE ASS'Y,ABS/ASR	1	J20001-
	561-22-71002	*DIFFERENTIAL ASS'Y	1	J20001-
	561-88-48340	**PINION ASS'Y	4	J20001-
1	561-88-48350	***PINION	4	J20001-
2	561-88-68850	***BEARING	4	J20001-
3	561-88-68440	***SLEEVE	4	J20001-
4	561-88-68990	***NUT	4	J20001-
5	561-22-61410	**SHAFT	1	J20001-
	561-22-71502	**CASE ASS'Y	1	J20001-
6	☆	***CASE	1	J20001-
7	☆	***CASE	1	J20001-
8	01011-62455	**BOLT	12	J20001-
9	581-22-14680	**WASHER	12	J20001-
10	561-22-61990	**PIN	4	J20001-
11	561-22-61530	**WASHER	2	J20001-
12	561-22-61431	**GEAR	2	J20001-
13	04020-01842	**PIN	4	J20001-
14	01010-62475	**BOLT	32	J20001-
15	01643-32460	**WASHER	32	J20001-
16	561-22-61960	**BEARING	2	J20001-
17	01010-62465	**BOLT	24	J20001-
18	01643-32460	**WASHER	24	J20001-
19	581-22-11750	**O-RING	1	J20001-
20	04020-01842	**PIN	2	J20001-
21	01582-03024	**NUT	1	J20001-
22	561-22-73510	**SCREW	1	J20001-




REAR AXLE (FINAL DRIVE) (L.H.) (1/2)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-88-70002	AXLE ASS'Y,ABS/ASR	1	J20001-
	561-88-70201	*FINAL DRIVE ASS'Y,ABS/ASR	1	J20001-
1	561-22-72713	**HUB	1	J20001-
2	569-22-72860	**BOLT	20	J20001-
3	569-22-72850	**BOLT	20	J20001-
4	561-22-72961	**BEARING	1	J20001-
5	561-22-62970	**BEARING	1	J20001-
6	561-22-72541	**GEAR	1	J20001-
7	561-22-72313	**HUB	1	J20001-
8	285-22-12341	**HOLDER	8	J20001-
9	01010-61225	**BOLT	16	J20001-
10	01643-31232	**WASHER	16	J20001-
11	561-22-72531	**GEAR	3	J20001-
12	561-22-72520	**BEARING	3	J20001-
13	561-22-72612	**CARRIER	1	J20001-
14	561-22-72511	**SHAFT	3	J20001-
15	04260-01905	**BALL	3	J20001-
16	07044-12412	**PLUG	1	J20001-
17	07002-12434	**O-RING	1	J20001-
18	01010-62465	**BOLT	39	J20001-
19	581-22-14680	**WASHER	39	J20001-
20	07000-12025	**O-RING	1	J20001-
21	562-22-12920	**O-RING	1	J20001-
22	04071-00180	**RING	3	J20001-




REAR AXLE (FINAL DRIVE) (L.H.) (2/2)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-88-70002	AXLE ASS'Y,ABS/ASR	1	J20001-
	561-88-70201	*FINAL DRIVE ASS'Y,ABS/ASR	1	J20001-
1	561-22-72141	**RETAINER	1	J20001-
2	07000-A5320	**O-RING	1	J20001-
3	561-22-72200	**SHIM ASS'Y	1	J20001-
	☆	***SHIM, 1.0MM	3	J20001-
	☆	***SHIM, 0.3MM	3	J20001-
	☆	***SHIM, 0.2MM	2	J20001-
	☆	***SHIM, 0.05MM	1	J20001-
4	561-22-72210	**RETAINER	1	J20001-
5	01010-62090	**BOLT	16	J20001-
6	568-22-12442	**SPACER	1	J20001-
7	561-22-72420	**GEAR	1	J20001-
8	561-22-62810	**RING	1	J20001-
9	561-22-72622	**COVER	1	J20001-
10	562-22-12630	**BUTTON	1	J20001-
11	41E-14-11110	**O-RING	1	J20001-
12	01010-61235	**BOLT	14	J20001-
13	01643-31232	**WASHER	14	J20001-
14	07044-13620	**PLUG	1	J20001-
15	07002-13634	**O-RING	1	J20001-
16	561-22-72410	**SHAFT	1	J20001-
17	561-22-73212	**TUBE	1	J20001-
18	07000-15405	**O-RING	1	J20001-
19	568-33-11440	**O-RING	1	J20001-
20	561-30-71620	**PLATE	1	J20001-
21	01010-61225	**BOLT	2	J20001-
22	01643-31232	**WASHER	2	J20001-
23	569-22-72870	**NUT	20	J20001-
24	426-09-11520	**WASHER	20	J20001-
25	569-22-72870	**NUT	20	J20001-
26	426-09-11520	**WASHER	20	J20001-
27	561-22-72891	**COVER	1	J20001-
28	01010-61650	**BOLT	4	J20001-
29	01643-31645	**WASHER	4	J20001-




REAR AXLE (FINAL BRAKE) (L.H.) (ABS/ASR) (1/4)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-88-70002	AXLE ASS'Y	1	J20001-
	561-88-70201	*FINAL DRIVE ASS'Y	1	J20001-
1	561-33-71115	**CYLINDER	1	J20001-
2	07000-F2025	**O-RING	5	J20001-
3	561-34-71114	**CYLINDER	1	J20001-
4	01010-62070	**BOLT	8	J20001-
5	708-8F-11260	**WASHER	8	J20001-
6	561-34-71124	**PISTON	1	J20001-
7	561-33-71123	**PISTON	1	J20001-
8	561-34-71220	**SPRING	39	J20001-
9	561-34-71210	**SPRING	39	J20001-
10	07040-12012	**PLUG	9	J20001-
11	07002-12034	**O-RING	9	J20001-
12	07040-11209	**PLUG	4	J20001-
13	07002-11223	**O-RING	4	J20001-
14	195-27-31490	**RING	1	J20001-
15	561-22-73740	**STUD	32	J20001-
16	569-33-71980	**PIN	1	J20001-
17	07040-11612	**PLUG	3	J20001-
18	07002-11623	**O-RING	3	J20001-
19	07040-11409	**PLUG	1	J20001-
20	07002-11423	**O-RING	1	J20001-
21	07040-11409	**PLUG	2	J20001-
22	07002-11423	**O-RING	2	J20001-
23	561-34-71540	**SEAL	1	J20001-
24	561-34-71630	**SEAL	1	J20001-
25	561-34-71590	**RING	1	J20001-
26	561-34-71680	**RING	1	J20001-
27	561-33-71510	**SEAL	1	J20001-
28	561-33-71410	**SEAL	1	J20001-
29	561-33-71550	**RING	1	J20001-
30	561-33-71450	**RING	1	J20001-
31	561-33-71840	**FLANGE	1	J20001-
32	07000-F2030	**O-RING	1	J20001-
33	01643-51232	**WASHER	4	J20001-
34	01010-81230	**BOLT	4	J20001-




REAR AXLE (FINAL BRAKE) (L.H.) (ABS/ASR) (2/4)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-88-70002	AXLE ASS'Y,ABS/ASR	1	J20001-
	561-88-70201	*FINAL DRIVE ASS'Y,ABS/ASR	1	J20001-
1	561-33-71931	**RETAINER	1	J20001-
2	01011-63045	**BOLT	20	J20001-
3	01643-33080	**WASHER	20	J20001-
4	561-33-71312	**GEAR	1	J20001-
	428-33-00021	**FLOATING SEAL ASS'Y	1	J20001-
5	568-33-11364	**RING	2	J20001-
6	428-33-11650	**O-RING	2	J20001-
	425-33-00111	**FLOATING SEAL A.	1	J20001-
7	287-33-11910	**RING	2	J20001-
8	425-33-11650	**O-RING	2	J20001-
9	568-33-11511	**SEAL	1	J20001-
10	561-88-71171	**RETAINER	1	J20001-
11	07000-A5495	**O-RING	1	J20001-
12	01252-61050	**BOLT	10	J20001-
13	561-88-71215	**GEAR, OUTER (L.H)	1	J20001-
14	561-33-71281	**SPACER	1	J20001-
15	561-33-71240	**DISC	9	J20001-
16	561-33-71230	**PLATE	8	J20001-
17	561-33-71261	**DAMPER	1	J20001-
18	561-33-71271	**DAMPER	1	J20001-
19	561-33-71761	**PLATE	4	J20001-
20	0101-60816	**BOLT	8	J20001-
21	01011-62060	**BOLT	45	J20001-
22	01643-32060	**WASHER	45	J20001-
23	195-27-31490	**O-RING	1	J20001-
24	01010-62090	**BOLT	36	J20001-
25	01643-32060	**WASHER	36	J20001-
26	07000-F2025	**O-RING	3	J20001-
27	07040-11007	**PLUG	5	J20001-
28	07002-11023	**O-RING	5	J20001-



REAR AXLE (FINAL BRAKE) (L.H.) (ABS/ASR) (3/4)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-88-70002	AXLE ASS'Y,ABS/ASR	1	J20001-
	561-88-70201	*FINAL DRIVE ASS'Y,ABS/ASR	1	J20001-
1	286-22-11850	**O-RING	1	J20001-
2	232-32-11350	**CAP	2	J20001-
3	566-32-11430	**BLEEDER	2	J20001-
4	569-33-72140	**JOINT	2	J20001-
5	07002-11223	**O-RING	2	J20001-
6	569-33-71720	**GUIDE	1	J20001-
7	561-33-71740	**GAGE	1	J20001-
8	07000-11005	**O-RING	1	J20001-
9	569-33-71730	**CAP	1	J20001-
10	07002-12434	**O-RING	1	J20001-
11	01643-32780	**WASHER	32	J20001-
12	01580-02722	**NUT	32	J20001-
13	01252-71280	**BOLT	4	J20001-
14	569-33-81241	**ADAPTER	1	J20001-
15	01010-62080	**BOLT	4	J20001-
16	01643-32060	**WASHER	4	J20001-
17	07002-12034	**O-RING	1	J20001-
18	07000-12018	**O-RING	1	J20001-
19	561-33-71921	**TANK	1	J20001-
20	561-33-71251	**COVER	1	J20001-
21	07040-11209	**PLUG	1	J20001-
22	07002-11223	**O-RING	1	J20001-
23	01010-61035	**BOLT	16	J20001-
24	01643-31032	**WASHER	16	J20001-
25	07834-00617	**ELBOW	1	J20001-
26	07832-00614	**NUT	1	J20001-
27	07831-00612	**SLEEVE	1	J20001-
28	07822-00608	**TUBE	1	J20001-
29	04434-51012	**CLIP	2	J20001-
30	01643-31232	**WASHER	2	J20001-
31	01010-81220	**BOLT	2	J20001-



REAR AXLE (FINAL BRAKE) (L.H.) (ABS/ASR) (4/4)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-88-70002	AXLE ASS'Y,ABS/ASR	1	J20001-
	561-88-70201	*FINAL DRIVE ASS'Y,ABS/ASR	1	J20001-
1	561-88-71311	*COVER	1	J20001-
2	561-88-71321	**COVER	1	J20001-
3	561-88-71332	**COVER	1	J20001-
4	01010-81635	**BOLT	2	J20001-
5	01643-31645	**WASHER	2	J20001-
6	01010-81220	**BOLT	3	J20001-
7	01643-31232	**WASHER	3	J20001-
8	04434-51512	**CLIP	3	J20001-
9	01010-81220	**BOLT	3	J20001-
10	01643-31232	**WASHER	3	J20001-
11	01010-62035	**BOLT	2	J20001-
12	01643-32060	**WASHER	2	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

REAR AXLE (FINAL BRAKE) (R.H.) (1/2)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-88-70002	AXLE ASS'Y,ABS/ASR	1	J20001-
	561-88-70301	*FINAL DRIVE ASS'Y,ABS/ASR	1	J20001-
1	561-22-72713	**HUB	1	J20001-
2	569-22-72860	**BOLT	20	J20001-
3	569-22-72850	**BOLT	20	J20001-
4	561-22-72961	**BEARING	1	J20001-
5	561-22-62970	**BEARING	1	J20001-
6	561-22-72541	**GEAR	1	J20001-
7	561-22-72313	**HUB	1	J20001-
8	285-22-12341	**HOLDER	8	J20001-
9	01010-61225	**BOLT	16	J20001-
10	01643-31232	**WASHER	16	J20001-
11	561-22-72531	**GEAR	3	J20001-
12	561-22-72520	**BEARING	3	J20001-
13	561-22-72612	**CARRIER	1	J20001-
14	561-22-72511	**SHAFT	3	J20001-
15	04260-01905	**BALL	3	J20001-
16	07044-12412	**PLUG	1	J20001-
17	07002-12434	**O-RING	1	J20001-
18	01010-62465	**BOLT	39	J20001-
19	581-22-14680	**WASHER	39	J20001-
20	07000-12025	**O-RING	1	J20001-
21	562-22-12920	**O-RING	1	J20001-
22	04071-00180	**RING	3	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

REAR AXLE (FINAL BRAKE) (R.H.) (2/2)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-88-70002	AXLE ASS'Y,ABS/ASR	1	J20001-
	561-88-70301	*FINAL DRIVE ASS'Y,ABS/ASR	1	J20001-
1	561-22-72141	**RETAINER	1	J20001-
2	07000-A5320	**O-RING	1	J20001-
3	561-22-72200	**SHIM ASS'Y	1	J20001-
	561-22-72230	***SHIM, 1.0MM	3	J20001-
	561-22-72240	***SHIM, 0.3MM	3	J20001-
	561-22-72250	***SHIM, 0.2MM	2	J20001-
	561-22-72260	***SHIM, 0.05MM	1	J20001-
4	561-22-72210	**RETAINER	1	J20001-
5	01010-62090	**BOLT	16	J20001-
6	568-22-12442	**SPACER	1	J20001-
7	561-22-72420	**GEAR	1	J20001-
8	561-22-62810	**RING	1	J20001-
9	561-22-72622	**COVER	1	J20001-
10	562-22-12630	**BUTTON	1	J20001-
11	41E-14-11110	**O-RING	1	J20001-
12	01010-61235	**BOLT	14	J20001-
13	01643-31232	**WASHER	14	J20001-
14	07044-13620	**PLUG	1	J20001-
15	07002-13634	**O-RING	1	J20001-
16	561-22-72410	**SHAFT	1	J20001-
17	561-22-73212	**TUBE	1	J20001-
18	07000-15405	**O-RING	1	J20001-
19	568-33-11440	**O-RING	1	J20001-
20	561-30-71620	**PLATE	1	J20001-
21	01010-61225	**BOLT	2	J20001-
22	01643-31232	**WASHER	2	J20001-
23	569-22-72870	**NUT	20	J20001-
24	426-09-11520	**WASHER	20	J20001-
25	569-22-72870	**NUT	20	J20001-
26	426-09-11520	**WASHER	20	J20001-
27	561-22-72891	**COVER	1	J20001-
28	01010-61650	**BOLT	4	J20001-
29	01643-31645	**WASHER	4	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up

REAR AXLE (FINAL BRAKE) (R.H.) (ABS/ASR) (1/4)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-88-70002	AXLE ASS'Y,ABS/ASR	1	J20001-
	561-88-70301	*FINAL DRIVE ASS'Y,ABS/ASR	1	J20001-
1	561-33-75111	**CYLINDER	1	J20001-
2	07000-F2025	**O-RING	5	J20001-
3	561-34-75112	**CYLINDER	1	J20001-
4	01010-62070	**BOLT	8	J20001-
5	708-8F-11260	**WASHER	8	J20001-
6	561-34-71124	**PISTON	1	J20001-
7	561-33-71123	**PISTON	1	J20001-
8	561-34-71220	**SPRING	39	J20001-
9	561-34-71210	**SPRING	39	J20001-
10	07040-12012	**PLUG	9	J20001-
11	07002-12034	**O-RING	9	J20001-
12	07040-11209	**PLUG	4	J20001-
13	07002-11223	**O-RING	4	J20001-
14	195-27-31490	**O-RING	1	J20001-
15	561-22-73740	**STUD	32	J20001-
16	569-33-71980	**PIN	1	J20001-
17	07040-11612	**PLUG	3	J20001-
18	07002-11623	**O-RING	3	J20001-
19	07040-11409	**PLUG	1	J20001-
20	07002-11423	**O-RING	1	J20001-
21	07040-11409	**PLUG	2	J20001-
22	07002-11423	**O-RING	2	J20001-
23	561-34-71540	**SEAL	1	J20001-
24	561-34-71630	**SEAL	1	J20001-
25	561-34-71590	**RING	1	J20001-
26	561-34-71680	**RING	1	J20001-
27	561-33-71510	**SEAL	1	J20001-
28	561-33-71410	**SEAL	1	J20001-
29	561-33-71550	***RING	1	J20001-
30	561-33-71450	**RING	1	J20001-
31	561-33-71840	**FLANGE	1	J20001-
32	07000-F2030	**O-RING	1	J20001-
33	01643-51232	**WASHER	4	J20001-
34	01010-81230	**BOLT	4	J20001-



REAR AXLE (FINAL BRAKE) (R.H.) (ABS/ASR) (2/4)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-88-70002	AXLE ASS'Y,ABS/ASR	1	J20001-
	561-88-70301	*FINAL DRIVE ASS'Y,ABS/ASR	1	J20001-
1	561-33-71931	**RETAINER	1	J20001-
2	01011-63045	**BOLT	20	J20001-
3	01643-33080	**WASHER	20	J20001-
4	561-33-71312	**GEAR	1	J20001-
	428-33-00021	**FLOATING SEAL ASS'Y	1	J20001-
5	568-33-11364	**RING	2	J20001-
6	428-33-11650	**O-RING	2	J20001-
	425-33-00111	**FLOATING SEAL A.	1	J20001-
7	287-33-11910	***RING	2	J20001-
8	425-33-11650	**O-RING	2	J20001-
9	568-33-11511	**SEAL	1	J20001-
10	561-88-71171	**RETAINER	1	J20001-
11	07000-A5495	**O-RING	1	J20001-
12	01252-61050	**BOLT	10	J20001-
13	561-88-75212	**GEAR,OUTER (R.H.)	1	J20001-
14	561-33-71281	**SPACER	1	J20001-
15	561-33-71240	**DISC	9	J20001-
16	561-33-71230	**PLATE	8	J20001-
17	561-33-71261	**DAMPER	1	J20001-
18	561-33-71271	**DAMPER	1	J20001-
19	561-33-71761	**PLATE	4	J20001-
20	01010-60816	**BOLT	8	J20001-
21	01011-62060	**BOLT	45	J20001-
22	01643-32060	**WASHER	45	J20001-
23	195-27-31490	**O-RING	1	J20001-
24	01010-62090	**BOLT	36	J20001-
25	01643-32060	**WASHER	36	J20001-
26	07000-F2025	**O-RING	3	J20001-
27	07040-11007	**PLUG	5	J20001-
28	07002-11023	**O-RING	5	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up

REAR AXLE (FINAL BRAKE) (R.H.) (ABS/ASR) (3/4)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-88-70002	AXLE ASS'Y,ABS/ASR	1	J20001-
	561-88-70301	*FINAL DRIVE ASS'Y,ABS/ASR	1	J20001-
1	286-22-11850	**O-RING	1	J20001-
2	232-32-11350	**CAP	2	J20001-
3	566-32-11430	**BLEEDER	2	J20001-
4	569-33-72140	**JOINT	2	J20001-
5	07002-11223	**O-RING	2	J20001-
6	569-33-71720	**GUIDE	1	J20001-
7	561-33-71740	**GAGE	1	J20001-
8	07000-11005	**O-RING	1	J20001-
9	569-33-71730	**CAP	1	J20001-
10	07002-12434	**O-RING	1	J20001-
11	01643-32780	**WASHER	32	J20001-
12	01580-02722	**NUT	32	J20001-
13	01252-71280	**BOLT	4	J20001-
14	569-33-81241	**ADAPTER	1	J20001-
15	01010-62080	**BOLT	4	J20001-
16	01643-32060	**WASHER	4	J20001-
17	07002-12034	**O-RING	1	J20001-
18	07000-12018	**O-RING	1	J20001-
19	561-33-71921	**TANK	1	J20001-
20	561-33-71251	**COVER	1	J20001-
21	07040-11209	**PLUG	1	J20001-
22	07002-11223	**O-RING	1	J20001-
23	01010-61035	**BOLT	16	J20001-
24	01643-31032	**WASHER	16	J20001-
25	07834-00617	**ELBOW	1	J20001-
26	07832-00614	**NUT	1	J20001-
27	07831-00612	**SLEEVE	1	J20001-
28	07822-00608	**TUBE	1	J20001-
29	04434-51012	**CLIP	2	J20001-
30	01643-31232	**WASHER	2	J20001-
31	01010-81220	**BOLT	2	J20001-



REAR AXLE (FINAL BRAKE) (R.H.) (ABS/ASR) (4/4)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-88-70002	AXLE ASS'Y,ABS/ASR	1	J20001-
	561-88-70301	*FINAL DRIVE ASS'Y,ABS/ASR	1	J20001-
1	561-88-75310	**COVER	1	J20001-
2	561-88-75320	**COVER	1	J20001-
3	561-88-75330	**COVER	1	J20001-
4	01010-81635	**BOLT	2	J20001-
5	01643-31645	**WASHER	2	J20001-
6	01010-81220	**BOLT	3	J20001-
7	01643-31232	**WASHER	3	J20001-
8	04434-51512	**CLIP	3	J20001-
9	01010-81220	**BOLT	3	J20001-
10	01643-31232	**WASHER	3	J20001-
11	01010-62035	**BOLT	2	J20001-
12	01643-32060	**WASHER	2	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

REAR AXLE (HOUSING)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-88-70002	AXLE ASS'Y,ABS/ASR	1	J20001-
1	561-22-73113	*HOUSING	1	J20001-
2	07030-00252	*BREATHER	1	J20001-
3	561-22-63680	*JOINT	1	J20001-
4	07044-13620	*PLUG	2	J20001-
5	07002-13634	*O-RING	2	J20001-
6	815-02-10110	*PLATE NAME	1	J20001-
7	04418-13060	*SCREW	4	J20001-
8	561-52-81170	*BUSHING	8	J20001-
9	561-52-8A180	*BUSHING	4	J20001-
10	561-22-73320	*TUBE	2	J20001-
11	01010-61225	*BOLT	4	J20001-
12	01643-31232	*WASHER	4	J20001-
13	561-22-63690	*SEAT	2	J20001-
14	569-40-61710	*WASHER	2	J20001-
15	01010-61450	*.BOLT	2	J20001-
16	561-22-63690	*SEAT	2	J20001-
17	569-40-61710	*WASHER	2	J20001-
18	01643-31445	*WASHER	2	J20001-
19	01010-61465	*BOLT	2	J20001-
20	561-22-73690	*SEAT	2	J20001-
21	569-40-61710	*WASHER	2	J20001-
22	01010-61450	*BOLT	2	J20001-
23	569-22-73680	*BOSS	2	J20001-
24	561-22-73461	*HANDLE	1	J20001-
25	01010-61625	*BOLT	2	J20001-
26	01643-31645	*WASHER	2	J20001-
27	561-22-73651	*BRACKET	1	J20001-
28	01010-82040	*BOLT	2	J20001-
29	01643-32060	*WASHER	2	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up


REAR AXLE (BRAKE PIPING) (ABS/ASR)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-88-70002	AXLE ASS'Y,ABS/ASR	1	J20001-
1	561-88-83611	*BRACKET	1	J20001-
2	01010-81230	*BOLT	2	J20001-
3	01643-31232	*WASHER	2	J20001-
4	569-43-83811	*BLOCK	1	J20001-
5	01010-81070	*BOLT	2	J20001-
6	01643-31032	*WASHER	2	J20001-
7	569-43-83820	*BRACKET	1	J20001-
8	01643-51232	*WASHER	4	J20001-
9	566-32-11430	*BLEEDER	1	J20001-
10	232-32-11350	*CAP	1	J20001-
11	02781-00422	*UNION	2	J20001-
12	07002-22034	*O-RING	2	J20001-
13	02896-21012	*O-RING	2	J20001-
14	02782-10516	*ELBOW	1	J20001-
15	07002-22034	*O-RING	1	J20001-
16	02896-21015	*O-RING	1	J20001-
17	561-43-86190	*SLACK ADJUSTER ASS'Y.....	1	J20001-
18	01010-81025	*BOLT	4	J20001-
19	01643-31032	*WASHER	4	J20001-
20	02781-00422	*UNION	2	J20001-
21	07002-22034	*O-RING	2	J20001-
22	02896-21012	*O-RING	2	J20001-
23	561-88-83661	*TUBE	1	J20001-
24	561-88-83651	*TUBE	1	J20001-
25	02781-00422	*UNION	2	J20001-
26	07002-22034	*O-RING	2	J20001-
27	02896-21012	*O-RING	2	J20001-
28	561-88-83631	*TUBE	1	J20001-
29	561-88-83641	*TUBE	1	J20001-
30	02781-00422	*UNION	2	J20001-
31	07002-22034	*O-RING	2	J20001-
32	02896-21012	*O-RING	2	J20001-
33	561-43-83981	*BRACKET	1	J20001-
34	01010-81225	*BOLT	2	J20001-
35	01643-31232	*WASHER	2	J20001-
36	07283-32236	*CLIP	2	J20001-
37	01597-01009	*NUT	4	J20001-
38	01643-31032	*WASHER	4	J20001-
39	561-43-83991	*BRACKET	1	J20001-
40	01010-81225	*BOLT	2	J20001-
41	01643-31232	*WASHER	2	J20001-
42	07283-32236	CLIP	2	J20001-
43	01597-01009	*NUT	4	J20001-
44	01643-31032	*WASHER	4	J20001-



REAR AXLE (BRAKE PIPING) (ABS/ASR)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
45	02781-00422	*UNION	2	J20001-
46	02896-21012	*O-RING	2	J20001-
47	07002-22034	*O-RING	2	J20001-



REAR AXLE (AXLE SENSOR)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-88-70002	AXLE ASS'Y,ABS/ASR	1	J20001-
1	566-88-66141	SENSOR	2	J20001-
2	561-88-66152	COLLAR	2	J20001-
3	416-881-1140	PLATE	4	J20001-
4	04434-51512	CLIP	8	J20001-
5	07283-32236	CLIP	4	J20001-
6	01643-31032	WASHER	8	J20001-
7	01597-01009	NUT	8	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

REAR AXLE (BLIND PARTS) (FOR WITH ABS)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	07378-12000	HEAD	2	J20001-
2	07000-12060	O-RING	2	J20001-
3	07371-32076	FLANGE	4	J20001-
4	01643-51232	WASHER	8	J20001-
5	07372-21240	BOLT	8	J20001-
6	07378-11400	HEAD	2	J20001-
7	07000-13048	O-RING	2	J20001-
8	07371-31465	FLANGE	4	J20001-
9	01643-51232	WASHER	8	J20001-
10	07372-21240	BOLT	8	J20001-
11	02789-00522	NUT	1	J20001-
12	02789-00422	NUT	2	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

REAR AXLE SUPPORT

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-52-81210	PIN	6	J20001-
2	561-52-81170	BUSHING	8	J20001-
3	01010-81430	BOLT	4	J20001-
4	01010-81425	BOLT	2	J20001-
5	569-40-61710	WASHER	6	J20001-
6	561-52-81150	SPACER	8	J20001-
7	561-52-8A180	BUSHING	4	J20001-
8	561-52-81310	ROD	2	J20001-
9	561-50-82310	BUSHING	4	J20001-
10	07000-12090	O-RING	8	J20001-
11	561-52-81140	BOOT	8	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

TRANSMISSION MOUNTING PARTS

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-16-82111	TRUNNION	1	J20001-
2	07020-00000	FITTING	1	J20001-
3	515-50-11731	HEAD	2	J20001-
4	561-16-82120	BRACKET	2	J20001-
5	01010-81680	BOLT	4	J20001-
6	01643-31645	WASHER	4	J20001-
7	561-16-82150	PIN,L.H.	1	J20001-
8	561-16-82180	PIN,R.H.	1	J20001-
9	01010-81655	BOLT	14	J20001-
10	01643-31645	WASHER	14	J20001-
11	04020-01842	PIN,DOWEL	2	J20001-
12	569-14-41130	CUSHION	2	J20001-
13	561-16-62131	BRACKET	2	J20001-
14	01010-81630	BOLT	2	J20001-
15	01643-31645	WASHER	2	J20001-
16	565-54-12841	WASHER	2	J20001-
17	566-14-41190	PLATE	4	J20001-
18	01010-81690	BOLT	8	J20001-
19	01643-31645	WASHER	8	J20001-
20	566-14-41140	SHIM ^a 0.5MM	16	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up


FRONT AXLE (R.H.) (HUB)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-27-71212	HUB	1	J20001-
2	561-27-71130	RETAINER	1	J20001-
3	561-27-61940	BEARING	1	J20001-
4	561-27-71960	BEARING	1	J20001-
5	561-27-71151	RETAINER	1	J20001-
6	561-27-71200	SHIM ASS'Y	1	J20001-
	☆	*SHIM, 0.2MM	2	J20001-
	☆	*SHIM, 0.3MM	3	J20001-
	☆	*SHIM, 1.0MM	2	J20001-
	☆	*SHIM, 0.05MM	1	J20001-
7	561-27-71141	RETAINER	1	J20001-
8	01011-62405	BOLT	8	J20001-
9	01643-32460	WASHER	8	J20001-
10	04020-01842	PIN	2	J20001-
11	569-22-72860	BOLT	20	J20001-
12	561-27-71160	CAP	1	J20001-
13	07000-12090	O-RING	1	J20001-
14	561-27-71220	COVER	1	J20001-
15	01010-61635	BOLT	6	J20001-
16	01643-31645	WASHER	6	J20001-
17	07000-15375	O-RING	1	J20001-
18	07044-12412	PLUG	1	J20001-
19	07002-12434	O-RING	1	J20001-
20	426-09-11520	WASHER	20	J20001-
21	569-22-72870	NUT	20	J20001-




FRONT AXLE (R.H.) (BRAKE) (1/3)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-32-75110	CYLINDER,(R.H.)	1	J20001-
2	07000-F2025	O-RING	5	J20001-
3	561-34-76112	CYLINDER,(R.H.)	1	J20001-
4	428-22-11280	O-RING	1	J20001-
5	01010-62075	BOLT	8	J20001-
6	708-8F-11260	WASHER	8	J20001-
7	561-34-72124	PISTON	1	J20001-
8	561-32-71123	PISTON	1	J20001-
9	07040-10807	PLUG	2	J20001-
10	07002-10823	O-RING	2	J20001-
11	561-34-72220	SPRING	31	J20001-
12	561-34-72210	SPRING	31	J20001-
13	07040-12012	PLUG	8	J20001-
14	07002-12034	O-RING	8	J20001-
15	07040-11209	PLUG	2	J20001-
16	07002-11223	O-RING	2	J20001-
17	07000-15360	O-RING	1	J20001-
18	569-33-71980	PIN	1	J20001-
19	07040-11409	PLUG	2	J20001-
20	07002-11423	O-RING	2	J20001-
21	561-34-71610	SEAL	1	J20001-
22	561-34-71530	SEAL	1	J20001-
23	561-34-71661	RING	1	J20001-
24	561-34-71580	RING	1	J20001-
25	561-33-71430	SEAL	1	J20001-
26	561-33-71440	SEAL	1	J20001-
27	561-33-71471	RING	1	J20001-
28	561-33-71480	RING	1	J20001-



FRONT AXLE (R.H.) (BRAKE) (2/3)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	428-33-00021	FLOATING SEAL ASS'Y	1	J20001-
	568-33-00093	*SEAL RING ASS'Y	1	J20001-
	☆	**RING	2	J20001-
2	428-33-00031	*O-RING ASS'Y	1	J20001-
	☆	**O-RING	2	J20001-
3	07000-F2020	O-RING	3	J20001-
4	568-33-11511	SEAL	1	J20001-
5	561-32-71320	RETAINER	1	J20001-
6	566-01-12690	O-RING	1	J20001-
7	01643-31232	WASHER	12	J20001-
8	01010-61230	BOLT	12	J20001-
9	561-32-75210	GEAR	1	J20001-
10	569-33-71280	SPACER	1	J20001-
11	585-33-21240	DISC	7	J20001-
12	561-33-61230	PLATE	7	J20001-
13	561-32-71260	DISC	1	J20001-
14	561-33-62260	DAMPER	1	J20001-
15	569-33-71760	PLATE	2	J20001-
16	01010-60820	BOLT	4	J20001-
17	01011-62060	BOLT	38	J20001-
18	01643-32060	WASHER	38	J20001-
19	428-22-11280	O-RING	1	J20001-
20	01010-62070	BOLT	30	J20001-
21	708-8F-11260	WASHER	30	J20001-
22	07040-11209	PLUG	4	J20001-
23	07002-11223	O-RING	4	J20001-
24	07040-11612	PLUG	1	J20001-
25	07002-11623	O-RING	1	J20001-



FRONT AXLE (R.H.) (BRAKE) (3/3)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	232-32-11350	CAP	2	J20001-
2	566-32-11430	BLEEDER	2	J20001-
3	569-33-72140	JOINT	2	J20001-
4	07002-11223	O-RING	2	J20001-
5	569-33-71720	GUIDE	1	J20001-
6	561-32-71741	GAGE	1	J20001-
7	07000-11005	O-RING	1	J20001-
8	569-33-71730	CAP	1	J20001-
9	07002-12434	O-RING	1	J20001-
10	561-32-71921	TANK	1	J20001-
11	01010-62090	BOLT	4	J20001-
12	01643-32060	WASHER	4	J20001-
13	569-33-81241	ADAPTER	1	J20001-
14	07002-12034	O-RING	1	J20001-
15	07000-12018	O-RING	1	J20001-
16	07040-11209	PLUG	1	J20001-
17	07002-11223	O-RING	1	J20001-
18	561-32-71251	COVER	1	J20001-
19	01010-61035	BOLT	12	J20001-
20	01643-31032	WASHER	12	J20001-
21	07040-11209	PLUG	1	J20001-
22	07002-11223	O-RING	1	J20001-
23	07834-00617	ELBOW	1	J20001-
24	07832-00614	NUT	1	J20001-
25	07831-00612	SLEEVE	1	J20001-
26	07822-00608	TUBE	1	J20001-
27	195-49-37150	BRACKET	1	J20001-
28	04434-51012	CLIP	1	J20001-
29	01643-31232	WASHER	1	J20001-
30	01010-81225	BOLT	1	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

FRONT AXLE (R.H.) (FRONT SUSPENSION ASS'Y) (CYLINDER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-50-85001	FRONT SUSPENSION A.	1	J20001-
1	561-50-81110	*CYLINDER	1	J20001-
2	561-50-81130	*ROD	1	J20001-
3	561-50-81410	*STOPPER	1	J20001-
4	561-50-81140	*FLANGE	1	J20001-
5	07043-00108	*PLUG	1	J20001-
6	561-50-81150	*RETAINER	1	J20001-
7	07000-15240	*O-RING	1	J20001-
8	07001-05240	*RING	1	J20001-
9	07000-15240	*O-RING	1	J20001-
10	01011-81425	*BOLT	15	J20001-
11	01643-31445	*WASHER	15	J20001-
12	561-50-81340	*BUSHING	1	J20001-
13	561-50-81320	*WEAR RING	1	J20001-
14	561-50-82330	*BUSHING	2	J20001-
15	561-50-82360	*U-PACKING	1	J20001-
16	561-50-82380	*SEAL	1	J20001-
17	707-51-21650	*RING	1	J20001-
18	07000-02080	*O-RING	2	J20001-
19	561-50-62310	*BUSHING	1	J20001-
20	04071-00130	*RING	2	J20001-
21	561-50-61321	*TUBE	1	J20001-
22	01010-81225	*BOLT	2	J20001-
23	01643-51232	*WASHER	2	J20001-
24	07000-13045	*O-RING	2	J20001-
25	07001-03045	*RING	2	J20001-
26	566-50-11301	*VALVE ASS'Y	1	J20001-
27	566-50-11320	**VALVE	1	J20001-
28	281-50-11721	**CORE	1	J20001-
29	566-50-11340	**CAP	1	J20001-
30	07000-11006	**O-RING	1	J20001-
31	566-50-21260	*VALVE	1	J20001-
32	566-50-11350	*PACKING	3	J20001-
33	566-50-41310	*PLATE	1	J20001-
	566-50-11271	*VALVE	1	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up


**FRONT AXLE (R.H.) (FRONT SUSPENSION ASS'Y) (CYLINDER)
(FOR PAYLOAD METER)**

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-50-81001	FRONT SUSPENSION A.,PAYLOAD METER	1	J20001-
1	561-50-81110	*CYLINDER	1	J20001-
2	561-50-81130	*ROD	1	J20001-
3	561-50-81410	*STOPPER	1	J20001-
4	561-50-81140	*FLANGE	1	J20001-
5	07043-00108	*PLUG	1	J20001-
6	561-50-81150	*RETAINER	1	J20001-
7	07000-15240	*O-RING	1	J20001-
8	07001-05240	*RING	1	J20001-
9	07000-15240	*O-RING	1	J20001-
10	01011-81425	*BOLT	15	J20001-
11	01643-31445	*WASHER	15	J20001-
12	561-50-81340	*BUSHING	1	J20001-
13	561-50-81320	*WEAR RING	1	J20001-
14	561-50-82330	*BUSHING	2	J20001-
15	561-50-82360	*U-PACKING	1	J20001-
16	561-50-82380	*SEAL	1	J20001-
17	707-51-21650	*RING	1	J20001-
18	07000-02080	*O-RING	2	J20001-
19	561-50-62310	*BUSHING	1	J20001-
20	04071-00130	*RING	2	J20001-
21	561-50-61321	*TUBE	1	J20001-
22	01010-81225	*BOLT	2	J20001-
23	01643-51232	*WASHER	2	J20001-
24	07000-13045	*O-RING	2	J20001-
25	07001-03045	*RING	2	J20001-
	566-50-11301	*VALVE ASS'Y	1	J20001-
26	566-50-11320	*VALVE	1	J20001-
27	281-50-11721	*CORE	1	J20001-
28	566-50-11340	*CAP	1	J20001-
29	07000-11006	*O-RING	1	J20001-
30	566-50-21260	*VALVE	1	J20001-
31	566-50-11350	*PACKING	3	J20001-
32	566-50-41310	*PLATE	1	J20001-
33	561-86-67700	*VALVE ASS'Y	1	J20001-
34	561-86-67710	*VALVE	1	J20001-
35	281-50-11721	*CORE	1	J20001-



FRONT AXLE (R.H.) (FRONT SUSPENSION ASS'Y) (VALVE)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(561-50-85001)	FRONT SUSPENSION	1	J20001-
	561-50-63060	*SPRING ASS'Y	1	J20001-
1	569-50-81210	**BODY	1	J20001-
2	561-50-61331	**PLATE	1	J20001-
3	569-50-61240	**PLATE	1	J20001-
4	569-50-61250	**PLATE	1	J20001-
5	569-50-61260	**PLATE	1	J20001-
6	569-50-61270	**PLATE	1	J20001-
7	569-50-61340	**PLATE	1	J20001-
8	569-50-61350	**PLATE	1	J20001-
9	569-50-61360	**PLATE	1	J20001-
10	569-50-61370	**PLATE	1	J20001-
11	01090-51045	**BOLT	1	J20001-
12	426-09-11160	**NUT	1	J20001-
13	561-50-61290	**WASHER	2	J20001-
14	04020-00514	**PIN	2	J20001-
15	01010-81030	**BOLT	4	J20001-
16	01643-51032	**WASHER	4	J20001-
17	07000-12125	*O-RING	1	J20001-
18	01011-61650	*BOLT	4	J20001-
19	01643-31645	*WASHER	4	J20001-
20	561-50-83310	*TUBE	1	J20001-
21	07372-21240	*BOLT	4	J20001-
22	01643-51232	*WASHER	4	J20001-
23	07000-13048	*O-RING	1	J20001-
24	01010-81285	*BOLT	4	J20001-
25	01643-31232	*WASHER	4	J20001-
26	07000-13045	*O-RING	1	J20001-



FRONT AXLE (R.H.) (FRONT SUSPENSION ASS'Y) (COVER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(561-50-85001)	FRONT SUSPENSION A.	1	J20001-
1	561-50-81190	*SEAT	1	J20001-
2	561-50-83171	*COVER	1	J20001-
3	561-50-83181	*COVER	1	J20001-
4	01010-81020	*BOLT	6	J20001-
5	01643-31032	*WASHER	6	J20001-
6	09415-03614	*CAP	1	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up
FRONT AXLE (R.H.) (FRONT SUSPENSION ASS'Y) (COVER)
(FOR PAYLOAD METER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(561-50-81001)	FRONT SUSPENSION A.	1	J20001-
1	561-50-81190	*SEAT	1	J20001-
2	561-50-83171	*COVER	1	J20001-
3	561-50-83181	*COVER	1	J20001-
4	01010-81020	*BOLT	6	J20001-
5	01643-31032	*WASHER	6	J20001-
6	561-50-63191	*GROMMET	1	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

FRONT AXLE (R.H.) (SENSOR) (FOR PAYLOAD METER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	7861-93-1620	SENSOR	1	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up


FRONT AXLE (R.H.) (LUBRICATION)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	421-09-12540	ELBOW	2	J20001-
2	423-09-12110	CONNECTOR	2	J20001-
3	561-52-82520	TUBE	1	J20001-
4	561-52-82540	TUBE	1	J20001-
5	562-95-13150	NIPPLE	2	J20001-
6	04434-50610	CLIP	4	J20001-
7	07020-00000	FITTING	2	J20001-
8	01010-81020	BOLT	2	J20001-
9	01643-31032	WASHER	2	J20001-
10	01580-11008	NUT	1	J20001-
11	01643-31032	WASHER	1	J20001-




FRONT AXLE (R.H.) (LEVER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-40-81311	LEVER	1	J20001-
2	561-40-61330	BUSHING	4	J20001-
3	561-40-81510	PIN	1	J20001-
4	561-40-81170	KEY	2	J20001-
5	561-40-61631	BOOT	4	J20001-
6	561-40-61531	PIN	2	J20001-
7	01010-81425	BOLT	2	J20001-
8	569-40-61710	WASHER	2	J20001-
9	561-40-81121	ARM, R.H.	1	J20001-
10	07137-06010	BUSHING	2	J20001-
11	07000-12060	O-RING	4	J20001-
12	561-40-61260	BUSHING	1	J20001-
13	07000-12105	O-RING	2	J20001-
14	04071-00210	RING	1	J20001-
15	561-40-61610	BOOT	4	J20001-
16	561-40-81150	HOLDER	1	J20001-
17	01010-81645	BOLT	3	J20001-
18	568-40-11331	LOCK	1	J20001-
19	01011-63620	BOLT	8	J20001-
20	01643-33690	WASHER	8	J20001-




FRONT AXLE (R.H.) (FINAL BRAKE LINE)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	02765-00412	HOSE	2	J20001-
2	08210-02905	SPIRAL TUBE	2	J20001-
3	561-44-84660	PLATE	1	J20001-
4	01010-81230	BOLT	2	J20001-
5	01643-31232	WASHER	2	J20001-
6	561-43-86180	ADJUSTER	1	J20001-
7	01010-81245	BOLT	4	J20001-
8	01643-31232	WASHER	4	J20001-
9	561-43-84822	TUBE	1	J20001-
10	02896-21012	O-RING	1	J20001-
11	02782-10422	ELBOW	1	J20001-
12	02896-21012	O-RING	1	J20001-
13	07002-22034	O-RING	1	J20001-
14	561-43-84832	TUBE	1	J20001-
15	02896-21012	O-RING	1	J20001-
16	02782-10423	ELBOW	1	J20001-
17	02896-21012	O-RING	1	J20001-
18	07002-22034	O-RING	1	J20001-
19	07094-30417	CLAMP	4	J20001-
20	07095-00421	CUSHION	4	J20001-
21	01010-81260	BOLT	1	J20001-
22	01643-31232	WASHER	1	J20001-
23	01010-81270	BOLT	1	J20001-
24	01643-31232	WASHER	1	J20001-
25	561-43-84810	BRACKET	1	J20001-
26	07283-34346	CLIP	1	J20001-
27	01597-01009	NUT	2	J20001-
28	01643-31032	WASHER	2	J20001-




FRONT EXLE (R.H) (BRAKE COOLING LINE)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-61-85652	TUBE	1	J20001-
2	07002-21023	O-RING	1	J20001-
3	07040-11007	PLUG	1	J20001-
4	07371-31465	FLANGE	2	J20001-
5	07372-21240	BOLT	4	J20001-
6	01643-51232	WASHER	4	J20001-
7	07000-F3048	O-RING	1	J20001-
8	561-61-85491	TUBE	1	J20001-
9	07002-21023	O-RING	1	J20001-
10	07040-11007	PLUG	1	J20001-
11	07371-31465	FLANGE	2	J20001-
12	07372-21240	BOLT	4	J20001-
13	01643-51232	WASHER	4	J20001-
14	07000-F3048	O-RING	1	J20001-
15	561-61-84580	BRACKET	1	J20001-
16	01010-81230	BOLT	2	J20001-
17	01643-31232	WASHER	2	J20001-
18	07283-34346	CLIP	2	J20001-
19	01643-31032	WASHER	4	J20001-
20	01597-01009	NUT	4	J20001-




FRONT AXLE (R.H) (TRANSPORT)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	07376-70422	PLUG	2	J20001-
2	02896-11012	O-RING	2	J20001-
3	07378-11200	HEAD	2	J20001-
4	07371-31255	FLANGE	4	J20001-
5	07372-21035	BOLT	8	J20001-
6	01643-51032	WASHER	8	J20001-
7	07000-13038	O-RING	2	J20001-
8	561-54-63520	RUBBER	1	J20001-



FRONT AXLE (R.H) (TRANSPORT)(AUTO SUSPENSION)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	07376-70422	PLUG	2	J20001-
2	02896-11012	O-RING	2	J20001-
3	07378-11200	HEAD	2	J20001-
4	07371-31255	FLANGE	4	J20001-
5	07372-21035	BOLT	8	J20001-
6	01643-51032	WASHER	8	J20001-
7	07000-13038	O-RING	2	J20001-
8	07376-70210	PLUG	4	J20001-
9	02896-11008	O-RING	4	J20001-
10	561-54-63520	RUBBER	1	J20001-



FRONT AXLE (L.H.) (HUB)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-27-71212	HUB	1	J20001-
2	561-27-71130	RETAINER	1	J20001-
3	561-27-61940	BEARING	1	J20001-
4	561-27-71960	BEARING	1	J20001-
5	561-27-71151	RETAINER	1	J20001-
6	561-27-71200	SHIM ASS'Y	1	J20001-
	561-27-71240	*SHIM, 0.2MM	2	J20001-
	561-27-71250	*SHIM, 0.3MM	3	J20001-
	561-27-71260	*SHIM, 1.0MM	2	J20001-
	561-27-71270	*SHIM, 0.05MM	1	J20001-
7	561-27-71141	RETAINER	1	J20001-
8	01011-62405	BOLT	8	J20001-
9	01643-32460	WASHER	8	J20001-
10	04020-01842	PIN	2	J20001-
11	569-22-72860	BOLT	20	J20001-
12	561-27-71160	CAP	1	J20001-
13	07000-12090	O-RING	1	J20001-
14	561-27-71220	COVER	1	J20001-
15	01010-61635	BOLT	6	J20001-
16	01643-31645	WASHER	6	J20001-
17	07000-15375	O-RING	1	J20001-
18	07044-12412	PLUG	1	J20001-
19	07002-12434	O-RING	1	J20001-
20	426-09-11520	WASHER	20	J20001-
21	569-22-72870	NUT	20	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

FRONT AXLE (L.H.) (BRAKE) (1/3)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-32-71115	CYLINDER,L.H.	1	J20001-
2	07000-F2025	O-RING	5	J20001-
3	561-34-72114	CYLINDER	1	J20001-
4	428-22-11280	O-RING	1	J20001-
5	01010-62075	BOLT	8	J20001-
6	708-8F-11260	WASHER	8	J20001-
7	561-34-72124	PISTON	1	J20001-
8	561-32-71123	PISTON	1	J20001-
9	07040-10807	PLUG	2	J20001-
10	07002-10823	O-RING	2	J20001-
11	561-34-72220	SPRING	31	J20001-
12	561-34-72210	SPRING	31	J20001-
13	07040-12012	PLUG	8	J20001-
14	07002-12034	O-RING	8	J20001-
15	07040-11209	PLUG	2	J20001-
16	07002-11223	O-RING	2	J20001-
17	07000-15360	O-RING	1	J20001-
18	569-33-71980	PIN	1	J20001-
19	07040-11409	PLUG	2	J20001-
20	07002-11423	O-RING	2	J20001-
21	561-34-71610	SEAL	1	J20001-
22	561-34-71530	SEAL	1	J20001-
23	561-34-71661	RING	1	J20001-
24	561-34-71580	RING	1	J20001-
25	561-33-71430	SEAL	1	J20001-
26	561-33-71440	SEAL	1	J20001-
27	561-33-71471	RING	1	J20001-
28	561-33-71480	RING	1	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up

FRONT AXLE (L.H.) (BRAKE) (2/3)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	428-33-00021	FLOATING SEAL ASS'Y	1	J20001-
1	568-33-11364	.RING	2	J20001-
2	428-33-11650	.O-RING	2	J20001-
3	07000-F2020	O-RING	3	J20001-
4	568-33-11511	SEAL	1	J20001-
5	561-32-71320	RETAINER	1	J20001-
6	566-01-12690	O-RING	1	J20001-
7	01643-31232	WASHER	12	J20001-
8	01010-61230	BOLT	12	J20001-
9	561-32-71210	GEAR	1	J20001-
10	569-33-71280	SPACER	1	J20001-
11	585-33-21240	DISC	7	J20001-
12	561-33-61230	PLATE	7	J20001-
13	561-32-71260	DISC	1	J20001-
14	561-33-62260	DAMPER	1	J20001-
15	569-33-71760	PLATE	2	J20001-
16	01010-60820	BOLT	4	J20001-
17	01011-62060	BOLT	38	J20001-
18	01643-32060	WASHER	38	J20001-
19	428-22-11280	O-RING	1	J20001-
20	01010-62070	BOLT	30	J20001-
21	708-8F-11260	WASHER	30	J20001-
22	07040-11209	PLUG	4	J20001-
23	07002-11223	O-RING	4	J20001-
24	07040-11612	PLUG	1	J20001-
25	07002-11623	O-RING	1	J20001-



FRONT AXLE (L.H.) (3/3)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	232-32-11350	CAP	2	J20001-
2	566-32-11430	BLEEDER	2	J20001-
3	569-33-72140	JOINT	2	J20001-
4	07002-11223	O-RING	2	J20001-
5	569-33-71720	GUIDE	1	J20001-
6	561-32-71741	GAGE	1	J20001-
7	07000-11005	O-RING	1	J20001-
8	569-33-71730	CAP	1	J20001-
9	07002-12434	O-RING	1	J20001-
10	561-32-71921	TANK	1	J20001-
11	01010-62090	BOLT	4	J20001-
12	01643-32060	WASHER	4	J20001-
13	569-33-81241	ADAPTER	1	J20001-
14	07002-12034	O-RING	1	J20001-
15	07000-12018	O-RING	1	J20001-
16	07040-11209	PLUG	1	J20001-
17	07002-11223	O-RING	1	J20001-
18	561-32-71251	COVER	1	J20001-
19	01010-61035	BOLT	12	J20001-
20	01643-31032	WASHER	12	J20001-
21	07040-11209	PLUG	1	J20001-
22	07002-11223	O-RING	1	J20001-
23	07834-00617	ELBOW	1	J20001-
24	07832-00614	NUT	1	J20001-
25	07831-00612	SLEEVE	1	J20001-
26	07822-00608	TUBE	1	J20001-
27	195-49-37150	BRACKET	1	J20001-
28	04434-51012	CLIP	1	J20001-
29	01643-31232	WASHER	1	J20001-
30	01010-81225	BOLT	1	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

FRONT AXLE (R.H.) (FRONT SUSPENSION ASS'Y) (CYLINDER)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-50-85001	FRONT SUSPENSION A.	1	J20001-
1	561-50-81110	*CYLINDER	1	J20001-
2	561-50-81130	*ROD	1	J20001-
3	561-50-81410	*STOPPER	1	J20001-
4	561-50-81140	*FLANGE	1	J20001-
5	07043-00108	*PLUG	1	J20001-
6	561-50-81150	*RETAINER	1	J20001-
7	07000-15240	*O-RING	1	J20001-
8	07001-05240	*RING	1	J20001-
9	07000-15240	*O-RING	1	J20001-
10	01011-81425	*BOLT	15	J20001-
11	01643-31445	*WASHER	15	J20001-
12	561-50-81340	*BUSHING	1	J20001-
13	561-50-81320	*WEAR RING	1	J20001-
14	561-50-82330	*BUSHING	2	J20001-
15	561-50-82360	*U-PACKING	1	J20001-
16	561-50-82380	*SEAL	1	J20001-
17	707-51-21650	*RING	1	J20001-
18	07000-02080	*O-RING	2	J20001-
19	561-50-62310	*BUSHING	1	J20001-
20	04071-00130	*RING	2	J20001-
21	561-50-61321	*TUBE	1	J20001-
22	01010-81225	*BOLT	2	J20001-
23	01643-51232	*WASHER	2	J20001-
24	07000-13045	*O-RING	2	J20001-
25	07001-03045	*RING	2	J20001-
	566-50-11301	*VALVE ASS'Y	1	J20001-
26	566-50-11320	**VALVE	1	J20001-
27	281-50-11721	**CORE	1	J20001-
28	566-50-11340	**CAP	1	J20001-
29	07000-11006	**O-RING	1	J20001-
30	566-50-21260	*VALVE	1	J20001-
31	566-50-11350	*PACKING	3	J20001-
32	566-50-41310	*PLATE	1	J20001-
33	566-50-11271	*VALVE	1	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up
FRONT AXLE (L.H.) (FRONT SUSPENSION ASS'Y) (CYLINDER)
(FOR PAYLOAD METER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-50-81001	FRONT SUSPENSION A.,PAYLOAD METER	1	J20001-
1	561-50-81110	*CYLINDER	1	J20001-
2	561-50-81130	*ROD	1	J20001-
3	561-50-81410	*STOPPER	1	J20001-
4	561-50-81140	*FLANGE	1	J20001-
5	07043-00108	*PLUG	1	J20001-
6	561-50-81150	*RETAINER	1	J20001-
7	07000-15240	*O-RING	1	J20001-
8	07001-05240	*RING	1	J20001-
9	07000-15240	*O-RING	1	J20001-
10	01011-81425	*BOLT	15	J20001-
11	01643-31445	*WASHER	15	J20001-
12	561-50-81340	*BUSHING	1	J20001-
13	561-50-81320	*WEAR RING	1	J20001-
14	561-50-82330	*BUSHING	2	J20001-
15	561-50-82360	*U-PACKING	1	J20001-
16	561-50-82380	*SEAL	1	J20001-
17	707-51-21650	*RING	1	J20001-
18	07000-02080	*O-RING	2	J20001-
19	561-50-62310	*BUSHING	1	J20001-
20	04071-00130	*RING	2	J20001-
21	561-50-61321	*TUBE	1	J20001-
22	01010-81225	*BOLT	2	J20001-
23	01643-51232	*WASHER	2	J20001-
24	07000-13045	*O-RING	2	J20001-
25	07001-03045	*RING	2	J20001-
26	566-50-11301	*VALVE ASS'Y	1	J20001-
27	566-50-11320	*VALVE	1	J20001-
28	281-50-11721	*CORE	1	J20001-
29	566-50-11340	*CAP	1	J20001-
30	07000-11006	*O-RING	1	J20001-
31	566-50-21260	*VALVE	1	J20001-
32	566-50-11350	*PACKING	3	J20001-
33	566-50-41310	*PLATE	1	J20001-
34	561-86-67700	*VALVE ASS'Y	1	J20001-
	561-86-67710	*VALVE	1	J20001-
	281-50-11721	*CORE	1	J20001-



FRONT AXLE (L.H.) (FRONT SUSPENSION ASS'Y) (VALVE)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(561-50-85001)	FRONT SUSPENSION A.	1	J20001-
	(561-50-81001)	FRONT SUSPENSION A, AUTO SUSPENSION	1	J20001-
	561-50-63060	*SPRING ASS'Y	1	J20001-
1	569-50-81210	**BODY	1	J20001-
2	561-50-61331	**PLATE	1	J20001-
3	569-50-61240	**PLATE	1	J20001-
4	569-50-61250	**PLATE	1	J20001-
5	569-50-61260	**PLATE	1	J20001-
6	569-50-61270	**PLATE	1	J20001-
7	569-50-61340	**PLATE	1	J20001-
8	569-50-61350	**PLATE	1	J20001-
9	569-50-61360	**PLATE	1	J20001-
10	569-50-61370	**PLATE	1	J20001-
11	01090-51045	**BOLT	1	J20001-
12	426-09-11160	**NUT	1	J20001-
13	561-50-61290	**WASHER	2	J20001-
14	04020-00514	**PIN	2	J20001-
15	01010-81030	**BOLT	4	J20001-
16	01643-51032	**WASHER	4	J20001-
17	07000-12125	*O-RING	1	J20001-
18	01011-61650	*BOLT	4	J20001-
19	01643-31645	*WASHER	4	J20001-
20	561-50-83310	*TUBE	1	J20001-
21	07372-21240	*BOLT	4	J20001-
22	01643-51232	*WASHER	4	J20001-
23	07000-13048	*O-RING	1	J20001-
24	01010-81285	*BOLT	4	J20001-
25	01643-31232	*WASHER	4	J20001-
26	07000-13045	*O-RING	1	J20001-



FRONT AXLE (L.H.) (FRONT SUSPENSION ASS'Y) (COVER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(561-50-85001)	FRONT SUSPENSION A.	1	J20001-
1	561-50-81190	*SEAT	1	J20001-
2	561-50-83171	*COVER	1	J20001-
3	561-50-83181	*COVER	1	J20001-
4	01010-81020	*BOLT	6	J20001-
5	01643-31032	*WASHER	6	J20001-
6	09415-03614	*CAP	1	J20001-

HD785-7 S/N J20001 and up




Front Suspension

HD785-7 S/N J20001 and up
FRONT AXLE (L.H.) (FRONT SUSPENSION ASS'Y) (COVER)
(FOR PAYLOAD METER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(561-50-81001)	FRONT SUSPENSION A.	1	J20001-
1	561-50-81190	*SEAT	1	J20001-
2	561-50-83171	*COVER	1	J20001-
3	561-50-83181	*COVER	1	J20001-
4	01010-81020	*BOLT	6	J20001-
5	01643-31032	*WASHER	6	J20001-
6	561-50-63191	*GROMMET	1	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up


FRONT AXLE (L.H.) (SENSOR) (FOR PAYLOAD METER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	7861-93-1620	SENSOR	1	J20001-



FRONT AXLE (L.H.) (LUBRICATION)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	421-09-12540	ELBOW	2	J20001-
2	423-09-12110	CONNECTOR	2	J20001-
3	561-52-82510	TUBE	1	J20001-
4	561-52-82530	TUBE	1	J20001-
5	562-95-13150	NIPPLE	2	J20001-
6	01010-81020	BOLT	2	J20001-
7	01643-31032	WASHER	2	J20001-
8	01580-11008	NUT	1	J20001-
9	04434-50610	CLIP	4	J20001-
10	07020-00000	FITTING	2	J20001-
11	01643-31032	WASHER	1	J20001-



FRONT AXLE (L.H.) (LEVER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-40-81311	LEVER	1	J20001-
2	561-40-61330	BUSHING	4	J20001-
3	561-40-81510	PIN	1	J20001-
4	561-40-81170	KEY	2	J20001-
5	561-40-61631	BOOT	4	J20001-
6	561-40-61531	PIN	2	J20001-
7	01010-81425	BOLT	2	J20001-
8	569-40-61710	WASHER	2	J20001-
9	561-40-81111	ARM, L.H.	1	J20001-
10	07137-06010	BUSHING	2	J20001-
11	07000-12060	O-RING	4	J20001-
12	561-40-61260	BUSHING	1	J20001-
13	07000-12105	O-RING	2	J20001-
14	04071-00210	RING	1	J20001-
15	561-40-61610	BOOT	4	J20001-
16	561-40-81150	HOLDER	1	J20001-
17	01010-81645	BOLT	3	J20001-
18	568-40-11331	LOCK	1	J20001-
19	01011-63620	BOLT	8	J20001-
20	01643-33690	WASHER	8	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

FRONT AXLE (L.H.) (BRAKE LINE)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	02765-00412	HOSE	2	J20001-
2	08210-02903	SPIRAL TUBE	2	J20001-
3	561-44-84670	PLATE	1	J20001-
4	01010-81230	BOLT	2	J20001-
5	01643-31232	WASHER	2	J20001-
6	561-43-86180	ADJUSTER	1	J20001-
7	01010-81245	BOLT	4	J20001-
8	01643-31232	WASHER	4	J20001-
9	561-43-84843	TUBE	1	J20001-
10	02896-21012	O-RING	1	J20001-
11	02782-10422	ELBOW	1	J20001-
12	02896-21012	O-RING	1	J20001-
13	07002-22034	O-RING	1	J20001-
14	561-43-84852	TUBE	1	J20001-
15	02896-21012	O-RING	1	J20001-
16	02782-10423	ELBOW	1	J20001-
17	02896-21012	O-RING	1	J20001-
18	07002-22034	O-RING	1	J20001-
19	07094-30417	CLAMP	4	J20001-
20	07095-00421	CUSHION	4	J20001-
21	01010-81260	BOLT	1	J20001-
22	01643-31232	WASHER	1	J20001-
23	01010-81270	BOLT	1	J20001-
24	01643-31232	WASHER	1	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

FRONT AXLE (L.H.) (BRAKE COOLING LINE)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-61-85643	TUBE	1	J20001-
2	07002-21023	O-RING	1	J20001-
3	07040-11007	PLUG	1	J20001-
4	07372-21245	BOLT	4	J20001-
5	01643-51232	WASHER	4	J20001-
6	07000-F3048	O-RING	1	J20001-
7	561-61-85393	TUBE	1	J20001-
8	07002-21023	O-RING	1	J20001-
9	07040-11007	PLUG	1	J20001-
10	07371-31465	FLANGE	2	J20001-
11	07372-21245	BOLT	4	J20001-
12	01643-51232	WASHER	4	J20001-
13	07000-F3048	O-RING	1	J20001-
14	561-61-84573	BRACKET	1	J20001-
15	01010-81230	BOLT	2	J20001-
16	01643-31232	WASHER	2	J20001-
17	07283-34949	CLIP	2	J20001-
18	01643-31032	WASHER	4	J20001-
19	01597-01009	NUT	4	J20001-

HD785-7 S/N J20001 and up




0 0 0 6 2 3 7 3

HD785-7 S/N J20001 and up

FRONT AXLE (L.H.) (TRANSPORT)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	07376-70422	PLUG	2	J20001-
2	02896-11012	O-RING	2	J20001-
3	07378-11200	HEAD	2	J20001-
4	07371-31255	FLANGE	4	J20001-
5	07372-21035	BOLT	8	J20001-
6	01643-51032	WASHER	8	J20001-
7	07000-13038	O-RING	2	J20001-
8	561-54-63520	RUBBER	1	J20001-





0 0 0 6 2 3 7 4


FRONT AXLE (L.H) (TRANSPORT)(AUTO SUSPENSION)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	07376-70422	PLUG	2	J20001-
2	02896-11012	O-RING	2	J20001-
3	07378-11200	HEAD	2	J20001-
4	07371-31255	FLANGE	4	J20001-
5	07372-21035	BOLT	8	J20001-
6	01643-51032	WASHER	8	J20001-
7	07000-13038	O-RING	2	J20001-
8	07376-70210	PLUG	4	J20001-
9	02896-11008	O-RING	4	J20001-
10	561-54-63520	RUBBER	1	J20001-


HD785-7 S/N J20001 and up



Detail A



Detail B




Detail C

HD785-7 S/N J20001 and up

FRONT AXLE (L.H) (HOSE CLIP) (FOR SUSPENSION CYLINDER LINE) (AUTO SUSPENSION)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	04434-53212	CLIP	8	J20001-
2	04434-53411	CLIP	4	J20001-
3	07095-00420	CUSHION	1	J20001-
4	07095-00423	CUSHION	3	J20001-
5	01010-81025	BOLT	4	J20001-
6	01643-31032	WASHER	4	J20001-
7	01580-11008	NUT	4	J20001-
8	01010-81020	BOLT	4	J20001-
9	01643-31032	WASHER	4	J20001-
10	01643-31032	WASHER	4	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

FRONT AXLE (L.H) (HOSE CLIP) (FOR SUSPENSION CYLINDER LINE) (AUTO SUSPENSION AND PAYLOAD METER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	04434-53212	CLIP	8	J20001-
2	04434-53411	CLIP	4	J20001-
3	07095-00420	CUSHION	1	J20001-
4	07095-00423	CUSHION	3	J20001-
5	01010-81025	BOLT	4	J20001-
6	01643-31032	WASHER	4	J20001-
7	01580-11008	NUT	4	J20001-
8	01010-81020	BOLT	6	J20001-
9	01643-31032	WASHER	6	J20001-
10	01643-31032	WASHER	4	J20001-

HYDRAULIC SYSTEM


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up


HYDRAULIC TANK ASS'Y (1/2)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-60-81113	TANK	1	J20001-
2	56B-60-17120	STRAINER ASS'Y	1	J20001-
3	07063-51210	ELEMENT	1	J20001-
4	07069-15560	VALVE	1	J20001-
5	07069-34080	SPRING	1	J20001-
6	07000-F5190	O-RING	1	J20001-
7	561-60-81150	COVER	1	J20001-
8	01010-81440	BOLT	2	J20001-
9	01643-31445	WASHER	2	J20001-
10	232-32-11350	CAP	1	J20001-
11	566-32-11430	BLEEDER	1	J20001-
12	581-32-12140	PLUG	1	J20001-
	566-60-15361	REATHER	1	J20001-
13	419-60-15240	*BODY	1	J20001-
14	419-60-15250	*ELEMENT	1	J20001-
15	419-60-15260	*COVER	1	J20001-
16	419-60-15270	*O-RING	1	J20001-
17	419-60-15280	*NUT	1	J20001-
18	419-60-15290	*WASHER	1	J20001-
19	419-60-15310	*WASHER	1	J20001-
20	569-60-81131	COVER	1	J20001-
21	07000-F2140	O-RING	1	J20001-
22	01010-81230	BOLT	4	J20001-
23	01643-31232	WASHER	4	J20001-
24	561-60-62530	GAUGE	1	J20001-
25	07002-25234	O-RING	1	J20001-
26	561-60-81120	COVER	1	J20001-
27	07000-F2140	O-RING	1	J20001-
28	01010-81230	BOLT	4	J20001-
29	01643-31232	WASHER	4	J20001-
	6693-22-5600	VALVE ASS'Y	1	J20001-
30	6693-22-5610	*BODY	1	J20001-
31	6693-22-5620	*VALVE	1	J20001-
32	07040-02412	*PLUG	1	J20001-
33	04020-00514	*PIN	1	J20001-
34	07000-F3028	O-RING	1	J20001-
35	01010-81025	BOLT	2	J20001-
36	01643-31032	WASHER	2	J20001-




HYDRAULIC TANK ASS'Y (2/2)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	07056-10045	STRAINER	1	J20001-
2	07051-01000	CAP	1	J20001-
3	561-60-81130	BRACKET	1	J20001-
4	01010-81230	BOLT	4	J20001-
5	01643-31232	WASHER	4	J20001-
6	561-60-81141	BRACKET	1	J20001-
7	01010-81230	BOLT	4	J20001-
8	01643-31232	WASHER	4	J20001-
9	561-60-61330	FLANGE	1	J20001-
10	7861-91-4220	O-RING	1	J20001-
11	01010-80616	BOLT	3	J20001-
12	01643-30623	WASHER	3	J20001-
	561-60-80200	FILTER ASS'Y	2	J20001-
13	561-60-81510	*CASE	1	J20001-
14	56B-60-17120	*STRAINER ASS'Y	1	J20001-
15	07063-51210	*ELEMENT	1	J20001-
16	07069-15560	*VALVE	1	J20001-
17	07069-34080	*SPRING	1	J20001-
18	07000-F5190	*O-RING	1	J20001-
19	561-60-81210	*COVER	1	J20001-
20	01010-81440	*BOLT	2	J20001-
21	01643-31445	*WASHER	2	J20001-
22	07042-80108	*PLUG	1	J20001-
23	01010-81235	BOLT	8	J20001-
24	01643-31232	WASHER	8	J20001-
25	02783-10210	ELBOW	1	J20001-
26	07002-21423	O-RING	1	J20001-
27	02783-10315	ELBOW	1	J20001-
28	07002-22034	O-RING	1	J20001-




HYDRAULIC TANK ASS'Y (2/2) (WITH VANDALISM PROTECTION)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	07056-10045	STRAINER	1	J20001-
2	07092-01000	CAP	1	J20001-
3	561-60-81130	BRACKET	1	J20001-
4	01010-81230	BOLT	4	J20001-
5	01643-31232	WASHER	4	J20001-
6	561-60-81141	BRACKET	1	J20001-
7	01010-81230	BOLT	4	J20001-
8	01643-31232	WASHER	4	J20001-
9	561-60-61330	FLANGE	1	J20001-
10	7861-91-4220	O-RING	1	J20001-
11	01010-80616	BOLT	3	J20001-
12	01643-30623	WASHER	3	J20001-
	561-60-80200	FILTER ASS'Y	2	J20001-
13	561-60-81510	*CASE	1	J20001-
14	56B-60-17120	*STRAINER ASS'Y	1	J20001-
15	07063-51210	*ELEMENT	1	J20001-
16	07069-15560	*VALVE	1	J20001-
17	07069-34080	*SPRING	1	J20001-
18	07000-F5190	*O-RING	1	J20001-
19	561-60-81210	*COVER	1	J20001-
20	01010-81440	*BOLT	2	J20001-
21	01643-31445	*WASHER	2	J20001-
22	07042-80108	*PLUG	1	J20001-
23	01010-81235	BOLT	8	J20001-
24	01643-31232	WASHER	8	J20001-
25	02783-10210	ELBOW	1	J20001-
26	07002-21423	O-RING	1	J20001-
27	02783-10315	ELBOW	1	J20001-
28	07002-22034	O-RING	1	J20001-




HYDRAULIC TANK ASS'Y (VALVE)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	(707-37-26000)	CONTROL VALVE	1	J20001-
2	01011-81210	BOLT	3	J20001-
3	01643-31232	WASHER	3	J20001-
4	02782-10210	ELBOW	2	J20001-
5	07002-21423	O-RING	2	J20001-
6	(702-21-02600)	VALVE	1	J20001-
7	01010-81230	BOLT	3	J20001-
8	01643-31232	WASHER	3	J20001-




HYDRAULIC TANK ASS'Y (TRANSMISSION FILTER.)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	569-16-81100	OIL FILTER ASS'Y	2	J20001-
1	569-16-81160	*ELEMENT	2	J20001-
2	425-16-21240	*COVER	1	J20001-
3	427-16-21120	*COVER	1	J20001-
4	425-16-21250	*RETAINER ASS'Y	2	J20001-
5	425-16-21260	*CASE	2	J20001-
6	425-16-21270	*PLUG	2	J20001-
7	07000-12014	*O-RING	2	J20001-
8	07000-12125	*O-RING	2	J20001-
9	425-16-11240	*PLUG	2	J20001-
10	07002-13334	*O-RING	2	J20001-
11	07000-13035	*O-RING	4	J20001-
12	427-16-21130	*PLATE	1	J20001-
13	425-16-11270	*PLATE	1	J20001-
14	01010-81040	*BOLT	9	J20001-
15	01010-81025	*BOLT	5	J20001-
16	01602-21030	*WASHER	14	J20001-
17	01580-11008	*NUT	3	J20001-
18	419-43-17930	CUSHION	8	J20001-
19	415-64-13130	CUSHION	8	J20001-
20	415-64-13120	WASHER	8	J20001-
21	421-62-18560	SPACER	8	J20001-
22	415-64-13120	WASHER	8	J20001-
23	01010-81055	BOLT	8	J20001-
24	01643-31032	WASHER	8	J20001-




HYDRAULIC TANK ASS'Y (BRAKE COOLING LINE)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-61-85451	TUBE	1	J20001-
2	01010-81285	BOLT	4	J20001-
3	01643-31232	WASHER	4	J20001-
4	01010-81270	BOLT	4	J20001-
5	01643-31232	WASHER	4	J20001-
6	07000-F2060	O-RING	4	J20001-
7	07040-11409	PLUG	2	J20001-
8	07002-21423	O-RING	2	J20001-
9	561-61-81520	TUBE	1	J20001-
10	07372-21240	BOLT	8	J20001-
11	01643-51232	WASHER	8	J20001-
12	07332-12000	COUPLING	1	J20001-
13	561-61-81322	TUBE	1	J20001-




HYDRAULIC TANK ASS'Y (SUCTION LINE)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-61-81110	TUBE	1	J20001-
2	07000-F2105	O-RING	1	J20001-
3	01010-81245	BOLT	4	J20001-
4	01643-31232	WASHER	4	J20001-




HYDRAULIC TANK ASS'Y (PETROL PIPING)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-16-81521	TUBE	1	J20001-
2	561-16-81540	BRACKET	1	J20001-
3	01010-81225	BOLT	2	J20001-
4	01643-31232	WASHER	2	J20001-
5	07283-36155	CLIP	1	J20001-
6	01597-01009	NUT	2	J20001-
7	01643-31032	WASHER	2	J20001-
8	561-16-81551	BRACKET	1	J20001-
9	01010-81230	BOLT	2	J20001-
10	01643-31232	WASHER	2	J20001-
11	07283-36155	CLIP	1	J20001-
12	01597-01009	NUT	2	J20001-
13	01643-31032	WASHER	2	J20001-
14	07051-01000	CAP	1	J20001-
15	07056-10045	STRAINER	1	J20001-
16	561-16-8A530	PLATE	1	J20001-
17	01010-81220	BOLT	2	J20001-
18	01643-31232	WASHER	2	J20001-
19	203-60-31100	ELBOW ASS'Y	2	J20001-
20	561-61-83910	TUBE	1	J20001-




HYDRAULIC TANK ASS'Y (WITH VANDALISM PROTECTION)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-16-81521	TUBE	1	J20001-
2	561-16-81540	BRACKET	1	J20001-
3	01010-81225	BOLT	2	J20001-
4	01643-31232	WASHER	2	J20001-
5	07283-36155	CLIP	1	J20001-
6	01597-01009	NUT	2	J20001-
7	01643-31032	WASHER	2	J20001-
8	561-16-81551	BRACKET	1	J20001-
9	01010-81230	BOLT	2	J20001-
10	01643-31232	WASHER	2	J20001-
11	07283-36155	CLIP	1	J20001-
12	01597-01009	NUT	2	J20001-
13	01643-31032	WASHER	2	J20001-
14	07092-01000	CAP	1	J20001-
15	07056-10045	STRAINER	1	J20001-
16	561-16-8A530	PLATE	1	J20001-
17	01010-81220	BOLT	2	J20001-
18	01643-31232	WASHER	2	J20001-
19	203-60-31100	ELBOW ASS'Y	2	J20001-
20	561-61-83910	TUBE	1	J20001-



HYDRAULIC TANK ASS'Y (D/V-FILTER LINE)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-61-82220	BLOCK	1	J20001-
2	07000-F2055	O-RING	1	J20001-
3	01011-81205	BOLT	4	J20001-
4	01643-31232	WASHER	4	J20001-
5	(702-13-43700)	VALVE ASS'Y	1	J20001-
6	07000-F3045	O-RING	1	J20001-
7	561-87-85131	TUBE	1	J20001-
8	01011-81420	BOLT	4	J20001-
9	01643-31445	WASHER	4	J20001-
10	07000-F2055	O-RING	1	J20001-
11	07040-11007	PLUG	1	J20001-
12	07002-21023	O-RING	1	J20001-
13	07088-014A7	HOSE	1	J20001-
14	07000-F3048	O-RING	1	J20001-
15	07371-31465	FLANGE	2	J20001-
16	07372-21240	BOLT	4	J20001-
17	01643-51232	WASHER	4	J20001-
18	561-87-85140	TUBE	1	J20001-
19	01010-81290	BOLT	4	J20001-
20	01643-31232	WASHER	4	J20001-
21	07000-F2055	O-RING	1	J20001-
22	07040-11007*	PLUG	1	J20001-
23	07002-21023	O-RING	1	J20001-
24	07088-01408	HOSE	1	J20001-
25	07000-F3048	O-RING	1	J20001-
26	07371-31465	FLANGE	2	J20001-
27	07372-21240	BOLT	4	J20001-
28	01643-51232	WASHER	4	J20001-



HYDRAULIC TANK ASS'Y (STEERING VALVE LINE)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-61-85130	FLANGE	1	J20001-
2	07000-F3045	O-RING	1	J20001-
3	01010-81235	BOLT	4	J20001-
4	01643-31232	WASHER	4	J20001-
5	02896-21018	O-RING	1	J20001-
6	02766-00606	HOSE	1	J20001-
7	02765-004A4	HOSE	1	J20001-
8	02896-21012	O-RING	1	J20001-
9	17M-03-46530	ELBOW	1	J20001-
10	07002-21423	O-RING	1	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up
HYDRAULIC TANK ASS'Y (HOIST VALVE TO DUMP CONTROL
VALVE LINE)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-61-83211	TUBE	1	J20001-
2	07000-F3045	O-RING	1	J20001-
3	01010-81275	BOLT	4	J20001-
4	01643-31232	WASHER	4	J20001-
5	07000-F2060	O-RING	1	J20001-
6	01010-81240	BOLT	4	J20001-
7	01643-31232	WASHER	4	J20001-



HYDRAULIC TANK ASS'Y (HOIST LINE)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-61-83241	TUBE	1	J20001-
2	07000-F3045	O-RING	1	J20001-
3	01010-81275	BOLT	4	J20001-
4	01643-31232	WASHER	4	J20001-
5	07040-11007	PLUG	1	J20001-
6	07002-21023	O-RING	1	J20001-
7	561-61-83370	BRACKET	1	J20001-
8	01010-81225	BOLT	2	J20001-
9	01643-31232	WASHER	2	J20001-
10	07283-34346	CLIP	1	J20001-
11	01597-01009	NUT	2	J20001-
12	01643-31032	WASHER	2	J20001-
13	561-61-83382	BRACKET	1	J20001-
14	07283-38973	CLIP	1	J20001-
15	01597-01211	NUT	2	J20001-
16	01643-31232	WASHER	2	J20001-
17	07283-34346	CLIP	1	J20001-
18	01597-01009	NUT	2	J20001-
19	01643-31032	WASHER	2	J20001-
20	561-61-83341	TUBE	1	J20001-
21	07000-F3048	O-RING	1	J20001-
22	01010-81240	BOLT	4	J20001-
23	01643-31232	WASHER	4	J20001-
24	07094-10518	CLAMP	2	J20001-
25	07095-00526	CUSHION	1	J20001-
26	01010-81270	BOLT	1	J20001-
27	01643-31232	WASHER	1	J20001-
28	14X-04-21630	ELBOW	1	J20001-
29	07002-22034	O-RING	2	J20001-
30	421-43-37362	VALVE	1	J20001-
31	02783-10210	ELBOW	1	J20001-
32	02896-21008	O-RING	1	J20001-
33	07002-21423	O-RING	1	J20001-
34	02766-002A5	HOSE	1	J20001-
35	02781-0021D	UNION	1	J20001-
36	02896-21008	O-RING	1	J20001-
37	07002-21423	O-RING	1	J20001-
38	427-W93-1490	CLIP	1	J20001-
39	04434-51912	CLIP	1	J20001-
40	07095-20213	CUSHION	1	J20001-
41	01010-81220	BOLT	1	J20001-
42	01643-31232	WASHER	1	J20001-
43	01580-01210	NUT	1	J20001-



HYDRAULIC TANK ASS'Y (RETURN LINE)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	02764-00607	HOSE	1	J20001-
2	02896-21018	O-RING	1	J20001-
3	02782-10628	ELBOW	1	J20001-
4	07002-22434	O-RING	1	J20001-
5	561-61-84162	TUBE	1	J20001-
6	07372-21245	BOLT	8	J20001-
7	01643-51232	WASHER	8	J20001-
8	07000-F3048	O-RING	2	J20001-
9	561-61-83633	TUBE	1	J20001-
10	561-61-83720	BRACKET	1	J20001-
11	01010-81230	BOLT	4	J20001-
12	01643-31232	WASHER	4	J20001-
13	07332-12000	COUPLING	1	J20001-
14	561-61-83642	FLANGE	1	J20001-
15	07000-F2060	O-RING	1	J20001-
16	02782-10628	ELBOW	1	J20001-
17	07002-22434	O-RING	1	J20001-
18	561-61-83611	TUBE	1	J20001-
19	01010-81280	BOLT	4	J20001-
20	01643-51232	WASHER	4	J20001-
21	07000-F3048	O-RING	1	J20001-
22	07000-F2055	O-RING	1	J20001-
23	07372-21250	BOLT	4	J20001-
24	01643-51232	WASHER	4	J20001-
25	02782-10628	ELBOW	1	J20001-
26	07002-22434	O-RING	1	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up


HYDRAULIC TANK ASS'Y (TRANSMISSION TO FILTER LINE)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-16-81141	TUBE	1	J20001-
2	07372-21040	BOLT	1	J20001-
3	07372-21050	BOLT	3	J20001-
4	01580-11008	NUT	3	J20001-
5	01643-51032	WASHER	4	J20001-
6	07000-F3035	O-RING	1	J20001-
7	07040-11007	PLUG	1	J20001-
8	07002-21023	O-RING	1	J20001-
9	561-16-81151	TUBE	1	J20001-
10	07371-21255	FLANGE	2	J20001-
11	07372-21035	BOLT	4	J20001-
12	01643-51032	WASHER	4	J20001-
13	07000-F3038	O-RING	1	J20001-
14	561-16-81161	TUBE	1	J20001-
15	07372-21040	BOLT	1	J20001-
16	07372-21050	BOLT	3	J20001-
17	01580-11008	NUT	3	J20001-
18	01643-51032	WASHER	4	J20001-
19	07000-F3035	O-RING	1	J20001-
20	07040-11007	PLUG	1	J20001-
21	07002-21023	O-RING	1	J20001-
22	561-16-81172	TUBE	1	J20001-
23	07371-21255	FLANGE	2	J20001-
24	07372-21035	BOLT	4	J20001-
25	01643-51032	WASHER	4	J20001-
26	07000-F3038	O-RING	1	J20001-
27	561-16-81241	PLATE	1	J20001-
28	01010-81235	BOLT	2	J20001-
29	01643-31232	WASHER	2	J20001-
30	07283-33442	CLIP	2	J20001-
31	01597-01009	NUT	4	J20001-
32	01643-31032	WASHER	4	J20001-
33	561-16-81230	PLATE	1	J20001-
34	01010-81235	BOLT	2	J20001-
35	01643-31232	WASHER	2	J20001-
36	07283-33442	CLIP	2	J20001-
37	01597-01009	NUT	4	J20001-
38	01643-31032	WASHER	4	J20001-
39	561-16-81220	PLATE	1	J20001-
40	561-16-81250	BRACKET	1	J20001-
41	07283-33442	CLIP	4	J20001-
42	01597-01009	NUT	8	J20001-
43	01643-31032	WASHER	8	J20001-




HYDRAULIC TANK ASS'Y (EMERGENCY STEERING LINE)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	569-40-85440	VALVE	1	J20001-
2	02896-21012	O-RING	1	J20001-
3	561-40-85120	TUBE	1	J20001-
4	07000-F3032	O-RING	1	J20001-
5	07372-21035	BOLT	4	J20001-
6	01643-51032	WASHER	4	J20001-




HYDRAULIC TANK ASS'Y (SENSOR)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	7861-93-3320	SENSOR	1	J20001-
2	08193-21012	CLIP	1	J20001-
3	01010-81016	BOLT	1	J20001-
4	01643-31032	WASHER	1	J20001-
5	7861-93-1930	SENSOR	2	J20001-
6	07005-01612	GASKET	2	J20001-
7	08034-20834	BAND	2	J20001-




HYDRAULIC TANK ASS'Y (MOUNTING PARTS)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-60-81370	BRACKET	1	J20001-
2	569-01-81130	CUSHION	1	J20001-
3	01643-32060	WASHER	4	J20001-
4	01010-82050	BOLT	4	J20001-
5	566-54-21920	PLATE	1	J20001-
6	01643-31845	WASHER	1	J20001-
7	01010-81895	BOLT	1	J20001-
8	561-60-81330	BRACKET	1	J20001-
9	561-60-81312	BRACKET	1	J20001-
10	561-46-62570	BOLT	3	J20001-
11	01580-12016	NUT	3	J20001-
12	01643-32060	WASHER	3	J20001-
13	561-60-81360	BRACKET	1	J20001-
14	561-60-81320	PLATE	1	J20001-
15	01010-82065	BOLT	1	J20001-
16	01643-32060	WASHER	1	J20001-
17	561-46-62570	BOLT	2	J20001-
18	01580-12016	NUT	2	J20001-
19	01643-32060	WASHER	2	J20001-
20	561-60-81610	PLATE	2	J20001-
21	01010-81675	BOLT	4	J20001-
22	01643-31645	WASHER	4	J20001-
23	07260-28728	HOSE	2	J20001-
24	07299-00105	CLAMP	8	J20001-
25	07260-25822	HOSE	1	J20001-
26	07299-00070	CLAMP	4	J20001-
27	07000-F3048	O-RING	2	J20001-
28	07371-31465	FLANGE	4	J20001-
29	07372-21240	BOLT	8	J20001-
30	01643-51232	WASHER	8	J20001-




BRAKE CONTROL VALVE

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	(561-60-62201)	VALVE ASS'Y	1	J20001-
2	561-60-82810	FLANGE	1	J20001-
3	07000-F3048	O-RING	1	J20001-
4	01011-81255	BOLT	4	J20001-
5	01643-31232	WASHER	4	J20001-
6	08034-20834	BAND	1	J20001-




BRAKE CONTROL VALVE (INNER PARTS)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-60-62201	VALVE ASS'Y	1	J20001-
1	561-60-62211	*BODY	1	J20001-
2	561-60-62221	*BODY	1	J20001-
3	561-60-62230	*VALVE	1	J20001-
4	561-60-62240	*SPRING	1	J20001-
5	561-60-62250	*SPRING	1	J20001-
6	700-80-51320	*HOLDER	1	J20001-
7	700-80-51170	*SEAT	1	J20001-
8	700-80-61190	*POPPET	1	J20001-
9	700-80-51240	*SPACER	1	J20001-
10	700-80-51230	*RETAINER	1	J20001-
11	700-10-51211	*SCREW	1	J20001-
12	700-10-51220	*COVER	1	J20001-
13	07000-F2055	*O-RING	1	J20001-
14	07002-12434	*O-RING	1	J20001-
15	07239-22410	*NUT	1	J20001-
16	07000-F2012	*O-RING	1	J20001-
17	07001-02012	*RING	1	J20001-
18	07002-11423	*O-RING	1	J20001-
19	01580-10605	*NUT	1	J20001-
20	07042-20108	*PLUG	4	J20001-
21	01010-81280	*BOLT	2	J20001-
22	01643-31232	*WASHER	2	J20001-
23	20Y-60-11510	*VALVE	1	J20001-
24	205-62-74580	*O-RING	4	J20001-
25	01252-30545	*BOLT	4	J20001-




HYDRAULIC MAIN PUMP

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	(705-52-42220)	PUMP ASS'Y	1	J20001-
2	07000-F2130	O-RING	1	J20001-
3	01010-81235	BOLT	4	J20001-
4	01643-31232	WASHER	4	J20001-
5	(705-95-07120)	PUMP ASS'Y	1	J20001-
6	07000-F2130	O-RING	1	J20001-
7	01010-81235	BOLT	4	J20001-
8	01643-31232	WASHER	4	J20001-
9	(705-56-44090)	PUMP ASS'Y	1	J20001-
10	07000-F2130	O-RING	1	J20001-
11	01010-81235	BOLT	4	J20001-
12	01643-31232	WASHER	4	J20001-




TRANSMISSION PIPING (1/4)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-61-81333	TUBE	1	J20001-
2	01010-81280	BOLT	4	J20001-
3	01643-31232	WASHER	4	J20001-
4	07000-F2050	O-RING	1	J20001-
5	561-61-81341	TUBE	1	J20001-
6	07372-21240	BOLT	4	J20001-
7	01643-51232	WASHER	4	J20001-
8	07000-F2045	O-RING	1	J20001-
9	07332-11400	COUPLING	1	J20001-
10	561-61-83821	TUBE	1	J20001-
11	01010-81290	BOLT	4	J20001-
12	01643-31232	WASHER	4	J20001-
13	07000-F2055	O-RING	1	J20001-
14	07332-12000	COUPLING	1	J20001-
15	07040-11007	PLUG	1	J20001-
16	07002-21023	O-RING	1	J20001-
17	561-16-8A512	TUBE	1	J20001-
18	07000-F2060	O-RING	1	J20001-
19	07372-21245	BOLT	4	J20001-
20	01643-51232	WASHER	4	J20001-
21	561-61-81390	PLATE	1	J20001-
22	07283-36155	CLIP	1	J20001-
23	07283-34949	CLIP	1	J20001-
24	01643-31032	WASHER	4	J20001-
25	01597-01009	NUT	4	J20001-




TRANSMISSION PIPING (2/4)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-16-8A111	TUBE	1	J20001-
2	07000-F2075	O-RING	1	J20001-
3	07372-21245	BOLT	4	J20001-
4	01643-51232	WASHER	4	J20001-
5	07260-07425	HOSE	1	J20001-
6	07299-00095	CLAMP	4	J20001-
7	561-16-8A121	TUBE	1	J20001-
8	07000-F2060	O-RING	1	J20001-
9	07372-21250	BOLT	4	J20001-
10	01643-51232	WASHER	4	J20001-
11	561-61-81150	BRACKET	1	J20001-
12	01010-81050	BOLT	2	J20001-
13	01643-31032	WASHER	2	J20001-
14	07283-37663	CLIP	1	J20001-
15	01597-01009	NUT	2	J20001-
16	01643-31032	WASHER	2	J20001-
17	561-16-8A130	TUBE	1	J20001-
18	07000-F2060	O-RING	1	J20001-
19	07372-21250	BOLT	4	J20001-
20	01643-51232	WASHER	4	J20001-
21	07332-12000	COUPLING	1	J20001-
22	561-61-85670	PLATE	1	J20001-
23	01010-81230	BOLT	2	J20001-
24	01643-31232	WASHER	2	J20001-
25	07283-37671	CLIP	1	J20001-
26	01597-01009	NUT	2	J20001-
27	01643-31032	WASHER	2	J20001-
28	561-61-85580	BRACKET	1	J20001-
29	07283-31079	CLIP	1	J20001-
30	01597-01211	NUT	2	J20001-
31	01643-31232	WASHER	2	J20001-
32	07283-37663	CLIP	1	J20001-
33	01597-01009	NUT	2	J20001-
34	01643-31032	WASHER	2	J20001-
35	561-61-85680	BRACKET	1	J20001-
36	01010-81230	BOLT	2	J20001-
37	01643-31232	WASHER	2	J20001-
38	07283-31079	CLIP	1	J20001-
39	01597-01211	NUT	2	J20001-
40	01643-31232	WASHER	2	J20001-




TRANSMISSION PIPING (3/4)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-16-81130	TUBE	1	J20001-
2	07000-F3035	O-RING	1	J20001-
3	07372-21045	BOLT	4	J20001-
4	01643-51032	WASHER	4	J20001-
5	561-16-81120	TUBE	1	J20001-
6	07000-F3035	O-RING	1	J20001-
7	07372-21045	BOLT	4	J20001-
8	01643-51032	WASHER	4	J20001-
9	561-16-81250	BRACKET	1	J20001-
10	07283-33442	CLIP	2	J20001-
11	01597-01009	NUT	4	J20001-
12	01643-31032	WASHER	4	J20001-
13	561-16-81211	BRACKET	1	J20001-
14	01010-81075	BOLT	2	J20001-
15	01643-31032	WASHER	2	J20001-
16	07283-33442	CLIP	2	J20001-
17	01597-01009	NUT	4	J20001-
18	01643-31032	WASHER	4	J20001-
19	07089-01209	HOSE	2	J20001-
20	07372-21035	BOLT	16	J20001-
21	01643-51032	WASHER	16	J20001-
22	07371-31255	FLANGE	8	J20001-
23	07000-F3038	O-RING	4	J20001-




TRANSMISSION PIPING (4/4)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	07087-01207	HOSE	2	J20001-
2	07371-31255	FLANGE	8	J20001-
3	07372-21035	BOLT	11	J20001-
4	419-877-1340	BOLT	5	J20001-
5	01643-51032	WASHER	16	J20001-
6	07000-F3038	O-RING	4	J20001-




TRANSMISSION PIPING (BREATHER TUBE) (1/2)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	07836-00817	CONNECTOR	1	J20001-
2	07831-00813	SLEEVE	1	J20001-
3	07832-00817	NUT	1	J20001-
4	07822-00833	TUBE	1	J20001-
5	04434-51210	CLIP	4	J20001-
6	01010-81020	BOLT	4	J20001-
7	01643-31032	WASHER	4	J20001-
8	01010-81090	BOLT	1	J20001-
9	01643-31032	WASHER	1	J20001-
10	01010-81055	BOLT	2	J20001-
11	01643-31032	WASHER	2	J20001-
12	04434-51210	CLIP	3	J20001-
13	6136-11-5120	SPACER	1	J20001-
14	6144-11-5630	SPACER	2	J20001-
15	285-35-12720	TEE	1	J20001-
16	07822-00807	TUBE	1	J20001-
17	04434-51212	CLIP	1	J20001-
18	144-54-51280	COLLAR	1	J20001-
19	01010-81275	BOLT	1	J20001-
20	01643-31232	WASHER	1	J20001-
21	07836-00817	CONNECTOR	1	J20001-
22	07831-00813	SLEEVE	1	J20001-
23	07832-00817	NUT	1	J20001-
24	561-16-81290	BLOCK	1	J20001-
25	01010-81230	BOLT	2	J20001-
26	01643-31232	WASHER	2	J20001-
27	07326-10302	ADAPTER	1	J20001-
28	07030-10252	BREATHER	1	J20001-
29	07836-00817	CONNECTOR	2	J20001-
30	07831-00813	SLEEVE	2	J20001-
31	07832-00817	NUT	2	J20001-
32	07822-00801	TUBE	1	J20001-
33	07836-00817	CONNECTOR	1	J20001-
34	07831-00813	SLEEVE	1	J20001-
35	07832-00817	NUT	1	J20001-




TRANSMISSION PIPING (BREATHER TUBE) (2/2)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	07822-00824	TUBE	1	J20001-
2	01010-81090	BOLT	1	J20001-
3	01643-31032	WASHER	1	J20001-
4	04434-51210	CLIP	1	J20001-
5	6136-11-5120	SPACER	1	J20001-
6	01010-81220	BOLT	1	J20001-
7	01643-31232	WASHER	1	J20001-
8	04434-51212	CLIP	1	J20001-
9	07283-34346	CLIP	1	J20001-
10	561-89-62830	PLATE	1	J20001-
11	04434-51210	CLIP	1	J20001-
12	01597-01009	NUT	2	J20001-
13	01643-31032	WASHER	2	J20001-
14	07283-34949	CLIP	2	J20001-
15	256-40-11620	PLATE	2	J20001-
16	04434-51210	CLIP	2	J20001-
17	01597-01009	NUT	4	J20001-
18	01643-31032	WASHER	4	J20001-
19	04434-51212	CLIP	1	J20001-
20	07836-00817	CONNECTOR	1	J20001-
21	07831-00813	SLEEVE	1	J20001-
22	07832-00817	NUT	1	J20001-




STEERING AND HOIST PIPING (STEERING CYLINDER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	(707-00-XX650)	CYLINDER GROUP	1	J20001-
2	(707-00-XX660)	CYLINDER GROUP	1	J20001-




STEERING AND HOIST PIPING (CROSS OVER VALVE)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	(561-60-82100)	VALVE ASS'Y	1	J20001-
2	01010-81050	BOLT	2	J20001-
3	01643-31032	WASHER	2	J20001-
4	561-60-82120	BRACKET	1	J20001-
5	01010-81230	BOLT	2	J20001-
6	01643-31232	WASHER	2	J20001-




STEERING AND HOIST PIPING (CROSS OVER VALVE) (FOR ASR)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	(561-60-82100)	VALVE ASS'Y	1	J20001-
2	01010-81050	BOLT	2	J20001-
3	01643-31032	WASHER	2	J20001-
4	561-88-86160	BRACKET	1	J20001-
5	01010-81230	BOLT	2	J20001-
6	01643-31232	WASHER	2	J20001-




STEERING AND HOIST PIPING (PIPING) (1/7)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	07373-31400	SPACER	2	J20001
2	07000-F3048	O-RING	2	J20001
3	561-87-81920	HOSE	1	J20001
4	561-87-81912	HOSE	1	J20001
5	07000-F3048	O-RING	4	J20001
6	07371-31465	FLANGE	8	J20001
7	07372-21250	BOLT	8	J20001
8	07372-21240	BOLT	8	J20001
9	01643-51232	WASHER	16	J20001
10	581-91-19110	FILTER	2	J20001
10A	07000-52090	*O-RING	1	J20001
10B	07001-02090	*RING	1	J20001
10C	581-91-19120	*ELEMENT	1	J20001
11	22W-62-18810	U-BOLT	4	J20001
12	01596-01009	NUT	8	J20001
13	01643-31032	WASHER	8	J20001
14	561-87-85160	BRACKET	1	J20001
15	01010-81230	BOLT	3	J20001
16	01643-31232	WASHER	3	J20001
17	561-87-85170	BRACKET	1	J20001
18	01010-81230	BOLT	3	J20001
19	01643-31232	WASHER	3	J20001
20	561-87-85151	PLATE	1	J20001
21	01010-81230	BOLT	4	J20001
22	01643-31232	WASHER	4	J20001
23	561-87-85180	BLOCK	1	J20001
24	561-87-85220	BLOCK	1	J20001
25	01010-81290	BOLT	4	J20001
26	01643-31232	WASHER	4	J20001
27	01010-81295	BOLT	4	J20001
28	01643-31232	WASHER	4	J20001
29	07000-F3048	O-RING	2	J20001




STEERING AND HOIST PIPING (PIPING) (2/7)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-61-84122	TUBE	1	J20001-
2	02896-21018	O-RING	2	J20001-
3	07040-11007	PLUG	2	J20001-
4	07002-21023	O-RING	2	J20001-
5	561-61-84180	TUBE	1	J20001-
6	02896-21012	O-RING	1	J20001-
7	07002-22034	O-RING	1	J20001-
8	561-61-84550	FILTER	1	J20001-
9	02896-21012	O-RING	1	J20001-
10	561-61-84152	TUBE	1	J20001-
11	02896-21018	O-RING	2	J20001-
12	07040-11409	PLUG	2	J20001-
13	07002-21423	O-RING	2	J20001-
14	561-61-84210	BRACKET	1	J20001-
15	01010-81230	BOLT	2	J20001-
16	01643-31232	WASHER	2	J20001-
17	07283-33442	CLIP	2	J20001-
18	07283-32236	CLIP	1	J20001-
19	01597-01009	NUT	6	J20001-
20	01643-31032	WASHER	6	J20001-
21	561-44-87470	BRACKET	1	J20001-
22	07283-33442	CLIP	2	J20001-
23	07283-32236	CLIP	1	J20001-
24	01597-01009	NUT	6	J20001-
25	01643-31032	WASHER	6	J20001-
26	561-61-84230	BRACKET	1	J20001-
27	01010-81230	BOLT	4	J20001-
28	01643-31232	WASHER	4	J20001-
29	07283-33442	CLIP	4	J20001-
30	07283-32236	CLIP	1	J20001-
31	01597-01009	NUT	10	J20001-
32	01643-31032	WASHER	10	J20001-




STEERING AND HOIST PIPING (PIPING) (3/7)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	07087-01409	HOSE	1	J20001-
2	07371-31465	FLANGE	4	J20001-
3	07372-21240	BOLT	8	J20001-
4	01643-51232	WASHER	8	J20001-
5	07000-F3048	O-RING	2	J20001-
6	561-61-83251	TUBE	1	J20001-
7	01010-81225	BOLT	2	J20001-
8	01643-31232	WASHER	2	J20001-
9	07088-412A9	HOSE	1	J20001-
10	07000-F3038	O-RING	2	J20001-
11	07371-31255	FLANGE	4	J20001-
12	07372-21035	BOLT	8	J20001-
13	01643-51032	WASHER	8	J20001-
14	07088-41222	HOSE	1	J20001-
15	07000-F3038	O-RING	2	J20001-
16	07371-31255	FLANGE	4	J20001-
17	07372-21035	BOLT	8	J20001-
18	01643-51032	WASHER	8	J20001-
19	07094-11432	CLAMP	2	J20001-
20	07095-01449	CUSHION	1	J20001-
21	01010-81290	BOLT	2	J20001-
22	01643-31232	WASHER	2	J20001-
23	561-61-83510	BLOCK	2	J20001-
24	07000-F3035	O-RING	2	J20001-
25	01010-81085	BOLT	8	J20001-
26	01643-31032	WASHER	8	J20001-
27	07040-11007	PLUG	2	J20001-
28	07002-21023	O-RING	2	J20001-




STEERING AND HOIST PIPING (PIPING) (4/7)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	02765-00619	HOSE	1	J20001-
2	02896-21018	O-RING	2	J20001-
3	04434-53412	CLIP	3	J20001-
4	07095-20627	CUSHION	3	J20001-
5	01010-81220	BOLT	3	J20001-
6	01643-31232	WASHER	3	J20001-
7	02782-10630	ELBOW	1	J20001-
8	07002-22434	O-RING	1	J20001-
9	561-61-83361	TUBE	1	J20001-
10	01010-81285	BOLT	2	J20001-
11	01643-31232	WASHER	2	J20001-
12	07088-406A6	HOSE	1	J20001-
13	07371-30638	FLANGE	4	J20001-
14	01010-80830	BOLT	8	J20001-
15	01643-30823	WASHER	8	J20001-
16	07000-F3025	O-RING	2	J20001-
17	07088-406A9	HOSE	1	J20001-
18	07371-30638	FLANGE	2	J20001-
19	01010-80830	BOLT	4	J20001-
20	01643-30823	WASHER	4	J20001-
21	07000-F3025	O-RING	2	J20001-
22	07094-10620	CLAMP	2	J20001-
23	07095-00630	CUSHION	1	J20001-
24	01010-81275	BOLT	1	J20001-
25	01643-31232	WASHER	1	J20001-
26	561-61-85570	BRACKET	1	J20001-
27	01010-81225	BOLT	2	J20001-
28	01643-31232	WASHER	2	J20001-
29	561-61-83531	BRACKET	1	J20001-
30	07283-36155	CLIP	2	J20001-
31	01597-01009	NUT	4	J20001-
32	01643-31032	WASHER	4	J20001-
33	07283-33442	CLIP	1	J20001-
34	07283-32738	CLIP	1	J20001-
35	01643-31032	WASHER	4	J20001-
36	01597-01009	NUT	4	J20001-
37	561-61-83541	BRACKET	1	J20001-
38	07371-30640	FLANGE	2	J20001-
39	07372-21035	BOLT	4	J20001-
40	01643-51032	WASHER	4	J20001-




STEERING AND HOIST PIPING (PIPING) (5/7)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	02762-00689	HOSE	1	J20001-
2	02896-21018	O-RING	1	J20001-
3	04434-53412	CLIP	14	J20001-
4	04434-53411	CLIP	5	J20001-
5	07095-20625	CUSHION	19	J20001-
6	285-03-11140	PLATE	2	J20001-
7	07283-38973	CLIP	2	J20001-
8	01597-01211	NUT	4	J20001-
9	01643-31232	WASHER	4	J20001-
10	01010-81225	BOLT	8	J20001-
11	01643-31232	WASHER	8	J20001-
12	01010-81220	BOLT	1	J20001-
13	01643-31232	WASHER	1	J20001-
14	561-88-81460	BRACKET	1	J20001-
15	01010-81225	BOLT	1	J20001-
16	01643-31232	WASHER	1	J20001-
17	569-54-41380	PLATE	1	J20001-
18	07283-36155	CLIP	1	J20001-
19	01643-31032	WASHER	2	J20001-
20	01597-01009	NUT	2	J20001-
21	561-89-62830	PLATE	3	J20001-
22	07283-34346	CLIP	3	J20001-
23	01597-01009	NUT	6	J20001-
24	01643-31032	WASHER	6	J20001-
25	256-40-11620	PLATE	1	J20001-
26	07283-34949	CLIP	1	J20001-
27	01597-01009	NUT	2	J20001-
28	01643-31032	WASHER	2	J20001-
29	02762-00679	HOSE	1	J20001-
30	02896-21018	O-RING	1	J20001-
31	04434-53412	CLIP	13	J20001-
32	04434-53411	CLIP	4	J20001-
33	07095-20625	CUSHION	17	J20001-




STEERING AND HOIST PIPING (PIPING) (6/7)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-61-84351	TUBE	1	J20001-
2	07000-F3035	O-RING	1	J20001-
3	01010-81060	BOLT	4	J20001-
4	01643-31032	WASHER	4	J20001-
5	02896-21018	O-RING	1	J20001-
6	561-61-84371	TUBE	1	J20001-
7	07000-F3035	O-RING	1	J20001-
8	01010-81060	BOLT	4	J20001-
9	01643-31032	WASHER	4	J20001-
10	07040-11007	PLUG	2	J20001-
11	07002-21023	O-RING	2	J20001-
12	07094-31024	CLAMP	2	J20001-
13	07095-01033	CUSHION	2	J20001-
14	01010-81275	BOLT	2	J20001-
15	01643-31232	WASHER	2	J20001-
16	02896-21018	O-RING	1	J20001-
17	07088-406A7	HOSE	1	J20001-
18	07088-40607	HOSE	1	J20001-
19	07088-40606	HOSE	2	J20001-
20	07000-F3025	O-RING	8	J20001-
21	07371-30638	FLANGE	8	J20001-
22	01010-80830	BOLT	16	J20001-
23	01643-50823	WASHER	16	J20001-
24	07371-30640	FLANGE	8	J20001-
25	07372-21035	BOLT	16	J20001-
26	01643-51032	WASHER	16	J20001-




STEERING AND HOIST PIPING (PIPING) (7/7)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-61-81130	TUBE	1	J20001-
2	01010-81250	BOLT	4	J20001-
3	01643-31232	WASHER	4	J20001-
4	07000-F2075	O-RING	1	J20001-
5	07260-09932	HOSE	1	J20001-
6	07299-00120	CLAMP	4	J20001-
7	561-61-81261	BRACKET	1	J20001-
8	07283-31079	CLIP	1	J20001-
9	01597-01211	NUT	2	J20001-
10	01643-31232	WASHER	2	J20001-
11	01010-81230	BOLT	2	J20001-
12	01643-31232	WASHER	2	J20001-
13	07332-12000	COUPLING	1	J20001-
14	561-61-81160	TUBE	1	J20001-
15	07000-F2075	O-RING	1	J20001-
16	01010-81250	BOLT	4	J20001-
17	01643-31232	WASHER	4	J20001-




STEERING AND HOIST PIPING (DUMP CONTROL)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	56B-43-12401	VALVE ASS'Y	1	J20001-
2	01010-81080	BOLT	3	J20001-
3	01643-31032	WASHER	3	J20001-
4	561-61-81431	BRACKET	1	J20001-
5	07040-11409	PLUG	1	J20001-
6	07002-21423	O-RING	1	J20001-
7	08034-20834	BAND	1	J20001-
8	02765-00339	HOSE	1	J20001-
9	02782-10315	ELBOW	1	J20001-
10	02896-21009	O-RING	1	J20001-
11	07002-22034	O-RING	1	J20001-
12	02782-10315	ELBOW	1	J20001-
13	02896-21009	O-RING	1	J20001-
14	07002-22034	O-RING	1	J20001-
15	02765-00315	HOSE, 1500MM	1	J20001-
16	02782-10210	ELBOW	1	J20001-
17	02896-21008	O-RING	1	J20001-
18	07002-21423	O-RING	1	J20001-
19	02765-00231	HOSE	1	J20001-
20	02782-10210	ELBOW	1	J20001-
21	02896-21008	O-RING	1	J20001-
22	07002-21423	O-RING	1	J20001-
23	02765-00235	HOSE	1	J20001-
24	02781-00210	UNION	1	J20001-
25	02896-21008	O-RING	1	J20001-
26	07002-21423	O-RING	1	J20001-
27	02766-00214	HOSE	1	J20001-




STEERING AND HOIST PIPING (DUMP CONTROL LINE) (1/3)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	22L-62-22520	NIPPLE	1	J20001-
2	07002-22434	O-RING	1	J20001-
3	02896-21009	O-RING	1	J20001-
4	561-61-85920	BRACKET	1	J20001-
5	04434-52112	CLIP	1	J20001-
6	07095-20314	CUSHION	1	J20001-
7	01010-81225	BOLT	3	J20001-
8	01643-31232	WASHER	3	J20001-
9	286-62-19130	PLATE	1	J20001-
10	04434-52112	CLIP	1	J20001-
11	07095-20314	CUSHION	1	J20001-
12	01010-81225	BOLT	2	J20001-
13	01643-31232	WASHER	2	J20001-
14	04434-52112	CLIP	3	J20001-
15	07095-20314	CUSHION	3	J20001-
16	01010-81220	BOLT	3	J20001-
17	01643-31232	WASHER	3	J20001-
18	256-40-11620	PLATE	1	J20001-
19	07283-34949	CLIP	1	J20001-
20	01643-31032	WASHER	2	J20001-
21	01597-01009	NUT	2	J20001-
22	04434-52110	CLIP	1	J20001-
23	07095-20314	CUSHION	1	J20001-
24	256-40-11620	PLATE	1	J20001-
25	07283-34949	CLIP	1	J20001-
26	01597-01009	NUT	2	J20001-
27	01643-31032	WASHER	2	J20001-
28	04434-52110	CLIP	1	J20001-
29	07095-20314	CUSHION	1	J20001-
30	04434-52112	CLIP	2	J20001-
31	07095-20314	CUSHION	2	J20001-
32	01010-81225	BOLT	1	J20001-
33	01643-31232	WASHER	1	J20001-
34	01010-81230	BOLT	1	J20001-
35	01643-31232	WASHER	1	J20001-




STEERING AND HOIST PIPING (DUMP CONTROL LINE) (2/3)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	04434-52112	CLIP	2	J20001-
2	07095-20314	CUSHION	2	J20001-
3	04434-52112	CLIP	1	J20001-
4	07095-20314	CUSHION	1	J20001-
5	02896-21009	O-RING	1	J20001-
6	04434-51912	CLIP	1	J20001-
7	07095-20211	CUSHION	1	J20001-
8	01010-81230	BOLT	1	J20001-
9	01643-31232	WASHER	1	J20001-
10	04434-51912	CLIP	4	J20001-
11	07095-20211	CUSHION	4	J20001-
12	01010-81225	BOLT	3	J20001-
13	01643-31232	WASHER	3	J20001-
14	02896-21008	O-RING	1	J20001-




STEERING AND HOIST PIPING (DUMP CONTROL LINE) (3/3)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	04434-51912	CLIP	6	J20001-
2	07095-20211	CUSHION	6	J20001-
3	01010-81225	BOLT	2	J20001-
4	01643-31232	WASHER	2	J20001-
5	281-70-16851	PLATE	2	J20001-
6	07283-32738	CLIP	2	J20001-
7	01597-01009	NUT	4	J20001-
8	01643-31032	WASHER	4	J20001-
9	04434-51910	CLIP	2	J20001-
10	07095-20211	CUSHION	2	J20001-
11	02896-21008	O-RING	1	J20001-
12	02896-21008	O-RING	1	J20001-
13	04434-51912	CLIP	2	J20001-
14	04434-51910	CLIP	1	J20001-
15	07095-20211	CUSHION	3	J20001-
16	01010-81220	BOLT	2	J20001-
17	01643-31232	WASHER	2	J20001-
18	01010-81240	BOLT	3	J20001-
19	01643-31232	WASHER	3	J20001-



CROSSOVER RELIEF VALVE


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-60-82100	VALVE ASS'Y	1	J20001-
	561-60-62110	*BODY	1	J20001-
	706-73-85600	*VALVE ASS'Y,RELIEF	2	J20001-
2	☆	**SLEEVE	1	J20001-
3	☆	**SEAT	1	J20001-
4	☆	**VALVE	1	J20001-
5	☆	**PISTON	1	J20001-
6	☆	**SPRING	1	J20001-
7	☆	**SCREW	1	J20001-
8	☆	**O-RING	1	J20001-
9	☆	**RING	1	J20001-
10	☆	**NUT	1	J20001-
11	07000-22016	**O-RING	1	J20001-
12	07001-02016	**RING	2	J20001-
13	07002-22434	**O-RING	1	J20001-



BRAKE COOLING OIL LINE (PUMP TO REAR BRAKE) (1/2)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-61-85660	FLANGE	2	J20001-
2	07000-F3042	O-RING	1	J20001-
3	07298-01223	HOSE	1	J20001-
4	07371-31255	FLANGE	4	J20001-
5	07372-21045	BOLT	4	J20001-
6	07372-21035	BOLT	4	J20001-
7	01643-51032	WASHER	8	J20001-
8	07000-F3038	O-RING	2	J20001-
9	07298-01221	HOSE	1	J20001-
10	07371-31255	FLANGE	4	J20001-
11	07000-F3042	O-RING	1	J20001-
12	07372-21045	BOLT	4	J20001-
13	07372-21035	BOLT	4	J20001-
14	01643-51032	WASHER	8	J20001-
15	07000-F3038	O-RING	2	J20001-
16	561-61-84710	BRACKET	1	J20001-
17	01010-81225	BOLT	2	J20001-
18	01643-31232	WASHER	2	J20001-
19	561-61-85291	BRACKET	1	J20001-
20	01010-81230	BOLT	2	J20001-
21	01643-31232	WASHER	2	J20001-
22	07283-38973	CLIP	1	J20001-
23	01643-31232	WASHER	2	J20001-
24	01597-01211	NUT	2	J20001-
25	07094-31228	CLAMP	4	J20001-
26	07095-01245	CUSHION	4	J20001-
27	01010-81285	BOLT	4	J20001-
28	01643-31232	WASHER	4	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

BRAKE COOLING OIL LINE (PUMP TO REAR BRAKE) (2/2)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-61-85813	TUBE	1	J20001-
2	561-61-85840	TUBE	1	J20001-
3	01643-51232	WASHER	4	J20001-
4	07372-21245	BOLT	4	J20001-
5	07000-F2060	O-RING	1	J20001-
6	01010-81230	BOLT	2	J20001-
7	01643-31232	WASHER	2	J20001-
8	01011-81245	BOLT	3	J20001-
9	01643-31232	WASHER	3	J20001-
10	07040-11007	PLUG	2	J20001-
11	07002-21023	O-RING	2	J20001-
12	561-61-81422	BRACKET	1	J20001-
13	01010-81240	BOLT	3	J20001-
14	01643-31232	WASHER	3	J20001-
15	561-61-85850	FLANGE	1	J20001-
16	07000-F2055	O-RING	1	J20001-
17	07297-01413	HOSE	2	J20001-
18	07000-F3048	O-RING	4	J20001-
19	07371-31465	FLANGE	8	J20001-
20	07372-21240	BOLT	12	J20001-
21	07372-21245	BOLT	4	J20001-
22	01643-51232	WASHER	16	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up

BRAKE COOLING OIL LINE (T/M TO FRONT BRAKE) (1/2)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-61-84661	TUBE	1	J20001-
2	07000-F2060	O-RING	1	J20001-
3	07372-21240	BOLT	4	J20001-
4	01643-51232	WASHER	4	J20001-
5	07040-11007	PLUG	1	J20001-
6	07002-21023	O-RING	1	J20001-
7	07296-020A7	HOSE	1	J20001-
8	07371-32076	FLANGE	4	J20001-
9	07372-21240	BOLT	8	J20001-
10	01643-51232	WASHER	8	J20001-
11	07000-F2060	O-RING	2	J20001-
12	561-61-85353	TUBE	1	J20001-
13	07000-F2060	O-RING	1	J20001-
14	07372-21240	BOLT	4	J20001-
15	01643-51232	WASHER	4	J20001-
16	561-61-85383	BRACKET	1	J20001-
17	01010-81230	BOLT	2	J20001-
18	01643-31232	WASHER	2	J20001-
19	07283-36155	CLIP	1	J20001-
20	01597-01009	NUT	2	J20001-
21	01643-31032	WASHER	2	J20001-
22	07283-38973	CLIP	1	J20001-
23	01597-01211	NUT	2	J20001-
24	01643-31232	WASHER	2	J20001-
25	561-61-85324	BRACKET	1	J20001-
26	01010-81230	BOLT	4	J20001-
27	01643-31232	WASHER	4	J20001-
28	07283-36155	CLIP	1	J20001-
29	01597-01009	NUT	2	J20001-
30	01643-31032	WASHER	2	J20001-
31	07283-38973	CLIP	1	J20001-
32	01597-01211	NUT	2	J20001-
33	01643-31232	WASHER	2	J20001-



BRAKE COOLING OIL LINE (T/M TO FRONT BRAKE) (2/2)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-61-84681	TUBE	1	J20001-
2	561-61-84433	BRACKET	1	J20001-
3	01010-81230	BOLT	2	J20001-
4	01643-31232	WASHER	2	J20001-
5	01010-81225	BOLT	2	J20001-
6	01643-31232	WASHER	2	J20001-
7	561-61-84421	BRACKET	1	J20001-
8	07283-34949	CLIP	2	J20001-
9	01597-01009	NUT	4	J20001-
10	01643-31032	WASHER	4	J20001-
11	01010-81230	BOLT	2	J20001-
12	01643-31232	WASHER	2	J20001-
13	561-61-84760	HOSE	4	J20001-
14	07371-31255	FLANGE	16	J20001-
15	07372-21035	BOLT	32	J20001-
16	01643-51032	WASHER	32	J20001-
17	07000-F3038	O-RING	8	J20001-
18	201-06-61370	GROMMET	4	J20001-
19	232-807-6161	CLIP	4	J20001-
20	01010-81225	BOLT	2	J20001-
21	01643-31232	WASHER	2	J20001-
22	01643-31232	WASHER	2	J20001-
23	01580-11210	NUT	2	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up

BRAKE COOLING OIL LINE (BRAKE TO OIL COOLER)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	07297-02013	HOSE	2	J20001-
2	07000-F2060	O-RING	4	J20001-
3	07371-32076	FLANGE	8	J20001-
4	07372-21240	BOLT	16	J20001-
5	01643-51232	WASHER	16	J20001-
6	561-86-85282	TUBE	1	J20001-
7	07040-11007	PLUG	2	J20001-
8	07002-21023	O-RING	2	J20001-
9	561-86-85290	TUBE	1	J20001-
10	07372-21245	BOLT	4	J20001-
11	01643-51232	WASHER	4	J20001-
12	07000-F2060	O-RING	1	J20001-
13	561-61-84820	PLATE	1	J20001-
14	561-61-84590	BRACKET	1	J20001-
15	07283-36155	CLIP	2	J20001-
16	07283-34949	CLIP	2	J20001-
17	01597-01009	NUT	8	J20001-
18	01643-31032	WASHER	8	J20001-
19	07332-03000	COUPLING	1	J20001-
20	561-61-85311	TUBE	1	J20001-
21	07283-38973	CLIP	1	J20001-
22	01597-01211	NUT	2	J20001-
23	01643-31232	WASHER	2	J20001-
24	07332-03000	COUPLING	1	J20001-
25	561-61-85373	TUBE	1	J20001-
26	561-61-84671	TUBE	1	J20001-
27	07372-21240	BOLT	4	J20001-
28	01643-51232	WASHER	4	J20001-
29	07332-03000	COUPLING	1	J20001-
30	561-61-85344	TUBE	1	J20001-
31	07000-F2100	O-RING	1	J20001-
32	01010-81245	BOLT	4	J20001-
33	130-43-64260	COLLAR	4	J20001-
34	561-61-84454	BRACKET	1	J20001-
35	01010-81230	BOLT	2	J20001-
36	01643-31232	WASHER	2	J20001-
37	07283-38973	CLIP	1	J20001-
38	01643-31232	WASHER	2	J20001-
39	01597-01211	NUT	2	J20001-
40	07283-36155	CLIP	1	J20001-
41	01643-31032	WASHER	2	J20001-
42	01597-01009	NUT	2	J20001-



BRAKE COOLING OIL LINE (OIL COOLER TO FILTER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	07332-12000	COUPLING	2	J20001-
2	561-61-85443	TUBE	1	J20001-
3	561-61-84462	BRACKET	1	J20001-
4	01010-81230	BOLT	2	J20001-
5	01643-31232	WASHER	2	J20001-
6	07283-36155	CLIP	1	J20001-
7	01597-01009	NUT	2	J20001-
8	01643-31032	WASHER	2	J20001-
9	07260-28728	HOSE	1	J20001-
10	07299-00105	CLAMP	4	J20001-
11	561-61-84690	TUBE	1	J20001-
12	561-61-85262	TUBE	1	J20001-
13	07372-21245	BOLT	4	J20001-
14	01643-51232	WASHER	4	J20001-
15	07000-F2090	O-RING	1	J20001-
16	561-61-85631	BRACKET	1	J20001-
17	01010-81230	BOLT	2	J20001-
18	01643-31232	WASHER	2	J20001-
19	07283-38973	CLIP	1	J20001-
20	01597-01211	NUT	2	J20001-
21	01643-31232	WASHER	2	J20001-
22	561-61-85470	BRACKET	1	J20001-
23	01010-81230	BOLT	2	J20001-
24	01643-31232	WASHER	2	J20001-
25	07283-38973	CLIP	2	J20001-
26	01597-01211	NUT	4	J20001-
27	01643-31232	WASHER	4	J20001-
28	561-61-85730	BRACKET	1	J20001-
29	01010-81235	BOLT	2	J20001-
30	01643-31232	WASHER	2	J20001-
31	561-61-85591	BRACKET	1	J20001-
32	01010-81230	BOLT	2	J20001-
33	01643-31232	WASHER	2	J20001-
34	01010-81235	BOLT	2	J20001-
35	01643-31232	WASHER	2	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up


BRAKE COOLING OIL LINE (BRAKE CONTROL VALVE TO FILTER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-61-85521	TUBE	1	J20001-
2	01010-81280	BOLT	4	J20001-
3	01643-31232	WASHER	4	J20001-
4	07000-F2060	O-RING	1	J20001-
5	561-61-84540	BRACKET	1	J20001-
6	01010-81230	BOLT	2	J20001-
7	01643-31232	WASHER	2	J20001-
8	07283-34949	CLIP	1	J20001-
9	01597-01009	NUT	2	J20001-
10	01643-31032	WASHER	2	J20001-
11	561-61-85720	BRACKET	1	J20001-
12	01010-81230	BOLT	2	J20001-
13	01643-31232	WASHER	2	J20001-
14	07283-34949	CLIP	1q	J20001-
15	01597-01009	NUT	2	J20001-
16	01643-31032	WASHER	2	J20001-
17	07332-11400	COUPLING	1	J20001-
18	02782-10210	ELBOW	1	J20001-
19	07002-21423	O-RING	1	J20001-
20	02896-21008	O-RING	1	J20001-
21	561-61-82361	HOSE	1	J20001-
22	02781-0021D	UNION	1	J20001-
23	07002-21423	O-RING	1	J20001-
24	02896-21008	O-RING	1	J20001-
25	04434-51712	CLIP	1	J20001-
26	07095-20211	CUSHION	1	J20001-
27	569-54-41380	PLATE	2	J20001-
28	07283-36155	CLIP	2	J20001-
29	01643-31032	WASHER	4	J20001-
30	01597-01009	NUT	4	J20001-
31	04434-51712	CLIP	2	J20001-
32	07095-20211	CUSHION	2	J20001-
33	04434-51712	CLIP	1	J20001-
34	07095-20211	CUSHION	1	J20001-
35	561-61-84490	BRACKET	1	J20001-
36	07283-36155	CLIP	1	J20001-
37	01597-01009	NUT	2	J20001-
38	01643-31032	WASHER	2	J20001-
39	01010-81225	BOLT	1	J20001-
40	01643-31232	WASHER	1	J20001-




BRAKE COOLING OIL LINE (SUCTION PIPING)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-61-81170	TUBE	1	J20001-
2	01010-81245	BOLT	4	J20001-
3	01643-31232	WASHER	4	J20001-
4	07332-04000	COUPLING	1	J20001-
5	07000-F2115	O-RING	1	J20001-
6	561-61-81272	TUBE	1	J20001-
7	07000-F2075	O-RING	1	J20001-
8	07372-21250	BOLT	4	J20001-
9	01643-51232	WASHER	4	J20001-
10	561-61-81230	BRACKET	1	J20001-
11	01010-81050	BOLT	2	J20001-
12	01643-31032	WASHER	2	J20001-
13	07283-31185	CLIP	1	J20001-
14	01597-01211	NUT	2	J20001-
15	01643-31232	WASHER	2	J20001-
16	561-61-81281	TUBE	1	J20001-
17	07000-F2075	O-RING	1	J20001-
18	07372-21250	BOLT	4	J20001-
19	01643-51232	WASHER	4	J20001-
20	07332-12400	COUPLING	1	J20001-




BRAKE COOLING OIL LINE (SENSOR)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	7861-93-3320	SENSOR	2	J20001-




ACCUMULATOR BOX (R.H) (1/3)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-43-84512	BRACKET	1	J20001-
2	561-43-84522	COVER	1	J20001-
3	01010-81020	BOLT	6	J20001-
4	01643-31032	WASHER	6	J20001-
5	(721-32-10410)	ACCUMULATOR ASS'Y	2	J20001-
6	421-43-22360	BAND	4	J20001-
7	421-40-12440	NUT	8	J20001-
8	01643-31232	WASHER	8	J20001-
9	569-43-84550	TEE	2	J20001-
10	07002-22434	O-RING	2	J20001-
11	07040-12412	PLUG	3	J20001-
12	07002-22434	O-RING	3	J20001-
13	07040-11812	PLUG	2	J20001-
14	07002-21823	O-RING	2	J20001-
15	02782-10313	ELBOW	1	J20001-
16	02896-21009	O-RING	1	J20001-
17	07002-21823	O-RING	1	J20001-
18	02782-10314	ELBOW	1	J20001-
19	02896-21009	O-RING	1	J20001-
20	07002-21823	O-RING	1	J20001-
21	02782-10522	ELBOW	1	J20001-
22	02896-21015	O-RING	1	J20001-
23	07002-22434	O-RING	1	J20001-
24	56B-43-17340	VALVE	2	J20001-
25	02896-21009	O-RING	2	J20001-
26	561-43-84541	BRACKET	1	J20001-
27	421-62-18550	CUSHION	3	J20001-
28	421-62-23710	CUSHION	3	J20001-
29	175-54-34170	WASHER	3	J20001-
30	01010-81040	BOLT	3	J20001-
31	01643-31032	WASHER	3	J20001-




ACCUMULATOR BOX (R.H) (2/3)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	(56B-43-17300)	VALVE	1	J20001-
2	01435-01090	BOLT	2	J20001-
3	02782-10518	ELBOW	1	J20001-
4	02896-21015	O-RING	1	J20001-
5	07002-22034	O-RING	1	J20001-
6	02782-10315	ELBOW	1	J20001-
7	02781-0031D	UNION	1	J20001-
8	02896-21009	O-RING	2	J20001-
9	07002-21423	O-RING	2	J20001-
10	02781-00516	UNION	1	J20001-
11	02896-21015	O-RING	1	J20001-
12	07002-22034	O-RING	1	J20001-
13	561-43-84530	BLOCK	1	J20001-
14	01010-81055	BOLT	3	J20001-
15	01643-31032	WASHER	3	J20001-
16	07040-12012	PLUG	1	J20001-
17	07002-22034	O-RING	1	J20001-
18	02782-10518	ELBOW	1	J20001-
19	02896-21015	O-RING	1	J20001-
20	07002-22034	O-RING	1	J20001-
21	02781-00516	UNION	2	J20001-
22	02896-21015	O-RING	2	J20001-
23	07002-22034	O-RING	2	J20001-
24	02782-10422	ELBOW	1	J20001-
25	02896-21012	O-RING	1	J20001-
26	07002-22034	O-RING	1	J20001-
27	02782-10516	ELBOW	1	J20001-
28	02896-21015	O-RING	1	J20001-
29	07002-22034	O-RING	1	J20001-




ACCUMULATOR BOX (R.H) (3/3)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-43-84560	TUBE	1	J20001-
2	02765-003A7	HOSE	1	J20001-
3	02766-00311	HOSE	1	J20001-
4	07094-30315	CLAMP	4	J20001-
5	07095-00318	CUSHION	4	J20001-
6	01010-81260	BOLT	2	J20001-
7	01643-31232	WASHER	2	J20001-
8	561-43-84590	HOSE	1	J20001-
9	07094-10518	CLAMP	4	J20001-
10	07095-00524	CUSHION	2	J20001-
11	01010-81265	BOLT	2	J20001-
12	01643-31232	WASHER	2	J20001-
13	02766-00504	HOSE	1	J20001-
14	02765-00403	HOSE	1	J20001-
15	02765-00528	HOSE	1	J20001-
16	02765-00511	HOSE	1	J20001-




ACCUMULATOR BOX (L.H)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-43-84411	BRACKET	1	J20001-
2	(721-32-10410)	ACCUMULATOR ASS'Y	2	J20001-
3	421-43-22360	BAND	4	J20001-
4	01643-31232	WASHER	8	J20001-
5	421-40-12440	NUT	8	J20001-
6	569-43-84550	TEE	2	J20001-
7	07002-22434	O-RING	2	J20001-
8	02782-10628	ELBOW	2	J20001-
9	02896-21018	O-RING	2	J20001-
10	07002-22434	O-RING	2	J20001-
11	56B-43-17340	VALVE	2	J20001-
12	02896-21009	O-RING	2	J20001-
13	07040-12412	PLUG	2	J20001-
14	07002-22434	O-RING	2	J20001-
15	07040-11812	PLUG	4	J20001-
16	07002-21823	O-RING	4	J20001-
17	561-43-84442	TUBE	1	J20001-
18	02896-21012	O-RING	1	J20001-




ACCUMULATOR CHARGER VALVE (INNER PARTS)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	56B-43-17300	VALVE, ACCUMULATOR CHARGE	1	J20001-
1	★	*BODY	1	J20001-
2	★	*SPOOL	1	J20001-
3	★	*VALVE, SEAT	1	J20001-
4	★	*PISTON	1	J20001-
5	★	*ORIFICE	1	J20001-
6	★	*PLUG	1	J20001-
7	★	*PLUG	2	J20001-
8	★	*ORIFICE	1	J20001-
9	★	*ORIFICE	1	J20001-
10	★	*RETAINER	1	J20001-
11	★	*ORIFICE	1	J20001-
12	419-43-12310	*RETAINER	1	J20001-
13	419-43-12330	*SCREW, ADJUST	2	J20001-
14	419-43-12340	*NUT	2	J20001-
15	419-43-12350	*SHIM	2	J20001-
16	419-43-12380	*PLUG ASS'Y	3	J20001-
	★	**O-RING	1	J20001-
17	419-43-12410	*PLUG ASS'Y	1	J20001-
	★	**O-RING	1	J20001-
18	419-43-12430	*O-RING	2	J20001-
19	421-43-27410	*RETAINER	1	J20001-
20	421-43-27430	*BALL	1	J20001-
21	421-43-27450	*SPRING	1	J20001-
22	421-43-27520	*FILTER	1	J20001-
23	421-43-27530	*RING	1	J20001-
24	42C-43-17310	*SPRING	1	J20001-
25	42C-43-17320	*SPRING	1	J20001-
26	42C-43-17330	*BALL	1	J20001-
27	42C-43-17340	*FILTER	1	J20001-
28	42C-43-17350	*BUSHING	1	J20001-
29	42C-43-17360	*PLUG	2	J20001-
30	07000-F1008	*O-RING	2	J20001-
31	07000-F2011	*O-RING	1	J20001-
32	07000-F2014	*O-RING	1	J20001-
33	07000-F2018	*O-RING	3	J20001-




BRAKE PIPING (FILTER LINE)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-43-83590	BRACKET	1	J20001-
2	01010-81225	BOLT	3	J20001-
3	01643-31232	WASHER	3	J20001-
4	(569-43-83910)	FILTER ASS'Y	1	J20001-
5	01010-81030	BOLT	4	J20001-
6	01643-31032	WASHER	4	J20001-
7	56B-43-17781	NIPPLE	1	J20001-
8	22W-62-13420	O-RING	1	J20001-
9	02896-21015	O-RING	1	J20001-
10	56B-43-17360	ELBOW	1	J20001-
11	22W-62-13420	O-RING	1	J20001-
12	02896-21015	O-RING	1	J20001-
13	02782-10522	ELBOW	1	J20001-
14	07002-22434	O-RING	1	J20001-
15	02896-21015	O-RING	1	J20001-
16	02765-00526	HOSE	1	J20001-
17	561-43-83810	BRACKET	2	J20001-
18	07283-38973	CLIP	2	J20001-
19	01643-31232	WASHER	4	J20001-
20	01597-01211	NUT	4	J20001-
21	07094-10518	CLAMP	10	J20001-
22	07095-00524	CUSHION	5	J20001-
23	01010-81265	BOLT	4	J20001-
24	01643-31232	WASHER	4	J20001-




BRAKE PIPING (FRAME L.H. SIDE)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	02766-00539	HOSE	1	J20001-
2	17M-49-15260	BRACKET	1	J20001-
3	01010-81225	BOLT	1	J20001-
4	01643-31232	WASHER	1	J20001-
5	07094-10518	CLAMP	10	J20001-
6	07095-00524	CUSHION	5	J20001-
7	01010-81265	BOLT	5	J20001-
8	01643-31232	WASHER	5	J20001-
9	561-43-83850	BRACKET	2	J20001-
10	01643-31232	WASHER	4	J20001-
11	01597-01211	NUT	4	J20001-
12	07283-38973	CLIP	2	J20001-
13	07094-10518	CLAMP	4	J20001-
14	07095-00524	CUSHION	2	J20001-
15	01010-81270	BOLT	2	J20001-
16	01643-31232	WASHER	2	J20001-
17	561-43-83393	TUBE	1	J20001-
18	02896-21015	O-RING	2	J20001-
19	07283-32236	CLIP	3	J20001-
20	01643-31032	WASHER	6	J20001-
21	01597-01009	NUT	6	J20001-
22	04434-52112	CLIP	3	J20001-
23	01010-81220	BOLT	2	J20001-
24	01643-31232	WASHER	2	J20001-




BRAKE PIPING (FRAME R.H. SIDE) (1/3)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-43-83311	TUBE	1	J20001-
2	02896-21012	O-RING	1	J20001-
3	02765-00407	HOSE 700MM	1	J20001-
4	561-43-83320	TUBE	1	J20001-
5	02896-21012	O-RING	1	J20001-
6	02765-00408	HOSE	1	J20001-
7	561-43-83332	TUBE	1	J20001-
8	02896-21012	O-RING	1	J20001-
9	561-43-83345	TUBE	1	J20001-
10	207-62-64740	O-RING	1	J20001-
11	561-43-83351	TUBE	1	J20001-
12	02896-21018	O-RING	1	J20001-
13	02767-00613	HOSE	1	J20001-
14	07094-10620	CLAMP	2	J20001-
15	07095-00628	CUSHION	1	J20001-
16	01643-31232	WASHER	1	J20001-
17	01011-81210	BOLT	1	J20001-
18	561-43-83361	TUBE	1	J20001-
19	02896-21015	O-RING	1	J20001-
20	561-43-83372	TUBE	1	J20001-
21	02896-21015	O-RING	1	J20001-
22	561-43-83380	TUBE	1	J20001-
23	02896-21015	O-RING	1	J20001-
24	02767-00511	HOSE	1	J20001-
25	07094-10518	CLAMP	2	J20001-
26	07095-00524	CUSHION	1	J20001-




BRAKE PIPING (FRAME R.H. SIDE) (2/3)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-43-83751	PLATE	1	J20001-
2	01010-81225	BOLT	4	J20001-
3	01643-31232	WASHER	4	J20001-
4	561-43-83731	PLATE	1	J20001-
5	01010-81230	BOLT	4	J20001-
6	01643-31232	WASHER	4	J20001-
7	07283-32236	CLIP	1	J20001-
8	07283-33442	CLIP	1	J20001-
9	07283-32738	CLIP	1	J20001-
10	01643-31032	WASHER	6	J20001-
11	01597-01009	NUT	6	J20001-
12	561-43-83741	PLATE	1	J20001-
13	01010-81230	BOLT	4	J20001-
14	01643-31232	WASHER	4	J20001-
15	07283-32236	CLIP	5	J20001-
16	01643-31032	WASHER	10	J20001-
17	01597-01009	NUT	10	J20001-
18	561-43-83773	BRACKET	1	J20001-
19	01010-81225	BOLT	2	J20001-
20	01643-31232	WASHER	2	J20001-
21	07283-33442	CLIP	1	J20001-
22	07283-32236	CLIP	1	J20001-
23	07283-32738	CLIP	1	J20001-
24	01643-31032	WASHER	6	J20001-
25	01597-01009	NUT	6	J20001-




BRAKE PIPING (FRAME R.H. SIDE) (3/3)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-43-84323	TUBE	1	J20001-
2	02896-21015	O-RING	2	J20001-
3	561-43-84342	TUBE	1	J20001-
4	02896-21015	O-RING	2	J20001-
5	561-43-84383	TUBE	1	J20001-
6	02896-21018	O-RING	2	J20001-
7	561-43-84372	TUBE	1	J20001-
8	02896-21015	O-RING	2	J20001-
9	561-43-84482	BRACKET	1	J20001-
10	561-43-83532	PLATE	1	J20001-
11	01010-81230	BOLT	4	J20001-
12	01643-31232	WASHER	4	J20001-
13	561-43-84781	PLATE	1	J20001-
14	07283-32236	CLIP	8	J20001-
15	07283-32738	CLIP	2	J20001-
16	01643-31032	WASHER	20	J20001-
17	01597-01009	NUT	20	J20001-
18	561-43-84491	BRACKET	1	J20001-
19	01010-81225	BOLT	2	J20001-
20	01643-31232	WASHER	2	J20001-
21	07094-30417	CLAMP	2	J20001-
22	07095-00421	CUSHION	2	J20001-
23	01010-81265	BOLT	1	J20001-
24	01643-31232	WASHER	1	J20001-
25	01643-31232	WASHER	1	J20001-
26	01580-01210	NUT	1	J20001-




BRAKE PIPING (FRAME R.H. SIDE) (FOR ASR)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-88-82411	TUBE	1	J20001-
2	02896-21015	O-RING	2	J20001-
3	561-88-82440	TUBE	1	J20001-
4	02896-21015	O-RING	2	J20001-
5	02766-00508	HOSE	1	J20001-
6	561-88-82420	PLATE	1	J20001-
7	07283-32236	CLIP	8	J20001-
8	01597-01009	NUT	16	J20001-
9	01643-31032	WASHER	16	J20001-




BRAKE PIPING (PARKING BRAKE VALVE LINE)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	(561-43-80601)	VALVE ASS'Y, PARKING BRAKE	1	J20001-
2	02766-006A3	HOSE	1	J20001-
3	02766-00505	HOSE	1	J20001-
4	02766-005A5	HOSE	1	J20001-
5	561-43-84152	TUBE	1	J20001-
6	207-62-64740	O-RING	1	J20001-
7	561-43-86472	PLATE	1	J20001-
8	01010-81230	BOLT	2	J20001-
9	01643-31232	WASHER	2	J20001-
10	07283-33442	CLIP	1	J20001-
11	01643-31032	WASHER	2	J20001-
12	01597-01009	NUT	2	J20001-
13	01010-81230	BOLT	3	J20001-
14	01643-31232	WASHER	3	J20001-




BRAKE PIPING (PARKING BRAKE VALVE LINE) (FOR ASR)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	(561-88-80601)	VALVE ASS'Y, PARKING BRAKING	1	J20001-
2	02766-006A3	HOSE	1	J20001-
3	02766-00505	HOSE	1	J20001-
4	02766-005A5	HOSE	1	J20001-
5	561-43-84152	TUBE	1	J20001-
6	207-62-64740	O-RING	1	J20001-
7	561-43-86472	PLATE	1	J20001-
8	01010-81230	BOLT	2	J20001-
9	01643-31232	WASHER	2	J20001-
10	07283-33442	CLIP	1	J20001-
11	01643-31032	WASHER	2	J20001-
12	01597-01009	NUT	2	J20001-
13	01010-81230	BOLT	3	J20001-
14	01643-31232	WASHER	3	J20001-



BRAKE PIPING (PROPORTIONAL VALVE LINE)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-43-80501	VALVE ASS'Y,PROPORTIONAL	1	J20001-
2	01010-81230	BOLT	5	J20001-
3	01643-31232	WASHER	5	J20001-
4	08210-02905	SPIRAL TUBE	1	J20001-
5	561-43-84182	BRACKET	1	J20001-
6	01010-81225	BOLT	2	J20001-
7	01643-31232	WASHER	2	J20001-
8	07094-11024	CLAMP	2	J20001-
9	07095-01034	CUSHION	1	J20001-
10	01010-81280	BOLT	2	J20001-
11	01643-31232	WASHER	2	J20001-



BRAKE PIPING (PROPORTIONAL VALVE LNE) (FOR ASR)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	(561-88-80501)	VALVE SUB ASS'Y	1	J20001-
2	01010-81230	BOLT	5	J20001-
3	01643-31232	WASHER	5	J20001-
4	08210-02905	SPIRAL TUBE	1	J20001-
5	561-43-84182	BRACKET	1	J20001-
6	01010-81225	BOLT	2	J20001-
7	01643-31232	WASHER	2	J20001-
8	07094-11024	CLAMP	2	J20001-
9	07095-01034	CUSHION	1	J20001-
10	01010-81280	BOLT	2	J20001-
11	01643-31232	WASHER	2	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

BRAKE PIPING (BRAKE SUB TANK) (TANK)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-43-84102	TANK ASS'Y	1	J20001-
1	561-43-84113	*TANK	1	J20001-
2	569-16-61570	*GAUGE	1	J20001-
	426-60-15150	*VALVE ASS'Y	1	J20001-
3	6693-22-5610	**BODY	1	J20001-
4	6693-22-5620	**VALVE	1	J20001-
5	04020-00514	**PIN	1	J20001-
6	426-60-15160	**PLUG	1	J20001-
7	07000-F3028	*O-RING	1	J20001-
8	01010-81025	*BOLT	2	J20001-
9	01643-31032	*WASHER	2	J20001-
10	201-60-22130	*COVER	1	J20001-
11	07000-F2140	*O-RING	1	J20001-
12	01010-81225	*BOLT	4	J20001-
13	01643-31232	*WASHER	4	J20001-
14	07056-10045	*STRAINER	1	J20001-
15	07051-01000	*CAP	1	J20001-
16	561-43-84910	*COVER	1	J20001-
17	01010-81220	*BOLT	2	J20001-
18	01643-31232	*WASHER	2	J20001-
19	561-43-84880	*SHEET	1	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up

BRAKE PIPING (BRAKE SUB TANK)(TANK)(WITH VANDALISM PROTECTION)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-43-80900	TANK ASS'Y,VANDALISM	1	J20001-
1	561-43-84113	.TANK	1	J20001-
2	569-16-61570	GAUGE.	1	J20001-
	426-60-15150	.VALVE ASS'Y	1	J20001-
3	6693-22-5610	.BODY	1	J20001-
4	6693-22-5620	..VALVE	1	J20001-
5	04020-00514	..PIN	1	J20001-
6	426-60-15160	..PLUG	1	J20001-
7	07000-F3028	.O-RING	1	J20001-
8	01010-81025	.BOLT	2	J20001-
9	01643-31032	.WASHER	2	J20001-
10	201-60-22130	.COVER	1	J20001-
11	07000-F2140	.O-RING	1	J20001-
12	01010-81225	.BOLT	4	J20001-
13	01643-31232	.WASHER	4	J20001-
14	07056-10045	.STRAINER	1	J20001-
15	07092-01000	.CAP	1	J20001-
16	561-43-84910	.COVER	1	J20001-
17	01010-81220	.BOLT	2	J20001-
18	01643-31232	.WASHER	2	J20001-
19	561-43-84880	.SHEET	1	J20001-



BRAKE PIPING (BRAKE SUB TANK) (TANK MOUNTING PARTS)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	01010-81640	BOLT	6	J20001-
2	01643-31645	WASHER	6	J20001-
3	561-43-84770	COVER	1	J20001-
4	04050-12015	PIN	1	J20001-
5	01541-21260	NUT	1	J20001-
6	01643-31232	WASHER	1	J20001-
7	01010-80820	BOLT	2	J20001-
8	01643-30823	WASHER	2	J20001-
9	561-43-84162	PLATE	1	J20001-
10	01010-81640	BOLT	2	J20001-
11	01643-31645	WASHER	2	J20001-
12	561-43-84172	PLATE	1	J20001-
13	01010-81640	BOLT	2	J20001-
14	01643-31645	WASHER	2	J20001-
15	561-43-84122	BRACKET	1	J20001-
16	01010-81635	BOLT	3	J20001-
17	01643-31645	WASHER	3	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up


BRAKE PIPING (BRAKE SUB TANK) (TANK RELATED PARTS)
(1/2)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-61-81413	TUBE	1	J20001-
2	07000-F3032	O-RING	1	J20001-
3	07372-21040	BOLT	4	J20001-
4	01643-51032	WASHER	4	J20001-
5	07260-03218	HOSE	1	J20001-
6	07289-00045	CLAMP	4	J20001-
7	561-43-84134	TUBE	1	J20001-
8	07000-F3032	O-RING	1	J20001-
9	07372-21035	BOLT	4	J20001-
10	01643-51032	WASHER	4	J20001-
11	561-43-84145	BRACKET	1	J20001-
12	07283-33442	CLIP	1	J20001-
13	01643-31032	WASHER	2	J20001-
14	01597-01009	NUT	2	J20001-
15	07283-38973	CLIP	1	J20001-
16	01643-31232	WASHER	2	J20001-
17	01597-01211	NUT	2	J20001-
18	07832-00817	NUT	1	J20001-
19	07831-00813	SLEEVE	1	J20001-
20	07834-00817	ELBOW	1	J20001-
21	07822-00821	TUBE	1	J20001-
22	175-40-22540	SPACER	1	J20001-
23	04434-51210	CLIP	2	J20001-
24	04434-51212	CLIP	3	J20001-
25	01010-81060	BOLT	1	J20001-
26	01643-31032	WASHER	1	J20001-
27	01010-81220	BOLT	1	J20001-
28	01643-31232	WASHER	1	J20001-
29	01010-81225	BOLT	2	J20001-
30	01643-31232	WASHER	2	J20001-
31	6142-22-4640	SPACER	1	J20001-
32	01010-81070	BOLT	1	J20001-
33	01643-31032	WASHER	1	J20001-



HD785-7 S/N J20001 and up
BRAKE PIPING (BRAKE SUB TANK) (TANK RELATED PARTS)
(2/2)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-43-84192	BRACKET	1	J20001-
2	07283-38973	CLIP	2	J20001-
3	01643-31232	WASHER	4	J20001-
4	01597-01211	NUT	4	J20001-
5	02782-10522	ELBOW	1	J20001-
6	02896-21015	O-RING	1	J20001-
7	07002-22434	O-RING	1	J20001-
8	21W-62-42640	ELBOW	2	J20001-
9	207-62-64740	O-RING	2	J20001-
10	07002-23334	O-RING	2	J20001-
11	02781-00628	UNION	2	J20001-
12	02896-21018	O-RING	2	J20001-
13	07002-22434	O-RING	2	J20001-
14	02765-006A5	HOSE	1	J20001-
15	561-43-83911	HOSE	1	J20001-
16	07094-11024	CLAMP	2	J20001-
17	07095-01034	CUSHION	1	J20001-
18	01010-81285	BOLT	2	J20001-
19	01643-31232	WASHER	2	J20001-
20	02782-10210	ELBOW	1	J20001-
21	561-43-84940	NIPPLE	1	J20001-
22	02896-21008	O-RING	2	J20001-
23	07002-21423	O-RING	2	J20001-
24	02766-00216	HOSE	1	J20001-
25	04434-51312	CLIP	3	J20001-
26	01010-81220	BOLT	1	J20001-
27	01643-31232	WASHER	1	J20001-



REAR BRAKE PIPING

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	02767-00506	HOSE	1	J20001-
2	02767-005A5	HOSE	1	J20001-
3	56B-43-17430	VALVE ASS'Y	1	J20001-
4	01010-80870	BOLT	2	J20001-
5	01643-30823	WASHER	2	J20001-
6	02781-00516	UNION	2	J20001-
7	569-43-83631	TEE	1	J20001-
8	07002-22034	O-RING	3	J20001-
9	02896-21015	O-RING	4	J20001-
10	02766-00512	HOSE	2	J20001-
11	02766-00508	HOSE	1	J20001-
12	07094-30518	CLAMP	2	J20001-
13	07095-00524	CUSHION	2	J20001-
14	01010-81265	BOLT	1	J20001-
15	01643-31232	WASHER	1	J20001-
16	01580-11210	NUT	1	J20001-
17	01643-31232	WASHER	1	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

REAR BRAKE PIPING (FOR ASR)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	02767-00506	HOSE	1	J20001-
2	02767-005A5	HOSE	1	J20001-
3	56B-43-17430	VALVE ASS'Y	1	J20001-
4	01010-80870	BOLT	2	J20001-
5	01643-30823	WASHER	2	J20001-
6	02781-00516	UNION	2	J20001-
7	569-43-83631	TEE	1	J20001-
8	07002-22034	O-RING	3	J20001-
9	02896-21015	O-RING	4	J20001-
10	02766-00506	HOSE	2	J20001-
11	02767-004A8	HOSE	2	J20001-
12	02766-00508	HOSE	1	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

FRONT BRAKE PIPING (R.H)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-43-84611	BLOCK	1	J20001-
2	01011-81245	BOLT	1	J20001-
3	01643-31232	WASHER	1	J20001-
4	01011-81200	BOLT	1	J20001-
5	01643-31232	WASHER	1	J20001-
6	566-16-11390	SPACER	2	J20001-
7	02781-00422	UNION	2	J20001-
8	02896-21012	O-RING	2	J20001-
9	07002-22034	O-RING	2	J20001-
10	02782-10422	ELBOW	2	J20001-
11	02896-21012	O-RING	2	J20001-
12	07002-22034	O-RING	2	J20001-
13	561-43-84671	BRACKET	1	J20001-
14	01010-81025	BOLT	2	J20001-
15	01643-31032	WASHER	2	J20001-
16	07094-30417	CLAMP	2	J20001-
17	07095-00421	CUSHION	2	J20001-
18	01010-81265	BOLT	1	J20001-
19	01643-31232	WASHER	1	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

FRONT BRAKE PIPING (L.H)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-43-84611	BLOCK	1	J20001-
2	566-16-11390	SPACER	2	J20001-
3	01011-81200	BOLT	2	J20001-
4	01643-31232	WASHER	2	J20001-
5	02781-00422	UNION	2	J20001-
6	02896-21012	O-RING	2	J20001-
7	07002-22034	O-RING	2	J20001-
8	02782-10422	ELBOW	2	J20001-
9	02896-21012	O-RING	2	J20001-
10	07002-22034	O-RING	2	J20001-
11	07094-30417	CLAMP	2	J20001-
12	07095-00421	CUSHION	2	J20001-
13	01010-81260	BOLT	1	J20001-
14	01643-31232	WASHER	1	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up


BRAKE PIPING (FILTER INNER PARTS)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	569-43-83910	FILTER ASS'Y	1	J20001-
2	569-43-83920	ELEMENT	1	J20001-
3	07000-12065	O-RING	1	J20001-
4	07001-02065	RING,BACK-UP	1	J20001-




BRAKE PIPING (PARKING BRAKE VALVE) (INNER PARTS)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-43-80601	VALVE ASS'Y	1	J20001-
1	42C-60-18230	VALVE	2	J20001-
2	561-43-84651	BLOCK	1	J20001-
3	02781-00628	UNION	1	J20001-
4	02896-21018	O-RING	1	J20001-
5	07002-22434	O-RING	1	J20001-
6	02781-00516	UNION	1	J20001-
7	02896-21015	O-RING	1	J20001-
8	07002-22034	O-RING	1	J20001-
9	02782-10516	ELBOW	1	J20001-
10	02896-21015	O-RING	1	J20001-
11	07002-22034	O-RING	1	J20001-
12	21W-62-42640	ELBOW	1	J20001-
13	207-62-64740	O-RING	1	J20001-
14	07002-23334	O-RING	1	J20001-
15	421-43-32912	SWITCH	2	J20001-
16	07002-21423	O-RING	2	J20001-
17	561-43-84711	PLATE	2	J20001-
18	01010-80816	BOLT	2	J20001-
19	01643-30823	WASHER	2	J20001-
20	08034-20834	BAND	4	J20001-




BRAKE PIPING (PARKING BRAKE VALVE) (INNER PARTS) (FOR ASR)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-88-80601	VALVE ASS'Y	1	J20001-
1	42C-60-18230	VALVE	2	J20001-
2	561-43-84651	BLOCK	1	J20001-
3	02781-00628	UNION	1	J20001-
4	02896-21018	O-RING	1	J20001-
5	07002-22434	O-RING	1	J20001-
6	02781-00516	UNION	1	J20001-
7	02896-21015	O-RING	1	J20001-
8	07002-22034	O-RING	1	J20001-
9	02782-10516	ELBOW	1	J20001-
10	02896-21015	O-RING	1	J20001-
11	07002-22034	O-RING	1	J20001-
12	561-88-82430	ELBOW	1	J20001-
13	207-62-64740	O-RING	1	J20001-
14	07002-23334	O-RING	1	J20001-
15	02896-21015	O-RING	1	J20001-
16	421-43-32912	SWITCH	2	J20001-
17	07002-21423	O-RING	2	J20001-
18	561-43-84711	PLATE	2	J20001-
19	01010-80816	BOLT	2	J20001-
20	01643-30823	WASHER	2	J20001-
21	08034-20834	BAND	4	J20001-




BRAKE PIPING (PROPORTIONAL VALVE) (INNER PARTS)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-43-80501	VALVE ASS'Y	1	J20001-
1	561-43-84682	.BRACKET	1	J20001-
2	569-43-83171	.VALVE	2	J20001-
3	01010-81095	.BOLT	4	J20001-
4	01643-31032	.WASHER	4	J20001-
5	02782-10516	.ELBOW	4	J20001-
6	02896-21015	.O-RING	4	J20001-
7	07002-22034	.O-RING	4	J20001-
8	561-43-83681	.ELBOW	2	J20001-
9	02896-21015	.O-RING	2	J20001-
10	07002-22034	.O-RING	2	J20001-
11	418-43-37681	.SWITCH	2	J20001-
12	07002-21423	.O-RING	2	J20001-
13	561-43-84642	.TUBE	1	J20001-
14	207-62-64740	.O-RING	2	J20001-
15	01010-81225	.BOLT	1	J20001-
16	01643-31232	.WASHER	1	J20001-
17	561-43-83940	.HOSE	1	J20001-
18	561-43-83911	.HOSE	1	J20001-
19	02767-00506	.HOSE	2	J20001-
20	02767-00507	HOSE	1	J20001-
21	02767-005A7	HOSE	1	J20001-
22	08037-03614	GROMMET	1	J20001-
23	08034-20834	BAND	3	J20001-



BRAKE PIPING (PROPORTIONAL VALVE) (INNER PARTS) (FOR ASR)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-88-80501	VALVE SUB ASS'Y	1	J20001-
1	561-43-84682	BRACKET	1	J20001-
2	569-43-83171	VALVE	2	J20001-
3	01010-81095	BOLT	4	J20001-
4	01643-31032	WASHER	4	J20001-
5	02782-10516	ELBOW	3	J20001-
6	02896-21015	O-RING	3	J20001-
7	07002-22034	O-RING	3	J20001-
8	561-88-86150	ELBOW	1	J20001-
9	02896-21015	O-RING	2	J20001-
10	07002-22034	O-RING	1	J20001-
11	561-43-83681	ELBOW	2	J20001-
12	02896-21015	O-RING	2	J20001-
13	07002-22034	O-RING	2	J20001-
14	418-43-37681	SWITCH	2	J20001-
15	07002-21423	O-RING	2	J20001-
16	561-43-84642	TUBE	1	J20001-
17	207-62-64740	O-RING	2	J20001-
18	01010-81225	BOLT	1	J20001-
19	01643-31232	WASHER	1	J20001-
20	561-43-83940	HOSE	1	J20001-
21	561-43-83911	HOSE	1	J20001-
22	02767-00506	HOSE	2	J20001-
23	02767-00507	HOSE	1	J20001-
24	02767-005A7	HOSE	1	J20001-
25	02765-005A6	HOSE	1	J20001-
26	07094-30518	CLAMP	2	J20001-
27	07095-00524	CUSHION	2	J20001-
28	01010-81265	BOLT	1	J20001-
29	01643-31232	WASHER	1	J20001-
30	01580-01210	NUT	1	J20001-
31	01643-31232	WASHER	1	J20001-
32	08037-03614	GROMMET	1	J20001-
33	08034-20834	BAND	3	J20001-




EMERGENCY STEERING FLOW SWITCH

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	421-06-35111	SWITCH	1	J20001-
2	20D-62-17150	O-RING	1	J20001-
3	08034-20834	BAND	1	J20001-

MAIN FRAME AND RELATED PARTS

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

MAIN FRAME (FRAME)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-46-81102	FRAME SUB ASS'Y	1	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up


MAIN FRAMEM(FRAME) (ASR) (ADDITIONAL FILTER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-46-81340	FRAME SUB ASS'Y	1	J20001-




MAIN FRAME (BRACKET)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-46-82412	BRACKET,(L.H.)	1	J20001-
2	561-46-82421	BRACKET,(R.H.)	1	J20001-
3	01010-82050	BOLT	12	J20001-
4	01643-32060	WASHER	12	J20001-
5	04020-01842	PIN	2	J20001-
6	561-46-82512	BRACKET,(L.H.)	1	J20001-
7	561-46-82542	BRACKET,(L.H.)	1	J20001-
8	561-46-62570	BOLT	4	J20001-
9	01643-32060	WASHER	4	J20001-
10	01580-12016	NUT	4	J20001-
11	561-46-82522	BRACKET,(R.H.)	1	J20001-
12	561-46-82532	BRACKET,(R.H.)	1	J20001-
13	561-46-62570	BOLT	4	J20001-
14	01643-32060	WASHER	4	J20001-
15	01580-12016	NUT	4	J20001-
16	561-46-82552	BRACKET,(L.H.)	1	J20001-
17	561-46-82561	BRACKET,(R.H.)	1	J20001-
18	01010-82055	BOLT	16	J20001-
19	01643-32060	WASHER	16	J20001-
20	04020-01842	PIN	2	J20001-
21	04080-08018	HOLDER	2	J20001-
22	04081-08016	LOCK	2	J20001-
23	01010-81640	BOLT	4	J20001-




MAIN FRAME (BRACKET) (ADDITIONAL FILTER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-46-82412	BRACKET,(L.H.)	1	J20001-
2	561-46-82490	BRACKET,(R.H.)	1	J20001-
3	01010-82050	BOLT	12	J20001-
4	01643-32060	WASHER	12	J20001-
5	04020-01842	PIN	2	J20001-
6	561-46-82512	BRACKET,(L.H.)	1	J20001-
7	561-46-82542	BRACKET,(L.H.)	1	J20001-
8	561-46-62570	BOLT	4	J20001-
9	01643-32060	WASHER	4	J20001-
10	01580-12016	NUT	4	J20001-
11	561-46-82522	BRACKET,(R.H.)	1	J20001-
12	561-46-82532	BRACKET,(R.H.)	1	J20001-
13	561-46-62570	BOLT	4	J20001-
14	01643-32060	WASHER	4	J20001-
15	01580-12016	NUT	4	J20001-
16	561-46-82552	BRACKET,(L.H.)	1	J20001-
17	561-46-82561	BRACKET,(R.H.)	1	J20001-
18	01010-82055	BOLT	16	J20001-
19	01643-32060	WASHER	16	J20001-
20	04020-01842	PIN	2	J20001-
21	04080-08018	HOLDER	2	J20001-
22	04081-08016	LOCK	2	J20001-
23	01010-81640	BOLT	4	J20001-




MAIN FRAME (AXLE SUPPORT)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-52-81120	ROD	2	J20001-
2	561-50-82310	BUSHING	4	J20001-
3	561-52-81140	BOOT	8	J20001-
4	07000-12090	O-RING	8	J20001-
5	561-52-81210	PIN	6	J20001-
6	561-52-81170	BUSHING	8	J20001-
7	01010-81430	BOLT	4	J20001-
8	01010-81425	BOLT	2	J20001-
9	569-40-61710	WASHER	6	J20001-
10	561-52-81150	SPACER	8	J20001-
11	561-52-8A180	BUSHING	4	J20001-



REAR SUPPORT


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-46-80200	REAR SUPPORT,(L.H.)	1	J20001-
1	561-46-81782	.SUPPORT	1	J20001-
2	569-54-82322	.BRACKET	2	J20001-
3	569-54-82371	.VISCOUS MOUNT	1	J20001-
4	01596-03024	.NUT	2	J20001-
5	01643-33080	.WASHER	2	J20001-
6	01010-82075	.BOLT	8	J20001-
7	01643-32060	.WASHER	8	J20001-
8	561-54-82371	.VISCOUS MOUNT	1	J20001-
9	01010-82475	BOLT	18	J20001-
10	01643-32460	WASHER	18	J20001-
11	561-46-81791	SUPPORT	1	J20001-
12	01010-81850	BOLT	7	J20001-
13	01643-31845	WASHER	7	J20001-



REAR SUPPORT (MUFFLER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-46-80200	REAR SUPPORT,(L.H.)	1	J20001-
1	561-46-81782	.SUPPORT	1	J20001-
2	569-54-82322	.BRACKET	2	J20001-
3	569-54-82371	.VISCOUS MOUNT	1	J20001-
4	01596-03024	.NUT	2	J20001-
5	01643-33080	.WASHER	2	J20001-
6	01010-82075	.BOLT	8	J20001-
7	01643-32060	.WASHER	8	J20001-
8	561-54-82371	.VISCOUS MOUNT	1	J20001-
9	01010-82475	BOLT	18	J20001-
10	01643-32460	WASHER	18	J20001-
11	561-84-84391	SUPPORT,R.H.	1	J20001-
12	01010-81850	BOLT	7	J20001-
13	01643-31845	WASHER	7	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

FRONT SUPPORT (SUPPORT) (L.H)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-54-80301	FRONT SUPPORT,(L.H.)	1	J20001-
1	561-54-81312	*SUPPORT,(L.H.)	1	J20001-
2	569-54-81391	*PLATE	1	J20001-
3	01010-81025	*BOLT	2	J20001-
4	01643-31032	*WASHER	2	J20001-
5	561-54-86661	*COVER	1	J20001-
6	01010-81230	*BOLT	4	J20001-
7	01643-31232	*WASHER	4	J20001-
8	09415-03614	*CAP	2	J20001-
9	561-54-86910	*COVER	1	J20001-
10	01010-81020	*BOLT	2	J20001-
11	01643-31032	*WASHER	2	J20001-
12	561-06-86652	*BRACKET	1	J20001-
13	415-64-13130	*CUSHION	3	J20001-
14	419-43-17930	*CUSHION	3	J20001-
15	419-43-17920	*WASHER	6	J20001-
16	417-54-13470	*SPACER	3	J20001-
17	01010-81250	*BOLT	3	J20001-
18	01643-31232	*WASHER	3	J20001-
19	566-06-6A310	*LAMP ASS'Y	2	J20001-
	23S-06-54121	**LENS ASS'Y	2	J20001-
	421-06-23330	**BULB, 70W	2	J20001-
20	23B-06-42460	*LAMP ASS'Y	1	J20001-
	41G-06-13210	**LENS	1	J20001-
	41G-06-13220	**LENS	1	J20001-
	41G-06-13230	**BULB, 5W	1	J20001-
	08105-12420	**BULB, 25W	1	J20001-
21	08053-01510	*CLIP	3	J20001-
22	04434-50810	*CLIP	2	J20001-
23	01010-81020	*BOLT	3	J20001-
24	01643-31032	*WASHER	3	J20001-
25	561-06-83252	*WIRING HARNESS	1	J20001-
26	04434-51010	*CLIP	3	J20001-
27	01010-81016	*BOLT	6	J20001-
28	01643-31032	*WASHER	6	J20001-
29	08034-20519	*BAND	4	J20001-
30	569-54-82310	*BRACKET	1	J20001-
31	569-54-82371	*VISCOUS MOUNT	1	J20001-
32	01596-03024	*NUT	1	J20001-
33	01643-33080	*WASHER	1	J20001-
34	01010-62065	*BOLT	4	J20001-
35	01643-32060	*WASHER	4	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up

FRONT SUPPORT (SUPPORT) (L.H) (FOG LAMP)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-85-80100	FRONT SUPPORT,(L.H.)	1	J20001-
1	561-85-81120	SUPPORT,(L.H.)	1	J20001-
2	569-54-81391	PLATE	1	J20001-
3	01010-81025	BOLT	2	J20001-
4	01643-31032	WASHER	2	J20001-
5	561-54-86661	COVER	1	J20001-
6	01010-81230	BOLT	4	J20001-
7	01643-31232	WASHER	4	J20001-
8	09415-03614	CAP	2	J20001-
9	561-54-86910	COVER	1	J20001-
10	01010-81020	BOLT	2	J20001-
11	01643-31032	WASHER	2	J20001-
12	561-06-86652	*BRACKET	1	J20001-
13	415-64-13130	*CUSHION	3	J20001-
14	419-43-17930	*CUSHION	3	J20001-
15	419-43-17920	*WASHER	6	J20001-
16	417-54-13470	*SPACER	3	J20001-
17	01010-81250	*BOLT	3	J20001-
18	01643-31232	*WASHER	3	J20001-
19	566-06-6A310	*LAMP ASS'Y	2	J20001-
	23S-06-54121	**LENS ASS'Y	2	J20001-
	421-06-23330	**BULB, 70W	2	J20001-
20	23B-06-42460	*LAMP ASS'Y	1	J20001-
	41G-06-13210	**LENS	1	J20001-
	41G-06-13220	**LENS	1	J20001-
	41G-06-13230	**BULB, 5W	1	J20001-
	08105-12420	**BULB, 25W	1	J20001-
21	08053-01510	*CLIP	3	J20001-
22	04434-50810	*CLIP	2	J20001-
23	01010-81020	*BOLT	3	J20001-
24	01643-31032	*WASHER	3	J20001-
25	561-06-83252	*WIRING HARNESS	1	J20001-
26	04434-51010	*CLIP	3	J20001-
27	01010-81016	*BOLT	6	J20001-
28	01643-31032	*WASHER	6	J20001-
29	08034-20519	*BAND	4	J20001-
30	569-54-82310	*BRACKET	1	J20001-
31	569-54-82371	*VISCOUS MOUNT	1	J20001-
32	01596-03024	*NUT	1	J20001-
33	01643-33080	*WASHER	1	J20001-
34	01010-62065	*BOLT	4	J20001-
35	01643-32060	*WASHER	4	J20001-



FRONT SUPPORT (L.H.) (BRACKET)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	569-54-81391	PLATE	1	J20001-
2	01010-81030	BOLT	2	J20001-
3	01643-31032	WASHER	2	J20001-
4	561-54-86612	COVER	1	J20001-
5	561-54-81372	STEP	1	J20001-
6	01010-81235	BOLT	4	J20001-
7	01643-31232	WASHER	4	J20001-
8	01010-81225	BOLT	2	J20001-
9	01643-31232	WASHER	2	J20001-
10	561-54-31690	STEP	1	J20001-
11	01010-81230	BOLT	4	J20001-
12	01643-31232	WASHER	4	J20001-
13	561-54-86871	STEP	1	J20001-
14	01010-81225	BOLT	4	J20001-
15	01643-31232	WASHER	4	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up


FRONT SUPPORT (L.H.) (SUPPORT RELATED PARTS)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	569-54-82310	BRACKET	1	J20001-
2	569-54-82371	VISCOUS MOUNT	1	J20001-
3	01596-03024	NUT	1	J20001-
4	01643-33080	WASHER	1	J20001-
5	01010-62065	BOLT	4	J20001-
6	01643-32060	WASHER	4	J20001-
7	01010-82270	BOLT	11	J20001-
8	01643-32260	WASHER	11	J20001-




FRONT SUPPORT (L.H.) (STEP)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-54-86740	STEP	1	J20001-
2	01010-81030	BOLT	4	J20001-
3	01643-31032	WASHER	4	J20001-
4	561-54-86751	BRACKET	2	J20001-
5	01010-81225	BOLT	4	J20001-
6	01643-31232	WASHER	4	J20001-
7	561-54-86811	GRIP	1	J20001-
8	07283-34949	CLIP	2	J20001-
9	01597-01009	NUT	4	J20001-
10	01643-31032	WASHER	4	J20001-
11	561-54-86970	GRIP	2	J20001-
12	01010-81230	BOLT	4	J20001-
13	01643-31232	WASHER	4	J20001-




FRONT SUPPORT (L.H.) (STEERING VALVE)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-54-81580	COVER	1	J20001-
2	01010-81220	BOLT	4	J20001-
3	01643-31232	WASHER	4	J20001-
4	561-54-81490	COVER	1	J20001-
5	01010-81220	BOLT	4	J20001-
6	01643-31232	WASHER	4	J20001-
7	561-40-83300	STEERING VALVE	1	J20001-
8	561-40-42620	CUSHION	4	J20001-
9	561-40-42630	COLLAR	4	J20001-
10	561-40-42650	PLATE	4	J20001-
11	02010-20638	BOLT	4	J20001-
12	01643-31032	WASHER	4	J20001-
13	569-40-83470	BRACKET	2	J20001-
14	569-40-83480	SEAL	1	J20001-
15	01010-80616	BOLT	2	J20001-
16	01643-30623	WASHER	2	J20001-
17	01643-30623	WASHER	2	J20001-
18	01580-10605	NUT	2	J20001-




FRONT SUPPORT (L.H.) (STEERING PIPING)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	02766-00423	HOSE	1	J20001-
2	02896-21012	O-RING	1	J20001-
3	561-61-82310	HOSE	1	J20001-
4	569-61-84770	NIPPLE	1	J20001-
5	02896-21018	O-RING	1	J20001-
6	437-40-22310	O-RING	1	J20001-
7	561-61-82320	HOSE	1	J20001-
8	569-61-84770	NIPPLE	1	J20001-
9	02896-21018	O-RING	1	J20001-
10	437-40-22310	O-RING	1	J20001-
11	561-61-82340	HOSE	1	J20001-
12	569-61-84780	NIPPLE	1	J20001-
13	02896-21018	O-RING	1	J20001-
14	418-62-11620	O-RING	1	J20001-
15	561-61-82350	HOSE	1	J20001-
16	569-61-84780	NIPPLE	1	J20001-
17	02896-21018	O-RING	1	J20001-
18	418-62-11620	O-RING	1	J20001-
19	561-61-64510	CLAMP	6	J20001-
20	561-61-64540	PLATE	3	J20001-
21	561-61-64530	SPACER	6	J20001-
22	561-61-64520	PLATE	3	J20001-
23	01010-81290	BOLT	6	J20001-
24	01643-31232	WASHER	6	J20001-




FRONT SUPPORT (R.H.) (SUPPORT)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-54-80401	FRONT SUPPORT,(R.H.)	1	J20001-
1	561-54-81321	*SUPPORT,(R.H.)	1	J20001-
2	561-54-86691	*COVER	1	J20001-
3	01010-81230	*BOLT	4	J20001-
4	01643-31232	*WASHER	4	J20001-
5	09415-03614	*CAP	2	J20001-
6	561-54-86920	*COVER	1	J20001-
7	01010-81020	*BOLT	2	J20001-
8	01643-31032	*WASHER	2	J20001-
9	561-06-86682	*BRACKET	1	J20001-
10	415-64-13130	*CUSHION	3	J20001-
11	419-43-17930	*CUSHION	3	J20001-
12	419-43-17920	*WASHER	6	J20001-
13	417-54-13470	*SPACER	3	J20001-
14	01010-81250	*BOLT	3	J20001-
15	01643-31232	*WASHER	3	J20001-
16	566-06-6A310	**LAMP ASS'Y	2	J20001-
	23S-06-54121	**LENS ASS'Y	2	J20001-
	421-06-23330	**BULB, 70W	2	J20001-
17	23B-06-42460	*LAMP ASS'Y	1	J20001-
	41G-06-13210	**LENS	1	J20001-
	41G-06-13220	**LENS	1	J20001-
	41G-06-13230	**BULB, 5W	1	J20001-
	08105-12420	**BULB, 25W	1	J20001-
18	08053-01510	*CLIP	3	J20001-
19	04434-50810	*CLIP	2	J20001-
20	01010-81020	*BOLT	3	J20001-
21	01643-31032	*WASHER	3	J20001-
22	561-06-83242	*WIRING HARNESS	1	J20001-
23	04434-51010	*CLIP	3	J20001-
24	01010-81016	*BOLT	6	J20001-
25	01643-31032	*WASHER	6	J20001-
26	08034-20519	*BAND	4	J20001-




FRONT SUPPORT (R.H)(SUPPORT) (FOG LAMP)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-85-80200	FRONT SUPPORT,(R.H.)	1	J20001-
1	561-85-81130	*SUPPORT,(R.H.)	1	J20001-
2	561-54-86691	*COVER	1	J20001-
3	01010-81230	*BOLT	4	J20001-
4	01643-31232	*WASHER	4	J20001-
5	09415-03614	*CAP	2	J20001-
6	561-54-86920	*COVER	1	J20001-
7	01010-81020	*BOLT	2	J20001-
8	01643-31032	*WASHER	2	J20001-
9	561-06-86682	*BRACKET	1	J20001-
10	415-64-13130	*CUSHION	3	J20001-
11	419-43-17930	*CUSHION	3	J20001-
12	419-43-17920	*WASHER	6	J20001-
13	417-54-13470	*SPACER	3	J20001-
14	01010-81250	*BOLT	3	J20001-
15	01643-31232	*WASHER	3	J20001-
16	566-06-6A310	*LAMP ASS'Y	2	J20001-
	23S-06-54121	**LENS ASS'Y	2	J20001-
	421-06-23330	**BULB, 70W	2	J20001-
17	23B-06-42460	*LAMP ASS'Y	1	J20001-
	41G-06-13210	**LENS	1	J20001-
	41G-06-13220	**LENS	1	J20001-
	41G-06-13230	**BULB, 5W	1	J20001-
	08105-12420	**BULB, 25W	1	J20001-
18	08053-01510	*CLIP	3	J20001-
19	04434-50810	*CLIP	2	J20001-
20	01010-81020	*BOLT	3	J20001-
21	01643-31032	*WASHER	3	J20001-
22	561-06-83242	*WIRING HARNESS	1	J20001-
23	04434-51010	*CLIP	3	J20001-
24	01010-81016	*BOLT	6	J20001-
25	01643-31032	*WASHER	6	J20001-
26	08034-20519	*BAND	4	J20001-




FRONT SUPPORT (R.H) (BOLT LINE)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	01010-82255	BOLT	5	J20001-
2	01643-32260	WASHER	5	J20001-




FRONT SUPPORT (R.H) (BRACKET)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-54-86624	COVER	1	J20001-
2	561-54-81372	STEP	1	J20001-
3	01010-81235	BOLT	4	J20001-
4	01643-31232	WASHER	4	J20001-
5	01010-81225	BOLT	2	J20001-
6	01643-31232	WASHER	2	J20001-
7	561-54-31690	STEP	1	J20001-
8	01010-81230	BOLT	4	J20001-
9	01643-31232	WASHER	4	J20001-
10	561-54-86871	STEP	1	J20001-
11	01010-81225	BOLT	4	J20001-
12	01643-31232	WASHER	4	J20001-




FRONT SUPPORT (R.H) (BRACKET) (VHMS LESS)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-54-87150	COVER	1	J20001-
2	561-54-81372	STEP	1	J20001-
3	01010-81235	BOLT	4	J20001-
4	01643-31232	WASHER	4	J20001-
5	01010-81225	BOLT	2	J20001-
6	01643-31232	WASHER	2	J20001-
7	561-54-31690	STEP	1	J20001-
8	01010-81230	BOLT	4	J20001-
9	01643-31232	WASHER	4	J20001-
10	561-54-86871	STEP	1	J20001-
11	01010-81225	BOLT	4	J20001-
12	01643-31232	WASHER	4	J20001-




FRONT SUPPORT (R.H) (STEP)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-54-86740	STEP	1	J20001-
2	01010-81030	BOLT	4	J20001-
3	01643-31032	WASHER	4	J20001-
4	561-54-86761	BRACKET	2	J20001-
5	01010-81225	BOLT	4	J20001-
6	01643-31232	WASHER	4	J20001-
7	561-54-86811	GRIP	1	J20001-
8	07283-34346	CLIP	2	J20001-
9	01597-01009	NUT	4	J20001-
10	01643-31032	WASHER	4	J20001-
11	561-54-86970	GRIP	1	J20001-
12	01010-81230	BOLT	2	J20001-
13	01643-31232	WASHER	2	J20001-




FRONT SUPPORT (CAB MOUNTING PARTS)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-54-87211	SHIM, 0.5MM	8	J20001-
	561-54-87221	SHIM, 1.0MM	8	J20001-
2	01010-81645	BOLT	8	J20001-
3	01643-31645	WASHER.....	8	J20001-
4	561-54-87231	SHIM, 0.5MM	8	J20001-
	561-54-87241	SHIM, 1.0MM	8	J20001-
5	01010-82055	BOLT	8	J20001-
6	01643-32060	WASHER.....	8	J20001-




ENGINE FUEL FILTER AND RELATED PARTS(L.H) (1/2)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-01-83200	FILTER,(L.H.)	1	J20001-
1	561-01-83222	*COVER,(L.H.)	1	J20001-
2	21W-46-38680	*BOLT	2	J20001-
3	203-54-56970	*WASHER	2	J20001-
	6217-71-7300	*HEAD ASS'Y (1-5/8)	1	J20001-
4	6217-71-7310	**HEAD (1-5/8)	1	J20001-
5	6110-73-6231	**PLUG	1	J20001-
6	07005-00812	**GASKET	1	J20001-
7	07043-70108	**PLUG	1	J20001-
8	01010-81040	*BOLT	4	J20001-
9	01643-31032	*WASHER	4	J20001-
10	600-311-3520	*CARTRIDGE (1-5/8)	1	J20001-
11	6156-71-5380	*JOINT	2	J20001-
12	07206-31014	*BOLT	2	J20001-
13	07005-01412	*GASKET	4	J20001-
14	6261-71-6430	*HEAD	1	J20001-
15	01010-81040	*BOLT	4	J20001-
16	01643-31032	*WASHER	4	J20001-
17	600-311-3410	**CARTRIDGE (1-1/4)	1	J20001-
17A	600-311-3220	**CAP	1	J20001-
17B	600-311-3230	**SEAL	1	J20001-
18	569-43-83610	*ELBOW	1	J20001-
19	07002-12034	*O-RING	1	J20001-
20	02782-10516	*ELBOW	1	J20001-
21	07002-12034	*O-RING	1	J20001-



HD785-7 S/N J20001 and up
ENGINE FUEL FILTER AND RELATED PARTS (L.H.)(ADDITIONAL
FILTER)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-84-81510	FILTER ASS'Y	1	J20001-
1	561-84-81520	*COVER	1	J20001-
2	21W-46-38680	*BOLT	2	J20001-
3	203-54-56970	*WASHER	2	J20001-
	6217-71-7300	*HEAD ASS'Y (1-5/8)	1	J20001-
4	6217-71-7310	*HEAD (1-5/8)	1	J20001-
5	6110-73-6231	*PLUG	1	J20001-
6	07005-00812	*GASKET	1	J20001-
7	07043-70108	*PLUG	1	J20001-
8	01010-81040	*BOLT	4	J20001-
9	01643-31032	*WASHER	4	J20001-
10	600-311-3520	*CARTRIDGE (1-5/8)	1	J20001-
11	6156-71-5380	*JOINT	2	J20001-
12	07206-31014	*BOLT	2	J20001-
13	07005-01412	*GASKET	4	J20001-
14	6261-71-6430	*HEAD	1	J20001-
15	01010-81040	*BOLT	4	J20001-
16	01643-31032	*WASHER	4	J20001-
17	600-311-3410	**CARTRIDGE	1	J20001-
17A	600-311-3220	**CAP	1	J20001-
17B	600-311-3230	**SEAL	1	J20001-
18	569-43-83610	*ELBOW	1	J20001-
19	07002-12034	*O-RING	1	J20001-
20	02782-10516	*ELBOW	1	J20001-
21	07002-12034	*O-RING	1	J20001-
22	561-54-86782	*GRIP	1	J20001-
23	01010-81025	*BOLT	1	J20001-
24	01643-31032	*WASHER	1	J20001-
25	01010-81030	*BOLT	1	J20001-
26	01643-31032	*WASHER	1	J20001-
27	01010-81225	*BOLT	4	J20001-
28	01643-31232	*WASHER	4	J20001-



ENGINE FUEL FILTER AND RELATED PARTS (L.H.) (2/2)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-01-83270	PUMP ASS'Y	1	J20001-
	6261-71-8100	*BLOCK ASS'Y	1	J20001-
1	6261-71-8110	***BLOCK	1	J20001-
2	6217-71-6850	***PLUG	1	J20001-
3	6217-71-6820	***VALVE	1	J20001-
4	6217-71-6830	***SPRING	1	J20001-
5	6217-71-6840	***WASHER	1	J20001-
6	6217-71-6870	***PIN	1	J20001-
7	07000-12014	***O-RING	2	J20001-
8	6261-71-8240	**PRIMING PUMP ASS'Y	1	J20001-
9	01010-81025	**BOLT	4	J20001-
10	01643-31032	**WASHER	4	J20001-
11	07040-11409	**PLUG	2	J20001-
12	07005-01412	**GASKET	2	J20001-
13	01010-81035	*BOLT	4	J20001-
14	01643-31032	*WASHER	4	J20001-
15	02782-10516	*ELBOW	1	J20001-
16	07002-12034	*O-RING	1	J20001-
17	02782-10518	*ELBOW	1	J20001-
18	07002-12034	*O-RING	1	J20001-
19	02762-00509	*HOSE	1	J20001-
20	02896-11015	*O-RING	2	J20001-
21	04434-53211	*CLIP	2	J20001-
22	07095-20523	*CUSHION	2	J20001-
23	01010-81025	*BOLT	2	J20001-
24	01643-31032	*WASHER	2	J20001-
25	561-54-86782	*GRIP	1	J20001-
26	01010-81025	*BOLT	2	J20001-
27	01643-31032	*WASHER	2	J20001-
28	01010-81225	BOLT	4	J20001-
29	01643-31232	ASHER	4	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

ENGINE FUEL FILTER AND RELATED PARTS (R.H.) (1/2)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-01-83290	FILTER ASS'Y,(R.H.)	1	J20001-
1	561-01-83214	*COVER,(R.H.)	1	J20001-
2	21W-46-38680	*BOLT	2	J20001-
3	203-54-56970	*WASHER	2	J20001-
	6217-71-7300	*HEAD ASS'Y (1-5/8)	1	J20001-
4	6217-71-7310	**HEAD (1-5/8)	1	J20001-
5	6110-73-6231	**PLUG	1	J20001-
6	07005-00812	**GASKET	1	J20001-
7	07043-70108	**PLUG	1	J20001-
8	01010-81040	*BOLT	4	J20001-
9	01643-31032	*WASHER	4	J20001-
10	600-311-3520	*CARTRIDGE (1-5/8)	1	J20001-
11	6156-71-5380	*JOINT	2	J20001-
12	07206-31014	*BOLT	2	J20001-
13	07005-01412	*GASKET	4	J20001-
14	6261-71-6430	*HEAD	1	J20001-
15	01010-81040	*BOLT	4	J20001-
16	01643-31032	*WASHER	4	J20001-
17	600-311-3410	**CARTRIDGE (1-1/4)	1	J20001-
17A	600-311-3220	**CAP	1	J20001-
17B	600-311-3230	**SEAL	1	J20001-
18	02782-10516	*ELBOW	1	J20001-
19	07002-12034	*O-RING	1	J20001-
20	02782-10516	*ELBOW	1	J20001-
21	07002-12034	*O-RING	1	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up
ENGINE FUEL FILTER AND RELATED PARTS (R.H) (ADDITIONAL
FILTER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-84-81610	FILTER ASS'Y	1	J20001-
1	561-84-81620	*COVER	1	J20001-
2	21W-46-38680	*BOLT	2	J20001-
3	203-54-56970	*WASHER	2	J20001-
	6217-71-7300	*HEAD ASS'Y (1-5/8)	1	J20001-
4	6217-71-7310	**HEAD (1-5/8)	1	J20001-
5	6110-73-6231	**PLUG	1	J20001-
6	07005-00812	**GASKET	1	J20001-
7	07043-70108	**PLUG	1	J20001-
8	01010-81040	*BOLT	4	J20001-
9	01643-31032	*WASHER	4	J20001-
10	600-311-3520	*CARTRIDGE (1-5/8)	1	J20001-
11	6156-71-5380	*JOINT	2	J20001-
12	07206-31014	*BOLT	2	J20001-
13	07005-01412	*GASKET	4	J20001-
14	6261-71-6430	*HEAD	1	J20001-
15	01010-81040	*BOLT	4	J20001-
16	01643-31032	*WASHER	4	J20001-
17	600-311-3410	**CARTRIDGE (1-1/4)	1	J20001-
17A	600-311-3220	**CAP	1	J20001-
17B	600-311-3230	**SEAL	1	J20001-
18	569-43-83610	*ELBOW	1	J20001-
19	07002-12034	*O-RING	1	J20001-
20	02782-10520	*ELBOW	1	J20001-
21	07002-12034	*O-RING	1	J20001-
22	561-54-86791	*GRIP	1	J20001-
23	01010-81025	*BOLT	1	J20001-
24	01643-31032	*WASHER	1	J20001-
25	01010-81020	*BOLT	1	J20001-
26	01643-31032	*WASHER	1	J20001-
27	01010-81225	*BOLT	4	J20001-
28	01643-31232	*WASHER	4	J20001-




FRONT SUPPORT (R.H) (BRACKET) (VHMS LESS)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-01-83290	FILTER ASS'Y,(R.H.)	1	J20001-
	561-01-83270	*PUMP ASS'Y	1	J20001-
	6261-71-8100	**BLOCK ASS'Y	1	J20001-
1	6261-71-8110	***BLOCK	1	J20001-
2	6217-71-6850	***PLUG	1	J20001-
3	6217-71-6820	***VALVE	1	J20001-
4	6217-71-6830	***SPRING	1	J20001-
5	6217-71-6840	***WASHER	1	J20001-
6	6217-71-6870	***PIN	1	J20001-
7	07000-12014	**O-RING	2	J20001-
8	6261-71-8240	**PRIMING PUMP ASS'Y	1	J20001-
9	01010-81025	**BOLT	4	J20001-
10	01643-31032	**WASHER	4	J20001-
11	07040-11409	**PLUG	2	J20001-
12	07005-01412	**GASKET	2	J20001-
13	01010-81035	*BOLT	4	J20001-
14	01643-31032	*WASHER	4	J20001-
15	02782-10518	*ELBOW	1	J20001-
16	07002-12034	*O-RING	1	J20001-
17	02782-10518	*ELBOW	1	J20001-
18	07002-12034	*O-RING	1	J20001-
19	02762-00508	*HOSE	1	J20001-
20	02896-11015	*O-RING	2	J20001-
21	04434-53211	*CLIP	2	J20001-
22	07095-20523	*CUSHION	2	J20001-
23	01010-81025	*BOLT	2	J20001-
24	01643-31032	*WASHER	2	J20001-
25	561-54-86791	*GRIP	1	J20001-
26	01010-81025	*BOLT	2	J20001-
27	01643-31032	*WASHER	2	J20001-
28	01010-81225	*BOLT	4	J20001-
29	01643-31232	*WASHER	4	J20001-




POSITIONER

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	7861-93-8710	SENSOR	1	J20001-
2	561-43-82310	LEVER	1	J20001-
3	04010-00310	KEY	1	J20001-
4	01010-81040	BOLT	3	J20001-
5	01643-31032	WASHER	3	J20001-
6	04245-41043	ROD	1	J20001-
7	01582-11008	NUT	2	J20001-
8	04250-81056	END	2	J20001-
9	566-40-11560	SPACER	4	J20001-
10	01010-81035	BOLT	2	J20001-
11	561-43-82320	BRACKET	1	J20001-
12	08193-21012	CLIP	1	J20001-
13	01010-81016	BOLT	1	J20001-
14	01643-31032	WASHER	1	J20001-
15	01643-50823	WASHER	1	J20001-
16	01010-80830	BOLT	1	J20001-



AIR INTAKE


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-02-82112	BOX	1	J20001-
2	08672-01000	INDICATOR	1	J20001-
3	01010-81225	BOLT	4	J20001-
4	01643-31232	WASHER	4	J20001-
5	561-02-82151	ELBOW	2	J20001-
6	07289-00160	CLAMP	2	J20001-
7	600-815-8860	INDICATOR	1	J20001-
8	08193-21012	CLIP	1	J20001-
9	01010-81016	BOLT	1	J20001-
10	01643-31032	WASHER	1	J20001-
11	561-02-12150	ELBOW	3	J20001-
12	07289-00170	CLAMP	3	J20001-
13	6560-61-7300	SENSOR ASS'Y	1	J20001-
	6735-21-1930	O-RING	1	J20001-
14	07289-00170	CLAMP	3	J20001-
15	07289-00160	CLAMP	2	J20001-



EXHAUST PIPING

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-02-81210	TUBE	1	J20001-
2	561-02-81221	BRACKET	1	J20001-
3	561-02-81350	BAND	1	J20001-
4	01580-11008	NUT	4	J20001-
5	01643-31032	WASHER	2	J20001-
6	6502-12-1722	V-BAND ASS'Y	1	J20001-
7	561-02-61240	V-CLAMP	2	J20001-
8	01010-81235	BOLT	2	J20001-
9	01643-31232	WASHER	2	J20001-
10	01010-81240	BOLT	2	J20001-
11	01643-31232	WASHER	2	J20001-
12	561-02-81230	TUBE	1	J20001-
13	561-02-81241	BRACKET	1	J20001-
14	561-02-81350	BAND	1	J20001-
15	01580-11008	NUT	4	J20001-
16	01643-31032	WASHER	2	J20001-
17	01010-81230	BOLT	2	J20001-
18	01643-31232	WASHER	2	J20001-
19	6151-11-5361	CLAMP	2	J20001-
20	561-02-81111	TUBE	1	J20001-
21	561-02-81121	TUBE	1	J20001-
22	561-02-81340	BAND	2	J20001-
23	01580-11008	NUT	8	J20001-
24	01643-31032	WASHER	4	J20001-
25	07042-20108	PLUG	2	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

EXHAUST PIPING (FOR EXHAUST BOX)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-84-84131	TUBE	1	J20001-
2	561-84-84121	TUBE	1	J20001-
3	07042-20108	PLUG	2	J20001-
4	6151-11-5361	CLAMP	2	J20001-
5	566-02-11930	BAND	2	J20001-
6	01643-31032	WASHER	4	J20001-
7	01580-11008	NUT	8	J20001-
8	561-02-61240	V-CLAMP	2	J20001-
9	561-84-84351	TUBE	1	J20001-
10	561-84-84611	BAND	1	J20001-
11	01643-31232	WASHER	2	J20001-
12	01580-11210	NUT	4	J20001-
13	6502-12-1722	V-BAND ASS'Y	2	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

EXHAUST PIPING (FOR MUFFLER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-84-84131	TUBE	1	J20001-
2	561-84-84121	TUBE	1	J20001-
3	07042-20108	PLUG	2	J20001-
4	6151-11-5361	CLAMP	2	J20001-
5	566-02-11930	BAND	2	J20001-
6	01643-31032	WASHER	4	J20001-
7	01580-11008	NUT	8	J20001-
8	561-02-61240	V-CLAMP	2	J20001-
9	561-84-84341	TUBE	1	J20001-
10	561-84-84361	BRACKET	1	J20001-
11	01010-81230	BOLT	4	J20001-
12	01643-31232	WASHER	4	J20001-
13	561-84-84611	BAND	2	J20001-
14	01643-31232	WASHER	4	J20001-
15	01580-11210	NUT	4	J20001-
16	6502-12-1722	V-BAND ASS'Y	1	J20001-
17	01580-11210	NUT	4	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

EXHAUST BOX

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-84-84100	EXHAUST BOX ASS'Y	1	J20001-
1	561-84-84111	*BOX	1	J20001-
2	561-84-64260	*SHUTTER	1	J20001-
3	561-84-81180	*LEVER	1	J20001-
4	561-84-81190	*LEVER	1	J20001-
5	01010-80630	*BOLT	2	J20001-
6	01643-30623	*WASHER	2	J20001-
7	56B-02-11930	*BUSHING	2	J20001-
8	561-84-81170	*PIN	1	J20001-
9	569-02-11170	*RING	1	J20001-
10	566-02-11740	*SPRING	1	J20001-
11	01011-81470	*BOLT	2	J20001-
12	01580-11411	*NUT	4	J20001-
13	561-84-84210	*FLANGE	1	J20001-
14	566-02-11450	*SPRING	2	J20001-
15	01011-81420	*BOLT	2	J20001-
16	01643-31445	*WASHER	2	J20001-
17	01580-11411	*NUT	2	J20001-
18	01011-81445	*BOLT	1	J20001-
19	01580-11411	*NUT	2	J20001-
20	566-02-11460	*LEVER	2	J20001-
21	04050-24022	*PIN	2	J20001-
22	01640-21426	*WASHER	2	J20001-
23	566-02-11721	*LEVER	2	J20001-
24	04010-00519	*KEY	2	J20001-
25	01010-80830	*BOLT	2	J20001-
26	01602-20825	*WASHER	2	J20001-
27	566-02-11972	*COVER	1	J20001-
28	566-02-11981	*PACKING	1	J20001-
29	01010-81225	*BOLT	4	J20001-
30	01643-31232	*WASHER	4	J20001-
31	561-84-64290	*FLANGE	1	J20001-
32	582-02-11351	*PACKING	1	J20001-
33	01010-81235	*BOLT	4	J20001-
34	01643-31232	*WASHER	4	J20001-
35	01010-81230	*BOLT	6	J20001-
36	01643-31232	*WASHER	6	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up

ENGINE CONTROL (ENGINE HARNESS)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-06-83321	WIRING HARNESS	1	J20001-
2	08038-00519	CAP	3	J20001-
3	08038-04030	CAP	1	J20001-
4	04434-51510	CLIP	9	J20001-
5	01010-81025	BOLT	1	J20001-
6	01643-31032	WASHER	1	J20001-
7	195-979-3570	COLLAR	2	J20001-
8	01010-81090	BOLT	2	J20001-
9	01643-31032	WASHER	2	J20001-
10	01010-81016	BOLT	9	J20001-
11	01643-31032	WASHER	9	J20001-
12	6131-22-3750	BOSS	2	J20001-
13	6206-11-4490	SPACER	1	J20001-
14	04434-50810	CLIP	3	J20001-
15	01010-81060	BOLT	1	J20001-
16	01643-31032	WASHER	1	J20001-
17	01010-81020	BOLT	2	J20001-
18	01643-31032	WASHER	2	J20001-
19	04434-52110	CLIP	1	J20001-
20	04434-50810	CLIP	3	J20001-
21	04434-50812	CLIP	1	J20001-
22	01010-81240	BOLT	1	J20001-
23	01643-31232	WASHER	1	J20001-
24	01010-81040	BOLT	1	J20001-
25	01643-31032	WASHER	1	J20001-
26	04434-51912	CLIP	1	J20001-
27	01010-81225	BOLT	1	J20001-
28	01643-31232	WASHER	1	J20001-
29	08193-21012	CLIP	1	J20001-
30	08034-20834	BAND	6	J20001-



ENGINE CONTROL (HEATER RELAY HARNESS)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-06-83331	WIRING HARNESS	1	J20001-
1A	08038-02027	CAP	2	J20001-
2	04434-51810	CLIP	6	J20001-
3	04434-51010	CLIP	6	J20001-
4	01010-81016	BOLT	7	J20001-
5	01643-31032	WASHER	7	J20001-
6	04434-51710	CLIP	2	J20001-
7	07095-20211	CUSHION	2	J20001-
8	04434-52511	CLIP	1	J20001-
9	07095-20318	CUSHION	1	J20001-

HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up
ENGINE CONTROL (HEATER RELAY HARNESS) (ADDITIONAL
FILTER)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-06-85690	WIRING HARNESS	1	J20001-
2	08038-02027	CAP	2	J20001-
3	04434-51810	CLIP	6	J20001-
4	04434-51010	CLIP	3	J20001-
5	01010-81016	BOLT	10	J20001-
6	01643-31032	WASHER	10	J20001-
7	04434-51710	CLIP	3	J20001-
8	07095-20211	CUSHION	3	J20001-
9	04434-52511	CLIP	1	J20001-
10	07095-20318	CUSHION	1	J20001-
11	08034-20834	BAND	4	J20001-
12	04434-52711	CLIP	1	J20001-
13	07095-20418	CUSHION	1	J20001-
14	04434-51410	CLIP	5	J20001-
15	04434-50812	CLIP	1	J20001-
16	04434-50810	CLIP	5	J20001-
17	04434-50610	CLIP	1	J20001-
18	6131-22-3750	BOSS	2	J20001-
19	01010-81040	BOLT	2	J20001-
20	01643-31032	WASHER	2	J20001-
21	195-979-3570	COLLAR	1	J20001-
22	01010-81090	BOLT	1	J20001-
23	01643-31032	WASHER	1	J20001-
24	195-979-5190	COLLAR	1	J20001-
25	01010-81070	BOLT	1	J20001-
26	01643-31032	WASHER	1	J20001-
27	6206-11-4490	SPACER	1	J20001-
28	01010-81060	BOLT	1	J20001-
29	01643-31032	WASHER	1	J20001-
30	569-54-41380	PLATE	1	J20001-
31	07283-36155	CLIP	1	J20001-
32	01643-31032	WASHER	2	J20001-
33	01597-01009	NUT	2	J20001-
34	01010-81025	BOLT	1	J20001-
35	01643-31032	WASHER	1	J20001-
36	01010-81220	BOLT	1	J20001-
37	01643-31232	WASHER	1	J20001-
38	144-854-1890	WASHER	1	J20001-
39	01010-81030	BOLT	1	J20001-



ENGINE EARTH

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	08028-45025	CABLE	1	J20001-
2	01010-81016	BOLT	2	J20001-
3	01643-31032	WASHER	2	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

ENGINE EARTH (ADDITIONAL FILTER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	08028-45025	CABLE	1	J20001-
2	01010-81016	BOLT	2	J20001-
3	01643-31032	WASHER	2	J20001-
4	569-06-88460	BRACKET	1	J20001-
5	01010-81020	BOLT	2	J20001-
6	01643-31032	WASHER	2	J20001-
7	600-815-9490	SWITCH	1	J20001-
8	01010-80616	BOLT	4	J20001-
9	01643-30623	WASHER	4	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

TRANSMISSION CONTROL

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-44-85411	WIRING HARNESS	1	J20001-
2	561-44-85310	BRACKET	1	J20001-
3	01010-81020	BOLT	2	J20001-
4	01643-31032	WASHER	2	J20001-
5	04434-52110	CLIP	8	J20001-
6	04434-52711	CLIP	2	J20001-
7	01010-81020	BOLT	3	J20001-
8	01643-31032	WASHER	3	J20001-
9	01010-81220	BOLT	1	J20001-
10	01643-31232	WASHER	1	J20001-
11	04434-53212	CLIP	1	J20001-
11A	07095-20522	CUSHION	1	J20001-
12	07095-20420	CUSHION	2	J20001-
13	6152-51-5520	SPACER	1	J20001-
14	01010-81070	BOLT	1	J20001-
15	01643-31032	WASHER	1	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up


STEERING LINK (LEVER AND ROD)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-40-81210	LEVER	1	J20001-
2	561-40-61330	BUSHING	4	J20001-
3	561-40-41130	BUSHING	2	J20001-
4	07145-00060	SEAL	2	J20001-
	561-40-81430	ROD ASS'Y	2	J20001-
5	561-40-81410	*ROD	2	J20001-
6	07137-05008	*BUSHING	4	J20001-
7	07000-02050	*O-RING	8	J20001-
8	04071-00110	*RING	8	J20001-
9	561-40-61631	BOOT	4	J20001-
10	561-40-61531	PIN	2	J20001-
11	01010-81425	BOLT	2	J20001-
12	569-40-61710	WASHER.....	2	J20001-



STEERING LINK (RELATED PARTS)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-40-81540	PIN	2	J20001-
2	561-52-61150	SPACER	4	J20001-
3	01010-81425	BOLT	2	J20001-
4	569-40-61710	WASHER	2	J20001-
5	561-40-61160	BUSHING	8	J20001-
6	561-40-61550	PIN	2	J20001-
7	561-40-61560	PIN	2	J20001-
8	566-52-41950	SPACER	8	J20001-
9	01010-81425	BOLT	4	J20001-
10	569-40-61710	WASHER	4	J20001-
11	561-40-61330	BUSHING	4	J20001-
12	561-40-61570	PIN	2	J20001-
13	561-40-61631	BOOT	4	J20001-
14	01010-81425	BOLT	2	J20001-
15	569-40-61710	WASHER	2	J20001-
16	561-40-41120	BUSHING	2	J20001-
17	561-40-61522	PIN	1	J20001-
18	01010-81425	BOLT	1	J20001-
19	569-40-61710	WASHER	1	J20001-
20	561-40-41140	PLATE	1	J20001-
21	04064-05520	RING	1	J20001-



STEERING LINK (LUBRICATION PIPING)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	19M-60-15330	ELBOW	2	J20001-
2	234-60-22672	ELBOW	2	J20001-
3	43A-18-11360	BRACKET	1	J20001-
4	562-95-13150	NIPPLE	2	J20001-
5	01010-81020	BOLT	1	J20001-
6	01643-31032	WASHER	1	J20001-
7	01010-81025	BOLT	1	J20001-
8	01643-31032	WASHER	1	J20001-
9	01580-11008	NUT	1	J20001-
10	07109-202A7	HOSE	1	J20001-
11	07109-202A7	HOSE	1	J20001-
12	04434-51810	CLIP	2	J20001-
13	562-95-13150	NIPPLE	4	J20001-
14	07020-00000	FITTING	4	J20001-
15	07020-00675	FITTING	2	J20001-
16	421-09-12540	ELBOW	5	J20001-
17	423-09-12110	CONNECTOR	5	J20001-
18	569-52-62130	CLIP	2	J20001-
19	561-52-62590	CLIP	2	J20001-
20	561-52-82231	JOINT	1	J20001-
21	561-52-82452	TUBE	1	J20001-
22	561-52-82462	TUBE	1	J20001-
23	561-52-82472	TUBE	1	J20001-
24	561-52-82481	TUBE	1	J20001-
25	561-52-82491	TUBE	1	J20001-
26	01010-81020	BOLT	2	J20001-
27	01643-31032	WASHER	2	J20001-
28	01010-81240	BOLT	2	J20001-
29	01643-31232	WASHER	2	J20001-
30	01580-11008	NUT	1	J20001-
31	07020-00000	FITTING	5	J20001-
32	562-95-13150	NIPPLE	2	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up


STEERING LINK (LUBRICATION PIPING) (ASR)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	19M-60-15330	ELBOW	2	J20001-
2	234-60-22672	ELBOW	2	J20001-
3	425-46-14130	PLATE	1	J20001-
4	562-95-13150	NIPPLE	2	J20001-
5	01010-81020	BOLT	1	J20001-
6	01643-31032	WASHER	1	J20001-
7	01010-81025	BOLT	1	J20001-
8	01643-31032	WASHER	1	J20001-
9	07109-20208	HOSE	2	J20001-
10	04434-51810	CLIP	2	J20001-
11	562-95-13150	NIPPLE	4	J20001-
12	07020-00000	FITTING	4	J20001-
13	07020-00675	FITTING	2	J20001-
14	561-52-82231	JOINT	1	J20001-
15	01010-81240	BOLT	2	J20001-
16	01643-31232	WASHER	2	J20001-
17	07020-00000	FITTING	5	J20001-
18	423-09-12110	CONNECTOR	5	J20001-
19	561-88-82451	TUBE	1	J20001-
20	561-88-82461	TUBE	1	J20001-
21	561-88-82471	TUBE	1	J20001-
22	561-88-82481	TUBE	1	J20001-
23	561-88-82491	TUBE	1	J20001-
24	569-52-62130	CLIP	2	J20001-
25	561-52-62590	CLIP	3	J20001-
26	01010-81020	BOLT	2	J20001-
27	01643-31032	WASHER	2	J20001-
28	01010-81025	BOLT	2	J20001-
29	01643-31032	WASHER	2	J20001-
30	01580-11008	NUT	1	J20001-
31	421-09-12540	ELBOW	5	J20001-
32	562-95-13150	NIPPLE	3	J20001-




EMERGENCY STEERING CONTROL (MOTOR)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-40-80100	EMERG. STEERING G.	1	J20001-
1	561-40-85130	*BRACKET	1	J20001-
2	421-62-32700	*MOTOR ASS'Y	1	J20001-
3	01010-81030	*BOLT	4	J20001-
4	01643-31032	*WASHER	4	J20001-
5	705-40-01041	*PUMP	1	J20001-
6	01010-81025	*BOLT	2	J20001-
7	01643-31032	*WASHER	2	J20001-
8	561-40-85110	*TUBE	1	J20001-
9	07000-F3032	*O-RING	1	J20001-
10	01010-81065	*BOLT	4	J20001-
11	01643-31032	*WASHER	4	J20001-
12	561-40-85141	*FLANGE	1	J20001-
13	07000-F3025	*O-RING	1	J20001-
14	01010-80835	*BOLT	4	J20001-
15	01643-50823	*WASHER	4	J20001-
16	02782-10420	*ELBOW	1	J20001-
17	07002-21823	*O-RING	1	J20001-
18	02896-21012	*O-RING	1	J20001-
19	02765-00405	*HOSE	1	J20001-
20	23S-61-34360	*PLATE	1	J20001-
21	01010-81225	*BOLT	1	J20001-
22	01643-31232	*WASHER	1	J20001-
23	04434-52711	*CLIP	1	J20001-
24	07095-20420	*CUSHION	1	J20001-
25	01010-81020	*BOLT	1	J20001-
26	01643-31032	*WASHER	1	J20001-
27	07260-03218	*HOSE	1	J20001-
28	07289-00045	*CLAMP	2	J20001-
29	561-06-81542	*BATTERY CABLE	1	J20001-
30	08038-00035	*CAP	1	J20001-
31	08028-45060	*CABLE	1	J20001-
32	04434-52511	*CLIP	1	J20001-
33	566-06-41290	*INSULATOR	1	J20001-
34	01010-81016	*BOLT	2	J20001-
35	01643-31032	*WASHER	2	J20001-
36	08038-00035	*CAP	1	J20001-



EMERGENCY STEERING CONTROL (RELATED PARTS)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	01010-81230	BOLT	4	J20001-
2	01643-31232	WASHER	4	J20001-
3	07289-00045	CLAMP	2	J20001-
4	04434-52711	CLIP	14	J20001-
5	01010-81020	BOLT	3	J20001-
6	01643-31032	WASHER	3	J20001-
7	01010-81016	BOLT	3	J20001-
8	01643-31032	WASHER	3	J20001-
9	08038-00035	CAP	1	J20001-




LUBRICATION PIPING

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	421-09-12540	ELBOW	6	J20001-
2	423-09-12110	CONNECTOR	6	J20001-
3	561-52-82570	TUBE	1	J20001-
4	561-52-82811	TUBE	1	J20001-
5	561-52-82581	TUBE	1	J20001-
6	561-52-82631	TUBE	1	J20001-
7	561-52-82641	TUBE	1	J20001-
8	561-52-82831	TUBE	1	J20001-
9	01010-80816	BOLT	6	J20001-
10	01643-30823	WASHER	6	J20001-
11	04434-50608	CLIP	6	J20001-
12	07020-00000	FITTING	6	J20001-
13	421-09-12540	ELBOW	2	J20001-
14	423-09-12110	CONNECTOR	2	J20001-
15	561-52-82610	TUBE	2	J20001-
16	01010-80816	BOLT	2	J20001-
17	01643-30823	WASHER	2	J20001-
18	04434-50608	CLIP	2	J20001-
19	07042-20108	PLUG	4	J20001-
20	07020-00000	FITTING	2	J20001-
21	07020-00000	FITTING	4	J20001-

OPERATOR'S COMPARTMENT AND CONTROL SYSTEM


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up


OPERATOR'S CAB (CAB)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-54-83111	CAB BODY ASS'Y	1	J20001-




OPERATOR'S CAB (L.H. DOOR) (1/3)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-54-84200	DOOR ASS'Y,L.H.	1	J20001-
1	561-54-84114	*DOOR	1	J20001-
2	561-54-84132	*SEAL,DOOR	1	J20001-
3	56B-54-14350	*REGULATOR	1	J20001-
4	01641-20608	*WASHER	2	J20001-
5	01584-00605	*NUT	2	J20001-
6	01023-60612	*SCREW	4	J20001-
7	56B-54-14370	*HOLDER	1	J20001-
8	569-54-84640	*SHEET	1	J20001-
9	01023-60612	*SCREW	2	J20001-
10	561-54-84140	*BAR	1	J20001-
11	01224-40408	*SCREW	1	J20001-
12	01023-60616	*SCREW	1	J20001-
13	56B-54-14320	*SEAL	1	J20001-
14	569-54-84310	*GLASS	1	J20001-
15	56B-54-14330	*SEAL	1	J20001-
16	56B-54-14340	*SEAL	1	J20001-
17	561-54-84281	*GLASS	1	J20001-
18	561-54-84291	*WEATHER STRIP	1	J20001-
19	561-54-84452	*WIRING HARNESS	1	J20001-
20	08037-01008	*GROMMET	3	J20001-
21	08056-00211	*BODY	1	J20001-
22	08056-00230	*HOLDER	1	J20001-
23	08059-00310	*CLIP	4	J20001-




OPERATOR'S CAB (L.H. DOOR) (2/3)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(561-54-84200)	DOOR ASS'Y,L.H.	1	J20001-
1	56B-54-14260	*HANDLE	1	J20001-
2	01023-60612	*SCREW	2	J20001-
3	427-56-11790	*LOCK ASS'Y	1	J20001-
4	561-54-84410	*BRACKET	1	J20001-
5	01023-60616	*SCREW	2	J20001-
6	561-54-84251	*ROD	1	J20001-
7	419-54-16880	*KNOB	1	J20001-
8	421-56-11611	*HOOK	1	J20001-
9	421-56-11550	*HANDLE	1	J20001-
10	01245-00616	*SCREW	2	J20001-
11	421-56-11560	*COVER	1	J20001-
12	421-56-11860	*SCREW	1	J20001-
13	56E-54-24190	*BRACKET	1	J20001-
14	01023-60616	*SCREW	2	J20001-
15	423-56-21230	*ROD	1	J20001-
16	421-56-11611	*HOOK	1	J20001-
17	56E-54-24291	*ROD	1	J20001-
18	421-56-11611	*HOOK	2	J20001-
19	561-54-84151	*LOCK	1	J20001-
20	01224-70616	*SCREW	3	J20001-
21	205-54-71830	*SNAP	1	J20001-
22	22B-54-16340	*SNAP	2	J20001-
23	421-56-11611	*HOOK	1	J20001-
24	561-54-84430	*LINK ASS'Y	1	J20001-
25	01023-60616	*SCREW	2	J20001-
26	561-54-84170	*ROD	1	J20001-
27	421-56-11611	*HOOK	2	J20001-
28	561-54-84160	*LEVER	1	J20001-
29	01023-60616	*SCREW	2	J20001-
30	561-54-84181	*ROD	1	J20001-
31	421-56-11611	*HOOK	2	J20001-




OPERATOR'S CAB (L.H. DOOR) (3/3)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(561-54-84200)	DOOR ASS'Y,L.H.	1	J20001-
1	561-54-84220	PLATE	1	J20001-
2	01023-60410	SCREW	4	J20001-
3	561-54-84230	SHEET	1	J20001-
4	569-54-84690	SHEET	1	J20001-
5	561-54-84240	COVER	1	J20001-
6	01023-60410	SCREW	4	J20001-
7	561-54-84123	COVER	1	J20001-
8	56E-54-24470	POCKET	1	J20001-
9	01370-00416	SCREW	7	J20001-
10	01640-20408	WASHER	7	J20001-
11	566-54-24811	GRILLE	1	J20001-
12	566-54-24821	SHUTTER ASS'Y	1	J20001-
13	01370-00616	SCREW	2	J20001-
14	561-54-84650	RUBBER	1	J20001-
15	361-54-21150	HANDLE	1	J20001-
16	01245-00816	SCREW	2	J20001-
17	08037-01008	GROMMET	1	J20001-
18	01225-70616	SCREW	10	J20001-
19	418-926-3490	WASHER	10	J20001-
20	56B-54-13340	STOPPER	1	J20001-
21	01640-20816	WASHER	1	J20001-
22	561-54-84271	COVER	1	J20001-
23	561-54-84770	SHEET	1	J20001-
24	01023-60616	SCREW	3	J20001-




OPERATOR'S CAB (R.H. DOOR) (1/3) (SASH WINDOW)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	56E-54-24505	DOOR ASS'Y	1	J20001-
1	561-54-84514	*DOOR ASS'Y	1	J20001-
2	561-54-84532	*SEAL	1	J20001-
	56E-54-24812	*SASH ASS'Y	1	J20001-
3	21X-54-34170	**STOPPER	2	J20001-
4	22B-54-17390	**STOPPER	2	J20001-
5	22M-54-16540	**LOCK ASS'Y	1	J20001-
6	56E-54-24822	**FRAME	1	J20001-
7	56E-54-24333	**GLASS	1	J20001-
8	56E-54-24343	**GLASS	1	J20001-
9	56E-54-24373	**SEAL	1	J20001-
10	56E-54-24882	**CHANNEL	1	J20001-
11	56E-54-24892	**CHANNEL	1	J20001-
12	56E-54-24411	*SEAL	1	J20001-
13	56E-54-24421	*RAIL	1	J20001-
14	01224-40408	*SCREW	2	J20001-
15	09415-01008	*CAP	1	J20001-



OPERATOR'S CAB (R.H. DOOR) (2/3)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	56E-54-24505	DOOR ASS'Y	1	J20001-
1	56B-54-14270	*HANDLE	1	J20001-
2	01023-60612	*SCREW	2	J20001-
3	427-56-11790	*LOCK ASS'Y	1	J20001-
4	561-54-84420	*BRACKET	1	J20001-
5	01023-60616	*SCREW	2	J20001-
6	561-54-84251	*ROD	1	J20001-
7	419-54-16880	*KNOB	1	J20001-
8	421-56-11611	*HOOK	1	J20001-
9	421-56-11730	*HANDLE	1	J20001-
10	01245-00616	*SCREW	2	J20001-
11	421-56-11740	*COVER	1	J20001-
12	421-56-11860	*SCREW	1	J20001-
13	56E-54-24190	*BRACKET	1	J20001-
14	01023-60616	*SCREW	2	J20001-
15	423-56-21240	*ROD	1	J20001-
16	421-56-11611	*HOOK	1	J20001-
17	56E-54-24291	*ROD	1	J20001-
18	421-56-11611	*HOOK	2	J20001-
19	561-54-84551	*LOCK	1	J20001-
20	01224-70616	*SCREW	3	J20001-
21	205-54-71830	*SNAP	1	J20001-
22	22B-54-16340	*SNAP	2	J20001-
23	421-56-11611	*HOOK	1	J20001-
24	561-54-84440	*LINK ASS'Y	1	J20001-
25	01023-60616	*SCREW	2	J20001-
26	561-54-84170	*ROD	1	J20001-
27	421-56-11611	*HOOK	2	J20001-
28	561-54-84160	*LEVER	1	J20001-
29	01023-60616	*SCREW	2	J20001-
30	561-54-84181	*ROD	1	J20001-
31	421-56-11611	*HOOK	2	J20001-



OPERATOR'S CAB (R.H. DOOR) (3/3)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	56E-54-24505	DOOR ASS'Y	1	J20001-
1	561-54-84230	*SHEET	1	J20001-
2	561-54-84620	*PLATE	1	J20001-
3	01023-60410	*SCREW	4	J20001-
4	561-54-84630	*SHEET	1	J20001-
5	569-54-84690	*SHEET	1	J20001-
6	561-54-84523	*COVER	1	J20001-
7	361-54-21150	*HANDLE	1	J20001-
8	01245-00816	*SCREW	2	J20001-
9	08037-01008	*GROMMET	1	J20001-
10	01225-70616	*SCREW	7	J20001-
11	418-926-3490	*WASHER	7	J20001-
12	56B-54-13340	*STOPPER	1	J20001-
13	01640-20816	*WASHER	1	J20001-
14	561-54-84271	*COVER	1	J20001-
15	561-54-84770	*SHEET	1	J20001-
16	01023-60616	*SCREW	3	J20001-
17	09415-02512	*CAP	1	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up

OPERATOR'S CAB (DOOR RELATED PARTS)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	01010-81020	BOLT	12	J20001-
2	01643-31032	WASHER	12	J20001-
3	20Y-53-11810	STRIKER	2	J20001-
4	20Y-54-35480	SHIM	2	J20001-
5	01240-00825	SCREW	4	J20001-
6	421-54-15760	WASHER	4	J20001-
7	426-926-3K40	PLATE	2	J20001-
8	424-926-3490	SWITCH	2	J20001-
9	419-923-2130	SCREW	2	J20001-
10	08056-00111	CONNECTOR	2	J20001-
11	08056-00130	HOLDER	2	J20001-
12	421-926-2950	CUSHION	2	J20001-
13	01023-70416	SCREW	2	J20001-
14	01643-70623	WASHER	4	J20001-
15	561-54-84780	GAS SPRING	2	J20001-
16	561-54-84712	PLATE	1	J20001-
17	561-54-84722	PLATE	1	J20001-
18	04205-30835	PIN	4	J20001-
19	426-925-3980	WASHER	8	J20001-
20	426-925-3990	SPACER	4	J20001-
21	04050-12015	PIN	4	J20001-



OPERATOR'S CAB (GLASS)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	569-54-83130	GLASS	1	J20001-
2	561-54-83240	WEATHER STRIP	1	J20001-
3	561-54-83150	GLASS	1	J20001-
4	561-54-83160	GLASS	1	J20001-
5	561-54-83180	DAM	2	J20001-
6	561-54-83170	GLASS	1	J20001-
7	561-54-83190	DAM	1	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

OPERATOR'S CAB (ANTENA CABLE)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	566-07-12150	CABLE	1	J20001-
2	561-54-64450	GROMMET	1	J20001-
3	08037-01008	GROMMET	2	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up


OPERATOR'S CAB (WITHOUT RADIO ANTENA)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	09415-01008	CAP	1	J20001-
2	09415-00706	CAP	2	J20001-



OPERATOR'S CAB (WIPER)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	56B-54-13220	WIPER MOTOR ASS'Y	1	J20001-
2	01010-80616	BOLT	4	J20001-
3	01643-30623	WASHER	4	J20001-
4	569-54-83230	ARM ASS'Y	1	J20001-
5	569-54-83240	BLADE	1	J20001-
6	08053-01510	CLIP	1	J20001-
7	01010-81016	BOLT	1	J20001-
8	01643-31032	WASHER	1	J20001-
9	22T-55-11630	NOZZLE ASS'Y	1	J20001-
10	561-54-83291	HOSE	1	J20001-
11	09415-01008	CAP	1	J20001-
12	20Y-54-18980	GROMMET	1	J20001-



OPERATOR'S CAB (SHEET CAB INSIDE)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-54-83811	SHEET	1	J20001-
2	561-54-83821	SHEET	1	J20001-
3	561-54-83831	SHEET	1	J20001-
4	561-54-83840	SHEET	1	J20001-
5	561-54-83851	SHEET	1	J20001-
6	561-54-83860	SHEET	1	J20001-
7	561-54-83870	SHEET	1	J20001-
8	561-54-83891	SHEET	1	J20001-
9	561-54-83911	SHEET	1	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

OPERATOR'S CAB (CAB ACCESSORY)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	56B-54-13390	SUN VISOR	2	J20001-
2	01023-70520	SCREW	8	J20001-
3	205-54-51250	HANGER	1	J20001-
4	01224-70412	SCREW	2	J20001-
5	421-06-26210	LAMP ASS'Y	1	J20001-
6	419-923-2130	SCREW	2	J20001-
7	56B-06-16790	LAMP ASS'Y	1	J20001-
8	419-923-2130	SCREW	2	J20001-
9	418-967-2140	SPEAKER	2	J20001-
10	418-967-2230	PLATE	2	J20001-
11	418-967-2150	COVER	2	J20001-
12	01023-70420	SCREW	8	J20001-
13	561-54-83411	WIRING HARNESS	1	J20001-
14	01010-80812	BOLT	1	J20001-
15	01643-30823	WASHER	1	J20001-
16	561-54-83491	COVER	1	J20001-
17	01225-70620	SCREW	3	J20001-
18	418-926-3490	WASHER	3	J20001-
18A	561-06-86210	FINISHER	1	J20001-
19	561-54-84561	STAY	5	J20001-
20	01010-80816	BOLT	10	J20001-
21	01643-30823	WASHER	10	J20001-
22	208-53-12991	HOLDER	1	J20001-
23	208-53-12980	PLATE	1	J20001-
24	426-925-3890	PLATE	1	J20001-
25	01023-20616	SCREW	2	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

OPERATOR'S CAB (CAB ACCESSORY) (WITHOUT SPEAKER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	56B-54-13390	SUN VISOR	2	J20001-
2	01023-70520	SCREW	8	J20001-
3	205-54-51250	HANGER	1	J20001-
4	01224-70412	SCREW	2	J20001-
5	421-06-26210	LAMP ASS'Y	1	J20001-
6	419-923-2130	SCREW	2	J20001-
7	56B-06-16790	LAMP ASS'Y	1	J20001-
8	419-923-2130	SCREW	2	J20001-
9	56B-54-14120	PLATE	2	J20001-
10	01023-70420	SCREW	8	J20001-
11	561-54-83411	WIRING HARNESS	1	J20001-
12	01010-80812	BOLT	1	J20001-
13	01643-30823	WASHER	1	J20001-
14	561-54-83491	COVER	1	J20001-
15	01225-70620	SCREW	3	J20001-
16	418-926-3490	WASHER	3	J20001-
16A	561-06-86210	FINISHER	1	J20001-
17	561-54-84561	STAY	5	J20001-
18	01010-80816	BOLT	10	J20001-
19	01643-30823	WASHER	10	J20001-
20	208-53-12991	HOLDER	1	J20001-
21	208-53-12980	PLATE	1	J20001-
22	426-925-3890	PLATE	1	J20001-
23	01023-20616	SCREW	2	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up
OPERATOR'S CAB (CAB ACCESSORY)(SUN VISOR SINGLE
TYPE)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	56B-54-13390	SUN VISOR	1	J20001-
2	01023-70520	SCREW	4	J20001-
3	56B-54-13C50	PLATE	2	J20001-
4	01023-70520	SCREW	4	J20001-
5	205-54-51250	HANGER	1	J20001-
6	01224-70412	SCREW	2	J20001-
7	421-06-26210	LAMP ASS'Y	1	J20001-
8	419-923-2130	SCREW	2	J20001-
9	56B-06-16790	LAMP ASS'Y	1	J20001-
10	419-923-2130	SCREW	2	J20001-
11	418-967-2140	SPEAKER	2	J20001-
12	418-967-2230	PLATE	2	J20001-
13	418-967-2150	COVER	2	J20001-
14	01023-70420	SCREW	8	J20001-
15	561-54-83411	WIRING HARNESS	1	J20001-
16	01010-80812	BOLT	1	J20001-
17	01643-30823	WASHER	1	J20001-
18	561-54-83491	COVER	1	J20001-
19	01225-70620	SCREW	3	J20001-
20	418-926-3490	WASHER	3	J20001-
20A	561-06-86210	FINISHER	1	J20001-
21	561-54-84561	STAY	5	J20001-
22	01010-80816	BOLT	10	J20001-
23	01643-30823	WASHER	10	J20001-
24	208-53-12991	HOLDER	1	J20001-
25	208-53-12980	PLATE	1	J20001-
26	426-925-3890	PLATE	1	J20001-
27	01023-20616	SCREW	2	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

OPERATOR'S CAB (ROOF PAD AND COVER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-54-83512	PAD	1	J20001-
1A	561-54-83610	FINISHER	2	J20001-
2	561-54-83520	PLATE	1	J20001-
3	561-54-83530	PLATE	1	J20001-
4	01225-70620	SCREW	9	J20001-
5	418-926-3490	WASHER	9	J20001-
6	423-56-21910	BUTTON	26	J20001-
7	561-54-83551	COVER	1	J20001-
8	01225-70620	SCREW	3	J20001-
9	418-926-3490	WASHER	3	J20001-
10	561-54-83561	COVER	1	J20001-
11	01225-70620	SCREW	3	J20001-
12	418-926-3490	WASHER	3	J20001-
13	561-54-83570	COVER	1	J20001-
14	01225-70620	SCREW	2	J20001-
15	418-926-3490	WASHER	2	J20001-
16	561-54-83580	COVER	1	J20001-
17	01225-70620	SCREW	2	J20001-
18	418-926-3490	WASHER	2	J20001-
19	09415-02110	CAP	2	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up


OPERATOR'S CAB (MARK AND PLATE)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	56B-93-11340	PLATE, MARK	1	J20001-
2	09970-00230	PLATE	1	J20001-




OPERATOR'S CAB (WINDOW WASHER TANK)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	569-06-61150	TANK ASS'Y	1	J20001-
2	01010-80620	BOLT	2	J20001-
3	01643-30623	WASHER	2	J20001-
4	561-54-81690	BRACKET	1	J20001-
5	01010-81020	BOLT	4	J20001-
6	01643-31032	WASHER	4	J20001-
7	08034-40521	BAND	1	J20001-



OPERATOR'S CAB (AIR CONDITIONER FILTER)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-07-82712	COVER	1	J20001-
2	561-07-82790	SCREW	4	J20001-
3	426-07-32441	FILTER	1	J20001-



FLOOR (FLOOR RELATED PARTS)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	569-40-83310	PLATE	1	J20001-
2	569-40-83A10	SEAL	1	J20001-
3	01010-80820	BOLT	2	J20001-
4	01643-30823	WASHER	2	J20001-
5	09415-02520	CAP	1	J20001-
6	09415-03614	CAP	1	J20001-
7	09415-03620	CAP	1	J20001-
8	421-56-21720	CAP	3	J20001-
9	01010-81016	BOLT	3	J20001-
10	01643-31032	WASHER	3	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up

FLOOR (ACCELERATOR PEDAL)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	729-14-12000	PEDAL	1	J20001-
1	729-14-12100	PEDAL	1	J20001-
2	729-14-11100	SENSOR	1	J20001-
3	01010-80820	BOLT	4	J20001-
4	01643-30823	WASHER	4	J20001-
5	426-43-31211	PLATE	1	J20001-



FLOOR (BRAKE CONTROLE) (1/3)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-43-86110	VALVE	1	J20001-
2	56B-43-17370	NIPPLE	2	J20001-
3	07002-22034	O-RING	2	J20001-
4	02896-21018	O-RING	2	J20001-
5	56B-43-27250	ELBOW	1	J20001-
6	07002-22434	O-RING	1	J20001-
7	56B-43-27240	NIPPLE	1	J20001-
8	07002-22434	O-RING	1	J20001-
9	207-62-64740	O-RING	1	J20001-
10	02782-10516	ELBOW	2	J20001-
11	07002-22034	O-RING	2	J20001-
12	02896-21015	O-RING	2	J20001-
13	01010-81030	BOLT	3	J20001-
14	01643-31032	WASHER	3	J20001-
15	561-43-86120	VALVE	1	J20001-
16	02782-10516	ELBOW	1	J20001-
17	07002-22034	O-RING	1	J20001-
18	02896-21015	O-RING	1	J20001-
19	56B-43-17370	NIPPLE	1	J20001-
20	07002-22034	O-RING	1	J20001-
21	02896-21018	O-RING	1	J20001-
22	561-43-84920	UNION	1	J20001-
23	07002-22034	O-RING	1	J20001-
24	207-62-64740	O-RING	1	J20001-
25	01010-81030	BOLT	4	J20001-
26	01643-31032	WASHER	4	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

FLOOR (BRAKE CONTROLE) (2/3)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	02767-00618	HOSE	1	J20001-
2	02765-00517	HOSE	2	J20001-
3	02765-00516	HOSE	1	J20001-
4	02765-00614	HOSE	1	J20001-
5	02765-00613	HOSE	1	J20001-
6	561-43-83921	HOSE	1	J20001-
7	561-43-83960	HOSE	1	J20001-
8	07094-30620	CLAMP	4	J20001-
9	07095-00628	CUSHION	4	J20001-
10	01010-81270	BOLT	2	J20001-
11	01643-31232	WASHER	2	J20001-
12	561-43-84980	PLATE	3	J20001-
13	561-43-84990	PLATE	3	J20001-
14	561-43-83232	CLAMP	3	J20001-
15	01010-81280	BOLT	6	J20001-
16	01643-31232	WASHER	6	J20001-
17	07094-31024	CLAMP	4	J20001-
18	07095-01034	CUSHION	4	J20001-
19	01010-81280	BOLT	4	J20001-
20	01643-31232	WASHER	4	J20001-
21	561-43-83512	BLOCK	1	J20001-
22	01010-81080	BOLT	3	J20001-
23	01643-31032	WASHER	3	J20001-
24	207-62-72110	UNION	2	J20001-
25	21W-62-42640	ELBOW	1	J20001-
26	02781-00628	UNION	6	J20001-
27	02781-00516	UNION	6	J20001-
28	02896-21018	O-RING	6	J20001-
29	07002-22434	O-RING	6	J20001-
30	02896-21015	O-RING	6	J20001-
31	07002-22034	O-RING	6	J20001-
32	207-62-64740	O-RING	3	J20001-
33	07002-23334	O-RING	3	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

FLOOR (BRAKE CONTROLE) (3/3)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	7861-93-1650	SENSOR	2	J20001-
2	421-06-35111	SWITCH	1	J20001-
3	08193-21012	CLIP	1	J20001-
4	01010-81016	BOLT	1	J20001-
5	01643-31032	WASHER	1	J20001-
6	08034-20834	BAND	1	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

FLOOR (AIR CONDITIONER PIPING)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	566-07-81100	COOLER ASS'Y	1	J20001-
	561-07-81111	COOLER	1	J20001-
	561-07-81200	*BLOWER ASS'Y	1	J20001-
2	561-07-81121	**BLOWER ASS'Y	1	J20001-
3	561-07-81131	**INTAKE ASS'Y	1	J20001-
4	561-07-81141	**CONTROL PANEL A.	1	J20001-
5	561-07-81160	*TUBE ASS'Y	1	J20001-
6	566-07-81170	*HOSE	1	J20001-
7	566-07-81180	*HOSE	1	J20001-
8	01010-80830	BOLT	4	J20001-
9	01643-30823	WASHER	4	J20001-
10	208-979-7540	COLLAR	4	J20001-
11	01010-81020	BOLT	3	J20001-
12	01643-31032	WASHER	3	J20001-
13	208-979-7540	COLLAR	3	J20001-
14	01010-81025	BOLT	3	J20001-
15	01643-31032	WASHER	3	J20001-
16	561-07-82390	GROMMET	1	J20001-
17	207-979-3180	GROMMET	3	J20001-
18	01023-20512	SCREW	4	J20001-
19	561-07-82810	SEAL	2	J20001-
20	561-07-82820	SEAL	1	J20001-
21	561-07-82613	BOX	1	J20001-
22	561-07-82620	SEAL	1	J20001-
23	561-07-82630	SEAL	1	J20001-
24	01010-80812	BOLT	6	J20001-
25	01643-30823	WASHER	6	J20001-
26	561-07-82512	BOX	1	J20001-
27	23A-952-1630	LOCK	1	J20001-
28	561-07-82551	SEAL	1	J20001-
29	01010-80812	BOLT	4	J20001-
30	01643-30823	WASHER	4	J20001-
31	426-07-32441	FILTER	1	J20001-
32	561-07-82562	COVER	1	J20001-
33	01010-80612	BOLT	4	J20001-
34	01643-30623	WASHER	4	J20001-
35	09483-10503	HOSE	2	J20001-
36	09479-02400	CLAMP	4	J20001-
37	416-942-1550	ELBOW	2	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up


FLOOR (DASHBOARD) (1/2)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-54-85413	DASHBOARD	1	J20001-
2	561-06-86220	FINISHER	1	J20001-
3	01010-81020	BOLT	6	J20001-
4	01643-31032	WASHER	6	J20001-
5	56B-54-15560	BRACKET	1	J20001-
6	01010-80616	BOLT	4	J20001-
7	01643-30623	WASHER	4	J20001-
8	561-54-85450	BRACKET	2	J20001-
9	01010-80616	BOLT	5	J20001-
10	01643-30623	WASHER	5	J20001-
11	561-54-85460	BRACKET	1	J20001-
12	561-54-85470	BRACKET	1	J20001-
13	01010-80616	BOLT	5	J20001-
14	01643-30623	WASHER	5	J20001-




FLOOR (DASHBOARD) (2/2)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-54-85300	COVER ASS'Y	1	J20001-
1	56B-54-15912	*COVER	1	J20001-
	561-54-15900	*DASHCOVER	1	J20001-
2	561-54-15920	**DASHCOVER	1	J20001-
3	56B-54-15972	**COVER	1	J20001-
4	56B-54-15932	*COVER	1	J20001-
	22U-979-2381	**GRILLE	1	J20001-
5	56B-54-15942	*COVER	1	J20001-
	22U-979-2381	**GRILLE	1	J20001-
6	569-54-85951	*COVER	1	J20001-
7	569-54-85961	*COVER	1	J20001-
8	01245-00616	SCREW	27	J20001-
9	01643-70623	WASHER	27	J20001-
10	09415-00506	CAP	2	J20001-
11	20Y-979-2161	GRILLE	1	J20001-



FLOOR (DASHBOARD)(2/2) (FOR REAR VIEW TV MONITOR)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-54-85500	COVER ASS'Y	1	J20001-
	561-86-83910	*DASHCOVER	1	J20001-
	561-54-15900	*DASHCOVER	1	J20001-
2	561-54-15920	**DASHCOVER	1	J20001-
3	56B-54-15972	**COVER	1	J20001-
4	56B-54-15932	*COVER	1	J20001-
5	22U-979-2381	**GRILLE	1	J20001-
	56B-54-15942	*COVER	1	J20001-
6	22U-979-2381	**GRILLE	1	J20001-
	569-54-85951	*COVER	1	J20001-
7	569-54-85961	*COVER	1	J20001-
8	01245-00616	SCREW	27	J20001-
9	01643-70623	WASHER	27	J20001-
10	09415-00506	CAP	2	J20001-
11	20Y-979-2161	GRILLE	1	J20001-




FLOOR (AIR DUCT)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-07-82112	DUCT	1	J20001-
2	01010-80616	BOLT	6	J20001-
3	01643-30623	WASHER	6	J20001-
4	561-07-82213	DUCT	1	J20001-
5	01010-80616	BOLT	6	J20001-
6	01643-30623	WASHER	6	J20001-
7	561-07-82310	DUCT	1	J20001-
8	01010-80616	BOLT	2	J20001-
9	01643-30623	WASHER	2	J20001-
10	561-07-82351	BRACKET	1	J20001-
11	561-07-82370	SEAL	1	J20001-
12	561-07-82360	BRACKET	1	J20001-
13	561-07-82370	SEAL	1	J20001-
14	01010-80620	BOLT	2	J20001-
15	01643-30623	WASHER	2	J20001-
16	561-07-82380	HOSE	1	J20001-
17	07281-00489	CLAMP	2	J20001-
18	561-07-82410	SHEET	1	J20001-
19	561-07-82420	SHEET	1	J20001-
20	561-07-82431	SHEET	1	J20001-
21	561-07-82440	SHEET	1	J20001-
22	561-54-85483	COVER	1	J20001-
23	421-54-22520	FINISHER	2	J20001-
24	01245-00616	SCREW	4	J20001-
25	01643-70623	WASHER	4	J20001-



INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	56B-06-16340	BRACKET	1	J20001-
2	01435-00610	BOLT	4	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up

FLOOR (RADIO AND CASSETTE AM/FM)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	425-S67-2160	CASSETTE STEREO	1	J20001-
	08040-00300	.FUSE, 3A	1	J20001-
	08040-00100	.FUSE, 1A	1	J20001-
2	56B-06-16142	BRACKET	2	J20001-
3	01023-60512	SCREW	4	J20001-
4	01435-00610	BOLT	4	J20001-



FLOOR (MONITOR DECAL)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	08086-10000	SWITCH	1	J20001-
2	568-95-11361	SWITCH	1	J20001-
3	56B-06-16810	BUSHING	1	J20001-
4	23W-05-15850	SWITCH ASS'Y	3	J20001-
5	23W-05-15870	SWITCH	2	J20001-
6	23W-05-15860	SWITCH	2	J20001-
7	569-06-61711	SWITCH	1	J20001-
8	56E-06-26192	BRACKET	1	J20001-
9	01023-20612	SCREW	6	J20001-
10	56B-06-16761	CAP	3	J20001-
11	09415-01610	CAP	1	J20001-
12	20Y-06-23472	LIGHTER	1	J20001-
13	569-06-61850	BUZZER	1	J20001-
14	01023-20416	SCREW	2	J20001-
15	416-06-22250	FLASHER	1	J20001-
16	01023-20616	SCREW	1	J20001-
17	421-06-26220	RELAY	1	J20001-
18	01023-20616	SCREW	2	J20001-
19	56B-06-16780	SWITCH	1	J20001-
20	23W-05-15850	SWITCH ASS'Y	1	J20001-
21	56B-06-16761	CAP	3	J20001-
22	56B-06-16761	CAP	3	J20001-

HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up
FLOOR (MONITOR DECAL) (LED DASHBOARD) (SIDE LAMP
SWITCH LESS)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	08086-10000	SWITCH	1	J20001-
2	568-95-11361	SWITCH	1	J20001-
3	56B-06-16810	BUSHING	1	J20001-
4	23W-05-15850	SWITCH ASS'Y	3	J20001-
5	23W-05-15870	SWITCH	2	J20001-
6	23W-05-15860	SWITCH	2	J20001-
7	569-06-61711	SWITCH	1	J20001-
8	56E-06-26192	BRACKET	1	J20001-
9	01023-20612	SCREW	6	J20001-
10	56B-06-16761	CAP	3	J20001-
11	09415-01610	CAP	1	J20001-
12	20Y-06-23472	LIGHTER	1	J20001-
13	569-06-61850	BUZZER	1	J20001-
14	01023-20416	SCREW	2	J20001-
15	561-06-81310	FLASHER	1	J20001-
16	01023-20616	SCREW	1	J20001-
17	421-06-26220	RELAY	1	J20001-
18	01023-20616	SCREW	2	J20001-
19	08034-20414	BAND	1	J20001-
20	56B-06-16780	SWITCH	1	J20001-
21	56B-06-16761	CAP	4	J20001-
22	56B-06-16761	CAP	3	J20001-



FLOOR (MONITORING DECAL) (WITH ARS SWITCH)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	08086-10000	SWITCH	1	J20001-
2	568-95-11361	SWITCH	1	J20001-
3	56B-06-16810	BUSHING	1	J20001-
4	23W-05-15850	SWITCH ASS'Y	3	J20001-
5	23W-05-15870	SWITCH	2	J20001-
6	23W-05-15860	SWITCH	2	J20001-
7	569-06-61711	SWITCH	1	J20001-
8	56E-06-26192	BRACKET	1	J20001-
9	01023-20612	SCREW	6	J20001-
10	56B-06-16761	CAP	3	J20001-
11	09415-01610	CAP	1	J20001-
12	20Y-06-23472	LIGHTER	1	J20001-
13	569-06-61850	BUZZER	1	J20001-
14	01023-20416	SCREW	2	J20001-
15	416-06-22250	FLASHER	1	J20001-
16	01023-20616	SCREW	1	J20001-
17	421-06-26220	RELAY	1	J20001-
18	01023-20616	SCREW	2	J20001-
19	23W-05-15850	SWITCH ASS'Y	1	J20001-
20	23W-05-15850	SWITCH ASS'Y	1	J20001-
21	56B-06-16761	CAP	3	J20001-
22	56B-06-16761	CAP	3	J20001-

HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up
FLOOR (MONITOR DECAL) (LED DASHBORD) (SIDE LAMP
SWITCH LESS)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	08086-10000	SWITCH	1	J20001-
2	568-95-11361	SWITCH	1	J20001-
3	56B-06-16810	BUSHING	1	J20001-
4	23W-05-15850	SWITCH ASS'Y	3	J20001-
5	23W-05-15870	SWITCH	2	J20001-
6	23W-05-15860	SWITCH	2	J20001-
7	569-06-61711	SWITCH	1	J20001-
8	56E-06-26192	BRACKET	1	J20001-
9	01023-20612	SCREW	6	J20001-
10	56B-06-16761	CAP	3	J20001-
11	09415-01610	CAP	1	J20001-
12	20Y-06-23472	LIGHTER	1	J20001-
13	569-06-61850	BUZZER	1	J20001-
14	01023-20416	SCREW	2	J20001-
15	416-06-22250	FLASHER	1	J20001-
16	01023-20616	SCREW	1	J20001-
17	421-06-26220	RELAY	1	J20001-
18	01023-20616	SCREW	2	J20001-
19	56B-06-16780	SWITCH	1	J20001-
20	56B-06-16761	CAP	4	J20001-
21	56B-06-16761	CAP	3	J20001-



FLOOR (MONITOR DECAL) (LED DASHBORD)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	08086-10000	SWITCH	1	J20001-
2	568-95-11361	SWITCH	1	J20001-
3	56B-06-16810	BUSHING	1	J20001-
4	23W-05-15850	SWITCH ASS'Y	3	J20001-
5	23W-05-15870	SWITCH	2	J20001-
6	23W-05-15860	SWITCH	2	J20001-
7	569-06-61711	SWITCH	1	J20001-
8	56E-06-26192	BRACKET	1	J20001-
9	01023-20612	SCREW	6	J20001-
10	56B-06-16761	CAP	3	J20001-
11	09415-01610	CAP	1	J20001-
12	20Y-06-23472	LIGHTER	1	J20001-
13	569-06-61850	BUZZER	1	J20001-
14	01023-20416	SCREW	2	J20001-
15	561-06-81310	FLASHER	1	J20001-
16	01023-20616	SCREW	1	J20001-
17	421-06-26220	RELAY	1	J20001-
18	01023-20616	SCREW	2	J20001-
19	08034-20414	BAND	1	J20001-
20	56B-06-16780	SWITCH	1	J20001-
21	23W-05-15850	SWITCH ASS'Y	1	J20001-
22	56B-06-16761	CAP	3	J20001-
23	56B-06-16761	CAP	3	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up

FLOOR (MONITOR PANEL) (KM/H)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	7831-46-7002	MONITOR	1	J20001-
2	01010-80612	BOLT	8	J20001-
3	01643-30623	WASHER	8	J20001-



FLOOR (STEERING COLUMN)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	569-40-83300	COLUMN ASS'Y	1	J20001-
2	01580-11008	NUT	2	J20001-
3	01436-01025	BOLT	2	J20001-
4	01643-31032	WASHER	2	J20001-
5	01050-81035	BOLT	1	J20001-
6	01640-21016	WASHER	1	J20001-
7	56E-40-23350	BRACKET	1	J20001-
8	01010-80616	BOLT	4	J20001-
9	01643-30623	WASHER	4	J20001-
9A	421-09-21420	SHEET	1	J20001-
10	56E-40-23360	COVER	1	J20001-
10A	421-09-21420	SHEET	2	J20001-
11	01245-00616	SCREW	3	J20001-
12	01643-70623	WASHER	3	J20001-
13	561-40-83381	COVER	1	J20001-
14	01010-80816	BOLT	2	J20001-
15	01643-30823	WASHER	2	J20001-
16	01245-00612	SCREW	2	J20001-
17	01643-70623	WASHER	2	J20001-
18	561-40-83371	COVER	1	J20001-
19	01010-80816	BOLT	2	J20001-
20	01643-30823	WASHER	2	J20001-
21	01245-00612	SCREW	4	J20001-
22	01643-70623	WASHER	4	J20001-

HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up
FLOOR (COLUMN SWITCH AND STEERING WHEEL) (WITH
SENSOR)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-06-86801	SWITCH ASS'Y	1	J20001-
	561-06-86701	*SWITCH ASS'Y	1	J20001-
1	☆	**BODY	1	J20001-
2	☆	**COVER	1	J20001-
3	☆	**COVER	1	J20001-
3A	☆	**TAPE	1	J20001-
4	56B-06-16710	**SWITCH	1	J20001-
5	56B-06-16720	**SWITCH	1	J20001-
6	56B-06-16730	**LEVER	1	J20001-
7	08192-18813	**CONNECTOR	1	J20001-
8	08192-19812	**CONNECTOR	1	J20001-
9	08192-26810	**CONNECTOR	1	J20001-
10	56B-06-16910	*SWITCH	1	J20001-
11	566-88-8H130	*SWITCH	1	J20001-
12	01023-70614	SCREW	3	J20001-
13	561-40-83390	BRACKET	1	J20001-
14	01010-80612	BOLT	2	J20001-
15	01643-30623	WASHER	2	J20001-
16	7861-92-2410	SENSOR	1	J20001-
17	01010-80612	BOLT	2	J20001-
18	01643-30623	WASHER	2	J20001-
19	561-44-67230	WHEEL	1	J20001-
20	01220-40408	SCREW	4	J20001-
21	01601-20410	WASHER	4	J20001-
22	01640-20408	WASHER	4	J20001-
23	561-44-67310	BRACKET	1	J20001-
24	561-44-67270	BODY	1	J20001-
25	561-44-67340	BEARING	1	J20001-
26	561-44-67330	WASHER	2	J20001-
27	561-44-67350	WASHER	2	J20001-
28	04064-05020	RING	1	J20001-
29	561-44-67261	RING	1	J20001-
30	561-44-67320	PLATE	1	J20001-
31	01252-30625	BOLT	4	J20001-
32	569-44-87311	BRACKET	1	J20001-
33	01010-80616	BOLT	2	J20001-
34	01643-30623	WASHER	2	J20001-
35	09415-00506	CAP	2	J20001-
	56B-40-13100	WHEEL ASS'Y	1	J20001-
36	56B-40-13110	*WHEEL	1	J20001-
37	56B-40-13120	*HORN BUTTON KIT	1	J20001-
38	56B-40-13130	**BRUSH	1	J20001-
39	56B-40-13140	**CABLE	1	J20001-
40	56B-40-13150	**BUTTON	1	J20001-



FLOOR (COLUMN SWITCH AND STEERING WHEEL)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-06-86801	SWITCH ASS'Y	1	J20001-
	561-06-86701	*SWITCH ASS'Y	1	J20001-
1	☆	**BODY	1	J20001-
2	☆	**COVER	1	J20001-
3	☆	**COVER	1	J20001-
3A	☆	**TAPE	1	J20001-
4	56B-06-16710	**SWITCH	1	J20001-
5	56B-06-16720	**SWITCH	1	J20001-
6	56B-06-16730	**LEVER	1	J20001-
7	08192-18813	**CONNECTOR	1	J20001-
8	08192-19812	**CONNECTOR	1	J20001-
9	08192-26810	**CONNECTOR	1	J20001-
10	56B-06-16910	*SWITCH	1	J20001-
11	566-88-8H130	*SWITCH	1	J20001-
12	01023-70614	*SCREW	3	J20001-
	56B-40-13100	WHEEL ASS'Y,STEERING	1	J20001-
13	56B-40-13110	*WHEEL	1	J20001-
14	56B-40-13120	*HORN BUTTON KIT	1	J20001-
15	56B-40-13130	**BRUSH	1	J20001-
16	56B-40-13140	**CABLE	1	J20001-
17	56B-40-13150	**BUTTON	1	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up

FLOOR (MONITOR DECAL)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	56B-93-11260	PLATE.....	1	J20001-
1	561-93-81120	PLATE.....	1	J20001-



FLOOR (OPERATOR'S SEAT)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	(569-57-81111)	SEAT ASS'Y	1	J20001-
2	01252-70820	BOLT	4	J20001-
3	561-57-81140	BRACKET	1	J20001-
4	01010-81020	BOLT	4	J20001-
5	01643-31032	WASHER	4	J20001-
6	08037-03614	GROMMET	1	J20001-
7	56B-57-11122	BELT	1	J20001-
8	04434-51010	CLIP	1	J20001-
9	01435-01016	BOLT	1	J20001-
10	08034-20519	BAND	1	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

FLOOR (OPERATOR'S SEAT) (INNER PARTS)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	569-57-81111	SEAT ASS'Y	1	J20001-
1	AS182908	*BACK COVER KIT	1	J20001-
2	AS157143	*BACK FOAM KIT	1	J20001-
3	AS157146	*SEAT COVER KIT	1	J20001-
4	AS157154	*SEAT FOAM KIT	1	J20001-
5	AS182907	*FRAME KIT	1	J20001-
6	AS187944	*HEIGHT RISER KIT	1	J20001-
7	AS151185	*HEAD REST KIT	1	J20001-
8	AS164899	*DAMPER KIT	1	J20001-
9	AS160438	*WEIGHT ADJUSTER KIT	1	J20001-
10	AS160436	*UP STOP/BUMP STOP K.....	1	J20001-
11	AS188057	*SUSPENSION ASS'Y	1	J20001-
12	AS187945	*ADJUSTMENT KIT	1	J20001-
13	AS187947	*KNOB KIT	1	J20001-
14	AS187946	*SUSPENSION COVER KIT	1	J20001-
15	AS160439	*BEARING KIT	1	J20001-
16	AS165989	*LEVER/CENTRE PIVOT	1	J20001-
17	AS163938	*SUPPORT KIT	1	J20001-
18	AS187948	*LATCH KIT,(NOT SHOWN).....	1	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up

FLOOR (DUMP CONTROL)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	569-43-82231	BRACKET	1	J20001-
2	01010-80820	BOLT	4	J20001-
3	01643-30823	WASHER	4	J20001-
4	566-43-11170	GROMMET	1	J20001-
5	569-43-82210	COVER	1	J20001-
6	01023-70614	SCREW	3	J20001-
7	421-09-21420	SHEET	3	J20001-
8	702-16-02133	LEVER ASS'Y	1	J20001-
9	01010-80645	BOLT	2	J20001-
10	01643-30623	WASHER	2	J20001-
11	01580-10605	NUT	2	J20001-
12	569-43-82221	BRACKET	1	J20001-
13	01010-81025	BOLT	2	J20001-
14	01643-31032	WASHER	2	J20001-
15	56B-43-12272	PLUNGER	1	J20001-
16	01643-71032	WASHER	1	J20001-
17	56B-43-12261	PLATE	1	J20001-
18	23S-43-51212	KNOB ASS'Y	1	J20001-
19	01583-11207	NUT	1	J20001-
20	569-06-86430	WIRING HARNESS	1	J20001-



FLOOR (CONSOLE BOX) (R.H. POWER WINDOW SWITCH LESS)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-54-85612	COVER	1	J20001-
2	423-54-32340	FINISHER	1	J20001-
3	01010-81016	BOLT	6	J20001-
4	01643-31032	WASHER	6	J20001-
5	56B-54-15622	COVER	1	J20001-
6	09415-05016	CAP	1	J20001-
7	01245-00616	SCREW	10	J20001-
8	01643-70623	WASHER	10	J20001-
9	56B-54-15631	COVER	1	J20001-
10	56B-54-15750	HINGE	2	J20001-
11	56B-54-16810	PLATE	2	J20001-
12	01023-20412	SCREW	8	J20001-
13	01580-10403	NUT	4	J20001-
14	01640-20408	WASHER	4	J20001-
15	56E-54-25650	SHEET	1	J20001-
16	56B-54-15651	SEAL	1	J20001-
17	423-54-32370	FINISHER	2	J20001-
18	569-54-63260	CATCHER	1	J20001-
19	01023-20308	SCREW	2	J20001-
20	569-54-63350	SEAT	1	J20001-
21	01224-70308	SCREW	1	J20001-
22	56B-54-15690	COVER	1	J20001-
23	569-06-86740	LEVER ASS'Y	1	J20001-
24	01010-80816	BOLT	4	J20001-
25	01643-30823	WASHER	4	J20001-
26	426-56-21490	SWITCH,POWER WINDOW	1	J20001-
27	56D-54-25670	DECAL	1	J20001-
28	56B-06-16770	SWITCH	1	J20001-
29	561-06-86420	WIRING HARNESS	1	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

FLOOR (CONSOLE BOX) (12V DC LESS)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	09415-02512	CAP	1	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

FLOOR (CONSOLE BOX) (12V DC)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	22U-06-22250	CONVERTER	1	J20001-
2	01010-80612	BOLT	2	J20001-
3	01643-30623	WASHER	2	J20001-
4	198-Z11-2640	SOCKET ASS'Y	1	J20001-
5	561-06-86461	WIRING HARNESS	1	J20001-
6	04434-50510	CLIP	2	J20001-
7	01010-81016	BOLT	2	J20001-
8	01643-31032	WASHER	2	J20001-
9	08034-20823	BAND	7	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up

FLOOR (REAR COVER)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-06-86112	COVER	1	J20001-
2	423-54-32340	FINISHER	1	J20001-
3	423-54-32370	FINISHER	1	J20001-
4	561-06-86210	FINISHER	1	J20001-
5	561-06-86220	FINISHER	1	J20001-
6	01010-81016	BOLT	3	J20001-
7	01643-31032	WASHER	3	J20001-
8	01245-00612	SCREW	4	J20001-
9	01643-70623	WASHER	4	J20001-
10	561-06-86141	COVER	1	J20001-
11	01245-00612	SCREW	2	J20001-
12	01643-70623	WASHER	2	J20001-
13	561-06-86151	COVER	1	J20001-
14	561-06-86251	SEAL	1	J20001-
15	561-06-86280	SCREW	2	J20001-
16	561-06-86122	COVER	1	J20001-
17	561-06-86210	FINISHER	1	J20001-
18	561-06-86230	FINISHER	1	J20001-
19	01010-81020	BOLT	2	J20001-
20	01643-31032	WASHER	2	J20001-
21	01245-00612	SCREW	3	J20001-
22	01643-70623	WASHER	3	J20001-
23	561-06-86160	COVER	1	J20001-
24	561-06-86251	SEAL	1	J20001-
25	561-06-86280	SCREW	2	J20001-



FLOOR (AUXILIARY SEAT)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-57-81300	SEAT	1	J20001-
2	01010-81020	BOLT	4	J20001-
3	01643-31032	WASHER	4	J20001-
4	561-54-85712	BRACKET	1	J20001-
5	423-54-32391	FINISHER	1	J20001-
6	01010-81020	BOLT	6	J20001-
7	01643-31032	WASHER	6	J20001-
8	561-54-85740	BOX	1	J20001-
9	421-06-32270	SEAL	1	J20001-
10	01023-70614	SCREW	4	J20001-
11	561-54-85730	PLATE	1	J20001-
12	01010-81016	BOLT	4	J20001-
13	01643-31032	WASHER	4	J20001-
14	561-54-83440	COVER	1	J20001-
15	561-06-86210	FINISHER	1	J20001-
16	01245-00616	SCREW	2	J20001-
17	01643-70623	WASHER	2	J20001-
18	08059-00310	CLIP	1	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up

FLOOR (AUXILIARY SEAT) (SEAT BELT 75MM)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-57-81300	SEAT	1	J20001-
2	01010-81020	BOLT	4	J20001-
3	01643-31032	WASHER	4	J20001-
4	561-54-85712	BRACKET	1	J20001-
5	423-54-32391	FINISHER	1	J20001-
6	01010-81020	BOLT	6	J20001-
7	01643-31032	WASHER	6	J20001-
8	561-54-85740	BOX	1	J20001-
9	421-06-32270	SEAL	1	J20001-
10	01023-70614	SCREW	4	J20001-
11	561-54-85730	PLATE	1	J20001-
12	01010-81016	BOLT	4	J20001-
13	01643-31032	WASHER	4	J20001-
14	561-54-83440	COVER	1	J20001-
15	561-06-86210	FINISHER	1	J20001-
16	01245-00616	SCREW	2	J20001-
17	01643-70623	WASHER	2	J20001-
18	08059-00310	CLIP	1	J20001-
19	09409-70000	BELT LAP	1	J20001-



FLOOR (FUSE BOX AND RELAY)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	01023-20620	SCREW	8	J20001-
2	08041-00500	FUSE, 5A	2	J20001-
3	08041-01000	FUSE, 10A	28	J20001-
4	08041-02000	FUSE, 20A	26	J20001-
5	08041-03000	FUSE, 30A	3	J20001-
6	569-06-61960	RELAY	16	J20001-
7	569-06-61960	RELAY	2	J20001-
8	569-06-61180	BRACKET	6	J20001-
9	01023-20616	SCREW	6	J20001-
10	56B-06-16841	RELAY	1	J20001-
11	569-06-86360	BRACKET	1	J20001-
12	56B-06-16380	SHEET	2	J20001-
13	56B-06-16390	SHEET	1	J20001-
14	56B-06-16690	SHEET	1	J20001-
15	421-09-21420	SHEET	2	J20001-
16	01010-80616	BOLT	2	J20001-
17	01643-30623	WASHER	2	J20001-
18	561-06-86183	BRACKET	1	J20001-
19	01010-81020	BOLT	4	J20001-
20	01643-31032	WASHER	4	J20001-
21	561-06-86192	BRACKET	1	J20001-
22	01010-81020	BOLT	4	J20001-
23	01643-31032	WASHER	4	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up

FLOOR (SIDE LAMP RELAY)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	569-06-61970	RELAY	1	J20001-



FLOOR (ROLL OVER ANGLE SENSOR)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	7861-93-5350	SENSOR	1	J20001-
2	01010-50635	BOLT	2	J20001-
3	01580-10605	NUT	2	J20001-
4	01602-20619	WASHER	2	J20001-
5	56D-06-25610	WIRING HARNESS	1	J20001-
6	08036-03014	CLIP	2	J20001-
7	01010-81016	BOLT	2	J20001-
8	01643-31032	WASHER	2	J20001-
9	08193-20010	CLIP	1	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

FLOOR (ROLL OVER ANGLE SENSOR LES PARTS)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	08192-23810	CONNECTOR	1	J20001-
2	08191-00770	PLUG	3	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

FLOOR (FLOOR WIRING)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-06-86131	BRACKET	1	J20001-
2	7818-64-5003	CONTROLLER	1	J20001-
3	01010-81020	BOLT	4	J20001-
4	01643-31032	WASHER	4	J20001-
5	01010-80885	BOLT	4	J20001-
6	01643-30823	WASHER	4	J20001-
7	7818-65-2004	CONTROLLER	1	J20001-
8	01010-80885	BOLT	4	J20001-
9	01643-30823	WASHER	4	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

FLOOR (EMERGENCY STARTING TIMER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-06-86510	BRACKET	1	J20001-
2	01010-80616	BOLT	1	J20001-
3	01643-30623	WASHER	1	J20001-
4	582-06-11811	TIMER	1	J20001-
5	582-06-11820	SOCKET	1	J20001-
6	561-06-86520	COVER	1	J20001-
7	01010-80616	BOLT	2	J20001-
8	01643-30623	WASHER	2	J20001-
9	08059-00310	CLIP	2	J20001-
10	561-06-86413	WIRING HARNESS	1	J20001-
11	56B-06-16830	CONNECTOR	1	J20001-
12	561-06-86430	WIRING HARNESS	1	J20001-
13	08034-20519	BAND	1	J20001-
14	04434-51008	CLIP	2	J20001-
15	08059-00310	CLIP	5	J20001-
16	08059-00413	CLIP	2	J20001-
17	08059-00515	CLIP	1	J20001-
18	281-01-13180	CLIP	6	J20001-
19	01010-81016	BOLT	6	J20001-
20	01643-31032	WASHER	6	J20001-
21	04434-51908	CLIP	2	J20001-
22	08053-01510	CLIP	1	J20001-
23	04434-51008	CLIP	1	J20001-
24	08053-00910	CLIP	1	J20001-
25	04434-50608	CLIP	1	J20001-
26	01010-80616	BOLT	2	J20001-
27	01643-30623	WASHER	2	J20001-
28	04434-51710	CLIP	1	J20001-
29	01010-81016	BOLT	1	J20001-
30	01643-31032	WASHER	1	J20001-
31	23S-62-25850	CLIP	2	J20001-
32	419-09-11150	CLIP	1	J20001-
33	01010-81016	BOLT	3	J20001-
34	01643-31032	WASHER	3	J20001-
35	01023-60414	SCREW	12	J20001-
36	01023-60425	SCREW	4	J20001-
37	04434-52210	CLIP	3	J20001-
38	01010-81020	BOLT	3	J20001-
39	01643-31032	WASHER	3	J20001-
40	04434-52110	CLIP	3	J20001-
41	01010-81020	BOLT	3	J20001-
42	01643-31032	WASHER	3	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up

FLOOR (REAR COVER)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-06-86310	BRACKET	1	J20001-
2	01010-81016	BOLT	2	J20001-
3	01643-31032	WASHER	2	J20001-
4	08034-20834	BAND	1	J20001-
5	561-06-86320	BRACKET	1	J20001-
6	01010-81020	BOLT	4	J20001-
7	01643-31032	WASHER	4	J20001-
8	04434-51010	CLIP	1	J20001-
9	04434-51410	CLIP	1	J20001-
10	04434-51710	CLIP	1	J20001-
11	01010-81016	BOLT	3	J20001-
12	01643-31032	WASHER	3	J20001-
13	08034-20834	BAND	1	J20001-
14	561-06-86170	COVER	1	J20001-
15	01010-81020	BOLT	2	J20001-
16	01643-31032	WASHER	2	J20001-
17	01245-00612	SCREW	2	J20001-
18	01643-70623	WASHER	2	J20001-
19	08037-05016	GROMMET	1	J20001-



FLOOR (PAYLOAD METER ANGLE SENSOR)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	7861-93-5350	SENSOR	1	J20001-
2	01010-50635	BOLT	2	J20001-
3	01580-10605	NUT	2	J20001-
4	01602-20619	WASHER	2	J20001-
5	569-06-61960	RELAY	3	J20001-
6	569-06-61970	RELAY	1	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up

FLOOR (PAYLOAD METER ANGLE SENSOR LESS PARTS)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	08192-23810	CONNECTOR	1	J20001-
2	08191-00770	PLUG	3	J20001-



FLOOR (VHMS)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-97-82112	BRACKET	1	J20001-
2	01010-80816	BOLT	4	J20001-
3	01643-30823	WASHER	4	J20001-
4	7826-13-8000	CONTROLLER	1	J20001-
5	01010-80885	BOLT	4	J20001-
6	01643-30823	WASHER	4	J20001-
7	561-97-82212	WIRING HARNESS	1	J20001-
8	569-97-82310	CONNECTOR	1	J20001-
9	569-97-82120	PLATE	1	J20001-
10	01023-70410	SCREW	4	J20001-
11	01023-20312	SCREW	8	J20001-
12	01601-20307	WASHER	8	J20001-
13	01580-60302	NUT	8	J20001-
14	04434-50810	CLIP	2	J20001-
15	01010-81016	BOLT	2	J20001-
16	01643-31032	WASHER	2	J20001-
17	04434-52110	CLIP	4	J20001-
18	01010-81016	BOLT	4	J20001-
19	01643-31032	WASHER	4	J20001-
20	04434-51410	CLIP	2	J20001-
21	01010-81016	BOLT	2	J20001-
22	01643-31032	WASHER	2	J20001-
23	04434-51010	CLIP	1	J20001-
24	561-97-82180	BRACKET	1	J20001-
25	01010-81016	BOLT	4	J20001-
26	01643-31032	WASHER	4	J20001-
27	6215-81-8150	AMPLIFIER	4	J20001-
28	01252-70616	BOLT	16	J20001-
29	569-97-82180	BRACKET	2	J20001-
30	01010-80816	BOLT	12	J20001-
31	01643-30823	WASHER	12	J20001-
32	08037-11425	GROMMET	2	J20001-
33	08034-20519	BAND	2	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

FLOOR (VHMS LESS PARTS)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	09415-02512	CAP	1	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

FLOOR (PAYLOAD METER LESS PARTS)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-06-86490	WIRING, HARNESS	1	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up


FLOOR (CONNECTOR PLUG)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-06-86470	PLATE	1	J20001-
2	561-06-86480	SHEET	1	J20001-
3	01640-20408	WASHER	4	J20001-
4	01580-10403	NUT	4	J20001-



FLOOR (CAB UNDER PARTS)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-06-83232	WIRING HARNESS	1	J20001-
2	04434-51210	CLIP	2	J20001-
3	04434-51410	CLIP	4	J20001-
4	04434-51010	CLIP	3	J20001-
5	04434-50610	CLIP	2	J20001-
6	04434-50612	CLIP	2	J20001-
7	08193-21012	CLIP	3	J20001-
8	01010-81016	BOLT	13	J20001-
9	01643-31032	WASHER	13	J20001-
10	08034-20834	BAND	2	J20001-
11	08028-45025	CABLE	2	J20001-
12	01010-81016	BOLT	4	J20001-
13	01643-31032	WASHER	4	J20001-
14	561-54-82111	COVER	1	J20001-
15	561-54-82120	COVER	1	J20001-
16	561-54-82131	COVER	1	J20001-
17	423-54-12290	PLATE	1	J20001-
18	423-54-15780	FINISHER	1	J20001-
19	22T-54-13440	FINISHER	1	J20001-
20	569-54-82240	SEAL	1	J20001-
21	561-54-82210	SEAL	1	J20001-
22	561-54-82230	SEAL	1	J20001-
23	569-54-82230	SEAL	1	J20001-
24	01010-81020	BOLT	26	J20001-
25	01643-31032	WASHER	26	J20001-
26	01010-81025	BOLT	5	J20001-
27	01643-31032	WASHER	5	J20001-



FLOOR MAT

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-54-85771	MAT	1	J20001-
2	561-54-85780	MAT	1	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

CAB GUARD (FRONT STEP)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-54-80103	STEP,FRONT	1	J20001-
1	561-54-81722	*STEP	1	J20001-
2	561-54-81772	*GUARD	1	J20001-
3	561-54-61910	*CLAMP	2	J20001-
4	01010-81635	*BOLT	4	J20001-
5	01643-31645	*WASHER	4	J20001-
6	561-54-86511	*GUARD	1	J20001-
7	01010-81020	*BOLT	3	J20001-
8	01643-31032	*WASHER	3	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

CAB GUARD (SIDE STEP)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-54-80202	STEP,SIDE	1	J20001-
1	561-54-81712	*STEP	1	J20001-
2	561-54-81820	*STEP	1	J20001-
3	01010-81230	*BOLT	4	J20001-
4	01643-31232	*WASHER	4	J20001-
5	561-54-86714	*GUARD	1	J20001-
6	01010-80612	*BOLT	4	J20001-
7	01643-30623	*WASHER	4	J20001-
8	561-54-86722	*GUARD	1	J20001-
9	561-54-61910	*CLAMP	4	J20001-
10	01010-81635	*BOLT	10	J20001-
11	01643-31645	*WASHER	10	J20001-
12	01010-81245	*BOLT	2	J20001-
13	01643-31232	*WASHER	2	J20001-
14	01580-11210	*NUT	2	J20001-
15	01643-31232	*WASHER	2	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up

CAB GUARD (TOE DUARD)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-54-80202	STEP,SIDE	1	J20001-
1	569-54-82521	BRACKET	1	J20001-
2	569-54-82531	BRACKET	1	J20001-
3	01010-81020	BOLT	6	J20001-
4	01643-31032	WASHER	6	J20001-



CAB GUARD (SIDE MIRROR (L.H.))

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-54-80202	STEP,SIDE	1	J20001-
1	56B-54-17311	.MIRROR,BACK	1	J20001-
2	561-54-87111	.PLATE	1	J20001-
3	07283-33442	.CLIP	2	J20001-
4	01597-01009	.NUT	4	J20001-
5	01643-31032	.WASHER	4	J20001-
6	569-54-87140	.COVER	1	J20001-
7	569-54-87150	.STAY	1	J20001-
8	01435-01016	.BOLT	2	J20001-
9	01580-11613	.NUT	1	J20001-
10	01643-31645	.WASHER	2	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up

CAB GUARD (BOLT LINE)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	01010-81225	BOLT	8	J20001-
2	01643-31232	WASHER	8	J20001-
3	01010-81230	BOLT	2	J20001-
4	01643-31232	WASHER	2	J20001-
5	01010-81250	BOLT	2	J20001-
6	01643-31232	WASHER	2	J20001-
7	01010-81230	BOLT	12	J20001-
8	01643-31232	WASHER	12	J20001-



CAB GUARD (RADIO ANTENA)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	175-911-6140	ANTENNA ASS'Y	1	J20001-
2	01225-40412	SCREW	1	J20001-
3	01023-10420	SCREW	1	J20001-
4	561-54-86940	COVER	1	J20001-
5	01435-01016	BOLT	2	J20001-
6	08037-01008	GROMMET	1	J20001-
7	08210-00610	SPIRAL TUBE	1	J20001-
8	08037-11825	GROMMET	1	J20001-
9	07270-51513	TUBE	1	J20001-
10	04434-51910	CLIP	7	J20001-
11	01435-01016	BOLT	7	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

CAB GUARD (CAP)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	421-56-21720	CAP	4	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up

CAB GUARD (MAD GUARD)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-54-86820	BRACKET	1	J20001-
2	01010-D1220	BOLT	3	J20001-
3	01643-71232	WASHER	3	J20001-
4	569-54-81571	GUARD	1	J20001-
5	283-54-11470	PLATE	2	J20001-
6	417-43-16210	WASHER	2	J20001-
7	01010-D1030	BOLT	6	J20001-
8	01643-71032	WASHER	6	J20001-
9	561-54-86670	BRACKET	1	J20001-
10	01010-D1025	BOLT	2	J20001-
11	01643-71032	WASHER	2	J20001-



CAB GUARD (CAB UNDER COVER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-54-82142	COVER	1	J20001-
2	569-54-82260	SEAL	1	J20001-
3	569-54-82290	SEAL	1	J20001-
4	01010-81020	BOLT	9	J20001-
5	01643-31032	WASHER	9	J20001-


PLATFORM AND RELATED PARTS



PLATFORM SUB ASS'Y (L.H.)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-54-80501	PLATFORM ASS'Y,(L.H.)	1	J20001-
1	561-54-81411	*PLATFORM	1	J20001-
2	08037-02512	*GROMMET	1	J20001-
3	421-56-21230	*FINISHER	1	J20001-
4	(6217-81-7103)	*AIR CLEANER ASS'Y	1	J20001-
5	600-181-3960	*CAP	3	J20001-
6	6151-11-9970	*BAND ASS'Y	6	J20001-
7	6643-11-4641	*BOLT	6	J20001-
8	561-02-82140	*BRACKET	3	J20001-
9	01010-81225	*BOLT	12	J20001-
10	01643-31232	*WASHER	12	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up
PLATFORM SUB ASS'Y (R.H.)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-54-80G01	PLATFORM ASS'Y	1	J20001-
	561-54-81422	*PLATFORM	1	J20001-
2	08037-03614	*GROMMET	1	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up

PLATFORM SUB ASS'Y (R.H.) (MUD GUARD)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(561-54-80G01)	PLATFORM ASS'Y	1	J20001-
1	561-54-67160	*GUARD	1	J20001-
2	561-54-81560	*PLATE	1	J20001-
3	01010-D1235	*BOLT	7	J20001-
4	01643-71232	*WASHER	7	J20001-



PLATFORM SUB ASS'Y (R.H.) (HANDRAIL)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(561-54-80G01)	PLATFORM ASS'Y	1	J20001-
1	561-54-81783	*GUARD	1	J20001-
2	561-54-81754	*GUARD	1	J20001-
3	561-54-81792	*GUARD	1	J20001-
4	01010-81245	*BOLT	3	J20001-
5	01643-31232	*WASHER	3	J20001-
6	01643-31232	*WASHER	3	J20001-
7	01580-11210	*NUT	3	J20001-
8	561-54-61910	*CLAMP	6	J20001-
9	01010-81635	*BOLT	12	J20001-
10	01643-31645	*WASHER	12	J20001-
11	01010-81230	*BOLT	2	J20001-
12	01643-31232	*WASHER	2	J20001-
13	561-54-86981	*GUARD	1	J20001-
14	01010-81245	*BOLT	2	J20001-
15	01643-31232	*WASHER	2	J20001-
16	01643-31232	*WASHER	2	J20001-
17	01580-11210	*NUT	2	J20001-
18	6143-11-5630	*SPACER	1	J20001-
19	01010-81230	*BOLT	4	J20001-
20	01643-31232	*WASHER	4	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up


PLATFORM SUB ASS'Y (R.H.) (TOE GUARD)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(561-54-80G01)	PLATFORM ASS'Y	1	J20001-
1	561-54-87280	.PLATE	1	J20001-
2	01010-81025	.BOLT	9	J20001-
3	01643-31032	.WASHER	9	J20001-
4	07049-01215	.PLUG	4	J20001-
5	561-54-86520	.PLATE	1	J20001-




PLATFORM SUB ASS'Y (PLATFORM RELATED PARTS)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	01643-32060	WASHER	6	J20001-
2	01010-82045	BOLT	6	J20001-
3	09415-05016	CAP	6	J20001-
4	01010-81235	BOLT	8	J20001-
5	01643-31232	WASHER	8	J20001-
6	561-54-86541	COVER	1	J20001-
7	07283-33442	CLIP	2	J20001-
8	01643-31032	WASHER	4	J20001-
9	01597-01009	NUT	4	J20001-
10	01010-81025	BOLT	3	J20001-
11	01643-31032	WASHER	3	J20001-



COOLANT RESERVE TANK


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-03-80101	TANK ASS'Y	1	J20001-
1	561-03-81911	.TANK	1	J20001-
2	208-04-19130	.ELBOW	2	J20001-
3	561-03-61940	.TUBE	1	J20001-
4	208-04-19160	.BALL	1	J20001-
5	07053-10000	.CAP	1	J20001-
6	01010-81225	BOLT	4	J20001-
7	01643-31232	WASHER	4	J20001-



COOLANT RESERVE TANK (VANDALISM PROTECTION)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-03-80200	TANK ASS'Y,VANDALISM PROTECTION	1	J20001-
1	561-03-81911	*TANK	1	J20001-
2	208-04-19130	*ELBOW	2	J20001-
3	561-03-61940	*TUBE	1	J20001-
4	208-04-19160	*BALL	1	J20001-
5	07093-20000	*CAP	1	J20001-
6	01010-81225	*BOLT	4	J20001-
7	01643-31232	WASHER	4	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up


UNDER MIRROR

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-54-80A01	UNDER MIRROR ASS'Y	2	J20001-
1	23W-P86-2890	*MIRROR	2	J20001-
2	561-54-81871	*STAY	2	J20001-
3	07283-32236	CLIP	4	J20001-
4	07283-52232	SEAT	4	J20001-
5	01597-01009	NUT	8	J20001-
6	01643-31032	WASHER	8	J20001-



SIDE MIRROR


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-54-80900	MIRROR & RAIL ASS'Y	1	J20001-
1	561-54-87120	*STAY	1	J20001-
2	569-54-87140	*COVER	1	J20001-
3	569-54-87150	*STAY	1	J20001-
4	01010-81020	*BOLT	2	J20001-
5	01643-31032	*WASHER	2	J20001-
6	01580-11613	*NUT	1	J20001-
7	01643-31645	*WASHER	2	J20001-
8	56B-54-17311	*MIRROR	1	J20001-
9	561-54-67131	*STAY	1	J20001-
10	01643-31032	*WASHER	1	J20001-
11	01010-81640	*OLT	1	J20001-
12	01643-31645	*WASHER	1	J20001-
13	01010-81035	*BOLT	1	J20001-
14	07283-33442	*CLIP	4	J20001-
15	01643-31032	*WASHER	8	J20001-
16	01597-01009	*NUT	8	J20001-



SIDE MIRROR (WITH ADDITIONAL SIDE MIRROR)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-54-80900	MIRROR & RAIL ASS'Y	2	J20001-
1	561-54-87120	*STAY	2	J20001-
2	569-54-87140	*COVER	2	J20001-
3	569-54-87150	*STAY	2	J20001-
4	01010-81020	*BOLT	4	J20001-
5	01643-31032	*WASHER	4	J20001-
6	01580-11613	*NUT	2	J20001-
7	01643-31645	*WASHER	4	J20001-
8	56B-54-17311	*MIRROR	2	J20001-
9	561-54-67131	*STAY	2	J20001-
10	01643-31032	*WASHER	2	J20001-
11	01010-81640	*BOLT	2	J20001-
12	01643-31645	*WASHER	2	J20001-
13	01010-81035	*BOLT	2	J20001-
14	07283-33442	*CLIP	4	J20001-
15	01643-31032	*WASHER	8	J20001-
16	01597-01009	*NUT	8	J20001-


GUARD



RADIATOR GUARD

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-54-81112	GUARD	1	J20001-
2	01010-81640	BOLT	4	J20001-
3	01643-31645	WASHER	4	J20001-
4	561-54-81142	SHIM, 1.0MM	16	J20001-
5	01010-81230	BOLT	3	J20001-
6	01643-31232	WASHER	3	J20001-
7	09415-03614	CAP	3	J20001-
8	561-54-81150	COVER	1	J20001-
9	01010-81020	BOLT	4	J20001-
10	01643-31032	WASHER	4	J20001-
11	09415-02512	CAP	4	J20001-
12	561-54-81763	GUARD	1	J20001-
13	01010-81230	BOLT	8	J20001-
14	01643-31232	WASHER	8	J20001-
15	561-54-86890	PLATE	1	J20001-
16	561-54-86881	PLATE	1	J20001-
17	01010-81025	BOLT	6	J20001-
18	01643-31032	WASHER	6	J20001-
19	561-54-81121	GRILLE	1	J20001-
20	01010-81230	BOLT	8	J20001-
21	01643-31232	WASHER	8	J20001-
22	09415-03614	CAP	2	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up

HOOD


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-54-80701	HOOD ASS'Y	1	J20001-
1	561-54-81212	.HOOD	1	J20001-
2	08037-03614	.GROMMET	1	J20001-
3	08037-05016	.GROMMET	1	J20001-
4	561-54-81221	.COVER	1	J20001-
5	01010-81025	.BOLT	6	J20001-
6	01643-31032	.WASHER	6	J20001-
7	569-54-81251	.STAY	1	J20001-
8	01010-80820	.BOLT	2	J20001-
9	01643-30823	.WASHER	2	J20001-
10	207-57-11260	.WASHER	2	J20001-
11	23S-54-27190	.SEAL	1	J20001-
12	561-46-81681	STAY	1	J20001-
13	01643-31645	WASHER	12	J20001-
14	01010-81650	BOLT	12	J20001-
15	561-54-86951	SHIM, 1.0MM	6	J20001-
16	01010-81225	BOLT	5	J20001-
17	01643-31232	WASHER	5	J20001-
18	09415-03614	CAP	5	J20001-
19	561-54-61290	SEAL	1	J20001-
20	561-54-81270	SEAL	1	J20001-



ENGINE SIDE COVER (R.H.)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-89-85121	COVER,(R.H.)	1	J20001-
2	01010-81225	BOLT	5	J20001-
3	01643-31232	WASHER	5	J20001-
4	561-89-85180	COVER	1	J20001-
5	01010-81225	BOLT	2	J20001-
6	01643-31232	WASHER	2	J20001-
7	561-89-84420	COVER,(R.H.)	1	J20001-
8	01010-81225	BOLT	3	J20001-
9	01643-31232	WASHER	3	J20001-
10	419-43-17920	WASHER	2	J20001-
11	561-89-85141	COVER,(R.H.)	1	J20001-
12	01010-81225	BOLT	4	J20001-
13	01643-31232	WASHER	4	J20001-
14	419-43-17920	WASHER	4	J20001-
15	01010-81225	BOLT	2	J20001-
16	01643-31232	WASHER	2	J20001-
17	561-89-84401	COVER,(R.H.)	1	J20001-
18	01010-81225	BOLT	7	J20001-
19	01643-31232	WASHER	7	J20001-
20	419-43-17920	WASHER	3	J20001-
21	561-89-85190	COVER,(R.H.)	1	J20001-
22	01010-81225	BOLT	6	J20001-
23	01643-31232	WASHER	6	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up


ENGINE SIDE COVER (L.H)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-89-85110	COVER,(L.H.)	1	J20001-
2	01010-81225	BOLT	5	J20001-
3	01643-31232	WASHER	5	J20001-
4	561-89-83632	COVER,(L.H.)	1	J20001-
5	01010-81225	BOLT	3	J20001-
6	01643-31232	WASHER	3	J20001-
7	419-43-17920	WASHER	2	J20001-
8	561-89-85132	COVER,(L.H.)	1	J20001-
9	01010-81225	BOLT	5	J20001-
10	01643-31232	WASHER	5	J20001-
11	419-43-17920	WASHER	5	J20001-
12	01010-81225	BOLT	2	J20001-
13	01643-31232	WASHER	2	J20001-
14	561-89-85180	COVER	1	J20001-
15	01010-81225	BOLT	2	J20001-
16	01643-31232	WASHER	2	J20001-
17	561-89-83301	COVER,(L.H.)	1	J20001-
18	01010-81225	BOLT	10	J20001-
19	01643-31232	WASHER	10	J20001-
20	419-43-17920	WASHER	6	J20001-



FIRE PROTECTION (ENGINE REAR COVER)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	562-03-12830	BRACKET	1	J20001-
2	01010-81225	BOLT	4	J20001-
3	01643-31232	WASHER	4	J20001-
4	561-89-86270	BRACKET	1	J20001-
5	561-89-82560	COVER	1	J20001-
6	01010-81225	BOLT	4	J20001-
7	01643-31232	WASHER	4	J20001-
8	561-89-82550	COVER	1	J20001-
9	419-43-17920	WASHER	4	J20001-
10	01010-81225	BOLT	9	J20001-
11	01643-31232	WASHER	9	J20001-
12	561-89-82511	COVER	1	J20001-
13	01010-81230	BOLT	4	J20001-
14	01643-31232	WASHER	4	J20001-
15	01010-81225	BOLT	4	J20001-
16	01643-31232	WASHER	4	J20001-
17	561-89-86170	BRACKET	1	J20001-
18	01010-81225	BOLT	2	J20001-
19	01643-31232	WASHER	2	J20001-
20	561-84-84431	COVER	1	J20001-
21	07283-32244	CLIP	2	J20001-
22	01643-31032	WASHER	4	J20001-
23	01597-01009	NUT	4	J20001-
24	561-84-84521	COVER	1	J20001-
25	01010-81225	BOLT	2	J20001-
26	01643-31232	WASHER	2	J20001-
27	561-89-86241	BRACKET	1	J20001-
28	01010-81025	BOLT	3	J20001-
29	01643-31032	WASHER	3	J20001-
30	561-89-86232	RUBBER	1	J20001-
31	561-89-86251	PLATE	1	J20001-
32	561-89-86262	BRACKET	2	J20001-
33	424-54-14220	WASHER	2	J20001-
34	01010-81025	BOLT	2	J20001-
35	01643-31032	WASHER	2	J20001-
36	01010-81025	BOLT	2	J20001-
37	01643-31032	WASHER	2	J20001-
38	01010-81025	BOLT	3	J20001-
39	01643-31032	WASHER	3	J20001-



FIRE PROTECTION (EXHAUST COVER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-89-86110	COVER	1	J20001-
2	01010-81230	BOLT	2	J20001-
3	01643-31232	WASHER	2	J20001-
4	01010-81225	BOLT	2	J20001-
5	01643-31232	WASHER	2	J20001-
6	561-89-86120	COVER	1	J20001-
7	01010-81230	BOLT	4	J20001-
8	01643-31232	WASHER	4	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up
FIRE PROTECTION (STEERING PIPING
PROTECTION)(WITHOUT SIDE COVER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-89-86181	COVER	1	J20001-
2	01010-81235	BOLT	2	J20001-
3	01643-31232	WASHER	2	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up

FENDER (L.H.)


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-54-81511	FENDER,(L.H.)	1	J20001-
2	01010-81230	BOLT	6	J20001-
3	01643-31232	WASHER	6	J20001-
4	09415-05016	CAP	1	J20001-
5	09415-02512	CAP	3	J20001-
6	561-54-87410	GUARD	1	J20001-
7	561-54-61541	PLATE	1	J20001-
8	561-54-61670	PLATE	1	J20001-
9	01010-81235	BOLT	9	J20001-
10	01643-31232	WASHER	9	J20001-



FENDER (R.H.)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-54-87420	GUARD	1	J20001-
2	561-54-61541	PLATE	1	J20001-
3	561-54-61670	PLATE	1	J20001-
4	561-54-87171	FENDER,(R.H.)	1	J20001-
5	01010-81230	BOLT	6	J20001-
6	01643-31232	WASHER	6	J20001-
7	01010-81235	BOLT	9	J20001-
8	01643-31232	WASHER	9	J20001-
9	09415-02512	CAP	1	J20001-
10	09415-05016	CAP	1	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up

ENGINE UNDER GUARD

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-54-86111	GUARD	1	J20001-
2	01010-82040	BOLT	3	J20001-
3	01643-32060	WASHER	3	J20001-
4	561-54-66250	COLLAR	2	J20001-
5	01010-82080	BOLT	2	J20001-
6	01580-12016	NUT	2	J20001-
7	01643-32060	WASHER	4	J20001-
8	04434-52310	CLIP	2	J20001-
9	01010-81016	BOLT	1	J20001-
10	01643-31032	WASHER	1	J20001-
11	01010-81025	BOLT	1	J20001-
12	01643-31032	WASHER	1	J20001-




TRANSMISSION UNDER GUARD

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-54-86201	GUARD ASS'Y	1	J20001-
1	561-54-86211	.BRACKET	1	J20001-
2	561-54-86220	.PLATE	6	J20001-
3	561-54-86230	.BRACKET	1	J20001-
4	01010-81230	.BOLT	12	J20001-
5	01643-31232	.WASHER	12	J20001-
6	561-54-66250	COLLAR	2	J20001-
7	01010-82080	BOLT	2	J20001-
8	01580-12016	NUT	2	J20001-
9	01643-32060	WASHER	4	J20001-
10	01010-82055	BOLT	2	J20001-
11	01643-32060	WASHER	2	J20001-

RIM AND TIRE

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

RIM (FRONT WHEEL)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-30-81101	RIM A.	2	J20001-
1	561-30-81111	*RIM BASE	2	J20001-
2	561-30-83330	*RING,SIDE	4	J20001-
3	561-30-11520	*BAND	2	J20001-
4	561-30-11540	*LOCK	2	J20001-
	561-30-81601	VALVE	2	J20001-
5	561-30-81611	*VALVE STEM KIT	2	J20001-
6	09281-00041	*CORE	2	J20001-
7	09282-00022	*CAP	2	J20001-
8	09283-00000	*SEAT	2	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

RIM (REAR WHEEL)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-30-81101	RIM A.	4	J20001-
1	561-30-81111	*RIM BASE	4	J20001-
2	561-30-83330	*RING	8	J20001-
3	561-30-11520	*BAND	4	J20001-
4	561-30-11540	*LOCK	4	J20001-
	09280-10020	VALVE ASS'Y	2	J20001-
5	09280-10130	*STEM	2	J20001-
6	09281-00041	*CORE	2	J20001-
7	09282-00022	*CAP	2	J20001-
8	09283-00000	*SEAT	2	J20001-
	561-30-81601	VALVE	2	J20001-
9	561-30-81611	*VALVE STEM KIT	2	J20001-
10	09281-00041	*CORE	2	J20001-
11	09282-00022	*CAP	2	J20001-
12	09283-00000	*SEAT	2	J20001-
13	561-30-81120	EXTENSION	2	J20001-
14	04434-51912	CLIP	4	J20001-
15	07095-20213	CUSHION	4	J20001-
16	01010-81220	BOLT	4	J20001-
17	01643-31232	WASHER	4	J20001-
18	01640-21223	WASHER	4	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

TIRE (27.00,R49,E4, BELSHINA)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	BELSHINA 561-81-31910	TIRE, 27.00, R49,E4,	6	J20001-
2	561-30-11250	O-RING	6	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

TIRE (27.00R49,E4,GP)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	BRIDGESTONE			
	561-30-19620	TIRE, VMTS	6	J20001-
	561-30-19690	TIRE, VMTP	6	J20001-
2	561-30-11250	O-RING	6	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

REAR SUSPENSION

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-50-82001	REAR SUSPENSION A.	2	J20001-
1	561-50-82110	*CYLINDER	2	J20001-
2	561-50-82130	*ROD	2	J20001-
3	561-50-82150	*RETAINER	2	J20001-
4	561-50-82140	*FLANGE	2	J20001-
5	561-50-82330	*BUSHING	2	J20001-
6	01011-81425	*BOLT	32	J20001-
7	01643-31445	*WASHER	32	J20001-
8	07000-15240	*O-RING	4	J20001-
9	07001-05240	*RING	2	J20001-
10	568-50-12180	*RING	2	J20001-
11	561-50-82360	*U-PACKING	2	J20001-
12	561-50-82380	*SEAL	2	J20001-
13	707-51-21650	*RING	2	J20001-
	566-50-11301	*VALVE ASS'Y	2	J20001-
14	566-50-11320	**VALVE	2	J20001-
15	281-50-11721	**CORE	2	J20001-
16	566-50-11340	**CAP	2	J20001-
17	07000-11006	**O-RING	2	J20001-
18	566-50-11350	**PACKING	4	J20001-
19	561-50-82410	*GUARD	2	J20001-
20	566-09-6A120	*CLAMP	2	J20001-
21	561-92-62331	*GUARD	2	J20001-
22	01010-81020	*BOLT	4	J20001-
23	01643-31032	*WASHER	4	J20001-
24	561-50-82340	*BUSHING	2	J20001-
25	561-50-82310	*BUSHING	4	J20001-
26	04071-00140	*RING	8	J20001-
27	07000-12090	*O-RING	8	J20001-
	561-86-67700	*VALVE ASS'Y	2	J20001-
28	561-86-67710	**VALVE	2	J20001-
29	281-50-11721	**CORE	2	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

REAR SUSPENSION PRESSURE SENSOR

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	7861-93-1620	SENSOR	2	J20001-
2	04434-51010	CLIP	2	J20001-

BODY

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

BODY

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-74-81102	BODY ASS'Y	1	J20001-
2	561-83-69411	PLATE	1	J20001-
3	561-83-69450	PLATE	2	J20001-
4	561-83-69440	PLATE	1	J20001-
5	561-83-69462	PLATE	4	J20001-
6	561-83-89490	PLATE	1	J20001-
7	581-74-11630	TUBE	5	J20001-
8	561-83-69481	PLATE	1	J20001-
9	561-83-69521	PLATE	2	J20001-
10	01011-82010	BOLT	5	J20001-
11	01643-32060	WASHER	5	J20001-
12	01580-12016	NUT	5	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

BODY (WITH PLATFORM GUARD)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-74-81102	BODY ASS'Y	1	J20001-
2	561-74-81430	GUARD	1	J20001-
3	561-83-69411	PLATE	1	J20001-
4	561-83-69450	PLATE	2	J20001-
5	561-83-69440	PLATE	1	J20001-
6	561-83-69462	PLATE	4	J20001-
7	561-83-89490	PLATE	1	J20001-
8	581-74-11630	TUBE	5	J20001-
9	561-83-69481	PLATE	1	J20001-
10	561-83-69521	PLATE	2	J20001-
11	01011-82010	BOLT	5	J20001-
12	01643-32060	WASHER	5	J20001-
13	01580-12016	NUT	5	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

BODY (WITH BODY LINIER)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-74-X5390	BODY SUB ASS'Y	1	J20001-
	561-74-81102	*BODY ASS'Y	1	J20001-
	561-83-81200	*BODY LINER	1	J20001-
2	561-83-81J50	**PLATE (WELDED)	2	J20001-
3	561-83-81J60	*PLATE (WELDED)	2	J20001-
4	561-83-81J70	*PLATE (WELDED)	2	J20001-
5	561-83-81J80	*PLATE (WELDED)	2	J20001-
6	561-83-81E60	*PLATE (WELDED)	2	J20001-
7	561-83-81E70	*PLATE (WELDED)	2	J20001-
8	561-83-81E90	*PLATE (WELDED)	1	J20001-
9	561-83-81E80	*PLATE (WELDED)	2	J20001-
10	561-83-81J40	*PLATE (WELDED)	1	J20001-
11	561-83-81E30	*PLATE (WELDED)	2	J20001-
12	561-83-81G80	*PLATE (WELDED)	2	J20001-
13	561-83-81F40	*PLATE (WELDED)	1	J20001-
14	561-83-81F50	*PLATE (WELDED)	1	J20001-
15	561-83-81E40	*PLATE (WELDED)	2	J20001-
16	561-83-81E50	*PLATE (WELDED)	2	J20001-
17	561-83-81G10	*PLATE (WELDED)	2	J20001-
18	561-83-81K10	*PLATE (WELDED)	2	J20001-
19	561-83-81G50	*PLATE (WELDED)	1	J20001-
20	561-83-81G60	*PLATE (WELDED)	1	J20001-
21	561-83-81G20	*PLATE (WELDED)	2	J20001-
22	561-83-81G30	*PLATE (WELDED)	3	J20001-
23	561-83-81G40	*PLATE (WELDED)	3	J20001-
24	561-83-6AU10	*BAR (WELDED)	4	J20001-
25	561-83-61G22	*PLATE (WELDED)	3	J20001-
26	561-83-81Y10	*PLATE (WELDED)	2	J20001-
27	561-83-81Y20	*PLATE (WELDED)	2	J20001-
28	561-83-81F20	*PLATE (WELDED)	1	J20001-
29	561-83-81F30	*PLATE (WELDED)	1	J20001-
30	561-83-69411	PLATE	1	J20001-
31	561-83-69450	PLATE	2	J20001-
32	561-83-69440	PLATE	1	J20001-
33	561-83-69462	PLATE	4	J20001-
34	561-83-89490	PLATE	1	J20001-
35	581-74-11630	TUBE	5	J20001-
36	561-83-69481	PLATE	1	J20001-
37	561-83-69521	PLATE	2	J20001-
38	01011-82010	BOLT	5	J20001-
39	01643-32060	WASHER	5	J20001-
40	01580-12016	NUT	5	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

BODY (WITH 300MM SPILL GUARD)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-74-81102	BODY ASS'Y	1	J20001-
	561-83-84100	*SPILL GUARD	1	J20001-
2	561-83-84110	*SPILL GUARD	1	J20001-
3	561-83-69411	PLATE	1	J20001-
4	561-83-69450	PLATE	2	J20001-
5	561-83-69440	PLATE	1	J20001-
6	561-83-69462	PLATE	4	J20001-
7	561-83-89490	PLATE	1	J20001-
8	581-74-11630	TUBE	5	J20001-
9	561-83-69481	PLATE	1	J20001-
10	561-83-69521	PLATE	2	J20001-
11	01011-82010	BOLT	5	J20001-
12	01643-32060	WASHER	5	J20001-
13	01580-12016	NUT	5	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

BODY ACCESSORY

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-74-81620	PLATE	2	J20001-
2	581-74-11360	PIN	2	J20001-
3	04050-18055	PIN	2	J20001-
4	04205-11650	PIN	2	J20001-
5	04052-11664	PIN	2	J20001-
6	561-74-61631	SUPPORT,(L.H.)	1	J20001-
7	561-74-61641	SUPPORT,(R.H.)	1	J20001-
8	01010-81225	BOLT	14	J20001-
9	01643-31232	WASHER	14	J20001-
10	561-46-8A890	BRACKET,(L.H.)	1	J20001-
11	561-46-8A870	BRACKET,(R.H.)	1	J20001-
12	561-74-61521	PAD	2	J20001-
13	561-74-61540	SHIM, 1.0MM	18	J20001-
14	01010-81660	BOLT	8	J20001-
15	01643-31645	WASHER	8	J20001-
16	561-74-61511	PAD	8	J20001-
17	561-74-61531	SHIM, 1.0MM	70	J20001-
18	01010-81645	BOLT	32	J20001-
19	01643-31645	WASHER	32	J20001-
20	561-74-61740	PIN	2	J20001-
21	01010-81635	BOLT	2	J20001-
22	421-70-11280	WASHER	2	J20001-
23	01643-31645	WASHER	2	J20001-
24	568-74-12650	SPACER, 6.0MM	2	J20001-
25	568-74-11421	SPACER, 2.3MM	8	J20001-
26	568-74-12660	SPACER, 1.0MM	8	J20001-
27	568-74-12670	SPACER, 4.5MM	2	J20001-
28	561-52-61211	PIN	2	J20001-
29	01010-81430	BOLT	2	J20001-
30	569-40-61710	WASHER	2	J20001-
31	561-86-68141	PIN	2	J20001-
32	561-74-61661	GUARD	2	J20001-
33	561-74-61651	PLATE	2	J20001-
34	01010-81230	BOLT	16	J20001-
35	01643-31232	WASHER	16	J20001-
36	561-74-81470	COVER	1	J20001-
37	01010-81220	BOLT	6	J20001-
38	01643-31232	WASHER	6	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

HOIST CYLINDER

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	(707-09-07090)	CYLINDER ASS'Y	2	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

EXHAUST BOX

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-74-80100	EXHAUST BOX ASS'Y	1	J20001-
1	561-02-61150	FLANGE	1	J20001-
2	582-02-11210	RING	1	J20001-
3	561-02-81170	TUBE	1	J20001-
4	581-02-31360	SPRING	4	J20001-
5	01580-11411	NUT	8	J20001-

MARKS AND PLATES

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

NAME PLATE UNIT (1/2)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-93-41160	PLATE,ARROW	1	J20001-
2	569-54-64490	RUBBER	1	J20001-
3	569-54-64470	RUBBER	2	J20001-
4	568-54-12821	RUBBER	5	J20001-
5	568-54-12841	RUBBER	2	J20001-
6	569-54-64460	RUBBER	1	J20001-
7	561-93-81370	MARK,HD785	1	J20001-
8	561-93-81320	MARK,STRIPE	2	J20001-
9	561-93-81310	MARK,HD785	1	J20001-
10	561-93-81360	MARK,HD785	1	J20001-
11	569-93-81330	PLATE, MARK,KOMATSU	1	J20001-
12	569-93-81980	PLATE	1	J20001-
13	561-93-81530	PLATE	1	J20001-
14	09960-01201	MARK,HANDLING	2	J20001-
15	09960-00601	MARK,HANDLING	2	J20001-
16	09960-00602	MARK,HANDLING	2	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

NAME PLATE UNIT (2/2) (ENGLISH)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	20Y-00-J1160	PLATE, NAME,(LIMITED SUPPLY)	1	J20001-
	04418-13060	SCREW	4	J20001-
2	561-93-81710	OIL CHART	1	J20001-
3	569-93-81720	PLATE, SAFETY,DUMP CONTROL ETC.	1	J20001-
4	561-93-61380	PLATE, OPERATING,STARTING SWITCH	1	J20001-
5	09669-0000E	PLATE, CAUTION	1	J20001-
6	09637-30163	PLATE, INSTRUCTION,AIR CLEANER	1	J20001-
7	567-93-43650	PLATE, CAUTION,COOLING WATER LEVEL	1	J20001-
8	09653-A0641	PLATE, SAFETY,CAP OF HYDRAULIC TANK ...	2	J20001-
9	561-93-61943	SAFETY PLATE,TIRE AIR PRESSURE	1	J20001-
10	09659-A0881	PLATE, SAFETY,EXPLOSION HAZARD	2	J20001-
11	567-93-72790	PLATE, OPERATING,DRIVING OVER ALONG-DISTANCE	1	J20001-
12	569-93-82450	PLATE, SAFETY,EMERGENCY STEERING ETC.	1	J20001-
13	569-93-88761	PLATE,RELAY SWITCH.....	1	J20001-
14	569-93-88772	PLATE,FUSE TABLE	1	J20001-
15	561-93-63180	PLATE,COOLANT LEVEL	1	J20001-
16	561-93-61370	PLATE, SAFETY,STEERING AND HOIST OIL ...	1	J20001-
17	09963-A1640	TAG,DO NOT OPERATE	1	J20001-
18	568-54-12821	RUBBER,ANTI SLIP	1	J20001-
19	09808-A1681	PLATE, SAFETY,BATTERY CABLE	1	J20001-
20	561-93-83960	PLATE,REAR SUSPENSION	2	J20001-
21	09817-A1103	PLATE, SAFETY,HIGH TEMP.....	2	J20001-
22	09667-A0880	PLATE, SAFETY,WHILE RUNNING	3	J20001-
23	56B-93-12170	PLATE,DUMP CONTROL	1	J20001-
24	09620-A2000	PLATE,ROPS/FOPS	1	J20001-
	205-00-72430	RIVET	4	J20001-
25	6217-71-6470	PLATE,FUEL FILTER	2	J20001-
26	566-88-6H311	PLATE,RETARDER	1	J20001-
27	09659-A057B	PLATE, SAFETY,EXPLOSION HAZARD	4	J20001-
28	561-93-83240	PLATE,LUBRICATION	1	J20001-
29	561-93-83460	PLATE,RETARDING GUIDELINES	1	J20001-
30	561-93-83790	PLATE	1	J20001-
31	561-93-83280	PLATE	1	J20001-
32	569-93-81920	SHEET	1	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

NAME PLATE UNIT (2/2) (INDONESIAN)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	20Y-00-J1160	PLATE, NAME,(LIMITED SUPPLY)	1	J20001-
	04418-13060	SCREW	4	J20001-
2	561-93-88710	OIL CHART	1	J20001-
3	569-93-81670	PLATE, SAFETY,DUMP CONTROL ETC.	1	J20001-
4	561-93-61380	PLATE, OPERATING,STARTING SWITCH	1	J20001-
5	09669-0000E	PLATE, CAUTION	1	J20001-
6	09637-05163	PLATE, INSTRUCTION,AIR CLEANER	1	J20001-
7	567-93-18331	PLATE, CAUTION,COOLING WATER LEVEL	1	J20001-
8	09653-A0641	PLATE, SAFETY,CAP OF HYDRAULIC TANK ...	2	J20001-
9	561-93-68423	SAFETY PLATE,TIRE AIR PRESSURE	1	J20001-
10	09659-A0881	PLATE, SAFETY,EXPLOSION HAZARD	2	J20001-
11	566-93-18792	PLATE, OPERATING,DRIVING OVER ALONG-DISTANCE	1	J20001-
12	56B-93-18181	PLATE, SAFETY,EMERGENCY STEERING ETC.	1	J20001-
13	561-93-88481	PLATE,RELAY SWITCH	1	J20001-
14	561-93-88351	PLATE,FUSE TABLE	1	J20001-
15	561-93-68182	PLATE,COOLANT LEVEL	1	J20001-
16	569-93-68371	PLATE, NAME,STEERING AND HOIST OIL	1	J20001-
17	09963-A1640	TAG,DO NOT OPERATE	1	J20001-
18	568-54-12821	RUBBER,ANTI SLIP	1	J20001-
19	09808-A1681	PLATE, SAFETY,BATTERY CABLE	1	J20001-
20	561-93-88960	PLATE,REAR SUSPENSION	2	J20001-
21	09817-A1103	PLATE, SAFETY,HIGH TEMP	2	J20001-
22	09667-A0880	PLATE, SAFETY,WHILE RUNNING	3	J20001-
23	569-93-82180	PLATE, SAFETY,DUMP CONTROL	1	J20001-
24	09620-A2000	PLATE,ROPS/FOPS	1	J20001-
25	09620-A2050	PLATE,ROPS/FOPS	1	J20001-
	205-00-72430	RIVET	4	J20001-
26	6217-71-6530	PLATE,FUEL FILTER	2	J20001-
27	566-93-68310	PLATE,RETARDER	1	J20001-
28	09659-A057B	PLATE, SAFETY,EXPLOSION HAZARD	4	J20001-
29	561-93-88240	PLATE,LUBRICATION	1	J20001-
30	561-93-88460	PLATE,RETARDING GUIDELINES	1	J20001-
31	561-93-88791	PLATE,POWER SUPPLY	1	J20001-
32	561-93-88280	PLATE, NAME,PANEL AND CONSOLE	1	J20001-
33	569-93-89950	PLATE	1	J20001-

TOOL

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

SPARE PARTS

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	600-211-1340	CARTRIDGE	4	J20001-
2	07063-51210	ELEMENT	3	J20001-
3	07000-F5190	O-RING	3	J20001-
4	600-311-3550	CARTRIDGE (1-5/8)	2	J20001-
	600-311-4500	FILTER ASS'Y	2	J20001-
5	600-311-4510	*CARTRIDGE (1-1/4)	1	J20001-
5A	600-311-3220	*CAP	1	J20001-
5B	600-311-3230	*SEAL	1	J20001-
6	04120-21951	V-BELT	1	J20001-
7	6215-61-3690	V-BELT SET	1	J20001-
	561-30-81601	VALVE	4	J20001-
8	561-30-81611	*VALVE STEM KIT	4	J20001-
9	09281-00041	*CORE	4	J20001-
10	09282-00022	*CAP	4	J20001-
11	09283-00000	*SEAT	4	J20001-
	09280-10020	VALVE ASS'Y	2	J20001-
12	09280-10130	*STEM	2	J20001-
13	09281-00041	*CORE	2	J20001-
14	09282-00022	*CAP	2	J20001-
15	09283-00000	*SEAT, VALVE	2	J20001-
16	561-30-81120	EXTENSION	2	J20001-
17	6217-11-8830	GASKET	12	J20001-
18	569-16-81160	ELEMENT	4	J20001-
19	07000-12125	O-RING	4	J20001-
20	07000-12014	O-RING	4	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

CAP AND OVERAL

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	09980-92550	CAP AND OVERALL KIT	1	J20001-
1	09980-10550	*OVERALL	1	J20001-
2	09982-20057	*CAP	1	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up
GENERAL TOOL UNIT (HOSE)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	56B-98-21110	HOSE ASS'Y	1	J20001-
	6215-21-5610	.NIPPLE	1	J20001-
	6245-61-6670	.CLIP	1	J20001-
	07286-02680	.HOSE	1	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

GENERAL TOOL UNIT

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	56B-98-21110	HOSE ASS'Y	1	J20001-
	6215-21-5610	.NIPPLE	1	J20001-
	6245-61-6670	.CLIP	1	J20001-
	07286-02680	.HOSE	1	J20001-
2	07950-90403	CARTRIDGE	1	J20001-
3	07951-31400	NOZZLE	1	J20001-
	07952-80003	GREASE PUMP ASS'Y	1	J20001-
4	07950-10450	.PUMP	1	J20001-
5	07951-41043	.NOZZLE	1	J20001-
6	09019-28035	WRENCH	1	J20001-
7	09033-00190	DRIVER	1	J20001-
8	09036-00150	PLIERS	1	J20001-
9	09039-00150	HAMMER	1	J20001-
10	09014-10200	WRENCH	1	J20001-
11	09054-00009	GAUGE	1	J20001-
12	09055-10390	BAR	1	J20001-
13	09000-30006	WRENCH SET	1	J20001-
14	09020-10284	SOCKET WRENCH SET	1	J20001-
15	09023-00380	HANDLE	1	J20001-
16	09289-10000	GAUGE	1	J20001-
17	09056-05513	BAG	1	J20001-
18	568-35-11210	HOSE	1	J20001-
19	582-98-11410	SOCKET	1	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

TOOL BOX UNIT

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-98-86110	TOOL BOX ASS'Y	1	J20001-
1	561-98-86120	.COVER	1	J20001-
2	417-54-21460	.SPRING	2	J20001-
3	01640-20816	.WASHER	2	J20001-
4	01010-80816	.BOLT	2	J20001-
5	01541-21260	.NUT	1	J20001-
6	01643-31232	.WASHER	1	J20001-
7	01010-81225	BOLT	4	J20001-
8	01643-31232	WASHER	4	J20001-

MISCELLANEOUS

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

AIR CONDITIONER RELATED PARTS (1/3)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-07-83413	BRACKET	1	J20001-
1A	6215-81-6150	PIN	1	J20001-
2	427-T46-1460	BOLT	1	J20001-
3	01643-31232	WASHER	1	J20001-
4	427-T46-1340	NUT	1	J20001-
5	04250-81683	END	1	J20001-
6	04254-11645	SPACER	2	J20001-
7	195-40-31530	SHIM, 0.5MM	3	J20001-
8	01018-21665	BOLT	1	J20001-
9	561-07-63420	ROD	1	J20001-
10	01582-11613	NUT	1	J20001-
11	427-T46-1420	BLOCK	1	J20001-
12	419-43-17590	BUSHING	1	J20001-
13	427-T46-1430	SPACER	2	J20001-
14	700-84-14790	SHIM 0.8MM	2	J20001-
15	01018-21465	BOLT	1	J20001-
16	01580-11613	NUT	2	J20001-
	561-07-82200	COMPRESSOR KIT	1	J20001-
17	423-S62-4330	.COMPRESSOR ASS'Y	1	J20001-
	08192-22830	..CONNECTOR	1	J20001-
18	561-07-81331	.HOSE	1	J20001-
19	561-07-81342	.HOSE	1	J20001-
20	01010-80895	BOLT	4	J20001-
21	01643-30823	WASHER	4	J20001-
22	08193-21012	CLIP	1	J20001-
23	01010-81016	BOLT	1	J20001-
24	01643-31032	WASHER	1	J20001-
25	08034-20834	BAND	1	J20001-
26	04120-21748	V-BELT	1	J20001-
27	09482-10000	VALVE	2	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

AIR CONDITIONER RELATED PARTS (2/3)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	561-07-82300	RECEIVER KIT	1	J20001-
1	423-07-31571	.RECEIVER DRYER	1	J20001-
2	23S-56-53610	.BRACKET	1	J20001-
3	561-07-81351	.HOSE	1	J20001-
4	561-07-81361	.HOSE	1	J20001-
5	01010-80816	BOLT	2	J20001-
6	01643-30823	WASHER	2	J20001-
7	01010-80616	BOLT	2	J20001-
8	01643-30623	WASHER	2	J20001-
9	561-07-81411	BRACKET	1	J20001-
10	01010-81225	BOLT	2	J20001-
11	01643-31232	WASHER	2	J20001-
12	01010-80830	BOLT	1	J20001-
13	01643-30823	WASHER	1	J20001-
14	01010-80830	BOLT	1	J20001-
15	01643-30823	WASHER	1	J20001-
16	01010-80630	BOLT	1	J20001-
17	01643-30623	WASHER	1	J20001-
18	01010-80630	BOLT	1	J20001-
19	01643-30623	WASHER	1	J20001-
20	09483-10518	HOSE	1	J20001-
21	09479-02400	CLAMP	2	J20001-
22	09483-10536	HOSE	1	J20001-
23	09479-02400	CLAMP	2	J20001-
24	361-62-21111	BRACKET	1	J20001-
25	01010-81020	BOLT	1	J20001-
26	01643-31032	WASHER	1	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

AIR CONDITIONER RELATED PARTS (3/3)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	56D-03-11941	BRACKET	1	J20001-
2	01010-81020	BOLT	1	J20001-
3	01643-31032	WASHER	1	J20001-
4	281-70-16190	PLATE	3	J20001-
5	07283-36155	CLIP	3	J20001-
6	01643-31032	WASHER	6	J20001-
7	01597-01009	NUT	6	J20001-
8	04434-52110	CLIP	8	J20001-
9	04434-52712	CLIP	1	J20001-
10	04434-53212	CLIP	5	J20001-
11	04434-52711	CLIP	7	J20001-
12	04434-53211	CLIP	9	J20001-
13	07095-20314	CUSHION	8	J20001-
14	07095-20419	CUSHION	8	J20001-
15	07095-20523	CUSHION	14	J20001-
16	195-979-5190	COLLAR	2	J20001-
17	01010-81016	BOLT	4	J20001-
18	01643-31032	WASHER	4	J20001-
19	01010-81020	BOLT	3	J20001-
20	01643-31032	WASHER	3	J20001-
21	01010-81075	BOLT	2	J20001-
22	01643-31032	WASHER	2	J20001-
23	01010-81220	BOLT	2	J20001-
24	01643-31232	WASHER	2	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

FIRE EXTINGUISHER (ENGLISH)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	09495-40000	FIRE EXTINGUISHER	1	J20001-
2	01435-00616	BOLT	4	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

CAP LOCK (VANDALISM PROTECTION)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	600-031-1040	CAP ASS'Y	1	J20001-
2	09460-00000	LOCK	1	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

FIRE EXTINGUISHER (INDONESIAN)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	09495-31000	FIRE EXTINGUISHER	1	J20001-
2	01435-00616	BOLT	4	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

FRONT PROPELLER SHAFT GUARD

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-89-82113	BRACKET	1	J20001-
2	561-89-82141	BRACKET	1	J20001-
3	01010-81650	BOLT	8	J20001-
4	01643-31645	WASHER	8	J20001-
5	561-89-82122	GUARD	1	J20001-
6	561-89-82130	GUARD	1	J20001-
7	01643-31645	WASHER	4	J20001-
8	01010-81665	BOLT	4	J20001-
9	04020-00616	PIN	6	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

REAR PROPELLER SHAFT GUARD

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-89-82211	GUARD	1	J20001-
2	01010-82785	BOLT	8	J20001-
3	01643-32780	WASHER	8	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

ABS/ASR CHASSIS (STEERING SENSOR)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	569-86-6M160	BRACKET	1	J20001-
2	01010-81230	BOLT	1	J20001-
3	01643-31232	WASHER	1	J20001-
4	08193-21012	CLIP	1	J20001-
5	01010-81225	BOLT	1	J20001-
6	01643-31232	WASHER	1	J20001-
7	561-86-8K420	BRACKET	1	J20001-
8	01010-81435	BOLT	2	J20001-
9	01643-31445	WASHER	2	J20001-
10	7861-93-8710	SENSOR	1	J20001-
11	01010-81025	BOLT	3	J20001-
12	01643-31032	WASHER	3	J20001-
13	561-86-8K430	BRACKET	1	J20001-
14	04010-00310	KEY	1	J20001-
15	01010-80830	BOLT	1	J20001-
16	01643-50823	WASHER	1	J20001-
17	561-88-8K470	PLATE	1	J20001-
18	01010-81025	BOLT	2	J20001-
19	01643-31032	WASHER	2	J20001-


HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up
ABS/ASR CHASSIS (VALVE)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	(561-88-80101)	VALVE SUB ASS'Y,ASR	1	J20001-
2	01010-81230	BOLT	5	J20001-
3	01643-31232	WASHER	5	J20001-
4	04434-51510	CLIP	1	J20001-
5	02767-005A3	HOSE	1	J20001-
6	02767-005A3	HOSE	1	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

ABS/ASR CHASSIS (WIRING HARNESS)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-88-86311	WIRING HARNESS	1	J20001-
2	04434-51910	CLIP	1	J20001-
3	01010-81016	BOLT	3	J20001-
4	01643-31032	WASHER	3	J20001-
5	08193-21012	CLIP	3	J20001-
6	6166-11-5390	SPACER	1	J20001-
7	04434-51910	CLIP	11	J20001-
8	01010-81055	BOLT	1	J20001-
9	01643-31032	WASHER	1	J20001-
10	195-979-5190	COLLAR	3	J20001-
11	04434-52711	CLIP	1	J20001-
12	07095-20420	CUSHION	1	J20001-
13	01010-81075	BOLT	3	J20001-
14	01643-31032	WASHER	3	J20001-
15	120-54-42430	SPACER	3	J20001-
16	01010-81050	BOLT	3	J20001-
17	01643-31032	WASHER	3	J20001-
18	6151-81-5960	BRACKET	1	J20001-
19	01010-81025	BOLT	2	J20001-
20	01643-31032	WASHER	2	J20001-
21	04434-50810	CLIP	3	J20001-
22	01643-31032	WASHER	1	J20001-
23	01580-11008	NUT	1	J20001-
24	01010-81020	BOLT	1	J20001-
25	01643-31032	WASHER	1	J20001-
26	04434-50812	CLIP	5	J20001-
27	01010-81225	BOLT	1	J20001-
28	01643-31232	WASHER	1	J20001-
29	285-03-11140	PLATE	1	J20001-
30	07283-38973	CLIP	1	J20001-
31	01643-31232	WASHER	2	J20001-
32	01597-01211	NUT	2	J20001-
33	08034-20834	BAND	4	J20001-
34	04434-53411	CLIP	1	J20001-
35	07095-20625	CUSHION	1	J20001-
36	04434-52511	CLIP	1	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

ABS/ASR CHASSIS (AXLE SENSOR)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	04434-51512	CLIP	5	J20001-
2	01010-81016	BOLT	4	J20001-
3	01643-31032	WASHER	4	J20001-
4	08193-21012	CLIP	2	J20001-
5	01010-81016	BOLT	2	J20001-
6	01643-31032	WASHER	2	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

ABS/ASR CHASSIS (ASR VALVE) (INNER PARTS) (1/2)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(561-88-80101)	VALVE SUB ASS'Y	1	J20001-
1	561-88-86111	*BRACKET	1	J20001-
2	561-88-86122	*BRACKET	1	J20001-
3	01010-81025	*BOLT	3	J20001-
4	01643-31032	*WASHER	3	J20001-
5	561-88-86141	*BLOCK	1	J20001-
6	01010-81070	*BOLT	3	J20001-
7	01643-31032	*WASHER	3	J20001-
8	07040-12012	*PLUG	1	J20001-
9	07002-22034	*O-RING	1	J20001-
10	42C-60-18230	*VALVE	1	J20001-
	42C-60-13610	*SOLENOID ASS'Y	1	J20001-
	07000-12018	**O-RING	1	J20001-
	07000-11009	**O-RING	4	J20001-
	01252-40545	**BOLT	4	J20001-
11	418-43-37681	*SWITCH	1	J20001-
12	07002-21423	*O-RING	1	J20001-
13	08034-20834	*BAND	1	J20001-
14	02781-00422	*UNION	3	J20001-
15	02896-21012	*O-RING	3	J20001-
16	07002-22034	*O-RING	3	J20001-
17	02782-10516	*ELBOW	2	J20001-
18	02896-21015	*O-RING	2	J20001-
19	07002-22034	*O-RING	2	J20001-
20	02782-10422	*ELBOW	1	J20001-
21	02896-21012	*O-RING	1	J20001-
22	07002-22034	*O-RING	1	J20001-
23	569-43-83171	*VALVE	2	J20001-
24	01010-81095	*BOLT	4	J20001-
25	01643-31032	*WASHER	4	J20001-
26	561-43-83681	*ELBOW	2	J20001-
27	02896-21015	*O-RING	2	J20001-
28	07002-22034	*O-RING	2	J20001-
29	418-43-37681	*SWITCH	2	J20001-
30	07002-21423	*O-RING	2	J20001-
31	08034-20834	*BAND	2	J20001-
32	02782-10422	*ELBOW	2	J20001-
33	02896-21012	*O-RING	2	J20001-
34	07002-22034	*O-RING	2	J20001-
35	02782-10423	*ELBOW	1	J20001-
36	02896-21012	*O-RING	1	J20001-
37	07002-22034	*O-RING	1	J20001-
38	02781-00422	*UNION	1	J20001-
39	02896-21012	*O-RING	1	J20001-
40	07002-22034	*O-RING	1	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

ABS/ASR CHASSIS (ASR VALVE) (INNER PARTS) (2/2)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(561-88-80101)	VALVE SUB ASS'Y	1	J20001-
1	56B-43-17430	*VALVE ASS'Y	2	J20001-
2	01010-80865	*BOLT	4	J20001-
3	01643-30823	*WASHER	4	J20001-
4	02781-00422	*UNION	2	J20001-
5	02896-21012	*O-RING	2	J20001-
6	07002-22034	*O-RING	2	J20001-
7	02781-00516	*UNION	1	J20001-
8	02896-21015	*O-RING	1	J20001-
9	07002-22034	*O-RING	1	J20001-
10	02782-10516	*ELBOW	3	J20001-
11	02896-21015	*O-RING	3	J20001-
12	07002-22034	*O-RING	3	J20001-
13	02766-004A5	*HOSE	1	J20001-
14	02765-00403	*HOSE	1	J20001-
15	02766-005A3	*HOSE	1	J20001-
16	02765-004A5	*HOSE	1	J20001-
17	02766-00405	*HOSE	1	J20001-
18	561-88-86131	*TUBE	1	J20001-
19	07094-10417	*CLAMP	2	J20001-
20	07095-00421	*CUSHION	1	J20001-
21	01010-81265	*BOLT	1	J20001-
22	01643-31232	*WASHER	1	J20001-
23	08193-21012	*CLIP	6	J20001-
24	01010-81020	*BOLT	4	J20001-
25	01643-31032	*WASHER	4	J20001-
26	04434-52711	*CLIP	2	J20001-
27	01010-81025	*BOLT	1	J20001-
28	01643-31032	*WASHER	1	J20001-
29	07095-20420	*CUSHION	2	J20001-
30	561-88-86320	*WIRING HARNESS	1	J20001-
31	04434-51510	*CLIP	1	J20001-
32	01010-81020	*BOLT	2	J20001-
33	01643-31032	*WASHER	2	J20001-
34	04434-51010	*CLIP	1	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

VEHICLE HEALTH MONITORING SYSTEM

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	7861-93-3520	SENSOR	1	J20001-
2	569-97-82461	COVER	1	J20001-
3	01010-81060	BOLT	2	J20001-
4	01643-31032	WASHER	2	J20001-
5	08193-21012	CLIP	1	J20001-
6	561-97-82250	CABLE	1	J20001-
7	04434-51710	CLIP	1	J20001-
8	07095-20211	CUSHION	1	J20001-
9	01010-81016	BOLT	1	J20001-
10	01643-31032	WASHER	1	J20001-
11	04434-51510	CLIP	2	J20001-
12	04434-51210	CLIP	1	J20001-
13	195-979-5190	COLLAR	2	J20001-
14	01010-81075	BOLT	2	J20001-
15	01643-31032	WASHER	2	J20001-
16	08034-20834	BAND	3	J20001-
17	561-97-82502	BOX ASS'Y	1	J20001-
18	01010-80816	BOLT	4	J20001-
19	01643-30823	WASHER	4	J20001-
20	08037-03614	GROMMET	1	J20001-
21	04434-51310	CLIP	2	J20001-
22	01010-81016	BOLT	1	J20001-
23	01643-31032	WASHER	1	J20001-

HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up

VEHICLE HEALTH MONITORING SYSTEM LESS

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	08192-29932	CONNECTOR	1	J20001-
2	08193-21012	CLIP	1	J20001-
3	08192-23830	CONNECTOR	1	J20001-

SERVICE KIT

HD785-7 S/N J20001 and up

KIT See subsequent pages for details.		
K-1	561-13-05030	TORQUE CONVERTER SERVICE KIT
K-2	561-13-05040	TORQUE CONVERTER CONTROL VALVE SERVICE KIT
K-3	561-15-05520	TRANSMISSION SERVICE KIT
K-4	561-15-05530	TRANSMISSION CONTROL VALVE SERVICE KIT

HD785-7 S/N J20001 and up

SERVICE KIT

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	561-13-05030	SERVICE KIT,TORQUE CONVERTER	1	J20001-
	07000-73022	*O-RING,(F3310-55A0 -15)	2	J20001-
	07000-73035	*O-RING,(F3310-54A0 -2)	3	J20001-
	07000-73048	*O-RING,(F3310-54A0 -3)	2	J20001-
	07000-75170	*O-RING,(F3310-52A0 -9)	1	J20001-
	07000-75295	*O-RING,(F3310-57A0 -7)	1	J20001-
	07000-75345	*O-RING,(F3310-55A0 -16)	2	J20001-
	07002-61023	*O-RING,(F3310-54A0 -5)	1	J20001-
	07012-50125	*OIL SEAL,(F3310-52A0 -7)	1	J20001-
	07018-31907	*RING,(F3310-51A0 -21)	1	J20001-
	113-15-12861	*RING,(F3310-53A0 -7)	2	J20001-
	426-15-19220	*RING,(F3310-53A0 -8)	2	J20001-
	561-13-53150	*O-RING,(F3310-54A0 -6)	1	J20001-
	772-19-14280	*SEAL,(F3310-52A0 -8)	1	J20001-
	561-13-05040	SERVICE KIT,TORQUE CONVERTER CON- TROL VALVE	1	J20001-
	07000-72012	*O-RING,(F3310-58A0 -29)	3	J20001-
	07000-73030	*O-RING,(F3310-58A0 -30)	1	J20001-
	07000-73038	*O-RING,(F3310-58A0 -31)	6	J20001-
	07000-73045	*O-RING,(F3310-56A0 -7)	1	J20001-
	07002-22034	*O-RING,(F3310-58A0 -28)	2	J20001-
3	07002-60823	*O-RING,(F3310-58A0 -41)	1	J20001-
	07002-61023	*O-RING,(F3310-58A0 -37)	1	J20001-
	07002-61023	*O-RING,(F3310-58A0 -39)	3	J20001-
	07002-61023	*O-RING,(F3310-58A0 -47)	2	J20001-
	07005-01212	*GASKET,(F3310-56A0 -10)	8	J20001-
	561-13-76661	*GASKET,(F3310-56A0 -17)	1	J20001-
	714-23-15560	*O-RING,(F3310-58A0 -25)	4	J20001-
	561-15-05520	SERVICE KIT,TRANSMISSION	1	J20001-
	02896-11009	*O-RING,(F3320-65A0 -32)	2	J20001-
	02896-61015	*O-RING,(F3320-59A0 -8)	2	J20001-
	07000-72012	*O-RING,(F3320-65A0 -7)	1	J20001-
	07000-72020	*O-RING,(F3320-58A0 -15)	3	J20001-
	07000-72020	*O-RING,(F3320-65A0 -27)	2	J20001-
	07000-72045	*O-RING,(F3320-65A0 -8)	1	J20001-
	07000-72045	*O-RING,(F3320-65A0 -28)	2	J20001-
	07000-72055	*O-RING,(F3320-52A0 -15)	1	J20001-
	07000-72055	*O-RING,(F3320-58A0 -14)	1	J20001-
	07000-72085	*O-RING,(F3320-66A0 -20)	2	J20001-
	07000-72105	*O-RING,(F3320-66A0 -6)	4	J20001-
	07000-73022	*O-RING,(F3320-58A0 -24)	5	J20001-
	07000-73025	*O-RING,(F3320-58A0 -23)	5	J20001-
	07000-73025	*O-RING,(F3320-59A0 -11)	2	J20001-
	07000-73028	*O-RING,(F3320-66A0 -15)	1	J20001-
	07000-73030	*O-RING,(F3320-65A0 -9)	1	J20001-

HD785-7 S/N J20001 and up

KIT See subsequent pages for details.		
K - 1	561-13-05030	TORQUE CONVERTER SERVICE KIT
K - 2	561-13-05040	TORQUE CONVERTER CONTROL VALVE SERVICE KIT
K - 3	561-15-05520	TRANSMISSION SERVICE KIT
K - 4	561-15-05530	TRANSMISSION CONTROL VALVE SERVICE KIT

HD785-7 S/N J20001 and up

SERVICE KIT

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	07000-73032	*O-RING,(F3320-58A0 -13)	10	J20001-
	07000-73032	*O-RING,(F3320-58A0 -16)	1	J20001-
	07000-73032	*O-RING,(F3320-58A0 -17)	1	J20001-
	07000-73032	*O-RING,(F3320-58A0 -18)	1	J20001-
	07000-73038	*O-RING,(F3320-58A0 -21)	2	J20001-
	07000-73045	*O-RING,(F3320-58A0 -19)	7	J20001-
	07000-73045	*O-RING,(F3320-58A0 -20)	1	J20001-
	07000-75220	*O-RING,(F3320-60A0 -6)	1	J20001-
	07002-22034	*O-RING,(F3320-65A0 -20)	1	J20001-
	07002-60823	*O-RING,(F3320-65A0 -13)	3	J20001-
	07002-61023	*O-RING,(F3320-65A0 -15)	1	J20001-
	07002-61023	*O-RING,(F3320-65A0 -23)	1	J20001-
	07002-61423	*O-RING,(F3320-65A0 -34)	1	J20001-
	07002-61823	*O-RING,(F3320-65A0 -33)	1	J20001-
	07002-62034	*O-RING,(F3320-59A0 -9)	2	J20001-
	07002-62034	*O-RING,(F3320-67A0 -22)	1	J20001-
	07002-63634	*O-RING,(F3320-58A0 -7)	2	J20001-
	07005-01212	*GASKET,(F3320-59A0 -16)	4	J20001-
	07012-50130	*SEAL,(F3320-60A0 -15)	1	J20001-
	14Y-22-13270	*RING,(F3320-56A0 -29)	1	J20001-
	155-15-12811	*RING,(F3320-51A0 -24)	1	J20001-
	155-15-12811	*RING,(F3320-52A0 -5)	1	J20001-
	175-15-59240	*RING,(F3320-51A0 -5)	1	J20001-
	175-15-59240	*RING,(F3320-51A0 -20)	1	J20001-
	175-15-59240	*RING,(F3320-51A0 -23)	1	J20001-
	175-15-59250	*RING,(F3320-52A0 -4)	1	J20001-
	195-09-18361	*RING,(F3320-54A0 -13)	1	J20001-
	195-15-29210	*RING,(F3320-51A0 -7)	1	J20001-
	195-15-39220	*RING,(F3320-51A0 -4)	1	J20001-
	195-15-39220	*RING,(F3320-51A0 -19)	1	J20001-
	198-22-69640	*O-RING,(F3320-58A0 -29)	1	J20001-
	232-15-19270	*RING,(F3320-53A0 -14)	1	J20001-
	232-15-19270	*RING,(F3320-53A0 -15)	1	J20001-
	561-15-69220	*SEAL RING,(F3320-57A0 -2)	1	J20001-
	561-15-71430	*GASKET,(F3320-66A0 -24)	1	J20001-
	561-15-79220	*RING,(F3320-53A0 -18)	1	J20001-
	561-15-79220	*RING,(F3320-53A0 -19)	1	J20001-
	561-15-79281	*RING,(F3320-56A0 -6)	1	J20001-
	562-15-19560	*RING,(F3320-51A0 -6)	1	J20001-
	569-15-12860	*RING,(F3320-53A0 -16)	1	J20001-
	569-15-12860	*RING,(F3320-53A0 -17)	1	J20001-
	569-15-59110	*O-RING,(F3320-52A0 -14)	1	J20001-
	569-15-59110	*O-RING,(F3320-58A0 -28)	1	J20001-
	714-23-15560	*O-RING,(F3320-65A0 -19)	2	J20001-

HD785-7 S/N J20001 and up


KIT See subsequent pages for details.		
K-1	561-13-05030	TORQUE CONVERTER SERVICE KIT
K-2	561-13-05040	TORQUE CONVERTER CONTROL VALVE SERVICE KIT
K-3	561-15-05520	TRANSMISSION SERVICE KIT
K-4	561-15-05530	TRANSMISSION CONTROL VALVE SERVICE KIT

HD785-7 S/N J20001 and up

SERVICE KIT

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
4	561-15-05530	SERVICE KIT,TRANSMISSION CONTROL VALVE	1	J20001-
	07000-02060	*O-RING,(F3320-64A0 -10)	1	J20001-
	07000-71007	*O-RING,(F3320-64A0 -4)	8	J20001-
	07000-72015	*O-RING,(F3320-64A0 -3)	32	J20001-
	07000-73022	*O-RING,(F3320-64A0 -17)	2	J20001-
	07002-61023	*O-RING,(F3320-61A0 -26)	1	J20001-
	07002-61023	*O-RING,(F3320-62A0 -26)	1	J20001-
	07002-61023	*O-RING,(F3320-63A0 -21)	1	J20001-
	07002-61623	*O-RING,(F3320-64A0 -7)	9	J20001-
	07002-61823	*O-RING,(F3320-64A0 -16)	1	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

HYDRAULIC PUMP (STEERING AND HOIST) (1/2)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	705-52-42220	PUMP ASS'Y,(SAR(4)180+180)	1	J20001-
		THIS ASSEMBLY CONSISTS OF ALL PARTS SHOWN IN FIGS Y1600-01A1 AND Y1600-02A1.		
	705-22-45040	*PUMP ASS'Y,(SAR(4)180)	1	J20001-
1	(★ 705-17-04021)	**BRACKET	1	J20001-
	(★ 705-17-04352)	***BUSHING,PLANE	2	J20001-
2	(★ 705-17-45010)	**CASE,GAER	1	J20001-
3	(★ 705-17-04260)	**CARRIER	1	J20001-
	(★ 705-17-04352)	***BUSHING,PLANE	2	J20001-
4	(★ 705-17-45430)	**GEAR,DRIVE	1	J20001-
5	(★ 705-17-45510)	**GEAR,DRIVEN	1	J20001-
6	705-17-04611	**PLATE,SIDE	2	J20001-
7	705-17-04441	**RING,BACK-UP	2	J20001-
8	705-17-04471	**SEAL	2	J20001-
9	705-17-04382	**O-RING	2	J20001-
10	04020-01842	**PIN,DOWEL	4	J20001-
11	705-17-04750	**BOLT	4	J20001-
12	705-17-04680	**BOLT	4	J20001-
13	705-17-04980	**WASHER	8	J20001-
14	704-17-05811	**SEAL,OIL	1	J20001-
15	705-17-04870	**PLATE	1	J20001-
16	04065-06220	**RING,SNAP	1	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

HYDRAULIC PUMP (STEERING AND HOIST) (2/2)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	705-52-42220	PUMP ASS'Y,(SAR(4)180+180)	1	J20001-
		THIS ASSEMBLY CONSISTS OF ALL PARTS SHOWN IN FIGS Y1600-01A1 AND Y1600-02A1.		
	705-22-45050	*PUMP ASS'Y,(SAR(4)180)	1	J20001-
1	(★ 705-17-04520)	**BRACKET	1	J20001-
	(★ 705-17-04352)	***BUSHING,PLANE	2	J20001-
2	(★ 705-17-45010)	**CASE,GAER	1	J20001-
3	(★ 705-17-04180)	**COVER	1	J20001-
	(★ 705-17-04352)	***BUSHING,PLANE	2	J20001-
4	(★ 705-17-45450)	**GEAR,DRIVE	1	J20001-
5	(★ 705-17-45510)	**GEAR,DRIVEN	1	J20001-
6	705-17-04611	**PLATE,SIDE	2	J20001-
7	705-17-04441	**RING,BACK-UP	2	J20001-
8	705-17-04471	**SEAL	2	J20001-
9	705-17-04382	**O-RING	2	J20001-
10	04020-01842	**PIN,DOWEL	4	J20001-
11	705-17-04750	**BOLT	4	J20001-
12	705-17-04680	**BOLT	4	J20001-
13	705-17-04980	**WASHER	8	J20001-
14	04020-01228	**PIN,DOWEL	2	J20001-
15	705-17-04330	*COUPLING	1	J20001-
16	705-17-04481	*O-RING	1	J20001-
17	01252-61445	*BOLT	4	J20001-
18	705-17-04980	*WASHER	4	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

HYDRAULIC PUMP (1/3)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(705-95-07120)	PUMP ASS'Y,SDR(30)100+100+SA(1)25 THIS ASSEMBLY CONSISTS OF ALL PARTS SHOWN IN FIGS Y1600-11A1 AND Y1600-13A1.	1	J20001-
1	(*705-95-80010)	.BRACKET ASS'Y	1	J20001-
	(*705-95-80610)	.BUSHING	2	J20001-
	(*705-95-80620)	.BUSHING	2	J20001-
2	(*705-95-40021)	.CASE	1	J20001-
3	(*705-95-40610)	.GEAR,DRIVE	1	J20001-
4	(*705-95-40510)	.GEAR,DRIVEN	1	J20001-
5	705-94-80711	.PLATE	1	J20001-
6	705-94-80721	.PLATE	1	J20001-
7	705-94-80770	.SEAL,RING	2	J20001-
8	04020-00820	.PIN,DOWEL	4	J20001-
9	705-94-80820	.SEAL,OIL	1	J20001-
10	04065-05820	.RING,SNAP	1	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

HYDRAULIC PUMP (2/3)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(705-95-07120)	PUMP ASS'Y,SDR(30)100+100+SA(1)25	1	J20001-
		THIS ASSEMBLY CONSISTS OF ALL PARTS SHOWN IN FIGS Y1600-11A1 AND Y1600-13A1.		
1	(★ 705-95-80211)	*CARRIER ASS'Y	1	J20001-
	(★ 705-95-80221)	**CARRIER	1	J20001-
	(★ 705-95-80610)	**BUSHING	1	J20001-
	(★ 705-95-80620)	**BUSHING	1	J20001-
2	(★ 705-95-40021)	*CASE	1	J20001-
3	(★ 705-95-81310)	*CARRIER ASS'Y	1	J20001-
	(★ 705-95-80610)	**BUSHING	1	J20001-
	(★ 705-95-80620)	**BUSHING	1	J20001-
4	(★ 705-95-40760)	*GEAR,DRIVE	1	J20001-
5	(★ 705-95-40510)	*GEAR,DRIVEN	1	J20001-
6	705-94-80711	*PLATE	1	J20001-
7	705-94-80721	*PLATE	1	J20001-
8	705-94-80770	*EAL,RING	2	J20001-
9	04020-00820	*PIN,DOWEL	4	J20001-
10	705-94-84230	*BOLT	8	J20001-
11	01643-31445	*WASHER	8	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

HYDRAULIC PUMP (3/3)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(705-95-07120)	PUMP ASS'Y,SDR(30)100+100+SA(1)25	1	J20001-
		THIS ASSEMBLY CONSISTS OF ALL PARTS SHOWN IN FIGS Y1600-11A1 AND Y1600-13A1.		
1	(★ 705-95-01971)	*BRACKET	1	J20001-
	(★ 705-95-28320)	*PUMP ASS'Y,ASR (1)125	1	J20001-
2	(★ 705-95-01541)	**BRACKET	1	J20001-
	(★ 705-95-01351)	***BUSHING	2	J20001-
3	(★ 705-95-28010)	**CASE	1	J20001-
4	(★ 705-95-01410)	**COVER ASS'Y	1	J20001-
	(★ 705-95-01351)	***BUSHING	2	J20001-
5	(★ 705-95-28940)	**GEAR DRIVE	1	J20001-
6	(★ 705-95-28510)	**GEAR DRIVEN	1	J20001-
7	705-17-01610	**PLATE	2	J20001-
8	705-67-01470	**SEAL,OIL	2	J20001-
9	705-67-01440	**RING,BACK-UP	2	J20001-
10	705-67-01380	**O-RING	2	J20001-
11	04020-00820	**PIN	4	J20001-
12	01252-61295	**BOLT	4	J20001-
13	01643-51232	**WASHER	4	J20001-
14	04020-00820	**PIN	2	J20001-
15	705-17-01860	**PLATE	1	J20001-
16	705-17-01950	**SEAL,OIL	1	J20001-
17	705-17-01330	*COUPLING ASS'Y	1	J20001-
18	705-17-01430	*O-RING	1	J20001-
19	705-40-80640	*RING,BACK-UP	1	J20001-
20	01252-61030	*BOLT	4	J20001-
21	01643-51032	*WASHER	4	J20001-
22	01252-61240	*BOLT	4	J20001-
23	01643-51232	*WASHER	4	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

HYDRAULIC PUMP (1/3)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	705-56-44090	PUMP ASS'Y,(SAR180+180+6)	1	J20001-
		THIS ASSEMBLY CONSISTS OF ALL PARTS SHOWN IN FIGS Y1600-21A1 AND Y1600-23A1.		
	705-12-45250	PUMP ASS'Y,(SAR(4)180)	1	J20001-
1	(★ 705-95-04021)	**BRACKET	1	J20001-
	(★ 705-95-04352)	***BUSHING,PLANE	2	J20001-
2	(★ 705-95-45010)	**CASE,GAER	1	J20001-
3	(★ 705-95-04221)	**CARRIER	1	J20001-
	(★ 705-95-04352)	***BUSHING,PLANE	2	J20001-
4	(★ 705-95-45340)	**GEAR,DRIVE	1	J20001-
5	(★ 705-95-45510)	**GEAR,DRIVEN	1	J20001-
6	705-17-04611	**PLATE,SIDE	2	J20001-
7	705-17-04441	**RING,BACK-UP	2	J20001-
8	705-17-04471	**SEAL	2	J20001-
9	705-17-04382	**O-RING	2	J20001-
10	04020-01842	**PIN,DOWEL	4	J20001-
11	705-17-04750	**BOLT	4	J20001-
12	705-17-04680	**BOLT	4	J20001-
13	705-17-04980	**WASHER	8	J20001-
14	704-17-05811	**SEAL,OIL	1	J20001-
15	705-17-04870	**PLATE	1	J20001-
16	04065-06220	**RING,SNAP	1	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

HYDRAULIC PUMP (2/3)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(705-56-44090)	PUMP ASS'Y,(SAR180+180+6)	1	J20001-
		THIS ASSEMBLY CONSISTS OF ALL PARTS SHOWN IN FIGS Y1600-21A1 AND Y1600-23A1.		
1	705-36-45340	*PUMP ASS'Y (SAR(4)180)	1	J20001-
	(★ 705-95-04520)	**BRACKET	1	J20001-
	(★ 705-95-04352)	***BUSHING,PLANE	2	J20001-
2	(★ 705-95-45010)	**CASE,GEAR	1	J20001-
3	(★ 705-95-04240)	**COVER	1	J20001-
	(★ 705-95-04352)	***BUSHING,PLANE	2	J20001-
4	(★ 705-95-45370)	**GEAR,DRIVE	1	J20001-
5	(★ 705-95-45510)	**GEAR,DRIVEN	1	J20001-
6	705-17-04611	**PLATE,SIDE	2	J20001-
7	705-17-04441	**RING,BACK-UP	2	J20001-
8	705-17-04471	**SEAL	2	J20001-
9	705-17-04382	**O-RING	2	J20001-
10	04020-01842	**PIN,DOWEL	4	J20001-
11	705-17-04750	**BOLT	4	J20001-
12	705-17-04680	**BOLT	4	J20001-
13	705-17-04980	**WASHER	8	J20001-
14	04020-01228	**PIN,DOWEL	2	J20001-
15	705-17-04330	*COUPLING	1	J20001-
16	705-17-04481	*O-RING	1	J20001-
17	01252-61445	*BOLT	4	J20001-
18	705-17-04980	*WASHER	4	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

HYDRAULIC PUMP (3/3)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(705-56-44090)	PUMP ASS'Y,(SAR180+180+6)	1	J20001-
		THIS ASSEMBLY CONSISTS OF ALL PARTS SHOWN IN FIGS Y1600-21A1 AND Y1600-23A1.		
1	705-12-19540	*PUMP ASS'Y	1	J20001-
	(★ 705-95-01610)	**BRACKET	1	J20001-
	(★ 705-95-01350)	***BUSHING, PLANE	2	J20001-
2	(★ 705-95-19010)	**CASE, GEAR	1	J20001-
3	(★ 705-95-01400)	**COVER	1	J20001-
	(★ 705-95-01350)	***BUSHING, PLANE	2	J20001-
4	(★ 705-95-19450)	**GEAR, DRIVE	1	J20001-
5	(★ 705-95-19510)	**GEAR, DRIVEN	1	J20001-
6	705-17-01610	**PLATE, SIDE	2	J20001-
7	705-67-01440	**RING, BACK-UP	2	J20001-
8	705-67-01470	**SEAL, SEAL	2	J20001-
9	705-67-01380	**O-RING	2	J20001-
10	04020-00820	**PIN, DOWEL	4	J20001-
11	04020-01228	**PIN, DOWEL	2	J20001-
12	01252-61270	**BOLT	4	J20001-
13	01643-51232	**WASHER	4	J20001-
14	705-19-01330	*COUPLING	1	J20001-
15	705-17-01880	*PLATE	1	J20001-
16	07000-E3032	*O-RING	1	J20001-
17	01010-81025	*BOLT	4	J20001-
18	01643-51032	*WASHER	4	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

HOIST CYLINDER (INNER PARTS)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(707-09-07090)	CYLINDER ASS'Y(FINAL COATING)	2	J20001-
	707-09-00070	CYLINDER ASS'Y	1	J20001-
1	707-18-21020	*CYLINDER	1	J20001-
2	561-63-62181	*HEAD	1	J20001-
3	581-63-92670	*SEAL (KIT)	1	J20001-
4	707-51-20250	*PACKING (KIT)	1	J20001-
5	581-63-22291	*BUSHING	1	J20001-
6	07001-05220	*RING (KIT)	1	J20001-
7	07000-15220	*O-RING (KIT)	1	J20001-
8	707-88-34620	*PLATE	1	J20001-
9	01011-82030	*BOLT	8	J20001-
10	01643-32060	*WASHER	8	J20001-
11	561-63-62160	*CYLINDER	1	J20001-
12	707-75-13010	*RING	1	J20001-
13	707-56-13520	*SEAL (KIT)	1	J20001-
14	707-52-11320	*BUSHING	1	J20001-
15	707-51-13130	*PACKING (KIT)	1	J20001-
16	581-63-22581	*RING (KIT)	1	J20001-
17	561-63-22770	*RING	1	J20001-
18	569-63-22880	*BUSHING	2	J20001-
19	04071-00130	*RING	4	J20001-
20	561-63-62122	*ROD	1	J20001-
21	707-36-18561	*PISTON	1	J20001-
22	707-44-18070	*RING	1	J20001-
23	07155-01845	*RING	1	J20001-
24	01124-82260	*STUD	5	J20001-
25	07165-12222	*NUT	5	J20001-
26	07020-00900	*FITTING,GREASE	1	J20001-
	=====			
KIT	707-99-79400	SERVICE KIT	2	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

STEERING CYLINDER (L.H) (INNER PARTS)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
G1	(#707-00-XX650)	CYLINDER GROUP, L.H.(FINAL COATING)	1	J20001-
	=====			
	707-00-0G700	CYLINDER ASS'Y	1	J20001-
1	707-11-11E20	*CYLINDER	1	J20001-
2	721-58-70430	*ROD,PISTON	1	J20001-
3	07137-05008	*BUSHING	2	J20001-
4	04065-01104	*RING,SNAP	4	J20001-
5	07000-13050	*O-RING (KIT)	4	J20001-
6	707-29-11720	*HEAD,CYLINDER	1	J20001-
7	07179-12084	*RING,SNAP	1	J20001-
8	707-56-70540	*SEAL,DUST (KIT)	1	J20001-
9	07146-02106	*RING,BACK-UP (KIT)	1	J20001-
10	07000-12105	*O-RING (KIT)	1	J20001-
11	07000-12110	*O-RING (KIT)	1	J20001-
12	707-52-10700	*BUSHING	1	J20001-
13	707-51-70211	*PACKING,ROD (KIT)	1	J20001-
14	707-36-11380	*PISTON	1	J20001-
15	707-44-11180	*RING,PISTON (KIT)	1	J20001-
16	07155-01125	*RING,WEAR (KIT)	1	J20001-
17	707-67-52020	*NUT	1	J20001-
18	02896-11018	*O-RING (KIT)	1	J20001-
19	707-86-68080	TUBE,L.H.	1	J20001-
20	707-86-68090	TUBE,L.H.	1	J20001-
21	02782-10628	ELBOW	1	J20001-
22	07002-12434	O-RING (KIT)	1	J20001-
23	02896-11018	O-RING (KIT)	1	J20001-
24	707-88-02401	PLATE,L.H.	1	J20001-
25	07283-32738	CLIP	3	J20001-
26	01597-01009	NUT	6	J20001-
27	01643-31032	WASHER	6	J20001-
	=====			
K	707-98-37690	SERVICE KIT	1	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

STEERING CYLINDER (R.H) (INNER PARTS)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
G1	(#707-00-XX660)	CYLINDER GROUP, R.H.(FINAL COATING)	1	J20001-
	=====			
	707-00-0G700	CYLINDER ASS'Y	1	J20001-
1	707-11-11E20	*CYLINDER	1	J20001-
2	721-58-70430	*ROD,PISTON	1	J20001-
3	07137-05008	*BUSHING	2	J20001-
4	04065-01104	*RING,SNAP	4	J20001-
5	07000-13050	*O-RING (KIT)	4	J20001-
6	707-29-11720	*HEAD,CYLINDER	1	J20001-
7	07179-12084	*RING,SNAP	1	J20001-
8	707-56-70540	*SEAL,DUST (KIT)	1	J20001-
9	07146-02106	*RING,BACK-UP (KIT)	1	J20001-
10	07000-12105	*O-RING (KIT)	1	J20001-
11	07000-12110	*O-RING (KIT)	1	J20001-
12	707-52-10700	*BUSHING	1	J20001-
13	707-51-70211	*PACKING,ROD (KIT)	1	J20001-
14	707-36-11380	*PISTON	1	J20001-
15	707-44-11180	*RING,PISTON (KIT)	1	J20001-
16	07155-01125	*RING,WEAR (KIT)	1	J20001-
17	707-67-52020	*NUT	1	J20001-
18	02896-11018	*O-RING (KIT)	1	J20001-
19	707-86-68100	TUBE,R.H.	1	J20001-
20	707-86-68110	TUBE,R.H.	1	J20001-
21	02782-10628	ELBOW	1	J20001-
22	07002-12434	O-RING (KIT)	1	J20001-
23	02896-11018	O-RING (KIT)	1	J20001-
24	707-88-03690	PLATE,R.H.	1	J20001-
25	07283-32738	CLIP	3	J20001-
26	01597-01009	NUT	6	J20001-
27	01643-31032	WASHER.....	6	J20001-
	=====			
K	707-98-37690	SERVICE KIT	1	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

ACCUMULATOR (BRAKE CONTROL) (INNER PARTS)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	721-32-10410	ACCUMULATOR ASS'Y	1	J20001-
1	721-10-10270	*CYLINDER	1	J20001-
2	721-36-10030	*PISTON	1	J20001-
3	721-47-12020	*SEAL	1	J20001-
4	721-47-12080	*SEAL	1	J20001-
5	721-26-10060	*COVER,BOTTOM	1	J20001-
6	721-29-10090	*COVER, TOP	1	J20001-
7	721-89-12010	*VALVE	1	J20001-
8	707-35-91020	*RING,BACK-UP	2	J20001-
9	07000-15090	*O-RING	2	J20001-
10	07000-12100	*O-RING	2	J20001-
11	707-88-45770	*COVER	1	J20001-
12	707-88-81480	*SCREW	2	J20001-
13	721-89-10053	*PLATE,SPECIFICATION	1	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

HOIST VALVE (1/3)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(701-37-26000)	CONTROL VALVE	1	J20001-
		THIS ASSEMBLY CONSISTS OF ALL PARTS SHOWN IN FIGS Y1660-01A0 AND Y1660-03A0		
1	701-31-82000	HOUSING ASS'Y	1	J20001-
	701-31-69131	*HOUSING	1	J20001-
	709-10-58700	**VALVE ASS'Y,RELIEF	1	J20001-
2	☆	***SLEEVE	1	J20001-
3	07000-F3032	***O-RING	1	J20001-
4	07001-03032	***RING	1	J20001-
5	07002-25234	***O-RING	1	J20001-
6	☆	***ORIFICE	1	J20001-
7	☆	***SLEEVE	1	J20001-
8	☆	***POPPET	1	J20001-
9	☆	***PISTON.....	1	J20001-
10	☆	***SEAL	1	J20001-
11	☆	***SPRING	1	J20001-
12	☆	***SEAT	1	J20001-
13	☆	***SPRING	1	J20001-
14	☆	***SEAL	1	J20001-
15	☆	***SPRING	1	J20001-
16	☆	***POPPET	1	J20001-
17	☆	***PLUG	1	J20001-
18	☆	***NUT	1	J20001-
19	☆	***SCREW.....	1	J20001-
20	☆	***SPACER	1	J20001-
21	☆	***O-RING	1	J20001-
22	☆	***O-RING	1	J20001-
23	700-22-11370	***PLUG	1	J20001-
24	07002-22434	**O-RING	1	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

HOIST VALVE (2/3)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(701-37-26000)	CONTROL VALVE	1	J20001-
		THIS ASSEMBLY CONSISTS OF ALL PARTS SHOWN IN FIGS Y1660-01A0 AND Y1660-03A0.		
	701-32-54000	*VALVE SUB ASS'Y	1	J20001-
1	☆	**BODY, VALVE	1	J20001-
2	☆	**SPOOL	1	J20001-
3	☆	**PIN	1	J20001-
4	701-32-45430	**CASE, SPRING	1	J20001-
5	701-32-45460	**RETAINER	1	J20001-
6	07000-F2065	**O-RING	1	J20001-
7	701-32-45480	**SPRING	1	J20001-
8	701-32-45570	**RETAINER	1	J20001-
9	701-32-45490	**SPRING	1	J20001-
10	701-32-45510	**SPRING	1	J20001-
11	701-32-45450	**FLANGE	1	J20001-
12	07000-F2060	**O-RING	1	J20001-
13	01252-61235	**BOLT	5	J20001-
14	01016-80850	**BOLT	2	J20001-
15	01010-80830	**BOLT	2	J20001-
16	01643-30823	**WASHER	4	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

HOIST VALVE (3/3)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	(701-37-26000)	CONTROL VALVE	1	J20001-
		THIS ASSEMBLY CONSISTS OF ALL PARTS SHOWN IN FIGS Y1660-01A0 AND Y1660-03A0.		
	(701-32-54000)	*VALVE SUB ASS'Y	1	J20001-
1	701-32-45420	*CASE,SPRING	1	J20001-
2	709-14-12570	**RETAINER	1	J20001-
3	07000-F2070	**O-RING	1	J20001-
4	701-32-45520	**SPRING	1	J20001-
5	701-32-45530	**SPRING	1	J20001-
6	01252-61240	**BOLT	2	J20001-
7	01252-61440	**BOLT	2	J20001-
8	701-33-31120	**VALVE	1	J20001-
9	701-33-31130	**SPRING	1	J20001-
10	701-33-31150	**SEAT	1	J20001-
11	07000-F3034	**O-RING	1	J20001-
12	701-32-45540	**PLUG	1	J20001-
13	07000-F3029	**O-RING	1	J20001-
14	07043-00312	**PLUG	1	J20001-
15	07040-11409	**PLUG	2	J20001-
16	07002-21423	*O-RING	2	J20001-
17	07000-F3048	*O-RING	2	J20001-
18	07000-F3030	*O-RING	2	J20001-
19	01010-81290	*BOLT	5	J20001-
20	01643-31232	*WASHER	5	J20001-
21	01010-81495	*BOLT	2	J20001-
22	01643-31445	*WASHER	2	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

DEMAND VALVE (1/2)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	702-21-02600	VALVE THIS ASSEMBLY CONSISTS OF ALL PARTS SHOWN IN FIGS Y1660-11A0 AND Y1660-12A0.	1	J20001-
1	☆	*BODY	1	J20001-
2	☆	*SPOOL	1	J20001-
3	281-64-14450	*PLUG	1	J20001-
4	07002-24234	*O-RING	1	J20001-
5	702-21-26380	*COVER	1	J20001-
6	702-21-26141	*SPRING	1	J20001-
7	01010-61865	*BOLT	4	J20001-
8	01602-21854	*WASHER,SPRING	4	J20001-
9	07000-F2070	*O-RING	1	J20001-
10	702-13-46290	*POPPET	1	J20001-
11	701-30-67130	*SPRING	1	J20001-
12	702-21-26390	*PLUG	1	J20001-
13	07000-F3030	*O-RING	1	J20001-
14	07001-03030	*RING,BACK-UP	1	J20001-
15	702-13-41320	*PLATE	2	J20001-
16	01010-81240	*BOLT	4	J20001-
17	01602-21236	*WASHER,SPRING	4	J20001-
18	01010-80830	*BOLT	2	J20001-
19	01602-20825	*WASHER,SPRING	2	J20001-
20	702-13-41160	*PLUG	1	J20001-
21	702-13-51280	*O-RING	1	J20001-
22	700-62-34140	*RING,BACK-UP	1	J20001-
23	07378-10600	*HEAD	1	J20001-
24	07000-F3025	*O-RING	1	J20001-
25	07371-30638	*FLANGE,SPLIT	2	J20001-
26	01010-80830	*BOLT	4	J20001-
27	01602-20825	*WASHER,SPRING	4	J20001-
28	702-21-26151	*ORIFICE	1	J20001-
29	702-21-26162	*ORIFICE	1	J20001-
30	07040-11409	*PLUG	1	J20001-
31	07002-21423	*O-RING	1	J20001-
32	702-21-26180	*BLOCK	1	J20001-
33	07040-11007	*PLUG	1	J20001-
34	07002-21023	*O-RING	1	J20001-
35	07000-F2018	*O-RING	4	J20001-
36	07040-11209	*PLUG	1	J20001-
37	07002-21223	*O-RING	1	J20001-
38	(709-10-53300)	*VALVE ASS'Y RELIEF	1	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

DEMAND VALVE (2/2)

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	702-21-02600	VALVE THIS ASSEMBLY CONSISTS OF ALL PARTS SHOWN IN FIGS Y1660-11A0 AND Y1660-12A0.	1	J20001-
	709-10-53300	*VALVE ASS'Y,RELIEF	1	J20001-
1	☆	**SLEEVE	1	J20001-
2	07000-23032	**O-RING	1	J20001-
3	07001-03032	**RING, BACK-UP	1	J20001-
4	07002-25234	**O-RING	1	J20001-
5	☆	**RING, BACK-UP	1	J20001-
6	☆	**VALVE	1	J20001-
7	☆	**SPRING	1	J20001-
8	☆	**SEAT	1	J20001-
9	☆	**O-RING	1	J20001-
10	☆	**RING, BACK-UP	1	J20001-
11	☆	**POPPET	1	J20001-
12	☆	**SPRING	1	J20001-
13	☆	**RETAINER	1	J20001-
14	☆	**HOLDER	1	J20001-
15	☆	**O-RING	1	J20001-
16	☆	**NUT	1	J20001-
17	☆	**SCREW	1	J20001-
18	☆	**NUT	1	J20001-
19	☆	**O-RING	1	J20001-

HD785-7 S/N J20001 and up




HD785-7 S/N J20001 and up

CHECK VALVE

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	702-13-43700	VALVE ASS'Y	1	J20001-
1	702-13-42910	*BODY	1	J20001-
2	702-13-42930	*PLATE	1	J20001-
3	702-13-42920	*POPPET	1	J20001-
4	702-13-42940	*SPRING	1	J20001-
5	07000-F2055	*O-RING	1	J20001-
6	01252-60612	*BOLT	2	J20001-

HD785-7 S/N J20001 and up



HD785-7 S/N J20001 and up

ELECTRIC LEVER

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	702-16-02133	LEVER ASS'Y,DUMP CONTROL	1	J20001-
2	01252-60512	*BOLT	5	J20001-
3	702-16-54920	*RING	1	J20001-
4	702-16-54641	*BOOT	1	J20001-
5	08192-24810	*CONNECTOR	1	J20001-
6	702-16-57930	*TUBE	1	J20001-
7	702-16-57940	*CLIP	1	J20001-

