



Y00K2301,"Construction equipment",Excavator,YB
[Info]
PcNo=Y00K2301
PcName=YB10-2(B3761)
JpnUse=1
JpnSec1=ÆŠ<@
JpnSec2=fofbNfz [
JpnSec3=YB
JpnPreface=0
EngUse=1
EngSec1=CONSTRUCTION
EngSec2=EXCAVATOR (YB)
EngSec3=YB
EngPreface=0

Fig. 1


ロアフレーム
LOWER FRAME <https://truckmanualshub.com/>



1,1,,E1914009100,, "CRAWLER ASSY",2,,,,,,,,,,,,,
2,2,,E1914009101,, "PLATE, SHOE",60,,,,,,,,,,,,,
3,2,,E1914009102,, "PIN, TRACK",60,,,,,,,,,,,,,
4,2,,E1914009103,, "WASHER, TRACK PIN",60,,,,,,,,,,,,,
5,2,,E1213000620,, "SPRING PIN, TRACK",60,,,,,,,,,,,,,
6,1,,E1914011100,, "CRAWLER BELT,RUBBER",2,,,,,,,,,,,,,



スチール
STEEL




ラバー
RUBBER

1,1,,E0071390000,, "ROLLER W/SHAFT, TRACK", 6,,,,,,,,,,,,,
3,2,,E0071300200,, SHAFT, 6,,,,,,,,,,,,,
4,2,,E1300006005,, BEARING, 12,,,,,,,,,,,,,
5,2,,E1431002547,, "SEAL, ROLLER", 12,,,,,,,,,,,,,
6,2,,E1221000047,, "RING, SNAP", 12,,,,,,,,,,,,,
7,2,,E1501820001,, PLUG, 6,,,,,,,,,,,,,
8,1,,E1100051225,, "BOLT M 12X 25, ROLLER", 12,,,,,,,,,,,,,
9,1,,E1140010012,, "SPRING WASHER 12", 12,,,,,,,,,,,,,

Fig. **3**


トラックローラ
TRUCK ROLLER

<https://truckmanualshub.com/>




1,1,,E0071490010,, "FRONT IDLER ASSY",2,,,,,,,,,,,,,
3,2,,E0071400200,, "SHAFT, IDLER",2,,,,,,,,,,,,,
4,2,,E0071400300,, "YOKE, SLIDE",4,,,,,,,,,,,,,
5,2,,E1300006006,, BEARING,4,,,,,,,,,,,,,
6,2,,E1431203055,, SEAL,4,,,,,,,,,,,,,
7,2,,E1221000055,, "SNAP RING",4,,,,,,,,,,,,,
8,2,,E1213000645,, "SPRING PIN",4,,,,,,,,,,,,,
9,2,,E1501820001,, PLUG,2,,,,,,,,,,,,,
10,1,,E0071590000,, "CUSHION ASSY",2,,,,,,,,,,,,,
11,2,,E0071501100,, CYLINDER,2,,,,,,,,,,,,,
12,2,,E0071500300,, PLATE,2,,,,,,,,,,,,,
13,2,,E0071500400,, PLATE,2,,,,,,,,,,,,,
14,2,,E0007000018,, SPRING,2,,,,,,,,,,,,,
15,2,,E1101051240,, "BOLT M12X40",4,,,,,,,,,,,,,
16,2,,E0071500600,, STOPPER,2,,,,,,,,,,,,,
17,2,,E1140010012,, "SPRING WASHER 12",4,,,,,,,,,,,,,
18,1,,E0071501200,, PISTON,2,,,,,,,,,,,,,
19,1,,E1541301601,, "VALVE, CHECK",2,,,,,,,,,,,,,
20,1,,E1541201616,, GASKET,2,,,,,,,,,,,,,
21,1,,E1560001000,, "NIPPLE, GREASE PT1/8",2,,,,,,,,,,,,,
22,1,,E1420010300,, O-RING,2,,,,,,,,,,,,,
23,1,,E1421020300,, "RING, BACKUP",2,,,,,,,,,,,,,
24,1,,E1400401654,, "SEAL, OIL",2,,,,,,,,,,,,,
25,1,,E1100051030,, "BOLT M10X 30",8,,,,,,,,,,,,,
26,1,,E1140010010,, "SPRING WASHER",8,,,,,,,,,,,,,

Fig. **4** アイドラ & クローラアジャスト
IDLER & CRAWLER ADJUSTER



1inc.(1)~9




1,1,,E1903105500,, "MOTOR ASSY",2,,,,,,,,3,,,,,,,,,
2,1,,E0071604100,, SPROCKET,2,,,,,,,,1,,,,,,,,,
3,1,,E0071605100,, SPROCKET,2,,,,,,,,2,,,,,,,,,
4,1,,E1111551020,, "BOLT, SOCKET",34,,,,,,,,,,,,,,,,,
5,1,,E1901501300,, "BRAKE VALVE ASSY",2,,,,,,,,4,,,,,,,,,


Fig. **5**

ソウコウクドウソウチ
DRIVING WHEEL

<https://truckmanualshub.com/>



1,1,,E0066303100,,BLADE,1,,,,,,,,,,,,,
2,1,,E0001500025,, "PIN, BLADE",2,,,,,,,,,,,,,
3,1,,E0001330086,, "PIN, BLADE",2,,,,,,,,,,,,,
4,1,,E0003000067,, "COLLAR T=1.6",2,,,,,,,,1,,,,,,,,,
5,1,,E0003000068,, "COLLAR T=2.3",2,,,,,,,,1,,,,,,,,,
6,1,,E0003000069,, "COLLAR T=3.2",2,,,,,,,,1,,,,,,,,,
7,1,,E1100050870,, "BOLT M 8X 70",2,,,,,,,,,,,,,
8,1,,E1130040008,, "NUT M 8",4,,,,,,,,,,,,,
9,1,,E1560001000,, "NIPPLE, GREASE PT1/8",4,,,,,,,,,,,,,
10,1,,E1210000845,, "COTTER PIN",2,,,,,,,,,,,,,
11,1,,E1900015300,, "BLADE CYLINDER ASSY",1,,,,,,,,2,,,,,,,,,




1,1,,E1909508053,, "HOSE ASSY",1,,,,,,,,,,,,,
2,1,,E1511000002,,ADAPTOR,2,,,,,,,,,,,,,
3,1,,E1511100002,, "ELBOW (90°)",6,,,,,,,,,,,,,
4,1,,E1420010110,, "O-RING P11-1B",4,,,,,,,,,,,,,
5,1,,E0077200400,, "GUIDE, HOSE",2,,,,,,,,,,,,,
6,1,,E1515600581,, "ADAPTER UNION",4,,,,,,,,,,,,,
7,1,,E1909508056,, "HOSE ASSY",1,,,,,,,,,,,,,
8,1,,E1531335025,, "TUBE, PROTECTOR",2,,,,,,,,,,,,,
9,1,,E1909108078,, "HOSE ASSY",2,,,,,,,,,,,,,
10,1,,E1909108070,, "HOSE, HIGH-PRESSURE",2,,,,,,,,,,,,,

Fig. 7

カブユアツハイカン LOWER HYDRAULIC OIL PIPING

<https://truckmanualshub.com/>




1,1,,E0007200087,,PLUG,2,,,,,,,,,,,,,
2,1,,E0007200088,,FITTINGS,2,,,,,,,,,,,,,
3,1,,E0072303100,, "COVER, GREASE",1,,,,,,,,,,,,,
4,1,,E1903104800,, "MOTOR ASSY",1,,,,,,,,1,,,,,,,,,
5,1,,E1901714000,, "C.B.VALVE ASS'Y.",1,,,,,,,,2,,,,,,,,,
6,1,,E1111041235,, "BOLT, SOCKET",4,,,,,,,,,,,,,
7,1,,E1141540012,, "WASHER 12",4,,,,,,,,,,,,,
8,1,,E1110040610,, "BOLT, SOCKET",2,,,,,,,,,,,,,
9,1,,E1140020006,, "SPRING WASHER 6",2,,,,,,,,,,,,,
10,1,,E1420010200,, O-RING,4,,,,,,,,,,,,,
11,1,,E1420310910,, "O-RING APR568-910-1B",2,,,,,,,,,,,,,
12,1,,E0097053200,, CONNECTOR,1,,,,,,,,,,,,,
13,1,,E1420310904,, "O-RING ARP568-904-1B",1,,,,,,,,,,,,,
14,1,,E1532620601,, ELBOW,1,,,,,,,,,,,,,
15,1,,E1903104802,, "GEAR, PINION",1,,,,,,W,1,TS-TERAGIMA, "FROM 1ST",,,,,,,,,,


Fig. 8

センカイドウソウチ
TURNING DRIVING GEAR

<https://truckmanualshub.com/>



1,1,,E0063035000,, "TURNING TABLE ASSY",1,,,,,,,,,,,,,
3,2,,E1100041220,, BOLT,4,,,,,,,,,,,,,
4,2,,E1130040012,, "NUT M12",4,,,,,,,,,,,,,
5,2,,E0003600026,, WASHER,8,,,,,,,,,,,,,
6,1,,E0062214100,, "PIN, LOCK",1,,,,,,,,,,,,,
7,1,,E0063114100,, BRACKET,1,,,,,,,,,,,,,
8,1,,E0063102200,, COVER,1,,,,,,,,,,,,,
8-1,1,,E0063112400,, COVER,1,,,,,,,,,,,,,
10,1,,E0103113200,, WASHER,1,,,,,,,,,,,,,
11,1,,E0001900118,, SHAFT,1,,,,,,,,,,,,,
12,1,,E0001900117,, PIN,1,,,,,,,,,,,,,
13,1,,E0001900034,, "PIN, HEAD",1,,,,,,,,,,,,,
14,1,,E0002600001,, BUSH,2,,,,,,,,,,,,,
15,1,,E0003030003,, "COLLAR T3.2, PIN 30",1,,,,,1,,,,,
16,1,,E0003030004,, "COLLAR T4.0, PIN 30",1,,,,,1,,,,,
17,1,,E0003030005,, "COLLAR T5.0, PIN 30",1,,,,,1,,,,,
18,1,,E1210000845,, "COTTER PIN",1,,,,,,,,,,,,,
19,1,,E1225120020,, SPRING,1,,,,,,,,,,,,,
20,1,,E1560001000,, "NIPPLE, GREASE PT1/8",1,,,,,,,,,,,,,
21,1,,E1101051080,, BOLT,1,,,,,,,,,,,,,
22,1,,E1100051020,, "BOLT M10X20",1,,,,,,,,,,,,,
23,1,,E1100040820,, "BOLT M 8X 20",1,,,,,,,,,,,,,
24,1,,E1130550010,, NUT,2,,,,,,,,,,,,,
25,1,,E1140020008,, "SPRING WASHER 8",1,,,,,,,,,,,,,
26,1,,E1140020008,, "SPRING WASHER 8",1,,,,,,,,,,,,,
27,1,,E1900033700,, "CYLINDER ASSY",1,,,,,2,,,,,
28,1,,E0068228500,, COVER,1,,,,,,,,,,,,,
29,1,,E0068229300,, COVER,1,,,,,,,,,,,,,
30,1,,E1100040816,, "BOLT M 8X 16",6,,,,,,,,,,,,,
31,1,,E1140020008,, "SPRING WASHER 8",6,,,,,,,,,,,,,
32,1,,E1141110008,, "WASHER 8",6,,,,,,,,,,,,,
33,1,,E0062214300,, ROD,1,,,,,,,,,,,,,
34,1,,E1141110008,, "WASHER 8",1,,,,,,,,,,,,,
35,1,,E1210002515,, "PIN, SPLIT",1,,,,,,,,,,,,,




```

1,1,,E0063257100,,STAND,1,,,,,,,,,,,,,,,,,
2,1,,E0063257200,,COVER,1,,,,,,,,,,,,,,,,,
3,1,,E0063257300,,COVER,1,,,,,,,,,,,,,,,,,
4,1,,E0063252500,,BRACKET,1,,,,,,,,,,,,,,,,,
5,1,,E0063252800,,LEVER(L,1,,,,,,,,,,,,,,,,,
6,1,,E0063252900,,LEVER(R,1,,,,,,,,,,,,,,,,,
7,1,,E0063257700,, "LEVER, ROCK",1,,,,,,,,,,,,,
8,1,,E0063255900,, "BLOCK, BEARING",2,,,,,,,,,,,,,
9,1,,E0063257800,,LEVER,1,,,,,,,,,,,,,,,,,
10,1,,E0063256200,,LEVER,1,,,,,,,,,,,,,,,,,
11,1,,E0063248900,,WASHER,3,,,,,,,,,,,,,,,,,
12,1,,E0543208900,,KNOB,1,,,,,,,,,,,,,,,,,
13,1,,E0068212800,,RUBBER,2,,,,,,,,,,,,,,,,,
14,1,,E0004215084,,SHAFT,1,,,,,,,,,,,,,,,,,
15,1,,E0007000023,,SPRING,1,,,,,,,,,,,,,,,,,
16,1,,E1620050000,, "LINK ASSY, JOINT",2,,,,,,,,,,,,,
17,1,,E1333001515,,BUSH,4,,,,,,,,,,,,,,,,,
18,1,,E1333001212,,BUSH,2,,,,,,,,,,,,,,,,,
19,1,,E1214000005,, "PIN 5",1,,,,,,,,,,,,,,,,,
20,1,,E1222000015,, "RING, SNAP",2,,,,,,,,,,,,,,,,,
21,1,,E1213010520,, "PIN, SPRING",1,,,,,,,,,,,,,,,,,
22,1,,E1213000425,, "PIN, SPRING",1,,,,,,,,,,,,,,,,,
23,1,,E1650200500,, "GRIP, LEVER",2,,,,,,,,,,,,,,,,,
24,1,,E1100041016,, "BOLT M10X16",4,,,,,,,,,,,,,,,,,
25,1,,E1100040820,, "BOLT M 8X 20",2,,,,,,,,,,,,,,,,,
26,1,,E1100040630,, "BOLT M 6X 30",4,,,,,,,,,,,,,,,,,
27,1,,E1100040612,, "BOLT M 6X12",10,,,,,,,,,,,,,,,,,
28,1,,E1140020010,, "SPRING WASHER 10",4,,,,,,,,,,,,,
29,1,,E1140020008,, "SPRING WASHER 8",2,,,,,,,,,,,,,
30,1,,E1140020006,, "SPRING WASHER 6",14,,,,,,,,,,,,,
31,1,,E1141110010,, "WASHER 10",1,,,,,,,,,,,,,,,,,
32,1,,E1120530510,, "SCREW M 5X10",2,,,,,,,,,,,,,,,,,
33,1,,E1140020005,, "SPRING WASHER 5",2,,,,,,,,,,,,,
34,1,,E1141110012,, "WASHER 12",3,,,,,,,,,,,,,,,,,

```


Fig. 10 コントロールレバー(ソウコウヨウ)
CONTROL LEVER (DRIVING)



1,1,,E0063255300,,BRACKET,2,,,,,,,,,,,,,
2,1,,E0063257900,,LEVER(L,1,,,,,,,,,,,,,
3,1,,E0063258000,,LEVER(R,1,,,,,,,,,,,,,
4,1,,E0063257400,, "ARM, LEVER", 2,,,,,,,,,,,,,
5,1,,E0063257500,,LEVER,2,,,,,,,,,,,,,
6,1,,E0063258100,,LEVER,2,,,,,,,,,,,,,
7,1,,E0063256100,,ROD,4,,,,,,,,,,,,,
8,1,,E0063248800,,BOOT,2,,,,,,,,,,,,,
9,1,,E0063248900,,WASHER,4,,,,,,,,,,,,,
10,1,,E0093208300,,WASHER,4,,,,,,,,,,,,,
11,1,,E0004215028,,SHAFT,2,,,,,,,,,,,,,
12,1,,E0003600025,,WASHER,2,,,,,,,,,,,,,
13,1,,E1340000085,,ROD-END,4,,,,,,,,,,,,,
14,1,,E1340300060,, "END, ROD", 4,,,,,,,,,,,,,
15,1,,E1333002020,,BUSHING,2,,,,,,,,,,,,,
16,1,,E1333001515,,BUSH,2,,,,,,,,,,,,,
17,1,,E1222000015,, "RING, SNAP", 4,,,,,,,,,,,,,
18,1,,E1213000525,, "SPRING PIN", 2,,,,,,,,,,,,,
19,1,,E1650201100,,GRIP,1,,,,,,,,,,,,,
20,1,,E1650201500,,GRIP,1,,,,,,,,,,,,,
21,1,,E1100040820,, "BOLT M 8X 20", 4,,,,,,,,,,,,,
22,1,,E1100040616,, "BOLT M 6X 16", 2,,,,,,,,,,,,,
23,1,,E1130040010,, "NUT M10", 2,,,,,,,,,,,,,
24,1,,E1130540008,,NUT,4,,,,,,,,,,,,,
25,1,,E1130140008,,NUT,6,,,,,,,,,,,,,
26,1,,E1130040006,, "NUT M 6", 12,,,,,,,,,,,,,
27,1,,E1100040625,, "BOLT M 6X 25", 8,,,,,,,,,,,,,
28,1,,E1140020010,, "SPRING WASHER 10", 2,,,,,,,,,,,,,
29,1,,E1140020008,, "SPRING WASHER 8", 8,,,,,,,,,,,,,
30,1,,E1140020006,, "SPRING WASHER 6", 2,,,,,,,,,,,,,


Fig. 11

コントロールレバー(ソウサヨウ)
CONTROL LEVER (OPERATION)




1,1,,E0063302100,,STAND,1,,,,,,,,,,,,,
2,1,,E0063300300,,LEVER,1,,,,,,,,,,,,,
3,1,,E0063302200,,LEVER,1,,,,,,,,,,,,,
4,1,,E0063302300,, "BOSS, LEVER",1,,,,,,,,,,,,,
5,1,,E0063302400,,LEVER,1,,,,,,,,,,,,,
6,1,,E0063300800,,PEDAL,1,,,,,,,,,,,,,
7,1,,E0063300900,,LEVER,1,,,,,,,,,,,,,
8,1,,E0063301000,, "ROD, YOKE",2,,,,,,,,,,,,,
9,1,,E0003600034,,WASHER,2,,,,,,,,,,,,,
10,1,,E0005008180,,ROD,1,,,,,,,,,,,,,
11,1,,E1220000020,, "SNAP RING S20",2,,,,,,,,,,,,,
12,1,,E1333002015,,BUSH,2,,,,,,,,,,,,,
13,1,,E1332052022,,MINI-PILLOW,2,,,,,,,,,,,,,
14,1,,E1340000080,,ROD-END,3,,,,,,,,,,,,,
15,1,,E1340000085,,ROD-END,1,,,,,,,,,,,,,
16,1,,E1213000830,, "SPRING PIN 8X 30",1,,,,,,,,,,,,,
17,1,,E1100041020,, "BOLT M10X 20",4,,,,,,,,,,,,,
18,1,,E1100040835,, "BOLT M 8X35",2,,,,,,,,,,,,,
19,1,,E1100040820,, "BOLT M 8X 20",1,,,,,,,,,,,,,
20,1,,E1100040816,, "BOLT M 8X 16",2,,,,,,,,,,,,,
21,1,,E1100040812,, "BOLT M 8X12",4,,,,,,,,,,,,,
22,1,,E1121050620,, "SCREW M 6X 20",2,,,,,,,,,,,,,
23,1,,E1130040008,, "NUT M 8",8,,,,,,,,,,,,,
24,1,,E1131540008,, "NUT, LEFT-HAND M 8",1,,,,,,,,,,,,,
25,1,,E1130040006,, "NUT M 6",2,,,,,,,,,,,,,
26,1,,E1140020010,, "SPRING WASHER 10",4,,,,,,,,,,,,,
27,1,,E1140020008,, "SPRING WASHER 8",10,,,,,,,,,,,,,
28,1,,E1214000005,, "PIN 5",2,,,,,,,,,,,,,
29,1,,E0004005117,, "PIN, LEVER",2,,,,,,,,,,,,,
30,1,,E1650200500,, "GRIP, LEVER",1,,,,,,,,,,,,,
31,1,,E1333002025,,BUSHING,1,,,,,,,,,,,,,

Fig. 12 **スイングレバー(スイングペダル)**
SWING LEVER (SWING PEDAL)




1,1,,E0064019100,, "FOOT,ENGINE(FR",1,,,,,,,,,,,,,
2,1,,E0064019200,, "FOOT,ENGINE(FL",1,,,,,,,,,,,,,
3,1,,E0064019300,, "FOOT,ENGINE(RR",1,,,,,,,,,,,,,
4,1,,E0064019400,, "FOOT,ENGINE(RL",1,,,,,,,,,,,,,
5,1,,E0064019500,, "BRACKET,RADIATOR",1,,,,,,,,,,,,,
6,1,,E0064016800,, STOPPER,2,,,,,,,,,,,,,
7,1,,E0144055300,, "SHIM 1.6T",2,,,,,,1,,,,,
8,1,,E0144055400,, "SHIM 2.3T",2,,,,,,1,,,,,
9,1,,E1651081361,, RUBBER,4,,,,,,,,,,,,,
10,1,,E1651014003,, "ABSORBER,SHOCK",4,,,,,,,,,,,,,
11,1,,E1702430280,, WIRE,1,,,,,,,,,,,,,
12,1,,E1101041245,, "BOLT M12X45",4,,,,,,,,,,,,,
13,1,,E1100041020,, "BOLT M10X 20",16,,,,,,,,,,,,,
14,1,,E1100041016,, "BOLT M10X16",2,,,,,,,,,,,,,
15,1,,E1100040820,, "BOLT M 8X 20",4,,,,,,,,,,,,,
16,1,,E1130040010,, "NUT M10",12,,,,,,,,,,,,,
17,1,,E1130040008,, "NUT M 8",8,,,,,,,,,,,,,
18,1,,E1140020010,, "SPRING WASHER 10",24,,,,,,,,,,,,,
19,1,,E1140020008,, "SPRING WASHER 8",12,,,,,,,,,,,,,
20,1,,E1141110010,, "WASHER 10",2,,,,,,,,,,,,,
21,1,,E1141110008,, "WASHER 8",4,,,,,,,,,,,,,
22,1,,E1141540012,, "WASHER 12",4,,,,,,,,,,,,,
23,1,,E1140330010,, "WASHER 10",2,,,,,,,,,,,,,
24,1,,119632-44500,, RADIATOR,1,,,,,,,,,,,,,
25,2,,124450-44590,, "CAP, RADIATOR",1,,,,,,,,,,,,,

Fig. 13 ラジエータ & エンジンマウント
RADIATOR & ENGINE MOUNT




1,1,,E0064019600,, "EXH. PIPE",1,,,,,,,,,,,,,
2,1,,E0064017000,, "BAND,MUFFLER",2,,,,,,,,,,,,,
3,1,,E1531407050,, TUBE,2,,,,,,,,,,,,,
4,1,,E1533120011,, "POWER BAND",4,,,,,,,,,,,,,
5,1,,E1100040820,, "BOLT M 8X 20",2,,,,,,,,,,,,,
6,1,,E1100040620,, "BOLT M 6X 20",2,,,,,,,,,,,,,
7,1,,E1130040008,, "NUT M 8",4,,,,,,,,,,,,,
8,1,,E1140020008,, "SPRING WASHER 8",14,,,,,,,,,,,,,
9,1,,E1140020006,, "SPRING WASHER 6",2,,,,,,,,,,,,,
10,1,,E1141110006,, WASHER,2,,,,,,,,,,,,,
11,1,,119688-49010,, "PIPE (A), C.W.",1,,,,,,,,,,,,,
12,1,,119632-49020,, "PIPE (B)",1,,,,,,,,,,,,,
13,1,,26366-080002,, "NUT M 8",1,,,,,,,,,,,,,
14,1,,121450-49100,, "BODY, COCK",1,,,,,,,,,,,,,
15,1,,119632-13500,, SILENCER,1,,,,,,,,,,,,,
16,1,,119632-13650,, "EXTENSION, SILENCER",1,,,,,,,,,,,,,
17,1,,124664-13580,, CLAMP,1,,,,,,,,,,,,,
18,1,,121450-13200,, "GASKET, SILENCER",2,,,,,,,,,,,,,
18-1,1,,121450-13201,, "GASKET, SILENCER",2,,,,,,N,,TL-90035,E041253,,,,,,
19,1,,23010-038000,, "CLAMP 38",4,,,,,,,,,,,,,
20,1,,124738-49150,, "PIPE, WATER DRAIN",1,,,,,,,,,,,,,
21,1,,121250-44590,, CLAMP,2,,,,,,,,,,,,,
22,1,,121250-49121,, PLUG,1,,,,,,,,,,,,,
23,1,,24311-000160,, "O-RING 1A P-16.0",1,,,,,,,,,,,,,
24,1,,194990-22050,, "NUT W/WASHER 8",8,,,,,,,,,,,,,
25,1,,26106-080552,, "BOLT M 8X 55 PLATED",1,,,,,,,,,,,,,

Fig. 14 エンジンカンレソウチ
ENGINE RELATED DEVICE




1,1,,E0064320100,, "PANEL, CONTROL",1,,,,,,,,,,,,,
2,1,,E0064321100,, "PANEL, CONTROL",1,,,,,,,,,,,,,
3,1,,E1652619260,, BUSHING,1,,,,,,,,,,,,,
4,1,,E1730045074,, "HOUR METER",1,,,,,,,,,,,,,
5,1,,E1730100010,, THERMOMETER,1,,,,,,,,,,,,,
6,1,,129155-77810,, RESISTOR,1,,,,,,,,,,,,,
7,1,,124732-77720,, "LAMP, CHARGING",1,,,,,,,,,,,,,
8,1,,124732-77970,, "LAMP, PILOT",1,,,,,,,,,,,,,
9,1,,119640-77710,, "LIMITER,CURRENT",1,,,,,,,,,,,,,
9-1,1,,119640-77711,, "LIMITER,CURRENT",1,,,,,R,,*,M/#X,,,,,,
10,1,,E1701200300,, "FUSE BOX",1,,,,,,,,,,,,,
11,1,,E1701000300,, "LIGHT SWITCH",1,,,,,,,,,,,,,
12,1,,E1652052200,, GROMMET,1,,,,,,,,,,,,,
13,1,,E1652050900,, GROMMET,2,,,,,,,,,,,,,
14,1,,E1100040816,, "BOLT M 8X 16",6,,,,,,,,,,,,,
15,1,,E1120530610,, "SCREW M6X 10",7,,,,,,,,,,,,,
16,1,,E1120530516,, "SCREW (+) M 5X16",2,,,,,,,,,,,,,
17,1,,E1140020008,, "SPRING WASHER 8",6,,,,,,,,,,,,,
18,1,,E1120530620,, "SCREW(+) M 6X 20",2,,,,,,,,,,,,,
19,1,,E1140330006,, WASHER,1,,,,,,,,,,,,,
20,1,,E0003608003,, WASHER,4,,,,,,,,,,,,,
21,1,,E1141110006,, WASHER,3,,,,,,,,,,,,,
22,1,,121522-77101,, RELAY,1,,,,,,,,,,,,,
23,1,,121522-77721,, "INDICATOR, CHARGING",1,,,,,,,,,,,,,
24,1,,E0064317300,, PLATE,1,,,,,,,,,,,,,
25,1,,E0064316500,, ANGLE,1,,,,,,,,,,,,,
26,1,,E1910030101,, "SWITCH, STARTER",1,,,,,,,,,,,,,
27,2,,E1910030102,, KEY,1,,,,,,,,,,,,,


Fig. **15** コントロールボックス CONTROL BOX <https://truckmanualshub.com/>




1,1,,E0064190030,, "ENGINE CONTROL ASSY",1,,,,,,,,,,,,,
2,2,,E0064128100,, BRACKET,1,,,,,,,,,,,,,
3,2,,E0064128200,, LEVER,1,,,,,,,,,,,,,
4,2,,E0064121800,, WASHER,1,,,,,,,,,,,,,
5,2,,E0064111700,, NUT,2,,,,,,,,,,,,,
6,2,,E1225120018,, WASHER,2,,,,,,,,,,,,,
7,2,,E1225000018,, WASHER,2,,,,,,,,,,,,,
8,2,,E1100040616,, "BOLT M 6X 16",2,,,,,,,,,,,,,
9,2,,E1140020006,, "SPRING WASHER 6",2,,,,,,,,,,,,,
10,2,,E1650200500,, "GRIP, LEVER",1,,,,,,,,,,,,,
11,2,,E0007000032,, SPRING,1,,,,,,,,,,,,,
12,2,,E1390000600,, "BALL, STEEL",1,,,,,,,,,,,,,
13,1,,E0064126300,, "CABLE, CONTROL",1,,,,,,,,,,,,,
14,1,,E0007900002,, BOLT,1,,,,,,,,,,,,,
15,1,,E0007900003,, PIN,2,,,,,,,,,,,,,
16,1,,E0007900014,, BOOT,1,,,,,,,,,,,,,
17,1,,E1224010006,, E-RING,2,,,,,,,,,,,,,
18,1,,E1110040510,, "BOLT, SOCKET",2,,,,,,,,,,,,,
19,1,,E1130140012,, NUT,2,,,,,,,,,,,,,
20,1,,E1652001002,, GROMMET,1,,,,,,,,,,,,,
21,1,,E0064127200,, STAY,1,,,,,,,,,,,,,
22,1,,E1100040816,, "BOLT M 8X 16",2,,,,,,,,,,,,,
23,1,,E1140020008,, "SPRING WASHER 8",2,,,,,,,,,,,,,



1,1,,E0064290080,, "HARNESS ASSY,WIRING",1,,,,,,,,,,,,,
2,2,,E0064249300,, "HARNESS,WIRING",1,,,,,,,,,,,,,
3,2,,E0064249200,, "HARNESS,WIRING",1,,,,,,,,,,,,,
4,1,,E0064249400,, WIRE,1,,,,,,,,,,,,,
4-1,1,,E0064251100,, WIRE,1,,,,,N, *, "M/# X",,,,,,
5,1,,E1703500412,, HORN,1,,,,,,,,,,,,,
5-1,1,,E1703500612,, HORN,1,,,,,R, *, M/#00869,,,,,
6,1,,E1703001500,, "LAMP, BOOM",1,,,,,,,,,,,,,
7,2,,E1703001506,, BULB,1,,,,,,,,,,,,,
8,1,,E0094245300,, WIRE,1,,,,,,,,,,,,,
9,1,,E1100040816,, "BOLT M 8X 16",1,,,,,,,,,,,,,
10,1,,E1140020008,, "SPRING WASHER 8",1,,,,,,,,,,,,,
11,1,,E0064416100,, HOLDER,1,,,,,,,,,,,,,
12,1,,E1702106260,, "HOOK BOLT",2,,,,,,,,,,,,,
13,1,,E1702015523,, BATTERY,1,,,,,,,,,,,,,
14,1,,E1702530060,, "CABLE, BATTERY L=600",1,,,,,,,,,,,,,
15,1,,E1702230340,, CABLE,1,,,,,,,,,,,,,
16,1,,E0097210300,, "GUARD, HOSE",1,,,,,,,,,,,,,
17,1,,E1702308513,, TERMINAL,1,,,,,,,,,,,,,
18,1,,E1702910007,, COVER,1,,,,,,,,,,,,,
19,1,,E1702901279,, COVER,1,,,,,,,,,,,,,
20,1,,E1654705180,, "STRIP,RUBBER",2,,,,,,,,,,,,,
21,1,,E1703211050,, "TUBE L500",1,,,,,,,,,,,,,
22,1,,E1130040008,, "NUT M 8",1,,,,,,,,,,,,,
23,1,,E1141110008,, "WASHER 8",1,,,,,,,,,,,,,
24,1,,E1130040006,, "NUT M 6",4,,,,,,,,,,,,,
25,1,,E1100051016,, "BOLT M10X 16",1,,,,,,,,,,,,,
26,1,,E1140330010,, "WASHER 10",1,,,,,,,,,,,,,
27,1,,E0544201500,, WIRE,2,,,,,,,,,,,,,
28,1,,E0064250100,, "HARNESS,WIRING",1,,,,,,,,,,,,,




1,1,,E0009101060,, "NIPPLE, PIPE",1,,,,,,,,,,,,,
2,1,,E1508000001,, "ELBOW (PT1/8)",1,,,,,,,,,,,,,
3,1,,E1532520601,, CONNECTOR,5,,,,,,,,,,,,,
4,1,,E1532020690,, TUBE,1,,,,,,,,,,,,,
5,1,,E1532020665,, "TUBE 650L",1,,,,,,,,,,,,,
6,1,,E1560001000,, "NIPPLE, GREASE PT1/8",3,,,,,,,,,,,,,
7,1,,E1532620601,, ELBOW,1,,,,,,,,,,,,,
8,1,,E1532020638,, TUBE,1,,,,,,,,,,,,,
9,1,,E1652200004,, "TIE WRAP",1,,,,,,,,,,,,,




1,1,,E0007203015,,ADAPTOR,6,,,,,,,,,,,,,
2,1,,E0007203022,,ADAPTOR,6,,,,,,,,,,,,,
3,1,,E1501300004,, "ELBOW 90°",1,,,,,,,,,,,,,
4,1,,E1502132104,,ADAPTOR,1,,,,,,,,,,,,,
5,1,,E1501910404,,ADAPTOR,1,,,,,,,,,,,,,
6,1,,E1502321203,, "NIPPLE,ELBOW",2,,,,,,,,,,,,,
7,1,,E1511100003,, "ELBOW 90°",1,,,,,,,,,,,,,
8,1,,E1420010110,, "O-RING P11-1B",12,,,,,,,,,,,,,
9,1,,E1901022100,, "VALVE,MAIN CONTROL",1,,,,,,,,1,,,,,,,,,
10,1,,E1100040825,, "BOLT M 8X25",3,,,,,,,,,,,,,
11,1,,E1100040820,, "BOLT M 8X 20",1,,,,,,,,,,,,,
12,1,,E1140020008,, "SPRING WASHER 8",4,,,,,,,,,,,,,

Fig. 19 **メインバルブ & フソクヒン**
MAIN VALVE & ACCESSORIES




1,1,,E0007203023,,ADAPTOR,2,,,,,,,,,,,,,
2,1,,E1513400003,,CONNECTOR,2,,,,,,,,,,,,,
2-1,1,,E1513400003,,CONNECTOR,1,,,,,K,,*,M/#00521,,,,,
3,1,,E0009900008,,NIPPLE,1,,,,,,,,,,,,,
4,1,,E1502711203,, "NIPPLE,ELBOW",1,,,,,,,,,,,,,
5,1,,E1502821203,,ADAPTOR,1,,,,,,,,,,,,,
6,1,,E1501300002,, "STREET ELBOW1/4,90°",2,,,,,,,,,,,,,
7,1,,E1513400001,,ADAPTOR,2,,,,,,,,,,,,,
8,1,,E1511000002,,ADAPTOR,2,,,,,,,,,,,,,
9,1,,E1511100003,, "ELBOW 90°",2,,,,,,,,,,,,,
10,1,,E1501300004,, "ELBOW 90°",1,,,,,,,,,,,,,
11,1,,E0009104065,,NIPPLE,1,,,,,,,,,,,,,
12,1,,E1508000004,, "ELBOW 90°",1,,,,,,,,,,,,,
13,1,,E1420010140,, "O-RING 1B-P14",4,,,,,,,,,,,,,
14,1,,E1901023400,, "SUB-CONTROL V.ASSY.",1,,,,,1,,,,,
15,1,,E1100040612,, "BOLT M 6X12",2,,,,,,,,,,,,,
16,1,,E1140020008,, "SPRING WASHER 8",2,,,,,,,,,,,,,
17,1,,E1501600403,,ADAPTER,1,,,,,W,,*,M/#00521,,,,,

Fig. **20** サブバルブ & フソクヒン SUB VALVE & ACCESSORIES




1,1,,E0067035200,,PIPE,1,,,,,,,,,,,,,
2,1,,E0067027100,, "PIPE, INLET",1,,,,,,,,,,,,,
3,1,,E0007221003,,NIPPLE,3,,,,,,,,,,,,,
4,1,,E1909109145,, "HOSE ASSY",1,,,,,,,,,,,,,
5,1,,E1909109125,, "HOSE ASSY",1,,,,,,,,,,,,,
6,1,,E1909109110,, "HOSE ASSY",1,,,,,,,,,,,,,
7,1,,E1513310009,, "ELBOW 90°",3,,,,,,,,,,,,,
8,2,,E1420310910,, "O-RING APR568-910-1B",3,,,,,,,,,,,,,
9,1,,E1530520032,,HOSE,3,,,,,,,,,,,,,
10,1,,E1530526035,, "HOSE ASSY",1,,,,,,,,,,,,,
10-1,1,,E1530526060,, "HOSE (600), LOW-PRESS",1,,,,,,,,N,,*, "M/# X",,,,,,,,,,
11,1,,E1530520029,, "HOSE ASSY",1,,,,,,,,,,,,,
11-1,1,,E1530520045,, "HOSE, LOW-PRESS.",1,,,,,,,,N,,*, "M/# X",,,,,,,,,,
12,1,,E1530532045,, "HOSE ASSY",1,,,,,,,,,,,,,
13,1,,E1533001030,, "CLAMP, WIRE",8,,,,,,,,,,,,,
14,1,,E1533001035,, "CLAMP 35, WIRE",2,,,,,,,,,,,,,
15,1,,E1533001045,, "CLAMP, WIRE",2,,,,,,,,,,,,,
16,1,,E1533201010,, "U-BOLT ASSY",1,,,,,,,,,,,,,
17,1,,E1652003602,,GROMMET,3,,,,,,,,,,,,,
18,1,,E1652002502,,GROMMET,4,,,,,,,,,,,,,
19,1,,E1420310912,, "O-RING ARP568-912-1B",3,,,,,,,,,,,,,
20,1,,E1130040008,, "NUT M 8",2,,,,,,,,,,,,,
20-1,1,,E1130040008,, "NUT M 8",3,,,,,,K,,*, M/#00731,,,,,,,,,
21,1,,E1140020008,, "SPRING WASHER 8",5,,,,,,,,,,,,,
22,1,,E1532620601,,ELBOW,1,,,,,,,,,,,,,
23,1,,E1501400201,,ADAPTOR,1,,,,,,,,,,,,,
24,1,,E1532020635,, "TUBE TC-206",1,,,,,,,,,,,,,
25,1,,E1531335040,,HOSE,1,,,,,,,,,,,,,
26,1,,E1531350020,,HOSE,1,,,,,,,,,,,,,
27,1,,E0007300001,,CLAMP,1,,,,,,,,,,,,,
28,1,,E1100040812,, "BOLT M 8X12",2,,,,,,1,,,,,,,,,,,,,
28-1,1,,E1100040816,, "BOLT M 8X 16",2,,,,,,N,,*, "M/# X",,,,,,,,,,
29,1,,E1141110008,, "WASHER 8",2,,,,,,,,,,,,,
30,1,,E1100040816,, "BOLT M 8X 16",1,,,,,,,,,,,,,
30-1,1,,E1100040825,, "BOLT M 8X25",1,,,,,,S,,*, M/#00731,,,,,,,,,
31,1,,E0007300003,, "CLAMP, HOSE",1,,,,,,,,,,,,,

Fig. **21** ジョウブユアツハイカン(1)
UPPER HYDRAULIC OIL PIPING (1)




1,1,,E0067035100,,CLAMP,1,,,,,,,,,,,,,
2,1,,E0067032200,,PIPE,1,,,,,,,,,,,,,
3,1,,E0067032300,,PIPE,1,,,,,,,,,,,,,
4,1,,E0007200042,,ADAPTOR,2,,,,,,,,,,,,,
5,1,,E0007262003,,ADAPTOR,2,,,,,,,,,,,,,
6,1,,E0007200054,,ADAPTOR,1,,,,,,,,,,,,,
7,1,,E1909408040,, "PIPE (8X 400)",2,,,,,,,,,,,,,
8,1,,E1909408085,, "PIPE 8X 850",1,,,,,,,,,,,,,
9,1,,E1909408045,, "PIPE 8X 450",2,,,,,,,,,,,,,
10,1,,E1909408050,, "PIPE 8X 500",1,,,,,,,,,,,,,
10-1,1,,E1920882500,,PIPE,1,,,,,,N,,*,M/#00537,,,,,,
11,1,,E1909408080,, "PIPE, HIGH-PRESSURE",1,,,,,,,,,,,,,
12,1,,E1909108050,, "HOSE ASSY",1,,,,,,,,,,,,,
13,1,,E1909108030,, "HOSE ASSY",1,,,,,,,,,,,,,
14,1,,E1909408065,, "HOSE ASSY",1,,,,,,,,,,,,,
15,1,,E1511100002,, "ELBOW (90°)",2,,,,,,,,,,,,,
16,1,,E1511000002,,ADAPTOR,5,,,,,,,,,,,,,
17,1,,E1511200002,, "ELBOW (45°)",1,,,,,,,,,,,,,
18,1,,E1501300002,, "STREET ELBOW1/4,90°",1,,,,,,,,,,,,,
19,1,,E1515000211,, "ELBOW 90°",2,,,,,,,,,,,,,
20,2,,E1420010110,, "O-RING P11-1B",2,,,,,,,,,,,,,
21,1,,E1110050830,, "BOLT, SOCKET",1,,,,,,,,,,,,,
22,1,,E1531335030,, "HOSE, PROTECTOR",1,,,,,,,,,,,,,
23,1,,E1531335050,,HOSE,1,,,,,,,,,,,,,




Fig. **22** ジョウブユアツハイカン(2) UPPER HYDRAULIC OIL PIPING (2)



```
1,1,,E0065216100,,HOUSING,1,,,,,,,,,,,,,  
2,1,,E0065215200,,CUPLING,1,,,,,,,,,,,,,  
3,1,,E0065216200,,PLATE,1,,,,,,,,,,,,,  
4,1,,E1602000080,, "COUPLING, FLEX",1,,,,,,,,,,,,,  
5,1,,E1902008300,, "PUMP ASSY",1,,,,,,,,,,,,,  
6,1,,E1400503217,, "SEAL, OIL",1,,,,,,,,,,,,,  
7,1,,E1110041030,, "BOLT, SOCKET",3,,,,,,,,,,,,,  
8,1,,E1110041040,, "BOLT M10X 40",3,,,,,,,,,,,,,  
9,1,,E1100041025,, "BOLT M10X 25",10,,,,,,,,,,,,,  
10,1,,E1140020010,, "SPRING WASHER 10",8,,,,,,,,,,,,,  
11,1,,E1141120010,, WASHER,2,,,,,,,,,,,,,  
12,1,,E1213000408,, "PIN, SPRING",9,,,,,,,,,,,,,
```




1,1,,E0068090100,, "TANK ASSY, HYD. OIL", 1,,,,,,,,,,,,,
3,2,,E0068025200,, FLANGE, 1,,,,,,,,,,,,,
4,2,,E0068023300,, GASKET, 1,,,,,,,,,,,,,
5,2,,E0218010900,, PLUG, 1,,,,,,,,,,,,,
6,2,,E1541201616,, GASKET, 1,,,,,,,,,,,,,
7,2,,E1501750010,, PLUG, 1,,,,,,,,,,,,,
7-1,2,,E1501750010,, PLUG, 3,,,,,,K, *, M/#01199,,,,,,
8,2,,E1550100500,, STRAINER, 1,,,,,,,,,,,,,
9,2,,E1553020655,, "GAUGE, OIL LEVEL", 1,,,,,,,,,,,,,
10,2,,E1508700010,, PLUG, 1,,,,,,Z, *, M/#01091,,,,,,
11,2,,E1100040818,, BOLT, 4,,,,,,,,,,,,,
12,2,,E1140020008,, "SPRING WASHER 8", 4,,,,,,,,,,,,,
13,2,,E1420010290,, "O-RING 1B-P29", 1,,,,,,,,,,,,,
13-1,2,,E1420010290,, "O-RING 1B-P29", 3,,,,,,K, *, M/#01199,,,,,,
14,2,,E1501750014,, PLUG, 2,,,,,,W, 1, *, M/#01091,,,,,,
14-1,2,,E1501750014,, PLUG, 2,,,,,,Z, 1, *, M/#01198,,,,,,
15,2,,E1420010440,, O-RING, 2,,,,,,W, 1, *, M/#01091,,,,,,
15-1,2,,E1420010440,, O-RING, 2,,,,,,Z, 1, *, M/#01198,,,,,,
16,1,,E1551045180,, "FILTER ASSY, SPIN", 1,,,,,,,,,,,,,
17,2,,E1551035180,, CARTRIDGE, 1,,,,,,,,,,,,,
18,1,,E1508200010,, TEE, 1,,,,,,Z, *, M/#00840,,,,,,
19,1,,E1513000010,, NIPPLE, 1,,,,,,Z, *, M/#00840,,,,,,
20,1,,E1508700010,, PLUG, 1,,,,,,Z, *, M/#00840,,,,,,
21,1,,E1100041020,, "BOLT M10X 20", 4,,,,,,,,,,,,,
22,1,,E1141540010,, "WASHER M10", 4,,,,,,,,,,,,,
23,1,,E1508000006,, ELBOW, 1,,,,,,Z, *, M/#00840,,,,,,
24,1,,E0009900003,, "NIPPLE, HOSE", 1,,,,,,Z, *, M/#00840,,,,,,
25,1,,E1513000006,, "NIPPLE PT3/4", 1,,,,,,Z, *, M/#00840,,,,,,
26,1,,E1508500006,, "NIPPLE 3/4", 1,,,,,,Z, *, M/#00840,,,,,,
27,1,,E1508600604,, ADAPTOR, 1,,,,,,Z, *, M/#00840,,,,,,
28,1,,E0009900008,, NIPPLE, 1,,,,,,Z, *, M/#00840,,,,,,
29,1,,E1508200006,, TEE, 1,,,,,,Z, *, M/#00840,,,,,,
30,1,,E1508601006,, ADAPTOR, 1,,,,,,Z, *, M/#00840,,,,,,
31,1,,E0068027200,, NIPPLE, 1,,,,,,W, *, M/#00841,,,,,,





1,1,,E0068190070,, "FUEL TANK ASSY",1,,,,,,,,,,,,,
3,2,,E0007200090,, "VALVE, DRAIN",1,,,,,,,,,,,,,
4,2,,E0068119200,, "LEVEL GAUGE",1,,,,,,,,,,,,,
5,2,,E1533120015,, "BAND, POWER",1,,,,,,,,,,,,,
6,2,,E1552001022,, COVER,1,,,,,,,,,,,,,
7,2,,E1552002012,, "SCREEN, FUEL OIL TANK",1,,,,,,,,,,,,,
8,2,,E1531010028,, TUBE,2,,,,,,,,,,,,,
9,2,,E1533001015,, "CLAMP, WIRE",2,,,,,,,,,,,,,
10,1,,129322-77400,, "FEED PUMP",1,,,,,,,,,,,,,
11,1,,E1531207010,, HOSE,1,,,,,,,,,,,,,
12,1,,E1531207020,, HOSE,1,,,,,,,,,,,,,
13,1,,E1531207022,, HOSE,1,,,,,,,,,,,,,
14,1,,E1531203650,, HOSE,1,,,,,,,,,,,,,
15,1,,E1533120012,, "CLIP, HOSE",6,,,,,,,,,,,,,
16,1,,E1533120008,, "CLIP, HOSE",2,,,,,,,,,,,,,
17,1,,E1100041035,, "BOLT M10X 35",4,,,,,,,,,,,,,
18,1,,E1100040865,, "BOLT M 8X 65",1,,,,,,,,,,,,,
19,1,,E1100040612,, "BOLT M 6X12",2,,,,,,,,,,,,,
20,1,,E1140020010,, "SPRING WASHER 10",4,,,,,,,,,,,,,
21,1,,E1140020008,, "SPRING WASHER 8",1,,,,,,,,,,,,,
22,1,,E1140020006,, "SPRING WASHER 6",2,,,,,,,,,,,,,
23,1,,E0003000072,, COLLAR,4,,,,,,,,,,,,,
24,1,,E0003600025,, WASHER,4,,,,,,,,,,,,,

1 inc.(1)~9
▼




1,1,,E0068231100,, "COVER, ENGINE",1,,,,,,,,,,,,,
2,1,,E0068239100,, "COVER, ENGINE",1,,,,,,,,,,,,,
3,1,,E0068231600,, COVER,1,,,,,,,,,,,,,
4,1,,E0068231800,, COVER,1,,,,,,,,,,,,,
5,1,,E0068233200,, ANGLE,1,,,,,,,,,,,,,
6,1,,E0068232600,, ROCK,1,,,,,,,,,,,,,
7,1,,E0068232700,, BRACKET,1,,,,,,,,,,,,,
8,1,,E0004206111,, SHAFT,1,,,,,,,,,,,,,
9,1,,E0068212100,, ROD,1,,,,,,,,,,,,,
10,1,,E0068212200,, YOKE,1,,,,,,,,,,,,,
11,1,,E0108218300,, HINGE,2,,,,,,,,,,,,,
12,1,,E0007000060,, SPRING,1,,,,,,,,,,,,,
13,1,,E0004206091,, "SHAFT, LEVER",2,,,,,,,,,,,,,
14,1,,E0004008021,, PIN,2,,,,,,,,,,,,,
15,1,,E1652505400,, "CUSHION, RUBBER",2,,,,,,,,,,,,,
16,1,,E1224010004,, CLIP,6,,,,,,,,,,,,,
17,1,,E1652052400,, GROMET,1,,,,,,,,,,,,,
18,1,,E1214000006,, "SNAP PIN",2,,,,,,,,,,,,,
19,1,,E1214000010,, "PIN (R)",1,,,,,,,,,,,,,
20,1,,E1100041025,, "BOLT M10X 25",4,,,,,,,,,,,,,
21,1,,E1100041020,, "BOLT M10X 20",4,,,,,,,,,,,,,
22,1,,E1100041016,, "BOLT M10X16",4,,,,,,,,,,,,,
23,1,,E1100040820,, "BOLT M 8X 20",2,,,,,,,,,,,,,
24,1,,E1100040816,, "BOLT M 8X 16",6,,,,,,,,,,,,,
25,1,,E1140020010,, "SPRING WASHER 10",12,,,,,,,,,,,,,
26,1,,E1140020008,, "SPRING WASHER 8",8,,,,,,,,,,,,,
27,1,,E1141110010,, "WASHER 10",2,,,,,,,,,,,,,
28,1,,E1141110008,, "WASHER 8",6,,,,,,,,,,,,,
29,1,,E0003600020,, WASHER,8,,,,,,,,,,,,,
30,1,,E0003608003,, WASHER,2,,,,,,,,,,,,,
31,1,,E1652511007,, "RUBBER, CUSHION",1,,,,,,,,,,,,,




1,1,,E0068243300,,COVER,1,,,,,,,,,,,,,
2,1,,E0068244200,,STAND,1,,,,,,,,,,,,,
3,1,,E0068238300,,COVER,1,,,,,,,,,,,,,
4,1,,E0068231700,,COVER,1,,,,,,,,,,,,,
5,1,,E0068231900,,COVER,1,,,,,,,,,,,,,
6,1,,E0068244300,,ANGLE,1,,,,,,,,,,,,,
7,1,,E0068243200,,STAGE,1,,,,,,,,,,,,,
8,1,,E0068228200,, "PLATE,RUBBER",1,,,,,,,,,,,,,
9,1,,E0068228700,, "PLATE,RUBBER",2,,,,,,,,,,,,,
10,1,,E1653611325,,LOCK,1,,,,,,,,,,,,,
11,2,,E1654000702,,KEY,1,,,,,,,,,,,,,
12,1,,E1652512200,,CUSHION,2,,,,,,,,,,,,,
13,1,,E0068232400,,ANGLE,1,,,,,,,,,,,,,
14,1,,E1213000420,, "PIN, SPRING 4X20",2,,,,,,,,,,,,,
15,1,,E1100041025,, "BOLT M10X 25",2,,,,,,,,,,,,,
16,1,,E1100041020,, "BOLT M10X 20",2,,,,,,,,,,,,,
17,1,,E1100040820,, "BOLT M 8X 20",2,,,,,,,,,,,,,
18,1,,E1100040816,, "BOLT M 8X 16",21,,,,,,,,,,,,,
19,1,,E1120530516,, "SCREW (+) M 5X16",4,,,,,,,,,,,,,
20,1,,E1140020010,, "SPRING WASHER 10",4,,,,,,,,,,,,,
21,1,,E1140020008,, "SPRING WASHER 8",23,,,,,,,,,,,,,
22,1,,E1140020005,, "SPRING WASHER 5",4,,,,,,,,,,,,,
23,1,,E1141110008,, "WASHER 8",16,,,,,,,,,,,,,
24,1,,E0003600020,,WASHER,4,,,,,,,,,,,,,
25,1,,E0003608003,,WASHER,9,,,,,,,,,,,,,
26,1,,E1653916009,,H-RUBBER,1,,,,,,,,,,,,,
27,1,,E1100041016,, "BOLT M10X16",1,,,,,,,,,,,,,


Fig. **27** ボンネットカンケイ(2)
BONNET RELATION (2)



1,1,,E1914100024,, "SEAT ASSY",1,,,,,,,,,,,,,
2,1,,E0063414100,, SPACER,2,,,,,,,,,,,,,
3,1,,E1100040830,, "BOLT M 8X 30",4,,,,,,,,,,,,,
4,1,,E1140020008,, "SPRING WASHER 8",4,,,,,,,,,,,,,




1,1,,E0068422100,,POLE(R,1,,,,,,,,,,,,,
2,1,,E0068422200,,POLE(L,1,,,,,,,,,,,,,
3,1,,E0068422300,,CANOPY,1,,,,,,,,,,,,,
4,1,,E0068422400,,HOOD,1,,,,,,,,,,,,,
5,1,,E0068430100,,GUARD,1,,,,,,,,,,,,,
6,1,,E1101041225,, "BOLT M12X 25",8,,,,,,,,,,,,,
7,1,,E1100041020,, "BOLT M10X 20",8,,,,,,,,,,,,,
8,1,,E1140020012,, "SPRING WASHER 12",8,,,,,,,,,,,,,
9,1,,E1140020010,, "SPRING WASHER 10",8,,,,,,,,,,,,,
10,1,,E1141110010,, "WASHER 10",8,,,,,,,,,,,,,
11,1,,E0068430200,, "GUARD,FRONT(R",1,,,,,,,,,,,,,
12,1,,E0068430300,, "GUARD,FRONT(L",1,,,,,,,,,,,,,
13,1,,E1100040816,, "BOLT M 8X 16",8,,,,,,,,,,,,,
14,1,,E1140020008,, "SPRING WASHER 8",8,,,,,,,,,,,,,
15,1,,E0003608003,,WASHER,8,,,,,,,,,,,,,



1,1,,E0066090010,, "BOOM ASSY",1,,,,,,,,,,,,,
3,2,,E0002330040,, "BUSH, SPIRAL",2,,,,,,,,,,,,,
4,2,,E0003500013,, "COLLAR, MEDDLE",1,,,,,,Z,,*,M/#X,,,,,,,,,
5,2,,E1560001900,, "NIPPLE, PT1/8, GREASE",1,,,,,,,,,,,,,
6,1,,E0066015200,, "COVER, ROD",1,,,,,,,,,,,,,
6-1,1,,E0066021100,, "COVER",1,,,,,,S,,*,M/#00781,,,,,,,,,
7,1,,E0001403002,, "PIN",1,,,,,,,,,,,,,
8,1,,E0001423001,, "PIN",1,,,,,,,,,,,,,
8-1,1,,E0001900139,, "PIN",1,,,,,,S,,*,M/#00781,,,,,,,,,
9,1,,E0001030137,, "PIN, BOOM",2,,,,,,,,,,,,,
10,1,,E0001030121,, "PIN, BOOM CYL.HEAD",1,,,,,,,,,,,,,
11,1,,E0003900012,, "WASHER",2,,,,,,,,,,,,,
12,1,,E0103113200,, "WASHER",1,,,,,,,,,,,,,
12-1,1,,E0003608003,, "WASHER",1,,,,,,S,,*,M/#00781,,,,,,,,,
13,1,,E0003030003,, "COLLAR T3.2, PIN 30",9,,,,,,1,,,,,,,,,
14,1,,E0003030004,, "COLLAR T4.0, PIN 30",9,,,,,,1,,,,,,,,,
15,1,,E0003030005,, "COLLAR T5.0, PIN 30",9,,,,,,1,,,,,,,,,
16,1,,E1132620024,, "NUT, CASTLE",2,,,,,,,,,,,,,
17,1,,E1210000845,, "COTTER PIN",9,,,,,,,,,,,,,
18,1,,E1210000545,, "COTTER PIN",2,,,,,,,,,,,,,
19,1,,E1560001000,, "NIPPLE, GREASE PT1/8",5,,,,,,,,,,,,,
20,1,,E1225120020,, "SPRING",1,,,,,,,,,,,,,
20-1,1,,E1225120016,, "SPRING",1,,,,,,S,,*,M/#00781,,,,,,,,,
21,1,,E1100040820,, "BOLT M 8X 20",1,,,,,,,,,,,,,
22,1,,E1140020008,, "SPRING WASHER 8",1,,,,,,,,,,,,,
22-1,1,,E1140020008,, "SPRING WASHER 8",3,,,,,,K,,*,M/#00780,,,,,,,,,
23,1,,E0003000070,, "COLLAR",1,,,,,,Z,4,*,"M/# X",,,,,,,,,,
24,1,,E0066190010,, "ARM ASSY",1,,,,,,2,,,,,,,,,
25,1,,E0066190020,, "ARM ASSY",1,,,,,,3,,,,,,,,,
28,2,,E0002330104,, "BUSH, SPIRAL",3,,,,,,,,,,,,,
29,1,,E0076100700,, "PLTTE (R), LOCKER",1,,,,,,,,,,,,,
30,1,,E0076100800,, "PLATE (L), LOCKER",1,,,,,,,,,,,,,
31,1,,E0001900036,, "PIN, BUCKET CYLINDER",1,,,,,,,,,,,,,
32,1,,E0001330170,, "PIN, BOOM POINT",3,,,,,,,,,,,,,
33,1,,E0001030112,, "PIN",2,,,,,,,,,,,,,
34,1,,E0076190000,, "ARM ASSY, STICK",1,,,,,,,,,,,,,
36,2,,E0002330104,, "BUSH, SPIRAL",1,,,,,,,,,,,,,
37,2,,E0002100010,, "BUSH",2,,,,,,,,,,,,,
38,1,,E1900033200,, "CYLINDER ASSY, ARM",1,,,,,,,,,,,,,
38-1,1,,E1900040000,, "ARM CYLINDER ASSY",1,,,,,,S,,X,M/#00521,,,,,,,,,
39,1,,E1900027100,, "CYLINDER, BUCKET",1,,,,,,,,,,,,,
40,1,,E1900033300,, "CYLINDER ASSY",1,,,,,,5,,,,,,,,,
40-1,1,,E1900039900,, "CYLINDER ASSY",1,,,,,,S,,*,M/#00521,,,,,,,,,
40-2,1,,E1900042000,, "CYLINDER, BOOM",1,,,,,,S,,*,M/#00781,,,,,,,,,
41,1,,E0306009200,, "SLIDE",2,,,,,,W,,*,M/#00781,,,,,,,,,
42,1,,E1100040835,, "BOLT M 8X35",2,,,,,,W,,*,M/#00781,,,,,,,,,

Fig. 30 **ブーム & アーム** **BOOM & ARM**


<https://truckmanualshub.com/>



1,1,,E0076201400,, "BUCKET 400",1,,,,,,,,,,,,,
2,2,,E0166200608,, TEETH,4,,,,,,,,,,,,,
3,2,,E0076200109,, "CUTTER, SIDE",2,,,,,,,,,,,,,
4,2,,E0002900009,, BUSHING,4,,,,,,,,,,,,,


Fig. **31** バケット BUCKET <https://truckmanualshub.com/>

1 inc. 2~4




1,1,,E0067332500,,PIPE(R,1,,,,,,,,,,,,,
2,1,,E0067332600,,PIPE(L,1,,,,,,,,,,,,,
3,1,,E0067332700,,PIPE,2,,,,,,,,,,,,,
4,1,,E0067332800,,CLAMP,1,,,,,,,,,,,,,
5,1,,E0067325400,,PLATE,2,,,,,,,,,,,,,
6,1,,E0067310200,, "CLAMP, PIPE",2,,,,,,,,,,,,,
7,1,,E0067310300,, "GUARD, PIPE",2,,,,,,,,,,,,,
8,1,,E0077320400,, "CLAMP, RUBBER",1,,,,,,,,,,,,,
9,1,,E0076000114,,CLAMP,2,,,,,,,,,,,,,
10,1,,E0076000115,, "CLAMP, PIPE",2,,,,,,,,,,,,,
11,1,,E1909900023,, "HOSE ASSY",2,,,,,,,,,,,,,
12,1,,E1909408090,, "PIPE 8X 900",1,,,,,,,,,,,,,
13,1,,E1909408085,, "PIPE 8X 850",2,,,,,,,,,,,,,
14,1,,E1909408080,, "PIPE, HIGH-PRESSURE",1,,,,,,,,,,,,,
15,1,,E1909008036,, "HOSE ASSY",2,,,,,,,,,,,,,
16,1,,E1908106065,, "PIPE (6X 650)",2,,,,,,,,,,,,,
17,1,,E1531354015,,HOSE,1,,,,,,,,,,,,,
18,1,,E1531115004,,HOSE,2,,,,,,,,,,,,,
19,1,,E1511000002,,ADAPTOR,2,,,,,,,,,,,,,
20,1,,E1511100002,, "ELBOW (90°)",4,,,,,,,,,,,,,
21,1,,E0067325500,,PLATE,2,,,,,,,,,,,,,
22,1,,E1100040830,, "BOLT M 8X 30",7,,,,,,,,,,,,,
23,1,,E1100040812,, "BOLT M 8X12",2,,,,,,,,,,,,,
24,1,,E1140020008,, "SPRING WASHER 8",9,,,,,,,,,,,,,

Fig. 32 ユアツハイカン(ブーム & アーム)
HYD. OIL PIPING (BOOM & ARM)




1,1,,E0069390400,, "LABEL SET",1,,,,,,,,,,,,,
2,2,,E0069336100,, "LABEL, MODEL",2,,,,,,,,,,,,,
3,2,,E0069361200,, "STRIPE A",1,,,,,,,,,,,,,
4,2,,E0069362200,, "STRIPE B",1,,,,,,,,,,,,,
5,2,,E0069362300,, "STRIPE C",1,,,,,,,,,,,,,
6,2,,E0069362400,, "STRIPE D",1,,,,,,,,,,,,,
7,2,,E0069362500,, "STRIPE E",1,,,,,,,,,,,,,
8,2,,E0069362600,, "STRIPE F",1,,,,,,,,,,,,,
9,2,,E0069362700,, "STRIPE G",1,,,,,,,,,,,,,
10,2,,E0069362800,, "STRIPE H",1,,,,,,,,,,,,,
11,2,,E0069362900,, LABEL,1,,,,,,,,,,,,,
12,2,,E0069337100,, "YANMAR MARK",2,,,,,,,,,,,,,
13,2,,E0099321100,, "YANMAR MARK",1,,,,,,,,,,,,,
14,2,,E0069390001,, "LABEL SET,SUB",1,,,,,,,,,,,,,
21,2,,E0069361100,, "LABEL, LEVER ROCK",1,,,,,W,,*,M/#00501,,,,,,,,,




14




A 矢視
VIEW "A"



1 inc. 2 ~ 21




1,1,,104200-92350,, "DRIVER, SCREW",1,,,,,,,,,,,,,
2,1,,28210-000140,, "OIL FEEDER",1,,,,,,,,,,,,,
3,1,,124550-35350,, REMOVER,1,,,,,,,,,,,,,
4,1,,28110-100120,, "WRENCH 10X12",1,,,,,,,,,,,,,
5,1,,28110-140170,, "WRENCH 14X17",1,,,,,,,,,,,,,
6,1,,28110-190220,, "WRENCH 19X22",1,,,,,,,,,,,,,
7,1,,E0069290030,, "TOOL SET",1,,,,,,,,,,,,,
8,2,,E1690100013,, "WRENCH 13",1,,,,,,,,,,,,,
9,2,,E1690850026,, "WRENCH 26",1,,,,,,,,,,,,,
10,2,,E0007900009,, PIPE,1,,,,,,,,,,,,,
11,2,,E1690500200,, "PLIER 200",1,,,,,,,,,,,,,
12,2,,E1690300330,, "HAMMER 3/4",1,,,,,,,,,,,,,
13,2,,E1691060600,, "GUN, GREASE",1,,,,,1,,,,,,,,,
13-1,2,,E1691050300,, "GUN, GREASE",1,,,,,N,*,M/#00501,,,,,
14,2,,E1691100003,, "NOZZLE, GREASE GUN",1,,,,,,,,,,,,,
15,2,,E1690400250,, "WRENCH 250",1,,,,,,,,,,,,,
16,2,,E1690600500,, "WRENCH 5",1,,,,,,,,,,,,,
17,2,,E1690600800,, "WRENCH 8",1,,,,,,,,,,,,,
18,2,,E1690002427,, "WRENCH 24X27",1,,,,,,,,,,,,,
19,2,,E0007900001,, PUNCH,1,,,,,,,,,,,,,
20,2,,E1691400001,, "BOX, TOOL",1,,,,,,,,,,,,,
21,1,,E1914009120,, "PIN, TRACK",3,,,,,,,,,,,,,
22,1,,E1914009103,, "WASHER, TRACK PIN",4,,,,,,,,,,,,,
23,1,,E1213000620,, "SPRING PIN, TRACK",4,,,,,,,,,,,,,
24,1,,E1210000845,, "COTTER PIN",3,,,,,,,,,,,,,
25,1,,E1691500001,, HOLDER,1,,,,,Z,1,*, "M/# X",,,,,,





1,1,,E1904003700,, "SWIVEL JOINT",1,,,,,,,,,,,,,
2,2,,E1904003799,, "SEAL SET",1,,,,,,,,,,,,,
11,2,,E1904003791,, "WASHER, THRUST",1,,,,,,,,,,,,,
12,2,,E1904000893,, "CIRCLIP, SHAFT",1,,,,,,,,,,,,,
13,2,,E1110040820,, "BOLT M 8X 20",4,,,,,,,,,,,,,
14,2,,E1501810001,, "PLUG PT1/8",2,,,,,,,,,,,,,

Fig. **35** スイベルジョイント
SWIVEL JOINT <https://truckmanualshub.com/>



1,1,,E1901022100,, "VALVE,MAIN CONTROL",1,,,,,,,,,,,,,
2,2,,E1901022113,, "BLOCK ASSY,BACKET",1,,,,,,1,,,,,,,,,
3,2,,E1901022111,, "BLOCK ASSY,BOOM",1,,,,,,1,,,,,,,,,
4,2,,E1901022116,, "BLOCK ASSY,TRACTION",1,,,,,,1,,,,,,,,,
5,2,,E1901021315,, "BLOCK ASSY,TRACTION",1,,,,,,1,,,,,,,,,
6,2,,E1901022112,, "BLOCK ASSY,ARM",1,,,,,,1,,,,,,,,,
7,2,,E1901022114,, "BLOCK ASSY,SLEW",1,,,,,,1,,,,,,,,,
8,3,,E1432900036,, "SEAL,OIL",12,,,,,,,,,,,,,
9,3,,E1901009841,, "HOLDER,SEAL",12,,,,,,,,,,,,,
10,3,,E1901004151,, "HOLDER,SPRING",12,,,,,,,,,,,,,
11,3,,E1901021356,, SPRING,6,,,,,,,,,,,,,
12,3,,E1901020391,, SPACER,6,,,,,,,,,,,,,
13,3,,E1110050820,, "BOLT M 8X20",6,,,,,,,,,,,,,
14,3,,E1901004162,, COVER,6,,,,,,,,,,,,,
15,3,,E1110050610,, "BOLT M 6X 10",12,,,,,,,,,,,,,
16,3,,E1110050620,, "BOLT M 6X 20",12,,,,,,,,,,,,,
17,2,,E1901021301,, HOUSING,1,,,,,,,,,,,,,
18,2,,E1901021302,, HOUSING,1,,,,,,,,,,,,,
19,2,,E1901022102,, HOUSING,1,,,,,,,,,,,,,
20,2,,E1501810002,, "PLUG PT 1/4",3,,,,,,,,,,,,,
21,2,,E1420110550,, "O-RING G55-1B",8,,,,,,,,,,,,,
22,2,,E1901022106,, "TIE ROD",3,,,,,,,,,,,,,
23,2,,E1130050008,, "NUT M 8",6,,,,,,,,,,,,,
24,2,,E1901021821,, "VALVE ASSY,RELIEF",1,,,,,,,,,,,,,
25,2,,E1901021322,, "VALVE ASSY,OV.LOAD",2,,,,,,,,,,,,,
26,2,,E1901022166,, PLUG,2,,,,,,,,,,,,,
27,2,,E1420510125,, O-RING,2,,,,,,,,,,,,,
28,2,,E1420010150,, O-RING,2,,,,,,,,,,,,,
29,2,,E1420010220,, "O-RING P22-1B",3,,,,,,,,,,,,,
30,2,,E1432900010,, O-RING,1,,,,,,,,,,,,,
31,2,,E1420510090,, O-RING,1,,,,,,,,,,,,,
32,2,,E1901021368,, PLUG,1,,,,,,,,,,,,,
33,2,,E1901021357,, SPRING,3,,,,,,,,,,,,,
34,2,,E1901021367,, SPACER,3,,,,,,,,,,,,,
35,2,,E1901021366,, VALVE,3,,,,,,,,,,,,,


1 inc. 2~35



1,1,,E1901023400,, "SUB-CONTROL V.ASSY.",1,,,,,,,,,,,,,
2,2,,E1901022218,, "SWING SWITCH VALVE",1,,,,,1,,,,,,
3,2,,E1901022217,, "BLADE SWITCH VALVE",1,,,,,1,,,,,,
4,3,,E1901009866,, CHECK,2,,,,,,,,,,,,,
5,3,,E1901016156,, SPRING,2,,,,,,,,,,,,,
6,3,,E1901004166,, PLUG,2,,,,,,,,,,,,,
7,3,,E1420010140,, "O-RING 1B-P14",2,,,,,,,,,,,,,
8,3,,E1432900036,, "SEAL,OIL",4,,,,,,,,,,,,,
9,3,,E1901009841,, "HOLDER,SEAL",4,,,,,,,,,,,,,
10,3,,E1110050610,, "BOLT M 6X 10",4,,,,,,,,,,,,,
11,3,,E1901020391,, SPACER,2,,,,,,,,,,,,,
12,3,,E1901021356,, SPRING,2,,,,,,,,,,,,,
13,3,,E1901004151,, "HOLDER,SPRING",4,,,,,,,,,,,,,
14,3,,E1901004162,, COVER,2,,,,,,,,,,,,,
15,3,,E1110050820,, "BOLT M 8X20",2,,,,,,,,,,,,,
16,3,,E1110050620,, "BOLT M 6X 20",4,,,,,,,,,,,,,
17,2,,E1901016105,, "HOUSING,INLET",1,,,,,,,,,,,,,
18,2,,E1901023404,, "HOUSING,OUTLET",1,,,,,,,,,,,,,
19,2,,E1901022201,, "HOUSING,INLET",1,,,,,,,,,,,,,
20,2,,E1901021821,, "VALVE ASSY,RELIEF",2,,,,,,,,,,,,,
21,3,,E1420010220,, "O-RING P22-1B",2,,,,,,,,,,,,,
22,3,,E1432900010,, O-RING,2,,,,,,,,,,,,,
23,2,,E1501810002,, "PLUG PT 1/4",2,,,,,,,,,,,,,
24,2,,E1420110550,, "O-RING G55-1B",4,,,,,,,,,,,,,
25,2,,E1901022206,, BOLT,4,,,,,,,,,,,,,
26,2,,E1130050008,, "NUT M 8",8,,,,,,,,,,,,,


Fig. **37** サブコントロールバルブ(スイング & ブレード)
SUB CONTROL VALVE (SWING & BLADE)

1 inc. 2 ~ 26




1,1,,E1901714000,, "C.B.VALVE ASS'Y.",1,,,,,,,,,,,,,
2,2,,E1420000070,, "O-RING 1A, P7",2,,,,,,,,,,,,,
3,2,,E1420010090,, "O-RING 1B P 9.0",4,,,,,,,,,,,,,
4,2,,E1420010101,, "O-RING 1B, P10A",2,,,,,,,,,,,,,
5,2,,E1420110250,, "O-RING 1B. G25",2,,,,,,,,,,,,,
6,1,,E1901501300,, "BRAKE VALVE ASSY",1,,,,,,,,,,,,,
7,2,,E1420010070,, "O-RING 1B. P7",2,,,,,,,,,,,,,
8,2,,E1420010240,, O-RING,2,,,,,,,,,,,,,
9,2,,E1420010120,, "O-RING 1B-P12",2,,,,,,,,,,,,,
10,2,,E1110050860,, "BOLT, SOCKET",4,,,,,,,,,,,,,

Fig. **38** ブレーキバルブ & カウンターバランスバルブ
<https://truckmanualshop.com/>
 BRAKE VALVE & COUNTER BALANCE VALVE




カウンタ-バランスバルブ
 COUNTER BALANCE VALVE



ブレーキバルブ
 BLAKE VALVE


1,1,,E1900033300,, "CYLINDER ASSY",1,,,,,,,,,,,,,
1-1,1,,E1900039900,, "CYLINDER ASSY",1,,,,,,S,1,X,M/#00521,,,,,,
2,2,,E1900031899,, "SEAL KIT",1,,,,,,,,,,,,,
2-1,2,,E1900039999,, "SEAL KIT",1,,,,,,S,1,X,M/#00521,,,,,,
10,2,,E1410706012,, "RING, WEAR",1,,,,,,,,,,,,,
11,2,,E1900033001,, "PISTON ROD",1,,,,,,,,,,,,,
11-1,2,,E1900039901,, "PISTON ROD",1,,,,,,S,1,X,M/#00521,,,,,,
12,2,,E1900029402,, BUSHING,2,,,,,,,,,,,,,
12-1,2,,E1900021502,, BUSH,2,,,,,,S,1,X,M/#00521,,,,,,
13,2,,E1900033303,, "ROD COVER",1,,,,,,,,,,,,,
13-1,2,,E1900031803,, "ROD COVER",1,,,,,,S,1,X,M/#00521,,,,,,
14,2,,E1900033004,, RETAINER,1,,,,,,,,,,,,,
14-1,2,,E1900039904,, RETAINER,1,,,,,,S,1,X,M/#00521,,,,,,
15,2,,E1900022955,, "HOLDER, PACKING",1,,,,,,,,,,,,,
15-1,2,,E1900009850,, "HOLDER, U-RING",1,,,,,,S,1,X,M/#00521,,,,,,
16,2,,E1900022906,, PISTON,1,,,,,,,,,,,,,
16-1,2,,E1900009806,, PISTON,1,,,,,,S,1,X,M/#00521,,,,,,
17,2,,E1900033007,, TUBE,1,,,,,,,,,,,,,
17-1,2,,E1900039907,, TUBE,1,,,,,,S,1,X,M/#00521,,,,,,
18,2,,E1900000309,, NUT,1,,,,,,,,,,,,,
18-1,2,,E1900021409,, NUT,1,,,,,,S,1,X,M/#00521,,,,,,
19,2,,E1900033011,, SPRING,1,,,,,,,,,,,,,
19-1,2,,E1900039911,, SPRING,1,,,,,,S,1,X,M/#00521,,,,,,
20,2,,E1900033012,, "GUIDE, SPRING",1,,,,,,,,,,,,,
20-1,2,,E1900039912,, "GUIDE, SPRING",1,,,,,,S,1,X,M/#00521,,,,,,
21,2,,E1900033015,, SPACER,1,,,,,,,,,,,,,
21-1,2,,E1900039915,, SPACER,1,,,,,,S,1,X,M/#00521,,,,,,
22,2,,E1900033016,, "CUSHION RING",1,,,,,,,,,,,,,
22-1,2,,E1900039916,, "CUSHION RING",1,,,,,,S,1,X,M/#00521,,,,,,
23,2,,E1560001000,, "NIPPLE, GREASE PT1/8",1,,,,,,,,,,,,,
24,2,,E1560001675,, "NIPPLE, GREASE PT1/8",1,,,,,,,,,,,,,
25,2,,E1210000545,, "COTTER PIN",1,,,,,,,,,,,,,
26,2,,E1333003525,, BUSH,1,,,,,,,,,,,,,

Fig. **39** ブームシリンダー (キョウカ・タ)
BOOM CYLINDER (PREVIOUS)
UP TO M/# ~ 00780



1,1,,E1900042000,, "CYLINDER, BOOM",1,,,,,,,,,,,,,
2,2,,E1900042099,, "SEAL KIT",1,,,,,,,,,,,,,
10,2,,E1410706012,, "RING, WEAR",1,,,,,,,,,,,,,
11,2,,E1900042001,, "PISTON ROD",1,,,,,,,,,,,,,
12,2,,E1900021502,, BUSH,2,,,,,,,,,,,,,
13,2,,E1900042003,, "ROD COVER",1,,,,,,,,,,,,,
14,2,,E1900042004,, RETAINER,1,,,,,,,,,,,,,
15,2,,E1900033505,, BEARING,1,,,,,,,,,,,,,
16,2,,E1900042055,, "HOLDER, PACKING",1,,,,,,,,,,,,,
17,2,,E1900042006,, PISTON,1,,,,,,,,,,,,,
18,2,,E1900042007,, TUBE,1,,,,,,,,,,,,,
19,2,,E1900021409,, NUT,1,,,,,,,,,,,,,
20,2,,E1900033515,, SPACER,1,,,,,,,,,,,,,
21,2,,E1900042016,, "CUSHION RING",1,,,,,,,,,,,,,
22,2,,E1560001000,, "NIPPLE, GREASE PT1/8",1,,,,,,,,,,,,,
23,2,,E1560001675,, "NIPPLE, GREASE PT1/8",1,,,,,,,,,,,,,
24,2,,E1210000545,, "COTTER PIN",1,,,,,,,,,,,,,
25,2,,E1333003525,, BUSH,1,,,,,,,,,,,,,


Fig. **40** ブームシリンダー (ツカ・タ)
 BOOM CYLINDER (NEW TYPE)
 FROM TO M/ #00781 ~




1,1,,E1900033200,, "CYLINDER ASSY, ARM",1,,,,,,,,,,,,,
1-1,1,,E1900040000,, "ARM CYLINDER ASSY",1,,,,,,S,1,X,M/#00521,,,,,,
2,2,,E1900009999,, "SEAL SET",1,,,,,,,,,,,,,
2-1,2,,E1900032299,, "SEAL KIT",1,,,,,,S,1,X,M/#00521,,,,,,
10,2,,E1410706012,, "RING, WEAR",1,,,,,,,,,,,,,
11,2,,E1900023001,, "PISTON ROD",1,,,,,,,,,,,,,
11-1,2,,E1900040001,, "PISTON ROD",1,,,,,,S,1,X,M/#00521,,,,,,
12,2,,E1900023002,, BUSH,1,,,,,,,,,,,,,
12-1,2,,E1900015402,, BUSH,1,,,,,,S,1,X,M/#00521,,,,,,
13,2,,E1900029402,, BUSHING,1,,,,,,,,,,,,,
13-1,2,,E1900021502,, BUSH,1,,,,,,S,1,X,M/#00521,,,,,,
14,2,,E1900023003,, "COVER, ROD",1,,,,,,,,,,,,,
14-1,2,,E1900009903,, "COVER, ROD",1,,,,,,S,1,X,M/#00521,,,,,,
15,2,,E1900023055,, "HOLDER, U-RING",1,,,,,,,,,,,,,
15-1,2,,E1900009850,, "HOLDER, U-RING",1,,,,,,S,1,X,M/#00521,,,,,,
16,2,,E1900023006,, PISTON,1,,,,,,,,,,,,,
16-1,2,,E1900009806,, PISTON,1,,,,,,S,1,X,M/#00521,,,,,,
17,2,,E1900023207,, TUBE,1,,,,,,,,,,,,,
17-1,2,,E1900040007,, TUBE,1,,,,,,S,1,X,M/#00521,,,,,,
18,2,,E1900023008,, "HOLDER, ROD PACKING",1,,,,,,,,,,,,,
18-1,2,,E1900009908,, "HOLDER, ROD PACKING",1,,,,,,S,1,X,M/#00521,,,,,,
19,2,,E1900000309,, NUT,1,,,,,,,,,,,,,
19-1,2,,E1900021409,, NUT,1,,,,,,S,1,X,M/#00521,,,,,,
20,2,,E1221000045,, "SNAP RING 45",1,,,,,,,,,,,,,
20-1,2,,E1900009914,, "RING, SNAP",1,,,,,,S,1,X,M/#00521,,,,,,
21,2,,E1333003525,, BUSH,1,,,,,,,,,,,,,
22,2,,E1210000545,, "COTTER PIN",1,,,,,,,,,,,,,
23,2,,E1560001900,, "NIPPLE, PT1/8, GREASE",2,,,,,,,,,,,,,

Fig. **41** アームシリンダー
ARM CYLINDER <https://truckmanualshub.com/>

1 inc. 2 ~ 23




1,1,,E1900027100,, "CYLINDER, BUCKET",1,,,,,,,,,,,,,
2,2,,E1900009999,, "SEAL SET",1,,,,,,,,,,,,,
10,2,,E1410706012,, "RING, WEAR",1,,,,,,,,,,,,,
11,2,,E1900010001,, "ROD ASSY, PISTON",1,,,,,,,,,,,,,
12,2,,E1900015402,, BUSH,2,,,,,,,,,,,,,
13,2,,E1900009903,, "COVER, ROD",1,,,,,,,,,,,,,
14,2,,E1900009850,, "HOLDER, U-RING",1,,,,,,,,,,,,,
15,2,,E1900009806,, PISTON,1,,,,,,,,,,,,,
16,2,,E1900027107,, TUBE,1,,,,,,,,,,,,,
17,2,,E1900009908,, "HOLDER, ROD PACKING",1,,,,,,,,,,,,,
18,2,,E1900021409,, NUT,1,,,,,,,,,,,,,
19,2,,E1900009914,, "RING, SNAP",1,,,,,,,,,,,,,
20,2,,E1900027118,, COVER,1,,,,,,,,,,,,,
21,2,,E1333003525,, BUSH,1,,,,,,,,,,,,,
22,2,,E1210000545,, "COTTER PIN",1,,,,,,,,,,,,,
23,2,,E1560001900,, "NIPPLE, PT1/8, GREASE",1,,,,,,,,,,,,,
23-1,2,,E1560001675,, "NIPPLE, GREASE PT1/8",1,,,,,N,,*,M/#XXX,,,,,,
24,2,,E1560001000,, "NIPPLE, GREASE PT1/8",1,,,,,,,,,,,,,
25,2,,E1100000618,, BOLT,3,,,,,,,,,,,,,
26,2,,E1140000006,, "WASHER, SPRING",3,,,,,,,,,,,,,



1,1,,E1900015300,, "BLADE CYLINDER ASSY",1,,,,,,,,,,,,,
2,2,,E1900015399,, "SEAL KIT",1,,,,,,,,,,,,,
10,2,,E1410706012,, "RING, WEAR",1,,,,,,,,,,,,,
11,2,,E1900010201,, "ROD, PISTON",1,,,,,,,,,,,,,
12,2,,E1900009920,, "BUSH, PIN",2,,,,,,,,,,,,,
13,2,,E1900009903,, "COVER, ROD",1,,,,,,,,,,,,,
14,2,,E1900009850,, "HOLDER, U-RING",1,,,,,,,,,,,,,
15,2,,E1900009806,, PISTON,1,,,,,,,,,,,,,
16,2,,E1900015307,, TUBE,1,,,,,,,,,,,,,
17,2,,E1900009908,, "HOLDER, ROD PACKING",1,,,,,,,,,,,,,
18,2,,E1900009809,, NUT,1,,,,,,,,,,,,,
19,2,,E1333003525,, BUSH,1,,,,,,,,,,,,,
20,2,,E1210000545,, "COTTER PIN",1,,,,,,,,,,,,,
21,2,,E1220000045,, "SNAP RING",1,,,,,,,,,,,,,


Fig. **43** ハイダンスリンダー
BLADE CYLINDER

inc. 2 ~ 21





1,1,,E1900033700,, "CYLINDER ASSY",1,,,,,,,,,,,,,
2,2,,E1900033799,, "SEAL KIT",1,,,,,,,,,,,,,
10,2,,E1410706312,, "RING,WEAR",1,,,,,,,,,,,,,
11,2,,E1900033701,, "ROD,PISTON",1,,,,,,,,,,,,,
12,2,,E1900015402,, BUSH,2,,,,,,,,,,,,,
13,2,,E1900027003,, "COVER,ROD",1,,,,,,,,,,,,,
14,2,,E1900033755,, "HOLDER,PACKING",1,,,,,,,,,,,,,
15,2,,E1900027006,, PISTON,1,,,,,,,,,,,,,
16,2,,E1900033707,, TUBE,1,,,,,,,,,,,,,
17,2,,E1900009908,, "HOLDER,ROD PACKING",1,,,,,,,,,,,,,
18,2,,E1900021409,, NUT,1,,,,,,,,,,,,,
19,2,,E1900009914,, "RING,SNAP",1,,,,,,,,,,,,,
20,2,,E1333003525,, BUSH,1,,,,,,,,,,,,,
21,2,,E1210002545,, "PIN,SPRIT",1,,,,,,,,,,,,,
22,2,,E1560001000,, "NIPPLE,GREASE PT1/8",1,,,,,,,,,,,,,
23,2,,E1501810001,, "PLUG PT1/8",1,,,,,,,,,,,,,

Fig. 44 スイングシリンダー SWING CYLINDER <https://www.manualshub.com/>



1,1,,E1903105500,, "MOTOR ASSY",1,,,,,,,,,,,,,
2,2,,E1903009300,, "HYD. OIL MOTOR",1,,,,,,,,,,,,,
3,3,,E1903009399,, "SEAL KIT",1,,,,,,,,,,,,,
12,3,,E1903103626,, "PLATE, SPACER",1,,,,,,,,,,,,,
13,3,,E1903103628,, "PLATE, VALVE",1,,,,,,,,,,,,,
14,3,,E1903103630,, VALVE,1,,,,,,,,,,,,,
15,3,,E1903103631,, PLATE,1,,,,,,,,,,,,,
16,3,,E1903103632,, SPRING,2,,,,,,,,,,,,,
17,3,,E1903103634,, PIN,2,,,,,,,,,,,,,
18,3,,E1903009336,, DRIVE,1,,,,,,,,,,,,,
19,3,,E1903009337,, ROLLER,1,,,,,,,,,,,,,
20,3,,E1903102624,, "VALVE DRIVE",1,,,,,,,,,,,,,
21,3,,E1903103640,, "STEEL BALL",2,,,,,,,,,,,,,
22,3,,E1903103641,, PLUG,2,,,,,,,,,,,,,
23,3,,E1903103643,, "HOUSING, VALVE",1,,,,,,,,,,,,,
24,3,,E1903103644,, PLUG,1,,,,,,,,,,,,,
25,3,,E1903103646,, "PLUG, BLIND",1,,,,,,,,,,,,,
26,3,,E1903009347,, BOLT,4,,,,,,,,,,,,,
27,3,,E1901501313,, "PLAT, NAME",1,,,,,,,,,,,,,
28,3,,E1901501314,, RIVET,2,,,,,,,,,,,,,
29,2,,E1912003300,, "REDUCTION UNIT",1,,,,,,,,,,,,,
30,3,,E1912003399,, "SEAL KIT",1,,,,,,,,,,,,,
35,3,,E1912003301,, FLANGE,1,,,,,,,,,,,,,
36,3,,E1903103607,, "SNAP RING",1,,,,,,,,,,,,,
37,3,,E1912003306,, HOUSING,1,,,,,,,,,,,,,
38,3,,E1110050615,, BOLT,9,,,,,,,,,,,,,
39,3,,E1912003308,, COVER,1,,,,,,,,,,,,,
40,3,,E1501810003,, "PLUG PT3/8",2,,,,,,,,,,,,,
41,2,,E1912003311,, "SUN GEAR",1,,,,,,,,,,,,,
42,2,,E1912003312,, "THRUST WASHER",1,,,,,,,,,,,,,
43,2,,E1912003313,, "THRUST WASHER",1,,,,,,,,,,,,,
44,2,,E1220000110,, CIRCLIP(S),1,,,,,,,,,,,,,
45,2,,E1912003319,, SPACER,1,,,,,,,,,,,,,
46,2,,E1903103606,, BEARING,2,,,,,,,,,,,,,
47,2,,E1912003322,, PIN,1,,,,,,,,,,,,,
48,2,,E1912003323,, BUSH,1,,,,,,,,,,,,,
49,2,,E1903105591,, "SUN GEAR S/A",1,,,,,,,,,,,,,
50,2,,E1903105592,, "FLOATING SEAL ASSY",1,,,,,,,,,,,,,




A 矢視
VIEW "A"

1,1,,E1903104800,, "MOTOR ASSY",1,,,,,,,,,,,,,
2,2,,E1903104899,, "SEAL KIT",1,,,,,,,,,,,,,
7,2,,E1903102699,, "SEAL KIT",1,,,,,,,,,,,,,

Fig. 46 センカイモーター
TURNING MOTOR


1 inc. 2, 7



1,1,,E1902008300,, "PUMP ASSY",1,,,,,,,,,,,,,
2,2,,E1902006299,, "SEAL KIT",1,,,,,,,,,,,,,
9,2,,E1902006416,, COVER,1,,,,,,,,,,,,,
10,2,,E1902006417,, "PLATE,CENTER",2,,,,,,,,,,,,,
11,2,,E1902006418,, "FLANGE,MOUNTING",1,,,,,,,,,,,,,
12,2,,E1902006519,, "COUPLING,SPLINE",2,,,,,,,,,,,,,
13,2,,E1902008320,, BOLT,4,,,,,,,,,,,,,
14,2,,E1140010010,, "SPRING WASHER",4,,,,,,,,,,,,,
15,2,,E1902008391,, "FRONT PUMP ASSY",1,,,,,,,,,,,,,
16,2,,E1902008392,, "CENTER PUMP ASSY",1,,,,,,,,,,,,,
17,2,,E1902008393,, "REAR PUMP ASSY",1,,,,,,,,,,,,,


Fig. **47** ユアツポンプ HYDRAULIC PUMP <https://www.manualshub.com/>

1 inc. 2 ~ 17



1,1,,E0076201300,, "BUCKET 250",1,,,,,,,,,,,,,
2,2,,E0166200608,, TEETH,3,,,,,,,,,,,,,
3,2,,E0076200109,, "CUTTER, SIDE",2,,,,,,,,,,,,,
4,2,,E0002900009,, BUSHING,4,,,,,,,,,,,,,
5,1,,E0076201500,, "BUCKET 300",1,,,,,,,,,,,,,
6,2,,E0166200608,, TEETH,3,,,,,,,,,,,,,
7,2,,E0076200109,, "CUTTER, SIDE",2,,,,,,,,,,,,,
8,2,,E0002900009,, BUSHING,4,,,,,,,,,,,,,
9,1,,E0076201100,, "BUCKET 350",1,,,,,,,,,,,,,
10,2,,E0166200608,, TEETH,3,,,,,,,,,,,,,
11,2,,E0076200109,, "CUTTER, SIDE",2,,,,,,,,,,,,,
12,2,,E0002900009,, BUSHING,4,,,,,,,,,,,,,
13,1,,E0076201200,, "BUCKET 450",1,,,,,,,,,,,,,
14,2,,E0166200608,, TEETH,4,,,,,,,,,,,,,
15,2,,E0076200109,, "CUTTER, SIDE",2,,,,,,,,,,,,,
16,2,,E0002900009,, BUSHING,4,,,,,,,,,,,,,

Fig. **48** バケット(オプション)
BUCKET (OPTIONAL) <https://manualshub.com/>



1,1,,E0071007100,, "LOWER FRAME",1,,,,,,,,,,,,,
2,1,,E0071005600,, COVER,1,,,,,,,,,,,,,
3,1,,E0071006700,, COVER(L,1,,,,,,,,,,,,,
4,1,,E0071006800,, COVER(R,1,,,,,,,,,,,,,
5,1,,E0071001700,, "SLIDER, SHOE",4,,,,,,,,,,,,,
5-1,1,,E0071008400,, SLID,4,,,,,,S,*M/#00695,,,,,,
6,1,,E1100051018,, "BOLT 10X18",8,,,,,,,,,,,,,
7,1,,E1140010010,, "SPRING WASHER",8,,,,,,,,,,,,,
8,1,,E1100040816,, "BOLT M 8X 16",4,,,,,,,,,,,,,
9,1,,E1140010008,, "SPRING WASHER 8",8,,,,,,,,,,,,,
10,1,,E1110041020,, "BOLT M10X 20",6,,,,,,,,,,,,,
11,1,,E1140020010,, "SPRING WASHER 10",6,,,,,,,,,,,,,
12,1,,E1141540010,, "WASHER M10",6,,,,,,,,,,,,,
13,1,,E1913002500,, "BEARING,TURNING",1,,,,,,,,,,,,,
14,1,,E1101051250,, "BOLT M12X 50",16,,,,,,,,,,,,,
15,1,,E1101051240,, "BOLT M12X40",18,,,,,,,,,,,,,
16,1,,E1141540012,, "WASHER 12",34,,,,,,,,,,,,,
17,1,,E0072100100,, STOPPER,1,,,,,,,,,,,,,
18,1,,E1904003700,, "SWIVEL JOINT",1,,,,,,1,,,,,,
19,1,,E1101051225,, "BOLT M12X25",2,,,,,,,,,,,,,
20,1,,E1140010012,, "SPRING WASHER 12",2,,,,,,,,,,,,,
21,1,,E1100050825,, "BOLT M 8X 25",4,,,,,,,,,,,,,
22,1,,E1130050008,, "NUT M 8",4,,,,,,,,,,,,,
23,1,,E1560001000,, "NIPPLE,GREASE PT1/8",2,,,,,,,,,,,,,