https://truckmanualshub.com/

HINO
Quick Reference Guide
2005-2010
(Updated June, 2009)

©2009 HINO MOTORS SALES USA INC · LT-0010

HINO Quick Reference Guide 2005-2010 Model Years

The Quick Reference Guide is designed to help you quickly look up parts for commonly ordered parts. The format has been changed from previous years.

The main sections are in alphabetical order but the Sub-sections are not.

The **PART NAME** is listed in the first column. The name refers to what HINO may call the part or what the typical truck industry name is.

The second column **DESCRIPTION** gives more detailed information about what the part includes or does not include.

The third column is the actual **PART NUMBER** and should be entered as shown. Supercessions may apply.

The forth column is the **MODEL** this part applies to and the model years that it applies to.

The fifth column is the **GROUP**. HINO uses five major groups. Engine – Electrical – Drive – Cab Rear Body and Chassis/Tool

The sixth column is the **FIGURE #** that the part can be found in the Hino Electronic Parts Catalog and is helpful if you need other parts in addition to what's listed in the Quick Reference Guide.

HINO Production Series Code

In order to insure you are ordering the correct part number for the vehicle you are working on it is critical that you use the Production Series Code. This is located just below the VIN number on the VIN plate. The plate is attached to the passenger side doorjamb on all conventional trucks. The Production Series Code can also be found in Dealer Connect through the warranty screen. Go to DC600 then DC611 and then click on options. The vehicle options will be displayed and the Production Series Code is shown directly below the header – Options – It will always consist of two letters and 1 number.



See the example shown above from the EPC.
The P/N 420807191A applies to the
Production Series Code of AA2

The second part number of 420807201A
applies to the Production Series Code of BA2

© 2009 HINO MOTOR SALES USA INC
Subject to change without notice
OEM names for reference purposes only.

https://truckmanualshub.com/

VIN Identification

Explanation of HINO VIN Number

JHB NA 6J F 2 5 1 S 10001

(Manufactures I.D.)
JHB – Built in Japan
5PV – Built in USA
(1-3)

Model (see list*)
(4-5)

Engine Type (see list)**
(6-7)

Wheelbase - Higher Letter is a Longer Wheelbase (see list *)**
(8)

Check Digit
(9)

Model Year (see list **)**
(10)

Assembly Plant Code
1= Japan 2= Long Beach CA.
(11)

Production Modification Code
(S) Starting (Initial Production)
(T) Major Production Modification)
(12)

Sequential Series Number
Chassis I.D. Number
(13-17)

**Engine Type

6J	J05D-TA	175HP
8J	J08E-TA	220HP
8J	J08E-TB	260HP

***Wheelbase

Code	Inches	Kind
F	147	LDT
G	152	MDT
J	175	LDT
K	183	LDT
L	187	LDT
M	201	MDT
N	212	MDT
P	217	MDT
R	235	MDT
T	253	MDT
V	271	MDT

*Model

Code	Model	GVW	Brake
NA	145	14,050	Hydraulic
NB	165	16,000	Hydraulic
NC	185	18,000	Hydraulic
ND	238/258	23,000/ 25,500	Hydraulic
NE	268	25,950	Hydraulic
NJ	268A	25,950	Full Air
NV	338	33,000	Full Air

****Model Year

Code	Year	Code	Year
5	2005	B	2011
6	2006	C	2012
7	2007	D	2013
8	2008	E	2014
9	2009	F	2015
A	2010	G	2016

https://truckmanualshub.com/

Accessories Guide

HINO 2005-2010 Accessories Guide

Note: some kit quantities are not shown in inventory and are assembled after order is placed.

Description	Part Number
Block Heater JO5E-TA (4 Cyl.)	3510238K4
Block Heater JO8E-TA (6 Cyl.)	3510238K6
Glow Plug Kit JO5E-TA (4 Cyl.)	191101271K4
Glow Plug Kit JO8E-TA (6 Cyl.)	191101271K6
Heated Mirror Kit with Lights	87902KIT05
Chrome Heated Mirror Kit. '08 Models only	87902KIT08C
Black Heated Mirror Kit. '08 Models only	87902KIT08B
Chrome Mirror Cover Kit. 2008 Models Only	87902KITCC
Fender mounted Mirror Kit (contains one mirror. Fits either side ALL MODELS)	97687
52 Gal. Dual Fuel Tank Conversion for ND, NE, NJ, NV. 2005-2008	D61
95 Gal. Fuel Tank Conversion for ND, NE, NJ, NV. 2005-2008	771004620K
For 2009 trucks or trucks using Aluminum fuel tanks you must buy the parts kit and the tanks separate. For 52gl Dual Fuel Tank	FAD61 (parts kit only) S7740E0430 Al. 52gl tank
For 2009 trucks or trucks using Aluminum fuel tanks you must by the parts kit and the tank separate. For 95gl Fuel Tank	FA771004620K (parts kit only) S7740E0450 Al. 95gl tank
Pac Brake (Exhaust Brake)4 Cyl. Eaton Manual Transmission. 2005-2007	C40012
Pac Brake (Exhaust Brake) 6 Cyl. With Air Brakes. 2005-2007	C40013
Pac Brake (Exhaust Brake) 6 Cyl. Without Air Brakes. 2005-2007	C40014
Pac Brake (Exhaust Brake) 4 Cyl. Aisin Transmission	C40011
4" Bumper Extension Kit for NA, NB, NC Models Only.	52101LDTKIT
4" Bumper Extension Kit for ND,NE, NJ, NV Models Only.	52101MDTKIT
Chrome Bumper- NA, NB, NC.	52101E0120
Chrome Bumper- ND,NE,NJ,NV.	52101E0130
Chrome Grill- NA,NB, NC	53101E0030
Chrome Grill- ND, NE, NV, NJ.	53101E0060
Chrome Headlamp Bezel (Left) All Models-2005 ONLY	761081500A
Chrome Headlamp Bezel (Right) All Models-2005 ONLY	761071660A
Chrome Wheel Simulator Kit. 16" Front and Rear Wheel Covers with Lug Nut Covers	42600H4010
Chrome Wheel Simulator Kit 19.5". FOR 258 LP ONLY. Front and Rear Wheel Covers with Lug Nut Covers. ND	42600H4090

Description	Part Number
Chrome Wheel Simulator Kit. 19.5" FOR 258 ALP ONLY Front and Rear Wheel. Covers with Lug Nut Covers. NJ	42600H4095
Chrome Wheel Simulator Kit. 22.5" Front and Rear Wheel Covers with Lug Nut Covers. ND-NV.	42600H4100
Air Deflector Kits. All Models -White	G-MAD-H-AS-01
Air Deflector Kits. All Models- Black	G-MAD-H-AS-01-05
Air Deflector Kits. All Models- Red	G-MAD-H-AS-01-07
Sun Visor Fits All Conventional Models	HIS54
Instrument Cluster. Simulated Wood Grain Trim Panel Kits. All Models - 2005-2007 only	554141290A
Door Trim Panel - L/S. Simulated Wood Grain Trim Panel Kits. All Models - 2005-2007 only	681431030A
Door Trim Panel - R/S. Simulated Wood Grain Trim Panel Kits. All Models - 2005-2007 only	681441020A
Mud Flaps 24"X30"	HPJ530DW
Mud Flaps 24"X36"	HPJ536DW
Floor Mats (All Models)	FLRMATNAPS
Hino Seat Covers Drivers Side	SA23623
Hino Seat Covers Passenger Side	SA23624
Hino Seat Covers Bench Seat	SA23625
Front Stabilizer Kit. 2005-2010 NA, NB, NC Models Only	D67
Rear Stabilizer Kit. 2005-2010 ND,NE, NJ Models Only	D68PL
Rear Stabilizer Kit. 2005-2010 NV Model Only	D68PL338
Rear Shock Kit. 2005-2010 NA, NB, NC Models Only	D68LDT
Rear Shock Kit. 2005-2010 ND,NE, NJ Models Only	D68MDTC6
Rear Shock Kit. 2005-2010 NV Model Only	D68MDTC7
Heavy Duty Rear Shock Kit for NV 338 Air Suspension Only	66994000
Hendrickson Air ride Susp. Kit. Also, for 268A and 338 Models	482501320A, 3150D2578
Dump Valve Kit. '05-'07 NJ, NV.	5018354KIT
Dump Valve Kit. 2008-2010 ND,NE, NJ, NV Models	27690E0010K
Air Horn Kit 05-07 NJ-NV & All 2008-2010 Models	135456
Differential Lock Kit. 2008-2010 NV and NJ Models Only	154100
Vertical Exhaust Kit. 2005-2007 Only ND- NV	152120
Vertical Exhaust Kit. 2008-2010 Only ND- NV	255152-70-0001

https://truckmanualshub.com/

Contents

Contents

		PAGE
Air Conditioning	Compressor, Belts, Condenser,s Receiver Driers, Evaporators, Thermostat, Expansion Valves, Idler Pulleys, Compressor Clutches, Control Panels, High Pressure Switches, Evaporator Filters and Air Conditioner Hoses	7-8
Brake System	Hydraulic: Brake Pads, Master Cylinders, Boosters, Servo Assembles, Calipers, Rotors, Caliper Pins/Boots/Seals Kits, Caliper Pistons and Caliper Hardware Kits	9-11
	Electrical: Stop Light Switches, ABS System: Sensors/Brackets, Tone Rings, Brake Motor Relays and Modulator Valves	12-13
	Air: Brake Shoes and Drums, Brake Hardware Kits and Springs	13
	Air: Slack Adjusters, S-Cams and Brake Chambers	14
	Air & Hydraulic – ABS Systems: Wheel Speed Sensors, Extension Harnesses, Air Switches and Modulator Valvea.	14-15
	Air: Pressure Regulators, Brake Valves, Driers, Pressure Control Valves, Rebuild Kits, Air Valves, Cartridges and Heater Assembly.	15-16
Bumpers	Chrome, White and Black, Three Piece And One Piece Options	16
Clutches	Clutch Kit, Spice Clutch Packs, Pilot/ Bearings, Release Bearings, Fork Springs Clutch Forks, Shaft Clutches, Shaft Keys, Spacers, Bushings and Lube Hose	17-18
	Master/Slave Cylinders, Push Rods, and Repair Kits	19
	Flywheels, Ring Gears, Bolts, Pins and Collars	20
Cooling System	Water Pumps, O-Rings, Water Pump Belts, Pulleys and Bolts	21
	Thermostat Kits, Gaskets, Radiators, Retainers, Caps and Reserve Tanks	22
	Fan Clutches, Radiator Hoses, Low Coolant Sensors	23
Driveline	Differential Pinion Seals, Axle Shafts	24
	Axle Gaskets, U-Joint Kits, Center Bearings, Boot Kits and U-Joint Scraps	25
Electrical (Cab)	Switches: Park Brake, Dimmer, Head Lamp & Directional, Wiper, Cruise Control, Cargo Box, Heated Mirror, Transmission Mode, ABS Diagnostic, Idle Control, Buzzer, Air Horn, Display, Ignition, and DPR Manual Operation	26
Engine (Electrical)	Senstors: Water Temp, Low Coolant, Oil Pressure, Cam and Crank Speed, Air Intake Pressure, Mass Air Flow, Common Rail Pressure, Throttle Position	27
	Starters, Alternators	27
	Headlight & Tail Lamp, Relays and Turn Signal Flashers	28
	EGR Solenoids, Computer Fuel Injection, and EGR Valves & Manifolds	29
	Intake Shutter, Throttle Body, and Intake Meter Assy	29
	Fuses, Fusible Links, and Fuse/Relay bBox Covers	29

Contents (Cont.)

		PAGE
Engine	Valves, Springs and Guides.	30
	Oil Pumps, Oil Caps, Plugs and Gaskets	30
	Conn Rod Bearing Sets, Main Bearings Sets and Thrust Washers	31
	Piston Liners, Ring Sets and Wrist Pin Kits	32-33
	Gaskets, Gasket Kits and Main Seals	34
	Intercooler and Intercooler Hoses	35
	Exhaust Systems: Turbochargers, Front and Tail Pipes, Muffler, Filters, Exhaust Sensors, Exhaust Brakes; Gaskets: Turbo, Header Pipe, Oil Return, Oil Supply, Exhaust Manifold, EGR Manifold, Crossover Pipe, Exhaust Pipe	36-37
Fuel Injection System	Common Rail Fuel Injection System	38
Filters	Oil, Air, Fuel and Power Steering.	39
Fuel	Fuel Tanks, Straps, Brackets, Sending Units, Gaskets and Fuel Caps	40
Heater	Heater Fan Motor, Resistor, Heater Core and Cables.	41
Horn	Horns, Horn Spiral Cable and Horn Cover.	41
Hubs	Hubs and Rotors, Hubs, Hob Seals, Front Covers and Gaskets.	42-44
Lettering And Badges	Lettering And Badges	45
Lighting	Head Lamps, Head Lamp Assemblies, Bulbs, Turn Signal Assemblies. Dome Lamp, Lens, Marker Lamp, Lens, Tail-Turn-Brake Light Assemblies.	46
Locks/Keys/Ignition Switch	Key Blanks, Door Locks, Lock Sets and Ignition Switches	47
Mirrors	Mirrors, Mirror Brackets and Mirror Light/Lamp Bulbs & Assemblies	48-49
Paint Codes	Paint Codes	50
Parking Brake	Cables, Handle Grip, Drums, Shoe-Brake Lining Assemblies and Park Brake Assemblies	51
Sealants	Sealants.	52
Steering	Power Steering Box, Pump Assembly, Tie Rods, Pin Kits, Etc.	52-53
Suspension (Front/Rear)	Shock Absorbers Front And Rear, Spring Assembly, Spring Bushings, U-bolts and Hardware	53-55
Transmission (Manual)	Pipe Plugs, Oil Seals, Gaskets, Transmissions, Speed Sensor Kits, Etc	56
Transmission (Automatic)	Aisin: Gauge Oil Level, Tube Sub Assembly, Seals, Gaskets, Etc.	57
	Automatic Shift Cables, Speed Sensor Kits, Driven Gears, Switch Assembly, Transmission Assembly, Retainer	57-58
Wheels	Wheel Bearings, Races, Wheels, Rims, Lug Nuts, Wheel Studs.	59-62
Windshield/Wipers	Windshield, Rubber Gasket Blades, Arms, Motor, Washer Reservoir, Cap, Pump	62

https://truckmanualshub.com/

A

https://truckmanualshub.com/

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Air Conditioning					
A/C Compressor Drive Belt	Single V-Belt	**SZ91045266**	NA,NB,NC 2005-2010	Engine	18-50
A/C Compressor Drive Belt	Single V-Belt	**883811100A**	ND,NE,NJ,NV 2005-2010	Engine	18-50
A/C Condenser	The Condenser Has The Dryer Built Into It	**S884102580**	ALL MODELS 2005-2007	Cab	B9-04
A/C Condenser	The Condenser Has The Dryer Built Into It	**88460E0130**	NA,NB,NC 2008-2010	Cab	B9-04
A/C Condenser	The Condenser Has The Dryer Built Into It	**88460E0120**	ND,NE,NJ,NV 2008-2010	Cab	B9-04
A/C Drier Cartridge	Dryer Desiccant Refill And Plug	**S884741040**	ALL MODELS 2005-2010	Cab	B9-04
A/C Evaporator	Core And Rubber Seal Around It	**S885011070**	ALL MODELS 2005-2010	Cab	B9-00
A/C Thermostat	Located At A/C-Heater/ Evaporator Box	**S886251170**	ALL MODELS 2005-2010	Cab	B9-00
A/C Expansion Valves	Located At A/C-Heater/ Evaporator Box	**S885151070**	ALL MODELS 2005-2010	R97469	B9-00
Idler Pulley Assembly	For Production Date Of 11/03 Only Does Not Include Adjusting Bolt	**883601200A**	NA,NB,NC 2005 ONLY	Engine	18-50
Idler Pulley Assembly	For Production Date Of 12/03 Forward Does Not Include Adjusting Bolt	**S883601430**	NA,NB,NC 2005-2010	Engine	18-50
Idler Pulley Assembly	Does Not Include Adjusting Bolt	**S883601380**	ND,NE,NJ,NV 2005-2010	Engine	18-50
A/C Compressor	With Clutch	**S883101810**	NA,NB,NC 2005-2010	Cab	B9-03
A/C Compressor	With Clutch	**S883101800**	ND,NE,NJ,NV 2005-2010	Cab	B9-03
A/C Compressor	With Out Clutch	**883201820A**	NA,NB,NC 2005-2010	Cab	B9-03
A/C Compressor	With Out Clutch	**S883201810**	ND,NE,NJ,NV 2005-2010	Cab	B9-03
Compressor Clutch	New-Denso	**S883301270**	ALL MODELS 2005-2010	Cab	B9-03
A/C And Heater Fan Motor Switch	Has No Knob- Comes With The 2 Lights	**S874801270**	ALL MODELS 2005-2010	Cab	B9-00
A/C On/Off Switch	In A/C-Heater Control Panel In Dash	**S886101150**	ALL MODELS 2005-2010	Cab	B9-01
A/C High Pressure Switch	Threads Into High Pressure Line-Not Shown In EPC Illustration	**S833802500**	ALL MODELS 2005-2010	Chassis	91-00
Blower Resistor	Located On Heater/Evaporator Box Under Dash	**S871381200**	ALL MODELS 2005-2010	Cab	B9-00

https://truckmanualshub.com/

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Air Conditioning (Cont.)					
A/C-Heater Control Panel	Includes Cables And Fan Switch - Does Not Include A/C On/Off Switch	**S874101600**	ALL MODELS 2005-2010	Cab	B9-00
A/C Filter Element	Filter/Screen In Evaporator Box	**S872121200**	ALL MODELS 2005-2010	Cab	B9-00
Hose Discharge	Condenser To Compressor	**S887114200**	NA,NB,NC 2005-2007	Chassis	91-00
Hose Discharge	Condenser To Compressor	**88711E0100**	NA,NB,NC 2008-2010	Chassis	91-00
Hose Suction	Compressor To Evaporator	**S887124770**	NA,NB,NC 2005-2007	Chassis	91-00
Hose Suction	Compressor To Evaporator	**88712E0180**	NA,NB,NC 2008-2010	Chassis	91-00
Hose Liquid	Evaporator To Condenser	**S887132340**	NA,NB,NC 2005-2007	Chassis	91-00
Hose Liquid	Evaporator To Condenser	**88721E0020**	NA,NB,NC 2008-2010	Chassis	91-00
Hose Liquid	Evaporator To Condenser	**S887132350**	ND,NE,NJ,NV 2005-2007	Chassis	91-00
Hose Liquid	Evaporator To Condenser	**88721E0010**	ND,NE,NJ,NV 2008-2010	Chassis	91-00
Hose Suction	Compressor To Evaporator	**887124780A**	ND,NE,NJ,NV 2005-2007	Chassis	91-00
Hose Suction	Compressor To Evaporator	**88712E0160**	ND,NE,NJ,NV 2008-2010	Chassis	91-00
Hose Discharge	Condenser To Compressor	**S887114210**	ND,NE,NJ,NV 2005-2007	Chassis	91-00
Hose Discharge	Condenser To Compressor	**88711E0080**	ND,NE,NJ,NV 2008-2010	Chassis	91-00

https://truckmanualshub.com/

B

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Brake System - Hydraulic - Disc Brake Pads					
Disc Brake Pads	4 Brake Pads With Holdown Plate Front Axle	**MDP5113**	NA,NB,NC 2005-2010	Drive	66-10
Disc Brake Pads	4 Brake Pads With Holdown Plate Rear Axle	**MDP5113**	NA,NB 2005-2010	Drive	68-10
Disc Brake Pads	4 Brake Pads - Front Axle	**KITD769AM**	ND,NE 2005-2010	Drive	66 -10
Disc Brake Pads	4 Brake Pads - Rear Axle	**KITD769AM**	NC,ND,NE 2005-2010	Drive	68-10
2005 - 2010 - Brake System - Hydraulic - Front Calipers, Master Cylinders					
Master Cylinder	On Firewall	**BX2234933**	NA,NB,NC, ND,NE 2005-2010	Chassis	37-05
Booster	Brake Booster Attaches To Rear Of Master Cylinder.	**0204022940**	NA,NB,NC, ND,NE 2005-2010	Chassis	37-05
Servo Assembly	Includes Master Cylinder, Booster And Back Up Pump Motor	**447201011A**	NA,NB,NC, ND,NE 2005-2010	Chassis	37-05
Disk Brake Caliper	Right Front Caliper - No Pads	**LRG715**	NA,NB,NC 2005-2010	Drive	66-10
Disk Brake Caliper	Left Front Caliper - No Pads	**LRG714**	NA,NB,NC 2005-2010	Drive	66-10
Disk Brake Caliper	Right Front Caliper 64mm Piston 8k Axle	**60450481**	ND,NE 2005-2010	Drive	66-10
Disk Brake Caliper	Right Front Caliper 64mm Piston 8k Axle With Pads	**60450474005**	ND.NE 2005-2010	Drive	66-10
Disk Brake Caliper	Left Front Caliper 64mm Piston 8k Axle	**60450480**	ND,NE 2005-2010	Drive	66-10
Disk Brake Caliper	Left Front Caliper 64mm Piston 8k Axle With Pads	**60450473005**	ND,NE 2005-2010	Drive	66-10
Disk Brake Caliper	Right Front Caliper 70mm Piston 10k Axle	**60450483**	NE 2005-2010	Drive	66-10
Disk Brake Caliper	Right Front Caliper 70mm Piston 10k Axle With Pads	**60450468005**	NE 2005-2010	Drive	66-10
Disk Brake Caliper	Left Front Caliper 70mm Piston 10k Axle	**60450482**	NE 2005-2010	Drive	66-10
Disk Brake Caliper	Left Front Caliper 70mm Piston 10k Axle With Pads	**60450469005**	NE 2005-2010	Drive	66-10

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Brake System - Hydraulic - Rear Calipers					
Disk Brake Caliper	Right Rear Caliper	**LRG716**	NA 2005-2010	Drive	68-10
Disk Brake Caliper	Left Rear Caliper	**LRG717**	NA 2005-2010	Drive	68-10
Disk Brake Caliper	Right Rear Caliper	**LRG714**	NB 2005-2010	Drive	68-10
Disk Brake Caliper	Left Rear Caliper	**LRG715**	NB 2005-2010	Drive	68-10
Disk Brake Caliper	Right Rear Caliper - 64mm	**60450480**	NC,ND 2005-2010	Drive	68-10
Disk Brake Caliper	Left Rear Caliper - 64mm	**60450481**	NC,ND 2005-2010	Drive	68-10
Disk Brake Caliper	Right Rear Caliper - 64mm With Pads	**60450473005**	NC,ND 2005-2010	Drive	68-10
Disk Brake Caliper	Left Rear Caliper - 64mm With Pads	**60450474005**	NC,ND 2005-2010	Drive	68-10
Disk Brake Caliper	Right Rear Caliper - 70mm	**60450482**	NE 2005-2010	Drive	68-10
Disk Brake Caliper	Left Rear Caliper - 70mm	**60450483**	NE 2005-2010	Drive	68-10
Disk Brake Caliper	Right Rear Caliper - 70mm With Pads	**60450468005**	NE 2005-2010	Drive	68-10
Disk Brake Caliper	Left Rear Caliper - 70mm With Pads	**60450469005**	NE 2005-2010	Drive	68-10
2005 - 2010 - Brake System - Hydraulic - Rotors					
Front Rotor	Rotor Only	**23123626002**	NA 2005-2010	Drive	66-00
Front Rotor	Rotor Only	**23123625002**	NB,NC 2005-2010	Drive	66-00
Front Rotor	Rotor Coated - Tone Ring Machined In	**23123557004**	ND,NE 2005-2010	Drive	66-00
Rear Rotor	Rotor-Tone Ring Included	**23123618007**	NA 2005-2010	Drive	68-00
Rear Rotor	Rotor-Tone Ring Included	**23123624007**	NB 2005-2010	Drive	68-00
Rear Rotor	Rotor Tone Ring Included	**23123617004**	NC 2005-2010	Drive	68-00
Rear Rotor	Rotor - Tone Ring Machined In	**23123557004**	ND,NE 2005-2010	Drive	38-00

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Brake System - Hydraulic - Caliper, Seals, Hardware					
Caliper Guide Pin Kit	2 Guide Pins, Boots, Bolts, Plugs, Grease	**SJ1035**	NA,NB,NC Front 2005-2010	Drive	66-10
Caliper Guide Pin Kit	2 Guide Pins, Boots, Bolts, Plugs, Grease	**SJ1035**	NA,NB Rear 2005-2010	Drive	68-10
Guide Pin Boot Kit	2 Guide Pin Boots And Grease	**SP8566**	NA,NB,NC Front 2005-2010	Drive	66-10
Guide Pin Boot Kit	2 Guide Pin Boots And Grease	**SP8566**	NA,NB Rear 2005-2010	Drive	68-10
Boot & Seal Kit	2 Caliper Seals, Dust Boots And Pin Boots	**SP8597**	NA,NB,NC Front 2005-2010	Drive	66-10
Boot & Seal Kit	2 Caliper Seals, Dust Boots And Pin Boots	**SP8597**	NA,NB Rear 2005-2010	Drive	68-10
Boot & Seal Kit	For 64mm Piston-Contains 4 Seals& Boots	**R4011731**	NC Rear 2005-2010	Drive	68-10
Boot & Seal Kit	For 64mm Piston-Contains 4 Seals& Boots	**R4011731**	ND,NE Front 2005-2010	Drive	66-10/68-10
Boot & Seal Kit	For 64mm Piston-Contains 4 Seals& Boots	**R4011731**	ND Rear 2005-2010	Drive	66-10/68-10
Boot & Seal Kit	For 70mm Piston-Contains 4 Seals& Boots	**R4011730**	NE Front/Rear 2005-2010	Drive	66-10/68-10
Caliper-Piston	1- 60 Mm Caliper Piston	**31320085**	NA,NB,NC Front 2005-2010	Drive	66-10
Caliper-Piston	1- 60 Mm Caliper Piston	**31320085**	NA,NB Rear 2005-2010	Drive	68-10
Caliper-Piston	64mm Piston And Plug	**R4011511**	NC Rear 2005-2010	Drive	68-10
Caliper-Piston	64mm Piston And Plug 8k Axle	**R4011511**	ND,NE Front/Rear 2005-2010	Drive	66-10/68-10
Caliper-Piston	70mm Piston And Plug 10k Axle	**60050334**	NE Front/Rear 2005-2010	Drive	66-10/68-10
Hardware Kit	For Both 64mm And 70mm Pistons	**R4011729**	Front/Rear 2005-2010	Drive	66-10/68-10

https://truckmanualshub.com/

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Brake System - Electrical - Brake Light Switches - ABS System					
Stop Light Switch	At Brake Pedal Bracket	**843802220A**	NA,NB,NC ND,NE 2005-2010	Chassis	35-00
Stop Light Switch	2nd Switch At Brake Pedal Bracket	**S843802190**	NA,NB,NC ND,NE 2007-2010	Chassis	35-00
Stop Light Switch	Air Brake	**S843802180**	NJ,NV 2005-2006	Chassis	35-00
Stop Light Switch	Air Brake	**S833802620**	NJ,NV 2007-2010	Chassis	35-00
ABS Wheel Speed Sensor	Front Sensor - W/O Retainer Clip	**894417770A**	NA,NB,NC 2005-2010	Drive	66-00
ABS Sensor Bracket	Bolts To Spider Front	**69180474**	NA,NB,NC 2005-2010	Drive	66-00
ABS Wheel Speed Sensor	Rear Sensor - W/O Retainer Clip	**894417810A**	NA,NB 2005-2010	Drive	66-00
ABS Sensor Bracket	Bolts To Spider Rear	**69180473**	NA,NB,NC 2005-2010	Drive	68-00
ABS Wheel Speed Sensor	Rear Sensor - W/O Retainer Clip	**894417830A**	NC 2005-2010	Drive	68-00
ABS Wheel Speed Sensor	Front Sensor - W/O Retainer Clip	**894417780A**	ND,NE NJ ALP 8k Axle 2005-2010	Drive	66-00
ABS Sensor Bracket	Bolts To Spider Front	**69180474**	ND,NE 8k Axle 2005-2010	Drive	66-00
ABS Wheel Speed Sensor	Front Sensor - W/O Retainer Clip	**894417790A**	ND,NE 10k Axle 2005-2010	Drive	66-00
ABS Sensor Bracket	Bolts To Spider Front	**69180473**	ND,NE 10k Axle 2005-2010	Drive	66-00
ABS Wheel Speed Sensor	Rear Sensor - W/O Retainer Clip	**894417830A**	ND,NE 2005-2010	Drive	68-00
ABS Sensor Bracket	Bolts To Spider Rear Axle	**69180472**	ND,NE 2005-2010	Drive	68-00
ABS Wheel Speed Sensor	Front Sensor - W/O Retainer Clip	**894417800A**	NJ,NV 2005-2010	Drive	66-00
ABS Wheel Speed Sensor	Right Side Rear Sensor - W/O Retainer Clip	**894417841A**	NJ,NV 2005-2010	Drive	68-00
ABS Wheel Speed Sensor	Left Side Rear Sensor - W/O Retainer Clip	**894417851A**	NJ,NV 2005-2010	Drive	68-00
ABS Wheel Speed Sensor Bushing	Speed Sensor Retainer Clip	**R955459**	ALL 2005-2010	Drive	66-00
Tone Ring	Rear Tone Ring Only - No Screws	**09002221**	NA,NB 2005-2010	Not Shown	Not Shown
Tone Ring	Rear Tone Ring	**3237N1262**	NJ 258 ALP 2008-2010	Not Shown	Not Shown
Tone Ring	Front Tone Ring	**09002217**	NB,NC 2005-2010	Not Shown	Not Shown

https://truckmanualshub.com/

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Brake System - Electrical - Brake Light Switches - ABS System (Cont.)					
ABS Tone Ring Screws	6 Required	**08205977**	NA,NB 2005-2010	Not Shown	Not Shown
Brake Motor Relay	Located At Servo	**BX2772777**	NA,NB,NC, ND,NE 2005-2010	Chassis	36-00
ABS Modulator Valve	1 Required	**S4784070580**	NA,NB,NC, ND,NE 2005-2010	Chassis	37-03
2005 - 2010 - Brakes - Air - Brake Shoes/Drums					
Brake Shoe W/Lining	1 Brake Shoe And Lining - Front Axle	**SMA2124702QP**	NJ,NV 2005-2010	Drive	66-10
Brake Shoe Kit	Brake Shoe Kit 1 Per Wheel Or 2 Per Axle W/Hardware Front Axle	**XK2124702QP**	NJ,NV 2005-2010	Drive	66-10
Brake Shoe W/Lining	1 Brake Shoe And Lining - Rear Axle	**SMA2124710QP**	NJ 258 ALP 2007-2010	Drive	66-10
Brake Shoe Kit	Brake Shoe Kit 1 Per Wheel Or 2 Per Axle W/Hardware Rear Axle	**XK2124710QP**	NJ 258 ALP 2007-2010	Drive	66-10
Brake Shoe W/Lining	1 Brake Shoe And Lining - Rear Axle	**SMA2124707QP**	NJ,NV 2005-2010	Drive	68-10
Brake Shoe Kit	Brake Shoe Kit 1 Per Wheel Or 2 Per Axle W/Hardware Rear Axle	**XK2124707QP**	NJ,NV 2005-2010	Drive	68-10
Front Brake Shoe Hardware Kit	Contains All Springs, Bushings, And Rollers Completes One Wheel	**KIT8824HD**	NJ,NV 2005-2010	Drive	66-10
Rear Brake Shoe Hardware Kit	Contains All Springs, Bushings, And Rollers Completes One Wheel	**KIT8000MBHD**	NJ,NV 2005-2010	Drive	68-10
Shoe Retaining Spring	2 Required Per Side	**2258H1230**	NJ,NV 2005-2010	Drive	66-10
Shoe Return Spring	1 Required Per Side	**258L1234**	NJ,NV 2005-2010	Drive	66-10
Drum	Front - Drum Only	**85123366002**	NJ,NV 2005-2010	Drive	66-00
Drum	Front - Drum Only	**85123465002**	NJ 258 A/LP 8k Axle 2007-2010	Drive	66-00
Drum	Rear - Drum Only	**85123466002**	NJ 258 A/LP 2007-2010	Drive	68-00
Drum	Rear - Drum Only	**85123207002**	NJ,NV 2005-2010	Drive	68-00

https://truckmanualshub.com/

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Brakes - Air - Slack Adjusters - Brake Chambers					
Automatic Slack Adjuster	Right Front	**R802699**	NJ,NV 2005-2010	Drive	66-10
Automatic Slack Adjuster	Left Front	**R802698**	NJ,NV 2005-2010	Drive	66-10
Automatic Slack Adjuster	Right Rear	**R802649**	NJ,NV 2005-2010	Drive	68-10
Automatic Slack Adjuster	Left Rear	**R802648**	NJ,NV 2005-2010	Drive	68-10
S-Cam	Right Front	**2210A7463**	NJ,NV 2005-2010	Drive	66-10
S-Cam	Left Front	**2210Z7462**	NJ,NV 2005-2010	Drive	66-10
S-Cam	Right Rear	**2210T7586**	NJ,NV 2005-2010	Drive	68-10
S-Cam	Left Rear	**2210U7587**	NJ,NV 2005-2010	Drive	68-10
S-Cam Bushing	Bushing Set- One Set Completes One Axle Fits Front Or Rear.	**KIT8042**	NJ,NV 2005-2010	Not Shown	Not Shown
Brake Chamber	Front	**A703276T20**	NJ,NV 2005-2010	Drive	66-10
Brake Chamber	Rear	**C313276D30**	NJ,NV 2005-2010	Drive	68-10
2005 - 2010 - Brakes - Air & Hydraulic - ABS System					
ABS Wheel Speed Sensor	Front Sensor - No Retainer Clip	**894417800A**	NJ,NV 2005-2010	Drive	66-00
ABS Wheel Speed Sensor	Left Rear Sensor - No Retainer Clip	**894417851A**	NJ,NV 2005-2010	Drive	66-00
ABS Wheel Speed Sensor	Right Rear Sensor - No Retainer Clip	**894417841A**	NJ,NV 2005-2010	Drive	66-00
ABS Wheel Speed Sensor Bushing	Speed Sensor Retainer Clip	**S8997605104**	ALL 2005-2010	Drive	66-00
ABS Extension Harness	19" Long	**82164E0L40**	NA,NB,NC, ND,NE 2005-2010	Not Shown	Not Shown
ABS Extension Harness	19'' Long	**820711490A**	NJ,NV 2005-2006 ONLY	Not Shown	Not Shown
ABS Extension Harness	19" Long	**82164E0L50**	NJ,NV 2007-2010	Not Shown	Not Shown
ABS Extension Harness	72" Long	**S820711510**	NJ,NV 2005-2010	Not Shown	Not Shown
ABS Extension Harness	120" Long	**820711520A**	NJ,NV 2005-2010	Not Shown	Not Shown

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Brakes - Air & Hydraulic - ABS System (Cont.)					
Air Switch	On Front Air Valve At Crossmember Controls Rpm	**S833802620**	NJ,NV 2005-2010	Chassis	36-00
Air Switch	On Rear Valve At Crossmember Top Of Valve Spring Brake Switch	**833802440A**	NJ,NV 2005-2010	Chassis	36-00
Air Switch	On Rear Valve At Crossmember Bottom Of Valve Buzzer Switch	**833802430A**	NJ,NV 2005-2010	Chassis	36-00
ABS Modulator Valve	1 For Each Wheel - Mounted On Frame	**S4008500540**	NJ,NV 2005-2010	Chassis	36-00
2005 - 2010 - Brakes - Air - Valves/Rebuild Kits/Air Drier					
Air Pressure Regulator	Air Governor	**282436**	NJ,NV 2005-2010	Chassis	36-51
Governor Rebuild Kit	O-Rings To Rebuild Valve 282436	**276121**	NJ,NV 2005-2010	Chassis	36-51
Air Brake Valve	Foot Valve	**800630**	NJ,NV 2005-2010	Chassis	36-69
Air Valve Rebuild Kit	Minor Rebuild Kit For 800630	**287368**	NJ,NV 2005-2010	Chassis	36-69
Air Valve Rebuild Kit	Major Rebuild Kit For 800630	**289352**	NJ,NV 2005-2010	Chassis	36-69
Pressure Control Valve	Pressure Control Valve For Spring Brake	**288063N**	NJ,NV 2005-2010	Chassis	36-77
Air Valve Rebuild Kit	O-Rings To Rebuild Valve 288063	**108123**	NJ,NV 2005-2010	Chassis	36-77
Air Valve	Spring Brake Control Valve-Maxi Brake	**800310**	NJ,NV 2005-2010	Chassis	36-86
Air Valve Rebuild Kit	O-Rings To Rebuild Valve 800310	**5006939**	NJ,NV 2005-2010	Chassis	36-86
Air Valve	Relay Air Valve	**103010N**	NJ,NV 2005-2010	Chassis	36-81
Air Valve Rebuild Kit	O-Rings To Rebuild Valve 103010	**102802**	NJ,NV 2005-2010	Chassis	36-81
Air Drier Assembly	Bendix-Complete Air Drier	**065612**	NJ,NV 2005-2007	Chassis	36-94
Air Drier Assembly	Complete Air Drier	**S4430E0160**	NA,NB,NC, ND,NE 2008-2010	Chassis	36-94
Air Drier Assembly	Complete Air Drier	**448303060A**	NJ,NV 2008-2010	Chassis	36-94
Air Drier Repair Kit-Major	Major Repair Kit Includes Bottom Half Of Drier, Purge Valve Kit, Delv. Chk. Valve Kit	**5005622**	NV,NJ Bendix 2005-2007	Chassis	36-94
Air Drier Repair Kit-Major	Major Repair Kit Includes Bottom Half Of Drier, Purge Valve Kit, Delv. Chk. Valve Kit	**S443061550**	NA,NB,NC, ND,NE 2008-2010	Chassis	36-94

https://truckmanualshub.com/

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Brakes - Air - Valves/Rebuild Kits/Air Drier (Cont.)					
Air Drier Repair Kit-Minor	Minor Repair Kit Includes Desiccant Material And All O-Rings	**440861100A**	NV,NJ Bendix 2005-2010	Chassis	36-94
Cartridge Assembly	Complete Desiccant Cartridge	**S443061450**	NV,NJ Bendix 2005-2010	Chassis	36-94
Cartridge Assembly	Complete Desiccant Cartridge	**S443061440**	NA,NB,NC, ND,NE 2008-2010	Chassis	36-94
Heater Assembly	Heater Element	**871102490A**	NV,NJ Bendix 2005-2010	Chassis	36-94
Heater Assembly	Heater Element	**871102490A**	NA,NB,NC, ND,NE 2008-2010	Chassis	36-94
2005 - 2010 - Bumpers					
Bumpers	White One Piece	**52101E0260**	NA,NB,NC 2005-2010	Chassis	44-00
Bumpers	Black One Piece	**52101E0270**	NA,NB,NC 2005-2010	Chassis	44-00
Bumpers	Chrome One Piece	**52101E0120**	NA,NB,NC 2005-2010	Chassis	44-00
Bumpers	White One Piece	**52101E0730**	ND,NE,NJ,NV 2005-2010	Chassis	44-00
Bumpers	Black One Piece	**52101E0210**	ND,NE,NJ,NV 2005-2010	Chassis	44-00
Bumpers	Chrome One Piece	**52101E0130**	ND,NE,NJ,NV 2005-2010	Chassis	44-00
Bumpers	White Three Piece Center Section Only	**52101E0230**	ND,NE,NJ,NV 2005-2010	Chassis	44-00
Bumpers	Black Three Piece Center Section Only	**52101E0240**	ND,NE,NJ,NV 2005-2010	Chassis	44-00
Bumpers	Three Piece Bumper End Piece Right Hand Side Black	**521051190A**	ND,NE,NJ,NV 2005-2010	Chassis	44-00
Bumpers	Three Piece Bumper End Piece Right Hand Side White	**S521051170**	ND,NE,NJ,NV 2005-2010	Chassis	44-00
Bumpers	Three Piece Bumper End Piece Left Hand Side Black	**521051200A**	ND,NE,NJ,NV 2005-2010	Chassis	44-00
Bumpers	Three Piece Bumper End Piece Left Hand Side White	**S521051180**	ND,NE,NJ,NV 2005-2010	Chassis	44-00

https://truckmanualshub.com/

https://truckmanualshub.com/

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Clutches					
Clutch Kit	Includes A 13.8 " Clutch And Pressure Plate With A Pilot & Release Bearing	**31200H3214**	NA,NB,NC 2005-2010	Drive	30-00
Spicer Clutch Pack	Includes A Matched Spicer Disc & Pressure Plate (Standard Clutch)	**312002010A**	ND,NE,NJ 2005 ONLY	Drive	30-00
Spicer Clutch Pack	Includes A Matched Spicer Disc & Pressure Plate (Standard Clutch)	**312001961A**	NV 2005 ONLY	Drive	30-00
Spicer Clutch Pack	14" Solo Spicer Self Adjusting Pressure Plate And Clutch Disk (Optional)	**312002061A**	ND,NE,NJ 2005 ONLY	Drive	30-00
Spicer Clutch Pack	Includes A Matched Spicer Disc & Pressure Plate (Standard Clutch)	**312001961A**	ND,NE,NJ,NV 2006-2010	Drive	30-00
Spicer Clutch Pack	14" Solo Spicer Self Adjusting Pressure Plate And Clutch Disc (Optional)	**312002061A**	ND,NE,NJ,NV 2006-2010	Drive	30-00
Spicer Clutch Pack	14" Pressure Plate, Center Plate And Clutch Discs (Twin Disk Option)	**312002080A**	ND,NE,NJ,NV 2006-2010	Drive	30-00
Twin Disk Spicer Clutch Pack	14" Solo Spicer Self Adjusting Pressure Plate, Center Plate And Clutch Discs (Twin Disk Option)	**312002090A**	ND,NE,NJ,NV 2006-2010	Drive	30-00

https://truckmanualshub.com/

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Clutch - Pilot/Release Bearings/Springs/Forks/Fork Shafts					
Pilot Bearing	Double Shielded Bearing	**SZ37120022**	ALL 2005-2010	Drive	30-00
Release Bearing	Bearing Only	**S312421141**	NA,NB,NC 2005-2010	Drive	30-10
Release Bearing Hub	Hub Only	**S312311820**	NA,NB,NC 2005-2010	Drive	30-10
Fork Springs	2 Required - Holds The Clutch Fork To The Hub	**312341020A**	NA,NB,NC 2005-2010	Drive	30-10
Clutch Fork	No Shafts	**312331330A**	NA,NB,NC 2005-2010	Drive	30-10
Clutch Fork	No Shafts	**312331470A**	ND,NE,NJ,NV 2005-2010	Drive	30-10
Shaft Clutch Release	Right Side Fork Release Shaft	**312451440A**	ALL 2005-2010	Drive	30-10
Shaft Clutch Release	Left Side Fork Release Shaft And Bushing	**312903250A**	NA,NB,NC 2005-2010	Drive	30-10
Shaft Clutch Release	Left Side Fork Release Shaft	**S312903260**	ND,NE,NJ,NV 2006-2010	Drive	30-10
Key	Left Side Shaft Key	**953905105A**	NA,NB,NC 2005-2010	Drive	30-10
Spacer	Left Side Shaft Key	**900312599A**	ND,NE,NJ,NV 2006-2010	Drive	30-10
Bushing	Left Side Shaft Bushing	**986712118A**	NA,NB,NC 2005-2010	Drive	30-10
Bushing	Bushings In Housing For Fork Shafts	**986725139A**	NA,NB,NC 2005-2010	Drive	30-10
Lube Hose	Hose And Fittings	**SZ93031104**	NA,NB,NC 2005-2010	Drive	30-10

https://truckmanualshub.com/

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 Clutch - Master/Slave Cylinders And Kits					
Master Cylinder	Includes Reservoir	**31420E0030**	ALL 2005-2010	Chassis	30-82
Slave Cylinder	Does Not Include Rod	**S314701171**	NA,NB,NC 2005-2010	Drive	30-83
Slave Cylinder	Does Not Include Rod	**314701310A**	ND,NE,NJ,NV 2005-2010	Drive	30-83
Rod Push	Slave Cylinder Push Rod	**319211160A**	NA,NB,NC 2005-2010	Drive	30-10
Rod Push	Slave Cylinder Push Rod	**S319211350**	ND,NE,NJ,NV 2005-2010	Drive	30-10
Nut	Nut For Push Rod	**921012100A**	ALL 2005-2010	Drive	30-10
Joint Link Rod	Threads On To Push Rod	**S782511190**	ALL 2005-2010	Drive	30-10
Pin	Clevis Pin For Above Part	**951912155A**	ALL 2005-2010	Drive	30-10
Pin	Clip For Clevis Pin	**950912118A**	ALL 2005-2010	Drive	30-10
Hanger Spring	Clutch Return Spring Attaches To This	**987906112A**	ALL 2005-2010	Drive	30-10
Repair Kit Master Cylinder	Seals, Boot And Piston	**314091050A**	ALL 2005-2010	Chassis	30-83
Repair Kit Slave Cylinder	Seals, Boot And Piston	**S040315018**	ALL 2005-2010	Chassis	30-83

https://truckmanualshub.com/

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 Clutch - Flywheels/Ring Gears/Bolts/Pins/Collars					
Flywheel W/Ring Gear	Std. Transmission (Note: Not Available For 2008-2010 Na Models)	**S134503890**	NA,NB,NC 2005-2007	Engine	12-00
Flywheel W/Ring Gear	Auto Transmission	**S134503901**	NA,NB,NC 2005-2007	Engine	12-00
Flywheel W/Ring Gear	Auto Transmission Aisin Auto Only	**S134503901**	NA 2008-2010	Engine	12-00
Flywheel W/Ring Gear	Auto Transmission Allison Only	**13450E0170**	NB,NC 2008-2010	Engine	12-00
Flywheel W/Ring Gear	Std. Transmission	**S134503830**	ND,NE,NJ,NV 2005-2010	Engine	12-00
Flywheel W/Ring Gear	Auto Transmission	**13450E0180**	ND,NE,NJ,NV 2005-2010	Engine	12-00
Flywheel Bolts	8 Required	**S134551550**	ALL 2005-2010	Engine	12-00
Pressure Plate Bolts	8 Required	**SZ11908017**	NA,NB,NC 2005-2010	Engine	30-00
Pressure Plate Bolts	8 Required	**901909107A**	ND,NE,NJ,NV 2005-2010	Engine	30-00
Pressure Plate Bolts	(Twin Disc Option) 8 Required	**901909108A**	ND,NE,NJ,NV 2005-2010	Engine	30-00
Ring Gear	129 Teeth	**S134531310**	ALL 2005-2010	Engine	12-00
Dowel Pins	2 Required	**SM21200824**	NA,NB,NC 2005-2010	Engine	30-00
Collar	1 Required	**900129119A**	ALL 2005-2010	Engine	12-00

https://truckmanualshub.com/

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Cooling System - Water Pumps/O-Rings/Belts					
Water Pump	No Gasket Used-Use Sealant # 041321207b	**161004150A**	NA,NB,NC 2005-2007	Engine	16-51
Water Pump	No Gasket Used-Use Sealant # 041321207b	**16100E0381**	NA,NB,NC 2008-2010	Engine	16-51
Water Pump	No Gasket Used-Use Sealant # 041321207b	**161004220A**	ND,NE,NJ,NV 2005-2007	Engine	16-51
Water Pump	No Gasket Used-Use Sealant # 041321207b	**16100E0090**	ND,NE,NJ,NV 2008-2010	Engine	16-51
O-Ring	At Thermostat Housing And Hose Neck 2 Required	**SZ30149006**	NA,NB,NC 2005-2010	Engine	16-00
O-Ring	At Thermostat Housing - 1 Required	**SZ30160008**	ND,NE,NJ,NV 2005-2010	Engine	16-00
O-Ring	At Hose Neck - 1 Required	**SZ30153006**	ND,NE,NJ,NV 2005-2010	Engine	16-00
Engine Drive Belt	V-Belt 2 Required-Goes Around Waterpump, Crank Shaft Pulley And Alternator	**SZ91045255**	NA,NB,NC 2005-2007	Engine	18-10
Engine Drive Belt	V-Belt 2 Required-Goes Around Water Pump, Crank Shaft Pulley And Alternator V-Belt Set	**SZ91049219**	NA,NB,NC 2008-2010	Engine	18-10
Engine Drive Belt	Serpentine Belt 1 Required-Goes Around Water Pump, Crankshaft, Tensioner & Alternator	**SZ91045254**	ND,NE,NJ,NV 2005-2007	Engine	18-10
Engine Drive Belt	Serpentine Belt 1 Required-Goes Around Water Pump, Crankshaft, Tensioner & Alternator	**SZ91045306**	ND,NE,NJ,NV 2008-2010	Engine	18-10
Pulley Assembly	Idler Pulley Not Tensioner	**16603E0060**	ND,NE,NJ,NV 2008-2010	Engine	18-10
Pulley Assembly	Serpentine Idler/Tensioner Pulley	**16630E0090**	ND,NE,NJ,NV 2008-2010	Engine	18-10
Pulley Assembly	Serpentine Idler/Tensioner Pulley	**16630E0250**	ND,NE,NJ,NV 2005-2007	Engine	18-10
Bolt	Bolt For Serpentine Idler/ Tensioner Pulley	**SZ11908215**	ND,NE,NJ,NV 2005-2010	Engine	18-10

https://truckmanualshub.com/

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Cooling System - Thermostat Kits/Gaskets/Radiators/Cap/Fan Clutch					
Thermostat Kit	Thermostat And Thermostat Gasket	**040166104A**	NA,NB,NC 2005-2009	Engine	16-00
Thermostat Kit	Thermostat And Thermostat Gasket	**S040166119**	NA,NB,NC 2010 Only	Engine	16-00
Thermostat Kit	Thermostat And Thermostat Gasket	**S040166114**	ND,NE,NJ,NV 2005-2010	Engine	16-00
Thermostat Gasket	Seals The Thermostat In The Housing- Use Sealant # 041321207b On The Flange	**163251390A**	NA,NB,NC 2005-2010	Engine	16-00
Thermostat Gasket	Seals The Thermostat In The Housing- Use Sealant # 041321207b On The Flange	**S163251400**	ND,NE,NJ,NV 2005-2010	Engine	16-00
Radiator, Manual Trans.	Includes The Radiator Cap	**S160906860**	NA,NB,NC 2005-2007	Chassis	22-00
Radiator, Manual Trans.	Includes The Radiator Cap	**16400E0230**	ND,NE,NJ,NV 2005-2007	Chassis	22-00
Radiator, Auto Trans.	Includes The Radiator Cap	**S160906850**	NA,NB,NC 2005-2007	Chassis	22-00
Radiator, Auto Trans.	Includes The Radiator Cap	**16400E0070**	ND,NE,NJ,NV 2005-2007	Chassis	22-00
Radiator, Manual Trans.	Includes The Radiator Cap	**16400E0280**	NB,NC 2008-2010	Chassis	22-00
Radiator, Manual Trans.	Includes The Radiator Cap	**16400E0250**	ND,NE,NJ,NV 2008-2010	Chassis	22-00
Radiator, Auto Trans.	Includes The Radiator Cap	**16400E0290**	NA 2008-2010	Chassis	22-00
Radiator, Auto Trans.	Includes The Radiator Cap	**16400E0300**	NB,NC 2008-2010	Chassis	22-00
Radiator, Auto Trans.	Includes The Radiator Cap	**16400E0260**	ND,NE,NJ,NV 2008-2010	Chassis	22-00
Retainer	Retainer Clip For Auto Transmission Fluid Hose At Bottom Of Radiator	**21598E0010**	ND,NE,NJ,NV 05-06-07	Chassis	22-00
Radiator Cap	8.3 Psi	**164011710A**	ALL 2005-2010	Chassis	22-00
Reserve Tank	Plastic Tank With Cap, Hose And Bracket	**16470E0030**	ALL 2005-2010	Chassis	22-00

https://truckmanualshub.com/

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Cooling System - Fan Clutch/Radiator Hoses/Sensor					
Fan Clutch	Does Not Include The Fan	**16250E0020**	NA,NB,NC 2005-2010	Engine	16-00
Fan Clutch	Does Not Include The Fan	**16250E0030**	ND,NE,NJ,NV 2005-2007	Engine	16-00
Fan Clutch	Does Not Include The Fan	**16250E0240**	ND,NE,NJ,NV 2008-2010	Engine	16-00
Lower Radiator Hose	Lower Radiator Hose	**900155759A**	NA,NB,NC 2005-2007	Chassis	22-00
Lower Radiator Hose	Lower Radiator Hose	**16572E0120**	NA,NB,NC 2008-2010	Chassis	22-00
Upper Radiator Hose	Upper Radiator Hose	**16571E0161**	NA,NB,NC 2008-2010	Chassis	22-00
Upper Radiator Hose	Upper Radiator Hose	**900155760A**	NA,NB,NC 2005-2007	Chassis	22-00
Lower Radiator Hose	Lower Radiator Hose	**900155767A**	ND,NE,NJ,NV 2005-2007	Chassis	22-00
Lower Radiator Hose	Lower Radiator Hose	**16572E0110**	ND,NE,NJ,NV 2008-2010	Chassis	22-00
Upper Radiator Hose	Upper Radiator Hose	**900155758A**	ND,NE,NJ,NV 2005-2007	Chassis	22-00
Upper Radiator Hose	Upper Radiator Hose	**16571E0140**	ND,NE,NJ,NV 2008-2010	Chassis	22-00
Low Coolant Sensor	In Radiator Top Tank	**S834601510**	ALL MODELS 2005-2010	Chassis	22-00

https://truckmanualshub.com/

D

https://truckmanualshub.com/

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Driveline - Differential Pinion Seals					
Remanufactured Carriers Are Available For Most Models And Applications Call 1-866-372-4466 Hino Customer Service For More Information					
Pinion Seal	Differential Pinion Seal	**A1205D1928**	NA,NB,NC 2005-2010	Drive	68-20
Nut Lock Pinion	Pinion Flange Nut	**1227Q1291**	NA,NB 2005-2010	Drive	68-20
Nut Lock Pinion	Pinion Flange Nut	**40X1236**	NC 2005-2010	Drive	68-20
Pinion Seal	Differential Pinion Seal	**A11205Z2730**	ND,NE,NJ,NV Standard 2005-2010	Drive	68-20
Pinion Seal	Differential Pinion Seal	**A1205Q2695**	NV Opt. 2005-2010	Drive	68-20
Nut Lock Pinion	Pinion Flange Nut	**40X1237**	ND,NE,NJ,NV 2005-2010	Drive	68-20
2005 - 2010 - Driveline - Axle Shafts					
Axle Shaft	Right Side Axle	**3206Q1863**	NA,NB 2005-2010	Drive	68-00
Axle Shaft	Left Side Axle	**3206P1862**	NA,NB 2005-2010	Drive	68-00
Axle Shaft	Right Side Axle	**3202E9001**	NC 2005-2010	Drive	68-00
Axle Shaft	Left Side Axle	**3202F9002**	NC 2005-2010	Drive	68-00
Axle Shaft	Right Side Axle 12 Hole Flange	**3202Y9047**	ND,NE,NJ,NV 2005-2010	Drive	68-00
Axle Shaft	Left Side Axle 12 Hole Flange	**3202X9046**	ND,NE,NJ,NV 2005-2010	Drive	68-00
Axle Shaft	Right Side Axle 8 Hole Flange	**3206S1345**	ND,NE,NJ,NV 2005-2010	Drive	68-00
Axle Shaft	Left Side Axle 8 Hole Flange	**3206Q1343**	ND,NE,NJ,NV 2005-2010	Drive	68-00
Axle Shaft	Depends On Options And Axle Ratio	**See EPC**	NV	Drive	68-00

https://truckmanualshub.com/

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Driveline - Axle Gaskets					
Gasket	Rear Axle Gasket	**RTV Silicone Red Grade**	NA,NB 2005-2010	Drive	68-00
Gasket	Rear Axle Gasket	**2208J426**	NC 2005-2010	Drive	68-00
Gasket	Rear Axle Gasket 8 Hole	**2208H476**	ND,NE 2005-2010	Drive	68-00
Gasket	Rear Axle Gasket 12 Hole	**2208E1123**	NJ,NV 2005-2008	Drive	68-00
2005 - 2010 - Driveline - U-Joints - Center Bearings - Boot Kits					
Remanufactured Carriers Are Available For Most Models And Applications Call 1-866-372-4466 Hino Customer Service For More Information					
U-Joint Kit	Caps And Cross	**SPL70-1X**	NA,NB,NC 2005-2010	Drive	34-00
U-Joint Kit	Caps And Cross	**SPL100-1X**	ND,NE,NJ 2005-2010	Drive	34-00
U-Joint Kit	Caps And Cross	**SPL140X**	NV 2005-2010	Drive	34-00
Center Bearing	Carrier Bearing, Insulator And Strap	**212261-1X**	NA,NB,NC, ND,NE,NJ 2005-2010	Drive	34-00
Center Bearing	Carrier Bearing, Insulator And Strap	**210121-1X**	NV 2005-2010	Drive	34-00
Boot Kit	Boot, Clamps And Grease	**212146X**	NA,NB,NC, ND,NE,NJ 2005-2010	Drive	34-00
Boot Kit	Boot, Clamps And Grease	**212059X**	NV 2005-2010	Drive	34-00
U-Joint Strap	Joint Strap Kit Includes 2 Straps And 4 Bolts	**3-70-38X**	NA,NB,NC 2005-2010	Drive	34-00
U-Joint Strap	Joint Strap Kit Includes 2 Straps And 4 Bolts	**90-70-28X**	ND,NE,NJ 2005-2010	Drive	34-00
U-Joint Strap	Joint Strap Kit Includes 2 Straps And 4 Bolts	**140-70-18X**	NV ONLY 2005-2010	Drive	34-00

https://truckmanualshub.com/

E

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010- Electrical - Switches					
Parking Brake Switch	Under Parking Brake Plastic Cover	**845501300A**	NA,NB,NC ND,NE 2005-2006	Chassis	38-20
Parking Brake Switch	Under Parking Brake Plastic Cover	**845501320A**	NA,NB,NC ND,NE 2005-2010	Chassis	38-20
Dimmer Switch	Dash Lights	**S841101460**	ALL 2005-2007 ONLY	Electrical	27-20
Dimmer Switch	Dash Lights	**84110E0010**	ALL 2008-2010	Electrical	27-20
Headlamp & Directional Switch	Left Side At Column	**S840111490**	ALL 2005-2010	Chassis	64-56
Wiper Switch	Right Side At Column	**S840311790**	ALL 2005-2007	Chassis	64-56
Wiper Switch	Right Side At Column	**840311800A**	ALL 2008-2010	Chassis	64-56
Cruise Control On/ Off	Left Side At Column	**842803750A**	ALL 2005-2010	Electrical	27-20
Cruise Control Set/Resume	Left Side At Column	**842803760A**	ALL 2005-2010	Electrical	27-20
Cargo Box Light Switch	Left Side At Column	**S842803780**	ALL 2005-2010	Electrical	27-20
Heated Mirror Switch	Heated Mirrors Are Not Standard - Part Of Cold Weather Option Package	**S842803770**	ALL 2005-2010	Electrical	27-20
Transmission Mode Switch	In Shift Lever Console For Power/Economy Mode	**S842803790**	ND,NE,NJ 2005-2010	Electrical	27-20
ABS Diagnostic Switch	Right Side At Column	**842803710A**	ALL 2005-2010	Electrical	27-20
Idle Control Switch	Located Right Side Of Column	**84581E0030**	ALL 2005-2010	Electrical	27-20
Buzzer	Psi Low Air Warning	**866501770A**	NJ,NV 2005-2010	Electrical	27-20
Air Horn Switch	Located On Right Side Column	**842804340A**	NJ,NV 2005-2010	Electrical	27-20
Display Switch	Located On Right Side Column For Multi-Display In Instrument Cluster	**842803460A**	ALL 2008-2010	Electrical	27-20
Ignition Switch	Does Not Include Lock Cylinder	**845601050A**	ALL 2005-2010	Electrical	27-20
DPR Manual Operation Switch	Regeneration Switch Located On Dash Left Of Steering Wheel	**84280E0040**	ALL 2008-2010	Electrical	27-20

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Electrical - Engine Sensors					
Water Temp. Sensor	Right Front Corner At Head	**S834201250**	ALL 2005-2010	Electrical	18-10
Low Coolant Sensor	In Radiator Top Tank	**S834601510**	ALL 2005-2010	Chassis	22-00
Oil Pressure Sensor	In Oil Cooler At Filter	**83530E0220**	ALL 2005-2010	Electrical	18-10
Crankshaft Speed Sensor	In Flywheel Housing At Top - 2 Pin	**S894111280**	ALL 2005-2010	Electrical	18-10
Camshaft Speed Sensor	In Back Of Head - (3 Pin - 90 Degree)	**894101570A**	NA,NB,NC 2005-2010	Electrical	18-10
Camshaft Speed Sensor	In Back Of Head - (3 Pin - Straight)	**894101590A**	ND,NE,NJ,NV 2005-2010	Electrical	18-10
Air Intake Pressure Sensor	At Air Intake Manifold (Turbo Boost Pressure Sensor)	**S893901080**	ALL 2005-2010	Electrical	18-10
Mass Air Flow Sensor	Both 4 Cylinder And 6 Cylinder	**S176601020**	ALL 2005-2010	Chassis	25-00
Common Rail Pressure Sensor	Both 4 Cylinder And 6 Cylinder	**S227621070**	ALL 2005-2007	Engine	15-88
Common Rail Pressure Sensor	Both 4 Cylinder And 6 Cylinder	**23810E0020**	ALL 2008-2010	Engine	15-88
Throttle Position Sensor	Accelerator Pedal Assembly With Throttle Position Sensor	**S780101200**	ALL 2005-2010	Chassis	61-00
2005 - 2010 - Electrical - Engine - Starters/Alternators					
Starter	Denso Reman	**281002910R**	NA,NB,NC 2005-2010	Electrical	19-05
Starter	Denso Reman	**S281002921**	ND,NE,NJ,NV 2005-2010	Electrical	19-05
Starter	Denso (New)	**281002911A**	NA,NB,NC 2005-2010	Electrical	19-05
Starter	Denso (New)	**S281002921**	ND,NE,NJ,NV 2005-2010	Electrical	19-05
Alternator Std.	Denso 12v 105 Amp Brushless Reman	**270402550R**	NA,NB,NC 2005-2010	Electrical	19-04
Alternator Std.	Denso 12v 105 Amp Brushless Reman	**270402560R**	ND,NE,NJ,NV 2005-2010	Electrical	19-04
Alternator Std.	Delco 12v 100 Amp (Reman) No Fan Or Pulley Core Charge Applies	**10459604**	NA,NB,NC 2005-2010	Electrical	19-04
Alternator Std.	Delco 12v 100 Amp (New) With Fan And Pulley	**270402530A**	NA,NB,NC 2005-2010	Electrical	19-04
Alternator Std.	Delco 12v 100 Amp (New) With Fan And Pulley	**270402540A**	ND,NE,NJ,NV 2005-2010	Electrical	19-04
Alternator Opt.	Denso 12v 105 Amp Brushless (New) With Fan And Pulley	**270402550A**	NA,NB,NC 2005-2010	Electrical	19-04
Alternator Opt.	Denso 12v 105 Amp Brushless (New) With Fan And Pulley	**S270402560**	ND,NE,NJ,NV 2005-2010	Electrical	19-04

https://truckmanualshub.com/

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Electrical - Relays And Turn Signal Flashers					
Headlight & Tail Lamp	Located In The Cab On The Right Side Behind The Fuse Cover	**88630E0040**	ALL 2005-2010	Electrical	27-20
Wiper Relay	Located In The Cab On The Right Side Behind The Fuse Cover	**S859401130**	ALL 2005-2010	Electrical	27-20
Stop Lamp Relay	Located In The Cab On The Right Side Behind The Fuse Cover	**88630E0040**	ALL 2005-2010	Electrical	27-20
ABS Motor Relay	Located In The Fuse/Relay Box Behind The Left Side Of The Cab	**S859202750**	ALL 2005-2010	Electrical	27-00
ECU Main Relay	Located In The Fuse/Relay Box Behind The Left Side Of The Cab	**88630E0040**	ALL 2005-2010	Electrical	27-00
Power Relay	Located In The Fuse/Relay Box Behind The Left Side Of The Cab	**88630E0040**	ALL 2005-2010	Electrical	27-00
Starter Relay	Located In The Fuse/Relay Box Behind The Left Side Of The Cab	**S283001280**	ALL 2005-2010	Electrical	27-00
Flasher, Turn Signal	Located In The Cab On The Right Side Behind The Fuse Cover	**819801990A**	All Models 2005-2006	Electrical	27-20
Flasher, Turn Signal	Located In The Cab On The Right Side Behind The Fuse Cover	**81980E0010**	All Models 2007-2010	Electrical	27-20
A/C Compressor Relay	Located In The Cab On The Right Side Behind The Fuse Cover	**S859202740**	ALL 2005-2010	Electrical	27-20
Glow Plug Relay (Option)	Located In The Fuse/Relay Box Behind The Left Side Of The Cab	**S286201470**	ALL 2005-2010	Electrical	27-00
Fuel Heater Relay (Option)	Located In The Fuse/Relay Box Behind The Left Side Of The Cab	**S859202760**	ALL 2005-2010	Electrical	27-00
ATM Back-Up Relay (Option)	Located In The Fuse/Relay Box Behind The Left Side Of The Cab	**88630E0040**	ALL 2005-2010	Electrical	27-00
Brake Light Relay	Located In The Cab On The Right Side Behind The Fuse Cover	**S859202840**	ALL 2005-2010	Electrical	27-00

https://truckmanualshub.com/

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010- Electrical - Engine - EGR Solenoids					
Computer - Fuel Injection	Engine Ecu	**S895606540**	ALL 2005-2007	Electrical	27-20
Computer - Fuel Injection	Engine Ecu	**89660E0100**	ALL 2008-2010	Electrical	27-20
EGR Valve	Includes Manifold And Egr Valve	**25620E0040**	NA,NB,NC 2005-2007	Engine	13-20
EGR Valve	Includes Manifold And Egr Valve (Valve Not Sold Separately)	**25620E0090**	NA,NB,NC 2008-2010	Engine	13-20
EGR Valve	Includes Manifold And Egr Valves	**25620E0030**	ND,NE,NJ NV 2005-2007	Engine	13-20
EGR Valve	Includes Manifold And Egr Valves (Valves Not Sold Separately)	**25620E0170**	ND,NE,NJ NV 2008-2010	Engine	13-20
2005 - 2010- Electrical - Engine - Intake Shutter, Throttle Body, And Intake Meter Assy					
Shutter	Intake Shutter Assembly Attaches To Intake Pipe On Left Side Of Engine	**26100E0061**	NA,NB,NC 2008-2010	Engine	13-20
Throttle Body	Diesel Throttle Body Attaches To Intake Pipe On Left Side Of Engine	**26100E0050**	ND,NE,NJ NV 2008-2010	Engine	13-20
Intake Meter	Intake Air Flow Meter Assembly On Pipe At Air Filter Housing	**S176601020**	ALL MODELS 2008-2010	Chassis	25-00
2005 - 2010 - Electrical - Fuses/Fusible Links					
Fuse	5a	**SZ98057050**	ALL 2005-2010	Electrical	27-00/27-20
Fuse	10a	**SZ98057051**	ALL 2005-2010	Electrical	27-00/27-20
Fuse	15a	**900857153A**	ALL 2005-2010	Electrical	27-00/27-20
Fuse	20a	**900857154A**	ALL 2005-2010	Electrical	27-00/27-20
Fuse	30a	**900857159A**	ALL 2005-2010	Electrical	27-00/27-10
Fusible Link	30a	**SZ98058056**	ALL 2005-2010	Electrical	27-00/27-20
Fusible Link	40a	**SZ98058060**	ALL 2005-2010	Electrical	27-00/27-20
Fusible Link	40a	**SZ98058062**	ALL 2005-2010	Electrical	27-00/27-20
Fusible Link	60a	**SZ98058061**	ALL 2005-2010	Electrical	27-00
Fusible Link	60a	**SZ98058063**	ALL 2005-2010	Electrical	27-00
Fusible Link	140a	**SZ98058064**	ALL 2005-2010	Electrical	27-00
Fuse/Relay Box Cover	Outside Fuse Box Cover	**S844961780**	ALL 2005-2010	Electrical	27-00

https://truckmanualshub.com/

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Engine - Valves,Springs,Guides					
Intake Valve	2 Per Cylinder	**S137111632**	ALL 2005-2010	Engine	13-10
Exhaust Valve	2 Per Cylinder	**S137151733**	ALL 2005-2010	Engine	13-10
Outer Valve Spring	1 Per Valve	**S137311610**	ALL 2005-2010	Engine	13-10
Inner Valve Spring	1 Per Valve	**S137321500**	ALL 2005-2010	Engine	13-10
Valve Guides Intake & Exhaust	4 Per Cylinder	**S111221220**	ALL 2005-2010	Engine	10-00
Valve Stem Seals	4 Per Cylinder	**S137191470**	ALL 2005-2010	Engine	13-10
Lock, Valve Spring Retainer	2 Per Valve	**SZ91026013**	ALL 2005-2010	Engine	13-10
2005 - 2010 - Engine - Oil Pumps, Oil Caps, Plugs					
Oil Pump Assembly	Does Not Include Gasket For 4 Cyl	**S151102160**	NA,NB,NC 2005-2010	Engine	14-00
Oil Pump Assembly	Does Not Include Gasket For 6 Cyl	**S151102150**	ND,NE,NJ,NV 2005-2007	Engine	14-00
Oil Pump Assembly	Does Not Include Gasket For 6 Cyl	**15110E0020**	ND,NE,NJ,NV 2008-2010	Engine	14-00
Oil Pump Gasket	Seals Pump At Block	**S151191134**	ALL	Engine	14-00
Oil Filler Cap	For Valve Cover	**S121081100**	ALL	Engine	10-00
Drain Plug	For Engine Oil Pan	**SZ34118014**	ALL	Engine	11-00
Washer/Gasket	For Oil Drain Plug	**SZ43018006**	ALL	Engine	11-00

https://truckmanualshub.com/

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Engine - Main And Rod Bearings - Thrust Washers					
Conn Rod Bearing Set	Full Bearing Set Std. For Connecting Rods W/Studs And Nuts Wide Tab Locks	**S132011800**	NA,NB,NC 2005-2006	Engine	12-00
Conn Rod Bearing Set	Full Bearing Set Std. For Connecting Rods W/Bolts Narrow Tab Locks	**S132012120**	NA,NB,NC 2007 ONLY	Engine	12-00
Conn Rod Bearing Set	Full Bearing Set Std.	**13041E0240**	NA,NB,NC 2008-2010	Engine	12-00
Conn Rod Bearing Set	Full Bearing Set Std. For Connecting Rods W/Studs And Nuts Wide Tab Locks	**S132011761**	ND,NE,NJ,NV 2005-2006	Engine	12-00
Conn Rod Bearing Set	Full Bearing Set Std. For Connecting Rods W/Bolts Narrow Tab Locks	**S132012100**	ND,NE,NJ,NV 2007 Only	Engine	12-00
Conn Rod Bearing Set	Full Bearing Set Std.	**13041E0140**	ND,NE,NJ,NV 2008-2010	Engine	12-00
Main Bearing Set	Full Bearing Set Std. No Thrust Washers	**S117012310**	NA,NB,NC 2005-2010	Engine	12-00
Main Bearing Set	Full Bearing Set Std. No Thrust Washers	**S117012140**	ND,NE,NJ,NV 2005-2010	Engine	12-00
Thrust Washer Set	Fits 4 Cylinder And 6 Cylinder	**110111380A**	ALL 2005-2010	Engine	12-00

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Engine - Piston Liners					
Piston Liner "A"	Liner Letter Located On R/S Of Block Just Below Head Deck And Behind Alternator.	**114673170A**	NA,NB,NC 2005-2010	Engine	11-00
Piston Liner "A"	Liner Letter Located On R/S Of Block Just Below Head Deck And Behind Alternator.	**114673200A**	ND,NE,NJ,NV 2005-2010	Engine	11-00
Piston Liner "B"	Liner Letter Located On R/S Of Block Just Below Head Deck And Behind Alternator.	**114673180A**	NA,NB,NC 2005-2010	Engine	11-00
Piston Liner "B"	Liner Letter Located On R/S Of Block Just Below Head Deck And Behind Alternator.	**S114673210**	ND,NE,NJ,NV 2005-2010	Engine	11-00
Piston Liner "C"	Liner Letter Located On R/S Of Block Just Below Head Deck And Behind Alternator.	**114673190A**	NA,NB,NC 2005-2010	Engine	11-00
Piston Liner "C"	Liner Letter Located On R/S Of Block Just Below Head Deck And Behind Alternator.	**114673220A**	ND,NE,NJ,NV 2005-2010	Engine	11-00
Piston & Liner Kit "A"	Includes Rings, Piston, Liner (1) Does Not Include Wrist Pin Or Retainers	**S040130135**	NA,NB,NC 2005-2007	Engine	12-00
Piston & Liner Kit "A"	Includes Rings, Piston, Liner (1) Does Not Include Wrist Pin Or Retainers	**S040130311**	NA,NB,NC 2008-2010	Engine	12-00
Piston & Liner Kit "A"	Includes Rings, Piston, Liner (1) Does Not Include Wrist Pin Or Retainers	**040130138A**	ND,NE,NJ,NV 2005-2007 Only	Engine	12-00
Piston & Liner Kit "A"	Includes Rings, Piston, Liner (1) Does Not Include Wrist Pin Or Retainers	**S040130314**	ND,NE,NJ,NV 2008-2010	Engine	12-00
Piston & Liner Kit "B"	Includes Rings, Piston, Liner (1) Does Not Include Wrist Pin Or Retainers	**S040130136**	NA,NB,NC 2005-2007	Engine	12-00
Piston & Liner Kit "B"	Includes Rings, Piston, Liner (1) Does Not Include Wrist Pin Or Retainers	**S040130312**	NA,NB,NC 2008-2010	Engine	12-00
Piston & Liner Kit "B"	Includes Rings, Piston, Liner (1) Does Not Include Wrist Pin Or Retainers	**S040130266**	ND,NE,NJ,NV 2005-2007	Engine	12-00
Piston & Liner Kit "B"	Includes Rings, Piston, Liner (1) Does Not Include Wrist Pin Or Retainers	**S040130315**	ND,NE,NJ,NV 2008-2010	Engine	12-00
Piston & Liner Kit "C"	Includes Rings, Piston, Liner (1) Does Not Include Wrist Pin Or Retainers	**S040130137**	NA,NB,NC 2005-2007	Engine	12-00
Piston & Liner Kit "C"	Includes Rings, Piston, Liner (1) Does Not Include Wrist Pin Or Retainers	**S040130313**	NA,NB,NC 2008-2010	Engine	12-00

https://truckmanualshub.com/

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Engine - Piston Liners (Cont.)					
Piston & Liner Kit "C"	Includes Rings, Piston, Liner (1) Does Not Include Wrist Pin Or Retainers	**S040130267**	ND,NE,NJ,NV 2005-2007 Only	Engine	12-00
Piston & Liner Kit "C"	Includes Rings, Piston, Liner (1) Does Not Include Wrist Pin Or Retainers	**S040130316**	ND,NE,NJ,NV 2008-2010	Engine	12-00
Piston With Ring Set	Piston And Rings Only (1)	**130051230A**	NA,NB,NC 2005-2007	Engine	12-00
Piston With Ring Set	Piston And Rings Only (1)	**S130BE0090**	NA,NB,NC 2008-2010	Engine	12-00
Piston With Ring Set	Piston And Rings Only (1)	**S130BE0010**	ND,NE,NJ,NV 2005-2007	Engine	12-00
Piston With Ring Set	Piston And Rings Only (1)	**S130BE0020**	ND,NE,NJ,NV 2008-2010	Engine	12-00
Ring Set	Rings For 1 Cyl Only	**S130191130**	NA,NB,NC 2005-2007	Engine	12-00
Ring Set	Rings For 1 Cyl Only	**S1304E0070**	NA,NB,NC 2008-2010	Engine	12-00
Ring Set	Rings For 1 Cyl Only	**S130192080**	ND,NE,NJ,NV 2005-2007 Only	Engine	12-00
Ring Set	Rings For 1 Cyl Only	**S1304E0030**	ND,NE,NJ,NV 2008-2010	Engine	12-00
Wrist Pin Kit	Wrist Pin And Retainers, Rod Bushing For 1cyl.	**S040132114**	ALL 2005-2006	Engine	12-00
Wrist Pin Kit	Wrist Pin And Retainers, Rod Bushing For 1cyl.	**S040132122**	ALL 2007-2010	Engine	12-00

https://truckmanualshub.com/

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Engine - Gaskets And Gasket Kits					
Engine Overhaul Gasket Set	Complete Overhaul Gasket Set	**040103833A**	NA,NB,NC 2005-2007	Engine	19-91
Engine Overhaul Gasket Set	Complete Overhaul Gasket Set	**S040104255**	NA,NB,NC 2008-2010	Engine	19-91
Engine Overhaul Gasket Set	Complete Overhaul Gasket Set	**S040103754**	ND,NE 2005-2007	Engine	19-91
Engine Overhaul Gasket Set	Complete Overhaul Gasket Set	**S040103755**	NJ,NV 2005-2007	Engine	19-91
Engine Overhaul Gasket Set	Complete Overhaul Gasket Set	**S040104256**	ND,NE,NJ,NV 2008-2010	Engine	19-91
Cylinder Head Gasket	Head Gasket Only	**111152900A**	NA,NB,NC 2005-2010	Engine	10-00
Cylinder Head Gasket	Head Gasket Only	**111152870A**	ND,NE,NJ,NV 2005-2010	Engine	10-00
Valve Cover Gasket	Gasket Only	**112132020A**	NA,NB,NC 2005-2010	Engine	10-00
Valve Cover Gasket	Gasket Only	**S112131880**	ND,NE,NJ,NV 2005-2010	Engine	10-00
Front Main Seal	Seal Only	**SZ31179002**	ALL 2005-2010	Engine	10-00
Rear Main Seal	Seal Only	**SZ31101045**	ALL 2005-2010	Engine	10-00
Camshaft Housing Gasket	Seal Bet-37ween Head And Camshaft Housing	**S111181011**	ND,NE,NJ,NV 2005-2010	Engine	10-00
Oil Pan Gasket	Pan Gasket Only	**S121512622**	NA,NB,NC 2005-2010	Engine	11-00
Oil Pan Gasket	Pan Gasket Only	**S121512611**	ND,NE,NJ,NV 2005-2010	Engine	11-00
Intake Manifold Gasket	Intake Manifold To Cylinder Head	**S171712000**	NA,NB,NC 2005-2010	Engine	13-20
Intake Manifold Gasket	Intake Manifold To Cylinder Head	**S171712200**	ND,NE,NJ,NV 2005-2010	Engine	13-20

https://truckmanualshub.com/

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Engine - Intercooler					
Intercooler	Intercooler Assembly	**S243002250**	ALL 2005-2007	Chassis	22-00
Intercooler	Intercooler Assembly	**17940E0330**	ALL 2008-2010	Chassis	22-00
Intercooler Hose	Right Side Turbo To Intercooler	**SZ92033903**	NA,NB,NC 2005-2007	Chassis	25-00
Intercooler Hose	Right Side Turbo To Intercooler	**SZ92033B21**	NA,NB,NC 2008-2010	Chassis	25-00
Intercooler Hose	Left Side Intercooler To Intake	**900239709A**	NA,NB,NC 2005-2007	Chassis	25-00
Intercooler Hose	Left Side Intercooler To Intake	**SZ92033B22**	NA,NB,NC 2008-2010	Chassis	25-00
Intercooler Hose	Right Side "Short Hose" Turbo To Pipe	**900239657A**	ND,NE,NJ,NV 2005-2007	Engine	18-30
Intercooler Hose	Right Side "Short Hose" Turbo To Pipe	**SZ92033892**	ND,NE,NJ,NV 2008-2010	Engine	18-30
Intercooler Hose	Right Side "Long Hose" Pipe To Intercooler	**SZ92033B18**	ND,NE,NJ,NV 2008-2010	Engine	25-00
Intercooler Hose	Right Side "Long Hose" Pipe To Intercooler	**SZ92033896**	ND,NE,NJ,NV 2005-2007	Chassis	25-00
Intercooler Hose	Left Side Intercooler To Intake	**SZ92033B19**	ND,NE,NJ,NV 2008-2010	Chassis	25-00
Intercooler Hose	Left Side Intercooler To Intake	**SZ92033897**	ND,NE,NJ,NV 2005-2007	Chassis	25-00

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Engine - Exhaust System					
Turbocharger	Turbocharger With Vnt Controller	**S040010439**	NA,NB,NC 2005-2007	Engine	18-30
Turbo Gasket Set	Complete Gasket Set For Replacment Of Turbo Charger	**S040010441**	NA,NB,NC 2005-2010	Not Shown	Not Shown
Turbocharger	Turbocharger With Vnt Controller	**17201E0361**	NA,NB,NC 2008-2010	Engine	18-30
Turbocharger	Turbocharger With Vnt Controller	**S040010440**	ND,NE,NJ,NV 2005-2007	Engine	18-30
Turbo Gasket Set	Complete Gasket Set For Replacment Of Turbo Charger	**S040010442**	ND,NE,NJ,NV 2005-2010	Not Shown	Not Shown
Turbocharger	Turbocharger With Vnt Controller	**17201E0352**	ND,NE,NJ,NV 2008-2010	Engine	18-30
Turbo Gasket	Turbo To Exhaust Manifold	**S241091860**	NA,NB,NC 2005-2010	Engine	18-30
Turbo Gasket	Turbo To Exhaust Manifold	**S241091820**	ND,NE,NJ,NV 2005-2010	Engine	18-30
Header Pipe Gasket	Turbo Exhaust Elbow	**S241091840**	NA,NB,NC 2005-2010	Engine	18-30
Header Pipe Gasket	Turbo Exhaust Elbow	**S241091830**	ND,NE,NJ,NV 2005-2010	Engine	18-30
Gasket Oil Return	Turbo Oil Return Tube - 2 Required	**S241351121**	ALL 2005-2010	Engine	18-30
Gasket Oil Supply	Upper Gaskets On Oil Supply Tube	**SL72201210**	ALL 2005-2010	Engine	18-30
Gasket Oil Supply	Lower Gaskets On Oil Supply Tube	**SL72201415**	ALL 2005-2010	Engine	18-30
Exhaust Manifold Gasket	(4 Required For 4 Cyl.) (6 Required For 6 Cyl.)	**S171041610**	ALL 2005-2010	Engine	13-20
EGR Manifold Gasket	Egr To Intake Manifold Gasket	**S171731850**	NA,NB,NC 2005-2010	Engine	13-20
EGR Manifold Gasket	Egr To Intake Manifold Gasket	**S171041910**	ALL 2008-2010	Engine	13-20
EGR Manifold Gasket	Egr To Intake Manifold Gasket	**S171731860**	ND,NE,NJ,NV 2005-2007	Engine	13-20
EGR Crossover Pipe Gasket	Both Ends Of Egr Crossover Pipe And Egr Inter Cooler To Exhaust Manifold (Qty 3)	**S171042010**	NA,NB,NC 2005-2010	Engine	13-20
EGR Crossover Pipe Gasket	Both Ends Of Egr Crossover Pipe (Qty 2)	**S171041990**	ND,NE,NJ,NV 2005-2010	Engine	13-20
EGR Crossover Pipe Gasket	Both Ends Of Egr Crossover Pipe And Egr Cooler To Egr Valve (Qty5)	**S171041990**	ND,NE,NJ,NV 2008-2010	Engine	13-20
EGR Crossover Pipe Gasket	Egr Cooler Cross Over Pipe At Egr Cooler (Qty 1)	**S171042000**	ND,NE,NJ,NV 2005-2007	Engine	13-20
Front Pipe	Turbo Elbow To Muffler	**17401E0560**	NA,NB,NC 2008-2010	Chassis	24-00

https://truckmanualshub.com/

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Engine - Exhaust System (Cont.)					
Front Pipe	Turbo Elbow To Muffler	**S176022000**	ND,NE,NJ,NV 2005-2007	Chassis	24-00
Front Pipe	Turbo Elbow To Muffler	**17401E0570**	ND,NE,NJ,NV 2008-2010	Chassis	24-00
Front Pipe	Turbo Elbow To Muffler With Vertical Exhaust	**17401E0580**	ND,NE,NJ,NV 2008-2010	Chassis	24-00
Muffler	Cat/Muffler	**S176071990**	NA,NB,NC 2005-2007	Chassis	24-00
Muffler	Cat/Muffler	**176071780A**	ND,NE,NJ,NV 2005-2007	Chassis	24-00
Filter	Particulate Filter Center Section Only	**S1805E0260**	NA,NB,NC 2008-2010	Chassis	24-00
Filter	Particulate Filter Center Section Only	**S1805E0270**	ND,NE,NJ,NV 2008-2010	Chassis	24-00
Gasket	Filter Gasket For Above 2 Per Truck	**S171041930**	ALL MODELS 2008-2010	Chassis	24-00
Filter & Muffler	Particulate Filter Assy. With Mufflers	**S1850E0270**	NA,NB,NC 2008-2010	Chassis	24-00
Filter & Muffler	Particulate Filter Assy. With Mufflers	**S1850E0281**	ND,NE,NJ,NV 2008-2010	Chassis	24-00
Tail Pipe	Pipe Only	**S174324090**	ALL 2005-2007	Chassis	24-00
Tail Pipe	Pipe Only	**17431E0240**	ALL 2008-2010	Chassis	24-00
Tail Pipe	Tail Pipe Vertical Exhaust From Flex Pipe Upward To Turn Out	**17405E0341**	ND,NE,NJ,NV 2008-2010	Chassis	24-00
Tail Pipe	Flex Pipe For Vertical Exhaust	**17401E0580**	ND,NE,NJ,NV 2008-2010	Chassis	24-00
Tail Pipe	Tail Pipe Vertical Exhaust From Muffler To Flex	**17405E0351**	ND,NE,NJ,NV 2008-2010	Chassis	24-00
Tail Pipe	Stack Pipe With Turn Out	**17431E0261**	ND,NE,NJ,NV 2008-2010	Chassis	24-00
Tail Pipe	Band Clamps For Vertical Exhaust	**17452E0070**	ND,NE,NJ,NV 2008-2010	Chassis	24-00
Tail Pipe	Gasket Between Front Pipe And Muffler	**S171041580**	NA,NB,NC 2005-2010	Chassis	24-00
Exhaust Pipe Gasket	Gasket Between Turbo Elbow And Front Exhaust Pipe	**S171041490**	NA,NB,NC 2005-2010	Chassis	24-00
Exhaust Pipe Gasket	Gasket Between Turbo Elbow And Front Pipe. Also Between Front Pipe And Muffler	**S171041580**	ND,NE,NJ,NV 2005-2010	Chassis	24-00
Exhaust Sensor	On Front And Rear Of Dpr Filter/ Muffler Two Per Truck	**S894416511**	ALL 2008-2010	Chassis	24-00
Exhaust Sensor	Pressure Sensor For Particulate Filter	**S893901090**	ALL 2008-2010	Chassis	24-00
Exhaust Brake	Exhaust Brake Assembly	**46700E0030**	ALL 2008-2010	Chassis	24-00
Exhaust Brake	Exhaust Brake Control Cylinder	**S174902450**	ALL 2008-2010	Chassis	24-53

https://truckmanualshub.com/

https://truckmanualshub.com/

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Fuel - Common Rail Fuel Injection System					
Injector	Complete Injector Assembly	**23670E0271**	NA,NB,NC 2005-2007	Engine	15-00
Injector	Complete Injector Assembly	**23670E0231**	NA,NB,NC 2008-2010	Engine	15-00
Injector	Complete Injector Assembly	**23670E0291**	ND,NE,NJ,NV 2005-2007	Engine	15-00
Injector	Complete Injector Assembly	**23670E0202**	ND,NE,NJ,NV 2008 Only	Engine	15-00
Injector	Complete Injector Assembly	**23670E0391**	ND,NE,NJ,NV 2009-2010	Engine	15-01
O-Ring	Orange O-Ring in Head to Seal Nozzle	**SZ91015047**	ALL 2005-2010	Engine	10-00
Seal	Injector Inlet Pipe at Head	**S230741070**	NA,NB,NC 2005-2010	Engine	10-00
Seal	Injector Inlet Pipe at Camshaft Housing	**S237451020**	ND,NE,NJ,NV 2005-2010	Engine	10-00
Pressure/Supply Pump	4 Cylinder Pump	**S227301321**	NA,NB,NC 2005-2007	Engine	15-00
Pressure/Supply Pump	4 Cylinder Pump	**22100E0110**	NA,NB,NC 2008-2010	Engine	15-00
Pressure/Supply Pump	6 Cylinder Pump	**S227301311**	ND,NE,NJ,NV 2005-2007	Engine	15-00
Pressure/Supply Pump	6 Cylinder Pump	**22100E0102**	ND,NE,NJ,NV 2008-2010	Engine	15-00
Pressure Pump O-Ring	O-Ring Seals Pressure Pump to Flange	**SN73210493**	ALL 2005-2010	Engine	15-00
Soft Washers	Washers Needed To Replace Fuel Supply Pump 2 Of Each Part Number	**S228771100 SZ43010011**	NA,NB,NC 2005-2010	Engine	15-00
Soft Washers	Washers Needed To Replace Fuel Supply Pump 2 Of Each Part Number	**S228771100 S228771120**	ND,NE,NJ,NV 2005-2010	Engine	15-00
Common Rail Assembly	Includes Pressure Sensor	**VIN Required Call Customer Service**	NA,NB,NC 2005-2010	Engine	15-00
Common Rail Assembly	Includes Pressure Sensor	**23810E0020**	ND,NE,NJ,NV 2005-2010	Engine	15-00
Common Rail Pressure Sensor	Both 4 Cylinder and 6 Cylinder	**S227621070**	ALL 2005-2010	Engine	15-88
Gasket - Pressure Sensor	Gasket to Seal Senor at Common Rail	**228472680A**	All 2005-2010	Engine	15-88
Common Rail Flow Dampner	Threads into Common Rail - No Gasket	**S227401110**	ALL 2005-2010	Engine	15-88
Flow Limiter Assembly	Threads into Common Rail Mid Year Change Of 11 Month 2006	**227701090A**	ALL 2005-2007	Engine	15-87
Flow Limiter Assembly	Threads into Common Rail Late 2007	**S227701110**	ALL 2007-2010	Engine	15-88

https://truckmanualshub.com/

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Filters- Oil /Air /Fuel /Power Steering					
Oil Filter	4 Cylinder	**156072170A**	NA,NB,NC 2005-2010	Engine	14-52
Oil Filter	6 Cylinder	**15613E0030**	ND,NE,NJ,NV 2005-2010	Engine	14-52
Air Filter	4 Cylinder	**178013430A**	NA,NB,NC 2005-2010	Chassis	25-51
Air Filter	6 Cylinder	**178013440A**	ND,NE,NJ,NV 2005-2010	Chassis	25-51
Air Filter Indicator	In Air Intake Pipe	**S178201410**	ALL 2005-2010	Chassis	25-00
Fuel Filter	Fuel/Water Separator Element for RACOR	**234011700A**	ALL w/RACOR	Chassis	20-53
ALL LIGHT DUTY TRUCKS NA/NB/NC 2005-2010 HAVE ONLY THE RACOR FUEL FILTER					
Fuel Filter	Fuel/Water Separator Element for DAVCO	**FS1962490**	ALL w/DAVCO	Chassis	20-53
ALL MEDIUM DUTY TRUCKS 2008-2010 ND/NE/NJ/NV COME WITH DAVCO FILTER AS STANDARD EQUIPMENT. RACOR FILTER IS OPTIONAL.					
Air, Fuel and Oil Filter Kit	Air, Fuel, and Oil Filter Kit For Use with Racor Fuel Filter	**LDTFKIT**	NA,NB,NC 2005-2010	Not Shown	Not Shown
Fuel and Oil Filter Kit	Fuel and Oil Filter Kit For use with Racor Fuel Filter	**LDTFKITM**	NA,NB,NC 2005-2010	Not Shown	Not Shown
Air, Fuel and Oil Filter Kit	Air, Fuel, and Oil Filter Kit For Use with Racor Fuel Filter	**MDTFKIT**	ND,NE,NJ,NV 2005-2010	Not Shown	Not Shown
Fuel and Oil Filter Kit	Fuel and Oil Filter Kit For use with Racor Fuel Filter	**MDTFKITM**	ND,NE,NJ,NV 2005-2007	Not Shown	Not Shown
Fuel and Oil Filter Kit	Fuel and Oil Filter Kit For use with Davco Fuel Filter	**MDTFKITD**	ND,NE,NJ,NV 2005-2008	Not Shown	Not Shown
P/S Reservoir Filter	Filter Element	**S443611070**	ALL 2005-2010	Chassis	64-53
P/S Reservoir Strainer	Plastic Strainer	**S472281050**	ALL 2005-2010	Chassis	64-53

https://truckmanualshub.com/

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Fuel Tanks, Sending Units					
Primary Fuel Tank	35 Gallon Tank w/Sending Unit	**771004611A**	NA,NB,NC 2005-2010	Chassis	20-00
Primary Fuel Tank	52 Gallon Tank w/Sending Unit	**771004601A**	ND,NE,NJ,NV 2005-2010	Chassis	20-00
Primary Fuel Tank	52 Gallon Tank w/Sending Unit FOR VERTICAL STACK TAIL PIPE	**S7740E0070**	ND,NE,NJ,NV 2008-2010	Chassis	20-00
Primary Fuel Tank	95 Gallon Tank NO/Sending Unit CAN NOT USE ON 2008-2010 ND,NE,NJ,NV WITH VERTICAL EXHAUST	**771004620A**	ND,NE,NJ,NV 2005-2010	Chassis	20-00
Primary Fuel Tank	Aluminum 35 Gallon Tank w/ Sending Unit	**S7740E0420**	NA,NB,NC 2005-2010	Chassis	20-00
Primary Fuel Tank	Aluminum 52 Gallon Tank w/ Sending Unit	**S7740E0430**	ND,NE,NJ,NV 2005-2010	Chassis	20-00
Primary Fuel Tank	Aluminum 52 Gallon Tank w/Sending Unit FOR VERTICAL STACK TAIL PIPE	**S7740E0440**	ND,NE,NJ,NV 2005-2010	Chassis	20-00
Primary Fuel Tank	Aluminum 95 Gallon Tank NO/ Sending Unit CAN NOT USE ON 2008-2010 ND,NE,NJ,NV WITH VERTICAL EXHAUST	**S7740E0450**	ND,NE,NJ,NV 2005-2010	Chassis	20-00
Band Strap	35 Gallon Tank	**77601E0150**	NA,NB,NC 2005-2010	Chassis	20-00
Band Strap	52/95 Gallon Tank	**77601E0130**	ND,NE,NJ,NV 2005-2010	Chassis	20-00
L-Support Brkt	35 Gallon Tank	**77205E0230**	NA,NB,NC 2005-2010	Chassis	20-00
L-Support Brkt	52/95 Gallon Tank	**776072142A**	ND,NE,NJ,NV 2005-2010	Chassis	20-00
Fuel Gauge Sending Unit	35 Gallon Tank	**833202311A**	NA,NB,NC 2005-2010	Chassis	20-00
Fuel Gauge Sending Unit	52/95 Gallon Tank	**833202321A**	ND,NE,NJ,NV 2005-2010	Chassis	20-00
Gasket, Fuel Gage	35/52/95 Gallon Tank	**S833611190**	ALL 2005-2010	Chassis	20-00
Locking Fuel Cap	35/52/95 Gallon Steel Tank	**77310H3600**	ALL 2005-2010	Not Shown	Not Shown
Cap, Fuel Tank	35/52/95 Gallon Steel Tank	**1A900**	ALL 2005-2010	Chassis	20-00
Cap, Fuel Tank	35/52/95 Gallon Aluminum Tank	**AAA01326S**	ALL 2005-2010	Chassis	20-01

https://truckmanualshub.com/

https://truckmanualshub.com/

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Heater					
Heater Fan Motor	Motor and Cage	**S871041120**	ALL MODELS 2005-2010	Cab	B9-00
Heater Motor Resistor	Located at A/C-Heater Box	**S871381200**	ALL MODELS 2005-2010	Cab	B9-00
Heater Core	Located at A/C-Heater Box	**871071250A**	ALL MODELS 2005-2010	Cab	B9-00
Cable	Black Cable-Fresh Air Control	**874151641A**	ALL MODELS 2005-2010	Cab	B9-00
Cable	White Cable-Temperature Control	**874151630A**	ALL MODELS 2005-2010	Cab	B9-00
Cable	Blue Cable-Vent Position	**874151660A**	ALL MODELS 2005-2010	Cab	B9-00
2005 - 2010 - Horn, Horn Cover, Horn Spiral Cable					
Horn	Low Note	**S865201380**	ALL 2005-2007	Electrical	27-00
Horn	2nd Horn	**S865001260**	ALL 2007-2010	Electrical	27-00
Horn Spiral Cable	Under Horn Button Cover	**S840511041**	ALL 2005-2010	Chassis	64-56
Horn Cover	On Steering Wheel	**S451301560**	ALL 2005-2010	Chassis	64-55

https://truckmanualshub.com/

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Hub And Rotor - Front And Rear					
Front Hub and Rotor	R/H Hub and Rotor Assembly	**17159771000**	NA 2005-2010	Drive	66-00
Front Hub and Rotor	L/H Hub and Rotor Assembly	**17159771001**	NA 2005-2010	Drive	66-00
Front Hub and Rotor	Right or Left Hub and Rotor Assembly	**17159761001**	NB,NC 2005-2010	Drive	66-00
Front Hub and Rotor	Hub and Rotor Assembly	**17159641006**	ND,NE 8k Axle 2005-2010	Drive	66-00
Front Hub and Rotor	Hub and Rotor Assembly	**17159461000**	ND 258/LP 2005-2010 8k Axle	Drive	66-00
Front Hub and Rotor	Hub and Rotor Assembly	**17159101004**	ND,NE 10k Axle 2005-2010	Drive	66-00
Rear Hub and Rotor	R/H Hub and Rotor Assembly	**16159741001**	NA 2005-2010	Drive	68-00
Rear Hub and Rotor	L/H Hub and Rotor Assembly	**16159741000**	NA 2005-2010	Drive	68-00
Rear Hub and Rotor	Right or Left Hub and Rotor Assembly	**16159751000**	NB 2005-2010	Drive	68-00
Rear Hub and Rotor	Right or Left Hub and Rotor Assembly With Tone Ring	**16159731000**	NC 2005-2010	Drive	68-00
Rear Hub and Rotor	Right or Left Hub and Rotor Assembly	**16157191000**	ND,NE 2005-2010	Drive	68-00
Rear Hub and Rotor	Right or Left Hub and Rotor Assembly	**16159721000**	ND 258 LP 2005-2010	Drive	68-00

https://truckmanualshub.com/

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Hubs - Front And Rear					
Front Hub	Right or Left Hub includes Races and ABS tone ring - No Wheel Studs	**0515977002**	NA 2005-2010	Drive	66-00
Front Hub	Right or Left Hub includes wheel studs and races	**0515976002**	NB-NC 2005-2010	Drive	66-00
Front Hub	Right or Left Hub includes wheel studs, races	**05159641058**	ND,NE 8k Axle 2005-2010	Drive	66-00
Front Hub	Right or Left Hub includes wheel studs, races	**0515946001**	ND258LP 8k Axle 2005-2010	Drive	66-00
Front Hub	Right or Left Hub includes wheel studs and races	**0515910002**	ND,NE 10k Axle 2005-2010	Drive	66-00
Front Hub	Right or Left Hub includes wheel studs and races	**05159381002**	NJ 258 A/LP 8k Axle 2008-2010	Drive	66-00
Front Hub	Right or Left Hub includes races and ABS tone ring (For 10k axle option)	**0515632001**	NJ,NV 2005-2010	Drive	66-00
Front Hub	Right or Left Hub includes races and ABS tone ring (For 12k Axle Option)	**05156321003**	NJ,NV 2005-2010	Drive	66-00
Right Rear Hub	Right Rear Hub includes wheel studs, axle studs and races	**0415974002**	NA 2005-2010	Drive	68-00
Left Rear Hub	Left Rear Hub includes wheel studs, axle studs and races	**0415974001**	NA 2005-2010	Drive	68-00
Rear Hub	Right or Left Hub includes Races and Studs	**0415975001**	NB 2005-2010	Drive	68-00
Rear Hub	Right or Left Hub includes Races and Studs	**0415973100**	NC 2005-2010	Drive	68-00
Rear Hub	Right or Left Hub includes Races	**04157191005**	ND,NE 2005-2010	Drive	68-00
Rear Hub	Right or Left Hub includes Races	**0415972099**	ND-258 Low Profile 2005-2010	Drive	68-00
Rear Hub	Right or Left Hub includes Races	**0415673002**	NJ 258 A/LP 8k Axle 2008-2010	Drive	68-00
Rear Hub	Right or Left Hub includes Races NO Studs	**0415675003**	NJ,NV 2005-2010	Drive	68-00

https://truckmanualshub.com/

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Hub Seals - Front And Rear					
Hub Seal	Front Wheel Seal - Grease only	**A1205Q2695**	NA,NB,NC 2005-2010	Drive	66-00
Hub Seal	Front Wheel Seal 8k Axle - Oil or Grease	**A1205C2161**	ND,NE,/ LO PRO 2005-2010	Drive	66-00
Hub Seal	Front Wheel Seal 10k Axle - Oil or Grease	**A1205U2491**	ND,NE 2005-2010	Drive	66-00
Hub Seal	Front Wheel Seal 12K - Oil or Grease	**A1205B2264**	NJ,NV 2005-2010	Drive	66-00
Hub Seal	Rear Inner Hub Seal	**A1205V2674**	NA,NB 2005-2010	Drive	68-00
Hub Seal	Rear Inner Hub Seal	**A1205W1557**	NC 2005-2010	Drive	68-00
Hub Seal	Rear Inner Hub Seal	**A1205W1349**	ND,NE and Low Pro 2005-2010	Drive	68-00
Hub Seal	Rear Inner Hub Seal	**A1205V2492**	NJ,NV 2005-2010	Drive	68-00
2005 - 2010 - Hub - Gaskets And Front Covers					
Front Hub Cover	4 Hole Hub Cover - Grease Lube	**3262K89**	NA,NB,NC 2005-2010	Drive	66-00
Front Hub Gasket	4 Hole Hub Cover Gasket - Grease Lube	**2208V1036**	NA,NB,NC 8k Axle ND,NE 05-10	Drive	66-00
Front Hub Cover	4 Hole Hub Cover - Grease Lube	**3262K89**	ND,NE 8k Axle 2005-2010	Drive	66-00
Front Hub Gasket	4 Hole Hub Cover Gasket - Oil Lube	**2208C835**	ND,NE 8k Axle 2005-2010	Drive	66-00
Front Hub Cover	4 Hole Hub Cover - Oil Lube	**A3262C1381**	ND,NE 8k Axle 2005-2010	Drive	66-00
Front Hub Cover	6 Hole Hub Cover for Grease Lube	**3262A53**	ND,NE,NJ,NV 2005-2010	Drive	66-00
Front Hub Gasket	6 Hole Hub Cover Gasket Grease/Oil Lube	**2208Y363**	ND,NE,NJ,NV 2005-2010	Drive	66-00
Front Hub Cover	6 Hole Hub Cover for Oil Lube	**A3262G215**	ND,NE,NJ,NV 2005-2010	Drive	66-00

https://truckmanualshub.com/

https://truckmanualshub.com/

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Lettering And Badges					
Badge	Hino Letter Badge	**S7541E0010**	ALL MODELS 2005-2010	Not Shown	Not Shown
Badge	Model 145	**S7542E0010**	NA 2005-2010	Not Shown	Not Shown
Badge	Model 165	**S7542E0020**	NB 2005-2010	Not Shown	Not Shown
Badge	Model 185	**S7542E0030**	NC 2005-2010	Not Shown	Not Shown
Badge	Model 238	**S7542E0040**	ND 2005-2010	Not Shown	Not Shown
Badge	Model 258	**S7542E0050**	ND NJ /LP 2005-2010	Not Shown	Not Shown
Badge	Model 268	**S7542E0060**	NE,NJ 2005-2010	Not Shown	Not Shown
Badge	Model 338	**S7542E0080**	NV 2005-2010	Not Shown	Not Shown

https://truckmanualshub.com/

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Lighting					
Head Lamp	2005 Only Right Or Left - Sealed Beam	**H6054**	ALL 2005 ONLY	Cab	B1-40
Head Lamp Assembly	2006-2010 Right Side Assembly	**9Hi946025-02**	ALL 2006-2010	Cab	B1-40
Head Lamp Assembly	2006-2010 Left Side Assembly	**9Hi946025-01**	ALL 2006-2010	Cab	B1-40
Lamp Assembly Turn R/F	Right Side Front Turn Signal Assembly 2005 Only	**9Hi946020-02**	ALL 2005 ONLY	Electrical	28-16
Lamp Assembly Turn L/F	Left Side Front Turn Signal Assembly 2005 Only	**9Hi946020-01**	ALL 2005 ONLY	Electrical	28-16
Bulb	Bulb For Above 2005 Turn Signal Assemblies	**9HiS93843927**	ALL 2005 ONLY	Electrical	28-16
Bulb	Bulb For 2006-2010 Headlamp Signal Assemblies	**9HiK93989102**	ALL 2006-2010	Electrical	28-24
Lamp Assembly Side Turn	Turn Signal Lamp On Hood - Both Sides	**S817401080**	ALL 2005-2010	Electrical	28-19
Bulb	Bulb For Hood Turn Signal Assembly	**900834121A**	ALL 2005-2010	Electrical	28-19
Lamp Assembly	Dome Lamp - Base, Bulb and Cover	**S812401390**	ALL 2005-2010	Electrical	28-21
Bulb	Dome Lamp Bulb	**SZ98032018**	ALL 2005-2010	Electrical	28-21
Lens	Dome Lamp Lens	**812411140A**	ALL 2005-2010	Electrical	28-21
Lamp Assembly	Marker Lamp With Lamp and Pigtail	**01-4691-85**	ALL 2005-2010	Electrical	28-26
Lamp Lens	Marker Lamp Lens Without Light	**01-4691-86**	ALL 2005-2010	Electrical	28-26
Lamp Assembly	Tail, Turn, Brake Lamp Assembly	**01-5297-77**	ALL 2005-2010	Electrical	28-34
Lens	Lens Only For Above Lamp Assembly	**01-9130-86**	ALL 2005-2010	Electrical	28-34
Mirror Light Bulb	Bulb For Mirror Light	**H205391312V**	ALL 2005-2007	Not Shown	Not Shown
Lamp Assembly	Tail, Turn, Brake Lamp Assembly	**01-5297-77**	ALL 2005-2008	Electrical	28-34
Lens	Lens Only For Above Lamp Assembly	**01-9130-86**	ALL 2005-2008	Electrical	28-34

https://truckmanualshub.com/

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Locks/Keys/Ignition Switch					
Switch	Ignition Switch Only	**845601050A**	2005/2006 ALL	Cab	27-20
Switch	Ignition Switch Only	**845102490A**	2007 ALL	Cab	27-20
Switch	Ignition Switch Only	**S845102313**	2008-2010	Cab	27-20
Key Blank	Plastic Coated End	**S845122230**	ALL 2005-2010	Cab	B5-50
Key Blank w/o Cover	No Plastic Coating	**S845122240**	ALL 2005-2010	Cab	B5-50
Complete Lock Set	Ignition and both doors	**S696103643**	ALL 2005-2010	Cab	B5-50
Complete Lock Set Keyed Alike	Ignition and both doors If The Dealer Wants Ten Trucks Keyed Alike They Must Order This Part Number Ten Times	**69005E0010**	ALL 2005-2010	NOT-SHOWN	NOT-SHOWN
L/H Door Lock	L/S Door Lock Cylinder, Key and Clip	**696103670A**	ALL 2005-2010	Cab	B5-50
R/H Door Lock	R/S Door Lock Cylinder, Key and Clip	**S696103660**	ALL 2005-2010	Cab	B5-50

https://truckmanualshub.com/

M

https://truckmanualshub.com/

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Mirrors					
Mirror	Plain Mirror No Lights Or Heat Fits Both Sides	**879023000A**	ALL 2005-2007	Cab and Rear Body	B6-81
Mirror Left	Left Hand Heated And Lighted	**87906E0020**	ALL 2005-2007	Cab and Rear Body	B6-81
Mirror Right	Right Hand Heated And Lighted	**87903E0020**	ALL 2005-2007	Cab and Rear Body	B6-81
Spot Mirror/Convex	Convex Mirror Fits Both Sides	**S8790E0010**	ALL 2005-2007	Cab and Rear Body	B6-81
Mirror Kit	Heated Mirror Kit Includes Both Sides Black Only	**87902KIT05**	ALL 2005-2007	Not Shown	Not Shown
Mirror	Plain Mirror No Lights Or Heat Right Hand Black	**87903E0090**	ALL 2008-2010	Cab and Rear Body	B6-81
Mirror	Plain Mirror No Lights Or Heat Right Hand Chrome	**87903E0102**	ALL 2008-2010	Cab and Rear Body	B6-81
Mirror	Plain Mirror No Lights Or Heat Left Hand Black	**87906E0050**	ALL 2008-2010	Cab and Rear Body	B6-81
Mirror	Plain Mirror No Lights Or Heat Left Hand Chrome	**87906E0062**	ALL 2008-2010	Cab and Rear Body	B6-81
Mirror Left	Left Hand Heated And Lighted Black Only	**87906E0030**	ALL 2008-2010	Cab and Rear Body	B6-81
Mirror Left	Left Hand Heated And Lighted Chrome Only	**87906E0042**	ALL 2008-2010	Cab and Rear Body	B6-81
Mirror Right	Right Hand Heated And Lighted Black Only	**87903E0030**	ALL 2008-2010	Cab and Rear Body	B6-81
Mirror Right	Right Hand Heated And Lighted Chrome Only	**87903E0042**	ALL 2008-2010	Cab and Rear Body	B6-81
Spot Mirror/Convex	Convex Mirror Fits Both Sides Chrome	**S8790E0032**	ALL 2008-2010	Cab and Rear Body	B6-81
Spot Mirror/Convex	Convex Mirror Fits Both Sides Black	**S8790E0020**	ALL 2008-2010	Cab and Rear Body	B6-81
Left Mirror Bracket	Left Hand Heated Mirror Stay Black	**87094E0030**	ALL 2008-2010	Cab and Rear Body	B6-81

https://truckmanualshub.com/

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Mirrors (Cont.)					
Left Mirror Bracket	Left Hand Heated Mirror Stay CHROME	**87094E0042**	ALL 2008-2010	Cab and Rear Body	B6-81
Right Mirror Bracket	Right Hand Heated Mirror Stay BLACK	**87093E0100**	ALL 2008-2010	Cab and Rear Body	B6-81
Right Mirror Bracket	Right Hand Heated Mirror Stay CHROME	**87093E0112**	ALL 2008-2010	Cab and Rear Body	B6-81
Lamp Assembly	Mirror Amber Light Assembly Complete	**CC205391412V**	FOR HEATED MIRROR OPT. 2005-2007	Cab and Rear Body	B6-81
Lamp Lens	Amber Lens for Mirror Light	**CC205391112V**	ALL 2005-2007	Cab and Rear Body	B6-81
Mirror Light Bulb	Bulb for Mirror Light	**H205391312V**	ALL 2005-2007	Not Shown	Not Shown
Lamp Assembly	Mirror Amber Light Assembly Complete	**114272001-PDC**	FOR HEATED MIRROR OPT. 2008-2010	Cab and Rear Body	Not Shown

https://truckmanualshub.com/

P

https://truckmanualshub.com/

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Paint Codes					
White	2005-2010 Toyota White	**058**	ALL	Not Shown	Not Shown
White	2005-2008 Dupont Imron 5000 White (Single Stage)	**F3405HN**	ALL	Not Shown	Not Shown
White	2005-2010 Dupont Imron 6000 White (2 Stage)	**F3405HL**	ALL	Not Shown	Not Shown
Penske Yellow	2005-2007 Dupont Imron 5000 Yellow (Single Stage)	**N2832**	ALL	Not Shown	Not Shown
Penske Yellow	2005-2007 Dupont Imron 6000 Yellow (2 Stage)	**L2832**	ALL	Not Shown	Not Shown
Penske Yellow	2008-2010 Hino- Dupont Imron Elite Basecoat Yellow (2 Stage)	**750206EB**	ALL 2008-2010	Not Shown	Not Shown
Red	2008-2010 Hino- Dupont Imron Elite Basecoat Red (2 Stage)	**786869EB**	ALL 2008-2010	Not Shown	Not Shown
Black	2008-2010 Hino- Dupont Imron Elite Basecoat Black (2 Stage)	**L0001EB**	ALL 2008-2010	Not Shown	Not Shown
Clear Coat	Dupont Clearcoat For Imron Elite Basecoats (2 Stage Paints)	**8840S**	ALL	Not Shown	Not Shown

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Parking Brake					
Cable P/B	Manual Transmission Park Brake Cable	**464029110A**	NA,NB,NC 2005-2010	Chassis	38-20
Cable P/B	Auto Transmission Park Brake Cable	**S464029121**	NA,NB,NC 2005-2010	Chassis	38-20
Cable P/B	Manual Transmission Park Brake Cable	**S464029131**	ND,NE 2005-2010	Chassis	38-20
Cable P/B	Auto Transmission Park Brake Cable	**S464029140**	ND,NE 2005-2010	Chassis	38-20
Grip P/B Lever	Plastic Park Brake Handle Cover No Screw	**462151231A**	NA,NB,NC, ND,NE 2005-2010	Chassis	38-20
Bolt	Special Bolt For Park Brake Handle Cover	**910904226A**	NA,NB,NC, ND,NE 2005-2010	Chassis	38-20
Drum P/B	Park Brake Drum Manual Transmission	**465111660A**	NA,NB,NC 2005-2010	Chassis	38-00
Drum P/B	Park Brake Drum Auto Transmission	**465111650A**	NA,NB,NC 2005-2010	Chassis	38-00
Drum P/B	Park Brake Drum Auto Transmission	**465111630A**	NB,NC 2008-2010	Chassis	38-00
Drum P/B	Park Brake Drum Manual Transmission	**465111640A**	ND,NE 2005-2010	Chassis	38-00
Drum P/B	Park Brake Drum Auto Transmission	**465111630A**	ND,NE 2005-2010	Chassis	38-00
Shoe-Brake Lining Assembly	Park Brake Shoe With Lining Installed	**A23722G501**	NA,NB,NC Automatic 2005-2010	Chassis	38-00
Shoe-Brake Lining Assembly	Park Brake Shoe With Lining Installed	**X4152206**	NA,NB,NC Manual 2005-2010	Chassis	38-00
Shoe-Brake Lining Assembly	Park Brake Shoe With Lining Installed	**X4152206**	NB,NC Automatic 2008-2010	Chassis	38-00
Shoe-Brake Lining Assembly	Park Brake Shoe With Lining Installed	**X4152206**	ND,NE Automatic 2005-2010	Chassis	38-00
Shoe-Brake Lining Assembly	Park Brake Shoe With Lining Installed	**A33722D420**	ND,NE Manual 2005-2010	Chassis	38-00
Park Brake Assembly	Complete Assembly for Manual Trans	**465104150A**	NA,NB,NC 2005-2010	Chassis	38-01
Park Brake Assembly	Complete Assembly for Auto Trans	**465104170A**	NA,NB,NC 2005-2010	Chassis	38-01
Park Brake Assembly	Complete Assembly for Auto Trans	**465104150A**	NB,NC 2008-2010	Chassis	38-01
Park Brake Assembly	Complete Assembly for Manual Trans	**465104160A**	ND,NE 2005-2010	Chassis	38-00
Park Brake Assembly	Complete Assembly for Auto Trans	**465104150A**	ND,NE 2005-2010	Chassis	38-01

https://truckmanualshub.com/

S

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Sealants					
Sealant	Silver Grade	**041321207D**	ALL 2005-2010	Not Shown	SHOP MANUAL
Sealant	Black Grade	**S041321217**	ALL 2005-2010	Not Shown	SHOP MANUAL
Sealant	White Grade	**041321211A**	ALL 2005-2010	Not Shown	SHOP MANUAL
Sealant	Red Grade	**041321207A**	ALL 2005-2010	Not Shown	SHOP MANUAL
2005 - 2010 - Steering					
Wheel Assembly	Steering Wheel w/o Horn Button	**S451101610**	ALL 2005-2010	Chassis	64-55
Button Assembly Horn	Horn Button - Cover	**S451301560**	ALL 2005-2010	Chassis	64-55
Reservoir Assembly P/S	Complete Power Steering Reservoir	**443602360A**	ALL 2005-2010	Chassis	64-53
Cap Sub Assembly	Reservoir Cap/Dipstick	**S443051070**	ALL 2005-2010	Chassis	64-53
Cover Sub Assembly	Plastic Cover for Top of Reservoir	**443091040A**	ALL 2005-2010	Chassis	64-53
Gasket - Oil Filter	Gasket for Plastic Reservoir Cover	**443681060A**	ALL 2005-2010	Chassis	64-53
Strainer Oil Reservoir	Plastic Strainer Under Dipstick/ Cap	**S472281050**	ALL 2005-2010	Chassis	64-53
Filter - Oil	Oil Filter Inside of Reservoir	**S443611070**	ALL 2005-2010	Chassis	64-53
Power Steering Box Assy	Complete Power Steering Box	**441102521A**	NA,NB,NC 2005-2010	Drive	64-00
Power Steering Box Assy	Complete Power Steering Box	**441102530A**	ND,NE 2005-2010	Drive	64-00
Power Steering Box Assy	Complete Power Steering Box	**441102540A**	NJ,NV 2005-2010	Drive	64-00
P/S Oil Pump Assy	Complete Power Steering Pump	**443501481A**	NA,NB,NC 2005-2010	Engine	19-14
P/S Oil Pump Assy	Complete Power Steering Pump	**44310E0200**	ND,NE,NJ,NV 2005-2010	Engine	19-14
Tie Rod End (LH)	End Only	**R230137**	NA,NB,NC 2005-2010	Drive	66-00
Tie Rod End (RH)	End Only	**R230138**	NA,NB,NC 2005-2010	Drive	66-00
Tie Rod End (LH)	End Only	**R230068**	ND,NE,NJ,NV 2005-2010	Drive	66-00
Tie Rod End (RH)	End Only	**R230069**	ND,NE,NJ,NV 2005-2010	Drive	66-00

https://truckmanualshub.com/

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Steering (Cont.)					
Rod Assy-End/Tie	1 5/8" Tube and Clamps Only	**A23102P4540**	NA,NB,NC 2005-2010	Drive	66-00
Rod Assy-End/Tie	1 9/16" Tube and Clamps Only	**A3102K4379**	ND,NE 2005-2010	Drive	66-00
Rod Assy-End/Tie	1 3/4" Tube and Clamps Only	**A3102L4380**	NE (10K Axle) NJ,NV 2005-2010	Drive	66-00
Link Assembly Steering Drag	Drag Link	**454802150A**	NA,NB,NC 2005-2010	Drive	64-00
Link Assembly Steering Drag	Drag Link	**454802160A**	ND,NE,NJ,NV 2005-2010	Drive	64-00
Pin Kit	Complete King Pin Kit	**R201478**	NA,NB,NC 2005-2010	Drive	66-00
Pin Kit	Complete King Pin Kit -Pins are 1.5" X 7.5" Note: also used on NJ-258 A/LP W/ 8k Axle 2008-2010 Model	**R201474**	ND,NE W/ 8k Axle 2005-2010	Drive	66-00
Pin Kit	Complete King Pin Kit -Pins are 2" X 10.375"	**R201470**	ND,NE,NJ,NV 2005-2010	Drive	66-00
2005 - 2010 - Suspension - Shock Absorbers Front And Rear					
Shock Absorber	Front	**485003710A**	NA,NB,NC 2005-2010	Chassis	55-54
Cushion	Front Shock Rubber Bushing	**900481161A**	NA,NB,NC 2005-2010	Chassis	55-54
Shock Absorber	Front	**S485003720**	ND,NE,NJ,NV 2005-2010	Chassis	55-54
Cushion	Front Shock Rubber Bushing	**900481162A**	ND,NE,NJ,NV 2005-2010	Chassis	55-54
Shock Absorber	Rear	**S485303280**	NA,NB,NC 2005-2010	Chassis	58-55
Cushion	Rear Shock Rubber Bushing	**900481161A**	NA,NB,NC 2005-2010	Chassis	55-55
Shock Absorber	Rear	**S485303290**	ND,NE,NJ,NV 2005-2010	Chassis	58-55
Cushion	Rear Shock Rubber Bushing	**900481106A**	ND,NE,NJ,NV 2005-2010	Chassis	55-55

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Suspension (Front) - Spring Assembly					
Spring Assembly	Front - 2 Leaves	**S481502780**	NA,NB,NC 2005-2010	Chassis	55-54
Spring Assembly	Front - 2 Leaves Standard 8k Axle	**S481502790**	ND,NE,NJ 2005-2010	Chassis	55-54
Spring Assembly	Front - 3 Leaves Optional 10k Axle	**S481502800**	ND,NJ,NV 2005-2010	Chassis	55-54
2005 - 2010 - Suspension (Front) - Spring Bushings, U-Bolts, Hardware					
Bumper Front Spring	Rubber Bumper on Top of Spring pack	**S431141230**	ALL 2005-2010	Chassis	55-00
Stabilizer	FRONT STABILIZER KIT	**D67**	NA,NB,NC 2005-2010	Chassis	NOT SHOWN
Spring Bushing	Front Spring Rubber Bushing	**493051730A**	ALL 2005-2010	Chassis	55-00
Bolt/Flange	Front Spring Bushing Flanged Bolt	**SZ10520015**	ALL 2005-2010	Chassis	55-00
Nut/Flange	Nut for Spring Bushing Bolt	**924920106A**	NA,NB,NC 2005-2010	Chassis	55-00
U-Bolt	Varies With Application	**See EPC**	ALL 2005-2010	Chassis	55-00
Nut Flange	U-Bolt Nut	**SZ17016025**	ND,NE,NJ,NV 2005-2010	Chassis	55-00
Nut Flange	U-Bolt Nut	**SZ17818002**	ND,NE,NJ,NV 2005-2010	Chassis	55-00
Washer Plain	Washer for U-Bolt	**926016330A**	NA,NB,NC 2005-2010	Chassis	55-00
Washer Plain	Washer for U-Bolt	**926918127A**	ND,NE,NJ,NV 2005-2010	Chassis	55-00
2005 - 2010 - Suspension (Rear) - Spring Assembly					
Spring Assembly	Rear - 16 Leaves	**482207990A**	NA 2005-2010	Chassis	58-54
Spring Assembly	Rear - 14 Leaves	**482208000A**	NB 2005-2010	Chassis	58-54
Spring Assembly	Rear - 14 Leaves	**482208010A**	NC 2005-2010	Chassis	58-54
Spring Assembly	Rear - 15 Leaves	**S482208020**	ND,NE,NJ 2005-2010	Chassis	58-54
Spring Assembly	Rear - 15 Leaves - Standard	**482208610A**	NV 2005-2010	Chassis	58-54
Spring Assembly	Rear - 15 Leaves - Optional	**482208550A**	NJ,NV 2005-2010	Chassis	58-54

https://truckmanualshub.com/

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Suspension (Rear) - Spring Bushings, U-Bolts, Hardware					
Air Ride Suspension Kit	Hendrickson Air Ride Suspension Kit (Both part numbers required)	**482501320A 3150D2578**	NJ,NV ONLY 2005-2010	Not Shown	Not Shown
Rear Stabilizer	Rear Stabilizer Kit	**D68PL**	ND,NE,NJ 2005-2010	Not Shown	Not Shown
Rear Stabilizer	Rear Stabilizer Kit	**D68PL338**	NV 2005-2010	Not Shown	Not Shown
Rear Shocks	Rear Shock Kit	**D68LDT**	NA,NB,NC 2005-2010	Not Shown	Not Shown
Rear Shocks	Rear Shock Kit	**D68MDTC6**	ND,NE,NJ 2005-2010	Not Shown	Not Shown
Rear Shocks	Rear Shock Kit	**D68MDTC7**	NV ONLY 2005-2010	Not Shown	Not Shown
Spring Bushing	At Front of Rear Spring	**51463**	ALL 2005-2010	Chassis	58-00
Spring Pin	Pin for Above Bushing	**484232720A**	ALL 2005-2010	Chassis	58-00
Bolt	Bolt for Above Pin	**SH56231275**	ALL 2005-2010	Chassis	58-00
Nut	Nut for Above Pin	**SL15101213**	ALL 2005-2010	Chassis	58-00
Fitting	Grease Zerk for Above Pin	**SN45101010**	ALL 2005-2010	Chassis	58-00
Pin	At Front and Rear of Spring	**SZ24016003**	ALL 2005-2010	Chassis	58-00
Washer	Washer for Above Pin	**926922121A**	ALL 2005-2010	Chassis	58-00
U-Bolt	Rear Spring - Front U-Bolt Without Shock Option - Length is 17.75"	**SZ94084260**	NA,NB,NC 2005-2010	Chassis	58-00
U-Bolt	Rear Spring - Front U-Bolt With Shock Option - Length is 19.75"	**900484735A**	NA,NB,NC 2005-2010	Chassis	58-00
U-Bolt	Rear Spring - Rear U-Bolt With or Without Shock Option Length is 18"	**SZ94084279**	NA,NB,NC 2005-2010	Chassis	58-00
Nut- Flange	U-Bolt Nut	**SZ17818002**	NA,NB,NC 2005-2010	Chassis	58-00
Washer Plain	Washer for U-Bolt	**926918127A**	NA,NB,NC 2005-2010	Chassis	58-00
U-Bolt	Depends on Options and Axle Ratio	**See EPC**	ND,NE,NJ,NV 2005-2010	Chassis	58-00

https://truckmanualshub.com/

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Transmission - Manual					
Pipe Plug	Transmission Fill Plug	**X12-1209**	ALL 2005-2010	Drive	32-10
Pipe Plug	Transmission Drain Plug	**X12-1207**	ALL 2005-2010	Drive	32-10
Oil seal - Manual Trans	Front Input Shaft Oil Seal	**4300204**	NA,NB,NC 2005-2010	Drive	32-10
Gasket - Manual Trans	Front Input Shaft Cover Gasket	**240321**	NA,NB,NC 2005-2010	Drive	32-10
Oil seal - Manual Trans	Rear Output Shaft Seal	**4300203**	NA,NB,NC 2005-2010	Drive	32-10
Nut - Manual trans	Output Shaft/Flange Nut	**21937**	NA,NB,NC 2005-2010	Drive	32-10
Gasket - Manual Trans	Top Cover Gasket	**240038**	NA,NB,NC 2005-2010	Drive	32-10
Gasket - Manual Trans	Shifter To Top Cover Gasket	**4301958**	NA,NB,NC 2005-2010	Drive	32-10
Gasket - Manual Trans	PTO Cover Gasket	**RTV Silicone Red Grade**	ALL 2005-2010	Drive	32-10
Oil seal - Manual Trans	Input Shaft Oil Seal	**4300121**	ND,NE 2005-2010	Drive	32-10
Gasket - Manual Trans	Input Shaft Cover Gasket	**240321**	ND,NE 2005-2010	Drive	32-10
Oil seal - Manual Trans	Output Shaft Seal	**4300119**	ND,NE 2005-2010	Drive	32-10
Oil seal - Manual Trans	Input Shaft Oil Seal	**4300121**	NJ,NV 2005-2010	Drive	32-10
Gasket - Manual Trans	Input Shaft Cover Gasket	**3315659**	NJ,NV 2005-2010	Drive	32-10
Oil seal - Manual Trans	Output Shaft Seal	**4300119**	NJ,NV 2005-2010	Drive	32-10
Nut - Manual trans	Output Shaft/Flange Nut	**K-3411**	ND,NE,NJ,NV 2005-2010	Drive	32-10
Gasket - Manual Trans	Top Cover Gasket	**4300854**	ND,NE,NJ,NV 2005-2010	Drive	32-10
Gasket - Manual Trans	Shifter To Top Cover Gasket	**4301958**	ND,NE,NJ,NV 2005-2010	Drive	32-10
Manual Transmission	Eaton Transmission Model FS4205A	**TA-696-66**	NA,NB,NC 2005-2010	Drive	32-10
Manual Transmission	Eaton Transmission Model FS5406A	**TA-C15-41**	ND,NE 2005-2010	Drive	32-10
Manual Transmission	Eaton Transmission Model FS5406A	**TA-C15-42**	NJ Only 2005-2010	Drive	32-10
Manual Transmission	Eaton Transmission Model FS6406A	**TA-C11-43**	NV 2005-2010	Drive	32-10
Speed Sensor Kit	Manual Transmission Speed Sensor	**K-3454**	ALL 2005-2010	Drive	32-10

https://truckmanualshub.com/

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Transmission - Automatic - Aisin					
Gauge Oil Level	Dipstick Only	**351031240A**	NA,NB,NC 2005-2007	Drive	33-00
Gauge Oil Level	Dipstick Only	**351031240A**	NA 2008-2010	Drive	33-00
Tube Sub Assembly	Dipstick Tube, Gauge, O-rings	**S350131230**	NA,NB,NC 2005-2007	Drive	33-00
Tube Sub Assembly	Dipstick Tube, Gauge, O-rings AISIN ONLY	**S350131230**	NA 2008-2010	Drive	33-00
Gauge Oil Level	Dipstick Tube, Gauge, O-rings for 1000 HS ALLISON ONLY	**35130E0010**	NB,NC 2008-2010	Drive	33-00
Seal	Torque Converter Oil Seal	**9031142010**	NA,NB,NC 2005-2007	Drive	33-00
Seal	Output Shaft Oil Seal	**S900750139**	NA,NB,NC 2005-2007	Drive	33-00
Nut	Output Shaft/Flange Nut	**S900705167**	NA,NB,NC 2005-2007	Drive	33-00
O-Ring	O-Ring For Output Shaft/Flange Nut	**S900756228**	NA,NB,NC 2005-2007	Drive	33-00
Gasket	PTO Cover Gasket	**900753123A**	NA,NB,NC 2005-2007	Drive	33-00
Oil Strainer	Screen in Trans Oil Pan USE THREE BOND #TB1218 FOR PAN GASKET	**S353031040**	NA,NB,NC 2005-2007	Drive	33-00
Pin	Alignment Dowel Pin to Flywheel Housing	**SM21200824**	NA,NB,NC 2005-2010	Drive	11-10
2005 - 2010 - Transmission - Automatic Shift Cables					
Cable T/M Control	Aisin Shift Cable	**337027151A**	NA,NB,NC 2005-2007 NA 2008-2010	Drive	32-50
Cable T/M Control	Allison Shift Cable	**337027160A**	ND,NE,NJ 2005-2010	Drive	32-50
Cable T/M Control	Allison Shift Cable	**33820E0540**	NB,NC 2008-2010	Drive	32-50

https://truckmanualshub.com/

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Transmission - Automatic					
Speed Sensor Kit	Aisin Speed Sensor (Top of Trans)	**894101640A**	NA,NB,NC 2005-2007	Drive	33-00
Speed Sensor Kit	Aisin Speed Sensor (For Speedometer)	**S831901550**	NA,NB,NC 2005-2007	Drive	33-00
Driven Gear	Pencil Gear At Output Shaft Housing	**349151040A**	NA 2005-2010	Drive	33-00
Driven Gear	Pencil Gear At Output Shaft Housing	**349151030A**	NB,NC 2005-2007 Only	Drive	33-00
Switch Assembly	Aisin Automatic Transmission Gear Position Switch	**S842201650**	NA,NB,NC 2005-2007	Drive	33-00
Auto Transmission	Aisin Automatic Assembly	**351003040A**	NA 2005-2007	Drive	33-00
Auto Transmission	Aisin Automatic Assembly	**35010E0081**	NA 2008-2010	Drive	33-00
Auto Transmission	Aisin Automatic Assembly	**351003030A**	NB,NC 2005-2007 Only	Drive	33-00
Auto Transmission	All Allison Transmissions Are Warrantied Thru Allison	**Contact Allison**	NB,NC,ND, NE,NJ,NV 2005-2010	Drive	33-00
Retainer	Quick Clip for Transmission Lines at Radiator	**21598E0010**	ALL 2005-2010	Chassis	22-00

https://truckmanualshub.com/

W

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Wheel Bearings And Races					
Cone - Bearing, Inner	Front - Inner Wheel Bearing	**NP449281**	NA,NB,NC 2005-2010	Drive	66-00
Cup - Bearing, Inner	Front - Inner Wheel Bearing Race	**25520**	NA,NB,NC 2005-2010	Drive	66-00
Cone - Bearing - Outer	Front - Outer Wheel Bearing	**LM48548A**	NA,NB,NC 2005-2010	Drive	66-00
Cup - Bearing - Outer	Front - Outer Wheel Bearing Race	**LM48510**	NA,NB,NC 2005-2010	Drive	66-00
Cone - Bearing, Inner	Front - Inner Wheel Bearing Note: also used on NJ-258 A/LP W/ 8k Axle 2008-2010 Model	**JM207049A**	ND,NE 8k Axle 2005-2010	Drive	66-00
Cup - Bearing, Inner	Front - Inner Wheel Bearing Race Note: also used on NJ-258 A/LP W/ 8k Axle 2008-2010 Model	**JM207010**	ND,NE 8k Axle 2005-2010	Drive	66-00
Cone - Bearing - Outer	Front - Outer Wheel Bearing Note: also used on NJ-258 A/LP W/ 8k Axle 2008-2010 Model	**25877**	ND,NE 8k Axle 2005-2010.	Drive	66-00
Cup - Bearing - Outer	Front - Outer Wheel Bearing Race Note: also used on NJ-258 A/LP W/ 8k Axle 2008-2010 Model	**25820**	ND,NE 8k Axle 2005-2010	Drive	66-00
Cone - Bearing, Inner	Front - Inner Wheel Bearing	**HM212049**	NE, 10k Axle NJ,NV 2005-2010	Drive	66-00
Cup - Bearing, Inner	Front - Inner Wheel Bearing Race	**HM212011**	NE,10k Axle NJ,NV 2005-2010	Drive	66-00
Cone - Bearing - Outer	Front - Outer Wheel Bearing	**3782**	NE, 10k Axle NJ,NV 2005-2010	Drive	66-00
Cup - Bearing - Outer	Front - Outer Wheel Bearing Race	**3720**	ND,NE, 10k Axle NJ,NV 2005-2010	Drive	66-00
Cone - Bearing, Inner	Rear - Inner Wheel Bearing	**39590**	NA,NB 2005-2010	Drive	68-00
Cup - Bearing - Inner	Rear - Inner Wheel Bearing Race	**39520**	NA,NB 2005-2010	Drive	68-00
Cone- Bearing, Outer	Rear - Outer Wheel Bearing	**JLM506849**	NA,NB 2005-2010	Drive	68-00
Cup - Bearing - Outer	Rear - Outer Wheel Bearing Race	**JLM506810**	NA,NB 2005-2010	Drive	68-00
Cone- Bearing, Inner	Rear Axle Hub Inner Bearing	**33287**	NC 2005-2010	Drive	68-00

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Wheel Bearings And Races (Cont.)					
Cup Inner Bearing	Rear Axle Hub Inner Bearing Race	**33462**	NC 2005-2010	Drive	68-00
Cone-Bearing, Outer	Rear Axle Hub Outer Bearing	**3982**	NC 2005-2010	Drive	68-00
Cup-Outer Bearing	Rear Axle Hub Outer Bearing Race	**3920**	NC 2005-2010	Drive	68-00
Cone-Bearing, Inner	Rear Axle Hub Inner Bearing	**47686**	ND,NE and Low Pro 2005-2010	Drive	68-00
Cup-Bearing, Inner	Rear Axle Hub Inner Bearing Race	**47620**	ND,NE and Low Pro 2005-2010	Drive	68-00
Cone-Bearing, Outer	Rear Axle Hub Outer Bearing	**39590**	ND,NE and Low Pro 2005-2010	Drive	68-00
Cup-Bearing, Outer	Rear Axle Hub Outer Bearing Race	**39520**	ND,NE and Low Pro 2005-2010	Drive	68-00
Cone-Bearing, Inner	Rear Axle Hub Inner Bearing Note: also used on NJ-258 A/LP W/ 8k Axle 2008-2010 Model	**594A**	NJ,NV 2005-2010	Drive	68-00
Cup-Bearing, Inner	Rear Axle Hub Inner Bearing Race Note: also used on NJ-258 A/LP W/ 8k Axle 2008-2010 Model	**592A**	NJ,NV 2005-2010	Drive	68-00
Cone-Bearing, Outer	Rear Axle Hub Outer Bearing Note: also used on NJ-258 A/LP W/ 8k Axle 2008-2010 Model	**580**	NJ,NV 2005-2010	Drive	68-00
Cup-Bearing, Outer	Rear Axle Hub Outer Bearing Race Note: also used on NJ-258 A/LP W/ 8k Axle 2008-2010 Model	**572**	NJ,NV 2005-2010	Drive	68-00

https://truckmanualshub.com/

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Wheels/Rims					
Wheel	16 X 6.0 (6 Lug) Front And Rear	**S426114960**	NA 2005-2010	Drive	59-00
Wheel	19.5 X 6.0 (8 Lug) Front And Rear	**29584PW**	NB,NC 2005-2010	Drive	59-00
Wheel	19.5 X 6.75 (8 Lug) Front And Rear	**28680PW**	ND Low Profile (258) 2005-2010	Drive	59-00
Wheel	22.5 X 8.25.0 (10 Lug) Front And Rear	**28408PW**	ND,NE,NJ,NV 2005-2010	Drive	59-00
Wheel	19.5 X 8.5 (10 Lug) Front And Rear Steel	**42611E0050**	NJ 258 A/LP 2008-2010	Drive	59-00
Wheel	Front And Rear Polished Aluminum Wheels Are Available Call Customer Service For Part Numbers	**Phone# 866-372-4466**	All Models Except NA 2005-2010	Not Shown	59-00
2005 - 2010 - Wheel/Rim Lug Nuts					
Nut Hub	Lug Nut - R/H Front	**900421114A**	NA 2005-2010	Chassis	59-00
Nut Hub	Lug Nut - L/H Front	**900422106A**	NA 2005-2010	Chassis	59-00
Nut Hub	Lug Nut - R/H Rear Inner	**SZ94023007**	NA 2005-2010	Chassis	59-00
Nut Hub	Lug Nut - L/H Rear Inner	**SZ94024007**	NA 2005-2010	Chassis	59-00
Nut Hub	Lug Nut - R/H Rear Outer	**SZ94021012**	NA 2005-2010	Chassis	59-00
Nut Hub	Lug Nut - L/H Rear Outer	**SZ94022014**	NA 2005-2010	Chassis	59-00
Nut Hub	Lug Nut - R/H and L/H - Front and Rear	**900431109A**	NB,NC 2005-2010	Chassis	59-00
Nut Hub	Lug Nut - R/H and L/H - Front and Rear	**900431110A**	ND,NE,NJ,NV 2005-2010	Chassis	59-00

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Wheel Studs - Front/Rear					
Wheel Studs	Front and Rear (RH)	**09002225**	NA 2005-2010	Drive	66-00
Wheel Studs	Front and Rear (LH)	**09002226**	NA 2005-2010	Drive	66-00
Wheel Studs	Front - Both Sides	**09002232**	NB,NC 2005-2010	Drive	66-00
Wheel Studs	Rear - Both Sides	**09002223**	NB,NC 2005-2010	Drive	66-00
Wheel Studs	Front - Both Sides	**09002013**	ND,NE 2005-2010	Drive	66-00
Wheel Studs	Rear - Both Sides	**09001989**	ND,NE 2005-2010	Drive	66-00
Wheel Studs	Front - Both Sides	**09001989**	NJ,NV 2005-2010	Drive	66-00
Wheel Studs	Rear - Both Sides	**09001728**	NJ,NV 2005-2010	Drive	66-00
2005 - 2010 - Windshield					
Glass W/S	Windshield	**794111880A**	ALL 2005-2010	Cab	B7-00
Weatherstrip W/S	Rubber Gasket for Windshield	**56121E0010**	ALL 2005-2010	Cab	B7-00
2005 - 2010 - Wiper Blades, Arms, Motor					
Blade	Right Side	**S852211120**	ALL 2005-2010	Electrical	28-44
Blade	Left Side	**S852211110**	ALL 2005-2010	Electrical	28-44
Blade Assy	Right Side	**S852201560**	ALL 2005-2010	Electrical	28-44
Blade Assy	Left Side	**S852201540**	ALL 2005-2010	Electrical	28-44
Arm Assy	Right Side	**85221E0060**	ALL 2005-2010	Electrical	28-44
Arm Assy	Left Side	**85221E0050**	ALL 2005-2010	Electrical	28-44
Motor Assy W/ Bracket	Wiper Motor and Bracket	**S851201550**	ALL 2005-2010	Electrical	28-44
Jar and Pump Assembly	Windshield Washer Reservoir, Pump, Cap	**S850801680**	ALL 2005-2010	Electrical	28-43
Cap Washer Jar	Windshield Washer Reservoir Cap	**S853321050**	ALL 2005-2010	Electrical	28-43
Motor and Pump Assembly	Windshield Washer Pump and Motor	**S853101120**	ALL 2005-2010	Electrical	28-43

https://truckmanualshub.com/

Technical Bulletins